

If something seems to be not working properly:





If the red satellite indicator lights chase along the row, the selected satellite cannot be found. Check for obstructions such as trees & buildings.



If the POWER, LNB & LOCK lights come on together (POWER & LOCK will blink) check the cable between controller & sat-dome.

Symptom	What you should do
The control box does not power up.	1) Check the power supply. 2) Switch the control unit off and on again.
The system seems to operate correctly but no satellite is found.	1) Make sure that the dish has a clear view of the satellite – avoid trees, buildings, pylons, etc. 2) Check cables and connections. 3) Switch the control unit off and on again.
A satellite is found but there's no picture on your TV.	1) Check that you have selected the correct satellite and that your receiver is set for the same one. 2) Check that cables and connectors between the sat-dome controller, the receiver and the TV are all secure.
You can see a picture on the TV but it is breaking up. If you are near the edge of the satellite's transmission area (footprint) this can happen.	1) Check that there are no obstructions between the dish and the satellite. 2) Check all cables and connectors.
The TV has sound but no picture.	1) Check that you have not selected radio on your receiver instead of TV. 2) Check that the power to your TV is sufficient for it to operate correctly.
You've tried the suggestions but the system is still not working.	1) Contact your installer or dealer. 2) If they are unable to fix the problem, contact RoadPro.



Auto-skew will significantly improve the chances of receiving a good signal in areas away from the centre of the footprint areas shown.

Distributed in the U.K. by

RoadPro Ltd, Unit 7, Stephenson Close, Daventry, Northants, NN11 8RF
Tel: 01327 312233 E-mail: sales@roadpro.co.uk www.roadpro.co.uk



Installation and instruction manual
for static RoadPro sat-domes

- D3201 / 2: 30 / 40cm static sat-dome
- D3205 / 6: 30 / 40cm static sat-dome with twin LNB
- D3209 / 10: 30 / 40cm static sat-dome with auto skew
- D3211 / 12: 30 / 40cm static sat-dome with twin LNB + auto skew

Thank you for buying a RoadPro sat-dome. To enable us to provide the best after-sales service, please make a note of the unit's serial number which you will find above the external cable connecting socket.

My RoadPro sat-dome's serial number is:.....

DELIVERY

RoadPro sat-domes come with the following parts in the box:

- Sat-dome
- Control box incl. power supply
- 1 HQ co-ax cable (10m) with F-plugs (2 cables are supplied with twin-LNB models)
- 1 HQ co-ax cable (1m)
- 1 Cable-entry box
- 12 screws (3 in dome cover, 9 in bag)
- Installation and usage instructions

INSTALLATION

We strongly recommend getting the sat-dome fitted to your vehicle or boat by a professional installer!

Preparation:

1. Ensure that the roof of your vehicle is able to carry the sat-dome. If you are not sure, check with your dealer or the vehicle's manufacturer.
2. Check that you have all the parts that are listed above.
3. Find a suitable place on the roof of your vehicle to mount the sat-dome. The sat-dome's external cable connector must face towards the rear of the vehicle. The mounting place must be level and even. Mark the outline of the sat-dome's feet with a pencil.
4. Ensure that the underside of the mounting feet and the area of the roof where they will sit is clean and dry. If necessary, clean with a suitable cleaning agent. Methylated spirits works well on most surfaces and with many adhesive / sealants. If in doubt, test the surface first and consult the manufacturer of the sealant / adhesive.
5. It may be necessary to roughen the underside of the feet and the fixing area on the roof: follow the instructions that came with the adhesive / sealant and then apply it evenly to the underside of the mounting feet. The minimum thickness of the adhesive layer must be at least 2mm. Within 5 minutes of applying the adhesive, replace the sat-dome on the roof in the pre-selected position. Press the feet onto the roof and trim off any excess adhesive.
6. It is essential that you give the adhesive enough time to harden completely. The time this takes will vary according to the adhesive used and the ambient temperature and humidity. Always follow the instructions that come with the adhesive / sealant and, if you are in any doubt as to how it should be applied, seek professional advice.
7. We strongly advise screwing the mounting feet to the roof after the adhesive has been applied.
8. At this point you should remove the cover of the dome, cut the cable tie and remove all packaging. Replace the cover with the screws supplied.
9. Use the cable-entry box supplied to take the 10M cable from the sat-dome through the roof to the controller. Ensure that the cable is secure and cannot be caught by obstacles.
10. Install the controller in a convenient position inside the vehicle and, using the power cable supplied, connect to a reliable 12V or 24V power source.
11. Connect the cable from the sat-dome to the connector marked **ANTENNA** on the back of the controller and the short cable supplied to the connector marked **RECEIVER**. Connect the other end of that cable to your satellite receiver.
12. The installation is now complete and you can connect a TV to the receiver, turn everything on and use your sat-dome for the first time.

Very important. Please read this!!

It is essential that your sat-dome is installed using the cables supplied and that these cables are not cut or modified in any way. If any other cables or connectors are used, or if the cables are cut, the system will not work correctly. This applies to both original and secondary installations.

BASIC OPERATION

The RoadPro sat-dome controller has a red on/off switch and a white "satellite selector" button. These control all operational functions of the sat-dome. Three LEDs show the status of the sat-dome and seven other LEDs show which satellite is being searched for or has been located. The controller is set for Astra 2 (south) when it is first delivered and other satellites can be chosen as required. Astra 2 is the satellite which carries all TV and radio channels intended for viewing and listening in the U.K.



Before attempting to operate the system, make sure that the controller is connected to a 12V / 24V power supply and that a suitable receiver is also connected. Make sure that the receiver is set to work with the same satellite that you want the sat-dome to find and that a TV or monitor is connected to the receiver and is switched to the appropriate "source".

To switch the system on:

Press the red button on the left of the controller.

The system will immediately begin searching for the selected satellite - the one with a corresponding red LED illuminated. It may find a different satellite first and then after calculating its position, move to the chosen satellite and lock on. This can take between 10 - 60 seconds depending on how far the system is from where it was when it was last used. Fine tuning will then be carried out and, shortly afterwards, a picture will appear on the TV or monitor.

When the satellite has been found, and you can see a picture on the screen, you can turn the controller off using the red button. The dish will remain in position until the next time you turn the controller on.

To select a different satellite:

The controller enables you to select a number of satellites: Astra 2, Astra 1, Hotbird, Sirius 4.8 (Astra 4), Hispasat and Atlantic Bird 3.

To select a different satellite* from the one currently selected, tap the white button on the controller. This will cause the illuminated LED to move along the row of marked satellites. When the satellite you want is illuminated, stop tapping. The system will now search for that satellite and will return to the same satellite the next time you turn the system on after you have turned it off.

*Make sure you've selected the same satellite on your receiver.

What the LEDs mean:



System set to search for Astra 2 south.



System has found a satellite and will now move to Astra 2 south.



Astra 2 south LED blinks once - the selected satellite has been found.



System has confirmed that the selected satellite (Astra 2 south) has been found and has locked on. Turn off power switch.