


Shark™

**Bagless Canister Vacuum
with HEPA Filter**

OWNER'S MANUAL

Model EP79
120V., 60Hz., 10.8 Amps



For information or assistance:
USA: EURO-PRO Operating LLC
94 Main Mill Street, Door 16
Plattsburgh, NY 12901
www.sharkcompany.com

EURO-PRO 



ONE (1) YEAR LIMITED WARRANTY

EURO-PRO OPERATING LLC warrants this product to be free from defects in material and workmanship for a period of one (1) year from the date of the original purchase, when utilized for normal household use, subject to the following conditions, exclusions and exceptions.

If your appliance fails to operate properly while in use under normal household conditions within the warranty period, return the complete appliance and accessories, freight prepaid to **EURO-PRO Operating LLC**, 94 Main Mill Street, Door 16, Plattsburgh, NY 12901. If the appliance is found by **EURO-PRO Operating LLC** to be defective in material or workmanship, **EURO-PRO Operating LLC** will repair or replace it free of charge. Proof of purchase date and \$ 11.95 to cover the cost of return shipping and handling must be included. *

Non-durable parts including, without limitation, filters, brushes and electrical parts which normally require replacement are specifically excluded from warranty.

The liability of **EURO-PRO Operating LLC** is limited solely to the cost of the repair or replacement of the unit at our option. This warranty does not cover normal wear of parts and does not apply to any unit that has been tampered with or used for commercial purposes. This limited warranty does not cover damage caused by misuse, abuse, negligent handling or damage due to faulty packaging or mishandling in transit. This warranty does not cover damage or defects caused by or resulting from damages from shipping or repairs, service or alterations to the product or any of its parts, which have been performed by a repair person not authorized by **EURO-PRO Operating LLC**.

This warranty is extended to the original purchaser of the unit and excludes all other legal and/or conventional warranties. The responsibility of **EURO-PRO Operating LLC** if any, is limited to the specific obligations expressly assumed by it under the terms of the limited warranty. **In no event** is **EURO-PRO Operating LLC** liable for incidental or consequential damages of any nature whatsoever. Some states do not permit the exclusion or limitation of incidental or consequential damages, so the above may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

***Important: Carefully pack item to avoid damage in shipping. Be sure to include proof of purchase date and to attach tag to item before packing with your name, complete address and phone number with a note giving purchase information, model number and what you believe is the problem with item. We recommend you insure the package (as damage in shipping is not covered by your warranty). Mark the outside of your package "ATTENTION CUSTOMER SERVICE".**



OWNERSHIP REGISTRATION CARD

Please fill out and mail the product registration card within ten (10) days of purchase. The registration will enable us to contact you in the unlikely event of a product safety notification. By returning this card you acknowledge to have read and understood the instructions for use, and warnings set forth in the accompanying instructions.

RETURN TO: **EURO-PRO OPERATING LLC**: 94 Main Mill Street, Door 16, Plattsburgh, Ny 12901

Model EP79

Appliance model

Date purchased

Name of store

Owner's name

Address

City

State

Zip code

ORDERING REPLACEMENT DUST CUP FILTERS

TO ORDER REPLACEMENT FILTERS for Model EP79

Call: 1-866-98SHARK (1-866-987-4275)

Monday to Friday 8:30 A.M. - 5:00 P.M. Eastern Standard Time

FOR TECHNICAL SUPPORT for Model EP79

Call: 1-800-798-7398

Monday to Friday 8:30 A.M. - 5:00 P.M. Eastern Standard Time

or

visit our website: www.sharkvac.com

Please Note: The HEPA Dust Cup Filter may be washed. We recommend Wash once a month or when suction appears reduced.

To wash your HEPA Dust Cup Filter, hold filter cartridge by frame flange and rinse under a tap until all observable dirt has been removed. Some discoloration of the HEPA filter material may occur, this is normal and will not affect the filter's performance. When finished, shake off excess water. Do **NOT** wash in dishwasher. It is important that when you wash the HEPA dust cup filter, you allow it to dry **COMPLETELY** before using again. We recommend 24 hours to air dry. **DO NOT DRY IN DRYER.**

IMPORTANT

PLEASE NOTE THAT THE MICRO-EXHAUST FILTER IS NOT WASHABLE

Motor Thermostat

IMPORTANT: This motor is equipped with a motor protective thermostat. If for some reason the vacuum cleaner should overheat, the thermostat will automatically turn the unit OFF. Should this occur, unplug the vacuum cleaner from wall outlet or turn off switch. Allow the unit to cool. To restart, re-plug into wall outlet or turn switch back on.

IMPORTANT SAFETY INSTRUCTIONS

When using your **SHARK Bagless Canister Vacuum with HEPA Filter**, basic safety precautions should always be observed, including the following:

1. Read all instructions before using your canister vacuum.
2. Use the system only for its intended use.
3. To protect against a risk of electric shock, do not immerse any part of the system in water or other liquids.
4. Never yank cord to disconnect from outlet; instead, grasp plug and pull to disconnect.
5. **Do not** allow cord to touch hot surfaces.
6. **Do not** run appliance over cord.
7. **Do not** operate the system with a damaged cord or plug, or if the appliance or any other part of the system has been dropped or damaged. To avoid the risk of electric shock, do not disassemble or attempt to repair the canister vacuum. Return the system to **EURO-PRO Operating LLC** (see warranty) for examination and repair. Incorrect re-assembly or repair can cause a risk of electrical shock or injury to persons when the canister vacuum is used.
8. Close supervision is necessary for any appliance being used by or near children. Do not leave the system unattended while connected.
9. Keep hair, loose clothing, fingers and all parts of body away from opening and moving parts.
10. **Do not** use to pick up flammable or combustible liquids such as gasoline or use in areas where they may be present.
11. **Do not** pick up anything that is burning or smoking such as cigarettes, matches or hot ashes.
12. Use extra care when cleaning on stairs.
13. **Do not** use the canister vacuum without the dust bag and/or filters in place.
14. **Do not** pick up hard or sharp objects such as glass, nails, screws, coins, etc.
15. This appliance is intended only for household use. Follow all user instructions in this manual.

To reduce the risk of fire, electric shock, or injury:


- **Do not** leave the canister vacuum plugged in when unattended. Unplug the electrical cord when not in use and before servicing.
- **Do not** allow to be used as a toy. Close attention is necessary when used by or near children, pets or plants.
- Use only as described in this manual. Use only manufacturer's recommended accessories.
- **Do not** pull cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Keep cord away from heated surfaces.
- Use **only** extension cords UL-rated or cUL at 15 amperes. extension cords rated for less amperage may overheat. Care should be taken to arrange the cord so that the cord cannot be pulled or tripped over.
- Turn off all controls as applicable before unplugging from electrical outlet.
- **Do not** unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- **Do not** handle plug or vacuum with wet hands or operate without shoes.
- **Do not** put any objects into openings. Do not use with any opening blocked. Keep free of dust, lint, hair and anything else that may reduce air flow.
- Store your appliance indoors in a cool, dry area.
- Keep your work area well lit.
- **Do not** immerse the vacuum into water or other liquids.
- Keep end of hose, wands and other openings away from your face and body.
- Use only on dry surfaces.
- Using improper voltage may result in damage to the motor and possible injury to the user. Correct voltage is listed on rating label.

SAVE THESE INSTRUCTIONS

For Household Use Only

WARNING: To reduce the risk of electric shock, this appliance has a polarized plug (one blade is wider than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet. Do not modify the plug in any way.

GETTING TO KNOW YOUR BAGLESS CANISTER VACUUM



Technical Specifications

Voltage: 120V. 60Hz.
Power: 10.8 Amps, 1300 Watts


OPERATING INSTRUCTIONS cont.

Important: Do NOT use the HEPA filter cartridge without the debris screen in place.


Changing and Cleaning the Pre-Motor Filter

- Filter should be cleaned at least twice a year or when it becomes visible solid.
- Always operate the cleaner with the filter installed.
- Disconnect from electrical outlet before cleaning the filter.
- Do not use a washing machine to rinse the filter.
- Do not use a hair dryer to dry it.

1. Push the dust cup lock to open the dust cup.
2. Remove the filter from the grill-filter.




3. Rinse filter in lukewarm water and dry the filter completely.



4. Put the filter into the grill-filter.
5. A severely solid or clogged filter should be thoroughly washed with fresh tepid water. A mild detergent can be used if required.

Changing the Micro-Exhaust Filter



1. Open the lid.
2. Remove the used micro-exhaust filter.
3. Insert a new micro-exhaust filter.
4. Close the lid.


Motor Thermostat

Important: This motor is equipped with a motor protective thermostat. If for some reason the vacuum cleaner should overheat, the thermostat will automatically turn the unit off. Should this occur, unplug the vacuum cleaner from the wall outlet and turn off switch. Allow the unit to cool. To restart, re-plug into wall outlet and turn switch back ON.

Attaching the Shoulder Strap

Use the hooks to attach the shoulder strap to the vacuum cleaner.


First pass the flexible hose through the loop of the shoulder strap and then attach the two hooks to the strap hookup holes at the bottom of the vacuum cleaner as shown in illustration below.



Flat & Upright Parking Position

Please note that your vacuum cleaner can be conveniently placed in a space saving vertical parking position or in a convenient flat parking position.


1. Place unit on its side. Slide floor nozzle into locking position with receptacle which rests on top of unit.
2. While laying flat on 3 wheels, slide floor nozzle into locking position with receptacle which rests on the rear side of the unit.



OPERATING INSTRUCTIONS cont.

Cleaning & Changing the HEPA Dust Cup Filter (cont.)


4. Take the HEPA dust cup filter out of the dust cup, do not let the dust fall out.



5. Take out the dust cup and dispose of the dust inside.



6. Separate the debris screen from the HEPA filter cartridge by grasping the debris screen with one hand and the filter frame with the other and pull apart.



7. Vigorously "TapClean" the HEPA Dust Cup Filter on a hard surface until no more dust is observed falling out from between the pleats of the filter.



8. "TapClean" the Debris Screen or rinse under a faucet until clean. Remember that the Debris Screen must be completely dry before reinstalling in the vacuum.




9. Reassemble the debris screen to the HEPA filter cartridge and replace into dust cup (container). Ensure that the filter assembly is completely seated inside the dust cup (container).



10. Attach the dust cup (container) to the vacuum.



PLEASE NOTE: The white pleated filter material in the HEPA Dust Cup Filter will discolor over time -This is NORMAL and will NOT affect the performance of the filter. If the HEPA Dust Cup Filter is properly "TapCleaned" after each use and suction does not return to 100%, then we suggest that the HEPA filter be "TapCleaned" vigorously until no more dust can be removed, then rinsed under the faucet and allowed to dry for 24 hours before refitting into the vacuum. (Fig. A) Wash once a month or when suction appears reduced.




CAUTION: The suction hole must be open, free of any obstructions at all times. Otherwise, the motor will overheat and could become damaged.


PRECAUTIONARY MEASURES

Important: If the suction opening in the unit, the hose or the extension tube are **BLOCKED**, switch off the vacuum cleaner and remove the blocking substance before you start the unit again.


1. Do not operate the vacuum cleaner to close to heaters, radiators or cigarette butts.




2. Before inserting the power plug into the wall outlet, make sure that your hands are dry.



3. Before you start vacuuming, make sure to remove large or sharp objects that might damage the dust bag.



4. When pulling out the power plug from the wall outlet, pull the plug not the power cord.



5. Do not pick up anything that is burning or smoking such as cigarettes, matches or hot ashes.

6. Do not use without dust cup filter or filters in place.

Note: This vacuum cleaner is equipped with a plug and power cord that retract automatically. If the cord or plug get damaged, it must be replaced by a qualified technician.

Warning: Hold the plug when rewinding the cord. Do not allow the cord to whip when rewinding.

OPERATING INSTRUCTIONS


Assembling Your Vacuum Cleaner

Note: Always remove the power plug from the wall outlet before assembling or removing accessories.

1. Attaching the Flexible Hose into the Vacuum


Connect the flexible hose into the air intake duct. Push in until you hear a "click", indicating it is in its position.

To remove the flexible hose, reverse the operation.




2. Fitting the Chrome Telescopic Tube to the Curved Wand / Hose Extension

Push the chrome telescopic tube into the curved wand / hose extension, as shown in the illustration.




3. Extending the Chrome Telescopic Tube

Push forward the plastic knob and pull the smaller tube outward.



4. Attaching Extension Tubes to Floor Attachment

Push extension tube into the floor attachment.



5. Air Driven Turbo Brush

The efficiency of your Air Driven Turbo Brush depends on the bristle brush rotating at high speed. Strong air suction is needed to accomplish this. In order to endure that maximum air suction is maintained, please read the following instructions:

- Empty the Dust Cup frequently during use.
- Always "TapClean" the HEPA dust cup filter and debris screen each time the dust cup is emptied.
- Ensure that the rotating bristle brush is kept free of hair and string.
- Inspect the turbine regularly to ensure that the air passage is free of dirt and debris.



Variable Suction Control

Your vacuum cleaner includes an manual variable suction control on the hose extension. The suction power can be adjusted by moving the slide regulator to the desired position. For example. Less suction is required on upholstery and draperies compared to thick shag carpets, which require maximum suction.

Crevice Tool and Dusting Brush

1. Crevice Tool

For radiators, crevices, corners, baseboards and between cushions.



2. Dusting Brush

The dusting brush is used for the furniture, venetian blinds, books, lamp shades and shelves.



OPERATING INSTRUCTIONS cont.


Warning: To reduce the risk of electric shock, the power cord must be disconnected before removing the dust cup, dust cup filter, changing the filters or performing maintenance/trouble shooting checks.

Note: Before using the appliance, unwind a sufficient length of cable and Insert the plug into the wall socket. A yellow mark on the power cord shows the ideal cable length. Don't pull the power cord beyond the red mark.


Power Cord

Your vacuum cleaner includes a power cord, which is automatically retractable. To extend your power cord, pull from rear and extend to desired length. When cleaning is finished, first switch off power and disconnect plug from electrical outlet. Then press on cord rewind button. If the cord does not fully retract, pull it out again and then press on cord rewind button.

1. Insert the power plug into the wall outlet.
2. Press the Power On/Off Switch to activate the vacuum cleaner.



3. To rewind the power cord, press the cable rewind button with one hand and guide the power cord with the other hand to ensure that it does not whip causing damage.



Cleaning & Changing the HEPA Dust Cup Filter

Warning: Always unplug the unit from electrical outlet before opening the Dust Cup (container).

Important: Do **NOT** use the HEPA filter cartridge without the debris screen in place.

Warning: After each Use - Always remove the Filter Debris Screen from the HEPA Dust Cup Filter, then vigorously "TapClean" HEPA Filter until no more dust can be removed.

IMPORTANT, Please Note : The "TapClean" HEPA Dust Cup Filter & Debris Screen will stop most of the tiniest dust particles and airborne allergens from re-entering the air you breathe. In fact it stops 99.97% of all particles as small as 0.3 microns - many times smaller than a human hair!!! Because of this incredible filtration performance, the HEPA Dust Cup Filter will quickly accumulate, inside the white filter folds, many fine dust particles that are difficult to see but which will eventually block or reduce your suction power - if not cleaned properly. This can cause the motor to overheat and the re-settable thermostat to trip. (Should this happen turn off the switch, unplug the unit and allow unit to cool down. Clean the HEPA Filter and Debris Screen as described in this section, then reconnect unit and proceed with vacuuming.)

1. Push the Power On/Off switch to the OFF position to disconnect the power.
2. Remove the flexible hose (see page 3).
3. Push the dust cup lock and open the dust cup.

