



MPH 6929

OWNER'S MANUAL

900 MHz Cordless

Phone with Digital

Answering System

Memorex

PRECAUTIONS

Before you read anything else, please observe the following:

Warning!

The manufacturer **DOES NOT** represent this unit to be waterproof. To reduce the risk of fire, electrical shock, or damage to the unit, **DO NOT** expose this to rain or moisture.

Rechargeable Nickel-Cadmium Battery Warning

- This equipment contains a rechargeable nickel-cadmium battery.
- Cadmium is a chemical known to the State of California to cause cancer.
- The rechargeable nickel-cadmium battery contained in this equipment may explode if disposed of in a fire.
- Do not short-circuit the battery.
- Do not charge the rechargeable nickel-cadmium battery used in this equipment in any charger other than the one designed to charge this battery as specified in the owner's manual. Using another charge may damage the battery or cause the battery to explode.

RECHARGEABLE NICKEL-CADMIUM BATTERIES MUST BE RECYCLED OR DISPOSED OF PROPERLY

May be covered under one or more of the following U.S. patents:

| | | | | | |
|-----------|-----------|-----------|-----------|-----------|-----------|
| 4,511,761 | 4,523,058 | 4,595,795 | 4,797,916 | 5,381,460 | 5,426,690 |
| 5,434,905 | 5,491,745 | 5,533,010 | 5,574,727 | 5,650,790 | 5,650,269 |
| 5,661,780 | 5,663,981 | 5,671,248 | 5,717,312 | 5,754,407 | 5,768,345 |
| 5,787,356 | 5,838,721 | 5,864,619 | 5,893,034 | 5,912,968 | 5,915,227 |
| 5,929,598 | 5,930,720 | 5,960,358 | 5,987,330 | | |

©2000 Memorex is a registered trademark of Memorex Telex N.V.
All rights reserved. • Printed in China UCZZ01237BC



NOTE

Fold out the back cover of this owner's manual to use the handy "Controls and Functions" page for reference.

CONTENTS

| | |
|---|----------------------------|
| Precautions! | Back Cover Fold-out |
| Controls and Functions | Back Cover Fold-out |
| Important Safety Instructions | i |
| Introduction | 1 |
| • Welcome | 1 |
| • Features | 1 |
| • Included in Your Package | 2 |
| • Important Electrical Considerations | 3 |
| Installing and Adjusting Your Phone | 5 |
| • Installation Considerations | 5 |
| • Adapter Safety Features | 6 |
| • Desk/Tabletop Installation | 7 |
| • Wall Installation | 8 |
| • Installing the Handset Battery Pack | 12 |
| • Charging the Battery Pack | 12 |
| • Cleaning the Battery Contacts | 13 |
| • Page | 13 |
| • Setting the Pulse/Tone Switch | 14 |
| • Adjusting the Ringer Controls | 14 |
| • Automatic Digital Code Security | 15 |
| Using Your New Phone | 16 |
| • Making and Receiving Calls | 16 |
| • Flash and Call Waiting | 16 |
| • Storing a Phone Number in Memory | 17 |
| • Dialing a STORED Number | 17 |
| • Chain Dialing | 18 |
| • Erasing a Stored Number from Memory | 18 |
| • Redial | 19 |
| • Tone | 19 |
| • Traveling Out-of-Range | 19 |
| • Channel | 19 |
| • Using the SpeakerPhone | 19 |
| • Three-way call | 19 |
| Setting Up the Integrated Answering Device | 20 |
| • The Integrated Answering Device | 20 |
| • Features | 20 |
| • Turning the Answering System On/Off | 21 |
| • Setting the Clock | 21 |
| • Setting Your Outgoing Message (Greeting) | 22 |
| • Selecting the Message RECORD Time | 23 |
| • Selecting a Pin Code | 24 |
| • Calling Party Control Feature | 24 |
| • Setting the Toll Saver Switch | 25 |
| • Using the Reset Button | 25 |
| Using the Integrated Answering Device | 26 |
| • Playing Your Messages | 26 |
| • Repeating a Message | 26 |
| • Skipping a Message | 27 |
| • Deleting a Message | 28 |
| • Memo | 28 |
| • Recording a Conversation | 29 |
| • Remote Access Away from Home | 29 |
| • Remote Room Monitor | 31 |
| Troubleshooting | 32 |
| • Quick Reference Chart | 32 |
| Specifications | 35 |
| • General | 35 |
| • Base | 35 |
| • Handset | 35 |
| Memorex Limited Warranty | 36 |

IMPORTANT SAFETY INSTRUCTIONS

When using your telephone equipment, these basic safety precautions should always be followed to reduce the risk of fire, electrical shock, and injury to persons:

1. Read and understand all instructions.
2. Follow all warnings and instructions marked on the product.
3. Unplug this product from the wall outlet before cleaning. Use a dry cloth for cleaning without liquid or aerosol cleaners.
4. Do not use this product near water; for example, near a bath tub, wash bowl, kitchen sink or laundry tub, in a wet basement, or near a swimming pool.
5. Do not place this product on an unstable cart, stand, or table. The telephone may fall, causing serious damage to the unit.
6. Slots and openings in the cabinet and the back or bottom are provided for ventilation. To protect the product from overheating, these openings must not be blocked or covered. This product should never be placed near or over a radiator or heat register. This product should not be placed in a built-in installation unless proper ventilation is provided.
7. This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your dealer or local power company.
8. Do not allow anything to rest on the power cord. Do not locate this product where the cord will be damaged by persons walking on it.
9. Do not overload wall outlets and extension cords, as this can result in the risk of fire or electrical shock.
10. Never push objects of any kind into this product through cabinet slots, as they may touch dangerous voltage points or short out parts that could result in a risk of fire or electric shock. Never spill liquid of any kind on the product.
11. To reduce the risk of electric shock, do not disassemble this product. Take it to qualified service personnel when service or repair work is required. Opening or removing covers may expose you to dangerous voltages or other risks. Incorrect reassembly can cause electric shock when the appliance is subsequently used.
12. Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:
 - A. When the power supply cord is damaged or frayed.
 - B. If liquid has been spilled into the product.
 - C. If the product has been exposed to rain or water.



- D. If the product does not operate normally when following the operating instructions.
(Adjust only those controls that are covered by the operating instructions. Improper adjustment of other controls may result in damage and will often require extensive repair work by a qualified technician.)
 - E. If the product has been dropped or the cabinet has been damaged.
 - F. If the product exhibits a distinct change in performance.
13. Do not use the telephone to report a gas leak in the vicinity of the leak.

▼ *Additional Battery Safety Precautions*

Caution! To reduce the risk of fire or injury to persons by the battery, read and follow these instructions:

1. Use only the appropriate type and size battery pack specified in the reference guide.
2. Do not dispose of the battery pack in a fire. The cell may explode.
3. Do not open or mutilate the battery pack. Released electrolyte is corrosive and may cause damage to the eyes or skin. It may be toxic if swallowed.
4. Exercise care in handling the battery in order not to short the battery with conducting materials such as rings, bracelets, and keys. The battery or conductor may overheat and cause burns.
5. Charge the battery pack provided with or identified for use with this product only in accordance with the instructions and limitations specified in the reference guide provided for this product.
6. Observe proper polarity orientation between the battery pack and battery charger.

▼ *Cordless Telephone Privacy*

Note! Cordless telephones are radio devices. Communications between the handset and base of your cordless telephone are accomplished by means of radio waves which are broadcast over the open airways. Because of the inherent physical properties of radio waves, your communications can be received by radio receiving devices other than your own cordless telephone unit. Consequently, any communications using your cordless telephone may not be private.



INTRODUCTION

TO YOUR NEW PHONE

WELCOME

Congratulations on your purchase of the Memorex MPH6929 cordless telephone and answering system. This phone is designed and engineered to exacting standards for reliability, long life, and outstanding performance.

FEATURES

- 900 MHz Extended Range Technology
- Integrated Telephone Answering Device (ITAD)
- 10 Number Memory Dialing
- 3 Instant Dial Priority Keys
- 32 Digit Redial
- Flash and Pause
- Pulse/Tone Dialing
- Page/Find
- 7 Hour Talk Time
- Handset Earpiece and Ringer Volume Control
- Hearing Aid Compatible

The MPH6929 features include *Instant Talk* and *Auto Disconnect*. *Instant Talk* allows you to answer a call by just removing the handset from the base so you don't have to waste time pushing buttons or flipping switches. *Auto Disconnect* allows you to hang up by simply returning the handset to the base.

The *Mega Clear Plus* true compander circuitry virtually eliminates background noise. This innovative technology, together with 40 different channels, provides you with the best possible reception during all your conversations.

To protect you against misbilled calls which might result from your phone being activated by other equipment, the MPH6929 has a digital security system which automatically selects one of over 65,000 digital security codes for the handset and base. Also, the *MegaSecure* feature electronically locks your phone when the handset is in the base.


To get the most from your phone, please read this owner's manual thoroughly. Also, be sure to complete the product registration form and mail it in.

Memorex® is a registered trademark of the Memorex Telex N.V.

TIP

To get the most from your phone, please read this owner's manual thoroughly. Also be sure to complete and mail the product registration form.


INCLUDED IN YOUR PACKAGE




Handset




Base




AC Adapter



Rechargeable Battery
(Located inside handset)



Telephone Cord



Wall Mount Adapter

Also included:

- This Owner's Manual



Please do not attempt to unplug any appliance during an electrical storm.

IMPORTANT ELECTRICAL CONSIDERATIONS

Unplug all electrical appliances when you know an electrical storm is approaching. Lightning can pass through your household wiring and damage any device connected to it. This phone is no exception.

The FCC Wants You To Know

Changes or modifications to this product not expressly approved by the manufacturer, or operation of this product in any way other than as detailed by the reference guide, could void your authority to operate this product. The equipment cannot be used on public coin phone service provided by the telephone company. Connection to party line service is subject to state tariffs. (Contact the state public utility commission, public service commission or corporation commission for information.)

Range

Your new phone is designed to achieve the maximum possible range by transmitting and receiving according to the highest specifications set forth by the FCC. We have rated this phone to operate at a maximum distance with the qualification that the range depends upon the environment in which the telephone is used. Many factors limit range, and it would be impossible to include all the variables in our rating. The Maximum Range rating of this phone is meant to be used as a means of comparison against other range claims.

Telephone Line Problems

The FCC has granted the telephone company the right to disconnect service in the event that your phone causes problems on the telephone line. Also, the telephone company may make changes in facilities and services which may affect the operation of your unit. However, your telephone company must give adequate notice in writing prior to such actions to allow you time for making necessary arrangements to continue uninterrupted service.

If you are having trouble with your telephone service, you must first disconnect your phone to determine if it is the cause of your problem. If you determine that it is the cause, you must leave it disconnected until the trouble has been corrected.



Radio Interference

Radio interference may occasionally cause buzzing and humming in your cordless handset, or clicking noises in the base. This interference is caused by an external source such as a TV, refrigerator, vacuum cleaner, fluorescent lighting, or electrical storm. Your unit is NOT DEFECTIVE. If these noises continue and are too distracting, please check around your home to see what appliances may be causing the problem. In addition, we recommend that the base not be plugged into a circuit that also powers a major appliance because of the potential for interference. Be certain the antenna is kept in the vertical position.

In the unlikely event that you consistently hear other voices or distracting transmissions on your phone, you may be receiving radio signals from another cordless telephone or other source of interference. If you cannot eliminate this type of interference, you need to change to a different channel.

Finally, it should be noted that some cordless telephones operate at frequencies that may cause interference to nearby TVs and VCRs. To minimize or prevent such interference, the base of the cordless telephone should not be placed near or on top of a TV or VCR. If interference is experienced, moving the cordless telephone farther away from the TV or VCR will often reduce or eliminate the interference.

More Than One Cordless Telephone

If you want to use more than one cordless telephone in your home, they must operate on different channels. Press the channel key to select a channel that provides the clearest communication.



INSTALLATION CONSIDERATIONS

Selecting a Location

Before choosing a location for your new phone, there are some important guidelines you should consider:

- The location should be close to both a phone jack and continuous power outlet. (*A continuous power outlet is an AC outlet which does not have a switch to interrupt its power.*)
- Keep the base and handset away from sources of electrical noise such as motors or fluorescent lighting.
- Be sure there is sufficient space to fully extend the base antenna.
- The base can be placed on a desk or tabletop or mounted on a standard AT&T or GTE wall plate.
- You should charge your new phone for 15-20 hours before completing the installation or using the handset.



Telephone Line Outlets

There are two types of phone outlets:

▼ *Modular Jack*

Most phone equipment available now uses modular jacks. Phone cords are fitted with a molded plastic connector which plugs into this type of jack. If you do not have modular phone jacks, contact your local telephone company for information about their installation.

▼ *Hardwired Jack*

Some equipment is wired directly to a phone jack, and these types of installations require a modular jack converter. This type of installation is not difficult; however, you should contact your local telephone dealer or a telephone supply store for advice about the proper adapter or converter for your particular situation.

INSTALLING
AND ADJUSTING YOUR PHONE





Place the power cord so that it does not create a trip hazard or where it could become chafed and create an electrical hazard or fire.



Before using your phone, fully charge the Nickel-Cadmium battery pack for 15-20 hours.

Connecting the Telephone Cords

Consider these safety guidelines before connecting the telephone cords:

Caution!

- Never install telephone wiring during a lightning storm.
- Never touch uninsulated telephone wires or terminals unless the telephone line has been disconnected.
- Use caution when installing or modifying telephone lines.

Applying Power to the Base

This phone requires an AC outlet, without a switch to interrupt power, and the included AC adapter. To relieve strain on the DC plug when the phone is placed on a desk or table, wrap the power cord around the strain relief notch on the bottom of the base.


ADAPTER SAFETY FEATURES

If the AC adapter furnished with this phone has a polarized line plug (a plug having one blade wider than the other), this plug will fit into the power outlet only one way. If you are unable to insert the plug fully into the outlet, try reversing the plug.

Do not alter the shape of the blades of the polarized plug!

NOTE: If you cannot plug the AC adapter into the outlet, contact someone about replacing the outlet.


Plug the AC Adapter into a standard 120 V AC wall outlet. Do not use an outlet controlled by a wall switch. Use only the AC Adapter supplied with this phone.



TIP

Before choosing a location for your phone, read the "Installation Considerations" included in the "Precautions and Important Safety Instructions" brochure.

DESK/TABLETOP INSTALLATION



- 1) Plug the AC adapter cord into the 9 V DC input jack on the back of the base.
- 2) Wrap the AC adapter cord around the strain relief notch.



Place the power cord so that it does not create a trip hazard or where it could become chafed and create a fire or electrical hazard.

- 3) Plug the AC adapter into a standard 120 V AC wall outlet.



Use only the supplied AC adapter supplied with this phone and DO NOT use an outlet controlled by a wall switch.

- 4) Charge the battery (refer to "Charging the Battery Pack," page 12).
- 5) Plug one end of the telephone cord into the **TEL LINE** jack on the back of the base.
- 6) Plug the other end of the cord into your telephone jack on the wall.


HINT

Before using your phone, fully charge the Nickel-Cadmium battery pack for 15-20 hours.

CAUTION

Place the power cord so that it does not create a trip hazard or where it could become chafed and create a fire or electrical hazard.

- 7) Set the base on a desk or tabletop, and place the handset into the base as shown. Then, raise the antenna to a vertical position.




WALL INSTALLATION


▼ Standard wall plate mounting

This phone can be mounted on any standard AT&T or GTE wall plate.

- 1) Slide the wall mount adapter into the notches at the top of the base.
- 2) Rotate the wall mount adapter down and snap it into place at the bottom of the base.



- 3) Plug the AC adapter into the base.
- 4) Put the AC adapter cord inside the molded wiring channel, then wrap it around the strain relief notch. Plug the AC adapter into a standard 120 V AC wall outlet.





DO NOT use an outlet controlled by a wall switch.






Before you plug the other end of the telephone cord into the modular jack on the wall, charge the battery (refer to "Charging the Battery Pack," page 12).

5) Plug one end of the telephone cord into the **TEL LINE** jack on the back of the base, then plug the other end into a standard telephone jack.

6) Line up the mounting slots on the base with the mounting posts on the wall, then push in and down until the phone is firmly seated.

7) On the base unit, pull the handset retainer out of the slot and rotate it clockwise 180 degrees.

8) Flip the retainer from front to back, then slide it back into the slot so that the lip of the retainer faces up and the oval is at the bottom of the retainer. This will hold the handset in place.




▼ *Direct wall mounting*


If you don't have a standard wall plate, you can mount your phone directly to the wall. Before doing this, consider the following:

- Select a location away from electrical cables, pipes, or other items behind the mounting location. Inserting screws into areas such as this can be hazardous.
- Try to mount your phone within 10 - 15 feet of a working phone jack in order to avoid excessive lengths. Remember, you are not mounting your phone to a wall plate with a built-in phone jack.
- If the selected mounting area has no wooden support beams directly behind it, you will need the appropriate anchoring devices in order for the wall to properly support your phone.

- 1) Insert two mounting screws into the wall, with their appropriate anchoring device if necessary, 3-15/16 inches apart. Allow about 3/16 of an inch between the wall and screw heads for mounting the phone.




- 2) Slide the wall mount into the notches at the top of the base.
- 3) Rotate the wall mount adapter down and snap it into place at the bottom of the base.




- 4) Plug the AC adapter into the base.


- 5) Put the AC adapter cord inside the molded wiring channel, then wrap the AC adapter cord around the strain relief notch. Plug the AC adapter into a standard 120 V AC wall outlet.




- 6) Plug one end of the telephone cord into the **TEL LINE** jack on the back of the base, then plug the other end into a standard telephone jack.




- 7) Line up the mounting slots on the base with the mounting screws on the wall, then push in and down until the phone is firmly seated.



- 8) On the base unit, pull the handset retainer out of the slot and rotate it clockwise 180 degrees.




- 9) Flip the retainer from front to back, then slide it back into the slot so that the lip of the retainer faces up and the oval is at the bottom of the retainer. This will hold the handset in place.



INSTALLING THE HANDSET BATTERY PACK

- 1) Remove the handset battery cover

For initial charging, the battery pack will already be inside the compartment, but will not be plugged in.



- 2) Plug the battery's cable into the handset
- 3) Replace the battery cover.



The plastic connectors will fit together only one way. Make sure the battery's connector is properly aligned. Use only the supplied battery pack (model BT-905).

CHARGING THE BATTERY PACK

▼ Initial battery charging

Before plugging the phone line into your new phone for the first time, fully charge the rechargeable battery pack for 15-20 hours *without interruption*.

- 1) Place the handset on the base.
- 2) Make sure that the **status** LED lights. If the LED doesn't light, check to see that the AC adapter is plugged in and that the handset makes good contact with the base charging contacts.




Use only the supplied battery (BT-905) supplied with your phone.

▼ *Low battery indicator*

When the battery pack is very low and needs to be charged, the phone is programmed to eliminate functions in order to save power. If the phone is not in use, the **talk/batt** LED flashes every three seconds.

If the phone is in use, the **talk/batt** LED flashes every three seconds and the handset beeps. Complete your conversation as quickly as possible and return the handset to the base for charging.




CLEANING THE BATTERY CONTACTS

To maintain a good charge, clean all charging contacts on the handset and base about once a month with a pencil eraser or other contact cleaner. DO NOT use liquids or solvents; you may damage your phone.

PAGE

To locate the handset (while it's off the base), press **page** on the base. The handset beeps for 60 seconds.

Paging is cancelled.
When the handset is returned to the base, paging is cancelled.




TIP

Most phone systems use tone dialing. Check with your local phone company if you're not sure whether your system is tone or pulse.

SETTING THE PULSE/TONE SWITCH

Be sure the **PULSE/TONE** switch is in the **TONE** position unless your local phone system uses pulse dialing.



ADJUSTING THE RINGER CONTROLS

▼ Handset ringer tone and ringer volume


When the phone is in standby mode, pressing the **volume** key on the handset selects the handset ringer volume and tone. There are two ringer tones each with two volume levels; high and low.

▼ Handset earpiece volume

The handset earpiece volume settings (Normal, High and Loud) can only be adjusted during a call. Press **volume** to select Normal, High, or Loud. When you hang up, the phone keeps the last **volume** setting selected.

▼ Base unit ringer on-off

To turn the base ringer on, select the **RINGER ON** position. To turn the base ringer off, select the **RINGER OFF** position.



AUTOMATIC DIGITAL CODE SECURITY



To prevent other parties from making unauthorized calls on your phone line, a digital code was added to the MPH6929. Your phone's handset and base share this code, which is randomly set each time you place the handset in the charging cradle.

▼ *To reestablish communication between the handset and the base in the event of a power failure*

- 1) Restore power to the base.
- 2) Place the handset on the base. The **status** LED blinks to indicate that the digital security code is reset.


MAKING AND RECEIVING CALLS

YOUR NEW PHONE

| | Handset On Base  | Handset Off Base  |
|------------------|---|--|
| To answer a call | Pick up the handset, or press speaker on the base. | Press any button on the handset or press speaker on the base. |
| To make a call | <ol style="list-style-type: none"> 1) Pick up the handset. 2) Press talk. 3) Listen for the dial tone. 4) Dial the number. | <ol style="list-style-type: none"> 1) Press talk. 2) Listen for the dial tone. 3) Dial the number. |
| To hang up | Press talk , or return the handset to the base (Auto Disconnect), or press speaker . | Press talk , or return the handset to the base (Auto Disconnect), or press speaker on the base. |
| To redial | <ol style="list-style-type: none"> 1) Pick up the handset. 2) Press talk. 3) Listen for the dial tone. 4) Press redial. | <ol style="list-style-type: none"> 1) Press talk. 2) Listen for the dial tone. 3) Press redial. |

FLASH AND CALL WAITING

If you have “call waiting” service and a call waiting tone sounds while you are on a call, press **flash** to accept the waiting call. There is a short pause, then you will hear the new caller. To return to the original caller, press **flash** again.



USING YOUR PHONE


NOTE

The pause button counts as one digit. Pressing **pause** more than once increases the length of pause between numbers.

STORING A PHONE NUMBER IN MEMORY

Your MPH6929 phone has 10 memory locations for storing important telephone numbers.

- 1) Remove the handset from the base.
- 2) Press **mem**.
The **talk/batt** LED blinks.
- 3) Enter the phone number, up to 16 digits. If a pause is needed during dialing to access a long distance or other service, press **pause** to insert a pause.
- 4) Press **mem** again.
- 5) Enter the memory location (0-9) on the keypad. A tone indicates that the number is stored.



NOTE

You cannot store numbers in **M1, M2 or M3**. Refer to "One-Touch Dialing."

DIALING A STORED NUMBER

▼ Using the memory location features

- 1) Press **talk**.
- 2) Press **mem**.
- 3) Enter the memory location (**0-9**, or **M1-M3**) on the keypad. The stored number automatically dials.

NOTE

If you select a memory location that does not have a stored number, the handset will beep rapidly and the phone will not dial.


NOTE

An error sounds and the erase procedure will be canceled if more than 20 seconds elapse between each keystroke.

▼ One-touch priority dialing

Your phone is equipped with three “One-Touch Priority” keys for instant dialing. *You cannot store phone numbers directly into **M1**, **M2** or **M3**.* They are only used to dial phone numbers stored into memory locations 1, 2 and 3. (See “Storing a Phone Number in Memory,” page 17.)

To instantly dial phone numbers stored in memory locations 1, 2 or 3, simply press **M1**, **M2** or **M3**. (There is no need to press talk; the phone will automatically dial.)



If you press **M1**, **M2** or **M3**, and no phone number was stored in memory locations 1, 2, or 3, the phone will beep rapidly but will not dial.

CHAIN DIALING

On certain occasions after dialing a number, you may be requested to enter an access code, such as your account number. You can enter this number into a memory location for later use by doing the following.

- 1) Store the access code into one of the memory locations (0-9) or memory keys **M1**, **M2**, or **M3** following the steps above.
- 2) Dial the party or service main number.
- 3) When you need to enter the special number, press **mem** followed by the memory location (0-9) or memory keys **M1**, **M2**, or **M3**.

ERASING A STORED NUMBER FROM MEMORY

- 1) Remove the handset from the base unit.
- 2) Press the **MEM** button twice.
- 3) Press the memory location (0-9). A tone indicates that the stored number is erased from memory.

NOTE


The tone feature only applies when the base unit is set to pulse.

REDIAL

The **redial** key redials the last number dialed. The redialed number can be up to 32 digits long.

TONE

If you are dialing in the pulse mode and need to enter tone digits, press **tone** to enter the digits. Once the call has ended, the tone mode is canceled and pulse dialing resumes.



TRAVELING OUT-OF-RANGE

During a call, as you begin to move your handset too far from your base unit, noise increases. If you pass the range limits of the base unit, your call will terminate within 20 seconds.

CHANNEL

To help eliminate background noise, press **chan** to change channels.

USING THE SPEAKERPHONE

To use the speakerphone to answer a call, press **speaker** on the base. Direct your voice to the microphone on the bottom of the base. To hang up, press **speaker** again.

To use the speakerphone while making a call, first dial the number using the handset. Then press **speaker** on the base unit. You can press **talk** to disconnect the handset and continue the call with the speakerphone. Press **speaker** to hang up.

THREE-WAY CALL

First, dial the number using the handset. Then, press **speaker** to set up a three-way call between the base, handset, and the person on the line.

TIP

Adjust the speakerphone volume by pressing ▲ for louder or ▼ for softer.

THE INTEGRATED ANSWERING DEVICE

The MPH6929 has a built-in answering system that answers and records incoming calls. You can also use your answering system to record a conversation, leave a memo message for others who use the phone, or to announce a special message to callers when you're away from your phone.

FEATURES

- Digital Tapeless Recording
- 15 minutes of Recording Time
- Call Screening
- Selectable Outgoing Messages
- Time and Day Stamp
- Remote Message Retrieval and Room Monitor
- Toll Saver
- Conversation Recording

Digital Tapeless Recording allows you to quickly review, save, or delete the messages you choose. You'll never have to worry about a tape wearing out, jamming, or resetting improperly.

The Integrated Answering System is easy and convenient to use, but ***please read*** through all of the instructions carefully before attempting to use it.

TIP

Adjust the volume of the system's announcements by pressing ▲ for louder or ▼ for softer on the base speaker.

NOTE


Press **skip** or **repeat** multiple times to scroll through days, hours, minutes, etc.

NOTE

If you make no entries within two minutes, the system returns to standby.

TURNING THE ANSWERING SYSTEM ON/OFF

- 1) To turn the answering system on, press **answer on/off**. A beep tone will sound and the current outgoing message will play on the base speaker. A beep tone will sound after the outgoing message plays. The message counter LED lights to indicate that the unit is ready to answer calls.




- 2) To turn the answering system off, press **answer on/off** again. A beep tone will sound followed by the announcement "Answer off" and the message counter LED will go out.


SETTING THE CLOCK

The clock on the MPH6929 Answering System starts when power is applied to the base. Follow these steps to set the clock to the correct time:

- 1) Press and hold **clock** until a beep tone sounds.



- 2) Next, press the **skip** or **repeat** key until the correct day is announced. (Numbers zero through six display on the base as each day is announced.)



- 3) Press **clock** again to select the day.

- 4) Press **skip** or **repeat** until you hear the current hour setting. Numbers 1 through 12 display on the base as each hour is announced.
- 5) Press **clock** again to select the correct hour.
- 6) Press **skip** or **repeat** until you hear the current minute setting. The numbers 0 through 59 display on the base as each minute is announced.
- 7) Press **clock** again to select the correct minute. The AM/PM setting is announced.
- 8) The LED displays an *A* or *P*. Press **skip** or **repeat** until you hear the correct AM/PM setting.
- 9) Press **clock** again to end the time/day setting. The MPH6929 announces the time that you have set.

NOTE

You can record up to a 30-second outgoing message.

NOTE

Stand within 12 inches in front of the microphone and speak clearly when recording your outgoing message.

SETTING YOUR OUTGOING MESSAGE (GREETING)

When you receive a call, the answering system automatically plays either a preset message or your own personal outgoing message.

▼ *Preset message*


The following message is prerecorded:

"Hello, no one is available to take your call. Please leave a message after the tone."

To record your own greeting, follow the steps below.

▼ *Recording your personal outgoing message*

- 1) Press and hold **OGM** until you hear a long tone. Start recording your message immediately after you hear the long tone end. The message counter LED will blink, indicating record mode.



- 2) When you are finished recording your message, press **OGM** again. A tone sounds and your message plays back on the base speaker.




*To choose between the prerecorded outgoing message and your personal outgoing message, press **OGM** during outgoing message playback. This switches between the two options.*

▼ *Announce only feature*

The Announce Only feature plays a prerecorded outgoing message or your own personal outgoing message, but it will not allow the caller to leave a message.


Move the **REC TIME** switch to the **ANN** position. The message counter LED displays **A** when the system is on standby.



SELECTING THE MESSAGE RECORD TIME

You can set your answering system to record messages up to one or four minutes long.

One minute option: move the **REC TIME** switch to **1**.



Four minute option: move the **REC TIME** switch to **4**.

SELECTING A PIN CODE

To play your messages from a remote location, you will need to enter a two-digit Personal Identification Number (**PIN**) code (00-99). To select a **PIN**, perform the following steps:


NOTE

If you make no entries within two minutes, the system returns to standby.


NOTE

Press **skip** or **repeat** multiple times to scroll through numbers on the display.

- 1) On the base, press and hold the **pin** button. A beep sounds, and the LED displays **00**.




- 2) To set the first number, press **skip** or **repeat** to scroll from **0** to **9**. When the desired number appears in the display, press **pin**. This selects the first number.



- 3) To set the second number, press **skip** or **repeat** to scroll from **0** to **9**. When the desired number appears in the display, press **pin**. This selects the second number and the entered **PIN** is announced.


SETTING THE TOLL SAVER SWITCH

The ring time/toll saver switch allows you to set the number of rings the caller hears before your answering system plays your outgoing message. You can set the switch to answer after **two** rings or after **four** rings. In the **TS** (Toll Saver) position, the answering system picks up after two rings if you have new messages, and after four rings if there are none. This way, if you call long distance to check your messages, you can hang up after the second ring to avoid billing charges.



USING THE RESET BUTTON

The **RESET** button is used to initialize the base computer.



The **RESET** button can be used if an AC power line disturbance causes the answering system to malfunction and become inoperative. Pressing **RESET** does NOT erase any data stored in your system memory.


HINT

To stop playing your messages at any time, press **play/stop** again.

PLAYING YOUR MESSAGES

The base LED shows the number of total messages on the display. If the display is blinking, then there are new messages waiting for you. The MPH6929 is designed to play your new messages first. After you play your new messages, you can then play your old messages.


- 1) Press **play/stop**. The system announces the number of new and old messages. The time and day each message was received is announced after the message is played, and the message counter LED displays the number of the current message.



- 2) When all new messages have played, a long tone is heard. The message counter LED stops flashing to indicate that all of the new messages have been reviewed.
- 3) After you have reviewed your new messages, you can play your old messages again. Press **play/stop** and follow the instructions above.

REPEATING A MESSAGE

- 1) Press **play/stop** to review your messages. The number of stored messages is announced.



ANSWERING DEVICE USE

USING
THE INTEGRATED ANSWERING DEVICE

NOTE

Pressing **repeat** before two half seconds of the message has played causes the system to scan back one message.


TIP

If you have several messages, press **repeat** until you return to the message you want to replay.

HINT

Each time **skip** is pressed, the system scans forward one message. If you have several messages, press **skip** to find the message you want to play.


- 2) After a message has played for a few seconds, press **repeat** to replay the message.




- 3) Press **play/stop** at any time to stop reviewing your messages and return to standby. The message counter LED shows the total number of message-s still on the system.

SKIPPING A MESSAGE

- 1) Press **play/stop** to review your messages. The number of messages is announced.



- 2) Press **skip** at anytime to skip to the next message.



- 3) Press **play/stop** at any time to stop reviewing your messages and return to standby. The message counter LED shows the total number of messages still on the system.

NOTE

When you press **delete**, you are permanently deleting the message. Once deleted, the message cannot be replayed.

NOTE


The system automatically returns to standby when all messages have played.

NOTE


The voice memo function is completely independent of the outgoing message. It's handy for leaving others a quick message.

DELETING A MESSAGE

1. Press **play/stop** to review your messages.



2. If you decide to delete a message, press **delete** anytime during the message. The system beeps and immediately goes to the next message.




3. After you have played all of your messages, a long tone sounds on the base speaker.

*To delete all messages, press and hold **delete** after reviewing your messages. A tone sounds when all message are cleared.*

MEMO

The Memo function allows the user to record a message on the base.

- 1) Press and hold **memo**. A beep tone sounds and the message counter LED begins to blink.



NOTE

A voice memo message is treated as a typical recorded message and will be added to the stored messages.

NOTE

A recorded conversation is treated as a typical message and will be added to the stored messages.

NOTE


For Remote Answering System On, wait ten rings until the machine answers.

- 2) Release **memo** and speak into the microphone.
- 3) When you have finished, press **memo** or **play/stop** to stop recording. The system returns to standby.

RECORDING A CONVERSATION

You can record up to a 10 minute conversation while you are using your phone.

- 1) During a conversation from the handset, press and hold **memo**. The unit begins recording and two dashes show in the display. A beep that can be heard by both parties sounds every 15 seconds.



- 2) To stop recording, press **memo** or **play/stop** again.

REMOTE ACCESS AWAY FROM HOME

You can operate your answering system from a remote location using any touch-tone telephone. Use this function to check for recorded messages, to play or delete messages, even to record a new outgoing message, and to monitor sounds in the room.

- 1) Call your telephone number.
- 2) During the outgoing message playback, press **#** followed by your **PIN** code. Refer to page 24 for instructions on how to select a **PIN** code.
- 3) The answering system announces the time and day stamp followed by the number of messages stored in memory. Message playback automatically begins.

NOTE

You must enter a command within 15 seconds of entering command waiting mode or the answering system automatically hangs up and returns to standby.

NOTE

The system will only play back messages for four minutes and then it returns to command waiting mode. To continue playing your messages, press # then 2 again within 15 seconds.

- 4) You may continue to listen to your messages, or you may select a command from the following chart:

| FUNCTION | PRESS |
|-----------------------|----------|
| Repeat a Message | # then 1 |
| Playing your Messages | # then 2 |
| Skipping a Message | # then 3 |
| Deleting a Message | # then 4 |
| Stop Message Playback | # then 5 |
| Answering System On | # then 6 |
| Memo Record/Stop | # then 7 |
| OGM Record/Stop | # then 8 |
| Answer System Off | # then 9 |
| Remote Room Monitor | # then * |

- 5) After all of your messages have played, you will hear intermittent beeps indicating that the system is in the command waiting mode. You may enter another command at this time from the chart above.
- 6) When you are finished, hang up to exit the system. The answering system automatically returns to standby.

ANSWERING DEVICE USE



REMOTE ROOM MONITOR

You can call your answering system from any touch-tone phone and monitor sounds in the room where your base is installed.

- 1) Call your telephone number.
- 2) During the outgoing message playback, press **#** followed by your **PIN** code.
- 3) The answering system begins announcing the time and day stamp.
- 4) Press **#** then ***** while the system announces the time and day stamp.
You hear sounds in the room where your phone is installed. After 15 seconds, the answering system returns to the command waiting mode.
- 5) Press **#** then ***** to monitor the room for another 15 seconds. Or, select another remote function. Or, hang up to exit the system. The answering system automatically returns to standby.

NOTE

You cannot use **#** and ***** while the new messages are playing. Press **#** then **5** to stop Message playback first and go to step 4.



TROUBLESHOOTING

YOUR NEW PHONE

QUICK REFERENCE CHART

If your phone is not performing to your expectations, please try these simple steps first.

| PROBLEM | SUGGESTION |
|--|---|
| The charge light won't come on when the handset is placed in the base. | <ul style="list-style-type: none">• Make sure the AC adapter is plugged into the base and wall outlet.• Make sure the handset is properly seated in base.• Make sure the charging contacts on the handset and base are clean. |
| The audio sounds weak and/or scratchy. | <ul style="list-style-type: none">• Make sure that the base antenna is in a vertical position.• Move the handset and/or base to a different location away from metal objects or appliances and try again.• Press chan to help eliminate background noise.• Make sure that you are not too far from the base. |
| Can't make or receive calls. | <ul style="list-style-type: none">• Check both ends of the base telephone line cord.• Make sure the AC adapter is plugged into the base and wall outlet.• Disconnect the AC adapter for a few minutes, then reconnect it.• Place the handset back on the charging cradle for a few seconds. The status LED will blink indicating that the phone has been reset.• Make sure that you are not too far from the base. |

| PROBLEM | SUGGESTION |
|---|--|
| The handset doesn't ring or receive a page. | <ul style="list-style-type: none">• The Nickel-Cadmium battery pack may be weak. Charge the battery on the base unit for 15-20 hours.• The handset may be too far away from the base unit.• Place the base unit away from appliances or metal objects.• Place the handset back on the charging cradle for a few seconds. The status LED will blink indicating that the phone has been reset. |
| The answering system does not work. | <ul style="list-style-type: none">• Make sure the base unit is plugged in.• Make sure the answering system is turned on.• Press RESET after an AC line spike. |
| The answering system does not answer calls. | <ul style="list-style-type: none">• Set the REC TIME switch to either the one minute or four minute option.• The memory may be full. Delete some or all of the saved messages. |
| Messages are incomplete. | <ul style="list-style-type: none">• The incoming messages may be too long. Remind callers to leave a brief message.• The memory may be full. Delete some or all of the saved messages. |
| After a power failure, the outgoing message is deleted. | <ul style="list-style-type: none">• Record your personal outgoing message again. The default messages should remain. |
| No sound on the base unit speaker during call monitoring or message playback. | <ul style="list-style-type: none">• Adjust the speaker volume on the base unit. |



| PROBLEM | SUGGESTION |
|--|--|
| Cannot access remote call-in features from another touch-tone phone. | <ul style="list-style-type: none">• Make sure you're using the correct PIN number.• Make sure that the touch-tone phone you're using can transmit the tone for at least two seconds. If it cannot, you may have to use another phone to access your messages. |



SPECIFICATIONS
OF YOUR NEW PHONE

GENERAL

The MPH6929 complies with FCC Parts 15 and 68.

Frequency control: PLL

Modulation: Frequency Shift Keying

Operating temperature: 0° to 50° C (+32° F to +122° F)

BASE

Transmit Frequency: 925.997 to 927.947 MHz

Receive Frequency: 902.102 to 904.102 (40 channels)

Power requirements: 9V 350 mA (from AC adapter)

Size: 7-3/8 in.(W) x 2 in. (D) x 8-3/4 in. (H)

Weight: Approx. 21.1 oz. (including optional battery)

HANDSET

Transmit Frequency: 902.102 to 904.102 MHz

Receive Frequency: 925.997 to 927.947 (40 channels)

Power requirements: Rechargeable Nickel-Cadmium battery pack

Size (without antenna): 2.28 in. (W) x 1.73 in. (D) x 7.09 in. (H)

Weight: Approx. 8.9 oz. (including battery)

Battery: BT-905

Capacity 600 mAH, 3.6V

Talk mode 7 hours

Standby mode 14 days

Specifications, features, and availability of optional accessories are all subject to change without prior notice.

MEMOREX LIMITED WARRANTY TELEPHONES

We at **MEMOREX** believe you will be pleased with your new Product. Please read this Warranty carefully. Memorex warrants this product to be free from manufacturing defects including original parts and workmanship for a period of one (1) year from the date of original purchase in, and if used in, the United States.

Should you find your unit is not operation properly during the terms of full coverage of this warranty, one (1) year, you should contract your original purchase for an exchange with a valid receipt. If necessary, Memorex will provide one of the following options (at Memorex's discretion), providing the manufacturing defect is verified along with the date of purchase.

- Repair service for one (1) year from date of original purchase at no charge for labor and parts at their authorized warranty service facility, providing the manufacturing defect is verified along with the date of purchase.
- Replacement of defective unit with either a new, refurbished, or equivalent model at no charge for one (1) year from date of original purchase.

This warranty is void if the product is:

- A) Damaged through negligence, abuse, misuse, accident, or acts of God.
- B) Used in commercial application or rentals.
- C) Modified or repaired by anyone other than Memorex or their expressly authorized representative.
- D) Damage resulting from the improper connection to equipment of other manufactures.

This warranty does not cover:

- A) Cost incurred in the shipping of the product to and from the Memorex authorized repair facility listed.
- B) Damage or improper operation caused by the failure to follow the operating instructions provided with the product.
- C) Routine adjustments to the product, which can be performed by the customer as outlined in the owner's manual.
- D) Signal reception problems caused by external factors.
- E) Products not purchased in the United States
- F) Damage to the products used outside the United States.
- G) Damage to audiocassette tapes.
- H) Damage to Compact Discs.

In the event that service is required under this warranty, please contact CUSTOMER SERVICE at 1-800-919-3647 or contact our website at www.memorex.com.

THIS WARRANTY IS NON-TRANSFERABLE AND APPLIES SOLELY TO THE ORIGINAL PURCHASER AND DOES NOT EXTEND TO SUBSEQUENT OWNERS OF THE PRODUCT. ANY APPLICABLE IMPLIED WARRANTIES, INCLUDING THE WARRANTY OF MERCHANTABILITY, ARE LIMITED IN DURATION TO A PERIOD OF THE EXPRESSED WARRANTY AS PROVIDED HEREIN BEGINNING WITH THE DATE OF THE ORIGINAL PURCHASE AT RETAIL AND NO WARRANTIES, WHETHER EXPRESSED OR IMPLIED SHALL APPLY TO THE PRODUCT THEREAFTER. MEMOREX MAKES NO WARRANTY AS TO THE FITNESS OF THE PRODUCT FOR ANY PARTICULAR PURPOSE OR USE.


THE EXTENT OF MEMOREX'S LIABILITY UNDER THIS LIMITED WARRANTY IS THE REPAIR OR REPLACEMENT PROVIDED ABOVE AT THE SOLE DISCRETION OF MEMOREX. IN NO EVENT SHALL MEMOREX'S LIABILITY EXCEED THE PURCHASE PRICE PAID BY THE PURCHASER. UNDER NO CIRCUMSTANCES SHALL MEMCORP BE LIABLE FOR ANY LOSS, DIRECT, INDIRECT, INCIDENTAL, FORESEEN, UNFORESEEN, SPECIAL, OR CONSEQUENTIAL DAMAGE ARISING OUT OF OR IN CONNECTION WITH THE USE OF THIS PRODUCT.

THIS WARRANTY IS VALID ONLY IN THE UNITED STATES. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, HOWEVER, YOU MAY HAVE OTHER RIGHTS WHICH MAY VARY FROM STATE TO STATE. SOME STATES DO NOT ALLOW LIMITATION ON IMPLIED WARRANTIES OR EXCLUSION OF CONSEQUENTIAL DAMAGE, THEREFORE THESE RESTRICTIONS MAY NOT APPLY TO YOU.

©1999, Memorex is a registered trademark of Memorex Telex N.V.

CONTROLS

AND FUNCTIONS



- | | | | |
|----------------------|-----------------------------|---------------------|----------------------|
| 1. Reset | 10. Flash | 22. Delete | 35. Play/Stop |
| 2. Base Ringer | 11. Memory | 23. Repeat | 36. Voice Memo |
| 3. Pulse/Tone | 12. Numeric Keypad | 24. Answer On/Off | 37. Skip |
| 4. DC In 9V Jack | 13. Tone | 25. Microphone | 38. Outgoing message |
| 5. Tel Line Jack | 14. Redial | 26. Set PIN | 39. Base Antenna |
| 6. Handset Antenna | 15. Pause | 27. Set Clock | 40. Record Time |
| 7. Handset Earpiece | 16. Handset Ringer | 28. Page | 41. Ring Time |
| 8. Talk/Batt Low LED | 17. Channel | 29. Base Speaker | |
| 9. Talk | 18. One-Touch Priority Keys | 30. Speaker Button | |
| | 19. Handset Microphone | 31. Speaker LED | |
| | 20. Handset Retainer Clip | 32. Speaker Volume | |
| | 21. Charging Contacts | 33. Status LED | |
| | | 34. Message Counter | |

