




# **MIL-120A**

## **Thin•Twist COAX to 10BASE-T Media Converter**



## **Installation Guide**

This guide includes the following information:

[“Installation” on page 2](#)

[“Link Test” on page 2](#)

[“Disabling Link” on page 2](#)

[“Diagnostic LEDs” on page 3](#)

[“Configuration” on page 3](#)

[“RJ-45 Pinouts” on page 3](#)

[“Legal” on page 4](#)

## Installation

Do the following to install the MIL-120A:

1. Attach a UTP cable from the network to the MIL-120A's RJ-45 port
2. Attach a T-type BNC connector from the network cabling to the BNC connector
3. Connect the power adapter's cord from the power source to the unit

**Note:** Use shielded twisted pair (CAT 5) cabling for CISPR 22 B installation.

## Link Test


The MIL-120A provides a *Link* test function, which is a 10BASE-T standard. The MIL-120A ships with the *Link* function test “enabled”—only pin one jumpered with a jumper block. This allows the LEDs to illuminate when there are links.

## Disabling Link

To disable the *Link* test:

1. Use a Phillips-head screwdriver to remove the four Phillips-type screws located on the sides of the unit
2. Remove the BNC nut and its washer
3. Slide the housing off, over the BNC connector
4. Locate the two-pin *Link* jumper (Figure 1)
5. Place the jumper block onto both pins
6. Reassemble the unit (reverse steps 1 through 3)

**Note:** The MIL-120A operates in a “StarLAN-10” environment when *Link* is disabled. Only the **Power** and **Link** LEDs illuminate.



**Figure 1.**Link and DIP Switch Locations

## Diagnostic LEDs

- COL/TP:** Collisions are occurring on the 10BASE-T network
- RCV/TP** Unit is receiving packets from the 10BASE-T network
- Link:** There is an active connection to a 10BASE-T hub (or another node) when *Link* is enabled
- Power:** Unit is receiving power
- RCV/CX** Unit is receiving packets from the 10BASE2 network
- COL/CX:** Collisions are occurring on the 10BASE2 network

## Configuration

Next to the COAX cable connector, there is a DIP switch that controls the 50 ohm termination resistor (Figure 1). These switches support a variety of configurations. Both switches are shipped in the UP position (default). Other configurations include:

If the MIL-120A is connected to the end of a multi-node segment without a T-connector and terminator, enable the 50 ohm resistor by:

- Placing switch 1: UP and
- Placing switch 2: DOWN

If the MIL-120A is connected to a single-node “without” a T-type connector and terminator on a COAX cable of less than one meter’s length:

- Place both switches (1 and 2) in the DOWN position

**Note:** For this configuration, you do not need a 50 ohm terminator on the COAX segment of the MIL-120A's BNC connector.

## RJ-45 Pinouts

### MDI

- Pin 1=TX+
- Pin 2=TX-
- Pin 3=RX+
- Pin 6=RX-




Figure 2. RJ-45 Pinouts

Follow these guidelines when connecting the 10BASE-T Port:

- For a Hub or a Repeater, use a straight-through cable (where the pins are connected 1 to 1, 2 to 2, 3 to 3, and 6 to 6)
- For a Workstation/PC port, use a swap cable (where the pins are connected 1 to 3, 2 to 6, 3 to 1, 6 to 2)

## Legal

### Regulatory Approvals

- FCC Class A
- UL 1950
- CSA 22 No. 950
- EN60950
- CE
  - EN55022 Class B
  - EN50082-1

### Canadian EMI Notice

This Class A digital apparatus meets all the requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe A respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

### European Notice

Products with the CE Marking comply with both the EMC Directive (89/336/EEC) and the Low Voltage Directive (73/23/EEC) issued by the commission of the European Community. Compliance with these directives implies conformity to the following European Norms:

- EN55022 (CISPR 22) - Radio Frequency Interference
- EN50082-1 (IEC801-2, IEC801-3, IEC801-4) - Electromagnetic Immunity
- EN60950 (IEC950) - Product Safety

### Five-Year Limited Warranty

Digi International warrants to the original consumer or purchaser that each of its products, and all components thereof, will be free from defects in material and/or workmanship for a period of five years from the original factory shipment date. Any warranty hereunder is extended to the original consumer or purchaser and is not assignable.

Digi makes no express or implied warranties including, but not limited to, any implied warranty of merchantability or fitness for a particular purpose, except as expressly set forth in this warranty. In no event shall Digi be liable for incidental or consequential damages, costs, or expenses arising out of or in connection with the performance of the product delivered hereunder. Digi will in no case cover damages arising out of the product being used in a negligent fashion or manner.

### To Contact Digi

For prompt response when calling for service information, have the following information ready:

- Product serial number and rev.
- Date of purchase
- Vendor or place of purchase

Reach Digi Technical Support at 408/744-2751  
Or E-mail at "sun-tech@dgii.com"

Address: 1299 Orleans Drive  
Sunnyvale, CA 94089

Voice: 408/744-2775

Fax: 408/744-2793

E-mail: info@dgii.com