


# INVERTEC V350-PRO

For use with machine code numbers 10873, 10874, 10876

## Safety Depends on You

Lincoln arc welding and cutting equipment is designed and built with safety in mind. However, your overall safety can be increased by proper installation . . . and thoughtful operation on your part. **DO NOT INSTALL, OPERATE OR REPAIR THIS EQUIPMENT WITHOUT READING THIS MANUAL AND THE SAFETY PRECAUTIONS CONTAINED THROUGHOUT.** And, most importantly, think before you act and be careful.



## SERVICE MANUAL



Copyright © 2002 Lincoln Global Inc.

• World's Leader in Welding and Cutting Products •

• Sales and Service through Subsidiaries and Distributors Worldwide •

Cleveland, Ohio 44117-1199 U.S.A. TEL: 216.481.8100 FAX: 216.486.1751 WEB SITE: www.lincolnelectric.com

## ⚠ WARNING



### CALIFORNIA PROPOSITION 65 WARNINGS



Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

The Above For Diesel Engines

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

The Above For Gasoline Engines

**ARC WELDING CAN BE HAZARDOUS. PROTECT YOURSELF AND OTHERS FROM POSSIBLE SERIOUS INJURY OR DEATH. KEEP CHILDREN AWAY. PACEMAKER WEARERS SHOULD CONSULT WITH THEIR DOCTOR BEFORE OPERATING.**

Read and understand the following safety highlights. For additional safety information, it is strongly recommended that you purchase a copy of "Safety in Welding & Cutting - ANSI Standard Z49.1" from the American Welding Society, P.O. Box 351040, Miami, Florida 33135 or CSA Standard W117.2-1974. A Free copy of "Arc Welding Safety" booklet E205 is available from the Lincoln Electric Company, 22801 St. Clair Avenue, Cleveland, Ohio 44117-1199.

**BE SURE THAT ALL INSTALLATION, OPERATION, MAINTENANCE AND REPAIR PROCEDURES ARE PERFORMED ONLY BY QUALIFIED INDIVIDUALS.**



### FOR ENGINE powered equipment.

1.a. Turn the engine off before troubleshooting and maintenance work unless the maintenance work requires it to be running.



1.b. Operate engines in open, well-ventilated areas or vent the engine exhaust fumes outdoors.



1.c. Do not add the fuel near an open flame welding arc or when the engine is running. Stop the engine and allow it to cool before refueling to prevent spilled fuel from vaporizing on contact with hot engine parts and igniting. Do not spill fuel when filling tank. If fuel is spilled, wipe it up and do not start engine until fumes have been eliminated.

1.d. Keep all equipment safety guards, covers and devices in position and in good repair. Keep hands, hair, clothing and tools away from V-belts, gears, fans and all other moving parts when starting, operating or repairing equipment.

1.e. In some cases it may be necessary to remove safety guards to perform required maintenance. Remove guards only when necessary and replace them when the maintenance requiring their removal is complete. Always use the greatest care when working near moving parts.




1.f. Do not put your hands near the engine fan. Do not attempt to override the governor or idler by pushing on the throttle control rods while the engine is running.

1.g. To prevent accidentally starting gasoline engines while turning the engine or welding generator during maintenance work, disconnect the spark plug wires, distributor cap or magneto wire as appropriate.



1.h. To avoid scalding, do not remove the radiator pressure cap when the engine is hot.



### ELECTRIC AND MAGNETIC FIELDS may be dangerous

2.a. Electric current flowing through any conductor causes localized Electric and Magnetic Fields (EMF). Welding current creates EMF fields around welding cables and welding machines

2.b. EMF fields may interfere with some pacemakers, and welders having a pacemaker should consult their physician before welding.

2.c. Exposure to EMF fields in welding may have other health effects which are now not known.

2.d. All welders should use the following procedures in order to minimize exposure to EMF fields from the welding circuit:

2.d.1. Route the electrode and work cables together - Secure them with tape when possible.

2.d.2. Never coil the electrode lead around your body.

2.d.3. Do not place your body between the electrode and work cables. If the electrode cable is on your right side, the work cable should also be on your right side.

2.d.4. Connect the work cable to the workpiece as close as possible to the area being welded.

2.d.5. Do not work next to welding power source.

Mar '95



### ELECTRIC SHOCK can kill.

- 3.a. The electrode and work (or ground) circuits are electrically "hot" when the welder is on. Do not touch these "hot" parts with your bare skin or wet clothing. Wear dry, hole-free gloves to insulate hands.
- 3.b. Insulate yourself from work and ground using dry insulation. Make certain the insulation is large enough to cover your full area of physical contact with work and ground.
- In addition to the normal safety precautions, if welding must be performed under electrically hazardous conditions (in damp locations or while wearing wet clothing; on metal structures such as floors, gratings or scaffolds; when in cramped positions such as sitting, kneeling or lying, if there is a high risk of unavoidable or accidental contact with the workpiece or ground) use the following equipment:**
- Semiautomatic DC Constant Voltage (Wire) Welder.
  - DC Manual (Stick) Welder.
  - AC Welder with Reduced Voltage Control.
- 3.c. In semiautomatic or automatic wire welding, the electrode, electrode reel, welding head, nozzle or semiautomatic welding gun are also electrically "hot".
- 3.d. Always be sure the work cable makes a good electrical connection with the metal being welded. The connection should be as close as possible to the area being welded.
- 3.e. Ground the work or metal to be welded to a good electrical (earth) ground.
- 3.f. Maintain the electrode holder, work clamp, welding cable and welding machine in good, safe operating condition. Replace damaged insulation.
- 3.g. Never dip the electrode in water for cooling.
- 3.h. Never simultaneously touch electrically "hot" parts of electrode holders connected to two welders because voltage between the two can be the total of the open circuit voltage of both welders.
- 3.i. When working above floor level, use a safety belt to protect yourself from a fall should you get a shock.
- 3.j. Also see Items 6.c. and 8.



### ARC RAYS can burn.


- 4.a. Use a shield with the proper filter and cover plates to protect your eyes from sparks and the rays of the arc when welding or observing open arc welding. Headshield and filter lens should conform to ANSI Z87.1 standards.
- 4.b. Use suitable clothing made from durable flame-resistant material to protect your skin and that of your helpers from the arc rays.
- 4.c. Protect other nearby personnel with suitable, non-flammable screening and/or warn them not to watch the arc nor expose themselves to the arc rays or to hot spatter or metal.



### FUMES AND GASES can be dangerous.

- 5.a. Welding may produce fumes and gases hazardous to health. Avoid breathing these fumes and gases. When welding, keep your head out of the fume. Use enough ventilation and/or exhaust at the arc to keep fumes and gases away from the breathing zone. **When welding with electrodes which require special ventilation such as stainless or hard facing (see instructions on container or MSDS) or on lead or cadmium plated steel and other metals or coatings which produce highly toxic fumes, keep exposure as low as possible and below Threshold Limit Values (TLV) using local exhaust or mechanical ventilation. In confined spaces or in some circumstances, outdoors, a respirator may be required. Additional precautions are also required when welding on galvanized steel.**
- 5.b. Do not weld in locations near chlorinated hydrocarbon vapors coming from degreasing, cleaning or spraying operations. The heat and rays of the arc can react with solvent vapors to form phosgene, a highly toxic gas, and other irritating products.
- 5.c. Shielding gases used for arc welding can displace air and cause injury or death. Always use enough ventilation, especially in confined areas, to insure breathing air is safe.
- 5.d. Read and understand the manufacturer's instructions for this equipment and the consumables to be used, including the material safety data sheet (MSDS) and follow your employer's safety practices. MSDS forms are available from your welding distributor or from the manufacturer.
- 5.e. Also see item 1.b.

Mar '95



## WELDING SPARKS can cause fire or explosion.

6.a. Remove fire hazards from the welding area. If this is not possible, cover them to prevent the welding sparks from starting a fire.

Remember that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas. Avoid welding near hydraulic lines. Have a fire extinguisher readily available.

6.b. Where compressed gases are to be used at the job site, special precautions should be used to prevent hazardous situations. Refer to "Safety in Welding and Cutting" (ANSI Standard Z49.1) and the operating information for the equipment being used.

6.c. When not welding, make certain no part of the electrode circuit is touching the work or ground. Accidental contact can cause overheating and create a fire hazard.


6.d. Do not heat, cut or weld tanks, drums or containers until the proper steps have been taken to insure that such procedures will not cause flammable or toxic vapors from substances inside. They can cause an explosion even though they have been "cleaned". For information, purchase "Recommended Safe Practices for the Preparation for Welding and Cutting of Containers and Piping That Have Held Hazardous Substances", AWS F4.1 from the American Welding Society (see address above).

6.e. Vent hollow castings or containers before heating, cutting or welding. They may explode.

6.f. Sparks and spatter are thrown from the welding arc. Wear oil free protective garments such as leather gloves, heavy shirt, cuffless trousers, high shoes and a cap over your hair. Wear ear plugs when welding out of position or in confined places. Always wear safety glasses with side shields when in a welding area.

6.g. Connect the work cable to the work as close to the welding area as practical. Work cables connected to the building framework or other locations away from the welding area increase the possibility of the welding current passing through lifting chains, crane cables or other alternate circuits. This can create fire hazards or overheat lifting chains or cables until they fail.

6.h. Also see item 1.c.



## CYLINDER may explode if damaged.

7.a. Use only compressed gas cylinders containing the correct shielding gas for the process used and properly operating regulators designed for the gas and pressure used. All hoses, fittings, etc. should be suitable for the application and maintained in good condition.

7.b. Always keep cylinders in an upright position securely chained to an undercarriage or fixed support.

7.c. Cylinders should be located:

- Away from areas where they may be struck or subjected to physical damage.

- A safe distance from arc welding or cutting operations and any other source of heat, sparks, or flame.

7.d. Never allow the electrode, electrode holder or any other electrically "hot" parts to touch a cylinder.

7.e. Keep your head and face away from the cylinder valve outlet when opening the cylinder valve.

7.f. Valve protection caps should always be in place and hand tight except when the cylinder is in use or connected for use.

7.g. Read and follow the instructions on compressed gas cylinders, associated equipment, and CGA publication P-1, "Precautions for Safe Handling of Compressed Gases in Cylinders," available from the Compressed Gas Association 1235 Jefferson Davis Highway, Arlington, VA 22202.



## FOR ELECTRICALLY powered equipment.

8.a. Turn off input power using the disconnect switch at the fuse box before working on the equipment.

8.b. Install equipment in accordance with the U.S. National Electrical Code, all local codes and the manufacturer's recommendations.

8.c. Ground the equipment in accordance with the U.S. National Electrical Code and the manufacturer's recommendations.

Mar '95

V350-PRO

**LINCOLN**<sup>®</sup>  
**ELECTRIC**

## PRÉCAUTIONS DE SÛRETÉ

Pour votre propre protection lire et observer toutes les instructions et les précautions de sûreté spécifiques qui paraissent dans ce manuel aussi bien que les précautions de sûreté générales suivantes:

### Sûreté Pour Soudage A L'Arc

1. Protégez-vous contre la secousse électrique:
  - a. Les circuits à l'électrode et à la pièce sont sous tension quand la machine à souder est en marche. Éviter toujours tout contact entre les parties sous tension et la peau nue ou les vêtements mouillés. Porter des gants secs et sans trous pour isoler les mains.
  - b. Faire très attention de bien s'isoler de la masse quand on soude dans des endroits humides, ou sur un plancher métallique ou des grilles métalliques, principalement dans les positions assis ou couché pour lesquelles une grande partie du corps peut être en contact avec la masse.
  - c. Maintenir le porte-électrode, la pince de masse, le câble de soudage et la machine à souder en bon et sûr état de fonctionnement.
  - d. Ne jamais plonger le porte-électrode dans l'eau pour le refroidir.
  - e. Ne jamais toucher simultanément les parties sous tension des porte-électrodes connectés à deux machines à souder parce que la tension entre les deux pinces peut être le total de la tension à vide des deux machines.
  - f. Si on utilise la machine à souder comme une source de courant pour soudage semi-automatique, ces précautions pour le porte-électrode s'appliquent aussi au pistolet de soudage.
2. Dans le cas de travail au dessus du niveau du sol, se protéger contre les chutes dans le cas où on recoit un choc. Ne jamais enrouler le câble-électrode autour de n'importe quelle partie du corps.
3. Un coup d'arc peut être plus sévère qu'un coup de soleil, donc:
  - a. Utiliser un bon masque avec un verre filtrant approprié ainsi qu'un verre blanc afin de se protéger les yeux du rayonnement de l'arc et des projections quand on soude ou quand on regarde l'arc.
  - b. Porter des vêtements convenables afin de protéger la peau de soudeur et des aides contre le rayonnement de l'arc.
  - c. Protéger l'autre personnel travaillant à proximité au soudage à l'aide d'écrans appropriés et non-inflammables.
4. Des gouttes de laitier en fusion sont émises de l'arc de soudage. Se protéger avec des vêtements de protection libres de l'huile, tels que les gants en cuir, chemise épaisse, pantalons sans revers, et chaussures montantes.
5. Toujours porter des lunettes de sécurité dans la zone de soudage. Utiliser des lunettes avec écrans latéraux dans les zones où l'on pique le laitier.

6. Eloigner les matériaux inflammables ou les recouvrir afin de prévenir tout risque d'incendie dû aux étincelles.
7. Quand on ne soude pas, poser la pince à un endroit isolé de la masse. Un court-circuit accidentel peut provoquer un échauffement et un risque d'incendie.
8. S'assurer que la masse est connectée le plus près possible de la zone de travail qu'il est pratique de le faire. Si on place la masse sur la charpente de la construction ou d'autres endroits éloignés de la zone de travail, on augmente le risque de voir passer le courant de soudage par les chaînes de levage, câbles de grue, ou autres circuits. Cela peut provoquer des risques d'incendie ou d'échauffement des chaînes et des câbles jusqu'à ce qu'ils se rompent.
9. Assurer une ventilation suffisante dans la zone de soudage. Ceci est particulièrement important pour le soudage de tôles galvanisées plombées, ou cadmiées ou tout autre métal qui produit des fumées toxiques.
10. Ne pas souder en présence de vapeurs de chlore provenant d'opérations de dégraissage, nettoyage ou pistilage. La chaleur ou les rayons de l'arc peuvent réagir avec les vapeurs du solvant pour produire du phosgène (gas fortement toxique) ou autres produits irritants.
11. Pour obtenir de plus amples renseignements sur la sûreté, voir le code "Code for safety in welding and cutting" CSA Standard W 117.2-1974.

## PRÉCAUTIONS DE SÛRETÉ POUR LES MACHINES À SOUDER À TRANSFORMATEUR ET À REDRESSEUR

1. Relier à la terre le châssis du poste conformément au code de l'électricité et aux recommandations du fabricant. Le dispositif de montage ou la pièce à souder doit être branché à une bonne mise à la terre.
2. Autant que possible, l'installation et l'entretien du poste seront effectués par un électricien qualifié.
3. Avant de faire des travaux à l'intérieur de poste, la débrancher à l'interrupteur à la boîte de fusibles.
4. Garder tous les couvercles et dispositifs de sûreté à leur place.

Mar. '93

V350-PRO

**LINCOLN**<sup>®</sup>  
**ELECTRIC**

# MASTER TABLE OF CONTENTS FOR ALL SECTIONS

[RETURN TO MAIN INDEX](#)

Page

<b>Safety</b> .....	i-iv
<b>Installation</b> .....	<b>Section A</b>
<b>Operation</b> .....	<b>Section B</b>
<b>Accessories</b> .....	<b>Section C</b>
<b>Maintenance</b> .....	<b>Section D</b>
<b>Theory of Operation</b> .....	<b>Section E</b>
<b>Troubleshooting and Repair</b> .....	<b>Section F</b>
How to Use Troubleshooting Guide .....	F-2
Troubleshooting Guide .....	F-4
Test Procedures .....	F-15
Replacement Procedures .....	F-51
<b>Electrical Diagrams</b> .....	<b>Section G</b>
<b>Parts Manual</b> .....	<b>P-401 Series</b>

V350-PRO



# TABLE OF CONTENTS - INSTALLATION SECTION -

---

## Installation

---

Technical Specifications .....	A-2
Safety Precautions.....	A-3
Stacking.....	A-3
Tilting .....	A-3
Input Grounding Connections .....	A-3
Power Cord Connection .....	A-3
Connection of Wire Feeders.....	A-3/A-4
Cobramatic Connection Instructions.....	A-4
Parallel Operation .....	A-5

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

V350-PRO





**TECHNICAL SPECIFICATIONS - INVERTEC V350-PRO**

**INPUT AC VOLTAGE & DC OUTPUT**

Product Name	Ordering Information	Input AC Voltage	Rated DC Output Amps/Volt /Duty Cycle	Output Range (continuous)	Weight with Cord	Dimensions HxWxD Voltage	Open Circuit
Invertec V350-PRO 60/50 Hz	K1728-5 Construction	200	350A / 34V / 60%	AMPS 5-425	Construction (81.0 lbs.) (36.7 kg.)	14.8" x 13.3" x 27.8"* (373 x 338 x 706*)mm	80 VDC
	K1728-6 Factory	208-230/380-400/415-460/575	300A / 32V /100%		Factory (81.0 lbs.) (36.7 kg.)		
	K1728-7 Advanced Process	1 & 3 Phase 60/50 Hz	Advanced Process (81.5 lbs.) (37.0 kg.)				

\* Overall Length Including Handle, 27.8" (706mm)

**V350-PRO INPUT CURRENT**

Recommended Fuse Sizes Base On The U.S. National Electrical Code And Maximum Machine Outputs

Input 50/60 Hz		Output		Recommended		Notes
Voltage	Phases	300Amps @ 32Volts(100%)	350Amps @ 34Volts(60%)	Line Cord AWG	Fuse size	
200	1	Not Recommended	Not Recommended		---	Note 1
208	1	76	94	2	125A	Note 2
230	1	69	85	4	125A	Note 2
380	1	Not Recommended	Not Recommended		---	Note 1
400	1	Not Recommended	Not Recommended	---	---	Note 1
415	1	41	64	6	80A	Note 2
460	1	36	42	8	70A	
575	1	31	37	8	50A	
200	3	41	50	8	80A	Note 2
208	3	39	50	6	80A	Note 2
230	3	36	42	8	70A	
380	3	23	28	8	50A	
400	3	22	27	8	50A	
415	3	22	26	8	50A	
460	3	19	23	8	50A	
575	3	16	18	8	35A	

Note 1. Not rated is indicated by 4-x's in the box on the rating plate.

Note 2. When operating on these inputs, the line cord should be changed to an input conductor of 6 AWG or larger.

**OUTPUT CABLES, CONNECTIONS AND LIMITATIONS**

Select The output cable size based upon the following chart.

Cable sizes for Combined Length of Electrode and Work Cable (Copper) 75C rated:

DUTY CYCLE	CURRENT	LENGTH UP TO 200FT.(61m)	200-250 FT. (61-76m)
100%	300	1/0	1/0
60%	350	1/0	2/0

V350-PRO



Return to Section TOC | Return to Master TOC



# INSTALLATION

## SAFETY PRECAUTIONS

### ⚠ WARNING



**ELECTRIC SHOCK** can kill.

- **TURN THE INPUT POWER OFF AT THE DISCONNECT SWITCH BEFORE ATTEMPTING TO CONNECT OR DISCONNECT INPUT POWER LINES, OUTPUT CABLES, OR CONTROL CABLES.**
- Only qualified personnel should perform this installation.
- Connect the green/yellow lead of the power cord to ground per U.S.National Electrical Code.

## SELECT SUITABLE LOCATION

The Invertec V350-PRO will operate in harsh environments. Even so, it is important that simple preventative measures are followed in order to assure long life and reliable operation.

- The machine must be located where there is free circulation of clean air such that air movement in the back, out the sides and bottom will not be restricted.
- Dirt and dust that can be drawn into the machine should be kept to a minimum. Failure to observe these precautions can result in excessive operating temperatures and nuisance shutdown.
- Keep machine dry. Shelter from rain and snow. Do not place on wet ground or in puddles.
- **DO NOT MOUNT OVER COMBUSTIBLE SURFACES.**

### ⚠ CAUTION

Where there is a combustible surface directly under stationary or fixed electrical equipment, that surface shall be covered with a steel plate at least .06" (1.6mm) thick, which shall extend not less than 5.90" (150mm) beyond the equipment on all sides.

## STACKING

V350-PRO cannot be stacked.

## TILTING

Place the machine directly on a secure, level surface or on a recommended undercarriage. The machine may topple over if this procedure is not followed.

## INPUT AND GROUNDING CONNECTIONS

- Only a qualified electrician should connect the Invertec V350-PRO. Installation should be made in accordance with the appropriate National Electrical Code, all local codes and the information detailed below.
- When received directly from the factory, multiple voltage machines are internally connected for 460VAC. If 460VAC is the desired input, then the machine may be connected to the power system without any setup required inside the machine.


- Initial 200VAC - 415VAC and 575VAC operation will require an Input voltage panel setup.
- Open the access panel on the rear of the machine.
- For 200 or 230: Position the large switch to 200-230.  
For higher voltages: Position the large switch to 380-575.
- Move the "A" lead to the appropriate terminal.

## POWER CORD CONNECTION

A 10 ft. power cord is provided and wired into the machine. Follow the power cord connection instructions.

### ⚠ CAUTION

**Incorrect connection may result in equipment damage.**



## Single Phase Input

Connect green lead to ground per National Electrical Code.

Connect black and white leads to power.

Wrap red lead with tape to provide 600V insulation.

## Three Phase Input

Connect green lead to ground per National Electric Code.

Connect black, red and white leads to power.

## CONNECTIONS OF WIRE FEEDERS TO V350-PRO

### LN-25 Connection Instructions

(Factory, Construction & Advanced Process versions can be connected. **-Not recommended for Pulse Welding with the Advanced Process Model**).

- Turn the Invertec power switch "off".
- Connect the electrode cable to the output terminal of polarity required by electrode. Connect the work lead to the other terminal.
- LN-25 with Remote Control options can be used with the Factory Advanced Process version of the V350. The 6-Pin (K444-1) and 14-pin (K444-2) remotes can be connected directly to the 6-pin & 14-pin MS-style connectors. The 42 Volt Remote Voltage and Output Control (K624-1) Kit can be connected to the V350's 14-pin MS-style connector using Remote Control Cable assembly K627- [ ]. LN-25s with a K431-1 remote kit can be connected to the V350's 14-pin MS-style connector using a K432 cable and K876 adapter. (See connection diagram S19899). Or the K432 cable could be modified with a K867 Universal Adapter Plug (See connection diagram S19405) to connect it to the V350's 14-pin MS-style connector.

V350-PRO



# INSTALLATION

## LN-7 Connection Instructions

An LN-7 can only be used with the "Factory" & "Advanced Process" versions of the 350-Pro.

- Turn the Invertec power switch "off".
- Connect the K480 control cable from the LN-7 to the 14-pin MS-style connector.
- Connect the electrode cable to the output terminal of the polarity required by electrode. Connect the work lead to the other terminal.
- Set the meter polarity switch on the front of the Invertec to coincide with wire feeder polarity used. The wire feeder will now display the welding voltage.
- If K480 is not available, see connection diagram S19404 for modification of K291 or K404 LN-7 input cable with K867 Universal Adapter Plug.
- If a remote control such as K857 is to be used with the LN-7, the remote can be connected directly to the 6-pin MS-style connector on the front of the Invertec or use a K864 adapter to connect the LN-7 and the remote to the 14-pin MS-style connector. (See connection diagram S19901)

## LN-10 Connection Instructions

An LN-10 can only be used with the "Factory" & "Advanced Process" versions of the 350-Pro.

- Turn the Invertec power switch "off"
- Connect the K1505 control cable from the LN-10 to the 14-pin MS-style connector.
- Connect the electrode cable to the output terminal of polarity required by the electrode. Connect the work lead to the other terminal.
- Set the meter polarity switch on the front of the Invertec to coincide with wire feeder polarity used.
- See the LN-10 manual for details on accessing Control DIP Switch

## LN-742 Connection Instructions

An LN-742 can only be used with the "Factory" & "Advanced Process" versions of the 350-Pro.

- Turn the Invertec power switch "off"
- Either a K591 or a K593 Input cable assembly is required to connect the LN-742 to the Invertec.
- Connect the control cable from the LN-742 to the 14-pin MS-style connector.
- Connect the electrode cable to the output terminal of the polarity required by electrode. Connect the work lead to the other terminal.
- Set the meter polarity switch on the front of the Invertec to coincide with wire feeder polarity used. The wire feeder will now display the welding voltage.
- If a remote control such as K857 is to be used with the LN-742, the remote can be connected directly to the 6-pin MS-style connector on the front of the Invertec or use a K864 adapter to connect the LN-742 and the remote to the 14-pin MS-style connector.

## Cobramatic Connection Instructions

A Cobramatic can only be used with the "Factory" & "Advanced Process" versions of the 350-Pro.

- Turn the Invertec power switch "off"
- Connect the control cable from the Cobramatic to the 14-pin MS-style connector.
- Connect the electrode cable to the output terminal of the polarity required by electrode. Connect the work lead to the other terminal.
- Set the meter polarity switch on the front of the Invertec to coincide with wire feeder polarity used.
- If a remote control such as K857 is to be used with the Cobramatic, the remote can be connected directly to the 6-pin MS-style connector on the front of the Invertec or use a K864 adapter to connect the cobramatic and the remote to the 14-pin MS-style connector.

## TIG Module K930-2

The TIG Module connects to the Factory and Advanced Process V350-Pro versions with a K936-1 (9-14 pin) control cable. Connect the K936-1 to the MS-style connector.

The TIG Module can also be used with the V350-Pro Construction version. A K936-4 control cable is required to supply 115VAC to the TIG Module from an external 115VAC supply.


## General Instructions for Connection of Wire Feeders to V350-Pro

Wire feeders other than those listed above may be used provided that the auxiliary power supply rating of the V350-Pro is not exceeded. K867 universal adapter plug is required. See connection diagram S24985 on page F-4.

## REMOTE CONTROL OF INVERTEC

Remote Control K857, Hand Amptrol K963 and Foot Amptrol K870.

## UNDERCARRIAGE MOUNTINGS



V350-PRO





Return to Section TOC  
Return to Master TOC  
Return to Section TOC  
Return to Master TOC  
Return to Section TOC  
Return to Master TOC  
Return to Section TOC  
Return to Master TOC

V350-PRO



# TABLE OF CONTENTS - OPERATION SECTION -

---

<b>Operation</b> .....	<b>Section B</b>
Safety Precautions.....	B-2
General Description.....	B-2
Duty Cycle.....	B-2
Operational Features and Controls .....	B-2
Weld Mode Select.....	B-3
CC-Stick Soft.....	B-3
CC-Stick Crisp.....	B-3
TIG GTAW .....	B-4
CV-Wire.....	B-4
CV-Innersheild.....	B-4
Advanced Process Panel.....	B-5
Controls .....	B-6
Electrode Material.....	B-6
Hot Start & Arc Control.....	B-6
Weld Mode Details.....	B-7
Pulse Programs .....	B-8
Lower Case Front .....	B-9
CV Modes.....	B-9
TIG Mode .....	B-9
CC-Stick Modes.....	B-9
Types of Remote Output Control.....	B-9
Types of Remote Weld Terminal Control .....	B-9
Auxiliary Power .....	B-10
Limitations.....	B-10
Recommended Processes.....	B-10
Descriptions of Special Welding Processes Available on this Machine.....	B-11

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

V350-PRO



## SAFETY PRECAUTIONS

### ⚠ WARNING




#### **ELECTRIC SHOCK can kill.**

- Do not touch electrically live parts or electrode with skin or wet clothing.
- Insulate yourself from work and ground.
- Always wear dry insulating gloves.



#### **FUMES AND GASES can be dangerous.**

- Keep your head out of fumes.
- Use ventilation or exhaust to remove fumes from breathing zone.



#### **WELDING SPARKS can cause fire or explosion.**

- Keep flammable material away.
- Do not weld on closed containers.



#### **ARC RAYS can burn eyes and skin.**

- Wear eye, ear and body protection.

See additional warning information at front of this operators manual.

## GENERAL DESCRIPTION

The Invertec V350-Pro offers multi-process CV, CC, and DC welding and is rated 350 amps, 34 volts at a 60% duty cycle. The V350-Pro is available in either a Construction version (no wire feeder connection and auxiliary power) and a Factory & Advanced Process versions (includes wire feeder connection and related power)

- The factory model is the construction model with the addition of the Wire Feeder/Remote Adapter.
- In this form, the V350-Pro provides the hardware to power and connect to 24, 42 or 115 VAC wire feeders.
- The advanced process model is the factory model with an advanced process panel installed in place of the standard mode panel. In this form, the V350-Pro provides access to the 5 standard weld modes (Stick Soft, Stick Crisp, TIG, CV-Wire, CV-Innershield), gouge, constant power and pulse MIG weld modes.

## DUTY CYCLE

The V350-Pro is rated at 350 amps, 60% duty cycle (based on a 10 minute cycle). It is also rated at 300 amps, 100% duty cycle.

## OPERATIONAL FEATURES and CONTROLS:

### UPPER CONTROL PANEL

#### 1. AMPS Meter

- Prior to STICK or TIG operation (current flow), the meter displays preset current value (+/- 2 amps or +/- 3%, whichever is greater).
- Prior to CV operation, the meter displays four dashes indicating non-presetable AMPS.
- During welding, this meter displays actual average amps.
- After welding, the meter holds the actual current value for 5 seconds. Output adjustment while in the "hold" period results in the "prior to operation" characteristics stated above. The displays blink indicating that the machine is in the "Hold" period.

#### 2. VOLT METER

- Prior to CV operation (current flow), the meter displays desired preset voltage value (+/- .5V).
- Prior to STICK or TIG operation, the meter displays the Open Circuit Voltage of the Power Source or four dashes if the output has not been turned on.
- During welding, this meter displays actual average volts.
- After welding, the meter holds the actual voltage value for 5 seconds. The displays blink indicating that the machine is in the "Hold" period.
- Output adjustment while in the "hold" period results in the "prior to operation" characteristics stated above.

#### 3. OUTPUT CONTROL

- Output control is conducted via a single turn potentiometer.
- Adjustment is indicated by the meters as stated above.
- When in TIG modes, this control sets the maximum welding current. Full depression of a foot or hand Amptrol results in the preset level of current.

#### 4. WELD TERMINALS-REMOTE / ON

- Two status lights indicate the location of trigger control as determined by the "WELD TERMINALS" push button.
- If trigger control is local "weld terminals on", the ON display will be lit.
- If trigger control is remote "weld terminals remotely controlled", the REMOTE display will be lit.

V350-PRO





# OPERATION

- The unit will power up in "pre-determined preferred" trigger modes.

STICK = ON

CV = REMOTE

TIG = REMOTE if remote output controls are attached to the machine.

TIG = 0N if remote output controls are not attached to the machine.

For all versions, these trigger modes can be over-riden (switched) with the WELD TERMINALS push button. When changed, the unit will power up in the configuration it was in when it was last powered down.

## 5. THERMAL

- This status light indicates when the power source has been driven into thermal overload. If the output terminals were "ON", the "ON" light will blink indicating that the output will be turned back on once the unit cools down to an acceptable temperature level. If the unit was operating in the "REMOTE" mode, the trigger will need to be opened before or after the thermal has cleared and closed after the machine has cooled down to an acceptable temperature to establish output.

## 6. CONTROL-REMOTE / LOCAL

- Two status lights indicate the location of output control as pre-determined by the power sources auto-configure system.
- The LOCAL display will be lit when control is at the power source.
- The REMOTE display will be lit when a remote pot/control is detected.

These Output Control configurations can be overridden (switched) with the CONTROL push button. When changed, the unit will power up in the configuration it was in when it was last powered down.

## 7. WELD MODE SELECT - FACTORY AND CONSTRUCTION (See Figure B.1)

The Mode Control button selects from the following welding modes.

**CC-STICK SOFT:** The Stick Soft process features continuous control ranging from 5 to 425 amps. This mode was intended for most SMAW applications, and Arc Gouging.


- Arc Gouging: Setting the output of the Stick Soft mode to 425 amps will enable the arc-gouging mode. The actual output current will depend on the size of carbon used. The recommended maximum size carbon is 5/16".
- The Hot Start control regulates the starting current at arc initiation. Hot Start can be adjusted from minimum (0), with no additional current added at arc start, to maximum (10), with double the preset current or 425 amps (max of machine) added for the first second after arc initiation.
- The Arc Control regulates the Arc Force to adjust the short circuit current. The minimum setting (-10) will produce a "soft" arc and will produce minimal spatter. The maximum setting (+10) will produce a "crisp" arc and will minimize electrode sticking.

**CC-STICK CRISP:**The Stick Crisp mode features continuous control from 5 to 425 amps. This mode was intended primarily for pipe welding applications.

- The Hot Start control regulates the starting current at arc initiation. Hot Start can adjust starting current up or down by 25% of the preset value. The recommended setting for Hot Start is 5 where the initial current is equal to the preset current.

### Hidden Middle Control Panel – Mode Panel

#### FIGURE B.1.



V350-PRO



Return to Section TOC  
 Return to Master TOC  
 Return to Section TOC  
 Return to Master TOC  
 Return to Section TOC  
 Return to Master TOC  
 Return to Section TOC  
 Return to Master TOC



- The Arc Control regulates the Arc Force to adjust the short circuit current. The minimum setting (-10) will produce a "soft" arc and will produce minimal spatter. The maximum setting (+10) will produce a "crisp" arc and will minimize electrode sticking.

**TIG GTAW:** The TIG mode features continuous control from 5 to 425 amps. The TIG mode can be run in either the TIG touch start or high frequency (optional equipment required) assisted start mode.

- The Hot Start control selects the starting mode desired. A setting of less than 5, the TIG lift start mode is selected. The OCV is controlled below 10v and the short circuit "TIG touch" current is maintained at 25 amps independent of the preset current. When the tungsten is lifted, an arc is initiated and the output is regulated at the preset value. Hot start settings between 0 and 5 regulate the arc initiation current. A setting of 5 results in the most positive arc initiation. A setting of 0 reduces hot start.
- Hot Start settings between 5 and 10, select high frequency assisted starting TIG mode. In this range, the OCV of the machine is controlled between 50 and 70 volts. If using the Lincoln K930-1 TIG Module, set the Hot start to 10 for maximum OCV.
- The Arc Control is not used in the TIG mode.

### TIG SOLENOID OPTION

The Solenoid only operates when the V350 is in the TIG mode. If the Weld Terminals are in "Remote" then the solenoid will open when the arc start switch is closed. The solenoid will close after the arc switch has been opened and the post flow time expired.

If the Weld Terminals are turned "ON", then the solenoid will open when the electrode is touched to the work. The electrode needs to remain in contact with the work to allow for gas coverage before attempting to start the arc. The solenoid will close after the arc has been broken and the post flow time expired.

**CV-WIRE:** The CV-WIRE mode features continuous control from 10 to 40 volts. The mode was intended for most GMAW, FCAW, and MCAW applications.

- The Hot Start control is not used in the CV-WIRE mode.
- The Arc Control regulates pinch effect. At the minimum setting (-10), minimizes pinch and results in a soft arc. Low pinch settings are preferable for welding with gas mixes containing mostly inert gases. At the maximum setting (+10), maximizes pinch effect and results in a crisp arc. High pinch settings are preferable for welding FCAW and GMAW with CO<sub>2</sub>.

**CV-INNERSHEILD:** The CV-INNERSHEILD mode features continuous control from 10 to 45 volts. This mode was designed for self-shielded flux cored wires that require tight voltage control.

- The Hot Start control is not active in the CV-FLUX CORED mode.
- The Arc Control regulates pinch effect. At the minimum setting (-10), minimizes pinch and results in a soft arc. At the maximum setting (+10), maximizes pinch effect and results in a crisp arc. Most self-shielded wires work well at an Arc Control setting of 5.

V350-PRO



# OPERATION

## 7A. ADVANCED PROCESS PANEL

(See Figure B.2)

To program Welding modes. **SELECT** knob is used to Scroll through all Welding modes. The **MEMORY** button is used to store and access Welding modes into locations M1 thru M8.

### Modes:

In addition to the 5 welding modes described in **SECTION 7**, the Advanced Process Panel allows you to select the Following additional modes.

#### • Power Mode

In the Power Mode;

The work point will be in the Volts window. The Amp window will have **CP** displayed indicating Constant Power. Once current starts flowing and during the 5 second "Hold" feature the displays will show Volts and Amps respectively. Refer to the detailed explanation at the end of this section.

#### • Gouge

Air Carbon Arc Cutting (CAC-A) is a physical means of removing base metal or weld metal by using a carbon electrode, an electric arc and compressed air.

#### • Pulsed Modes

In Pulse Modes;

The work point will be in the Amps window and should be set close to the wire feed speed of the wire feeder in inches per minute. The Volts window will have **SPd** displayed indicating Wire Feed Speed. Once current starts flowing and during the 5 second "Hold" feature the displays will show amps and volts.

Pulse Mode features that are displayed while selecting a Welding pulse mode are listed below;  
Steel - .030, .035, .045, .052 – Argon Blends  
Stainless Steel - .030, .035, .045 – Argon Blends & Helium/Argon Blends

Aluminum - .035, 3/64, 1/16 – 4043 & 5356


Metal Core - .045, .052 – Argon Blends

Nickel - .035, .045 – Argon/Helium blends

Refer to the detailed explanation at the end of this section.

### ADVANCED PROCESS PANEL VERSION

FIGURE B.2



V350-PRO



Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

# OPERATION

## CONTROLS: (See Figure B.2.)

The **MEMORY button** and **SELECT knob** are used together to select a welding process and store it in memory (M1 thru M8). The **SELECT knob** scrolls through the, welding process modes and memory M1 thru M8. The **MEMORY button** stores the welding process in memory.

- **SELECT button** (The right button) selects between the "Hot Start" or "Arc Control". The < will indicate the active feature shown below.

Right Digital Window  
 "Hot Start" (-10 to 0 +10)  
 "Arc Control" (0 to 10) <

- The **ADJUST knob** adjusts the desired settings for the Hot Start or Arc Control feature that is active.

## WELDING PROCESS MODES AVAILABLE

Stick SMAW, TIG GTAW  
 Gouge CAG, CV MIG GMAW  
 CV Flux Core, Pulse MIG

## ELECTRODE MATERIAL

Steel, Metal Core, Stainless, Aluminum, Nickel

## EXAMPLE OF SAVING WELDING MODES TO MEMORY

The following example is how to select **Pulse MIG** using .035 steel and store it into memory.

1. Turn the **Select knob** until welding process is displayed.

LEFT WINDOW	RIGHT WINDOW
Pulse MIG	Argon Blends
Steel .035	

2. Wait two seconds and the right window will display Arc Control on the second line on the right side.

Pulse MIG	Argon Blends
Steel .035	Arc Cntrl ### <

3. **SPd** is displayed in the upper right **Volts** window. The left **Amps** window matches the desired wire feed speed that is set on the wire feeder. Adjust the **Output knob** until desired number is displayed.

4. Start welding. If the arc length is too short turn the **Output knob** up. If the arc length is too long turn the **Output knob** down.

The Arc Control which is displayed in the right digital window can be used to fine-tune the arc length and characteristics.

5. After all adjustments have been made press and hold the **Memory button** until the display changes. The right and the left window will display what memory to save in, lets say M1. To store in M1 push the **Memory button** again to save the Pulse Mig mode to memory M1.

6. The display in the digital windows will read as follows:

M1	Pulse MIG	Argon Blends
Steel	.035	Arc Cntrl 1.2

7. Saving or entering a second welding mode to a memory, M2. Turn the **Select knob** until the desired welding process mode is displayed in right digital window. Then follow steps 1 thru 6.

Press the **Memory button** till the digital window reads,

Save to MEM  
M2

Press the **Memory button** again and the New Welding process is saved in M2.

8. Adjust the output control to the correct wire feed setting and the V350-PRO is ready to weld again. (Note: The wire feed speed setting is not stored in memory and will need to be reset.)

9. Adjust the Arc Control and note that the M1 goes away indicating that the V350-PRO settings no longer match what is stored in memory. Going back to the original settings will not bring the M1 back. You will need to push the **Memory button** to recall the original settings in M1.

Note: After all memory's M1 thru M8 are used and the welder needs to store another welding process, a new welding process will overwrite what was originally in the memory and will read,

Save to MEM  
M1 Overwrite

M1 which stored Pulse Mig is Overwritten with the new welding process.

## LN-10/DH-10 Wire Feeder Compatibility Note:

The LN-10 and DH-10 feeders can be used to pulse weld and in the power mode with the panel. The displays on the LN-10 & DH-10 do not show the wire feed speed or power.

8. **HOT START** and **ARC CONTROL** features have different functions depending on the welding Mode that is active. Each feature is described under the welding mode heading. (See Item 7 or 7.A for specified Mode Operations) (See Figure B.1 or B.2)

V350-PRO



# OPERATION

## WELD MODE DETAILS:

Mode	Range	Comments
Stick Soft	5 - 425 amps	The stick soft mode is the best selection for general stick applications. Arc Control = Arc Force Hot Start = Initial hot start current (min = start a match set amps, Max. = greatest hot start current) During hot start, arc force is set at high and is fast response. For gouging applications: Turn current up to 425 amps.
Stick Crisp	5 - 425 amps	The stick crisp mode features an aggressive arc force routine well suited for Exx10, Exx11 series electrodes. Arc Control = Arc Force Hot Start = Initial hot start current (Mid range = welding current and will vary up and down with knobcontrol.) During hot start, arc force is set at high and is fast response. For gouging applications: Turn current up to 425 amps.
GTAW (Tig mode)	5 - 425 amps	The tig mode produces a soft, steady constant current waveform for either touch start or high frequency assisted start DC GTAW applications. Hot Start = Min to Mid range = Touch start with low OCV Mid to Max range = High frequency assisted starting with adjustable OCV up to 70 volts.
GMAW - CV	10 - 45 volts	The GMAW - CV mode is the best selection for general MIG welding, Metal core, and gas shielded applications. Arc Control = Pinch (Min = min pinch, softest arc), (Max = max pinch, crispest arc)
FCAW-SS	10 - 45 volts	The FCAW-SS mode is designed for Self Shielded Innershield products that require tight voltage control. For example; the NR 203 series or NR 207) Arc Control = Pinch (Min = min pinch, softest arc), (Max = max pinch, crispest arc, )
<b>ADVANCED PULSE PANEL WELDING PROGRAMS</b>		
Gouging	60 - 425 amps	The gouging mode is a low power version of other Lincoln welding equipment gouging programs, for example a PowerWave 455.
GMAW - Power	1 - 18 (No Units)	Refer to the detailed explanation at the end of this section.  This mode does not allow preset voltage. In the short arc GMAW mode, the set KW will not equal the actual Volts * Amps. The set power is regulated only when an arc is present. During shorting, the output is allowed to increase to clear the short.

V350-PRO



# OPERATION

## PULSE PROGRAMS:

MODE	Range (IPM*)	COMMENTS
.030 Steel	65 - 1200	<p>The V350 pulse programs are non-synergic and allow independent control of the wire feed speed (at the wire feeder) and the arc length. The Output Control Knob on the V350, adjusts an "SPD" value. Similar to trim, the "SPD" value indicates the relative arc length setting. <b>The "SPD" value displayed on the V350 may not match the actual wire feed speed!</b> The value of "SPD" is meant to be a point at which to set the arc length relative to the wire feed speed and should be set the same as actual speed for a starting point. Depending on the application, the "SPD" value can be adjusted to obtain the desired arc length. Refer to the detailed explanation at the end of this section.</p> <p>The operation of the Arc Control knob on the V350 is similar to the PowerWave series. As Arc Control is increased, the frequency is increased and the background reduced. Decreasing Arc Control will reduce frequency and increase background current. Arc Control acts to fine tune the arc plasma to the specific application.</p> <p>Preferred gas selections:</p> <p><b>Steel Argon Blends = Argon with CO2 additions from 2 to 20 % or Oxygen additions from 2 to 5%.</b></p> <p><b>Stainless Argon Blends = Argon with Oxygen additions up to 2%.</b></p> <p><b>Stainless He Ar CO2 = ~ 90% Helium, 7 1/2 % Argon 2 1/2 CO2</b>  <b>Aluminum 100% Argon</b></p>
.035 Steel	55 - 800	
.045 Steel	50 - 700	
.052 Steel	75 - 550	
.045 Metal Core	50 - 650	
.052 Metal Core	50 - 500	
.030 Stainless Ar Blends	85 - 770	
.030 Stainless He Ar CO2	110 - 770	
.035 Stainless Ar Blends	65 - 770	
.035 Stainless He Ar CO2	75 - 770	
.045 Stainless Ar Blends	50 - 600	
.045 Stainless He Ar CO2	50 - 600	
.035 Aluminum 4043	100 - 700	
.035 Aluminum 5356	115 - 740	
3/64 Aluminum 4043	80 - 550	
3/64 Aluminum 5356	85 - 700	
1/16 Aluminum 4043	75 - 325	
1/16 Aluminum 5356	75 - 450	
.035 Nickel Alloys (Non Adaptive)	80 - 700	<p>The Nickel Alloy pulse programs are non adaptive. The operator sets the output control knob to deliver the correct arc length at desired wire feed speed and stick out. While welding, the operator manipulates the stick out to maintain the correct arc length. This method of operation produces very stable arc performance considering the nature of nickel alloys.</p> <p><b>Preferred gas: Argon/Helium Blends = for the best results add helium to the argon base from 0-25%.</b></p>
.045 Nickel Alloys (Non Adaptive)	75 - 550	
PULSE ON PULSE		
.035 4043 (4x Pulse on Pulse)	120 - 600	<p><b>Arc Control = Pulse on Pulse frequency. For faster travel speed welds, the arc control should be increased.</b></p> <p><b>For larger puddle, slower travel speeds, the arc control should be decreased.</b> Refer to the detailed explanation at the end of this section.</p>
3/64 4043 (4x Pulse on Pulse)	85 - 400	
.035 5356 (5x Pulse on Pulse)	130 - 700	
3/64 5356 (5x Pulse on Pulse)	100 - 550	

\*IPM (INCHES PER MINUTE)

Return to Section TOC  
Return to Master TOC



# OPERATION

## LOWER CASE PANEL

The output studs, line switch and remote connector are located on the lower case front.

9. Both terminals are "Twist-Mate" connectors. The Negative terminal is configured to accept the pass through gas system.
10. The **METER POLARITY switch** is located above the output connectors. The switch provides a work connection for wire feeder voltmeters. Place the switch in the position of the electrode polarity indicated by the decal. **The switch does not change the welding polarity.**
11. **6-pin MS-style connector** for remote control.
12. **14-pin MS-style connector** for wire feeder connection and remote control.

## REMOTE CONTROL of the OUTPUT CONTROL and WELD TERMINALS

The Invertec V350-Pro has auto sensing of remote output controls. If after connecting or removing a remote, the Invertec V350-Pro did not configure the way you would like the local or remote control settings can be changed by pushing the OUTPUT CONTROL or WELD TERMINAL button. (A user cannot select between the 6 and 14 pin MS-style connectors.)

### CV modes

- The remote will default to the 14-pin MS-style connector if a remote is connected. If no remote is connected to the 14-pin MS-style connector then the remote will default to the 6-pin MS-style connector if a remote is connected to it.
- In all of the CV modes, the WELD TERMINAL control will default to REMOTE.

### TIG mode

- The remote will default to the 6-pin MS-style if a remote control is connected to the 6-pin MS-style and to the 14-pin MS-style connector. If a remote is not connected to the 6-pin MS-style connector then the remote will default to the 14-pin MS-style connector if a remote is connected.
- If a remote control is connected to any of the MS-style connectors the WELD TERMINAL control will default to REMOTE. If there are not any remote control devices attached the WELD TERMINAL control will default to ON.

### CC-Stick modes

- The remote will default to only the 6-pin MS-style connector if a remote is connected to it.
- The WELD TERMINAL control will default to ON with or without a remote connected.

## Types of Remote OUTPUT CONTROL

- The Invertec V350-Pro's Output Control can be controlled by either a potentiometer connected between 77 & 75 with the wiper connected to 76 or a 0V to 10V DC supply connected between 76 & 75. (76 needs to be positive)
- 14-Pin Ms-style connector lead 75 is pin G, lead 76 is pin F and lead 77 is pin E.
- 6-Pin Ms-style connector lead 75 is pin C, lead 76 is pin B and lead 77 is pin A.

## Potentiometer Control

- The total resistance should be between 2000 ohms (2K) and 10,000 ohms (10K)
- The machine output will be at minimum when lead 76 (wiper) is at the end of the potentiometer that is connected to 75. The machine's output will increase as the wiper of the potentiometer is moved to the end that is connected to 77. (Note: In TIG mode, moving the lead 76 (wiper) to lead 77 would produce the current that has been set by the Invertec V350-Pro's front panel Output Control.)
- Remotes of this type offered by Lincoln Electric are the K857, K812 and K870.

## Voltage Control

- The supply must be an isolated supply. (Not referenced to earth ground, any auxiliary power from the Invertec V350-Pro or the welding output) The supply should be capable of supplying at least 20mA.
- 0 volts supplied to 76 will set the Invertec V350-Pro to minimum output for the mode that has been selected while 10 volts supplied to 76 will set the Invertec V350-Pro to the maximum output for the mode. (Note: In TIG mode, 10 volts supplied to lead 76 would produce the current that has been set by the Invertec V350-Pro's front panel Output Control.)

## Types of Remote WELD TERMINAL Control

- The Invertec V350-Pro's Weld Terminals can be controlled from each of the MS-style connectors. The circuit has a nominal OCV of 15VDC and requires a dry contact closure (less than 100 ohms) to activate the output of the Invertec V350-Pro.
- 14-Pin MS-style connector, the Weld Terminals are controlled from pin C (lead 2) and pin D (lead 4). Pin C is positive.
- 6-Pin MS-style connector, the Weld Terminals are controlled from pin D (lead 2) and pin E (lead 4). In the 6-pin MS-style connector pin D is positive.

V350-PRO



# OPERATION

## AUXILIARY POWER

- 115VAC, 42VAC and 24VAC power is available from the 14-pin MS-style connector. The Construction model of the Invertec V350-Pro does not have the 14-pin MS-style connector) These supplies are intended to supply power for auxiliary equipment like wire feeders and the TIG Module.
- 115VAC supply is rated at 2 amps and is protected by a 3.5 amp breaker.
- 42 VAC supply is rated at 5.5 amps and is protected by a 6 amp breaker.
- 24 VAC supply is rated at 5.5 amps and is protected by a 6 amp breaker.

## LIMITATIONS

- The V350-Pro is not recommended for processes other than those listed.
- The V350-Pro can only be used with the recommended equipment and options.

## RECOMMENDED PROCESSES

Properly equipped, the Invertec V350-Pro supports GMAW-P, FCAW, SMAW, GTAW and CAC-A processes for a variety of materials, including mild steel, stainless steel, cored wires, and aluminum.

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

V350-PRO





# OPERATION

## SPECIAL WELDING PROCESSES AVAILABLE ON THIS MACHINE

### POWER MODE™

The Power Mode™ process was developed by Lincoln to maintain a stable and smooth arc at low procedure settings which are needed to weld thin metal without pop-outs or burning-through. For Aluminum welding, it provides excellent control and the ability to maintain constant arc length. This results in improved welding performance in two primary types of applications.

- Short Arc MIG at low procedure settings.
- Aluminum MIG welding.

Power Mode™ is a method of high speed regulation of the output power whenever an arc is established. It provides a fast response to changes in the arc. The higher the Power Mode Setting, the longer the arc. If a welding procedure is not established, the best way to determine the Power Mode Setting is by experimentation until the desired output result is established.

In the Power Mode variables need to be set:

- Wire Feed Speed
- Output
- Arc Control

Setting up a Power Mode procedure is similar to setting a CV MIG procedure. Select a shielding gas appropriate for a short arc process.

- For steel, use 75/25 Ar/CO2 shield gas.
- For Stainless, select a Helium blend Tri-Mix.
- For Aluminum, use 100% Ar.

Start by setting the wire feed speed based upon material thickness and appropriate travel speed. Then adjust the Output knob as follows:

- For steel, listen for the traditional “frying egg” sound of a good short-arc MIG procedure to know you have the process set correctly.
- For aluminum, simply adjust the Output knob until the desired arc length is obtained.

Note the Volts display is simply a relative number and DOES NOT correspond to voltage.

Some procedure recommendations appear in the table below.

### Recommended Welding Procedures for Power Mode

MATERIAL	Aluminum 4043	Aluminum 5356	Mild Steel	Mild Steel	Mild Steel	Mild Steel	Mild Steel	Mild Steel	Stainless Steel	Stainless Steel
WIRE	E4043	E5356	L56	L56	L56	L56	L56	L56	E308L	E308L
WIRE SIZE	0.035	0.035	0.025	0.025	0.030	0.030	0.035	0.035	0.030	0.035
GAS	100% Ar.	100% Ar.	100% CO <sub>2</sub>	75/25% Ar/CO <sub>2</sub>	100% CO <sub>2</sub>	75/25% Ar/CO <sub>2</sub>	100% CO <sub>2</sub>	75/25% Ar/CO <sub>2</sub>	Tri-mix	Tri-mix
MATERIAL THICKNESS WFS / POWER MODE SETTING	22 ga.	125 / 2.25	125 / 1.75	Not Recommended	100 / 0.8	Not Recommended	90 / 1.0			
	20 ga.	150 / 2.5	150 / 2.3	120 / 1.0	120 / 1.0	100 / 0.7	100 / 1.0		80 / 1.5	50 / 0.5
	18 ga.	200 / 3.75	200 / 3.0	140 / 1.7	140 / 1.5	110 / 1.5	110 / 1.5	100 / 2.5	100 / 2.5	110 / 2.0
	16 ga.	300 / 7.75	300 / 6.85	190 / 2.0	190 / 2.0	125 / 2.0	125 / 2.0	125 / 3.0	125 / 3.0	140 / 2.5
	14 ga.	400 / 9.0	400 / 7.5	260 / 3.0	260 / 3.0	160 / 2.3	160 / 2.3	160 / 3.8	160 / 3.5	210 / 3.0
	12 ga.	450 / 9.5	450 / 8.0	330 / 5.0	330 / 4.5	230 / 3.5	230 / 3.5	200 / 5.0	200 / 4.5	270 / 5.0
	10 ga.	500 / 10.0	500 / 8.5			300 / 6.0	300 / 6.0	240 / 6.5	240 / 7.0	325 / 6.5
	3/16	600 / 11.25	600 / 9.5			400 / 7.5	400 / 7.0			
	1/4		700 / 11							

V350-PRO



Return to Section TOC

Return to Master TOC

# OPERATION



## PULSE WELDING (GMAW-P)

The pulsed-arc process is, by definition, a spray transfer process wherein spray transfer occurs in pulses at regularly spaced intervals. In the time between pulses, the welding current is reduced and no metal transfer occurs.

Pulsed-arc transfer is obtained by operating a power source between low and high current levels. The high current level or "pulse" forces an electrode drop to the workpiece. The low current level or "background" maintains the arc between pulses. (See Figure below).

Pulsed MIG is an advanced form of welding that takes the best of all the other forms of transfer while minimizing or eliminating their disadvantages. Unlike short circuit, pulsed MIG does not create spatter or run the risk of cold lapping. The welding positions in pulsed MIG are not limited as they are with globular or spray and its wire use is definitely more efficient. Unlike the spray arc process, pulsing offers controlled heat input that allows better welding on thin materials, lower wire feed speeds and leads to less distortion and improved overall quality and appearance. This is especially important with stainless, nickel and other alloys that are sensitive to heat input.

In **GMAW-P mode**, arc control adjusts the background current and frequency of the wave. When arc control goes up, the frequency increases thus increasing the droplet transfer.



V350-PRO



Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC


Return to Master TOC

# OPERATION


## PULSE-ON-PULSE™ (GMAW-PP)

Pulse on Pulse™ is a Lincoln process specifically designed for use in welding relatively thin (less than 1/4" thick) aluminum (See the table below). It gives weld beads with very consistent uniform ripple.

In Pulse on Pulse modes, two distinct pulse types are used, instead of the single pulse type normally used in GMAW-P. A number of high energy pulses are used to obtain spray transfer and transfer metal across the arc. Such pulses are shown in the figure below. After a number "N" of such pulses, depending on the wire feed speed used, an identical number "N" of low energy pulses are performed. These low energy pulses, shown in the figure below, do not transfer any filler metal across the arc and help to cool the arc and keep the heat input low.



The Peak Current, Background Current, and Frequency are identical for the high energy and low energy pulses. In addition to cooling the weld down, the major effect of the low energy pulses is that they form a weld ripple. Since they occur at very regular time intervals, the weld bead obtained is very uniform with a very consistent ripple pattern. In fact, the bead has its best appearance if no oscillation of the welding gun ("whipping") is used. (See the figure below)



When Arc Control is used in the Pulse on Pulse modes, it does the same things it does in the other pulsed modes: decreasing the Arc Control decreases the droplet transfer and weld deposition rate. Increasing the Arc Control increases the droplet transfer and weld deposition rate. Since Arc Control varies weld droplet transfer rate, the Arc Control can be used to vary the ripple spacing in the weld bead.

## BENEFITS OF PULSE ON PULSE FROM LINCOLN ELECTRIC

- Excellent appearance of the weld bead
- Improved cleaning action
- Reduced porosity

Table B.2 shows WFS and Trim settings for common aluminum types and wire sizes when welding with Pulse-on-Pulse. The welds made to obtain the values in the table were fillet welds in the flat position. The values in the table can be helpful as a starting point to establish a welding procedure. From there, adjustments need to be made to set the proper procedure for each specific application (out-of-position, other types of joints, etc.).

The comments on the table below show values of WFS below which it is not recommended to weld. The reason is, that below these values the weld transfer will change from a spray arc to a short-arc, which is not advisable when welding aluminum.

### WELDING PROCEDURES FOR PULSE-ON-PULSE

MATERIAL	Aluminum 4043	Aluminum 4043	Aluminum 5356	Aluminum 5356
GAS	100% Ar.	100% Ar.	100% Ar.	100% Ar.
WIRE	E4043	E4043	E5356	E5356
WIRE SIZE	0.035	3/64	0.035	3/64
MATERIAL THICKNESS WFS / ARC CONTROL	14 ga.	250 / 0	200 / 0	230 / 0
	10 ga.	400 / 0	280 / 0	425 / 0
	3/16	550 / 0	340 / 0	670 / 0
	1/4	600 / 0	400 / 0	700 / 0
COMMENTS	Not Recommended below 200 WFS	Not Recommended below 100 WFS	Not Recommended below 200 WFS	Not Recommended below 200 WFS

V350-PRO



Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

# NOTES

---

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

V350-PRO



# TABLE OF CONTENTS - ACCESSORIES SECTION -

---

**Accessories.....Section C**

Cobramatic & Tig Module Connection Instructions.....C-2

Options/Accessories.....C-2

Quick Disconnect Plugs .....C-3

Connection of Lincoln Electric Wire Feeders.....C-4 Thru C-11

    V350-PRO/LN-25 with Optional 6 Pin K441-1 Remote.....C-4

    V350-PRO/LN-25 with Optional 6 Pin K857 Remote .....C-5

    LN-25 with K431 Remote Option.....C-6

    V350-PRO/LN-25 with K867 Adapter .....C-7

    V350-PRO/LN-7 with K480 Control Cable .....C-8

    V350-PRO/LN-7 with K867 Adapter .....C-9

    V350-PRO/LN-742 .....C-10

    V350-PRO/LN-10 with K1505 Control Cable .....C-11

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

V350-PRO



# ACCESSORIES

## Cobramatic Connection Instructions

A Cobramatic can only be used with a Factory or "CE" version of the V350

1. Turn the Invertec power switch "off"
2. Connect the control cable from the Cobramatic to the 24/42 VAC 14-pin wire feeder amphenol on the rear of the Invertec.
3. Connect the electrode cable to the output terminal of the polarity required by electrode. Connect the work lead to the other terminal.
4. Set the meter polarity switch on the front of the Invertec to coincide with wire feeder polarity used.
5. If a remote control such as K857 is to be used with the Cobramatic, the remote can be connected directly to the 6pin amphenol on the front of the Invertec or use a K864 adapter to connect the cobramatic and the remote to the 24/42VAC 14-pin wire feeder amphenol connector on the rear of the Invertec.

## TIG Module K930-2

The TIG Module connects to the V350-Pro Factory or CE versions with a K936-1 (9-14 pin) control cable. Connect the K936-1 to the 115VAC Wire Feeder Amphenol on the rear of the V350-Pro.

The TIG Module can also be used with the V350 Construction version. A K936-4 control cable is required to supply 115VAC to the TIG Module from an external 115VAC supply.

## General Instructions for Connection of Wire Feeders to V350-Pro

Wire feeders other than LN-7 and LN-25 may be used provided that the auxiliary power supply capacity of the V350-Pro is not exceeded. K867 universal adapter plug is required. See connection diagram S19406 and S19386 at the back of this manual for more information.

## Remote Control of Invertec

Remote Control K857, Hand Amptrol K963 and Foot Amptrol K870.

## OPTIONS / ACCESSORIES

### Construction Version – K1728-2

- All welding modes for this model run with local output control and weld terminals ON (e.g. Stick, TIG, LN25 off the arc).

K930-1	TIG Module
K428, K446, K449	LN-25(Off the Arc)

### "CE" Version – K1728-3

- The "CE" version is the Factory version with the addition of power line filtering allowing the machine to comply with the European and Australian EMC emission requirements.

### Field Installed Options/Accessories

Two versions of the V350-Pro are available from the factory for both the CE and ROW versions. Options for K1728-1 Factory and K1728-3 "CE" V350's

- TIG Gas Control Kit – K1762-2
- Advanced Process Panel – K1763-1

### Options for all models of V350-PRO

- Undercarriage – K1764-1
- Valet Style Undercarriage - K1838-1

### Welding Cable Connectors:

- K852-70 1/0-2/0 cable
- K852-95 2/0-3/0 cable

## FACTORY VERSION and ADVANCED PROCESS VERSION

K857	Remote Output Control
K814	Arc Start Switch
K812	Hand Operated Amptrol
K870	Foot Operated Amptrol

Note: All of the above remote controls connect directly to the 6-pin MS-style connector, with either a K864 or K876 adapter and connect it to the 14 pin wire feeder MS-style connector. (See Diagram in Section F-1)

K930-[ ]	TIG Module
K428, K446, K449	LN-25 *
K617 (-1 or -2) K618 (-1 or -2)	LN-742
K440 (-1), K567-1	LN-7 GMA
K1559-1, K1564-1	LN-10
K1499-1, K1521-1	DH-10
K1587-1	Cobramatic

\*Not recommended for pulse welding


V350-PRO




## QUICK DISCONNECT PLUGS

A quick disconnect system is used for the welding cable connections. The K852-70 is designed to accept a welding cable size of 1/0 to 2/0.

1. Remove 25mm (1 in.) of welding cable insulation.
2. Slide rubber boot onto cable end. The boot end may be trimmed to match the cable diameter. Soap or other lubricant will help to slide the boot over the cable.



3. Slide the copper tube into the brass plug.
4. Insert cable into copper tube.



5. Tighten set screw to collapse copper tube. Screw must apply pressure against welding cable. The top of the set screw will be well below the surface of the brass plug after tightening.
6. Slide rubber boot over brass plug. The rubber boot must be positioned to completely cover all electrical surfaces after the plug is locked into the receptacle.

V350-PRO

**LINCOLN**<sup>®</sup>  
**ELECTRIC**



## CONNECTION OF LINCOLN ELECTRIC WIRE FEEDERS

### CONNECTION OF THE LN-25 TO THE V350-PRO "ACROSS THE ARC" WITH OPTIONAL 6 PIN K441-1 REMOTE CONTROL.

1. Remove input power to the V350-PRO.
2. Connect the electrode cable to the output terminal of polarity required by the electrode. Connect the work lead to the other terminal. Welding cable must be sized for current and duty cycle of the application.
3. Attach the single lead from the LN-25 control box to the work using the spring clip on the end of the lead. This is only a control lead - it carries no welding current.

4. Set the voltmeter switch to the electrode polarity chosen.
5. Set "CONTROL SELECT" to "REMOTE".
6. Set the "MODE" to the "CV-WIRE" position.
7. Set "WELD TERMINALS SELECT" to the "ON"


#### **⚠ CAUTION**

position.

**If you are using an LN-25 without an internal contactor, the electrode will be "HOT" when the V350-PRO is energized.**

8. Set the "ARC CONTROL" to the "O" position and then adjust to suit.

**Figure C.1 V350-PRO/LN-25 ACROSS THE ARC CONNECTION DIAGRAM**



**NOTE:** Illustration shows electrode connected for negative polarity.

V350-PRO

**LINCOLN**<sup>®</sup>  
**ELECTRIC**

## ACCESSORIES


### CONNECTION OF THE LN-25 TO THE V350-PRO "ACROSS THE ARC" WITH OPTIONAL 6 PIN K857 REMOTE CONTROL.

1. Remove input power to the V350-PRO.
2. Connect the electrode cable to the output terminal of polarity required by the electrode. Connect the work lead to the other terminal. Welding cable must be sized for current and duty cycle of the application.
3. Connect the K857 remote control to the 6-pin amphenol on the V350-PRO.
4. Attach the single lead from the LN-25 control box to the work using the spring clip on the end of the lead. This is only a control lead - it carries no welding current.
5. Set the voltmeter switch to the electrode polarity chosen.
6. Set "CONTROL SELECT" to "REMOTE".
7. Set the "MODE" to the "CV-WIRE" position.
8. Set "WELD TERMINALS SELECT" to the "ON" position.
9. Set the "ARC CONTROL" to the "O" position and then adjust to suit.

### CAUTION

If you are using an LN-25 without an internal contactor, the electrode will be "HOT" when the V350-PRO is energized.

**Figure C.2 V350-PRO/LN-25 ACROSS THE ARC CONNECTION DIAGRAM WITH K857 REMOTE CONTROL**



**NOTE:** Illustration shows electrode connected for negative polarity.

V350-PRO

**LINCOLN**<sup>®</sup>  
**ELECTRIC**

# ACCESSORIES


## CONNECTION OF THE LN-25 WITH K431 REMOTE OPTION TO THE V350-PRO.

**NOTE: AN LN-25 CAN ONLY BE USED WITH A FACTORY OR "CE" VERSION OF THE V350-PRO.**

1. Remove input power to the V350-PRO.
2. Connect the electrode cable to the output terminal of polarity required by the electrode. Connect the work lead to the other terminal. Welding cable must be sized for current and duty cycle of the application.
3. Attach the single lead from the LN-25 control box to the work using the spring clip on the end of the lead. This is only a control lead - it carries no welding current.
4. Set the voltmeter switch to the electrode polarity chosen.
5. Set "CONTROL SELECT" to "REMOTE".
6. Set the "MODE" to the "CV-WIRE" position.
7. Set "WELD TERMINALS SELECT" to the "REMOTE" position.
8. Set the "ARC CONTROL" to the "O" position and then adjust to suit.
9. Connect the K432 remote control cable to the LN-25.
10. Connect the K876 adapter to the K432 and to the 24/42VAC 14-pin amphenol located at the rear of the V350-PRO.
11. Adjust the wire feed speed and voltage at the LN-25.

**NOTE:** See **Figure C.4** for connection Using K867 adapter.

**Figure C.3 LN-25 with K431 Remote Option to the V350-PRO**



**NOTE:** Illustration shows electrode connected for positive polarity.

V350-PRO





## ACCESSORIES

### CONNECTION OF THE LN-7 TO THE V350-PRO USING K480 CONTROL CABLE (SEE FIGURE C.5)

**NOTE: AN LN-7 CAN ONLY BE USED WITH A FACTORY OR "CE" VERSION OF THE V350-PRO. IF YOUR LN-7 COMES EQUIPPED WITH A K291 OR K404 INPUT CABLE, REFER TO THE CONNECTION OF THE LN-7 USING K867 UNIVERSAL ADAPTER.**


1. Remove input power to the V350-PRO.
2. Connect the electrode cable from the K480 control cable to the "+" terminal of the welder and to the LN-7 wire feeder. Connect the work cable to the "-" terminal of the welder.

**NOTE:** Figure C.5 shows the electrode connected for positive polarity. To change polarity, shut the welder off and reverse the electrode and work cables at the output terminals.

**NOTE:** Welding cable must be sized for current and duty cycle of application.

3. Connect the input cable from the K480 control cable to the (115VAC) 14 pin amphenol on the V350-PRO and the input cable plug on the LN-7.
4. Set the "VOLTMETER" switch to "+" or "-" depending on the polarity chosen.
5. Set "CONTROL SELECT" to "REMOTE".
6. Set the "MODE" to the "CV-WIRE" position.
7. Place the "WELD TERMINALS SELECT" in the "REMOTE" position.
8. Adjust wire feed speed at the LN-7 and adjust the welding voltage with the optional remote control if used.
9. Set the "ARC" control at "0" initially and adjust to suit.

**Figure C.5 V350-PRO/LN-7 with K480 Control Cable Connection Diagram**




V350-PRO

**LINCOLN**<sup>®</sup>  
**ELECTRIC**

## CONNECTION OF THE K867 ADAPTER FOR USE WITH THE K291 OR K404 INPUT CABLES AND LN-7.

1. Insulate each unused lead individually.
2. Splice leads and insulate.

Figure C.6 Connection of LN-7 to V350-PRO using K867 adapter.



V350-PRO

**LINCOLN**<sup>®</sup>  
**ELECTRIC**

## ACCESSORIES

### CONNECTION OF THE LN-742 TO THE V350-PRO (SEE FIGURE C.7)

**NOTE: AN LN-7 CAN ONLY BE USED WITH A FACTORY OR "CE" VERSION OF THE V350-PRO.**


1. Remove input power to the V350-PRO.
2. Connect the electrode cable from the LN-742 to the "+" terminal of the welder. Connect the work cable to the "-" terminal of the welder.

**NOTE:** Figure C.7 shows the electrode connected for positive polarity. To change polarity, shut the welder off and reverse the electrode and work cables at the output terminals.

**NOTE:** Welding cable must be sized for current and duty cycle of application.

3. Connect the K591 control cable to the 24/42VAC 14 pin amphenol on the back of the V350-PRO and the input cable plug on the LN-742.
4. Set the "VOLTMETER" switch to "+" or "-" depending on the polarity chosen.
5. Set the "MODE" to the "CV-WIRE" position..
6. Set "CONTROL SELECT" to "LOCAL".
7. Place the "WELD TERMINALS SELECT" in the "REMOTE" position.
8. Adjust wire feed speed at the LN-742.
9. Set the "ARC" control at "0" initially and adjust to suit.

**Figure C.7 V350-PRO/LN-742 Connection Diagram**



V350-PRO






## ACCESSORIES

### CONNECTION OF THE LN-10 TO THE V350-PRO USING THE K1505 CONTROL CABLE.

**NOTE: AN LN-10 CAN ONLY BE USED WITH A FACTORY OR "CE" VERSION OF THE V350-PRO.**

1. Remove input power to the V350-PRO.
2. Connect the K1505 control cable from the LN-10 to the Invertec 24/42VAC 14 pin amphenol connector on the rear of the V350-PRO.
3. Connect the electrode cable to the output terminal of polarity required by the electrode. Connect the work lead to the other terminal.
4. Set the meter polarity switch on the front of the V350-PRO to coincide with wire feeder polarity used.
5. Set "CONTROL SELECT" to "REMOTE".
6. Set the "MODE" to the "CV-WIRE" position..
7. Set the "WELD TERMINALS SELECT" to the "REMOTE" position.
8. Set the "ARC CONTROL" to the "0" position and then adjust to suit.
9. Set wire feed speed and voltage at the LN-10.  
**NOTE:** The voltage set point displayed on the V350-PRO should be ignored when operating in the remote control mode with the LN-10.
10. See the LN-10 manual for details on accessing the control DIP switch.
11. The control DIP switch inside the LN-10 should be set per the instructions in the LN-10 manual.

**Figure C.8 LN-10 V350-PRO**



V350-PRO

**LINCOLN**<sup>®</sup>  
**ELECTRIC**

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

V350-PRO



# TABLE OF CONTENTS -MAINTENANCE-

---

<b>Maintenance .....</b>	<b>Section D</b>
Capacitor Discharge Procedure .....	D-2
Visual Inspection.....	D-2
Routine Maintenance.....	D-2
Periodic Maintenance.....	D-2
Major Component Locations .....	D-3

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

V350-PRO



# MAINTENANCE

## ⚠ WARNING


Have qualified personnel do the maintenance work. Always use the greatest care when working near moving parts.

Do not put your hands near the cooling blower fan. If a problem cannot be corrected by following the instructions, take the machine to the nearest Lincoln Field Service Shop.



**ELECTRIC SHOCK can kill.**

- Do not touch electrically live parts or electrode with skin or wet clothing.
- Insulate yourself from work and ground
- Always wear dry insulating gloves.




**EXPLODING PARTS can cause injury.**

- Failed parts can explode or cause other parts to explode when power is applied.
- Always wear a face shield and long sleeves when servicing.

See additional warning information throughout this Operator's Manual.

## CAPACITOR DISCHARGE PROCEDURE

1. Obtain a power resistor (25 ohms, 25 watts).
2. Hold resistor body with electrically insulated glove. **DO NOT TOUCH TERMINALS.** Connect the resistor terminals across the two studs in the position shown. Hold in each position for 1 second. Repeat for all four capacitors.



3. Use a DC voltmeter to check that voltage is not present across the terminals on all four capacitors.

## VISUAL INSPECTION

Clean interior of machine with a low pressure air stream. Make a thorough inspection of all components. Look for signs of overheating, broken leads or other obvious problems. Many problems can be uncovered with a good visual inspection.

## ROUTINE MAINTENANCE

1. Every 6 months or so the machine should be cleaned with a low pressure airstream. Keeping the machine clean will result in cooler operation and higher reliability. Be sure to clean these areas:
  - All printed circuit boards
  - Power switch
  - Main transformer
  - Input rectifier
  - Auxiliary Transformer
  - Reconnect Switch Area
  - Fan (Blow air through the rear louvers)
2. Examine the sheet metal case for dents or breakage. Repair the case as required. Keep the case in good condition to insure that high voltage parts are protected and correct spacings are maintained. All external sheet metal screws must be in place to insure case strength and electrical ground continuity.

## PERIODIC MAINTENANCE

### Overload Protection

The machine is electrically protected from producing high output currents. Should the output current exceed 430A, an electronic protection circuit will reduce the current to approximately 100A. The machine will continue to produce this low current until the protection circuit is reset. Reset occurs when the output load is removed.

### Thermal Protection

Thermostats protect the machine from excessive operating temperatures. Excessive temperatures may be caused by a lack of cooling air or operating the machine beyond the duty cycle and output rating. If excessive operating temperature should occur, the thermostat will prevent output voltage or current. The meter will remain energized during this time.

Thermostats are self-resetting once the machine cools sufficiently. If the thermostat shutdown was caused by excessive output or duty cycle and the fan is operating normally, the Power Switch may be left on and the reset should occur within a 15 minute period.


V350-PRO



# MAINTENANCE

FIGURE D.1 – MAJOR COMPONENT LOCATIONS

- 1. Center Panel
- 2. Base Assembly
- 3. Case Back
- 4. Case Front
- 5. Case Wraparound



V350-PRO



Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC


Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

# TABLE OF CONTENTS -THEORY OF OPERATION SECTION-

<b>Theory of Operation</b> .....	<b>Section E</b>
General Description .....	E-2
Input Line Voltage, Auxiliary Transformer and Precharge.....	E-2
Switch Board and Main Transformer .....	E-3
Power board, Control Board, and SPI Communications.....	E-4
Output Rectifier and Choke .....	E-5
Thermal Protection .....	E-6
Protection Circuits .....	E-6
Over current Protection .....	E-6
Under/Over Voltage Protection .....	E-6
Insulated Gate Bipolar Transistor (IGBT) Operation .....	E-7
Pulse Width Modulation.....	E-8
Minimum/Maximum Output.....	E-8

**FIGURE E.1 – V350-PRO BLOCK LOGIC DIAGRAM**



Return to Master TOC


Return to Master TOC

Return to Master TOC

Return to Master TOC

# THEORY OF OPERATION

## FIGURE E.2 – INPUT VOLTAGE AND PRECHARGE



### GENERAL DESCRIPTION

The Invertec V350-Pro is an inverter based welding power source that offers multi mode constant voltage (CV) and constant current (CC) welding and is rated at 350 amps 34VDC at a 60% duty cycle. The Invertec V350-Pro is available in a construction version (no wire feeder connection or auxiliary power), a factory version that includes a wire feeder connection and related power, an advanced process version and a rack version.

### INPUT LINE VOLTAGE, AUXILIARY TRANSFORMER, & PRECHARGE

The Invertec V350-Pro can be connected for a variety of three-phase or single-phase input voltages. The initial power is applied to the V350 through a line switch located on the front of the machine. Two phases of the input voltage are applied to the auxiliary transformer. The auxiliary transformer develops four different secondary voltages. The 115VAC is used to power the fan motor and also is applied to the 14 pin amphenol type connector for wirefeeder operation. The 24VAC and 42VAC voltages are also applied to the 14 pin amphenol type connector to power wirefeeders. The 28VAC

is rectified and the resultant 40VDC is applied to the power board.

The input voltage is rectified by the input rectifier and the resultant DC voltage is applied to the switch board through the reconnect switch assembly located at the rear of the machine. The reconnect switch connect the two pairs of input capacitors either in a parallel (lower voltage) or series (higher voltage) configuration to accommodate the applied input voltage.

During the precharge time the DC input voltage is applied to the input capacitors through a current limiting circuit. The input capacitors are charged slowly and current limited. A voltage to frequency converter circuit located on the switch board monitors the capacitor voltages. This signal is coupled to the control board (measure frequency, not voltage to check signal). When the input capacitors have charged to an acceptable level, the control board energizes the input relays, that are located on the switch board, making all of the input power, without current limiting, available to the input capacitors. If the capacitors become under or over voltage the control board will de-energize the input relays and the V350 output will be disabled. Other possible faults may also cause the input relays to drop out.


**NOTE:** Unshaded areas of Block Logic Diagram are the subject of discussion.





# THEORY OF OPERATION

**FIGURE E.4 – POWER BOARD, CONTROL BOARD AND SERIAL PERIPHERAL INTERFACE (SPI) COMMUNICATIONS**



## POWER BOARD, CONTROL BOARD AND SERIAL PERIPHERAL INTERFACE (SPI) COMMUNICATIONS

### POWER BOARD

The 28VAC auxiliary is rectified and filtered and applied to the power board. The power board, utilizing a switching power supply, processes the 40VDC input and develops several regulated positive and negative DC supplies. Three DC supplies are fed to the control board for machine control supplies. Two positive DC voltages are coupled to the control board for the Serial Peripheral Communications (SPI) supplies. A +5VDC is used for the RS232 connection supply. An over or under input voltage detection and shutdown circuit is also part of the power board's circuitry. The optional 12VDC gas solenoid is powered by the remote board.

### CONTROL BOARD

The control board performs the primary interfacing functions to establish and maintain output control of

the V350 machine. The control board sends and receives command signals from the mode or advanced process panel, the display panel and the remote panel. These communications are processed through a digital network called a Serial Peripheral Interface (SPI). This network digitally communicates to and from the control board the user's commands and various machine status messages. The software that is contained within the control board processes and compares these commands with the voltage and current feedback information it receives from the output current sensor and the output voltage sensing leads. The appropriate pulse width modulation (PWM) signals (**See Pulse Width Modulation** in this section) are sent to the switch board IGBTs. In this manner, the digitally controlled high-speed welding waveform is created and regulated.

The control board also monitors the thermostats, the main transformer primary currents and the input capacitor voltages.


**NOTE:** Unshaded areas of Block Logic Diagram are the subject of discussion.

V350-PRO

**LINCOLN**  
ELECTRIC

# THEORY OF OPERATION

FIGURE E.5 – OUTPUT RECTIFIER AND CHOKE



## OUTPUT RECTIFIER AND CHOKE

The output rectifier receives the AC output from the main transformer secondary and rectifies it to a DC voltage level. Since the output choke is in series with the negative leg of the output rectifier and also in series with the welding load, a filtered DC output is applied to the machine's output terminals.

**NOTE:** Unshaded areas of Block Logic Diagram are the subject of discussion.

Return to Section TOC  
Return to Master TOC

# THEORY OF OPERATION

## THERMAL PROTECTION

Two normally closed (NC) thermostats protect the machine from excessive operating temperatures. These thermostats are wired in series and are connected to the control board. One of the thermostats is located on the heat sink of the switch board and the other is located on the output choke. Excessive temperatures may be caused by a lack of cooling air or operating the machine beyond its duty cycle or output rating. If excessive operating temperatures should occur, the thermostats will prevent output from the machine. The yellow thermal light, located on the front of the machine, will be illuminated. The thermostats are self-resetting once the machine cools sufficiently. If the thermostat shutdown was caused by excessive output or duty cycle and the fan is operating normally, the power switch may be left on and the reset should occur within a 15-minute period.

## PROTECTIVE CIRCUITS

Protective circuits are designed into the V350-PRO to sense trouble and shut down the machine before damage occurs to the machine's internal components.

## OVER CURRENT PROTECTION

If the average current exceeds 450 amps for one second, then the output will be limited to 100 amps until the load is removed. If the peak current exceeds 600 amps for 150 ms, the output will be limited to 100 amps until the load is removed.

## UNDER/OVER VOLTAGE PROTECTION

Protective circuits are included on the switch and control boards to monitor the voltage across the input capacitors. In the event that a capacitor pair voltage is too high, or too low, the machine output will be disabled. The protection circuits will prevent output if any of the following conditions exist.

1. Voltage across a capacitor pair exceeds 467 volts. (High line surges or improper input voltage connections.)
2. Voltage across a capacitor pair is under 190 volts. (Due to improper input voltage connections.)
3. Internal component damage.

V350-PRO



Return to Section TOC  
Return to Master TOC  
Return to Section TOC  
Return to Master TOC  
Return to Section TOC  
Return to Master TOC  
Return to Section TOC  
Return to Master TOC

## INSULATED GATE BIPOLAR TRANSISTOR (IGBT) OPERATION


An IGBT is a type of transistor. IGBT are semiconductors well suited for high frequency switching and high current applications.

Example A in Figure E.6 shows an IGBT in passive mode. There is no gate signal, zero volts relative to the source, and therefore, no current flow. The drain terminal of the IGBT may be connected to a voltage supply; but since there is no conduction, the circuit will not supply current to components connected to the source. The circuit is turned OFF like a light switch.

Example B shows the IGBT in an active mode. When the gate signal, a positive DC voltage relative to the source, is applied to the gate terminal of the IGBT, it is

capable of conducting current. A voltage supply connected to the drain terminal will allow the IGBT to conduct and supply current to the circuit components coupled to the source. Current will flow through the conducting IGBT to downstream components as long as the positive gate signal is present. This is similar to turning ON a light switch.



FIGURE E.6 – IGBT



Return to Section TOC  
Return to Master TOC  
Return to Section TOC  
Return to Master TOC  
Return to Section TOC  
Return to Master TOC  
Return to Section TOC  
Return to Master TOC

# THEORY OF OPERATION

FIGURE E.7 — TYPICAL IGBT OUTPUTS.



## PULSE WIDTH MODULATION

The term Pulse Width Modulation is used to describe how much time is devoted to conduction in the positive and negative portions of the cycle. Changing the pulse width is known as modulation. Pulse Width Modulation (PWM) is the varying of the pulse width over the allowed range of a cycle to affect the output of the machine.

## MINIMUM OUTPUT

By controlling the duration of the gate signal, the IGBT is turned on and off for different durations during the cycle. The top drawing in Figure E.7 shows the minimum output signal possible over a 50-microsecond time period.

The positive portion of the signal represents one IGBT group<sup>1</sup> conducting for one microsecond. The negative portion is the other IGBT group<sup>1</sup>. The dwell time (off time) is 48 microseconds (both IGBT groups off). Since only two microseconds of the 50-microsecond time period is devoted to conducting, the output power is minimized.

## MAXIMUM OUTPUT

By holding the gate signal on for 24 microseconds each, and allowing only two microseconds of dwell time (off time) during the 50-microsecond cycle, the output is maximized. The darkened area under the top curve can be compared to the area under the bottom curve. The more dark area that is under the curve indicates that more power is present.

<sup>1</sup>An IGBT group consists of two IGBT modules feeding one transformer primary winding.

V350-PRO

**LINCOLN**<sup>®</sup>  
**ELECTRIC**

# TABLE OF CONTENTS

## TROUBLESHOOTING & REPAIR SECTION

---

**Troubleshooting & Repair Section .....Section F**

How to Use Troubleshooting Guide .....F-2

PC Board Troubleshooting Procedures and Replacement .....F-3

Troubleshooting Guide .....F-4

Test Procedures

- Input Filter Capacitor Discharge Procedure .....F-15
- Main Switch Board Test .....F-17
- Input Rectifier Test .....F-21
- Power Board Test.....F-25
- Output Diode Modules Test .....F-29
- Auxiliary Transformer Test .....F-33
- Current Transducer Test.....F-37
- Fan Control and Motor Test .....F-41
- SPI Cable Resistance and Voltage Test .....F-45
- Voltage and Current Calibration Procedure .....F-47

Replacement Procedures

- Control Board Removal and Replacement .....F-51
- Display Board Removal and Replacement .....F-55
- Main Switch Board Removal and Replacement .....F-59
- Advanced Process Panel Removal and Replacement .....F-63
- Remote Board Removal and Replacement .....F-69
- Snubber Board Removal and Replacement .....F-73
- Power Board Removal and Replacement.....F-75
- Input Rectifier Removal and Replacement .....F-79
- Output Rectifier Modules Removal and Replacement .....F-83
- Current Transducer Removal and Replacement.....F-87
- Retest after Repair .....F-92

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

V350-PRO





# TROUBLESHOOTING & REPAIR

## HOW TO USE TROUBLESHOOTING GUIDE



### CAUTION

Service and repair should be performed by only Lincoln Electric Factory Trained Personnel. Unauthorized repairs performed on this equipment may result in danger to the technician and machine operator and will invalidate your factory warranty. For your safety and to avoid Electrical Shock, please observe all safety notes and precautions detailed throughout this manual.

This Troubleshooting Guide is provided to help you locate and repair possible machine malfunctions. Simply follow the three-step procedure listed below.

**Step 1. LOCATE PROBLEM (SYMPTOM).** Look under the column labeled “PROBLEM (SYMPTOMS)”. This column describes possible symptoms that the machine may exhibit. Find the listing that best describes the symptom that the machine is exhibiting. Symptoms are grouped into three main categories: Output Problems, Function Problems, and LED Function Problems.

**Step 2. PERFORM EXTERNAL TESTS.** The second column, labeled “POSSIBLE AREAS OF MISADJUSTMENT(S)”, lists the obvious external possibilities that may contribute to the machine symptom. Perform these tests/checks in the order listed. In general, these tests can be conducted without removing the case wrap-around cover.

**Step 3. PERFORM COMPONENT TESTS.** The last column, labeled “Recommended Course of Action” lists the most likely components that may have failed in your machine. It also specifies the appropriate test procedure to verify that the subject component is either good or bad. If there are a number of possible components, check the components in the order listed to eliminate one possibility at a time until you locate the cause of your problem.

All of the referenced test procedures referred to in the Troubleshooting Guide are described in detail at the end of this chapter. Refer to the Troubleshooting and Repair Table of Contents to locate each specific Test Procedure. All of the referred to test points, components, terminal strips, etc., can be found on the referenced electrical wiring diagrams and schematics. Refer to the Electrical Diagrams Section Table of Contents to locate the appropriate diagram.



### CAUTION

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-800-833-9353.(WELD)

V350-PRO



# TROUBLESHOOTING & REPAIR

## PC BOARD TROUBLESHOOTING PROCEDURES

### ⚠ WARNING



#### ELECTRIC SHOCK can kill.

- Have an electrician install and service this equipment. Turn the input power OFF at the fuse box before working on equipment. Do not touch electrically hot parts.

### ⚠ CAUTION

Sometimes machine failures appear to be due to PC board failures. These problems can sometimes be traced to poor electrical connections. To avoid problems when troubleshooting and replacing PC boards, please use the following procedure:

1. Determine to the best of your technical ability that the PC board is the most likely component causing the failure symptom.
2. Check for loose connections at the PC board to assure that the PC board is properly connected.
3. If the problem persists, replace the suspect PC board using standard practices to avoid static electrical damage and electrical shock. Read the warning inside the static resistant bag and perform the following procedures:

#### PC board can be damaged by static electricity.



#### ATTENTION Static-Sensitive Devices Handle only at Static-Safe Workstations

- Remove your body's static charge before opening the static-shielding bag. Wear an anti-static wrist strap. For safety, use a 1 Meg ohm resistive cord connected to a grounded part of the equipment frame.

- If you don't have a wrist strap, touch an un-painted, grounded, part of the equipment frame. Keep touching the frame to prevent static build-up. Be sure not to touch any electrically live parts at the same time.

- Tools which come in contact with the PC board must be either conductive, anti-static or static-dissipative.

- Remove the PC board from the static-shielding bag and place it directly into the equipment. Don't set the PC board on or near paper, plastic or cloth which could have a static charge. If the PC board can't be installed immediately, put it back in the static-shielding bag.

- If the PC board uses protective shorting jumpers, don't remove them until installation is complete.

- If you return a PC board to The Lincoln Electric Company for credit, it must be in the static-shielding bag. This will prevent further damage and allow proper failure analysis.

4. Test the machine to determine if the failure symptom has been corrected by the replacement PC board.

**NOTE:** It is desirable to have a spare (known good) PC board available for PC board troubleshooting.

**NOTE:** Allow the machine to heat up so that all electrical components can reach their operating temperature.

5. Remove the replacement PC board and substitute it with the original PC board to recreate the original problem.

a. If the original problem does not reappear by substituting the original board, then the PC board was not the problem. Continue to look for bad connections in the control wiring harness, junction blocks, and terminal strips.

b. If the original problem is recreated by the substitution of the original board, then the PC board was the problem. Reinstall the replacement PC board and test the machine.

6. Always indicate that this procedure was followed when warranty reports are to be submitted.

**NOTE:** Following this procedure and writing on the warranty report, "INSTALLED AND SWITCHED PC BOARDS TO VERIFY PROBLEM," will help avoid denial of legitimate PC board warranty claims.

V350-PRO

**LINCOLN**<sup>®</sup>  
**ELECTRIC**

# TROUBLESHOOTING & REPAIR

## TROUBLESHOOTING GUIDE

Observe Safety Guidelines detailed in the beginning of this manual.

PROBLEMS (SYMPTOMS)	POSSIBLE AREAS OF MISADJUSTMENT(S)	RECOMMENDED COURSE OF ACTION
<b>OUTPUT PROBLEMS</b>		
Major physical or electrical damage is evident when the sheet metal cover is removed.	1. Contact your local authorized Lincoln Electric Field Service Facility for technical assistance.	1. Contact the Lincoln Electric Service Department, 1-800-833-9353(WELD).
The machine is dead—no output—no displays.	<ol style="list-style-type: none"> <li>1. Make sure the input line/breaker switch is in the ON position.</li> <li>2. Check the 3.5 amp circuit breaker (CB3). Reset if tripped.</li> <li>3. Check the main input line fuses. If open, replace.</li> <li>4. Check the 3.5 amp circuit breaker (CB2). Reset if tripped.</li> <li>5. Check the 6 amp circuit breaker (CB1). Reset if tripped.</li> <li>6. Make sure the reconnect switch and jumper lead is configured correctly for the applied input voltage.</li> <li>7. If the machine is being operated with single phase input voltage make sure the red lead is not connected. See the <i>Installation Section</i>.</li> </ol>	<ol style="list-style-type: none"> <li>1. Perform the <b>Auxiliary Transformer Test</b>.</li> <li>2. Perform the <b>Power Board Test</b>.</li> <li>3. The control rectifier and or associated filter capacitor (C5) may be faulty. Check and replace as necessary.</li> <li>4. Perform <b>The SPI Cable Resistance and Voltage Test</b>.</li> <li>5. The Control Board may be faulty.</li> </ol>
The main input fuses (or breaker) repeatedly fail.	<ol style="list-style-type: none"> <li>1. Make certain the fuses or breakers are sized properly.</li> <li>2. Make sure the reconnect switch and jumper lead is configured correctly for the applied input voltage.</li> <li>3. The welding procedure may be drawing too much input current or the duty cycle may be too high. Reduce the welding current and /or reduce the duty cycle.</li> </ol>	<ol style="list-style-type: none"> <li>1. Check the reconnect switches and associated wiring. See the Wiring Diagram.</li> <li>2. Perform the <b>Input Rectifier Test</b>.</li> <li>3. Perform the <b>Main Switch Board Test</b>.</li> <li>4. Perform the <b>Output Diode Module Test</b>.</li> <li>5. The Input Filter Capacitors may be faulty. Check, and if any are faulty replace all four.</li> </ol>

**CAUTION**

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-800-833-9353(WELD).

V350-PRO



Return to Section TOC

Return to Master TOC

# TROUBLESHOOTING & REPAIR

## TROUBLESHOOTING GUIDE

Observe Safety Guidelines detailed in the beginning of this manual.

PROBLEMS (SYMPTOMS)	POSSIBLE AREAS OF MISADJUSTMENT(S)	RECOMMENDED COURSE OF ACTION
<b>OUTPUT PROBLEMS</b>		
<p>The V350-Pro does not have welding output. The displays are lit.</p>	<ol style="list-style-type: none"> <li>1. Make sure the reconnect switch is configured correctly for the input voltage applied.</li> <li>2. Make sure the Weld Terminals Select is ON. If the problem is solved the remote control device or associated circuitry may be faulty. See the wiring diagram.</li> <li>3. Put the Control Select in the Local position. If the problem is solved the remote control device or associated circuitry may be faulty.</li> <li>4. If an error code is displayed see <b>Fault Code Explanations</b>.</li> </ol>	<ol style="list-style-type: none"> <li>1. Check the reconnect switch and associated leads for loose or faulty connections. See the wiring diagram.</li> <li>2. Perform the <b>Main Switch Board Test</b>.</li> <li>3. Perform the <b>Power Board Test</b>.</li> <li>4. Perform the <b>Output Diode Module Test</b>.</li> <li>5. The control board may be faulty.</li> <li>6. The input filter capacitors may be faulty. Check and replace if necessary.</li> <li>7. The remote board may be faulty.</li> </ol>
<p>The V350-Pro will not produce full output.</p>	<ol style="list-style-type: none"> <li>1. The input voltage may be too low, limiting the output capability of the machine. Make certain the input voltage is correct for the machine and the reconnect switch and jumper lead configuration.</li> <li>2. The welding current may be too high. The machine will fold back to 100 amps if the welding current exceeds 450 amps.</li> <li>3. Make sure the machine is in "Local" output control.. If the problem is resolved the Remote control board or the external remote control unit may be faulty.</li> </ol>	<ol style="list-style-type: none"> <li>1. Perform the <b>Output Rectifier Test</b>.</li> <li>2. Perform the <b>Main Switch Board Test</b>.</li> <li>3. Perform the <b>Power Board Test</b>.</li> <li>4. Perform the <b>Current Transducer Test</b>.</li> <li>5. If the preset function is not performing properly the status panel board or the output control may be faulty.</li> <li>6. The control board may be faulty.</li> </ol>


CAUTION

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-800-833-9353(WELD).

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

# TROUBLESHOOTING & REPAIR

Observe Safety Guidelines detailed in the beginning of this manual.

## TROUBLESHOOTING GUIDE

PROBLEMS (SYMPTOMS)	POSSIBLE AREAS OF MISADJUSTMENT(S)	RECOMMENDED COURSE OF ACTION
FUNCTION PROBLEMS		
The machine regularly overheats and the yellow thermal light is ON indicating a thermal overload.	<ol style="list-style-type: none"> <li>1. Check the 3.5 amp circuit breaker (CB2). Reset if tripped.</li> <li>2. The welding application may be exceeding the recommended duty cycle of the V350-Pro.</li> <li>3. Dirt and dust may have clogged the cooling channels inside the machine.</li> <li>4. Air intake and exhaust louvers may be blocked due to inadequate clearance around the machine.</li> <li>5. Make certain the fan as needed (F.A.N.) is operating properly. The fan should operate when welding voltage is present and/or when there is an over temperature condition.</li> </ol>	<ol style="list-style-type: none"> <li>1. The 115VAC fan motor is controlled by the control board via the main switch board. Perform the <b>Fan Motor And Control Test</b>.</li> <li>1. A thermostat or associated circuitry may be faulty. See the wiring diagram. One normally closed thermostat is located on the output choke and the other is located on the main switch board heat sink. See the wiring diagram.</li> </ol> <p>Note: <b>The Main Switch Board Removal Procedure</b> will be required to gain access to the heat sink thermostat.</p>
An attached wire feeder will not function correctly.	<ol style="list-style-type: none"> <li>1. Make certain the wire feeder control cable is connected to the correct 14-pin amphenol type plug (115VAC or 24/42VAC) for the wire feeder being used. See the connection diagram. If wirefeeder has DIP switch, be sure it is set correctly.</li> <li>2. Check the two circuit breakers located at the rear of the machine. Reset if tripped.</li> <li>3. The wire feeder or control cable may be faulty.</li> </ol>	<ol style="list-style-type: none"> <li>1. Perform the <b>Auxiliary Transformer Test</b>.</li> <li>2. Check the leads between the 14-pin amphenol type plugs and the auxiliary transformer for loose or faulty connections.</li> </ol>

⚠ CAUTION

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-800-833-9353(WELD).

V350-PRO



Return to Section TOC

Return to Master TOC

# TROUBLESHOOTING & REPAIR

## TROUBLESHOOTING GUIDE

Observe Safety Guidelines detailed in the beginning of this manual.

PROBLEMS (SYMPTOMS)	POSSIBLE AREAS OF MISADJUSTMENT(S)	RECOMMENDED COURSE OF ACTION
<b>FUNCTION PROBLEMS</b>		
The machine's welding output is very high and uncontrollable.	<ol style="list-style-type: none"> <li>1. Put the Control Select in the Local position. If the problem is solved the remote control device or associated circuitry may be faulty.</li>   <li>2. Check for proper current and voltage calibration.</li> </ol>	<ol style="list-style-type: none"> <li>1. Perform the <b>Current Transducer Test</b>.</li>   <li>2. If the output is normal when the Control Select is in the Local position but the output is very high in the Remote position the remote board may be faulty. Perform The <b>SPI Cable Resistance and Voltage Test</b>.</li>   <li>3. The control board may be faulty.</li> </ol>
The Weld Mode Select does not function properly.	<ol style="list-style-type: none"> <li>1. Refer to <b>Operation Section</b> of this manual for normal operation characteristics.</li> </ol> <p><b>NOTE:</b> The mode panel is not present if the advanced process panel is installed.</p>	<ol style="list-style-type: none"> <li>1. Check for loose or faulty plug connections between the control board and the mode select panel. See the wiring diagram.</li>   <li>2. Perform the <b>SPI Cable Resistance and Voltage Test</b>.</li>   <li>3. The Mode Select Panel board may be faulty.</li>   <li>4. The control board may be faulty.</li> </ol>
The output control and/or Weld Terminals Select functions do not operate properly.	<ol style="list-style-type: none"> <li>1. Refer to <b>Operation Section</b> of this manual for normal operation characteristics.</li>   <li>2. Check for proper current and voltage calibration.</li> </ol>	<ol style="list-style-type: none"> <li>1. Check for loose or faulty plug connections between the remote board and the weld/output controls. See the wiring diagram.</li>   <li>2. The Remote Board may be faulty.</li>   <li>3. The control board may be faulty.</li> </ol>

**CAUTION**

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-800-833-9353(WELD).

V350-PRO



Return to Section TOC

Return to Master TOC

# TROUBLESHOOTING & REPAIR

## TROUBLESHOOTING GUIDE

Observe Safety Guidelines detailed in the beginning of this manual.

PROBLEMS (SYMPTOMS)	POSSIBLE AREAS OF MISADJUSTMENT(S)	RECOMMENDED COURSE OF ACTION
<b>FUNCTION PROBLEMS</b>		
The display is not functioning properly.	<ol style="list-style-type: none"> <li>1. Refer to the <b>Operation Section</b> of this manual for normal operation characteristics.</li> <li>2. Check for proper current and voltage calibration.</li> </ol>	<ol style="list-style-type: none"> <li>1. Check for loose or faulty plug connections between the Display board and the control board. See the wiring diagram.</li> <li>2. The display board may be faulty.</li> <li>3. The control board may be faulty.</li> </ol>
A fault or error code is displayed.	<ol style="list-style-type: none"> <li>1. See the <b>Fault Code Explanations</b>.</li> </ol>	<ol style="list-style-type: none"> <li>1. See <b>Fault Code Explanations</b>.</li> </ol>
For no apparent reason the welding characteristics have change.	<ol style="list-style-type: none"> <li>1. Check the welding cables for loose or faulty connection.</li> <li>2. Make sure the machine's mode and output are set correctly for the process being used. (CV, CC,TIG etc.)</li> <li>3. If Mig welding make sure the shielding gas and wire speed are correct for the process being used.</li> <li>4. Check for proper current and voltage calibration.</li> </ol>	<ol style="list-style-type: none"> <li>1. Perform the <b>Voltage and Current Calibration Procedure</b>.</li> <li>2. Perform the <b>Current Transducer Test</b>.</li> <li>3. Perform the <b>Output Diode Module Test</b></li> <li>4. The control board may be faulty.</li> <li>5. The advanced process panel (If used) may be faulty.</li> </ol>

**CAUTION**

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-800-833-9353(WELD).

V350-PRO



Return to Section TOC  
Return to Master TOC



## TROUBLESHOOTING & REPAIR

FAULT CODES	DESCRIPTION/ DEFINITION	CORRECTIVE ACTION	SERVICE FACILITY CORRECTIVE ACTION
31	Main transformer primary over current	Turn the machine off and back on to reset the machine. If condition persists, contact an authorized Lincoln Field Service Facility.	<p>Perform the <b>Main Switch Board Test</b>.</p> <p>Perform the <b>Power Board Test</b>.</p> <p>There may be a problem with the primary current sensors (CT) located on the main switch board. See the Wiring diagram</p> <p>The control board may be faulty.</p>
32	Capacitor bank "A" (lower) is under voltage	Make sure the reconnect switches are configured for the input voltage being applied to the machine. The machine is self clearing when condition ceases.	<p>There may be a problem with the V/F signals from the main switch board to the control board.</p> <p>Perform the <b>Main Switch Board Test</b>.</p> <p>Perform the <b>Power Board Test</b>.</p> <p>The control board may be faulty.</p>

**NOTE:** If more than one fault message is being displayed, perform all the checks for the faults before replacing the printed circuit board

V350-PRO



## TROUBLESHOOTING & REPAIR

FAULT CODES	DESCRIPTION/ DEFINITION	CORRECTIVE ACTION	SERVICE FACILITY CORRECTIVE ACTION
33	Capacitor bank "B"(upper) is under voltage.	Make sure the reconnect switches are configured for the input voltage being applied to the machine. The machine is self-clearing when condition ceases.	<p>There may be a problem with the V/F signals from the main switch board to the control board.</p> <p>Perform the <b>Main Switch Board Test</b>.</p> <p>Perform the <b>Power Board Test</b>.</p> <p>The control board may be faulty.</p>
34	Capacitor bank "A"(lower) is over voltage.	Make sure the reconnect switches are configured for the input voltage being applied to the machine. The machine is self-clearing when condition ceases.	<p>There may be a problem with the V/F signals from the main switch board to the control board.</p> <p>Perform the <b>Main Switch Board Test</b>.</p> <p>Perform the <b>Power Board Test</b>.</p> <p>The control board may be faulty.</p>

**NOTE:** If more than one fault message is being displayed, perform all the checks for the faults before replacing the printed circuit board  
V350-PRO



Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

## TROUBLESHOOTING & REPAIR

FAULT CODES	DESCRIPTION/ DEFINITION	CORRECTIVE ACTION	SERVICE FACILITY CORRECTIVE ACTION
35	Capacitor bank "B"(lower) is over voltage.	Make sure the reconnect switches are configured for the input voltage being applied to the machine. The machine is self-clearing when condition ceases.	<p>There may be a problem with the V/F signals from the main switch board to the control board.</p> <p>Perform the <b>Main Switch Board Test</b>.</p> <p>Perform the <b>Power Board Test</b>.</p> <p>The control board may be faulty.</p>
37	The soft start function failed.	Turn the machine off and back on to reset the machine.	<p>There may be a problem with the V/F signals from the main switch board to the control board.</p> <p>Perform the <b>Main Switch Board Test</b>.</p> <p>Perform the <b>Power Board Test</b>.</p> <p>The control board may be faulty.</p>

**NOTE:** If more than one fault message is being displayed, perform all the checks for the faults before replacing the printed circuit board  
V350-PRO



Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

## TROUBLESHOOTING & REPAIR

FAULT CODES	DESCRIPTION/ DEFINITION	CORRECTIVE ACTION	SERVICE FACILITY CORRECTIVE ACTION
39	Electrical "glitch" on the primary over current fault detector circuit.	Possibly caused by an external electrical "noise" or signal level. Make sure the V350-Pro is grounded correctly. The machine is self clearing when condition ceases.	<p>Perform the <b>Main Switch Board Test</b>.</p> <p>Perform the <b>Power Board Test</b>.</p> <p>There may be a problem with the primary current sensors (CT) located on the main switch board. See the wiring diagram.</p> <p>The control board may be faulty.</p>
43	Capacitor banks "A" (lower) and "B"(upper) are not balanced.	Make sure the reconnect switches are configured for the input voltage being applied to the machine. The machine is self-clearing when condition ceases.	<p>There may be a problem with the V/F signals from the main switch board to the control board.</p> <p>Perform the <b>Main Switch Board Test</b>.</p> <p>The capacitor(s) may be faulty. Check and replace if necessary.</p>
44	The machine has detected a fault in the central processing unit (CPU).	Make sure the V350-Pro is grounded correctly. The machine is self clearing when condition ceases.	<p>Perform the <b>Power Board Test</b>.</p> <p>The control board or associated wiring may be faulty. See the wiring diagram.</p>

**NOTE:** If more than one fault message is being displayed, perform all the checks for the faults before replacing the printed circuit board

V350-PRO



## TROUBLESHOOTING & REPAIR

FAULT CODES	DESCRIPTION/ DEFINITION	CORRECTIVE ACTION	SERVICE FACILITY CORRECTIVE ACTION
47	Electrical "glitch" on the V/F signals from the main switch board to the control board.	Possibly caused by an external electrical "noise" or signal level. Make sure the V350-Pro is grounded correctly. The machine is self clearing when condition ceases.	<p>There may be a problem with the V/F signals from the main switch board to the control board.</p> <p>Perform the <b>Main Switch Board Test</b>.</p> <p>Perform the <b>Power Board Test</b>.</p> <p>The control board may be faulty.</p>
"bad node" "####"	The selected weld mode does not exist in the weld table that is presently loaded in the machine.	Press the Mode Select button to select a different welding mode.	<p>If new software was just installed, try reinstalling the software or put the original software back.</p> <p>Perform the <b>Power Board Test</b>.</p> <p>Perform the <b>SPI Cable Resistance and Voltage Test</b>.</p> <p>The control board may be faulty.</p>

**NOTE:** If more than one fault message is being displayed, perform all the checks for the faults before replacing the printed circuit board

V350-PRO



Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

# TROUBLESHOOTING & REPAIR

## INPUT FILTER CAPACITOR DISCHARGE PROCEDURE



### WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-800-833-9353 (WELD).

### DESCRIPTION

This procedure will drain off any charge stored in the four large capacitors that are part of the switch board assembly. This procedure **MUST** be performed, as a safety precaution, before conducting any test or repair procedure that requires you to touch internal components of the machine.

### MATERIALS NEEDED

- 5/16" Nut Driver
- Insulated Pliers
- Insulated Gloves
- High Wattage Resistor (25-1000 ohms and 25 watts minimum)
- DC Volt Meter

**This procedure takes approximately 20 minutes to perform.**

V350-PRO





## INPUT FILTER CAPACITOR DISCHARGE PROCEDURE *(continued)*

### **⚠ WARNING**

**ELECTRIC SHOCK** can kill.




- Have an electrician install and service this equipment.
- Turn the input power off at the fuse box before working on equipment.
- Do not touch electrically hot parts.
- Prior to performing preventative maintenance, perform the following capacitor discharge procedure to avoid electric shock.

### DISCHARGE PROCEDURE

1. Remove the input power to the V350-PRO.
2. Using the 5/16" wrench remove the screws from the case wraparound cover.
3. Be careful not to make contact with the capacitor terminals located at the top and bottom of the switch board.

4. Obtain a high resistance and high wattage resistor (25-1000 ohms and 25 watts minimum). This resistor is not with the machine. NEVER USE A SHORTING STRAP FOR THIS PROCEDURE.
5. Locate the eight capacitor terminals shown in figure F.1.
6. Using electrically insulated gloves and pliers, hold the body of the resistor with the pliers and connect the resistor leads across the two capacitor terminals. Hold the resistor in place for 10 seconds. DO NOT TOUCH CAPACITOR TERMINALS WITH YOUR BARE HANDS.
7. Repeat the discharge procedure for the other three capacitors.
8. Check the voltage across the terminals of all capacitors with a DC voltmeter. Polarity of the capacitor terminals is marked on the PC board above the terminals. Voltage should be zero. If any voltage remains, repeat this capacitor discharge procedure.

FIGURE F.1 – LOCATION OF INPUT FILTER CAPACITOR TERMINALS



V350-PRO

**LINCOLN**  
ELECTRIC

# TROUBLESHOOTING & REPAIR

## MAIN SWITCH BOARD TEST



### WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-800-833-9353 (WELD).

### DESCRIPTION

This test will help determine if the “power section” of the switch boards are functioning correctly. This test will NOT indicate if the entire PC board is functional. This resistance test is preferable to a voltage test with the machine energized because this board can be damaged easily. In addition, it is dangerous to work on this board with the machine energized.

### MATERIALS NEEDED

- Analog Volt/Ohmmeter
- 5/16 in. Wrench
- 7/16 in. Wrench

**This procedure takes approximately 30 minutes to perform.**


V350-PRO



# TROUBLESHOOTING & REPAIR

## MAIN SWITCH BOARD TEST (continued)

FIGURE F.2 MAIN SWITCH BOARD LEAD LOCATIONS



### TEST PROCEDURE

1. Remove input power to the V350-PRO.
2. Using a 5/16" nut driver, remove the case wraparound.
3. Perform the **Input Filter Capacitor Discharge Procedure** detailed earlier in this section.
4. Using a 7/16" wrench locate, label and remove leads 201, 202, 203, 204, 205, 206, 207 and 208 from the switch board. Note lead and washer placement for reassembly. Clear leads.
5. Using the Analog ohmmeter, perform the resistance tests detailed in **Table F.1**. Refer to figure F.2 for test point locations. Note: Test using an Analog ohmmeter on the Rx1 range. Make sure the test probes are making electrical contact with the conductor surfaces on the PC board.

V350-PRO

**LINCOLN**<sup>®</sup>  
**ELECTRIC**

# TROUBLESHOOTING & REPAIR

## MAIN SWITCH BOARD TEST *(continued)*

6. If any test fails replace the switch board. See **Main Switch Board Removal and Replacement.**
7. If the switch board resistance tests are OK, check connections on plugs J20, J21, J22 and all associated wiring. See wiring diagram.
8. Reconnect leads 201, 202, 203, 204, 205, 206, 207, and 208 to the switch board. Ensure that the leads are installed in their proper locations. Pre-Torque all leads nuts to 25 inch lbs. before tightening them to 44 inch lbs.
9. Replace the case wraparound cover using a 5/16" nut driver.

**TABLE F.1. SWITCH BOARD RESISTANCE TEST**

APPLY POSITIVE TEST PROBE TO TERMINAL	APPLY NEGATIVE TEST PROBE TO TERMINAL	NORMAL RESISTANCE READING
+206	-205	Greater than 1000 ohms
+208	-203	Greater than 1000 ohms
+202	-204	Greater than 1000 ohms
+201	-207	Greater than 1000 ohms
+205	-206	Less than 100 ohms
+203	-208	Less than 100 ohms
+204	-202	Less than 100 ohms
+207	-201	Less than 100 ohms

# NOTES

---

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

V350-PRO



# TROUBLESHOOTING & REPAIR

## INPUT RECTIFIER TEST



### WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-800-833-9353 (WELD).

---

### DESCRIPTION

This test will help determine if the input rectifier has “shorted” or “open” diodes.

### MATERIALS NEEDED

- Analog Voltmeter/Ohmmeter (Multimeter)
- 5/16” Nut Driver
- Phillips Head Screwdriver
- Wiring Diagram

This procedure takes approximately 25 minutes to perform.

V350-PRO




# TROUBLESHOOTING & REPAIR

## INPUT RECTIFIER TEST (CONTINUED)

### TEST PROCEDURE

1. Remove input power to the V350-PRO machine.
2. Using a 5/16" nut driver, remove the case wraparound cover.
3. Perform the **Capacitor Discharge Procedure** detailed earlier in this section.
4. Locate the input rectifier and associated leads. See Figure F.3.
5. Carefully remove the silicone sealant from leads 207, 207A, and 209.
6. Using a phillips head screwdriver, remove leads 207, 207A, and 209 from the input rectifier.
7. Use the analog ohmmeter to perform the tests detailed in **Table F.2**. See the Wiring Diagram.
8. Visually inspect the three MOV'S for damage (TP1,TP2,TP3). Replace if necessary.

Figure F.3 Input Rectifier



Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

# TROUBLESHOOTING & REPAIR

## INPUT RECTIFIER TEST (CONTINUED)

Table F.2 Input Rectifier Test Points

TEST POINT TERMINALS		ANALOG METER X10 RANGE
+ PROBE	- PROBE	Acceptable Meter Readings
A	207	Greater than 1000 ohms
B	207	Greater than 1000 ohms
C	207	Greater than 1000 ohms
A	207A	Greater than 1000 ohms
B	207A	Greater than 1000 ohms
C	207A	Greater than 1000 ohms
A	209	Less than 100 ohms
B	209	Less than 100 ohms
C	209	Less than 100 ohms
207	A	Less than 100 ohms
207	B	Less than 100 ohms
207	C	Less than 100 ohms
207A	A	Less than 100 ohms
207A	B	Less than 100 ohms
207A	C	Less than 100 ohms
209	A	Greater than 1000 ohms
209	B	Greater than 1000 ohms
209	C	Greater than 1000 ohms

9. If the input rectifier does not meet the acceptable readings outlined in Table F.2 the component may be faulty. Replace

**Note:** Before replacing the input rectifier, check the input power switch and perform the **Main Switch Board Test**. Also check for leaky or faulty filter capacitors.

10. If the input rectifier is good, be sure to reconnect leads 207, 207A, and 209 to the correct terminals and torque to 31 inch lbs. Apply silicone sealant.

11. If the input rectifier is faulty, see the **Input Rectifier Bridge Removal & Replacement** procedure.

12. Replace the case wraparound cover.



# NOTES

---

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

V350-PRO



# TROUBLESHOOTING & REPAIR

## POWER BOARD TEST



### WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-800-833-9353 (WELD).

### DESCRIPTION

This test will help determine if the power board is receiving the correct voltages and also if the power board is regulating and producing the correct DC voltages.

### MATERIALS NEEDED

Volt-Ohmmeter  
5/16" Nut Driver  
Wiring Diagram

**This procedure takes approximately 30 minutes to perform.**

V350-PRO




# TROUBLESHOOTING & REPAIR

## POWER BOARD TEST (CONTINUED)

### TEST PROCEDURE

1. Remove input power to the V350-PRO machine.
2. Using a 5/16" nut driver, remove the case wraparound cover.
3. Perform the **Capacitor Discharge Procedure** detailed earlier in this section.
4. Locate the power board and plugs J41, J42 and J43. **Do not remove plugs from the power board.** See Figure F.4.
5. Carefully apply the correct input voltage to the V350-PRO.
6. Carefully test for the correct voltages at the power board. **See Table F.3.**
7. If the 40VDC is low, or not present at plug J41, check the rectifier bridge and C5 filter capacitor. See Wiring Diagram. Also perform the **Auxiliary Transformer Test.**
8. If any of the DC voltages are low, or not present at plugs J42 or J43, the power board may be faulty.
9. Remove the input power to the V350-PRO.
10. Replace the case wraparound cover using a 5/16" nut driver.

Figure F.4 Power Board Plug Location



V350-PRO

**LINCOLN**<sup>®</sup>  
**ELECTRIC**

# TROUBLESHOOTING & REPAIR

## POWER BOARD TEST (CONTINUED)

Table F.3 Power Board Voltage Checks

CHECK POINT LOCATION	TEST DESCRIPTION	CONNECTOR PLUG PIN NO.	LEAD NO. OR IDENTITY	NORMAL ACCEPTABLE VOLTAGE READING
POWER PC BOARD CONNECTOR PLUG J41	CHECK 40VDC SUPPLY FROM RECT. BRIDGE TO POWER BD.	<p>2(+) 1(-) 65 66</p>	65 (+) 66 (-)	38-42 VDC
POWER PC BOARD CONNECTOR PLUG J42	CHECK +15VDC SUPPLY FROM POWER PC BOARD	<p>1(+) 5(-) 410 412</p>	412 (+) 410 (-)	15 VDC
POWER PC BOARD CONNECTOR PLUG J42	CHECK +5VDC SUPPLY FROM POWER PC BOARD	<p>3(+) 5(-) 410 408</p>	408 (+) 410 (-)	5 VDC
POWER PC BOARD CONNECTOR PLUG J42	CHECK -15VDC SUPPLY FROM POWER PC BOARD	<p>2(+) 5(-) 410 411</p>	411 (+) 410 (-)	-15 VDC
POWER PC BOARD CONNECTOR PLUG J43	CHECK +5VDC "SPI" SUPPLY FROM POWER PC BOARD	<p>3(+) 12(-) 401 403</p>	403 (+) 401 (-)	5 VDC
POWER PC BOARD CONNECTOR PLUG J43	CHECK +5VDC "RS232" SUPPLY FROM POWER PC BOARD	<p>4(+) 9(-) 405 406</p>	406 (+) 405 (-)	5 VDC
POWER PC BOARD CONNECTOR PLUG J43	CHECK +15VDC "SPI" SUPPLY FROM POWER PC BOARD	<p>6(+) 12(-) 401 402</p>	402 (+) 401 (-)	15 VDC

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC  
Return to Master TOC  
Return to Section TOC  
Return to Master TOC  
Return to Section TOC  
Return to Master TOC  
Return to Section TOC  
Return to Master TOC

# TROUBLESHOOTING & REPAIR

## OUTPUT DIODE MODULES TEST



### WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-800-833-9353 (WELD).

---

### DESCRIPTION

This test will help determine if any of the output diodes are “shorted”.

### MATERIALS NEEDED

Analog Voltmeter/Ohmmeter  
Wiring Diagram

**This procedure takes approximately 20 minutes to perform.**


V350-PRO



# TROUBLESHOOTING & REPAIR

## OUTPUT DIODE MODULES TEST *(continued)*

FIGURE F.5 Machine Output Terminals



### TEST PROCEDURE

1. Remove input power to the V350-PRO.
2. Locate the output terminals on the front panel of the machine. See Figure F.5.
3. Remove any output cables and load from the output terminals.
4. Using the analog ohmmeter test for more than 200 ohms resistance between positive and negative output terminals. Positive test lead to the positive terminal; Negative test lead to the negative terminal. **See Figure F.6.**

**NOTE:** The polarity of the test leads is most important. If the test leads polarity is not correct, the test will have erroneous results.


V350-PRO



# TROUBLESHOOTING & REPAIR

## OUTPUT DIODE MODULES TEST (continued)

Figure F.6 Terminal Probes



5. If 200 ohms is measured then the output diodes are not “shorted”.  
**NOTE:** There is a 250 ohm resistor across the welding output terminals.
6. If less than 200 ohms is measured, one or more diodes or the snubber board may be faulty.
7. Perform the **Filter Capacitor Discharge Procedure** detailed earlier in this section.
8. Locate the output diode modules and snubber board. **See Figure F.7.**
9. Test all output diode modules individually.

**NOTE:** This may require the disassembly of the leads and the snubber board from the diode modules. Refer to the **Output Diode Modules Removal and Replacement Procedure** for detailed instructions.

V350-PRO

**LINCOLN**<sup>®</sup>  
ELECTRIC




# TROUBLESHOOTING & REPAIR

## OUTPUT DIODE MODULES TEST *(continued)*

Return to Section TOC  
Return to Section TOC  
Return to Section TOC  
Return to Section TOC  
Return to Master TOC  
Return to Master TOC  
Return to Master TOC

Figure F.7 Snubber and Output Diode Locations



# TROUBLESHOOTING & REPAIR

## AUXILIARY TRANSFORMER TEST



### WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-800-833-9353 (WELD).

---

### DESCRIPTION

This procedure will determine if the correct voltage is being applied to the primary of auxiliary transformer and also if the correct voltage is being induced on the secondary windings of the transformer.

### MATERIALS NEEDED

- Volt-ohmmeter (Multimeter)
- 5/16" Nut Driver
- Wiring Diagram

**This procedure takes approximately 25 minutes to perform.**


V350-PRO



# TROUBLESHOOTING & REPAIR

## AUXILIARY TRANSFORMER TEST (continued)


FIGURE F.8 Auxiliary Transformer



### TEST PROCEDURE

1. Remove input power to the V350-PRO.
2. Using a 5/16" nut driver, remove the case wraparound cover.
3. Perform the **Input Capacitor Discharge Procedure** detailed earlier in this section.
4. Locate the auxiliary transformer. See Figure F.8.
5. Locate the secondary leads and plug P52. See Figure F.8 and F.9.

FIGURE F.9 Plug Lead Connections Viewed From Transformer Lead Side of Plug



V350-PRO



Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

# TROUBLESHOOTING & REPAIR

## AUXILIARY TRANSFORMER NO.1 TEST *(continued)*

TABLE F.4

LEAD IDENTIFICATION	NORMAL EXPECTED VOLTAGE
31 TO 532	115 VAC
42 TO 541	42 VAC
24 TO 541	24 VAC
54 TO 541	28 VAC

7. Carefully apply the correct input voltage to the V350-PRO and check for the correct secondary voltages per table F.4. Make sure the reconnect jumper lead and switch are configured correctly for the input voltage being applied. Make sure circuit breaker (CB3) is functioning properly.

**NOTE:** The secondary voltages will vary if the input line voltage varies.

8. If the correct secondary voltages are present, the auxiliary transformer is functioning properly. If any of the secondary voltages are missing or low, check to make certain the primary is configured correctly for the input voltage applied. See Wiring Diagram.



### WARNING

**High voltage is present at primary of Auxiliary Transformer.**

9. If the correct input voltage is applied to the primary, and the secondary voltage(s) are not correct, the auxiliary transformer may be faulty.
10. Remove the input power to the V350-PRO.
11. Install the case wraparound cover using a 5/16" nut driver.

V350-PRO



# NOTES

---

Return to Section TOC      Return to Section TOC      Return to Section TOC  
Return to Master TOC      Return to Master TOC      Return to Master TOC

V350-PRO



# TROUBLESHOOTING AND REPAIR

## CURRENT TRANSDUCER TEST



### WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-800-833-9353 (WELD).

---

### DESCRIPTION

This test will help determine if the current transducer and associated wiring are functioning correctly.

### MATERIALS NEEDED

- Volt-ohmmeter
- 5/16" Nut Driver
- Resistive Load Bank
- External DC Ammeter

**This procedure takes approximately 45 minutes to perform.**


V350-PRO



# TROUBLESHOOTING AND REPAIR

## CURRENT TRANSDUCER TEST (continued)

FIGURE F.10 Metal Plate Removal & Plug J8 Location




Plug J8

### TEST PROCEDURE

1. Remove input power to the V350-PRO.
2. Using the 5/16" nut driver, remove the case wraparound cover.
3. Perform the **Input Capacitor Discharge Procedure**.
4. Locate plug J8 on the control board. Do not remove the plug from the P.C. Board.
5. Apply the correct input power to the V350-PRO.
6. Check for the correct DC supply voltages to the current transducer at plug J8. See Figure F.11.
  - A. Pin 2 (lead 802+) to pin 6 (lead 806-) should read +15 VDC.
  - B. Pin 4 (lead 804+) to pin 6 (lead 806-) should read -15 VDC.
7. If either of the supply voltages are low or missing, the control board may be faulty.

FIGURE F.11. Plug J8 Viewed From Lead Side of Plug



V350-PRO



Return to Section TOC  
 Return to Section TOC  
 Return to Section TOC  
 Return to Master TOC  
 Return to Master TOC  
 Return to Master TOC  
 Return to Master TOC

# TROUBLESHOOTING AND REPAIR

## CURRENT TRANSDUCER TEST *(continued)*

TABLE F.5

OUTPUT LOAD CURRENT	EXPECTED TRANSDUCER FEEDBACK VOLTAGE
300	2.4
250	2.0
200	1.6
150	1.2
100	0.8

8. Check the feedback voltage from the current transducer using a resistive load bank and with the V350-PRO in mode 200. Mode 200 is a constant current test mode. This mode can be accessed from the front panel of the V350 by pressing and holding the Mode Select button while turning the machine on. **NOTE:** Machines with an Advanced Process Panels do not have a mode select button. Use the same procedure except hold in the Memory button on the advanced process panel instead of the mode select button. Then, rotate the output knob while still holding the Mode Select button in until the displays read "Mode 200". Release the Mode Select Button and the machine will be in mode 200. With the V350-PRO in mode 200, apply the grid load across the output of the V350-PRO, set machine output to 300 amps and enable WELD TERMINALS. Adjust the grid load to obtain 300 amps on the external ammeter and check feedback voltages per Table F.5.
  - A. Pin 1 (lead 801) to Pin 6 (lead 806) should read 2.4 VDC (machine loaded to 300 amps).
9. If for any reason the machine cannot be loaded to 300 amps, Table F.5. shows what feedback voltage is produced at various current loads.
10. If the correct supply voltages are applied to the current transducer, and with the machine loaded, the feedback voltage is missing or not correct the current transducer may be faulty. Before replacing the current transducer, check the leads and plugs between the control board (J8) and the current transducer (J90). See The Wiring Diagram. For access to plug J90 and the current transducer refer to: ***Current Transducer Removal and Replacement Procedure.***
11. Remove input power to the V350-PRO.
12. Replace the control box top and any cable ties previously removed.
13. Install the case wraparound cover using the 5/16" nut driver.

V350-PRO





Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

V350-PRO



# TROUBLESHOOTING AND REPAIR

## FAN CONTROL AND MOTOR TEST



### WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-800-833-9353 (WELD).

---

### DESCRIPTION

This test will help determine if the fan motor, control board, switch board, or associated leads and connectors are functioning correctly.

### MATERIALS NEEDED

Voltmeter

5/16" Nut Driver

**This procedure takes approximately 40 minutes to perform.**

V350-PRO




# TROUBLESHOOTING AND REPAIR

## FAN CONTROL AND MOTOR TEST (continued)

### TEST PROCEDURE


1. Remove the input power to the V350-PRO machine.
2. Using the 5/16" nut driver, remove the case wraparound cover.
3. Perform the **Input Filter Capacitor Discharge Procedure**.
4. Locate plug J22 on the main switch board. Do not remove the plug from the board. See Figure F.12.

FIGURE F.12 PLUG J22 LOCATION



5. Carefully apply the correct input power to the machine.
6. Carefully check for 115VAC at plug J22 pin-2 to J22 pin-3. (leads 32A to 31B(C) See Figure F.13. **WARNING: HIGH VOLTAGE IS PRESENT AT THE MAIN SWITCH BOARD.**

FIGURE F.13 PLUG J22



V350-PRO



Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

# TROUBLESHOOTING AND REPAIR

## FAN CONTROL AND MOTOR TEST (continued)

7. If the 115VAC is low or not present check circuit breaker CB2 located on the front panel. If the circuit breaker is OK, perform **The Auxiliary Transformer Test**. Check plug J22, circuit breaker CB2 and associated leads for loose or faulty connections. See the Wiring Diagram.
8. Energize the weld output terminals (Select Weld Terminals ON) and carefully check for 115VAC at plug J22 pin-1 to J22 pin-4 (fan leads). **See Figure F.13**. If the 115VAC is present and the fan is not running then the fan motor may be faulty. Also check the associated leads between plug J22 and the fan motor for loose or faulty connections. See the Wiring Diagram. **WARNING: HIGH VOLTAGE IS PRESENT AT THE SWITCH BOARD.**
9. If the 115VAC is NOT present in the previous step then proceed to the fan control test.

### FAN CONTROL TEST PROCEDURE

1. Locate plug J20 on the switch board. Do not remove the plug from the switch board. See **Figure F.12** and F.14.
2. Energize the weld output terminals (Select Weld Terminals ON) and carefully check for +15VDC at plug J20 pin-6+ to J20 pin-2- (leads 715 to 716). See Figure F.14. If the 15VDC is present and the fan is not running then the switch board may be faulty. If the 15VDC is not present when the weld terminals are energized then the control board may be faulty. Also check plugs J20, J7, and all associated leads for loose or faulty connections. See the Wiring Diagram.


**WARNING: HIGH VOLTAGE IS PRESENT AT THE SWITCH BOARD.**

3. Remove the input power to the V350-PRO.

**Note:** The fan motor may be accessed by the removal of the rear panel detailed in **The Current Transducer Removal and Replacement Procedure**.

4. Replace the case wrap-around cover.

FIGURE F.14 PLUG J20



V350-PRO

**LINCOLN**<sup>®</sup>  
**ELECTRIC**

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

# TROUBLESHOOTING AND REPAIR

---

## SPI CABLE RESISTANCE AND VOLTAGE TEST



### WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-800-833-9353 (WELD).

---

### DESCRIPTION

This test will help determine if there is a possible “open” in the SPI cable and also determine if the correct supply voltages are being applied to the boards in the SPI network.

### MATERIALS NEEDED

Volt/Ohmmeter

5/16” Nut Driver

**This procedure takes approximately 35 minutes to perform.**

V350-PRO




# TROUBLESHOOTING AND REPAIR

## SPI CABLE RESISTANCE AND VOLTAGE TEST *(continued)*

### TEST PROCEDURE

1. Remove the input power to the V350-PRO.
2. Using the 5/16" nut driver, remove the case wraparound cover.
3. Perform the **Capacitor Discharge Procedure**.
4. Perform the **Display Board Removal Procedure**. Do not remove the SPI ribbon cable connecting the display board to the remote/status boards.
5. Locate and remove plug J3 from the control board. See Figure F.15.
6. Check the resistance and continuity of the SPI cable by testing with the ohmmeter from each pin on plug J3 to the corresponding pins on plug J34. See the Wiring Diagram.
7. The resistance reading pin to corresponding pin should be zero ohms or very low resistance. If the resistance reading is high or "open" check the plug connections to the SPI network PC boards. If the connections are OK and the resistance is high or "open" the SPI cable may be faulty.
8. Reconnect the plug into the control board and perform the **Display Board Replacement Procedure**.
9. With plug J3 still removed from the control board, carefully apply the correct input power to V350-PRO.
10. Turn on the machine.
11. Carefully check for the presence of +15VDC from plug J3 pin -1(+) to plug J3 pin -10(-) at the control board receptacle. See Figure F.15.
12. Carefully check for the presence of +5VDC from plug J3 pin -2(+) to plug J3 pin -10(-) at the control board receptacle. See Figure F.15.
13. If either of these voltages are low or not present, the control board may be faulty. Replace. Also Perform the **Power Board Test**.
14. Remove the input power to the V350-PRO machine.
15. Replace plug J3 into the control board.
16. Replace any cable ties previously removed.
17. Replace the case wrap-around cover.

FIGURE F.15 Plug J3



V350-PRO



# TROUBLESHOOTING AND REPAIR

## VOLTAGE AND CURRENT CALIBRATION PROCEDURE



### WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-800-833-9353 (WELD).

---

### DESCRIPTION

This test will help determine if the machine is capable of producing welding output and to check and adjust, if necessary, the voltage and or current calibration.

### MATERIALS NEEDED

- Resistive Load Bank
- Calibrated Test Voltmeter
- Calibrated Test Ammeter

**This procedure takes approximately 20 minutes to perform.**

V350-PRO





# TROUBLESHOOTING AND REPAIR

## VOLTAGE AND CURRENT CALIBRATION PROCEDURE *(continued)*

### CALIBRATION CHECK

The calibration of the V350-PRO can be checked using a resistive load bank with the V350-PRO in mode 200. Mode 200 is a constant current test mode.

1. Press and hold in the Mode Select button.
2. Turn on the V350-PRO.
3. Rotate the output knob, while still holding the mode select button in, until the displays read "mode 200". **NOTE:** Machines with an Advanced Process Panels do not have a mode select button. Use the same procedure except hold in the Memory button on the advanced process panel instead of the mode select button.
4. Release the Mode Select/Memory button and the machine will be in mode 200.
5. With the machine in mode 200 apply a resistive load to the welding output terminals (approximately .087 ohms) set the machine output to 300 amps and enable the Weld Terminals. (Weld Terminals Select ON).
6. Using the test meters note the output voltage and current.
7. The V350-PRO voltmeter must match the test meter reading to within +/- 1 volt.
8. The V350-PRO ammeter must match the test meter within +/- 5 amps.
9. If the voltmeter does not meet the specification then proceed to the **Voltage Calibration Procedure**.
10. If the ammeter does not meet the specification then proceed to the **Current Calibration Procedure**.

**NOTE:** Before attempting to calibrate the voltage or current setting of the V350-PRO, be sure to read the entire voltage or current calibration section. If the steps are not completed quickly, the machine will automatically leave the calibration mode without changing the calibration settings. The voltage and current calibration settings of the V350-PRO are completely independent of each other. Adjusting one will not affect the other.

### VOLTAGE CALIBRATION

1. Connect the resistive load band (approximately .087 ohms) and test voltmeter to the welding output terminals.
2. Press and hold in the Mode Select/Memory button.
3. Turn on the V350-PRO.
4. Rotate the Output Control knob until the display reads "vol cAL".
5. Release the Mode Select/Memory button.
6. Adjust the output control knob until the actual output voltage reading on the test volt meter is 20volts +/- .5 volts.
7. Wait for the machine's output to be automatically turned off and then back on.
8. Adjust the Output Control knob again if necessary to make the actual voltage output 20 volts +/- .5 volts.
9. Wait for the machine's output to be automatically turned off and then back on.
10. Repeat the above two steps if necessary.
11. Press and release the Mode Select/Memory button to save the calibration.

**NOTE:** If the Mode Select/Memory button is not pressed within 30 seconds after adjusting the Output Control knob the machine will leave the calibration mode and use the previous calibration settings.

V350-PRO



# TROUBLESHOOTING AND REPAIR

## VOLTAGE AND CURRENT CALIBRATION PROCEDURE *(continued)*

### CURRENT CALIBRATION PROCEDURE

1. Connect the resistive load band (approximately .087 ohms) and test ammeter to the welding output terminals.
2. Press and hold in the Mode Select/Memory button.
3. Turn on the V350-PRO.
4. Rotate the Output Control knob until the display reads "cur cAL".
5. Release the Mode Select/Memory button.
6. The left display will change to "IcAL" to indicate that current calibration is in progress.
7. The right display will scroll the following message: Adj oCP SorEAL cur-300A.
8. Adjust the Output Control knob until the actual output current reading on the test ammeter is 300amps +/-2A.
9. Wait for the machines output to be automatically turned off and then back on.
10. Adjust the Output Control knob again if necessary to make the actual output current reading on the test ammeter 300 amps +/-2A.
11. Wait for the machines output to be automatically turned off and then back on.
12. Repeat the above two steps if necessary.
13. Press and release the Mode Select/Memory button to save the calibration.
14. The left display will scroll the message IcAL SAVEd.
15. The machine will reset to normal operation.

**NOTE:** If the Mode Select/Memory button is not pressed within 30 seconds after adjusting the Output Control knob the machine will leave the calibration mode and use the previous calibration settings.

V350-PRO



Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

# TROUBLESHOOTING & REPAIR

## CONTROL BOARD REMOVAL AND REPLACEMENT



### WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-800-833-9353 (WELD).

### DESCRIPTION

The following procedure will aid the technician in removing the control board for maintenance or replacement.

### MATERIALS NEEDED

- 5/16" Nut Driver
- 3/8" Nut Driver
- Flathead Screwdriver
- Phillips Head Screwdriver

This procedure takes approximately 30 minutes to perform.


V350-PRO



# TROUBLESHOOTING & REPAIR

## CONTROL BOARD REMOVAL AND REPLACEMENT *(continued)*


FIGURE F.16 - CONTROL BOARD LOCATION



### PROCEDURE

1. Remove input power to the V350-PRO.
2. Using a 5/16" nut driver remove the case wrap-around cover.
3. Perform the ***Input Filter Capacitor Discharge Procedure*** detailed earlier in this section.
4. Locate the control board behind the front panel of the machine. See Figure F.16.
5. Using a 5/16" nut driver remove the two screws from the bottom of the front of the machine. See Figure F.17.

FIGURE F.17 CASE FRONT SCREW REMOVAL



V350-PRO



Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC

Return to Master TOC


Return to Master TOC

Return to Master TOC

# TROUBLESHOOTING & REPAIR

## CONTROL BOARD REMOVAL AND REPLACEMENT (continued)

FIGURE F.18. - CONTROL BOARD ALL PLUG LOCATIONS



### ⚠ CAUTION

Observe static precautions detailed in **PC Board Troubleshooting Procedures** at the beginning of this section.

6. Using a flat head screwdriver remove the two screws and their washers from above and below the input power switch. See **Figure F.17**.
7. Using a phillips head screwdriver remove the four screws from around the two welder output terminals on the front of the machine. See **Figure F.17**.
8. The front of the machine may now gently be pulled forward to gain access to the display Board. Note: The front of the machine cannot be removed completely, only pulled forward a few inches.
9. Beginning at the right side of the control board remove plugs J10A and J10B. Note: Be sure to label each plugs position upon removal. See **Figure F.18**.
10. Working your way across the top of the board from right to left, label and remove plugs #J9, #J8, #J7, #J6, and #J5. See **Figure F.18**.
11. Working your way down the left side of the board, label and remove plugs #J4 and #J3. See **Figure F.18**.

V350-PRO


**LINCOLN**  
ELECTRIC

## TROUBLESHOOTING & REPAIR

### CONTROL BOARD REMOVAL AND REPLACEMENT *(continued)*

12. Using a 3/8" nut driver remove the two mounting nuts from the top two corners of the control board. See Figure F.19.
13. Cut any necessary cable ties.
14. Replace the control board.

**FIGURE F.19 CONTROL BOARD MOUNTING SCREW LOCATION**



15. Replace the two 3/8" mounting nuts at the top two corners of the control board.
16. Replace any previously removed cable ties.
17. Replace plugs #J3, #J4, #J5, #J6, #J7, #J8, #J9, #J10B, and #J10A previously removed.
18. Replace the two screws and their washers from above and below the input power switch.
19. Replace the four screws from around the two welder output terminals on the front of the machine.
20. Replace the two case front mounting screws at the bottom of the front of the machine.
21. Replace the case wraparound cover.
22. Perform the **Voltage and Current Calibration Procedure**.

V350-PRO



# TROUBLESHOOTING & REPAIR

## DISPLAY BOARD REMOVAL AND REPLACEMENT



### WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call or 1-800-833-9353 (WELD).

### DESCRIPTION

The following procedure will aid the technician in removing the display board for maintenance or replacement.

### MATERIALS NEEDED

5/16" Nut Driver

Flathead Screwdriver

Phillips Head Screwdriver

**This procedure takes approximately 30 minutes to perform.**

V350-PRO






# TROUBLESHOOTING & REPAIR

## DISPLAY BOARD REMOVAL & REPLACEMENT *(continued)*

FIGURE F.20. – DISPLAY BOARD LOCATION



### PROCEDURE

1. Remove input power to the V350-PRO.
2. Using a 5/16" nut driver remove the case wraparound cover.
3. Perform the ***Input Filter Capacitor Discharge Procedure*** detailed earlier in this section.
4. Locate the display board behind the front panel of the machine. See Figure F.20.


V350-PRO



# TROUBLESHOOTING & REPAIR

## DISPLAY BOARD REMOVAL & REPLACEMENT *(continued)*

FIGURE F.21. - CASE FRONT SCREW LOCATION



- Using a 5/16" nut driver remove the two screws from the bottom of the front of the machine. See Figure F.21.
- Using a flat head screwdriver remove the two screws and their washers from above and below the input power switch. See Figure F.21.
- Using a phillips head screwdriver remove the four screws from around the two welder output terminals on the front of the machine. See Figure F.21.
- The front of the machine may now gently be pulled forward to gain access to the display Board. Note: The front of the machine cannot be removed completely, only pulled forward a few inches.
- The display board is now accessible to replace.

V350-PRO

**LINCOLN**<sup>®</sup>  
**ELECTRIC**

## TROUBLESHOOTING & REPAIR

---

### DISPLAY BOARD REMOVAL & REPLACEMENT *(continued)*

10. Remove plug J37 from the display board. See the Wiring Diagram.
11. Remove plug J3 originating from the control board located directly across from the display board. See the Wiring Diagram.
12. Remove the display board. Note: Gentle prying from behind the board may be required.
13. Replace the display board.
14. Replace plugs #J3 and #J37 previously removed.
15. Replace the four phillips head screws removed from the front of the machine located around the two welder output terminals.
16. Replace the two flat head screws and their washers mounting the input power switch.
17. Using a 5/16" nut driver replace the two screws previously removed from the bottom front of the machine.
18. Replace the case wraparound cover.

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

V350-PRO



# TROUBLESHOOTING & REPAIR

## MAIN SWITCH BOARD REMOVAL AND REPLACEMENT



### WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-800-833-9353 (WELD).

### DESCRIPTION

The following procedure will aid the technician in removing the main switch board for maintenance or replacement.

### MATERIALS NEEDED

5/16" Nut Driver

Flathead Screwdriver

7/16" mm Socket

3/16" Allen Wrench

3/8" Nut Driver

**This procedure takes approximately 35 minutes to perform.**


V350-PRO



# TROUBLESHOOTING & REPAIR

## MAIN SWITCH BOARD REMOVAL & REPLACEMENT (continued)

FIGURE F.22. – MAIN SWITCH BOARD LEAD LOCATIONS



### PROCEDURE

1. Remove the input power to the V350-PRO.
2. Using a 5/16" nut driver remove the case wrap-around cover.
3. Perform the **Input Filter Capacitor Discharge Procedure** detailed earlier in this section.
4. Locate the main switch board and all associated plug and lead connections. See figure F.22. See Wiring Diagram.
5. Using a 5/16" and 3/8" nut driver remove the input lead shield from the area at the bottom of the main switch board.
6. Using a 7/16" socket, remove leads 201, 202, 203, 204, 205, 206, 207, 208, 209 from the switch board. Note lead terminal locations and washer positions upon removal.
7. Locate and disconnect the three harness plugs associated with the main switch board. Plugs #J20, #J21, #J22. See Figure F.22.
8. Locate the eight capacitor terminals and remove the nuts using a 7/16" socket or nut driver. Note the position of the washers behind each nut for replacement.

### CAUTION


Observe static precautions detailed in **PC Board Troubleshooting Procedures** at the beginning of this section. Failure to do so can result in permanent damage to equipment.

V350-PRO

**LINCOLN**<sup>®</sup>  
**ELECTRIC**


## MAIN SWITCH BOARD REMOVAL & REPLACEMENT *(continued)*

FIGURE F.23. – 3/16" ALLEN BOLT LOCATION



9. Using a 3/16" allen wrench remove four allen bolts and washers as shown in Figure F.23. At this point, the board is ready for removal. Carefully remove the board from the 4 nylon mounting pins. Note: Depress the retaining pins on the sides of the nylon mounts to release the board. See Figure F.24.
10. Carefully maneuver the board out of the machine.
11. Apply a thin coat of Penetrox A-13 to the IGBT heatsinks on the back of the new switch boards mating surfaces. Note: Keep compound away from the mounting holes.
12. Mount the new board on the nylon mounting pins.
13. Replace the four allen bolts and washers previously removed.
14. Replace the eight capacitor terminal nuts, washers, and necessary leads previously removed.
15. Reconnect the three harness plugs previously removed.
16. Reconnect the nine leads (#201-#209) that were previously removed.
17. Pre-torque all screws to 25 inch lbs. before tightening to 44 inch lbs.
18. Replace the case wraparound cover.

FIGURE F.24. – NYLON MOUNTING PIN



DEPRESS  
LOCKING TAB ON  
MOUNTING PIN

V350-PRO

**LINCOLN**<sup>®</sup>  
**ELECTRIC**

# NOTES

---

Return to Section TOC      Return to Section TOC      Return to Section TOC  
Return to Master TOC      Return to Master TOC      Return to Master TOC

V350-PRO



# TROUBLESHOOTING & REPAIR

## ADVANCED PROCESS PANEL REMOVAL AND REPLACEMENT



### WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-800-833-9353 (WELD).

### DESCRIPTION

The following procedure will aid the technician in removing the mode board for maintenance or replacement.

### MATERIALS NEEDED

- 5/16" Nut Driver
- Small Flathead Screwdriver
- Flathead Screwdriver
- Small Phillips Head Screwdriver
- Phillips Head Screwdriver
- 9/16" Wrench

**This procedure takes approximately 40 minutes to perform.**

V350-PRO






# TROUBLESHOOTING & REPAIR

## ADVANCED PROCESS PANEL REMOVAL AND REPLACEMENT *(continued)*

FIGURE F.25. – MODE BOARD LOCATION



### PROCEDURE

1. Remove input power to the V350-PRO.
2. Using a 5/16" nut driver remove the case wraparound cover.
3. Perform the **Input Filter Capacitor Discharge Procedure** detailed earlier in this section.
4. Locate the advanced process board behind the front panel of the machine. See Figure F.25.


V350-PRO



# TROUBLESHOOTING & REPAIR

## ADVANCED PROCESS PANEL REMOVAL AND REPLACEMENT *(continued)*

FIGURE F.26. – CASE FRONT SCREW REMOVAL



5. Using a 5/16" nut driver remove the two screws from the bottom of the front of the machine. See Figure F.26.
6. Using a flat head screwdriver remove the two screws and their washers from above and below the input power switch. See Figure F.26..
7. Using a phillips head screwdriver remove the four screws from around the two welder output terminals on the front of the machine. See Figure F.26.
8. The front of the machine may now gently be pulled forward to gain access to the mode board. Note: The front of the machine cannot be removed completely, only pulled forward a few inches.


V350-PRO

**LINCOLN**<sup>®</sup>  
**ELECTRIC**

# TROUBLESHOOTING & REPAIR

## ADVANCED PROCESS PANEL REMOVAL AND REPLACEMENT *(continued)*

FIGURE F.27.. – CASE FRONT



9. Remove plug #J33 from the remote board. See the Wiring Diagram.
10. Open the cover of the weld mode display on the front of the machine.
11. Using a 5/16" nut driver, remove the three 5/16" screws as shown in Figure F.27.
12. Place both knobs in the six o'clock position.
13. Using a small flathead screwdriver, loosen the screw in the "Select" knob and the "Adjust" knob. The knobs should slide off of their shafts. **See Figure F.28.**
14. Using a 9/16" wrench remove the nuts and their washers behind the two knobs previously removed.
15. Perform the **Remote Board Removal Procedure. (Start at step #10)**
16. Using a phillips head screwdriver remove the two phillips head mounting screws at the bottom of the Advanced Process board.
17. Remove the Advanced Process board.


V350-PRO

**LINCOLN**<sup>®</sup>  
**ELECTRIC**

## TROUBLESHOOTING & REPAIR

### ADVANCED PROCESS PANEL REMOVAL AND REPLACEMENT *(continued)*

FIGURE F.28. – SCREW IN CAP



- |  |   |
|--|---|
| 18. Replace the Advanced Process board.  | 25. Replace the four phillips head screws removed from the front of the machine located around the two welder output terminals. |
| 19. Replace the two phillips head screws at the bottom of the advanced process board.  | 26. Replace the two flat head screws and their washers from around the input power switch.                                      |
| 20. Perform the <b>Remote Board Replacement Procedure</b> .  | 27. Using a 5/16" nut driver replace the two screws previously removed from the bottom front of the machine                     |
| 21. Replace the 9/16" nuts and their washers behind the "Adjust" and "Select" knobs.   | 28. Replace the case wraparound cover.  |
| 22. Using a small screwdriver replace the two knobs previously removed.  |   |
| 23. Replace the three 5/16" screws previously removed from the front of the machine located around the Advanced Process board. |   |
| 24. Reconnect plug #J33 previously removed.  |   |

V350-PRO



# NOTES

---

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

# TROUBLESHOOTING & REPAIR

## REMOTE BOARD REMOVAL AND REPLACEMENT



### WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-800-833-9353 (WELD).

### DESCRIPTION

The following procedure will aid the technician in removing the status board for maintenance or replacement.

### MATERIALS NEEDED

- 5/16" Nut Driver
- Flathead Screwdriver
- Phillips Head Screwdriver

This procedure takes approximately 30 minutes to perform.

V350-PRO




# TROUBLESHOOTING & REPAIR

## REMOTE BOARD REMOVAL AND REPLACEMENT (*continued*)

### PROCEDURE

1. Remove input power to the V350-PRO.
2. Using a 5/16" nut driver remove the case wrap-around cover.
3. Perform the ***Input Filter Capacitor Discharge Procedure*** detailed earlier in this section.
4. Locate the remote board behind the front panel of the machine. See Figure F.29.

FIGURE F.29. – REMOTE BOARD LOCATION



V350-PRO


**LINCOLN**<sup>®</sup>  
**ELECTRIC**

# TROUBLESHOOTING & REPAIR

## REMOTE BOARD REMOVAL AND REPLACEMENT *(continued)*

5. Using a 5/16" nut driver remove the two screws from the bottom front of the machine. See Figure F.30.
6. Using a flat head screwdriver remove the two screws and their washers from around the input power switch. See Figure F.30.
7. Using a phillips head screwdriver remove the four screws from around the two welder output terminals on the front of the machine. See Figure F.30.
8. The front of the machine may now gently be pulled forward to gain access to the remote Board.  
Note: The front of the machine cannot be removed completely, only pulled forward a few inches.
9. The remote board is now accessible to replace.

FIGURE F.30. - FRONT SCREW REMOVAL



V350-PRO

**LINCOLN**<sup>®</sup>  
**ELECTRIC**




# TROUBLESHOOTING & REPAIR

## REMOTE BOARD REMOVAL AND REPLACEMENT *(continued)*

- |  |  |
|--|--|
| <p>10. Remove plug J37 from the display board. See Wiring Diagram.</p> <p>11. Remove plugs J33, J333 and J331 from the remote board.</p> <p>12. Using a flat head screwdriver, remove the two mounting screws and washers from the bottom of the remote board. See Figure F.31.</p> <p>13. Remove the remote board.</p> <p>14. Replace the remote board.</p> <p>15. Replace the two flat head mounting screws and washers previously removed from the bottom of the remote board.</p> <p>16. Replace plugs J331, J333, J33 and previously removed from the remote board.</p> | <p>17. Replace plug J37 previously removed from the display board.</p> <p>18. Replace the four phillips head screws removed from the front of the machine located around the two welder output terminals.</p> <p>19. Replace the two flat head screws and their washers from around the input power switch.</p> <p>20. Using a 5/16" nut driver replace the two screws previously removed from the bottom front of the machine</p> <p>21. Replace the case wraparound cover.</p> |
|--|--|

**FIGURE F.31. – REMOTE BOARD (PLUG LOCATION)**



V350-PRO

**LINCOLN**<sup>®</sup>  
**ELECTRIC**

# TROUBLESHOOTING & REPAIR

---

## SNUBBER BOARD REMOVAL AND REPLACEMENT



### WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-800-833-9353 (WELD).

---

### DESCRIPTION

The following procedure will aid the technician in removing the snubber board for maintenance or replacement.

### MATERIALS NEEDED

5/16" Nut Driver

7/16 Socket or Nut Driver

**This procedure takes approximately 15 minutes to perform.**

V350-PRO




# TROUBLESHOOTING & REPAIR

## SNUBBER BOARD REMOVAL AND REPLACEMENT (continued)

### PROCEDURE

1. Remove input power to the V350-PRO.
2. Using a 5/16" nut driver remove the case wrap-around cover.
3. Perform the **Input Filter Capacitor Discharge Procedure** detailed earlier in this section.
4. Locate the snubber board.. See Figure F.32.

FIGURE F.32. – SNUBBER BOARD LOCATION




Snubber Board

### LEFT SIDE

5. Remove small lead #B1 from the board. See Figure F.33.
6. Remove the four bolts using a 7/16" socket. Two of these bolts have leads #30 and #10 connected to them. Note the position of all leads and associated washers upon removal.
7. Carefully remove the snubber board.
8. Replace the snubber board.
9. Replace the bolts, leads, and washers previously removed. Torque bolt to 30-40 Inch Lbs.
10. Replace the case wraparound cover.

FIGURE F.33. – SNUBBER BOARD LEADS (CLOSE UP)



V350-PRO

**LINCOLN**<sup>®</sup>  
**ELECTRIC**

# TROUBLESHOOTING & REPAIR

---

## POWER BOARD REMOVAL AND REPLACEMENT



### WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-800-833-9353 (WELD).

---

### DESCRIPTION

The following procedure will aid the technician in removing the power board for maintenance or replacement.

### MATERIALS NEEDED

- 5/16" Nut Driver
- 3/8" Nut Driver

**This procedure takes approximately 20 minutes to perform.**


V350-PRO



# TROUBLESHOOTING & REPAIR

## POWER BOARD REMOVAL AND REPLACEMENT *(continued)*

FIGURE F.34. POWER BOARD LOCATION



### PROCEDURE

1. Remove input power to the V350-PRO.
2. Using a 5/16" nut driver remove the case wrap-around cover.
3. Perform the ***Input Filter Capacitor Discharge Procedure*** detailed earlier in this section.
4. Locate the power board. See Figure F.34.

V350-PRO




# TROUBLESHOOTING & REPAIR

## POWER BOARD REMOVAL AND REPLACEMENT *(continued)*

5. Locate the three plug connections. J41, J42 and J43. See figure F.35.
6. Carefully remove the three plugs from the power board.
7. Remove the three nuts and at the corners of the board using a 3/8" nut driver. Board is ready for removal.
8. Remove the power board.
9. Replace with new power board.
10. Secure the new power board into its proper position with the three 3/8" nuts previously removed.
11. Replace the three plugs previously removed. Plugs J41, J42 and J43.
12. Replace the case wraparound cover.

**FIGURE F.35. – POWER BOARD LEAD LOCATION**



V350-PRO

**LINCOLN**<sup>®</sup>  
**ELECTRIC**

# NOTES

---

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

V350-PRO



# TROUBLESHOOTING & REPAIR

---

## INPUT RECTIFIER REMOVAL AND REPLACEMENT



### WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-800-833-9353 (WELD).

---

### DESCRIPTION

The following procedure will aid the technician in removing the input rectifier for maintenance or replacement.

### MATERIALS NEEDED

- 3/16" Allen wrench
- 5/16" Nut Driver
- Flathead Screwdriver
- Penetrox A-13 Heatsink Compound
- Silicon Sealant

**This procedure takes approximately 30 minutes to perform.**

V350-PRO






# TROUBLESHOOTING & REPAIR

## INPUT RECTIFIER REMOVAL AND REPLACEMENT *(continued)*

### PROCEDURE

1. Remove input power to the V350-PRO.
2. Using a 5/16" nut driver remove the case wraparound cover.
3. Perform the **Input Filter Capacitor Discharge Procedure** detailed earlier in this section.
4. Locate the input rectifier. See figure F.36.
5. Carefully remove the silicon sealant insulating the six input rectifier terminals.
6. Remove the six screws from the terminals using a flathead screwdriver. Carefully note the position of all leads and their positions upon removal. **See Figure F.37.**
7. Using a 3/16" in. allen wrench remove the two mounting screws and washers from the input bridge. **See Figure F.37.**
8. Remove the input bridge.

FIGURE F.36. – INPUT RECTIFIER LOCATION



V350-PRO


**LINCOLN**<sup>®</sup>  
**ELECTRIC**

# TROUBLESHOOTING & REPAIR

## INPUT RECTIFIER REMOVAL AND REPLACEMENT *(continued)*

- |   |   |
|---|---|
| <p>9. Apply a thin coat of Penetrox A-13 heatsink compound to the point of contact between the input rectifier and the mounting surface.</p> <p>10. Secure the new input bridge into its proper position with the two 3/16" in. allen mounting screws previously removed. Torque to 44 inch pounds.</p> | <p>11. Reconnect the previously removed leads to their proper locations. Torque to 31 inch pounds.</p> <p>12. Cover the input rectifier and its six terminals with silicon sealant.</p> <p>13. Replace the case wraparound cover.</p> |
|---|---|

**FIGURE F.37. - INPUT RECTIFIER (CLOSE-UP)**



V350-PRO



Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

# NOTES

---

Return to Section TOC      Return to Section TOC      Return to Section TOC  
Return to Master TOC      Return to Master TOC      Return to Master TOC

V350-PRO



# TROUBLESHOOTING & REPAIR

---

## OUTPUT RECTIFIER MODULES REMOVAL AND REPLACEMENT



### WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-800-833-9353 (WELD).

---

### DESCRIPTION

The following procedure will aid the technician in removing the output rectifier modules for maintenance or replacement.

### MATERIALS NEEDED

- 3/16" Allen wrench
- 9/64" Allen wrench
- 5/16" Nut Driver
- 7/16" Wrench
- Flathead Screwdriver
- Penetrox A-13 Heatsink Compound
- Thin Knife/Screwdriver

**This procedure takes approximately 30 minutes to perform.**

V350-PRO



# TROUBLESHOOTING & REPAIR


## OUTPUT RECTIFIER MODULES

### REMOVAL AND REPLACEMENT (*continued*)

#### PROCEDURE

1. Remove input power to the V350-PRO.
2. Using a 5/16" nut driver remove the case wrap-around cover.
3. Perform the **Input Filter Capacitor Discharge Procedure** detailed earlier in this section.
4. Locate the output diode modules located behind the snubber board. See figure F.38.
5. Before the output rectifier modules can be reached, the **Snubber Board Removal Procedure** must be performed.
6. After the snubber board is removed, remove the four leads connected to the modules using a 3/16" allen wrench. These leads are #X4, #X2, #20, #40. Note their positions for reassembly. **See Figure F.39.**
7. Remove the copper plates from the tops of the modules.

FIGURE F.38. – OUTPUT RECTIFIER MODULE LEAD LOCATIONS



V350-PRO

**LINCOLN**<sup>®</sup>  
**ELECTRIC**


# TROUBLESHOOTING & REPAIR

## OUTPUT RECTIFIER MODULES

### REMOVAL AND REPLACEMENT (*continued*)

8. Under the copper plate previously removed, there is an allen bolt. Remove it using a 9/64" allen wrench. See Figure F.39.
9. Using a 7/16" socket remove the mounting bolts at the top and bottom of the modules. See Figure F.39.
10. The output rectifier modules are ready for removal and/or replacement.
11. Before replacing the diode module, apply a thin even coat of Penetrox A-13 heatsink compound to the bottom surface of the diode module. Note: Keep the compound away from the mounting holes.
12. Press the module firmly against the sink while aligning the mounting holes. Insert each outer screw through a spring washer and then a plain washer and into the holes. Start threading all three screws into the heat sink (2 or 3 turns by hand).
13. The screw threads may catch on the threads of the heat sink, so be sure to get the face of the screw into contact with the surface of the module (using just hand torque).
14. Using a 7/16" socket, tighten each mounting bolt to between 5 and 10 inch pounds.
15. Tighten the center allen screw to between 12 and 18 inch pounds.
16. Tighten each mounting bolt again (30 to 40 inch pounds this time).
15. Replace leads #X2, #X4, #20, #40 to their original terminals in their proper positions. Torque bolts to 30-40 Inch Pounds.
16. Perform the **Snubber Board Replacement Procedure** detailed earlier in this section.
17. Replace the case wraparound cover.

**FIGURE F.39. - OUTPUT RECTIFIER MODULE MOUNTING BOLT LOCATIONS**



V350-PRO

**LINCOLN**<sup>®</sup>  
**ELECTRIC**

Return to Section TOC  
Return to Master TOC  
Return to Section TOC  
Return to Master TOC  
Return to Section TOC  
Return to Master TOC  
Return to Section TOC  
Return to Master TOC

# TROUBLESHOOTING & REPAIR

## CURRENT TRANSDUCER REMOVAL AND REPLACEMENT



### WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-800-833-9353 (WELD).

---

### DESCRIPTION

The following procedure will aid the technician in removing the current transducer for maintenance or replacement.

### MATERIALS NEEDED

- 5/16" Nut Driver
- 1/4" Nut Driver
- 1/2" Nut driver
- 3/8" Nut Driver
- Channel Locks
- Flathead Screwdriver
- Phillips Head Screwdriver
- Hammer
- Crescent Wrench
- Pliers

This procedure takes approximately 45 minutes to perform.

V350-PRO






## TROUBLESHOOTING & REPAIR

### CURRENT TRANSDUCER REMOVAL AND REPLACEMENT *(continued)*

#### PROCEDURE

1. Remove input power to the V350-PRO.
2. Using a 5/16" nut driver remove the case wrap-around cover.
3. Perform the ***Input Filter Capacitor Discharge Procedure*** detailed earlier in this section.
4. Using a 5/16" nut driver remove the four screws from the bottom and right side of the rear assembly. See Figure F.40.

FIGURE F.40. – CASE BACK SCREW LOCATIONS



V350-PRO


**LINCOLN**<sup>®</sup>  
**ELECTRIC**

## TROUBLESHOOTING & REPAIR

### CURRENT TRANSDUCER REMOVAL AND REPLACEMENT *(continued)*

5. Label and remove the five leads connected to the reconnect panel. Pliers may be necessary.
6. Label and remove the two leads connected to the CB2 circuit breaker.
7. Using a crescent wrench, remove the large plastic nut from around the input power line located at bottom of the rear assembly. See Figure F.41.
8. Locate the steel nut located directly on the other side of the rear assembly behind the plastic nut that was previously removed. See Figure F.41.
9. Using a hammer and a flathead screwdriver, firmly tap the metal nut from the bottom of one of its ribs. This tapping will loosen the nut. Note: Be sure to tap from the bottom so the nut loosens in a counter clockwise fashion if viewed from the front of the machine.
10. Using a 3/8" nut driver label and remove leads #202, #203, #206, #207A from the reconnect switches. See Figure F.41.

FIGURE F.41. LEAD LOCATIONS



V350-PRO


**LINCOLN**<sup>®</sup>  
**ELECTRIC**

## TROUBLESHOOTING & REPAIR

### CURRENT TRANSDUCER REMOVAL AND REPLACEMENT *(continued)*

11. The back of the machine may now gently be pulled away to gain access to the current transducer. Note: The rear of the machine cannot be removed completely.
12. Carefully swing the rear of the machine open to the left while facing the rear of the machine.
13. Perform the **Snubber Board Removal Procedure**.
14. Remove leads #X2 and #20 from the output diode module.
15. Remove leads #X4 and #40 from the other output diode module.
16. Using a 3/8" wrench, remove the three mounting screws from the output diode heatsink assembly. Take note placement of insulation for reassembly. See Figure F.42.
17. Cut any necessary cable ties and carefully remove the heavy lead from the diode heatsink using a 1/2" nut driver.
18. Remove the output diode heatsink assembly through the rear of the machine.
19. Remove plug #J90 from the current transducer.
20. Using a 3/8" nut driver, remove the two mounting nuts from the current transducer.

**FIGURE F.42- OUTPUT HEATSINK MOUNTING SCREW LOCATION**



V350-PRO

**LINCOLN**<sup>®</sup>  
**ELECTRIC**

## TROUBLESHOOTING & REPAIR

### CURRENT TRANSDUCER REMOVAL AND REPLACEMENT (*continued*)

21. Replace the current transducer.
  22. Replace the two 3/8" mounting nuts previously removed.
  23. Reconnect plug #J90 to the current transducer.
  24. Replace any necessary cable ties previously cut.
  25. From the rear of the machine, replace the heavy flex lead to the bottom of the output diode heatsink assembly using a 1/2" wrench. Note: Don't forget to include all washers.
  26. Replace the output diode heatsink assembly previously removed using a 3/8" wrench.
- Note: **Be sure to place insulation in its original location.**
27. Replace leads X2, #20, X4, # 40 previously removed from the two output diode modules. Torque to 30-40 inch lbs.
  28. Perform the ***Snubber Board Replacement Procedure***.
  29. The rear of the machine may now be placed back into its original position.
  30. Using a 3/8" wrench, replace leads #202, #203, #206, and #207A previously removed from the reconnect switches.
  31. Tighten the metal nut previously removed from the inside of the rear wall on the back of the machine. Channel locks may be necessary.
  32. Replace the large plastic nut from around input power line located at the back of the machine.
  33. Replace the five leads to the reconnect panel in their proper locations.
  34. Replace the two CB2 circuit breaker leads previously removed.
  35. Using a 5/16" nut driver, replace the four screws at the bottom and right side of the rear assembly.
  36. Replace the case wraparound cover.
  37. Perform the ***Voltage and Current Calibration Procedure***.

V350-PRO



# TROUBLESHOOTING AND REPAIR

## RETEST AFTER REPAIR

Retest a machine:

If it is rejected under test for any reason that requires you to remove any part which could affect the machine's electrical characteristics.

If you repair or replace any electrical components:

Press and hold the MODE SELECT button (or the MEMORY button if an advanced process panel is installed) while applying power to the machine. Rotate the output control knob until the display reads SPIdIAG. Release the MODE SELECT button.

Test Steps	Required Action	Expected Results	
		Lft. display	Rt. display
1	Adjust the output control potentiometer to its highest setting (completely clockwise).	oCP	HI
2	Adjust the output control potentiometer to its lowest setting (completely counterclockwise).	oCP	Lo
NOTE: If a standard Mode Select Panel is not installed in the machine, skip steps 3-12			
3	Adjust the hot start potentiometer to its highest setting.	HSP	HI
4	Adjust the hot start potentiometer to its lowest setting.	HSP	Lo
5	Adjust the arc control potentiometer to its highest setting.	ACP	HI
6	Adjust the arc control potentiometer to its lowest setting.	ACP	Lo
7	All weld mode indicator LEDs should be off. Press the weld mode select push button to select the first weld mode. Only the top weld mode indicator LED should be on, all others should be off.	NodE	1
8	Press the weld mode select push button again to select the second weld mode. Only the second weld mode indicator LED should be on, all others should be off.	NodE	2
9	Press the weld mode select push button again to select the third weld mode. Only the third weld mode indicator LED should be on, all others should be off.	NodE	3
10	Press the weld mode select push button again to select the fourth weld mode. Only the fourth weld mode indicator LED should be on, all others should be off.	NodE	4
11	Press the weld mode select push button again to select the fifth weld mode. Only the bottom weld mode indicator LED should be on, all others should be off.	NodE	5
12	Press the weld mode select push button again and verify that all weld mode indicator LEDs are off. <b>The test will automatically advance to step 25</b>	NodE	CLr

V350-PRO



Return to Section TOC

Return to Master TOC

**TROUBLESHOOTING AND REPAIR****RETEST AFTER REPAIR**

Test Steps	Required Action	Expected Results	
		Lft. display	Rt. display
<b>NOTE: If an Advanced Process Panel is not installed in the machine, skip steps 13-24</b>			
13	Turn the Advanced Process Panel left encoder clockwise until the value displayed on the Advanced Process Panel lower left display equals 100. Note that this should require exactly one revolution of the encoder knob.	LEnc	=100
14	Turn the Advanced Process Panel left encoder counter-clockwise until the value displayed on the Advanced Process Panel lower left display equals zero. Note that this should require exactly one revolution of the encoder knob.	LEnc	=0
15	Turn the Advanced Process Panel right encoder clockwise until the value displayed on the Advanced Process Panel lower left display equals 100. Note that this should require exactly one revolution of the encoder knob.	rEnc	=100
16	Turn the Advanced Process Panel right encoder counter-clockwise until the value displayed on the Advanced Process Panel lower left display equals zero. Note that this should require exactly one revolution of the encoder knob.	rEnc	=0
17	Press and hold the Advanced Process Panel Memory button until the right display changes to on.	EorY	oFF
18	Release the Advanced Process Panel Memory button.	EorY	on
19	Press and hold the Advanced Process Panel Select button.	rSEL	oFF
20	Release the Advanced Process Panel Select button.	rSEL	on
21	Verify that the Advanced Process Panel upper left display contains the following pattern and that the brightness of the characters is uniform: "0123456789ABCDEF" Press and release the Advanced Process Panel Memory button to advance to the next step.	dISP	1
22	Verify that the Advanced Process Panel lower left display contains the following pattern and that the brightness of the characters is uniform: "0123456789ABCDEF" Press and release the Advanced Process Panel Memory button to advance to the next step.	dISP	2

V350-PRO



**TROUBLESHOOTING AND REPAIR****RETEST AFTER REPAIR**

Test Steps	Required Action	Expected Results	
		Lft. display	Rt. display
23	Verify that the Advanced Process Panel upper right display contains the following pattern and that the brightness of the characters is uniform: "0123456789ABCDEF" Press and release the Advanced Process Panel Memory button to advance to the next step.	dISP	3
24	Verify that the Advanced Process Panel lower right display contains the following pattern and that the brightness of the characters is uniform: "0123456789ABCDEF" Press and release the Advanced Process Panel Memory button to advance to the next step.	dISP	4
25	The weld terminals "ON" and "REMOTE" LEDs should both be off. Press the weld terminals push button to select weld terminals (studs) "ON" and verify that the weld terminals "ON" LED turns on.	SudS	on
26	Press the weld terminals push button again to select weld terminals "REMOTE" and verify that the weld terminals "ON" LED turns off and that the weld terminals "REMOTE" LED turns on.	SudS	rE
27	Press the weld terminals push button again and verify that both of the weld terminals LEDs are off.	SudS	cLr
28	The "LOCAL" and "REMOTE" workpoint source LEDs should both be off. Press the workpoint source push button to select "LOCAL" and verify that the workpoint source "LOCAL" LED turns on and that the "REMOTE" workpoint source LED remains off.	LorE	LoCL
29	Press the workpoint source pushbutton again to select workpoint source "REMOTE" and verify that the workpoint source "LOCAL" LED turns off and the workpoint source "REMOTE" workpoint source LED turns on.	LorE	rE
30	Press the workpoint source pushbutton again and verify that both workpoint source LEDs are off.	LorE	cLr
31	This will only appear if a potentiometer is already connected to the 6-pin amphenol connector on the front of the machine. If this message appears, disconnect the potentiometer from the 6-pin amphenol connector.	dcon	6-PIn roCP
32	Connect a remote output control potentiometer to the 6-pin amphenol connector on the front of the machine.	con	6-PIn roCP

V350-PRO





**TROUBLESHOOTING AND REPAIR****RETEST AFTER REPAIR**

Test Steps	Required Action	Expected Results	
		Lft. display	Rt. display
33	Adjust the remote output control potentiometer connected to the 6-pin amphenol connector to its highest setting.	6-PIn roCP	HI
34	Adjust the remote output control potentiometer connected to the 6-pin amphenol connector to its lowest setting.	6-PIn roCP	Lo
35	This will only appear if a trigger switch is already connected to the 6-pin amphenol connector on the front of the machine and the trigger switch is presently on. Turn the trigger switch connected to the 6-pin amphenol connector off.	6-PIn rlgr	oFF
36	Turn the trigger switch connected to the 6-pin amphenol connector on.	6-PIn Rigr	on
37	Turn the trigger switch connected to the 6-pin amphenol connector off.	6-PIn rLgr	oFF
38	This will only appear if a potentiometer is still connected to the 6-pin amphenol connector. If this message appears, disconnect the potentiometer from the 6-pin amphenol connector.	dcon	6-PIn roCP
39	This will only appear if a potentiometer is already connected to the 14-pin amphenol connector. If this message appears, disconnect the potentiometer from the 14-pin amphenol connector.	dcon	14-PIn roCP
40	Connect a remote output control potentiometer to the 14-pin amphenol connector.	con	14-PIn roCP
41	Adjust the remote output control potentiometer connected to the 14-pin amphenol connector to its highest setting.	14-PIn roCP	HI
42	Adjust the remote output control potentiometer connected to the 14-pin amphenol connector to its lowest setting.	14-PIn roCP	Lo
43	This will only appear if a trigger switch is already connected to the 14-pin amphenol connector and the trigger switch is presently on. Turn the trigger switch connected to the 14-pin amphenol connector off.	14-PIn rlgr	oFF
44	Turn the trigger switch connected to the 14-pin amphenol connector on.	14-PIn rlgr	on
45	Turn the trigger switch connected to the 14-pin amphenol connector off.	14-PIn rlgr	oFF

V350-PRO





# TROUBLESHOOTING AND REPAIR

## RETEST AFTER REPAIR

Test Steps	Required Action	Expected Results	
		Lft. display	Rt. display
46	This will only appear if a potentiometer is still connected to the 14-pin amphenol connector. If this message appears, disconnect the potentiometer from the 14-pin amphenol connector.	dcon	14-pIn roCP
47	<p>Test steps 21-24 verify the functionality of the gas solenoid. If an oscilloscope is available, verify that the current flowing through the gas solenoid is zero before the solenoid is energized, increases to approximately 700mA (pull in current), remains at 700 mA for approximately 150 msec, and decreases to approximately 200mA (hold current). Press the local/remote pushbutton to turn the gas solenoid on.</p> <div style="text-align: center;"> <p>&lt; - 150msec - &gt;</p> </div> <p>Or, the signal can be verified by measuring 12.3 VDC +/- .5V from lead 553A to 554A (Lead 553A should be positive)</p>	GAS	On
48	Press the local/remote pushbutton again to turn the gas solenoid off.	GAS	OFF
<b>After completing all of the above tests, the following will appear on the display.</b>			
	Verify this message appears for approximately 3 seconds	DIAg	PASS

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

## TABLE OF CONTENTS -ELECTRICAL DIAGRAMS SECTION-

ELECTRICAL DIAGRAMS .....	SECTION G
WIRING DIAGRAM .....	G-2
MACHINE SCHEMATIC .....	G-3
CONTROL PC BOARD SCHEMATIC #1 .....	G-4
CONTROL PC BOARD SCHEMATIC #2 .....	G-5
CONTROL PC BOARD SCHEMATIC #3 .....	G-6
CONTROL PC BOARD SCHEMATIC #4 .....	G-7
CONTROL PC BOARD ASSEMBLY (L11088-1) .....	*
POWER SUPPLY PC BOARD SCHEMATIC .....	G-8
POWER SUPPLY PC BOARD ASSEMBLY (G3632-2) .....	*
SWITCH PC BOARD SCHEMATIC .....	G-9
SWITCH PC BOARD ASSEMBLY .....	G-10
DISPLAY PC BOARD SCHEMATIC .....	G-11
DISPLAY PC BOARD ASSEMBLY .....	G-12
LED SELECT PC BOARD SCHEMATIC .....	G-13
LED SELECT PC BOARD ASSEMBLY .....	G-14
LED POTENTIOMETER PC BOARD SCHEMATIC .....	G-15
LED POTENTIOMETER PC BOARD ASSEMBLY .....	G-16
SPI REMOTE PC BOARD SCHEMATIC .....	G-17
SPI REMOTE PC BOARD ASSEMBLY .....	G-18
SNUBBER PC BOARD SCHEMATIC .....	G-19
SNUBBER PC BOARD ASSEMBLY .....	G-20

\* NOTE: Many PC Board Assemblies are now totally encapsulated and are therefore considered to be unserviceable. The Assembly numbers are provided on this page but the actual drawings are no longer included.










SCHEMATIC - DIGITAL CONTROL PC BOARD #2

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC



NOTES:  
 N.A. SINCE COMPONENTS OR CIRCUITRY ON A PRINTED CIRCUIT BOARD MAY CHANGE WITHOUT AFFECTING THE INTERCHANGEABILITY OF A COMPLETE BOARD, THIS DIAGRAM MAY NOT SHOW THE EXACT COMPONENTS OR CIRCUITRY OF CONTROLS HAVING A COMMON CODE NUMBER.

THIS SHEET CONTAINS PROPRIETARY INFORMATION OWNED BY THE LINCOLN ELECTRIC CO. AND IS NOT TO BE REPRODUCED, DISCLOSED OR USED WITHOUT THE EXPRESS PERMISSION OF THE LINCOLN ELECTRIC CO.		DR. FM	DATE 08/02/2000	CHK.	SUP'D'G.	SHT. NO. G3789-100
UNLESS OTHERWISE SPECIFIED TOLERANCE	ON HOLES SIZES PER ASME	*X* INFO.				
ON 2 PLACE DECIMALS IS ± .02	ON 3 PLACE DECIMALS IS ± .002	6-2-2000A				
ON ALL ANGLES IS ± .5 OF A DEGREE	MATERIAL TOLERANCE (M) TO AGREE WITH PUBLISHED STANDARDS	8-4-2000P				

GENERAL INFORMATION  
 ELECTRICAL SYMBOLS PER E1537  
 CAPACITORS = MFD (.022/50V UNLESS OTHERWISE SPECIFIED)  
 RESISTORS = Ohms ( 1/4W UNLESS OTHERWISE SPECIFIED)  
 DIODES = 1A,400V (UNLESS OTHERWISE SPECIFIED)

FILENAME: G3789.1D

THE LINCOLN ELECTRIC CO.  
 CLEVELAND, OHIO U.S.A.

EQUIP. TYPE INVERTER WELDERS  
 SUBJECT SCHEMATIC, DIGITAL CONTROL


LAST NO. USED  
 R -  
 C -  
 D -

LEGEND:  
 ⏚ SUPPLY VOLTAGE NET  
 ⏚ POWER SUPPLY SOURCE POINT  
 ⏚ COMMON CONNECTION  
 ⏚ FRAME CONNECTION  
 ⏚ EARTH GROUND CONNECTION

NOTE: This diagram is for reference only. It may not be accurate for all machines covered by this manual.



SCHEMATIC - DIGITAL CONTROL PC BOARD #4



NOTE: This diagram is for reference only. It may not be accurate for all machines covered by this manual.



Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC

Return to Section TOC

Return to Master TOC




SCHEMATIC - POWER SUPPLY PRINTED CIRCUIT BOARD

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC



NOTES:  
 N/A. SINCE COMPONENTS OR CIRCUITRY ON A PRINTED CIRCUIT BOARD MAY CHANGE WITHOUT AFFECTING THE INTERCHANGEABILITY OF A COMPLETE BOARD, THIS DIAGRAM MAY NOT SHOW THE EXACT COMPONENTS OR CIRCUITRY OF CONTROLS HAVING A COMMON CODE NUMBER.


FILENAME: G3631-2D2											
GENERAL INFORMATION											
ELECTRICAL SYMBOLS PER E1537											
CAPACITORS = MFD / 525/50V UNLESS OTHERWISE SPECIFIED)											
RESISTORS = Ohms ( 1/4W UNLESS OTHERWISE SPECIFIED)											
DIODES = 1A, 60V ( UNLESS OTHERWISE SPECIFIED)											
<table border="0"> <tr> <td>LIST NO. USED</td> <td></td> </tr> <tr> <td>R.</td> <td></td> </tr> <tr> <td>C.</td> <td></td> </tr> <tr> <td>D.</td> <td></td> </tr> </table>		LIST NO. USED		R.		C.		D.			
LIST NO. USED											
R.											
C.											
D.											
<table border="0"> <tr> <td>▲</td> <td>SUPPLY VOLTAGE NET</td> </tr> <tr> <td>○</td> <td>POWER SUPPLY SOURCE POINT</td> </tr> <tr> <td>▽</td> <td>COMMON CONNECTION</td> </tr> <tr> <td>⌌</td> <td>FRAME CONNECTION</td> </tr> <tr> <td>⊥</td> <td>EARTH GROUND CONNECTION</td> </tr> </table>		▲	SUPPLY VOLTAGE NET	○	POWER SUPPLY SOURCE POINT	▽	COMMON CONNECTION	⌌	FRAME CONNECTION	⊥	EARTH GROUND CONNECTION
▲	SUPPLY VOLTAGE NET										
○	POWER SUPPLY SOURCE POINT										
▽	COMMON CONNECTION										
⌌	FRAME CONNECTION										
⊥	EARTH GROUND CONNECTION										

THIS SHEET CONTAINS PROPRIETARY INFORMATION OWNED BY THE LINCOLN ELECTRIC COMPANY AND IS NOT TO BE REPRODUCED, DISCLOSED OR USED WITHOUT THE EXPRESS WRITTEN PERMISSION OF THE LINCOLN ELECTRIC COMPANY, CLEVELAND, OHIO, U.S.A.	
DESIGN INFORMATION	REFERENCE
EQUIPMENT TYPE: Digital Systems	
SUBJECT: Schematic, Digital Power Supply	
SCALE: NONE	DATE: 11-30-98 DRAWING No.: G 3631

NOTE: This diagram is for reference only. It may not be accurate for all machines covered by this manual.



SCHEMATIC - SWITCH PRINTED CIRCUIT BOARD



**GENERAL INFORMATION**

ELECTRICAL SYMBOLS PER E1537  
 CAPACITORS = MFD ( / 22 / 51V UNLESS OTHERWISE SPECIFIED)  
 RESISTORS = OHMS ( / 1 / 4W UNLESS OTHERWISE SPECIFIED)  
 DIODES = 1A 40V UNLESS OTHERWISE SPECIFIED

**FILENAME:** L11487\_1C

**LAST NO. USED:**  
 R-43 X-4 1E-43  
 P-43 P-4 1E-43  
 C-2 Z-1 1E-43

**LABELS:**  
 ▲ SUPPLY VOLTAGE NET  
 ○ COMMON CONNECTION  
 ▽ FRAME CONNECTION  
 ⊕ EARTH GROUND CONNECTION

**THE LINCOLN ELECTRIC CO.**  
 CLEVELAND, OHIO U.S.A.

**SWITCH PCB SCHEMATIC**

PG # 01 SCALE NONE  
 DR. LL DATE 06/22/00 CHK. SHT. L 11487  
 SUPS/D/C.

**NOTES:**

N4. SINCE COMPONENTS OR CIRCUITRY ON A PRINTED CIRCUIT BOARD MAY CHANGE WITHOUT AFFECTING THE INTERCHANGEABILITY OF A COMPLETE BOARD, THIS DIAGRAM MAY NOT REPRESENT THE EXACT COMPONENTS OR CIRCUITRY OF CONTROLS HAVING A COMMON CODE NUMBER.

THIS SHEET CONTAINS PROPRIETARY INFORMATION OWNED BY THE LINCOLN ELECTRIC CO. AND IS NOT TO BE REPRODUCED, DISCLOSED OR USED WITHOUT THE EXPRESS PERMISSION OF THE LINCOLN ELECTRIC CO.

UNLESS OTHERWISE SPECIFIED TOLERANCE:  
 DIMENSIONS PER E-288  
 DIMENSIONS PER E-289  
 DIMENSIONS PER E-290  
 DIMENSIONS PER E-291  
 DIMENSIONS PER E-292  
 DIMENSIONS PER E-293  
 DIMENSIONS PER E-294  
 DIMENSIONS PER E-295  
 DIMENSIONS PER E-296  
 DIMENSIONS PER E-297  
 DIMENSIONS PER E-298  
 DIMENSIONS PER E-299  
 DIMENSIONS PER E-300  
 DIMENSIONS PER E-301  
 DIMENSIONS PER E-302  
 DIMENSIONS PER E-303  
 DIMENSIONS PER E-304  
 DIMENSIONS PER E-305  
 DIMENSIONS PER E-306  
 DIMENSIONS PER E-307  
 DIMENSIONS PER E-308  
 DIMENSIONS PER E-309  
 DIMENSIONS PER E-310  
 DIMENSIONS PER E-311  
 DIMENSIONS PER E-312  
 DIMENSIONS PER E-313  
 DIMENSIONS PER E-314  
 DIMENSIONS PER E-315  
 DIMENSIONS PER E-316  
 DIMENSIONS PER E-317  
 DIMENSIONS PER E-318  
 DIMENSIONS PER E-319  
 DIMENSIONS PER E-320  
 DIMENSIONS PER E-321  
 DIMENSIONS PER E-322  
 DIMENSIONS PER E-323  
 DIMENSIONS PER E-324  
 DIMENSIONS PER E-325  
 DIMENSIONS PER E-326  
 DIMENSIONS PER E-327  
 DIMENSIONS PER E-328  
 DIMENSIONS PER E-329  
 DIMENSIONS PER E-330  
 DIMENSIONS PER E-331  
 DIMENSIONS PER E-332  
 DIMENSIONS PER E-333  
 DIMENSIONS PER E-334  
 DIMENSIONS PER E-335  
 DIMENSIONS PER E-336  
 DIMENSIONS PER E-337  
 DIMENSIONS PER E-338  
 DIMENSIONS PER E-339  
 DIMENSIONS PER E-340  
 DIMENSIONS PER E-341  
 DIMENSIONS PER E-342  
 DIMENSIONS PER E-343  
 DIMENSIONS PER E-344  
 DIMENSIONS PER E-345  
 DIMENSIONS PER E-346  
 DIMENSIONS PER E-347  
 DIMENSIONS PER E-348  
 DIMENSIONS PER E-349  
 DIMENSIONS PER E-350  
 DIMENSIONS PER E-351  
 DIMENSIONS PER E-352  
 DIMENSIONS PER E-353  
 DIMENSIONS PER E-354  
 DIMENSIONS PER E-355  
 DIMENSIONS PER E-356  
 DIMENSIONS PER E-357  
 DIMENSIONS PER E-358  
 DIMENSIONS PER E-359  
 DIMENSIONS PER E-360  
 DIMENSIONS PER E-361  
 DIMENSIONS PER E-362  
 DIMENSIONS PER E-363  
 DIMENSIONS PER E-364  
 DIMENSIONS PER E-365  
 DIMENSIONS PER E-366  
 DIMENSIONS PER E-367  
 DIMENSIONS PER E-368  
 DIMENSIONS PER E-369  
 DIMENSIONS PER E-370  
 DIMENSIONS PER E-371  
 DIMENSIONS PER E-372  
 DIMENSIONS PER E-373  
 DIMENSIONS PER E-374  
 DIMENSIONS PER E-375  
 DIMENSIONS PER E-376  
 DIMENSIONS PER E-377  
 DIMENSIONS PER E-378  
 DIMENSIONS PER E-379  
 DIMENSIONS PER E-380  
 DIMENSIONS PER E-381  
 DIMENSIONS PER E-382  
 DIMENSIONS PER E-383  
 DIMENSIONS PER E-384  
 DIMENSIONS PER E-385  
 DIMENSIONS PER E-386  
 DIMENSIONS PER E-387  
 DIMENSIONS PER E-388  
 DIMENSIONS PER E-389  
 DIMENSIONS PER E-390  
 DIMENSIONS PER E-391  
 DIMENSIONS PER E-392  
 DIMENSIONS PER E-393  
 DIMENSIONS PER E-394  
 DIMENSIONS PER E-395  
 DIMENSIONS PER E-396  
 DIMENSIONS PER E-397  
 DIMENSIONS PER E-398  
 DIMENSIONS PER E-399  
 DIMENSIONS PER E-400  
 DIMENSIONS PER E-401  
 DIMENSIONS PER E-402  
 DIMENSIONS PER E-403  
 DIMENSIONS PER E-404  
 DIMENSIONS PER E-405  
 DIMENSIONS PER E-406  
 DIMENSIONS PER E-407  
 DIMENSIONS PER E-408  
 DIMENSIONS PER E-409  
 DIMENSIONS PER E-410  
 DIMENSIONS PER E-411  
 DIMENSIONS PER E-412  
 DIMENSIONS PER E-413  
 DIMENSIONS PER E-414  
 DIMENSIONS PER E-415  
 DIMENSIONS PER E-416  
 DIMENSIONS PER E-417  
 DIMENSIONS PER E-418  
 DIMENSIONS PER E-419  
 DIMENSIONS PER E-420  
 DIMENSIONS PER E-421  
 DIMENSIONS PER E-422  
 DIMENSIONS PER E-423  
 DIMENSIONS PER E-424  
 DIMENSIONS PER E-425  
 DIMENSIONS PER E-426  
 DIMENSIONS PER E-427  
 DIMENSIONS PER E-428  
 DIMENSIONS PER E-429  
 DIMENSIONS PER E-430  
 DIMENSIONS PER E-431  
 DIMENSIONS PER E-432  
 DIMENSIONS PER E-433  
 DIMENSIONS PER E-434  
 DIMENSIONS PER E-435  
 DIMENSIONS PER E-436  
 DIMENSIONS PER E-437  
 DIMENSIONS PER E-438  
 DIMENSIONS PER E-439  
 DIMENSIONS PER E-440  
 DIMENSIONS PER E-441  
 DIMENSIONS PER E-442  
 DIMENSIONS PER E-443  
 DIMENSIONS PER E-444  
 DIMENSIONS PER E-445  
 DIMENSIONS PER E-446  
 DIMENSIONS PER E-447  
 DIMENSIONS PER E-448  
 DIMENSIONS PER E-449  
 DIMENSIONS PER E-450  
 DIMENSIONS PER E-451  
 DIMENSIONS PER E-452  
 DIMENSIONS PER E-453  
 DIMENSIONS PER E-454  
 DIMENSIONS PER E-455  
 DIMENSIONS PER E-456  
 DIMENSIONS PER E-457  
 DIMENSIONS PER E-458  
 DIMENSIONS PER E-459  
 DIMENSIONS PER E-460  
 DIMENSIONS PER E-461  
 DIMENSIONS PER E-462  
 DIMENSIONS PER E-463  
 DIMENSIONS PER E-464  
 DIMENSIONS PER E-465  
 DIMENSIONS PER E-466  
 DIMENSIONS PER E-467  
 DIMENSIONS PER E-468  
 DIMENSIONS PER E-469  
 DIMENSIONS PER E-470  
 DIMENSIONS PER E-471  
 DIMENSIONS PER E-472  
 DIMENSIONS PER E-473  
 DIMENSIONS PER E-474  
 DIMENSIONS PER E-475  
 DIMENSIONS PER E-476  
 DIMENSIONS PER E-477  
 DIMENSIONS PER E-478  
 DIMENSIONS PER E-479  
 DIMENSIONS PER E-480  
 DIMENSIONS PER E-481  
 DIMENSIONS PER E-482  
 DIMENSIONS PER E-483  
 DIMENSIONS PER E-484  
 DIMENSIONS PER E-485  
 DIMENSIONS PER E-486  
 DIMENSIONS PER E-487  
 DIMENSIONS PER E-488  
 DIMENSIONS PER E-489  
 DIMENSIONS PER E-490  
 DIMENSIONS PER E-491  
 DIMENSIONS PER E-492  
 DIMENSIONS PER E-493  
 DIMENSIONS PER E-494  
 DIMENSIONS PER E-495  
 DIMENSIONS PER E-496  
 DIMENSIONS PER E-497  
 DIMENSIONS PER E-498  
 DIMENSIONS PER E-499  
 DIMENSIONS PER E-500  
 DIMENSIONS PER E-501  
 DIMENSIONS PER E-502  
 DIMENSIONS PER E-503  
 DIMENSIONS PER E-504  
 DIMENSIONS PER E-505  
 DIMENSIONS PER E-506  
 DIMENSIONS PER E-507  
 DIMENSIONS PER E-508  
 DIMENSIONS PER E-509  
 DIMENSIONS PER E-510  
 DIMENSIONS PER E-511  
 DIMENSIONS PER E-512  
 DIMENSIONS PER E-513  
 DIMENSIONS PER E-514  
 DIMENSIONS PER E-515  
 DIMENSIONS PER E-516  
 DIMENSIONS PER E-517  
 DIMENSIONS PER E-518  
 DIMENSIONS PER E-519  
 DIMENSIONS PER E-520  
 DIMENSIONS PER E-521  
 DIMENSIONS PER E-522  
 DIMENSIONS PER E-523  
 DIMENSIONS PER E-524  
 DIMENSIONS PER E-525  
 DIMENSIONS PER E-526  
 DIMENSIONS PER E-527  
 DIMENSIONS PER E-528  
 DIMENSIONS PER E-529  
 DIMENSIONS PER E-530  
 DIMENSIONS PER E-531  
 DIMENSIONS PER E-532  
 DIMENSIONS PER E-533  
 DIMENSIONS PER E-534  
 DIMENSIONS PER E-535  
 DIMENSIONS PER E-536  
 DIMENSIONS PER E-537  
 DIMENSIONS PER E-538  
 DIMENSIONS PER E-539  
 DIMENSIONS PER E-540  
 DIMENSIONS PER E-541  
 DIMENSIONS PER E-542  
 DIMENSIONS PER E-543  
 DIMENSIONS PER E-544  
 DIMENSIONS PER E-545  
 DIMENSIONS PER E-546  
 DIMENSIONS PER E-547  
 DIMENSIONS PER E-548  
 DIMENSIONS PER E-549  
 DIMENSIONS PER E-550  
 DIMENSIONS PER E-551  
 DIMENSIONS PER E-552  
 DIMENSIONS PER E-553  
 DIMENSIONS PER E-554  
 DIMENSIONS PER E-555  
 DIMENSIONS PER E-556  
 DIMENSIONS PER E-557  
 DIMENSIONS PER E-558  
 DIMENSIONS PER E-559  
 DIMENSIONS PER E-560  
 DIMENSIONS PER E-561  
 DIMENSIONS PER E-562  
 DIMENSIONS PER E-563  
 DIMENSIONS PER E-564  
 DIMENSIONS PER E-565  
 DIMENSIONS PER E-566  
 DIMENSIONS PER E-567  
 DIMENSIONS PER E-568  
 DIMENSIONS PER E-569  
 DIMENSIONS PER E-570  
 DIMENSIONS PER E-571  
 DIMENSIONS PER E-572  
 DIMENSIONS PER E-573  
 DIMENSIONS PER E-574  
 DIMENSIONS PER E-575  
 DIMENSIONS PER E-576  
 DIMENSIONS PER E-577  
 DIMENSIONS PER E-578  
 DIMENSIONS PER E-579  
 DIMENSIONS PER E-580  
 DIMENSIONS PER E-581  
 DIMENSIONS PER E-582  
 DIMENSIONS PER E-583  
 DIMENSIONS PER E-584  
 DIMENSIONS PER E-585  
 DIMENSIONS PER E-586  
 DIMENSIONS PER E-587  
 DIMENSIONS PER E-588  
 DIMENSIONS PER E-589  
 DIMENSIONS PER E-590  
 DIMENSIONS PER E-591  
 DIMENSIONS PER E-592  
 DIMENSIONS PER E-593  
 DIMENSIONS PER E-594  
 DIMENSIONS PER E-595  
 DIMENSIONS PER E-596  
 DIMENSIONS PER E-597  
 DIMENSIONS PER E-598  
 DIMENSIONS PER E-599  
 DIMENSIONS PER E-600  
 DIMENSIONS PER E-601  
 DIMENSIONS PER E-602  
 DIMENSIONS PER E-603  
 DIMENSIONS PER E-604  
 DIMENSIONS PER E-605  
 DIMENSIONS PER E-606  
 DIMENSIONS PER E-607  
 DIMENSIONS PER E-608  
 DIMENSIONS PER E-609  
 DIMENSIONS PER E-610  
 DIMENSIONS PER E-611  
 DIMENSIONS PER E-612  
 DIMENSIONS PER E-613  
 DIMENSIONS PER E-614  
 DIMENSIONS PER E-615  
 DIMENSIONS PER E-616  
 DIMENSIONS PER E-617  
 DIMENSIONS PER E-618  
 DIMENSIONS PER E-619  
 DIMENSIONS PER E-620  
 DIMENSIONS PER E-621  
 DIMENSIONS PER E-622  
 DIMENSIONS PER E-623  
 DIMENSIONS PER E-624  
 DIMENSIONS PER E-625  
 DIMENSIONS PER E-626  
 DIMENSIONS PER E-627  
 DIMENSIONS PER E-628  
 DIMENSIONS PER E-629  
 DIMENSIONS PER E-630  
 DIMENSIONS PER E-631  
 DIMENSIONS PER E-632  
 DIMENSIONS PER E-633  
 DIMENSIONS PER E-634  
 DIMENSIONS PER E-635  
 DIMENSIONS PER E-636  
 DIMENSIONS PER E-637  
 DIMENSIONS PER E-638  
 DIMENSIONS PER E-639  
 DIMENSIONS PER E-640  
 DIMENSIONS PER E-641  
 DIMENSIONS PER E-642  
 DIMENSIONS PER E-643  
 DIMENSIONS PER E-644  
 DIMENSIONS PER E-645  
 DIMENSIONS PER E-646  
 DIMENSIONS PER E-647  
 DIMENSIONS PER E-648  
 DIMENSIONS PER E-649  
 DIMENSIONS PER E-650  
 DIMENSIONS PER E-651  
 DIMENSIONS PER E-652  
 DIMENSIONS PER E-653  
 DIMENSIONS PER E-654  
 DIMENSIONS PER E-655  
 DIMENSIONS PER E-656  
 DIMENSIONS PER E-657  
 DIMENSIONS PER E-658  
 DIMENSIONS PER E-659  
 DIMENSIONS PER E-660  
 DIMENSIONS PER E-661  
 DIMENSIONS PER E-662  
 DIMENSIONS PER E-663  
 DIMENSIONS PER E-664  
 DIMENSIONS PER E-665  
 DIMENSIONS PER E-666  
 DIMENSIONS PER E-667  
 DIMENSIONS PER E-668  
 DIMENSIONS PER E-669  
 DIMENSIONS PER E-670  
 DIMENSIONS PER E-671  
 DIMENSIONS PER E-672  
 DIMENSIONS PER E-673  
 DIMENSIONS PER E-674  
 DIMENSIONS PER E-675  
 DIMENSIONS PER E-676  
 DIMENSIONS PER E-677  
 DIMENSIONS PER E-678  
 DIMENSIONS PER E-679  
 DIMENSIONS PER E-680  
 DIMENSIONS PER E-681  
 DIMENSIONS PER E-682  
 DIMENSIONS PER E-683  
 DIMENSIONS PER E-684  
 DIMENSIONS PER E-685  
 DIMENSIONS PER E-686  
 DIMENSIONS PER E-687  
 DIMENSIONS PER E-688  
 DIMENSIONS PER E-689  
 DIMENSIONS PER E-690  
 DIMENSIONS PER E-691  
 DIMENSIONS PER E-692  
 DIMENSIONS PER E-693  
 DIMENSIONS PER E-694  
 DIMENSIONS PER E-695  
 DIMENSIONS PER E-696  
 DIMENSIONS PER E-697  
 DIMENSIONS PER E-698  
 DIMENSIONS PER E-699  
 DIMENSIONS PER E-700  
 DIMENSIONS PER E-701  
 DIMENSIONS PER E-702  
 DIMENSIONS PER E-703  
 DIMENSIONS PER E-704  
 DIMENSIONS PER E-705  
 DIMENSIONS PER E-706  
 DIMENSIONS PER E-707  
 DIMENSIONS PER E-708  
 DIMENSIONS PER E-709  
 DIMENSIONS PER E-710  
 DIMENSIONS PER E-711  
 DIMENSIONS PER E-712  
 DIMENSIONS PER E-713  
 DIMENSIONS PER E-714  
 DIMENSIONS PER E-715  
 DIMENSIONS PER E-716  
 DIMENSIONS PER E-717  
 DIMENSIONS PER E-718  
 DIMENSIONS PER E-719  
 DIMENSIONS PER E-720  
 DIMENSIONS PER E-721  
 DIMENSIONS PER E-722  
 DIMENSIONS PER E-723  
 DIMENSIONS PER E-724  
 DIMENSIONS PER E-725  
 DIMENSIONS PER E-726  
 DIMENSIONS PER E-727  
 DIMENSIONS PER E-728  
 DIMENSIONS PER E-729  
 DIMENSIONS PER E-730  
 DIMENSIONS PER E-731  
 DIMENSIONS PER E-732  
 DIMENSIONS PER E-733  
 DIMENSIONS PER E-734  
 DIMENSIONS PER E-735  
 DIMENSIONS PER E-736  
 DIMENSIONS PER E-737  
 DIMENSIONS PER E-738  
 DIMENSIONS PER E-739  
 DIMENSIONS PER E-740  
 DIMENSIONS PER E-741  
 DIMENSIONS PER E-742  
 DIMENSIONS PER E-743  
 DIMENSIONS PER E-744  
 DIMENSIONS PER E-745  
 DIMENSIONS PER E-746  
 DIMENSIONS PER E-747  
 DIMENSIONS PER E-748  
 DIMENSIONS PER E-749  
 DIMENSIONS PER E-750  
 DIMENSIONS PER E-751  
 DIMENSIONS PER E-752  
 DIMENSIONS PER E-753  
 DIMENSIONS PER E-754  
 DIMENSIONS PER E-755  
 DIMENSIONS PER E-756  
 DIMENSIONS PER E-757  
 DIMENSIONS PER E-758  
 DIMENSIONS PER E-759  
 DIMENSIONS PER E-760  
 DIMENSIONS PER E-761  
 DIMENSIONS PER E-762  
 DIMENSIONS PER E-763  
 DIMENSIONS PER E-764  
 DIMENSIONS PER E-765  
 DIMENSIONS PER E-766  
 DIMENSIONS PER E-767  
 DIMENSIONS PER E-768  
 DIMENSIONS PER E-769  
 DIMENSIONS PER E-770  
 DIMENSIONS PER E-771  
 DIMENSIONS PER E-772  
 DIMENSIONS PER E-773  
 DIMENSIONS PER E-774  
 DIMENSIONS PER E-775  
 DIMENSIONS PER E-776  
 DIMENSIONS PER E-777  
 DIMENSIONS PER E-778  
 DIMENSIONS PER E-779  
 DIMENSIONS PER E-780  
 DIMENSIONS PER E-781  
 DIMENSIONS PER E-782  
 DIMENSIONS PER E-783  
 DIMENSIONS PER E-784  
 DIMENSIONS PER E-785  
 DIMENSIONS PER E-786  
 DIMENSIONS PER E-787  
 DIMENSIONS PER E-788  
 DIMENSIONS PER E-789  
 DIMENSIONS PER E-790  
 DIMENSIONS PER E-791  
 DIMENSIONS PER E-792  
 DIMENSIONS PER E-793  
 DIMENSIONS PER E-794  
 DIMENSIONS PER E-795  
 DIMENSIONS PER E-796  
 DIMENSIONS PER E-797  
 DIMENSIONS PER E-798  
 DIMENSIONS PER E-799  
 DIMENSIONS PER E-800  
 DIMENSIONS PER E-801  
 DIMENSIONS PER E-802  
 DIMENSIONS PER E-803  
 DIMENSIONS PER E-804  
 DIMENSIONS PER E-805  
 DIMENSIONS PER E-806  
 DIMENSIONS PER E-807  
 DIMENSIONS PER E-808  
 DIMENSIONS PER E-809  
 DIMENSIONS PER E-810  
 DIMENSIONS PER E-811  
 DIMENSIONS PER E-812  
 DIMENSIONS PER E-813  
 DIMENSIONS PER E-814  
 DIMENSIONS PER E-815  
 DIMENSIONS PER E-816  
 DIMENSIONS PER E-817  
 DIMENSIONS PER E-818  
 DIMENSIONS PER E-819  
 DIMENSIONS PER E-820  
 DIMENSIONS PER E-821  
 DIMENSIONS PER E-822  
 DIMENSIONS PER E-823  
 DIMENSIONS PER E-824  
 DIMENSIONS PER E-825  
 DIMENSIONS PER E-826  
 DIMENSIONS PER E-827  
 DIMENSIONS PER E-828  
 DIMENSIONS PER E-829  
 DIMENSIONS PER E-830  
 DIMENSIONS PER E-831  
 DIMENSIONS PER E-832  
 DIMENSIONS PER E-833  
 DIMENSIONS PER E-834  
 DIMENSIONS PER E-835  
 DIMENSIONS PER E-836  
 DIMENSIONS PER E-837  
 DIMENSIONS PER E-838  
 DIMENSIONS PER E-839  
 DIMENSIONS PER E-840  
 DIMENSIONS PER E-841  
 DIMENSIONS PER E-842  
 DIMENSIONS PER E-843  
 DIMENSIONS PER E-844  
 DIMENSIONS PER E-845  
 DIMENSIONS PER E-846  
 DIMENSIONS PER E-847  
 DIMENSIONS PER E-848  
 DIMENSIONS PER E-849  
 DIMENSIONS PER E-850  
 DIMENSIONS PER E-851  
 DIMENSIONS PER E-852  
 DIMENSIONS PER E-853  
 DIMENSIONS PER E-854  
 DIMENSIONS PER E-855  
 DIMENSIONS PER E-856  
 DIMENSIONS PER E-857  
 DIMENSIONS PER E-858  
 DIMENSIONS PER E-859  
 DIMENSIONS PER E-860  
 DIMENSIONS PER E-861  
 DIMENSIONS PER E-862  
 DIMENSIONS PER E-863  
 DIMENSIONS PER E-864  
 DIMENSIONS PER E-865  
 DIMENSIONS PER E-866  
 DIMENSIONS PER E-867  
 DIMENSIONS PER E-868  
 DIMENSIONS PER E-869  
 DIMENSIONS PER E-870  
 DIMENSIONS PER E-871  
 DIMENSIONS PER E-872  
 DIMENSIONS PER E-873  
 DIMENSIONS PER E-874  
 DIMENSIONS PER E-875  
 DIMENSIONS PER E-876  
 DIMENSIONS PER E-877  
 DIMENSIONS PER E-878  
 DIMENSIONS PER E-879  
 DIMENSIONS PER E-880  
 DIMENSIONS PER E-881  
 DIMENSIONS PER E-882  
 DIMENSIONS PER E-883  
 DIMENSIONS PER E-884  
 DIMENSIONS PER E-885  
 DIMENSIONS PER E-886  
 DIMENSIONS PER E-887  
 DIMENSIONS PER E-888  
 DIMENSIONS PER E-889  
 DIMENSIONS PER E-890  
 DIMENSIONS PER E-891  
 DIMENSIONS PER E-892  
 DIMENSIONS PER E-893  
 DIMENSIONS PER E-894  
 DIMENSIONS PER E-895  
 DIMENSIONS PER E-896  
 DIMENSIONS PER E-897  
 DIMENSIONS PER E-898  
 DIMENSIONS PER E-899  
 DIMENSIONS PER E-900  
 DIMENSIONS PER E-901  
 DIMENSIONS PER E-902  
 DIMENSIONS PER E-903  
 DIMENSIONS PER E-904  
 DIMENSIONS PER E-905  
 DIMENSIONS PER E-906  
 DIMENSIONS PER E-907  
 DIMENSIONS PER E-908  
 DIMENSIONS PER E-909  
 DIMENSIONS PER E-910  
 DIMENSIONS PER E-911  
 DIMENSIONS PER E-912  
 DIMENSIONS PER E-913  
 DIMENSIONS PER E-914  
 DIMENSIONS PER E-915  
 DIMENSIONS PER E-916  
 DIMENSIONS PER E-917  
 DIMENSIONS PER E-918  
 DIMENSIONS PER E-919  
 DIMENSIONS PER E-920  
 DIMENSIONS PER E-921  
 DIMENSIONS PER E-922  
 DIMENSIONS PER E-923  
 DIMENSIONS PER E-924  
 DIMENSIONS PER E-925  
 DIMENSIONS PER E-926  
 DIMENSIONS PER E-927  
 DIMENSIONS PER E-928  
 DIMENSIONS PER E-929  
 DIMENSIONS PER E-930  
 DIMENSIONS PER E-931  
 DIMENSIONS PER E-932  
 DIMENSIONS PER E-933  
 DIMENSIONS PER E-934  
 DIMENSIONS PER E-935  
 DIMENSIONS PER E-936  
 DIMENSIONS PER E-937  
 DIMENSIONS PER E-938  
 DIMENSIONS PER E-939  
 DIMENSIONS PER E-940  
 DIMENSIONS PER E-941  
 DIMENSIONS PER E-942  
 DIMENSIONS PER E-943  
 DIMENSIONS PER E-944  
 DIMENSIONS PER E-945  
 DIMENSIONS PER E-946  
 DIMENSIONS PER E-947  
 DIMENSIONS PER E-948  
 DIMENSIONS PER E-949  
 DIMENSIONS PER E-950  
 DIMENSIONS PER E-951  
 DIMENSIONS PER E-952  
 DIMENSIONS PER E-953  
 DIMENSIONS PER E-954  
 DIMENSIONS PER E-955  
 DIMENSIONS PER E-956  
 DIMENSIONS PER E-957  
 DIMENSIONS PER E-958  
 DIMENSIONS PER E-959  
 DIMENSIONS PER E-960  
 DIMENSIONS PER E-961  
 DIMENSIONS PER E-962  
 DIMENSIONS PER E-963  
 DIMENSIONS PER E-964  
 DIMENSIONS PER E-965  
 DIMENSIONS PER E-966  
 DIMENSIONS PER E-967  
 DIMENSIONS PER E-968  
 DIMENSIONS PER E-969  
 DIMENSIONS PER E-970  
 DIMENSIONS PER E-971  
 DIMENSIONS PER E-972  
 DIMENSIONS PER E-973  
 DIMENSIONS PER E-974  
 DIMENSIONS PER E-975  
 DIMENSIONS PER E-976  
 DIMENSIONS PER E-977  
 DIMENSIONS PER E-978  
 DIMENSIONS PER E-979  
 DIMENSIONS PER E-980  
 DIMENSIONS PER E-981  
 DIMENSIONS PER E-982  
 DIMENSIONS PER E-983  
 DIMENSIONS PER E-984  
 DIMENSIONS PER E-985  
 DIMENSIONS PER E-986  
 DIMENSIONS PER E-987  
 DIMENSIONS PER E-988  
 DIMENSIONS PER E-989  
 DIMENSIONS PER E-990  
 DIMENSIONS PER E-991  
 DIMENSIONS PER E-992  
 DIMENSIONS PER E-993  
 DIMENSIONS PER E-994  
 DIMENSIONS PER E-995  
 DIMENSIONS PER E-996  
 DIMENSIONS PER E-997  
 DIMENSIONS PER E-998  
 DIMENSIONS PER E-999  
 DIMENSIONS PER E-1000

NOTE: This diagram is for reference only. It may not be accurate for all machines covered by this manual.



PC BOARD ASSEMBLY-SWITCH

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC



MANUFACTURED AS:  
**G3830-1D0**  
 PART NO. IDENTIFICATION CODE

- NOTES:
- N.A. CAUTION: THIS DEVICE IS SUBJECT TO DAMAGE BY STATIC ELECTRICITY. LINCOLN ELECTRIC TO SEE E2454 BEFORE HANDLING.
  - N.B. SNAP POWER TERMINALS INTO COMPONENT SIDE OF BOARD.
  - N.C. UNLESS OTHERWISE SPECIFIED, THESE AREAS TO BE COVERED ON BOTH SIDES OF BOARD (WHERE POSSIBLE) WITH SEALANT PRIOR TO ENCAPSULATION.
  - N.D. INJECT SEALANT ITEM 8 THROUGH THE PC BOARD HOLES (16 HOLES) TO SEAL MODULE LEADS. CAVITY BETWEEN BOARD AND MODULE TO BE COMPLETELY FILLED WITH ITEM 8 SEALANT MATERIAL AS PER APPROPRIATE MANUFACTURING WORK INSTRUCTIONS. COVER ALL MODULE LEADS THAT PROTRUDE FROM THE NON-MODULE SIDE OF THE BOARD WITH ITEM 8 SEALANT.
  - N.E. FEMALE EYELET TO BE AGAINST THE NON-COMPONENT SIDE AS SHOWN. EYELET MUST NOT SPIN AFTER CLINCHING.
  - N.F. SOLDER EYELET SO THAT SOLDER COVERS ENTIRE EYELET AND ALL AROUND EYELET ON COPPER SIDE ONLY. NO ICICLES OR SOLDER BLOBS PERMITTED.
  - N.G. AFTER SOLDERING, INSPECT POWER TERMINAL CONNECTIONS PER E1880.
  - N.H. THIS AREA TO BE COVERED ON COMPONENT SIDE OF BOARD WITH SEALANT PRIOR TO ENCAPSULATION. MATERIAL MUST BE APPLIED FROM TOP TO COMPLETELY FILL TO UNDERSIDE OF DEVICE. THEN APPLY SEALANT AROUND BASE OF DEVICE.
  - N.I. THIS AREA TO BE COVERED ON OPPOSITE COMPONENT SIDE OF BOARD WITH ITEM 8 PRIOR TO ENCAPSULATION. DO NOT COAT WITH ENCAPSULATION MATERIAL ON THE TOP SURFACES NOR THE THREADS.
  - N.K. SEALANT HEIGHT BETWEEN MODULES NOT TO EXCEED .17" MAX.
  - N.L. ITEM 5 MUST HAVE FULL CONTACT WITH ITEM 3 ON THE CONTACT SURFACE.
  - N.M. THE TWO MODULES, ITEM 2 MUST BE MATCHED. THE LAST TWO DIGITS OF THEIR SORT CODES MUST BE IDENTICAL.
  - N.N. SMALL PC BOARD HOLES TO BE FREE OF ENCAPSULATION MATERIAL FOR A CENTERED .40 MINIMUM DIAMETER AND .45 MAXIMUM DIAMETER (4 HOLES). TO BE CENTERED WITHIN .06 (DO NOT GET ON MATING SURFACES). MASK PER APPROPRIATE MANUFACTURING WORK INSTRUCTIONS.
  - N.P. ELECTRONIC MODULES TO BE ASSEMBLED AND ENCAPSULATED PER E3875.

PC BOARD BLANK REFERENCE INFORMATION  
 BUY COMPLETE AS G3830-D (4 LAYER BOARD PER E3281)  
 (MAKES 2 BOARDS PER PANEL, SEE ELECTRONIC FILE FOR ADDITIONAL INFORMATION)  
 PANEL SIZE PER E1911

CAPACITORS = MFD/VOLTS  
 INDUCTANCE = HENRIES  
 RESISTOR = OHMS

SCHEMATIC REFERENCE L11487-1D0  
 MAKE PER E1911  
 ENCAPSULATE WITH E1844, 3 COATS  
 TEST PER E3817-SW

ITEM	REQ'D	PART NO.	DESCRIPTION
C1, C23	2	S20500-4	CAPACITOR, PPMF, .0047, 1000V, BOX
C2, C24	2	S20500-7	CAPACITOR, PPMF, .047, 1600V, BOX, 10%
C3, C18	2	S13490-93	CAPACITOR, TAEI, .27, 35V, 10%
C4, C21	2	S20500-1	CAPACITOR, PPMF, 0.1, 1000V, 10%, BOX
C5, C6, C15, C16	4	S16668-6	CAPACITOR, CEMO, .4700p, .50V, 10%
C7, C12, C13, C14, C20, C27, C28, C29	8	S16668-5	CAPACITOR, CEMO, .022, .50V, 20%
C8, C9, C22	3	S16668-9	CAPACITOR, CEMO, .150p, .100V, 5%
C10, C11	2	S13490-85	CAPACITOR, PCF, .027, .50V, 5%
C25, C26	2	T11577-57	CAPACITOR, PEF, 0.1, 400V, 10%
C31, C32	2	S16668-7	CAPACITOR, CEMO, .820p, .50V, 5%
CR1, CR2	2	S14293-18	RELAY, DPST, 12VDC, AG-CDO
D1, D4, D16, D17	4	T12705-59	DIODE, AXLDS, 3A, 600V, UFR
D7, D8, D9, D12, D14, D18, D19, D20, D21	9	T12199-1	DIODE, AXLDS, 1A, 400V
D21, D22, D23, D25, D26, D215, D216, D218, D219, D223	10	T12702-29	ZENER DIODE, 1W, 15V, 5% 1N4744A
D24, D27, D217, D220	4	T12702-40	ZENER DIODE, 1W, 6.2V, 5% 1N4735A
D28	1	T12702-19	ZENER DIODE, 1W, 12V, 5% 1N4742A
D29, D210, D212, D213	4	T12702-45	ZENER DIODE, 1W, 18V, 5% 1N4746A
D211, D222	2	T12702-4	ZENER DIODE, 1W, 20V, 5% 1N4747A
J20, J21	2	S24016-8	CONNECTOR, MOLEX, MINI, PCB, RT-L, 8-PIN
J22	1	S24016-4	CONNECTOR, MOLEX, MINI, PCB, RT-L, 4-PIN
OC11, OC12, OC13	3	S15000-22	OPTOCOUPLER, PHOTO-Q, 70V, CNY17-3/VDE
OC14	1	S15000-29	OPTOCOUPLER, TRIAC, DRV, RANDOM, 600V
Q1	1	T12704-75	TRANSISTOR, NMF, T247, 4A, 900V (SS)
Q2, Q3, Q4, Q5	4	T12704-73	MOSFET, 4-PIN DIP, 1A, 100V, RFD110 (SS)
R1, R2, R3, R4, R7, R8, R9, R10, R124, R125, R126, R127, R130, R131, R132, R133	16	T14648-5	RESISTOR, MW, 5W, 3.3K, 5%, 5Q
R5, R6, R19, R26, R93, R105, R109, R128, R129	9	S19400-1001	RESISTOR, MF, 1/4W, 1.00K, 1%
R11, R12, R30, R31, R142	5	S19400-1503	RESISTOR, MF, 1/4W, 150K, 1%
R13, R39, R43, R60, R81, R92	6	S19400-3321	RESISTOR, MF, 1/4W, 3.32K, 1%
R14, R107	2	S19400-1652	RESISTOR, MF, 1/4W, 16.5K, 1%
R15, R20, R21, R22, R27, R28, R97, R98, R99, R100, R101, R106	12	S19400-10R0	RESISTOR, MF, 1/4W, 10.0, 1%
R32, R33, R34, R48, R49, R50, R51, R62, R63, R74, R75, R85, R86, R87, R134, R135	16	S19400-1003	RESISTOR, MF, 1/4W, 100K, 1%
R35, R52, R73, R84	4	S19400-6191	RESISTOR, MF, 1/4W, 6.19K, 1%
R36, R37, R123	3	S19400-2213	RESISTOR, MF, 1/4W, 221K, 1%
R38, R40, R42, R45, R53, R59, R66, R69, R70, R72, R80, R82	12	S19400-1002	RESISTOR, MF, 1/4W, 10.0K, 1%
R41, R67	2	S19400-4752	RESISTOR, MF, 1/4W, 47.5K, 1%
R44, R68	2	T12300-79	RESISTOR, MW, 1W, 1.0, 1%
R46, R76	2	S19400-3322	RESISTOR, MF, 1/4W, 33.2K, 1%
R47, R64	2	S19400-2000	RESISTOR, MF, 1/4W, 200, 1%
R55, R56, R57, R58	4	S24376-3	RESISTOR, MW, 10W, 100, 5%
R61, R77	2	S19400-8251	RESISTOR, MF, 1/4W, 8.25K, 1%
R65, R120	2	S19400-2001	RESISTOR, MF, 1/4W, 2.00K, 1%
R78, R79	2	S16296-5	TRIMMER, MT, 1/2W, 10K, 10%, LINEAR
R83, R122, R141	3	S19400-1000	RESISTOR, MF, 1/4W, 100, 1%
R137	1	S19400-3570	RESISTOR, MF, 1/4W, 357, 1%
R138	1	S19400-1500	RESISTOR, MF, 1/4W, 150, 1%
R139	1	S19400-4750	RESISTOR, MF, 1/4W, 475, 1%
R140	1	S19400-39R2	RESISTOR, MF, 1/4W, 39.2, 1%
T1	1	S13000-46	TRANSFORMER, PCB:
TP1	1	T13640-24	MOV, 175VRMS, 120J, 20MM
TR11	1	S15161-27	TRIAC, T220, 8A, 800V
X1, X4	2	S15128-10	VOLTAGE REF, ADJ., PRECISION, 4311
X2, X3	2	S15128-18	OP-AMP, QUAD, HIGH-PERF, 33074

ITEM	PART NO.	DESCRIPTION	QTY
1	SEE DETAIL	P.C. BOARD BLANK	41
2	N16100-44	ELECTRONIC MODULE (A1, A2)	2
3	S23008	TERMINAL (B211, B218, B204, B205, B206)	5
4	N19612	CURRENT TRANSDUCER (T2, T3)	2
5	S24866	POWER TERMINAL (B201, B208)	2
6	T9147-11	EYELET-FEMALE	8
7	T9147-15	EYELET-MALE	8
8	E2861	SEALANT	5.0oz

N.A., N.M., N.P.


THIS SHEET CONTAINS PROPRIETARY INFORMATION OWNED BY THE LINCOLN ELECTRIC COMPANY AND IS NOT TO BE REPRODUCED, DISCLOSED OR USED WITHOUT THE EXPRESS WRITTEN PERMISSION OF THE LINCOLN ELECTRIC COMPANY, CLEVELAND, OHIO U.S.A.			
UNLESS OTHERWISE SPECIFIED TOLERANCES:	Chg. Sheet No.	TK INFO.	DESIGN INFORMATION
MANUFACTURING TOLERANCES PER ASME:	6-2-2000A		REFERENCE
ON 2 PLACE DECIMALS: 8 + .00			DRAWN BY: F.V.J.B.
ON 3 PLACE DECIMALS: 8 + .002	6-22-2000A		ENGINEER
ON ALL ANGLES: 8 + 5 OF A DEGREE	6-27-2000F		SUPERSEDING
MATERIAL TOLERANCES: 1 TO 49999	6-26-2001C		APPROVED:
UNFINISHED STANDARDS			
NO TYPICAL DIMENSIONS			

FOR PARTS ORDERS AND SUBSIDIARY ORDERS:  
 INCLUDE (1) S25191PRINT AND (1) T12837-1.

**NOTE:** Lincoln Electric assumes no responsibility for liabilities resulting from board level troubleshooting. PC Board repairs will invalidate your factory warranty. **Individual Printed Circuit Board Components are not available from Lincoln Electric.** This information is provided for reference only. Lincoln Electric discourages board level troubleshooting and repair since it may compromise the quality of the design and may result in danger to the Machine Operator or Technician. Improper PC board repairs could result in damage to the machine.



SCHEMATIC - DISPLAY PRINTED CIRCUIT BOARD



NOTE: This diagram is for reference only. It may not be accurate for all machines covered by this manual.

GENERAL INFORMATION

ELECTRICAL SYMBOLS PER IES97  
CAPACITORS - 0.1W UNLESS OTHERWISE SPECIFIED  
RESISTORS - 0.1W UNLESS OTHERWISE SPECIFIED  
DIODES - 1A, 400V UNLESS OTHERWISE SPECIFIED

LAST NO. USED  
R-29 X-8  
C-20 D-0

LABELS

▲ SUPPLY VOLTAGE NET  
○ POWER SUPPLY SOURCE POINT  
▽ COMMON CONNECTION  
□ FRAME CONNECTION  
⊥ EARTH GROUND CONNECTION

FILENAME: L11109\_3D

EQUIP. TYPE UNIFIED SPI PANELS  
SUBJECT DISPLAY PCB SCHEMATIC

THE LINCOLN ELECTRIC CO.  
CLEVELAND, OHIO U.S.A.

PC # 01 SCALE NONE  
DR. M.L.D. DATE 11/06/00 CHK. SHT. L 11108  
SUPS/DWG.

NOTES:

N.A. SINCE COMPONENTS OR CIRCUITRY ON A PRINTED CIRCUIT BOARD MAY CHANGE WITHOUT AFFECTING THE INTERCHANGEABILITY OF A COMPLETE BOARD, THIS DIAGRAM MAY NOT SHOW THE EXACT COMPONENTS OR CIRCUITRY OF CONTROLS HAVING A COMMON CODE NUMBER.

THIS SHEET CONTAINS PROPRIETARY INFORMATION OWNED BY THE LINCOLN ELECTRIC CO. AND IS NOT TO BE REPRODUCED, DISCLOSED OR USED WITHOUT THE EXPRESS PERMISSION OF THE LINCOLN ELECTRIC CO.

UNLESS OTHERWISE SPECIFIED TOLERANCE  
ON HOLES SIZES PER E-288  
ON 2 PLACE DECIMALS IS ±.02  
ON 3 PLACE DECIMALS IS ±.002  
ON ANGLES TOLERANCE IS TO DEGREE  
MATERIAL TOLERANCE IS TO DEGREE  
WITH PUBLISHED STANDARDS

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC




PC BOARD ASSEMBLY-DISPLAY

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC



(V)

ITEM	REQ'D	PART NO.	DESCRIPTION
1	1	L11130-D	DISPLAY P.C. BOARD BLANK (REF ONLY)
2	1	L11166-1	FLEX CIRCUIT
3	4	T15176-2	LED, SPACER, 0.140 HIGH
4	.01 OZ.	E3539	ELECTRICAL INSULATING COMPOUND
FOR ITEMS BELOW REFER TO ELECTRONIC COMPONENTS DATABASE FOR COMPONENT SPECIFICATIONS			
C1	1	S25024-7SMT	CAPACITOR, SMD, TANTALUM, 47ME, 20V, 10%, S7343
C2, C3, C4, C5, C11, C12, C19, C20	8	S25020-3SMT	CAPACITOR, SMD, CERAMIC, 0.1ME, 50V, 10%, X7R, S0805
N.A., N.D. DISP1, DISP2, DISP3, DISP4 DISP5, DISP6, DISP7, DISP8	8	S17395-6	LED, DISPLAY, 7-SEGMENT, CC, BRIGHT
J37	1	S18248-10	CONNECTOR, MOLEX, MINI, PCB, 10-PIN
N.A. LED1, LED2, LED3, LED4	4	T13657-6	LED, T-1, RED, HLMP-K101
N.A. LED 5, LED6, LED7	3	T13657-12	LED, T-1, 3/4, YELLOW, HIGH-INTENSITY
R6, R16	2	S25000-1501SMT	RESISTOR, SMD, METAL FILM, 1/10W, 1.50K, 1%, S0805
R9, R10, R11, R12, R13, R14	6	S25000-1212SMT	RESISTOR, SMD, METAL FILM, 1/10W, 12.1K, 1%, S0805
R20	1	S25000-2670SMT	RESISTOR, SMD, METAL FILM, 1/10W, 267OHMS, 1%, S0805
R21, R25, R26, R28, R29	5	S25000-1001SMT	RESISTOR, SMD, METAL FILM, 1/10W, 1.00K, 1%, S0805
R22, R23	2	S25000-10R0SMT	RESISTOR, SMD, METAL FILM, 1/10W, 10.0OHMS, 1%, S0805
R24	1	S25000-4751SMT	RESISTOR, SMD, METAL FILM, 1/10W, 4.75K, 1%, S0805
R27	1	S25000-4752SMT	RESISTOR, SMD, METAL FILM, 1/10W, 47.5K, 1%, S0805
N.B. X1	1	S17900-8SMT	IC, SMD, CMOS, INVERTER, SCHMITT, HEX, HC14A (SS)
N.B. X2	1	S17900-26SMT	IC, CMOS, SMD, MUX, DAT, 8-INPUT, HC151 (SS)
N.B. X3	1	S17900-28SMT	IC, SMD, CMOS, INVERTING BUFFER, 3-ST (SS)
N.B. X4	1	S17900-10SMT	IC, SMD, CMOS, REGISTER, SHFT, S-PI/SO, 8-BIT (SS)
X5, X6, X7	3	S20496-1SMT	IC, SMD, CMOS, DRIVER, DISPLAY, LED, CC, MCU

UNLESS OTHERWISE SPECIFIED:  
 CAPACITORS = MFD/VOLTS  
 INDUCTANCE = HENRIES  
 RESISTANCE = OHMS

- NOTES:
- N.A. DO NOT COAT WITH ENCAPSULATION MATERIAL.
  - N.B. **CAUTION:** THIS DEVICE IS SUBJECT TO DAMAGE BY STATIC ELECTRICITY. SEE E2454 BEFORE HANDLING.
  - N.C. USE ITEM 3 TO STAND LED1, LED2, LED3 AND LED4 FROM THE P.C. BOARD. THERE MUST NOT BE MORE THAN .020 GAP BETWEEN SPACER AND P.C. BOARD OR BETWEEN SPACER AND LED. ENCAPSULATE P.C. BOARD, SPACER AND LOWER HALF OF LED.
  - N.D. DISP 1 THRU DISP 8 MUST ALWAYS BE MATCHED BY VENDOR NAME. DO NOT MIX DIFFERENT VENDORS ON THE SAME BOARD ASSEMBLY.
  - N.E. CONNECTOR MUST BE GREASED WITH ITEM 4 PRIOR TO ENCAPSULATION.

ENCAPSULATE WITH HUMISEAL 1A27LU PER E1844 OR WITH EQUIVALENT AS APPROVED BY LINCOLN ELECTRIC COMPANY. (2 COATS)

BUY AS:

**L11130-3D0**

PART NO. IDENTIFICATION CODE


BUY PER E3867  
 TEST PER E3856-D

THIS SHEET CONTAINS PROPRIETARY INFORMATION OWNED BY THE LINCOLN ELECTRIC COMPANY AND IS NOT TO BE REPRODUCED, DISCLOSED OR USED WITHOUT THE EXPRESS WRITTEN PERMISSION OF THE LINCOLN ELECTRIC COMPANY, CLEVELAND, OHIO U.S.A.																							
UNLESS OTHERWISE SPECIFIED TOLERANCE: MANUFACTURING TOLERANCE PER E2056 ON 2 PLACE DECIMALS IS ± .02 ON 3 PLACE DECIMALS IS ± .002 ON ALL ANGLES IS ± 5 OF A DEGREE MATERIAL TOLERANCE (1:1) TO AGREE WITH PUBLISHED STANDARDS DO NOT SCALE THIS DRAWING	<table border="1"> <tr> <th>TX INFO</th> <th>Chg. Sheet No.</th> </tr> <tr> <td>XM5626</td> <td>6-2-2000A</td> </tr> <tr> <td>XA</td> <td>8-4-2000C</td> </tr> </table>	TX INFO	Chg. Sheet No.	XM5626	6-2-2000A	XA	8-4-2000C	<table border="1"> <tr> <th>DESIGN INFORMATION</th> <th>REFERENCE</th> </tr> <tr> <td>DRAWN BY: JBI</td> <td>L11130-2</td> </tr> <tr> <td>ENGINEER:</td> <td>SUPERSEDED:</td> </tr> <tr> <td>APPROVED:</td> <td></td> </tr> </table>	DESIGN INFORMATION	REFERENCE	DRAWN BY: JBI	L11130-2	ENGINEER:	SUPERSEDED:	APPROVED:		<table border="1"> <tr> <td>EQUIPMENT TYPE:</td> <td>MISCELLANEOUS</td> </tr> <tr> <td>SUBJECT:</td> <td>SPI DISPLAY P.C. BOARD ASSEMBLY</td> </tr> <tr> <td>SCALE: FULL</td> <td>DATE: 5-11-2000 DRAWING No.: L 11130-3</td> </tr> </table>	EQUIPMENT TYPE:	MISCELLANEOUS	SUBJECT:	SPI DISPLAY P.C. BOARD ASSEMBLY	SCALE: FULL	DATE: 5-11-2000 DRAWING No.: L 11130-3
TX INFO	Chg. Sheet No.																						
XM5626	6-2-2000A																						
XA	8-4-2000C																						
DESIGN INFORMATION	REFERENCE																						
DRAWN BY: JBI	L11130-2																						
ENGINEER:	SUPERSEDED:																						
APPROVED:																							
EQUIPMENT TYPE:	MISCELLANEOUS																						
SUBJECT:	SPI DISPLAY P.C. BOARD ASSEMBLY																						
SCALE: FULL	DATE: 5-11-2000 DRAWING No.: L 11130-3																						

**NOTE:** Lincoln Electric assumes no responsibility for liabilities resulting from board level troubleshooting. PC Board repairs will invalidate your factory warranty. **Individual Printed Circuit Board Components are not available from Lincoln Electric.** This information is provided for reference only. Lincoln Electric discourages board level troubleshooting and repair since it may compromise the quality of the design and may result in danger to the Machine Operator or Technician. Improper PC board repairs could result in damage to the machine.



SCHEMATIC - LED SELECT PRINTED CIRCUIT BOARD



THIS SHEET CONTAINS PROPRIETARY INFORMATION OWNED BY THE LINCOLN ELECTRIC CO. AND IS NOT TO BE REPRODUCED, DISCLOSED OR USED WITHOUT THE EXPRESS PERMISSION OF THE LINCOLN ELECTRIC CO. CLEVELAND, OHIO U.S.A.

NOTES :

N.A. SINCE COMPONENTS OR CIRCUITRY ON A PRINTED CIRCUIT BOARD MAY CHANGE WITHOUT AFFECTING THE INTERCHANGEABILITY OF A COMPLETE BOARD. THIS DIAGRAM MAY NOT SHOW THE EXACT COMPONENTS OR CIRCUITRY OF CONTROLS HAVING A COMMON CODE NUMBER.

GENERAL INFORMATION

ELECTRICAL SYMBOLS PER E1537  
 CAPACITORS = MFD (----- UNLESS OTHERWISE SPECIFIED)  
 RESISTORS = Ohms (----- UNLESS OTHERWISE SPECIFIED)  
 DIODES = ----- (UNLESS OTHERWISE SPECIFIED)

LABELS

▲ SUPPLY VOLTAGE NET  
 ○ POWER SUPPLY SOURCE POINT  
 ▽ COMMON CONNECTION  
 ≡ FRAME CONNECTION  
 ⊥ EARTH GROUND CONNECTION

LAST NO. USED	
R-	2
C-	-
D-	-

FILENAME: S25259\_1B

UNLESS OTHERWISE SPECIFIED TOLERANCE ON HOLES SIZES PER E2056  
 ON 2 PLACE DECIMALS IS ± .02  
 ON 3 PLACE DECIMALS IS ± .002  
 ON ALL ANGLES IS ± .5 OF A DEGREE  
 MATERIAL TOLERANCE ("t") TO AGREE WITH PUBLISHED STANDARDS

DO NOT SCALE THIS DRAWING

Chg. Sheet No.	"X" INFO.
XA	
1-25-2002	

DESIGN INFORMATION
DRAWN BY:
ENGINEER:
REVISED BY:

EQUIPMENT TYPE:	V-350 LED SELECT
SUBJECT:	SCHEMATIC, PC BOARD
DATE: 01/17/02	SCALE: ---- REF.: -----
DRWG. NO. S25259-1B0	


NOTE: This diagram is for reference only. It may not be accurate for all machines covered by this manual.

Return to Section TOC  
Return to Master TOC  
Return to Section TOC  
Return to Master TOC  
Return to Section TOC  
Return to Master TOC  
Return to Section TOC  
Return to Master TOC


PC BOARD ASSEMBLY-LED SELECT

Return to Section TOC  
Return to Section TOC  
Return to Section TOC  
Return to Section TOC  
Return to Section TOC  
Return to Section TOC  
Return to Section TOC  
Return to Section TOC  
Return to Section TOC  
Return to Section TOC

**P.C. BOARD BLANK INFORMATION:**  
 MAKE FROM S19399 (MAKES 63 BOARDS  
 PER PANEL, SEE ELECTRONIC FILE FOR  
 ADDITIONAL INFORMATION)  
 BLANK PART NUMBER  
 M19875-B



**ENLARGED DETAIL  
(LED ORIENTATION)**



ITEM	REQ'D	PART NO	DESCRIPTION
1	1	SEE BLANK	P.C. BOARD BLANK
2	1	CI001498	E3165-.25-.75-.20
FOR ITEMS BELOW REFER TO ELECTRONIC COMPONENTS DATABASE FOR COMPONENT SPECIFICATIONS			
J60	1	S19365-5	CONNECTOR,PCB,WW,MALE,RT-L,15-PIN
LED1,LED2,LED3,LED4,LED5,LED6	6	T13657-13	LED,T-1,3/4,RED,HIGH-INTENSITY, OVAL
R1,R2	2	S19400-7500	RESISTOR, MF, 1/4W, 750, 1%
S1	1	T13381-16	SWTCH,PUSHBUTTON,SPST

RESISTANCE = OHMS

MANUFACTURE AS:  
**M19875-1B0**  
 PART NO.                      IDENTIFICATION CODE

ENCAPSULATE WITH E1844. (2 COATS)  
 BRUSH COAT ACCEPTABLE

**NOTES:**

- N.A. DO NOT COAT WITH ENCAPSULATION MATERIAL.
- N.B. INSERT ITEM 2 BETWEEN ROWS OF LED'S. ITEM 2 MUST BE FLUSH WITH LED BULB.
- N.C. ENCAPSULATE PC BOARD AND LOWER HALF OF LED.
- N.D. ENCAPSULATE AROUND BASE OF COMPONENT
- N.E. COAT EXTERNAL PINS WITH ENCAPSULATION MATERIAL.

SCHEMATIC REFERENCE: S25259-1B0


FOR PARTS ORDERS ONLY  
 TEST PER E3964-ST

THIS SHEET CONTAINS PROPRIETARY INFORMATION OWNED BY THE LINCOLN ELECTRIC COMPANY AND IS NOT TO BE REPRODUCED, DISCLOSED OR USED WITHOUT THE EXPRESS WRITTEN PERMISSION OF THE LINCOLN ELECTRIC COMPANY, CLEVELAND, OHIO U.S.A.			
UNLESS OTHERWISE SPECIFIED TOLERANCE MANUFACTURING TOLERANCE PER E2056 ON 2 PLACE DECIMALS IS ± .02 ON 3 PLACE DECIMALS IS ± .002 ON ALL ANGLES IS ± .5 OF A DEGREE MATERIAL TOLERANCE ("I") TO AGREE WITH PUBLISHED STANDARDS. <b>DO NOT SCALE THIS DRAWING</b>	"X" INFO.	Chg. Sheet No.	DESIGN INFORMATION
		1-25-2002	DRAWN BY: F.V.
			ENGINEER: Craig Hejl
			APPROVED:
			REFERENCE: M19874-1
			SUPERSEDING:
EQUIPMENT TYPE: INVERTER WELDERS		SUBJECT: LED SELECT PC BD AS'BLY	
SCALE:FUL		DATE:3-21-2001	DRAWING No.: M 19875-1

**NOTE:** Lincoln Electric assumes no responsibility for liabilities resulting from board level troubleshooting. PC Board repairs will invalidate your factory warranty. **Individual Printed Circuit Board Components are not available from Lincoln Electric.** This information is provided for reference only. Lincoln Electric discourages board level troubleshooting and repair since it may compromise the quality of the design and may result in danger to the Machine Operator or Technician. Improper PC board repairs could result in damage to the machine.

SCHEMATIC - LED POTENTIOMETER PRINTED CIRCUIT BOARD

Return to Section TOC  
Return to Section TOC  
Return to Section TOC  
Return to Section TOC  
Return to Section TOC  
Return to Section TOC  
Return to Section TOC  
Return to Section TOC



THIS SHEET CONTAINS PROPRIETARY INFORMATION OWNED BY THE LINCOLN ELECTRIC CO. AND IS NOT TO BE REPRODUCED, DISCLOSED OR USED WITHOUT THE EXPRESS PERMISSION OF THE LINCOLN ELECTRIC CO. CLEVELAND, OHIO U.S.A.

**NOTES :**  
 N.A. SINCE COMPONENTS OR CIRCUITRY ON A PRINTED CIRCUIT BOARD MAY CHANGE WITHOUT AFFECTING THE INTERCHANGEABILITY OF A COMPLETE BOARD, THIS DIAGRAM MAY NOT SHOW THE EXACT COMPONENTS OR CIRCUITRY OF CONTROLS HAVING A COMMON CODE NUMBER.

**GENERAL INFORMATION**  
 ELECTRICAL SYMBOLS PER E1537  
 CAPACITORS = MFD (----- UNLESS OTHERWISE SPECIFIED)  
 RESISTORS = Ohms (----- UNLESS OTHERWISE SPECIFIED)  
 DIODES = ----- (UNLESS OTHERWISE SPECIFIED)

**LABELS**  
 ▲ SUPPLY VOLTAGE NET  
 ○ POWER SUPPLY SOURCE POINT  
 ▽ COMMON CONNECTION

▬▬▬ FRAME CONNECTION  
 ⊥ EARTH GROUND CONNECTION

LAST NO. USED  
 R- -  
 C- -  
 D- -

FILENAME: S25258-1A

UNLESS OTHERWISE SPECIFIED TOLERANCE ON HOLES SIZES PER E2056 ON 2 PLACE DECIMALS IS ± .02 ON 3 PLACE DECIMALS IS ± .002 ON ALL ANGLES IS ± .5 OF A DEGREE MATERIAL TOLERANCE ("±") TO AGREE WITH PUBLISHED STANDARDS	Chg. Sheet No.	"X" INFO.	DESIGN INFORMATION	EQUIPMENT TYPE: V350 LED/POT
		5011992	DRAWN BY: CFH	SUBJECT: LED/POT PCB SCHEMATIC
		XA	ENGINEER: CFH	DATE: 03/08/01 SCALE: ---- REF.: -----
	DO NOT SCALE THIS DRAWING		REVISED BY: ---	DRWG. NO. S25258

NOTE: This diagram is for reference only. It may not be accurate for all machines covered by this manual.



PC BOARD ASSEMBLY-LED POTENTIOMETER

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC


Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

**P.C. BOARD BLANK INFORMATION:**  
MAKE FROM S19399 (MAKES 18 BOARDS  
PER PANEL, SEE ELECTRONIC FILE FOR  
ADDITIONAL INFORMATION)  
BLANK PART NUMBER  
M19874-A

ITEM	REQ'D	PART NO	DESCRIPTION
1	1	SEE BLANK	P.C. BOARD BLANK
2	10	T15176-1	LED SPACER
FOR ITEMS BELOW REFER TO ELECTRONIC COMPONENTS DATABASE FOR COMPONENT SPECIFICATIONS			
J61	1	S19365-15	CONNECTOR,PCB,WW,MALE,RT-L,15-PIN
LED1,LED2,LED3,LED4,LED5	5	T13657-11	LED,T-1,3/4,RED,HIGH-INTENSITY
R1,R2	2	S19366-1	POT,ST,0.5W,10K,10%,LINEAR
S1	1	T13381-17	SWITCH,PUSHBUTTON,SPST,GREEN,W/BLACK

RESISTANCE = OHMS



MANUFACTURE AS:  
M19874-1A2  
PART NO. IDENTIFICATION CODE

ENCAPSULATE WITH E1844. (2 COATS)  
BRUSH COAT ACCEPTABLE

NOTES:

- N.A. DO NOT COAT WITH ENCAPSULATION MATERIAL.
- N.B. THERE MUST NOT BE MORE THAN A .010 GAP BETWEEN SPACER & LED, OR BETWEEN SPACER & P.C. BOARD. ENCAPSULATE P.C. BOARD, SPACERS & LOWER HALF OF LED. LEDS MUST BE PERPENDICULAR WITH P.C. BOARD.
- N.C. ENCAPSULATE AROUND BASE OF COMPONENT
- N.D. COAT EXTERNAL PINS WITH ENCAPSULATION MATERIAL.

SCHEMATIC REFERENCE: S25258-1A1

FOR PARTS ORDERS ONLY  
TEST PER E3964-MS


THIS SHEET CONTAINS PROPRIETARY INFORMATION OWNED BY THE LINCOLN ELECTRIC COMPANY AND IS NOT TO BE REPRODUCED, DISCLOSED OR USED WITHOUT THE EXPRESS WRITTEN PERMISSION OF THE LINCOLN ELECTRIC COMPANY, CLEVELAND, OHIO U.S.A.			
UNLESS OTHERWISE SPECIFIED TOLERANCE MANUFACTURING TOLERANCE PER E2056 ON 2 PLACE DECIMALS IS ± .02 ON 3 PLACE DECIMALS IS ± .002 ON ALL ANGLES IS ± .5 OF A DEGREE MATERIAL TOLERANCE ("I") TO AGREE WITH PUBLISHED STANDARDS.	"X" INFO.	Chg. Sheet No. 1-25-2002	DESIGN INFORMATION DRAWN BY: F.V. ENGINEER: Craig Hejl APPROVED:
DO NOT SCALE THIS DRAWING			REFERENCE: EQUIPMENT TYPE: INVERTER WELDERS SUBJECT: LED POT P.C. BOARD ASSEMBLY SCALE: FULL DATE: 3-9-2001 DRAWING No.: M 19874-1

EN-166

SOLID EDGE

**NOTE:** Lincoln Electric assumes no responsibility for liabilities resulting from board level troubleshooting. PC Board repairs will invalidate your factory warranty. **Individual Printed Circuit Board Components are not available from Lincoln Electric.** This information is provided for reference only. Lincoln Electric discourages board level troubleshooting and repair since it may compromise the quality of the design and may result in danger to the Machine Operator or Technician. Improper PC board repairs could result in damage to the machine.

SCHEMATIC-SPI REMOTE PRINTED CIRCUIT BOARD



GENERAL INFORMATION		EQUIP. TYPE	
ELECTRICAL SYMBOLS PER E1537		COMMON CONTROLS	
CAPACITORS = MFD ( 0.22/50V UNLESS OTHERWISE SPECIFIED)		SUBJECT SPI REMOTE/UI PCB SCHEMATIC	
RESISTORS = OHMS ( 1/4W UNLESS OTHERWISE SPECIFIED)		SCALE NONE	
DIODES = 1A,400V (UNLESS OTHERWISE SPECIFIED)		DATE 01/10/02	
LAST NO. USED		SHT. NO. G 4017-1C0/1	
R- 100 0-20 X-13			
C- 42 02-10 L-1			
D- 20 0-9			
SUPPLY VOLTAGE NET			
POWER SUPPLY SOURCE POINT			
COMMON CONNECTION			
FRAME CONNECTION			
EARTH GROUND CONNECTION			

THIS SHEET CONTAINS PROPRIETARY INFORMATION OWNED BY THE LINCOLN ELECTRIC CO. AND IS NOT TO BE REPRODUCED, DISCLOSED OR USED WITHOUT THE EXPRESS PERMISSION OF THE LINCOLN ELECTRIC CO.

SINCE COMPONENTS OR CIRCUITRY ON A PRINTED CIRCUIT BOARD MAY CHANGE WITHOUT AFFECTING THE INTERCHANGEABILITY OF A COMPLETE BOARD, THIS DIAGRAM MAY NOT SHOW THE EXACT COMPONENTS OR CIRCUITRY OF CONTROLS HAVING A COMMON CODE NUMBER.

Chge.Sht.No. 1-25-2002

THE LINCOLN ELECTRIC CO. CLEVELAND, OHIO U.S.A.

PG # 01 SCALE NONE

DR. DATE 01/10/02 CHK. SUP'D'G. SHT. NO. G 4017-1C0/1

NOTE: This diagram is for reference only. It may not be accurate for all machines covered by this manual.



Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Section TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

PC BOARD ASSEMBLY-SPI REMOTE

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

**ITEM**    **REQ'D**    **PART No.**    **DESCRIPTION**

1	1	S4018-C	SPI REMOTE UI PC BOARD BLANK
2	1	S19496-3	POTTING TRAY
3	2	S8025-80	SELF TAPPING SCREW
4	1	S11868-1	FLEX CIRCUIT ASSEMBLY
5	4.00	E2827	EPOXY ENCAPSULATING RESIN
6	108	E3339	ELECTRICAL INSULATING COMPOUND
N.B.	1	S25336-1	SOFTWARE CPLD (X3)
N.C.	1	S25337-1	SOFTWARE CPLD (X4)
N.D.	1		PROGRAM X2 to 250K Hz
N.K.	1	S24671	KEYING PLUG

FOR ITEMS BELOW, REFER TO ELECTRONIC COMPONENTS DATABASE FOR COMPONENT SPECIFICATIONS

C1, C2, C3, C4, C5, C6, C7, C8, C9	44	S25020-3SMT	CAPACITOR, SMD, CERAMIC, 0.1MF, 50V, 10%, X7R, S0805
C10, C11, C12, C13, C14, C15			
C16, C17, C18, C19, C20, C21			
C22, C23, C24, C25, C26, C27			
C28, C29, C30, C31, C32, C33			
C34, C35, C36, C37, C48, C49			
C50, C54, C55, C56, C57			
C38, C39	2	S25020-3SMT	CAPACITOR, SMD, CERAMIC, 2700PF, 50V, 5%, X7R, S0805
C40	1	S13490-183	CAPACITOR, AL, EL, 120MF, 50V, 20%
C41	1	S25020-17SMT	CAPACITOR, SMD, CERAMIC, 0.27MF, 50V, 10%, X7R, S1812
C42	1	S13490-179	CAPACITOR, AL, EL, 1000, 35V, 20%
C43	1	S25024-10SMT	CAPACITOR, SMD, TANTALUM, 22MF, 25V, 10%, S7343
C44, C45, C46	3	S25024-2SMT	CAPACITOR, SMD, TANTALUM, 1.0MF, 35V, 10%, S3528
C47, C51, C52, C53	4	S25024-3SMT	CAPACITOR, SMD, TANTALUM, 2.2MF, 20V, 10%, S3528
C58, C59, C60, C61, C62	5	S25020-2SMT	CAPACITOR, SMD, CERAMIC, 0.022MF, 50V, 10%, X7R, S0805
D1, D2, D3, D4, D5, D6, D7, D8	8	S25049-4SMT	DIODE, SMD, DUAL, 200MA, 30V, SCHOTTKY, SOT-23
D9, D10, D11	3	S25040-1SMT	DIODE, SMD, 1A, 400V, FAST RECOVERY, DO-214BA
D12, D13, D14, D15	4	S25040-2SMT	DIODE, SMD, 1A, 400V, DO-214BAUC
D16, D17	2	S25040-3SMT	DIODE, SMD, DUAL, 0.200A, 70V, UFR
D18, D19	2	S25040-4SMT	DIODE, SMD, DUAL, 0.200A, 70V, UFR
D20	1	S25049-2SMT	DIODE, SMD, 1A, 30V, SMD, SCHOTTKY
D21, D22	2	S25044-1SMT	ZENER DIODE, SMD, 3W, 5.1V, 5%, SMB
D23, D24, D25, D26, D27, D28	6	S25044-3SMT	ZENER DIODE, SMD, 3W, 12V, 5%, SMB
D29, DZ10	2	S25045-1SMT	ZENER, DIODE, SMD, 225mW, 12V, 5%, SOT-23
FTP1, FTP2, FTP3, FTP4, FTP5	6	TESTPT, FUNTION	FUNCTIONAL TEST POINT
FTP6	1	S18248-10	CONNECTOR, MOLEX, M/N, PCB, 10-PIN
J33	1	S24020-12	CONNECTOR, MOLEX, M/N, PCB, 12-PIN, 1IN
J332, J333	2	S24020-16	CONNECTOR, MOLEX, M/N, PCB, 16-PIN, 1IN
L1	1	S25083-3SMT	CHOKE, SMD, POWER, 47UH, 10%, 1.25A
Q1, Q2, Q3, Q4	4	S25050-1SMT	TRANSISTOR, SMD, NPN, 0.5A, 40V, SOT-23, MMBT4401L1
Q5, Q6	2	S25051-4SMT	TRANSISTOR, SMD, NPN, SOT-23, 0.115A, 60V, 7002L1(S)
Q7, Q8	2	S25050-2SMT	TRANSISTOR, SMD, PNP, SOT-23, 0.5A, 40V, MMBT4403L1
Q9	1	S25051-6SMT	TRANSISTOR, SMD, NPN, DPAK, TO-252, 10A, 100V(S)

**P.C. BOARD BLANK REFERENCE INFORMATION**  
BUY COMPLETE AS G4018-C (4 LAYER BOARD PER E3281)

UNLESS OTHERWISE SPECIFIED:  
CAPACITANCE = MICROVOLTS  
INDUCTANCE = HENRIES  
RESISTANCE = OHMS

NOTES:  
N.A. CAUTION: THIS DEVICE IS SUBJECT TO DAMAGE BY STATIC ELECTRICITY. SEE E2454 BEFORE HANDLING.  
N.B. PROGRAM X3 WITH ITEM 7.  
N.C. PROGRAM X4 WITH ITEM 8.  
N.D. PROGRAM X2 WITH ITEM 9.  
N.E. ALL CONNECTORS MUST BE GREASED WITH ITEM 6 PRIOR TO ENCAPSULATION.  
N.F. ATTACH ITEM 1 TO ITEM 2 WITH ITEM 3. TIGHTEN ITEM 3 TO 60 ± 0.5 Nm (5.3 ± 0.5 in-lbs).  
N.G. PLACE BARCODED ASSEMBLY NUMBER IDENTIFICATION AND BARCODED SERIAL IDENTIFICATION IN AREA SHOWN.  
N.H. THESE COMPONENTS MUST BE COMPLETELY COVERED WITH ITEM 5.  
N.K. PLACE ITEM 10 ON PIN 8 OF J332 AS SHOWN.  
N.L. BOARD TO BE POTTED WITH ITEM 4 LAYING ACROSS BOARD AS SHOWN. ONLY 0.4" OR LESS OF ITEM 4 TO BE COVERED WITH ITEM 5.

SCHEMATIC REFERENCE: G4017-100

BUY AS:  
G 4 0 1 8 - 1 C 0  
PART NUMBER IDENTIFICATION CODE

BUY PER E3967  
TEST PER E3964-RM


THIS SHEET CONTAINS PROPRIETARY INFORMATION OWNED BY THE LINCOLN ELECTRIC COMPANY AND IS NOT TO BE REPRODUCED, DISCLOSED OR USED WITHOUT THE EXPRESS WRITTEN PERMISSION OF THE LINCOLN ELECTRIC COMPANY, CLEVELAND, OHIO U.S.A.

UNLESS OTHERWISE SPECIFIED TOLERANCE	DATE	DESIGN INFORMATION	EQUIPMENT TYPE:
MANUFACTURING TOLERANCE PER E2008	1-25-02	DESIGN BY: J.V.	MISCELLANEOUS
ON PLACE DECIMALS BY 100		ENGINEER: Ed Fumoni	SUBJECT: SPI REMOTE/UI P.C. BOARD ASSEMBLY
ON ALL ANGLES IS ± 0.5 OF A DEGREE		APPROVED:	SCALE: FULL DATE: 3-27-2001 DRAWING No.: G 4018-1
MATERIAL TOLERANCE (1) TO AGREE WITH DIMENSIONS INDICATED			
IF NOT INDICATED THIS DRAWING			

NOTE: Lincoln Electric assumes no responsibility for liabilities resulting from board level troubleshooting. PC Board repairs will invalidate your factory warranty. Individual Printed Circuit Board Components are not available from Lincoln Electric. This information is provided for reference only. Lincoln Electric discourages board level troubleshooting and repair since it may compromise the quality of the design and may result in danger to the Machine Operator or Technician. Improper PC board repairs could result in damage to the machine.



SCHEMATIC-SNUBBER PRINTED CIRCUIT BOARD



6-2-2000  
S24761

NOTE: This diagram is for reference only. It may not be accurate for all machines covered by this manual.

Return to Section TOC  
Return to Master TOC  
Return to Section TOC  
Return to Master TOC  
Return to Section TOC  
Return to Master TOC  
Return to Section TOC  
Return to Master TOC



PC BOARD ASSEMBLY-SNUBBER

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC

Return to Section TOC  
Return to Master TOC



ITEM	REQ'D	PART NO.	DESCRIPTION
C1,C2,C3,C4	4	S20500-4	CAPACITOR,PPMF,.0047,1000V,BOX
R1,R3	2	T14648-20	RESISTOR,WW,5W,150,5%,SQ
R2,R4	2	T14648-25	RESISTOR,WW,5W,10,5%,SQ

ITEM	PART NO.	DESCRIPTION	QTY
1	M19532-A	P.C. BOARD BLANK	1
2	T13157-16	TAB TERMINAL	1
3	T9147-11	EYELET-FEMALE	4
4	T9147-15	EYELET-MALE	4

NOTES:  
 N.A. FEMALE EYELET TO BE AGAINST THE COPPER SIDE AS SHOWN  
 EYELET MUST NOT SPIN AFTER CLINCHING.  
 N.B. SOLDER EYELET SO THAT SOLDER COVERS ENTIRE EYELET  
 AND ALL AROUND EYELET ON COPPER SIDE ONLY.  
 NO ICICLES OR SOLDER BLOBS PERMITTED.

MAKE PER E1911  
 ENCAPSULATE WITH E1844, 2 COATS  
 TEST PER E3817-SN

MANUFACTURED AS:  
**M19532-1A0**  
 IDENTIFICATION CODE

THIS SHEET CONTAINS PROPRIETARY INFORMATION OWNED BY THE LINCOLN ELECTRIC COMPANY AND IS NOT TO BE REPRODUCED, DISCLOSED OR USED WITHOUT THE EXPRESS WRITTEN PERMISSION OF THE LINCOLN ELECTRIC COMPANY, CLEVELAND, OHIO U.S.A.					
UNLESS OTHERWISE SPECIFIED TOLERANCE MANUFACTURING TOLERANCE PER E2056 ON 2 PLACE DECIMALS IS ± .02 ON 3 PLACE DECIMALS IS ± .002 ON ALL ANGLES IS ± .5 OF A DEGREE MATERIAL TOLERANCE ("I") TO AGREE WITH PUBLISHED STANDARDS. DO NOT SCALE THIS DRAWING	Chg. Sheet No.	"X" INFO.	DESIGN INFORMATION	REFERENCE:	EQUIPMENT TYPE: INVERTER WELDERS
	6-2-2000	XM5626	DRAWN BY: F.V.		SUBJECT: SNUBBER P.C. BOARD ASSEMBLY
		XC-UF	ENGINEER:	SUPERSEDING:	SCALE: NONE DATE: 10-6-99 DRAWING No.: M 19532-1
			APPROVED:		

EN-166

SOLID EDGE

NOTE: Lincoln Electric assumes no responsibility for liabilities resulting from board level troubleshooting. PC Board repairs will invalidate your factory warranty. **Individual Printed Circuit Board Components are not available from Lincoln Electric.** This information is provided for reference only. Lincoln Electric discourages board level troubleshooting and repair since it may compromise the quality of the design and may result in danger to the Machine Operator or Technician. Improper PC board repairs could result in damage to the machine.

