

This service manual covers adjustment, disassembly, operation, preventative maintenance, troubleshooting procedures and contains an illustrated parts list for the GBC Shredmaster 1130S shredder. The GBC Shredmaster 1130S straight cut shredder is designed for small offices and low volume requirements.

Innovative engineering has provided this shredder with the following operating and safety features:


1. **Automatic Operation** - The unit begins to operate when paper actuates the trigger in the shredder throat area. The motor stops running when the paper has cleared the cutting head and after the shredder has timed out.
2. **Overload Warning** - Whenever the capacity of the shredder is exceeded the unit will stop shredding and the "Reverse" icon will illuminate.
3. **Bin Full** - When the shred bag becomes full, the motor automatically turns off and the "Bin full" icon will illuminate. The shredder will not operate until the shredded material is either compacted or emptied.
4. **Door Ajar** - When the door of the shredder is not fully closed, the "Door Ajar" icon will illuminate. This is a safety feature that will only allow the shredder to operate when the cabinet door is in the closed position.

Before attempting any repairs on the 1130S shredder, review the operating instructions first to gain experience and familiarity with its operation. You will then be better prepared to use the remaining sections of this manual to troubleshoot and repair the shredder.

Required Electrical Service:	115V AC +/- 10%, 60 Hz, 15 Amp
Electrical Rating:	115V AC 3A, @ 60Hz
Motor:	1/8 Hp Thermally Protected
Duty Cycle:	10 Min. On/30 Min. Off
Dimensions: HxWxD	26.75" x 16.75"x 15" (67.9 x 42.5 x 38.1 cm)
Weight W/ Cabinet:	38.71 lbs.
Shredding Speed:	25 FPM @ 1 sheet
Shred Size:	5/32" (4mm)
Throat Width:	9 1/4" (23.5cm)
Capacity:	11-12 sheets of 20# Bond Paper
Noise Level:	68 dB No Load
Shipping Carton Dimensions: HxWxD	32.06" x 22.5" x 20" (81.4 x 57.15 x 50.8 cm)

IMPORTANT SAFETY INSTRUCTIONS

Your safety as well as the safety of others is important to GBC. In this instruction manual and on the product are important safety messages. Read these messages carefully.

-  The safety alert symbol precedes each safety message in this instruction manual and on the product. This symbol indicates a potential personal safety hazard that could hurt you or others, as well as cause product or property damage. Do not connect this unit to electrical power or attempt to operate it before you have read these operating instructions. Save these instructions for later use.

The following two warnings are found on the bottom of the product:






This safety message means that you could be seriously hurt or killed if you open the product and expose yourself to hazardous voltage.











This safety message means that you could be seriously hurt if you place your hands in the discharge shoot.

The following ISO and IEC symbols appear on this product, and their meanings are as follows:

-  Means Power ON
-  Means OFF
-  Means REVERSE

The symbols which become illuminated are:

-  Means Power ON
-  Means the shred bin is full.
-  Means the cabinet door is open.
-  Means an overload has occurred.
Depress the R side of the rocker switch

-  This means you should be careful because long hair can become entangled in the cutting head. This could hurt you.
-  This means don't reach into the feed opening of the cutting head. This could hurt you.
-  This means be careful of ties and other loose clothing which could become entangled in the cutting head. This could hurt you.
-  This means you should be careful of loose jewelry which could become entangled in the cutting head. This could hurt you.

ELECTRICAL SAFEGUARDS

- Unplug your shredder before moving it, emptying the shred bag, or when it is not in use for an extended period of time.
- Do not operate with a damaged power supply cord or plug, after it malfunctions, or after it has been damaged in any manner.
- Do not overload electrical outlets beyond capacity as this can result in fire or electrical shock.
- The socket-outlet should be installed near the equipment and shall be easily accessible.
- Do not alter attachment plug. The plug is configured for the appropriate electrical supply.





FIGURE 1.




FIGURE 2.




FIGURE 3.

SET UP

To insure proper installation and avoid injury, GBC recommends that two people set up this unit.

To protect against damage, your shredder has been shipped in two parts, the shredder head A, the cabinet B.

FIGURE 1. Lock the casters (A) before using the machine to prevent any moving or sliding.

Open the cabinet door. Lift the shredder head by the outside edges and place onto the cabinet.

FIGURE 2. Remove the wire bag rim from the cabinet. Place one of the starter bags onto the rim. Slide the rim with bag back into the cabinet. Close the cabinet door. Your shredder ready for use!

OPERATION -FIGURE 3.

Connect power cord to an appropriate power source. Press the rocker switch (A) to the on "I" position. When the shredder is properly set up with cabinet door fully closed, the Power On light (B) will illuminate.

You are now ready to shred!

To shred simply insert paper into the throat of the unit. Once your document has activated the Automatic On switch the unit will start and then will stop once your document is shredded.

BIN FULL

In order to prevent shreds from backing up into the cutters and jamming your shredder this unit features an automatic bin full shut off. Once the shred bin is full the unit will shut off automatically and the Bin Full light (C) will illuminate. You can now either compact the shreds and continue shredding, or empty the shred bag.

DOOR AJAR

Your shredder is equipped with a safety interlock which will not allow the unit to operate if the cabinet door is open. The Door Ajar light (D) will illuminate if your cabinet door is not fully closed.

OVERLOAD **R**

If too much paper is inserted into the throat of the unit the shredder will sense an overload and the Overload Light (E) will illuminate. To clear the overload, switch the unit to Reverse "R" mode until the paper is clear of the throat area. Switch your unit back into the Power On position, separate your pages into smaller sets and shred.