



Microwave SMW 900 EDS A1



 **Microwave**
Operating instructions

 **Mikrobølgeovn**
Betjeningsvejledning

SMW 900 EDS A1



INDEX	PAGE
Intended Use	3
Important safety instructions	3
Items supplied	6
Technical Data	6
Before you begin	7
Basic principles of microwave cookery.....	7
Use suitable cookware.....	7
Description of the appliance	8
Commissioning	8
Installation of the appliance.....	8
Preparing the appliance.....	8
Inserting the turntable 3.....	9
Operation	9
Setting the Clock.....	9
Dormant mode.....	9
Setting the kitchen timer.....	10
Child protection system.....	10
Query functions.....	10
Heating and cooking	10
Microwave operation.....	10
Grill function "Top heat".....	12
Grill function "Top and bottom heat".....	12
Grill function "Bottom heat".....	12
Combination cooking process "Grill".....	12
Convection operation.....	14
Convection operation with preheating.....	14
Combination cooking process "Convection".....	14
Defrosting	15
Defrosting by weight.....	15
Defrosting by time.....	16
Auto menu	16
Starting the Auto Menu.....	16
Memory function.....	19
Select a start time.....	20

Recipes	21
Meat patty	21
Baking frozen ready-made breadrolls	21
Potato gratin	21
Muffins	22
Cleaning and Care	22
Troubleshooting	23
Disposal	24
Warranty and Service	24
Importer	24

Read these operating instructions carefully before using the appliance for the first time and preserve this booklet for later reference. Pass this booklet on to whoever might acquire the appliance at a future date.

MICROWAVE

Intended Use

This appliance is intended for the heating up and preparation of foodstuffs according to the described procedures.

Any modifications to the appliance shall be deemed to be improper use and implies substantial danger of accidents. The manufacturer declines to accept responsibility for damage(s) arising out of usage contrary to the instructions specified below.

This appliance is not intended for commercial use.

Important safety instructions

Carefully read these safety and operating instructions before the first use and preserve them for future reference.

Attention!

Warnings regarding damages to the appliance.

Danger! / **Risk of injury!**

Warning about physical injuries and electric shock!

Risk of fire!

Warning about risks of fire.

Notice!

Note – Hints and tips for using the microwave.

Safety precautions for the avoidance of excessive contact with microwave energy

- Do not try to operate the appliance while the door is open, as this can lead to you coming into contact with a potentially harmful dose of microwave radiation. It is also important not to break open or manipulate the safety locks .
- Do not jam anything between the front of the appliance and the door, and make sure that there is no residual food or cleaning agent on the seals.

Risk of injury!

- *If the door or the door seal is damaged, UNDER NO CIRCUMSTANCES may you continue to use the appliance. Arrange for it to be repaired as soon as possible by qualified specialists.*
- *Never attempt to repair the appliance yourself. Removal of the appliance housing could cause the release of microwave energy. Arrange for the repair to be carried out only by qualified specialists.*
- *This appliance is not intended for use by individuals (including children) with restricted physical, physiological or intellectual abilities or deficiencies in experience and/or knowledge unless they are supervised by a person responsible for their safety or receive from this person instruction in how the appliance is to be used. Children should be supervised to ensure that they do not play with the appliance.*
- *Children may only be allowed to use the appliance without supervision if appropriate instructions have been given that have provided the child with the knowledge to use the cooker in a safe manner and to understand the risks of improper use.*

- Only use this appliance for its intended purpose as described in this manual. Do not use any caustic chemicals or vapours in this appliance. This microwave oven is especially designed for the heating, cooking, grilling or drying of foodstuffs. It is not designed for use in industrial or laboratory areas.
- Do not operate the microwave oven if the power cable or plug are damaged. To avoid the risk of injury, arrange for damaged power cables or plugs to be exchanged by qualified specialists.
- Keep children well away from the microwave oven when it is in use. Risk of Burns!
- UNDER NO CIRCUMSTANCES should you remove the microwave oven housing.
- Should the lamp in the interior of the microwave oven need replacing, arrange for this to be done by a qualified specialist.
- NEVER touch the microwave oven door, housing, ventilation openings, accessories or the dinnerware directly after the grill, combi or automatic menu process. The parts will be very hot. Allow them to cool down before cleaning them.
- Ensure that the plug is at all times easily accessible, so that it can be quickly removed in the event of an emergency.
- People fitted with a heart pacemaker should consult their doctor about the possible risks of using a microwave oven before taking one into use.
- Do not allow the power cable to hang from a table or work surface. Children could pull on it.
- After they have been warmed up, always open containers, popcorn-bags etc. with the opening pointing away from your body. Escaping steam could lead to scalds.
- NEVER stand directly against the microwave oven when opening the door. Escaping steam could lead to scalds.
- Do not fry in the microwave. Hot oil can damage parts of the appliance and utensils and even cause skin burns.
- ALWAYS shake-up or stir warmed up baby glasses or bottles! The contents could have heated up unevenly and the baby could be burned/scalded by them. AT ALL EVENTS, check their temperature BEFORE feeding them to the baby!
- Do not modify the microwave oven.
- Microwave radiation is dangerous! Maintenance and repairs requiring the removal of access covers, which are intended for protection against contact with microwave radiation, are to be carried out by trained specialists only.
- Before feeding babies, check the temperature of the foodstuff/drink so as to avoid potentially lethal burns or scalds.
Cooking utensils may become hot from the heat emitted by the food, therefore you may require oven gloves to touch them. In this case, a check should also be made to ensure that the cooking utensils are suitable for use with the microwave oven.



Attention! Hot surfaces!



Risk of fire

- NEVER leave the microwave oven unattended if you are heating foodstuffs packed in plastics or paper.
- NEVER place flammable materials close to the microwave oven or the ventilation openings.
- Remove ALL metallic closures from the packaging of the foodstuff that you intend to warm up.
Risk of fire!
- When making popcorn, use only popcorn-bags suitable for microwave ovens.

- Do not use the microwave oven to warm up cushions filled with kernels, cherry stones or gels. Risk of fire!
- Do not use the microwave oven for storing food-stuffs or other objects.
- Do not exceed the cooking times detailed by the manufacturer.
- Do not place any objects on the microwave oven when it is in use. The ventilation openings would be blocked!
- Do not place the microwave oven adjacent to other appliances discharging heat, for example, an oven.
- Clean the microwave oven thoroughly after warming up greasy foods, especially if they were not covered. Allow the appliance to cool down completely before cleaning it. Residues such as fat or grease cannot be allowed to collect on the heating elements of the grill. They could possibly ignite.
- Do not thaw frozen fat or oil in the microwave oven. The fat or oil could ignite.
- Do not use an external timing switch or a separate remote control system to operate the appliance.

Attention! Appliance Damage!

- Do not use the microwave oven when it is empty. The only exception is for the initial commissioning (see chapter "Commissioning").
- NEVER insert foreign objects into the ventilation openings or the door safety locks.
- Do not use metallic utensils which reflect microwaves and lead to sparking. Do not place tins in the microwave oven.
- Do not place plastic containers in the microwave oven immediately after a grill, combi or automatic menu process. The plastic could melt.

- This microwave oven may not be located in areas with high humidity or where moisture could collect.

Liquids and other foods must not be heated in airtight containers, as these may explode and damage the appliance.

- Do not lean on the microwave oven door.
- Insufficient cleanliness of the appliance could lead to the destruction of the upper surfaces, which themselves influence its useful lifespan and could possibly also lead to dangerous situations.

Danger

- NEVER submerge the appliance, the power cable or the plug in water or other fluids.
- Keep the power cable away from hot surfaces. Do not lead it in front of the microwave oven door. The heat could damage the cable.
- NEVER pour fluids into the ventilation openings or the safety locks. Should fluids ever enter them, IMMEDIATELY switch the microwave oven off and remove the plug from the mains power socket. Arrange for the microwave oven to be checked by qualified specialists.

Safety tips

- To minimize the risk of fire in the microwave: When heating food in plastic or paper containers, always keep an eye on the microwave oven when it is in operation, as these materials can easily catch fire.

When heating drinks in the microwave, bubbling may be delayed when the drink boils. Therefore, be careful when handling the container. To avoid sudden simmering:

- If possible, place a glass rod in the fluid for as long as it is being heated.

- To avoid an unexpected reboiling, leave the fluid to stand in the microwave oven for ca. 20 seconds after being warmed up.

- Puncture the skins of potatoes, sausages or similar. Otherwise, they could explode.
- Proceed with caution when warming up fluids. Use only open containers, so that any air bubbles produced can escape.
- Should you notice smoke, switch the appliance off or remove the plug from the socket and keep the door closed to suffocate any possible flames.
- Eggs in their shells and hard-boiled eggs should not be heated in the microwave oven as they could explode, even on completion of the heating process.
Food with thick skins, such as potatoes, whole pumpkins, apples and chestnuts must be pricked before cooking.
- Do not transport the microwave oven when it is in use.

Earthing information/correct installation

This appliance must be earthed. This appliance is to be connected only to a correctly earthed power socket. An individual circuit, solely for the connection of the microwave oven, is recommended.

⚠ Danger: Improper use of the earthing connector could increase the risk of an electric shock.

- **Take note:** Should have any questions about earthing or the instructions on the use of this electrical appliance, please consult an electrician or a maintenance technician.

Neither the manufacturer nor the dealer can accept liability for damage to the microwave oven or injury to persons resulting from failure to comply with the instructions for electrical connection.

Interference with other appliances

The operation of the microwave may cause interference on your radio, television or similar appliances. If such interferences should occur, they may be reduced or corrected by the following remedial measures:

- Clean the door and the seal of the microwave.
- Re-align the receiver antenna of your radio or television.
- Position the microwave in a different place to the receiver.
- Move the microwave away from the receiver.
- Plug the microwave into another wall socket.
The microwave and the receiver should be connected to different circuits.

Items supplied

Microwave oven
Turntable
Grill stand
Operating instructions
Concise Information

Technical Data

Power rating:	230 - 240 V ~ 50 Hz
Maximum power consumption:	2000 W
Microwave:	1400 W
Double Grill:	1700 W
Top Grill:	1200 W
Convection:	2000 W
Maximum power output Microwave:	900 W
Microwave frequency:	2450 MHz

Before you begin

Basic principles of microwave cookery

- Arrange the food with consideration.
- The thickest parts near the edges.
- Pay attention to the cooking time. Select the shortest possible stated cooking time and increase as required. Food that is cooked too long can begin to smoke or catch fire.
- Cover the food during cooking with a lid suitable for microwave cookery. The lid prevents splashing and helps in the even cooking of the food.
- While cooking, turn the food in the microwave once so that items such as chicken or hamburgers are cooked more quickly.
- Large pieces of food, such as joints of meat, must be turned at least once.
- Completely re-arrange foods such as meatballs after half the cooking time. Turn them and move the meatballs from the middle of the cookware to the edge.

Use suitable cookware

- The ideal material for a microwave oven is microwave-permeable, allowing the energy to penetrate the container to heat the food. Microwaves cannot permeate metal. For this reason metal containers and cookware may not be used.

- When using the microwave for heating do not use products made of recycled paper. These can contain minute fragments of metal, which can generate sparks and/or fires.
- We recommend the use of round/oval cookware instead of square or oblong containers, as food in corner areas tends to overcook. The following list provides general hints to assist you in selecting the correct cookware.










Cookware	Micro-wave oven	Grill	Con-vection	Combi-nation
Heat-resistant glass	Yes	Yes	Yes	Yes
Non-heat-resistant glass	No	No	No	No
Heat-resistant ceramics	Yes	Yes	Yes	Yes
Plastic crockery suitable for microwave	Yes	No	No	No
Kitchen roll	Yes	No	No	No
Metal tray/plate	No	Yes	Yes	No
Grill stand	No	Yes	Yes	No
Alufoil & Foil containers	No	Yes	Yes	No

Risk of fire!

NEVER use the grill stand or other metallic objects when you are using the appliance in the microwave mode or in the combination cooking process.

Metals reflect the microwave radiation and it leads to the generation of sparks. This could cause a fire and irreparably damage the appliance!

Description of the appliance

- 1 Display
- 2 Door opener button
- 3 Turntable
- 4 Rollers
- 5 Cold air intake
- 6 Combination button Microwave - Convection 
- 7 Grill Button 
- 8 Clock/Timer button 
- 9 Convection button 
- 10 Control dial/Button Start/Quickstart 
- 11 Stop/Child safety 
- 12 Weight/Kitchen timer button 
- 13 Combination button Microwave - Grill 
- 14 Operation (Microwave) button 
- 15 Grill stand

Commissioning

Installation of the appliance

Risk of fire!

This microwave oven is not suitable for installation in a kitchen cabinet. In closed cabinets sufficient ventilation for the appliance cannot be assured. The appliance could be damaged and there would be the additional risk of a fire!

- Select an even surface offering sufficient space for the adequate ventilation of the appliance: Ensure that you maintain a minimum distance of 10 cm from neighbouring walls/surfaces. Make sure that the door of the microwave oven can be opened easily. Maintain a gap of at least 20 cm above the microwave oven.
- Ensure that the electrical plug is accessible without problem, so that in case of danger it can be easily reached and removed.
- Do not remove the pads underneath the microwave oven.
- Do not block the ventilation openings 5. If you do, it could cause damage to the appliance.
- Install the appliance as far away as possible from radios and televisions. The operation of the microwave oven can cause malfunctions of radio and television reception.

Warning:

Do not install the microwave above a cooker or any other appliance generating heat. Installation at such a location could cause damage to the appliance and thereby a subsequent lapse of the warranty provisions.





Preparing the appliance

- Remove all packaging materials and any protective film on the surface of the housing.
- Insert the plug into a mains power socket. Use a 230 - 240 V, 50 Hz mains power socket with a 16 A fuse. It is recommended that the microwave oven is powered from its own ring main. If you are unsure about how to connect the microwave oven, consult a specialist.

Before the first regular usage of the microwave oven the appliance must be heated up to remove any remaining production residues.

After inserting the mains plug into the socket, open the microwave door.

Without foodstuffs or accessories (turntable ③ and grill stand ⑮), switch the appliance on in the mode Grill:

- Press the button Grill ⑦  twice. With this, you have chosen to use the grill with top and bottom heat. In the display ① the symbol  and the symbol  appear.
- Adjust the control dial ⑩ to a cooking time of 10 minutes.
- Press button Start/Quickstart ⑩  to start the grilling process.

Take note:

On the first usage, the generation of light smoke and a slight smell can occur, this is due to the production residues. This is harmless. Provide for sufficient ventilation. For example, open a window.

- After 10 minutes, the appliance switches itself off automatically. Wait until it has cooled down completely.
- Remove the plug from the mains power socket then, after cleaning the appliance with a moist cloth, dry it carefully.





Inserting the turntable ③


- Place the turntable ③ centrally on the axle in the cooking area. Ensure that it slides completely onto the axle and is firmly seated.

Operation

Setting the Clock

After inserting the mains plug into the socket, open the microwave door once. The display ① indicates "1:00".

1. Press the button Clock ⑧ . In the display appears ① "Hr 24". Press the button Clock ⑧  once again should you wish to switch to the 12-hour mode.
2. By turning the control dial ⑩ programme in the current hour.
3. Press the button Clock ⑧ . The minutes value blinks.
4. By turning the control dial ⑩ programme in the current minute.
5. When the correct time is programmed in, press the button Clock ⑧ . The colon blinks to indicate that the clock is running.








To read off the current time when the microwave oven is in operation, press the button Clock ⑧ ; the time will then be indicated in the display ① for approx. 4 seconds.

Dormant mode

The microwave automatically switches itself into a dormant mode if no keys are pressed for a long time. The display lighting is first dimmed slightly. After about 4 minutes the display lighting switches off. Press any key to exit the dormant mode and press the appropriate button to call up the required function.

Setting the kitchen timer


The microwave oven is provided with a kitchen timer which you can use independent of the microwave operation.







1. Press the button Weight/Kitchen timer .
 when the appliance is in standby mode. In the display **1** appears "0:00" and the symbol .
2. Now set the desired time using the control dial . You can select any time range from 10 seconds to 95 minutes.
3. Press the button Start/Quickstart . the appliance emits an acoustic signal. The count down begins. After approx. 3 seconds the current time is shown once again. The cooking timer progresses further in the background.
If you wish to check the progress of the kitchen timer, press the Weight/Kitchentimer button  . It appears for a brief period in the kitchen timer.

Once the set time has expired, signal tones sound until the door is opened.

Child protection system


Engage this setting to prevent accidental activation by children and other persons not familiar with the operation of the appliance.

The symbol for Child safety  appears in the display **1** and, for as long as this function is activated, the appliance cannot be put into operation.


- Press and hold the button Stop/Child safety   until a signal tone sounds and the symbol for Child safety  appears in the display **1**. The buttons and the control dial now no longer have a function.
- To deactivate Child safety, press and hold the Stop/Child safety button   until a signal tone sounds and the symbol for Child safety  extinguishes.

Query functions

Query the time during operation

During the cooking process press the button Clock . The time appears in the display **1** for approx. 3 seconds.

Query the power level operation

During the cooking process press the button Operation . In the display **1** the activated operational level appears for approx. 3 seconds.

Heating and cooking

Note

This microwave is equipped with a cooling function. This means that after a cooking or grill process that takes at least two minutes, the fan of the machine continues running for about 3 minutes. This is not a malfunction of the appliance! The rapid cooling helps to prolong the life of the appliance.

Note

*For hygienic reasons, never place the food you want to cook in the microwave directly onto the turntable **3**.*


Always place it in dishes suitable for microwave ovens. Excepted from this is the preparation of fresh pizza (see chapter "Automatic Menu").

Microwave operation



Note


During the cooking process, drops of water can form on the oven door or on the housing. This is normal and is not an indication of a malfunction. When the appliance has cooled down, wipe the moisture off with a dry cloth.

Risk of fire!

NEVER use the grill stand  or other metallic objects when you are using the appliance in the microwave mode. Metals reflect the microwave radiation and it leads to the generation of sparks. This could cause a fire and irreparably damage the appliance!


Selecting the operation level

- Press the button Operation   the appropriate number of times to set the required power.
- **1x** for 900 Watt power (P900).
- **2x** for 800 Watt power (P800).
- **3x** for 700 Watt power (P700).
- **4x** for 600 Watt power (P600).
- **5x** for 500 Watt power (P500).
- **6x** for 400 Watt power (P400).
- **7x** for 300 Watt power (P300).
- **8x** for 200 Watt power (P200).
- **9x** for 100 Watt power (P100).

The operational level is indicated in the display  (e. g. P800 at 800 Watt power).

Programming the cooking time


After you have selected the power level, programme in the desired cooking time:

- Turn the control dial  until the desired cooking time has been programmed in.

The increments for setting the time with the control dial are as follows:




- from 0 sec. to 5 min: in 10 second increments
- from 5 to 10 min: in 30 second increments
- from 10 to 30 min: in 1 minute increments
- from 30 to 95 min: in 5 minute increments

Aborting/stopping an input process





Press the button Stop   once to cancel or end the input of data. The appliance reverts to standby mode.

Starting the cooking process

When you have set the power and cooking time, you can start the cooking process:

To start the cooking process, press button Start/Quick start . In the display  the symbols for microwave operation  and "M1" appear. The programmed time counts backwards.

Interrupting the cooking process







Press the button Stop   once to interrupt a cooking process. The appliance interrupts the cooking process and stops countdown of the remaining time. Press the button Start/Quickstart   to continue the cooking process.

Abort the cooking process

Press the button Stop   twice to stop the cooking process. The appliance reverts to standby mode.

Quick start

With this function you can immediately begin cooking at 900 W power for 30 seconds (or longer, up to 95 minutes).

- Press the button Start/Quickstart   once. In the display  appear the symbols for microwave operation  and "M1", as well as ":30". The microwave starts the cooking process for 30 seconds. The countdown begins. Should you wish to cook for longer than 30 seconds, repeatedly press the button Start/Quickstart   until the desired time is reached.

The time levels are apportioned as follows:




- from 30 sec. to 5 min: in 30 second increments
- from 5 Min. to 95 Min: in 1 minute increments

Grill function "Top heat"

This grill function is eminently suitable for baked-over sandwiches and gratins.

When grilling with "top heat", always use the metal stand **15**. To achieve an optimal grilling result.





Always place the grillstand **15** on the turntable **3**.

1. Press the button Grill  **7** once to activate the grill function "top heat".
In the display **1** appear the symbols for the grill function "top heat"  and "Gr 1".
2. Set the required cooking time with the rotary switch **10**. The maximum possible cooking time setting is 95 minutes.
3. Press button Start/Quickstart **10**  to start the grill function.

Grill function "Top and bottom heat"

This grilling function can be used for thin slices of meat, steaks, meatballs, sausage or pieces of chicken. When grilling with "top and bottom heat", always use the metal stand **15**. To achieve an optimal grilling result.




Always place the grillstand **15** on the turntable **3**.

1. Press the button Grill  **7** twice to activate the grill function "top and bottom heat".
In the display **1** appear the symbols for the grill function "top heat" , for the grill function "bottom heat"  and "Gr 2".
2. Set the required cooking time with the rotary switch **10**. The maximum possible cooking time setting is 95 minutes.
3. Press button Start/Quickstart **10**  to start the grill function.

Grill function "Bottom heat"

When grilling with "bottom heat", always use the metal stand **15**. To achieve an optimal grilling result.

Always place the grillstand **15** on the turntable **3**.

1. Press the button Grill  **7** three times to activate the grill function "bottom heat".
In the display **1** appear the symbols for the grill function "bottom heat"  and "Gr 3".
2. Set the required cooking time with the rotary switch **10**. The maximum possible cooking time setting is 95 minutes.
3. Press button Start/Quickstart **10**  to start the grill function.

Combination cooking process "Grill"

This function combines the grill function and the normal microwave operation. During the combination mode, a certain amount of time for cooking and the remaining time for grilling is carried out automatically and in one process. You may notice a quiet clicking noise when the oven is switching between modes.





Risk of fire!

*NEVER use the grill stand **15** or other metallic objects, when you are using the appliance in the combination cooking process. Metals reflect the microwave radiation and it leads to the generation of sparks. This could cause a fire and irreparably damage the appliance!*

Combination 1





In Combination 1 the microwave element amounts to 30% and the grill element amounts to 70% of the cooking time. This is suitable for, for example fish or gratins.

The microwave function and the grill function "top heat" are used.

1. Press the combination button Microwave – Grill  once to activate combination 1. In the display **1** appears , , and "C 1".
2. Set the required cooking time with the rotary switch **10**. The maximum possible cooking time setting is 95 minutes.
3. To start, press the button Start/Quickstart **10** .






Combination 2

In Combination 2 the microwave element amounts to 55% and the grill element amounts to 45% of the cooking time. This is suitable for, for example omlettes, puddings or lasagne. The microwave function and the grill function "top heat" are used.

1. Press the combination button Microwave – Grill  twice to activate combination 2. In the display **1** appears , , and "C 2".
2. Set the required cooking time with the rotary switch **10**. The maximum possible cooking time setting is 95 minutes.
3. To start, press the button Start/Quickstart **10** .






Combination 3

In Combination 3 the microwave element amounts to 30% and the grill element amounts to 70% of the cooking time. This is suitable for, for example potatoes. The microwave function and the grill functions "top and bottom heat" are used.

1. Press the combination button Microwave – Grill  three times to activate combination 3. In the display **1** appears , , , and "C 3".
2. Set the required cooking time with the rotary switch **10**. The maximum possible cooking time setting is 95 minutes.
3. To start, press the button Start/Quickstart **10** .

Combination 4


In Combination 4 the microwave element amounts to 55% and the grill element amounts to 45% of the cooking time. This is suitable for, for example, poultry dishes. The microwave function and the grill functions "top and bottom heat" are used.


1. Press the combination button Microwave – Grill  four times to activate combination 4. In the display **1** appears , ,  and "C 4".
2. Set the required cooking time with the rotary switch **10**. The maximum possible cooking time setting is 95 minutes.
3. To start, press the button Start/Quickstart **10** .

Convection operation

When cooking with convection, hot air circulates in the oven. Hot air is especially recommended for cooking souffles or crunchy foods.

Selecting the temperature

- Press the button Convection  the appropriate number of times to set the required temperature.
- **1x** for 230 °C
- **2x** for 215 °C
- **3x** for 200 °C
- **4x** for 185 °C
- **5x** for 170 °C
- **6x** for 155 °C
- **7x** for 140 °C
- **8x** for 125 °C
- **9x** for 110 °C
- **10x** for 95 °C

The temperature level is indicated in the display  (e. g. 230C for a temperature of 230 °C).





Programming the cooking time

After you have selected the temperature level, programme in the desired cooking time:


- Turn the control dial  until the desired cooking time has been programmed in.

Starting the cooking process

When you have set the temperature and cooking time, you can start the cooking process:








To start the cooking process, press button Start/Quick start   . In the display  the symbols for hot air operation  and "M1" appear.

The programmed time counts backwards.

When the set time has elapsed, "End" and "Hot" will appear alternately in the display  . A signal tone is heard repeatedly.

Convection operation with preheating


You can also preheat your microwave before you start a cooking process:






1. Select the desired temperature by pressing the Convection  button the required number of times.
2. To preheat, press the button Start/Quickstart   . In the display  appears "30:00" and the time counts down. As soon as the set temperature is reached, a signal tone is heard.
3. Open the door and insert the food to be cooked into the microwave.
4. Set the required cooking time with the rotary switch  . The maximum possible cooking time setting is 95 minutes.
5. To start, press the button Start/Quickstart   .


Combination cooking process "Convection"



This function combines the convection function with the normal microwave operation. With this, for example, meat is juicy and tender but still crisp.

Risk of fire!

NEVER use the grill stand  or other metallic objects, when you are using the appliance in the combination cooking process. Metals reflect the microwave radiation and it leads to the generation of sparks. This could cause a fire and irreparably damage the appliance!

1. Press the combination button Microwave - Convection   :
 - 1 x, to activate the combination with 200 °C,
 - 2 x, to activate the combination with 170 °C,
 - 3 x, to activate the combination with 140 °C,
 - 4 x, to activate the combination with 110 °C.In the display  appear the selected temperature, "M1" and the symbols  and  .

- Set the required cooking time with the rotary switch **10**. The maximum possible cooking time setting is 95 minutes.
- To start, press the button Start/Quickstart **10** 

- When the food you have selected appears in the display **1**, press the button Weight/Kitchen Timer **12**   repeatedly until the desired weight is shown in the display **1**.



Defrosting

Defrosting by weight

i Take note:

Always place the food to be defrosted on dishes suitable for use in a microwave oven. Never directly onto the turntable **3**!

This function enables you to defrost meat, poultry and fish with ease. The defrosting time and the power level are calculated and set automatically once you have entered the weight.

- In standby mode turn the control dial **10** anti-clockwise until "A -12" and  appear in the display **1**.
- Press the button Start/Quickstart **10** .
- Now select the food to be defrosted by turning the control dial **10**. In the display **1** appears:

"d-01" and  for "Beef"

„d-02“ and  for "Pork"

"d-03" and  for "Pizza"

"d-04" and  for "Poultry"

"d-05" and  for "Fruit/Vegetables"

"d-06" and  for "Fish"

"d-07" and  for "Potates"

The following weights can be set:

"d-01" /  / "Beef" 100 - 1800g


„d-02“ /  / "Pork" 100 - 1800g


"d-03" /  / "Pizza" 100 - 900g

"d-04" /  / "Poultry" 100 - 1800g


"d-05" /  / "Fruit/Vegetables" 100 - 900g

"d-06" /  / "Fish" 100 - 1800g

"d-07" /  / "Potatoes" 100 - 900g

- When the required weight appears in the display **1**, press the button Start/Quickstart **10** . The appliance automatically calculates the required defrosting period.


i Take note:










To ensure optimum defrosting, it is necessary to turn the food during the thawing process. The appliance reminds you of the need to turn by sounding signal tones and "turn" appears on the display **1**. Open the appliance door, turn the foodstuff and then re-close the door. Press the button Start/Quickstart **10**  to continue the thawing process.

If you do not want to turn the foodstuff, just wait for the signal tones to stop. The appliance will automatically continue the thawing process. We recommend that you do turn the food. This will ensure an even thawing.




Defrosting by time

Take note:

Always place the food to be defrosted on dishes suitable for use in a microwave oven. Never directly onto the turntable !

1. In standby mode turn the control dial  anti-clockwise until "A -13" and  appear in the display .
2. Press the button Weight/Kitchen Timer 
 / .
3. Set the desired time using the control dial .
4. Press button Start/Quickstart   to start the defrosting operation. The count down begins.

Take note:

To ensure optimum defrosting, it is necessary to turn the food during the thawing process. The appliance reminds you of the need to turn by sounding signal tones and "turn" appears on the display . Open the appliance door, turn the foodstuff and then re-close the door. Press the button Start/Quickstart   to continue the thawing process.

If you do not want to turn the foodstuff, just wait for the signal tones to stop. The appliance will automatically continue the thawing process. We recommend that you do turn the food. This will ensure an even thawing.

Auto menu




For foods that are intended to be prepared in the Auto Menu modus it is not necessary to programme in the period of the cooking process and the power level. It is quite sufficient to enter which type of food is to be cooked/boiled, and its weight.














Note







The microwave calculates the time/operational level for **fresh** foods. Frozen foods are not cooked with the timings set by the microwave (except for automatic programme "Pizza").

If needs be, defrost frozen foods with the defrost programme beforehand (see section "Defrosting").


Starting the Auto Menu






1. Turn the control dial  (in standby operation) slowly to the left to call-up the automatic menu mode. In the display  a numer appears (e.g. "A - 02" for automatic programme 2 (sausage)) and the symbol "sausage". By turning the control dial  select the automatic menu appropriate for your food.



Display	Symbol	Foodstuff	Weight
A-01		Beef	200 - 1400g
A-02		Sausage	100 - 500g
A-03		Pizza	P1 150-450g P2 150-450g P3 150-450g
A-04		Beverages	200 - 500ml
A-05		Pork	200 - 1400g
A-06		Fish	200 - 1200g
A-07		Entrees	300 / 500g
A-08		Warming	300 - 700g
A-09		Poultry	400 - 1400g
A-10		Fruit/ Vegetables	100 - 1000g
A-11		Potatoes	100 - 800g
A-12		Defrosting by weight	-
A-13		Defrosting by time	-

- Press, if necessary repeatedly, the button Weight/Kitchen Timer    until the desired weight appears in the display .
- Press the button Start/Quickstart   to commence the cooking process.

 **Note**

To obtain uniform warming or cooking, some foodstuffs should be turned after 1/2 - 2/3 of the period of the cooking process. The microwave oven will stop automatically after this time, four signal tones sound and "Turn" appears on the display .

Display	Symbol	Foodstuff	turn over after.
A-01		Beef	1/2 of the time
A-02		Sausage	2/3 of the time
A-05		Pork	1/2 of the time
A-06		Fish	2/3 of the time
A-09		Poultry	2/3 of the time

- Turn the foodstuff. Proceed cautiously with the possibly already hot food.
- Press the button Start/Quickstart   to continue the cooking process.

 **Note**

If you do not want to turn the foodstuff, just wait for the signal tones to stop. The appliance will automatically continue the cooking process. We recommend that you do turn the food. This will ensure even cooking.


Note

Should the meal not be properly cooked on completion of the auto-menu, continue cooking for a couple of minutes with the Quick start programme.

Risk of fire!

For the programmes with enabled Grill function (A-01, A-02, A-03, A-05, A-06, A-09), under NO circumstances may you use covers or non-heat-resistant dishes, as they can melt or catch fire!

Risk of injury!








After a cooking process, the turntable  is very hot! You should therefore always use an oven cloth or heat resistant oven gloves when removing it from the cooking area.

Take note:

Take note that size, shape and the type of foodstuff help determine the result of the cooking process.



Example 1:






Proceed as follows to cook 400 g of vegetables or fruit:

1. In standby mode turn the control dial  slowly to the left until "A-10" appears in the display .
2. Press the button Weight/Kitchen Timer   four times. 400 g appears in the display .
3. Press the button Start/Quickstart   to commence the cooking process.

Example 2:








To heat 300 ml water, proceed as follows:

1. In standby mode turn the control dial  slowly to the left until "A-04" appears in the display .

2. Press the button Weight/Kitchen Timer   three times. 300 g appears in the display .
3. Press the button Start/Quickstart   to commence the cooking process.












Example 3:



To heat 300 g of appetizers, proceed as follows:

1. In standby mode turn the control dial  slowly to the left until "A-07" appears in the display .
2. Press the button Weight/Kitchen Timer   once. 300 g appears in the display .
3. Press the button Start/Quickstart   to commence the cooking process.


Baking Pizza

With the automatic programme "Pizza" you can prepare delicious pizza in the microwave.

1. In standby mode turn the control dial  slowly to the left until "A-03" appears in the display .
2. Press the button Start/Quickstart  .
3. Using the control dial  select the matching pizza programme:
 - "P-01" for deep-frozen pizza, temperature approx. -18 °C
Weight 150 g - 450 g ("P-01" appears in the display .
 - "P-02: for chilled pizza, temperature approx. 5 °C,
Weight 150 g - 450 g ("P-02" appears in the display .
 - "P-03" for fresh pizza, temperature approx. 20 °C,
Weight 150 g - 450 g ("P-03" appears in the display .
4. Repeatedly press the button Weight/Kitchen Timer   until the desired weight appears in the display .











5. Press the button Start/Quickstart   to commence the cooking process.

Note

If you cook fresh pizza, you can place it directly on the turntable . It will be very crispy. Ensure that the edge of the pizza does not extend up to the walls of the cooking area during cooking.

Example:

Proceed as follows to cook a deep-frozen, 450 g heavy pizza:

1. In standby mode turn the control dial  slowly to the left until "A-03" appears in the display .
2. Press the button Start/Quickstart  .
3. Using the control dial  select the programme "P-01".
4. Press the button Weight/Kitchen Timer   repeatedly until 450g appears in the display .
6. Press the button Start/Quickstart   to commence the cooking process. The appliance calculates the time required automatically.

Memory function













Use the memory function if you wish to carry out up to 3 processes, one after the other. .

After finishing a process, the acoustic signal sounds once and the next process starts immediately.

Note

The automatic menu programmes defrosting by time and defrosting by weight cannot be saved.

To save three events in succession, proceed as follows:








1. Programme in the first operation. For instance, a microwave process, at 900 W power, for 2 minutes. "2:00", "M1" and  appear in the display . Do NOT then press the button Start/Quickstart   !
2. Programme in the second operation. For example, a grilling, with bottom heat, for 3 minutes. "3:00", "M2" and  appear in the display . Do NOT then press the button Start/Quickstart   !
3. Programme in the third operation. For example, a convection process, at 200 °C, for 2 minutes. "2:00", "M3" and  appear in the display .
4. To start, press the button Start/Quickstart  .



The microwave starts the first operation. When an operation is completed, you will hear a signal tone and the oven automatically starts the next operation.

Select a start time

With this programme you can preset a specific start time for the cooking or grilling of the foodstuff. If the programming is carried out correctly, the appliance starts automatically at the programmed time.




i Take note: The clock must be correctly set to be able to select the function "Selecting the start time"..

1. Enter the desired cooking program:
 - For microwave operation: Press the button Operation **14**  the appropriate number of times to set the required power level. Programme the cooking time with the control dial **10**.
 - For grilling: Press the button Grill  **7** until the desired grill function is activated. Set the required cooking time with the control dial **10**.
 - For convection operation: Press the button Convection **9**  the appropriate number of times to set the required temperature. Programme the cooking time with the control dial **10**.
 - For the combination process "Convection": Press the combination button Microwave - Convection **6**  the appropriate number of times to set the required temperature. Programme the cooking time with the control dial **10**.
 - For the combination process "Grill": Press the combination button Microwave - Grill **13**  the appropriate number of times to set the grilling process. Programme the cooking time with the control dial **10**.
 - For an automatic menu: Select the desired automatic menu using the control dial **10**. Repeatedly press the button Weight/Kitchen Timer **12**  until the desired weight appears in the display **1**.
2. Press the button Clock/Timer **8**  . The display **1** shows the currently set time and the hour digit flashes.
3. Turn the control dial **10** to programme in the hours.

4. Press the button Clock/Timer **8**  , now the minute figure flashes.
5. Turn the control dial **10** to programme in the minutes.
6. Press the button Start/Quickstart **10** **10**  . The hourglass appears in the display **1**. The microwave oven automatically starts the cooking process at the programmed time.

i Take note:

To query the saved start time, press the button Clock/Timer **8**  .

The saved start time will be shown in the display **1**. To delete the saved start time and thus cancel the programmed procedure, press the button Clock/Timer **8**  so that the set start time appears in the display **1**. Then, while the start time is to be seen in the display **1**, press the button Stop/Child safety  +  **11**. The hourglass in the display **1** extinguishes. The saved procedure is deleted.

Recipes

Meat patty

- Shape approx. 125g of minced beef into a patty (about 75mm in diameter, height 35mm).
- Locate the meat patties evenly on a plate suitable for microwave ovens and then place it on the turntable ③.

Preparation

The best results are achieved with the following self-programmed combination (See also the chapter memory function):

- Process 1:
Convection 230 °C, 4:00 Mins.
- Process 2:
Microwave 900 W power, 5:30 Mins.
- Process 3:
Convection 230 °C, 2:00 Mins (depending on personal taste, a time of up to 4:00 min can also be possible).

Baking frozen ready-made breadrolls

- For the baking of breadrolls, select the convection function.
- Locate 3-4 rolls on an appropriate dish for microwave ovens then place it on the turntable ③. Pre-heating of the microwave is not required.

Select the following settings for the baking process:

- Convection 170 °C, Duration: 12 Minutes

If you wish to bake additional rolls directly afterwards, shorten the baking time for these by about 1-2 minutes, as the appliance is now already pre-heated.

Potato gratin

Ingredients

- 750 g waxy potatoes, peeled
 - 300 g cream
 - 100 g grated cheese with a fat content of 25% to 30% fat in dry matter.
 - Spices to taste (e.g., salt/pepper)
- Use a microwave-proof, round dish with a lid, height 5-6 cm and a diameter of about 22 cm.

Preparation

- Cut the potatoes into slices approximately 3-4 mm thick.
- Lay about half of the potatoes in the casserole dish in the style of roof tiles.
- Sprinkle the potatoes with about half of the cheese.
- Then add half of the spices, and about 150 g of cream.
- Lay the rest of the sliced potatoes on it, also in the style of roof tiles.
- Sprinkle the remaining cheese over the potatoes and pour the remaining cream over them.
- Sprinkle the remaining spices over the gratin.
- Cover the dish with the lid and place it in the centre of the turntable ③.

The best results are achieved with the following self-programmed combination:

- Process 1:
Microwave 900 W power, 10:00 Mins.
- Process 2:
Convection 230 °C, 10:00 Mins.
- Process 3:
Microwave 900 W power, 10:00 Mins.

A pre-heating is not required.

Muffins

Ingredients

This recipe yields 10 to 20 muffins.


- Baking margarine (80% fat content) or salted butter
- 170 g granulated sugar (up to 0.3 mm grain size)
- 3 eggs (55-60 g with shell/Size M)
- 225 g wheat flour
- 7 g baking powder
- 0,25 g salt

Preparation

- Mix all ingredients well.
- Fill the muffin pastry into commercial paper baking cases (diameter 45 mm, height 28 mm)
- Preheat the oven with the convection function to 170°C.

Take note:

Should, due to the number of muffins, multiple baking operations be necessary, preheating is required only once.

- Distribute the muffins evenly on the turntable .
- Select the following settings for the baking process:
Convection 170°C, Duration: 12 Minutes

Cleaning and Care

Risk of injury!

Before cleaning, switch the microwave oven off and remove the plug from the mains power socket.


Otherwise, there is the great risk of receiving an electric shock!



UNDER NO CIRCUMSTANCES should you immerse the appliance in water or other liquids. This could result in you receiving a fatal electric shock and the appliance could be damaged.

- Always keep the interior of the microwave oven clean.
- If splashes of food or spilt liquids stick to the walls of the microwave, wipe them off with a damp cloth.
- Use a mild detergent if the microwave is more heavily soiled.
- Avoid using cleaning sprays and other aggressive cleaning agents, as they can cause stains, stripes or a blurring of the door surface.

Clean the external walls with a damp cloth.

- To avoid damage to the functional components in the interior of the microwave, do not let liquids to seep in through the ventilation slits .
- Regularly remove splashes or contaminants. Clean the door, both sides of the viewing window, door seals and adjacent components with a damp cloth. Do not use abrasive cleaning agents.

- Should steam collect on or around the outside of the appliance door, wipe it off with a soft towel. This can happen if the microwave is operated in extremely humid conditions.
- Clean the turntable ③ regularly. Clean the plate in warm soapy water or in the dishwasher.
- Clean the grill stand ⑮ in warm dishwater and dry it well.
- Regularly eliminate odours. Place a deep microwave bowl with a cup of water and the juice and peel of a lemon into the microwave oven. Heat it up for 5 minutes. Wipe off thoroughly and rub dry with a cloth.
- Should replacement of the bulb in the microwave be necessary, arrange for it to be exchanged by a dealer or consult our Service Department.

Troubleshooting

The display ❶ indicates nothing.

- The plug is not inserted into a power socket. Check the plug.
- The mains power socket is defective. Try another mains power socket.
- The display ❶ is defective. Contact our Customer Services Department.

The appliance does not respond to pressing the buttons.

- The Child safety facility is activated. Deactivate the Child safety facility (see chapter "Operation").

The appliance does not start the cooking/warming process.

- The door is not properly closed. Close the door correctly.

The turntable ③ generates loud noise when revolving.

- The turntable ③ is not correctly positioned on the axle. Insert the turntable ③ correctly into the cooking area.
- The small rollers ④ and/or the floor of the cooking area are unclean. Clean the rollers ④ and the floor of the cooking area.

The display ❶ indicates "E01" and signal tones sound.

- The microwave is overheated. Terminate the current programme immediately. Remove the plug from the mains power socket, open the microwave door and allow the appliance to cool down.

The display ❶ indicates "E02" and signal tones sound.

- There is an error on the sensor. Interrupt the programme and let the appliance cool down. Then restart the microwave. If the error occurs again, contact Customer Support.
- There is an error during the heating up of the appliance. Interrupt the programme and let the appliance cool down. Then restart the microwave. If the error occurs again, contact Customer Support.

The display ❶ indicates "E03" and signal tones sound.

- Due to a short circuit or open circuit voltage, the microwave has switched into fault protection. Stop the programme and remove the power plug. If possible, eliminate the problem, e.g. metals in the cooking area, which can lead to the above problem when using the microwave function. Otherwise, please contact our Customer Support.

Disposal



Do not dispose of this appliance in your normal domestic waste. This product is subject to the provisions of European Directive 2002/96/EC.

Dispose of the appliance through an approved disposal centre or at your community waste facility. Observe the currently applicable regulations. In case of doubt, please contact your waste disposal centre.



Dispose of all packaging materials in an environmentally friendly manner.

Warranty and Service

You receive a 3-year warranty for this appliance as of the purchase date. This appliance has been manufactured with care and meticulously examined before delivery.

Please retain your receipt as proof of purchase. In the case of a warranty claim, please make contact by telephone with our service department. Only in this way can a post-free despatch for your goods be assured.

The warranty covers only claims for material and manufacturing defects, not for transport damages, worn parts or for damage to fragile components, e.g. buttons or batteries. This product is for private use only and is not intended for commercial applications.

In the event of misuse and improper handling, use of force and interference not carried out by our authorized service branch, the warranty will become void.. Your statutory rights are not restricted in any way by this warranty.

The warranty period is not extended by repairs effected under warranty. This applies also to replaced and repaired parts. Damages or defects discovered after purchase are to be reported directly after unpacking, at the latest two days after the purchase date. Repairs carried out after lapse of the warranty period are subject to charge.

DES UK LTD

Tel.: 0871 5000 700 (£ 0.10 / minute)
e-mail: support.uk@kompernass.com

Kompernass Service Ireland

Tel.: 1850 930 412 (0,082 EUR/Min.)
Standard call rates apply. Mobile operators may vary.
e-mail: support.ie@kompernass.com

Kompernass Service Cyprus

Tel.: 800 9 44 01
e-mail: support.cy@kompernass.com

Importer

KOMPERNASS GMBH
BURGSTRASSE 21
44867 BOCHUM, GERMANY

www.kompernass.com

INDHOLDSFORTEGNELSE	SIDE
Anvendelsesområde	27
Vigtige sikkerhedsanvisninger	27
Medfølger ved levering	30
Tekniske data	30
Før du starter	31
Grundprincipper ved tilberedning i mikrobølgeovn.....	31
Anvend velegnede køkkenredskaber.....	31
Beskrivelse af mikrobølgeovnen	32
Første brug	32
Opstilling af mikrobølgeovnen.....	32
Forberedelse af mikrobølgeovnen.....	32
Indsætning af drejetallerkenen.....	33
Betjening	33
Indstilling af ur.....	33
Hvile-modus.....	33
Indstilling af minuturet.....	34
Børnesikring.....	34
Informationsfunktioner.....	34
Tilberedning	34
Mikrobølgefunktion.....	34
Grillfunktion "overvarme".....	36
Grillfunktion "over- og undervarme".....	36
Grillfunktion "undervarme".....	36
Kombinationstilberedning "grill".....	36
Varmluftdrift.....	38
Varmluftfunktion med forvarmning.....	38
Kombinationstilberedning "varmluft".....	38
Optøning	39
Optøning efter vægt.....	39
Optøning efter tid.....	40
Automatisk menu	40
Start for den automatiske menu.....	40
Hukommelsesfunktion.....	43
Valg af starttid.....	44

Opskrifter	45
Frikadeller	45
Bagning af færdige frostboller	45
Kartoffelgratin.....	45
Muffins	46
Rengøring og vedligeholdelse	46
Afhjælpning af fejl	47
Bortskaffelse	48
Garanti og service	48
Importør	48

Læs betjeningsvejledningen omhyggeligt igennem, før du bruger mikrobølgeovnen første gang, og gem vejledningen til senere brug. Hvis du giver mikrobølgeovnen videre til andre, skal vejledningen også følge med.

MIKROBØLGEOVN

Anvendelsesområde

Denne mikrobølgeovn er beregnet til opvarmning og tilberedning af fødevarer som angivet under de beskrevne fremgangsmåder.

Enhver ændring af mikrobølgeovnen anses for anvendelse uden for anvendelsesområdet og indebærer betydelige farer for ulykker. Producenten påtager sig intet ansvar for skader, der opstår som følge af anvendelse uden for anvendelsesområdet.

Denne mikrobølgeovn er ikke beregnet til erhvervs-mæssigt brug.

Vigtige sikkerhedsanvisninger

Læs sikkerhedsanvisningerne og betjeningsvejledningen omhyggeligt igennem, før du bruger mikrobølgeovnen første gang, og gem disse til senere brug.

Obs!

Advarsel mod skader på mikrobølgeovnen.

Pas på! | **Fare for uheld!**

Advarsel mod personskader og elektriske stød!

Brandfare!

Advarsel mod brandfare.

Bemærk!

Anvisninger og tips vedrørende behandling af mikrobølgeovnen.

Forholdsregler der forhindrer mulig, langvarig kontakt med mikrobølgeenergi

- Prøv ikke på at bruge mikrobølgeovnen med åben dør, da du så kan udsættes for en skadelig dosis mikrobølgestråling. Det er også vigtigt, at du ikke bryder sikkerhedslåsene op eller manipulerer dem.
- Sæt aldrig noget i klemme mellem ovnens forside og døren, og sørg for, at der ikke samler sig snavs eller rester fra rengøringsmidler på tætningsfladerne.

Fare for uheld!

- Hvis døren eller dørpakningerne er beskadigede, må mikrobølgeovnen ikke anvendes længere. Lad den omgående reparere af en kvalificeret reparatør.
- Prøv ikke på at reparere mikrobølgeovnen selv. Når kabinettet tages af, kan der frigøres mikrobølgeenergi. Lad kun reparationer udføre af en kvalificeret reparatør.
- Denne mikrobølgeovn må ikke benyttes af personer (inklusive børn) med begrænsede fysiske, sensoriske eller psykiske evner eller med manglende erfaringer og/eller manglende viden, medmindre en ansvarlig person holder opsyn med dem og giver dem anvisninger til, hvordan mikrobølgeovnen anvendes. Børn skal være under opsyn, så det sikres, at de ikke leger med mikrobølgeovnen.
- Børn må kun bruge mikrobølgeovnen uden opsyn, hvis de er blevet oplært tilstrækkeligt i at bruge den sikkert og kan forstå de farer, der kan opstå ved forkert betjening.

- Mikrobølgeovnen må kun anvendes til anvendelsesområdet efter beskrivelsen i denne vejledning. Der må ikke anvendes ætsende kemikalier eller dampe i denne ovn. Denne mikrobølgeovn er specielt konstrueret til opvarmning, kogning, grillning eller tørring af fødevarer. Den er ikke beregnet til brug inden for industrien eller på laboratorier.
- Brug ikke mikrobølgeovnen, hvis strømledningen/strømskikket er beskadiget. Lad en professionel reparatør udskifte ledningen/strømskikket, så risiko for ulykker undgås.
- Hold børn på afstand af mikrobølgeovnens dør, mens ovnen er i funktion. Forbrændingsfare!
- Fjern aldrig mikrobølgeovnens kabinet.
- Lampen inden i mikrobølgeovnen må udelukkende udskiftes af en kvalificeret reparatør.
- Rør aldrig ved mikrobølgeovnens dør, kabinnet, ventilationsåbninger, tilbehørsdele eller bestikket lige efter grill-, kombi- eller automatik-menuprogrammet. Delene bliver meget varme. Lad delene afkøle før rengøring.
- Sørg for, at det altid er nemt at komme til stikket, så det hurtigt kan trækkes ud, hvis der opstår nødsituationer.
- Personer, som bærer pacemaker, skal kontakte deres læge om mulige risici, før mikrobølgeovnen tages i brug.
- Lad aldrig ledningen hænge over bordet eller arbejdsområdet. Børn kan trække i den.
- Åbn altid dåser, popcornposer etc. efter opvarmningen, så åbningen peger væk fra din krop. Du kan blive skoldet af dampene, som lukkes ud.
- Stil dig ikke lige foran mikrobølgeovnen, når du åbner døren. Du kan blive skoldet af dampene, som lukkes ud.
- Lad være med at friturestege i mikrobølgeovnen. Varm olie kan beskadige ovnens dele og køkkenredskaber og også forårsage forbrændinger på huden.
- Ryst altid opvarmede babyglas eller babyflasker, eller rør rundt i dem! Indholdet kan opvarmes uensartet, og barnet kan brænde sig på det. Kontrollér altid temperaturen, før du mader barnet!
- Lad være med at ændre noget ved mikrobølgeovnen.
- Mikrobølgestråler er farlige! Lad kun en autoriseret reparatør vedligeholde eller reparere mikrobølgeovnen, hvis det er nødvendigt at fjerne afdækningerne, som beskytter mod kontakt med mikrobølgestråler.
- Kontrollér temperaturen, før maden spises, så barnet ikke udsættes for livsfarlige forbrændinger. Køkkenredskaber kan blive varme af den opvarmede mads afgivne varme, så det kan være nødvendigt at bruge grydelapper for at holde på dem. Køkkenredskaberne skal være godkendt til brug i mikrobølgeovn.



Obs! Varm overflade!



Brandfare!

- Lad aldrig mikrobølgeovnen være uden opsyn, hvis du varmer madvarer op i plast- eller papiremballage.
- Stil ikke brændbare materialer i nærheden af mikrobølgeovnen eller ventilationsåbningen.
- Fjern alle lukninger af metal på emballagerne til de madvarer, du vil opvarme. Brandfare!
- Brug kun popcorn-poser, som er egnede til mikrobølgeovn, hvis du vil lave popcorn.

- Brug ikke mikrobølgeovnen til at opvarme puder, der er fyldt med granulat, kirsebærsten eller gel. Brandfare!
- Brug ikke mikrobølgeovnen til opbevaring af madvarer eller andre ting.
- Overskrid aldrig tilberedningstiderne, som er angivet af producenten.
- Stil ikke genstande på mikrobølgeovnen, så længe den er i gang. Ventilationsåbningerne dækkes til!
- Stil ikke mikrobølgeovnen i nærheden af apparater, som afgiver varme, som f.eks. en bageovn.
- Rengør mikrobølgeovnen grundigt efter opvarmning af fedtholdige madvarer, og især hvis de ikke har været tildækket. Lad ovnen køle helt af, før den rengøres. Der må ikke sidde rester som for eksempel fedt på grillens varmeelementer. Det kan føre til overopvarmning og antændelse.
- Lad være med at optø frosset fedt eller olie i mikrobølgeovnen. Fedtet eller olien kan antændes.
- Brug aldrig et eksternt tænd-sluk-ur eller et separat fjernkontrollsystem til at styre mikrobølgeovnen med.
- Mikrobølgeovnen må ikke opstilles på steder med høj luftfugtighed, eller hvor der samler sig fugtighed.
- Væsker og andre næringsmidler må ikke opvarmes i lufttætte beholdere, da de kan eksplodere og beskadige mikrobølgeovnen.
- Læn dig ikke op ad mikrobølgeovnens dør.
- Hvis køkkenredskaberne ikke er ordentligt rene, kan det betyde, at overfladen ødelægges, hvilket påvirker brugstiden og muligvis kan føre til farlige situationer.

Fare!

- Læg aldrig ledningen eller stikkene ned i vand eller andre væsker.
- Hold ledningen på afstand af varmekilder. Lad den ikke ligge foran mikrobølgeovnens dør. Varmen kan ødelægge ledningen.
- Hæld aldrig væsker i ventilationsåbningerne eller sikkerhedsdørlåsene. Hvis der kommer væske ind, skal du straks slukke for mikroovnen og tage stikket ud af stikkontakten. Lad mikrobølgeovnen efterse af en kvalificeret reparatør.

Obs! Skader på mikrobølgeovnen!

- Mikrobølgeovnen må ikke startes, hvis den er tom. Det gælder dog ikke den første opstart (se kapitlet "Første opstart").
- Sæt aldrig genstande ind i ventilationsåbningerne eller sikkerhedsdørlåsene.
- Brug ikke redskaber af metal, som reflekterer mikrobølger og fører til gnistdannelse. Stil ikke metaldåser ind i mikrobølgeovnen.
- Stil ikke plastbeholdere ind i mikrobølgeovnen lige efter et grill-, kombi- eller automatik-menu-program. Plasten kan smelte.

Sikkerhedstips

- For at minimere brandrisikoen i mikrobølgeovnen: Hold altid øje med mikrobølgeovnen, når du opvarmer mad i plast- eller papirbeholdere, da materialet eventuelt kan antændes.
- Ved opvarmning af drikkevarer i mikrobølgeovnen kan det begynde at boble med forsinkelse, når drikken koger. Vær derfor forsigtig, når du tager fat i beholderen. Hvis du vil undgå pludselig kogning:

- Hvis du har en glaspind, kan du stille den i væsken, så længe den opvarmes.
- For at undgå, at væsken bruser pludseligt op, skal den blive stående 20 sekunder i mikrobølgeovnen efter opvarmning.

- Prik kartofler, pølser og lign. med en gaffel. Ellers kan de eksplodere.
- Vær forsigtig ved opvarmning af væsker. Brug kun åbne skåle, så luftbobler, som opstår under opvarmningen, kan slippe væk.
- Hvis der opstår røg, skal du slukke for ovnen, tage stikket ud og holde døren lukket, så eventuelle flammer kvæles.
- Æg i skal og hårdkogte æg må ikke opvarmes i mikrobølgeovnen, da de kan eksplodere i ovnen, selv efter at opvarmningen er slut. Fødevarer med tyk skræl som f.eks. kartofler, hele knolde, æbler og kanstanjer, skal prikkes før kogningen.
- Flyt ikke mikrobølgeovnen, mens den er i funktion.

Jordingsanvisninger/korrekt installation

Denne mikrobølgeovnen skal jordes. Denne mikrobølgeovnen må kun slutes til en stikkontakt, som er sluttet til jord efter forskrifterne. Det anbefales at bruge en separat strømkreds, der kun forsyner mikrobølgeovnen.

⚠ Fare: Hvis jordstikket behandles forkert, kan det medføre risiko for elektrisk stød.

i Bemærk: Hvis du har spørgsmål angående jording eller anvisningerne på elområdet, skal du henvende dig til en elektriker eller service-tekniker.

Producenten eller forhandleren kan ikke påtage sig ansvaret for beskadigelse af mikrobølgeovnen eller for personskader, der skyldes, at fremgangsmåden i forbindelse med ilttilslutningen ikke er blevet fulgt.

Radiointerferens med andre apparater

Når du bruger mikrobølgeovnen, kan det fremkalde forstyrrelser i din radio, dit fjernsyn eller lignende apparater.

Hvis der skulle opstå sådanne interferenser, kan de reduceres eller fjernes ved hjælp af følgende foranstaltninger:

- Rengør mikrobølgeovnens dør og tætningsflade.
- Foretag en ny justering af radioens eller fjernsynets antenne.
- Anbring mikrobølgeovnen et andet sted end der, hvor modtageren står.
- Fjern mikrobølgeovnen fra modtageren.
- Tilslut mikrobølgeovnen til en anden stikkontakt. Mikrobølgeovnen og modtageren skal belaste hver sin gren af strømkredsløbet.

Medfølger ved levering

Mikrobølgeovn
Drejetallerken
Grillstativ
Betjeningsvejledning
Kort information

Tekniske data

Mærkespænding:	230 - 240V ~ 50 Hz
Maks. optaget effekt:	2000 W
Mikrobølgeovn:	1400 W
Doppelt-grill:	1700 W
Øverste grill:	1200 W
Varmluft:	2000 W
Maksimal effekt, mikrobølge:	900 W
Mikrobølgefrekvens:	2450 MHz

Før du starter

Grundprincipper ved tilberedning i mikrobølgeovn

- Anbring madvarerne med omtanke.
- De tykkeste steder skal være i nærheden af kanten.
- Vær opmærksom på tilberedningstiden. Vælg den korteste af de angivne tilberedningstider, og forlæng den ved behov. Madvarer, der tilberedes alt for længe, kan begynde at ryge eller antændes.
- Dæk madvarerne til med et låg, der er egnet til mikrobølgeovn under tilberedningen. Låget forhindrer sprøjt og bidrager også til, at madvarerne tilberedes ensartet.
- Vend madvarerne en gang under tilberedningen i mikrobølgeovnen, så madretter som kylling eller hamburger bliver hurtigere færdige.
- Store stykker som for eksempel en steg skal vendes mindst én gang.
- Flyt dele som f.eks. kødboller rundt efter halvdelen af tilberedningstiden. Vend dem, og anbring bollerne fra midten og ud mod kanten.

Anvend velegnede køkkenredskaber.

- Det ideelle materiale til en mikrobølgeovn er mikrobølgegennembrængeligt, hvilket vil sige, at det slipper energien gennem beholderen, så maden opvarmes. Mikrobølger er ikke i stand til at trænge gennem metal. Derfor må der ikke anvendes metalbeholdere eller metalkøkkenredskaber.

- Brug ikke produkter af genbrugspapir ved opvarmning i mikrobølgeovn. Papiret kan indeholde bittesmå metalfragmenter, der kan fremkalde gnister og/eller brand.
- Det anbefales at bruge rundt/ovalt køkken-service i stedet for firkantet/aflangt, da madvarerne, som ligger i hjørnerne, let koger ud. Den efterfølgende liste skal opfattes som en generel hjælp til valg af køkkenredskaber.

Køkken-service	Mikrobølgeovn	Grill	Varm luft	Kombination
Varmebestandigt glas	Ja	Ja	Ja	Ja
Ikke-varmebestandigt glas	Nej	Nej	Nej	Nej
Varmebestandigt keramik	Ja	Ja	Ja	Ja
Plastservice, egnet til mikrobølgeovn	Ja	Nej	Nej	Nej
Køkkenrulle	Ja	Nej	Nej	Nej
Metalbakke/-plade	Nej	Ja	Ja	Nej
Grillstativ	Nej	Ja	Ja	Nej
Alufolie & foliebeholder	Nej	Ja	Ja	Nej

Brandfare!

Brug aldrig grillstativet eller andre metalgenstande, hvis du anvender mikrobølgeovnen til mikrobølgefunktion eller til kombinationstilberedning. Metal reflekterer mikrobølgestrålingen og fører dermed til gnistdannelse. Det kan føre til brand, og ovnen kan gå i stykker, så den ikke kan repareres igen!

Beskrivelse af mikrobølgeovnen

- 1 Display
- 2 Knap til døråbner
- 3 Drejetallerken
- 4 Ruller
- 5 Ventilationsåbning
- 6 knap kombination mikroovn - varmluft 
- 7 Knap grill 
- 8 Knap ur/timer 
- 9 Knap varmluft 
- 10 Drejeknap / knap start/lynstart 
- 11 Stop/børnesikring 
- 12 Knap vægt/minutur 
- 13 Knap kombination mikrobølge - grill 
- 14 Knap effekt (mikrobølge) 
- 15 Grillstativ

Første brug

Opstilling af mikrobølgeovnen

Brandfare!

Denne mikrobølgeovn er ikke beregnet til indbygning i et køkkenskab. I lukkede skabe ventileres mikrobølgeovnen ikke tilstrækkeligt. Derved kan ovnen beskadiges, og der er risiko for brand!

- Vælg en jævn flade, hvor der er tilstrækkelig plads til siderne for ventilation af ovnen. Mellem ovnen og de tilstødende vægge er det vigtigt, at der er en minimumafstand på 10 cm. Kontrollér, at mikrobølgeovnens dør kan åbnes uden problemer. Der skal være en afstand på mindst 20 cm over mikrobølgeovnen.
- Det skal være nemt at komme til strømstikket, så det hurtigt kan trækkes ud, hvis der opstår farlige situationer.
- Afmonter ikke fødderne under mikrobølgeovnen.
- Blokér ikke ventilationsåbningen **5**. Ellers kan ovnen ødelægges.
- Anbring mikrobølgeovnen så langt væk fra radio og fjernsyn som muligt. Når mikrobølgeovnen arbejder, kan det forstyrre radio- eller fjernsynsmodtagelsen.

Obs:

Placér ikke mikrobølgeovnen over et komfur eller et andet apparat, der frembringer varme. Hvis ovnen opstilles sådan et sted, kan den skades, hvilket samtidig betyder bortfald af garantien.





Forberedelse af mikrobølgeovnen

- Fjern emballagematerialet og en eventuel beskyttelsesfolie på kabinetets overflade.
- Sæt stikket i stikkontakten. Brug en 230 - 240 V, 50 Hz stikkontakt med en 16 A sikring. Det anbefales, at mikrobølgeovnen forsynes med en separat strømkreds. Hvis du ikke er sikker på, hvordan mikrobølgeovnen skal sluttes til, skal du søge råd hos en fagmand.

Før mikrobølgeovnen anvendes, skal den varmes op, mens den er tom, så rester efter produktionen kan fordampe.

Når du har sat stikket i stikkontakten, skal du åbne døren til mikrobølgeovnen én gang.

Tænd for ovnen uden fødevarer og tilbehør (drejetallerken ③ og grillstativ ⑮) på grillfunktionen:

- Tryk to gange på knappen grill ⑦ . Derved vælger du grillfunktionen med over- og undervarme. I displayet ① vises symbolet  og symbolet .
- Indstil en tilberedningstid på 10 minutter med drejeknappen ⑩.
- Tryk på knappen start/lynstart ⑩  for at starte grillningen.

Bemærk:

Når mikrobølgeovnen bruges første gang, kan der udvikles lidt røg og lugt på grund af rester i forbindelse med produktionsteknikken. Dette er uskadeligt. Sørg for tilstrækkelig udluftning. Åbn for eksempel vinduet.

- Efter 10 minutter slukkes ovnen automatisk. Vent, til den er helt afkølet.
- Tag stikket ud af stikkontakten, og rengør derefter ovnen indeni og tør den omhyggeligt af.





Indsætning af drejetallerkenen ③


- Sæt drejetallerkenen ③ midt på akslen i ovnrummet. Sørg for, at den glider helt ned på akslen og sidder fast.

Betjening

Indstilling af ur

Når du har sat stikket i stikkontakten, skal du åbne døren til mikrobølgeovnen én gang. Displayet ① viser "1:00".

1. Tryk på ur-knappen ⑧ . I displayet ① vises "Hr 24". Tryk på ur-knappen ⑧  igen, hvis du vil skifte til 12-timers-modus.
2. Indstil den ønskede time ved at dreje på drejeknappen ⑩.
3. Tryk på tasten ur ⑧ . Minutangivelsen blinker.
4. Indstil de ønskede minutter ved at dreje på drejeknappen ⑩.
5. Når du har indstillet klokkeslættet, skal du trykke på tasten ur ⑧ . Dobbelpunktet viser, at uret er i gang ved at blinke.







For at aflæse det aktuelle klokkeslæt mens mikrobølgeovnen er i gang, skal du trykke på tasten ur ⑧ ; Klokkeslættet vises i ca. 4 sekunder i displayet ①.

Hvile-modus

Mikrobølgeovnen skifter automatisk til hvile-modus, hvis der ikke trykkes på nogen knap i længere tid. Displaybelysningen dæmpes først lidt. Efter ca. 4 minutter slukkes displaybelysningen. Tryk på en vilkårlig knap for at forlade hvile-modus og åbne funktionen til knappen, der er trykket på.

Indstilling af minuturet



Mikrobølgeovnen er udstyret med et minutur, som du kan anvende uafhængigt af mikrobølgefunktionen.






1. Tryk på knappen vægt/minutur  , når ovnen står på standby-funktion. I displayet  vises "0:00" og symbolet .
2. Indstil nu den ønskede tid med drejeknappen  . Du kan foretage tidsindstillinger fra 10 sekunder til 95 minutter.
3. Tryk på knappen start/lynstart  . Der lyder en signaltone. Tiden tæller ned. Efter cirka 3 sekunder vises det normale klokkeslæt igen. Minuturet kører videre i baggrunden. Hvis du ind imellem vil kontrollere minuturets tid, kan du trykke på knappen vægt/minutur  . Minuturet vises i kort tid.

Så snart den indstillede tid er gået, lyder signaltonerne, indtil døren åbnes.

Børnesikring



Aktivér børnesikringen for at forhindre, at mikrobølgeovnen kan sættes i gang af små børn, som ikke er under opsyn, eller af andre personer, som ikke er fortrolige med betjening af ovnen.

Symbolet for børnesikringen  vises i displayet  , og ovnen kan ikke tændes, så længe denne funktion er aktiveret.



- Tryk på knappen stop/børnesikring  , og hold den nede, indtil der lyder en signaltone, og symbolet for børnesikring  vises i displayet  . Mikrobølgeovnens knapper og drejeknappen fungerer nu ikke længere.
- For at deaktivere børnesikringen skal du trykke på knappen stop/børnesikring  og holde den nede, indtil der lyder en signaltone, og symbolet for børnesikring  forsvinder.

Informationsfunktioner

Aflæsning af klokkeslæt mens ovnen er i gang

Tryk under tilberedningen på tasten ur  . I displayet  vises klokkeslættet i ca. 3 sekunder.

Aflæsning af effekttrin mens ovnen er i gang


Tryk under tilberedningen på knappen effekt  . I displayet  vises det aktiverede effekttrin i ca. 3 sekunder.

Tilberedning

Bemærk

Denne mikrobølgeovn er udstyret med en afkølingsfunktion. Efter tilberedning eller grillning, der varer mindst 2 minutter, fortsætter ovnens ventilator derfor med at køre i cirka 3 minutter. Det er ikke en fejl-funktion ved mikrobølgeovnen! Den hurtige afkøling hjælper med til, at ovnen holder længere.

Bemærk

Af hygiejniske grunde må du aldrig lægge fødevarer, som skal tilberedes i mikrobølgeovnen, direkte på drejetallerkenen .


Læg dem altid på køkkenredskaber, der er egnet til mikrobølgeovne. Undtagen herfra er tilberedning af frisk pizza (se kapitlet "Automatisk menu").

Mikrobølgefunktion

Bemærk

På mikrobølgeovnens dør eller på kabinettet kan der dannes vanddråber under tilberedningen. Det er normalt og ikke tegn på, at mikrobølgeovnen har fejlfunktioner. Tør fugten af med en tør klud, når ovnen er kølet af.

Brandfare!

Brug aldrig grillstativet  eller andre metalgenstande, hvis mikrobølgeovnen anvendes i mikrobølgefunktion. Metal reflekterer mikrobølgestrålingen og fører dermed til gnistdannelse. Det kan føre til brand, og ovnen kan gå i stykker, så den ikke kan repareres igen!

Valg af effekt

Tryk på knappen effekt   for at vælge det ønskede effektrin.

- **1x** for 900 Watt effekt (P900).
- **2x** for 800 Watt effekt (P800).
- **3x** for 700 Watt effekt (P700).
- **4x** for 600 Watt effekt (P600).
- **5x** for 500 Watt effekt (P500).
- **6x** for 400 Watt effekt (P400).
- **7x** for 300 Watt effekt (P300).
- **8x** for 200 Watt effekt (P200).
- **9x** for 100 Watt effekt (P100).

Effekten vises i displayet  (f. eks. P800 ved effekt på 800 Watt).

Indstilling af tilberedningstiden




Når effekten er valgt, skal du indstille den ønskede tilberedningstid:

- Drej drejeknappen , til den ønskede tilberedningstid er indstillet.

Trinene for drejeknappens indstillingstid er følgende:

- fra 0 sek. til 5 min.: i trin på 10 sek.
- Fra 5 til 10 min.: i trin på 30 sek.
- Fra 10 til 30 min.: i trin på 1 min.
- Fra 30 til 95 min.: i trin på 5 min.

Afbrydelse/afslutning for indtastningen






 +  Tryk én gang på knappen Stop  "11" for at afbryde en indtastning og afslutte. Ovnen skifter tilbage til standby-tilstand igen.

Start for tilberedningen


Når du har indstillet effekten og tilberedningstiden, kan tilberedningen startes:

Tryk på knappen start/lynstart   for at starte tilberedningen. I displayet  vises symbolerne for mikrobølgefunktion  og "M1". Den indstillede tid tæller ned.

Afbrydelse af tilberedningen





Tryk én gang på knappen stop   +  for at afbryde tilberedningen. Mikrobølgeovnen afbryder tilberedningen og stopper den resterende tid. Tryk på knappen start/lynstart   for at fortsætte tilberedningen igen.



Stop for tilberedningen

Tryk to gange på tasten stop   +  for at afbryde tilberedningen. Ovnen skifter tilbage til standby-tilstand igen.

Lynstart

Med denne funktion kan du straks starte tilberedningen i 30 sekunder (eller længere, op til 95 minutter) med 900 W effekt.

- Tryk én gang på knappen start/lynstart   . I displayet  vises symbolerne for mikrobølgefunktion  og "M1". samt ":30". Mikrobølgeovnen starter tilberedningen i 30 sekunder. Tiden tæller ned.

Hvis du vil varme længere end 30 sekunder, skal du trykke på knappen start/lynstart   , til den ønskede tid er nået.

Tids-trinene opdeles på følgende måde:




- fra 30 sek. til 5 min.: i trin på 30 sek.
- fra 5 min. til 95 min.: i trin på 1 min.

Grillfunktion "overvarme"

Denne grillfunktion er særdeles velegnet til gratinerede sandwiches og gratiner.

Brug altid grillstativet **15**, når der grilles med "overvarme". Så opnår du det bedste grillresultat.

Stil altid grillstativet **15** på drejetallerkenen **3**.





1. Tryk én gang på knappen grill  **7** for at aktivere grillfunktionen "overvarme". I displayet **1** vises symbolet for grillfunktionen "overvarme"  og "Gr 1".
2. Indstil den ønskede tilberedningstid med drejeknappen **10**. Den længste tilberedningstid, der kan indstilles, er på 95 minutter.
3. Tryk på knappen start/lynstart **10**  for at starte grillfunktionen.

Grillfunktion "over- og undervarme"

Denne grillfunktion kan anvendes til tynde skiver kød, steaks, frikadeller, pølser eller kyllingestykker.

Brug altid grillstativet **15**, når der grilles med "over- og undervarme". Så opnår du det bedste grillresultat.




Stil altid grillstativet **15** på drejetallerkenen **3**.

1. Tryk to gange på knappen grill  **7** for at aktivere grillfunktionen "over- og undervarme". I displayet **1** vises symbolet for grillfunktionen "overvarme" , for grillfunktionen "undervarme"  og "Gr 2".
2. Indstil den ønskede tilberedningstid med drejeknappen **10**. Den længste tilberedningstid, der kan indstilles, er på 95 minutter.
3. Tryk på knappen start/lynstart **10**  for at starte grillfunktionen.

Grillfunktion "undervarme"

Brug altid grillstativet **15**, når der grilles med "undervarme". Så opnår du det bedste grillresultat.

Stil altid grillstativet **15** på drejetallerkenen **3**.

1. Tryk tre gange på knappen grill  **7** for at aktivere grillfunktionen "undervarme". I displayet **1** vises symbolet for grillfunktionen "undervarme"  og "Gr 3".
2. Indstil den ønskede tilberedningstid med drejeknappen **10**. Den længste tilberedningstid, der kan indstilles, er på 95 minutter.
3. Tryk på knappen start/lynstart **10**  for at starte grillfunktionen.

Kombinationstilberedning "grill"

Denne funktion kombinerer grillfunktionen og den normale mikrobølgefunktion. Under kombinationstilberedningen anvendes der automatisk en bestemt tid til tilberedningen og den resterende tid til grillning, og det udføres i én arbejdsgang. Du kan høre et svagt klik, når ovnen skifter fra den ene til den anden funktion.








Brandfare!

Brug aldrig grillstativet **15** eller andre metalgenstande, hvis mikrobølgeovnen anvendes til kombinationstilberedning. Metal reflekterer mikrobølgestrålingen og fører dermed til gnistdannelse. Det kan føre til brand, og ovnen kan gå i stykker, så den ikke kan repareres igen!

Kombination 1








Ved kombination 1 er mikrobølgeeffekten 30 % og grilleffekten 70 % af tilberedningstiden. Dette er f. eks. velegnet til fisk eller gratiner.

Der anvendes mikrobølgefunktionen og grillfunktionen "overvarme".

1. Tryk på knappen kombination mikrobølgeovn-grill  for at aktivere kombination 1. I displayet  vises , , samt "C 1".
2. Indstil den ønskede tilberedningstid med drejeknappen . Den længste tilberedningstid, der kan indstilles, er på 95 minutter.
3. Tryk på knappen start/lynstart   for at starte.








Kombination 2

Ved kombination 2 er mikrobølgeeffekten 55 % og grilleffekten 45 % af tilberedningstiden. Dette er f. eks. velegnet til omeletter, buddinger eller lasagne. Der anvendes mikrobølgefunktionen og grillfunktionen "overvarme".

1. Tryk på knappen kombination mikrobølgeovn-grill  for at aktivere kombination 2. I displayet  vises ,  samt "C 2".
2. Indstil den ønskede tilberedningstid med drejeknappen . Den længste tilberedningstid, der kan indstilles, er på 95 minutter.
3. Tryk på knappen start/lynstart   for at starte.








Kombination 3

Ved kombination 3 er mikrobølgeeffekten 30 % og grilleffekten 70 % af tilberedningstiden. Dette egner sig for eksempel til kartofler. Der bruges mikrobølgefunktionen og grillfunktionen "over- og undervarme".

1. Tryk på knappen kombination mikrobølgeovn-grill  for at aktivere kombination 3. I displayet  vises ,  samt "C 3".
2. Indstil den ønskede tilberedningstid med drejeknappen . Den længste tilberedningstid, der kan indstilles, er på 95 minutter.
3. Tryk på knappen start/lynstart   for at starte.

Kombination 4



Ved kombination 4 er mikrobølgeeffekten 55 % og grilleffekten 45 % af tilberedningstiden. Det egner sig for eksempel til fjerkræretter. Der bruges mikrobølgefunktionen og grillfunktionen "over- og undervarme".

1. Tryk på knappen kombination mikrobølgeovn-grill  for at aktivere kombination 4. I displayet  vises ,  samt "C 4".
2. Indstil den ønskede tilberedningstid med drejeknappen . Den længste tilberedningstid, der kan indstilles, er på 95 minutter.
3. Tryk på knappen start/lynstart   for at starte.

Varmluftdrift

Ved tilberedning med varmluft cirkulerer der varm luft i ovnrummet. Varmluft anbefales især til tilberedning af gratiner eller sprøde fødevarer.


Valg af temperatur

- Tryk på knappen varmluft   for at vælge temperaturen.
- **1x** til 230 °C
- **2x** til 215 °C
- **3x** til 200 °C
- **4x** til 185 °C
- **5x** til 170 °C
- **6x** til 155 °C
- **7x** til 140 °C
- **8x** til 125 °C
- **9x** til 110 °C
- **10x** til 95 °C

Temperaturen vises i displayet  (f. eks. 230C ved 230 °C temperatur).





Indstilling af tilberedningstiden


Når temperaturen er valgt, skal du indstille den ønskede tilberedningstid:

- Drej drejeknappen , til den ønskede tilberedningstid er indstillet.

Start for tilberedningen









Når du har indstillet temperaturen og tilberedningstiden, kan tilberedningen startes:

Tryk på knappen start/lynstart   for at starte tilberedningen. I displayet  vises symbolerne for varmluffunktion  og "M1". Den indstillede tid tæller ned.

Når den indstillede tid er gået, vises skiftevist "End" og "Hot" i displayet . En signaltone lyder flere gange efter hinanden.

Varmluftfunktion med forvarmning


Du kan også forvarme mikrobølgeovnen, før du starter tilberedningen:






1. Vælg den ønskede temperatur ved at trykke på knappen varmluft   tilstrækkeligt mange gange.
2. Tryk på knappen start/lynstart   for at forvarme. I displayet  vises "30:00", og tiden tæller ned. Så snart den indstillede temperatur er nået, lyder der en signaltone.
3. Åbn døren, og stil fødevarerne, der skal tilberedes ind.
4. Indstil den ønskede tilberedningstid med drejeknappen . Den længste tilberedningstid, der kan indstilles, er på 95 minutter.
5. Tryk på knappen start/lynstart   for at starte.


Kombinationstilberedning "varmluft"


Denne funktion kombinerer varmluft-funktionen og den normale mikrobølgefunktion. Derved bliver kødet saftigt, mørt og alligevel sprødt.

Brandfare!

Brug aldrig grillstativet  eller andre metalgenstande, hvis mikrobølgeovnen anvendes til kombinationstilberedning. Metal reflekterer mikrobølgestrålingen og fører dermed til gnistdannelse. Det kan føre til brand, og ovnen kan gå i stykker, så den ikke kan repareres igen!

1. Tryk på knappen kombination mikrobølgeovn-varmluft  .
 - 1 x for at aktivere kombinationen med 200 °C,
 - 2 x for at aktivere kombinationen med 170 °C,
 - 3 x for at aktivere kombinationen med 140 °C,
 - 4 x for at aktivere kombinationen med 110 °C,
- I displayet  vises den valgte temperatur, "M1" og symbolerne  og .

- Indstil den ønskede tilberedningstid med drejeknappen **10**. Den længste tilberedningstid, der kan indstilles, er på 95 minutter.
- Tryk på knappen start/lynstart **10**  for at starte.

- Når den ønskede fødevarer vises i displayet **1**, skal du trykke på knappen vægt/minutur **12** , indtil den ønskede vægt vises i displayet **1**.



Optøning

Optøning efter vægt

1 Bemærk:

Læg fødevarerne, der skal tøs op, på køkkenservice, der er egnet til mikrobølgeovn. Læg dem aldrig direkte på drejetallerkenen **3**!

Med denne funktion kan du uden problemer optø kød, fjerkræ og fisk. Optøningstiden og effekttrinet udregnes og indstilles automatisk, når vægten indtastes.

- Drej drejeknappen **10** i standby-mode mod urets retning, indtil der vises "A-12" og  **1** displayet.
- Tryk på knappen start/lynstart **10** .
- Vælg nu fødevarerne, der skal tøs op, ved at dreje på drejeknappen **10**. I displayet **1** vises:

"d-01" og  for "okse"

"d-02" og  for "svin"

"d-03" og  for "pizza"


"d-04" og  for "fjerkræ"


"d-05" og  for "frugt/grønt"


"d-06" og  for "fisk"

"d-07" og  for "kartofler"

Følgende vægtindstillinger er mulige:

"d-01"/  / "okse" 100 - 1800g

"d-02"/  / "svin" 100 - 1800g


"d-03"/  / "pizza" 100 - 900g

"d-04"/  / "fjerkræ" 100 - 1800g


"d-05"/  / "frugt/grønt" 100 - 900g

"d-06"/  / "fisk" 100 - 1800g

"d-07"/  / "kartofler" 100 - 900g

- Når den ønskede vægt vises i displayet **1**, skal du trykke på knappen start/lynstart **10**  . Ovnens beregner automatisk den nødvendige optøningstid.


1 Bemærk:










For at garantere optimal optøning er det nødvendigt at vende fødevarerne under optøningen. Ovnens minder dig med signaltoner om, at du skal vende, og på displayet **1** vises "turn". Åbn mikrobølgeovnens dør, vend fødevarerne, og luk døren igen. Tryk på knappen start/lynstart **10**  for at fortsætte optøningen.

Hvis du ikke vil vende fødevarerne, skal du bare vente, til signaltonerne holder op. Mikrobølgeovnen fortsætter automatisk optøningen. Vi anbefaler, at maden vendes. Dermed opnår du en ensartet optøning.




Optøning efter tid

Bemærk:

Læg fødevarerne, der skal tøs op, på køkkenservice, der er egnet til mikrobølgeovn. Læg dem aldrig direkte på drejetallerkenen !

1. Drej drejeknappen  i standby-mode mod urets retning, indtil der vises "A-13" og  i displayet .
2. Tryk på knappen vægt/minutur   .
3. Indstil den ønskede tid med drejeknappen .
4. Tryk på knappen start/lynstart   for at starte optøningen. Tiden tæller ned.

Bemærk:

For at garantere optimal optøning er det nødvendigt at vende fødevarerne under optøningen. Ovnen minder dig med signaltoner om, at du skal vende, og på displayet  vises "turn". Åbn mikrobølgeovnens dør, vend fødevarerne, og luk døren igen. Tryk på knappen start/lynstart   for at fortsætte optøningen.

Hvis du ikke vil vende fødevarerne, skal du bare vente, til signaltonerne holder op. Mikrobølgeovnen fortsætter automatisk optøningen. Vi anbefaler, at maden vendes. Dermed opnår du en ensartet optøning.

Automatisk menu




Til madretter, som skal tilberedes i automatisk menu-modus, er det ikke nødvendigt at indtaste kogeforløbets tid og effekttrinnet. Det er tilstrækkeligt, at du indtaster, hvilken type fødevarer, der skal tilberede/koges, samt vægten for denne fødevarer.














Bemærk





Mikrobølgeovnen beregner tiden/effekttrinnet for **friske** fødevarer. Dybfrosne fødevarer bliver ikke færdigtillberedt med tiderne, der er fastsat af mikrobølgeovnen (undtagen det automatiske program "pizza").

Optø evt. dybfrosne fødevarer med optøningsprogrammet først (se kapitlet "Optøning").


Start for den automatiske menu






1. Drej drejeknappen  (i standby-funktion) langsomt til venstre for at åbne den automatiske menufunktion. I displayet  vises et tal (f. eks. "A - 02" for autoprogram 2 (pølse)) og symbolet "pølse". Vælg den automatiske menu, der passer til dine fødevarer, ved at dreje drejeknappen .

Display	Symbol	Fødevarer	Vægt
A-01		Oksekød	200 - 1400 g
A-02		Pølse	100 - 500 g
A-03		Pizza	P1 150-450g P2 150-450g P3 150-450g
A-04		Drikkevarer	200 - 500ml
A-05		Svinekød	200 - 1400 g
A-06		Fisk	200 - 1200 g
A-07		Forretter	300 /500 g
A-08		Opvarmning	300 - 700 g
A-09		Fjerkræ	400 - 1400 g
A-10		Grøntsager/ frugt	100 - 1000 g
A-11		Kartofler	100 - 800 g
A-12		Optøning efter vægt	-
A-13		Optøning efter tid	-

- Tryk flere gange på knappen vægt/minutur  , indtil den ønskede vægt vises i displayet .
- Tryk på knappen start/lynstart   for at starte tilberedningen.

Bemærk

For at opnå ensartet tilberedning skal nogle fødevarer vendes om, når 1/2 - 2/3 af tiden er gået. Mikrobølgeovnen stopper automatisk efter denne tid, der lyder 4 signaltoner, og "Turn" vises i displayet .

Display	Symbol	Fødevarer	Vend efter..
A-01		Oksekød	1/2 af tiden
A-02		Pølse	2/3 af tiden
A-05		Svinekød	1/2 af tiden
A-06		Fisk	2/3 af tiden
A-09		Fjerkræ	2/3 af tiden

- Vend fødevarerne om. Vær forsigtig, da fødevarerne er varme.

Tryk på knappen start/lynstart   for at fortsætte tilberedningen igen.

Bemærk

Hvis du ikke vil vende fødevarerne, skal du bare vente, til signaltonerne holder op. Mikrobølgeovnen fortsætter automatisk tilberedningen. Vi anbefaler, at maden vendes. Derved opnår du en ensartet tilberedning.


Bemærk

Hvis retten ikke er rigtigt tilberedt, når den automatiske menu er afsluttet, kan du tilberede den nogle minutter med lynstartprogrammet.

Brandfare!

Brug aldrig afdækninger eller køkkenservice, der ikke er varmebestandigt, hvis grillfunktionen er aktiveret (A-01, A-02, A-03, A-05, A-06, A-09), da disse kan smelte eller antændes!

Fare for uheld!








Drejetallerkenen  er meget varm efter tilberedning med grill! Brug altid grydelapper eller varmebestandige handsker, når du tager maden ud af ovnen.

Bemærk:

Bemærk, at fødevarernes størrelse, form og sort også har betydning for resultatet.



Anvendelseksempel 1:






Du skal gøre følgende, når du vil tilberede 400 g grøntsager eller frugt:

1. Drej drejeknappen  (i standby-mode) langsomt til venstre, indtil der vises "A-10" i displayet .
2. Tryk 4 gange på knappen vægt/minutur  . Der vises 400 g i displayet .
3. Tryk på knappen start/lynstart   for at starte tilberedningen.

Anvendelseksempel 2:








Gå frem på følgende måde, hvis du vil opvarme 300 ml vand:

1. Drej drejeknappen  (i standby-mode) langsomt til venstre, indtil der vises "A-04" i displayet .

2. Tryk 3 gange på knappen vægt/minutur  . Der vises 300 g i displayet .
3. Tryk på knappen start/lynstart   for at starte tilberedningen.












Anvendelseksempel 3:



Gå frem på følgende måde, hvis du vil opvarme 300 g forret:

1. Drej drejeknappen  (i standby-mode) langsomt til venstre, indtil der vises "A-07" i displayet .
2. Tryk én gang på knappen vægt/minutur  . Der vises 300 g i displayet .
3. Tryk på knappen start/lynstart   for at starte tilberedningen.


Bagning af pizza

Med det automatiske program "pizza" kan du tilberede sprøde pizzaer i mikrobølgeovnen.

1. Drej drejeknappen  (i standby-mode) langsomt til venstre, indtil der vises "A-03" i displayet .
2. Tryk på knappen start/lynstart  .
3. Vælg det ønskede pizza-program med drejeknappen :
 - "P-01" for dybfrossen pizza, Temperatur ca. -18 grader
Vægt 150 g - 450 g
(Der vises "P-01" i displayet .
 - "P-02" for kølet pizza, Temperatur ca. 5 grader
Vægt 150 g - 450 g
(Der vises "P-02" i displayet .
 - "P-03" for frisk pizza, Temperatur ca. 20 grader
Vægt 150 g - 450 g
(Der vises "P-03" i displayet .
4. Tryk på knappen vægt/minutur  , indtil den ønskede vægt vises i displayet .











- 5 Tryk på knappen start/lynstart   for at starte tilberedningen.

Bemærk

Hvis du vil tilberede frisk pizza, kan du lægge den direkte på drejetallerkenen . Så bliver den særligt sprød. Sørg for, at pizzaens kant ikke rager ud til ovnrummets vægge under tilberedningen.

Anvendelseksempel:

Gør følgende for at tilberede en dybfrossen pizza på 450 g:

1. Drej drejeknappen  (i standby-mode) langsomt til venstre, indtil der vises "A-03" i displayet .
2. Tryk på knappen start/lynstart  .
3. Vælg programmet "P-01" med drejeknappen .
4. Tryk på knappen vægt/minutur   , indtil der vises "450 g" i displayet .
- 6 Tryk på knappen start/lynstart   for at starte tilberedningen. Mikrobølgeovnen beregner automatisk den nødvendige tid.













Hukommelsesfunktion

Udnyt hukommelsesfunktionen, hvis du vil udføre op til 3 forskellige tilberedningsforløb efter hinanden. Når det ene forløb er afsluttet, lyder der et enkelt signal, og derefter startes det næste forløb med det samme.

Bemærk

De automatiske menuprogrammer, optøning efter tid og optøning efter vægt kan ikke gemmes.









For at gemme 3 forløb efter hinanden skal du gøre følgende:



1. Indtast det første forløb. For eksempel et mikrobølgeforløb, 900 W effekt, 2 minutter. "2:00", "M1" og  vises i displayet . Tryk så **ikke** på knappen start/lynstart   !
2. Indtast det andet forløb. For eksempel et grillforløb, overvarme, 3 minutter. "3:00", "M2" og  vises i displayet . Tryk så **ikke** på knappen start/lynstart   !
3. Indtast det tredje forløb. For eksempel et varmluftforløb, 200 °C, 2 minutter. "2:00", "M3" og  vises i displayet .
4. Tryk først derefter på knappen start/lynstart   . Mikrobølgeovnen starter det første forløb. Når et forløb er afsluttet, lyder der en signaltone, og mikrobølgeovnen starter automatisk det næste forløb.


Valg af starttid




Med dette program kan du forprogrammere en bestemt starttid for tilberedning eller grillning af maden. Når du har startet indstillingerne, starter ovnen automatisk på det indstillede tidspunkt.

i Bemærk: Uret skal indstilles, for at funktionen "Forindstil starttid" kan benyttes.

1. Indtast det ønskede tilberedningsprogram:
 - Til mikrobølgefunktionen: Tryk på knappen effekt **14**  for at vælge det ønskede effektrin. Indstil kogetiden med drejeknappen **10**.
 - Til grillfunktionen: Tryk på knappen grill  **7**, indtil den ønskede grillfunktion er aktiveret. Indstil den ønskede tilberedningstid med drejeknappen **10**.
 - Til varmluftfunktion: Tryk på knappen varmluft **9**  for at vælge temperaturen. Indstil kogetiden med drejeknappen **10**.
 - Til kombinationsforløbet "varmluft": Tryk på knappen kombination mikrobølgeovn - varmluft **6**  for at vælge temperaturen. Indstil kogetiden med drejeknappen **10**.
 - Til kombinationsforløbet "grill": Tryk på knappen kombination mikrobølgeovn - grill **15**  for at vælge det ønskede grillforløb. Indstil kogetiden med drejeknappen **10**.
 - For en automatisk menu: Vælg den ønskede automatiske menu med drejeknappen **10**. Tryk på knappen vægt/minutur **12**   , indtil den ønskede vægt vises i displayet **1**.
2. Tryk på ur/timer-knappen **8**  . Displayet **1** viser det aktuelt indstillede klokkeslæt, og timetallet blinker.
3. Drej drejeknappen **10** for at indstille timerne.

4. Tryk på knappen ur/timer **8**  , nu blinker minutcifrene.
5. Drej nu på drejeknappen **10** for at indstille minutterne.
6. Tryk på knappen start/lynstart **10**  . Timeglasset vises i displayet **1**. Mikrobølgeovnen starter automatisk forløbet på det indstillede tidspunkt.

i Bemærk:
Hvis du vil se på den gemte starttid, skal du trykke på knappen ur/timer **8**  .

I displayet **1** vises den indstillede starttid.
For at slette den gemte starttid og dermed afbryde det gemte forløb skal du trykke på knappen ur/timer **8**  , så den indstillede starttid vises i displayet **1**. Tryk så, mens starttiden vises i displayet **1** på knappen stop/børnesikring  +  **11**. Timeglasset i displayet **1** slukkes. Det gemte forløb er slettet.

Opskrifter

Frikadeller

- Form frikadellerne af ca. 125g hakket oksekød for hver (diameter ca. 75mm, højde ca. 35mm).
- Fordel frikadellerne på en tallerken, der er egnet til mikrobølgeovn, og stil den på drejetallerkenen ③.

Tilberedning

Det bedste resultat opnår du ved selv at indstille følgende programkombination (se også kapitlet Gemmefunktion):

- Fremgangsmåde 1:
Varmluft 230 °C, 4:00 min.
- Fremgangsmåde 2:
Mikrobølgeovn 900 W effekt , 5:30 min.
- Fremgangsmåde 3:
Varmluft 230 °C, 2:00 min (afhængigt af smag kan en tid på op til 4:00 min. også være mulig).

Bagning af færdige frostboller

- Vælg varmluftfunktionen til bagning af boller.
- Læg 3-4 boller på en tallerken, der er egnet til mikrobølger, og stil den på drejetallerkenen ③.
Forvarmning af mikrobølgeovnen er ikke nødvendig.

Vælg følgende indstilling til bagningen:

- Varmluft 170 °C, tid: 12 minutter

Hvis du vil bage flere boller lige efter, skal du afkorte tiden med ca. 1-2 minutter, da ovnen allerede er forvarmet.

Kartoffelgratin

Ingredienser

- 750 g faste, skrællede kartofler
 - 300 g fløde
 - 100 g revet ost med et fedtindhold på 25% til 30 % fedt i tørmasse.
 - Krydderier efter smag (f.eks. salt/peber)
- Brug rundt køkkenservice med låg, som kan tåle mikrobølger, med en højde på 5 til 6 cm og en diameter på ca. 22 cm.

Tilberedning

- Skær kartoflerne i ca. 3 - 4 mm tykke skiver.
- Læg cirka halvdelen af kartoflerne som tagsten i gratinformen.
- Strø halvdelen af osten over kartoflerne.
- Tilsæt halvdelen af krydderierne samt ca. 150 g fløde.
- Læg resten af de skårne kartofler over - også som tagsten.
- Fordel resten af osten over kartoflerne, og hæld resten af fløden over.
- Strø resten af krydderierne over gratinen.
- Dæk formen til med låget, og stil den i midten på drejetallerkenen ③.

Det bedste resultat opnår du ved selv at indstille følgende programkombination:

- Fremgangsmåde 1:
Mikrobølgeovn 900 W effekt , 10:00 min.
- Fremgangsmåde 2:
Varmluft 230 °C, 10:00 min.
- Fremgangsmåde 3:
Mikrobølgeovn 900 W effekt , 10:00 min.

Forvarmning er ikke nødvendig.

Muffins

Ingredienser

Opskriften er nok til ca. 10 til 20 muffins.

- Bagemargarine (80% fedtindhold) eller saltet smør
- 170 g krystalsukker (maks. kornstørrelse 0,3 mm)
- 3 æg (55 - 60 g med skal/størrelse M)
- 225 g hvedemel
- 7 g bagepulver
- 0,25 g salt

Tilberedning

- Bland alle ingredienserne godt.
- Fyld muffindejen i almindelige papir-bageforme (diameter ca. 45 mm, højde ca. 28 mm)
- Varm mikrobølgeovnen op med varmlufffunktionen til 170 °C.

i Bemærk:

Hvis du skal bage flere gange efter hinanden, fordi du har dej til mange muffins, skal du kun forvarme en gang.

- Fordel nu muffinerne på drejetallerkenen **3**.
- Vælg følgende indstilling til bagningen:
Varmluft 170 °C, tid: 12 minutter

Rengøring og vedligeholdelse

⚠ Fare for uheld!

Før du begynder rengøringen, skal du slukke for mikrobølgeovnen og trække stikket ud af stikkontakten. Ellers er der fare for elektrisk stød!

⚠ Mikrobølgeovnen må under ingen omstændigheder lægges ned i vand eller andre væsker. Det kan være livsfarligt på grund af elektrisk stød, og mikrobølgeovnen kan ødelægges.

- Hold altid mikrobølgeovnen ren indeni.
- Hvis sprøjt fra mad eller spildt væske sidder fast på væggene i mikrobølgeovnen, skal du tørre væggene af med en fugtig klud.
- Anvend et mildt opvaskemiddel, hvis mikrobølgeovnen er mere snavset.
- Undgå at anvende rengøringspray og andre skræppe rengøringsmidler, da de kan frembringe pletter, striber eller gøre dørens overflade mat.
- Rengør ovnens ydervægge med en fugtig klud.
- Sørg for, at der ikke kan trænge vand ind i ventilationsåbningen **5**, så det undgås, at funktionsdelene inden i mikrobølgeovnen beskadiges.
- Fjern regelmæssigt sprøjt og snavs. Rengør døren og vinduet på begge sider, dørtætningerne og de tilstødende dele med en fugtig klud. Der må ikke anvendes skuremiddel.

- Hvis ovndøren dampes til udenpå eller indeni, skal den tørres af med en blød klud. Det kan ske, hvis mikrobølgeovnen står i et miljø med høj luftfugtighed.
- Rengør drejetallerkenen ③ regelmæssigt. Vask glastallerkenen i varmt sæbevand eller i opvaskemaskinen.
- Rengør grillstativet ⑤ i varmt opvaskevand, og tør det godt af.
- Fjern jævnlige lugt. Stil en dyb mikrobølgeskål, der er fyldt med en kop vand, saft og skal fra en citron, ind i mikrobølgeovnen. Varm op i 5 minutter. Tør grundigt efter, og gnid den helt tør med en blød klud.
- Hvis det er nødvendigt at skifte pæren i mikrobølgeovnen, skal du overlade det til forhandleren eller spørge vores serviceafdeling.

Afhjælpning af fejl

Displayet ① viser ingenting.

- Stikket sidder ikke i stikkontakten. Kontrollér stikket.
- Stikkontakten er defekt. Prøv en anden stikkontakt.
- Displayet ① er defekt. Kontakt service.

Mikrobølgeovnen reagerer ikke, når der trykkes på knapperne.

- Børnesikringen er aktiveret. Deaktiver børnesikringen (se kapitlet "Betjening").

Mikrobølgeovnen starter ikke tilberedningen.

- Døren er ikke lukket rigtigt. Luk døren rigtigt.

Drejetallerkenen ③ laver høje lyde, når den drejer.

- Drejetallerkenen ③ sidder ikke rigtigt på akslen. Stil drejetallerkenen ③ rigtigt ind i ovnen.
- De små hjul ④ og/eller bunden af ovnrummet er snavsede. Rengør hjulene ④ og bunden.

Displayet ① viser "E01", og signaltonerne lyder.

- Mikrobølgeovnen er overophedet. Afbryd omgående det igangværende program. Tag strømstikket ud, åbn mikrobølgedøren, og lad ovnen køle af.

Displayet ① viser "E02", og signaltonerne lyder.

- Der foreligger en fejl på sensoren. Afbryd programmet, og lad ovnen køle af. Start så mikrobølgeovnen igen. Hvis fejlen forekommer flere gange, bedes du henvende dig til kundeservice.
- Der er en fejl ved opvarmning af mikrobølgeovnen. Afbryd programmet, og lad ovnen køle af. Start så mikrobølgeovnen igen. Hvis fejlen forekommer flere gange, bedes du henvende dig til kundeservice.

Displayet ① viser "E03", og signaltonerne lyder.

- Mikrobølgeovnen er skiftet til fejlfunktionsbeskyttelse på grund af en kortslutning eller tomgangsspænding. Afbryd programmet, og tag strømstikket ud. Afhjælp problemet hvis det er muligt, f.eks. metal i ovnrummet, som kan føre til ovennævnte problem ved brug af mikrobølgefunktionen. Ellers bedes du henvende dig til kundeservice.

Bortskaffelse



Smid aldrig mikrobølgeovnen ud sammen med det normale husholdningsaffald. Dette produkt er underkastet det europæiske direktiv 2002/96/EF.

Bortskaf mikrobølgeovnen via en godkendt bortskaffelsesvirksomhed eller den kommunale genbrugsstation.

Følg de aktuelt gældende regler.

Henvend dig i tvivlstilfælde til det lokale bortskaffelsessted.



Aflever alle emballagematerialer på et affaldsdepot, så miljøet skånes.

Garanti og service

På denne mikrobølgeovn får du 3 års garanti fra købsdatoen. Mikrobølgeovnen er produceret omhyggeligt og inden levering afprøvet samvittighedsfuldt.

Opbevar kassebonen som bevis for købet. Kontakt venligst din serviceafdeling telefonisk, hvis du ønsker at gøre brug af garantien. På denne måde garanteres det, at tilsendelsen af varen er gratis.

Garantien gælder kun for materiale- eller fabriktionsfejl, men ikke for transportskader, sliddele eller skrøbelige dele som f.eks. kontakten eller akkumulatorer. Produktet er kun beregnet til privat og ikke til erhvervsmæssigt brug.

Ved misbrug og uhensigtsmæssig behandling, anvendelse af vold og ved indgreb, som ikke er foretaget af vores autoriserede serviceafdeling, ophører garantien. Dine juridiske rettigheder indskrænkes ikke ved denne garanti.

Garantiperioden forlænges ikke, hvis der gøres brug af garantien. Det gælder også for udskiftede og reparerede dele. Skader og mangler, der eventuelt allerede fandtes ved købet, skal straks anmeldes efter udpakningen og senest to dage efter købsdatoen. Når garantiperioden er udløbet, er reparationer betalingspligtige.

(DK) Kompernass Service Danmark

Tel.: 80-889 980

(Der kan kun ringes til servicenummeret fra fastnet)

e-mail: support.dk@kompernass.com

Importør

KOMPERNASS GMBH
BURGSTRASSE 21
44867 BOCHUM, GERMANY

www.kompernass.com