

Electronic Crane Scale

XK3190-H2B Weighing Indicator

USER GUIDE

VER 1.02

Shanghai Yaohua Weighing System Co.,Ltd.

Version: May,2004

Content

I Technical Specification

II Configuration, Installation and Application

- I .Configuration of the scale body
- II. External layout of indicator
- III. Wireless working mode
- IV. Wire working style
- V. Replacing the printing paper and the ink ribbon of the micro printer
- VI. External printer installation
- VII. Communication interfaces
- VIII. Scoreboard Connection
- IX. Charge

III Keypad Functions

- I. Keys setting and keypad layout
- II. Keys functions

IV Data Printing Format

- I. Micro-printer printing format
- II. External printer printing format

V Error message from wrong operation

VI Error message from wrong inner operation

VII Trouble Shooting

Appendix


Attention: Please read the instruction before operating the instrument.

I Technical Specification

1. Model	XK3190-H2B
2. Accuracy	Meets the regulations of OIML, R76, JJG-555 and national standard of the electronic crane scale. Accuracy – Class III
Division	From 0.01 to 50, 12 options in total. Verifying division will be set automatically each time when powered on. Usually, the division is supposed not to be modified.
Units of Measure	4 options: t, kg, g and mg
3. Analogue	
Conversion Principle	24 bit $\Sigma-\Delta$ mode, A/D converter
Input Signal Range	-2mV~+18mV
Max Net Input Signal	20mV
Conversion Rate	6.25 times per second
A/D Conversion Resolution	500,000
Non-linearity	<0.01%F.S
F.S. Temperature Coefficient	<6PPM/°C
Calibration	Full digital calibration (FDC)
Load Cell Excitation	DC 5V
Load Cell Drive Capacity	up to 4 load cells at 350 Ω
Connecting Method of Load Cell	4 leads
Displaying Cycle	160ms
4. Clock	Displaying Y/M/D, H/M/S and leap year/month
Accuracy	$\pm 5s/24h$, free from influence of powering off
5. Keypad	
Digital Keys	0~9, ., -
Function Keys	24 (12 overlapped with digital keys)
Key Material	Sealed elastomer
6. Scoreboard Interface	Serial output mode
Transmission Mode	20mA current loop
Data Type	11 bits
Baud Rate	600
Transmission Distance	$\leq 2000m$
7. Serial Communication Interface	
Transmission Mode	RS232C/RS422 (Optional)
Baud Rate	600, 1200, 2400, 4800, 9600
Transmitted data format	10 bit: 1 start bit, 8 data bits (ASC II Code), 1 stop bit
Transmission Distance	RS232: $\leq 30m$ RS422: $\leq 1200m$
8. Printer Port	Standard parallel output port
9. Data Storage	11 categories of weight records, net/gross

weight information, weighing time and weighed result can be stored (each category is composed of 99 sets of data), and category identification marks can also be set.

10. Power Supply	
Power of Indicator	12V/1.6Ah NiCd battery
Power of Scale Body	12V/1.8~2.2Ah NiCd battery or CP7-12 storage battery.
11. Signal Transmission	wire/wireless
Transmission Distance	200m (wireless) 50m (wire)
Wireless Frequencies	223.300MHz, 224.900MHz, 230.050MHz, 233.050MHz, 234.050MHz in 230MHz BAND; 450.0125MHz, 450.0625MHz, 450.1125MHz, 450.1625MHz, 450.2125MHz in 450MHz BAND. 10 frequencies in total (the number can be increased if necessary)
12. Display	11 bits LED, LED indicates driving voltages (Brightness):16 degree adjustable, EL background light adjustable.
Display Cycle	160ms



(Figure1) LED sketch map

13. Other Functions
- 1). Various digital filtering modes are adopted. Displaying stabilizing time: $\leq 10s$ during swaying angle $\leq \pm 2^\circ$
 - 2). Non-linearity **parabolic modification**
 - 3). Auto zero-point and minus tare weight point tracking
 - 4). Tare function: Tare can be weighed or preset. Tare range is set to be between 0-Max. There are different annunciators corresponding to Net Weight, Tare and Gross Weight states.
 - 5). Minus weight function
 - 6). Power-saving function. Entering power-saving mode 30 seconds after weight is stabilized. 1 wireless digital transmission every 5 seconds. Powering off automatically 30 minutes after no any fluctuation in weight.
14. Operating Environment
- | | |
|--------------------------------------|---|
| Operating Temperature | Indicator: $0^\circ\text{C} \sim 40^\circ\text{C}$
Body: $-20^\circ\text{C} \sim 40^\circ\text{C}$ |
| Storing and Transporting Temperature | $-25^\circ\text{C} \sim 55^\circ\text{C}$ |
| Relative Humidity | $\leq 85\%RH$ |

15. Dimension

330 x 230 x 60 (mm)

Weight

around 1.5kg


II Configuration, Installation and Application

The wireless electronic crane scale is mainly composed of scale body and indicator, accessories like charger, cable, are also supplied.


1. Configuration of the scale body

This part is makes up of weighing load cell, carrier and transmitting mechanism, case, A/D module, wireless digital transmitter, battery, etc.

2. External layout of indicator



(Figure 2) Front layout



(Figure 3)Rear Wiring Layout

3. Wireless working mode:


Usually, XK3190-H2B Indicator is used in wireless transmitting electronic crane scale. Install the transmitting antenna before operation, and then open the small cover on the scale body to install the battery, after inserting battery plug into the battery socket and turning on the switch, the

annunciator begin to twinkle, indicating the electric circuitry of the scale body in working state. The crane scale will go into the power-saving mode and twinkle once every 5 seconds when it has been out of operation or the weight on the scale has kept unchanged for 30 seconds. At this time, the scale will go into the normal working condition automatically if the load varies $\geq 0.1\%F.S$ and $0.3\%F.S.$ within one second. The scale will be powered off automatically if the load weight keeps unchanged for 30 minutes. If need to be restarted, turn the power switch off or take off the battery plug, and then turn power switch on or insert plug several seconds later,

Note: No keeping battery in scale for a long time without antenna installed, just in case that damages happen to wireless digital transmitter in scale body.

4. Wire Working Style

No necessary to install battery and antenna to XK3190-H2B during indicator wire working mode. Weighing operation can be performed after connecting scale body and indicator to the 2 ends of signal cable and turning on the switch. When powered off, press <<Off>> to shut down the indicator first and then cut off the back power switch or take off the wire transmitting cable. The indicator will remain supplying power to scale body and shorten the life of the battery if the back power switch is not off or the cable is not took off.



(Figure 4) Signal cable interface view

5. Replacing the printing paper and the ink ribbon of the micro printer


Open the printer cover, press the pothooks on the both sides of printer rack to take the printer off, take out the paper reel (paper is used up) and put a new reel of paper in, cut the paper end into an arch and then push it into the paper feeding slot of the printer, press <<Paper>> to set it into an appropriate position, and close the printer cover.

The ink ribbon needs to be replaced when the printed letter became vague. Open the cover of the printer and press the button marked with <<PUSH>> on the ink ribbon, one end of the ribbon will be tilted. Take out the old ribbon and install the new ribbon in a reverse direction, then close the cover.

6. External printer installation

The printer interface adopts standard parallel output and 25-pin RS232 plug, the pins of which are laid out as shown in Figure 4, compatible with stylus printer with character database (such as KX-P1131, LQ1600K, etc)

ST D0 D1 D2 D3 D4 D5 D6 D7 BUSY



(Figure 5) Printer signal interface

If necessary to connect wide-format printer, please switch off power first and fix the printer cable, and then turn on the printer power to make printer online, the XK3190-H2B indicator will be get online together with printer automatically after switching on, and stop built-in micro printer operation. If reusing the internal micro printer, please disassemble the external printer, the internal micro printing function will be resumed after powered on again.


The indicator will be disconnected with internal and external printer automatically whenever something wrong happens during printing process. After settle down the problem and turn switch on again, the online operation can be resumed.

Printing Notes:

- ▲ ! The printing function can only be put into use after proper setting operation.
- ▲ ! The output down-lead of the indicator printing interface must be connected to the printer accurately and only the special printer connecting cable can be used. If connected in wrong way, the output port of the indicator and the input port of the printer will be damaged, and sometimes the damage will happen to the indicator and printer.
- ▲ ! Please choose the recommended printers because there are a great variety of printers with different performances and compatibilities.

7. Communication interfaces

RS-232C/RS485/422 are interface options for XK3190-H2B. Usually, RS-232C is used if no designation from customer.



(Figure 6) Serial communication interface and scoreboard output signal interfaces

- ▲! The down-lead of the communication interface must be connected to the computer

accurately. If connected in wrong way, the output port of the indicator or the input port of computer communication will be damaged, and sometimes the damage will happen to the indicator, computer and peripherals.

▲! Special computer operation skills and programming ability is required for computer communication operation, which shall be performed and directed by qualified service personnel only. Non-professionals are supposed to be out of connection operation.

1. The communication port adopts the 15-pin plug (jointly used with the scoreboard). Pins layout and definition is shown in **Figure 6**: 6,7,8 (RS232) , and, 1,2,3,4(RS422/485)
2. All datum are ASCII and each set is composed of 10 bits: 1 start bit, 2-9 data bit, 10 stop bit.

Communicating methods are classified as follows:

1). In Sequence:

The data transmitted is the present weight displayed (gross or net), each frame of datum is composed of 14 sets of datum. Hereunder is the format:

Byte Serial Number	Descriptions	
1	02H(XON)	begin
2	+ or -	symbol bit
3	Weighing data	high bit
...	Weighing data	...
...	Weighing data	...
10	Weighing data	low bit
11	Decimal	from right to left (0~4)
12	XOR verifying	high 4 bits
13	XOR verifying	low 4 bits
14	03H(XOFF)	end

$XOR=2 \oplus 3 \oplus 4 \cdots 8 \oplus 9$

2). Instruction method

The indicator transmits the corresponding data according to the instruction of upper computer. One frame of datum will be transmitted every time when upper computer send one instruction. Hereunder is the instruction transmitted:

Byte Serial Number	Descriptions	
1	02H(XON)	begin
2	A~Z	address serial number
3	A~B	order A: Handshaking
		Order B: Read the displayed weight
4	XOR verifying	high 4 bits
5	XOR verifying	low 4 bits
6	03H (XOFF)	end

$XOR=2 \oplus 3$

The output content of indicator:

Byte Serial Number	Descriptions
--------------------	--------------

1	02H(XON)	begin
2	A~Z	address serial number
3	A~B	order A: Handshaking
		order B: Read the displayed weight
4	Transmitting the corresponding data according to the instruction	
...	Transmitting the corresponding data according to the instruction	
n-1	Transmitting the corresponding data according to the instruction	
n	Transmitting the corresponding data according to the instruction	
n+1	XOR verifying	high 4 bits
n+2	XOR verifying	low 4 bits
n+3	03H (X0FF)	end

$XOR = 2 \oplus 3 \oplus \dots \oplus (n-1) \oplus n$

Hereunder is the content of 4~n during indicator transmitting:

Order A	No data	Each frame is composed of 6 sets of datum
Order B	Present weight, format:	Each frame is composed of 16 sets of datum
	a: sign (+ or -)	
	b: weight value(8 bits)	
	: (from up to down)	
	g	
	h: decimal digits from right to left (0~4)	

Remarks: high/low 4 bits confirmation via XOR verifying: If XOR and high/low 4 bit ≤ 9 , add 30h to become ASC II, and then sent out. For example: When XOR verifying high 4 bits=6, add 30h, then become 6 in ASC II and sent out. If XOR and high/low 4 bits ≥ 9 , add 9, then become ASC II to be sent out. For example: When XOR verifying high 4 bits=B, add 37h, then become 42h, i.e., B of ASC II to be sent out.

3). Mode transmitting

During weighing mode, press <<Comm.>> <<Accumulation Display>><<Mode Transmitting>> key to transmit the weight data list of the present category. Every batch weight data is transmitted first through the format below:

Sect	Length (byte)	Definition	Description
1	1	Beginning sign	02H
2	1	Transmitting head	A~Z, representing indicator address
3	1	Gross/net weight	net weight= "N"/gross weight = "G"
4	4	Category//number	xxx + Space key
6	11	Date	2004y04m05d
7	9	Time	08h15m20s
8	10	Weight	ASCII character string
9	3	Unit	space + t/kg/g/mg
10	1	Enter key	0DH
11	2	Verifying sum	1 byte (in hex) verifying sum in 2 bytes ASCII

			characters, counts from the transmitting head
12	1	End sign	03H

44 bytes in total

Transmitting the accumulated weight by using the format below:

Sect	Length (byte)	Definition	Description
1	1	Beginning sign	02H
2	1	Transmitting head	A~Z, representing indicator address
3	4	Sign	"SUM="
4	11	Weight	ASCII character string
5	3	Unit	space + t/kg/g/mg
6	1	Enter key	0DH
7	2	Verifying sum	1 byte (in hex) verifying sum in 2 bytes ASCII characters, counting from the transmitting head
8	1	End sign	03H

24 bytes in total

3. Indicator communicating parameter setting:

1). Communicating parameter

Consisting of communicating address (parameter P21), baud rate (parameter P19) and communicating mode (parameter P20).

2). Parameter Setting

Refer to Keys Function chapter for setting methods

8. Scoreboard Connection


▲! The down-lead of scoreboard must be connected to the scoreboard accurately. If be connected in wrong way, damages will happen to the output port of indicator and the input port of scoreboard, and sometimes damage will happen to the indicator and the scoreboard. Special wire is required in connection.

1. The interface of the scoreboard adopts the 15-pin RS232 plug (using the same socket with the COM port). Refer to 9 and 10 pin in Figure 6 for down-lead definition:

2. The 20mA current loop signals or RS232 signals is supposed to be the signals of scoreboard and are serially transmitted by means of binary coded character with baud rate as 600. Each frame of datum has 11 bits: 1 start bit (0), 8 data bits (low bit in front), 1 sign bit and 1 stop bit.


3. One set of datum is transmitted once every 200ms and each set of datum consists of 3 frame datum.

The first frame:




(图 6.1) The first frame view

The second frame:



(Figure 6.2) The second frame view

The third frame:



(Figure 6.3) The third frame view

The first frame datum: sign bit is 0

X: D0, D1, D2--Decimal place (0~4)

Y: D3--- Weight sign (1—minus, 0—plus)

D4--- Spare

G18~G16: Weight data

The second frame of data: sign bit is 0

G15~G8: Weight data

The third frame of data: sign bit is 1

G7~G0: Weight data

G0~G18: The weight (net weight) is constructed from down upward in 19 bits binary system code.

9. Charge

Charge the battery of indicator in time if the LoBAT character in the screen of the indicator twinkles, which means that the battery of the indicator is low. Or the indicator will power off automatically 3 minutes later. **The back power switch should be off when the indicator charged by the intelligent&quick charger H2CDQ, this can avoid the damage resulted from impact on circuit of the power source from the big current.** Before charging the battery in the condition of no LoBAT twinkles, press discharging button to get battery discharge, and in this way, battery capacity degradation can be effectively prevented

Charge the battery of scale body in time if the LoBAT character in the screen of the indicator keeps lights, which shows the battery of the body is low. Or the scale body will power off 10 minutes later. Before charging the battery in the condition of no LoBAT twinkles, press discharging button to get battery discharge, and in this way, battery capacity degradation can be effectively prevented.

III Keypad Functions

I. Keys setting and keypad layout

The lower name on the key is the basic function and the function of the upper name on the key can be executed simultaneously by pressing <shift> key.

1 COMM	2 MODE TRANS	3 TYPE	4 TYPE CANCEL	CALIBRAT E VERIFY	CONTRAST BRIGHT	OFF	ON/RES ET
5 ACCUM	6 MEMO RECALL	7 MEMO CLEAR	8 TOTAL CLEAR	WT LIMIT SET WT LIMIT	TARE PRESET TARE WT	DELETE EXIT	ENTER WEIGH
SHIFT MODIFY	9 TIME	0 MINUS WT	● GW/NW	DIVISION TARE	TYPE SIGN ZERO	LIST PR PAPER ROLL	MARK PR PRINT

II. Keys functions

Notes: <xx><xx> represent keys series and <Figure keys> represents keys operation series, composed of <0>~<9>,<.>,<->,etc..<Shift>key perform <-> function when entering non-linearity edited value and category mark in upper name function state. In other cases, serve as switch between the upper name function and lower name function states.

1. <<On/ Reset>> Power on and reset. Self-checking begins upon powering on and then go to weighing display mode. The displayed value zeroed if the difference between present weight and preset zero point is within initial zero-setting range and the automatic zero-setting switch is on (p29=1), if without , <Err 50> appears and the last zero point remains.
2. <<Off>> Turn off the instrument.
3. <<Zero >> In gross weight and steady data state, this function works and present value return to zero, provided that conforming to relevant zero-setting range. Every first zero-setting is initial one upon powering on and zero-setting range is determined by P16 with 20(% Max) as default. **After zero-setting, zero-setting range become $\pm 2\%$ Max of initial zero point.**
4. <<GW/NW>>Switching between gross weight and net weight, tare data remains.
5. <<Tare>> In gross weight and steady data state, tare the present value and then go to net weight state.
6. <<Shift>><<Division>><<Figure Key>><<Enter>> Set division d, resume previous calibrated division after powering off.
7. <<Shift>><<Type sign>><<Figure Key>><<Enter>> A figure with any decimal digit and minus can be set to identify the category of present goods. This category mark can be printed by external printer only and internal printer can not print this category mark. Press <<Shift>><<Type sign>>to check category marks during operation.
8. <<PR>> Print present data. If present data is weight with category mark, it will be saved to weighing record and added into accumulation value. Only the displayed information

can be printed when outside of weighing mode. The present weight can not be printed if unsteady, but it can be printed after resuming steady (**the data is supposed to be steady only after the unit of measure displayed**). Reprinting can not be performed within 5 seconds after each printing. While power is low, printing can not be performed, or abnormal printing will appear. Printing format can be referred to in Chapter 4. **Minus weight value can not be accumulated and recorded.**

9. << Paper roll >> Keep printer conveying printing paper until releasing this key. It does not work to external printer.
10. <<Shift>><<Mark PR>> Print weighing report heading.
11. <<Memo recall>><<Shift>><<List PR>> Print weight record and accumulated value of the present category, available in accumulation function state.
12. <<Entert>>(<<Weigh>>) Check the validity of the data inputted just now and save it, then return to weighing mode. If no data entered, return to weighing mode directly.
13. <<TIME>>Display present date
rq XX-XX-XX
 Press again, Current time appear
SJ XX-XX-XX
 Press <<Weigh>> to quit
14. <<Time>> (<<Time>>)<<Modify>><<Figure>><<Enter>> Edit date or time, and decimal point serves as dividing symbol of year and date; hour, minute and second. The internal real-time clock will not work if time was not set after battery installation.
15. <<Minus WT>> Go to minus weighing mode, the instrument identifying mark becomes F and weight displayed become 0 at the same time. The weight of the object taken off from the scale will be displayed then. Press<<Minus Weight>> to quit the minus weighing mode.
16. <<Shift>><<Delete>> Delete the last weighing record of present category in accumulation state. Delete the last figure entered in entering state. Return to weighing mode when no figure entered.
- 17 <<Exit>> Return to weighing mode.
- 18 <<WT limit set>> Display present weighing limit. The weighing limit is set to be +9e upon powered on. The displayed figure is
HZL XXXXX kg
 Press <<Weigh>> key to quit.
- 19 <<Shift>><<WT limit set>><<Figure>><<Enter>> Set weighing limit and the limit is not supposed to be above maximum weight to be weighed.
- 20 <<Tare>>Check the present tare and the figure is displayed as follows:
PZL XXXXXkg
 Press <<Weigh>> to quit
21. <<Shift>><< Tare Preset >><<Figure>><<Enter>> Preset tare.
22. <<Background Light>> LCD background light on/off key, the light time is decided by the parameter P23
23. <<Shift>><<Contrast bright>><<Figure>><<Enter>> Set contrast within the scope (0-15), the weakest is 0 and the brightest is 15
- 24 <<Verify>> Check every data in the instrument and next data will displayed after each

press. Press <<**Exit**>> or <<**Enter**>> to return to weighing mode. If a programmable data needs to be modified, press keys in the order of <<**Modify**>><<**Figures**>><<**Enter**>> to enter new data. Data order is displayed as follows:

Pressing times	Reminding symbols	Data meaning
1	YXX	printing is not allowed in weighing mode of division=0.1e
2	A/D	Weight A/D internal code
3	P09	Display the weight in zero point
4	P10	Display zero point upon powered on
5	P11	Calibrate zero point internal code
6	F	Full Scale
7	E	Check division 0.01~50, 12 options in total
8	P14	Displaying ratio
9	P15	Displaying Non-linearity edited value within the scope of -1%Max~1%Max, weight unit
10	P16	Initial zeroing range 2~100 unit: %Max. This parameter determined the difference between present load and calibrated zero point with 20%Max as default in first zero-setting upon powered on.
11	P17	Zero-tracing switch, 0 is off and 1 is on
12	P18	Weight unit: 0=t 1=kg 2=g 3=mg
13	P19	bit number 0=600 1=1200 2=2400 3=4800 4=9600BPS
14	P20	Communication mode: 0= constant sending 1= answer style
15	P21	Communication address: 1~255
16	P22	Printer styles: 0=without Chinese characters database 1=with Chinese characters database (only the printer with Chinese characters database is applicable at present, this para. does not work)
17	P23	The lighting time of the background light 1~255, unit: Second. 0=no automatic off
18	P24	Scoreboard switch: 0=on 1=off
19	P25	RS232 switch 0= on 1=off
20	P26	Displaying divisions 0.01~50 12 options total
21	P27	Displaying Version No. For example: H2C

		1.02
22	P28	The biggest added tare limit switch: 1=permit 2=prohibited If the difference between load and preset zero point is above 1.2Max upon powered on, the instrument alarm will ring, regardless of the present zero point.
23	P29	Automatic zeroing switch upon powered on: 1= permit 2= prohibited
24	P30	Zeroing range 2~100 unit: %Max. This parameter determine the biggest difference allowed between the zero points of zero-setting and initial zero-setting after initial zero-setting. This difference shall be $\pm 2\%Max$

Notes: YXX represents the XX times weighing of the Yth category.

P10 represents the 10th parameter, others is the same.

* means the parameter read-only and can not be rewritten.

**mean the parameter can only be rewritten while calibration switch is on.

25. Calibration procedures:

- 1) Turn on the calibration switch (push leftwards) (hardware)
- 2) Press <<Shift>><<Calibrate>> to enter into calibration procedures, “PAS” remind you of entering password. Enter 3190 and then press <<Calibrate>>.
- 3) “F XXXXX” reminds you of entering the Full Scale. XXXXX means the previous Full Scale. Press <<Figure>> to enter the Full Scale and then press <<Calibrate>> again.
- 4) “E XXX” reminds you of entering division and xxx means previous division. Press <<Figure>> to enter division and then press <<Calibrate>>.
- 5) “noL xxxxxxx” represents present A/D internal code, reminding you of confirming zero point. Press <<Calibrate>> to confirm after data is stabilized.
- 6) “Lod 0” remind you of entering standard weight. Press <<Figure>> to enter standard weight and then press <<Calibrate>>
- 7) XXXXXXX in “Adl XXXXXXX” represents present A/D internal code, reminding you of the added load confirmed. Adding standard weight, press <<Calibrate>> to confirm after data stabilized.
- 8) XXX of “P15 XXX” represents the previous non-linearity edited value, reminding you of entering new non-linearity edited value. Press <<Figure>> to enter non-linearity edited value or press <<Calibrate>> directly
- 9) The calibrated data is written into EEPROM and then restart.
- 10) Turn off the calibration switch (push rightwards) to finish calibration.
- 11) Perform checking and then confirm weighing performance.

If a parameter needs not to be modified during calibration process, press <<Calibration>> to bypass. Or, press <<Exit>> to exit the calibration state and the calibration fails. Other keys are invalid.

Press keys in the order of <<Verify>>...<<Verify>>, <<modify>>, <<Figure>> and <<Enter>> to enter or edit a calibrated data.

(Initializing) zeroing scopes (P16 or P30) can be achieved by using above-mentioned method only, with 2-100(%Max) as valid value scope. Non-linearity tolerance is the difference between zero point and 50%F.S after the full scale is calibrated. Non-linearity edited value (15) is the negative of non-linearity tolerance.

- 26 <<Type>><<Figure>> Set new category number. After press <<Type>>, the category cursor twinkles.
- 27 <<Type Cancel>> Category number and weighing serial number disappear and then accumulation and data saving can not be executed.
- 28 <<COMM >> switch of the communication function to the upper computer. **Marked by COMM**
- 29 <<Accum>> Record and accumulate the present weight, then go to accumulation display mode.
- 30 <<Memo recall>>Display the accumulated weight of the present category. Accumulated value is marked by **SUM**.
- 31 <<Memo clear>> Clear the weight record of the present category and the accumulated weight, and then return to weighing mode. It only works in accumulation state.
- 32 << Memo recall>> <<Total clear>>Clear all weighing records and accumulated value.
- 33 <<COMM>><<memo recall>><<Mode Tranl>>Transfer the weight list to upper computer.

IV Data Printing Format

1. Micro-printer printing format

a) Heading printing format

Weight list		
Xk3190—H2B 1.02		
16:39 15th Oct. 2003		
Serial No.	Weight	Unit

b) Data printing format

State	Data format
Net weight	NYZZXXXXXXXXX kg
Gross weight	GYZZXXXXXXXXX kg
Tare	PZL XXXXXXXXX kg
Weight limit	XZL XXXXXXXXX kg
Accumulation SUM XXXXXXXXX kg
Date & time	XX year XX month XX day XX hour XX minute
Weight A/D inner code	A/D XXXXXXXX
Parameter YY	PYY XXXXXXXX

“Y” represents Type No. , “YY” represents Para. No., “ZZ” represents Serial No., “XXXXX” represents Data

XX.XX.XX.XX.XX represent year, month, day, hour, minute respectively

2. External printer printing format

Note: Only the printer with Chinese character database is applicable

Heading format

Weight list	
Time :xxxx year xx month xx day xx hour xx minute xx second	
Type sign : xxxxxxxx	Indicator model No. : XK3190-H2B 1.02
Type NO. serial NO.	weighing time : weight

Weight printing format:

G	0	01	08h:10m:20s	15th	Jan.	2004	2450	kg
---	---	----	-------------	------	------	------	------	----

“G” represents gross weight “N” represents net weight

Other printing formats are similar to micro-printer’s

List printing as follows:

Weight list	
Time : xxxx year xx month xx day xx hour xx minute xx second	
Type Sign : xxxxxxxx	Indicator model: XK3190-H2B 1.02
Type NO.	Serial NO.
weighing time : weight	
GO	01
08:10:20 15th Jan. 2004	
2450	kg
GO	01
08:16:30 15th Jan. 2004	
3100	kg
.....	
Total weight:	5550 kg

“G” represents gross weight “N” represents net weight

V Error message from wrong operation

Usually, wrong operation message is caused by illegal operation or the parameters entered beyond the preset range.

Error message	Comments
Err 21	Calibrated data lost, input or calibrate again
Err 23	Wrong 24C256 stored data checking, may be caused by turning off power supply switch first instead of indicator.
Err 25	Error program checking codes, rewrite them
Err 26	Error accumulated value, the value of this type has been deleted
Err 27	The figure displayed on scoreboard exceeds 6 digits (including decimal), the problem

	can be settled by increasing division
Err 30	After the datum is stabilized for 30 minutes, the scale body powered off automatically
Err 32	No signal from scale body received, cause by no battery installed or long distance.
Err 33	Accumulation serial No. has reached 99, impossible to accumulate again.
Err 34	Illegal division code, new division need to be entered
Err 35	Accumulation serial No. is 0, deletion is unavailable
Err 36	Accumulation condition unconformable, accumulation unavailable
Err 37	The data entered from keyboard is beyond the range
Err 38	Attempt to modify read-only data
Err 40	The calibrated switch is off, preset data modification unavailable
Err 41	Error password entered
Err 42	Minus ratio: Caused by (1) Load cell is connected in wrong direction (2) wrong calibration operation program (3) The change of inner code is below 5000 after adding standard weight
Err 43	The non-linearity modified value inputted exceeds $\pm 1\%$ Max
Err 50	Zero point exceeds initial zeroing range upon switching on
Err 51	No answer signal received from upper computer during mode transmission
CHAO	Weight exceeds Max+9e or preset weight limit

VI Error message from wrong inner operation

Usually, inner operation error is resulted from wrong para.setting, low power, no signal, etc. Please check and revise the wrong parameter. If cannot be solved, please record all datum and then contact the Technical Department of Shanghai Yaohua Weighing System Co. Ltd.

Error Message	Comments
XXXX 2Error	In program address XXXX, exceeding error happens in subprogram of multiplication
XXXX 3Error	In program address XXXX, the error of being divided by zero happens in subprogram of division
XXXX 4Error	In program address XXXX, exceeding error happens in subprogram of addition and subtraction
XXXX 5Error	In program address XXXX, exceeding error happens in subprogram of BCD code becoming floating code.
XXXX 6Error	In program address XXXX, exceeding error happens in subprogram of floating codes becoming BCD codes
XXXX 7Error	In program address XXXX, being powered off automatically 3 minutes later due to low power
XXXX 8Error	In program address XXXX, being powered off automatically 3 minutes after no signal received from the scale body.

VII Trouble Shooting

Trouble-shooting overview

Number	Trouble	Reason	Trouble shooting
1	Press <<Power on/Reset”, the annunciator is not light and no figure displayed	1. No voltage in instrument battery 2. The power switch in the back of instrument is not on.	1. Check and solve the power problem 2. Turn on the switch.
2	No annunciator twinkles	1. The signal is not connected during cable operation. 2. No antenna installed during wireless operation. 3. No scale body battery installed or low voltage	1. connected signal cable; 2. Install the antenna; 3. Install new battery with full power
3	Instrument alarm, No weight value displayed	1. The weight of the goods exceed the weight limit or F.S+9e 2. The battery voltage of scale body is too low	1. Reset weight limit or decrease the weight of goods; 2. Install new battery with full power
4	The printed figure is too vague	Ink ribbon is used up	Replace it with new ink ribbon
5	No figure printed out	The ink ribbon is out of slot	Reinstall the ink ribbon
6	Paper moving problem or stopped	Too much dust on printer head	Clean the printer head and add some oil
7	Too weak signal or irregular twinkle of annunciator	1. No battery installed in scale body 2. No antenna installed 3. Inappropriate antenna specification 4. Wireless communicating distance is too long	1. Install battery 2. Install antenna 3. Replaced right antenna 4. Shorten the distance between the indicator and the scale body

Appendix

Specification of optional, wearable, quick-wear and expendable parts

Number	Name	Model	Code	Remarks
1	Storage battery	1.6Ah/12V NiH battery		Indicator battery
2	Storage battery	2.2Ah/12V NiCd battery		Scale-body battery

3	Battery plug			
4	Battery socket			
5	Indicator keyboard			For XK3190-H2B
6	LCD screen			For XK3190-H2B
7	Ink ribbon	Epson ERC-05		For Epson M150-II
8	Printing paper	Width $44.5 \pm 0.5\text{mm}$		For Epson M150-II
9	Printing head	Epson M150-II		
10	Antenna	To be purchased according to wireless transmitting frequency		450MHz, 230MHz
11	Charging wire			
12	Printer cable			Optional parts

Notes: The specification, model and codes must be clearly expressed while purchasing optional parts.