

QuickStand Series

Portable Frame-Folding Projection Screen

User's Guide



Setup Procedure

The frame and supports are made of 1 3/8" aluminum tubing with an anodized finish. Please follow the instructions in this package. With proper care, your QuickStand screen will provide many years of reliable service.

Two Section Frame

(For presentation screens that are less than 120" in diagonal measurement)

- 1. Take the frame out of the case and remove its wrappings. Unfold the main joints as shown in (fig 1).
- 2. Once the main joints are unfolded, make sure that the snap latches "click" into the locked position. The frame should now be fully elongated as in (fig2). *Note: The snap latches will automatically lock when the joint is straightened. Press the snap latch button in order to release the lock.
- 3. While holding the bottom of the frame in place, lift the top of the frame to unfold the sides which will cause the snap latches lock when fully extended. Secure the corner braces into the locked position. The screen frame should now be fully opened as in (fig 3).







fig 2



Three Section Frame

(For large presentation screens that are 120" or more in diagonal measurement)

- 1. Take the frame out of the case and remove its wrappings. Unfold the main joints making sure that both the end and middle spans are in prefect alignment as shown in (fig 4).
- 2. Make sure that the snap latches have locked the joints in the frame so that it is at its full horizontal extension as shown in (fig 5)
- 3. While holding the bottom of the frame in place, lift the top of the frame to unfold the sides which will cause the snap latches lock when fully extended. Secure the corner braces into the locked position. The screen frame should now be fully opened as in (fig 6).






fig 5





Standard T-Leg Support

- shown in (fig 8)




AT-Leg (optional support buttress recommended for the large screens with diagonal measurements of 150" and over)

- 1. Take the AT-Leg buttress out of the case and remove its wrappings. Unfold the buttress as shown in (fig 10).
- 2. Snap latches will automatically lock in the center joint. Use the snap latch buttons to unlock the end joints as shown in (fig 11).
- 3. Attach the AT-leg to the T-Leg by securing the locking bolts through the frame using the frame spacers between the metal parts as shown in (fig 12) (*Note: It is important to always use the plastic frame spacers between the pieces whenever connecting any of the aluminum surfaces such as T-bars to AT, SAT and Frame components.)




SAT-Leg (optional added stability buttress recommended for the large screens with diagonal measurements of 180" and over) 1. Take the SAT-Leg out of the case and remove it wrappings as shown in (fig13).

- 2. Undo the snap locks to loosen and bend the joints for proper fitting as shown in (fig 14).
- 3. Attach the SAT-Legs by securing the locking bolts through the frame using the frame spacers between the metal parts as shown in (fig 15)



Attaching the Frame to its Supports

- 1. Always use at least two locking bolts through the T-Leg Support, the Spacer and into the Frame on each side.
- 2. Height can be adjusted in 8" increments up or down. Normal screen height is 44" from the bottom of the frame to the floor.
- 3. Reverse this process to dismantle and pack away the screen.



Folding the Screen material for proper packing

Please observe the following precautions before folding up the screen material.

- 1. Do not bring the viewing surface into contact with chemical solvents, sharp or abrasive objects, painted, varnished or plastic finished items.(*See the cleaning instructions for exceptions to this)
- 2. Make certain that the screen is laid out on a dry, clean and flat surface.

Folding up the screen:

Lay out the screen with the viewing surface facing up and cover it with flat (not crumpled) tissue or packing paper that is clean and unprinted. *Note: Do not ever use abrasive paper, newspaper or any printed material on your projection screen.

1. With the viewing surface facing up, fold the fabric in half from top to bottom. When folding, make certain that the viewing surface does not come into contact with the black binding, grommets or snap buttons. *Note: The screens are shipped from production with tissue paper in the folds that should be retained for future use.

- 2. Make sure that the first folds never exceed 3 feet in width (fold again if necessary). Also make sure that there is always clean packing paper in between the two surfaces.
- 3. Larger sized screens will need to be folded with more frequency than smaller screens. Follow the instructions from step 1 as well.
- 4. Fold the material from top to bottom first then alternate in folding left to right until the material is of a sufficient size that will fit into the leatherette case.

Note: Keep the screen material inside its case when not in use. Failure to follow this precaution may eventually result in staining or discoloration.

Cleaning

The screen surface can be cleaned as follows.

Use a clean white cloth (100% cotton preferred) and dampen it with clear water. Gently wipe in one direction and NOT in a circular motion. Use another dry cloth to dry after each cleaning session. To remove a stubborn stain or sticky surface, use denatured alcohol (methanol or methyl alcohol) in lieu of water.

Attaching the Screen once it is unpacked

- 1. Using the snap buttons to connect the Screen material with the case
- 2. Start at the top working in whatever direction is most comfortable to you
- 3. Stretch the corners if necessary to pair up the buttons with their corresponding snaps







Parts List

- 1. Frame x 1 piece
- 2. Support (T) Legs x 2 pieces
- 3. AT-Legs x 2 pieces (optional depending on size)
- 4. SAT-Legs x 2 pieces. (optional depending on size)
- 5. Screen Fabric x 1 piece
- 6. Locking Bolt x 6-26 pieces
- 7. Frame Spacer x 6-26 pieces
- 8. User Guide x 1 pieces

Please make sure all parts listed are supplied. Should any parts be missing contact us at service@elitescreens.com

The following points should be noted to assure the sound performance and longevity of your screen

- 1. Never use your hand to touch the screen surface.
- 2. Never scrabble on the screen with anything.
- 3. Don't touch the screen with hard or sharp objects.
- 4. Please use a clean cotton cloth or soft dust brush to remove any dust particles on the screen.
- 5. The screen material may be cleaned

Warranty Policy

- Two (2) year parts and labor warranty from defects in workmanship from purchase date (except for refurbished units as specified below):
- Refurbished units carry a 90-day parts and labor warranty.
- Each party will be responsible for one way shipping during regular warranty period. Elite Screens is not responsible for applicable international tariffs such as broker fees and customs duties.
- An RMA (Return Merchandise Authorization) number must be issued in order to process a replacement. Elite Screens will either replace or repair the defective unit with a brand new replacement *(see exceptions below) after the defective unit is received and/or confirmed defective. Once the product is received, Elite Screens will send out a new *unit to the customer by ground service (subject to inventory availability). Please do not return any unauthorized items to Elite Screens, as they will be refused. The RMA number must be included on the outside label of your shipping box. Our warehouse is not authorized to accept returns thout an RMA number on the shipping label. RMA numbers are valid for 45 days from the date of issue.
- Missing Parts must be reported within the 7-days of receipt. If reported after 7 days, customer will only be responsible for shipping and handling fees. If reported after 30 days of receipt, the customer is responsible for cost of the parts and shipping & handling fees.

For Warranty and Service requests please fill out a RMA/Service Form at http://www.elitescreens.com/warrantysupportform

Please Visit this link for full Warranty information:

http://www.elitescreens.com/warranty

Remember to register your Elite Screens product at:

www.elitescreens.com/register

^{*}A new or refurbished replacement will be sent out to the customer depending on the type of purchase (new or refurbished) and is based on stock availability.

CONTACTS

US & Canada Tech Support & Warranty Claim

Please contact us at service@elitescreens.com or call +1 877-511-1211 #3 Service

Europe Tech Support & Warranty Claim

Please contact us at service@elitescreens.eu or call +49-(0) 40-30392958

Asia Tech Support & Warranty Claim

Please contact us at service@elitescreens.com.cn or call +86-(0) 755-8461-7989

Taiwan Tech Support & Warranty Claim

Please contact us at service@elitescreens.com.tw or call +886-(02) 2747-8979

America:

Elite Screens Inc.

16410 Manning Way Cerritos, CA 90703 USA Tel: +1-562-483-8198 Fax: +1-562-483-8498 info@elitescreens.com www.elitescreens.com

Asia:

Elite Screens China Corp.

Longxi Duimianling Industry Zone Longcheng Longgang District, ShenZhen GuangDong, China Tel: +86-(0)755-8461-7989 Fax: +86-(0)755-8461-7669 info@elitescreens.com.cn www.elitescreens.com.cn

Taiwan:

Elite Screens Taiwan Co. Ltd.

No.38, Alley 22, Lane 66, Sec. 5, Nanjing E. Rd., Songshan District, Taipei City 105, Taiwan Tel: +886-(02)2747-8979 Fax: +886-(02)2747-8978

info@elitescreens.com.tw www.elitscreens.com.tw

Europe:

Elite Screens Europe GmbH

Elite Screens Europe GmbH Lübecker Straße 1 22087 Hamburg, Germany Tel: +49-40-30392494 Fax: +49-40-49219200 info@elitescreens.eu www.elitescreens.eu

Elite Screens France S.A.S

11, Allée William Penn 92150 Suresnes, France Tel: +33-1-45064735 Fax: +33-1-45064735 pascale.dautemer@elitescreens.com www.elitescreens.com/fr

Latin America Contact:

erik.garcia@elitescreens.com

East Asia Contact:

info.ea@elitescreens.com

Japan Contact:

info.japan@elitescreens.com