



Moo'n View Cow™

Instructions

Model Number 73761



Product features and decorations may vary from the illustration above.

Please save these instructions for future reference.


Requires three "AA" batteries (included).

Adult assembly is required for battery replacement.

Tool required for battery replacement: Phillips Screwdriver (not included).

Battery Replacement

For best performance, we recommend replacing the batteries that came with this toy with three new alkaline batteries.



- Locate the battery compartment on the bottom of the toy.
- Loosen the screw in the battery compartment door with a Phillips screwdriver. (The screw will remain in the door.)
- Lift to remove the battery compartment door.
- Insert three "AA" (LR6) **alkaline** batteries as indicated inside the battery compartment.

Hint: We recommend using alkaline batteries for longer battery life.


- Replace the battery compartment door and tighten the screw with a Phillips screwdriver. Do not over-tighten.
- When sounds from this toy become faint or stop working, it's time for an adult to replace the batteries!

Battery Tips

- Do not mix old and new batteries.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium).
- Remove the batteries during long periods of non-use. Always remove exhausted batteries from the toy. Battery leakage and corrosion can damage this toy. Dispose of batteries safely.
- Never short circuit the battery terminals.
- Non-rechargeable batteries are not to be recharged.
- Only batteries of the same or equivalent type as recommended in the "Battery Replacement" instructions are to be used.
- If removable rechargeable batteries are used, they are only to be charged under adult supervision.
- Rechargeable batteries are to be removed from the toy before they are charged.
- If you use a battery charger, it should be examined regularly for damage to the cord, plug, enclosure and other parts. Do not use a damaged battery charger until it has been properly repaired.



Adjusting the Volume



- Locate the volume switch on front of the toy.
- Slide the switch to the desired position: Off ●, On with low volume 🗣️, or On with higher volume 🗣️.

Let's Play!

- Tip or bat the cow to hear a friendly “Moo!” and a fun farm tune.
- Cow bell lights up and flashes as the music plays!

Let's Sing Along!

Old MacDonald

Old MacDonald had a farm,
Ee i ee i oh!

And on his farm he had some cows,
Ee i ee i oh!

With a moo-moo here,
And a moo-moo there
Here a moo, there a moo,
Everywhere a moo-moo!
Old MacDonald had a farm,
Ee i ee i oh!

The Farmer in the Dell

The farmer in the dell
The farmer in the dell
Hi-ho, the derry-o
The farmer in the dell!

Care

- Wipe this toy with a clean cloth dampened with a mild soap and water solution. Do not immerse this toy.
- This toy has no consumer serviceable parts. Please do not take this toy apart.

FCC Note (United States Only)

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

Consumer Information

Questions? We'd like to hear from you!

Call Fisher-Price® Consumer Relations, toll-free at **1-800-432-KIDS**, 8 AM - 6 PM EST Monday through Friday. Hearing-impaired consumers using TTY/TTD equipment, please call 1-800-382-7470. Or, write to: Fisher-Price® Consumer Relations, 636 Girard Avenue, East Aurora, New York 14052.

If you have any questions about this product:

In CANADA, Mattel Canada Inc. 6155 Freemont Blvd., Mississauga, Ontario L5R 3W2. Questions? **1-800-567-7724**

In GREAT BRITAIN, Mattel U.K., Ltd. Helpline: 01628 500303.

In AUSTRALIA, Mattel Australia Pty. Ltd., 658 Church Street, Locked Bag #870, Richmond, Victoria 3121 Australia.
Consumer Advisory Service 1-800-800-812 (valid only in Australia).

www.fisher-price.com