

# Breville

Breville is a registered trademark of Breville Pty. Ltd.  
ABN 98 000 092 928

## **Breville Customer Service Centre Australian Customers**

Breville Customer Service Centre  
PO Box 22  
Botany NSW 2019  
AUSTRALIA

Customer Service: 1300 139 798

Fax (02) 9384 9601

Email Customer Service: [askus@breville.com.au](mailto:askus@breville.com.au)

## **New Zealand Customers**

Breville Customer Service Centre  
Private Bag 94411  
Greenmount  
Auckland, New Zealand

Customer Service: 0800 273 845

Fax 0800 288 513

Email Customer Service: [askus@breville.com.au](mailto:askus@breville.com.au)

**[www.breville.com.au](http://www.breville.com.au)**

© Copyright. Breville Pty. Ltd. 2008  
Due to continual improvements in design or otherwise,  
the product you purchase may differ slightly from the one  
illustrated in this booklet.  
Model: BFP50 Issue 1/08

# Breville

## **Wizz Chopper & Shaker**

**Instructions and Recipes**  
BFP50



Inspiration. Every day.™



	Page
<b>Breville Recommends Safety First</b>	5
<b>Know Your Breville Wizz Chopper &amp; Shaker</b>	7
<b>Operating Your Breville Wizz Chopper &amp; Shaker</b>	8
<b>Care, Cleaning and Storage</b>	11
<b>Troubleshooting</b>	12

# Congratulations

on the purchase of your new Breville Wizz Chopper & Shaker

We at Breville are very safety conscious. We design and manufacture consumer products with the safety of you, our valued customer, foremost in mind. In addition we ask that you exercise a degree of care when using any electrical appliance and adhere to the following precautions:

### IMPORTANT SAFEGUARDS FOR YOUR BREVILLE WIZZ CHOPPER & SHAKER

- Carefully read all instructions before operating and save for future reference.
- Remove and safely discard any packaging material and promotional labels before using the Wizz Chopper & Shaker for the first time.
- To eliminate a choking hazard for young children, remove and safely discard the protective cover that is fitted to the power plug of the Wizz Chopper & Shaker.
- Do not place the Wizz Chopper & Shaker near the edge of a bench or table during operation. Ensure the surface is level, clean and free of water, flour, etc.
- Do not place the Wizz Chopper & Shaker on or near a hot gas or electric burner, or where it could touch a heated oven.
- Do not use the Wizz Chopper & Shaker on a sink drain board.
- Handle the Wizz Chopper & Shaker with care – remember the chopping blade is very sharp and should be kept out of reach of children.
- Always make sure the Wizz Chopper & Shaker is completely assembled before operating. Always operate the Wizz Chopper & Shaker with the processing lid in position. The appliance will not operate unless properly assembled.
- Ensure the Wizz Chopper & Shaker is switched off at the power outlet and the power cord is unplugged from the power outlet before inserting the chopping blade, processing lid or motor body.
- Do not use attachments other than those provided with the Wizz Chopper & Shaker.
- Do not attempt to operate the Wizz Chopper & Shaker by any method other than those described in this booklet.
- Do not process hot or boiling liquids – allow liquids to cool before placing into the processing bowl.
- Do not operate the Wizz Chopper & Shaker continuously for more than 1 minute. Allow the motor to rest for 10 minutes after each 1 minute of operation.
- Do not operate the Wizz Chopper & Shaker with a heavy load. None of the foods or quantities suggested in this manual are considered a heavy load.
- Do not operate the Wizz Chopper & Shaker without food in the bowl.
- Always ensure the chopping blade has stopped rotating and the Wizz Chopper & Shaker is switched off at the power outlet and the power cord is unplugged from the power outlet before removing the motor body and processing lid.
- Always ensure the Wizz Chopper & Shaker is switched off at the power outlet and the power cord is unplugged from the power outlet before attempting to move the appliance, when not in use, if left unattended and before disassembling, cleaning or storing.
- To protect against electric shock do not immerse the motor body, power cord or power plug in water or any other liquid.
- Do not move the Wizz Chopper & Shaker during operation.
- Do not leave the Wizz Chopper & Shaker unattended when in use.
- Keep the appliance clean. Follow the cleaning instructions provided in this book (page 11).

### IMPORTANT SAFEGUARDS FOR ALL ELECTRICAL APPLIANCES

- Unwind the power cord before use.
- Do not let the power cord hang over the edge of a table or counter, touch hot surfaces or become knotted.
- The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- It is recommended to regularly inspect the appliance. Do not use the appliance if power supply cord, power plug or appliance becomes damaged in any way. Return the entire appliance to the nearest authorised Breville service centre for examination and/or repair.
- Any maintenance, other than cleaning, should be performed at an authorised Breville Service Centre.
- This appliance is for household use only. Do not use this appliance for anything other than its intended use. Do not use moving vehicles or boats. Do not use outdoors. Misuse may cause injury.
- The installation of a residual current device (safety switch) is recommended to provide additional safety protection when using electrical appliances. It is advisable that a safety switch with a rated residual operating current not exceeding 30mA be installed in the electrical circuit supplying the appliance. See your electrician for professional advice.



## Before first use

Before using your Breville Wizz Chopper & Shaker, remove and safely discard all packaging materials and promotional labels, being careful when handling the chopping blade, as it is very sharp. Wash the processing bowl, processing lid and chopping blades in warm, soapy water. Dry thoroughly.

## Operation of your Wizz Chopper & Shaker

1. Place the processing bowl on a dry, level surface. Insert the chopping blade onto the centering shaft in the processing bowl.



2. Add food to be processed into the bowl. For types of food and quantities refer to page 10.
3. Insert the processing lid into the processing bowl. Align the grooves on the processing lid with those on the processing bowl and slide to 'click' into place. The top of the chopping blade spindle should be centered through the hole of the processing lid.



4. Ensure the power is switched off at the power outlet and the power plug is unplugged from the power outlet. Place the motor body on top of the processing lid so it fits snugly into place and sits flush against the rim of the processing bowl.



5. Insert the power plug into a 230/240V power outlet and switch on at the power outlet.
6. Press the operate button with the palm of your hand to process the ingredients. Refer to page 10 for approximate processing times.



**The Wizz Chopper & Shaker will not operate unless the processing lid and motor body are correctly assembled.**

**Note**



## Operating your Breville Wizz Chopper & Shaker

7. If desired, use the shaker attachment to sprinkle processed food. The shaker attachment can be assembled by removing the motor body, processing lid and chopping blade from the processing bowl. Insert the shaker attachment onto the processing bowl.



### Handy Hints for best results

- Do not overload the appliance by putting in too much food (Refer to table on page 10 for quantities). Do not exceed 'MAX' marking on processing bowl.
- Chop larger quantities in batches; do not exceed recommended maximum quantities.
- Do not operate continuously for more than one minute.
- Always remove chopping blade before pouring or shaking out food.
- To ensure even chopping results, cut food into pieces of similar size, up to 2cm square.
- When chopping herbs, ensure they are as dry as possible.
- To avoid damage to the chopping blade, do not process hard items such as frozen foods, ice, cereals and rice.
- Do not process chocolate.
- Do not process soft or semi-hard cheeses. Only process hard cheeses such as Parmesan or Romano.
- Do not process thin liquids such as water or milk.
- Do not process raw or cooked meats.
- Chopped ingredients such as fresh/dried herbs, garlic, breadcrumbs, nuts or cheese are ideal to use with the shaker attachment to garnish meals.

## Operating your Breville Wizz Chopper & Shaker

### Recommended foods, quantities and times

Type of Food	Preparation	Max. amount at one time	Approximate Time
Garlic	Peel	10 cloves	15-20 seconds
Fresh chilli	Trim, remove seeds if desired. Cut into 2cm pieces	50g	15-20 seconds
Dried chilli	Whole	15g	15-20 seconds
Fresh herbs	Wash and dry well. Remove stalks/stems if necessary	15g	20-30 seconds
Dried herbs	Remove stalks/stems if necessary	20g	15-20 seconds
Nuts	Shells removed	75g	20 seconds
Breadcrumbs	Cut into 2cm cubes	50g	20 seconds
Hard cheese (Parmesan, Romano)	Cut into 2cm cubes	75g	20-30 seconds

## Cleaning

### Motor base

Always ensure the Wizz Chopper & Shaker is switched off at the power outlet and the power cord is unplugged from the power outlet before cleaning.

Wipe the motor body with a clean damp cloth after each use.

### Other parts

Wash the processing bowl, processing lid, shaker attachment and chopping blade in warm to hot soapy water using a mild detergent. Rinse and dry thoroughly.

The processing bowl, processing lid, chopping blade and shaker attachment may also be washed in the dishwasher (top shelf only).

Do not use steel wool, scouring pads or abrasive cleaners, as these will scratch the surfaces.

The chopping blade is very sharp so handle with care at all times. Use extreme care when washing. To avoid accidental cuts do not leave the chopping blade to soak in sudsy water.

Note

### Food stains and odours

Food such as spices may leave a stain on plastic parts whilst other foods such as garlic will leave a strong odour. To remove either, soak the parts for 5 minutes in 1 litre water with ¼ cup lemon juice.

### Storage

Before storing, thoroughly wash and dry all parts.

Always ensure the Wizz Chopper & Shaker is switched off at the power outlet and the power cord is unplugged from the power outlet before storing.

Store the Wizz Chopper & Shaker assembled, with the chopping blade inserted in the bowl, on the kitchen bench or in an easy to access cupboard. Store the Wizz Chopper & Shaker out of reach of children. Store the appliance upright. Do not store anything on top of the appliance.

The chopping blade is very sharp, use extreme care when storing.

Note

## Troubleshooting table

PROBLEM	SOLUTION
<b>Motor doesn't start or chopping blade doesn't rotate</b>	Check that the processing bowl, processing lid, and motor body are assembled correctly and securely in place. Check that the power plug is securely inserted into the power outlet and switched 'ON'.
<b>Food is unevenly chopped</b>	Either too much food is being chopped at one time or the pieces are not small enough. Try cutting food into smaller pieces of even size and processing a smaller amount per batch. For best results the food should be chopped into pieces no larger than 2cm.
<b>Food is chopped too fine</b>	The food is over processed. Next time use brief pulses or process for a shorter time.
<b>Food collects under the processing lid or around sides of processing bowl</b>	Processing too much food. Turn the Wizz Chopper & Shaker off at the power outlet. When the chopping blade stops rotating, remove the motor body and processing lid. Clean the processing bowl and processing lid with a spatula. Reduce quantity of food to be processed.
<b>Food sticks to chopping blade</b>	Processing too much food. Turn the Wizz Chopper & Shaker off at the power outlet. When the chopping blade stops rotating, remove the motor body and processing lid. Carefully remove the blade. Remove the food from the chopping blade with a spatula. Reduce quantity of food and continue processing.



**CAUTION: NEVER IMMERSE THE MOTOR BODY, POWER CORD OR POWER PLUG IN WATER OR ANY OTHER LIQUID. DO NOT PLACE THE MOTOR BODY IN THE DISHWASHER.**

