

TECHNICAL INFORMATION




PRODUCT

P 1 / 13

Models No. ▶ BHR202

Description ▶ Cordless Combination Hammer



CONCEPT AND MAIN APPLICATIONS

The subject model features 18V Li-ion Battery and 3 mode selection for ensuring an operator its easy handling and versatility.

The highly durable tool head mechanism is the same as AC model HR2470.

These new products are available in the following variations.

| Model No. | Battery | | Charger | Plastic carrying case |
|-----------|---------|----------|---------|-----------------------|
| | Type | Quantity | | |
| BHR202RFE | BL1830 | 2 | DC18RA | Yes |
| BHR202RF | | 1 | | Yes |
| BHR202Z | No | --- | No | No |

| Dimensions: mm (") | |
|--------------------|--------------|
| Length (L) | 358 (14-1/8) |
| Width (W) | 84 (3-5/16) |
| Height (H) | 259 (10-1/4) |

The variations for USA, Canada, Mexico and Panama are as follows.

| Model No. | Battery | | Charger | Plastic carrying case |
|-----------|---------|----------|---------|-----------------------|
| | Type | Quantity | | |
| BHR202 | BL1830 | 2 | DC18RA | Yes |
| BHR202Z | No | --- | No | No |

► Specification

| | | |
|---|---|-----------------------------|
| No load speed: (min. ⁻¹ = rpm) | 0 - 1,100 | |
| Blows per min: (bpm=min. ⁻¹) | 0 - 4,000 | |
| Max. Output(W) | 330 | |
| Battery | Voltage: V | 18 |
| | Cell and Capacity | Li-ion 3.0 Ah |
| | Charging Time | approx. 22 min. with DC18RA |
| Chuck Capacity: mm (") | 10 (3/8) | |
| Bit Shank | SDS plus | |
| Capacity : mm (") | Steel | 13 (1/2) |
| | Wood | 26 (1) |
| | * Concrete | 20 (13/16) |
| Operation mode | 3 modes (Rotation only/ Rotation with Hammering/ Hammering only) | |
| Variable switch | Yes | |
| Reverse switch | Yes | |
| Clutch (Torque Limiter) | Yes | |
| Electric Brake | Yes | |
| LED Light | Yes | |
| Net Weight: kg (lbs) | 3.2 (7.0) including Battery BL1830 | |

* Concrete: 24 (15/16) for North America

► Standard equipment

* Grip Assembly 1 set * Depth Gauge (Stopper Pole) 1 pc.

Note: The standard equipment for the tool shown above may differ by country.

► Optional accessories

| | | | | |
|--------------------------|-----------------------|---------------------|-----------------------------|----------------------|
| * SDS-Plus bits | * Drill chuck S13 | * Grooving chisels | * Bit grease | * Hammer service kit |
| * Taper shank T.C.T bits | * Chuck key S13 | * Scaling chisels | * Blow out bulb | * Charger DC18RA |
| * Taper shank adapter | * Keyless drill chuck | * Bull points | * Safety goggle | * Charger DC18SC |
| * Cotter | * Grip assembly | * Dust cup set | * Dust extractor attachment | * Charger DC24SA |
| * Drill chuck assembly | * Scraper Assembly | * Dust cups | * Joint 25 | * Charger DC24SC |
| | * Cold chisels | * Grease Vessel 30g | * Hose | |

► Repair

CAUTION: Remove the bit and the battery from the machine for safety before repair/ maintenance in accordance with the instruction manual!

[1] NECESSARY REPAIRING TOOLS

| Code No. | Description | Use for |
|----------|--|---|
| 1R003 | Retaining ring S pliers ST-2N | Removing Ring spring 19 |
| 1R004 | Retaining ring S pliers ST-2 | Removing Ring spring 29 |
| 1R022 | Bearing plate(for arbor press) | Attachment of 1R306 / Removing and Helical gear 25 |
| 1R023 | Pipe ring (for arbor press) | Removing Helical gear 25 |
| 1R032 | Bearing setting plate 8.2 | Assembling Swash bearing 10 |
| 1R033 | Bearing setting plate 10.2 | Assembling Helical gear 25 |
| 1R038 | Armature holder 32 set for use with vise | Holding Tool holder complete when removing Ring spring 28 from Tool holder complete |
| 1R164 | Ring spring setting tool A | Assembling Oil seal 25 and Needle bearing complete to Gear housing complete |
| 1R165 | Ring spring setting tool B | Assembling Needle bearing complete into Gear housing complete |
| 1R212 | Tip for Retaining ring pliers | Attachment of 1R003 |
| 1R232 | Pipe 30 | Assembling Oil seal 25 to Gear housing complete |
| 1R252 | Round bar for arbor 30-100 | Removing Oil seal 25 from Gear housing complete |
| 1R269 | Bearing extractor | Removing Ball bearing 608ZZ from Swash bearing section |
| 1R281 | Round bar for arbor 7-50 | Removing Ring 8 from Cam shaft |
| 1R291 | Retaining ring S and R pliers | Removing Retaining Ring S-7 from Cam shaft |
| 1R306 | Ring spring removing jig | Removing Ring spring 29 from Tool holder complete |
| 318132-2 | Piston cylinder | Assembling Ring spring 28 to Tool holder complete |

[2] LUBRICATION


Apply the following grease to protect parts and product from unusual abrasion.

* Makita grease R No.00 to the portions marked with black triangle

* Molybdenum disulfide lubricant to the portions marked with gray triangle

| Item No. | Description | Portion to lubricate | Lubricant | Amount |
|----------|-----------------------|--|------------------------|----------|
| ① | Cap 35 | Lip portion where Bit is inserted | Makita grease R No. 00 | a little |
| ⑬ | Change lever | Pin portion | | |
| ⑯ | O ring 17 | Whole portion | | |
| ⑰ | Gear housing complete | Inside where Swash bearing section rotates | | |
| ⑳ | Spur gear 51 | (a) Teeth portion, (b) Surface where Clutch portion of ⑳ Tool holder complete contacts | | |
| ㉑ | Steel ball 7 | Whole portion | | |
| ㉓ | Tool holder complete | (c) Surface where Needle bearing complete contacts | | |
| | | (d) Surface where Plane bearing 28 of ㉓ Inner housing complete contacts | | |
| | | (e) Inside where ④ Piston cylinder reciprocates | | |
| ㉔ | Ring 10 | Surface where Cushion ring 13 contacts | | |
| ㉗ | O ring 9 | Whole portion | | |


Fig. 1



► **Repair**

[2] LUBRICATION (cont.)

| Item No. | Description | Portion to lubricate | Lubricant | Amount |
|----------|------------------------|---|--------------------------------|----------|
| ④① | O ring 16 | Whole portion | | |
| ④① | Piston cylinder | (f) Inside where Striker moves | Makita grease R No. 00 | a little |
| | | (g) Hole for accepting Piston joint | | |
| | | (h) Surface where ③① Tool holder complete contacts. (Refer to Fig. 1.) | Molybdenum disulfide lubricant | |
| ④⑨ | Spur gear 10 | Gear teeth where ②⑧ Spur gear 51 engages (Refer to Fig. 1.) | Makita grease R No. 00 | a little |
| ⑤① | Clutch cam | (i) Outside groove | Molybdenum disulfide lubricant | |
| ⑤② | Swash bearing 10 | (j) Side where ⑤② Swash bearing 10 engages | | 4g |
| | | Pole portion which is inserted into Piston joint | | |
| ⑤③ | Helical gear 25 | Bearing portion | | 17g |
| ⑥③ | Inner housing complete | Teeth portion | Makita grease R No. 00 | a little |
| ①⑦ | Gear housing complete | Space where Armature's drive end and ⑤③ Helical gear 25 engages | | 5g |
| ①⑦ | Gear housing complete | (k) Crank room | | |




[3] DISASSEMBLY/ASSEMBLY

[3] -1. Tool Holder Section

DISASSEMBLING

Disassemble Tool holder section as illustrated in **Fig. 3.**

Fig. 3



ASSEMBLING

Do the reverse of the disassembling step. Refer to **Fig. 3.**

Note: Be sure to place the flat portion of Ring spring 19 on Steel ball 7.0.

► Repair

[3] DISASSEMBLY/ASSEMBLY

[3] -2. Change Lever

DISASSEMBLING

Disassemble Change lever as illustrated in **Figs. 4 and 5.**

Fig. 4





Fig. 5



ASSEMBLING

- 1) Assemble Change lever to Gear housing complete in the order of **Figs. 6 and 7.**
- 2) Make sure that Change lever stops at every operation mode exactly after assembling.

Fig. 6





Fig. 7



► **Repair**

[3] DISASSEMBLY/ASSEMBLY

[3] -4. Armature

DISASSEMBLING

- 1) Remove Holder cap cover by inserting Slotted screwdriver between Holder cap cover and Motor housing complete. (Fig. 8) Then remove Holder cap and Carbon brushes.
- 2) Separate Gear housing complete from Motor housing complete by loosening 4x40 Tapping screws (4 pcs.). Armature is left on Gear housing complete in this step. (Fig. 9)
- 3) Pull Armature out from Gear housing complete by hand. (Fig. 10) This way is easier than using Plastic hammer to strike Gear housing portion. (Ball bearing 6000DDW of Armature is tightly fit into the bearing room in Gear housing complete using O ring 26.)

Fig. 8




Fig. 9





Fig. 10



ASSEMBLING

Do the reverse of the disassembling step.

[3] -5. Torque Limiter Section

DISASSEMBLING

- 1) Disassemble Tool holder section as illustrated in Fig. 3.
- 2) Disassemble Change lever as illustrated in Figs.4 and 5.
- 3) Separate Gear housing complete from Motor housing. Then remove Armature from Gear housing complete. (Figs. 8 to 10)
- 4) Disassemble Torque limiter section as illustrated in Figs. 11 and 12.
- 5) Remove the Ring spring 29 to separate Washer 31, Compression spring 32 and Spur gear 51 (Figs. 13 and 14)

Fig. 11




Fig. 12




Fig. 13





Fig. 14



► **Repair**

[3] DISASSEMBLY/ASSEMBLY

[3] -5. Torque Limiter Section (cont.)

ASSEMBLING

Do the reverse of disassembling steps.

Note: Do not forget to assemble Flat washer 28 between Torque limiter section and Inner housing complete. Refer to **Fig. 12**.

[3] DISASSEMBLY/ASSEMBLY

[3] -6. Needle Bearing Complete and Oil Seal 25

DISASSEMBLING

1) Disassemble Torque limiter section and Inner housing complete from Gear housing complete.

See Disassembly of **[3] -5. Torque Limiter Section**.

2) Insert Inner housing complete into Gear housing complete. (**Fig. 15**)

3) Remove Needle bearing complete and Oil seal 25. (**Fig. 16**)

Fig. 15





Fig. 16



ASSEMBLING

1) Assemble Oil seal 25 to Gear housing complete in the order of **Figs. 17 and 18**.

2) Assemble Needle bearing complete as illustrated in **Figs. 19 and 20**.

Fig. 17




Fig. 18




Fig. 19





Fig. 20



► **Repair**

[3] DISASSEMBLY/ASSEMBLY

[3] -7. Impact Bolt Section

DISASSEMBLING

- 1) Referring to "[3] -5. Torque Limiter Section", disassemble Ring spring 29, Washer 31, Compression spring 32 and Spur gear 51 from Tool holder complete. Refer to **Figs. 11 to 14**.
- 2) Holding Gear housing complete in vise and 1R038, Tap Ring spring 28 in Tool holder complete as illustrated in **Figs. 21 and 22**.
- 3) Remove Ring spring 28 from Tool holder complete and disassemble Impact bolt section. (**Figs. 23 to 24**)

Fig. 21




Fig. 23




Fig. 22





Fig. 24



ASSEMBLING

- 1) Referring to **Figs. 25, 26 and 27** assemble the Impact bolt section to Tool holder complete as illustrated in **Fig. 28**.

Fig. 25




Fig. 26




Fig. 27





Fig. 28



► Repair


[3] DISASSEMBLY/ASSEMBLY

[3] -7. Impact Bolt Section (cont.)

ASSEMBLING

2) Push Ring spring 28 with Piston cylinder until it fits to the inner groove of Tool holder complete. (Fig. 29)

Fig. 29



[3] -8. Swash Bearing Section

DISASSEMBLING

- 1) Disassemble Tool holder section as illustrated in Fig. 3.
- 2) Disassemble Change lever as illustrated in Figs. 4 and 5.
- 3) Separate Gear housing complete from Motor housing complete. And then, remove Armature from Gear housing complete. (Refer to Figs. 8 to 10.)
- 4) Remove Stop ring E-4, Flat washer 5 and Compression spring 6 from pin of Inner housing complete. (Fig. 30)
- 5) Remove two M4x12 Hex socket bolts that fasten Bearing retainer to Inner housing complete. (Fig. 31)

Fig. 30





Fig. 31



► Repair

[3] DISASSEMBLY/ASSEMBLY

[3] -8. Swash Bearing Section (cont.)

DISASSEMBLING

6) Move Piston cylinder to the rear dead center position (**Fig. 32**).

7) Remove Swash bearing section from Inner housing by pulling in the direction of the arrow. Then, remove Change plate from the groove of Clutch cam. (**Fig. 33**).

Fig. 32





Fig. 33




8) Remove Ball bearing 606ZZ from Gear housing complete using the removed Swash bearing section as a jig as follows;

* Insert Cam shaft of Swash bearing section into the Ball bearing again.

* Tilt the Ball bearing a little bit by moving Swash bearing section as illustrated to **left in Fig. 34**.

* Ball bearing 606ZZ can now be removed by lightly tapping the edge of Gear housing complete with plastic hammer as illustrated to **right in Fig. 34**.

Fig. 34



9) Remove Ring 8 using 1R022, 1R023, 1R281 and arbor press as illustrated in **Fig. 35**.

10) Remove Ball bearing 608ZZ using 1R269. Flat washer 8 and Bearing retainer can now be removed by hand. (**Fig. 36**)

Fig. 35





Fig. 36



► Repair

[3] DISASSEMBLY/ASSEMBLY

[3] -8. Swash Bearing Section (cont.)

DISASSEMBLING

- 11) Remove Helical gear 26 using 1R022, 1R023 and 1R281.
as illustrated to left in **Fig. 37**. Swash bearing 10 and Clutch cam can now be removed by hand (**right in Fig. 37**).
- 12) Remove Retaining ring S-7 using 1R291 (**left in Fig. 38**). Compression spring 7 and Spur gear 10 can now be removed by hand. (**right in Fig. 38**).

Fig. 37





Fig. 38




ASSEMBLING

- 1) Assemble Swash bearing section using 1R032, 1R033, 1R291 and arbor press as illustrated in **Fig. 39**.

Note: Be sure to put Flat washer 8 in place, or else Bearing retainer will be clamped between Ball bearing 608ZZ and Helical gear 26.

Fig. 39



► Repair

[[3] DISASSEMBLY/ASSEMBLY

[3] -8. Swash Bearing Section (cont.)

ASSEMBLING

2) Assemble Piston joint and two Flat washers 12 to Piston cylinder as illustrated in Fig. 40.

Note: Do not forget to apply Makita grease R No.00. Refer to Fig. 2.

3) Insert Piston cylinder into Inner housing complete. (Fig. 41).

Fig. 40





Fig. 41



4) Move Piston cylinder to the rear dead center position. (Fig. 42)

5) Insert the pole of Swash bearing 10 into the hole of Piston joint as illustrated in Fig. 43.

Fig. 42





Fig. 43



6) Insert Ring 8 (the end of Swash bearing section) into Inner housing complete. (Fig. 44)

7) Fitting the tip of Change plate in the groove on Clutch cam, insert Change plate over the pins of Inner housing complete. (Fig. 45)

Note: Ball bearing 608ZZ of Swash bearing section is not yet inserted into Inner housing complete in this step.

Fig. 44






Fig. 45



8) Insert Ball bearing 608ZZ of Swash bearing section into Inner housing complete, and fasten Swash bearing section to Inner housing complete with two M4x12 hex socket head bolts. Then, put Compression spring 6 and Flat washer 5 through the upper pin of Inner housing complete, and secure them with Stop ring E-4 (Fig. 46)

Fig. 46



► Repair


[3] DISASSEMBLY/ASSEMBLY

[3]-9. F/R Change Lever

ASSEMBLING

Fit the protrusion of Switch into Oval hole of F/R change lever and assemble them to Housing L. F/R change lever is symmetric between right and left, therefore, it is not directional. (Fig. 47)

Fig. 47



► Maintenance program

It is recommended to replace the following parts shown below and apply lubricant to the specific parts designated in Figs. 2 and 3 when replacing Carbon brushes.

