

XK3190-A1^{+P}

Weighing Indicator

USER' S GUIDE

Attention:

Please read this User's Guide carefully when you use the indicator!

XK3190-A1⁺P

1 . Specifications

2 . Installation

- 2.1 Front & Back View of Indicator
- 2.2 Keyboard Function
- 2.3 Connecting Loadcell to Indicator

3. Calibration

4. Operating Instructions

- 4.1 Starting and Starting auto zero setting at turning on
- 4.2 Manual Zero Setting (Semi-automatically setting zero)
- 4.3 Tare Function
- 4.4 Connecting Scoreboard to Indicator
- 4.5 Connecting Pinter to Indicator
- 4.6 Connecting Serial Communication port to Indicator
- 4.7 Setting of Time and Date
- 4.8 Storing, Checking and Deleting of Data
- 4.9 insufficient voltage indication

5. Maintenance and Announcements

6. Errors and Information

Important Notes!!!

1. Printer interface invalid due to the built-in micro-printer (optional supply upon special requirement)
2. The function key is used as the paper roll key, it works upon pressing and stops working upon releasing.
3. “5” should be chosen as printer parameter TypE
4. There is only one print format - linked bill format when micro-printer used.
5. The discount ratio printer option must be off while using:
“odE=0”
“dct=0”

XK3190-A1⁺


1 Specification

1	Model	XK3190-A1 ⁺
2	Sample rated	5~25 times / sec
3	Load cell sensitivity	1~ 2mv/v
4	Division	1/2/5/10/20/50/100 optional
5	Display	7-bits LED digital display 0.56" in character height and 7 status indicating.
6	Clock	can display day/month/year and second/minute/hour
7	Scoreboard display interface	Using serial output method : current loop signal, transmission distance ≤50m RS323 signal, transmission distance ≤30m
8	Communication port	RS-232C Baud rate: 600/1200/2400/4800/9600 optional
9	Printing Port	Standard parallel output port, can connect with Tpus16 micro-printer, TM800,LX-300, KXP—1121and LQ-1600k wide-line printer.
10	Power Supply	AC 187~242V ; 49~50Hz The built-in repair-proof storage cell; 12V,7AH
11	Operating Temperature and Relative Humidity	0~40℃, ≤ 90% RH
12	Storage /transportation Temperature	-20 ~50℃
13	Fuse	500mA

XK3190-A1^P


2. Installation

2.1 Front & Back View of the Indicator



(Graph 2-1) Front View of Indicator

* ACCU - accumulating FUN- function CALB – Calibrating



(Graph 2-2) Back View of the Indicator

XK3190-A1^P

2.2 Keyboard Function



	Key	Function
1	[ACCU],[UNIT PRICE]	No meaning
2		In calibration mode, pressing [PRE-TARE/2] , can input digital key “2”; In weighing mode, the key is used for presetting tare.
3	[DELETE/4]	In calibration mode, pressing [DELETE/4], can input digital key “4”; In weighing mode, it is deleting function key , more details shown in episode “deleting”.
4	[CHECK/5]	In calibration mode, pressing [CHECK/5], can input digital key “5”; In weighing mode, it is checking function key , more details shown in episode “checking”.
5	[DATE/6]	In calibration mode, pressing [DATE/6] can input digital key “6” ;In weighing mode, it is date function key , more details shown in episode “setting of time and date”.
6	[SET PRINT]	In calibration mode, pressing [SET PRINT] can input digital key “7” ;In weighing mode, it is printing setup key , more details shown in episode “printing function”.
7	[CALB/8]	In calibration mode, it is calibration function key ; In other operation modes it only inputs digital key “8”
8	[TIME/9]	In calibration mode, pressing [TIME/9] can input digital key “9” ;In weighing mode, it is time function key , more details shown in episode “setting of time and date”.
9	[STORE/0]	In calibration mode, pressing [STORE/0] can input digital key “0” ;In weighing mode, it is storing function key , more details shown in episode “storing data”.
10	[ACCU/1],[UNIT PRICE/3]	In calibration mode, pressing [ACCU/1] or [UNIT PRICE/3] can input digital key, “1”; “3”;In weighing mode, there are no meaning.
11		In weighing mode, when stable sign appears, press [TARE] key to clear tare. If indicator displays zero, the weight value is net weight.
12		In weighing mode, when stable sign appears, press [ZERO] key to clear limited weight on the platform. You can set zero range , generally the zero range is 4% of full scale.
13		In weighing mode, when stable sign appears, press [PRINT] key to print weight data.
14		In calibration mode, press [ENTER] key to confirm that parameters have been inputted and will enter to next parameter setting automatically. When indicator is in date, time, printing and communication setting mode, push [ENTER] key to confirm that parameters have been inputted.

XK3190-A1^P

15 In calibration or parameters setting mode, pressing [weigh], it will exit from original calibration or setting mode and return to weighing mode.

2.3 Connecting Loadcell to Indicator

1. The 9-pin socket is used for the link-up of loadcell, which has been clearly shown in the graph 2-3.
2. The 4-pin shielded cable is used, +S must be short connected with +E, -S and -E. The indicator does not have the function of long distance compensation.
3. **▲ ! Indicator must be reliably connect ed to Loadcell and shielded-cable of loadcell must be reliably connect ed to underground . If indicator is powered on, the user should not insert or withdraw the plug in order to protect the indicator and loadcell.**
4. **▲ ! Sensor and indicator are static sensitive devices; you must adopt anti-static measures. In order to protect the operator ,indicator, and relevant devices, you should install lightning rod in the thunderstorm frenquently happening area.**



(Graph 3-2) Connection of the load cell

3. Calibration

According to the Graph 2-3, connecting Indicator and loadcell, and the indicator enters weighing mode.

1. Connecting calibration jumper to the 15- pin socket on the indicator back panel.
(There is a 15-pin plug in the packing carton with its 14-pin short connected with 15-pin.)
2. According to table 4-3, carry out calibration step by step.

Table 4 - 1

step	Operation	Display	Explanation
1	press [CALB]		after calibration jumper is inserted
2	press [1] [0] press [Enter]	[E **] [E 10]	Enter division value selecting 1/2/5/10/20/50/100/200 Example: 10
3	press [0] press [Enter]	[dc *] [dc 0]	Enter decimal point (0 -4) Example: without Decimal point 0
4	press [2] [3] press [Enter]	[pon XY] [pon 23]	Enter Zero range X: zero set range (1-5) it stands for 2% 4% 10% 20% 100% of F.S Y: power on Zero set range it Stands for (1-5) 2% 4% 10% 20% 100% of F.S example 23
5	press [3] [0] [0] [9] [0]	[F *****] [F 30090]	Enter overload warning value when inputting F value,and re-pressing [Enter] key, the calibration will begin. directly pressing [Enter],will enter into the tenth step. If pressing [weighting], Indicator will return to weighing status.
6	press [Enter]		Example: 30090
7		[noLoAdn]	Confirming Zero position. At this time there is no load on the scale.Pressing [Input] when the stable light is on.

XK3190-A1^P

step	Operation	Display	Explanation
8	press [1] [5] [0] [0] press [Enter]	[A LoAd1] [d 1500]	Loading weight \geq 5% Max.。 Example: 1500 After stable light is on, press [Enter] key.
9	press [Enter]	[noLoAd]	Confirming zero position again.
10	press [2] [0] [0][0] [0] press [Enter]	[ALoAd2] [20000]	Reloading weight on scale \geq 50% Max. It is better that this loading weight is near the F.S. Example: 20000 After stable light is on, press [Enter] key.
11	press [Enter] press [Enter] press [Enter]	[H xxxxxx] [L yyyyy] [td zzzz]	H. L. td indicating three calibrating coefficients . Recording them for spare use.
12	press [1] press [Enter]	[Adr **] [Adr 01]	communication address (01-26) Example: 1
13	press [1] press [Enter]	[bt *] [bt 1]	Serial communication baud rate (0-4). It respectively represents baud rate: 600, 1200, 2400, 4800, 9600. Example: 1 (1200)
14	press [0] press [Enter]	[tF *] [tF 0]	Serial communication Mode: 0- Continuous transmitting mode, no receiving. 1- Command response mode, Example: 0
15		Weighing mode	Calibration End.

Note: At step 6, 7, 8, 9, if press [Weighing] key, you can enter next step.

H. L. td indicating three calibrating coefficients .Recording them for spare use.

CAUTION!

When calibration is over, the calibration jumper must be pulled

out.

4. . Operating Instructions

4.1 Power on

- 1 When using AC power , power on , setting the ship- form switch at the back cover of the indicator on “1” ; If using DC power , setting the ship- form switch at the back cover of indicator on “1”, then pressing the recover switch, the indicator will perform “999999 - 000000 ” selfchecking. And then enter weighing mode. Or after pressing any key, self-checking stops and enters weighing mode automatically.
- 2 When power on, if loading weight on the plat form of the scale deviates from the zero point, but still within zero set range, Then indicator will set zero at power on automatically. If the loading weight is over the zero range, you should adjust zero point of scale or recalibrate and reset the indicator.

4.2 Manual zero setting:

- 1 In weighing mode, press [Zero] key. Indicator will perform zero-setting.
- 2 If displayed value deviates from zero point, but still within zero-range, pressing [Zero] key is available. Otherwise, [Zero] key is invalid. (In this status, please recalibrate or reset zero parameters)
- 3 Only when stability sign lamp is on, you are allowed to set zero operation.


4.3 Tare function

- 1 Normal Tare :

When Indicator at weighing status, and displaying positive weight stably.,press [Tare] key, indicator will deduct the displayed weight value as tare weight.. Then indicator displays net weight as “ 0 ”. And Tare sign Lamp is on.

- 2 Preset tare:

When Indicator at weighing status, press [Pre Tare] key, indicator will display [P *****], Using digital key entering known tare weight value, then press [Enter] key, the pre-tare is finished. At this time indicator displays net weight and tare sign lamp is lighted.




(Graph 4-1) Serial Communication port and score display port

4.4 Connecting Scoreboard to Indicator

1. The display interface of scoreboard is 15-pin socket, which has been clearly shown in the Graph 4-1.
2. The scoreboard signal is 20mA continuous current loop, outputting in binary code, the baud rate is 600.

4.5 Connecting Printer to Indicator

1. The print port adopts parallel output and 25-pin connecting socket, which has been clearly shown in the Graph 4-3.



2. Printing notes:
 - ▲ You must set the printer before you use it.
 - ▲ You must connect the indicator and the printer correctly. The wrong connection will destroy indicator output interface or printer input interface, and may even destroy the indicator or printer.
 - ▲ Turning on the printer as following: connecting the line correctly first, turning on the indicator power, and turning on the printer power finally.
Turning off the printer as following: turning off the printer power first, and then turning off the indicator power, cutting off the line finally.
Wrong procedure may destroy the indicator or printer.

XK3190-A1^{+P}

- ▲ The printer must be compatible to the indicator, please choose the recommended printer.
- ▲ The printer GND can not be connected to the power GND, otherwise the indicator or printer will be destroyed.

3. Set print parameters

step	operating	display	Explanation
1	press [PRN Set] press [9] [7] press [Enter]	[P 00] [P 97]	Enter printing setup Input password 97
2	press [0] press [Enter]	[Auto 1] [Auto 0]	Auto/ manual print 0: manual 1: Auto Example: 0
3	press [2] press [Enter]	[type 0] [type 2]	Selecting type of the printer. 0: print inhibited 1: TPup16TP (Eng. mode) 2: TIMES TM-800 3 National KX-P1121 4: EPSON LQ-1600K Example: 2
4	press [0] press [Enter]	[H-u 1] [H-u 0]	Selecting print format 0: Record format 1: document format Example:0
5	press [3] press [Enter]	[Arr 1] [Arr 3]	selecting document numbers (1-3) Example: 3
6	press [1] [0] [0] press [Enter]	[L 000.10] [L001.00]	Selecting Auto-print lower Limit. L: must> 10e Example: 1:00
7	Press[0] Press[Enter]	[ode *] [ode]	0: doesn't choose blank filling mode 1: choose blank filling print mode
8	Press[0]	[dct *]	0: doesn't use discount

XK3190-A1⁺P

	Press[Enter]	[dct]	1: use discount
		End	

Note:

You can use discount only when the blank filling mode is selected.

4. print and print format

Press [PRINT] key, you can print required weighing data according to print setting.

Record Format:

Weight Bill

Date 97-01-31

NO.	Time	Gross (kg)	Tare (kg)	Net (kg)	Accumulating(kg)
0001	08.56.16	299.98	1	298.98	298.98
0002	09.00.09	299.98	2	297.98	596.96
0003	09.00.28	299.98	3	296.98	893.94

Document Format

Weight Bill

NO. :	007
Date :	96-09-25
Time :	09.03.21
Gross :	299.98 (kg)
Tare :	9.98 (kg)
Net :	290.00 (kg)
Total :	2059.90 (kg)

Blank filling format (Compleat printing only in five sconds)

WEIGHT BILL	
Fist bill for operator	
SERIAL No.	123
DATE	1999-05-28
TIME	12.35.28
VEHICLE No.	
CARGO No.	
GROSS	1580 kg
TARE	80 kg
DISCOUNT	10 %
NET	1350 kg

XK3190-A1^P

REMARK	
--------	--

★ If setting the odE parameter to 1, you can perform the blank filling printing, at this time the other printing formats are invalid (Records format and document format are invalid).

Method: pushing [print] key, if dct parameter is set to 1, it will display [BFL**], inputting the discount rate and pushing [Input], it will print out the blank filling report: if dct parameter is set to 0, it will print out the blank filling report directly, 'discount rate' will be in blank.

★ The XK3190-A1 does not have the functions of truck No. and Article No. administration. The blank filling format is in blank.

★ In blank filling format, the indicator can print out the report in 1 or 3 fold.

★ The user can contact with the local dealer if the user wants the customized blank filling format.

4.6 Connecting Serial Communication port to Indicator

1. Communication port adopts 15 pins socket which was shared with scoreboard. It was shown on page 9 of User's Guide for A1, the pin 6(RXD) is used to receive the signal from the computer, the pin 7(TXD) is used to output the signal to computer.
2. Communication port adopts RS-232C, and all data are ASCII codes. Every group of data consists of ten bits binary codes, The first bit is start bit. The tenth bit is stop bit, the other eight bits are data bits.

Mode of communication:

- (1) Continues output mode

Indicator transmits current data of weight value (Gross or net weight).

- (2). Command mode

Every time Indicator receives command from the master computer, it transmits one frame data. Master computer transmits command to indicator, the indicator responses and transmits one frame weight value data.

3. Setting communication parameters

- (1) Communication parameters

Communication parameters consist of communication address, baud rate and

XK3190-A1^P

communication mode parameters.

(2) The sequence of parameters setting as following:

Connecting the loadcell , the indicator enters into working mode which is shown in the Graph 2-3.

Insert the setting jumper into 15-pin socket at the back of indicator. (There is a 15-pin plug in the packing carton with its 14-pin short connected with 15-pin.).

Setup communication parameters as following:

Step	Operation	Display	Explanation
1	Press[CALB]		Plug in calibration jumper
2	Press[Enter]	[E **]	Don't change this data and enter next step.
3	Press[Enter]	[dc **]	Don't change this data and enter next step.
4	Press[Enter]	[Pon **]	Don't change this data and enter next step.
5	Press[Enter]	[F *****]	Don't change this data and enter next step.
6	Press[Enter] Press[Enter]	[H *****] [L *****] [td **. **]	Don't change this data and enter next step.
7	Press[1] Press[Enter]	[A d r **] [A d r01]	Communication address (01~26) Example: 1
8	Press[1] Press[Enter]	[bt *] [bt 1]	Baud rate of serial communication (0~4) which represent baud rate of 600,1200,2400,4800,9600
9	Press[0] Press[Enter]	[tF *] [tF 0]	Serial communication mode: 0- Continous transmitting mode, unreceiving 1- command responding mode
10		Weighing mode	End of communication parameters setting

(Please note the explanation. Don't change other parameters setting carelessly)

4.7 Date, Time Set-up

(1) Under weighing status of the indicator, press [Date] key, and date sign lamp is lighted. Indicator display original data at this time. If it is correct, then press

XK3190-A1^{+P}

[Enter] key or [weighing] key to exit. If it is incorrect, using digital keys enters new date , then press [Enter] key.

- (2) Under weighing status of the indicator, press [Time] key, and Time sign lamp is lighted. Indicator display original Time data at this time. If it is correct, then press [Enter] key or the [weighing] key to exit. If it is incorrect, using digital keys enters new time data, then press [Enter] key.

4.8 Weight data store, check and clear

1 Data storing.

- (1) After weighing display becoming stable, press [Store] key, At this time, indicator will store weight value store into internal memory and accumulats it.
- (2) At the same time, displaying [LoAd] for fifteen seconds to prompt operator.
- (3) Negative or zero weight value can't be stored.
- (4) Indicator can store:total accumulated times. total accumulated weight value, and 200 groups of weighing records.
- (5) When print control "Auto" is set to " 1", system not only auto-prints, but also auto- stories and auto-accumulates weighing data.

2 Checking

Press [Check] key, to check the weight record data in internal memory of the Indicator.

Including: Total accumulating times, Total accumulating weight value, and every group of weighing record.

Operating as following:

Step	Operating	Display	Explanation
1	press [Check]	[****]	n=Total accumulating times
	press [Check]	[H ***]	H=Total accumulating weight High 3 bits
	press [Check]	[L *****]	L=Total accumulating weight low 5 bits
2	press [Check]	[no 001]	First group of weighing sign symbols record
	press [Check]	[dt ****]	Date (M.D)
	press [Check]	[t ****]	Time (H.m)
	press [Check]	[A *****]	Gross
	press [Check]	[P *****]	Tare
	press [Check]	[n *****]	Net
	press [check]	[no 002]	The second group of weighing sign symbols record

- ☆ Checking ends, Indicator auto-returns to weighing mode, and using [weighing] key, you can quit checking mode.

3 Clear

Press [clear] key, can clean accumulating weight value or stored data.

Step	Operating	Display	Explanation
1	press [Clear]		
2	press [1] [sure 1]	[sure 0] [sure 1]	Selecting clear/not clear 0: no 1: yes Example: 1
		End	

4.9 Insufficient voltage indicating

When the storage cell voltage is insufficient, the insufficient voltage lamp is on. At this time the indicator will twinkle. You should set the ship-like switch at the back cover of indicator to “0” to protect the storage cell. Continual using will result in the further decreasing of the storage cell voltage, in this case the indicator will cut off the storage cell supply.

5. Maintenance and Announcements

- 5.1 To guarantee the clarity and using life, the indicator shouldn't be placed directly under sunshine and should be placed in the plain space .
- 5.2 The indicator should avoid dust pollution, vibration and moisture.
- 5.3 Loadcell should connect with indicator reliably, and the system should be connected into ground properly. The indicator must be detected from high electrical fields.
 - ▲ **! In order to protect the operator ,indicator, and relevant device, you should mount lightning rod in thunderstorm frequently happening area.**
 - ▲ **! Loadcell and indicator are static sensitive devices, you must adopt anti-static measures.**
- 5.4 It is strictly forbidden to clean the case of indicator with intensive solvents (for example: benzene and nitro oils)
- 5.5 Liquid and electrical conducting particles should not poured onto the indicator, otherwise the

XK3190-A1^P

electronic components will be damaged and electric shock is likely to happen.

- 5.6 You should cut off power supply of indicator and relevant device before you pull-in and out the connecting line of indicator and external device.
- ▲ **! You must cut off power supply of the indicator , before you plug the connecting line of the loadcell in and out.**
 - ▲ **! You must cut off power supply of the indicator and the printer, before you plug in connecting line of the printer.**
 - ▲ **! You must cut off power supply of the indicator and the scoreboard, before you plug connecting line of the scoreboard in and out.**
 - ▲ **! You must cut off power supply of the indicator and the master computer, before you pull connecting line of communication in and out.**
 - ▲ **! You must cut off power supply of the indicator and external connecting system, before you pull connecting line of control output in and out.**
- 5.7 The user should return this indicator to our company for repair. Non-weighing manufacturer should not repair it, or by yourself, otherwise further destruction may occur.
- 5.8 From invoice date, the indicator has a total one-year free repair period. If any non-artificially obstacle about the indicator occurs while under correct using conditions within the period, the user is allowed to send the product with its guarantee card (of the correct number) back to our corporation for free repair.
- 5.9 The indicator shouldn't be taken apart, otherwise free guarantee will be cancelled.

6. Errors and Information

6.1 Normal information

- | | | | |
|--------|--|--------|--|
| 1 | <table border="1"><tr><td>.....</td></tr></table> | | Wait a moment, and this is a normal display. |
| | | | |
| 2 | <table border="1"><tr><td>Prnt</td></tr></table> | Prnt | Wait a moment, the data are being transmitted between indicator and printer. |
| Prnt | | | |
| 3 | <table border="1"><tr><td>LoAd</td></tr></table> | LoAd | Storing data, it will indicate for not less than 2 seconds to prompt the operator. |
| LoAd | | | |
| 4 | <table border="1"><tr><td>--OF--</td></tr></table> | --OF-- | No meaning. |
| --OF-- | | | |

6.2 Error information indicating

- | | | | |
|--------|--|--------|--|
| 1 | <table border="1"><tr><td>Err 03</td></tr></table> | Err 03 | Overload warning |
| Err 03 | | | |
| 2 | <table border="1"><tr><td>Err 10</td></tr></table> | Err 10 | Zero or Negative weight value, can't be stored. |
| Err 10 | | | |
| 3 | <table border="1"><tr><td>Err 11</td></tr></table> | Err 11 | dissatisfying demands of document format , or printing set is wrong. |
| Err 11 | | | |
| 4 | <table border="1"><tr><td>Err 12</td></tr></table> | Err 12 | dissatisfying demands of the printer set. |
| Err 12 | | | |
| 5 | <table border="1"><tr><td>Err 16</td></tr></table> | Err 16 | Date or Time is illegal. |
| Err 16 | | | |

6.3 Wrong setting information indicating

- 1 **Err 13** Wrong setting of the division value .
- 2 **Err 14** Decimal point must be less than 5, please reset the decimal bit.
- 3 **Err 15** Overload warning must be > 100, please reset it.
- Err 17** Enter new data which should be less than 65000.

6.4 Wrong connection information indicating

- 1 **Err P** It means the printer has trouble or is wrongly connected. push any key to quit.
- 2 **Err 01** It means the load cell signal line is wrongly connected, or its signal is negative.
 - (1) If this scale is under usage , then can be sure : the load cell connecting wires had troubles, or load cell has been damaged.
 - (2) If this scale hasn't been calibrated, the user should check the load cell's connective wires first. (Whether the signal line has been negatively connected). If the loadcell cable is corretly linked, but the indicator still indicates Err01 , the problem can then be solved by short connecting pin 4 and pin 6.
- 3 **Err 02** It means the load cell's wires are wrongly linked, or the signal value exceeds the A/D converting range.
 - (1) If this scale is under usage, then can be sure: the load cell's connective wires had troubles, or load cell is damaged.
 - (2) If this scale hasn't been calibrated, please check as following:
 - a) Carefully check the load cell's connective wires is right or not.
 - b) Check if load cell is suitable or not: It should satisfy the following terms: the "scale's dead load + scale's rated capacity " must be less than the load cell's rated capacity.
 - c) This may happen in case that there are more than one load cell in the weighing system.
 - d) Short connecting the pin 4 and pin 1 on the socket of the load cell.

6.5 Error of components and solving method

- 1 **Err 18** Key board has problems, It will indicates for ten seconds, then indicator enters weighing mode.
- 2 **Err 20** The data is partly lost in RAM. Operator should put in the calibration plug to self-check, and then pull it out.

XK3190-A1^P

3 **Err 21** Calibrating data have been lost in RAM and EPROM, Operator must put

in the calibration plug, then reenter the original calibration data, turn on the indicator again or re-calibrate it.

4 **Err 22** EPROM has been damaged.

5 **Err 23** RAM has been damaged.

6.6 Other information indicating

1. **Err 24** In normal operation, you must pull off the calibration jumper. The indicator is under normal operation, and the calibration jumper shouldn't be put in. If calibration is needed, the calibration jumper should be put in at set-up. You should pull out the calibration jump when turning off the indicator. If the indicator finds that the calibration jump was inserted when turning on, it will display **Err 24** for 6 seconds to prompt the operator.

2 **Err 25** Illegal software, or E2PROM was damaged

.

12 groups of data constitutes of a frame

Date No. in a frame	explanation
1	02 (X ON) , start
2	+ or - ,
3	Weight date
4	Weight date
5	Weight date
6	Weight date
7	Weight date
8	Weight date
9	Decimal position, from right to left (0 – 4)
10	Checking XRL, higher 4 bits
11	Checking XRL, lower 4 bits
12	03 (X OFF) END

XK3190-A1^P

The frame from the computer consists of 6 data

	explanation
1	02 (X ON) start
2	A ~ Z address
3	A: Shaking hands B: asking GW C: asking tare D: asking NW E: asking accumulated times and accumulated weight
4	XRL checking
5	XRL checking
6	03 (X OFF) end

$$\text{XRL} = 2 \oplus 3$$

XK3190-A1^P

The explanation of data No : 4 - n

Command A	No data	Each frame consists of 6 groups of data
Command B	GW: + / - GW data (6 bits) . . . GW data Decimal position	Each frame consists of 14 groups of data
Command C	Tare: + / - Tare data . . . Tare data Decimal position	Each frame consists of 14 groups of data
Command D	NW: + / - NW data . . . NW data Decimal position	Each frame consists of 14 groups of data

XK3190-A1^P

Command E	Accumulated times and weigh Accumulated times (4 bits) . . . , (comma) separation mark Accumulated weight (10 bits) . . Decimal position	Each frame consists of 22 groups of data
--------------	---	--