



Consumer Information



WARNING


To prevent entanglement injury, never place the gym in a crib or playpen. Never add strings, ties or other products to the gym.

- Please keep this instruction sheet for future reference, as it contains important information.
- Requires three "AA" (LR6) **alkaline** batteries (not included).
- Adult assembly is required.
- Tool required for assembly: Phillips screwdriver (not included).
- Wipe this toy with a clean cloth dampened with a mild soap and water solution. Do not immerse this toy.
- This hub has no consumer serviceable parts. Do not take this toy apart.


Assembled Parts




Hub



4 Tubes



Quilt



7 Toys



CONSUMER ASSISTANCE

1-800-432-5437 (US & Canada)
1300 135 312 (Australia)

service.fisher-price.com

Fisher-Price, Inc., 636 Girard Avenue, East Aurora, NY 14052.
Hearing-impaired consumers: 1-800-382-7470.

Outside the United States:

Canada: Mattel Canada Inc., 6155 Freemont Blvd.,
Mississauga, Ontario L5R 3W2; www.service.mattel.com.


Great Britain: Mattel UK Ltd, Vanwall Business Park,
Maidenhead SL6 4UB. Helpline: 01628 500303.
www.service.mattel.com/uk

Mattel Europa, B.V., Gondel 1, 1186 MJ Amstelveen, Nederland.



Australia: Mattel Australia Pty. Ltd., 658 Church Street,
Locked Bag #870, Richmond, Victoria 3121 Australia.

New Zealand: 16-18 William Pickering Drive,
Albany 1331, Auckland.



Setup



- Slide a tube through one of the sleeves on the quilt.
- Hint: You may need to adjust the fabric on the sleeve after you insert the tube.*
- Repeat this procedure to attach the remaining tubes.



- Insert the foot at the bottom of each tube through the elastic loops on the quilt.
- Make sure the elastic loop is fitted below the tab on each tube.



- Insert the ends of the tubes into the sockets in the hub. Make sure you hear a **"snap"**.
- Pull each tube to be sure it is secure to the hub.



- Hang the toys from the loops around the gym.

Battery Safety Information

In exceptional circumstances, batteries may leak fluids that can cause a chemical burn injury or ruin your product. To avoid battery leakage:

- Do not mix old and new batteries or batteries of different types: alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium).
- Insert batteries as indicated inside the battery compartment.
- Remove batteries during long periods of non-use. Always remove exhausted batteries from the product. Dispose of batteries safely. Do not dispose of product in a fire. The batteries inside may explode or leak.
- Never short-circuit the battery terminals.
- Use only batteries of the same or equivalent type, as recommended.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the product before charging.
- If removable, rechargeable batteries are used, they are only to be charged under adult supervision.

ICES-003

This Class B digital apparatus complies with Canadian ICES-003.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

NMB-003

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

L'utilisation de ce dispositif est autorisée seulement aux conditions suivantes : (1) il ne doit pas produire de brouillage et (2) l'utilisateur du dispositif doit être prêt à accepter tout brouillage radioélectrique reçu, même si ce brouillage est susceptible de compromettre le fonctionnement du dispositif.

FCC Statement

United States Only


This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

Note: Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

Battery Installation




- Locate the battery compartment on the top of the hub.
 - Loosen the screws in the battery compartment door with a Phillips screwdriver. Remove the battery compartment door.
 - Insert three, new “AA” (LR6) **alkaline** batteries.
- Hint: We recommend **alkaline** batteries for longer battery life.*
- Replace the battery compartment door and tighten the screws.
 - If this product begins to operate erratically, you may need to reset the electronics. Slide the power switch off and then back on.
 - When sounds or lights from this toy become faint or stop, it's time for an adult to change the batteries.




- Protect the environment by not disposing of this product with household waste (2002/96/EC). Check your local authority for recycling advice and facilities (Europe only).

Music, Lights and Ocean Friends!




- Slide the power/volume switch on the top of the hub to ON with low volume (◀), or ON with high volume (▶).
- Press the mode button to play up to 20 minutes of fun sounds and lights!
- Press the button again to turn long play mode off and let baby's movement activate sounds and lights!
- When you are finished playing with this toy, slide the power/volume switch OFF (○).


Storage




- Press the button above each tube on the hub to release the tubes.



- Lay the tubes across the center of the quilt.
- Place the hub under one of the mesh arches, as shown.



- Fold the quilt in half, as shown.
- Then, fold in half again.



- Slide one end of the storage strap through the storage loop.
- Fasten the ends of the storage strap.