




Hand Held
VACUUM CLEANER
Household Type
OWNER'S GUIDE
170 SERIES



IMPORTANT

Do not return this product to the store.

For assembly problems or questions contact: Eureka's Customer Service Division toll free at 1-800-282-2886*, 8 a.m. to 7:30 p.m., (CST), Monday - Friday and 10 a.m. to 6:30 p.m. Saturday.

For replacement of broken or missing items to be shipped direct to you, call 1-800-438-7352*, 8 a.m. to 4:45 p.m., (CST), Monday - Friday.

To order replacement parts and accessories call 1-800-438-7352*, 8 a.m. to 4:45 p.m., (CST), Monday - Friday or visit our web site, www.eureka.com.

*En Mexico llame al 5670-6169.

Index

Important Information ...2
 Assembly Parts3
 How to Use3
 Filters4
 Troubleshooting5
 Warranty5

Please Retain

We suggest you record the model, type and serial numbers below. They are located on the silver rating plate on your cleaner. For prompt and complete service information, always refer to these numbers when inquiring about service.

Model& Type _____

Serial No. _____

It is also important to keep your receipt as proof of date of purchase.

IMPORTANT SAFEGUARDS

When using an electrical appliance, basic precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING THIS VACUUM CLEANER.

WARNING

To reduce the risk of fire, electric shock, or injury:

- Do not use outdoors or on wet surfaces.
- **Do not leave vacuum cleaner when plugged in.** Turn off the switch and unplug the electrical cord when not in use and before servicing.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If vacuum cleaner is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center before using.
- Do not pull or carry by cord, use cord as a handle, close door on cord, or pull cord around sharp edges or corners. Do not run vacuum cleaner over cord. Keep cord away from heated surfaces.
- Do not use extension cords or outlets with inadequate current carrying capacity.
- Turn off all controls before unplugging.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or vacuum cleaner with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
- This vacuum cleaner creates suction and contains a revolving brush roll. Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without motor filter in place.
- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids such as gasoline, or use in areas where they may be present.
- Store your cleaner indoors in a cool, dry area.
- Keep your work area well lighted.
- Unplug electrical appliances before vacuuming them.

SAVE THESE INSTRUCTIONS

To reduce the risk of electric shock, this appliance has a polarized plug (one blade is wider than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet. Do not change the plug in any way.



DO NOT OIL the motor or the brush roll. The motor and brush roll are permanently sealed and lubricated.

GENERAL INFORMATION

Use the cleaner to pick up dirt and dust particles. Avoid picking up hard or sharp objects that could damage the vacuum cleaner.

Service Information

The instructions in this booklet serve as a guide to routine maintenance. For additional service information, telephone our toll free number for the nearest Eureka Authorized Warranty Station. **You should know the model, type and serial number or date code when you call:**

USA: 1-800-282-2886 Mexico: 5670-6169
Canada: 1-800-282-2886




If you prefer, you can write to The Eureka Company, Service Division, 807 North Main St., Bloomington, Illinois 61701, USA. In Canada, write to The Eureka Company, 866 Langs Drive, Cambridge, Ontario N3H 2N7. Refer to The Eureka Warranty for complete service information.

Assembly Parts

1. Handle
2. On/Off Power Switch
3. Dust Cup Release Button
4. Dust Cup
5. Carrying Strap Connection
6. Telescoping Handle
7. Floor Nozzle
8. Carrying Strap
9. Storage Bag
10. Flexible Hose
11. Crevice Brush
12. Cleaning Brush
13. Dust Cup Filter (inside dust cup)

NOTE: Dust cup filter must be used when operating the vac.


To open the dust cup, push release button and pull dust cup away from cleaner. Verify that the dust cup filter is inside, reattach the dust cup to the hand vac.




How to Use

CAUTION: Always unplug from electrical outlet before changing tools or maintenance of vacuum.


Stick Vac




How to Use (continued)



Adjust telescoping handle by grasping vacuum firmly in one hand while pushing button on handle forward and sliding handle to desired length.




Stick vac can be used for above the floor cleaning.



Release handle from vacuum by pressing the black button release and pulling up on handle.

Hand Vac




CAUTION: The hand vac is a very powerful unit. Make sure that you hold it firmly, otherwise it can slip out of your hand and cause injury.

1. Hold the hand vac firmly with your hand on handle.
2. Push the On (-) Off (0) power switch to "On (-)" position.
3. Start vacuuming.


Changing And Cleaning Dust Cup Filters

CAUTION: Always unplug from electrical outlet before opening the dust cup.

1. To open the dust cup, push release button and pull dust cup away from vacuum.
2. Pull filter cover and filter away from vacuum.
3. Empty debris from the dust cup and brush debris from filter cover and filter.
4. Occasionally rinse the filter cover and filter in cold water. Then wait until they dry completely before placing them back on vacuum.
5. Place the dust cup filter into filter cover and place filter cover back on vacuum.
6. Reattach the dust cup to the vacuum.



Dust Cup



CAUTION: Adequate airflow must be maintained at all times through the cleaner. Any obstructions will cause the motor to overheat resulting in permanent damage.

Trouble Shooting Guide

PROBLEM	SOLUTION
Hand vac will not operate.	<ol style="list-style-type: none">1. Plug unit in firmly.2. Check fuse or breaker. Replace fuse/reset breaker.
Hand vac will not pickup or suction power is weak.	<ol style="list-style-type: none">1. Empty dust cup.2. Turn unit off and unplug from wall outlet and check for object(s) causing clog and remove.3. Clean or replace the filter cover and filter.
Dust escaping from hand vac.	<ol style="list-style-type: none">1. Empty dust cup and clean filter cover and filter.2. Review dust cup filter instructions.3. Replace dust cup filter.
Hand vac hose or brushes will not pickup.	<ol style="list-style-type: none">1. Remove hose and/or brushes. Remove obstruction from hose.2. Empty and clean dust cup and clean filter cover and filter.

THE EUREKA LIMITED WARRANTY

What This Warranty Covers

Your Eureka cleaner is warranted to be free from all defects in material and workmanship in normal household use for a period of one year. The warranty is granted only to the original purchaser and members of his or her immediate household. The warranty is subject to the following provisions.

What This Warranty Does Not Cover

- Parts of the cleaner that require replacement under normal use, such as disposable dust bags, filters, drive belts, light bulbs, brush roll bristles, impellers and cleaning.
- Damages or malfunctions caused by negligence, abuse, or use not in accordance with the Owner's Guide.
- Defects or damages caused by unauthorized service or the use of other than Genuine Eureka parts.

What The Eureka Company Will Do

The Eureka Company will, at its option, repair or replace a defective cleaner or cleaner part that is covered by this warranty. As a matter of warranty policy, the Eureka Company will not refund the consumer's purchase price.

Warranty Registration

Please fill out and return the warranty registration card accompanying your cleaner.

Obtaining Warranty Service

To obtain warranty service you must return the defective cleaner or cleaner part along with proof of purchase to any Eureka Authorized Warranty Station. You will find the nearest location in the Yellow Pages, under "Vacuum Cleaners—Service and Repair." Be certain that the Warranty Station is "Eureka Authorized."

For the location of the nearest Eureka Authorized Warranty Station or for service information visit www.eureka.com, or telephone toll free: USA: 1-800-282-2886, Mexico: 5670-6169, Canada: 1-800-282-2886.

If you prefer, you can write to The Eureka Company, Service Division, 807 North Main Street, Bloomington, Illinois 61701, USA. In Canada write to The Eureka Company, 866 Langs Drive, Cambridge, Ontario N3H 2N7.

If it is necessary to ship the cleaner outside your community to obtain warranty repair, you must pay the shipping charges to the Eureka Authorized Warranty Station.

Return shipping charges will be paid by the Warranty Station. When returning parts for repair, please include the model, type, and serial number from the data plate on the cleaner.

Further Limitations and Exclusions

Any warranty that may be implied in connection with your purchase or use of the cleaner, including any warranty of Merchantability or any warranty of Fitness For A Particular Purpose is limited to the duration of this warranty. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

Your relief for the breach of this warranty is limited to the relief expressly provided above. In no event shall Eureka be liable for any consequential or incidental damages you may incur in connection with your purchase or use of the cleaner. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

This warranty gives you specific legal rights. You may also have other rights which vary by state.

Questions & Answers about Genuine Eureka Products

Q: Why should I use only Genuine Eureka paper bags, belts, and parts in my Eureka vacuum cleaner?

A: **Using Genuine Eureka Products, which are made to our exacting specifications and engineered with emphasis on quality, performance, and customer satisfaction, ensures the long life and cleaning efficiency of your vacuum cleaner.**

Q: How can I be sure I am using only genuine Eureka products in my vacuum cleaner?

A: **Typically, packaged products and paper bags are labeled "Genuine Eureka Product".**

Q: Are there any differences between "made to fit" or "imitation" and Genuine Eureka paper bags, belts, and parts?

A: **Yes, there are some very important differences in materials, quality, and reliability.**

For Genuine Eureka Value, Accept No Imitations!

THE EUREKA COMPANY

Bloomington, Illinois 61701