



# New Solution Series

## NSK 4000 / 4480 / 4480B

### User's Manual

Manuel de l'utilisateur

Anwenderhandbuch

Manuale per l'operatore

Manual del usuario

取扱説明書

At Antec, we continually refine and improve our products to ensure the highest quality. It's possible that your new case will differ slightly from the descriptions in this manual. This isn't a problem; it's simply an improvement. As of the date of publication, all features, descriptions, and illustrations in this manual are correct.

### **Disclaimer**

This manual is intended only as a guide for Antec's Computer Enclosures. For more comprehensive instructions on installing the motherboard and peripherals, please refer to the user's manuals that come with those components.

## **New Solution Series User's Manual**

### **NSK 4000 / 4480 / 4480B**

#### **Super Mini Tower Case**

This case is designed to meet Intel's Thermally Advantaged Chassis (TAC) design guide requirements.

#### **The NSK4000 Case Only**

NSK 4000 comes without a pre-installed power supply unit (PSU). This allows you to install your choice of Antec power supply to match your individual needs.

#### **The NSK4480 Case with EA-380 power supply**

NSK 4480 and NSK 4480B come with an EarthWatts 380 watt PSU. Universal input, active PFC single 80mm fan cooled power supply that follows the ATX12V version 2.2 specifications. This includes dual +12V output rails that deliver safer and more reliable output to your system's components. Featuring higher energy efficiency, which reduces power consumption by up to 25%, saving you money on your electricity bill. EarthWatts' power supplies have achieved 80 PLUS® Certification, the latest independent standard in power supply efficiency. In addition EarthWatts includes a variety of protective circuitry: OPP (over power protection), OVP (over voltage protection), and SCP (short circuit protection).

The power supply comes with a main power switch. Make sure you turn the switch to the ON (I) position before you boot up the computer for the first time. Normally, you won't need to switch to the OFF (O) position, since the power supply includes a soft on/off feature. This lets you turn the computer on and off by using the soft switch on the computer case. If the computer crashes and you can't shut it down using the soft switch, you can switch the main power to the OFF (O) position, to clear the fault, then reboot.

#### **For models designed for sale in the European Union:**

Antec power supply models feature Power Factor Correction (PFC) circuitry in accordance with European standard regulation code EN61000-3-2. By altering the input current wave shape, PFC improves the power factor of the PSU. A better Power Factor increases energy efficiency, reduces heat, improves output voltage stability and prolongs the life of all equipment. The PSU's high efficiency design and the quiet fan deliver not only a cleaner but also a quieter operating environment.

Although care has been taken to prevent sharp edges in your Antec case, we strongly recommend taking your time and the appropriate care when working with it. Hurried or careless motion and use of excessive force, particularly when you are working in areas you cannot see clearly, are but a few examples of activity that should be avoided. Please use reasonable precaution.

### Setting Up

1. Take the case out of the box. Remove the Styrofoam and plastic bag.
2. Place the case upright with the power supply fan at the back facing you on a stable flat surface.
3. Remove the two thumbscrews that fasten the top cover onto the case. These are the only screws you need to remove to open the case. Set these screws aside and keep them separate from the other screws.
4. Slide the top panel toward the rear of the case and lift it up to remove.
5. At the top of the each side panel, in front of the power supply, there is a 4" wide tab. Using this, lift and pull the side panels out to remove.
6. Inside the case you should see the power supply, some wiring (LED's, etc.), an installed I/O panel, a power cord and a plastic bag containing more hardware (screws, brass standoff, plastic stands, etc.).

### Motherboard Installation

This manual is not designed to cover CPU, RAM, or expansion card installation. Please consult the motherboard manual for specific mounting instructions and troubleshooting.

1. Lay the case down so that the open side is up. You should be able to see the drive cage and power supply.
2. Make sure you have the appropriate I/O panel for the motherboard. If the panel provided is not suitable for the motherboard, please contact the motherboard manufacturer for the correct I/O panel.
3. Line up the motherboard with the standoff holes, and determine which ones line up and remember where they are. (Not all motherboards will match with all of the provided screw holes, and this is not necessary for proper functionality.) Some standoffs may be pre-installed for your convenience.
4. Lift up and remove the motherboard.
5. Screw in the brass standoffs to the threaded holes that line up with the motherboard.
6. Place the motherboard on the brass standoffs.
7. Screw in the motherboard to the standoffs with the provided Phillips-head screws.
8. The motherboard is now installed.

### Connecting the Power and LED

The power supply conforms to the ATX12V Version 2.2 standard. If the motherboard has a 20-pin power receptacle, detach the 4-pin attachment on the 24-pin power connector, see pictures 1 and 2. Before you connect the power supply to any devices, please consult the appropriate user manuals for the motherboard and other peripherals.

Picture 1



For 24-pin motherboards

Picture 2



For 20-pin motherboards

1. Connect the 24-pin Main Power Connector and the 4-pin or 8-pin connector to the motherboard as


- needed. If the motherboard uses a 20-pin connector; detach the 4-pin attachment on the 24-pin power connector (see pictures 1 and 2). **Note:** the detachable 4-pin section cannot be used in place of the 4-pin +12V connector.
2. Connect the Reset switch (labeled RESET SW) to the motherboard at the RST connector. Polarity (positive and negative) does not matter for switches.
  3. Power Switch (labeled POWER SW) connects to the PWR connector on the motherboard.
  4. Power LED (labeled POWER LED) connector is located behind the Reset connector. For LEDs, the colored wire is positive (+) and the white wire is negative (-). If the LED does not light up when the system is powered on, try reversing the connection. For more info on connecting LEDs to your motherboard, see your motherboard manual.
  5. Hard Drive LED (labeled H.D.D. LED) connects to the IDE connector.

### USB Connection

The USB2.0 connector going to the motherboard matches up with the Intel standard as follow: power, negative signal, positive signal, and ground consecutively. Before you connect the USB2.0 connector to the motherboard, please check the motherboard user manual for the correct pin layout.

**Note:** Please check the motherboard manual for the USB header pin layout and make sure it matches the table below. If it does not match this Intel® standard, please visit Antec’s web store at <http://www.antec.com/StoreFront.bok> and search for part number 30095 to order a USB Internal Adapter Cable. This adapter will allow you to connect the front USB to your motherboard on a pin-by-pin basis.

Motherboard Pin Layout



Pin	Signal Names	Pin	Signal Names
1	USB Power 1	2	USB Power 2
3	Negative Signal 1	4	Negative Signal 2
5	Positive Signal 1	6	Positive Signal 2
7	Ground 1	8	Ground 2
9	Key (No Connection)	10	Empty Pin

### 3.5" Device Installation

There is one 3.5" drive cage inside the case. It can hold 2 external 3.5" drives and 3 internal 3.5" (HDD) drives.

1. Remove the screw, which fastens the cage to the case. Slide the cage out of the case.
2. Mount your external 3.5" drives into the top two drive bays and the internal drives into the third drive bay down. Load the drives from the back, lining them up to the front of the drive cage.
3. With one hand supporting the drive, fasten the drive to the cage with the screws provided.
4. Slide and fasten the cage back to the case.
5. Find a small 4-pin white connector on the power supply and connect it to the male 4-pin connector on the floppy drive.
6. Connect a 4-pin large white connector from the power supply to the male 4-pin connector on each of the other internal devices.

## 5.25" Device Installation

There are three external 5.25" drive bays.

1. Looking from the rear of the case you can see metal grilles covering the 5.25" drive bays. Carefully push a screwdriver through the metal grille and gently push the plastic drive bay cover outwards until it comes off.
2. Using your hands, twist the metal plate back and forth until it breaks off.  
**Note:** Don't break off the metal grilles covering the drive bays that you are not using now. Be careful of the newly exposed metal where the grille was attached, as these areas are likely to be sharp.
3. Fasten the 5.25" device into the drive bay with screws provided.
4. Repeat the same procedure for other devices.
5. Connect a 4-pin large white connector from the power supply to the male 4-pin connector on each of the devices.

## Advanced Thermal Chassis Air Guide

According to the Intel Advanced Thermal Chassis Design Guide, the air guide is designed to provide cool air ventilation directly to the CPU through the duct. The air guide consists three parts: upper duct, flange, and lower duct. You can adjust the distance between the lower duct and CPU from 12 to 20mm by sliding the lower duct for maximum cooling efficiency.

An optional 80mm fan can be installed between the air guide and the side panel in order to blow air in to further cool down the system.

1. Remove Chassis Air Guide from the side panel.
2. Install the optional 80mm fan first by locking it to the side panel as shown in Picture 3.
3. Using the fan screws, lock the flange of the air guide to the fan as shown in Picture 4.
4. Connect a large 4-pin white connector from the power supply to the male 4-pin connector on the fan.



Picture 3



Picture 4

## Cooling System

### The Rear Exhaust TriCool™ fan:

The NSK 4000, 4480 and 4480B come with one 120mm TriCool™ fan preinstalled. This fan has a three-speed switch that lets you choose between quiet, performance, or maximum cooling. (See specifications below.) The fan is installed so that the air is blowing out of the case. Connect a large 4-pin connector from the power supply to the male 4-pin connector on the fan.

**Note:** The default setting of the fan is Low. We recommend this speed for maximum quiet computing.

**Note:** The minimum voltage to start the fan is 5V. We recommend that our users to set the fan speed to High if you choose to connect the fan to a fan control device or to the Fan-Only connector found on some of Antec’s power supplies. A fan-control device regulates the fan speed by varying the voltage to it. The voltage may start as low as 4.5V to 5V. Connecting a TriCool™ set on Medium or Low to a fan-control device may result in the fan not being able to start. The already lowered voltage from the fan control device will be further reduced by the TriCool™ circuitry below 5V.

**Specifications:**

Size: 120 x 120 x 25.4 mm  
 Rated Voltage: DC 12V  
 Operating Voltage: 10.2V ~ 13.8V

Speed	Input Current	Air Flow	Static Pressure	Acoustical Noise	Input Power
High 2000 RPM	0.24A (Max.)	2.24 m <sup>3</sup> / min (79 CFM)	2.54 mm-H2O (0.10 inch-H2O)	30 dBA	2.9 W
Medium 1600 RPM	0.2A	1.59 m <sup>3</sup> / min (56 CFM)	1.53 mm-H2O (0.06 inch-H2O)	28 dBA	2.4 W
Low 1200 RPM	0.13A	1.1 m <sup>3</sup> / min (39 CFM)	0.92 mm-H2O (0.04 inch-H2O)	25 dBA	1.6 W

**The Front 80mm Fan**

An **optional 80mm fan** can be installed to pull air into the case at the bottom front of the case. A mounting bracket is provided for this purpose.

1. Squeeze the upper right and left sides of the fan cage together to release the tabs. Once loose, you should be able to pull the cage back and out of the case.
2. Drop the fan into the cage and push it in until it clips in. No screws are needed. The front fan should be installed so that the air is blowing into the case.
3. Reattach the cage/fan assembly to the case paying attention to the wires of the fan. There are slots near each corner to put the wires through (any corner will work, find the one that’s best for you).
4. If you’re using a 4-pin fan, connect a 4-pin large white connector from the power supply. If you’re using a 3-pin fan, connect the 3-pin connector to a motherboard fan header.

**Learn more about 80 PLUS®:**

80 PLUS® is an innovative, electric utility-funded incentive program to integrate more energy-efficient power supplies into desktop computers and servers. The 80 PLUS performance specifications require power supplies in computers and servers to be 80% or greater energy efficient. This makes an 80 PLUS certified power supply at least 33% more efficient than current power supplies. 80 PLUS certified power supplies:

- Achieve energy savings, up to \$70 over the life of a desktop computer
- Reduce a room’s cooling load, increasing comfort and saving up to 30%
- Increase computer system reliability and save on maintenance costs by as much as 40%
- Minimize the need for noisy fans, creating a quieter environment
- Save on construction — saves hundreds of dollars in electrical system upgrades

- Allow more computers on the same branch circuit
- Save the environment — prevent pollution by reducing energy consumption

Run Cool, Run Reliably, Run with 80 PLUS® Energy Efficient®

More than 80% efficient at 20%, 50% & 100% load

**[www.80PLUS.org](http://www.80PLUS.org)**

System Integrators / VAR's for more information on 80 PLUS® financial and marketing advantages in North America go to **[www.antec.com/us/80Plus.html](http://www.antec.com/us/80Plus.html)**.

**Antec, Inc.**

47900 Fremont Blvd.  
Fremont, CA 94538  
USA  
tel: 510-770-1200  
fax: 510-770-1288

**Antec Europe B.V.**

Stuttgartstraat 12  
3047 AS Rotterdam  
The Netherlands  
tel: + 31 (0) 10 462-2060  
fax: + 31 (0) 10 437-1752

**Customer Support:**

**US & Canada**

1-800-22ANTEC  
customersupport@antec.com

**Europe**

+ 31 (0) 10 462-2060  
europe.techsupport@antec.com

**[www.antec.com](http://www.antec.com)**