

Digital Photo Frame LVF-PF72S **User Guide**



Thank you for purchasing our 7" Digital Photo Frame. You can play your favorite photos (JPEG file) directly from a memory card or a USB flash drive without a computer. Read the following instructions for more details









Figure 2






















- . Keep away from water, moisture and dust
- Ambient Temperature should be 0~40°C. Do not store the unit in hot or cold areas.
- . Do not drop the unit or give a strong impact
- Do not try to disassemble the unit by yourself.
- Connect the AC adapter to the DC5V jack and to the wall outlet.
- · Use attachments/accessories specified by the
- . When left unused for a long period of time, the unit should be unplugged from the wall outlet.

Warning: To reduce the risk of fire or electric shock do not expose the unit to rain, moisture and water. Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the

FCC NOTICE

This device complies with Part 15 of the FCC Rules Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

Canadian ICES-003 Information

This class B digital apparatus complies with Canadian ICES-003

This set complies with the EMC Directive 2004/108 and with the LVD Directive 2006/95

*Supports a USB fl

ash drive only

10 Stand receptacle

*For attaching the

supplied stand.

9 DC5V jack

OFF

Product Overview (Figure 1)

- 1 LEFT/ ► (Previous) 7 SD/MMC/MS/xD button 8 USB port
- 2 RIGHT/ ►► (Next) button 3 DOWN/\$ (Brightness)
- button *Each press of the button will adjust the
- brightness level. 4 UP/ → (Rotate) button 11 Power switch ON/ 5 MODE/ **■** (Stop) button
- 6 SEL.(Select) / ▶II (Play/ 12 Wall-mounting

Attaching the Stand (Figure 2)

- Insert the round end of the stand into the receptacle
- 2. Rotate the stand to the direction as shown in Figure until it is fixed tightly in position. Note: The unit can be placed horizontally or vertically for a landscape or portrait display

Mounting the Photo Frame on Wall (Figure 3)

- Remove the stand from the unit
- 2. Place the mounting holes of the unit on the wall screws (not supplied) as shown in Figure.
- Note: Take care when installing it. It may cause damage or serious injury should it fall from its mountings.

Connecting to the Power (Figure 4)

- 1. Connect one end of the supplied AC adapter (DC5V/1.5A) to the unit, and the other end to the wall outlet.
- 2. Switch the power on (to the position "I") to turn 2. Press UP or DOWN button to select "Clock & on the unit.

Removing and Installing the Changeable Frame (Figure 5)

A.Removing the Changeable Frame Release all the hooks in the edge of the changeable frame by pulling up the changeable

frame using your fingers.

- **B.Installing the Changeable Frame** 1. Hold the changeable frame and place it on the
- 2. Press the changeable frame for all the hooks to be fixed in place. Now the changeable frame is installed

successfully

Inserting a Memory Card or a USB Flash Drive (Figure 6)

- This unit can play only JPEG format.
- 1. Insert your memory card into the memory card slot according to the orientation marked on the back of the unit.

Caution: Do not insert "Memory Stick Duo" or "Memory Stick Pro Duo" into the unit. In case of using them, be sure to attach "Memory Stick Adapter" in order not to have a trouble to remove it from the unit.

2. Insert a USB flash drive to the USB port. Note: This unit can display photos in either a memory card or a USB flash drive at a time. If a USB flash drive and a SD/MMC/ MS/xD card are inserted in the unit at the same time, files in the USB flash drive will be displayed. If you want to display files in a SD/MMC/MS/xD card, remove the USB flash drive from the unit.

Viewing Photos and Slide Shows (Figure 7)

Note: Displaying photos bigger than 480 x 234 pixels will take longer time for loading.

- 1. Press LEFT or RIGHT button to select on "Photo" in the main menu, then press SEL./ >II button to confirm.
- 2. The slideshow starts
- 3. To pause the slideshow, press SEL./ ▶॥ button. Press SEL./ ▶ u button again to restart the

A. Thumbnail Mode

- Press MODE/ button during the slideshow to enter Thumbnail mode.
- 2. Press LEFT or RIGHT button to select the photo you wish to play, then press SEL./ ▶II button

Note: If the thumbnail has more than one page, move the cursor to the last photo and press RIGHT/ ▶ button to go to the next page. Move the cursor to the first photo and press LEFT/ ◄ button to return to the previous page

3. The slideshow starts with the photo selected. Note 1: Refer to Setup Menu in this user guide for the slideshow settings.

Note 2: Press MODE/ ■ button again to return to the main menu.

B. Rotation

Auto Rotation

- In the initial setting of the unit, Auto Rotation is set to ON in Setup menu. Landscape or portrait display of a photo will be automatically switched according to the unit orientation. If the horizontally placed unit is rotated left by 90 degrees, the photo will automatically rotate by 90 degrees clockwise. If the vertically placed unit is rotated right by 90 degrees, the photo will automatically rotate by 90 degrees counterclockwise.
- Note 1: When the unit is placed horizontally, Auto Rotation only works by rotating the unit to left by 90 degrees. Rotating the unit to right will not have any response. When the unit is placed vertically, Auto Rotation only works by rotating the unit to right by 90 degrees. Rotating the unit to left will not have any response

Note 2: The photo will be scaled down to an appropriate size to fit in the height or width of the unit if the photo orientation is different from its original one.

Manual Rotation

• Press LEFT or RIGHT button to select the photo you wish to rotate in the slideshow, then press UP/ & button to rotate by 90 degrees clockwise

Note 1: Each press of UP/ → button will rotate the photo by 90 degrees clockwise.

Note 2: Manual Rotation can be also set in the Thumbnail mode.

Note 3: All the rotation effects will be cancelled when returning to the main menu.

Clock & Calendar Setting (Figure 8)

Once power is switched off, the set time and calendar will be reset, because there is no battery back up in this unit.

A. Viewing the Clock & Calendar

- 1. Press LEFT or RIGHT button to select "Clock & Calendar" in the main menu and press SEL./ ▶II button.
- 2. Pressing SEL./ ▶II button will switch between Clock, Calendar and photos of a memory card.
- 3. Press MODE/ button again to return to the

B. Setting Clock & Calendar

- 1. Press LEFT or RIGHT button to select 📆 "Setup" in the main menu, then press SEL./ ▶II
- Calendar" and then press SEL./ ▶॥ button. Setting the Time
- 3. Press UP or DOWN button to select "Set The Time", and press SEL./ ▶

 ■ button, then "Set Time" window will appear on the screen. 4. Press LEFT or RIGHT button to select Hour,
- Minute, Second or AM/PM and set the time by pressing UP or DOWN button. 5. Press LEFT or RIGHT button to select "OK"

and press SEL./ ▶॥ button to set it. Setting the Date

- 3. Press UP or DOWN button to select "Set The Date", and press SEL./ ▶" button, then "Set Date" window will appear on the screen.
- 4. Press LEFT or RIGHT button to select Year, Month or Day and set the calendar by pressing UP or DOWN button. 5. Press LEFT or RIGHT button to select "OK"
- and press SEL./▶" button to set it. 6. To leave the Setup menu. press MODE/■
- button again

Editing Files in the Internal Memory (Figure 9)

A. Copying Photos from a Memory Card or a USB Flash Drive

- 1. Press LEFT or RIGHT button to select 同 "Edit" in the main menu, and press SEL./ ▶॥ button. Then "Edit Dialog" window will appear. 2. Press LEFT or RIGHT button to select "Copy",
- then press SEL./ ▶II button to enter the 3. Press UP or DOWN button to select a file, then
- press SEL./ ▶II button to select photos you wish to copy. Note 1: Press SEL./ ▶॥ button on the selected
- folder to enter the Sub-menu. Note 2: To deselect the file, press SEL./ ▶II button again on the selected file.
- Note 3: Repeat the above step 3 to select some files and the selected files will be highlighted. Note 4: The internal memory can store about 45
- photos in case each photo is less than 32 megapixels. 4. Press RIGHT button and then LEFT button to
- select "Save", then press SEL./ ▶॥ button. 5. The file is now saved in the internal memory
- 6. To exit Edit mode, press LEFT or RIGHT button to select "Exit", then press SEL./ ▶□ button.

B. Deleting Photos in the Internal Memory

- 1. Press LEFT or RIGHT button to select (a) "Edit" in the main menu, and press SEL./ ▶II button.
- Then Edit Dialog window will appear. 2 Press RIGHT button to select "Delete" then
- press SEL./ ▶" button to enter the Edit mode. 3. Press LEFT or RIGHT button to select a photoand press DOWN button to select "Delete", then press SEL./ ▶II button to delete it. Press UP button to deselect "Delete"
- Note 1: To delete all, press DOWN button and press RIGHT button to select "Delete All", then press SEL./ ▶II button. Press UP button to deselect "Delete All".
- Note 2: Press MODE / button to return to the main menu.

Viewing Files in the Internal Memory (Figure 10)

- 1. Press LEFT or RIGHT button to select 🖲 "Favorites" in the main menu, then press SEL./
- 2. The slideshow will start from the internal
- 3. Press MODE / button to enter the Thumbnail
- 4. Press LEFT or RIGHT button to select the photo you wish to play, then press SEL./ ▶II
- 5. The slideshow starts with the photo selected.

Setup Menu

- 1 Press MODE/ button to enter the main menu.
- 2. Press LEFT or RIGHT button to select [[7]] "SETUP" in the main menu, then press SEL./ ▶॥
- 3. Press UP or DOWN button to select an item in the Setup menu, and press SEL./ ▶" or RIGHT button to go to the Sub menus as shown in the
- 4. Press UP or DOWN button to select a setting, then press SEL./ ▶II to set it.
- 5. To leave Setup menu, press MODE / button

12 Hours, 1 Day No Effect, Random, Cover Up, Cover Down, Uncover Left, Push Right,				
No Effect, Random, Cover Up, Cover Down, Uncover Left, Push Right,				
No Effect, Random, Cover Up, Cover Down, Uncover Left, Push Right,				
Cover Up, Cover Down, Uncover Left, Push Right,				
Jncover Left, Push Right,				
•				
Nipe Up, Wipe Down				
12H , 24H				
Set The Time				
Set The Date				
4, -3, -2, -1, 0, +1, +2, +3, +4				
English, French, German, Italian, Spanish, Portuguese,				
				Outch, Polish
				Full Screen, Original*
On , Off				
Confirm**				

Select "Original" to display photos in their original aspect ratios. Black bands appear on left and right sides of the screen in landscape view, or top and bottom of the screen in portrait view. Select "Full Screen" to display photos in

7" colour TFT LCD panel

the above table.)

View Area	480 X 234 pixels, 16:9 aspect		
	ratio		
Brightness	150 cd/m ²		
Contrast	150:1		
Stand	Detachable		
Memory Card Slot	SD/SDHC/MMC/MS/MS Pro/		
	xD		
I/O Ports	DC-in / USB 2.0 port		
Internal Memory	About 45 photos can		
	be stored (in case each		
	photo is less than 32		
	megapixels).		
Supported File	JPEG (up to approx. 144		
Format	megapixels)		
AC Adapter	Input: 100-240V ~50/60Hz		
	0.4A		
	Output: 5V / 1.5A		
Dimensions	Approx.		
	206 x 139 x 33 mm		
	(W x H x D)		
	(Without Detachable Stand		
	and Changeable Frame)		
Weight	Approx.		
	337g		
	(Without Detachable Stand		
	and Changeable Frame)		
Accessories	AC adapter		
	Detachable stand		
	White changeable frame		
	(Attached to the unit)		
	User Guide		
	6 bonus static stickers		

Troubleshooting

No power

• Check if the AC adapter is plugged into the wall

outlet Make sure there is power to the wall outlet

Unable to view photos

- This unit is designed to show photos in standard JPEG format following the camera industry standard. Some images in non-standard JPEG format such as web images, scanned images or photos in RAW format taken by professional cameras cannot be displayed in the unit correctly. Please use PC applications to convert such images into standard JPEG format.
- · Check if using compatible memory cards.

If photo display is slow

• Use lower resolution photo.

Notes

Selecting Reset will restore the initial settings. (The initial settings are marked by squares in

Specifications

Display

For EU users only

Your SANYO product is designed and manufactured with high quality materials and components which can be recycled and reused. This symbol means that electrical and electronic equipment, at their end-of-life, should be disposed of separately from your household waste. Please dispose of this equipment at your local community waste collection/ recycling centre. In the European Union there are separate collection systems for used electrical and electronic products. Please help us to conserve the environment we live in!



Manufacturer and Address SANYO Electric Co., Ltd. 5-5, Keihan-hondori, 2-chome, Moriguchi City Osaka, Japan

Authorized Representative and Address SANYO FISHER Sales(Europe) GmbH Stahlgruberring 4,D-81829 Munich, Germany

Trademark Information

SD™ is a trademark.

