

eMachines G630/G430 Service Guide

Service guide files and updates are available on the ACER/CSD web; for more information, please refer to <http://csd.acer.com.tw>

PRINTED IN TAIWAN

Revision History

Please refer to the table below for the updates made on eMachines G630/G430 service guides.

Date	Chapter	Updates

Copyright

Copyright © 2009 by Acer Incorporated. All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of Acer Incorporated.

Disclaimer

The information in this guide is subject to change without notice.

Acer Incorporated makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties of merchantability or fitness for any particular purpose. Any Acer Incorporated software described in this manual is sold or licensed "as is". Should the programs prove defective following their purchase, the buyer (and not Acer Incorporated, its distributor, or its dealer) assumes the entire cost of all necessary servicing, repair, and any incidental or consequential damages resulting from any defect in the software.

Acer is a registered trademark of Acer Corporation.

Intel is a registered trademark of Intel Corporation.

Other brand and product names are trademarks and/or registered trademarks of their respective holders.

Conventions

The following conventions are used in this manual:

SCREEN MESSAGES	Denotes actual messages that appear on screen.
NOTE	Gives bits and pieces of additional information related to the current topic.
WARNING	Alerts you to any damage that might result from doing or not doing specific actions.
CAUTION	Gives precautionary measures to avoid possible hardware or software problems.
IMPORTANT	Reminds you to do specific actions relevant to the accomplishment of procedures.

Preface

Before using this information and the product it supports, please read the following general information.

1. This Service Guide provides you with all technical information relating to the BASIC CONFIGURATION decided for Acer's "global" product offering. To better fit local market requirements and enhance product competitiveness, your regional office MAY have decided to extend the functionality of a machine (e.g. add-on card, modem, or extra memory capability). These LOCALIZED FEATURES will NOT be covered in this generic service guide. In such cases, please contact your regional offices or the responsible personnel/channel to provide you with further technical details.
2. Please note WHEN ORDERING FRU PARTS, that you should check the most up-to-date information available on your regional web or channel. If, for whatever reason, a part number change is made, it will not be noted in the printed Service Guide. For ACER-AUTHORIZED SERVICE PROVIDERS, your Acer office may have a DIFFERENT part number code to those given in the FRU list of this printed Service Guide. You MUST use the list provided by your regional Acer office to order FRU parts for repair and service of customer machines.

System Specifications	1
Features	1
System Block Diagram	3
Your Acer Notebook tour	4
Front View	4
Closed Front View	5
Rear View	6
Left View	6
Right View	7
Bottom View	7
Indicators	9
TouchPad Basics	10
Using the Keyboard	11
Lock Keys and embedded numeric keypad	11
Windows Keys	12
Hot Keys	13
Special Key	14
Hardware Specifications and Configurations	15
 System Utilities	 21
BIOS Setup Utility	21
Navigating the BIOS Utility	21
eMachines G630/G430 BIOS	22
Information	22
Main	23
Security	24
Boot	27
Exit	28
BIOS Flash Utilities	29
DOS Flash Utility	30
WinFlash Utility	31
Remove HDD/BIOS Password Utilities	32
 Machine Disassembly and Replacement	 37
Disassembly Requirements	37
Pre-disassembly Instructions	38
Disassembly Process	38
External Module Disassembly Process	39
External Modules Disassembly Flowchart	39
Removing the Battery Pack	40
Removing the SD Dummy Card	41
Removing the Lower Covers	42
Removing the Optical Drive Module	43
Removing the DIMM Modules	45
Removing the WLAN Module	46
Removing the Hard Disk Drive Module	48
Main Unit Disassembly Process	50
Main Unit Disassembly Flowchart	50
Removing the Switch Cover	51
Removing the Keyboard	52
Removing the LCD Module	53
Removing the Upper Cover	57
Removing the Power Board	61
Removing the Left Speaker Module	62

Table of Contents

Removing the Right Speaker Module	64
Removing the TouchPad Bracket	66
Removing the Mainboard	68
Removing the RTC Battery	69
Removing the Thermal Module	70
Removing the CPU Fan	72
Removing the CPU	74
LCD Module Disassembly Process	75
LCD Module Disassembly Flowchart	75
Removing the LCD Bezel	76
Removing the Camera Module	77
Removing the LCD Panel	78
Removing the LCD Brackets and FPC Cable	80
Removing the Antennas	82
LCD Module Reassembly Procedure	85
Replacing the Antennas	85
Replacing the LCD Panel	88
Replacing the Camera Module	90
Replacing the LCD Bezel	91
Main Module Reassembly Procedure	93
Replacing the CPU	93
Replacing the CPU Fan	94
Replacing the Thermal Module	94
Replacing the Mainboard	95
Replacing the TouchPad Bracket	96
Replacing the Right Speaker Module	98
Replacing the Left Speaker Module	99
Replacing the Power Board	100
Replacing the Upper Cover	100
Replacing the LCD Module	104
Replacing the Keyboard	109
Replacing the Switch Cover	110
Replacing the Hard Disk Drive Module	110
Replacing the WLAN Module	112
Replacing the DIMM Modules	112
Replacing the ODD Module	113
Replacing the Lower Covers	113
Replacing the SD Dummy Card	114
Replacing the Battery	115

Troubleshooting

117

Common Problems	117
Power On Issue	118
No Display Issue	119
Random Loss of BIOS Settings	120
LCD Failure	121
Built-In Keyboard Failure	121
TouchPad Failure	122
Internal Speaker Failure	122
HDD Not Operating Correctly	124
ODD Failure	125
Wireless Function Failure	128
Thermal Unit Failure	128
External Mouse Failure	129
Other Failures	129

Table of Contents

Intermittent Problems	130
Undetermined Problems	130
Post Codes	131
Jumper and Connector Locations	137
Top View	137
Bottom View	138
Power Board	139
ODD Board	139
Battery Board	140
Lid Board	140
Clearing Password Check and BIOS Recovery	141
Clearing Password Check	141
Clear CMOS Jumper	141
BIOS Recovery by Crisis Disk	142
FRU (Field Replaceable Unit) List	143
eMachines G630/G430 Exploded Diagrams	144
Main Assembly	144
Base Assembly	146
Rear Assembly	147
eMachines G630/G430 FRU List	148
Model Definition and Configuration	156
eMachines G430	156
eMachines G630G	157
eMachines G630	166
Test Compatible Components	177
Microsoft® Windows® 7 Environment Test	178
Online Support Information	183

Table of Contents

System Specifications

Features

Below is a brief summary of the computer's many features:

Operating System

- Genuine Windows® 7™

Platform

- AMD Turion™ II dual-core processor*
- AMD Athlon™ 64 II dual-core processor*
- AMD Sempron™ processor*
- AMD M880G Chipset

System Memory

- Dual-channel support
- Up to 2 GB of DDR2 667 MHz memory, upgradeable to 4 GB using two soDIMM modules

Display

- 17.3" HD+ 1600 x 900
- 16:9 aspect ratio

Graphics

- ATI Mobility Radeon™ HD 4570*
- ATI Mobility Radeon™ HD 4200*

Storage subsystem

- 2.5" hard disk drive
- DVD-Super Multi double-layer drive
- Multi-in-1 card reader

Audio

- Two built-in stereo speakers
- High-definition audio support
- MS-Sound compatible

Dimensions and Weight

- 410.5 (W) x 268 (D) x 26.8/39.6 (H) mm (16 x 10.45 x 1.04/1.54 inches)

-
- 3.30 kg (7.29 lbs.) with 6-cell battery pack

Communication

- Integrated webcam*
- WLAN:
 - 802.11b/g
- LAN:
 - Fast Ethernet; Wake-on-LAN ready

Privacy control

- BIOS user, supervisor, HDD passwords
- Kensington lock slot

Power subsystem

- ACPI 3.0
- 48.8 W 4400 mAh PES-certified battery
- 3-pin 65 W AC adapter*
- 3-pin 90 W AC adapter*
- ENERGY STAR®*

Special keys and controls

- 99-/100-/103-key keyboard
- Touchpad pointing device


I/O interface

- Multi-in-1 card reader
- USB 2.0 ports
- External display (VGA) port
- Headphones/speaker/line-out jacks
- Microphone-in jack
- Ethernet (RJ-45) port
- DC-in jack for AC adapter

Environment


- Temperature:
 - Operating: 5 °C to 35 °C
 - Non-operating: -20 °C to 65 °C
- Humidity (non-condensing):
 - Operating: 20% to 80%
 - Non-operating: 20% to 80%




System Block Diagram






Your Acer Notebook tour

Front View






No.	Icon	Item	Description
1		Acer Crystal Eye webcam	Web camera for video communication (for selected models).
2		Display screen	Also called Liquid-Crystal Display (LCD), displays computer output.
3		Touchpad toggle	Turns the internal touchpad on and off.
		Power button	Turns the computer on and off.
		Wireless LAN communication button/indicator	Enables/disables the wireless LAN function. Indicates the status of wireless LAN communication.
4		Speakers	Left and right speakers deliver stereo audio output.
5		Keyboard	For entering data into your computer.
6		TouchPad	Touch-sensitive pointing device which functions like a computer mouse.

No.	Icon	Item	Description
7		Click buttons (left and right)	The left and right buttons function like the left and right mouse buttons.
8		Palmrest	Comfortable support area for your hands when you use the computer.
9		HDD	Indicates when the hard disk drive is active.
		Num Lock	Lights up when Num Lock is activated.
		Caps Lock	Lights up when Caps Lock is activated.

Closed Front View



No.	Icon	Item	Description
1		Power ¹	Indicates the computer's power status.
		Battery ¹	Indicates the computer's battery status. 1. Charging: The light shows amber when the battery is charging. 2. Fully charged: The light shows green when in AC mode.
2		Multi-in-1 card reader	Accepts: Secure Digital (SD), MultiMediaCard (MMC), Memory Stick (MS), Memory Stick PRO (MS PRO), xD-Picture Card (xD). NOTE: Push to remove/install the card. Only one card can operate at any given time.


NOTE: ¹ The front panel indicators are visible even when the computer cover is closed







Rear View



No.	Icon	Item	Description
1		Ventilation slots	Enable the computer to stay cool, even after prolonged use.



Left View




No.	Icon	Item	Description
1		DC-in jack	Connects to an AC adapter
2		Ethernet (RJ-45) port	Connects to an Ethernet 10/100-based network.
2		External display (VGA) port	Connects to a display device (e.g. external monitor, LCD projector).
4		USB 2.0 ports	Connect to USB 2.0 devices (e.g. USB mouse, USB camera).
5		Microphone-in jack	Accepts input from external microphones.
		Headphones/speaker/line-out jack	Connects to audio line-out devices (e.g. speakers, headphones).



Right View





No.	Item	Description	
1		Optical drive	Internal optical drive; accepts CDs or DVDs.
2		Optical disk access indicator	Lights up when the optical drive is active.
3		Optical drive eject button	Ejects the optical disk from the drive.
4		Emergency eject hole	Ejects the optical drive tray when the computer is turned off. Note: Insert a paper clip into the emergency eject hole to eject the optical drive tray when the computer is off.
5		Kensington lock slot 	Connects to a Kensington-compatible computer security lock. Note: Wrap the computer security lock cable around an immovable object such as a table or handle of a locked drawer. Insert the lock into the notch and turn the key to secure the lock. Some keyless models are also available.

Bottom View








No.	Icon	Item	Description
1		Battery bay	Houses the computer's battery pack.
2		Battery release latch	Releases the battery for removal.
3		Battery lock	Locks the battery in position.

No.	Icon	Item	Description
4		Hard disk bay	Houses the computer's hard disk (secured with screws).
5		Memory compartment	Houses the computer's main memory.
5		Ventilation slots and cooling fan	Enable the computer to stay cool, even after prolonged use. Note: Do not cover or obstruct the fan opening.


Indicators

The computer has several easy-to-read status indicators. The front panel indicators are visible even when the computer cover is closed.

Icon	Function	Description
	Power	Indicates the computer's power status.
	Battery	Indicates the computer's battery status. Charging: The light shows amber when the battery is charging. Fully charged: The light shows green when in AC mode.
	HDD	Indicates when the hard disk drive is active.
	Num Lock	Lights up when Num Lock is activated.
	Caps Lock	Lights up when Caps Lock is activated.

TouchPad Basics

The following items show you how to use the TouchPad:



- Move your finger across the TouchPad (1) to move the cursor.
- Press the left (2) and right (3) buttons located beneath the TouchPad to perform selection and execution functions. These two buttons are similar to the left and right buttons on a mouse. Tapping on the TouchPad is the same as clicking the left button.

Function	Left Button (2)	Right Button (3)	Main TouchPad (1)
Execute	Quickly click twice.		Tap twice (at the same speed as double-clicking a mouse button).
Select	Click once.		Tap once.
Drag	Click and hold, then use finger on the TouchPad to drag the cursor.		Tap twice (at the same speed as double-clicking a mouse button); rest your finger on the TouchPad on the second tap and drag the cursor.
Access context menu		Click once.	

NOTE: When using the TouchPad, keep it - and your fingers - dry and clean. The TouchPad is sensitive to finger movement; hence, the lighter the touch, the better the response. Tapping too hard will not increase the TouchPad's responsiveness.

Using the Keyboard

The keyboard has full-sized keys and an embedded numeric keypad, separate cursor, lock, Windows, function and special keys.

Lock Keys and embedded numeric keypad

The keyboard has three lock keys which you can toggle on and off.






















Lock key	Description
Caps Lock	When Caps Lock is on, all alphabetic characters typed are in uppercase.
Num Lock <Fn> + <F11>	When Num Lock is on, the embedded keypad is in numeric mode. The keys function as a calculator (complete with the arithmetic operators +, -, *, and /). Use this mode when you need to do a lot of numeric data entry. A better solution would be to connect an external keypad.
Scroll Lock <Fn> + <F12>	When Scroll Lock is on, the screen moves one line up or down when you press the up or down arrow keys respectively. Scroll Lock does not work with some applications.

The embedded numeric keypad functions like a desktop numeric keypad. It is indicated by small characters located on the upper right corner of the keycaps. To simplify the keyboard legend, cursor-control key symbols are not printed on the keys.

Desired access	Num Lock on	Num Lock off
Number keys on embedded keypad	Type numbers in a normal manner.	
Cursor-control keys on embedded keypad	Hold <Shift> while using cursor-control keys.	Hold <Fn> while using cursor-control keys.
Main keyboard keys	Hold <Fn> while typing letters on embedded keypad.	Type the letters in a normal manner.

Windows Keys

The keyboard has two keys that perform Windows-specific functions.

Key	Description
 Windows key	<p>Pressed alone, this key has the same effect as clicking on the Windows Start button; it launches the Start menu. It can also be used with other keys to provide a variety of functions:</p> <ul style="list-style-type: none"> <  >: Open or close the Start menu <  > + <D>: Display the desktop <  > + <E>: Open Windows Explore <  > + <F>: Search for a file or folder <  > + <G>: Cycle through Sidebar gadgets <  > + <L>: Lock your computer (if you are connected to a network domain), or switch users (if you're not connected to a network domain) <  > + <M>: Minimizes all windows <  > + <R>: Open the Run dialog box <  > + <T>: Cycle through programs on the taskbar <  > + <U>: Open Ease of Access Center <  > + <X>: Open Windows Mobility Center <  > + <BREAK>: Display the System Properties dialog box <  > + <SHIFT+M>: Restore minimized windows to the desktop <  > + <TAB>: Cycle through programs on the taskbar by using Windows Flip 3-D <  > + <SPACEBAR>: Bring all gadgets to the front and select Windows Sidebar <CTRL> + <  > + <F>: Search for computers (if you are on a network) <CTRL> + <  > + <TAB>: Use the arrow keys to cycle through programs on the taskbar by using Windows Flip 3-D <p>Note: Depending on your edition of Windows 7, some shortcuts may not function as described.</p>
 Application key	<p>This key has the same effect as clicking the right mouse button; it opens the application's context menu.</p>

Hot Keys

The computer employs hotkeys or key combinations to access most of the computer's controls like screen brightness, volume output and the BIOS utility.

To activate hot keys, press and hold the <Fn> key before pressing the other key in the hotkey combination.



Hotkey	Icon	Function	Description
<Fn> + <F4>		Sleep	Puts the computer in Sleep mode.
<Fn> + <F5>		Display toggle	Switches display output between the display screen, external monitor (if connected) and both.
<Fn> + <F6>		Screen blank	Turns the display screen backlight off to save power. Press any key to return.
<Fn> + <F8>		Speaker toggle	Turns the speakers on and off.
<Fn> + <Δ>		Volume up	Increases the sound volume.
<Fn> + <▽>		Volume down	Decreases the sound volume.
<Fn> + <▷>		Brightness up	Increases the screen brightness.
<Fn> + <◁>		Brightness down	Decreases the screen brightness.

Special Key

You can locate the Euro symbol and the US dollar sign at the upper-center and/or bottom-right of your keyboard.



The Euro symbol

1. Open a text editor or word processor.
2. Hold <Alt Gr> and then press the <5> key at the upper-center of the keyboard.

NOTE: Note: Some fonts and software do not support the Euro symbol. Please refer to www.microsoft.com/typography/faq/faq12.htm for more information.

The US dollar sign

1. Open a text editor or word processor.
2. Hold <Shift> and then press the <4> key at the upper-center of the keyboard.

NOTE: This function varies by the operating system version.

Hardware Specifications and Configurations

Processor

Item	Specification
CPU	<ul style="list-style-type: none"> • AMD Turion™ II dual-core processor • AMD Athlon™ 64 II dual-core processor • AMD Sempron™ processor
Core Logic	<ul style="list-style-type: none"> • AMD M880G Chipset • ATI Mobility Radeon™ HD 4570 • ENE KB926 D3 for Keyboard Controller, Battery management Unit, and RTC • Integrated VGA solution for RS880M
CPU Package	<ul style="list-style-type: none"> • Micro uPGA-638 Package

Processor Specifications

Item	CPU Speed	Cores	Bus Speed	Mfg Tech	Cache Size	Package	Core Voltage	Acer P/N
AAM300	2.0GHz	2	N/A	N/A	1MB	N/A	35W	KC.AM002.300
ATM500	2.2GHz	2	N/A	N/A	1MB	N/A	35W	KC.TM002.500
ATM520	2.3GHz	2	N/A	N/A	1MB	N/A	35W	KC.TM002.520
SMPM100	2.0 GHz	N/A	N/A	N/A	512K	N/A	25W	KC.SM002.100

CPU Fan True Value Table

Step	Action	Trip Point (Diode)		
		Low Limit	High Limit	Therm# (Thermal Sensor)
c. Thermal Policy	Fan Off	-	55	P1
Step 1	Fan Speed1	50	60	P2
Step 1	Fan Speed2	55	65	P3
Step 2	Fan Speed3	60	75	P4
Step 3	Fan Speed4	65	85	P5
Step 4	Fan Speed5	75	95	
Step 5	Throttling 50%	80	100	
EC Shutdown				

Step	Action	Fan			CPU Cut Frequency	SPL Spec (dBA)
		Fan Speed (RPM)	Fan Voltage (V)	Fan Current (I)		
c. Thermal Policy	Fan Off	0	---	---	0%	-
Step 1	Fan Speed1	2900	TBD	TBD	0%	28
Step 1	Fan Speed2	3200	TBD	TBD	0%	31
Step 2	Fan Speed3	3500	TBD	TBD	0%	34
Step 3	Fan Speed4	3900	TBD	TBD	0%	37
Step 4	Fan Speed5	4300	TBD	TBD	0%	40
Step 5	Throttling 50%	4300	TBD	TBD	50%	40
EC Shutdown						

Northbridge

Item	Specification
Chipset	AMDRS880M
Features	HDCP EEPROM

Southbridge

Item	Specification
Chipset	AMD SB710
Features	N/A

BIOS

Item	Specification
BIOS vendor	Phoenix BIOS
BIOS Version	V0.11T04
BIOS ROM type	Flash
Features	<ul style="list-style-type: none">Flash ROM 1MBSupports ISIPPSupports Acer UISupports multi-bootSuspend to RAM (S3)/Disk (S4)Various hot-keys for system controlSupports SMBUS 2.0, PCI2.3ACPI 2.0 compliance with Intel Speed Step support C1, C2, C3, C4 and S3, S4 for mobile CPUDMI utility for BIOS serial number configurable/asset tagSupports PXESupports Y2K solutionSupports Win Flash Wake on LAN from S3Wake on LAN form S4 in AC modeSystem information

System Memory

Item	Specification
Memory controller	AMDRS880M + AMD SB710
Memory size	4GB maximum
DIMM socket number	2
Supports memory size per socket	2GB
Supports maximum memory size	4GB (total)
Supports DIMM type	200-pin +1.8V DDRII
Supports DIMM Speed	667/800 MHz
Supports DIMM voltage	1.8V
Cache	Upto 1MB L2 Cache on CPU

Memory Combinations

Slot 1	Slot 2	Total Memory
0MB	512MB	512MB
0MB	1024MB	1024MB
0MB	2048MB	2048MB
512MB	512MB	1024MB
512MB	1024MB	1536MB
512MB	2048MB	2560MB
1024MB	0MB	1024MB
1024MB	512MB	1536MB
1024MB	1024MB	2048MB
1024MB	2048MB	3072MB
2048MB	0MB	2048MB
2048MB	512MB	2560MB
2048MB	1024MB	3072MB
2048MB	2048MB	4096MB

NOTE: Above table lists some system memory configurations. You may combine DIMMs with various capacities to form other combinations. On above table, the configuration of slot 1 and slot 2 could be reversed.

LAN Interface

Item	Specification
LAN Chipset	AR8132L
Package	48pin QFN (6 x 6 mm)
LAN connector type	RJ-45
Feature	Support10/100
Interface	PCI Express bus

Wireless Module 802.11b/g

Item	Specification
Manufacturer	<ul style="list-style-type: none"> Foxconn FOX_ATH_XB63 Foxconn Atheros XB63 minicard b/g Liteon Wireless LAN Reltek RTL8191SE (WN6605LH) (1x1)
Model	Atheros xb63 Reltek RTL8191SE
IEEE Standard	b/g N/A

Hard Disk Drive Interface

Item	Specification			
Vendor & Model Name	SEAGATE	TOSHIBA	WD	HGST
Capacity (MB)	500, 250	320, 250, 160	500, 320, 250, 160	160, 250, 320, 500
Bytes per sector	512	512	512	512
Data heads	4, 2	4, 2, 2	4, 4, 3, 2	N/A
Drive Format				
Disks	2, 1	2, 1, 1	2, 2, 2, 1	
Spindle speed (RPM)	5400	5400	5400	5400
Performance Specifications				

Item	Specification			
Buffer size	8 MB	8 MB	8 MB	
Interface	SATA	SATA	SATA	SATA
Internal transfer rate (Mbits/sec, max)	N/A	395~952 (typical)	850 Mbits/s maximum	N/A
I/O data transfer rate (Mbytes/sec max)	N/A	300	300 maximum	N/A
DC Power Requirements				
Voltage tolerance	5V ±5%	5V ±5%	5V ±5%	5V ±5%

Super-Multi Drive

Item	Specification			
Vendor & model name	HLDS GT20N		Sony AD7580S	
Performance Specification	With CD Diskette	With DVD Diskette	With CD Diskette	With DVD Diskette
Transfer rate (MB/sec)	Sustained: 3,600 KB/s (24x) max.	Sustained: 11.08 Mbytes/s (8x) max.	Sustained: 1,571 (typical)	Sustained: 10,993 (typical)
Buffer Memory	2 MB			
Interface	SATA			

Item	Specification	
Applicable disc formats	<ul style="list-style-type: none"> • DVD-ROM: <ul style="list-style-type: none"> • 4.7GB (Single Layer) • 8.5GB (Dual Layer) • DVD-R: <ul style="list-style-type: none"> • 3.95GB (Ver. 1.0: read only) • 4.7GB (Ver. 2.0 for Authoring: read only) • 4.7GB (Ver. 2.1 for General: read & write) • (DL) 8.5GB (Ver. 3.0) • DVD-RW: <ul style="list-style-type: none"> • 4.7GB (Ver. 1.2/ Rev 1.0, 2.0, 3.0) • DVD-RAM: 1.46GB/side, 4.7GB/side (Ver. 2.2) • DVD+R: 4.7GB (Ver. 1.3) <ul style="list-style-type: none"> • (DL) 8.5GB (Ver. 1.1) • DVD+RW: <ul style="list-style-type: none"> • 4.7GB (Vol.1 Ver.1.3) • CD-ROM Mode-1 data disc • CD-ROM Mode-2 data disc • CD-ROM XA, CD-I, Photo-CD Multi-Session, Video CD • CD-Audio Disc • Mixed mode CD-ROM disc (data and audio) • CD-Extra • CD-Text • CD-R (Conforming to "Orange Book Part 2": read & write) • CD-RW (Conforming to "Orange Book Part 3": read & write) 	<p>DVD Read:</p> <p>DVD-ROM (DVD-5, DVD-9, DVD-10, DVD-18), DVD-Video, DVD-Audio, SACD (Hybrid), UDF DVD, DVD-R, DVD-R DL, DVD-R 3.95 GB, DVD-R Authoring, DVD-R Multi-Border, DVD-RW, DVD+R, DVD+R DL, DVD+R Multi-Session, DVD+RW, DVD-RAM V1.0, DVDRAM V2.0 & 2.1 & 2.2.</p> <p>CD Read:</p> <p>CD-DA, CD-ROM Mode-1, CD-ROM/XA Mode-2 Form-1 and Mode-2 Form-2, CD-i, CD-i Bridge, Video-CD (MPEG-1), Karaoke CD, Photo-CD, Enhanced CD, CD Plus, CD Extra, itrax CD, CD-Text, UDF CD, CD-R, and CD-RW</p> <p>DVD Write:</p> <p>DVD Data & Video</p> <p>CD Read:</p> <p>CD-DA, CD-ROM Mode-1, CD-ROM/XA Mode-2 Form-1 and Mode-2 Form-2, CD-i, Video-CD, CD-Text</p>
Loading mechanism	<p>Drawer (Solenoid Open)</p> <p>Tact SW (Open)</p> <p>Emergency Release (draw open hole)</p>	
Power Requirement		
Input Voltage	DC 5 V +/- 5%	

Audio Interface

Item	Specification
Chipset	ALC272X
Package	48-pin LQFP 'Green'
Features	High Definition Audio Codec with Dolby Digital Live

Speakers

Item	Specification
Vendor and Model	Built-In
Dimensions	N/A
Weight	N/A
Nominal Impedance	40ohm
Power Rating	2W
Output Sound Pressure Level	N/A

Item	Specification
Frequency Range	N/A
Distortion	N/A

Microphone

Item	Specification
Vendor and Model	N/A
Directivity	N/A
Current Consumption	N/A
S/N Ratio	N/A
Frequency	N/A

Power and Keyboard Controller

Item	Specification
Controller	Keyboard eMACHINES EM-7T
Features	<ul style="list-style-type: none"> • Touchpad pointing device
Total number of keypads	99-/100-/103-key keyboard
Windows logo key	Yes
Hotkeys	See "Hot Keys" on page 13.

Battery

Item	Specification
	6 Cell
Vendor & model name	SANYO/SONY/PANASONIC/SIMPLO
Battery Type	Li-ion
Pack capacity	4400 mAh
Normal Voltage	2.2 Ah
Package configuration	3S2P

LCD 17.3"

Item	Specification
Vendor/model name	AUO/CMO/LPL/SAMSUNG
Features	N/A

Card Reader

Item	Specification
Part Name	5-in1 card reader
Supported Formats	MS, MS Pro, SD, SC, XD
Package	Built-in
General Features	<ul style="list-style-type: none"> • PCI-E interface • Push-push type • Dummy card

System Utilities

BIOS Setup Utility

The BIOS Setup Utility is a hardware configuration program built into your computer's BIOS (Basic Input/Output System).

Your computer is already properly configured and optimized, and you do not need to run this utility. However, if you encounter configuration problems, you may need to run Setup. Please also refer to Chapter 4 Troubleshooting when problem arises.

To activate the BIOS Utility, press **F2** during POST (when "Press <F2> to enter Setup" message is prompted on the bottom of screen).

Press **F2** to enter setup. The default parameter of F12 Boot Menu is set to "disabled". If you want to change boot device without entering BIOS Setup Utility, please set the parameter to "enabled".

Press <F12> during POST to enter multi-boot menu. In this menu, user can change boot device without entering BIOS SETUP Utility.

Navigating the BIOS Utility

There are six menu options: Information, Main, Advanced, Security, Boot, and Exit.

Follow these instructions:


- To choose a menu, use the left and right arrow keys.
- To choose an item, use the up and down arrow keys.
- To change the value of a parameter, press **F5** or **F6**.
- A plus sign (+) indicates the item has sub-items. Press **Enter** to expand this item.
- Press **Esc** while you are in any of the menu options to go to the Exit menu.
- In any menu, you can load default settings by pressing **F9**. You can also press **F10** to save any changes made and exit the BIOS Setup Utility.

NOTE: You can change the value of a parameter if it is enclosed in square brackets. Navigation keys for a particular menu are shown on the bottom of the screen. Help for parameters are found in the Item Specific Help part of the screen. Read this carefully when making changes to parameter values. **Please note that system information is subject to different models.**

eMachines G630/G430 BIOS

Information

The Information screen displays a summary of your computer hardware information.




NOTE: The screen above is for your reference only. Actual values may differ according to model.

The table below describes the parameters in this screen.

Parameter	Description
CPU Type	This field shows the CPU type and speed of the system.
CPU Speed	This field shows the speed of the CPU.
HDD Model Name	This field shows the model name of HDD installed on primary IDE master.
HDD Serial Number	This field displays the serial number of HDD installed on primary IDE master.
ATAPI Model Name	This field shows the model name of the Optical device installed in the system.
System BIOS Version	Displays system BIOS version.
VGA BIOS Version	This field displays the VGA firmware version of the system.
Serial Number	This field displays the serial number of this unit.
Asset Tag Number	This field displays the asset tag number of the system.
Product Name	This field shows product name of the system.
Manufacturer Name	This field displays the manufacturer of this system.
UUID Number	Universally Unique Identifier (UUID) is an identifier standard used in software construction, standardized by the Open Software Foundation (OSF) as part of the Distributed Computing Environment (DCE).

Main

The Main screen allows the user to set the system time and date as well as enable and disable boot option and recovery.




NOTE: The screen above is for your reference only. Actual values may differ.

The table below describes the parameters in this screen.

Parameter	Description	Format/Option
System Time	Sets the system time. The hours are displayed with 24-hour format.	Format: HH:MM:SS (hour:minute:second)
System Date	Sets the system date.	Format MM/DD/YYYY (month/day/year)
Total Memory	This field reports the Total Memory size.	N/A
Video Memory	This field shows the memory allocated for the video graphics.	N/A
Quiet Boot	Allows startup to skip certain tests while booting, decreasing the time needed to boot the system.	Option: Enabled or Disabled
Network Boot	Enables, disables the system boot from LAN (remote server).	Option: Enabled or Disabled
F12 Boot Menu	Enables, disables Boot Menu during POST.	Option: Enabled or Disabled
D2D Recovery	Enables, disables D2D Recovery function. The function allows the user to create a hidden partition on hard disc drive to store operation system and restore the system to factory defaults.	Option: Enabled or Disabled
SATA Mode	Control the mode in which the SATA controller should operate.	Option: AHCI or IDE

Security

The Security screen contains parameters that help safeguard and protect your computer from unauthorized use.



The table below describes the parameters in this screen. Settings in **boldface** are the default and suggested parameter settings.

Parameter	Description	Option
Supervisor Password Is	Shows the setting of the Supervisor password	Clear or Set
User Password Is	Shows the setting of the user password.	Clear or Set
SATA Port 0 Disk Status	Shows the setting of the SATA Port 0 Disk.	Clear or Set
SATA Port 1 Disk Status	Shows the setting of the SATA Port 1 Disk.	Clear or Set
Set Supervisor Password	Press Enter to set the supervisor password. When set, this password protects the BIOS Setup Utility from unauthorized access. The user can not either enter the Setup menu nor change the value of parameters.	N/A
Set User Password	Press Enter to set the user password. When user password is set, this password protects the BIOS Setup Utility from unauthorized access. The user can enter Setup menu only and does not have right to change the value of parameters.	N/A
Set SATA Port 0 HDD Password	Enter HDD Password.	N/A
Set SATA Port 1 HDD Password	Enter HDD Password.	N/A
Password on Boot	Defines whether a password is required or not while the events defined in this group happened. The following sub-options are all requires the Supervisor password for changes and should be grayed out if the user password was used to enter setup.	Disabled or Enabled


NOTE: When you are prompted to enter a password, you have three tries before the system halts. Don't forget

your password. If you forget your password, you may have to return your notebook computer to your dealer to reset it.

Setting a Password

Follow these steps as you set the user or the supervisor password:

1. Use the ↑ and ↓ keys to highlight the Set Supervisor Password parameter and press the **Enter** key. The Set Supervisor Password box appears:



The screenshot shows a blue-bordered box titled "Set Supervisor Password". Inside the box, there are two input fields: "Enter New Password" and "Confirm New Password". Both fields are currently empty, indicated by black rectangular boxes.

2. Type a password in the "Enter New Password" field. The password length can not exceed 8 alphanumeric characters (A-Z, a-z, 0-9, not case sensitive). Retype the password in the "Confirm New Password" field.

IMPORTANT: Be very careful when typing your password because the characters do not appear on the screen.

3. Press **Enter**. After setting the password, the computer sets the User Password parameter to "Set".
4. If desired, you can opt to enable the Password on boot parameter.
5. When you are done, press F10 to save the changes and exit the BIOS Setup Utility.

Removing a Password

Follow these steps:

1. Use the ↑ and ↓ keys to highlight the Set Supervisor Password parameter and press the **Enter** key. The Set Password box appears:



The screenshot shows a blue-bordered box titled "Set Supervisor Password". Inside the box, there are three input fields: "Enter Current Password", "Enter New Password", and "Confirm New Password". The "Enter Current Password" field is filled with a black rectangular box, while the other two fields are empty.

2. Type the current password in the Enter Current Password field and press **Enter**.
3. Press **Enter** twice **without** typing anything in the Enter New Password and Confirm New Password fields. The computer then sets the Supervisor Password parameter to "Clear".
4. When you have changed the settings, press u to save the changes and exit the BIOS Setup Utility.

Changing a Password


1. Use the ↑ and ↓ keys to highlight the Set Supervisor Password parameter and press the **Enter** key. The Set Password box appears.



The screenshot shows a blue-themed BIOS screen titled "Set Supervisor Password". It contains three input fields: "Enter Current Password", "Enter New Password", and "Confirm New Password". Each field is followed by a pair of square brackets [] representing the input area.

2. Type the current password in the Enter Current Password field and press **Enter**.
3. Type a password in the Enter New Password field. Retype the password in the Confirm New Password field.
4. Press **Enter**. After setting the password, the computer sets the User Password parameter to "Set".
5. If desired, you can enable the Password on boot parameter.
6. When you are done, press F10 to save the changes and exit the BIOS Setup Utility.

If the verification is OK, the screen will display the following message.



The screenshot shows a white BIOS screen titled "Setup Notice". The text "Changes have been saved." is displayed in the center. Below the text is a black button with the word "Continue" in white.

The password setting is complete after the user presses **Enter**.

If the current password entered does not match the actual current password, the screen will show you the Setup Warning.



The screenshot shows a white BIOS screen titled "Setup Warning" in red text. Below the title, the text "Invalid Password." is displayed in red. At the bottom, there is a black button with the word "Continue" in white.

If the new password and confirm new password strings do not match, the screen will display the following message.



The screenshot shows a white BIOS screen titled "Setup Warning" in red text. Below the title, the text "Passwords do not match. Re-enter password." is displayed in red. At the bottom, there is a black button with the word "Continue" in white.

Boot


This menu allows the user to decide the order of boot devices to load the operating system. Bootable devices includes the USB diskette drives, the onboard hard disk drive and the DVD drive in the module bay.

Select Boot Devices to select specific devices to support boot.

The screenshot shows the PhoenixBIOS Setup Utility interface. At the top, the title bar reads "PhoenixBIOS Setup Utility". Below it, a navigation bar contains the following tabs: "Information", "Main", "Security", "Boot" (which is highlighted), and "Exit". The main content area is split into two columns. The left column displays the "Boot priority order:" with a list of seven items: "1: IDE 0: HTS545016B9A300", "2: IDE 1:", "3: IDE 2:", "4: USB FDD:", "5: Network Boot:", "6: USB HDD:", and "7: USB CD/DVD ROM:". The seventh item is highlighted in red. The right column is titled "Item Specific Help" and contains the text: "Use <↑> or <↓> to select a device, then press <F6> to move it up the List, or <F5> to move it down the list. Press <Esc> to escape the menu." At the bottom of the screen, a blue bar contains the following keyboard shortcuts: "F1 Help", "↑↓ Select Item", "F5/F6 Change Values", "F9 Setup Defaults", "Esc Exit", "← Select Menu", "Enter Select", and "▶ Sub-Menu", "F10 Save and Exit".

Exit

The Exit screen allows you to save or discard any changes you made and quit the BIOS Utility.



The table below describes the parameters in this screen.

Parameter	Description
Exit Saving Changes	Exit System Setup and save your changes to CMOS.
Exit Discarding Changes	Exit utility without saving setup data to CMOS.
Load Setup Default	Load default values for all SETUP item.
Discard Changes	Load previous values from CMOS for all SETUP items.
Save Changes	Save Setup Data to CMOS.

BIOS Flash Utilities

The BIOS flash memory update is required for the following conditions:

- New versions of system programs
- New features or options
- Restore a BIOS when it becomes corrupted.

Use the Flash utility to update the system BIOS flash ROM.

NOTE: If you do not have a crisis recovery diskette at hand, then you should create a **Crisis Recovery Diskette** before you use the Flash utility.

NOTE: Do not install memory-related drivers (XMS, EMS, DPMI) when you use the Flash.

NOTE: Please use the AC adaptor power supply when you run the Flash utility. If the battery pack does not contain enough power to finish BIOS flash, you may not boot the system because the BIOS is not completely loaded.


Follow the steps below to run the Flash.

1. Prepare a bootable diskette.
2. Copy the flash utilities to the bootable diskette.
3. Then boot the system from the bootable diskette. The flash utility has auto-execution function.

DOS Flash Utility

Perform the following steps to use the DOS Flash Utility:

1. Press F2 during boot to enter the Setup Menu.
2. Select **Boot Menu** to modify the boot priority order, for example, if using USB HDD to Update BIOS, move USB HDD to position 1.




3. Execute the **FLASH.BAT** batch file to update BIOS in DOS mode.

The flash process begins as shown.



-
4. In flash BIOS, the message **Please do not remove AC Power Source** displays.



Plug in the AC power to continue.

5. Flash is complete when the message **Flash programming complete** displays.

WinFlash Utility

Perform the following steps to use the WinFlash Utility:


1. Double-click the WinFlash executable.
 2. Click **OK** to begin the update. WinFlash closes all applications and shuts down the system.
- NOTE:** Place only one *.wph file with flash32.exe in the same folder when executing this procedure.

Remove HDD/BIOS Password Utilities

This section provides you with details about removing HDD/BIOS password:

Remove HDD Password:

If you key in the wrong HDD password three times, an error is generated.



To reset the HDD password, perform the following steps:

1. An error code is generated for unlocking the HDD. Note down this code.



2. Execute the **UnlockHD.EXE** file to create the unlock code in DOS Mode using the format **UnlockHD [Encode code]** with the code noted in the previous step, as follows:

UnlockHD 76943488




3. Select 2 to obtain the password. This password which can be used for unlocking the HDD.

Password :46548274

4. Shut down the computer by pressing down the Power button for 4 seconds.
5. Turn on the computer and key in the password to unlock the HDD.

Removing BIOS Passwords:


To clear the User or Supervisor passwords through hardware, open the WLAN door and use a metal instrument to short the **J1** jumper.



Cleaning BIOS Passwords

To clean the User or Supervisor passwords using software utilities, perform the following steps:

1. From a DOS prompt, execute **clnpwd.exe**



2. Press **1** or **2** to clean the desired password shown on the screen.

The onscreen message determines whether the function is successful or not.



Using Boot Sequence Selector

The Boot Sequence Selector allows the boot order to be changed without accessing the BIOS. To use Boot Sequence Selector, perform the following steps:

1. Enter into DOS.
2. Execute **BS.exe** to display the usage screen.

```
d:\BOOTSEQ>bs
*** Boot Sequence Selector Version 0.03 ***
Create by Rockwell Chuang 10/01/2005.
Usage:
  BS [ 1 | 2 | 3 | 4 ]
BS 1 : [ Floppy ] => [ HardDisk ] => [ CD-ROM ] => [ LAN ]
BS 2 : [ HardDisk ] => [ CD-ROM ] => [ LAN ] => [ Floppy ]
BS 3 : [ CD-ROM ] => [ HardDisk ] => [ LAN ] => [ Floppy ]
BS 4 : [ LAN ] => [ Floppy ] => [ HardDisk ] => [ CD-ROM ]
d:\BOOTSEQ>
```

3. Select the desired boot sequence by entering the corresponding sequence. For example, enter **BS2** to change the boot sequence to HDD | CD ROM | LAN | Floppy.

Using DMI Tools

The DMI (Desktop Management Interface) Tool copies BIOS information to EEPROM to be used in the DMI pool for hardware management.

When the BIOS displays **Verifying DMI pool data** it is checking that the table correlates with the hardware before sending to the operating system (Windows, etc.).

To update the DMI Pool, perform the following steps:

1. Boot into DOS.
2. Execute **dmitools**. The following messages report to screen to confirm completion:
 - `dmitools /r ==>` Read dmi string from bios
 - `dmitools /wm xxxx ==>` Write manufacturer name to eeprom (max. 16 characters)
 - `dmitools /wp xxxx ==>` Write product name to eeprom (max. 16 characters)
 - `dmitools /ws xxxx ==>` Write serial number to eeprom (max. 22 characters)
 - `dmitools /wu xxxx ==>` Write uuid to eeprom
 - `dmitools /wa xxxx ==>` Write asset tag to eeprom (max. 32 characters)

The following examples show the commands and the corresponding output information.

Read DMI Information from Memory

Input:

```
dmitools /r
```

Output:

```
Manufacturer (Type1, Offset04h): Acer
Product Name (Type1, Offset05h): TravelMate xxxxx
Serial Number (Type1, Offset07h): 01234567890123456789
UUID String (Type1, Offset08h): xxxxxxxx-xxxx-xxxx-xxxx-xxxxxxxxxxxxx
Asset Tag (Type3, Offset04h): Acet Asstag
```

Write Product Name to EEPROM

Input:

```
dmitools /wp Acer
```

Write Serial Number to EEPROM

Input:

```
dmitools /ws 01234567890123456789
```

4). Write UUID to EEPROM (Create UUID from Intel WFM20.pdf)

Input:

```
dmitools /wu
```

5). Write Asset Tag to EEPROM

Input:

```
dmitools /wa Acer Asstag
```

NOTE: When using any of the Write options, restart the system to make the new DMI data effective.

Using the LAN MAC EEPROM Utility

You can use the MAC.BAT utility to write the MAC.CFG file to the EEPROM under DOS mode.


1. Use a text editor (for example: Notepad) to open the MAC.CFG file. You can see the MAC.CFG contents as below:



```
MAC.CFG - 記事本
檔案(F) 編輯(E) 格式(O) 檢視(V) 說明(H)
Title= MAC Address byte
WriteData='001122334455'
StartAddr=7A
WriteLeng=6
KeepByte=0
```

WriteData = '001122334455'	MAC value
StartAddr=7A	MAC address
WriteLeng=6	MAC value length
KeepByte=0	don't care

2. In DOS mode, run the **MAC.BAT** file to write MAC values to eeprom.



```
C:\MAC>mac.bat
C:\MAC>eeprom w MAC.cfg
Progress --> \
Write Data to EEPROM OK!!
```

Machine Disassembly and Replacement

IMPORTANT: The outside housing and color may vary from the mass produced model.

This chapter contains step-by-step procedures on how to disassemble the notebook computer for maintenance and troubleshooting.

Disassembly Requirements

To disassemble the computer, you need the following tools:

- Wrist grounding strap and conductive mat for preventing electrostatic discharge
- Flat screwdriver
- Philips screwdriver
- Plastic flat screwdriver
- Plastic tweezers

NOTE: The screws for the different components vary in size. During the disassembly process, group the screws with the corresponding components to avoid mismatch when putting back the components.

Pre-disassembly Instructions

Before proceeding with the disassembly procedure, make sure that you do the following:

1. Turn off the power to the system and all peripherals.
2. Unplug the AC adapter and all power and signal cables from the system.



3. Place the system on a flat, stable surface.
4. Remove the battery pack.

Disassembly Process

IMPORTANT: The LCD Module cannot be disassembled outside of factory conditions. If any part of the LCD Module is faulty, such as the camera, antenna or LCD panel, the whole module must be replaced.

The disassembly process is divided into the following stages:

- External module disassembly
- Main unit disassembly
- LCD module disassembly

The flowcharts provided in the succeeding disassembly sections illustrate the entire disassembly sequence. Observe the order of the sequence to avoid damage to any of the hardware components. For example, if you want to remove the mainboard, you must first remove the keyboard, then disassemble the inside assembly frame in that order.

Main Screw List


Screw	Quantity	Part Number
SCREW M2.5*4	1	86.N3702.001
SCREW M2.5*6	10	86.N3702.002
SCREW M2.5*8	30	86.N3702.003
SCREW M2*3	17	86.N3702.004
SCREW M3*3	4	86.N3702.006

External Module Disassembly Process

IMPORTANT: The outside housing and color may vary from the mass produced model.

External Modules Disassembly Flowchart

The flowchart below gives you a graphic representation of the external module disassembly sequence and instructs you on the components that need to be removed during servicing. For example, if you want to remove the keyboard, you must first remove the switch board.



Screw List


Step	Screw	Quantity	Part No.
Lower Covers	M2.5*8	3	86.N3702.003
ODD Module	M2.5*8	1	86.N3702.003
WLAN Module	M2*3	2	86.N3702.004
HDD Carrier	M3*3	4	86.N3702.006

Removing the Battery Pack

1. Turn the computer over. Slide the battery lock in the direction shown.



2. Slide and hold the battery release latch to the release position (1), then lift out the battery pack from the main unit (2).



Removing the SD Dummy Card

1. Push the SD dummy card all the way in to eject it.




2. Pull it out from the slot.



Removing the Lower Covers

1. See "Removing the Battery Pack" on page 40.
2. Remove the three (3) screws securing the Memory and HDD Covers.



Step	Size	Quantity	Screw Type
Lower Covers	M2.5*8	3	

3. Remove the HDD cover as shown.




4. Carefully open the Memory Cover.




Removing the Optical Drive Module

1. See "Removing the Battery Pack" on page 40.
2. Remove the screw securing the ODD module.




Step	Size	Quantity	Screw Type
ODD Module	M2.5*8	1	

3. Insert a suitable tool into the access slot in the battery bay as shown. Gently lever the ODD module out of the chassis.
4. Pull the optical drive module out from the chassis.



5. Remove the two (2) screws securing the ODD bracket and remove the ODD bracket from the optical disk drive module.




Step	Size	Quantity	Screw Type
ODD Bracket	M2*3	2	

6. Remove the ODD bezel by rotating the top edge downward and pulling it clear of the module.




Removing the DIMM Modules

1. See “Removing the Lower Covers” on page 42.
2. Push out the release latches on both sides of the DIMM socket to release the DIMM module.




3. Remove the DIMM module.



4. Repeat steps for the second DIMM module if present.

Removing the WLAN Module

1. See "Removing the Lower Covers" on page 42.
2. Remove the adhesive tape securing the Antenna cables in place.




3. Disconnect the antenna cables from the WLAN Board.



NOTE: Cable placement is **Black** to the **MAIN** terminal (upper) and **White** to the **AUX** terminal (lower).

4. Move the antenna away and remove the two (2) screws to release the WLAN Board.



Step	Size	Quantity	Screw Type
WLAN Module	M2*3	2	


5. Detach the WLAN Board from the WLAN socket.



NOTE: When reattaching the antennas, ensure the cables are tucked into the chassis to prevent damage.

Removing the Hard Disk Drive Module

1. See “Removing the Lower Covers” on page 42.
2. Using the pull-tab, slide the HDD Module in the direction of the arrow to disconnect the interface.




3. Lift the HDD Module clear of the HDD bay.



NOTE: To prevent damage to device, avoid pressing down on it or placing heavy objects on top of it.

4. Remove the four (4) screws (two each side) securing the hard disk to the carrier.




Step	Size	Quantity	Screw Type
HDD Carrier	M3*3	4	

5. Remove the HDD from the carrier.



Main Unit Disassembly Process

Main Unit Disassembly Flowchart



Screw List

Step	Screw	Quantity	Part No.
LCD Module	M2.5*8	2	86.N3702.003
LCD Module	M2.5*8	4	86.N3702.003
Upper Cover	M2.5*8	11	86.N3702.003
Upper Cover	M2.5*8	9	86.N3702.003
Power Board	M2*3	2	86.N3702.004
Left Speaker Module	M2*3	1	86.N3702.004
Right Speaker Module	M2*3	1	86.N3702.004
TouchPad Bracket	M2*3	2	86.N3702.004
Mainboard	M2.5*4	1	86.N3702.001
Thermal Module	M2.5*6	4	86.N3702.002
CPU Fan	M2*3	3	86.N3702.004

Removing the Switch Cover

CAUTION: Using metal tools to remove the Switch Cover may cause damage to the outer casing. The use of plastic tools or fingers is recommended to remove the Switch Cover.

1. See “Removing the Battery Pack” on page 40.
2. Turn the computer over. Press down the / and * keys on the right side of the Keyboard to expose the cutout. Insert a suitable plastic tool (or finger) and pry the Switch Cover upward, away from the Upper Cover.



3. Work along the Switch Cover toward the left hinge, gently prying up the cover as shown.



4. Lift the Switch Cover clear of the computer.



Removing the Keyboard


1. See "Removing the Switch Cover" on page 51.
2. Pry up the centre of the Keyboard and rotate it upward away from the Upper Cover.



3. Turn the keyboard over on to the TouchPad area to expose the FFC connector.



4. Open the locking latch and disconnect the FFC from the mainboard.




5. Lift the keyboard clear of the Upper Cover.


Removing the LCD Module

1. See "Removing the Keyboard" on page 52.
2. Turn the computer over. Remove the two (2) securing screws from the bottom of the chassis.



Step	Size	Quantity	Screw Type
LCD Module	M2.5*8	2	



3. Remove the Antenna Cables from the cable channel as shown. Ensure that the cables are free from all cable clips.





4. Stand the computer on the LCD Panel and pull the Antenna cables completely through the chassis.




5. Disconnect the LCD cable from the Mainboard and remove the cable from the cable channel.




6. Remove the white Antenna cable from the cable channel. Ensure that the cable is completely free of the retaining clips all the way to the hinge well.



7. Remove the adhesive tape securing the Antenna cable to the Upper Cover.



8. Remove the black Antenna cable from the cable channel as shown. Ensure that the cable is completely free of the retaining clips all the way to the hinge well.




9. Open the LCD Panel to the full extent to expose the Hinge Covers.


10. Press the left side Hinge Cover inward, as shown, and lift to remove the cover from the chassis.




11. Repeat the process for the right side Hinge Cover.

12. Remove the four (4) securing screws (two each side) from the LCD module.




Step	Size	Quantity	Screw Type
LCD Module	M2.5*8	4	

13. Remove the left and right screw covers from on top of the hinges





14. Lift the LCD Module clear of the Upper Cover.




Removing the Upper Cover

1. See "Removing the LCD Module" on page 53.
2. Turn the computer over. Remove the eleven (11) screws on the bottom panel.




Step	Size	Quantity	Screw Type
Upper Cover	M2.5*8	11	


3. Turn the computer over. Remove the three (3) screw caps at the rear of the Upper Cover as shown.




4. Disconnect the following four (4) cables from the Mainboard.





5. Disconnect **A** as shown.




6. Disconnect **C** as shown.



7. Release the locking latch on **B** and remove the FFC cable as shown.




8. Release the locking latch on **D** and remove the FFC cable as shown.




NOTE: Avoid pulling on cables directly to prevent damage to the connectors.


NOTE: Use the pull-tabs on FFCs whenever available to prevent damage.

9. Remove the nine (9) screws on the top panel.




Step	Size	Quantity	Screw Type
Upper Cover	M2.5*8	9	

10. Starting at the rear left side of the cover, pry apart the Upper and Lower Covers as shown. Work along the back edge of the casing to the right as shown, then lift the Upper Cover clear of the Lower Cover.





Removing the Power Board

1. See "Removing the Upper Cover" on page 57.
2. Locate the Power Board on the Upper Cover as shown.




3. Remove the two (2) screws securing the Power Board to the Upper Cover.




Step	Size	Quantity	Screw Type
Power Board	M2*3	2	

4. Lift the Power Board clear of the Upper Cover as shown.




Removing the Left Speaker Module


1. See "Removing the Upper Cover" on page 57.
2. Locate the Left Speaker Module on the Upper Cover as shown.




3. Remove the adhesive tape from the Speaker cable.




4. Remove the Speaker cable from the cable channel. Ensure that the cable is free from all cable clips.




5. Remove the single securing screw from the Left Speaker Module.




Step	Size	Quantity	Screw Type
Left Speaker Module	M2*3	1	

6. Lift the Speaker clear of the Upper Cover, left side first as shown.




Removing the Right Speaker Module


1. See "Removing the Upper Cover" on page 57.
2. Locate the Right Speaker Module on the Upper Cover as shown.



3. Turn the Upper Cover over and remove the Right Speaker Module cable from the cable channel. Ensure that the cable is free from all cable clips.




4. Turn the Upper Cover over and pass the cable through the cover as shown.




5. Remove the single securing screw from the Right Speaker Module.



Step	Size	Quantity	Screw Type
Right Speaker Module	M2*3	1	


6. Lift the Speaker clear of the Upper Cover, right side first as shown.




Removing the TouchPad Bracket

IMPORTANT: The TouchPad Board cannot be removed individually. To replace the TouchPad Board, replace the entire Upper Cover.


1. See “Removing the Upper Cover” on page 57.
2. Lift the FFC to detach the adhesive securing the cable to the Upper Cover.




3. Release the FFC locking latch and disconnect the TouchPad FFC from the cover.




4. Remove the two (2) screws from TouchPad bracket.




Step	Size	Quantity	Screw Type
TouchPad Bracket	M2*3	2	


5. Lift the rear edge of the TouchPad bracket first to clear the securing clips and remove it as shown.




Removing the Mainboard

- 1. See "Removing the Upper Cover" on page 57.
- 2. Remove the single securing screw from the Mainboard.



Step	Size	Quantity	Screw Type
Mainboard	M2.5*4	1	

- 3. Lift the mainboard from the chassis, right edge first, and place it on a clean, dust-free surface.



Removing the RTC Battery

IMPORTANT: Follow local regulations for disposal of all batteries.

The RTC Battery is soldered to the Mainboard. To replace the battery, solder the new battery to the connections shown.




Removing the Thermal Module

1. See "Removing the Lower Covers" on page 42.
2. Turn the Mainboard over to access the Thermal Module.




3. Remove the four (4) securing screws (in reverse numerical order from screw 4 to screw 1) from the Thermal Module.



Step	Size	Quantity	Screw Type
Thermal Module	M2.5*6	4	

4. Using both hands, lift the Thermal Module clear of the Mainboard.





Removing the CPU Fan

- 1. See "Removing the Thermal Module" on page 70.
- 2. Disconnect the Fan cable from the Mainboard as shown.



- 3. Remove the three (3) securing screws from the Fan Module.



Step	Size	Quantity	Screw Type
CPU Fan	M2*3	3	

4. Lift the CPU Fan clear of the Mainboard as shown.




Removing the CPU

IMPORTANT: The pins on the underside of the CPU are very delicate. If they are damaged, the CPU may malfunction. Place the CPU on a clean, dry surface when it is not installed.

1. See “Removing the Thermal Module” on page 70.
2. Using a flat-bladed screw driver, rotate the CPU locking screw 180° counter-clockwise as shown.




3. Lift the CPU clear of the socket as shown.



LCD Module Disassembly Process

LCD Module Disassembly Flowchart




Screw List

Step	Screw	Quantity	Part No.
LCD Bezel	M2.5*6	4	86.N3702.002
LCD Panel	M2.5*6	2	86.N3702.002
LCD Brackets	M2*3	6	86.N3702.004

Removing the LCD Bezel

- 1. See "Removing the LCD Module" on page 53.
- 2. Remove the two (2) upper and two (2) lower bezel screw caps and screws.



Step	Size	Quantity	Screw Type
LCD Bezel	M2.5*6	4	

- 3. Starting from the bottom edge of the bezel, pry the bezel upwards and away from the panel. Work along the right side toward the top of the bezel, prying the covers apart. Continue along the top edge and down the left side to remove the bezel.

NOTE: If necessary, use a pry to lift up the outside edges of the bezel.




Removing the Camera Module

1. See "Removing the LCD Bezel" on page 76.
2. Locate the Camera Module at the top of the LCD Module and disconnect the camera cable.




3. Remove the Camera from the module.




Removing the LCD Panel

- 1. See "Removing the Camera Module" on page 77.
- 2. Remove the two (2) securing screws from the LCD Panel.




Step	Size	Quantity	Screw Type
LCD Panel	M2.5*6	2	

- 3. Remove the adhesive strip holding the cables in place.



- 4. Remove the Camera cable cluster from the LCD Module as shown.





5. Lift the LCD Panel clear of the module.




Removing the LCD Brackets and FPC Cable

- 1. See "Removing the LCD Panel" on page 78.
- 2. Remove the six (6) securing screws (three on each side) from the LCD Panel brackets.




Step	Size	Quantity	Screw Type
LCD Brackets	M2*3	6	


- 3. Remove the LCD brackets by pulling away from the LCD Panel.




4. Turn the LCD panel over to expose the rear. Lift the adhesive protector and disconnect the cable from the LCD Panel.



5. Lift the cable as shown to disengage the adhesive strip securing it in place.



6. Lift the FPC cable to disengage the remaining adhesive and remove the cable from the panel.




Removing the Antennas

1. See "Removing the LCD Panel" on page 78.
2. Remove the adhesive strips holding the left antenna cable in place. Ensure the cable is free from obstructions.




3. Remove the cable from the cable channel. Ensure that the cable is free from all cable clips and adhesive strips.




4. Remove the adhesive tape securing the left Antenna to the LCD Module.



5. Lift the left Antenna clear of the cover.



6. Remove the adhesive strips holding the right antenna cable in place. Ensure the cable is free from obstructions.




7. Remove the cable from the cable channel. Ensure that the cable is free from all cable clips and adhesive strips.



8. Remove the adhesive tape securing the right Antenna to the LCD Module.




9. Lift the right Antenna clear of the cover.




LCD Module Reassembly Procedure

Replacing the Antennas


1. Replace the right Antenna as shown. Ensure that the locating pins on the Antenna are correctly seated.




2. Replace the adhesive strip to secure the Antenna in place.
3. Run the cable down the side of the LCD Module using all available clips and adhesive.



4. Run the cable along the cable channel as shown, using all available cable clips.




5. Replace the left Antenna as shown. Ensure that the locating pins on the Antenna are correctly seated.



6. Replace the adhesive strip to secure the Antenna in place.

7. Run the cable down the side of the LCD Module using all available clips and adhesive.



8. Run the cable along the cable channel as shown, using all available cable clips and adhesive.



9. The Antennas and cables appear as shown when correctly installed.





Replacing the LCD Panel


1. Connect the LCD cable to the panel connector as shown.
2. Press down the adhesive strip to secure the cable in place.



3. Run the cable along the back of the panel and press down as indicated to secure the cable in place.
4. Run the cable across the back of the panel as shown and press down as indicated to secure the cable in place.



IMPORTANT: Ensure that the LCD cable runs between the green callouts to avoid trapping when the panel is replaced in the LCD Module.




5. Align the LCD brackets with the screw holes on the panel. Replace the six (6) screws (three on each side) in the brackets as shown.




6. Place the LCD Panel in the LCD Module, top edge first, and secure the LCD cable with adhesive tape.

IMPORTANT: Ensure that the LCD power cable passes through the hinge well and is not trapped under the panel.



7. Replace the Camera cable cluster in the LCD Module.




8. Secure the LCD module with the two (2) securing screws.



Replacing the Camera Module

1. Place the camera in the LCD Module.



2. Connect the cable to the camera module.



Replacing the LCD Bezel

1. Replace the bezel and press down until there are no gaps between the bezel and the LCD Module.

IMPORTANT: Ensure that the LCD cables pass through the hinge wells and are not trapped by the bezel.



2. Replace the four (4) screws and screw caps provided.




Main Module Reassembly Procedure


Replacing the CPU

IMPORTANT: The CPU has a Pin1 locator that must be positioned corresponding to the marker on the CPU socket.

1. Place the CPU into the CPU socket as shown, taking note of the Pin1 locator.



2. Using a flat-bladed screw driver, rotate the CPU locking screw 180° clockwise to secure the CPU in place.




Replacing the CPU Fan

1. Align the screw holes on the CPU Fan and Mainboard and replace the Fan.



2. Replace the three (3) screws to secure the Fan to the Mainboard.



3. Connect the Fan power cable to the Mainboard connector.



Replacing the Thermal Module

IMPORTANT: Apply a suitable thermal grease and ensure all heat pads are in place before replacing the Thermal Module.

The following thermal grease types are approved for use:


- Silmore GP50
- Honeywell
- Jet Motor 7762

The following thermal pads are approved for use:

- Eapus XR-PE


1. Remove all traces of thermal grease from the CPU using a lint-free cloth or cotton swab and Isopropyl Alcohol, Acetone, or other approved cleaning agent.
2. Apply a small amount of thermal grease to the centre of the CPU—there is no need to spread the grease manually, the force used during the installation of the Thermal Module is sufficient.

- Align the screw holes on the Thermal Module and Mainboard then replace the module. Keep the module as level as possible to spread the thermal grease evenly.
- Replace the four (4) securing screws (in numerical order from screw 1 to screw 4) to secure the Thermal Module in place.



Replacing the Mainboard

- Ensure that the Mainboard is face up (the CPU is not visible). Place the Mainboard in the casing, left edge first (1), then rotate it downward into position (2).





NOTE: Ensure the I/O ports are positioned correctly through the casing.

- Replace the single securing screw in the mainboard.




Replacing the TouchPad Bracket



1. Replace the TouchPad bracket top edge first to engage the securing clips.
2. Press the bracket down to engage the securing clips.




3. Replace the two (2) screws to secure the TouchPad Bracket to the Upper Cover.



4. Replace the TouchPad FFC and close the locking latch on the connector.



5. Replace the FFC and press down as indicated to secure it to the Upper Cover.





Replacing the Right Speaker Module

1. Place the module left side first on the Upper Cover as shown. Ensure that the left side of the module is seated correctly in the securing clip.
2. Replace the single screw to secure the module in place.



3. Pass the cable through the Upper Cover as shown.
4. Turn the Upper Cover over and run the cable along the cable channel using all available cable clips.





5. The cable runs as shown when correctly installed.





Replacing the Left Speaker Module


1. Place the module right side first on the Upper Cover as shown. Ensure that the right side of the module is seated correctly in the securing clip.
2. Replace the single screw to secure the module in place.



3. Run the cable along the cable channel using all available cable clips.



4. Secure the cable in place with adhesive tape.





5. The cable runs as shown when correctly installed.




Replacing the Power Board


1. Slide the Power Board in to the Upper Cover front edge first to engage the securing clip.



2. Press the board down to locate the securing pin.



3. Replace the two (2) screws to secure the board to the Upper Cover.



Replacing the Upper Cover

1. Place the Upper Cover on the Lower Cover as shown.




2. Press down around the edges to secure it in place.




3. Replace the nine (9) screws in the Upper Cover as shown.




4. Replace the three (3) screw caps as shown.




5. Connect the following cables to the Mainboard.





6. Connect A as shown.




7. Connect C as shown.




8. Connect B and close the locking latch to secure the cable in place.



9. Connect D and close the locking latch to secure the cable in place.




10. Turn the computer over and replace the eleven (11) screws as shown.




Replacing the LCD Module


1. Align the screw holes on the LCD Module and Upper Cover and replace the LCD Module.
2. The left and right screw covers are shaped differently. Ensure that the correct cover is used.



3. Replace the left screw cover as shown. Ensure that the securing tab on the rear of the cover is seated correctly in the Upper Cover.



4. Replace the right screw cover as shown. Ensure that the securing tab on the rear of the cover is seated correctly in the Upper Cover.




5. Replace the four (4) screws securing the LCD Module to the Upper Cover.




6. Ensure that the Hinge Covers are replaced correctly. Identify the rear edge of the covers by the two (2) securing clips.

7. Align the left Hinge Cover as shown and press down to replace the cover.




8. Repeat the process for the right side Hinge Cover.



9. Run the black Antenna cable along the cable channel as shown using all available retaining clips.




10. Replace the adhesive strip to secure the cable in place.




11. Run the white Antenna cable along the cable channel as shown using all available retaining clips.



12. Run the LCD cable along the cable channel using all available cable clips.



13. Connect the LCD cable to the Mainboard as shown.




14. Stand the computer on the LCD Panel and pass the Antenna cables through the chassis.



15. The Upper Cover appears as shown when the Antenna and LCD cables are correctly installed.



16. Turn the computer over. Run the Antenna cables along the cable channel as shown, using all available cable clips.





17. Replace the two (2) screws securing the LCD Module to the Lower Cover.



Replacing the Keyboard

1. Connect the Keyboard FFC to the Mainboard and close the locking latch to secure the cable in place.



2. Turn the Keyboard over and insert it front edge first into the chassis.
3. Press down as indicated to secure the Keyboard in place.

NOTE: Ensure that the six (6) locating tabs are correctly seated.



Replacing the Switch Cover

1. Place the Switch Cover left side first on to the Upper Cover.





2. Press down as indicated to snap the Switch Cover into place.



Replacing the Hard Disk Drive Module


1. Place the HDD in the HDD carrier.
2. Replace the four (4) screws (two each side) to secure the carrier.



3. Insert the HDD, as indicated and lower it into place.



4. Slide the HDD in the direction of the arrow to connect the interface.




Replacing the WLAN Module

1. Insert the WLAN Module into the WLAN socket.
2. Replace the two (2) screws to secure the module.





3. Connect the two (2) Antenna cables to the module.
NOTE: The black cable connects to the upper terminal (MAIN) and the white cable to the lower terminal (MAIN).
4. After connecting the cables to the terminals, secure the cables in place with adhesive tape to avoid trapping.



Replacing the DIMM Modules

1. Insert the DIMM Module in place.
2. Press down to lock the DIMM module in place.




3. Repeat steps for the second DIMM module if present.

Replacing the ODD Module

1. Press the bezel into the tray, bottom edge first, to secure it to the ODD Module.
2. Secure the ODD bracket with the two (2) screws.



3. Push the ODD Module into the ODD bay until it is flush with the casing.
4. Replace the single screw to secure the Module.



Replacing the Lower Covers

1. Replace the Memory Cover as shown.
2. Replace the HDD Cover as shown.



IMPORTANT: Press down around the perimeter of the covers to ensure that all the securing tabs are correctly located in the casing.

-
3. Replace the three (3) screws to secure the covers in place.




Replacing the SD Dummy Card

1. Insert the SD Dummy Card into the slot as shown.
2. Push until the card clicks into place and is flush with the casing.



Replacing the Battery

1. Slide and hold the battery release latch to the release position (1), insert the battery pack and press down (2).



2. Slide the battery lock in the direction shown to secure the battery in place.



Troubleshooting

Common Problems

Use the following procedure as a guide for computer problems.

NOTE: The diagnostic tests are intended to test only Acer products. Non-Acer products, prototype cards, or modified options can give false errors and invalid system responses.


1. Obtain the failing symptoms in as much detail as possible.
2. Verify the symptoms by attempting to re-create the failure by running the diagnostic test or by repeating the same operation.
3. Use the following table with the verified symptom to determine which page to go to.

Symptoms (Verified)	Go To
Power On Issue	Page 118
No Display Issue	Page 119
LCD Failure	Page 121
Internal Keyboard Failure	Page 121
TouchPad Failure	Page 122
Internal Speaker Failure	Page 122
ODD Failure	Page 125
WLAN Failure	Page 128
Thermal Unit Failure	Page 128
Other Functions Failure	Page 129
Intermittent Failures	Page 130
Undermined Failures	Page 130

4. If the Issue is still not resolved, see "Online Support Information" on page 183.

Power On Issue

If the system doesn't power on, perform the following actions one at a time to correct the problem. Do not replace a non-defective FRUs:




Computer Shutdown Intermittently

If the system powers off at intervals, perform the following actions one at a time to correct the problem.

1. Check the power cable is properly connected to the computer and the electrical outlet.
2. Remove any extension cables between the computer and the outlet.
3. Remove any surge protectors between the computer and the electrical outlet. Plug the computer directly into a known good electrical outlet.
4. Disconnect the power and open the casing to check the Thermal Unit (see "Thermal Unit Failure" on page 128) and fan airways are free of obstructions.
5. Remove all external and non-essential hardware connected to the computer that are not necessary to boot the computer to the failure point.
6. Remove any recently installed software.
7. If the Issue is still not resolved, see "Online Support Information" on page 183.

No Display Issue

If the **Display** doesn't work, perform the following actions one at a time to correct the problem. Do not replace a non-defective FRUs:



No POST or Video

If the POST or video doesn't display, perform the following actions one at a time to correct the problem.

1. Make sure that the internal display is selected. On this notebook model, switching between the internal display and the external display is done by pressing **Fn+F5**. Reference Product pages for specific model procedures.
2. Make sure the computer has power by checking at least one of the following occurs:
 - Fans start up
 - Status LEDs light up

If there is no power, see "Power On Issue" on page 118.

3. Drain any stored power by removing the power cable and battery and holding down the power button for 10 seconds. Reconnect the power and reboot the computer.
4. Connect an external monitor to the computer and switch between the internal display and the external display is by pressing **Fn+F5** (on this model).

If the POST or video appears on the external display, see "LCD Failure" on page 121.

5. Disconnect power and all external devices including port replicators or docking stations. Remove any memory cards and CD/DVD discs. Restart the computer.

If the computer boots correctly, add the devices one by one until the failure point is discovered.

6. Reseat the memory modules.
7. Remove the drives (see "Disassembly Process" on page 38).
8. If the Issue is still not resolved, see "Online Support Information" on page 183.

Abnormal Video Display

If video displays abnormally, perform the following actions one at a time to correct the problem.

1. Reboot the computer.
2. If permanent vertical/horizontal lines or dark spots display in the same location, the LCD is faulty and should be replaced. See “Disassembly Process” on page 38.
3. If extensive pixel damage is present (different colored spots in the same locations on the screen), the LCD is faulty and should be replaced. See “Disassembly Process” on page 38.
4. Adjust the brightness to its highest level. See the User Manual for instructions on adjusting settings.
NOTE: Ensure that the computer is not running on battery alone as this may reduce display brightness.
If the display is too dim at the highest brightness setting, the LCD is faulty and should be replaced. See “Disassembly Process” on page 38.
5. Check the display resolution is correctly configured:
 - a. Minimize or close all Windows.
 - b. If display size is only abnormal in an application, check the view settings and control/mouse wheel zoom feature in the application.
 - c. If desktop display resolution is not normal, right-click on the desktop and select **Personalize**→ **Display Settings**.
 - d. Click and drag the Resolution slider to the desired resolution.
 - e. Click **Apply** and check the display. Readjust if necessary.
6. Roll back the video driver to the previous version if updated.
7. Remove and reinstall the video driver.
8. Check the Device Manager to determine that:
 - The device is properly installed. There are no red Xs or yellow exclamation marks.
 - There are no device conflicts.
 - No hardware is listed under Other Devices.
9. If the Issue is still not resolved, see “Online Support Information” on page 183.
10. Run the Windows Memory Diagnostic from the operating system DVD and follow the onscreen prompts.
11. If the Issue is still not resolved, see “Online Support Information” on page 183.


Random Loss of BIOS Settings

If the computer is experiencing intermittent loss of BIOS information, perform the following actions one at a time to correct the problem.

1. If the computer is more than one year old, replace the CMOS battery.
2. Run a complete virus scan using up-to-date software to ensure the computer is virus free.
3. If the computer is experiencing HDD or ODD BIOS information loss, disconnect and reconnect the power and data cables between devices.
If the BIOS settings are still lost, replace the cables.
4. If HDD information is missing from the BIOS, the drive may be defective and should be replaced.
5. Replace the Motherboard.
6. If the Issue is still not resolved, see “Online Support Information” on page 183.


LCD Failure

If the **LCD** fails, perform the following actions one at a time to correct the problem. Do not replace a non-defective FRUs:




Built-In Keyboard Failure

If the built-in **Keyboard** fails, perform the following actions one at a time to correct the problem. Do not replace a non-defective FRUs:




TouchPad Failure

If the **TouchPad** doesn't work, perform the following actions one at a time to correct the problem. Do not replace a non-defective FRUs:



Internal Speaker Failure

If the internal **Speakers** fail, perform the following actions one at a time to correct the problem. Do not replace a non-defective FRUs:



Sound Problems

If sound problems are experienced, perform the following actions one at a time to correct the problem.

1. Reboot the computer.
2. Navigate to **Start**→ **Control Panel**→ **System and Maintenance**→ **System**→ **Device Manager**. Check the Device Manager to determine that:
 - The device is properly installed.
 - There are no red Xs or yellow exclamation marks.
 - There are no device conflicts.
 - No hardware is listed under Other Devices.
3. Roll back the audio driver to the previous version, if updated recently.
4. Remove and reinstall the audio driver.
5. Ensure that all volume controls are set mid range:
 - a. Click the volume icon on the taskbar and drag the slider to 50. Ensure that the volume is not muted.
 - b. Click Mixer to verify that other audio applications are set to 50 and not muted.
6. Navigate to **Start**→ **Control Panel**→ **Hardware and Sound**→ **Sound**. Ensure that Speakers are selected as the default audio device (green check mark).

NOTE: If Speakers does not show, right-click on the **Playback** tab and select **Show Disabled Devices** (clear by default).
7. Select Speakers and click **Configure** to start **Speaker Setup**. Follow the onscreen prompts to configure the speakers.
8. Remove and recently installed hardware or software.
9. Restore system and file settings from a known good date using **System Restore**.

If the issue is not fixed, repeat the preceding steps and select an earlier time and date.
10. Reinstall the Operating System.
11. If the Issue is still not resolved, see “Online Support Information” on page 183.

Microphone Problems

If internal or external **Microphones** do not operate correctly, perform the following actions one at a time to correct the problem.

1. Check that the microphone is enabled. Navigate to **Start**→ **Control Panel**→ **Hardware and Sound**→ **Sound** and select the **Recording** tab.
2. Right-click on the **Recording** tab and select **Show Disabled Devices** (clear by default).
3. The microphone appears on the **Recording** tab.
4. Right-click on the microphone and select **Enable**.
5. Select the microphone then click **Properties**. Select the **Levels** tab.
6. Increase the volume to the maximum setting and click **OK**.
7. Test the microphone hardware:
 - a. Select the microphone and click **Configure**.
 - b. Select **Set up microphone**.
 - c. Select the microphone type from the list and click **Next**.
 - d. Follow the onscreen prompts to complete the test.
8. If the Issue is still not resolved, see “Online Support Information” on page 183.

HDD Not Operating Correctly

If the **HDD** does not operate correctly, perform the following actions one at a time to correct the problem.

1. Disconnect all external devices.
2. Run a complete virus scan using up-to-date software to ensure the computer is virus free.
3. Run the Windows 7 Startup Repair Utility:
 - a. insert the Windows 7 Operating System DVD in the ODD and restart the computer.
 - b. When prompted, press any key to start to the operating system DVD.
 - c. The **Install Windows** screen displays. Click **Next**.
 - d. Select **Repair your computer**.
 - e. The **System Recovery Options** screen displays. Click **Next**.
 - f. Select the appropriate operating system, and click **Next**.

NOTE: Click **Load Drivers** if controller drives are required.

- g. Select **Startup Repair**.
- h. Startup Repair attempts to locate and resolve issues with the computer.
- i. When complete, click **Finish**.


If an issue is discovered, follow the onscreen information to resolve the problem.

4. Run the Windows Memory Diagnostic Tool. For more information see Windows Help and Support.
5. Restart the computer and press F2 to enter the BIOS Utility. Check the BIOS settings are correct and that CD/DVD drive is set as the first boot device on the Boot menu.
6. Ensure all cables and jumpers on the HDD and ODD are set correctly.
7. Remove any recently added hardware and associated software.
8. Run the Windows Disk Defragmenter. For more information see Windows Help and Support.
9. Run Windows Check Disk by entering **chkdsk /r** from a command prompt. For more information see Windows Help and Support.
10. Restore system and file settings from a known good date using **System Restore**.

If the issue is not fixed, repeat the preceding steps and select an earlier time and date.
11. Replace the HDD. See "Disassembly Process" on page 38.

ODD Failure

If the **ODD** fails, perform the following actions one at a time to correct the problem. Do not replace a non-defective FRUs:



ODD Not Operating Correctly

If the **ODD** exhibits any of the following symptoms it may be faulty:

- Audio CDs do not play when loaded
- DVDs do not play when loaded
- Blank discs do not burn correctly
- DVD or CD play breaks up or jumps
- Optical drive not found or not active:
 - Not shown in My Computer or the BIOS setup
 - LED does not flash when the computer starts up
 - The tray does not eject
- Access failure screen displays
- The ODD is noisy

Perform the following general solutions one at a time to correct the problem.

1. Reboot the computer and retry the operation.
2. Try an alternate disc.
3. Navigate to **Start** → **Computer**. Check that the ODD device is displayed in the **Devices with Removable Storage** panel.
4. Navigate to **Start** → **Control Panel** → **System and Maintenance** → **System** → **Device Manager**.

-
- a. Double-click **IDE ATA/ATAPI controllers**. If a device displays a down arrow, right-click on the device and click **Enable**.
 - b. Double-click **DVD/CD-ROM drives**. If the device displays a down arrow, right-click on the device and click **Enable**.
 - c. Check that there are no yellow exclamation marks against the items in **IDE ATA/ATAPI controllers**. If a device has an exclamation mark, right-click on the device and uninstall and reinstall the driver.
 - d. Check that there are no yellow exclamation marks against the items in **DVD/CD-ROM drives**. If a device has an exclamation mark, right-click on the device and uninstall and reinstall the driver.
 - e. If the exclamation marker is not removed from the item in the lists, try removing any recently installed software and retrying the operation.

Discs Do Not Play

If discs do not play when inserted in the drive, perform the following actions one at a time to correct the problem.

1. Check that the disc is correctly seated in the drive tray and that the label on the disc is visible.
2. Check that the media is clean and scratch free.
3. Try an alternate disc in the drive.
4. Ensure that **AutoPlay** is enabled:
 - a. Navigate to **Start** → **Control Panel** → **Hardware and Sound** → **AutoPlay**.
 - b. Select **Use AutoPlay for all media and devices**.
 - c. In the Audio CD and DVD Movie fields, select the desired player from the drop down menu.
5. Check that the Regional Code is correct for the selected media:

IMPORTANT:Region can only be changed a limited number of times. After Changes remaining reaches zero, the region cannot be changed even Windows is reinstalled or the drive is moved to another computer.

- a. Navigate to **Start** → **Control Panel** → **System and Maintenance** → **System** → **Device Manager**.
- b. Double-click **DVD/CD-ROM drives**.
- c. Right-click **DVD drive** and click **Properties**, then click the **DVD Region** tab.
- d. Select the region suitable for the media inserted in the drive.

Discs Do Not Burn Properly

If discs can not be burned, perform the following actions one at a time to correct the problem.

1. Ensure that the default drive is record enabled:
 - a. Navigate to **Start** → **Computer** and right-click the writable ODD icon. Click **Properties**.
 - b. Select the **Recording** tab. In the **Desktop disc recording** panel, select the writable ODD from the drop down list.
 - c. Click **OK**.
2. Ensure that the software used for burning discs is the factory default. If using different software, refer to the software's user manual.

Playback is Choppy

If playback is choppy or jumps, perform the following actions one at a time to correct the problem.

1. Check that system resources are not running low:
 - a. Try closing some applications.
 - b. Reboot and try the operation again.
2. Check that the ODD controller transfer mode is set to DMA:
 - a. Navigate to **Start** → **Control Panel** → **System and Maintenance** → **System** → **Device Manager**.

-
- b. Double-click **IDE ATA/ATAPI controllers**, then right-click ATA Device 0.
 - c. Click **Properties** and select the **Advanced Settings** tab. Ensure that the **Enable DMA** box is checked and click **OK**.
 - d. Repeat for the other ATA Devices shown if applicable.

Drive Not Detected

If Windows cannot detect the drive, perform the following actions one at a time to correct the problem.

1. Restart the computer and press F2 to enter the BIOS Utility.
2. Check that the drive is detected in the **ATAPI Model Name** field on the Information page.
NOTE: Check that the entry is identical to one of the ODDs specified in “Hardware Specifications and Configurations” on page 15.
3. Turn off the power and remove the cover to inspect the connections to the ODD. See “Disassembly Process” on page 38.
 - a. Check for broken connectors on the drive, motherboard, and cables.
 - b. Check for bent or broken pins on the drive, motherboard, and cable connections.
 - c. Try an alternate cable, if available. If the drive works with the new cable, the original cable should be replaced.
4. Reseat the drive ensuring and all cables are connected correctly.
5. Replace the ODD. See “Disassembly Process” on page 38.

Drive Read Failure

If discs cannot be read when inserted in the drive, perform the following actions one at a time to correct the problem.


1. Remove and clean the failed disc.
2. Retry reading the CD or DVD.
 - d. Test the drive using other discs.
 - e. Play a DVD movie
 - f. Listen to a music CD

If the ODD works properly with alternate discs, the original disc is probably defective and should be replaced.

3. Turn off the power and remove the cover to inspect the connections to the ODD. See “Disassembly Process” on page 38.
 - a. Check for broken connectors on the drive, motherboard, and cables.
 - b. Check for bent or broken pins on the drive, motherboard, and cable connections.
 - c. Try an alternate cable, if available. If the drive works with the new cable, the original cable should be replaced.
4. Replace the ODD. See “Disassembly Process” on page 38.


Wireless Function Failure

If the **WLAN** fails, perform the following actions one at a time to correct the problem. Do not replace a non-defective FRUs:



Thermal Unit Failure

If the **Thermal Unit** fails, perform the following actions one at a time to correct the problem. Do not replace a non-defective FRUs:



External Mouse Failure

If an external **Mouse** fails, perform the following actions one at a time to correct the problem.

1. Try an alternative mouse.
2. If the mouse uses a wireless connection, insert new batteries and confirm there is a good connection. See the mouse user manual.
3. If the mouse uses a USB connection, try an alternate USB port.
4. Try an alternative program to verify mouse operation. Reinstall the program experiencing mouse failure.
5. Restart the computer.
6. Remove any recently added hardware and associated software.
7. Remove any recently added software and reboot.
8. Restore system and file settings from a known good date using **System Restore**.
If the issue is not fixed, repeat the preceding steps and select an earlier time and date.
9. Run the Event Viewer to check the events log for errors. For more information see Windows Help and Support.
10. Roll back the mouse driver to the previous version if updated recently.
11. Remove and reinstall the mouse driver.
12. Check the Device Manager to determine that:
 - The device is properly installed. There are no red Xs or yellow exclamation marks.
 - There are no device conflicts.
 - No hardware is listed under Other Devices.
13. If the Issue is still not resolved, see "Online Support Information" on page 183.

Other Failures

If the CRT Switch, Dock, LAN Port, external MIC or Speakers, PCI Express Card, 5-in-1 Card Reader or Volume Wheel fail, perform the following general steps to correct the problem. Do not replace a non-defective FRUs:

1. Check Drive whether is OK.
2. Check Test Fixture is ok.
3. Swap M/B to Try.

Intermittent Problems

Intermittent system hang problems can be caused by a variety of reasons that have nothing to do with a hardware defect, such as: cosmic radiation, electrostatic discharge, or software errors. FRU replacement should be considered only when a recurring problem exists.

When analyzing an intermittent problem, do the following:

1. Run the advanced diagnostic test for the system board in loop mode at least 10 times.
2. If no error is detected, do not replace any FRU.
3. If any error is detected, replace the FRU. Rerun the test to verify that there are no more errors.

Undetermined Problems

The diagnostic problems does not identify which adapter or device failed, which installed devices are incorrect, whether a short circuit is suspected, or whether the system is inoperative.

Follow these procedures to isolate the failing FRU (do not isolate non-defective FRU).

NOTE: Verify that all attached devices are supported by the computer.

NOTE: Verify that the power supply being used at the time of the failure is operating correctly. (See “Power On Issue” on page 118.):

1. Power-off the computer.
2. Visually check them for damage. If any problems are found, replace the FRU.
3. Remove or disconnect all of the following devices:
 - Non-Acer devices
 - Printer, mouse, and other external devices
 - Battery pack
 - Hard disk drive
 - DIMM
 - CD-ROM/Diskette drive Module
 - PC Cards
4. Power-on the computer.
5. Determine if the problem has changed.
6. If the problem does not recur, reconnect the removed devices one at a time until you find the failing FRU.
7. If the problem remains, replace the following FRU one at a time. Do not replace a non-defective FRU:
 - System board
 - LCD assembly

Post Codes

These tables describe the POST codes and descriptions during the POST.

Sec: NO_EVICTION_MODE_DEBUG EQU 1 (CommonPlatform\sec\ia32\SecCore.inc)	
Code	Description
0xC2	MTRR setup
0xC3	Enable cache
0xC4	Establish cache tags
0xC5	Enter NEM, Place the BSP in No Fill mode, set CR0.CD = 1, CR0.NW = 0.
0xCF	Cache Init Finished

Memory: DEBUG_BIOS equ 1 (Chipset\Alviso\MemoryInitAsm\IA32\IMEMORY.INC)	
Code	Description
0xA0	First memory check point
0x01	Enable MCHBAR
0x02	Check for DRAM initialization interrupt and reset fail
0x03	Verify all DIMMs are DDR or DDR2 and unbuffered
0x04	Detect an improper warm reset and handle
0x05	Detect if ECC SO-DIMMs are present in the system
0x06	Verify all DIMMs are single or double sided and not asymmetric
0x07	Verify all DIMMs are x8 or x16 width
0x08	Find a common CAS latency between the DIMMS and the MCH
0x09	Determine the memory frequency and CAS latency to program
0x10	Determine the smallest common TRAS for all DIMMs
0x11	Determine the smallest common TRP for all DIMMs
0x12	Determine the smallest common TRCD for all DIMMs
0x13	Determine the smallest refresh period for all DIMMs
0x14	Verify burst length of 8 is supported by all DIMMs
0x15	Determine the smallest tWR supported by all DIMMs
0x16	Determine DIMM size parameters
0x17	Program the correct system memory frequency
0x18	Determine and set the mode of operation for the memory channels
0x19	Program clock crossing registers
0x20	Disable Fast Dispatch
0x21	Program the DRAM Row Attributes and DRAM Row Boundary registers
0x22	Program the DRAM Bank Architecture register
0x23	Program the DRAM Timing & and DRAM Control registers
0x24	Program ODT
0x25	Perform steps required before memory init
0x26	Program the receive enable reference timing control register Program the DLL Timing Control Registers , RCOMP settings
0x27	Enable DRAM Channel I/O Buffers
0x28	Enable all clocks on populated rows

Memory: DEBUG_BIOS equ 1 (Chipset\Alviso\MemoryInitAsm\IA32\IMEMORY.INC)	
Code	Description
0x29	Perform JEDEC memory initialization for all memory rows
0x30	Perform steps required after memory init
0x31	Program DRAM throttling and throttling event registers
0x32	Setup DRAM control register for normal operation and enable
0x33	Enable RCOMP
0x34	Clear DRAM initialization bit in the SB
0x35	Initialization Sequence Completed, program graphic clocks
0x43	Program Thermal Throttling

BDS & Specific action:	
Code	Description
0x00	Report the legacy boot is happening
0x12	Wake up the Aps
0x13	Initialize SMM Private Data and relocate BSP SMBASE
0x21	PC init begin at the stage1
0x27	Report every memory range do the hard ware ECC init
0x28	Report status code of every memory range
0x50	Get the root bridge handle
0x51	Notify pci bus driver starts to program the resource
0x58	Reset the host controller
0x5A	IdeBus begin initialization
0x79	Report that the remote terminal is being disabled
0x7A	Report that the remote terminal is being enabled
0x90	Keyboard reset
0x91	USB Keyboard disable
0x92	Keyboard detection
0x93	Report that the usb keyboard is being enabled
0x94	Clear the keyboard buffer
0x95	Init Keyboard
0x98	Mouse reset
0x99	Mouse disable
0x9A	Detect PS2 mouse
0x9B	Report that the mouse is being enabled
0xB8	Peripheral removable media reset(ex:IsaFloppy, USB device)
0xB9	Peripheral removable media disable
0xBB	Peripheral removable media enable
0xE4	Report Status Code here for DXE_ENTRY_POINT once it is available
0xF8	Report that ExitBootServices() has been called
0xF9	Runtime driver set virtual address map

Each PEIM entry point used in 80_PORT	
Code	Description
0x00	
0x01	PEI_EVENT_LOG
0xA1	PEI_OEM_SERVICE
0xA2	PEI_SIO_INIT
0xA3	PEI_MONO_STATUS_CODE
0xA4	PEI_CPU_IO_PCI_CFG
0x06	PEI_CPU_IO
0x07	PEI_PCI_CFG
0xA5	PEI_CPU_PEIM
0xA6	PEI_PLATFORM_STAGE1
0xA7	PEI_VARIABLE
0xA8	PEI_SB_INIT
0x0C	PEI_CAPSULE
0xAA	PEI_PLATFORM_STAGE2
0xAC	PEI_SB_SMBUS_ARP_DISABLED
0x0F	PEI_HOST_TO_SYSTEM
0x40	PEI_MEMORY_INIT
0x41	PEI_S3_RESUME
0xAD	PEI_CLOCK_GEN
0xAB	PEI_OP_PRESENCE
0xAE	PEI_FIND_FV
0x16	PEI_H2O_DEBUG_IO
0x17	PEI_H2O_DEBUG_COMM
0x16~0x1F	PEI_RESERVED
0x20~0x2E	PEI_OEM_DEFINED
0xAF	PEI_DXE_IPL

Each Driver entry point used in 80_PORT	
Code	Description
0x30	RESERVED
0xB6	DXE_CRC32_SECTION_EXTRACT
0xB8	SCRIPT_SAVE
0xB9	ACPI_S3_SAVE
0xBA	SMART_TIMER
0xBB	JPEG_DECODER
0xBC	PCX_DECODER
0xBE	HT_CPU / MP_CPU
0xBF	LEGACY_METRONOME
0xC0	FTWLITE

Each Driver entry point used in 80_PORT	
Code	Description
0xC1	RUN_RIME
0xC2	MONOTONIC_COUNTER
0xC3	WATCH_DOG_TIMER
0xC4	SECURITY_STUB
0xC5	DXE_CPU_IO
0xC6	CF9_RESET
0xC7	PC_RTC
0xC8	STATUS_CODE
0xC9	VARIABLE
	EMU_VARIABLE
0xD9	DXE_CHIPSET_INIT
0x45	DXE_ALERT_FORMAT
0xD6	PCI_HOST_BRIDGE
0xD7	PCI_EXPRESS
0xD5	DXE_SB_INIT
0xDA	IDE_CONTROLLER
0xDB	SATA_CONTROLLER
0xDD	SB_SM_BUS
0xE7	ISA_ACPI_DRIVER
0xE8	ISA_BUS
0xE9	ISA_SERIAL
0xED	BUS_PCI_UNDI
0xEC	PCI_BUS
0xF6	BOOT_PRIORITY
0xF7	FVB_SERVICE
0xF8	ACPI_PLATFORM
0xFB	PCI_HOT_PLUG
0xFC	DXE_PLATFORM
0xFD	PLATFORM_IDE
0x97	SMBIOS
0x98	MEMORY_SUB_CLASS
0x99	MISC_SUB_CLASS
0x82	CON_PLATFORM
0x83	SAVE_MEMORY_CONFIG
0x84	ACPI_SUPPORT
0x85	CON_SPLITTER_UGA_VGA / CON_SPLITTER
0x88	VGA_CLASS
0x89	DATA_HUB
0x60	DISK_IO
0x8B	MEMORY_TEST
0x62	CRISIS_RECOVERY
0x8D	LEGACY_8259


Each Driver entry point used in 80_PORT	
Code	Description
0x8E	LEGACY_REGION
0x8F	LEGACY_INTERRUPT
0x70	BIOS_KEYBOARD
0x71	BIOS_VEDIO
0x72	MONITER_KEY
0x73	LEGACY_BIOS
0x75	LEGACY_BIOS_PLATFORM
0x76	PCI_PLATFORM
0x6C	ISA_FLOOPY
0x6D	PS2_MOUSE
0x6E	USB_BOT
0x6F	USB_CBI0
0x74	USB_MOUSE
0xFA	SETUP_UTILITY
0x90	FW_BLOCK_SERVICE
0x78	SMM_USB_LEGACY
0x86	GRAPHICS_CONSOLE
0x87	TERMINAL
0x8A	DATA_HUB_STD_ERR
0x7C	FAT
0x7D	PARTITION
0x7E	ENGLISH
0x7F	FRENCH
0x9E	HII_DATABASE
0x9F	OEM_SETUP_BROWSER
0x8C	OEM_BADGING_SUPPORT
0xF9	SETUP_MOUSE
0x72	MONITOR_KEY
0xBD	PLATFORM_BDS
0x8D	RESERVED
0x8E	RESERVED
0x8F	RESERVED
0xA0	DXE_H2O_DEBUG_IO
0xB3	DXE_TPM_TCG
0xB4	DXE_TPM_PHYSICAL_PRESENCE
0xB7	DXE_OEM_SERVICE
0x9B	DXE_SECURITY_HDD_PASSWORD_SERVICE
0xA9	DXE_LAN_IDER_CONTROLLER
0x9C	DXE_SECURITY_SYSTEM_PASSWORD_SERVICE
0x9D	DXE_SECURITY_PASSWORD_CONSOLE
0xCB	DXE_DATA_HUB_RECORD_POLICY
0xB5	DXE_TPM_DRIVER

Each Driver entry point used in 80_PORT	
Code	Description
0x11	CHINESE
0xB0	JAPANESE
0xB1	DXE_UNICODE_COLLATION

Each SmmDriver entry point used in 80_PORT	
Code	Description
0xD4	SMM_ACCESS
0xDE	SMM_CONTROL
0xCC	SMM_BASE
0xD2	SMM_RUNTIME
0xDF	SB_SMM_DISPATCH
0xD0	SMM_THUNK
0xCA	SMM_ACPI_SW_CHILD
0xFE	SMM_PLATFORM
0xD8	SMM_GMCH_MBI
0x90	SMM_FW_BLOCK_SERVICE
0x91	SMM_VARIABLE
0x92	SMM_IHISI
0x93	SMM_INT15_MICROCODE
0x94	SMM_PNP
0x95	SMM_INIT_PPM
0xD3	SMM_OEM_SERVICE


Jumper and Connector Locations

Top View




Item	Description
JL VDS1	LCD Connector
JP14	Power/B Connector
JSPK1	Speaker(Left) Connector
JSPK2	Speaker(Right) Connector
JKB1	Internal Keyboard Connector
JTP1	Touch Pad Connector
U18	South Bridge
SW4	Touch pad (Left) Button
SW5	Touch pad (Right) Button

Bottom View




ITEM	DESCRIPTION
PJP1	AC-IN Connector
JRJ1	RJ45 Connector
JCRT1	CRT Connector
JP12	Fan Connector
JUSB1	USB Connector
JUSB2	USB Connector
JMIC1	MIC-In Jack
JHP1	Head-Phone Jack
JSATA2	HDD Connector
U39	North Bridge
JCPU1	CPU Socket
JREAD1	Card Reader Socket
PJP3	Battery Connector
JDIMM2	Memory DIMM2 Connector
JDIMM1	Memory DIMM1 Connector
JP2	ODD Connector
JMINI2	Wireless Card Connector

Power Board




ITEM	DESCRIPTION
SW1	TP Lock Button
SW2	ON/OFF Button
SW3	Wireless Button
LED 7	TP Lock LED
LED 1	ON/OFF LED
LED 5	Wireless LED
LED 3	Media LED
LED 4	Num LED
LED 6	Caps LED

ODD Board




ITEM	DESCRIPTION
JP1	M/B Connector
JP2	HDD Connector
JP3	ODD Connector

Battery Board



ITEM	DESCRIPTION
PJP1	M/B Connector
PJP2	Battery Connector

Lid Board



ITEM	DESCRIPTION
U1	Lid Switch

Clearing Password Check and BIOS Recovery

This section provides you with the standard operating procedures of clearing password and BIOS recovery for eMachines G630/G430. The machine provides one Hardware Open Gap on main board for clearing password check, and one Hotkey for enabling BIOS Recovery.

Clearing Password Check

Steps for Clearing BIOS Password Check

If users set BIOS Password (Supervisor Password and/or User Password) for a security reason, BIOS will ask the password during systems POST or when systems enter to BIOS Setup menu. However, once it is necessary to bypass the password check, users need to short the HW Gap to clear the password by the following steps:

1. Power Off the system, and remove HDD, AC and Battery from the machine.
2. Disconnect the RTC Battery cable and locate the R379 jumper.
3. Use an electric conductivity tool to short the two points of the HW Gap.
4. Plug in AC, keep the short condition on the HW Gap, and press Power Button to power on the system till BIOS POST finish. Then remove the tool from the HW Gap.
5. Restart system. Press **F2** key to enter BIOS Setup menu.
6. If there is no Password request, BIOS Password is cleared. Otherwise, please follow the steps and try again.

NOTE: These steps are only for clearing BIOS Password (Supervisor Password and User Password).

Clear CMOS Jumper



Item	Description	Location
R379	Clear CMOS Jumper	Thermal Module Bay, under Modem Board

BIOS Recovery by Crisis Disk

BIOS Recovery Boot Block:

BIOS Recovery Boot Block is a special block of BIOS. It is used to boot up the system with minimum BIOS initialization. Users can enable this feature to restore the BIOS firmware to a successful one once the previous BIOS flashing process failed.

BIOS Recovery Hotkey:

The system provides a function hotkey: **Fn+Esc**, for enable BIOS Recovery process when system is powered on during BIOS POST. To use this function, it is strongly recommended to have the AC adapter and Battery present. If this function is enabled, the system will force the BIOS to enter a special BIOS block, called Boot Block.

Steps for BIOS Recovery from USB Storage:

Before doing this, prepare the Crisis USB key. The Crisis USB key could be made by executing the Crisis Disk program in another system with Windows XP OS.

Follow the steps below:

1. Copy the **xxxxx.wph** BIOS file into the Crisis folder which is included with the crisis program.
2. Rename the **xxxxx.wph** file to **BIOS.wph**.
3. Plug in the USB disk.
4. Launch the **wincris.exe** program to create a USB Crisis Disk. Click **Start** to initiate the process.
5. Select the **Quick Format** option to format the disk and click **Start**. Follow the instructions on the screen to create the disk.

To use the Crisis USB key, do the following:

1. Plug USB storage into USB port.
2. Press **Fn + ESC** button then plug in AC power.
The Power button flashes orange once.
3. Press **Power** button to initiate system CRISIS mode.
When CRISIS is complete, the system auto restarts with a workable BIOS.
4. Update the latest version BIOS for this machine by regular BIOS flashing process.

FRU (Field Replaceable Unit) List


This chapter gives you the FRU (Field Replaceable Unit) listing in global configurations of eMachines G630/G430. Refer to this chapter whenever ordering for parts to repair or for RMA (Return Merchandise Authorization).

Please note that WHEN ORDERING FRU PARTS, you should check the most up-to-date information available on your regional web or channel. For whatever reasons a part number change is made, it will not be noted on the printed Service Guide. For ACER AUTHORIZED SERVICE PROVIDERS, your Acer office may have a DIFFERENT part number code from those given in the FRU list of this printed Service Guide. You MUST use the local FRU list provided by your regional Acer office to order FRU parts for repair and service of customer machines.

NOTE: To scrap or to return the defective parts, you should follow the local government ordinance or regulations on how to dispose it properly, or follow the rules set by your regional Acer office on how to return it.


eMachines G630/G430 Exploded Diagrams

Main Assembly




No.	Description	Acer P/N
1	Middle Cover Assy	60.N3702.003
2	Hinge Cap Assy	42.N3702.001
3	Upper Case Assy	60.N3702.001
4	Mainboard	MB.N6702.001
5	Lower Case	60.N3702.002

Base Assembly



No.	Description	Acer P/N
1	Fan	23.N3702.001
2	Thermal Module	60.N6702.001
3	Mainboard	MB.N6702.001







Rear Assembly









No.	Description	Acer P/N
1	RAM Door	42.N3702.002
2	HDD Door	42.N3702.003
3	Lower Case	60.N3702.002






eMachines G630/G430 FRU List

CATEGORY	Description	AcerPN
Board		
	POWER BOARD	55.N3702.001
	WLAN CARD-XB63	NI.23600.007
	WLAN CARD-BCM4312	NI.23600.029
Cable		
	TP FFC	50.N3702.001
	POWER CORD US 3 PIN	27.TAVV5.001
	POWER CORD EU 3 PIN	27.TAVV5.002
	POWER CORD AUS 3 PIN	27.TAVV5.003
	POWER CORD UK 3 PIN	27.TAVV5.004
	POWER CORD CHINA 3 PIN	27.TAVV5.005
	POWER CORD SWISS 3 PIN	27.TAVV5.006
	POWER CORD ITALIAN 3 PIN	27.TAVV5.007
	POWER CORD DENMARK 3 PIN	27.TAVV5.008
	POWER CORD JP 3 PIN	27.TAVV5.009
	POWER CORD SOUTH AFRICA 3 PIN	27.TAVV5.010
	POWER CORD KOERA 3 PIN	27.TAVV5.011
	POWER CORD ISRAEL 3 PIN	27.TAVV5.012
	POWER CORD INDIA 3 PIN	27.TAVV5.013
	POWER CORD TWN 3 PIN	27.TAVV5.014
POWER CORD ARGENTINA 3 PIN	27.APV02.001	
CPU/Processor		
	CPU AMD Athlon TF20 PGA 1.6G 512K 638 15W G2	KC.ATF02.200
	CPU AMD AthlonX2 TK42 1.6G 1M 638 20W G2	KC.ATK02.420
Case/Cover/Bracket Assembly		
	UPPER CASE ASSY	60.N3702.001



CATEGORY	Description	AcerPN
	LOWER CASE	60.N3702.002
	TP BRACKET	33.N3702.001
	MIDDLE COVER ASSY	60.N3702.003
	HINGE CAP ASSY	42.N3702.001
	RAM DOOR ASSY	42.N3702.002
	HDD DOOR ASSY	42.N3702.003

CATEGORY	Description	AcerPN
HDD		
	HDD SEAGATE 2.5" 5400rpm 160GB ST9160310AS Crockett SATA LF F/W:0303	KH.16001.034
	HDD TOSHIBA 2.5" 5400rpm 160GB MK1655GSX Libra SATA LF F/W: FG011J	KH.16004.006
	HDD HGST 2.5" 5400rpm 160GB HTS543216L9A300 Falcon-B SATA LF F/W:C40C	KH.16007.019
	HDD WD 2.5" 5400rpm 160GB WD1600BEVT-22ZCTO ML160 SATA LF F/W:11.01A11	KH.16008.022
	HDD SEAGATE 2.5" 5400rpm 250GB ST9250315AS Wyatt SATA LF F/W:0001SDM1	KH.25001.016
	HDD TOSHIBA 2.5" 5400rpm 250GB MK2555GSX Libra SATA LF F/W:FG001J	KH.25004.003
	HDD HGST 2.5" 5400rpm 250GB HTS543225L9A300 Falcon-B SATA LF F/W:C40C	KH.25007.013
	HDD HGST 2.5" 5400rpm 250GB HTS545025B9A300 Panther B SATA LF F/W:C60F	KH.25007.015
	HDD WD 2.5" 5400rpm 250GB WD2500BEVT-22ZCT0 ML160 SATA LF F/W:11.01A11	KH.25008.021
	HDD SEAGATE 2.5" 5400rpm 320GB ST9320320AS Crockett SATA LF F/W:0303	KH.32001.008
	HDD TOSHIBA 2.5" 5400rpm 320GB MK3255GSX Libra SATA LF F/W:FG011J	KH.32004.002
	HDD HGST 2.5" 5400rpm 320GB HTS545032B9A300 Panther B SATA LF F/W: C60F	KH.32007.007
	HDD WD 2.5" 5400rpm 320GB WD3200BEVT-22ZCT0 ML160 SATA LF F/W:11.01A11	KH.32008.013
	HDD SEAGATE 2.5" 5400rpm 500GB ST9500325AS Wyatt SATA LF F/W:0001SDM1	KH.50001.011
	HDD WD 2.5" 5400rpm 500GB WD5000BEVT-22ZAT0 ML250 SATA LF F/W:01.01A01	KH.50008.013
	HDD HGST 2.5" 5400rpm 500GB HTS545050B9A300 Panther B SATA LF F/W:C60F	KH.50007.009
HDD HGST 2.5" 5400rpm 500GB HTS545050B9A300 Panther B SATA LF F/W:C60F	KH.50007.009	
	HDD BRACKET ASSY	33.N3702.002
ODD		
	DVD SUPER MULTI DRIVE MODULE	6M.N3702.001
	ODD PANASONIC Super-Multi DRIVE 12.7mm Tray DL 8X UJ880A LF W/O bezel SATA	KU.00807.064
	ODD HLDS Super-Multi DRIVE 12.7mm Tray DL 8X GT20N LF W/O bezel SATA	KU.0080D.040
	ODD SONY Super-Multi DRIVE 12.7mm Tray DL 8X AD- 7580S LF W/O bezel SATA	KU.0080E.017
	ODD PLDS Super-Multi DRIVE 12.7mm Tray DL 8X DS- 8A3S LF W/O bezel SATA	KU.0080F.004

CATEGORY	Description	AcerPN
	ODD BEZEL-SUPER MULTI	42.N3702.005
	ODD BRACKET	33.N3702.003
Keyboard		
	Keyboard EM-7T HM50/70 Internal 17 Standard 99KS Black US International	KB.I1700.438
	Keyboard EM-7T HM50/70 Internal 17 Standard 99KS Black Greek	KB.I1700.423
	Keyboard EM-7T HM50/70 Internal 17 Standard 99KS Black Arabic	KB.I1700.414
	Keyboard EM-7T HM50/70 Internal 17 Standard 99KS Black Russian	KB.I1700.430
	Keyboard EM-7T HM50/70 Internal 17 Standard 99KS Black Thailand	KB.I1700.435
	Keyboard EM-7T HM50/70 Internal 17 Standard 100KS Black UK	KB.I1700.437
	Keyboard EM-7T HM50/70 Internal 17 Standard 100KS Black German	KB.I1700.422
	Keyboard EM-7T HM50/70 Internal 17 Standard 100KS Black Swiss/G	KB.I1700.434
	Keyboard EM-7T HM50/70 Internal 17 Standard 99KS Black Chinese	KB.I1700.418
	Keyboard EM-7T HM50/70 Internal 17 Standard 99KS Black US International w/ Hebrew	KB.I1700.439
	Keyboard EM-7T HM50/70 Internal 17 Standard 100KS Black FR/Arabic	KB.I1700.420
	Keyboard EM-7T HM50/70 Internal 17 Standard 100KS Black US w/ Canadian French	KB.I1700.440
	Keyboard EM-7T HM50/70 Internal 17 Standard 100KS Black Brazilian Portuguese	KB.I1700.416
	Keyboard EM-7T HM50/70 Internal 17 Standard 100KS Black CZ/SK	KB.I1700.417
	Keyboard EM-7T HM50/70 Internal 17 Standard 103KS Black Japanese	KB.I1700.426
	Keyboard EM-7T HM50/70 Internal 17 Standard 100KS Black Belgium	KB.I1700.415
	Keyboard EM-7T HM50/70 Internal 17 Standard 100KS Black Danish	KB.I1700.419
	Keyboard EM-7T HM50/70 Internal 17 Standard 100KS Black Italian	KB.I1700.425
	Keyboard EM-7T HM50/70 Internal 17 Standard 100KS Black French	KB.I1700.421
	Keyboard EM-7T HM50/70 Internal 17 Standard 100KS Black Hungarian	KB.I1700.424
Keyboard EM-7T HM50/70 Internal 17 Standard 100KS Black Norwegian	KB.I1700.428	

CATEGORY	Description	AcerPN
	Keyboard EM-7T HM50/70 Internal 17 Standard 100KS Black Portuguese	KB.I1700.429
	Keyboard EM-7T HM50/70 Internal 17 Standard 100KS Black Spanish	KB.I1700.432
	Keyboard EM-7T HM50/70 Internal 17 Standard 100KS Black Turkish	KB.I1700.436
	Keyboard EM-7T HM50/70 Internal 17 Standard 100KS Black Sweden	KB.I1700.433
	Keyboard EM-7T HM50/70 Internal 17 Standard 100KS Black SLO/CRO	KB.I1700.431
	Keyboard EM-7T HM50/70 Internal 17 Standard 100KS Black Nordic	KB.I1700.427
LCD		
	ASSY LED MODULE 17.3 IN. WXGA GLARE W/ ANTENNA*2 CCD 0.3M	6M.N3702.002
	ASSY LED MODULE 17.3 IN. WXGA GLARE W/ ANTENNA*2, W/O CCD	6M.N4702.001
	ASSY LED MODULE 17.3 IN. WXGA GLARE W/ ANTENNA*3, W/O CCD	6M.N3202.001
	LED LCD AUO 17.3" WXGA+ Glare B173RW01-V0 LF 220nit 8ms 600:1	LK.17305.001
	LED LCD SAMSUNG 17.3" WXGA+ Glare LTN173KT01- A01 LF 220nit 8ms 600:1	LK.17306.001
	CCFL LCD SAMSUNG 15.6"W WXGA Glare LTN156AT01-A01 LF 220nit 8ms 600:1	LK.15606.001
	LED LCD LPL 17.3" WXGA+ Glare LP173WD1-TLA1 LF 220nit 8ms 600:1	LK.17308.001
	LED LCD CMO 17.3" WXGA+ Glare N173O6-L02 LF 220nit 8ms 600:1	LK.1730D.001
	LCD COVER	60.N3702.004
	ANTENNA-AUX	50.N3702.004
	ANTENNA-MAIN	50.N3702.002
	LCD BEZEL FOR W/CCD F	60.N3702.005

CATEGORY	Description	AcerPN
	LCD CABLE FOR W/CCD F	60.N3702.006
	LCD BRACKET R&L FOR LED F	33.N3702.004
	CAMERA 0.3	57.N2802.001
	LCD BEZEL FOR W/O CCD F	60.N4702.001
	LED CABLE FOR W/O CCD F	60.N4702.002
	ANTENNA-MAIN+MIMO	50.N3702.003
Mainboard		
	Mainboard G627 ATI RS780 SB710 8132 W/O 1394 V1.0 LF	MB.N6702.001
Memory		
	Memory NANYA SO-DIMM DDRII 667 1GB NT1GT64UH8D0FN-3C LF 64*16 0.07um	KN.1GB03.026
	Memory MICRON SO-DIMM DDRII 667 1GB MT8HTF12864HDY-667G1 LF 64*16 0.065um	KN.1GB04.010
	Memory SAMSUNG SO-DIMM DDRII 667 1GB M470T2864EH3-CE6 LF 64*16 0.055um	KN.1GB0B.027
	Memory HYNIX SO-DIMM DDRII 667 1GB HYMP112S64CP6-Y5 LF	KN.1GB0G.012
	Memory HYNIX SO-DIMM DDRII 667 1GB HMP112S6EFR6C-Y5 LF 64*16 0.055um	KN.1GB0G.022
	Memory NANYA SO-DIMM DDRII 667 2GB NT2GT64U8HD0BN-3C LF 128*8 0.07um	KN.2GB03.011
	Memory MICRON SO-DIMM DDRII 667 2GB MT16HTF25664HY-667G1 LF 128*8 0.065um	KN.2GB04.010
	Memory SAMSUNG SO-DIMM DDRII 667 2GB M470T5663EH3-CE6 LF 128*8 0.055um	KN.2GB0B.011
	Memory HYNIX SO-DIMM DDRII 667 2GB HYMP125S64CP8-Y5 LF	KN.2GB0G.004
	Memory HYNIX SO-DIMM DDRII 667 2GB HMP125S6EFR8C-Y5 LF 128*8 0.055um	KN.2GB0G.012
Heatsink		
	THERMAL MODULE-AMD	60.N6702.001
	FAN	23.N3702.001

CATEGORY	Description	AcerPN
Speaker		
	SPEAKER R	23.N3702.002
	SPEAKER L	23.N3702.003
Miscellaneous		
	NAME PLATE-EMG627	40.N6702.001
	NAME PLATE-EMG427	40.N6702.002

Screw List	Acer PN
SCREW M2.48D 4.0L K 5.5D 0.8T ZKNL	86.N3702.001
SCREW M2.48D 6.0L K 5.5D 0.8T ZKNL	86.N3702.002
SCREW M2.45D 8.0L K 5.5D 0.8T ZKNL	86.N3702.003
SCREW M1.98D 3.0L K 4.6D 0.8T ZKNL	86.N3702.004
SCREW M M 2D 5L K 4.6D NI NL+	86.N3702.005
SCREW M M 3.0D 3.0L K 4.9D NI+	86.N3702.006
SCREW ASSY CPU THERMAL	86.N3702.007

Model Definition and Configuration

eMachines G430

Model	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	Memory 3
eMG430-102G16Mi	SMPM100	NLED17.3 WXGA+G	UMA	N	SO2GBII6	N	N
eMG430-103G32Mi	SMPM100	NLED17.3 WXGA+G	UMA	N	SO2GBII6	SO1GBII6	N
eMG430-102G16Mi	SMPM100	NLED17.3 WXGA+G	UMA	N	SO2GBII6	N	N
eMG430-102G16Mi	SMPM100	NLED17.3 WXGA+G	UMA	N	SO2GBII6	N	N

Model	RO	Country	Acer Part No	Description
eMG430-102G16Mi	EMEA	UK	LX.N9202.002	eMG430-102G16Mi W7HP64eTGB1 UMACKk 1*2G/160/6L2.2/5R/CB_bg_0.3D_HG_EN11
eMG430-103G32Mi	EMEA	France	LX.N9202.001	eMG430-103G32Mi W7HP64eTFR1 UMACKk 2G+1G/320/6L2.2/5R/CB_bg_0.3D_HG_FR21
eMG430-102G16Mi	WW	WW	S2.N920C.001	eMG430-102G16Mi LINPUSeWW1 UMACKk 1*2G/160/6L2.2/5R/CB_bg_0.3D_HG_EN12
eMG430-102G16Mi	WW	WW	S2.N910C.001	eMG430-102G16Mi LINPUSeWW1 UMAkk 1*2G/160/6L2.2/5R/CB_bg_HG_EN12

Model	Memory 4	HDD 1(GB)	HDD 2(GB)	ODD	Media Processor	Extra SW1
eMG430-102G16Mi	N	N160GB5.4KS	N	NSM8XS	N	NIS
eMG430-103G32Mi	N	N320GB5.4KS	N	NSM8XS	N	NIS
eMG430-102G16Mi	N	N160GB5.4KS	N	NSM8XS	N	N
eMG430-102G16Mi	N	N160GB5.4KS	N	NSM8XS	N	N

Model	Card Reader	Wireless LAN1	Bluetooth	VOIP Phone	Finger Print
eMG430-102G16Mi	5 in 1-Build in	3rd WiFi BG	N	N	N
eMG430-103G32Mi	5 in 1-Build in	3rd WiFi BG	N	N	N
eMG430-102G16Mi	5 in 1-Build in	3rd WiFi BG	N	N	N
eMG430-102G16Mi	5 in 1-Build in	3rd WiFi BG	N	N	N

eMachines G630G

Model	RO	Country	Acer Part No	Description
eMG630G-524G50Mn	WW	WW	S2.N960C.003	eMG630G-524G50Mn LIMPUSeWW1 M92XT512Ckk 2*2G/500_L/6L2.2/5R/CB_bgn_0.3D_HG_EN12
eMG630G-524G50Mn	WW	GCTWN	S2.N960C.002	eMG630G-524G50Mn LIMPUSeWW1 M92XT512Ckk 2*2G/500_L/6L2.2/5R/CB_bgn_0.3D_HG_ENX2
eMG630G-303G25Mi	EMEA	Russia	LX.N9601.001	eMG630G-303G25Mi W7HB64RUeTRU1 M92XT512Ckk 2G+1G/250/6L2.2/5R/CB_bg_0.3D_HG_RU11
eMG630G-302G25Mi	EMEA	Middle East	LX.N9602.038	eMG630G-302G25Mi EM W7HP64EMeTME2 M92XT512Ckk 1*2G/250/6L2.2/5R/CB_bg_0.3D_HG_AR11
eMG630G-302G25Mi	EMEA	Middle East	LX.N9602.037	eMG630G-302G25Mi EM W7HP64EMeTME3 M92XT512Ckk 1*2G/250/6L2.2/5R/CB_bg_0.3D_HG_ES81
eMG630G-302G25Mi	EMEA	Middle East	LX.N9602.036	eMG630G-302G25Mi EM W7HP64EMeTME4 M92XT512Ckk 1*2G/250/6L2.2/5R/CB_bg_0.3D_HG_ES61
eMG630G-302G25Mi	EMEA	Middle East	LX.N9602.035	eMG630G-302G25Mi EM W7HP64EMeTME2 M92XT512Ckk 1*2G/250/6L2.2/5R/CB_bg_0.3D_HG_AR21
eMG630G-302G25Mi	EMEA	Middle East	LX.N9602.034	eMG630G-302G25Mi EM W7HP64EMeTME6 M92XT512Ckk 1*2G/250/6L2.2/5R/CB_bg_0.3D_HG_ES61
eMG630G-302G25Mi	EMEA	Middle East	LX.N9602.033	eMG630G-302G25Mi EM W7HP64EMeTME9 M92XT512Ckk 1*2G/250/6L2.2/5R/CB_bg_0.3D_HG_ES81
eMG630G-302G25Mi	EMEA	Turkey	LX.N9602.032	eMG630G-302G25Mi EM W7HP64EMeTTR1 M92XT512Ckk 1*2G/250/6L2.2/5R/CB_bg_0.3D_HG_TR31
eMG630G-302G25Mi	EMEA	South Africa	LX.N9602.031	eMG630G-302G25Mi EM W7HP64EMeTZA2 M92XT512Ckk 1*2G/250/6L2.2/5R/CB_bg_0.3D_HG_ES61
eMG630G-302G25Mi	EMEA	Middle East	LX.N9602.030	eMG630G-302G25Mi EM W7HP64EMeTME2 M92XT512Ckk 1*2G/250/6L2.2/5R/CB_bg_0.3D_HG_ES61
eMG630G-302G25Mi	EMEA	Algeria	LX.N9602.029	eMG630G-302G25Mi EM W7HP64EMeTDZ1 M92XT512Ckk 1*2G/250/6L2.2/5R/CB_bg_0.3D_HG_ES81
eMG630G-302G25Mi	EMEA	South Africa	LX.N9602.028	eMG630G-302G25Mi EM W7HP64EMeTZA1 M92XT512Ckk 1*2G/250/6L2.2/5R/CB_bg_0.3D_HG_ES81
eMG630G-302G25Mi	EMEA	Russia	LX.N9602.027	eMG630G-302G25Mi W7HP64RUeTRU1 M92XT512Ckk 1*2G/250/6L2.2/5R/CB_bg_0.3D_HG_RU11
eMG630G-302G25Mi	EMEA	Ukraine	LX.N9602.026	eMG630G-302G25Mi W7HP64RUeTUK1 M92XT512Ckk 1*2G/250/6L2.2/5R/CB_bg_0.3D_HG_RU61
eMG630G-302G25Mi	EMEA	Serbia/Macedonia	LX.N9602.025	eMG630G-302G25Mi W7HP64eTCS1 M92XT512Ckk 1*2G/250/6L2.2/5R/CB_bg_0.3D_HG_SL12

Model	RO	Country	Acer Part No	Description
eMG630G-302G25Mi	EMEA	Hungary	LX.N9602.024	eMG630G-302G25Mi W7HP64eTHU1 M92XT512Ckk 1*2G/250/6L2.2/5R/ CB_bg_0.3D_HG_HU11
eMG630G-302G25Mi	EMEA	Latvia	LX.N9602.023	eMG630G-302G25Mi W7HP64eTLV1 M92XT512Ckk 1*2G/250/6L2.2/5R/ CB_bg_0.3D_HG_RU22
eMG630G-302G25Mi	EMEA	Germany	LX.N9602.022	eMG630G-302G25Mi W7HP64eTDE1 M92XT512Ckk 1*2G/250/6L2.2/5R/ CB_bg_0.3D_HG_DE11
eMG630G-302G25Mi	EMEA	Greece	LX.N9602.021	eMG630G-302G25Mi W7HP64eTGR1 M92XT512Ckk 1*2G/250/6L2.2/5R/ CB_bg_0.3D_HG_EL31
eMG630G-302G25Mi	EMEA	Serbia/ Macedonia	LX.N9602.020	eMG630G-302G25Mi EM W7HP64eTCS1 M92XT512Ckk 1*2G/250/6L2.2/5R/CB_bg_0.3D_HG_SL11
eMG630G-302G25Mi	EMEA	Holland	LX.N9602.019	eMG630G-302G25Mi W7HP64eTNL1 M92XT512Ckk 1*2G/250/6L2.2/5R/ CB_bg_0.3D_HG_NL11
eMG630G-302G25Mi	EMEA	Spain	LX.N9602.018	eMG630G-302G25Mi W7HP64eTES1 M92XT512Ckk 1*2G/250/6L2.2/5R/ CB_bg_0.3D_HG_ES51
eMG630G-302G25Mi	EMEA	Eastern Europe	LX.N9602.017	eMG630G-302G25Mi W7HP64eTEU7 M92XT512Ckk 1*2G/250/6L2.2/5R/ CB_bg_0.3D_HG_ENQ1
eMG630G-302G25Mi	EMEA	Italy	LX.N9602.016	eMG630G-302G25Mi W7HP64eTIT1 M92XT512Ckk 1*2G/250/6L2.2/5R/ CB_bg_0.3D_HG_IT11
eMG630G-302G25Mi	EMEA	France	LX.N9602.015	eMG630G-302G25Mi W7HP64eTFR1 M92XT512Ckk 1*2G/250/6L2.2/5R/ CB_bg_0.3D_HG_FR21
eMG630G-302G25Mi	EMEA	Eastern Europe	LX.N9602.014	eMG630G-302G25Mi W7HP64eTEU5 M92XT512Ckk 1*2G/250/6L2.2/5R/ CB_bg_0.3D_HG_PL71
eMG630G-302G25Mi	EMEA	Luxembourg	LX.N9602.013	eMG630G-302G25Mi W7HP64eTLU3 M92XT512Ckk 1*2G/250/6L2.2/5R/ CB_bg_0.3D_HG_IT41
eMG630G-302G25Mi	EMEA	Austria	LX.N9602.012	eMG630G-302G25Mi W7HP64eTAT1 M92XT512Ckk 1*2G/250/6L2.2/5R/ CB_bg_0.3D_HG_DE61
eMG630G-302G25Mi	EMEA	Switzerland	LX.N9602.011	eMG630G-302G25Mi W7HP64eTCH1 M92XT512Ckk 1*2G/250/6L2.2/5R/ CB_bg_0.3D_HG_IT41
eMG630G-302G25Mi	EMEA	Eastern Europe	LX.N9602.010	eMG630G-302G25Mi W7HP64eTEU5 M92XT512Ckk 1*2G/250/6L2.2/5R/ CB_bg_0.3D_HG_RO11
eMG630G-302G25Mi	EMEA	Denmark	LX.N9602.009	eMG630G-302G25Mi W7HP64eTDK2 M92XT512Ckk 1*2G/250/6L2.2/5R/ CB_bg_0.3D_HG_ENS1
eMG630G-302G25Mi	EMEA	Eastern Europe	LX.N9602.008	eMG630G-302G25Mi W7HP64eTEU7 M92XT512Ckk 1*2G/250/6L2.2/5R/ CB_bg_0.3D_HG_SL11

Model	RO	Country	Acer Part No	Description
eMG630G-302G25Mi	EMEA	Israel	LX.N9602.007	eMG630G-302G25Mi W7HP64eTIL1 M92XT512Ckk 1*2G/250/6L2.2/5R/ CB_bg_0.3D_HG_HE11
eMG630G-302G25Mi	EMEA	Portugal	LX.N9602.006	eMG630G-302G25Mi W7HP64eTPT1 M92XT512Ckk 1*2G/250/6L2.2/5R/ CB_bg_0.3D_HG_PT11
eMG630G-302G25Mi	EMEA	UK	LX.N9602.004	eMG630G-302G25Mi W7HP64eTGB1 M92XT512Ckk 1*2G/250/6L2.2/5R/ CB_bg_0.3D_HG_EN11
eMG630G-302G25Mi	EMEA	Belgium	LX.N9602.005	eMG630G-302G25Mi W7HP64eTBE1 M92XT512Ckk 1*2G/250/6L2.2/5R/ CB_bg_0.3D_HG_NL11
eMG630G-302G25Mi	EMEA	Czech	LX.N9602.003	eMG630G-302G25Mi W7HP64eTCZ2 M92XT512Ckk 1*2G/250/6L2.2/5R/ CB_bg_0.3D_HG_SK11
eMG630G-302G25Mi	EMEA	Cyprus	LX.N9602.002	eMG630G-302G25Mi W7HP64eTCY1 M92XT512Ckk 1*2G/250/6L2.2/5R/ CB_bg_0.3D_HG_ES61
eMG630G-302G25Mi	EMEA	Eastern Europe	LX.N9602.001	eMG630G-302G25Mi W7HP64eTEU4 M92XT512Ckk 1*2G/250/6L2.2/5R/ CB_bg_0.3D_HG_SV21
eMG630G-302G25Mi	WW	WW	S2.N960C.001	eMG630G-302G25Mi LINPUSeWW1 M92XTckk 1*2G/250/6L2.2/5R/ CB_bg_0.3D_HG_EN12
eMG630G-302G25Mi	EMEA	Russia	LX.N9501.001	eMG630G-302G25Mi W7HB64RUeTRU1 M92XT512kk 1*2G/250/6L2.2/5R/ CB_bg_HG_RU11
eMG630G-302G25Mi	WW	WW	S2.N950C.001	eMG630G-302G25Mi LINPUSeWW1 M92XTkk 1*2G/250/6L2.2/5R/ CB_bg_HG_EN12

Model	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	Memory 3
eMG630G-524G50Mn	ATM520	NLED17.3 WXGA+G	M92SXT	512M-DDR2(6 4*16*4)	SO2GBII6	SO2GBII6	N
eMG630G-524G50Mn	ATM520	NLED17.3 WXGA+G	M92SXT	512M-DDR2(6 4*16*4)	SO2GBII6	SO2GBII6	N
eMG630G-303G25Mi	AAM300	NLED17.3 WXGA+G	M92SXT	512M-DDR2(6 4*16*4)	SO2GBII6	SO1GBII6	N
eMG630G-302G25Mi	AAM300	NLED17.3 WXGA+G	M92SXT	512M-DDR2(6 4*16*4)	SO2GBII6	N	N
eMG630G-302G25Mi	AAM300	NLED17.3 WXGA+G	M92SXT	512M-DDR2(6 4*16*4)	SO2GBII6	N	N
eMG630G-302G25Mi	AAM300	NLED17.3 WXGA+G	M92SXT	512M-DDR2(6 4*16*4)	SO2GBII6	N	N

Model	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	Memory 3
eMG630G-302G25Mi	AAM300	NLED17.3 WXGA+G	M92SXT	512M-DDR2(64*16*4)	SO2GBII6	N	N
eMG630G-302G25Mi	AAM300	NLED17.3 WXGA+G	M92SXT	512M-DDR2(64*16*4)	SO2GBII6	N	N
eMG630G-302G25Mi	AAM300	NLED17.3 WXGA+G	M92SXT	512M-DDR2(64*16*4)	SO2GBII6	N	N
eMG630G-302G25Mi	AAM300	NLED17.3 WXGA+G	M92SXT	512M-DDR2(64*16*4)	SO2GBII6	N	N

Model	Memory 4	HDD 1(GB)	HDD 2(GB)	ODD	Media Processor	Extra SW1
eMG630G-524G50Mn	N	N500GB5.4KS	N	NSM8XS	N	N
eMG630G-524G50Mn	N	N500GB5.4KS	N	NSM8XS	N	N
eMG630G-303G25Mi	N	N250GB5.4KS	N	NSM8XS	N	NIS
eMG630G-302G25Mi	N	N250GB5.4KS	N	NSM8XS	N	NIS
eMG630G-302G25Mi	N	N250GB5.4KS	N	NSM8XS	N	NIS
eMG630G-302G25Mi	N	N250GB5.4KS	N	NSM8XS	N	NIS
eMG630G-302G25Mi	N	N250GB5.4KS	N	NSM8XS	N	NIS
eMG630G-302G25Mi	N	N250GB5.4KS	N	NSM8XS	N	NIS
eMG630G-302G25Mi	N	N250GB5.4KS	N	NSM8XS	N	NIS
eMG630G-302G25Mi	N	N250GB5.4KS	N	NSM8XS	N	NIS
eMG630G-302G25Mi	N	N250GB5.4KS	N	NSM8XS	N	NIS
eMG630G-302G25Mi	N	N250GB5.4KS	N	NSM8XS	N	NIS
eMG630G-302G25Mi	N	N250GB5.4KS	N	NSM8XS	N	NIS
eMG630G-302G25Mi	N	N250GB5.4KS	N	NSM8XS	N	NIS
eMG630G-302G25Mi	N	N250GB5.4KS	N	NSM8XS	N	NIS
eMG630G-302G25Mi	N	N250GB5.4KS	N	NSM8XS	N	NIS
eMG630G-302G25Mi	N	N250GB5.4KS	N	NSM8XS	N	NIS

eMachines G630

Model	RO	Country	Acer Part No	Description
eMG630-302G16Mi	EMEA	Russia	LX.N9308.001	eMG630-302G16Mi W7ST32RUeTRU1 UMACkk 1*2G/160/6L2.2/5R/ CB_bg_0.3D_HG_RU11
eMG630-323G25Mi	EMEA	Russia	LX.N9301.001	eMG630-323G25Mi W7HB64RUeTRU1 UMACkk 2G+1G/250/6L2.2/5R/ CB_bg_0.3D_HG_RU11
eMG630-303G25Mi	EMEA	Sweden	LX.N9302.048	eMG630-303G25Mi W7HP64eTSE1 UMACkk 2G+1G/250/6L2.2/5R/ CB_bg_0.3D_HG_FI12
eMG630-303G25Mi	EMEA	Norway	LX.N9302.047	eMG630-303G25Mi W7HP64eTNO1 UMACkk 2G+1G/250/6L2.2/5R/ CB_bg_0.3D_HG_NO12
eMG630-303G25Mi	EMEA	Finland	LX.N9302.046	eMG630-303G25Mi W7HP64eTFI2 UMACkk 2G+1G/250/6L2.2/5R/ CB_bg_0.3D_HG_FI12
eMG630-303G25Mi	EMEA	Denmark	LX.N9302.045	eMG630-303G25Mi W7HP64eTDK2 UMACkk 2G+1G/250/6L2.2/5R/ CB_bg_0.3D_HG_ENS1
eMG630-303G32Mi	EMEA	Sweden	LX.N9302.044	eMG630-303G32Mi W7HP64eTSE1 UMACkk 2G+1G/320/6L2.2/5R/ CB_bg_0.3D_HG_FI12
eMG630-303G32Mi	EMEA	Norway	LX.N9302.043	eMG630-303G32Mi W7HP64eTNO1 UMACkk 2G+1G/320/6L2.2/5R/ CB_bg_0.3D_HG_NO12
eMG630-303G32Mi	EMEA	Finland	LX.N9302.042	eMG630-303G32Mi W7HP64eTFI2 UMACkk 2G+1G/320/6L2.2/5R/ CB_bg_0.3D_HG_FI12
eMG630-303G32Mi	EMEA	Russia	LX.N9302.041	eMG630-303G32Mi W7HP64RUeTRU1 UMACkk 2G+1G/320/6L2.2/5R/ CB_bg_0.3D_HG_RU11
eMG630-303G32Mi	EMEA	Ukraine	LX.N9302.040	eMG630-303G32Mi W7HP64RUeTUK1 UMACkk 2G+1G/320/6L2.2/5R/ CB_bg_0.3D_HG_RU61
eMG630-303G32Mi	EMEA	Middle East	LX.N9302.038	eMG630-303G32Mi EM W7HP64EMeTME3 UMACkk 2G+1G/ 320/6L2.2/5R/CB_bg_0.3D_HG_ES81
eMG630-303G32Mi	EMEA	Middle East	LX.N9302.039	eMG630-303G32Mi EM W7HP64EMeTME2 UMACkk 2G+1G/ 320/6L2.2/5R/CB_bg_0.3D_HG_AR11
eMG630-303G32Mi	EMEA	Middle East	LX.N9302.037	eMG630-303G32Mi EM W7HP64EMeTME4 UMACkk 2G+1G/ 320/6L2.2/5R/CB_bg_0.3D_HG_ES61
eMG630-303G32Mi	EMEA	Middle East	LX.N9302.036	eMG630-303G32Mi EM W7HP64EMeTME2 UMACkk 2G+1G/ 320/6L2.2/5R/CB_bg_0.3D_HG_AR21
eMG630-303G32Mi	EMEA	Middle East	LX.N9302.035	eMG630-303G32Mi EM W7HP64EMeTME6 UMACkk 2G+1G/ 320/6L2.2/5R/CB_bg_0.3D_HG_ES61
eMG630-303G32Mi	EMEA	Turkey	LX.N9302.033	eMG630-303G32Mi EM W7HP64EMeTTR1 UMACkk 2G+1G/ 320/6L2.2/5R/CB_bg_0.3D_HG_TR31

Model	RO	Country	Acer Part No	Description
eMG630-303G32Mi	EMEA	Middle East	LX.N9302.034	eMG630-303G32Mi EM W7HP64EMeTME9 UMACKk 2G+1G/320/6L2.2/5R/CB_bg_0.3D_HG_ES81
eMG630-303G32Mi	EMEA	South Africa	LX.N9302.032	eMG630-303G32Mi EM W7HP64EMeTZA2 UMACKk 2G+1G/320/6L2.2/5R/CB_bg_0.3D_HG_ES61
eMG630-303G32Mi	EMEA	Algeria	LX.N9302.030	eMG630-303G32Mi EM W7HP64EMeTDZ1 UMACKk 2G+1G/320/6L2.2/5R/CB_bg_0.3D_HG_ES81
eMG630-303G32Mi	EMEA	Middle East	LX.N9302.031	eMG630-303G32Mi EM W7HP64EMeTME2 UMACKk 2G+1G/320/6L2.2/5R/CB_bg_0.3D_HG_ES61
eMG630-303G32Mi	EMEA	Hungary	LX.N9302.029	eMG630-303G32Mi W7HP64eTHU1 UMACKk 2G+1G/320/6L2.2/5R/CB_bg_0.3D_HG_HU11
eMG630-303G32Mi	EMEA	Serbia/ Macedonia	LX.N9302.028	eMG630-303G32Mi W7HP64eTCS1 UMACKk 2G+1G/320/6L2.2/5R/CB_bg_0.3D_HG_SL12
eMG630-303G32Mi	EMEA	Latvia	LX.N9302.026	eMG630-303G32Mi W7HP64eTLV1 UMACKk 2G+1G/320/6L2.2/5R/CB_bg_0.3D_HG_RU22
eMG630-303G32Mi	EMEA	Greece	LX.N9302.027	eMG630-303G32Mi W7HP64eTGR1 UMACKk 2G+1G/320/6L2.2/5R/CB_bg_0.3D_HG_EL31
eMG630-303G32Mi	EMEA	Serbia/ Macedonia	LX.N9302.025	eMG630-303G32Mi EM W7HP64eTCS1 UMACKk 2G+1G/320/6L2.2/5R/CB_bg_0.3D_HG_SL11
eMG630-303G32Mi	EMEA	Eastern Europe	LX.N9302.024	eMG630-303G32Mi W7HP64eTEU7 UMACKk 2G+1G/320/6L2.2/5R/CB_bg_0.3D_HG_ENQ1
eMG630-303G32Mi	EMEA	Holland	LX.N9302.023	eMG630-303G32Mi W7HP64eTNL1 UMACKk 2G+1G/320/6L2.2/5R/CB_bg_0.3D_HG_NL11
eMG630-303G32Mi	EMEA	Spain	LX.N9302.022	eMG630-303G32Mi W7HP64eTES1 UMACKk 2G+1G/320/6L2.2/5R/CB_bg_0.3D_HG_ES51
eMG630-303G32Mi	EMEA	Poland	LX.N9302.021	eMG630-303G32Mi W7HP64eTPL1 UMACKk 2G+1G/320/6L2.2/5R/CB_bg_0.3D_HG_PL11
eMG630-303G32Mi	EMEA	Eastern Europe	LX.N9302.020	eMG630-303G32Mi W7HP64eTEU5 UMACKk 2G+1G/320/6L2.2/5R/CB_bg_0.3D_HG_PL71
eMG630-303G32Mi	EMEA	Italy	LX.N9302.019	eMG630-303G32Mi W7HP64eTIT1 UMACKk 2G+1G/320/6L2.2/5R/CB_bg_0.3D_HG_IT11
eMG630-303G32Mi	EMEA	France	LX.N9302.018	eMG630-303G32Mi W7HP64eTFR1 UMACKk 2G+1G/320/6L2.2/5R/CB_bg_0.3D_HG_FR21
eMG630-303G32Mi	EMEA	Luxembourg	LX.N9302.017	eMG630-303G32Mi W7HP64eTLU3 UMACKk 2G+1G/320/6L2.2/5R/CB_bg_0.3D_HG_IT41

Model	RO	Country	Acer Part No	Description
eMG630-303G32Mi	EMEA	South Africa	LX.N9302.016	eMG630-303G32Mi EM W7HP64EMeTZA1 UMACkk 2G+1G/320/6L2.2/5R/CB_bg_0.3D_HG_ES81
eMG630-303G32Mi	EMEA	Eastern Europe	LX.N9302.015	eMG630-303G32Mi W7HP64eTEU5 UMACkk 2G+1G/320/6L2.2/5R/CB_bg_0.3D_HG_RO11
eMG630-303G32Mi	EMEA	Austria	LX.N9302.014	eMG630-303G32Mi W7HP64eTAT1 UMACkk 2G+1G/320/6L2.2/5R/CB_bg_0.3D_HG_DE61
eMG630-303G32Mi	EMEA	Switzerland	LX.N9302.013	eMG630-303G32Mi W7HP64eTCH1 UMACkk 2G+1G/320/6L2.2/5R/CB_bg_0.3D_HG_IT41
eMG630-303G32Mi	EMEA	Denmark	LX.N9302.012	eMG630-303G32Mi W7HP64eTDK2 UMACkk 2G+1G/320/6L2.2/5R/CB_bg_0.3D_HG_ENS1
eMG630-303G32Mi	EMEA	Eastern Europe	LX.N9302.011	eMG630-303G32Mi W7HP64eTEU7 UMACkk 2G+1G/320/6L2.2/5R/CB_bg_0.3D_HG_SL11
eMG630-303G32Mi	EMEA	Israel	LX.N9302.010	eMG630-303G32Mi W7HP64eTIL1 UMACkk 2G+1G/320/6L2.2/5R/CB_bg_0.3D_HG_HE11
eMG630-303G32Mi	EMEA	Portugal	LX.N9302.009	eMG630-303G32Mi W7HP64eTPT1 UMACkk 2G+1G/320/6L2.2/5R/CB_bg_0.3D_HG_PT11
eMG630-303G32Mi	EMEA	Belgium	LX.N9302.008	eMG630-303G32Mi W7HP64eTBE1 UMACkk 2G+1G/320/6L2.2/5R/CB_bg_0.3D_HG_NL11
eMG630-303G32Mi	EMEA	Cyprus	LX.N9302.007	eMG630-303G32Mi W7HP64eTCY1 UMACkk 2G+1G/320/6L2.2/5R/CB_bg_0.3D_HG_ES61
eMG630-303G32Mi	EMEA	Eastern Europe	LX.N9302.006	eMG630-303G32Mi W7HP64eTEU4 UMACkk 2G+1G/320/6L2.2/5R/CB_bg_0.3D_HG_SV21
eMG630-303G32Mi	EMEA	UK	LX.N9302.005	eMG630-303G32Mi W7HP64eTGB1 UMACkk 2G+1G/320/6L2.2/5R/CB_bg_0.3D_HG_EN11
eMG630-303G32Mi	EMEA	Czech	LX.N9302.004	eMG630-303G32Mi W7HP64eTCZ2 UMACkk 2G+1G/320/6L2.2/5R/CB_bg_0.3D_HG_SK11
eMG630-303G32Mi	EMEA	Germany	LX.N9302.003	eMG630-303G32Mi W7HP64eTDE1 UMACkk 2G+1G/320/6L2.2/5R/CB_bg_0.3D_HG_DE11
eMG630-303G25Mi	EMEA	Germany	LX.N9302.002	eMG630-303G25Mi W7HP64eTDE1 UMACkk 2G+1G/250/6L2.2/5R/CB_bg_0.3D_HG_DE11
eMG630-303G25Mi	EMEA	UK	LX.N9302.001	eMG630-303G25Mi W7HP64eTGB1 UMACkk 2G+1G/250/6L2.2/5R/CB_bg_0.3D_HG_EN11
eMG630-302G25Mi	WW	WW	S2.N930C.001	eMG630-302G25Mi LINPUSeWW1 UMACkk 1*2G/250/6L2.2/5R/CB_bg_0.3D_HG_EN12

Model	CPU	LCD	VGA Chip	VRAM 1	Memory 1	Memory 2	Memory 3
eMG630-303G32Mi	AAM300	NLED17.3 WXGA+G	UMA	N	SO2GBII6	SO1GBII6	N
eMG630-303G32Mi	AAM300	NLED17.3 WXGA+G	UMA	N	SO2GBII6	SO1GBII6	N
eMG630-303G25Mi	AAM300	NLED17.3 WXGA+G	UMA	N	SO2GBII6	SO1GBII6	N
eMG630-303G25Mi	AAM300	NLED17.3 WXGA+G	UMA	N	SO2GBII6	SO1GBII6	N
eMG630-302G25Mi	AAM300	NLED17.3 WXGA+G	UMA	N	SO2GBII6	N	N
eMG630-302G25Mi	AAM300	NLED17.3 WXGA+G	UMA	N	SO2GBII6	N	N

Model	Memory 4	HDD 1(GB)	HDD 2(GB)	ODD	Media Processor	Extra SW1
eMG630-302G16Mi	N	N160GB5.4KS	N	NSM8XS	N	NIS
eMG630-323G25Mi	N	N250GB5.4KS	N	NSM8XS	N	NIS
eMG630-303G25Mi	N	N250GB5.4KS	N	NSM8XS	N	NIS
eMG630-303G25Mi	N	N250GB5.4KS	N	NSM8XS	N	NIS
eMG630-303G25Mi	N	N250GB5.4KS	N	NSM8XS	N	NIS
eMG630-303G25Mi	N	N250GB5.4KS	N	NSM8XS	N	NIS
eMG630-303G25Mi	N	N250GB5.4KS	N	NSM8XS	N	NIS
eMG630-303G32Mi	N	N320GB5.4KS	N	NSM8XS	N	NIS
eMG630-303G32Mi	N	N320GB5.4KS	N	NSM8XS	N	NIS
eMG630-303G32Mi	N	N320GB5.4KS	N	NSM8XS	N	NIS
eMG630-303G32Mi	N	N320GB5.4KS	N	NSM8XS	N	NIS
eMG630-303G32Mi	N	N320GB5.4KS	N	NSM8XS	N	NIS
eMG630-303G32Mi	N	N320GB5.4KS	N	NSM8XS	N	NIS
eMG630-303G32Mi	N	N320GB5.4KS	N	NSM8XS	N	NIS
eMG630-303G32Mi	N	N320GB5.4KS	N	NSM8XS	N	NIS
eMG630-303G32Mi	N	N320GB5.4KS	N	NSM8XS	N	NIS
eMG630-303G32Mi	N	N320GB5.4KS	N	NSM8XS	N	NIS
eMG630-303G32Mi	N	N320GB5.4KS	N	NSM8XS	N	NIS
eMG630-303G32Mi	N	N320GB5.4KS	N	NSM8XS	N	NIS
eMG630-303G32Mi	N	N320GB5.4KS	N	NSM8XS	N	NIS

Model	Memory 4	HDD 1(GB)	HDD 2(GB)	ODD	Media Processor	Extra SW1
eMG630-303G32Mi	N	N320GB5.4KS	N	NSM8XS	N	NIS
eMG630-303G32Mi	N	N320GB5.4KS	N	NSM8XS	N	NIS
eMG630-303G32Mi	N	N320GB5.4KS	N	NSM8XS	N	NIS
eMG630-303G32Mi	N	N320GB5.4KS	N	NSM8XS	N	NIS
eMG630-303G32Mi	N	N320GB5.4KS	N	NSM8XS	N	NIS
eMG630-303G32Mi	N	N320GB5.4KS	N	NSM8XS	N	NIS
eMG630-303G32Mi	N	N320GB5.4KS	N	NSM8XS	N	NIS
eMG630-303G25Mi	N	N250GB5.4KS	N	NSM8XS	N	NIS
eMG630-303G25Mi	N	N250GB5.4KS	N	NSM8XS	N	NIS
eMG630-302G25Mi	N	N250GB5.4KS	N	NSM8XS	N	N
eMG630-302G25Mi	N	N250GB5.4KS	N	NSM8XS	N	N

Model	Card Reader	Wireless LAN1	Bluetooth	VOIP Phone	Finger Print
eMG630-302G16Mi	5 in 1-Build in	3rd WiFi BG	N	N	N
eMG630-323G25Mi	5 in 1-Build in	3rd WiFi BG	N	N	N
eMG630-303G25Mi	5 in 1-Build in	3rd WiFi BG	N	N	N
eMG630-303G25Mi	5 in 1-Build in	3rd WiFi BG	N	N	N
eMG630-303G25Mi	5 in 1-Build in	3rd WiFi BG	N	N	N
eMG630-303G25Mi	5 in 1-Build in	3rd WiFi BG	N	N	N
eMG630-303G32Mi	5 in 1-Build in	3rd WiFi BG	N	N	N
eMG630-303G32Mi	5 in 1-Build in	3rd WiFi BG	N	N	N
eMG630-303G32Mi	5 in 1-Build in	3rd WiFi BG	N	N	N
eMG630-303G32Mi	5 in 1-Build in	3rd WiFi BG	N	N	N
eMG630-303G32Mi	5 in 1-Build in	3rd WiFi BG	N	N	N

Model	Card Reader	Wireless LAN1	Bluetooth	VOIP Phone	Finger Print
eMG630-303G32Mi	5 in 1-Build in	3rd WiFi BG	N	N	N
eMG630-303G32Mi	5 in 1-Build in	3rd WiFi BG	N	N	N
eMG630-303G32Mi	5 in 1-Build in	3rd WiFi BG	N	N	N
eMG630-303G32Mi	5 in 1-Build in	3rd WiFi BG	N	N	N
eMG630-303G32Mi	5 in 1-Build in	3rd WiFi BG	N	N	N
eMG630-303G32Mi	5 in 1-Build in	3rd WiFi BG	N	N	N
eMG630-303G32Mi	5 in 1-Build in	3rd WiFi BG	N	N	N
eMG630-303G32Mi	5 in 1-Build in	3rd WiFi BG	N	N	N
eMG630-303G32Mi	5 in 1-Build in	3rd WiFi BG	N	N	N
eMG630-303G32Mi	5 in 1-Build in	3rd WiFi BG	N	N	N
eMG630-303G25Mi	5 in 1-Build in	3rd WiFi BG	N	N	N
eMG630-303G25Mi	5 in 1-Build in	3rd WiFi BG	N	N	N
eMG630-302G25Mi	5 in 1-Build in	3rd WiFi BG	N	N	N
eMG630-302G25Mi	5 in 1-Build in	3rd WiFi BG	N	N	N

Test Compatible Components

This computer's compatibility is tested and verified by Acer's internal testing department. All of its system functions are tested under the Windows® 7 environment.

Refer to the following lists for components, adapter cards, and peripherals which have passed these tests. Regarding configuration, combination and test procedures, please refer to the eMachines G630/G430 Compatibility Test Report released by the Acer Mobile System Testing Department.

Microsoft® Windows® 7 Environment Test

Vendor	Type	Description
Adapter		
DELTA	90W	Adapter DELTA 90W 19V 1.7x5.5x11 Blue ADP-90CD DB A, LV5 LED LF
HIPRO	65W	Adapter HIPRO 65W 19V 1.7x5.5x11 Yellow HP-A0652R3B 1LF, LV5 LED LF
HIPRO	90W	Adapter HIPRO 90W 19V 1.7x5.5x11 Blue HP-A0904A3 B1LF, LV5 LED LF
LITE-ON	65W	Adapter LITE-ON 65W 19V 1.7x5.5x11 Yellow PA-1650-22AC LV5 LED LF
LITE-ON	90W	Adapter LITE-ON 90W 19V 1.7x5.5x11 Blue PA-1900-34AR, LV5 LED LF
Audio Codec		
Realtek	ALC272X	Realtek Audio Codec ALC272X
Battery		
PANASONIC	6CELL2.2	Battery PANASONIC AS-2009A Li-Ion 3S2P PANASONIC 6 cell 4400mAh Main COMMON 2.2Ah(CG)
SAMSUNG	6CELL2.2	Battery SAMSUNG AS-2009A Li-Ion 3S2P SAMSUNG 6 cell 4400mAh Main COMMON 2.2Ah(F)
SANYO	6CELL2.2	Battery SANYO AS-2009A Li-Ion 3S2P SANYO 6 cell 4400mAh Main COMMON 2.2Ah(A)
SIMPLO	6CELL2.2	Battery SIMPLO AS-2009A Li-Ion 3S2P LGC 6 cell 4400mAh Main COMMON LGC 2.2Ah(S3)
SIMPLO	6CELL2.2	Battery SIMPLO AS-2009A Li-Ion 3S2P LGC 6 cell 4400mAh Main COMMON LGC 2.2Ah(S3)
SIMPLO	6CELL2.2	Battery SIMPLO AS-2009A Li-Ion 3S2P LGC 6 cell 4400mAh Main COMMON LGC 2.2Ah(S3)
SONY	6CELL2.2	Battery SONY AS-2009A Li-Ion 3S2P SONY 6 cell 4400mAh Main COMMON 2.2Ah(G6F)
Camera		
Chicony	0.3M DV	Chicony 0.3M DV Calla_2G
Chicony	0.3M DV	Chicony 0.3M DV Calla_2G
Chicony	0.3M DV	Chicony 0.3M DV Calla_2G
Suyin	0.3M DV	Suyin 0.3M DV Camellia_2G
Suyin	0.3M DV	Suyin 0.3M DV Camellia_2
Card Reader		
	5 in 1-Build in	5 in 1-Build in MS, MS Pro, SD, SC, XD
CPU		
AMD	AAM300	CPU AMD AthlonII M300 2.0G 1M 35W Caspian
AMD	AAM320	CPU AMD AthlonII M320 2.1G 1M 35W Caspian
AMD	ATM500	CPU AMD TurionII M500 2.2G 1M 35W
AMD	ATM520	CPU AMD TurionII M520 2.3G 1M 35W
AMD	SMPM100	CPU AMD SempronM M100 2.0G 512K 25W Caspian
HDD		

Vendor	Type	Description
HGST	N160GB5.4KS	HDD HGST 2.5" 5400rpm 160GB HTS545016B9A300 Panther B SATA LF F/W:C60F Disk imbalance criteria = 0.014g-cm
HGST	N250GB5.4KS	HDD HGST 2.5" 5400rpm 250GB HTS545025B9A300 Panther B SATA LF F/W:C60F Disk imbalance criteria = 0.014g-cm
HGST	N320GB5.4KS	HDD HGST 2.5" 5400rpm 320GB HTS543232L9A300 Falcon B SATA LF F/W:C40C Disk imbalance criteria = 0.014g-cm
HGST	N320GB5.4KS	HDD HGST 2.5" 5400rpm 320GB HTS543232L9A300 Falcon B SATA LF F/W:C40C Disk imbalance criteria = 0.014g-cm
HGST	N500GB5.4KS	HDD HGST 2.5" 5400rpm 500GB HTS545050B9A300 Panther B SATA LF F/W:C60F Disk imbalance criteria = 0.014g-cm
SEAGATE	N160GB5.4KS	HDD SEAGATE 2.5" 5400rpm 160GB ST9160314AS Wyatt SATA LF F/W:0001SDM1
SEAGATE	N250GB5.4KS	HDD SEAGATE 2.5" 5400rpm 250GB ST9250315AS Wyatt SATA LF F/W:0001SDM1
SEAGATE	N320GB5.4KS	HDD SEAGATE 2.5" 5400rpm 320GB ST9320325AS Wyatt SATA LF F/W:0001SDM1
SEAGATE	N500GB5.4KS	HDD SEAGATE 2.5" 5400rpm 500GB ST9500325AS Wyatt SATA LF F/W:0001SDM1
TOSHIBA	N160GB5.4KS	HDD TOSHIBA 2.5" 5400rpm 160GB MK1665GSX, Capricorn BS, 320G/P SATA 8MB LF F/W:GJ001J
TOSHIBA	N250GB5.4KS	HDD TOSHIBA 2.5" 5400rpm 250GB MK2565GSX, Capricorn BS, 320G/P SATA 8MB LF F/W:GJ001J
TOSHIBA	N320GB5.4KS	HDD TOSHIBA 2.5" 5400rpm 320GB Capricorn BS ,MK3265GSX SATA 8MB LF F/W:GJ001J
TOSHIBA	N500GB5.4KS	HDD TOSHIBA 2.5" 5400rpm 500GB MK5065GSX,Capricorn BS, 320G/P SATA 8MB LF F/W:GJ001J
TOSHIBA	N640GB5.4KS	HDD TOSHIBA 2.5" 5400rpm 640GB MK6465GSX,Capricorn BS,320G/P SATA 8MB LF F/W:GJ001J
WD	N160GB5.4KS	HDD WD 2.5" 5400rpm 160GB WD1600BEVT-22A23T0 , WD, ML320S SATA 8MB LF F/W:01.01A01
WD	N250GB5.4KS	HDD WD 2.5" 5400rpm 250GB WD2500BEVT-22A23T0, WD, ML320S SATA 8MB LF F/W:01.01A01.
WD	N320GB5.4KS	HDD WD 2.5" 5400rpm 320GB WD3200BEVT-22A23T0,ML320S,WD SATA 8MB LF F/W:01.01A01
WD	N500GB5.4KS	HDD WD 2.5" 5400rpm 500GB WD5000BEVT-22A0RT0, ML320M,WD SATA 8MB LF F/W:01.01A01
WD	N640GB5.4KS	HDD WD 2.5" 5400rpm 640GB WD6400BEVT-22A0RT0, ML320 SATA 8MB LF F/W:01.01A01
Keyboard		
eMACHINES	EM-7T	Keyboard eMACHINES EM-7T HM50/70 Internal 17 Standard Black
LAN		
Atheros	AR8132L	Atheros AR8132L

Vendor	Type	Description
LCD		
AUO	NLED17.3WXGA +G	LED LCD AUO 17.3" WXGA+ Glare B173RW01-V0 LF 220nit 8ms 600:1
CMO	NLED17.3WXGA +G	LED LCD CMO 17.3" WXGA+ Glare N173O6-L02 LF 220nit 8ms 600:1
LPL	NLED17.3WXGA +G	LED LCD LPL 17.3" WXGA+ Glare LP173WD1-TLA3 LF 220nit 8ms 600:1
LPL	NLED17.3WXGA +G	LED LCD LPL 17.3" WXGA+ Glare LP173WD1-TLA3 LF 220nit 8ms 600:1
SAMSUNG	NLED17.3WXGA +G	LED LCD SAMSUNG 17.3" WXGA+ Glare LTN173KT01-A01 LF 220nit 8ms 600:1
MEMORY		
HYNIX	SO1GBII6	Memory HYNIX SO-DIMM DDRII 667 1GB HMP112S6EFR6C-Y5 LF 64*16 0.055um
HYNIX	SO1GBII6	Memory HYNIX SO-DIMM DDRII 667 1GB HMP112S6EFR6C-Y5 LF 64*16 0.055um
HYNIX	SO2GBII6	Memory HYNIX SO-DIMM DDRII 667 2GB HMP125S6EFR8C-Y5 LF 128*8 0.055um
HYNIX	SO2GBII6	Memory HYNIX SO-DIMM DDRII 667 2GB HMP125S6EFR8C-Y5 LF 128*8 0.055um
MICRON	SO1GBII6	Memory MICRON SO-DIMM DDRII 667 1GB MT8HTF12864HDY-667G1 LF 64*16 0.065um
MICRON	SO2GBII6	Memory MICRON SO-DIMM DDRII 667 2GB MT16HTF25664HY-667G1 LF 128*8 0.065um
NANYA	SO1GBII6	Memory NANYA SO-DIMM DDRII 667 1GB NT1GT64UH8D0FN-3C LF 64*16 0.07um
NANYA	SO2GBII6	Memory NANYA SO-DIMM DDRII 667 2GB NT2GT64U8HD0BN-3C LF 128*8 0.07um
SAMSUNG	SO1GBII6	Memory SAMSUNG SO-DIMM DDRII 667 1GB M470T2864EH3-CE6 LF 64*16 0.055um
SAMSUNG	SO2GBII6	Memory SAMSUNG SO-DIMM DDRII 667 2GB M470T5663EH3-CE6 LF 128*8 0.055um
Modem		
	External USB Lite+LSI modem	External USB Lite+LSI modem
NB Chipset		
AMD	AMDRS880M	AMD RS880M w/ HDCP EEPROM
ODD		
HLDS	NSM8XS	ODD HLDS Super-Multi DRIVE 12.7mm Tray DL 8X GT30N LF W/O bezel SATA (HF + Windows 7)
PLDS	NSM8XS	ODD PLDS Super-Multi DRIVE 12.7mm Tray DL 8X DS-8A4SH LF W/O bezel SATA (HF + Windows 7)
SONY	NSM8XS	ODD SONY Super-Multi DRIVE 12.7mm Tray DL 8X AD-7585H LF W/O bezel SATA (HF + Windows 7)
TOSHIBA	NSM8XS	ODD TOSHIBA Super-Multi DRIVE 12.7mm Tray DL 8X TS-L633C LF W/O bezel SATA (HF + Windows 7)
SB Chipset		
AMD	AMDSB710	AMD SB710

Vendor	Type	Description
Software		
	NIS	Antivirus application NIS
VGA Chip		
AMD	M92SXT	AMD M92SXT 55nm 23mm*23mm S2 package
None	UMA	UMA (AMD)
VRAM		
	512M- DDR2(64*16*4)	512M-DDR2 64*16*4
WiFi Antenna		
WNC	PIFA	PIFA
Wireless LAN		
Foxconn	3rd WiFi BG	Foxconn Wireless LAN Broadcom 4312 minicard b/g
Foxconn	3rd WiFi BG	Foxconn Wireless LAN Broadcom 4312H BG (HM)
Foxconn	3rd WiFi BG	Foxconn Wireless LAN Broadcom 4312 minicard b/g
Foxconn	3rd WiFi BG	Foxconn Wireless LAN Broadcom 4312H BG (HM)

Online Support Information

This section describes online technical support services available to help you repair your Acer Systems.

If you are a distributor, dealer, ASP or TPM, please refer your technical queries to your local Acer branch office. Acer Branch Offices and Regional Business Units may access our website. However some information sources will require a user i.d. and password. These can be obtained directly from Acer CSD Taiwan.

Acer's Website offers you convenient and valuable support resources whenever you need them.

In the Technical Information section you can download information on all of Acer's Notebook, Desktop and Server models including:

- Service guides for all models
- User's manuals
- Training materials
- Bios updates
- Software utilities
- Spare parts lists
- TABs (Technical Announcement Bulletin)

For these purposes, we have included an Acrobat File to facilitate the problem-free downloading of our technical material.

Also contained on this website are:

- Detailed information on Acer's International Traveler's Warranty (ITW)
- Returned material authorization procedures
- An overview of all the support services we offer, accompanied by a list of telephone, fax and email contacts for all your technical queries.

We are always looking for ways to optimize and improve our services, so if you have any suggestions or comments, please do not hesitate to communicate these to us.

A

AFLASH Utility 29

Antennas

Removing 82

Replacing 85

B

Battery

Replacing 115

Battery Pack

Removing 40

BIOS

ROM type 16

vendor 16

Version 16

BIOS Utility 21–29

Boot 27

Exit 28

Navigating 21

Onboard Device Configuration 25

Save and Exit 28

Security 24

System Security 28

Board Layout

Top View 137

brightness

hotkeys 13

C

Camera Module

Removing 77

Replacing 90

caps lock

on indicator 5, 9

Common Problems 118

computer

on indicator 5, 9

CPU

Removing 74

Replacing 93

CPU Fan

Removing 72

Replacing 94

D

DIMM Modules

Removing 45

Replacing 112

Display 3

display

hotkeys 13

E

EasyTouch Failure 128

Euro 14

External Module Disassembly

Flowchart 39

F

Features 1

Flash Utility 29

FPC Cable

Removing 80

FRU (Field Replaceable Unit) List 143

H

Hard Disk Drive

Removing 48

Replacing 110

HDTV Switch Failure 129

Hot Keys 11

I

Indicators 9

Intermittent Problems 130

Internal Speaker Failure 122

J

Jumper and Connector Locations 137

K

Keyboard

Removing 52

Replacing 109

Keyboard Failure 121

L

LCD Bezel

Removing 76

Replacing 91

- LCD Brackets
 - Removing 80
 - Replacing 88
- LCD Cable
 - Replacing 88
- LCD Failure 121
- LCD Module
 - Removing 53
 - Replacing 104
- LCD Module Disassembly
 - Flowchart 75
- LCD Module Reassembly Procedure 85
- LCD Panel
 - Removing 78
 - Replacing 88
- Left Speaker Module
 - Removing 62
- Lower Covers
 - Removing 42
 - Replacing 113

M

- Main Unit Disassembly
 - Flowchart 50
- Mainboard
 - Removing 68
 - Replacing 95
- media access
 - on indicator 5, 9
- Memory
 - Removing 45
 - Replacing 112
- Memory Check 118
- Model Definition 156

N

- No Display Issue 119
- num lock
 - on indicator 5, 9

O

- ODD Failure 125
- Online Support Information 183
- Optical Disk Drive
 - Replacing 113

- Optical Drive Module
 - Removing 43

P

- Panel 4
 - Bottom 7
- PC Card 9
- Power Board
 - Removing 61
 - Replacing 100
- Power On Failure 118

R

- Right Speaker Module
 - Removing 64
 - Replacing 98
- RTC Battery
 - Removing 69

S

- SD Dummy Card
 - Removing 41
 - Replacing 114
- Speakers
 - Removing 62, 64
- speakers
 - hotkey 13
- Switch Cover
 - Removing 51
 - Replacing 110
- System
 - Block Diagram 3

T

- Test Compatible Components 177
- Thermal Module
 - Removing 70
 - Replacing 94
- Thermal Unit Failure 128
- TouchPad
 - Removing 66
- TouchPad Bracket
 - Removing 66
 - Replacing 96
- TouchPad Failure 122

Troubleshooting

- Built-in KB Failure 121
- EasyTouch Buttons 128
- HDTV Switch 129
- Internal Speakers 122
- LCD Failure 121
- No Display 119
- ODD 125
- Other Failures 129
- Power On 118
- Thermal Unit 128
- TouchPad 122
- WLAN 128

U

Undetermined Problems 130

Upper Cover

- Removing 57
- Replacing 100

utility

- BIOS 21–29

W

Windows 2000 Environment Test 178

Wireless Function Failure 128

WLAN Module

- Removing 46
- Replacing 112

