Motion Marketing, Kansas City Service and Help

www motionmarketinginc.com

em all: service@ motionmarketinginc.com

Motion Marketing

PS100

Electronic Postal Scale

W ith fold-up platform for weighing large flats or mailing tubes $Max.10\ bs\ d=0.10z$



The PS100 is a quality electronic digital scale with m any features and functions. Please read this manual carefully to enjoy this product

Operating Instructions

SCALE SPECIFICATIONS

Range : $0 \sim 10$ bs

M echanical overbad protection

Tare : Unlim ited to the total capacity of the scale

Accuracy : $\pm 0.1 \%$ of reading $\pm 1 \text{ digit}$

Calibration : Fourpoints of Automatic Calibration for greater accuracy

Resolution : 01 oz M inim um W eight : 01 oz M in.Add-on W t. : 01 oz

Power : AC Adaptor: 9 V, 100m A (Supplied)

Battery: 9 V A kaline battery (Not supplied)

Warm -up time : 1 m inute or less

Display : 7 segmentLCD with 3 + 2 halfdigits

Auto Off : Auto offaffer5 m inutes of non-use in battery operation
Tem perature : Good perform ance within 20 degrees to 110 degrees F

Case & Platform : Fine textured ABS plastic

Load CellTechnology: Four optimal placed single stain gages with temperature

compensation

Load CellBody : High Tensile Strength Alum inum Alby

Unpacking and assembling the scale

Unpack the scale and rem ove the pieces of shock protector inserted between the platform and the scale.

Using the scale with a battery

Rem ove the battery compartment cover underneath the scale. Insert a 9V alkaline battery and connect to the battery snap. Replace the battery compartment cover.

Using the scale with the power adapter

Connect the supplied power adapter to the input socket at the rear of the scale and plug it into the power supply. It is advisable to rem ove the battery when using the power adapter.

Scale startup

Press the NTARE key. Willappearbriefly in the LCD window as the scale performs a self-check/zeroing routine, afterwhich willappear in the LCD window. Wait 60 seconds for the scale to warm up. Your scale is now ready to weigh.

W hat is the function of TARE Key?

You can tare (set to zero) any article used as a container for small item s in the following way.

If the scale is switched off, press the to display. Place the container onto the platform, and then press the

key. The display will show. Place the item to be weighed into the container, on the platform. The scale will now show the weight of the item, excluding the weight of the container.

Be sure that the scale is operated on a flat surface

In order to operate correctly, the scale must be installed on a firm , flat surface. It is advisable to turn the scale on 1 to 2 m inutes prior to use.

Error M essages



The weight capacity of the scale has been exceeded.

W hen the battery voltage is less than 7V, LO appears in the LCD at the scale's startup - replace battery or use AC adapter.

M ake sure to rem ove exhausted battery as old batteries leak.

Lim ited W arranty

This Postalscale is warranted to be free of defects in parts and workmanship for a period of one year from the time of purchase by the original owner. Many problems can be solved by yourself when you read the detailed instructions on our website. If this product is found to be defective, Motion Marketing will repair or replace defective parts at no charge, subject to the following conditions:

- 1.) Ownermustrequesta return authorization from Motion Marketing please fillup the webform boated at www.motionmarketinginc.com
- 2.) Ownerm ust include verification of the date of purchase when requesting Limited Warranty Service. Copy of Dated Sales Receipt Required)

www motionmarketinginc.com

em ail: service@ m otionm arketinginc.com

Phone Number: 913-631-4402