




by Schneider Electric

# Installation

## MGE™ Galaxy™ 3500 10-40 kVA 380/400/415 V with batteries



### IMPORTANT SAFETY INSTRUCTIONS SAVE THESE INSTRUCTIONS



**Warning:** ALL safety instructions in the Safety Sheet (990-2940) must be read, understood, and followed when installing the UPS system. Failure to do so could result in equipment damage, serious injury, or death.



**Warning:** After the UPS has been electrically wired, do not start it up. Start-up is commissioned to authorized personnel from Schneider Electric.



**Caution:** All electrical power and power control wiring must be installed by a qualified electrician, and must comply with local and national regulations for maximum power rating.



**Note:** Ensure that the unit is in its final location prior to installation.



**Note:** Battery and utility/mains power must not be connected until all other wiring has been completed.




**See Also:** For parallel configurations see manual 990-3568.

## Level the Enclosure



**Warning:** The system must be installed on a level floor. The leveling feet will stabilize the enclosure, but will not account for a badly sloped floor.



1 Use a 13/14 mm wrench to adjust the four leveling feet.

2 Ensure that the system is level.




**Caution:** Do not move the enclosure after the leveling feet have been lowered.

## Floor Anchoring (if applicable)

### Anchor the UPS enclosure to the floor



**Note:** Floor-anchoring bolts are not provided with the UPS. Purchase the bolts locally (minimum size: M8). Follow the specifications given by the manufacturer of the floor anchoring system when bolting the UPS system to the floor.




1 Reuse the two transport brackets (one on each side) that were used to secure the UPS to the pallet during transport.


2 Drill two to six holes in the floor for each bracket. Attach with bolts.

## Prepare for Cables

### Bottom cable entry



1 From the rear of the UPS, loosen the six M4 screws from the upper cover (the cable landing area) on the back and remove.



2 Route the cables from the slanted back plate, up through the punched bracket, and into the cable landing area.

3 Fasten the cables with cable ties



**Note:** A conduit box (part no. SUVTOPT001 or SUVTOPT002) is available as an option.



## Connect the AC Input and AC Output Cables




**Warning:** Use compression type lugs **ONLY**. Do not loosen or add cables to any factory preinstalled cables on busbars. Use the front part of busbar for connection only.





**See Also:** For different grounding configurations please see manual 990-3606.

### Single mains




- ➊ Connect the AC input cables and the neutral to the input cable landings.
- ➋ Connect the AC output cables and the neutral to the output cable landings.
- ➌ Connect the ground cables to the studs (earth symbol beneath) using a screw.

### Dual mains



- ➊ Remove the three busbars A, B, and C by removing two M6 screws from each busbar.
- ➋ Connect the AC input cables and the neutral to the input cable landings.
- ➌ Connect the bypass cables and the neutral to the bypass cable landings.
- ➍ Connect the output cables and the neutral to the output cable landings.
- ➎ Connect the ground cables to the studs (earth symbol beneath) using a screw.

## Connect the DC Battery Cables (if applicable)



- ➊ Connect battery cables BAT+, BAT-, and N to the battery cable landings.

## Connect the Communication Cables



**Warning:** Make sure that the UPS is completely OFF as the connectors are very close to the power busbars.

### J106 (XR Battery Enclosure) and J108 (EPO)



**Note:** Use only 1-1½ mm<sup>2</sup> copper wire for the connection of the Emergency Power Off (EPO) and other optional equipment.




**Note:** The UPS must be connected to either a dry contact or a 24 VDC EPO (Emergency Power Off) switch.



**Note:** The external EPO +24 VDC, 1500 mA circuit can be supplied through other vendors.



**Note:** Always follow the pin connection procedures from the top and work down: J106 (8-1), J108 (1-6).




- ➊ **J108 pin connections:**
  - 1 Normally open EPO
  - 2 Normally open EPO return
  - 3 Normally closed EPO
  - 4 Normally closed EPO return
  - 5 +24 V SELV supply
  - 6 SELV ground

- ➋ **J106 pin connections:**
  - 8 Ext. charging control return
  - 7 External control of charging
  - 6 Q3 active return
  - 5 Q3 active
  - 4 Battery measurement supply\*
  - 3 Battery unit quantity\*
  - 2 Max. battery temperature\*
  - 1 Battery measurement return\*


\* Should be used with MGE Galaxy 3500 XR Enclosures

**EPO wiring – pin connections J108.** Connect the EPO cable using one of the following four wiring configurations.




**1: Dry Contacts Normally Open**

EPO is activated when pin 1 is connected to pins 3 and 5.  
Connections: 2-4-6, 3-5 and 1 (—/—)




**2: +24 V Normally Open**

EPO is activated when an isolated SELV 24 VDC voltage is supplied on pin 1 with reference to pin 2.  
Connections: 3-5 and 4-6.




**3: Dry Contacts Normally Closed**

EPO is activated when a connection from pin 3 to pin 5 is opened.  
Connections: 4-6.



**4: +24 V Normally Closed**

EPO is activated when a SELV 24 VDC voltage is removed from pin 3 with reference to pin 4.



**Note:** When connecting the Q3 auxiliary signal, use gold-plated N/C auxiliary switch.



**Note:** Reinstall the cable landing cover.

**Connect APC communication options**




**Note:** The cable routing of the power chute software and the temperature sensor is identical.



**Note:** The temperature sensor is provided in a plastic bag attached to the front of the UPS behind the front panel.

**Front panel removal.**




**1** Use a coin or similar to turn the two black lock devices on either side of the display in the direction of each other to a vertical position.

**2** Push the front panel upwards and pull it outwards to disengage the locking device at the top of the enclosure.

**3** Lift the front panel free of the two slots at the bottom of the enclosure.


**Pin connections J106 (UPS).**



Pins 1 to 4 are for battery measurement (only applicable to MGE Galaxy 3500 XR Battery Enclosures (see J200 drawing).

Pins 5 and 6 are for external maintenance bypass Q3 (auxiliary switch N/C type).  
When Q3 is closed, signals are fed back to the UPS controller (see Q3 drawing).

Pins 7 and 8 are for external charge control. When 7 and 8 are closed, the UPS charges batteries with a pre-defined percentage (0-25-50-75-100%) of the maximum charging power. To be used in generator applications, or if special codes require control of charging.  
When Q3 is closed, signals are fed back to the UPS controller.



- ④ Remove the two screws from the cable-inlet at the front and remove the cable-inlet plate.
- ⑤ Guide the cable through the hole in the bottom plate and up through the cable-inlet.
- ⑥ Guide the cable through the side panel hole and run the cable upwards inside the panel.
- ⑦ Pull the cable out of the side panel through the hole closest to the Network Management Card area.
- ⑧ Plug the cable into the probe socket / PowerChute inlet.
- ⑨ Reattach the cable-inlet plate (④).

## Specifications



**Warning:** The UPS must be supplied from a 380/220 V, 400/230 V or 415/240 V L1, L2, L3, N, PE, 50 Hz.

### AC input

UPS ratings	10 kVA		
	380 V	400 V	415 V
Input frequency (Hz)	40-70	40-70	40-70
Nominal input current (A) <sup>1</sup>	13.0	12.3	11.9
Max. input current (A) <sup>2</sup>	14.3	13.5	13.1
Input current limit (A) <sup>3</sup>	16.8	16.8	16.8

UPS ratings	15 kVA			20 kVA		
	380 V	400 V	415 V	380 V	400 V	415 V
Input frequency (Hz)	40-70	40-70	40-70	40-70	40-70	40-70
Nominal input current (A) <sup>1</sup>	19.4	18.5	17.8	26.0	24.7	23.8
Max. input current (A) <sup>2</sup>	21.4	20.3	19.6	28.6	27.2	26.2
Input current limit (A) <sup>3</sup>	25.2	25.2	25.2	33.8	33.8	33.8

UPS ratings	30 kVA			40 kVA		
	380 V	400 V	415 V	380 V	400 V	415 V
Input frequency (Hz)	40-70	40-70	40-70	40-70	40-70	40-70
Nominal input current (A) <sup>1</sup>	38.6	36.7	35.3	51.7	49.1	47.3
Max. input current (A) <sup>2</sup>	42.5	40.3	38.9	56.8	54.0	52.1
Input current limit (A) <sup>3</sup>	50.1	50.1	50.1	66.9	66.9	66.9

### AC output

UPS ratings	10 kVA		
	380 V	400 V	415 V
Nominal output current (A)	15.2	14.4	13.9

UPS ratings	15 kVA			20 kVA		
	380 V	400 V	415 V	380 V	400 V	415 V
Nominal output current (A)	22.8	21.7	20.9	30.4	28.9	27.8

UPS ratings	30 kVA			40 kVA		
	380 V	400 V	415 V	380 V	400 V	415 V
Nominal output current (A)	45.6	43.3	41.7	60.8	57.7	55.6

### Battery input

UPS ratings	10 kVA	15 kVA	20 kVA	30 kVA	40 kVA
Nominal voltage (V)	± 192	± 192	± 192	± 192	± 192
External battery fuse (A)	125	125	125	125	125
	1.6-1.75 V/cell (automatic, depending on load)				

## Bypass input

UPS ratings	10 kVA		
	380 V	400 V	415 V
Input frequency (Hz) <sup>4</sup>	50±10 or 60±10	50±10 or 60±10	50±10 or 60±10
Nominal input current (A) <sup>1</sup>	15.2	14.4	13.9

UPS ratings	15 kVA			20 kVA		
	380 V	400 V	415 V	380 V	400 V	415 V
Input frequency (Hz) <sup>4</sup>	50±10 or 60±10	50±10 or 60±10	50±10 or 60±10	50±10 or 60±10	50±10 or 60±10	50±10 or 60±10
Nominal input current (A) <sup>1</sup>	22.8	21.7	20.9	30.4	28.9	27.8

UPS ratings	30 kVA			40 kVA		
	380 V	400 V	415 V	380 V	400 V	415 V
Input frequency (Hz) <sup>4</sup>	50±10 or 60±10	50±10 or 60±10	50±10 or 60±10	50±10 or 60±10	50±10 or 60±10	50±10 or 60±10
Nominal input current (A) <sup>1</sup>	45.6	43.3	41.7	60.8	57.7	55.6

### Notes

<sup>1</sup> Input current based on rated load and batteries fully charged.

<sup>2</sup> Input current based on full battery recharge, nominal voltage and rated load.

<sup>3</sup> Current limitation through electronic current limiting is based on full battery recharge and low input voltage.

<sup>4</sup> Synchronization adjustable: ± 10Hz, ± 3Hz or ± 0.1Hz.

## Recommended current protection



**Note:** AC input/output over-current protection and AC input/output disconnect must be provided by the customer

	Q1 <sup>1</sup>	Q3	Q2
	Utility input	Bypass input	Output
10 kVA	16	16	16
15 kVA	25	25	25
20 kVA	35	35	35
30 kVA	50	50	50
40 kVA	63	63	63

<sup>1</sup> Required upstream current protection, mains input: gL type fuse.

## Recommended cable sizes



**Note:** The recommended cable sizes are based on an environment with an ambient temperature of 30°C.

	Mains input [mm <sup>2</sup> ]	AC output [mm <sup>2</sup> ]	Battery input [mm <sup>2</sup> ] 75°C Wire	Bypass input [mm <sup>2</sup> ]
10 kVA	2.5	2.5	50	2.5
15 kVA	6	6	50	6
20 kVA	10	10	50	10
30 kVA	16	16	50	16
40 kVA	25	25	50	25



**Note:** Use Molex lug type or equivalent, and crimp to manufacturer's specifications.



**Warning:** At 100% switch mode load, the neutral must be rated for 200% phase current.

## Minimum breaker settings

	800% overload bypass operation	150% overload normal/ battery operation	125% overload normal/ battery operation	Continuously
<b>10 kVA</b>				
Mains input	– <sup>1</sup>	–	–	16.4 A
Bypass input	121.5 A	–	–	16.7 A
Output	121.5 A	22.8 A	19 A	16.7 A
Duration	500 ms	60 s	10 min.	∞
<b>15 kVA</b>				
Mains input	– <sup>1</sup>	–	–	24.6 A
Bypass input	182 A	–	–	25.1 A
Output	182 A	34.2 A	25.4 A	25.1 A
Duration	500 ms	60 s	10 min.	∞
<b>20 kVA</b>				
Mains input	– <sup>1</sup>	–	–	32.5 A
Bypass input	244 A	–	–	33.4 A
Output	244 A	45.6 A	38 A	33.4 A
Duration	500 ms	60 s	10 min.	∞
<b>30 kVA</b>				
Mains input	– <sup>1</sup>	–	–	49.1 A
Bypass input	364 A	–	–	50.1 A
Output	364 A	68.4 A	57 A	50.1 A
Duration	500 ms	60 s	10 min.	∞
<b>40 kVA</b>				
Mains input	– <sup>1</sup>	–	–	65.6 A
Bypass input	487 A	–	–	66.9 A
Output	487 A	91.2 A	76 A	66.9 A
Duration	500 ms	60 s	10 min.	∞

<sup>1</sup> At single feed use the higher value of mains and bypass.

## Recommended lug size and torque value



**Note:** Power terminal lug diameter: 6 mm. Torque value: 7 Nm.


# Contact Information

For local, country-specific centers: go to [www.apc.com/support/contact](http://www.apc.com/support/contact).

## Appendix

### Wiring diagrams

**Diagram with Maintenance Bypass Panel**



**Diagram without Maintenance Bypass Panel**

