

Pro Steam Travel Steam and dry iron

Instruction Booklet SR2300

Please read these instructions carefully and retain for future reference.



Contents

unbeam's Safety Precautions	3
eatures of your Travel Iron	4
Jsing your Travel Iron	6
Care and Cleaning of your Travel Iron	7

Important instructions – retain for future use.

تأكد من تفهّم احتياطات السلامة المذكورة اعلاه

請務必理解上述的安全預防措施。

Assurez-vous que les précautions ci-dessus relatives à la sécurité sont bien comprises

Versichern Sie sich, dass die obenstehenden Sicherheitsmaßnahmen verstanden werden

Βεβαιώνετε πως οι παραπάνω προφυλάξεις ασφαλείας γίνονται κατανοητές

Pastikan bahwa tindakan-tindakan keselamatan seperti di atas dimengerti anda

Accertatevi che le suddette norme di sicurezza siano comprese a dovere

上記の注意事項をよくお読みになり、安全を御確認ください

Уверете се дека погоре споменатите мерки на претпазливост се добро разбрани

Asegúrese de que las precauciones de seguridad precedentes sean bien comprendidas

کاری بکنید که احتیاطهای بالا حتماً درك بشوند

ต้องแน่ใจว่า ข้อควรระวังเรื่องความปลอดภัยข้างต้น เป็นที่เข้าใจกันดี

Yukarda belirtilen güvenlik önlemlerinin anlaşıldığından emin olunuz

Xin kiểm chắc rằng những biện pháp làm an toàn kể trên được hiểu rõ

Sunbeam's Safety Precautions

SAFETY PRECAUTIONS FOR YOUR IRON

- Do not leave a hot iron within reach of children. If they come into contact with a hot iron it could lead to serious burns.
- Iron only on an ironing board.
- An iron takes approximately 30 minutes to cool down. Allow the iron to cool completely before storing.
- Do not wind the cord around the soleplate while the iron is still hot.
- The iron is not intended for frequent use.
- Do not leave the iron unattended while it is plugged into the power outlet.

- Always unplug the iron from the power outlet before filling or emptying the water tank.
 Always ensure that the iron is set to the correct.
- Always ensure that the iron is set to the correct voltage for the country of use before plugging it into the power outlet. Using an incorrect voltage may cause serious harm to your appliance.
- Always ensure that the iron has completely cooled before placing it in the travel pouch.
- The iron must be used and rested on a stable surface.
- When placing the iron on its stand, ensure that the surface on which the stand is placed is stable.
- The iron is not to be used if it has been dropped, if there are visible signs of damage or if it is leaking.

Sunbeam is very safety conscious when designing and manufacturing consumer products, but it is essential that the product user also exercise care when using an electrical appliance. Listed below are precautions which are essential for the safe use of an electrical appliance:

- Read carefully and save all the instructions provided with an appliance.
- Always turn the power off at the power outlet before you insert or remove a plug. Remove by grasping the plug - do not pull on the cord.
- Turn the power off and remove the plug when the appliance is not in use and before cleaning.
- Do not use your appliance with an extension cord unless this cord has been checked and tested by a qualified technician or service person.
- Always use your appliance from a power outlet of the voltage (A.C. only) marked on the appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- The temperature of accessible surfaces may be high when the appliance is operating.
- Never leave an appliance unattended while in use.

- Do not use an appliance for any purpose other than its intended use.
- Do not place an appliance on or near a hot gas flame, electric element or on a heated oven.
- Do not place on top of any other appliance.
- Do not let the power cord of an appliance hang over the edge of a table or bench top or touch any hot surface.
- Do not operate any electrical appliance with a damaged cord or after the appliance has been damaged in any manner. If damage is suspected, return the appliance to the nearest Sunbeam Appointed Service Centre for examination, repair or adjustment.
- For additional protection, Sunbeam recommend the use of a residual current device (RCD) with a tripping current not exceeding 30mA in the electrical circuit supplying power to your appliances.
- Do not immerse the appliance in water or any other liquid unless recommended.
- Appliances are not intended to be operated by means of an external timer or separate remote control system.
- This appliance is intended to be used in household and similar applications such as: staff kitchen areas in shops, offices and other working environments; farm houses; by clients in hotels, motels and other residential type environments; bed and breakfast type environments.

If you have any concerns regarding the performance and use of your appliance, please visit www.sunbeam.com.au or contact the Sunbeam Consumer Service Line. Ensure the above safety precautions are understood.

Features of your Sunbeam Travel Iron

റ്റ Powerful shot of steam

Pressing the shot of steam button instantly produces a powerful shot of steam to remove stubborn wrinkles.

Vertical shot of steam

Pressing the shot of steam button with the iron in an upright position produces a vertical shot of steam, which is ideal for refreshing hanging garments and delicate fabrics.

Steam/dry dial

Offers a choice of steam or dry ironing, making it suitable for use on a variety of fabrics.

Water inlet cover


The water inlet enables easy filling.

Non-stick soleplate

Glides easily across all types of fabric and prevents sticking.


Full length button groove

For ironing around buttons.



Thermostat light

Illuminates to indicate that the iron is heating and goes out when it has reached the temperature selected on the temperature dial. The thermostat light cycles on and off during ironing as the iron maintains the selected temperature.



Allows you to select the desired temperature for each garment. The adjustable temperature dial also indicates the recommended temperature setting for steam.

Using your Sunbeam Travel Iron

Before first use

Remove any adhesive stickers, plastic covers or cardboard sleeves from the soleplate. Ensure that all adhesive is removed by rubbing the soleplate with a cloth dampened with methylated spirits. Fill the water tank and empty the water. This will rinse out any foreign particles remaining in the water tank from the manufacturing process.

NOTE: When turned on for the first time, your new iron may give off vapours for up to 10 minutes. This is due to the initial heating of the materials used. It is safe, not detrimental to the performance of the iron, and will not reoccur.

Filling the iron with water

Before filling the iron with water ensure the power is turned off and the plug is removed from the power outlet. The iron can be filled with water when hot.

- 1. Turn the STEAM/DRY dial to DRY.
- Place the iron horizontally with the soleplate facing down and open the water inlet cover.

NOTE: Do not leave the iron unattended when the soleplate is facing down.

 Slowly pour water into the water inlet until the maximum water level is reached.
 Do not exceed the maximum water level indicator. Push the water inlet cover firmly to close.

NOTE: The special soleplate design allows you to use tap water with your Travel iron without affecting the steam performance. However in very hard water areas, Sunbeam recommend the use of distilled water, or water which has been demineralised.

For best performance, we recommend the use of Sunbeam Water Klean, available from Sunbeam Service Centres and selected retailers. This will produce up to 30 litres of demineralised water.


Do not fill the iron with fabric conditioner, starches or any other solution as these will damage the steam mechanism. Do not use contaminated water.

Using your iron

Always ensure that the iron is set to the correct voltage for the country of use before plugging it into the power outlet.

NOTE: Using an incorrect voltage may cause serious harm to your appliance. Ensure that you are aware of the required voltage before entering a new country.

1. Using a five cent coin or similar, turn the dual voltage selector (located at the base of the iron) so that the inverted groove is aligned with the desired voltage setting. (Figure 2 shows the voltage set to the 230-240V position.)



- 2. Insert the 3 pin plug into a power outlet and turn the power on.
- 3. Turn the temperature dial to the desired setting by aligning the setting on the dial with the temperature indicator. The thermostat light (positioned behind the temperature dial) will illuminate to indicate that the iron is heating to the selected temperature. When the thermostat light goes out the iron is at the selected temperature and is ready to iron.

NOTE: When the temperature dial is changed from a high setting to a lower temperature setting during ironing, the thermostat light will go out immediately. This indicates that the iron is cooling to the selected temperature. To ensure that the iron has reached the selected temperature and is not too hot, wait until the thermostat light comes on again and then goes out before ironing.

Dry ironing

Follow steps 1 to 3 on page 6 under "Using your iron".

 Select DRY on the STEAM/DRY dial. This will cut off the steam flow if there is water in the tank.

Steam ironing

Follow steps 1 to 3 on page 6 under "Using your iron".

NOTE: When steam ironing, ensure that the temperature dial is set to the three dot (•••) temperature setting, and that the tank is at least ½ full of water.

4. Select STEAM on the STEAM/DRY dial.

Using the shot of steam

The shot of steam can be used when dry or steam ironing, when the temperature dial is set to the three dot (•••) temperature setting.

- 1. Ensure the tank is at least ¼ full of water.
- Select the three dot (•••) temperature setting and wait until the thermostat light goes out.
- 3. Press the shot of steam button several times with the iron on the soleplate to prime the pump.


NOTE: If the tank has run dry, it may be necessary to re-prime the pump after filling the iron with water.

After each use

- 1. Turn the STFAM/DRY dial to DRY.
- 2. Turn the power off and remove the plug from the power outlet.
- Empty any remaining water from the water tank.
- 4. Allow the iron to cool before winding the cord around the soleplate or placing it in the travel pouch.

Storage

Always store the iron on its heel rest.



NOTE: Do not store the iron with the soleplate facing down, or in the carton.

Cleaning

To clean the exterior of your iron, wipe over with a damp soft cloth and wipe dry.

Caution: Do not use harsh abrasives, chemical cleaners or solvents to clean the exterior of your iron as these will damage the surface.

Cleaning the non-stick soleplate

The non-stick coating reduces sticking of fabrics and starches to the soleplate. Do not iron over sharp objects such as buttons, studs and zippers, as these will scratch the surface.

Wipe the soleplate with a damp soft cloth after each use. If polyester has burnt to the soleplate, iron a damp cotton cloth while hot.

Caution: Do not use scouring pads, abrasives or harsh cleaners to clean your non-stick soleplate, as these will scratch and damage the surface

To clean the steam holes

To remove build up from the steam holes which may affect steam performance, use a cotton wool tip moistened in methylated spirits.

Notes

Notes

Notes



2 Year Replacement Guarantee

In the unlikely event that this appliance develops any malfunction within 2 years of purchase (3 months commercial use) due to faulty materials or manufacture, we will replace it for you free of charge.

Should you experience any difficulties with your appliance, please phone our customer service line for advice on 1300 881 861 in Australia, or 0800 786 232 in New Zealand. Alternatively, you can send a written claim to Sunbeam at the address listed below. On receipt of your claim, Sunbeam will seek to resolve your difficulties or, if the appliance is defective, advise you on how to obtain a replacement or refund.

Your Sunbeam 2 Year Replacement Guarantee naturally does not cover misuse or negligent handling and normal wear and tear

Similarly your 2 Year Replacement Guarantee does not cover freight or any other costs incurred in making a claim. Please retain your receipt as proof of purchase.

The benefits given to you by this guarantee are in addition to your other rights and remedies under any laws which relate to the appliance.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law and under the New Zealand Consumer Guarantees Act.

In Australia you are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Should your appliance require repair or service <u>after</u> the guarantee period, contact your nearest Sunbeam service centre.

For a complete list of Sunbeam's authorised service centres visit our website or call:

Australia

www.sunbeam.com.au

1300 881 861

Units 5 & 6, 13 Lord Street Botany NSW 2019 Australia

New Zealand

www.sunbeam.co.nz

0800 786 232

26 Vestey Drive, Mt Wellington Auckland, New Zealand



Need help with your appliance?

Contact our customer service team or visit our website for information and tips on getting the most from your appliance.

In Australia

Visit www.sunbeam.com.au Or call 1300 881 861

In New Zealand

Visit www.sunbeam.co.nz Or call 0800 786 232



Sunbeam is a registered trademark.

'Pro Steam' is a trademark of Sunbeam Corporation.

Made in China.

Due to minor changes in design or otherwise, the product may differ from the one shown in this leaflet.

© Copyright, Sunbeam Corporation Limited 2010.

ABN 45 000 006 771

Units 5 & 6, 13 Lord Street

Botany NSW 2019 Australia

Unit 3, Building D

26 Vestey Drive

Mt Wellington Auckland

New Zealand

Sunbeam Corporation is a division of GUD Holdings Ltd.