



K352

user guide

User Guide for the K352 Phone

This manual is based on the production version of the Kyocera K352 phone. Software changes may have occurred after this printing. Kyocera reserves the right to make changes in technical and product specifications without prior notice. The products and equipment described in this documentation are manufactured under license from QUALCOMM Incorporated under one or more of the following U.S. patents:

4,901,307 5,109,390 5,267,262 5,416,797 5,506,865
5,544,196 5,657,420 5,101,501 5,267,261 5,414,796
5,504,773 5,535,239 5,600,754 5,778,338 5,228,054
5,337,338 5,710,784 5,056,109 5,568,483 5,659,569
5,490,165 5,511,073

Other patents pending.

The Kyocera Wireless Corp. ("KWC") products described in this manual may include copyrighted KWC and third party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for KWC and third party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software contained in the KWC products may not be modified, reverse engineered, distributed or reproduced in any manner not permitted by law. Furthermore, the purchase of the KWC products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents or patent applications of KWC or any third party software provider, except for the normal, non-exclusive royalty-free license to use that arises by operation of law in the sale of a product.

Kyocera is a registered trademark of Kyocera Corporation. Brick Attack™ is a trademark of Kyocera Wireless Corp.

QUALCOMM is a registered trademark of QUALCOMM, Inc. eZiText is a registered trademark of Zi Corporation.

All other trademarks are the property of their respective owners. Copyright © 2006 Kyocera Wireless Corp. All rights reserved. Ringer Tones Copyright © 2000-2002 Kyocera Wireless Corp.

82-G1655-1EN, Rev 002



"This device complies with the standards of Anatel Agência Nacional de Telecomunicações". Operation is subject to 2 conditions: (1) this device may not cause harmful interference; and (2) this device must accept any interference received, including interference that may harm its operation.

To maintain the compliance with Anatel's radiofrequency exposure standards, if you use the handset next to your body, use the Kyocera Wireless of Brazil (KWB) supplied and approved holster CV90-B1753-01. The use of other accessories may not ensure compliance with radiofrequency exposure guidelines, SAR Resolution 303 of Anatel Agência Nacional de Telecomunicações.

THIS MODEL PHONE MEETS THE GOVERNMENT REQUIREMENTS FOR EXPOSURE TO RADIO WAVES.

Your cellular phone is a radio transmitter and receiver. It was designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by Anatel and by the Brazilian Government.

These limits are part of comprehensive standards and establish permitted levels of radio frequency energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations.

The standards include a substantial safety margin designed to assure the safety to all persons, regardless of age and health.

The exposure standard for wireless mobile devices employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by Anatel is 2.0 W/kg.*

Tests for SAR are conducted using standard operating positions specified by the standards of Anatel, with the phone transmitting at its highest certified power level, in all frequency bands.

Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating may be well below the maximum value. This is because the phone is designed to operate at multiple power levels, so as to use only the power required to reach the network. In general, the closer the telephone is to a radio base station, the lower the power transmitted.

Before a phone model is available for sale to the public, it must be tested, approved, and certified by Anatel that it does not exceed the limit of the government requirements related to safety in the event of exposure to interference. The tests are conducted in positions and locations (e.g., at the ear and used next to the body) specified by Anatel for each model. The highest values of the SAR for this phone model are described below in accordance with the technical certificate of compliance.

(The measurements of use next to the body differ according to the model phone, depending on the accessories available and the requirements of Anatel).

This phone was tested for operation next to the body and complies with the exposure specifications of Anatel RF when used with the Kyocera Wireless of Brazil (KWB) supplied and approved holster CV90-B1753-01 or when used with an accessory that does not contain metal and that positions the phone at a minimum of 15.0 mm from the body.

While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirements with regard to safe exposure.

Anatel has granted an equipment authorization for this model phone with all reported SAR levels evaluated as in compliance with the radio frequency emission guidelines of Anatel.

SAR information on this model phone is on file with Anatel and can be found at its web site. <http://www.anatel.gov.br>

Additional information on SAR values can be found on the web site of CTIA (Cellular Telecommunications and Internet Association), at <http://www.wow-com.com>.

* In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection to the public, and to account for any variation in measurement.

Caution

The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the warranty and user's authority to operate the equipment.

Optimize your phone's performance

Use the guidelines on Blueage to learn how to optimize the performance and life of your phone and battery.

Air bags

If you have an air bag, DO NOT place installed or portable phone equipment or other objects over the air bag or in the air bag deployment area. If equipment is not properly installed, you and your passengers risk serious injury.

Medical devices

Pacemakers—Warning to pacemaker wearers:

Wireless phones, when in the 'on' position, have been shown to interfere with pacemakers. The phone should be kept at least six (6) inches away from the pacemaker to reduce risk.

The Health Industry Manufacturers Association and the wireless technology research community recommend that you follow these guidelines to minimize the potential for interference.

Always keep the phone at least six inches (15 centimeters) away from your pacemaker when the phone is turned on.

Do not carry your phone near your heart. Use the ear opposite the pacemaker. If you have any reason to suspect that interference is taking place, turn off your phone immediately.

Hearing aids—Some digital wireless phones may interfere with hearing aids. In the event of such interference, you may want to consult your service provider or call the customer service line to discuss alternatives.

Other medical devices—If you use any other personal medical device, consult the manufacturer of the device to determine if it is adequately shielded from external RF energy. Your physician may be able to help you obtain this information.

In health care facilities—Turn your phone off in health care facilities when instructed. Hospitals and health care facilities may be using equipment that is sensitive to external RF energy.

Potentially unsafe areas

Posted facilities—Turn your phone off in any facility when posted notices require you to do so.

Vehicles—RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles. Check with the manufacturer of the device to determine if it is adequately shielded from external RF energy.

Blasting areas—Turn off your phone where blasting is in progress. Observe restrictions, and follow any regulations or rules.

Potentially explosive atmospheres—Turn off your phone when you are in any area with a potentially explosive atmosphere. Obey all signs and instructions. Sparks in such areas could cause an explosion or fire, resulting in bodily injury or death.

Areas with a potentially explosive atmosphere are often, but not always, clearly marked.

They include:

fueling areas such as gas stations

below deck on boats

transfer or storage facilities for fuel or chemicals vehicles using liquefied petroleum gas, such as propane or butane

areas where the air contains chemicals or particles such as grain, dust, or metal powders

any other area where you would normally be advised to turn off your vehicle engine

Use with care

Use only in normal position (to ear).

Avoid dropping, hitting, bending, or sitting on the phone.

Keep phone dry

If the phone gets wet, turn the power off immediately and contact your dealer. Water damage may not be covered under warranty.

Resetting the phone

If the screen seems frozen and the keypad does not respond to keypresses, reset the phone by completing the following steps:

Remove the battery door.

Remove and replace the battery.

If the problem persists, return the phone to the dealer for service.

Accessories

Use only Kyocera-approved accessories with Kyocera phones. Use of any unauthorized accessories may be dangerous and will invalidate the phone warranty if said accessories cause damage or a defect to the phone.

To shop online for phone accessories, visit www.kyocera-wireless.com/store.

To order by phone, call 800-349-4188 (U.S.A. only) or 858-882-1410.

Radio Frequency (RF) energy

Your telephone is a radio transmitter and receiver. When it is on, it receives and sends out RF energy. Your service provider's network controls the power of the RF signal. This power level can range from 0.006 to 0.6 watts.

Kyocera Wireless Corp.

10300 Campus Point Drive, San Diego, CA 92121
U.S.A.

Visit us at www.kyocera-wireless.com

CONTENTS



1	Getting Started	1	8	Connecting to the Internet	33
	Installing the battery	1		Using the WAP Browser	33
	Removing the battery	1	9	Using the Music Player	35
	Getting to know your phone	4		Putting music files onto the phone	35
	Main menu	6		Accessing songs	35
	Using this guide	6		Managing music player settings	36
	Performing basic functions	7	10	Accessing Multimedia Content	37
2	Making and Answering Calls	8		Accessing online games	37
	Making a call	8		Accessing pre-loaded games	37
	Answering calls	8		Accessing online sounds and images	37
	Speed dialing	10	11	Customizing Your Phone	39
	Setting up voicemail	11		Accessing the main menu	39
	Calling emergency services	11		Setting your menu style	39
	Customizing call settings	12		Setting sounds for your phone	39
3	Entering Text, Numbers, and Symbols	14		Personalizing the screen	41
	Text entry modes	14		Choosing a different language	43
	Quick reference to text entry	16	12	Using Voice Recognition	44
4	Storing Contacts	17		Using voice memos	45
	Creating a new contact	17	13	Utilities	46
	Editing or erasing a contact	19		Calendar	46
	Editing a phone number	19		Alarm Clock	46
	Searching the Contacts directory	20		Calculator	47
5	Sending and Receiving Text Messages	21		Stopwatch	47
	Sending text messages	21		Timer	47
	Retrieving text messages	22	14	Configuring Your Phone	48
	Customizing message settings	24		Managing network settings	48
6	Sending and Receiving Multimedia Messages	26		Creating a secure environment	49
	Sending multimedia messages	26	15	Getting Help	52
	Receiving multimedia messages	27		Customer support	52
	Viewing multimedia messages	28	16	Using the Camera	54
7	Managing Downloads	30		Index	56
	Downloading an application	30			
	Opening an application	31			
	Checking available memory	32			

1 GETTING STARTED

Installing the battery

Your phone comes with a rechargeable 850 mAh battery.

1. Hold the phone with the back facing you and pull downwards to slide the battery cover open.
2. Lift the cover off.
3. With the metal contacts pointing toward the bottom of the phone, insert the top of the battery in the phone casing, making sure the plastic tabs slide into the corresponding openings at the top.
4. Press down on the battery until it clicks into place.
5. Place the battery cover over the phone casing and slide it upward until it snaps into place.



3. Place your fingernail in the recess provided at the base of the battery housing and lift the battery out.





Charging the battery

You must have at least a partial charge in the battery to make or receive calls.


Fully charge the battery before using the phone.

To charge the battery, remove the silicone strip covering the jack on the bottom of the phone, connect the AC adapter to the jack, and then plug the adapter into a wall outlet.

The battery icon tells you whether the phone is:

- Charging (the icon is animated)
- Partially charged 
- Fully charged 

After the battery charging is finished, if the cell phone is in the power on state, then the screen will show “Charge completed”.



Removing the battery

1. Turn the cellular phone off.
2. Hold the phone with the back facing you and slide the battery cover open.

Recharging the battery

Recharge the battery only when the power has been depleted.

Note: Although the battery can be recharged, it has a certain service life. When the battery has been fully recharged but it lasts only for a short period, replace the battery.

Caring for the battery

General safety guidelines


















- Do not take apart, puncture, or short-circuit the battery.
- If you have not used the battery for more than a month, recharge it before using your phone.
- Avoid exposing the battery to extreme temperatures, direct sunlight, or high humidity.
- Never dispose of any battery in or near a fire—it could explode.

Common causes of battery drain

- Playing games.
- Keeping backlighting on.
- Operating in digital mode when far away from a base station or cell site.
- Using accessories.
- Operating when no service is available, or service is available intermittently.
- High earpiece and ringer volume settings.
- Repeating sound, vibration or lighted alerts.


Understanding screen icons

These icons may appear on your phone's home screen.

- | | | | |
|--|---|---|--|
|  | The phone is operating in IS2000 (1X) digital mode. |  | Indicates MP3 is not available. MP3 music will not play when the handset is in U-disk mode, a ringer or melody is playing or MP3 player initialization is not completed after powering up. |
|  | The phone is receiving a signal. You can make and receive calls. Fewer bars indicate a weaker signal. |  | Indicates MP3 hard keys are locked (any operation through these hard keys will be disregarded). Press and hold the camera key to unlock. |
|  | A call is in progress. |  | Indicates MP3 hard keys are locked after pressing and holding the camera key while MP3 player is paused. |
|  | The phone is not receiving a signal. You cannot make or receive calls. |  | Indicates MP3 is in pause state after pressing MP3 pause key while MP3 is playing. |
|  | The phone is roaming outside of its home service area. |  | Indicates MP3 hard keys are locked after long pressing the camera key while MP3 player is playing. |
|  | You have a message. | | |
|  | The battery is fully charged. The more black bars, the greater the charge. | | |
|  | The alarm clock is set. | | |
|  | The phone is in privacy mode. | | |
|  | The phone is set to light up instead of ring. | | |
|  | The phone is set to vibrate or to vibrate and then ring. | | |
|  | Indicates MP3 player is on. | | |

Getting to know your phone

1. Home screen.
2. **Play/Stop key** controls the MP3 Player.
3. **Previous song key** for listening to the previous song in the playlist.
4. **Left soft key** enters or executes the main menu from the home screen, or other functions as indicated on the screen.
5. **Send/Talk key** starts or answers calls and accesses the All Calls list.
6. **Navigation keys** scroll through lists, position the cursor during text entry, or access the main menu items to which you map them.
7. **Keypad** for entering numbers, letters, or symbols.
8. *** key** changes the text or symbol mode in text entry. Locks the keypad.
9. **0 key** adds a + needed for IDD dialing.
10. **Jack** for inserting charger or USB cable (included)*.




* **Warning:** Inserting an accessory into the incorrect jack will damage the phone.

11. **Record/Pause key** for recording voice memos or pausing the MP3 Player.
 12. **Next song key** for listening to the next song in the playlist.
 13. **OK key** selects a menu item or option.
 14. **Right soft key** connects to the WAP browser from the home screen. This key often acts as a Back key, but can function as indicated on the screen.
- Note:** In Downloads, this key acts as a Back key although there is no indication on the screen.
15. **End/Power key** turns the phone on and off. Ends a call.
 16. **# key** press and hold to set the phone to vibrate mode. Adds a space when in text entry.

- 17. **Jack for hands-free headset***
- 18. **Camera key** on the right side activates Camera mode and can also be used to take the picture.
- 19. **Mirror** for taking your own picture.
- 20. **Camera lens**
- 21. **Up and Down Volume control keys** adjust the earpiece or speaker volume or, in menu mode, scroll to select menu options.

* **Warning:** Inserting an accessory into the incorrect jack will damage the phone.



Main menu

The contents of the main menu are as follows:

Phonebook

Voice mail
Contacts
Memory Stat
Speed Dial
Information

Calls

All
Missed
Received
Sent
Call Settings
Call Time
Erase

Voice mail

Messages

New Message
Recvd Msgs
Sent Msgs
Voice mail
Msg Template
Svd Msgs
Drafts
Msg Settings

Downloads

Download Center
Settings
Help

WAP

Home
Favorites
Go To...
WAP Options
Information

Tones & Images

MP3 Player
Images
Tones
Memory
DCF Files

Entertain.

Brick Attack
Online Games
Information

My Movistar

Main Keys
Menu Style
Sounds
Display
Language
Silent Mode
Voice Dial
Key Guard

Utilities

Calendar
Alarm Clock
Calculator
Voice Memo
Stopwatch
Timer

Settings

Network
Security
Call Settings
Msg Settings
WAP Settings
Date/Time
Orig Setting
Mode Setting







Help


Cust Care Center
Int'l Roam
Phone Info
Icon Glossary

Camera


Capture
Settings
Camera Pictures
Last Picture
Memory Status





Navigating menus and options

- From the home screen, press  to enter main menu options.
- Press  left, right, up, or down to view menus and options and to highlight one.
- Press  or  to select a menu item.
- Press  to back up a menu level or screen.
- Press  to return to the home screen.
- In messaging, browser and downloads screens, a scroll bar on the right side of the screen indicates that there are more options or text.




















Press  down to go to the next option or screen of text.

Using this guide

In this guide, an arrow  tells you to select an option from a menu.

For example, **Menu**  **Messages** tells you to press the left soft key  to select **Menu** options, scroll up or down with the navigation key  to highlight the **Messages** option, and then press  to select it.


Performing basic functions

To...	From the home screen...
Turn the phone on	Press and hold  until the phone powers on.
Turn the phone off	Press and hold  until the phone starts chiming.
Make a call	Enter the number, then press  .
End a call	Press  .
Answer a call	Press  .
Access menu options	Press  .
Access voicemail	Press and hold  . Follow the system prompts.
Verify your phone number information	Select  Menu → Help → Phone Info .
Silence the ringer on an incoming call	Press  , then  to answer.
Access the WAP browser	Press  .
Access Tones & Images*	Press  left.
Access Calls*	Press  up.
Access My Movistar*	Press  right.
Access Phonebook*	Press  down.
Take a picture	Select  Menu → Camera → Capture .
Play a song	Press  . Press  or  to listen to the next or previous songs in the list. You must have music loaded onto the phone. (See page 35.)



*See "Mapping your main keys," on page 39 for information on mapping main menu items to the four navigation keys.

2 MAKING AND ANSWERING CALLS


Making a call

1. Make sure you are in an area where a signal can be received. Look for  on the home screen.

Note: The more bars you see in this symbol, the stronger the signal. If there are no bars, move to where the signal strength is better.



2. Enter the phone number.
3. Press .
4. When you are finished, press  to end the call.



Redialing a number

To redial the last number called, received, or missed, press  twice.

Calling a saved number

If you have already saved a phone number, you can use the Contacts list to find it quickly.



1. Press  to select **Menu** → **Phonebook** → **Contacts** → **View All**.
2. Scroll down the list to find the contact you want to call.
3. Highlight the name and press  to dial the number.

Note: If the contact has more than one phone number assigned to it, press  to select the contact's name, highlight the phone number you want to call, and press .

Answering calls


When a call comes in, the phone rings and a phone icon appears on the screen. The phone number of the caller also appears if it is not restricted. If the number is stored in your **Phonebook** directory, the contact name appears.

To answer the call:

- Press  or  to answer the incoming call.


To silence or ignore the call

When an incoming call is received, you can:


- Press  twice to reject the call.

Adjusting the volume during a call

To adjust the volume during a call:

- Press  up or down during a call to adjust the volume.

Options during a call









While you are in a call, you can press  to select from the following soft options without interrupting your call:

- **Contacts** opens your Contacts list.
- **Messages** opens the messages menu.
- **Mute/Unmute** silences the current call.
- **Send DTMF** enables the touch-tone option.
- **New Call** allows you to dial and add another caller to the current call.
- **Hand Free** turns on the speakerphone.
- **Long DTMF** allows you to switch between long and short touch-tones.
- **End Call** ends the current call.
- **Phone Info** accesses information about your phone.

Call waiting



You can answer a call while you are in a call.



Important: Check with your service provider for availability of this option.

- Press  +  or  to drop the first call and answer the second call.
- Press  +  to answer the call or to switch between the calls.
- Press  to select **Ignore** and ignore the call.
- Press  +  to connect all calls in a 3-way call.

Making conference calls

To initiate a 3-way conference call:





1. Call the first person (A).
2. Call the second person (B).
(A will be on hold.)
3. Press  +  to connect all calls.

Tip: To return to a 2-way call from a 3-way call: Press  +  to hang up with B and continue the call with A.

Important: The 3-way conference call function varies depending on your service provider. Check with your service provider for details.

Dealing with missed calls


When you have missed a call and the caller does not leave a voicemail a “Notification” message appears on the screen.

- To clear the screen, press  to select **Back**.
- To view details of the call:
 - Press  to select **View**.
 - Highlight the missed call number and press .
- To return the call, select **View**. Highlight the missed call number and press .

Recent calls


The recent calls list stores details on the last calls you made, received, or missed. The following icons identify the type of call:

 Outgoing call



 Incoming call

 Missed call


Viewing recent calls

1. Select **Menu** → **Calls**.
2. Select a list: **All**, **Missed**, **Received** or **Sent**.
3. Highlight a recent call and press  to select **View**.

Calling a recent call

1. Select **Menu** → **Calls**.
2. Select a list: **All**, **Missed**, **Received**, or **Sent**.
3. Highlight a recent call and press 
- or -
Press  thrice to select **View** → **Option** → **Call**.

Recent Call options


1. Highlight a recent call and press  twice to select **View** → **Options**.

Choose an option:

- **Call** Dials the phone number.
- **Save** Adds the phone number to the Contacts list.

- **Send SMS** Allows you to send a text message to the phone number.
- **Send MMS** Allows you to send an MMS message to the phone number
- **Erase** Erases the phone number from the list.
- **Erase All** Erases all the phone numbers in the list.



Erasing recent calls




1. Select **Menu** → **Calls** → **Erase**.
2. Select an option: **All**, **Received**, **Sent** or **Missed**.
Note: Select **Information** for a description of this function.
3. Press  to select **OK**.

Speed dialing

Speed dialing allows you to quickly dial a stored phone number. Use the digits keys 1–9 to represent different telephone numbers.

Add a speed dialing number to an existing contact:

1. Select **Menu** → **Phonebook** → **Speed Dial**.
2. Press  to select **Set** and enter the speed dial number you want to use for your contact
- or -
Press  twice to select **Set** → **Search** to look up a contact in the phonebook.

3. Select the contact you want and press  .
4. Highlight the contact's number to which you want to assign the speed dial number and then press  .
5. Press  two times. The speed dial list is displayed again, showing the speed dial location assigned to the contact.

Using speed dialing

To call a contact that has a speed dial location:


- From the home screen, press and hold the one-digit speed dial location.

Note: If the digit key is not configured to represent an existing contact number, then the cell phone will display “**No Speed #**”.

Setting up voicemail


Before your phone can receive voicemail messages, you must set up a password and record a personal greeting with your service provider.

When you have set up your voicemail, all unanswered calls to your phone are automatically transferred to voicemail, even if your phone is in use or turned off.


1. From the home screen, press and hold  .
2. Follow the system prompts to create a password and record a greeting.

Note: If you are having trouble accessing your voicemail, contact your service provider.


Checking voicemail messages

When a voice message is received, your screen displays “**You have X voicemail(s)**” along with the  symbol at the top of your screen. The symbol flashes if the message is urgent.



If you see “You have X voicemail(s)”

1. Press  to select **Options** → **Call** to call your voicemail number.
2. Follow the prompts to retrieve the message.

To clear the screen without checking messages:

- Press  to select **Back** and return to the main menu.


Silencing an incoming call

- To silence an incoming call quickly, press  .
- Then press  to answer the call.

This action silences the current call only. The next call rings as normal.

Calling emergency services

Note: Regardless of your 3-digit emergency code, your phone operates as described below.



- Dial your 3-digit emergency code and press  .

You can call the code even if your phone is locked or your account is restricted. When you call, your phone enters **Emergency callback mode**.

This mode enables the emergency service exclusive access to your phone to call you back, if necessary. To make or receive regular calls after dialing the code, you must exit this mode.


To exit Emergency mode

When you have completed the emergency call:

1. Press  to select **Exit**.
2. Press  again to confirm your choice.

Tracking calls

You can track the number and duration of calls made and received on your phone.

1. Select **Menu** → **Calls** → **Call Time**.
2. Press  to select a timer:
 - **Last Call** tracks the last call you made since you last reset this timer.
 - **Received** tracks incoming calls you have received since you last reset this timer.
 - **Sent** tracks outgoing calls you have made since you last reset this timer.
 - **Life Time** tracks all calls you have made and received.

Timing your calls

You can set your phone to beep 10 seconds before each minute that passes when you are on a call.

Select **Menu** → **My Movistar** → **Sounds** → **Alerts** → **Minute Beep** → **Enable**.

Customizing call settings

You can enable or disable various call settings on your K352. These settings are available from:

Menu → **Calls** → **Call Settings** and/or
Menu → **Settings** → **Call Settings**.

Setting call waiting

You can enable or disable call waiting on your phone. For more information, see “Call waiting” on page 9.

- From **Call Settings** → **Call Waiting**, select one of the following options:
 - **Enable** applies the call waiting feature.
 - **Disable** turns off the call waiting feature.

Setting call forwarding

You can choose to forward all incoming calls to your voicemail or a separate designated phone number.

Important: Check with your service provider for availability of this option.

To use this feature:

1. From **Call Settings** → **Call Forward**, select one of the following options:
 - **Unconditional** to forward all incoming calls.
 - **Busy** to forward all incoming calls when the line is busy.
 - **No Answer** to forward incoming calls when there is no answer

2. Press **OK** to select:
 - **Enable** Then, select **Voicemail** or **To Phone #**. If you select **To Phone #**, you must enter the telephone number to which you wish to forward incoming calls.
 - **Disable** turns off the selected call forward setting.


Setting call restriction preferences

You can choose to prevent incoming or outgoing calls from your phone.

1. From **Call Settings** → **Call Restrctn**, select one of the following options:
 - **Received** restricts all incoming calls.
 - **Sent** restricts all outgoing calls.
2. Press **OK** to select:
 - **Enable** applies the call restriction that you choose.
 - **Disable** turns off the call restriction setting.

Setting the phone to answer mode

You can set your phone to answer a call in several ways.

- From **Call Settings** → **Answer Mode**, select an option:
 - **Press Send** sets the phone to answer as soon as you press .
 - **Press any key** sets the phone to answer an incoming call when you press any key.

- **Auto Answer** allows the phone to answer an incoming call automatically when using a headset.

Setting Auto Redial

You can set your phone to automatically redial a number if you get a busy signal.

- From **Call Settings** → **Auto Redial**, select one of the following options:
 - **Enable** applies the setting.
 - **Disable** turns off the setting.

3 ENTERING TEXT, NUMBERS, AND SYMBOLS

You can enter letters, numbers, and symbols in contacts, text messages, and your banner.

Text entry modes

There are six text entry modes:

- Numbers only 123
- Normal alpha ABC, abc, Abc
- Rapid Entry EN (EN, En, en) or SP (SP, Sp, sp)
- Add Symbols

Note: The mode you start in depends on the task you are doing. For example, when entering a phone number, you're in number mode. When entering a name for a contact, you're in normal text mode.

123 Entering numbers

- To enter a number while in 123 mode, press a number key once.








ABC Entering words letter by letter

Use normal alpha to enter letters.


- Press a key once for the first letter, twice for the second letter, and so on. Accented letters are available.

Entering words quickly

When you press a series of keys using **EN**, **En** or **en** mode, the phone checks its dictionary of common words and guesses at the word you are trying to spell.



1. Press and hold  to access **EN (EN, En, en)** or **SP (SP, Sp, sp)** mode.
2. For each letter of the word you want, press the key once. For example, to enter the word “uma” press:  →  → .
3. If the word doesn't match what you want, press  right to look at other word matches. Press  left to go back a word.
4. When you see the word you want, press .

Entering symbols

While entering text, you can enter symbols by pressing , such as:

• & @ , 1 ' : ?

For entering more symbols:


1. Press  to select **Options** → **Insr Sym**.
2. Press  to scroll through the list.
3. Press the corresponding number key for the symbol you want.

Changing modes


Sometimes you need to change modes.

For example, to enter numbers in an email address while in **ABC** mode, you must change to **123** mode, enter the numbers, and then change back to **ABC** mode to complete the address.

To change text entry modes:














- Press  until the icon for the mode you want appears.

Capitalization settings

You can change capitalization at any time while entering text. Press (but do not hold)  to choose upper case (**ABC**), sentence case (**Abc**) or lower case (**abc**) while in Normal Alpha mode.

Quick reference to text entry

This table gives general instructions for entering letters, numbers, and symbols.

To...	Do this...
Enter a letter	Use ABC mode and press a key until you see the letter you want. For more information, see page 14.
Enter a number	Use 123 mode and press a key once to enter its number. For more options, see page 14.
Enter a symbol	Press  to select Options → Insrt Sym . Press  up or down to find the symbol you want, then press the key corresponding to the number for the symbol.
Enter a space	Press  .
Erase a character	Press  .
Erase all characters	Press and hold  .
Move the cursor right or left	Press  right or left.
Move the cursor up or down	Press  up or down.
Change text entry modes	Press and hold  .
Capitalize any letter	In abc mode, press  . Choose ABC .
Lowercase any letter	In ABC mode, press  . Choose abc .
Use sentence case	In ABC or abc mode, press  . Choose Abc .
Select soft options on the screen	Press  or  .





4 STORING CONTACTS

Use your phone's **Phonebook** to store information about a person or company in the contacts directory. Your phone can hold, on average, approximately 500 phone numbers.


Creating a new contact

1. Select **Menu** → **Phonebook** → **Contacts** → **Add New**.


Note: To save a contact after entering the number on the home screen, enter the phone number you want to save including the area code, then select **Options** → **Save Number**, and skip to step 3.

2. Select **Options** → **Edit**.
3. Enter the name of the contact. If you need to learn how to enter letters, see page 14.
4. Press  to select **Options** → **Save and exit**.
5. To add numbers to a contact, press  down to select the type of number: **Mobile**, **Work**, **Home**, **E-mail**, or **URL**, and press  to select **Options** → **Edit**.
6. Enter the contact's number and press  to select **OK**.

Note: You can choose to save now or add more information.

7. To save, press  to select **Options** → **Save**. To add more information, see “Adding more contact information” on this page.

Adding more contact information

1. Locate the contact you wish to edit. See “Searching the Contacts directory” on page 20.
2. Highlight the contact's name and press .
3. Highlight the type of information you wish to modify. The options are:

Name

Group

Mobile



URL



Work



Memo



Home



Address



Email 1






Fax



Email 2








4. Press  to select **Options** → **Modify**.
5. Enter the contact's information and press  to select **Options** → **Save and exit**.
6. Press  and select **Options** → **Save**.

Adding a code or extension

When you save the phone number of an automated service, you may include a pause where your phone would stop dialing; for example, where you would wait to dial an extension.

Note: You can also choose to insert a **Time pause** to stop dialing for two seconds and then continue.





1. Enter the first portion of the phone number.
2. Press  to select **Options**:
 - **Hard Pause, P** will appear.
 - **Time Pause, T** will appear.
3. Enter the remaining numbers.
4. Press  to select **Options** → **Save Number**.
5. Enter the contact's name and press  to select **Options** → **Save and exit**.
6. Press  down to add more information to this contact, or press  to select **Options** → **Save**.

Organizing contacts

You can organize your contacts by placing them either in the available group lists or in custom groups that you can create.

Adding a contact to a group



You can classify a contact into a group list.

1. Locate the contact you wish to add. See “Searching the Contacts directory” on page 20.
2. Highlight the contact and press .
3. Select **Group Default** and press  to select **Options** → **Modify**.
4. Select your desired group from the list and then press .
5. Press  to select **Options** → **Save**.

Creating groups


You can create and save additional custom group lists.

Note: The maximum number of recipients in all the lists combined is 500.

1. Select **Menu** → **Phonebook** → **Contacts** → **Groups**.
2. Press  to select **Option** → **Add New**.
3. Enter a name for the list. For help entering text, see “Entering Text, Numbers, and Symbols” on page 14.
4. Press  to select **Save and Exit**.

Group options



You can manage your groups by assigning icons, ringers, renaming or deleting them.

1. Select **Menu** → **Phonebook** → **Contacts** → **Groups**.
2. Select the group list that you want and press  to select **Options**.
3. Choose an option:
 - **List** view the contacts in the selected group list.
 - **Icons** change the icon of the selected group list.
 - **Ringer** assign a ringer type to the contacts of the selected group list.
 - **Rename*** change the name of a group list that you have created before.
 - **Add New** create a new name for the selected group list.
 - **Erase*** erase a group list that you have created before.



Note: *These options are available only for groups that you have created; pre-listed groups cannot be deleted or renamed.

Editing or erasing a contact




To make changes to a contact, take these steps:



1. Select **Menu** → **Phonebook** → **Contacts** → **Search**.
2. Locate the contact to edit and press .
3. Press  to select **Options**.



The choices are:

- **Modify** make changes to the selected item.
 - **Save** save the contact record.
 - **Erase** erase the entire contact.
 - **Send SMS** send a text message to the contact.
 - **Send MMS** send a multimedia message to the contact. (This option is available when a contact number or email address is highlighted).
 - **Add Voice** record a voice dial tag.
 - **Select Picture** add a picture to the contact.
 - **Launch Web** access the contact's designated URL.
 - **Ringer** assign a ringer to the contact.
4. Highlight an option and press  to select it.
 5. After completing all selections and edits, press  to save.

Editing a phone number

1. Select **Menu** → **Phonebook** → **Contacts**.
2. Locate the contact to edit and press .
3. Press  down to select the number you want to modify and press  to select **Options** → **Modify**.

Note: Press  left or right to skip a digit of the phone number. Press  to erase a digit.


4. Press  to select **OK**.
5. Press  or select **Options** → **Save**.

Searching the Contacts directory


To view contacts quickly:

1. Select **Menu** → **Phonebook** → **Contacts** → **View All**.
2. Scroll down the list until you locate the contact you want.


To search for a particular contact by name, number or group:

1. Select **Menu** → **Phonebook** → **Contacts** → **Search**.
2. Select the type of search, enter the search information and press  to select **OK**.

The options are:


- **Name Search** enter the name, or first few letters of the contact's name.
 - **Number Search** enter the contact's phone number.
 - **Group Search** highlight the group name.
3. Scroll until you find the name you want, then press .

Contact Options

The following options are available when you select a contact and press  :

- **Modify** to edit the highlighted information.
- **Save** to save the contact information.
- **Erase** to erase the contact information.
- **Send SMS** to send a short text message.

- **Send MMS** send a multimedia message to the contact. (This option is available when a contact number or email address is highlighted).
- **Add Voice** to add a voice dial tag for this contact.
- **Select Picture** to assign a photo to this contact.
- **Launch Web** to launch the contact's web page.
- **Ringler** to assign a ringler to this contact.

Note: To call the contact, highlight a phone number and press .

5 SENDING AND RECEIVING TEXT MESSAGES

This chapter describes how to send, receive, and erase text messages from your phone. For information on voicemail messages, see page 11.

Important: The features and menus described in this chapter may vary depending on services available in your area. In addition, usage charges may apply to each message. For details, check with your service provider.

Sending text messages



Enter the recipient's number or search for the recipient's number in the Contacts directory to send the message. It can be sent to a group of up to 30 phone numbers simultaneously. You can only send text messages to phones that are capable of receiving them.


Creating a new text message

1. Select **Menu** → **Messages** → **New Message** → **New SMS**.




Note: Select the **Information** option for a description of this feature.

2. Enter the text message.


Note: To add prewritten text, select **Options** → **Insert Template**. Press  up or down to choose your prewritten text and then press  to add the text to the message.

3. Once you have completed the message, press  to select **Options**.




Select one of the following:

- **Send** to send your message. See step 4.
 - **Insert Template** to insert pre-written text in your message.
 - **Save to Drafts** to save the message in your Drafts folder.
 - **Save to Saved** to save the message in your Saved messages folder.
 - **Insrt Sym** to select a symbol from the symbols list and insert it into the message.
 - **Enter Number** to select a phone number in the Contacts directory and insert it into the message.
 - **Insert Mode** to select a text entry mode for entering the message. See Chapter 3 on page 14.
 - **Priority** to select normal or urgent priority.
 - **Back** to return to the **New Message** menu without saving.
4. If you select **Send**, you are taken to the **Receiver** screen to enter your contact's phone number.
 - Press  to select **Search**. Highlight the contact's name and press . If the contact has multiple phone numbers, you also need to select the number you want and press .
 5. To add another recipient to this message, scroll to the next line in the **Receiver** screen and repeat step 4.

Note: You can send a message to up to 30 contacts at once. The messages are sent one at a time, once to each recipient.

- When you have completed entering recipients, press  to select **Send**.



Receiving incoming calls while creating messages

- When you receive a call the phone will return to the home screen. If you don't want to answer the call, select . The message is saved and you can return to the message screen.
- To answer the call, press . When you finish the call, press . The message is saved in the **Drafts** folder and you can return to the home screen.


Retrieving text messages

When a text message is received, your screen displays “X New Message(s)”, along with the symbol at the top of your screen.

If you see the “X New Message(s)” note


You can view the message by pressing , or ignore the message by pressing  and return to the main menu.


If you see the symbol



If you see the  symbol flashing, the message is urgent.

- Select **Menu** → **Messages** → **Rcvd Messages**.

A list of all your received messages appears.


 indicates a new, unread message.

 indicates a read message.

- Press  up or down to scroll through the list of messages.
- Press  to select **Read**. The message is displayed.

Reading the message




Note: The options available to you may vary. Check with your service provider.

- If the text message is long, press  down to view the entire message.
- When you have finished viewing the message, you can select from the following **Options**:
 - Reply** to reply to the sender.
 - Reply With Copy** to reply to the sender and copy.
 - Forward** to forward the message.
 - Erase** to erase the message.
 - Erase All** to erase all the unprotected messages.
 - Call Back** to call the sender of the message.
 - Save Numbers** to save the sender's phone number in your Contacts list.
 - Save to Saved** to save the message to the Saved messages folder.
 - Extract URL** to extract the URL.
 - Protect** to prevent the message from being accidentally deleted. The **Unprotect** option is available when the message is already protected.

3. Follow the prompts depending on your selection above.

Viewing messages

You can view, save, protect or delete messages stored on your phone in the Sent, Saved and Drafts folders.

1. Select from the following message lists:
 - To access the **Sent** messages list, select **Menu** → **Messages** → **Sent Msgs.**
 - To access the **Saved** messages list, select **Menu** → **Messages** → **Svd Msgs.**
 - To access the **Drafts** folder, select **Menu** → **Messages** → **Drafts.**
2. Press  up or down through the list of messages.
3. Press  to select **Read**. The message details are displayed.
4. Press  to select **Options**.

Your options are:





- **Forward** to send the message to another recipient.
- **Erase** to delete the message.
- **Erase All** to delete all the unprotected messages.
- **Save to Saved** to save the message to the Saved messages folder.
- **Protect** to protect the message from being accidentally deleted. The **Unprotect** option is available when the message is already protected.

- **Status** to view the status of the message and any error messages. (This option appears when there is an error or message that could not be sent.)

Creating and editing prewritten messages (Templates)

Your phone comes with prewritten (Template) messages, such as “Please call me back,” that you can insert into the body of a text message. You can create new ones. Your phone stores up to 22 Auto Text messages, with up to 160 characters per message.

To create or edit templates:

1. Select **Menu** → **Messages** → **Msg Template** → **SMS**.
2. Highlight a template and press  twice to select **OK** and then make your edits.
3. Press  and then press  to select an option.
 - **Send** allows you to enter a recipient's number, or press  in the Receiver screen, to select **Search** and enter a recipient from the Contacts list.
 - **Save to Draft** allows you to save your text message in your draft folder.
 - **Enter Number** allows you to include a phone number in your message.
 - **Insert Template** allows you to insert a pre-written template.

- **Insert Mode** accesses the templates list where you can select another template to insert in the current one.
- **Modify** saves the modified template in the templates folder.

Note: For help entering text, see page 14.

Customizing message settings

To make messaging easier, you can customize settings for sending and receiving messages.

You can enable or disable various message settings on your K352. These settings are available from:

- **Menu** → **Messages** → **Msg Settings**.
and
- **Menu** → **Settings** → **Msg Settings**.

Incoming message settings

- From the **Msg Settings** menu, select **Incoming**. The following options are available:
 - **Auto Erase** when the total number of messages reaches 200, this enables the phone to receive a new message by deleting the oldest message. (The erase order proceeds from Sent, Drafts, Saved and Inbox lists).
 - **Reminder** choose how often you wish to be alerted of incoming messages. Select **Off** to disable this option.
 - **Auto Retrieve** enable this option to automatically receive and download text and multimedia messages.

Setting message alerts

You can set your phone to alert you of incoming text messages or pages. For more information, see “Setting message alerts” on page 41.

Outgoing message settings


- From the **Msg Settings** menu, select **Outgoing**. The following options are available:
 - **Priority** set normal or urgent priority for your outgoing messages.
 - **Delvry Notic** enable this option to receive notification of message delivery.
 - **Saved Msgs** choose whether to save your outgoing messages to the Saved Messages folder, or to be prompted to save when you send a multimedia message.
 - **Call Back** enter a call back number to include with the message to let recipients know at what number they can call you back.
 - **Signature** enable this option to include your signature in all outgoing messages. See “Adding your signature” on this page.

Adding your signature

The signature you create is included at the end of outgoing messages when the signature option is enabled. See “Incoming message settings” on page 24. However, it does not appear in the message creation screen.


To create a signature:


1. Select **Menu** → **Messages** → **Msg Settings** → **Signature**.

2. Enter your signature in the Content field.
3. Press  to select **OK** → **Save and Exit**

Note: The characters in the signature are included in the total character count of the message.

Setting the insert mode

You can set the initial text entry mode for messaging. This mode can be changed in a text entry screen by pressing the  key. See page 14 for more information.

1. Select **Menu** → **Messages** → **Msg Setting** → **Insert Mode**.
2. Highlight the mode you want and press  to set it.

Checking available memory




To check available memory, select **Menu** → **Messages** → **Msg Settings** → **Memory** and select a folder. The number of used messages is displayed.

Erasing messages

Your phone is designed to store 200 text messages. It's a good idea to erase old messages, as messages take up memory in your phone.

You have the option of erasing text messages as you send or read them, erasing them one at a time from the lists in the Received Box, Sent Box, Message Templates, Saved Messages or Drafts, or erasing them all at once.

Erasing single messages

1. Select **Menu** → **Messages**.
2. Press  down to the type of message you want to erase: **Recvd Msgs** or **Sent Msgs**.
3. Highlight the message to erase and press  to select **Read**.
4. Press  to select **Options** → **Erase**. A notification appears: "Erase?"
5. Select **OK** to erase the message.

Erasing all messages

1. Select **Menu** → **Messages** → **Msg Settings** → **Erase Msgs**.
2. To erase messages from all folders select **All Messages**.
-OR-
3. Select a folder to erase all messages from just that folder:
 - **Recvd Msgs**
 - **Sent Msgs**
 - **Msg Template**
 - **Svd Msgs**
 - **Drafts**

Note: Select the **Information** option for a description of this feature.

4. A message appears: "Erase?" Select **OK** to erase messages or **Back** to cancel.



Sending multimedia messages












You can only send multimedia messages to phones that are capable of receiving them or to email addresses. For details, check with your service provider.

Multimedia messages have a predetermined character and file size limit. When you reach the character and file size limit for a single multimedia message, you must edit the message to meet the size limitation.

Note: Multimedia message file size limits may apply. For details, check with your service provider.







Creating a multimedia message

1. Select **Menu** → **Messages** → **New Message** → **New MMS**.
Note: Select the **Information** option for a description of this feature.
2. Enter the recipient's phone number or email address in the **To** field.
3. To add more recipients:
 - Press  to select **Options** → **Edit** to enter a recipient.
 - Press  down to enter additional recipients manually,
- or -




- Press  to select **Options** → **Contacts** to access your contacts directory; and then press  to insert the number or e-mail address.
 - Press  when you are done.
4. Press  down to the **CC** and **BCC** fields and press  to select **Options** → **Edit** to add additional recipients:
 5. Press  down to the **Subject** field and press  to select **Options** → **Edit** to enter text. Press  when you are done.
 6. Press  down once to enter the **Picture** field and press  to select **Options**. Press  when you are done.
The options are:
 - **Send** to send the message.
 - **Take photo** to instantly take a new photo and attach it to your message.
 - **Album** to select a photo from the camera photo album.
 - **Images** to select from images stored on the phone.
 - **Preview** to play your multimedia message prior to sending.
 - **Save message** to save the message

- **Send Setting** to choose the settings for the message. The options are:
Priority- Normal or Urgent
Delvry Notif- Enable or Disable
Saved Message- Save, Not Save or Prompt.
- **Add slide and Remove slide** to add or remove a slide.
- **Name Card** to add a Name Card to the message.
- **DCF** to add a DCF file to the message.

Note: You can add only one picture per slide. Up to three slides are allowed per multimedia message.

7. Press  down once to enter the **Message** field.
 - Enter your message manually, or
 - Press  to select **Options** → **Edit** and enter the message. Press  again for access to quick text.
 - Press  when you are done.
8. Press  down once to enter the **Sound** field and press  to select **Options**. Choose from:
 - **Send** to send the message.
 - **Preloaded sounds** already in your phone
 - **Sound** to access your downloaded tones and music.

Note: You can add only one new or stored sound per slide. Up to three slides are allowed per multimedia message.

- **Voice** to access voice notes on your phone
 - **Recording** to record a new voice memo
 - **Preview** to play your multimedia message prior to sending.
 - **Save Message** to save your multimedia message to the **Drafts** or **Templates** folders and send it later.
 - **Send Settings** to choose the settings for the message. The options are:
Priority Normal or Urgent
Delivery Notif Enable or Disable
Saved Message Save, Not Save or Prompt.
 - **Add slide and Remove slide** to add or remove a slide.
 - **Name Card** to add a Name Card to the message.
 - **DCF** to add a DCF file to the message.
9. When you have completed entering your message information, press  to select **Send**.
 10. Press  to send your multimedia message.
 11. Press  again at the prompt to save your multimedia message

Receiving multimedia messages



There are various settings for receiving a multimedia message on your phone.

Note: See “Customizing message settings” on page 24 for more information on settings for incoming and outgoing messages.

Auto Receive mode

When a multimedia message is received, it is automatically downloaded onto your phone.



The alert “New Message(s)” appears along with the text “Message Received. View now?”

- To **View** the multimedia message, press .
- To view **Later**, press .

Note: In idle state, the phone downloads the message approximately one minute after the last key is pressed.


Reminder mode

When a multimedia message is received, your screen displays the alert “New Message(s)” along with the question “Retrieve Now?”

- To **View** the multimedia message, press .
- Select **Erase** to never download the multimedia message.
- To view **Later**, press .





Note: If a multimedia message is received during a call, then the phone screen displays the alert “New Message(s)” after the call ends.

To activate a message alert:

1. Select **Menu** → **Messages** → **Msg Settings** → **Incoming** → **Reminder**.
2. Highlight an option to be alerted of incoming messages:
 - **Once Only** or **Evry Two Min**, or
 - **Off** not be alerted of incoming messages.
3. Press .

Viewing multimedia messages

When you receive a multimedia message, a notification appears on your phone’s screen and remains until all messages are viewed.

1. Press  to **View** the multimedia message. If the message is long, press  down to view the entire multimedia message.
2. Press  to select **Options**. Press  down to highlight additional options for the multimedia message (options vary according to selection):


Note: The options available to you may vary. Check with your service provider.

- **Reply** reply to the sender.
- **Reply All** reply to all recipients of the message.
- **Forward** launches the message creation screen, allowing you to forward the multimedia message. The original address will not be shown, nor will the graphic, sound, and text fields.
- **Call Back** initiates call to the sender of the multimedia message.
- **Save Message** saves the multimedia message to the Saved folder on the phone.
- **Save Image** saves the currently viewed picture embedded in the multimedia message.
- **Save Sound** saves the current sound embedded in the multimedia message.

- **Delete** allows you to erase the currently displayed multimedia message.
- **Message Info** displays multimedia message information (priority, sender, subject, time sent and received, and message size).
- **Protect** protect the message to avoid accidentally erasing it.

7 MANAGING DOWNLOADS

Your K352 has the ability to download and manage applications through Downloads.

Tip: As you navigate the screens in the Downloads menu, use  to go back one menu level.

For more information

For more information about Downloads capabilities and application pricing, contact your service provider.

How do Downloads work?

You connect to the server, download applications, and then manage them as you like. When you choose an application, you have the option of choosing a demo, various limited use options, or the full version—all varying in price. If you choose a demo, Downloads lets you know when it has expired. If you choose a priced version, the amount is added to your phone bill. Downloads also lets you know if you're running out of memory. At that point, you can either disable an application or remove it completely.

Once applications are loaded, you can update to newer versions as they become available.


Changing the airtime charges alert

To be warned of airtime charges when you access the internet, select **Menu** → **Downloads** → **Settings** → **Airtime Warnings** → **All Enabled**.

Downloading an application

1. From the home screen, select **Menu** → **Downloads**.
2. Select **Download Center**. Download Center is your link to downloading applications.
When a connection to the server is made, the Downloads Center menu appears with a list of application types to choose from.
3. Select an application type.
A full list of applications of the type you selected appears. New applications are indicated by an arrow on the left.
Note: Long titles scroll left as you highlight them.
4. Select an application.
A list of usages appears.
There may be one or more usages available. The costs are specified for each.
5. Select a usage.
You are then prompted by a message asking you to confirm your choice.
6. Select **Yes** to confirm.
The application is downloaded to your phone.
Note: Download times vary.

7. To open the application now, select **Yes**. If you choose **No**, you return to the Downloads menu, where you see a link to your new application.

Note: Your connection to the application server automatically ends after a short period, unless you connect again to download more applications. If you want to end the connection manually, press  on your phone.

Options after downloading

The following options appear after you receive a prompt indicating that you have successfully downloaded content.

- **Yes** select this option to run the application.
- **No** select this option to return to the Downloads Center screen.

Opening an application

Downloaded applications are stored under the Downloads menu. Each application comes with its own unique icon, to help you identify it easily.

1. Select **Menu** → **Downloads**.

Note: The Downloads icon always remains at the top of this menu. Downloaded applications are listed after.

2. Highlight and select the icon for the application you want to open.

Viewing application details

You can get information about the size of an application and how many uses it has left before it runs out.

1. Select **Menu** → **Downloads** → **Settings** → **Manage Apps**.
2. Select the application you want details for.

Removing an application

Important: If you remove an application, it is removed completely from your phone. If you want to use it again, you must pay for it again. If you want to free up space on your phone, we recommend you disable the application (see next section).

1. Select **Menu** → **Downloads** → **Settings** → **Manage Apps**.
2. Select the application and then select **Remove**.
3. Select **Yes** to confirm your choice.

Disabling an application

If you are running out of memory and would like to download more applications, but do not want to completely remove those you have paid for, you can simply disable them. This means you have to re-download an application in order to use it again, but don't have to pay for it again.

Locking an application

To prevent disabling an application, you need to first lock an app.

1. Select **Menu** → **Downloads** → **Settings** → **Manage Apps**.
2. Select the application and then select **Lock App**.
3. Select **Yes** to confirm your choice.

Note: The app is still listed in the Downloads menu. The icon looks like an empty box.

Checking available memory

The amount of available memory depends on the number of applications you downloaded.

Select **Menu** → **Downloads** → **Settings** → **Manage Apps**.

- **System Info** is already highlighted. The amount of memory left is shown at the bottom of the screen.
- To get more detailed memory information select **System Info**. The System Info screen is displayed with further information.

8 CONNECTING TO THE INTERNET

Using the WAP Browser

You can use your phone to browse the Internet if you have obtained phone Internet services from your service provider and if over-the-air Internet access is available in your area.

Note: You cannot receive incoming calls while you are using the WAP Browser.


Starting the WAP Browser

1. From the home screen, press the right soft key to select **WAP**.


Note: For information about how airtime is charged, contact your service provider. To change this alert see “Changing the airtime charges alert” on page 30.




2. Press  to continue.


If this is the first time you have connected to the Internet, a message informs you that security is not yet enabled for your Web Browser.

3. Press  to select **Yes** to enable security.

When you are connected, a WAP home page appears. It has a list of bookmarks and some Web menu options at the bottom of the screen.

- A  appears in a secure session.

- An underline and an arrow indicate that there is more text. Press  down to view more text. Press  to return to the previous screen.
- To choose a site, highlight it and press  to select **Go**.

4. When you have finished using the Internet, press  to exit the browser.

WAP menu

The Wap menu contains the following options:

- **Home** accesses the WAP home page.
- **Favorites** accesses the page containing your saved web sites.
- **Go To...** takes you to a WAP Browser URL that you specify.
- **WAP Options** lists the alerts for managing your Web use. **Web prompt** alerts you at the beginning or end of every browser session; and a **Session timer** provides alerts at 60, 90, 120, or 150 seconds of browser use.
- **Information** provides a description of the WAP options.

Options menu

As you browse through the internet, you have several options available from the Options menu.

- Select **WAP** → **Menu** → **Options**.

The options are:

- **Back** takes you back to the previous page.
- **Forward** takes you to the next page indicated by your current page.
- **Home** returns you to the main Web Browser window or home page.
- **Go to URL** takes you to the URL that you specify.
- **Show URL** displays the entire URL.
- **Search** accesses the browser's search function.
- **Mark Page** saves the current location as a bookmark for easy access.
- **Refresh** refreshes the current page.
- **Favorites List** displays a list of your saved Web sites.
- **Save Page** takes you to a saved page.
- **Saved Page List** takes you to a list of your saved pages.
- **History List** clears the history.
- **Preferences**
- **Restart Browser** restarts the Web Browser.
- **About NetFront** displays information about your Web Browser version.
- **Exit WAP** exits the browser and takes you back to the Menu.

Searching for a Web site

How you search for a Web site depends on your service provider. For more information, contact your service provider.

Going to a bookmarked site

1. Select **WAP** → **Favorites**. If you see a message prompt, press **OK** to continue.
- or -
Select **WAP** → **Menu** → **Options** → **Bookmarks List**. A list of bookmarks appears.
2. Enter the number that corresponds to the bookmark you want and press **OK**.

9 USING THE MUSIC PLAYER

Use your phone's music player to listen to your favorite songs. Copy music files from your computer to your phone for your own portable music player.

Putting music files onto the phone

Music files can be put onto your K352 by using the provided USB cable and placing the K352 into **Mass Storage Mode**.

Note: The K352 supports music files in the MP3 format only.

1. On the phone, select **Menu** → **Settings** → **Mode Setting** → **Mass Storage Mode**.
2. Plug the USB cable into the jack at the bottom of the K352.
3. Plug the other end of the USB cable into a USB port on your computer.
4. Your K352 will now be 'viewed' by your computer as a 'Mass Storage Device'.









Note: Your phone will not be recognized by the computer as a Mass Storage Device unless you change the mode to the Mass Storage setting before you connect to the computer as described in step 1.





5. On your computer double-click on 'My Computer'.
6. You will see the K352 as a Removable disk drive.

7. Double-click on the appropriate Removable Disk drive.
8. Double-click on the **Music** folder.
9. Drag and drop your music files onto the **Music** folder in the removable disk drive.
Note: The K352 supports only the mp3 music file type.
10. When you are done placing music onto the K352, disconnect it from your computer.

Accessing songs








Playing songs



1. Press .
-or-
Select **Menu** → **Tones & Images** → **MP3 Player**.
2. Press  to listen to the displayed song.
Note: The MP3 Player icon  is displayed on the top row of your phone screen.
3. Use the  and  keys to play the next and previous songs in the list.
4. To skip directly to a different song:
 - Press  and select **List**.
 - Press  up or down to scroll through the list.
 - Highlight a song, press  and select **Play**.

Tip: Use the  and  keys on the left side of the phone to adjust the volume when the music is playing. Press  to pause a song and  to resume it.

Saving songs to the playlist

You can select songs to the playlist and play just those songs on your phone.



1. Select **Menu** → **Tones & Images** → **MP3 Player**
2. Press  to select options.
3. Highlight **List** and press .
4. Highlight the song you wish to select and press .
5. Highlight **Select Play** and press  to select the song for the playlist.
6. Scroll through the list and press  to continue selecting songs to the playlist.
7. When you have completed your selection, press  to select **Back**. The message “Save to playlist?” will appear.
8. Select  to save your selections to the playlist.

Note: The next time you use the  and  keys the songs selected to the playlist will play.

Managing music player settings

You can set personal preferences for skins and play options in your music player.

To access the music player settings:

1. Select **Menu** → **Tones & Images** → **MP3 Player**.
2. Press  to select options.
3. Highlight **List** and press .
4. Choose an option from the **Settings** menu:
 - **Sound Effect** assigns a sound effect to the selected song.
 - **Repeat** keeps repeating the selected song or stops the selected song from repeating.
 - **Random** plays the songs in your playlist in a random order.
 - **Volume** adjusts the volume of the music player.
 - **Skin** changes the appearance of the music player screen.

Troubleshooting

Scenario: Song is not playing

Try renaming the file on your PC, removing any special characters, spaces, and limiting the length to 20 characters long.

If the file still does not play:

- The file type may not be supported.
- The file may be DRM (digital rights management) protected.
- The file may be corrupted.

Scenario: Audio is choppy

- The audio file may be corrupted, but the audio still plays. Check your audio file for corruption.

10 ACCESSING MULTIMEDIA CONTENT

The **Entertain.** menu on your phone gives you access to online and preloaded games. You can also purchase, download, store, and access other online multimedia content from the **Tones & Images** folder in your phone.

Note: See “Using the Music Player” on page 35 for more information on the MP3 player.

Accessing online games

To access online games from your phone:





- Select **Menu** → **Entertain.** → **Online Games.**


Note: Select the **Information** option for a description of this feature. Contact your service provider for more details.

Accessing pre-loaded games

Brick Attack

Your K352 comes with a pre-loaded game called Brick Attack. The goal of this game is to eliminate bricks arranged in levels. You send a moving ball upward using a paddle at the bottom of the screen.

1. Select **Menu** → **Entertain** → **Brick Attack.**
2. Press  to select New.
 - To pause the game, press , then press  to **Resume.**
 - To move the paddle, press  left or right.

- To exit the game, highlight **Exit** and press .

Accessing online sounds and images

You can download and store sounds and images to the **Tones & Images** folder on your phone for easy access.

Note: You will not be able to use downloaded files that are DRM protected until the DRM rights arrive. See “Using DRM protected content” on page 38 for more information.

- To access an online site where you can download sounds select **Menu** → **Tones & Images** → **Tones** → **More Tones.**
- To access an online site where you can download images select **Menu** → **Tones & Images** → **Images** → **More Images.**

After you have downloaded sounds or images, you can access them as follows:

- To access stored sounds, select **Menu** → **Tones & Images** → **Tones** → **Saved Tones.**
- To access stored images, select **Menu** → **Tones & Images** → **Images** → **Saved Images.**


To check the used and available memory in the **Tones & Images** folder:

- Select **Menu** → **Tones & Images** → **Memory.**

Using DRM protected content

You will not be able to use downloaded files that are DRM protected until the DRM rights arrive. DRM protected Separate Delivery contents are stored in the **Menu** → **Tones & Images** → **DCF Files** folder. Once decrypted, the content is stored in the corresponding folders in **Tones & Images**.

To decrypt DRM Content Files:

1. Select **Menu** → **Tones & Images** → **DCF Files**.
2. Highlight a DCF File and press  to select **Options**.

The options are:


- **Send MMS** send this content in an MMS message.
- **Use** follow the prompts to purchase rights and use the file.

You may receive a WAP message “New rights received. Use it in DCF Folder?” select **Yes** to decrypt the file and use it.

Note: Once decrypted, the content is stored in the corresponding folders in **Tones & Images** from where you can select and play/view the contents.

Setting incoming alerts

You can set specific tones to be alerted of incoming messages from your **Tones & Images** folder.


1. Select **Menu** → **Tones & Images** → **Tones** → **Incmng Alrts**.
2. Highlight a tone to listen to it and press  to select it.

11 CUSTOMIZING YOUR PHONE





Accessing the main menu

You can access the main menu in different ways depending on how you configure your phone settings.

Using shortcuts


From the home screen, you can access shortcuts by pressing  in four different directions.


Four shortcuts are automatically programmed into your phone (up, down, left, and right).

Press  up	Access Calls
Press  down	Access Phonebook
Press  left	Access Tones and Images
Press  right	Access My Movistar




Mapping your main keys

You can associate each of the four navigation keys with a main menu item of your choice for immediate access.

1. Select **Menu** → **My Movistar** → **Main Keys**.
2. Highlight the key you wish to map.
3. Press  to the right or left to scroll through the list of menu options until the menu option you wish to assign to the key is displayed.


4. Press  down to select the next key that you wish to map and repeat step 3.

Tip: If you wish to make the icons for the mapped navigation keys visible or invisible on the home screen, highlight **On Idle Screen** and select **Visible** or **Invisible**.

5. When you have completed mapping all the keys, press  to select **Preview**. You can now see the new appearance of the home screen.
6. Press  to return to the mapping menu and make further changes or press  to choose **Select** and save the new settings.

Setting your menu style


You can choose from a list or icon view of the main menu items.

1. Select **Menu** → **My Movistar** → **Menu Style**.
2. Highlight **Grid** or **List** view and press .

Setting sounds for your phone


Your phone is set to make sounds when you receive calls, press keys, navigate through menus, and receive alerts (such as new messages). You can set the phone to a different mode such as vibrate when you receive calls and alerts.


1. Select **Menu** → **My Movistar** → **Sounds**.

2. Press  to select from the following options:
 - **Type** select different ringers for the listed functions in the phone.
 - **Volume** set the volume for the listed functions in the phone.
 - **Alerts** set alerts and reminders for tasks, messages, missed calls etc.
 - **Key Length** select the duration of the key press.
 - **Information** read a description of these options.

Choosing ringers

Your K352 has several preset ringers you can choose to use for incoming calls.

1. Select **Menu** → **My Movistar** → **Sounds** → **Type**.
2. Press  to select **Call**. You can choose from:
 - **Ringer Type** sets a ringer for all incoming calls.
 - **Business** sets a common ringer for all contacts listed in the Business Group.
 - **Personal** sets a common ringer for all contacts listed in the Personal Group.
 - **Roam** allows you to enable or disable a unique ringer for calls that may be subject to roaming charges.
3. Scroll down the list to hear the different rings.

4. Press  to select a ringer.

Setting the roam ringer

You can set a ringer to indicate when an incoming call will be subject to roaming charges.

Select **Menu** → **My Movistar** → **Sounds** → **Type** → **Calls** → **Roam** → **Enable**.

The phone now emits a distinctive roam ring to indicate when you are roaming during calls.


Setting roaming alert

You can set the phone to warn you before you answer or place a call while roaming.



Select **Menu** → **My Movistar** → **Sounds** → **Alerts** → **Roaming** → **Enable**.

Assigning a ringer to a group

You can assign a ringer to a group. All contacts in the group list will have the same ringer.

1. Select **Menu** → **Phonebook** → **Contacts** → **Groups**.
2. Select a group from the list and press  to select **Options** → **Ringer**.




Your choices are:

 - **Fix Ring** pre-set ringers
 - **Dwnld Ring** downloaded ringers
 - **MP3** your MP3 songs
3. Select the ringer type you wish to use and press .
4. Select a ringer from the list and press  to save.

Adjusting volume


You can adjust the voice and ringer volume as well as key tones.

Adjusting voice volume



You can adjust voice volume manually during a call. Press   on the left side of the phone, then press  left or right to adjust the volume.

Adjusting key pad volume

You can change the volume of the tones the phone makes when you press the keys.

1. Select **Menu** → **My Movistar** → **Sounds** → **Volume** → **Keypad**.
2. Press  left or right to adjust the volume.


Adjusting the ringer volume

1. Select **Menu** → **My Movistar** → **Sounds** → **Volume** → **Calls**.
2. Press  right to increase the volume, or left to decrease the volume.
3. Press  to select and save.

Setting message alerts

You can choose how you want to be alerted of incoming voicemail, or text messages.

1. Select **Menu** → **My Movistar** → **Sounds** → **Alerts**.
2. Select the type of alert: **Minute Beep**, **Roaming**, **Connect**, **Disconnect**, **Signal Fade**, **Messages**, **Voicemail**, **MsdCall Alrt**, **On/Off**.


3. Highlight the **Enable** or **Disable** option and press  to select it.

Personalizing the screen

Note: The **Information** option describes the function of this menu.


Changing your banner




The banner is the personal label for your phone. It appears on the home screen above the time and date. The banner can be up to 14 characters long.

1. Select **Menu** → **My Movistar** → **Display** → **Banner**.
2. Enter your banner text.
3. Press  to select **Save and Exit**.

Selecting a wallpaper



Wallpaper appears on the home screen.

1. Select **Menu** → **My Movistar** → **Display** → **Wallpaper**.
2. Press  to select
 - **Consistent** → **Edit** for a single wallpaper, - or -
 - **Change Daily** → **Edit** to select a different wallpaper for each day of the week.
3. Select either
 - **Fix Wallppr** for pre-loaded wallpapers, or
 - **Dwnld Wallpr** for your downloaded wallpapers.


4. Highlight a wallpaper and press  to view it.
Note: You can press  go back and select a different wallpaper.
5. Press  to save the selected wallpaper, or to select which day of the week to display the wallpaper.

Selecting a screen saver

Screen savers appear on the home screen and are activated one minute after the last keypress. Incoming calls and alerts override screen savers.

1. Select **Menu** → **My Movistar** → **Display** → **Screen Saver**.
2. Select an option and press  to view it.
3. Press  to save the selected screen saver.

Selecting a color theme

1. Select **Menu** → **My Movistar** → **Display** → **Themes**.
2. Select an option and press .

Adjusting the backlight

Your screen lights up while you are in a call or when you press a key on the keypad. However, you can set the duration that the backlight remains on.

1. Select **Menu** → **My Movistar** → **Display** → **Backlight**.



2. Select an option from the list:
 - **10 Sec., 30 Sec.,** or **1 Min.**, the duration backlighting remains on after your last keypress.
 - **Always On** keeps backlighting on all the time.

Note: These settings drain the battery more quickly and reduce talk and standby times.

Note: Power backlighting may not be available with the optional desktop charger or other accessories.

Note: The battery charges more slowly when power backlighting is on.

Changing the display contrast

1. Select **Menu** → **My Movistar** → **Display** → **Contrast**.
2. Press  left or right to adjust the contrast.
3. Press  to select **OK**.


Setting numbers to auto-hyphenate

Auto-hyphenation, when enabled, automatically inserts hyphens into your phone numbers to be consistent with the U.S. dialing plan. For example, (121) 234-5555.

- Select **Menu** → **My Movistar** → **Display** → **Auto-Hyphen** → **Enable**.

Choosing a different language


Your phone may display alternative languages.

1. Select **Menu** → **My Movistar** → **Language**.
2. Select a language, and press .

Silencing all sounds

You can silence all sounds and set the phone to vibrate or light up when you receive calls and alerts.

Setting the phone to vibrate or light up


1. Select **Menu** → **My Movistar** → **Silent Mode**.
2. Choose an option and press :
 - **Vibrate Only** the phone vibrates for the duration of the incoming call or other alert.
 - **Vibe then Ring** the phone vibrates first and then rings for the remainder of the incoming call alert.
 - **Lights Only** the phone lights up for the duration of the incoming call or other alert.
 - **Ring** the phone rings for the incoming call or alert (returns to a non-silent mode).


Voice Dial

For more information on this feature, see “Creating a voice tag” on page 44.

Locking the keypad

You can lock the keypad of your phone to prevent dialing numbers when the keys are pressed unintentionally.

1. Select **Menu** → **My Movistar** → **Key Guard**
2. Select from the following options and press  to activate it:
 - **Guard Now** locks the keypad immediately.
 - **30 sec auto, 1min auto, 5min auto** the duration of time from the last keypress after which the keypad will be locked.
 - **Disabled** unlocks the keypad.

Tip: To use the phone when keyguard is working, press and hold  to unlock the phone.

12 USING VOICE RECOGNITION

Voice recognition allows you to make calls by speaking commands into the phone's microphone. Your K352 can store 20 voice dial tags.

Note: You cannot use voice recognition to end a call; you must press .

Setting up voice dialing

To make calls using voice dialing, contacts must be saved with associated voice tags.


Creating a voice tag



1. Select **Menu** → **My Movistar** → **Voice Dial** → **Add V Dial**.

Note: Select **Menu** → **My Movistar** → **Voice Dial** → **Information** to read a description of this feature.





2. Follow the voice prompts to record a name for the contact.
3. Input the contact's phone number and then go to step 5.

- or -

Press  to select **Search** to input an existing contact from the **Phonebook**.

4. Press  to select the phone number.
5. Press  to select **OK**.
6. Select **OK** again to save the voice tag to the selected number.

Adding a voice tag to an existing contact


1. Select **Menu** → **Phonebook** → **Contacts** → **Search**.
2. Select Name, Number or Group search and enter your search criteria to locate a contact.
3. Highlight the contact's name and press .
4. Press  to select **Options**.
5. Press  down to highlight **Add Voice** and then press .
6. Follow the voice prompts to record a name for the contact.

Viewing entries with voice tags

To view a list of all contacts with assigned voice tags:



- Select **Menu** → **My Movistar** → **Voice Dial** → **V Dial List**.

Editing or deleting a voice tag

1. Select **Menu** → **My Movistar** → **Voice Dial** → **V Dial List**.
2. Highlight the voice tag you want to edit, and press  to select **Options**.
3. Select an option:
 - **Dial** to dial the selected number.
 - **Play** to listen to the voice tag.
 - **Edit Voice Dial** allows you to change the recorded voice tag.

- **Edit Number** allows you to change the number.
 - **Erase** erases the recorded voice tag.
 - **Erase All** erases ALL the recorded voice tags in the Voice Dial List.
4. Follow the prompts.


Calling using voice tags








1. If you haven't already done so, record a voice tag for the person you wish to call.
2. Select **Menu** → **My Movistar** → **Voice Dial** → **Voice Dial**.
- or -
Press  once from the home screen.
3. Follow the voice prompts.
Note: If the phone finds multiple voice tags that sound like the name you said, you will be asked to verify which name you want to call.
4. When you are finished with the call, press .

Using voice memos



The voice memos tool allows you to record and play back audio notes. Your phone can store 10 voice memos.

Recording a voice memo

1. Press and hold the record key  located between the phone screen and the keypad.
- or -
Select **Menu** → **Utilities** → **Voice Memo** → **Record New**.

2. Press  to select **Start** and begin speaking your memo.
Note: You can press  to **Pause** and then press  again to **Continue** recording.
3. Press  to **Stop** recording.
4. Press  to **Save** when finished.
Note: You can choose to press  to **Cancel** recording.
5. Rename the record and press  to select **Option** → **Save and Exit**.
Note: Voice memos saved without names are identified by numbered records.

Playing and editing voice memos

1. Select **Menu** → **Tones & Images** → **Tones** → **Voice Memo**.
- or -
Select **Menu** → **Utilities** → **Voice Memo** → **Recorded Memos**.
2. Highlight the voice memo you want to hear and press .
3. Select an option:
 - **Play** to review your voice memo.
 - **Rename** to change the name of the voice memo.
 - **Erase** to erase the selected voice memo.
 - **Erase All** to erase all voice memos.
 - **Details** to view the date and duration of the voice memo.
4. Follow the prompts and then press  to select **OK**.










13 UTILITIES




The **Utilities** menu on your phone provides tools to help you schedule events, organize your time, perform basic calculations and record notes.

Calendar



The calendar allows you to schedule events and set reminder alerts.

Creating an event

1. Select **Menu** → **Utilities** → **Calendar**.
2. Press  to select a date and press .
3. Press  to select **Options** → **Add**.
4. To enter an event description:
 - Press  to select **Options** → **Edit Item**.
 - Enter a name for the event in the **Content** field. For help entering text, see page 14.
 - Press  to select **OK**.
5. To enter an event time:
 - Press  to select **Options** → **Edit Time**.
 - Enter a time for the event in the **Enter Time** field. Use  to move through the fields.
 - Press  to select **OK**.
6. To alter the date:
 - Press  to select **Options** → **Edit Date**.



- Enter a date for the event in the **Edit Date** field. Use  to move through the fields.
 - Press  to select **OK**.
7. Press  to select **Save All**.


Viewing or erasing an event


1. Select **Menu** → **Utilities** → **Calendar**.
2. Highlight a date and press .
3. Highlight an event and press  to select **Options**:
 - **View** to view the event details.
 - **Add** to add a new event.
 - **Erase** to erase the selected event.
 - **Erase All** to erase all events for the selected date.
4. Follow the prompts.

Alarm Clock

Use the Alarm Clock to set an alert for a specific time. The alert occurs only if the phone is on.



1. Select **Menu** → **Utilities** → **Alarm Clock** → **Time**.
2. Enter the time of day you want the alarm to sound and press .
3. Select **Period** and press  to select:
 - **Once** the alarm sounds when the scheduled time occurs next.

- **Daily** the alarm sounds every day at the scheduled time.
 - **Mon – Fri** the alarm sounds every week day at the scheduled time.
 - **Sat – Sun** the alarm sounds on weekends at the scheduled time.
4. Select **On** and press  to set the alarm.


Note: When the alarm sounds, press  to silence the alarm.

Calculator

Use the calculator to perform basic arithmetic.

1. Select **Menu** → **Utilities** → **Calculator**.
2. Use the keypad to enter numbers.
3. Press  to select mathematical operations as displayed on the screen.
4. Press  to calculate the result.





Example: Enter 5, press  left once to select **X**, enter 2, then press  to obtain the result of 10.

5. Press  to erase entries or return to the previous screen.

Voice Memo





The voice memo tool allows you to record and play back audio notes. Your phone can store 10 voice memos. For information, see “Using voice memos” on page 45.

Stopwatch

1. Select **Menu** → **Utilities** → **Stopwatch**.
2. Press  to select **Start** to begin counting.
3. Press  to select **Pause** to stop counting and **Resume** to continue counting.
 - Press  to select **Reset** to clear the counter.
 - Press  to select **Back** and return to the previous screen.

Timer

The timer counts down for a specified amount of time. It beeps when that amount of time has elapsed.


1. Select **Menu** → **Utilities** → **Timer**.
2. Press  to select **Set**.
3. Use the keypad to enter the time.
4. Press  to begin the countdown.
 - Press  to select **Cancel** to clear the timer.
 - Press  to select **Back** and return to the previous screen.

Managing network settings

Setting the phone to receive data or faxes

Your phone may be able to receive certain data or faxes, depending on the system sending the information. You cannot receive voice calls while the phone is in data/fax mode. To receive data or faxes, you must connect the phone to a laptop or PC and switch the phone from voice mode to data/fax mode.

Note: To purchase a cable visit www.kyocera-wireless.com/store.

1. Connect the phone to the laptop or PC.
2. Select **Menu** → **Settings** → **Network** → **Set Network** → **Data/Fax**.
3. Highlight an option and press  to select it:
 - **Voice only** allows only voice calls.
 - **Fax, once** or **Data, once** sets the phone to fax mode or data mode for one time.
 - **Fax, until off** or **Data, until off** forces the phone into fax mode or data mode until the phone is turned off.

Note: You cannot receive voice calls while the phone is in data/fax mode.

Ensuring call privacy

You can set your phone to sound an alert if enhanced CDMA voice privacy is lost or regained. Check with your service provider to see if CDMA voice privacy is enabled in your area.


1. Select **Menu** → **Settings** → **Network** → **Set Network** → **Voice Priv** → **Enable**.

Switching between phone lines

Your phone can have two service accounts, or phone lines, associated with it. Each phone line has its own phone number.

When you are using one line, you cannot make or receive calls on the other. It's like the phone is "off" for that number. Your voicemail, however, still takes messages. All contacts and settings are shared for both lines.

Note: You must first establish a second phone line with your service provider. Once established, a second phone number becomes available in the menu for selection:

1. Select **Menu** → **Settings** → **Network** → **Set NAM**.
2. Select one of the two lines and press .

Viewing your internet user ID

You can view your internet user ID and password at the following location:



Menu → **Settings** → **Network** → **Net User ID**.

Creating a secure environment

This section describes all the features involved in securing your phone and preventing access to personal information. All security features are shielded by a four-digit lock code.

Changing your lock code

The default lock code is typically 0000 or the last 4 digits of your phone number.


1. Select **Menu** → **Settings** → **Security**.
2. Enter your four-digit lock code.
3. Select **New Lck Code**.
4. Enter the existing lock code.
5. Enter a new four-digit code and press .
6. Enter your new lock code again and press .

Locking your phone

When your phone is locked, you can call only emergency numbers or your service provider number. You can still receive incoming calls.

1. Select **Menu** → **Settings** → **Security**.
2. Enter your four-digit lock code.
3. Select **Lock Phone** → **Enable**.

Unlocking the phone

1. From the home screen, press  to select **Unlock**.
2. Enter your four-digit lock code.

Restricting calls



You can restrict the calls that can be made from your phone to emergency numbers, your contacts, and service provider numbers.

1. Select **Menu** → **Settings** → **Security**.
2. Enter your four-digit lock code.
3. Select **Limit Calls**.
4. Choose an option:
 - **Received** limits incoming calls only. Outgoing calls can still be sent.
 - **Sent** limits outgoing calls only. Incoming calls can still be received.
5. Select:
 - **Enable** to activate the call restriction, or
 - **Disable** to remove the call restriction

Designating important numbers

The important numbers feature allows you to specify three personal phone numbers that can be called when the phone is locked.



1. Select **Menu** → **Settings** → **Security**.
2. Enter your four-digit lock code.
3. Select **Important #**.

4. Highlight important number 1, 2, or 3rd press  to select the slot.
5. Enter the phone number, including the area code. Do not enter 1 before the area code.
6. Press  two times to select **OK** and save.

Important: To make a call to an emergency number from a locked phone, you must dial the number (including area code) exactly as it was stored in Important Numbers.

Erasing all contacts

You can erase all entries from your Contacts directory.

1. Select **Menu** → **Settings** → **Security**.
2. Enter your four-digit lock code.
3. Select **Erase Contacts** and press . A message appears: “Erase All Contacts?”.
4. Press  to select **OK**.

Note: You can press  to exit this screen without erasing contacts.

Call and message settings

- See “Customizing call settings” on page 12 for details on configuring incoming and outgoing call settings on your phone.
- See “Customizing message settings” on page 24 for details on configuring message settings on your phone.

WAP Settings

Setting a Web connection prompt

You can set an alert to be notified with a WAP connection warning message, “Do you want to connect to WAP?”.

1. Select **Menu** → **Settings** → **WAP Settings** → **Web Prompt**.

Your options are:

- **Off** if you do not wish to be notified of web activation.
- **At Start** to be notified at the beginning of a WAP session.
- **At End** to be notified at the end of a WAP session.
- **Both** to be notified both at the beginning and end of a WAP session.

Setting a Web session timer

You can set a session timer alert while you browse the internet.

1. Select **Menu** → **Settings** → **WAP Settings** → **Session Timer**.

Choose to be alerted every 60, 90, 120 or 150 seconds.

Setting the date and time format

You can set the way the date and time are displayed on your phone.

1. Select **Menu** → **Settings** → **Date/Time**.
2. To set the date format:
 - Select **Date Format**.
 - Highlight **mm/dd/yyyy** or **dd/mm/yyyy** and press **OK**.
3. To set the time format:
 - Select **Time Format**.
 - Highlight **12-hour** or **24-hour** and press **OK**.

Resetting the phone

- To reset the phone and clear all data stored in flash, select **Menu** → **Settings** → **Orig Setting** → **Master Clear**.

Customer support

Your service provider's customer support department is accessible directly from your phone. They can answer questions about your phone, phone bill, call coverage area, and specific features available to you, such as call forwarding or voicemail.

For customer support select:

- **Menu** → **Help** → **Cust Care Center**.

For roaming call center numbers select:

- **Menu** → **Help** → **Int'l Roam**.
 - In Venezuela
 - In USA

For questions about the phone features, refer to the materials provided with your phone, or visit www.kyocera-wireless.com.

For additional questions, you may contact the Kyocera Wireless Corp. Customer Care Center in any of the following ways:

- Web site: www.kyocera-wireless.com
- Email: phone-help@kyocera-wireless.com
- Phone: 1-800-349-4478 (U.S. and Canada) or 1-858-882-1401. Customer support phone numbers are also available in the following countries.

Argentina:	0-800-666-0052
Australia:	1-800-507-000
Brazil:	0-800-55-2362
Chile:	800-43-1212
Colombia:	01-800-700-1546
India:	Toll free: 1-600-121214 Toll: 0124-284-5000
Mexico:	001-866-650-5103
New Zealand:	0-800-990-100
Panama:	001-800-201-1984
Peru:	0-800-51-934
Puerto Rico:	1-866-664-6443
Venezuela:	0-800-100-2640

Before requesting support, please try to reproduce and isolate the problem. When you contact the Customer Care Center, be ready to provide the following information:

- The name of your service provider.
- The actual error message or problem you are experiencing.
- The steps you took to reproduce the problem.

- The phone's electronic serial number (ESN).

To locate the ESN:

- Select **Menu** → **Help** → **Phone Info**
and scroll down to **ESN**: for the
11-digit number.

Qualified service

If the problem with your phone persists, return the phone with all accessories and packaging to the dealer for qualified service.

Phone accessories

To shop for K352 phone-accessories, visit www.kyocera-wireless.com/store. You may also call us at 1-800-349-4188 (U.S.A. only) or 1-858-882-1410.

Become a product evaluator

To participate in the testing and evaluation of Kyocera Wireless Corp. products, including cellular or PCS phones, visit beta.kyocera-wireless.com.

Tips for using your camera

- You cannot activate the camera while on an active call or while browsing files in the Camera Photos folder.
- Once the camera is active, the home screen acts as the viewfinder.
- If you get a “Low memory” error, check your resolution and quality compression settings. See “Setting up the camera for photos” on this page.
- All photos are automatically saved in the Camera Photos folder.
- You can rename a photo.
See step 2 on page 55.
- Your phone only produces images in JPEG format.


Camera Options

The following options are available in the Camera menu when you select **Menu** → **Camera**:

- **Capture** to take a picture. See “Taking a picture” on page 55.
- **Settings** to set options for taking pictures. See “Setting up the camera for photos” on this page.
- **Camera Pictures** to view saved pictures.
- **Last Picture** to view the last picture taken.









- **Memory Status** to display the number of pictures taken (maximum is 100).

Setting up the camera for photos


1. Select **Menu** → **Camera** → **Settings**
2. Choose a setting option and press  to select it.
 - **Resolution** options are 160 x 120, 320 x 240 and 640 x 480.
 - **Low Light Mode** brightens the picture for low light environments.
 - **Timer** options are Off (default), 3, 5, or 10 second pauses. When set, the timer is displayed.
 - **Multishot** allows you to take multiple pictures (up to 6) while the camera key is pressed and held. A tone will play each time a picture is taken. A second tone will play when the final picture is taken. You can enable or disable this feature.
 - **White Balance** options are Automatic, Incandescent, Florescent or Daylight.
 - **Color Tone** options are Normal, Black & White, Negative, and Sepia.
 - **Quality** options are Low, Medium and High
 - **Viewfinder** options are Actual or Full Screen.

- **Shutter Sound** sets the sound used when the camera takes a picture.
 - **Frame** allows you to add a frame. A frame cannot be removed once it has been used in a picture.
- Note:** The picture resolution changes to 160 x 120 while taking pictures with frames. The resolution returns to the original setting once Frame is disabled.

Taking a picture

1. Press  on the right side of the phone.
- or -
Select **Menu** → **Camera** → **Capture**
- Tip:** Press  up or down to zoom in or zoom out. (You cannot zoom when the resolution is set to 640*480.)
2. Focus on the image using the phone screen.
 3. Press  or  to take the picture.
- or -
Press  to select **Capture**.
- Note:** The pictures are automatically saved in the **Camera Pictures** folder.
4. Press  to **Send** or **Erase** the picture.
 5. Press  to select **Back**. The camera returns to taking the next picture.
 6. Press  twice to return to the **Camera** menu when you have finished taking pictures.

Accessing saved camera pictures

1. You can access the **Camera Pictures** folder in two ways.
Select **Menu** → **Tones & Images** → **Images** → **Camera Photos**.
- or -
Select **Menu** → **Camera** → **Camera Pictures**.
2. Highlight the picture you want to view and press  to select an option.
 - **View** the selected picture.
 - **Rename** the picture.
 - **Erase** the current picture.
 - **Erase All** pictures.
 - **Details** view the settings used when the picture was taken.
 - **Take Picture** take another picture.

INDEX

- A**
 - accessing songs, 35
 - accessories, 53
 - alarm clock, 3, 46
 - alerts
 - for messages, 41
 - auto text, 23
 - auto-hyphenation, 42
- B**
 - banner, 41
 - basic functions, 7
 - battery, 1
 - charging, 1, 2
 - blocking outgoing calls, 49
- C**
 - calculator, 47
 - call counters, 12
 - call settings, 12
 - answer mode, 13
 - auto redial, 13
 - call restriction, 13
 - timing, 12
 - Call waiting
 - using, 9
 - call waiting setting, 12
 - calls
 - answering, 8
 - conference, 9
 - conference calls, 9
 - forwarding, 9
 - ignoring, 8
 - making, 8
 - missed, 9
 - options, 9
 - recent, 10
 - redialing, 8
 - restriction, 13
 - timing, 12
 - volume, 8
 - camera
 - accessing pictures, 55
 - options, 54
 - setting up, 55
 - settings, 54
 - taking a picture, 55
 - checking memory, 32
 - color theme, 42
 - contacts directory, 17
 - contrast, 42
- D**
 - data/fax setup, 48
 - display contrast, 42
 - downloaded applications
 - disabling, 31
 - opening, 31
 - removing, 31
 - viewing, 31
 - downloading, 30
 - an application, 30
 - options, 31
- E**
 - emergency
 - calls, 11
 - emergency mode, 11
 - exit emergency mode, 12
 - entertainment
 - online games, 37
- erasing
 - contact entries, 50
 - text messages, 25
- F**
 - fax mode, 48
- H**
 - hands-free headset
 - purchasing, 53
- I**
 - icons, 3
 - insert mode, 25
- L**
 - language, 43
 - lights
 - lights-only mode, 3, 43
 - limiting calls out, 49
 - locking
 - keypad, 43
 - phone, 49
- M**
 - main menu
 - contents, 6
 - mapping, 39
 - shortcuts, 39
 - style, 39
 - memory, saving, 25
 - multimedia messages
 - receiving, 27
 - music player
 - music files, 35
 - settings, 36
 - songs, 35

- troubleshooting, 36
- N**
 - number mode, 14
- P**
 - phone numbers
 - editing, 19
 - verifying your own, 7
 - phone, unlocking, 49
- R**
 - receiving
 - calls, 8
 - multimedia messages, 27
 - text messages, 22
 - recent calls
 - calling, 10
 - erasing, 10
 - icons, 10
 - options, 10
 - viewing, 10
 - ringers
 - assigning to groups, 40
 - choosing types, 40
 - silencing, 7
 - volume, 41
 - roaming, 3
- S**
 - saved phone numbers
 - editing, 19
 - screen contrast, 42
 - screen icons, 3, 14
 - screen saver, 42
 - security, 49
 - locking keypad, 43
 - sent messages, 23
 - setting
 - color theme, 42
 - roam alert, 40
 - roam ringer, 40
 - screen saver, 42
 - sounds, 39
 - wallpaper, 41
 - setting call forwarding, 12
 - shortcuts, 39
 - signature, 24
 - silent mode, 3, 43
 - light up, 43
 - vibrate, 43
 - songs
 - playing, 35
 - putting onto phone, 35
 - sounds
 - setting, 39
 - setting roam alert, 40
 - setting roam ringer, 40
 - speed dialing, 10
 - symbol mode, 14
- T**
 - technical support, 52
 - text entry, 14
 - quick reference, 16
 - text messages, 21
 - creating, 21
 - erasing, 25
 - reading, 22
 - retrieving, 22
 - settings, 24
- U**
 - unlocking the phone, 49
 - utilities
 - alarm clock, 46
 - calculator, 47
 - calendar, 46
 - stopwatch, 47
 - timer, 47
 - voice memos, 47
- V**
 - vibrate, 3, 43
 - voice dialing, 44
 - voice memos
 - playing, 45
 - recording, 45
 - voice tags
 - creating, 44
 - deleting, 44
 - editing, 44
 - using, 45
 - voicemail, 11
 - setting up, 7
 - volume
 - key beep, 41
 - ringer, 41
- W**
 - wallpaper, 41
 - WAP browser, 33
 - menu options, 33



Kyocera Wireless Corp.
10300 Campus Point Drive
San Diego, California 92121 USA
www.kyocera-wireless.com

82-G1655-1EN, Rev. 002