


eranodoi

200101830IWTI-01

INSTRUCTION

YOU'RE IN CONTROL OF A JURASSIC PARK 3 **DINOSAUR:**



HOW TO USE:

On the chest of your JP3 Dinosaur is the on/off

Slide the on/off switch to the ON position to turn on vour dinosaur.

Now, move or jiggle your dinosaur to give it motion. Movement of the dinosaur activates the roaring sounds and flashing lights.

To turn off your dinosaur:


Slide the on/off switch to the OFF position.

INSERTING THE BATTERIES:

To change the batteries. have an adult open the battery compartment cover at the bottom of the game. (Remove the screw holding the battery door between the dinosaur's feet and remove the door.) Insert 2 LR54/G10A batteries or equivalent as shown.

Two LR54/G10A batteries

DO NOT DISPOSE OF BATTERIES IN FIRE.



are included.

BATTERIES MAY EXPLODE OR LEAK. TO ENSURE PROPER FUNCTION:

- Do not mix old and new batteries.
- Do not mix alkaline, standard or rechargeable batteries.
- Battery installation should be done by an adult.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from
- the toy before being charged (if removable). - Rechargeable batteries are only to be charged
- under adult supervision (if removable). - Only batteries of the same or equivalent type as
- recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the tov.
- The supply terminals are not to be short circuited.

CAUTION:

Do not disassemble this product to prevent children from swallowing small parts.

Throw away the transparent material after opening the package. It is packing material - not part of the kevchain.



DEFECT OR DAMAGE

If a part of your Keychain is damaged or something has been left out, DO NOT RETURN IT TO THE STORE. The store doesn't have replacement parts. Instead, write to us at:

TIGER REPAIR DEPARTMENT 1000 N. Butterfield Road, Unit 1023, Vernon Hills, IL 60061, U.S.A.

In your note, mention the product name, the model number, and tell us briefly what the problem is. Also include sales slip, date, place of purchase and price paid. We will do our best to help.

90-DAY LIMITED WARRANTY

Tiger Electronics. (Tiger) warrants to the original consumer purchaser of this product that the product will be free from defects in materials or workmanship for 90 days from the date of original purchase. This warranty does not cover damages resulting from accident, negligence, improper service or use or other causes not arising out of defects in materials or workmanship.

During this 90-day warranty period, the product will either be repaired or replaced (at Tiger's option) without charge to the purchaser, when returned with proof of the date of purchase to either the dealer or to Tiger.

Product returned to Tiger without proof of the date of purchase or after the 90-day warranty period has expired, but prior to one year from the original date of purchase, will be repaired or replaced (at Tiger's option) for a service fee of U.S.\$3.00. Payments must be by check or money order payable to Tiger Electronics.

The foregoing states the purchaser's sole and exclusive remedy for any breach of warranty with respect to the product.

All product returned must be shipped prepaid and insured for loss or damage to:

TIGER REPAIR DEPARTMENT 1000 N. Butterfield Road, Unit 1023, Vernon Hills, IL 60061, U.S.A.

The product should be carefully packed in the original box or other packing materials sufficient to avoid damage during shipment. Include a complete written description of the defect, a check if product is beyond the 90-day warranty period, and your printed name, address and telephone number.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES AND NO OTHER REPRESENTATIONS OR CLAIMS OF ANY NATURE SHALL BE BINDING ON OR OBLIGATE TIGER IN ANY WAY. ANY IMPLIED WARRANTIES APPLICABLE TO THIS PRODUCT, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE NINETY (90) DAY PERIOD DESCRIBED ABOVE. IN NO EVENT WILL TIGER BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM POSSESSION, USE, OR MALFUNCTION OF THIS TIGER PRODUCT.

Some states do not allow limitations as to how long an implied warranty lasts and/or exclusions or limitations of incidental or consequential damages, so the above limitations and/or exclusions of liability may not apply to you. This warranty gives you specific rights, and you may also have other rights which vary from state to state.

For more information about Tiger Electronics, our products and special promotions, please visit our Wed Site at: www.tigertoys.com



Jurassic Park III is a trademark and copyright of Universal Studios and Amblin Entertainment, Inc. Licensed by Universal Studios Licensing, Inc. All rights reserved.

A Note to Parents in the USA:

The Jurassic Park films are rated PG-13. Consult

www.filmratings.com for further information.

In Canada, please consult your local newspaper to find out the Jurassic Park III rating.

Avis aux parents: Consultez votre journal local pour connaÓtre la cote du film Jurassic Park III.

Nota para los padres: Consulte su periÛdico local para conocer la clasificaciÛn de la pellcula Jurassic Park III.

Universal Studios Consumer Products Group is a proud sponsor of dinosaur research.





A division of Hasbro, Inc.

®, TM, & © 2001 Tiger Electronics All rights reserved.

980 Woodlands Parkway, Vernon Hills, IL 60061, USA.

®, TM, & © 2001 Tiger Electronics UK Ltd. All rights reserved. Belvedere House, Victoria Avenue, Harrogate, North Yorkshire HG1 1EL. United Kingdom.

www.tigertovs.com

PRINTED IN CHINA