

InternetVue™ IV-2020

User Manual






Table of Contents

Introduction	3
Product Specifications	3
Retail Box Contents	4
Ports and Connectors	4
Overall Reguirements	
Configuration Options	
Configuration A: Wireless / Wireless	
Configuration B: Wireless / Wired	
Configuration C: Wired / Wired	
Configuration D: Wired / Wireless	
Installation Procedure	
Configuration Wizard	
TV Type	
Connection Summary	
Password Setup	
Device Name (SSID)	
Wireless Network	
Configuration A	
Configuration B	
Configuration C	
Configuration D	
Configuration Summary	
Factory Reset	
PC2TV Software	
Main PC2TV Window	
PC2TV Advanced Settings	
rezi v Advanced Settings	. 20
PC2TV Advanced Settings	.)1
PC2TV Advanced Settings	. 21
PC2TV Advanced Settings	. 21
Summary	. 21
Summary Device Settings	. 21 . 22 . 23
Summary Device Settings About the Security Access Number feature	. 21 . 22 . 23 . 24
Summary Device Settings About the Security Access Number feature TV Type TV Type	. 21 . 22 . 23 . 24 . 24
Summary Device Settings About the Security Access Number feature TV Type TV Type Internet Connection	. 21 . 22 . 23 . 24 . 24 . 25
Summary Device Settings About the Security Access Number feature TV Type TV Type Internet Connection TCP/IP Settings	. 21 . 22 . 23 . 24 . 24 . 25 . 25
Summary Device Settings About the Security Access Number feature TV Type TV Type TV Type Internet Connection TCP/IP Settings Wireless Settings	21 22 23 24 24 24 25 25 25 25
Summary Device Settings About the Security Access Number feature TV Type TV Type Internet Connection TCP/IP Settings Wireless Settings Advanced	21 22 23 24 24 24 25 25 25 25 25 25
Summary Device Settings About the Security Access Number feature TV Type TV Type Internet Connection TCP/IP Settings Wireless Settings Advanced Password Setup	. 21 . 22 . 23 . 24 . 24 . 25 . 25 . 25 . 26 . 26
Summary Device Settings About the Security Access Number feature TV Type TV Type Internet Connection TCP/IP Settings Wireless Settings Advanced Password Setup Upgrade	. 21 . 22 . 23 . 24 . 24 . 25 . 25 . 25 . 26 . 26 . 26
Summary Device Settings About the Security Access Number feature TV Type TV Type Internet Connection TCP/IP Settings Wireless Settings Advanced Password Setup Upgrade Video Settings	. 21 . 22 . 23 . 24 . 24 . 25 . 25 . 25 . 25 . 26 . 26 . 26 . 26
Summary Device Settings About the Security Access Number feature TV Type TV Type Internet Connection TCP/IP Settings Wireless Settings Advanced Password Setup Upgrade Video Settings Pan and Scan	21 22 23 24 24 25 25 25 25 26 26 26 26 26
Summary Device Settings About the Security Access Number feature TECHNOLOGY TV Type TV Type Internet Connection TCP/IP Settings Wireless Settings Advanced Password Setup Upgrade Video Settings Pan and Scan Troubleshooting Tips	. 21 . 22 . 23 . 24 . 25 . 25 . 25 . 26 . 26 . 26 . 26 . 26 . 27
Summary Device Settings About the Security Access Number feature TV Type TV Type TV Type Internet Connection TCP/IP Settings Wireless Settings Advanced Password Setup Upgrade Video Settings Pan and Scan Troubleshooting Tips If InternetVue does not appear on the list of available wireless networks	. 21 . 22 . 23 . 24 . 24 . 25 . 25 . 25 . 25 . 26 . 26 . 26 . 26 . 26 . 26 . 27 . 27
Summary Device Settings About the Security Access Number feature TV Type TV Type TV Type Internet Connection TCP/IP Settings Wireless Settings Advanced Password Setup Upgrade Video Settings Pan and Scan Troubleshooting Tips If InternetVue does not appear on the list of available wireless networks If you cannot connect to the Internet while projecting	. 21 . 22 . 23 . 24 . 24 . 25 . 25 . 25 . 25 . 25 . 26 . 26 . 26 . 26 . 26 . 26 . 27 . 27 . 27
Summary Device Settings About the Security Access Number feature TV Type TV Type TV Type Internet Connection TCP/IP Settings Wireless Settings Advanced Password Setup Upgrade Video Settings Pan and Scan Troubleshooting Tips If InternetVue does not appear on the list of available wireless networks If you cannot connect to the Internet while projecting If your video performance is sluggish	. 21 . 22 . 23 . 24 . 25 . 25 . 25 . 25 . 26 . 26 . 26 . 26 . 26 . 26 . 27 . 27 . 27
Summary Device Settings. About the Security Access Number feature TV Type. TV Type. Internet Connection . TCP/IP Settings. Wireless Settings. Advanced. Password Setup Upgrade. Video Settings. Pan and Scan. Troubleshooting Tips. If InternetVue does not appear on the list of available wireless networks. If your video performance is sluggish. If your video performance is sluggish. If your InternetVue™ fails to connect on repeated attempts.	21 22 23 24 24 25 25 25 25 26 26 26 26 26 26 26 26 27 27 27 27 27
Summary Device Settings	. 21 . 22 . 23 . 24 . 25 . 25 . 25 . 25 . 26 . 26 . 26 . 26 . 26 . 26 . 26 . 27 . 27 . 27 . 27 . 27
Summary Device Settings About the Security Access Number feature TV Type TV Type TV Type TV Ppe Internet Connection TCP/IP Settings Wireless Settings Advanced Password Setup Upgrade Video Settings Pan and Scan Troubleshooting Tips If InternetVue does not appear on the list of available wireless networks If you cannot connect to the Internet while projecting If your video performance is sluggish If your video performance is sluggish If you see black border on the TV If the video pauses at the beginning of the sequence for less than 2 seconds and restarts	21 22 23 24 24 25 25 25 25 26 26 26 26 26 26 26 26 27 27 27 27 27 27 27 27 28
Summary Device Settings	. 21 . 22 . 23 . 24 . 25 . 25 . 25 . 25 . 26 . 26 . 26 . 26 . 26 . 26 . 27 . 27 . 27 . 27 . 27 . 28 . 28
Summary Device Settings	 21 22 23 24 25 25 25 26 26 26 26 26 26 27 28 28 28
Summary Device Settings	 21 22 23 24 25 25 25 26 26 26 26 26 26 27 27 27 27 27 27 27 27 28 28 28 28 28



Introduction

Congratulations, and thank you for your InternetVue[™] purchase. InternetVue[™] will allow you to display your PC's screen contents on any TV or projector wirelessly. You will be able to view videos, digital photos, websites, and just about anything on your PC, will be shown on your TV. Moreover, your PC's audio will also be heard from your TV or audio system.



InternetVue[™] is a two-part solution - a software component and a hardware receiver/decoder module. The software running on the PC (a) captures the audio stream and video display information, then sends that data to the receiver (b) as standard TCP/IP packets. The receiver box becomes a node on the network, either wired or wireless. The receiver not only decodes the incoming packets back to analog audio and video signals for the TV (c), but it can also serve as a wireless bridge (d), relaying your internet connection between the PC and your wireless gateway (e).

Product Specifications

Maximum Output Resolution	1280 x 720 @ 60 Hz (Photo mode)	Industry Certifications	RoHS, UL, cUL, FCC Part 15 Class B, CE
Composite Video Formats Interfaces and Ports	NTSC, PAL RJ45 10/100Base-TX Component Video Composite Video 3.5mm stereo jack Reverse SMA Antenna	Wireless Encryption Operating System Support	TKIP only Windows XP Home and Professional (32-bit and 64-bit) SP2, Windows 2000 Professional SP4, Windows Vista (32-bit and 64-bit)
Networking Standards Max. Wireless Data Rate Wireless Frequency Band Wireless Security Standards	IEEE 802.11b/g, IEEE 802.3 54 Mbps 2.4 GHz ISM band WEP 64/128-bit HEX/ASCII, WPA, WPA-PSK	Input Power Dimensions Weight	5V DC 1.38" x 5.91" x 3.15" 7.5 oz



Retail Box Contents

Ensure that your InternetVue[™] kit has all the following items. Otherwise, contact Tech Support for more information.



Ports and Connectors

InternetVue[™] has two sets of output video connectors, and one audio output connector. For video, there are the Component Video and Composite video outputs.

Composite Video (CVBS) is an older standard, and is very common in all kinds of display devices. Its connector is denoted by a yellow center insulator. Composite Video carries a specific video format depending on the country of usage. In the USA, the video format is NTSC. NTSC video frames consist of 525 lines of vertical resolution, shown at 29.97 frames per second.

Component Video (Y-Pr-Pb) is a newer standard, capable of carrying signals from 480i up to 1080p. InternetVue^M can output up to 720p using this interface. Component Video is commonly used in high-definition TVs and projectors, and is <u>the preferred interface</u> for maximum image clarity, color vibrancy, and sharpness.


digital life ... addlogix style

Audio output is through a 3.5mm stereo mini-jack. An included audio cable has dual stereo RCA connectors on the opposite end.

The RJ45 connector is for wired 10/100Base-T networking. This interface will not affect the wireless networking operation of the unit.

The factory reset button must only be used when necessary. To perform a factory reset, depress the button for at least 10 seconds, remove power, wait 10 seconds, then re-attach power.

3.04.58 NOV0507



Overall Requirements

1. TV, projector, or other display device with component or composite video inputs.

For the best possible InternetVue[™] experience, an HDTV with component inputs is best. PCs with dual/quad-core processors and/or faster speed and more memory will result in smoother video playback especially when viewing content from the web.

- 2. PC Configuration:
 - Windows XP Home/Pro SP2, 2000 SP4, Vista (all versions) with administrator privileges
 - Pentium 4 or M, 1.8 GHz or faster
 - o 512MB RAM or more
 - O Wired (10/100BT) or wireless (802.11 b/g) network connection; WEP, WPA/WPA-PSK with TKIP encryption supported. For AES encryption support, please check the InternetVue™ support website.

Recommended PC Configuration:

These recommendations are for optimized viewing of full-motion video through InternetVue™.

- ✓ Pentium 4 or M, 2.0 GHz or newer, dual or quad-core CPU
- ✓ Wired (100BT) or wireless (802.11 g)
- ✓ No unnecessary applications running in the background
- ✓ If using a notebook, laptop, or tablet, Power Scheme should be set to "Desktop", or attach power supply for maximum performance.

Optional:

• Wired or wireless internet connection for internet access while using InternetVue™




Configuration Options

There are four possible ways to interface the InternetVue[™], your PC, and your internet connection. However, keep in mind that the internet connection is not necessary. Select which Configuration works best for you from the table below.

Configuration	Α	В	С	D
PC Network	Wireless	Wireless	Wired	Wired
Connection Type				
Internet Router Type	Wireless	Wired	Wired	Wireless

Configuration A: Wireless / Wireless In this Configuration, your PC communicates to InternetVue[™] via wireless networking. The InternetVue[™] then enables its "AP+" feature which allows it to connect your PC to your existing wireless router/gateway at the same time. Any form of wireless security enabled on your router/gateway will be automatically detected and used between the InternetVue[™] and your PC. You may be asked to provide wireless security passwords/passkeys. Write it down here for future reference:



TECHNOLOGY






Configuration B: Wireless / Wired In this Configuration, your PC communicates to InternetVue[™] via wireless networking. The InternetVue[™] is directly connected to your router/gateway via the wired network connection. **Broadband Router** Internet access is relayed through the InternetVue[™] to your PC via wireless networking. 2) PC2TV PC тν Configuration C: Wired / Wired In this Configuration, your PC communicates to both the InternetVue[™] and your router/gateway through wired network connections. **Broadband Router** ΡC2TV PC TV

Configuration D: Wired / Wireless

In this last Configuration, your PC utilizes its wired network connection for internet access from the gateway/router, while sending A/V to the InternetVue[™] through the wireless connection.







Installation Procedure

● Make sure that the TV or projector and the InternetVue[™] is unpowered. Connect the InternetVue[™] receiver box to your TV or projector's appropriate AV inputs.


TV with Component Video Inputs (Best Quality):



TV with Composite Video Input:



Ocnnect the power adapter to the InternetVue[™] DC power jack input first (a), then plug in the power adapter into an AC outlet (b). Turn on your TV or projector and select the appropriate AV input. If your configuration involves a wired connection to the InternetVue[™], go ahead and connect it to your router using an Ethernet cable.





 The InternetVue[™] will autodetect which output is being use to connect to the TV. In about 30-60 seconds, it will be fully initialized, and the following "Welcome Screen" will come up on your TV or projector:

	Č.
ed	Welcome to InternetVue
	To install the PC software:
	Insert the supplied CD and follow the installation instructions
)	2 Launch the InternetVue application on your PC
	Your InternetVue Display ID's are listed below:
	Wireless ID: PC2TV-HD
	Direct Connect ID:
	Wireless Internet ID:
	Security Access Number:
	add Logix digital life addlogix style

This confirms the connection between the InternetVue[™] receiver and the TV or projector. Now, you can begin installation of the PC2TV software on your computer by inserting the CD into your PC's CD-ROM drive. Follow all onscreen instructions and prompts. FRN

PC2TV Welcome Screen shown on your TV



NOTE: If you have an existing PC2TV software installation, please UNINSTALL IT FIRST. To do this, click on START \rightarrow ALL PROGRAMS \rightarrow PC2TV \rightarrow UNINSTALL. Follow the instructions. A system reboot may be required.

 Launch the PC2TV application by double-clicking its icon on your Windows desktop. 	🖏 PC2T¥ Display List	Select Output Display	×
Typically, the PC2TV will connect to your InternetVue™ receiver — automatically when there are no other receivers on the wired LAN or within wireless range.		Connecting to: PC2TV-5512	Ĵ
		Connect	Cancel
3.04.58	xipol bbs		



In the event that there is more than one InternetVue[™], the *Select Output Display* window will appear. Here, you can select the InternetVue[™] receiver by its "Wireless ID" as shown in the image of step 3 above.


Depending on your InternetVue[™] receiver's internal firmware, the PC2TV software may prompt you to upgrade its firmware to the latest version for optimal performance. Simply follow the instructions as this is done automatically.

	Select Output Display
	O Connect via Wireless ID
	PC2TV-HD
	PC2TV-DR1
= L	PC2TV-REC
. 🧶	PC2TV-SOB
	O Connect via Direct Connect ID

● When the PC2TV software connects to the InternetVue[™] for the very first time after initial installation, it automatically launches the Configuration Wizard. The Configuration Wizard allows you to select various options for Internet Connections as well as personal preferences and protection settings such as user passwords and display access codes.

Configuration Wizard

The Configuration Wizard runs after initial installation of the PC2TV software. The wizard will guide you through a step-by-step process. Follow the instructions, select the appropriate options, and then click NEXT until completed.








resolutions like 1280 x 720 for Photo mode.







Configuration Wizard			X
PC2TV Display Conn	ectivity Wizard		Do not show this wizard again 🔲
Configuration	Settings		Tutorial
🚨 Welcome			Password The Continue of Continue
🛤 ТV Туре	Password:		The (optional) Configuration Password protects the PC2TV Display configuration
🖗 Conn Summary	Confirm Password:		from being tampered with by unauthorized users.
Password Setup		Clear	Confirm Password The password must be re-entered to
🛏 Device Settings			ensure it was entered correctly.
Wireless Settings			
🔇 Summary			
Cancel		Sack Next >>	Finish
Password Setup			
This is completely		d to prevent <mark>other</mark> s from ch	anging your configuration.
inis is completely	VU	E	




Configuration Wizard PC2TV Display Conn	ectivity Mizard		Do not show this wizard again 🗖
Configuration Configuration Velcome TV Type Conn Summary Password Setup C. Device Settings Vireless Settings Summary	Settings Device Name (SSID):	PC2TV- HDTV	Tutorial Oevice Name The Device Name or SSID is a unique wireless identifier for your PC2TV display device.
Cancel		< Back Next >>	Finish
Device Name (SSID)			TV

Device Name (SSID)

This allows you to change the "Wireless ID" broadcasted by the InternetVue™. This is useful when multiple receivers are present. You can assign any four-character alphanumeric suffix to each InternetVue[™] box. The InternetVue[™] receiver will then have an SSID of "PC2TV-xxxx" where the "xxxx" is the four-character alphanumeric name entered.

VUE —





Wireless Network

Select the correct settings here for internet access while connected to the InternetVue™ receiver. The correct option here is based on your configuration as described in the beginning of this manual.

Configuration A

Select "Connect to external networks using wireless"

Select the wireless gateway/router you wish to connect to for internet access. If wireless security is present, the icon next to the SSID will have a padlock icon and the security type shown:

If you are connecting to a wireless gateway/router with security, you will be prompted to enter the passkey —

The same exact key, encryption type, channel, and security will be automatically detected, must and will be used by the InternetVue[™] receiver.

8 95)		×
	Wireless Settings	
	Enter Wireless Network Key	
	Enter wireless network key between 8 and 23 characters.	
		٦
🔽 Display	keys as clear text	


AES encryption compatibility is not guaranteed. Please disable AES encryption on your wireless gateway/router if problems arise.



You can also manually enter the wireless gateway/router SSID, channel, security and encryption details by clicking on this button (1 - see previous page). The following window will appear:

Security Information	×
Colle	ect Security Connection Info
Access Point ID:	Clear
Wireless Channel:	11 💌
Security Type:	WPA2-PSK (TKIP)
	WPA2-PSK (TKIP)
	The encryption key for WPA2PSK should be entered as 8 to 23 ascii characters.
Shared Key:	Clear
Reenter Key:	
🔲 Show keys as clear text	OK Cancel

If the entered passkey, channel, SSID, or security type is incorrect, PC2TV will prompt you to try again. Click YES:






Configuration B

Select "Connect to external networks using wired ethernet"

Configuration C Select "None"

Configuration D Select "None"

In configurations B and D, only your PC and the InternetVue^M communicate wirelessly; the internet connection to the gateway/router is wired. Wireless security can be enabled between the PC and the InternetVue^M by clicking on the "*Enable Display Encryption*" checkbox (1).



The following window will appear. Enter 8 to 23 characters here. This will create a secure connection between the InternetVue^M and your PC.

<mark>89</mark> -}	Wireless Settings	X
	Enter Wireless Network Key	
	Enter wireless network key between 8 and 23 characters.	
🔽 Display I	keys as clear text	



Configuration Summary


This screen displays summary of the selections made and connections between various devices.

Configuration	Configuration	n Summary —		– 😰 Tutorial
Velcome TV Type Conn Summary Password Setup Device Settings Wireless Settings	Network Connection Security SSID	LAN Wireless Yes PC2TV-5512	Internet Wired N/A	Connectivity Summary This Summary displays the networkin connectivity based on your current configuration selections.
	Network Key	12345678 as clear text		

Click the Cancel button at the bottom of the screen to exit the Configuration Wizard at any time or click on Finish at the end of the wizard. After initial completion of the Configuration Wizard, the standard PC2TV application window will appear the next time it is run. The only way to invoke the Configuration Wizard again is to perform a *Factory Reset*, or clicking on the Wizard Button, see p. 22.

Depending on the settings made, PC2TV software may force the InternetVue[™] receiver to reboot. If so, the following message will appear. Click OK. →

The reboot process may take <u>30-60 seconds</u>. Once the Welcome screen is up on your TV, you now can start the PC2TV software.





Factory Reset



Sometimes a factory reset is necessary to clear all settings in the InternetVue M receiver. It will be brought back to the factory default state. The SSID may change, and starting the PC2TV software will invoke the Configuration Wizard once again.

Factory Reset Button To perform a factory reset, make sure the InternetVue[™] receiver is powered on and running for a few minutes. This is to ensure that it is not initializing. Press the Factory Reset Button for 10 seconds continuously, then release. After 30-60 seconds, the Welcome Screen will appear on the TV. Otherwise, try removing the power adapter from the InternetVue[™] for 10 seconds, then re-attach the power jack.

PC2TV Software


Click on the PC2TV icon on the Windows desktop (or from Start/All Programs).





The application automatically scans for InternetVue^M devices. If there is only one InternetVue^M, you will be connected to that unit automatically. Otherwise, you will be presented with the "*PC2TV Display List*" window. Here, you can select which InternetVue^M receiver to connect to:

👫 PC2T¥ Display	y List	×
	Select Output Display	
	Connect via Wireless ID	
	PC2TV-626 Refre	sh
	C Connect via Direct Connect ID	
	Connect Canc	el 🌖



Click **Hide/Mute** to blank the video and mute the audio.



PC2TV Advanced Settings

The Advanced Settings are the same as those in the Configuration Wizard, aside from a few additional options.

Summary


The first screen shows the overall connection summary:

Connected to: PC2T\	/-626	_	_	_ = X
Select TV		Video	Photo	Hide/Mute
General	Configuration	Summary		- ?
Summary L Device Settings TV Type				\square
🖗 Conn Summary	Network Connection	LAN Wireless	Internet Wireless	
	Security	Yes	Yes	
	SSID I Network Key	PC2TV-626	addlogix	1
Internet Connection				
Advanced	🔲 Show keys a	s clear text		



Device Settings

Clicking on "Device Settings" on the left side shows the next screen:







About the Security Access Number feature

When enabled, this forces the user to enter a four-digit code displayed on the TV before the InternetVue[™] will allow the PC to connect to it. This code changes each time the InternetVue[™] receiver is power-cycled.

The Security Access Number provides additional security by not allowing users to display video or change PC2TV settings without seeing the TV image. When starting the PC2TV software, enter the four digit Security Access Number as shown on the Welcome Screen on the TV.

Welcome to Internet						
To install the PC software:	Powered By					
	d follow the installation instructions					
2 Launch the InternetVue ap	pplication on your PC					
Your InternetVue Display I	ID's are listed below:					
Wireless ID:	PC2TV-HD					
Direct Connect ID:	0.0.0.0					
Wireless Internet ID:	192.168.1.187					
Security Access Numb	ber: 80864					
digital life addiogix style						
Enter t	this number here					
89	PC2TV Display Password					
	Display Access Validation					
	Display locess valuation					
	Enter the Access Number to access this projector.					
	Display Access Number:					
	OK Cancel					




TV Туре

You can change the TV Type here, either standard or HDTV:



Connection Summary

Here, you can select which output connectors to use, either composite or component video:





Internet Connection

In this screen, the settings for the internet connection can be changed.

TCP/IP Settings

There are two ways for InternetVue™ to have its IP address assigned.


First the through DHCP, the default method. In DHCP, the router/gateway, or DHCP server assigns InternetVue[™] an IP address automatically.

Secondly, you can enter the IP address, and all other related settings manually. When doing so, ensure that the IP address is unique, and that all other settings are accurate.

Wireless Settings

In this screen, the method of connecting to the internet and wireless security settings can be changed. See p. 15-16 for details.

Connected to: PC2TV	-626			- 🗆 X
	AL			
Select TV		Video	Photo	Hide/Mute
General	TCP/IP Settings			- (?)
Internet Connection	Obtain an IP addr	ess for this device a	automatically	
Wireless Settings	C Use the following	IP address configur	ation	
	IP Adorone:	0.0	. 0 . 0	
	that Manke	0.0	. 0 . 0	
	Galavraye	0.0	. 0 . 0	
	DUS	192 . 168	. 1. 3	
Advanced			0	Apply





Advanced



screen, shown at a lower resolution. Improves frame rate, and increases size when watching windowed video.



Troubleshooting Tips

If InternetVue does not appear on the list of available wireless networks

- InternetVue[™] is powered off, its wireless signal is too weak, or the antenna has come loose. Check for these conditions, or try moving the PC closer to it.
- If you are using Microsoft wireless utility:
 - 1. Exit the PC2TV application.
 - 2. Open the utility and view available wireless networks. Press the Refresh button to update the list of available APs. If the InternetVue[™] still does not appear in the available list, perform the following:
 - 3. Exit the PC2TV application. See p.19 if the PC2TV application refuses to completely shut down.
 - 4. Disable the wireless adapter from Windows "Network and Dialup Connections" dialog box.
 - 5. Enable the wireless adapter again.
 - 6. Re-launch the PC2TV application.
 - If you are using a non-Microsoft wireless utility:
 - 1. Exit the PC2TV application.
 - 2. Open the utility and connect to InternetVue[™].
 - 3. Re-launch the PC2TV application.
 - 4. After exiting the PC2TV application, you can use the wireless utility to reconnect to your network.

If you cannot connect to the Internet while projecting

- Make sure that the Welcome screen, displays a valid IP address in either the "Wireless Internet ID" or "Direct Connect ID" boxes. If there is no IP address, or it reads "0.0.0.0" the Internet connection will not be successful. If this is the case, do the following:
 - 1. Exit the PC2TV application and try to connect the PC to the Internet in the normal fashion.
 - 2. If the PC does not connect, the problem may be with your PC or broadband router.
 - 3. If the PC connects to the Internet directly, launch the PC2TV software and run the wizard again. Make sure that you configure for Wired Internet connectivity or Wireless Internet connectivity properly using the IP address displayed on the Welcome screen
- If your PC is projecting to the TV, and the Welcome screen had displayed a valid IP address, try connecting again by closing and restarting the PC2TV application software. Ensure than the security, channel, and encryption type between the PC2TV software and the router/gateway precisely match.

If your video performance is sluggish

- Update your PC's video card, storage, and any CPU optimization drivers
- Check your PC documentation and disable settings that bring down CPU performance when operating on battery power.
- In Windows XP, go to CONTROL PANEL > SYSTEM > ADVANCED > PERFORMANCE SETTINGS, to tune the settings to the following:
 - Battery Power Setting maximum performance
 - CPU maximum performance
 - Backlight lower-power mode
 - o Virtual Memory maximum number
 - Power Options maximum performance\
 - Reduce screen resolution or enable Pan and Scan
- You PC hardware is not powerful enough

If your InternetVue[™] fails to connect on repeated attempts

- Refer to p.19 and perform a Factory Reset.
- Uninstall the PC2TV software by clicking on START > ALL PROGRAMS > PC2TV > UNINSTALL. Follow the instructions. A system reboot may be required.
- Reinstall the PC2TV software from the CD.

If you see black border on the TV

- This is normal behavior.
- Due to variations in the TV settings when using (analog) component and composite inputs, the PC2TV display is sized so that any information at the bottom and top end of the PC screen is not cut off.



If the video pauses at the beginning of the sequence for less than 2 seconds and restarts

• This is normal behavior. The system is optimizing settings to optimize video compression and display performance.

If the DVD or video playback is jerky or does not display on the TV screen

- Check your video playback software documentation, and try disabling "Overlay"
- In the event that your PC has more than one display enabled, make sure video is being played back on your PC's primary display
- We recommend PowerDVD player for optimal viewing experience

If the video appears excessively blocky

- Check the quality of your wireless signal
- Try changing the wireless channel under Advanced Settings
- If possible, connect your system as described in Configuration C

The following messages for Vista are normal

- Dialog box that prompts if you would like to save the wireless setting as Home, Work or Public click Cancel button if this screen appears.
- Reverting to 16 bit Vista Basic Graphics configuration message on the Systray icon.

Registration and Support

To register InternetVue PC2TV product, go to <u>www.addlogix.com/register</u>

For technical support inquiries, go to www.addlogix.com/support





FCC Notice (USA)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the manufacturer's instructions, may cause interference to radio communications. Operation of the equipment in a residential area is likely to cause harmful interference in which the user will be required to correct the interference at the user's own expense.

There is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the problem by one or more of the following measures:

- o Reorient or relocate the receiving antenna.
- o Increase the separation between the equipment and receiver.
- o Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- o Consult an experienced radio-TV technician for help.
- o Use shielded I/O cables when operating this equipment.

This device complies with Part 15 of the FCC rules. Operation of this device is subject to the following two conditions:

o This device must not cause harmful interference.

o This device must accept interference which may cause undesired operation.

NOTICE: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Addlogix Inc. 459 Wald, Irvine, CA 92618, USA Technical support: www.addlogix.com/support

Copyright © 2007, Addlogix, all rights reserved.

InternetVue is a trademark of Addlogix. PC2TV is a trademark of Quartics, Inc. Windows and Internet Explorer are registered trademarks and Windows Vista is a trademark of Microsoft Corporation in the United States and other countries. Other brand and product names may be registered trademarks or trademarks of their respective holders.

