

# **SANbox 5000 Series Fibre Channel Switch**

## **Installation Guide**

Firmware Version 6.7

Information furnished in this manual is believed to be accurate and reliable. However, QLogic Corporation assumes no responsibility for its use, nor for any infringements of patents or other rights of third parties which may result from its use. QLogic Corporation reserves the right to change product specifications at any time without notice. Applications described in this document for any of these products are for illustrative purposes only. QLogic Corporation makes no representation nor warranty that such applications are suitable for the specified use without further testing or modification. QLogic Corporation assumes no responsibility for any errors that may appear in this document.

This SANbox switch is covered by one or more of the following patents: 6697359; other patents pending.

General Devices is trademark of General Devices Company, Inc.

Gnome is a trademark of the GNOME Foundation Corporation.

Java and Solaris are registered trademarks of Sun Microsystems, Inc.

Linux is a registered trademark of Linus Torvalds.

Mac OS X and Safari are registered trademarks of Apple Computer, Inc.

Microsoft, Windows XP, and Windows 2000/2003, and Internet Explorer are registered trademarks of Microsoft Corporation.

Motorola is a registered trademark of Motorola, Inc.

Netscape Navigator and Mozilla are trademarks or registered trademarks of Netscape Communications Corporation.

Red Hat is a registered trademark of Red Hat Software Inc.

S.u.S.E is a trademark of SUSE LINUX AG.

All other brand and product names are trademarks or registered trademarks of their respective owners.

### Document Revision History

Release, Revision A, July 25, 2007

Firmware Version 6.7

Enterprise Fabric Suite 2007 Version 6.07

# Table of Contents

<b>Section 1</b>	<b>Introduction</b>	
1.1	Intended Audience . . . . .	1-2
1.2	Related Materials . . . . .	1-2
1.3	New in this Release . . . . .	1-3
1.4	Safety Notices . . . . .	1-4
1.5	Sicherheitshinweise . . . . .	1-4
1.6	Notes informatives relatives à la sécurité. . . . .	1-4
1.7	Communications Statements . . . . .	1-5
1.7.1	Federal Communications Commission (FCC) Class A Statement . . .	1-5
1.7.2	Canadian Department of Communications Class A Compliance Statement . . . . .	1-5
1.7.3	Avis de conformité aux normes du ministère des Communications du Canada . . . . .	1-6
1.7.4	CE Statement . . . . .	1-6
1.7.5	VCCI Class A Statement . . . . .	1-7
1.7.6	MIC Class A Statement (model 5200 only) . . . . .	1-7
1.8	Laser Safety Information . . . . .	1-8
1.9	Electrostatic Discharge Sensitivity (ESDS) Precautions . . . . .	1-8
1.10	Accessible Parts . . . . .	1-9
1.11	Pièces Accessibles. . . . .	1-9
1.12	Zugängliche Teile . . . . .	1-9
1.13	General Public License . . . . .	1-10
1.13.1	Preamble . . . . .	1-10
1.13.2	Terms And Conditions For Copying, Distribution And Modification . . .	1-11
1.13.3	How to Apply These Terms to Your New Programs . . . . .	1-16
1.14	Technical Support. . . . .	1-17
1.14.1	Availability . . . . .	1-17
1.14.2	Training . . . . .	1-17
1.14.3	Contact Information . . . . .	1-18
<b>Section 2</b>	<b>General Description</b>	
2.1	Chassis Controls and LEDs . . . . .	2-2
2.1.1	Maintenance Button. . . . .	2-2
2.1.1.1	Resetting a Switch . . . . .	2-2
2.1.1.2	Placing the Switch in Maintenance Mode. . . . .	2-3

2.1.2	Chassis LEDs . . . . .	2-3
2.1.2.1	Input Power LED (Green) . . . . .	2-4
2.1.2.2	Heartbeat LED (Green) . . . . .	2-4
2.1.2.3	System Fault LED (Amber) . . . . .	2-4
2.2	Fibre Channel Ports . . . . .	2-5
2.2.1	Port LEDs . . . . .	2-6
2.2.1.1	Port Logged-In LED (Green) . . . . .	2-6
2.2.1.2	Port Activity LED (Green) . . . . .	2-6
2.2.2	Transceivers . . . . .	2-7
2.2.3	Port Types . . . . .	2-7
2.3	Ethernet Port . . . . .	2-8
2.4	Serial Port. . . . .	2-9
2.5	Power Supplies and Fans . . . . .	2-10
2.6	Switch Management. . . . .	2-11
2.6.1	QuickTools Web Applet . . . . .	2-11
2.6.2	Enterprise Fabric Suite 2007 . . . . .	2-12
2.6.3	Command Line Interface . . . . .	2-12
2.6.4	Application Programming Interface . . . . .	2-12
2.6.5	Simple Network Management Protocol . . . . .	2-13
2.6.6	Storage Management Initiative–Specification (SMI-S) . . . . .	2-13
2.6.7	File Transfer Protocols . . . . .	2-13
<b>Section 3 Planning</b>		
3.1	Devices. . . . .	3-1
3.2	Device Access . . . . .	3-2
3.3	Performance. . . . .	3-3
3.3.1	Distance. . . . .	3-4
3.3.2	Bandwidth . . . . .	3-5
3.3.3	Latency . . . . .	3-5
3.4	Feature Licensing. . . . .	3-6
3.5	Multiple Chassis Fabrics . . . . .	3-7
3.5.1	Optimizing Device Performance . . . . .	3-7
3.5.2	Domain ID, Principal Priority, and Domain ID Lock . . . . .	3-8
3.5.3	Stacking . . . . .	3-9
3.5.4	Common Topologies . . . . .	3-11
3.5.4.1	Cascade Topology . . . . .	3-12
3.5.4.2	Mesh Topology . . . . .	3-13
3.5.4.3	MultiStage Topology . . . . .	3-14
3.6	Switch Services . . . . .	3-15
3.7	Fabric Security . . . . .	3-16

3.7.1	Connection Security . . . . .	3-17
3.7.2	User Account Security . . . . .	3-17
3.7.3	Port Binding . . . . .	3-18
3.7.4	Device Security . . . . .	3-19
3.7.4.1	Security Example: Switches and HBAs with Authentication . . . . .	3-20
3.7.4.2	Security Example: RADIUS Server . . . . .	3-23
3.7.4.3	Security Example: Host Authentication . . . . .	3-27
3.8	Fabric Management . . . . .	3-29

**Section 4 Installation**

4.1	Site Requirements . . . . .	4-1
4.1.1	Fabric Management Workstation . . . . .	4-2
4.1.2	Switch Power Requirements . . . . .	4-2
4.1.3	Environmental Conditions . . . . .	4-2
4.2	Installing a Switch . . . . .	4-3
4.2.1	Mount the Switch . . . . .	4-4
4.2.2	Install Transceivers . . . . .	4-6
4.2.3	Configure the Workstation . . . . .	4-8
4.2.3.1	Configuring the Workstation IP Address for Ethernet Connections . . . . .	4-8
4.2.3.2	Configuring the Workstation Serial Port . . . . .	4-9
4.2.4	Connect the Workstation to the Switch . . . . .	4-10
4.2.5	Connect the Switch to AC Power . . . . .	4-11
4.2.6	Configure the Switch . . . . .	4-14
4.2.7	Cable Devices to the Switch . . . . .	4-16
4.3	Installing Firmware . . . . .	4-16
4.3.1	Using QuickTools to Install Firmware . . . . .	4-18
4.3.2	Using the CLI to Install Firmware . . . . .	4-18
4.3.2.1	One-Step Firmware Installation . . . . .	4-18
4.3.2.2	Custom Firmware Installation . . . . .	4-20
4.4	Adding a Switch to an Existing Fabric . . . . .	4-21
4.5	Installing Feature License Keys . . . . .	4-21

**Section 5 Diagnostics/Troubleshooting**

5.1	Chassis Diagnostics . . . . .	5-1
5.1.1	Input Power LED Is Extinguished . . . . .	5-2
5.1.2	System Fault LED Is Illuminated . . . . .	5-2
5.2	Power-On Self Test Diagnostics . . . . .	5-3

5.2.1	Heartbeat LED Blink Patterns . . . . .	5-3
5.2.1.1	Internal Firmware Failure Blink Pattern . . . . .	5-4
5.2.1.2	Fatal POST Error Blink Pattern. . . . .	5-4
5.2.1.3	Configuration File System Error Blink Pattern . . . . .	5-5
5.2.1.4	Over Temperature Blink Pattern . . . . .	5-6
5.2.2	Logged-In LED Indications . . . . .	5-7
5.2.2.1	E_Port Isolation . . . . .	5-8
5.2.2.2	Excessive Port Errors . . . . .	5-9
5.3	Transceiver Diagnostics . . . . .	5-11
5.4	Power Supply Diagnostics . . . . .	5-12
5.5	Recovering a Switch Using Maintenance Mode. . . . .	5-13
5.5.1	Exiting the Maintenance Menu . . . . .	5-14
5.5.2	Unpacking a Firmware Image File in Maintenance Mode . . . . .	5-14
5.5.3	Resetting the Network Configuration in Maintenance Mode . . . . .	5-15
5.5.4	Resetting User Accounts in Maintenance Mode . . . . .	5-15
5.5.5	Copying Log Files in Maintenance Mode . . . . .	5-15
5.5.6	Removing the Switch Configuration in Maintenance Mode. . . . .	5-15
5.5.7	Remaking the File System in Maintenance Mode . . . . .	5-16
5.5.8	Resetting the Switch in Maintenance Mode . . . . .	5-16
5.5.9	Updating the Boot Loader in Maintenance Mode . . . . .	5-16
<b>Section 6 Removal/Replacement</b>		
6.1	SFP Transceiver Removal and Replacement . . . . .	6-1
6.2	Power Supply Removal and Replacement. . . . .	6-2
<b>Appendix A Specifications</b>		
A.1	Fabric Specifications . . . . .	A-1
A.2	Maintainability. . . . .	A-3
A.3	Fabric Management . . . . .	A-4
A.4	Dimensions. . . . .	A-4
A.5	Electrical. . . . .	A-5
A.6	Environmental . . . . .	A-5
A.7	Regulatory Certifications . . . . .	A-6

**Glossary**

**Index**

## List of Figures

<b>Figure</b>	<b>Page</b>
2-1 SANbox 5000 Series Fibre Channel Switch. . . . .	2-1
2-2 Chassis Controls and LEDs. . . . .	2-2
2-3 Chassis LEDs. . . . .	2-3
2-4 Fibre Channel Ports . . . . .	2-5
2-5 Port LEDs. . . . .	2-6
2-6 Ethernet Port . . . . .	2-8
2-7 Serial Port and Pin Identification . . . . .	2-9
2-8 Model 5202/5602 Switch Power Supplies . . . . .	2-10
3-1 Two-Switch Stack . . . . .	3-9
3-2 Three-Switch Stack . . . . .	3-9
3-3 Four-Switch Stack . . . . .	3-10
3-4 Five Switch Stack . . . . .	3-10
3-5 Six Switch Stack. . . . .	3-11
3-6 Cascade-with-a-Loop Topology . . . . .	3-12
3-7 Mesh Topology. . . . .	3-13
3-8 Multistage Topology . . . . .	3-14
3-9 Security Example: Switches and HBAs . . . . .	3-20
3-10 Security Example: RADIUS Server . . . . .	3-23
3-11 Security Example: Management Server. . . . .	3-27
4-1 SANbox 5000 Series Fibre Channel Switch. . . . .	4-3
4-2 Mounting the Model 5200/5600 Switch in a Rack without Rails. . . . .	4-5
4-3 Mounting the Model 5200/5600 Switch in a Rack with a Rail Kit. . . . .	4-6
4-4 Removing 10-Gbps Port Covers . . . . .	4-7
4-5 Installing XPAK Switch Stacking Cables . . . . .	4-7
4-6 Workstation Cable Connections. . . . .	4-10
5-1 Chassis LEDs. . . . .	5-1
5-2 Logged-In LED. . . . .	5-7
5-3 Model 5202/5602 Switch Power Supply LEDs. . . . .	5-12
6-1 Power Supply Removal . . . . .	6-2
6-2 Power Supply Installation. . . . .	6-3

## List of Tables

<b>Table</b>	<b>Page</b>
1-1 SANbox 5000 Series Switch Models . . . . .	1-1
2-1 Serial Port Pin Identification . . . . .	2-9
3-1 Zoning Database Limits . . . . .	3-3
3-2 Extended Credit Distances and Cable Lengths . . . . .	3-4
3-3 Port-to-Port Latency. . . . .	3-5
4-1 Management Workstation Requirements. . . . .	4-2
4-2 Configuration Wizard Prompts . . . . .	4-14

---

## Notes



# Section 1

## Introduction

This manual describes the features and installation of the SANbox® 5000 Series Fibre Channel switch, firmware version 6.7. [Table 1-1](#) describes the SANbox 5000 Series switch models and their distinguishing features.

**Table 1-1. SANbox 5000 Series Switch Models**

Model	1-Gbps/2-Gbps	1/2/4-Gbps	Dual Replaceable Power Supplies
5200	✓		
5202	✓		✓
5600		✓	
5602		✓	✓

This manual is organized as follows:

- [Section 1](#) describes the intended audience, related materials, safety notices, communications statements, laser safety information, electrostatic discharge sensitivity precautions, accessible parts, general program license, and technical support.
- [Section 2](#) is an overview of the switch. It describes indicator LEDs and all user controls and connections.
- [Section 3](#) describes the factors to consider when planning a fabric.
- [Section 4](#) explains how to install and configure the switch.
- [Section 5](#) describes the diagnostic methods and troubleshooting procedures.
- [Section 6](#) describes the removal and replacement of field replaceable units. This includes media transceivers for all models and power supplies for switch models 5202 and 5602.
- [Appendix A](#) lists the switch specifications.

Please read the communications statements and laser safety information later in this section.

## 1.1 Intended Audience

This manual introduces users to the switch and explains its installation and service. It is intended for users who are responsible for installing and servicing network equipment.

## 1.2 Related Materials

The following manuals and materials are referenced in the text and/or provide additional information.

- *SANbox 5000 Series Enterprise Fabric Suite 2007 User Guide*, publication number 59097-04.
- *SANbox 5000 Series QuickTools Switch Management User Guide*, publication number 59235-01.
- *SANbox 5000 Series Fibre Channel Switch Command Line Interface Guide*, publication number 59183-01.
- *SANbox Fibre Channel Switch CLI Quick Reference Guide*, publication number 59261-00
- *SANbox Simple Network Management Protocol Reference Guide*, publication number 59047-07
- *CIM Agent Reference Guide*, publication number 59223-01
- *QLogic Switch Interoperability Guide v3.0*. This PDF document can be downloaded at <http://www.qlogic.com/interopguide/info.asp#inter>.
- Fibre Channel-Arbitrated Loop (FC-AL-2) Rev. 6.8.
- Fibre Channel-10-bit Interface Rev. 2.3.
- Definitions of Managed Objects for the Fabric Element in Fibre Channel Standard (draft-ietf-ipfc-fabric-element-mib-04.txt).

The Fibre Channel Standards are available from:

Global Engineering Documents, 15 Inverness Way East, Englewood, CO  
80112-5776 Phone: (800) 854-7179 or (303) 397-7956  
Fax: (303) 397-2740.

## 1.3

**New in this Release**

The following items are new in the current release:

- The switch is equipped with the QuickTools embedded graphical user interface. QuickTools is a web applet that provides basic switch management tools.
- Enterprise Fabric Suite 2007 is a workstation-based Java® application that provides a graphical user interface for fabric management. Enterprise Fabric Suite 2007 includes the mPort Technology feature by which you can move port licenses from active ports to inactive ports including 10-Gbps ports. Enterprise Fabric Suite 2007 comes with a free 30-day trial license – a permanent license is available for purchase from your authorized reseller.
- The following optional features are available in Enterprise Fabric Suite 2007 and the Command Line Interface (CLI) with the purchase and installation of a license key:
  - ❑ Fabric Security provides for Secure Socket Layer (SSL) and Secure Shell (SSH) connection security, device security using Challenge Handshake Authentication Protocol (CHAP), and remote authentication using a Remote Authentication Dial-In User Service (RADIUS) server.
  - ❑ SANdoctor provides tools for Fibre Channel connection verification, Fibre Channel route tracing, and transceiver diagnostic information.
  - ❑ Port Activation enables additional Fibre Channel ports up to the 20-port maximum.
- You can download firmware image files using Trivial File Transfer Protocol (TFTP) using the Firmware Install, Image Install, and Image TFTP commands.
- The switch supports hardware enforced hard zoning by default. If the zoning configuration exceeds the hardware limits; zones revert to soft zones.
- You can remove inactive zone sets and all zones and aliases not in the active zone set.
- Port binding establishes a list of port/devices that are permitted to log in to a switch port.
- Support for 5- and 6-switch stacks connected with 10-Gbps stacking cables.

## 1.4 Safety Notices

A **Warning** notice indicates the presence of a hazard that has the potential of causing personal injury.

4-4, 4-5, 4-11

4-4, 4-5, 4-11, 6-1

A **Caution** notice indicates the presence of a hazard that has the potential of causing damage to the equipment.

5-16

5-16, 6-2

## 1.5 Sicherheitshinweise

Ein **Warnhinweis** weist auf das Vorhandensein einer Gefahr hin, die möglicherweise Verletzungen zur Folge hat.

4-4, 4-5, 4-12

4-4, 4-5, 4-12, 6-1

Ein **Vorsichtshinweis** weist auf das Vorhandensein einer Gefahr hin, die möglicherweise Geräteschäden zur Folge hat.

5-16

5-16, 6-2

## 1.6 Notes informatives relatives à la sécurité

Une note informative **Avertissement** indique la présence d'un risque pouvant entraîner des blessures.

4-4, 4-5, 4-11

4-4, 4-5, 4-11, 6-1

Une note informative **Attention** indique la présence d'un risque pouvant entraîner des dégâts matériels.

5-16

5-16, 6-2

## 1.7 Communications Statements

The following statements apply to this product. The statements for other products intended for use with this product appear in their accompanying manuals.

### 1.7.1 Federal Communications Commission (FCC) Class A Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy, and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area may cause unacceptable interference, in which case the user will be required to correct the interference at their own expense.

Neither the provider nor the manufacturer is responsible for any radio or television interference caused by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.

### 1.7.2 Canadian Department of Communications Class A Compliance Statement

This equipment does not exceed Class A limits for radio emissions for digital apparatus, set out in Radio Interference Regulation of the Canadian Department of Communications. Operation in a residential area may cause unacceptable interference to radio and TV reception requiring the owner or operator to take whatever steps necessary to correct the interference.

### 1.7.3

## Avis de conformité aux normes du ministère des Communications du Canada

Cet équipement ne dépasse pas les limites de Classe A d'émission de bruits radioélectriques par les appareils numériques, telles que prescrites par le Règlement sur le brouillage radioélectrique établi par le ministère des Communications du Canada. L'exploitation faite en milieu résidentiel peut entraîner le brouillage des réceptions radio et télé, ce qui obligerait le propriétaire ou l'opérateur à prendre les dispositions nécessaires pour en éliminer les causes.

### 1.7.4

## CE Statement

The CE symbol on the equipment indicates that this system complies with the EMC (Electromagnetic Compatibility) directive of the European Community (89/336/EEC) and to the Low Voltage (Safety) Directive (73/23/EEC). Such marking indicates that this system meets or exceeds the following technical standards:

- EN 60950-1, A11:2004 – “Safety of Information Technology Equipment”.
- EN 55022:1998, A1:2000, A2:2003 – “Limits and Methods of Measurement of Radio Interference Characteristics of Information Technology Equipment”.
- EN 55024:1998, A1:2001, A2: 2003 – “Electromagnetic compatibility - Generic immunity standard Part 1: Residential commercial, and light industry.”
  - EN 61000-4-2: 1995, A1:1998, A2: 2001 – “Electrostatic Discharge Immunity Test”
  - EN 61000-4-3: 2002 – “Radiated, Radio-Frequency, Electromagnetic Field Immunity Test”
  - EN 61000-4-4: 1995, A1:2001, A2:2001 – “Electrical Fast Transient/Burst Immunity Test”
  - EN 61000-4-5: 1995, A1:2001 – “Surge Immunity Test”
  - EN 61000-4-6: 1996, A1:2001 – “Immunity To Conducted Disturbances, Induced By Radio-Frequency Fields”
  - EN 61000-4-8: 1993, A1:2001 – “Power Frequency Magnetic Field Immunity Test”
  - EN 61000-4-11 Second Edition: 2004 – “Voltage Dips, Short Interruptions And Voltage Variations Immunity Tests”
- EN 61000-3-2: 2000 – “Limits For Harmonic Current Emissions (Equipment Input Current Less Than/Equal To 16 A Per Phase)” Class A

- EN 61000-3-3: 1995, A1:2001 – “Limitation Of Voltage Fluctuations And Flicker In Low-Voltage Supply Systems For Equipment With Rated Current Less Than Or Equal To 16 A”

#### 1.7.5

### VCCI Class A Statement

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラス A 情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

This is a Class A product based on the standard of the Voluntary Control Council For Interference by Information Technology Equipment (VCCI). If this equipment is used in a domestic environment, radio disturbance may arise. When such trouble occurs, the user may be required to take corrective actions.

#### 1.7.6

### MIC Class A Statement (model 5200 only)

#### A급 기기 (업무용 정보통신기기)

이 기기는 업무용으로 전자파적합등록을 한 기기이오니 판매자 또는 사용자는 이 점을 주의하시기 바라며, 만약 잘못판매 또는 구입하였을 때에는 가정용으로 교환하시기 바랍니다.

As this equipment has undergone EMC registration for business purpose, the seller and/or the buyer is asked to beware of this point and in case a wrongful sale or purchase has been made, it is asked that a change to household use be made.

## 1.8 Laser Safety Information

This product uses Class 1 laser optical transceivers to communicate over the fiber optic conductors. The U.S. Department of Health and Human Services (DHHS) does not consider Class 1 lasers to be hazardous. The International Electrotechnical Commission (IEC) 825 Laser Safety Standard requires labeling in English, German, Finnish, and French stating that the product uses Class 1 lasers. Because it is impractical to label the transceivers, the following label is provided in this manual.



The following warning applies to XPAK optical transceivers:

**WARNING!!** LASER RADIATION  
DO NOT VIEW DIRECTLY WITH OPTICAL INSTRUMENTS  
CLASS 1M LASER PRODUCT

## 1.9 Electrostatic Discharge Sensitivity (ESDS) Precautions

The assemblies used in the switch chassis are ESD sensitive. Observe ESD handling procedures when handling any assembly used in the switch chassis.



## 1.10

**Accessible Parts**

The Field Replaceable Units (FRUs) for the SANbox 5000 Series switch are the following:

- Power supplies (models 5202 and 5602)
- Small Form-Factor Pluggable (SFP) optical transceivers
- XPAK optical transceivers

## 1.11

**Pièces Accessibles**

Les pièces remplaçables, Field Replaceable Units (FRU), du commutateur SANbox 5000 Series Fibre Channel Switch sont les suivantes:

- Alimentations de courant (5202, 5602)
- Interfaces aux media d'interconnexion appelés SFP transceivers.
- Interfaces aux media d'interconnexion appelés XPAK transceivers.

## 1.12

**Zugängliche Teile**

Nur die folgenden Teile im SANbox 5000 Series Fibre Channel Switch können kundenseitig ersetzt werden:

- Netzteile (5202, 5602)
- Schnittstellen für die Zwischenverbindungsträger, SFP transceivers genannt.
- Schnittstellen für die Zwischenverbindungsträger, XPAK transceivers genannt.

1.13

## General Public License

QLogic® Fibre Channel switches are powered by the Linux operating system. A machine-readable copy of the Linux source code is available upon written request to the following address. A nominal fee will be charged for reproduction, shipping, and handling costs in accordance with the General Public License.

QLogic Corporation  
6321 Bury Drive  
Eden Prairie, MN 55346-1739  
Attention: Technical Support - Source Request

Warning: Installation of software or files not authorized by QLogic will immediately and irrevocably void all warranty and service contracts on the affected units.

The following general public license has been reproduced with permission from:

GNU General Public License  
Version 2, June 1991  
Copyright (C) 1989, 1991 Free Software Foundation, Inc.  
59 Temple Place - Suite 330, Boston, MA 02111-1307, USA

1.13.1

### Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Library General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

#### 1.13.2

### **Terms And Conditions For Copying, Distribution And Modification**

1. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

2. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

3. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:
  - a. You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
  - b. You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
  - c. If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

4. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:
  - a. Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1

- and 2 above on a medium customarily used for software interchange;  
or,
- b. Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
  - c. Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

5. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.
6. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

7. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.
8. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

9. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.
10. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

11. Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.
12. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

13. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.
14. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

### 1.13.3

## How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

one line to give the program's name and an idea of what it does.

Copyright (C) *yyyy name of author*

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 59 Temple Place - Suite 330, Boston, MA 02111-1307, USA.

Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) *year name of author*

Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type `show w'. This is free software, and you are welcome to redistribute it under certain conditions; type `show c' for details.

The hypothetical commands `show w' and `show c' should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than `show w' and `show c'; they could even be mouse-clicks or menu items--whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample; alter the names:



Yoyodyne, Inc., hereby disclaims all copyright interest in the program  
'Gnomovision' (which makes passes at compilers) written by James Hacker.

*signature of Ty Coon*, 1 April 1989  
Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Library General Public License instead of this License.

## 1.14 Technical Support

Customers should contact their authorized maintenance provider for technical support of their QLogic switch products. QLogic-direct customers may contact QLogic Technical Support; others will be redirected to their authorized maintenance provider.

Visit the QLogic support Web site listed in [Contact Information](#) for the latest firmware and software updates.

### 1.14.1 Availability

QLogic Technical Support for products under warranty is available during local standard working hours excluding QLogic Observed Holidays.

### 1.14.2 Training

QLogic offers certification training for the technical professional for both the SANblade™ HBAs and the SANbox switches. From the training link at [www.qlogic.com](http://www.qlogic.com), you may choose Electronic-Based Training or schedule an intensive "hands-on" Certification course.

Technical Certification courses include installation, maintenance and troubleshooting QLogic SAN products. Upon demonstrating knowledge using live equipment, QLogic awards a certificate identifying the student as a Certified Professional. The training professionals at QLogic may be reached by email at [tech.training@qlogic.com](mailto:tech.training@qlogic.com).

1.14.3

**Contact Information**

<b>Support Headquarters</b>	QLogic Corporation 12984 Valley View Road Eden Prairie, MN 55344-3657 USA
QLogic Web Site	<a href="http://www.qlogic.com">www.qlogic.com</a>
Technical Support Web Site	<a href="mailto:support@qlogic.com">support@qlogic.com</a>
Technical Support Email	support@qlogic.com
Technical Training Email	tech.training@qlogic.com
<b>North American Region</b>	
Email	support@qlogic.com
Phone	+1-952-932-4040
Fax	+1 952-974-4910
<b>Europe, Middle East, and Africa Region</b>	
Email	emeasupport@qlogic.com
Phone Numbers by Language	+353 1 6924960 - English +353 1 6924961 - Français +353 1 6924962 - Deutsch +353 1 6924963 - Español +353 1 6924964 - Português +353 1 6924965 - Italiano
<b>Asia Pacific Region</b>	
Email	apacsupport@qlogic.com
Phone Numbers by Language	+63-2-885-6712 - English +63-2-885-6713 - (Mandarin) +63-2-885-6714 - (Japanese) +63-2-885-6715 - (Korean)
<b>Latin and South America Region</b>	
Email	calasupport@qlogic.com
Phone Numbers by Language	+52 55 5278 7016 - English +52 55 5278 7017 - Español +52 55 5278 7015 - Português

## Section 2


# General Description

This section describes the features and capabilities of the SANbox 5000 Series Fibre Channel switches. This includes models 5200 and 5600 and the dual power supply models 5202 and 5602 as shown in [Figure 2-1](#). The following topics are described:

- [Chassis Controls and LEDs](#)
- [Fibre Channel Ports](#)
- [Ethernet Port](#)
- [Switch Management](#)

Fabrics are managed with the Command Line Interface (CLI), the QuickTools web applet, or Enterprise Fabric Suite 2007™ (version 6.07).


- Refer to *SANbox 5000 Series Fibre Channel Switch Command Line Interface Guide* for more information about the CLI.
- Refer to the *SANbox 5000 Series QuickTools Switch Management User Guide* for information about QuickTools.
- Refer to the *SANbox 5000 Series Enterprise Fabric Suite 2007 User Guide* for information about using the Enterprise Fabric Suite 2007 application. Enterprise Fabric Suite 2007 comes with a 30-day trial license.



**Figure 2-1. SANbox 5000 Series Fibre Channel Switch**

## 2.1 Chassis Controls and LEDs

The Maintenance button shown in [Figure 2-2](#) is the only chassis control and is used to reset a switch or to recover a disabled switch. The chassis LEDs provide information about the switch's operational status. These LEDs include the Input Power LED, Heartbeat LED, and the System Fault LED. To apply power to the switch, plug the power cord into the switch AC power receptacle and into a 100–240 VAC power source.



**Figure 2-2. Chassis Controls and LEDs**

### 2.1.1 Maintenance Button

The Maintenance button is a dual-function momentary switch on the front panel. Its purpose is to reset the switch or to place the switch in maintenance mode. Maintenance mode sets the IP address to 10.0.0.1 and provides access to the switch for maintenance purposes when flash memory or the resident configuration file is corrupted. Refer to [“Recovering a Switch Using Maintenance Mode” on page 5-13](#) for more information about using maintenance mode.

#### 2.1.1.1 Resetting a Switch

To reset the switch, use a pointed tool to momentarily press and release (less than 2 seconds) the Maintenance button. The switch will respond as follows:

1. All the chassis LEDs will illuminate except the System Fault LED.
2. After approximately 1 minute, the power-on self test (POST) begins, extinguishing the Heartbeat LED.
3. When the POST is complete, the Input Power LED is illuminated and the Heartbeat LED is flashing once per second.

2.1.1.2

**Placing the Switch in Maintenance Mode**

To place the switch in maintenance mode, do the following:


1. Isolate the switch from the fabric.
2. Press and hold the Maintenance button with a pointed tool for a few seconds until the Heartbeat LED alone is illuminated. Continue holding the maintenance button until the Heartbeat LED extinguishes, then release the button. The Heartbeat LED illuminates continuously while the switch is in maintenance mode.

To exit maintenance mode and return to normal operation, momentarily press and release the Maintenance button to reset the switch.

2.1.2

**Chassis LEDs**

The chassis LEDs provide status information about switch operation. [Figure 2-3](#) identifies the chassis LEDs on a model 5200/5600 switch. The model 5202/5602 switch LED arrangement is the same. Refer to [“Port LEDs” on page 2-6](#) for information about port LEDs.



**Figure 2-3. Chassis LEDs**

2.1.2.1

### Input Power LED (Green)

The Input Power LED indicates the voltage status at the switch logic circuitry. During normal operation, this LED illuminates to indicate that the switch logic circuitry is receiving the proper DC voltages. When the switch is in maintenance mode, this LED is extinguished.

2.1.2.2

### Heartbeat LED (Green)

The Heartbeat LED indicates the status of the internal switch processor and the results of the POST. Following a normal power-up, the Heartbeat LED blinks about once per second to indicate that the switch passed the POST and that the internal switch processor is running. In maintenance mode, the Heartbeat LED illuminates continuously. Refer to [“Heartbeat LED Blink Patterns” on page 5-3](#) for more information about Heartbeat LED blink patterns.

2.1.2.3

### System Fault LED (Amber)


The System Fault LED illuminates to indicate a fault exists in the switch firmware or hardware. Fault conditions include POST errors, over temperature conditions, and power supply malfunctions. The Heartbeat LED shows a blink code for POST errors and over temperature conditions. Refer to [“Heartbeat LED Blink Patterns” on page 5-3](#) for more information about Heartbeat LED blink patterns. On model 5202/5602 switches, the Power Supply Fault LED indicates power supply faults. Refer to [“Power Supply Diagnostics” on page 5-12](#) for information about power supply faults.

## 2.2 Fibre Channel Ports

**NOTE:** This document refers to ports 0–15 as 1/2/4-Gbps ports for convenience though SANbox 5200 Series switches do not support 4-Gbps transmission.

The SANbox 5000 Series switch has sixteen 1/2/4-Gbps Fibre Channel ports and four 10-Gbps Fibre Channel ports. Ports are numbered 0–19 as shown in [Figure 2-4](#). Each of the 1/2/4-Gbps ports is served by a Small Form-Factor Pluggable (SFP) transceiver and is capable of 1-Gbps, 2-Gbps, or 4-Gbps transmission. SFPs are hot-pluggable. User ports can self-discover both the port type and transmission speed when connected to devices or other switches. The 1/2/4-Gbps port LEDs are located above their respective ports and provide port login and activity status information.

Each 10-Gbps port is served by an XPAK optical transceiver or an XPAK switch stacking cable for connecting to other SANbox 5000 Series switches. The XPAK switch stacking cable is a passive cable and transceiver assembly that is hot-pluggable. The 10-Gbps ports come from the factory with covers that must be removed before installing transceivers or cables. 10-Gbps port LEDs are located to the left of their respective ports and provide port login and activity status.




**Figure 2-4. Fibre Channel Ports**

The SANbox 5000 Series switch comes from the factory as an 8-, 12-, 16-, or 20-port switch, enabling ports 0–7, 0–11, 0–15, or 0–19 respectively. You can choose which ports are active using the mPort Technology feature in Enterprise Fabric Suite 2007, or enable additional ports up to the 20-port maximum through the purchase of a license key. Refer to [“Installing Feature License Keys” on page 4-21](#) for more information.

## 2.2.1 Port LEDs

Each port has its own Logged-In LED (L) and Activity LED (A) as shown in [Figure 2-5](#).



**Figure 2-5. Port LEDs**

### 2.2.1.1 Port Logged-In LED (Green)

The Logged-in LED indicates the logged-in or initialization status of the connected devices. After successful completion of the POST, the switch extinguishes all Logged-In LEDs. Following a successful port login, the switch illuminates the corresponding logged-in LED. This shows that the port is properly connected and able to communicate with its attached devices. The Logged-In LED remains illuminated as long as the port is initialized or logged in. If the port connection is broken or an error occurs that disables the port, the Logged-In LED is extinguished. Refer to [“Logged-In LED Indications” on page 5-7](#) for more information about the Logged-In LED.

### 2.2.1.2 Port Activity LED (Green)

The Activity LED indicates that data is passing through the port. Each frame that the port transmits or receives causes this LED to illuminate for 50 milliseconds. This makes it possible to observe the transmission of a single frame. When extending credits, the Activity LED for a donor port will reflect the traffic of the recipient port. Refer to [“Distance” on page 3-4](#) for more information about extended credits and donor ports.



### 2.2.2

## Transceivers

The SANbox 5000 Series switch supports SFP optical transceivers for the 1/2/4-Gbps ports and XPAK optical transceivers for the 10-Gbps ports. A transceiver converts electrical signals to and from optical laser signals to transmit and receive data. Duplex fiber optic cables plug into the transceivers which then connect to the devices. A 1/2/4-Gbps port is capable of transmitting at 1-Gbps, 2-Gbps, or 4-Gbps; however, the transceiver must also be capable of delivering at these rates.

The SFP and XPAK transceivers are hot pluggable. This means that you can remove or install a transceiver while the switch is operating without harming the switch or the transceiver. However, communication with the connected device will be interrupted. Refer to [“Install Transceivers” on page 4-6](#) for information about installing and removing SFP and XPAK optical transceivers.

### 2.2.3

## Port Types

SANbox 5000 Series switches support generic ports (G\_Port, GL\_Port), fabric ports (F\_Port, FL\_Port), and expansion ports (E\_Port). Switches come from the factory with all 1/2/4-Gbps ports configured as GL\_Ports. The 10-Gbps ports come from the factory configured as G\_Ports. Generic, fabric, and expansion ports function as follows:


- A GL\_Port self-configures as an FL\_Port when connected to a loop device, as an F\_Port when connected to a single device, or as an E\_Port when connected to another switch. If the device is a single device on a loop, the GL\_Port will attempt to configure first as an F\_Port, then if that fails, as an FL\_Port.
- A G\_Port self-configures as an F\_Port when connected to a single device, or as an E\_Port when connected to another switch.
- An FL\_Port supports a loop of up to 126 devices. An FL\_Port can also configure itself during the fabric login process as an F\_Port when connected to a single device (N\_Port).
- An F\_Port supports a single device.

E\_Ports enable you to expand the fabric by connecting SANbox 5000 Series switches. SANbox 5000 Series switches self-discover all inter-switch connections. Refer to [“Multiple Chassis Fabrics” on page 3-7](#) for more information about multiple chassis fabrics.

### 2.3 Ethernet Port

The Ethernet port is an RJ-45 connector that provides a connection to a management workstation through a 10/100 Base-T Ethernet cable. [Figure 2-6](#) shows the Ethernet port on a model 5200/5600; the model 5202/5602 is similar. A management workstation can be a Windows®, Solaris™, or a Linux® workstation that is used to configure and manage the switch fabric. You can manage the switch over an Ethernet connection using the CLI, QuickTools, Enterprise Fabric Suite 2007, or SNMP. The switch through which the fabric is managed is called the fabric management switch.


The Ethernet port has two LEDs: the Link Status LED (green) and the Activity LED (green). The Link Status LED illuminates continuously when an Ethernet connection has been established. The Activity LED illuminates when data is being transmitted or received over the Ethernet connection.



**Figure 2-6. Ethernet Port**

## 2.4 Serial Port

The SANbox 5000 Series switch is equipped with an RS-232 serial port for maintenance purposes. [Figure 2-7](#) shows the serial port on a model 5200/5600 switch; the model 5202/5602 is similar. You can manage the switch through the serial port using the CLI.



**Figure 2-7. Serial Port and Pin Identification**

The serial port connector requires a null-modem F/F DB9 cable. The pins on the switch RS-232 connector are shown in [Figure 2-7](#) and identified in [Table 2-1](#). Refer to [“Connect the Workstation to the Switch” on page 4-10](#) for information about connecting the management workstation through the serial port.

**Table 2-1. Serial Port Pin Identification**


Pin Number	Description
1	Carrier Detect (DCD)
2	Receive Data (RxD)
3	Transmit Data (TxD)
4	Data Terminal Ready (DTR)
5	Signal Ground (GND)
6	Data Set Ready (DSR)
7	Request to Send (RTS)
8	Clear to Send (CTS)
9	Ring Indicator (RI)

## 2.5 Power Supplies and Fans

The model 5200/5600 switch has a single power supply that converts 100–240 VAC to DC voltages for the various switch circuits. Four internal fans provide cooling. The switch monitors internal air temperature, and therefore does not monitor or report fan operational status. Air flow is front-to-back. To energize the switch, plug the power cord into the switch AC receptacle and into a 100–240 VAC power source.

The model 5202/5602 switch has two, hot pluggable power supplies that convert standard 100–240 VAC to DC voltages for the various switch circuits. Each power supply has an AC power receptacle and two status LEDs as shown in [Figure 2-8](#):

- The Power Supply Status LED (green) illuminates to indicate that the power supply is receiving AC voltage and producing the proper DC voltages.
- The Power Supply Fault LED (amber) illuminates to indicate that a power supply fault exists and requires attention.



**Figure 2-8. Model 5202/5602 Switch Power Supplies**

Each power supply is capable of providing all of the switch's power needs. During normal operation, each power supply provides half of the demand. If one power supply goes offline, the second power supply steps up and provides the difference.

The power supplies are hot swappable and interchangeable. Hot pluggable means that you can remove and replace one power supply while the switch is in operation without disrupting service. Refer to [Section 6](#) for information about replacing the power supplies.

Connecting a power supply to an AC voltage source energizes the switch logic circuitry. Internal fans provide cooling. Air flow is front-to-back.

## 2.6 Switch Management

The switch supports the following management tools:

- [QuickTools Web Applet](#)
- [Enterprise Fabric Suite 2007](#)
- [Command Line Interface](#)
- [Application Programming Interface](#)
- [Simple Network Management Protocol](#)
- [Storage Management Initiative–Specification \(SMI-S\)](#)
- [File Transfer Protocols](#)

### 2.6.1 QuickTools Web Applet

To provide basic switch management tools in a graphical user interface and to make switch management less dependent on a particular platform, each switch contains a web applet called QuickTools. QuickTools is designed to provide switch management for fabrics with less than four switches. For larger fabrics, consider the optional management application, Enterprise Fabric Suite 2007.

You run QuickTools by opening the switch IP address with an internet browser. Refer to the *SANbox 5000 Series QuickTools Switch Management User Guide*. QuickTools provides the following management features:

- Faceplate device management
- Switch and port statistics
- Configuration wizard
- Zoning administration
- Fabric tree for fabric management
- User account configuration
- Switch and fabric events
- Operational and environmental statistics
- Global device nicknames
- Online help

### 2.6.2

## Enterprise Fabric Suite 2007

Enterprise Fabric Suite 2007 is a separately licensed workstation-based Java® application that provides a graphical user interface for full fabric and switch management. Enterprise Fabric Suite 2007 is designed for managing fabrics of four or more switches and comes with a 30-day trial license. Enterprise Fabric Suite 2007 can run on a Windows, Solaris, Linux, or MacOS X workstation. Enterprise Fabric Suite 2007 provides all of the management features of QuickTools plus the following:

- Fabric tracker for monitoring fabric firmware versions
- Port threshold alarm configuration
- Topology display for fabric management
- Stack management
- Performance View for port performance
- Extended Credits Wizard
- Zoning Wizard
- mPort Technology for moveable port licenses

Refer to the *SANbox 5000 Series Enterprise Fabric Suite 2007 User Guide* for information about the Enterprise Fabric Suite 2007 application and its use.

### 2.6.3

## Command Line Interface

The command line interface (CLI) provides monitoring and configuration functions by which the administrator can manage the fabric and its switches. The CLI is available over an Ethernet connection or a serial connection. Refer to *SANbox 5000 Series Fibre Channel Switch Command Line Interface Guide* for more information.

### 2.6.4

## Application Programming Interface

The Application Programming Interface (API) enables an application provider to build a management application for QLogic switches. The library is implemented in ANSI standard C, relying only on standard POSIX run-time libraries. Contact your distributor or authorized reseller for information about the API.

### 2.6.5

## Simple Network Management Protocol

SNMP provides monitoring and trap functions for the fabric. SANbox firmware supports SNMP versions 1 and 2, the Fibre Alliance Management Information Base (FA-MIB) version 4.0, and the Fabric Element Management Information Base (FE-MIB) RFC 2837. Traps can be formatted using SNMP version 1 or 2. Refer to the *SANbox Simple Network Management Protocol Reference Guide* for more information about using SNMP.

### 2.6.6

## Storage Management Initiative–Specification (SMI-S)

SMI-S Provides for the management of the switch through third-party applications that use the SMI-S. Refer to the *CIM Agent Reference Guide* for more information.

### 2.6.7

## File Transfer Protocols

FTP and TFTP provide the command line interface for exchanging files between the switch and the management workstation. These files include firmware image files, configuration files, and log files.

---

## Notes



## Section 3

# Planning

Consider the following when planning a fabric:

- [Devices](#)
- [Device Access](#)
- [Performance](#)
- [Feature Licensing](#)
- [Multiple Chassis Fabrics](#)
- [Switch Services](#)
- [Fabric Security](#)
- [Fabric Management](#)

### 3.1

## Devices

**NOTE:** This document refers to ports 0–15 as 1/2/4-Gbps ports for convenience though SANbox 5200 Series switches do not support 4-Gbps transmission.

When planning a fabric, consider the number of devices and the anticipated demand. This will determine the number of ports that are needed and in turn the number of switches. Consider how many and what types of switches are needed.

The switch uses SFP transceivers in the 1/2/4-Gbps ports, but the device host bus adapters you are using may not. Consider whether the device adapters use SFP or Gigabit Interface Converters (GBIC) transceivers, and choose fiber optic cables accordingly. Use LC-type cable connectors for SFP transceivers and SC-type cable connectors for GBIC transceivers. Also consider the transmission speed compatibility of your devices, HBAs, switches, and SFPs.

Consider the distribution of targets and initiators. An F\_Port supports a single device. An FL\_Port can support up to 126 devices in an arbitrated loop.

## 3.2 Device Access

Consider device access needs within the fabric. Access is controlled by the use of zoning. Some zoning strategies include the following:

- Separate devices by operating system.
- Separate devices that have no need to communicate with other devices in the fabric or have classified data.
- Separate devices into department, administrative, or other functional group.
- Reserve a path and its bandwidth from one port to another.

Zoning divides the fabric for purposes of controlling discovery and inbound traffic. A zone is a named group of ports or devices. Members of the same zone can communicate with each other and transmit outside the zone, but cannot receive inbound traffic from outside the zone. A port/device can be a member of up to eight zones whose combined membership does not exceed 64.

Zoning is hardware enforced on a switch port if the sum of the logged-in devices plus the devices zoned with devices on that port is 64 or less. If a port exceeds this sum, that port behaves as a soft zone member. The port continues to behave as a soft zone member until the sum of logged-in and zoned devices falls back to 64, and the port is reset.

A zone can be a component of more than one zone set. Several zone sets can be defined for a fabric, but only one zone set can be active at one time. The active zone set determines the current fabric zoning.

A zoning database is maintained on each switch. [Table 3-1](#) describes the zoning database limits, excluding the active zone set.

**Table 3-1. Zoning Database Limits**

Limit	Description
MaxZoneSets	Maximum number of zone sets (256).
MaxZones	Maximum number of zones (2000).
MaxAliases	Maximum number of aliases (2500).
MaxTotalMembers	Maximum number of zone and alias members (10000) that can be stored in the zoning database. Each instance of a zone member or alias member counts toward this maximum.
MaxZonesInZoneSets	Maximum number of zones that are components of zone sets (2000), excluding the orphan zone set. Each instance of a zone in a zone set counts toward this maximum.
MaxMembersPerZone	Maximum number of members in a zone (2000).
MaxMembersPerAlias	Maximum number of members in an alias (2000)

### 3.3 Performance

**NOTE:** This document refers to ports 0–15 as 1/2/4-Gbps ports for convenience though SANbox 5200 series switches do not support 4-Gbps transmission.

The SANbox 5000 Series switch supports class 2 and class 3 Fibre Channel service at transmission rates of 1-, 2-, 4-, or 10-Gbps with a maximum frame size of 2148 bytes. A 1/2/4-Gbps port adapts its transmission speed to match that of the device to which it is connected prior to login when the connected device powers up. 10-Gbps ports transmit at 10-Gbps. Related performance characteristics include the following:

- [Distance](#)
- [Bandwidth](#)
- [Latency](#)

### 3.3.1 Distance

Consider the physical distribution of devices and switches in the fabric. Choose SFP transceivers that are compatible with the cable type, distance, Fibre Channel revision level, and the device host bus adapter. Refer to [Appendix A](#) for more information about cable types and transceivers.

Each Fibre Channel port is supported by a data buffer with a 16 credit capacity; that is, 16 maximum sized frames. For fibre optic cables, this enables full bandwidth over the following approximate distances:

- 26 kilometers at 1-Gbps (0.6 credits/Km)
- 13 kilometers at 2-Gbps (1.2 credits/Km)
- 6 kilometers at 4-Gbps (2.4 credits/km)

Longer distances can be spanned at full bandwidth on 1/2/4-Gbps ports by extending credits to G\_Ports, F\_Ports, and E\_Ports. Each port can donate 15 credits to a pool from which a recipient port can borrow. However, 1/2/4-Gbps ports can borrow only from other 1/2/4-Gbps ports. 10-Gbps ports cannot borrow or donate credits. The recipient port also loses a credit in the process. For example, you can configure a 1/2/4-Gbps recipient port to borrow 15 credits from one donor port for a total of 30 credits (15+15=30).

Regardless of how many credits are borrowed, extending credits requires a minimum cable length that is dependent on transmission speed. Extending credits over short cables can result in excessive port resets. [Table 3-2](#) describes the distances that are possible for a port with 30 credits and the minimum cable lengths.

**Table 3-2. Extended Credit Distances and Cable Lengths**

Transmission Speed	Range for 30 Credits	Minimum Cable Length
1-Gbps	50 Km (30÷0.6)	3 Km
2-Gbps	25 Km (30÷1.2)	1.5 Km
4-Gbps	12 Km (30÷2.4)	0.75 Km

You can configure recipient and donor ports using the Set Config Port CLI command.

## 3.3.2

## Bandwidth

Bandwidth is a measure of the volume of data that can be transmitted at a given transmission rate. A 1/2/4-Gbps port can transmit or receive at nominal rates of 1-, 2-, or 4-Gbps depending on the device to which it is connected. This corresponds to full duplex bandwidth values of 212 MB, 424 MB, and 850 MB respectively. 10-Gbps ports transmit at a nominal rate of 10-Gbps which corresponds to a full duplex bandwidth value of 2550 MB. Multiple source ports can transmit to the same destination port if the destination bandwidth is greater than or equal to the combined source bandwidth. For example, two 1-Gbps source ports can transmit to one 2-Gbps destination port. Similarly, one source port can feed multiple destination ports if the combined destination bandwidth is greater than or equal to the source bandwidth.

In multiple chassis fabrics, each link between chassis contributes 212, 424, 850, or 2550 megabytes of bandwidth between those chassis depending on the speed of the link. When additional bandwidth is needed between devices, increase the number of links between the connecting switches. The switch guarantees in-order-delivery with any number of links between chassis.

## 3.3.3

## Latency

Latency is a measure of how fast a frame travels from one port to another. The factors that affect latency include transmission rate and the source/destination port relationship as shown in [Table 3-3](#).

**Table 3-3. Port-to-Port Latency**

	Destination Rate				
	Gbps	1	2	4	10
Source Rate	1	< 0.6 $\mu$ sec	< 0.8 $\mu$ sec <sup>1</sup>	< 0.8 $\mu$ sec <sup>1</sup>	< 0.8 $\mu$ sec <sup>1</sup>
	2	< 0.5 $\mu$ sec	< 0.4 $\mu$ sec	< 0.4 $\mu$ sec <sup>1</sup>	< 0.4 $\mu$ sec <sup>1</sup>
	4	< 0.4 $\mu$ sec	< 0.3 $\mu$ sec	< 0.3 $\mu$ sec	< 0.3 $\mu$ sec <sup>1</sup>
	10	< 0.4 $\mu$ sec	< 0.3 $\mu$ sec	< 0.3 $\mu$ sec	< 0.2 $\mu$ sec

<sup>1</sup> Based on minimum frame size of 36 bytes. Latency increases for larger frame sizes.

### 3.4 Feature Licensing

**NOTE:** License keys enable menu selections in Enterprise Fabric Suite 2007 and commands and keywords in the CLI. License keys do not affect the capabilities of the QuickTools web applet.

License keys provide a way to expand the capabilities of your switch and fabric as your needs grow. Consider your need for the following features and arrange to purchase license keys from your switch distributor or authorized reseller.

- Enterprise Fabric Suite 2007 provides access to the Enterprise Fabric Suite 2007 application which is included on the product CD with a 30-day trial license. Enterprise Fabric Suite 2007 is a graphical user interface designed to provide comprehensive fabric management for fabrics of four or more switches. This license enables you to install and use Enterprise Fabric Suite 2007 on an unlimited number of workstations.
- Fabric Security provides access to the following security tools:
  - ❑ Security for Ethernet connections using the Secure Socket Layer (SSL) protocol and Telnet connections using the Secure Shell (SSH) protocol
  - ❑ Device and switch authorization and authentication using the Challenge Handshake Authentication Protocol (CHAP).
  - ❑ Remote authentication of users and devices using the Remote Authentication Dial-In User Service (RADIUS)
- SANdoctor provides access to the following tools:
  - ❑ Fibre Channel connection verification (Fcping CLI command)
  - ❑ Fibre Channel route tracing (Fctrace CLI command)
  - ❑ Transceiver diagnostic information (Show Media CLI command).
- Port Activation activates additional Fibre Channel ports to 12, 16, or 20 ports.

Upgrading a switch is not disruptive, nor does it require a switch reset. To order a license key, contact your switch distributor or your authorized reseller. Refer to [“Installing Feature License Keys” on page 4-21](#) for information about installing a license key.

### 3.5 Multiple Chassis Fabrics

By connecting switches together you can expand the number of available ports for devices. Each switch in the fabric is identified by a unique domain ID, and the fabric can automatically resolve domain ID conflicts. Because the Fibre Channel ports are self-configuring, you can connect SANbox 5000 Series switches together in a wide variety of topologies.

You can connect up to four SANbox 5000 Series switches together through the 10-Gbps ports, thus preserving the user ports for devices. This is called stacking. SANbox 5000 Series switches divide the 10-Gbps port buffer to balance traffic across the connection. The 10-Gbps ports operate with any standard XPAK interface. If the 10-Gbps ports are not active, you can connect SANbox 5000 Series switches with other switches through the 1/2/4-Gbps ports in a wide variety of topologies. Consider your topology and cabling requirements.

#### 3.5.1 Optimizing Device Performance

When choosing a topology for a multiple chassis fabric, you should also consider the locality of your server and storage devices and the performance requirements of your application. Storage applications such as video distribution, medical record storage/retrieval or real-time data acquisition can have specific latency or bandwidth requirements.

The SANbox 5000 Series switch provides the lowest latency of any product in its class. Refer to [“Performance” on page 3-3](#) for information about latency. However, the highest performance is achieved on Fibre Channel switches by keeping traffic within a single switch instead of relying on ISLs. Therefore, for optimal device performance, place devices on the same switch under the following conditions:

- Heavy I/O traffic between specific server and storage devices.
- Distinct speed mismatch between devices such as the following:
  - A 2-Gbps server and a slower 1-Gbps storage device
  - A high performance server and slow tape storage device

### 3.5.2

## Domain ID, Principal Priority, and Domain ID Lock

The following switch configuration settings affect multiple chassis fabrics:

- Domain ID
- Principal priority
- Domain ID lock

The domain ID is a unique number from 1–239 that identifies each switch in a fabric. The principal priority is a number (1–255) that determines the principal switch which manages domain ID assignments for the fabric. The switch with the highest principal priority (1 is high, 255 is low) becomes the principal switch. If the principal priority is the same for all switches in a fabric, the switch with the lowest WWN becomes the principal switch.

The domain ID lock allows (False) or prevents (True) the reassignment of the domain ID on that switch. Switches come from the factory with the domain ID set to 1, the domain ID lock set to False, and the principal priority set to 254. Refer to the Set Config Switch command in the *SANbox 5000 Series Fibre Channel Switch Command Line Interface Guide* for information about changing the default domain ID, domain ID lock, and principal priority parameters.


An unresolved domain ID conflict means that the switch with the higher WWN will isolate as a separate fabric, and the Logged-In LEDs on both switches will flash green to show the affected ports. If you connect a new switch to an existing fabric with its domain ID unlocked, and a domain ID conflict occurs, the new switch will isolate as a separate fabric. However, you can remedy this by resetting the new switch or taking it offline then back online. The principal switch will reassign the domain ID and the switch will join the fabric.

**NOTE:** Domain ID reassignment is not reflected in zoning that is defined by domain ID/port number pair or Fibre Channel address. You must reconfigure zones that are affected by domain ID reassignment. To prevent zoning definitions from becoming invalid under these conditions, lock the domain IDs.




### 3.5.3 Stacking

You can connect up to six 20-port SANbox 5000 Series switches together through the 10-Gbps ports, thus preserving the user ports for devices. This is called stacking. The following 2-, 3-, 4-, 5-, and 6-switch stacking configurations are recommended for best performance and redundancy. Each 10-Gbps port contributes 1 GB of bandwidth between chassis with one chassis hop between any two ports. [Figure 3-1](#) shows a two-switch stack of model 5000 switches using two 3-inch XPAK switch stacking cables. 32 1/2/4-Gbps ports are available for devices.




**Figure 3-1. Two-Switch Stack**

[Figure 3-2](#) shows a three-switch stack of SANbox 5000 Series switches using two 3-inch and one 9-inch XPAK switch stacking cables. 48 1/2/4-Gbps ports are available for devices.




**Figure 3-2. Three-Switch Stack**

Figure 3-3 shows a four-switch stack of model 5000 switches using three 3-inch and three 9-inch XPAK switch stacking cables. 64 1/2/4-Gbps ports are available for devices.




**Figure 3-3. Four-Switch Stack**

Figure 3-4 shows a five-switch stack of model 5000 switches using ten XPAK switch stacking cables. Eighty 1/2/4-Gbps ports are available for devices.



**Figure 3-4. Five Switch Stack**

Figure 3-5 shows a six-switch stack of model 5000 switches using eight XPAK switch stacking cables. Ninety-six 1/2/4-Gbps ports are available for devices.



**Figure 3-5. Six Switch Stack**

**3.5.4**

**Common Topologies**

The SANbox 5000 Series switch supports the following topologies using the 1/2/4-Gbps Fibre Channel ports:


- Cascade Topology
- Mesh Topology
- MultiStage Topology

### 3.5.4.1

## Cascade Topology

A cascade topology describes a fabric in which the switches are connected in series. If you connect the last switch back to the first switch, you create a cascade-with-a-loop topology as shown in [Figure 3-6](#). The loop reduces latency because any switch can route traffic in the shortest direction to any switch in the loop. The loop also provides failover should a switch fail.

- Each chassis link contributes up to 425 MB of bandwidth between chassis, 850 MB in full duplex. However, because of the sequential structure, that bandwidth will be shared by traffic between devices on other chassis.
- Latency between any two ports is no more than two chassis hops.
- 48 1/2/4-Gbps Fibre Channel ports are available for devices.




**Figure 3-6. Cascade-with-a-Loop Topology**

3.5.4.2

**Mesh Topology**

A mesh topology describes a fabric in which each chassis has at least one port directly connected to each other chassis in the fabric. Using 16-port SANbox 5000 Series switches the mesh fabric shown in [Figure 3-7](#) has the following characteristics:

- Each link contributes up to 425 MB of bandwidth between switches, 850 MB in full duplex. Because of multiple parallel paths, there is less competition for this bandwidth than with a cascade or a Multistage topology.
- Latency between any two ports is one chassis hop.
- 40 1/2/4-Gbps Fibre Channel ports are available for devices.




**Figure 3-7. Mesh Topology**

### 3.5.4.3

## MultiStage Topology

- Each link contributes up to 425 MB of bandwidth between chassis. Competition for this bandwidth is less than that of a cascade topology, but greater than that of the mesh topology.
- Latency between any two ports is no more than two chassis hops.
- 52 1/2/4-Gbps Fibre Channel ports are available for devices.



**Figure 3-8. Multistage Topology**

### 3.6 Switch Services

You can configure your switch to suit the demands of your environment by enabling or disabling a variety of switch services. Familiarize yourself with the following switch services and determine which ones you need. Notice that the SSH and SSL services require the Fabric Security license key.

- **Telnet:** Provides for the management of the switch over a Telnet connection. Disabling this service is not recommended. The default is enabled.
- **Secure Shell (SSH):** Provides for secure remote connections to the switch using SSH. Your workstation must also use an SSH client. The default is disabled. This service requires the Fabric Security license key.
- **GUI Management:** Provides for out-of-band management of the switch with Enterprise Fabric Suite 2007, the Application Programming Interface (API), SNMP, and SMI-S. If this service is disabled, the switch can only be managed inband or through the serial port. The default is enabled.
- **Inband Management:** Provides for the management of the switch over an inter-switch link using Enterprise Fabric Suite 2007, SNMP, management server, or the API. If you disable inband management, you can no longer communicate with that switch by means other than an Ethernet or serial connection. The default is enabled.
- **Secure Socket Layer (SSL):** Provides for secure SSL connections for Enterprise Fabric Suite 2007, the QuickTools web applet, the API, and SMI-S. This service must be enabled to authenticate users through a RADIUS server when using Enterprise Fabric Suite 2007. To enable secure SSL connections, you must first synchronize the date and time on the switch and workstation. Enabling SSL automatically creates a security certificate on the switch. The default is enabled. This service requires the Fabric Security license key.
- **QuickTools web applet (EmbeddedGUI):** Provides for access to the QuickTools web applet. QuickTools enables you to point at a switch with an internet browser and manage the switch through the browser. The default is enabled.
- **Simple Network Management Protocol (SNMP):** Provides for the management of the switch through third-party applications that use the Simple Network Management Protocol (SNMP). Security consists of a read community string and a write community string that serve as passwords that control read and write access to the switch. These strings are set at the factory to these well-known defaults and should be changed if SNMP is to be enabled. Otherwise, you risk unwanted access to the switch. The default is enabled.

- **Common Information Model (CIM):** Provides for the management of the switch through third-party applications that use the Storage Management Initiative–Specification (SMI-S). The default is enabled.
- **File Transfer Protocol (FTP):** Provides for transferring files rapidly between the workstation and the switch using FTP. The default is enabled.
- **Management Server (MS):** Enables or disables the management of the switch through third-party applications that use GS-3 Management Server. The default is disabled.

### 3.7 Fabric Security

An effective security profile begins with a security policy that states the requirements. A threat analysis is needed to define the plan of action followed by an implementation that meets the security policy requirements. Internet portals, such as remote access and E-mail, usually present the greatest threats. Fabric security should also be considered in defining the security policy.

Most fabrics are located at a single site and are protected by physical security, such as key-code locked computer rooms. For these cases, security methods such as user passwords for equipment and zoning for controlling device access, are satisfactory.

Fabric security is needed when security policy requirements are more demanding: for example, when fabrics span multiple locations and traditional physical protection is insufficient to protect the IT infrastructure. Another benefit of fabric security is that it creates a structure that helps prevent unintended changes to the fabric.

Fabric security consists of the following:

- [Connection Security](#)
- [User Account Security](#)
- [Port Binding](#)
- [Device Security](#)



### 3.7.1

## Connection Security

**NOTE:** You must install the Fabric Security license key to secure connections using SSH and SSL.

Connection security provides an encrypted data path for switch management methods. The switch supports the Secure Shell (SSH) protocol for the command line interface and the Secure Socket Layer (SSL) protocol for management applications such as Enterprise Fabric Suite 2007 and SMI-S.

The SSL handshake process between the workstation and the switch involves the exchanging of certificates. These certificates contain the public and private keys that define the encryption. When the SSL service is enabled, a certificate is automatically created on the switch. The workstation validates the switch certificate by comparing the workstation date and time to the switch certificate creation date and time. For this reason, it is important to synchronize the workstation and switch with the same date, time, and time zone. The switch certificate is valid 24 hours before its creation date and 365 days after its creation date. If the certificate should become invalid, create a new certificate using the Create Certificate CLI command. Refer to the *SANbox 5000 Series Fibre Channel Switch Installation Guide* for information about the Create Certificate CLI command.

Consider your requirements for connection security: for the command line interface (SSH), management applications such as Enterprise Fabric Suite 2007 (SSL), or both. Access to the device security menu selections in Enterprise Fabric Suite 2007 requires an SSL connection. If an SSL connection security is required, also consider using the Network Time Protocol (NTP) to synchronize workstations and switches.

### 3.7.2

## User Account Security

User account security consists of the administration of account names, passwords, expiration date, and authority level. If an account has Admin authority, all management tasks can be performed by that account in the CLI, QuickTools, and Enterprise Fabric Suite 2007™. Otherwise only monitoring tasks are available. The default account name, Admin, is the only account that can create or add account names and change passwords of other accounts. All users can change their own passwords. Account names and passwords are always required when connecting to a switch.

---

Authentication of the user account and password can be performed locally using the switch's user account database or it can be done remotely using a RADIUS server such as Microsoft® RADIUS. Authenticating user logins on a RADIUS server requires a secure management connection to the switch. Refer to [“Connection Security” on page 3-17](#) for information about securing the management connection. A RADIUS server can also be used to authenticate devices and other switches as described in [“Device Security” on page 3-19](#).

Consider your management needs and determine the number of user accounts, their authority needs, and expiration dates. Also consider the advantages of centralizing user administration and authentication on a RADIUS server.

**NOTE:** If the same user account exists on a switch and its RADIUS server, that user can login with either password, but the authority and account expiration will always come from the switch database.

### 3.7.3 Port Binding

Port binding provides authorization for a list of up to 32 switch and device WWNs that are permitted to log in to a particular switch port. Switches or devices that are not among the 32 are refused access to the port. Consider what ports to secure and the set of switches and devices that are permitted to log in to those ports.

### 3.7.4 Device Security

**NOTE:** You must install the Fabric Security license key to configure and activate device security and RADIUS servers. If you are upgrading your switch firmware to version 6.7 from version 5.x, you are granted a 30-day temporary license.

Device security provides for the authorization and authentication of devices that you attach to a switch. You can configure a switch with a group of devices against which the switch authorizes new attachments by devices, other switches, or devices issuing management server commands. Device security is configured through the use of security sets and groups.

A group is a list of device worldwide names that are authorized to attach to a switch. There are three types of groups: one for other switches (ISL), another for devices (port), and a third for devices issuing management server commands (MS).

A security set is a set of up to three groups with no more than one of each group type. The security configuration is made up of all security sets on the switch. The security database has the following limits:

- Maximum number of security sets is 4.
- Maximum number of groups is 16.
- Maximum number of members in a group is 1000.
- Maximum total number of group members is 1000.

In addition to authorization, the switch can be configured to require authentication to validate the identity of the connecting switch, device, or host. Authentication can be performed locally using the switch's security database, or remotely using a Remote Dial-In User Service (RADIUS) server such as Microsoft® RADIUS. With a RADIUS server, the security database for the entire fabric resides on the server. In this way, the security database can be managed centrally, rather than on each switch. You can configure up to five RADIUS servers to provide failover.

You can configure the RADIUS server to authenticate just the switch or both the switch and the initiator device if the device supports authentication. When using a RADIUS server, every switch in the fabric must have a network connection. A RADIUS server can also be configured to authenticate user accounts as described in [“User Account Security” on page 3-17](#). A secure connection is required to authenticate user logins with a RADIUS server. Refer to [“Connection Security” on page 3-17](#) for more information.

Consider the devices, switches, and management agents and evaluate the need for authorization and authentication. Also consider whether the security database is to be distributed on the switches or centralized on a RADIUS server and how many servers to configure.


The following examples illustrate how to configure a security database:

- [Security Example: Switches and HBAs with Authentication](#)
- [Security Example: RADIUS Server](#)
- [Security Example: Host Authentication](#)

### 3.7.4.1

## Security Example: Switches and HBAs with Authentication

Consider the fabric shown in [Figure 3-9](#). In this fabric, Switch\_1, HBA\_1, and Switch\_2 support authentication while the JBOD and HBA\_2 do not. The objective is to secure F\_Ports and E\_Ports in the fabric. To do this, configure security on the devices that support security: Switch\_1, Switch\_2, and HBA\_1.



**Figure 3-9. Security Example: Switches and HBAs**

1. Create a security set (Security\_Set\_1) on Switch\_1.
  - a. Create a port group (Group\_Port\_1) in Security\_Set\_1 with Switch\_1, HBA\_1, and JBOD as members.

Port Group on Switch_1: Group_Port_1	
Switch_1	Node WWN: 10:00:00:c0:dd:07:e3:4c Authentication: CHAP Primary Hash: MD5 Primary Secret: 0123456789abcdef
HBA_1	Node WWN: 10:00:00:c0:dd:07:c3:4d Authentication: CHAP Primary Hash: MD5 Primary Secret: fedcba9876543210
JBOD	Node WWN: 10:00:00:d1:ee:18:d4:5e Authentication: None  Node WWN: 10:00:00:d1:ee:18:d4:5f Authentication: None  Node WWN: 10:00:00:d1:ee:18:d4:5g Authentication: None

- Switch\_1 and all devices and switches connected to Switch\_1 must be included in the group even if the switch or devices does not support authentication. Others wise, the Switch\_1 port will isolate.
- You must specify HBAs by node worldwide name. Switches can be specified by port or node worldwide name. The type of switch worldwide name you use in the switch security database must be the same as that in the HBA security database. For example, if you specify a switch with a port worldwide name in the switch security database, you must also specify that switch in the HBA security database with the same port worldwide name.
- For CHAP authentication, create 32-character hexadecimal or 16-character ASCII secrets. The switch secret must be shared with the HBA security database.

- b. Create an ISL group (Group\_ISL\_1) in Security\_Set\_1 with Switch\_1, Switch\_2, HBA1, and JBOD as members. The Switch\_1 secret must be shared with the Switch\_2 security database.

ISL Group on Switch_1: Group_ISL_1	
Switch_1	Node WWN: 10:00:00:c0:dd:07:e3:4c Authentication: CHAP Primary Hash: MD5 Primary Secret: 0123456789abcdef Binding: None
Switch_2	Node WWN: 10:00:00:c0:dd:07:e3:4e Authentication: CHAP Primary Hash: MD5 Primary Secret: abcdefabcdef012 Binding: None

2. Configure security on HBA\_1 using the appropriate management tool. Logins between the Switch\_1 and HBA\_1 will be challenged for their respective secrets. Therefore, the secrets for Switch\_1 and HBA\_1 that you configured on Switch\_1 must also be configured on HBA\_1.
3. Save and activate Security\_Set\_1 on Switch\_1.
4. Create a security set (Security\_Set\_2) on Switch\_2. Create an ISL group (Group\_ISL\_2) in Security\_Set\_2 with Switch\_2 and Switch\_1 as members.

ISL Group on Switch_2: Group_ISL_2	
Switch_2	Node WWN: 10:00:00:c0:dd:07:e3:4e Authentication: CHAP Primary Hash: MD5 Primary Secret: 0123456789abcdef Binding: None
Switch_1	Node WWN: 10:00:00:c0:dd:07:e3:4c Authentication: CHAP Primary Hash: MD5 Secret: abcdefabcdef012 Binding: None


5. Save and activate Security\_Set\_2 on Switch\_2.

3.7.4.2

**Security Example: RADIUS Server**

Consider the fabric shown in [Figure 3-10](#). This fabric is similar to the one shown in [Figure 3-9](#) with the addition of Radius\_1 acting as a RADIUS server. Authorization and authentication is passed from the switch to Radius\_1 in the following cases:

- HBA\_1 login to Switch\_1
- Switch\_1 login to Switch\_2
- Switch\_2 login to Switch\_1



**Figure 3-10. Security Example: RADIUS Server**

1. Configure the Radius\_1 host as a RADIUS server on Switch\_1 and Switch\_2 to authenticate device logins. Specify the server IP address and the secret with which the switches will authenticate with the server. Configure the switches so that devices authenticate through the switches only if the RADIUS server is unavailable.

<b>Radius_1 Configuration on Switch_1 and Switch_2</b>	
Device Authentication Order	RadiusLocal – Authenticate devices using the RADIUS server security database first. If the RADIUS server is unavailable, then use the local switch security database.
Total Servers	1 – Enables support for one RADIUS server
Device Authentication Server	True – Enables Radius_1 to authenticate device logins.
Server IP Address	10.20.30.40
Secret	1234567890123456 – 16-character ASCII string (MD5 hash). This is the secret that allows direct communication with the RADIUS server.



2. Create a security set (Security\_Set\_1) on Switch\_1.
  - a. Create a port group (Group\_Port\_1) in Security\_Set\_1 with Switch\_1 and HBA\_1 as members.

Port Group on Switch_1: Group_Port_1	
Switch_1	Node WWN: 10:00:00:c0:dd:07:e3:4c Authentication: CHAP Primary Hash: MD5 Primary Secret: 0123456789abcdef
HBA_1	Node WWN: 10:00:00:c0:dd:07:c3:4d Authentication: CHAP Primary Hash: MD5 Primary Secret: fedcba9876543210

- Switch\_1 and all devices and switches connected to Switch\_1 must be included in the group even if the switch or device does not support authentication. Others wise, the Switch\_1 port will isolate.
- You must specify HBAs by node worldwide name. Switches can be specified by port or node worldwide name. The type of switch worldwide name you use in the switch security database must be the same as that in the HBA security database. For example, if you specify a switch with a port worldwide name in the switch security database, you must also specify that switch in the HBA security database with the same port worldwide name.
- For CHAP authentication, create 32-character hexadecimal or 16-character ASCII secrets. The switch secret must be shared with the HBA security database.

- b. Create an ISL group (Group\_ISL\_1) in Security\_Set\_1 with Switch\_1 and Switch\_2 as members. The Switch\_1 secret must be shared with the Switch\_2 security database.

ISL Group on Switch_1: Group_ISL_1	
Switch_1	Node WWN: 10:00:00:c0:dd:07:e3:4c Authentication: CHAP Primary Hash: MD5 Primary Secret: 0123456789abcdef Binding: None
Switch_2	Node WWN: 10:00:00:c0:dd:07:e3:4e Authentication: CHAP Primary Hash: MD5 Primary Secret: abcdefabcdef012 Binding: None

3. Configure security on HBA\_1 using the appropriate management tool. Logins between the Switch\_1 and HBA\_1 will be challenged (CHAP) for their respective secrets. Therefore, the secrets for Switch\_1 and HBA\_1 that you configured on Switch\_1 must also be configured on HBA\_1.
4. Save and activate Security\_Set\_1 on Switch\_1.
5. Create a security set (Security\_Set\_2) on Switch\_2. Create an ISL group (Group\_ISL\_2) in Security\_Set\_2 with Switch\_1 and Switch\_2 as members.


ISL Group on Switch_2: Group_ISL_2	
Switch_2	Node WWN: 10:00:00:c0:dd:07:e3:4e Authentication: CHAP Primary Hash: MD5 Primary Secret: abcdefabcdef0123 Binding: None
Switch_1	Node WWN: 10:00:00:c0:dd:07:e3:4c Authentication: CHAP Primary Hash: MD5 Primary Secret: 0123456789abcdef Binding: None

6. Save and activate Security\_Set\_2 on Switch\_2.

3.7.4.3

**Security Example: Host Authentication**

Consider the fabric shown in [Figure 3-11](#). In this fabric, only Switch\_2 and HBA\_2/APP\_2 support security, where APP\_2 is a host application. The objective is to secure the management server on Switch\_2 from unauthorized access by an HBA or an associated host application.



**Figure 3-11. Security Example: Management Server**

1. Create a security set (Security\_Set\_2) on Switch\_2.
2. Create a Management Server group (Group\_1) in Security\_Set\_2 with Switch\_2 and HBA\_2 or APP\_2 as its member.
  - You must specify HBAs by node worldwide name. Switches can be specified by port or node worldwide name. The type of switch worldwide name you use in the switch security database must be the same as that in the HBA security database. For example, if you specify a switch with a port worldwide name in the switch security database, you must also specify that switch in the HBA security database with the same port worldwide name.
  - For MD5 authentication, create secrets.

<b>MS Group: Group_1</b>	
Switch_2	Node WWN: 10:00:00:c0:dd:07:c3:4e CT Authentication: True Hash: MD5 Secret: 9876543210fedcba9
HBA_2 or APP_2	Node WWN: 10:00:00:c0:dd:07:c3:4d CT Authentication: True Hash: MD5 Secret: fedcba9876543210

3. Configure security on HBA\_2 or APP\_2 using the appropriate management tool. Logins between the Switch\_2 and HBA\_2 or APP\_2 will be challenged (MD5) for their respective secrets. Therefore, the secrets that you configured for HBA\_2 or APP\_2 on Switch\_2 must also be configured on HBA\_2 or APP\_2.
4. Save and activate Security\_Set\_2.

### 3.8 Fabric Management

The Enterprise Fabric Suite 2007 application executes on a management workstation and provides for the configuration, control, and maintenance of multiple fabrics. Supported platforms include Windows, Solaris, Linux, and MacOS X. Enterprise Fabric Suite 2007 comes with a 30-day trial license – a permanent license is available for purchase from your authorized reseller.

The browser-based application, QuickTools, and the CLI reside in the switch firmware and provide for the management of individual switches in a single fabric.

Consider how many fabrics and switches will be managed, how many management workstations are needed, and whether the fabrics will be managed with Enterprise Fabric Suite 2007, QuickTools, or the CLI.

A switch supports a combined maximum of 19 logins reserved as follows:

- 4 logins or sessions for internal applications such as management server and SNMP
- 9 high priority Telnet sessions
- 6 logins or sessions for Enterprise Fabric Suite 2007 inband and out-of-band logins, Application Programming Interface (API) inband and out-of-band logins, and Telnet logins. Additional logins will be refused.

---

## Notes

## **Section 4**

# **Installation**

This section describes how to install and configure the switch. The following topics are covered:

- [Site Requirements](#)
- [Installing a Switch](#)
- [Installing Firmware](#)
- [Adding a Switch to an Existing Fabric](#)
- [Installing Feature License Keys](#)

### **4.1**

## **Site Requirements**

Consider the following items when installing a SANbox 5000 Series switch:

- [Fabric Management Workstation](#)
- [Switch Power Requirements](#)
- [Environmental Conditions](#)

#### 4.1.1

### Fabric Management Workstation

The requirements for fabric management workstations are described in [Table 4-1](#):

**Table 4-1. Management Workstation Requirements**

Operating System	<ul style="list-style-type: none"><li>■ Windows 2003 SP1/SP2, XP</li><li>■ Solaris 9, 10, 10 x86</li><li>■ Red Hat® Enterprise Linux® 3, 4</li><li>■ SUSE™ Linux Enterprise Server 9, 10</li><li>■ Mac® OS X 10.4</li></ul>
Memory	256 MB or more
Disk Space	150 MB per installation (Enterprise Fabric Suite 2007)
Processor	1 GHz or faster
Internet Browser	Microsoft® Internet Explorer® 5.0 or later Netscape Navigator® 6.0 and later Mozilla™ 1.5 and later Safari® 1.0 and later Firefox 1.0 and later Java 2 Standard Edition Runtime Environment 1.4.2 for QuickTools

Telnet workstations require an RJ-45 Ethernet port or an RS-232 serial port and an operating system with a Telnet client.

#### 4.1.2

### Switch Power Requirements

Power requirements are 1 Amp at 100 VAC or 0.5 A at 240 VAC.

#### 4.1.3

### Environmental Conditions

Consider the factors that affect the climate in your facility such as equipment heat dissipation and ventilation. The switch requires the following operating conditions:


- Operating temperature range: 5–40°C (41–104°F)
- Relative humidity: 15–80%, non-condensing



## 4.2 Installing a Switch

Unpack the switch and accessories. The SANbox 5000 Series product is shipped with the components shown in [Figure 4-1](#):

- SANbox 5000 Series Fibre Channel Switch (1) with firmware installed
- Power cords
  - (1) –model 5200/5600
  - (2) –model 5202/5602
- Rubber feet (4)
- Mounting brackets (2) – model 5200/5600
- CD-ROM containing a 30-day trial license for Enterprise Fabric Suite 2007 switch management application, release notes, and documentation.



**Figure 4-1. SANbox 5000 Series Fibre Channel Switch**

Installing a SANbox 5000 Series switch involves the following steps:

1. [Mount the Switch](#)
2. [Install Transceivers](#)
3. [Configure the Workstation](#)
4. [Connect the Workstation to the Switch](#)
5. [Connect the Switch to AC Power](#)
6. [Configure the Switch](#)
7. [Cable Devices to the Switch](#)

#### 4.2.1

### Mount the Switch

The switch can be placed on a flat surface and stacked or mounted in a 19" EIA rack. Refer to [“Dimensions” on page A-4](#) for weight and dimensional specifications. Adhesive rubber feet are provided for surface mounts. Without the rubber feet, the switch occupies 1U of space in an EIA rack.

- A model 5200/5600 switch can be rack mounted without rails, however, rail kits are available from General Devices™ Company, model number C-874:

General Devices Company, LTD.  
P.O. Box 39100  
Indianapolis, IN 46239-0100  
317-897-7000  
www.generaldevices.com

- A model 5202/5602 switch requires a QLogic rail kit (part numbers SB5202-RACKKIT and SB5602-RACKKIT) for rack mounting.

**WARNING!!** Mount switches in the rack so that the weight is distributed evenly. An unevenly loaded rack can become unstable possibly resulting in equipment damage or personal injury.

#### **AVERTISSEMENT!!**

Installer les commutateurs dans l'armoire informatique de sorte que le poids soit réparti uniformément. Une armoire informatique déséquilibré risque d'entraîner des blessures ou d'endommager l'équipement.

**WARNUNG!!** Switches so in das Rack einbauen, dass das Gewicht gleichmäßig verteilt ist. Ein Rack mit ungleichmäßiger Gewichtsverteilung kann schwanken/umfallen und Gerätbeschädigung oder Verletzung verursachen.


**WARNING!!** If the switch is mounted in a closed or multi-rack assembly, the operating temperature of the rack environment may be greater than the ambient temperature. Be sure to install the chassis in an environment that is compatible with the maximum rated ambient temperature. Refer to [“Environmental” on page A-5](#) for technical specifications.

Do not restrict chassis air flow. Allow 16 cm (6.5 in) minimum clearance at the front and rear of the switch (surface mount) or rack for service access and ventilation.

Multiple rack-mounted units connected to the AC supply circuit may overload that circuit or overload the AC supply wiring. Consider the power source capacity and the total power usage of all switches on the circuit. Refer to [“Electrical” on page A-5](#).

Reliable grounding in the rack must be maintained from the switch chassis to the AC power source.


To mount a model 5200/5600 switch in a rack without the use of rails, fasten the brackets to the switch as shown in [Figure 4-2](#). Choose the bracket screw holes to produce the setback you want. Place the switch in the rack and fasten the bracket flanges to the rack with two screws on each side.



**Figure 4-2. Mounting the Model 5200/5600 Switch in a Rack without Rails**

To mount a model 5200/5600 switch in a rack using the General Devices C-874 rail kit, you must fasten the switch brackets and inner rails to the switch as shown in [Figure 4-3](#). Use the screws that come with the rail kit. Refer to the rail kit instructions for complete information.

**Figure 4-3. Mounting the Model 5200/5600 Switch in a Rack with a Rail Kit**




#### 4.2.2 Install Transceivers

The switch supports a variety of SFP and XPAK transceivers. To install a transceiver, insert the transceiver into the port and gently press until it snaps in place. To remove a transceiver, gently press the transceiver into the port to release the tension, then pull on the release tab or lever and remove the transceiver. Different transceiver manufacturers have different release mechanisms. Consult the documentation for your transceiver.

**NOTE:** The transceiver will fit only one way. If the transceiver does not install under gentle pressure, flip it over and try again.


**CAUTION!** To maintain proper air flow and prevent the switch from overheating, keep covers installed in unused 10-Gbps ports.

If you are using the 10-Gbps ports, remove the port covers by the cover tabs using your fingers or pliers as shown in [Figure 4-4](#).



**Figure 4-4. Removing 10-Gbps Port Covers**

To install XPAK switch stacking cables, position the cable connectors with the circuit board toward the mid line of the respective switch faceplates as shown in [Figure 4-5](#). When installing the 3-inch XPAK switch stacking cable, insert the cable connectors into the 10-Gbps ports at the same time.



**Figure 4-5. Installing XPAK Switch Stacking Cables**

### 4.2.3

## Configure the Workstation

If you plan to use the command line interface to configure and manage the switch, you must configure the workstation. This involves setting the workstation IP address for Ethernet connections, or configuring the workstation serial port. If you plan to use QuickTools or Enterprise Fabric Suite 2007 to manage the switch, the Configuration Wizard manages the workstation IP address for you – proceed to [“Connect the Workstation to the Switch” on page 4-10](#).

#### 4.2.3.1

### Configuring the Workstation IP Address for Ethernet Connections

The default IP address of a new switch is 10.0.0.1. To ensure that your workstation is configured to communicate with the 10.0.0 subnet, refer to the following instructions for your workstation:

- For a Windows workstation, do the following:
  1. Choose the **Start** button. Choose **Settings>Control Panel>Network and Dial-Up Connections**.
  2. Choose **Make New Connection**.
  3. Click the **Connect to a private network through the Internet** radio button then click the **Next** button.
  4. Enter 10.0.0.253 for the IP address.
- For a Linux or Solaris workstation, open a command window and enter the following command where (interface) is your interface name:

```
ifconfig (interface) ipaddress 10.0.0.253 netmask 255.255.255.0 up
```
- For a MacOS X workstation, do the following:
  1. Choose **System Preferences>System Preferences>Network**.
  2. Double-click your network adapter.
  3. In the configuration dialog, select **Manually** from the Configure IPv4 drop down menu.
  4. Enter 10.0.0.253 in the IP Address field.
  5. Enter 255.255.255.0 in the Subnet Mask field.
  6. Click **Apply Now**.

#### 4.2.3.2

### Configuring the Workstation Serial Port

To configure the workstation serial port, do the following:

1. Connect a null modem F/F DB9 cable from a COM port on the management workstation to the RS-232 serial port on the switch.
2. Configure the workstation serial port according to your platform:
  - For Windows:
    - a. Open the HyperTerminal application. Choose the **Start** button, select **Programs, Accessories, HyperTerminal, and HyperTerminal**.
    - b. Enter a name for the switch connection and choose an icon in the Connection Description window. Choose the **OK** button.
    - c. Enter the following COM Port settings in the COM Properties window and choose the **OK** button.
      - Bits per second: 9600
      - Data Bits: 8
      - Parity: None
      - Stop Bits: 1
      - Flow Control: None
  - For Linux:
    - a. Set up minicom to use the serial port. Create or modify the `/etc/minirc.dfl` file with the following content.
 

```
pr portdev/ttyS0
pu minit
pu mreset
pu mhangup
```
    - b. Verify that all users have permission to run minicom. Review the `/etc/minicom.users` file and confirm that the line "ALL" exists or that there are specific user entries.
  - For Solaris: Modify the `/etc/remote` file to include the following lines. `/dev/term/a` refers to serial port a. Choose the "dv" setting to match the workstation port to which you connected to the switch.
 


```
hardware:\ :dv=/dev/term/a:br#9600:e1=^C^S^Q^U^D:ie=%$:oe=^D:
```
3. Proceed to ["Connect the Switch to AC Power" on page 4-11](#).

4.2.4

### Connect the Workstation to the Switch

You can manage the switch using the CLI, QuickTools, or Enterprise Fabric Suite 2007. QuickTools and Enterprise Fabric Suite 2007 require an Ethernet connection to the switch. The CLI can use an Ethernet connection or a serial connection. Choose a switch management method, then connect the management workstation to the switch in one of the following ways:

- Indirect Ethernet connection from the management workstation to the switch RJ-45 Ethernet connector through an Ethernet switch or a hub. This requires a 10/100 Base-T straight cable as shown in [Figure 4-6](#).
- Direct Ethernet connection from the management workstation to the switch RJ-45 Ethernet connector. This requires a 10/100 Base-T cross-over cable as shown in [Figure 4-6](#).
- Serial port connection from the management workstation to the switch RS-232 serial port connector. This requires a null modem F/F DB9 cable as shown in [Figure 4-6](#).



**Figure 4-6. Workstation Cable Connections**



## 4.2.5

**Connect the Switch to AC Power**

**WARNING!!** This product is supplied with a 3-wire power cable and plug for the user's safety. Use this power cable in conjunction with a properly grounded outlet to avoid electrical shock. An electrical outlet that is not correctly wired could place hazardous voltage on metal parts of the switch chassis. It is the responsibility of the customer to ensure that the outlet is correctly wired and grounded to prevent electrical shock.

You may require a different power cable in some countries because the plug on the cable supplied with the equipment will not fit your electrical outlet. In this case, you must supply your own power cable. The cable you use must meet the following requirements:

- For 125 Volt electrical service, the cable must be rated at 10 Amps and be approved by UL and CSA.
- For 250 Volt electrical service: The cable must be rated at 10 Amps, meet the requirements of H05VV-F, and be approved by VDE, SEMKO, and DEMKO.

**AVERTISSEMENT!!**

Pour la sécurité de l'utilisateur, l'appareil est livré avec un câble d'alimentation trifilaire et une fiche. Pour éviter toute secousse électrique, enficher ce câble à une prise correctement mise à la terre. Une prise électrique dont les fils sont mal branchés peut créer une tension dangereuse dans les pièces métalliques du châssis switch. Pour éviter toute secousse électrique, s'assurer que les fils sont correctement branchés et que la prise est bien mise à la terre.

Dans certains pays les prises électriques sont de modèle différent; on ne peut y enficher le câble de l'appareil. On doit donc en utiliser un autre ayant les caractéristiques suivantes:

- Alimentation 125 V: Câble pour courant nominal de 10 A, agréé LAC et CSA.
- Alimentation 250 V: Câble pour courant nominal de 10 A, conforme au H05VV-F, et agréé VDE, SEMKO et DEMKO.

**WARNUNG!!** Dieses Produkt wird mit einem 3-adrigen Netzkabel mit Stecker geliefert. Dieses Kabel erfüllt die Sicherheitsanforderungen und sollte an einer vorschriftsmäßigen Schukosteckdose angeschlossen werden, um die Gefahr eines elektrischen Schlages zu vermeiden. Elektrosteckdosen, die nicht richtig verdrahtet sind, können gefährliche Hochspannung an den Metallteilen des switch-Gehäuses verursachen. Der Kunde trägt die Verantwortung für eine vorschriftsmäßige Verdrahtung und Erdung der Steckdose zur Vermeidung eines elektrischen Schlages.

In manchen Ländern ist eventuell die Verwendung eines anderen Kabels erforderlich, da der Stecker des mitgelieferten Kabels nicht in die landesüblichen Steckdosen paßt. In diesem Fall müssen Sie sich ein Kabel besorgen, daß die folgenden Anforderungen erfüllt:

- Für 125 Volt-Netze: 10 Ampere Kabel mit UL- und CSA-Zulassung.
- Für 250 Volt-Netze: 10 Ampere Kabel gemäß den Anforderungen der H05VV-F und VDE-, SEMKO- und DEMKO-Zulassung.

To power up a SANbox 5000 Series switch, do the following:

- For a model 5200/5600 switch, connect the power cord to the AC power receptacle on the front of the switch chassis and to a grounded AC outlet.
- For a model 5202/5602 switch, connect the power cords to the power supply receptacles on the back of the switch chassis and to a grounded AC outlet. To provide redundancy in the event of an AC power circuit failure, connect the switch power supplies to separate AC circuits.

The switch responds in the following sequence:

1. The chassis LEDs (Input Power, Heartbeat, System Fault) illuminate followed by all port Logged-In LEDs. The Logged-In LEDs that illuminate indicate the ports that are enabled.
2. After a couple seconds the System Fault LED is extinguished while the Input Power LED and Heartbeat LED remain illuminated.
3. After approximately one minute, the POST executes and the Heartbeat LED is extinguished.
4. After about another minute, the POST is complete, all LEDs are extinguished except the Input Power LED and the Heartbeat LED:
  - The Input Power LED remains illuminated indicating that the switch logic circuitry is receiving DC voltage. If not, contact your authorized maintenance provider.
  - The Heartbeat LED indicates the results of the POST. The POST tests the condition of firmware, memories, data-paths, and switch logic circuitry. If the Heartbeat LED blinks steadily about once per second, the POST was successful, and you can continue with the installation process. Any other blink pattern indicates that an error has occurred. Refer to [“Heartbeat LED Blink Patterns” on page 5-3](#) for more information about error blink patterns.

#### 4.2.6

### Configure the Switch

You can configure the switch using the CLI, QuickTools, or Enterprise Fabric Suite 2007. Enterprise Fabric Suite 2007 is an optional, full fabric graphical user interface that comes with a 30-day trial license. Refer to the *SANbox 5000 Series Enterprise Fabric Suite 2007 User Guide* for information about installing Enterprise Fabric Suite 2007.

To log in and configure the switch using QuickTools, do the following:

1. Open an Internet browser and enter the default IP address 10.0.0.1 to start the QuickTools web applet.
2. Log in to the switch using the default user name (*admin*) and password (*password*).
3. Obtain the IP address and subnet mask from your network administrator.
4. Open the QuickTools Wizards menu and select **Configuration Wizard**. Follow the instructions to set network parameters and the password. Changing the IP address will terminate the QuickTools session.
5. Open an Internet browser again and log in with the new IP address.

The Configuration wizard prompts you for the following configuration information:

**Table 4-2. Configuration Wizard Prompts**

Temporary IP address	
Temporary subnet mask	
Archive template file	
Switch domain ID (1--239)	
Domain ID Lock (Locked/Unlocked)	
Switch name	
Permanent IP address	
Permanent subnet mask	
Permanent gateway address	
Permanent network discovery method	
Date and time	
Admin account password	
Create a configuration archive?	

To configure the switch using the command line interface, do the following:

1. Open a command window according to the type of workstation and connection:
  - Ethernet (all platforms): Open a Telnet session with the default switch IP address and log in to the switch with default account name and password (admin/password).

```
telnet 10.0.0.1
Switch Login: admin
Password:      *****
```
  - NOTE:** To insure fabric security, you should change the password for the Admin account name. Refer to the *Passwd* command in the *SANbox 5000 Series Fibre Channel Switch Command Line Interface Guide*
  - Serial – Windows: Open the HyperTerminal application on a Windows platform.
    - a. Choose the **Start** button, select **Programs, Accessories, HyperTerminal, and HyperTerminal**.
    - b. Select the connection you created earlier and choose the **OK** button.
  - Serial – Linux: Open a command window and enter the following command:

```
minicom
```
  - Serial – Solaris: Open a command window and enter the following command:

```
tip hardware
```
2. Open an admin session and enter the Set Setup System command. Enter the values you want for switch IP address (EthNetworkAddress) and the network mask (EthNetworkMask). Refer to the *SANbox 5000 Series Fibre Channel Switch Command Line Interface Guide* for more information about the CLI commands.

```
SANbox #> admin start
SANbox (admin) #> set setup system
```
3. Open a Config Edit session and use the Set Config Switch command to modify the switch configuration.

#### 4.2.7

### Cable Devices to the Switch

Connect cables to the SFP transceivers and their corresponding devices, and then energize the devices. Device host bus adapters can have SFP (or SFF) transceivers or GigaBit Interface Converters (GBIC). LC-type duplex fiber optic cable connectors are designed for SFP transceivers, while SC-type connectors are designed for GBICs. Duplex cable connectors are keyed to ensure proper orientation. Choose the fiber optic cable with the connector combination that matches the device host bus adapter.

GL\_Ports self configure as FL\_Ports when connected to loop of devices or F\_Ports when connected to a single device. G\_Ports self configure as F\_Ports when connected to a single device. Both GL\_Ports and G\_Ports self configure as E\_Ports when connected to another switch.

#### 4.3

### Installing Firmware

The switch comes with current firmware installed. You can upgrade the firmware from the management workstation as new firmware becomes available. You can use the CLI, QuickTools, or Enterprise Fabric Suite 2007 to install new firmware. This guide describes how to install firmware using QuickTools and the CLI. Refer to the *SANbox 5000 Series Enterprise Fabric Suite 2007 User Guide* for information about installing firmware using Enterprise Fabric Suite 2007.

- [Using QuickTools to Install Firmware](#)
- [Using the CLI to Install Firmware](#)

**NOTE:** You can load and activate version 6.7 firmware on an operating switch without disrupting data traffic or having to re-initialize attached devices. If you attempt to perform a non-disruptive activation without satisfying the following conditions, the activation will fail. If the non-disruptive activation fails, you will usually be prompted to try again later. Otherwise, the switch will perform a disruptive activation.

- The current firmware version permits the installation and non-disruptive activation of 6.7 firmware. Refer to the *6.7 Firmware Release Notes* for previous compatible firmware versions.
- No changes are being made to switches in the fabric including powering up, powering down, disconnecting or connecting ISLs, changing switch configurations, or installing firmware.
- No port in the fabric is in the diagnostic state.
- No Zoning Edit sessions are open in the fabric.
- No changes are being made to attached devices including powering up, powering down, disconnecting, connecting, and HBA configuration changes.
- Install firmware on one switch at a time in the fabric. If you are installing firmware on one switch, wait 120 seconds after the activation is complete before installing firmware on a second switch.
- For a fabric in which all switches are running 6.7 firmware, no more than two Enterprise Fabric Suite 2007 sessions can be open.
- For a fabric in which one or more switches are running firmware prior to version 6.7, only one Enterprise Fabric Suite 2007 session can be open.

Ports that are stable when the non-disruptive activation begins, then change states, will be reset. When the non-disruptive activation is complete, Enterprise Fabric Suite 2007 sessions reconnect automatically. However, Telnet sessions must be restarted manually.

#### 4.3.1

### Using QuickTools to Install Firmware

To install firmware using QuickTools, do the following:

1. In the faceplate display, open the Switch menu and select Load Firmware.
2. In the Firmware Upload dialog, click the **Browse** button to browse and select the firmware file to be uploaded.
3. Click the **Start** button to begin the firmware load process. You will be shown a message warning you that the switch will be reset in order to activate the firmware.
4. QuickTools prompts you to activate the new firmware using a hot (non-disruptive) reset, if possible. Click the **OK** button to reset the switch and activate the new firmware.

#### 4.3.2

### Using the CLI to Install Firmware

The method you choose to install firmware using the CLI depends on the type of firmware activation you want.

- For a disruptive activation, enter the Firmware Install or Image Install command to download the firmware image file from an FTP or TFTP server, unpack it, and activate it in one step. Refer to [“One-Step Firmware Installation” on page 4-18](#).
- For a non-disruptive activation, enter the Image Fetch command to download the firmware image file from an FTP or TFTP server. Enter the Image Unpack command to unpack the image file, then enter the Hotreset command to perform a non-disruptive activation. Refer to [“Custom Firmware Installation” on page 4-20](#).

Refer to the *SANbox 5000 Series Fibre Channel Switch Command Line Interface Guide* for information about the CLI commands.

#### 4.3.2.1

### One-Step Firmware Installation

The Firmware Install and Image Install commands download the firmware image file from an FTP or TFTP server to the switch, unpacks the image file, and performs a disruptive activation in one step. The installation process prompts you to enter the following:

- The file transfer protocol (FTP or TFTP)
- IP address of the remote host
- An account name and password on the remote host (FTP only)
- Pathname for the firmware image file



Refer to the *SANbox 5000 Series Fibre Channel Switch Command Line Interface Guide* for information about the CLI commands.

1. Enter the following commands to download the firmware from a remote host to the switch, install the firmware, then reset the switch to activate the firmware.

```
SANbox #> admin start
```

```
SANbox #> firmware install
```

```
The switch will be reset. This process will cause a  
disruption to I/O traffic.
```

```
Continuing with this action will terminate all management  
sessions, including any Telnet sessions. When the firmware  
activation is complete, you may log in to the switch again.
```

```
Do you want to continue? [y/n]: y
```

```
Press 'q' and the ENTER key to abort this command.
```

2. Enter your choice for the file transfer protocol with which to download the firmware image file. FTP requires an user account and a password; TFTP does not.

```
FTP or TFTP      : ftp
```

3. Enter your account name on the remote host (FTP only) and the IP address of the remote host. When prompted for the source file name, enter the path for the firmware image file.

```
User Account     : johndoe
```

```
IP Address       : 10.0.0.254
```

```
Source Filename  : 6.7.00.11_mpc
```

```
About to install image. Do you want to continue? [y/n] y
```

4. When prompted to install the new firmware, enter Yes to continue or No to cancel. Entering Yes will disrupt traffic. This is the last opportunity to cancel.

```
About to install image. Do you want to continue? [y/n] y
```

```
Connected to 10.20.20.200 (10.20.20.200).
```

```
220 localhost.localdomain FTP server (Version wu-2.6.1-18)  
ready.
```

5. Enter the password for your account name (FTP only).

```
331 Password required for johndoe.
```

```
Password:*****
```

```
230 User johndoe logged in.
```

6. The firmware will now be downloaded from the remote host to the switch, installed, and activated.

To install firmware using the CLI when a File Transfer Protocol (FTP) server is present on the management workstation, use the Firmware Install command.

#### 4.3.2.2

### Custom Firmware Installation

A custom firmware installation downloads the firmware image file from an FTP or TFTP server to the switch, unpacks the image file, and resets the switch in separate steps. This allows you to choose the type of switch reset and whether the activation will be disruptive (Reset Switch command) or nondisruptive (Hotreset command). The following example illustrates a custom firmware installation with a nondisruptive activation.

1. Download the firmware image file from the workstation to the switch.
  - If your workstation has an FTP server, you can enter the Image Fetch command:  

```
SANbox (admin) #> image fetch account_name ip_address filename
```
  - If your workstation has a TFTP server, you can enter the Image TFTP command to download the firmware image file.  

```
SANbox (admin) #> image tftp ip_address filename
```
  - If your workstation has neither an FTP nor a TFTP server, open an FTP session and download the firmware image file by entering FTP commands:  

```
>ftp ip_address or switchname  
user:images  
password: images  
ftp>bin  
ftp>put filename  
ftp>quit
```
2. Display the list of firmware image files on the switch to confirm that the file was loaded.  

```
SANbox (admin) $>image list
```
3. Unpack the firmware image file to install the new firmware in flash memory.  

```
SANbox (admin) $>image unpack filename
```
4. Wait for the unpack to complete.  

```
image unpack command result: Passed
```
5. A message will prompt you to reset the switch to activate the firmware. Use the Hotreset command to attempt a non-disruptive activation.  

```
SANbox (admin) $>hotreset
```

## 4.4

## Adding a Switch to an Existing Fabric

If there are no special conditions to be configured for the new switch, simply plug in the switch and the switch becomes functional with the default fabric configuration. The default fabric configuration settings are as follows:

- Fabric zoning is sent to the switch from the fabric
- All ports will be GL\_Ports
- The default IP address 10.0.0.1 is assigned to the switch without a gateway or boot protocol configured (RARP, BOOTP, and DHCP).

If you are adding a switch to a fabric and do not want to accept the default fabric configuration, do the following:

1. If the switch is not new from the factory, reset the switch to the factory configuration before adding the switch to the fabric.
2. If you want to manage the switch through the Ethernet port, you must first configure the IP address.
3. Plug in the inter-switch links (ISL), but do not connect the devices.
4. Configure the port types for the new switch. The ports can be G\_Port, GL\_Port, F\_Port, FL\_Port, or Donor.
5. Connect the devices to the switch.
6. Make any necessary zoning changes.

## 4.5

## Installing Feature License Keys

Refer to [“Feature Licensing” on page 3-6](#) for information about available license keys. To install a license key using QuickTools, do the following:

1. Open the Switch Menu and select **Features** to open the Feature Licenses dialog.
2. In the Feature Licenses dialog, click the **Add** button to open the Add License Key dialog.
3. In the Add License Key dialog, enter the license key in the Key field.
4. Click the **Get Description** button to display the upgrade description.
5. Click the **Add** button to upgrade the switch. Allow a minute or two for the upgrade to complete.

To upgrade a switch using the command line interface, refer to the Feature command in the *SANbox 5000 Series Fibre Channel Switch Command Line Interface Guide*.

---

## Notes

## Section 5

# Diagnostics/Troubleshooting


Diagnostic information about the switch is available through the chassis LEDs and the port LEDs. Diagnostic information is also available through the CLI, QuickTools, or Enterprise Fabric Suite 2007 event logs and error displays. This section describes the following types of diagnostics:

- **Chassis Diagnostics** describes the Input Power LED and System Fault LED indications.
- **Power-On Self Test Diagnostics** describe the Heartbeat LED and the port Logged-In LED indications.
- **Power Supply Diagnostics** describes Power Supply Status LED and Power Supply Fault LED indications for model 5202/5602 switches.

This section also describes using maintenance mode to recover a disabled switch.

### 5.1 Chassis Diagnostics

Figure 5-1 shows the chassis LEDs on a model 5200/5600 switch; the model 5202/5602 switch is similar.



**Figure 5-1. Chassis LEDs**

The following conditions are described:

- **Input Power LED Is Extinguished**
- **System Fault LED Is Illuminated**

### 5.1.1

## Input Power LED Is Extinguished

The Input Power LED illuminates to indicate that the switch logic circuitry is receiving proper voltages. If the Input Power LED is extinguished, do the following:

1. Inspect the power cords and connectors. Is the cord unplugged? Is the cord or connector damaged?
  - Yes - Make necessary corrections or repairs. If the condition remains, continue.
  - No - Continue.
2. Inspect the AC power source. Is the power source delivering the proper voltage?
  - Yes - Continue.
  - No - Make necessary repairs.
    - For a model 5200/5600 switch, if the condition remains, contact your authorized maintenance provider.
    - For a model 5202/5602 switch, if the condition remains, continue.
3. Inspect the power supplies. Are the power supplies fully seated in their bays?
  - Yes - Continue. Replace the power supplies.
  - No - Reinstall the power supplies. If the condition remains, replace the power supplies.

### 5.1.2

## System Fault LED Is Illuminated

The System Fault LED illuminates to indicate that a fault exists in the switch firmware or hardware. If the System Fault LED illuminates, do the following:

- Check the Heartbeat LED for an error blink pattern and take the necessary actions. Refer to [“Heartbeat LED Blink Patterns” on page 5-3](#).
- For a model 5202/5602 switch, check the power supply LEDs and take the necessary actions. Refer to [“Power Supply Diagnostics” on page 5-12](#).

## 5.2

## Power-On Self Test Diagnostics

The switch performs a series of tests as part of its power-up procedure. The POST diagnostic program performs the following tests:

- Checksum tests on the boot firmware in PROM and the switch firmware in flash memory
- Internal data loopback test on all ports
- Access and integrity test on the ASIC

During the POST, the switch logs any errors encountered. Some POST errors are critical, others are not. The switch uses the Heartbeat LED and the Logged-In LED to indicate switch and port status. A critical error disables the switch so that it will not operate. A non-critical error allows the switch to operate, but disables the ports that have errors. If two or more ports fail the POST, the entire switch is disabled. Whether the problem is critical or not, contact your authorized maintenance provider.

If there are no errors, the Heartbeat LED blinks at a steady rate of once per second. If a critical error occurs, the Heartbeat LED will show an error blink pattern and the System Fault LED will illuminate. If there are non-critical errors, the switch disables the failed ports and flashes the associated Logged-In LEDs. Refer to [“Heartbeat LED Blink Patterns” on page 5-3](#) for more information about Heartbeat LED blink patterns.

## 5.2.1

### Heartbeat LED Blink Patterns

The Heartbeat LED indicates the operational status of the switch. When the POST completes with no errors, the Heartbeat LED blinks at steady rate of once per second. When the switch is in maintenance mode, the Heartbeat LED illuminates continuously. Refer to [“Recovering a Switch Using Maintenance Mode” on page 5-13](#) for more information about maintenance mode. All other blink patterns indicate critical errors. In addition to producing a Heartbeat error blink patterns, a critical error also illuminates the System Fault LED.


The Heartbeat LED shows an error blink pattern for the following conditions:

- 1 blink - Normal operation
- 2 blinks - [Internal Firmware Failure Blink Pattern](#)
- 3 blinks - [Fatal POST Error Blink Pattern](#)
- 4 blinks - [Configuration File System Error Blink Pattern](#)
- 5 blinks - [Over Temperature Blink Pattern](#)

### 5.2.1.1

## Internal Firmware Failure Blink Pattern


An internal firmware failure blink pattern is 2 blinks followed by a two second pause. The 2-blink error pattern indicates that the firmware has failed, and that the switch must be reset. Momentarily press and release the Maintenance button to reset the switch.



### 5.2.1.2

## Fatal POST Error Blink Pattern

A system error blink pattern is 3 blinks followed by a two second pause. The 3-blink error pattern indicates that a POST failure or a system error has left the switch inoperable. If a system error occurs, contact your authorized maintenance provider. Momentarily press and release the Maintenance button to reset the switch.






## 5.2.1.3

### Configuration File System Error Blink Pattern

A configuration file system error blink pattern is 4 blinks followed by a two second pause. The 4-blink error pattern indicates that a configuration file system error has occurred, and that the configuration file must be restored.



To restore the switch configuration, do the following:

1. Establish communications with the switch using Telnet. Enter one of the following on the command line:

```
telnet xxx.xxx.xxx.xxx
```

or

```
telnet switchname
```

where *xxx.xxx.xxx.xxx* is the switch IP address and *switchname* is the switch name associated with the IP address.

2. A Telnet window opens prompting you for a login. Enter an account name and password. The default account name and password are (admin, password).

3. Open an admin session to acquire the necessary authority.

```
SANbox $>admin start
```

4. Restore the configuration. When the restore is complete, the switch will reset.


```
SANbox (admin) $>config restore
```

If a configuration does not exist, enter the Config Backup command, then enter the Config Restore command.

#### 5.2.1.4

### Over Temperature Blink Pattern

An over temperature blink pattern is 5 blinks followed by a two second pause. The 5-blink error pattern indicates that the air temperature inside the switch has exceeded the failure temperature threshold.




If the Heartbeat LED shows the over temperature blink pattern, do the following:

1. Inspect the chassis vents. Are the intake and exhaust vents clear?
  - Yes - Continue.
  - No - Remove any debris from fan intake and exhaust if necessary. If the condition remains, continue.
2. For a model 5202/5602 switch, inspect the Power Supply Fault LED on both power supplies; otherwise continue. Is the Power Supply Fault LED illuminated on either power supply?
  - Yes - Replace the power supply. If the condition remains, continue.
  - No - Continue.
3. For a model 5202/5602 switch, observe the air flow direction from both power supplies; otherwise continue. Are the flow directions the same?
  - Yes - Continue.
  - No - Determine the proper air flow direction for the switch. Replace the power supply with the incorrect air flow direction with another having the correct air flow direction. Air flow direction is marked on the power supply part number label. If the condition remains, continue.
4. Consider the ambient air temperature near the switch and clearance around the switch. Make necessary corrections. If the condition remains, open a command line window and log on to the switch. Enter the Shutdown command, then power down the switch. Contact your authorized maintenance provider.

5.2.2

**Logged-In LED Indications**

Port diagnostics are indicated by the Logged-In LED for each port as shown in [Figure 5-2](#).



**Figure 5-2. Logged-In LED**

The Logged-In LED has three indications:

- Continuous illumination: A device is logged in to the port.
- Flashing once per second: A device is logging in to the port, or the port is in the diagnostics state.
- Flashing twice per second: The port is down, offline, or an error has occurred.

If a Logged-In LED is flashing twice per second, review the event browser for alarm messages regarding the affected port. You can also inspect the alarm log using the Show Alarm command. If there is an error, alarm messages may point to one or more of the following conditions:

- [E\\_Port Isolation](#)
- [Excessive Port Errors](#)

### 5.2.2.1

## E\_Port Isolation

A Logged-In LED error indication is often the result of E\_Port isolation. E\_Port isolation can be caused by the following:

- Security failure
- FL\_Port is connected to another switch
- Conflicting domain IDs
- Conflicting timeout values
- Conflicting zone membership between active zone sets

Review the event browser and do the following to diagnose and correct an isolated E\_Port:

1. Does the event browser show an alarm about an invalid attach on the affected port?
  - Yes - Review the ISL group in the active security set to ensure that the membership includes the necessary ports and that the secrets on all switches are correct.
  - No - Continue.
2. Does the event browser show a repeating alarm about an unsupported E\_Port command on the affected port?
  - Yes - The port is configured as an FL\_Port and connected to another switch. Correct the port connection or the port type.
  - No - Continue.
3. Display the fabric domain IDs using the Show Domains command. Are all domain IDs in the fabric unique?
  - Yes - Continue.
  - No - Correct the domain IDs on the offending switches using the Set Config Switch command. Reset the port. If the condition remains, continue.

4. Compare the RA\_TOV and ED\_TOV timeout values for all switches in the fabric using the Show Config Switch command. Is each timeout value the same on every switch?
  - Yes - Continue.
  - No - Correct the timeout values on the offending switches using the Set Config Switch CLI. Reset the port. If the condition remains, continue.
5. Display the active zone set on each switch using the Zoning Active command. Compare the zone membership between the two active zone sets. Are they the same?
  - Yes - Contact your authorized maintenance provider.
  - No - Deactivate one of the active zone sets or edit the conflicting zones so that their membership is the same. Reset the port. If the condition remains, contact your authorized maintenance provider.

**NOTE:** This can be caused by merging two fabrics whose active zone sets have two zones with the same name, but different membership.

#### 5.2.2.2

### Excessive Port Errors

The switch can monitor a set of port errors and generates alarms based on user-defined sample windows and thresholds. These port errors include the following:

- CRC errors
- Decode errors
- ISL connection count
- Device login errors
- Device logout errors
- Loss-of-signal errors

Port threshold alarm monitoring is disabled by default. Refer to the *SANbox 5000 Series Fibre Channel Switch Command Line Interface Guide* for information about managing port threshold alarms.

If the count for any of these errors exceeds the rising trigger for three consecutive sample windows, the switch generates an alarm and disables the affected port, changing its operational state to “down”. Port errors can be caused by the following:

- Triggers are too low or the sample window is too small
- Faulty Fibre Channel port cable
- Faulty SFP
- Faulty port
- Faulty device or HBA

Review the event browser to determine if excessive port errors are responsible for disabling the port. Look for a message that mentions one of the monitored error types indicating that the port has been disabled, then do the following:

1. Examine the alarm configuration for the associated error using the Show Config Threshold command. Refer to the Show Config Threshold command in the *SANbox 5000 Series Fibre Channel Switch Command Line Interface Guide*. Are the thresholds and sample window correct?
  - Yes - Continue
  - No - Correct the alarm configuration. If the condition remains, continue.
2. Reset the port, then perform an external port loopback test to validate the port and the SFP. Refer to the *SANbox 5000 Series Fibre Channel Switch Command Line Interface Guide* for information about testing ports. Does the port pass the test?
  - Yes - Continue
  - No - Replace the SFP and repeat the test. If the port does not pass the test, contact your authorized maintenance provider. Otherwise continue.
3. Replace the Fibre Channel port cable. Is the problem corrected?
  - Yes - Complete.
  - No - Continue.
4. Inspect the device to which the affected port is connected and confirm that the device and its HBA are working properly. Make repairs and corrections as needed. If the condition remains, contact your authorized maintenance provider.

### 5.3 Transceiver Diagnostics

**NOTE:** Transceiver diagnostic information is available with purchase of the SANdoctor license key. To purchase a license key, contact your authorized maintenance provider.


You can display the following transceiver information using the Show Media CLI command:

- Port number
- Manufacturer
- Temperature (°C)
- Operating voltage (volts)
- Transmitter bias (milliamps)
- Transmitter power (milliwatts)
- Receiver power (milliwatts)

The display indicates warning and alarm conditions for both high and low values.

## 5.4 Power Supply Diagnostics

A model 5202/5602 switch power supply has a Status LED (Green) and a Fault LED (Amber) as shown in [Figure 5-3](#). Under normal operating conditions, the Power Supply Status LED is illuminated and the Power Supply Fault LED is extinguished.



**Figure 5-3. Model 5202/5602 Switch Power Supply LEDs**

Consider the following indications:

- All power supply LEDs are normal, yet the System Fault LED is illuminated and the Heartbeat LED does not show a blink pattern. This means that the two power supplies have different air flow directions. Replace the power supply with the incorrect air flow direction with another having the correct air flow direction. Air flow direction is marked on the power supply part number label. Refer to [“Power Supply Removal and Replacement” on page 6-2](#).
- Power Supply Fault LED is illuminated. This means that the power supply is failing or has failed. Replace the power supply with another having the same air flow direction. Air flow direction is indicated on the power supply part number label. Refer to [“Power Supply Removal and Replacement” on page 6-2](#).



## 5.5

**Recovering a Switch Using Maintenance Mode**

A switch can become inoperable or unmanageable for the following reasons:

- Firmware becomes corrupt
- IP address is lost
- Switch configuration becomes corrupt
- Forgotten password

In these specific cases, you can recover the switch using maintenance mode. Maintenance mode temporarily returns the switch IP address to 10.0.0.1 and provides opportunities to do the following:

- [Exiting the Maintenance Menu](#)
- [Unpacking a Firmware Image File in Maintenance Mode](#)
- [Resetting the Network Configuration in Maintenance Mode](#)
- [Resetting User Accounts in Maintenance Mode](#)
- [Copying Log Files in Maintenance Mode](#)
- [Removing the Switch Configuration in Maintenance Mode](#)
- [Remaking the File System in Maintenance Mode](#)
- [Resetting the Switch in Maintenance Mode](#)
- [Updating the Boot Loader in Maintenance Mode](#)

To recover a switch, do the following:

1. Place the switch in maintenance mode. Press and hold the Maintenance button with a pointed tool until the Heartbeat LED alone is illuminated, then release the button. The Heartbeat LED illuminates continuously when the switch is in maintenance mode.
2. Establish a Telnet session with the switch using the maintenance mode IP address 10.0.0.1.
3. Enter the maintenance mode account name and password (prom, prom), and press the Enter key.

```
Switch login: prom
Password:xxxx
```

4. The maintenance menu displays several recovery options. To select a switch recovery option, press the corresponding number (displayed in option: field) on the keyboard and press the Enter key.

```
0) Exit
1) Image Unpack
2) Reset Network Config
3) Reset User Accounts to Default
4) Copy Log Files
5) Remove Switch Config
6) Remake Filesystem
7) Reset Switch
8) Update Boot Loader
Option:
```

These options and their use are described in the following subsections.

#### 5.5.1

### Exiting the Maintenance Menu

This option closes the current Maintenance menu session. To log in again, enter the maintenance mode account name and password (prom, prom). To return to normal operation, momentarily press and release the Maintenance button or power cycle the switch.

#### 5.5.2

### Unpacking a Firmware Image File in Maintenance Mode

This option unpacks and installs new firmware when the current firmware has become corrupt. Before using this option, you must load the new firmware image file onto the switch. The steps to install new firmware using this option are as follows:

1. Place the switch in maintenance mode. Refer to the procedure for maintenance mode in [“Recovering a Switch Using Maintenance Mode” on page 5-13](#).
2. Use FTP to load a new firmware image file onto the switch. Refer to [“Custom Firmware Installation” on page 4-20](#) for an example of how to load the image file. Close the FTP session.
3. Establish a Telnet session with the switch using the default IP address 10.0.0.1.
4. Enter the maintenance mode account name and password (prom, prom), and press the Enter key.

```
telnet 10.0.0.1
Switch login: prom
Password:xxxx
```

5. Select option 1 from the maintenance menu. When prompted for a file name prompt, enter the firmware image file name.  
Image filename: *filename*  
Unpacking 'filename', please wait...  
Unpackage successful.
6. Select option 7 to reset the switch and exit maintenance mode.

### 5.5.3

## Resetting the Network Configuration in Maintenance Mode

This option resets the network properties to the factory default values and saves them on the switch. Refer to *SANbox 5000 Series Fibre Channel Switch Command Line Interface Guide* for the default network configuration values.

### 5.5.4

## Resetting User Accounts in Maintenance Mode

This option restores the password for the Admin account name to the default (password) and removes all other user accounts from the switch.

### 5.5.5

## Copying Log Files in Maintenance Mode

This option copies all log file buffers to a file on the switch named *logfile*. You can use FTP to download this file to the management workstation. You must download the logfile before resetting the switch. Refer to the *SANbox 5000 Series Fibre Channel Switch Command Line Interface Guide* for information about downloading files from the switch.

### 5.5.6

## Removing the Switch Configuration in Maintenance Mode

This option deletes all configurations from the switch except the default configuration. This restores switch configuration parameters to the factory defaults. Refer to Reset command in the *SANbox 5000 Series Fibre Channel Switch Command Line Interface Guide* for the factory default values.

### 5.5.7

## Remaking the File System in Maintenance Mode

In the event of a loss of power, the switch configuration may become corrupt. The file system on which the configuration is stored must be re-created. This option resets the switch to the factory default values including user accounts and zoning. Refer to the Reset command in the *SANbox 5000 Series Fibre Channel Switch Command Line Interface Guide* for the factory default values.

**CAUTION!** If you choose the **Remake Filesystem** option, you will lose all changes made to the fabric configuration that involve that switch, such as password and zoning changes. You must then restore the switch from an archived configuration or reconfigure the portions of the fabric that involve the switch.

### 5.5.8

## Resetting the Switch in Maintenance Mode

This option closes the Telnet session, exits maintenance mode and reboots the switch using the current switch configuration. All unpacked firmware image files that reside on the switch are deleted.

### 5.5.9

## Updating the Boot Loader in Maintenance Mode

This option updates the system boot loader which loads the Linux kernel into memory. Use this option only at the direction of your authorized maintenance provider.

## Section 6

# Removal/Replacement

This section describes the removal and replacement procedures for the following field replaceable units (FRU):

- SFP transceivers
- Power supplies for model 5202/5602 switches

The switch is equipped with a battery that powers the non-volatile memory. This memory stores the switch configuration. The battery is not a field replaceable unit.

**WARNING!!** Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of the used battery according to the manufacturer's instructions.

**WARNUNG!!** Bei unsachgemäß ausgetauschter Batterie besteht Explosionsgefahr. Die Batterie nur mit der gleichen Batterie oder mit einem äquivalenten, vom Hersteller empfohlenen Batterietyp ersetzen. Die gebrauchte Batterie gemäß den Herstelleranweisungen entsorgen.

**AVERTISSEMENT!!**

Danger d'explosion si le remplacement de la pile est incorrect. Ne remplacer que par une pile de type identique ou équivalent recommandé par le fabricant. Jeter la pile usagée en observant les instructions du fabricant.

### 6.1 SFP Transceiver Removal and Replacement

The SFP transceivers can be removed and replaced while the switch is operating without damaging the switch or the transceiver. However, transmission on the affected port will be interrupted until the transceiver is installed.

To remove a transceiver, gently press the transceiver into the port to release the tension, then pull on the release tab or lever and remove the transceiver. Different transceiver manufacturers have different release mechanisms. Consult the documentation for your transceiver. To install, insert the transceiver into the port and gently press until it snaps in place.

**NOTE:** The SFP transceiver will fit only one way. If the SFP does not install under gentle pressure, flip it over and try again.

## 6.2 Power Supply Removal and Replacement


The SANbox 5202/5602 power supplies are hot pluggable. This means you can remove or install one of the power supplies while the switch is operating without disrupting service. The power supplies are also interchangeable; that is, the left and right power supplies are the same unit.

- CAUTION!**
- Both power supplies must have the same air flow direction to prevent the switch from overheating.
  - To avoid overheating, do not operate the switch with one power supply any longer than necessary.

When removing or replacing a power supply, consider the following:


- The left and right power supplies are interchangeable. However, you must orient the power supply so that AC receptacle is on the right.
- Both power supplies must have the same air flow direction. The part number label on the power supply indicates the air flow direction.
- When removing or replacing a power supply on an operating switch, be sure the Heartbeat LED is showing the normal 1 blink per second. This allows the switch to correctly report power supply status.

To remove a power supply, unplug the power supply and loosen the two knurled fasteners with a cross-head screw driver as shown in [Figure 6-1](#). Grasp the power supply handle and pull firmly to disengage the modular connector. Slide the power supply out of its bay.



**Figure 6-1. Power Supply Removal**

1. Confirm that the Heartbeat LED is showing the normal 1 blink per second. This allows the switch to correctly report power supply status.
2. Confirm that the new power supply is compatible with the switch air flow direction. The part number label on the power supply indicates the air flow direction as shown in [Figure 6-2](#).
3. With the AC receptacle on the right, slide the power supply into the bay until it is firmly seated. Secure the knurled fasteners by hand.
4. Plug the power cord into the AC receptacle and confirm that the air flow is correct.



**Figure 6-2. Power Supply Installation**

---

## Notes



# Appendix A Specifications

This appendix contains the specifications for the SANbox 5000 Series Fibre Channel switch. Refer to [Section 2](#) for the location of all connections, switches, controls, and components.

## A.1 Fabric Specifications

Fibre Channel Protocols .....	FC-PH Rev. 4.3 FC-PH-2 FC-PH-3 FC-AL Rev 4.6 FC-AL-2 Rev 7.0 FC-FLA FC-GS FC-GS-2 FC-GS-3 FC-FG FC-Tape FC-VI FC-SW-2 Fibre Channel Element MIB RFC 2837 Fibre Alliance MIB Version 4.0
Fibre Channel Classes of Service ..	Classes 2 and 3
Modes of Operation .....	Fibre Channel Classes 2 and 3, connectionless
Port Types	
■ 1/2/4-Gbps Ports.....	G_Port, GL_Port, F_Port, FL_Port, E_Port
■ 10-Gbps Ports.....	G_Port, F_Port, E_Port
Port Characteristics .....	All ports are auto-discovering and self-configuring.

Number of Fibre Channel Ports ..... (5200 Series models do not support 4-Gbps)	Variable and can be upgraded in the following configurations: <ul style="list-style-type: none"> <li>■ Eight 1/2/4-Gbps FC ports</li> <li>■ Twelve 1/2/4-Gbps FC ports</li> <li>■ Sixteen 1/2/4-Gbps FC ports</li> <li>■ Sixteen 1/2/4-Gbps FC ports plus four 10-Gbps FC ports</li> </ul>
Scalability.....	Maximum 239 switches depending on configuration
Maximum User Ports .....	> 475,000 ports depending on configuration
Buffer Credits.....	16 buffer credits per port, ASIC embedded memory
Media Type	
Ports 0-15 .....	SFP optical transceiver
Ports 16-19 .....	XPAK switch stacking cables
Fabric Port Speed	
Ports 0-15 (5200 series) .....	1.0625 or 2.125
Ports 0-15 (5600 series) .....	1.0625, 2.125, or 4.250-Gbps
Ports 16-19 .....	12.750 Gbps
Maximum Frame Size.....	2148 bytes (2112 byte payload)
System Processor.....	200 MHz Motorola® 8245 PowerPc®
Fabric Latency (intra-switch)	
1-Gbps to 1-Gbps .....	< 0.6 µsec
2-Gbps to 2-Gbps .....	< 0.4 µsec
4-Gbps to 4-Gbps .....	< 0.3 µsec (5600 series only)
10-Gbps to 10-Gbps .....	< 0.2 µsec

Bandwidth	
Point-to-Point .....	212 MB, Full Duplex @ 1-Gbps 224 MB, Full Duplex @ 2-Gbps 850 MB, Full Duplex @ 4-Gbps <sup>1</sup>
Aggregate (single switch) .....	2550 MB, Full Duplex @ 10-Gbps
	Up to 23.80 GB Full Duplex

Bandwidth	
Point-to-Point .....	212 MB, Full Duplex @ 1-Gbps 224 MB, Full Duplex @ 2-Gbps 850 MB, Full Duplex @ 4-Gbps <sup>1</sup> 2550 MB, Full Duplex @ 10-Gbps
Aggregate (single switch) .....	Up to 23.80 GB Full Duplex

<sup>1</sup> 5600 series only

## A.2 Maintainability

Diagnostics .....	Power-On Self Test (POST) tests all functional components except SFP transceivers. Port tests include online, internal, and external tests.
User Interface .....	LED indicators
Field Replaceable Units	Power supplies (model 5202/5602 only)

### A.3 Fabric Management

Management Methods .....	Enterprise Fabric Suite 2007 graphical user interface QuickTools web applet Command Line Interface Application Programming Interface SMI-S GS-3 Management Server SNMP FTP TFTP
Maintenance Connection .....	RS-232 connector; null modem F/F DB9 cable
Ethernet Connection .....	RJ-45 connector; 10/100 BASE-T cable
Switch Agent.....	Allows a network management station to obtain configuration values, traffic information, and failure data pertaining to the Fibre Channels using SNMP through the Ethernet interface.

### A.4 Dimensions

	<b>Model 5200/5600</b>	<b>Model 5202/5602</b>
Width.....	17" (432 mm), 19" rack	17" (432 mm), 19" rack
Height .....	1.70" (43.2 mm) (1U)	1.70" (43.2 mm) (1U)
Depth .....	12.0" (305 mm)	19.69" (500 mm)
Weight.....	9 lbs (4.08 Kg)	16 lbs (7.25 Kg)

### A.5 Electrical

Operating voltage .....	100 to 240 VAC; 50 to 60 Hz
Power source loading (maximum) ..	1 A at 120 VAC 0.5 A at 240 VAC
Heat Output (maximum) .....	100 watts
Circuit Protection .....	Internally fused

### A.6 Environmental

Temperature	
■ Operating .....	5 to 40°C (41 to 104°F)
■ Non-operating .....	-40 to 70°C (-40 to 158°F)
Humidity	
■ Operating .....	5% to 90%, non-condensing
■ Non-operating .....	5% to 93%, non-condensing
Altitude	
■ Operating .....	0 to 3048m (0 to 10,000 feet)
■ Non-operating .....	0 to 15,240m (0 to 50,000 feet)
Vibration	
■ Operating .....	IEC 68-2
■ Non-operating .....	5-500 Hz, random, 0.21 G rms, 10 minutes
■ Non-operating .....	5-500 Hz, random, 2.09 G rms, 10 minutes
Shock	
■ Operating .....	IEC 68-2
■ Non-operating .....	4 g, 11ms, 20 repetitions
■ Non-operating .....	30g, 292 ips, 3 repetitions, 3 axis
Air flow .....	Front-to-back

## A.7 Regulatory Certifications

Safety Standards .....	UL60950:2000 CSA 22.2 No. 60950-00 (Canada) EN60950 (EC) CB Scheme-IEC 60950
Emissions Standards .....	FCC Part 15B Class A ICES-03 Issue 3 VCCI Class A ITE CISPR 22, Class A EN 55022, Class A
Voltage Fluctuations .....	EN 61000-3-3
Harmonics.....	EN 61000-3-2
Immunity .....	EN 55024
Marking .....	FCC Part 15 UL <sub>US</sub> (United States) TUV <sub>US</sub> (United States) cUL (Canada) cTUV (Canada) TUV Europe (Germany) VCCI CE

# Glossary

## **Access Control List Zone**

Access Control List zoning divides the fabric for purposes of controlling discovery and inbound traffic.

## **Active Zone Set**

The zone set that defines the current zoning for the fabric.

## **Active Firmware**

The firmware image on the switch that is in use.

## **Activity LED**

A port LED that indicates when frames are entering or leaving the port.

## **Administrative State**

State that determines the operating state of the port, I/O blade, or switch. The configured administrative state is stored in the switch configuration. The configured administrative state can be temporarily overridden using the command line interface.

## **Alarm**

A message generated by the switch that specifically requests attention. Alarms are generated by several switch processes. Some alarms can be configured.

## **Alias**

A named set of ports or devices. An alias is not a zone, and can not have a zone or another alias as a member.

## **AL\_PA**

Arbitrated Loop Physical Address

## **Arbitrated Loop**

A Fibre Channel topology where ports use arbitration to establish a point-to-point circuit.

## **Arbitrated Loop Physical Address (AL\_PA)**

A unique one-byte value assigned during loop initialization to each NL\_Port on a loop.

## **ASIC**

Application Specific Integrated Circuit. A chip designed for a specific applications, such as a transmission protocol or a computer.

## **Auto Save**

Zoning parameter that determines whether changes to the active zone set that a switch receives from other switches in the fabric will be saved to permanent memory on that switch.

## **BootP**

Boot Strap Protocol. A type of network server.

## **Buffer Credit**

A measure of port buffer capacity equal to one frame.

## **Cascade Topology**

A fabric in which the switches are connected in series. If you connect the last switch back to the first switch, you create a cascade-with-a-loop topology.

---

### **Class 2 Service**

A service which multiplexes frames at frame boundaries to or from one or more N\_Ports with acknowledgment provided.

### **Chassis Hop**

A measure of fabric latency represented by the ISL that any frame crosses when travelling from one switch to another. A frame that travels from one switch to another over an ISL experiences one chassis hop.

### **Class 3 Service**

A service which multiplexes frames at frame boundaries to or from one or more N\_Ports without acknowledgment.

### **Configured Zone Sets**

The zone sets stored on a switch excluding the active zone set.

### **Default Visibility**

Zoning parameter that determines the level of communication among ports/devices when there is no active zone set.

### **Device Security**

A component of fabric security that provides for the authorization and authentication of devices that attach to a switch through the use of groups and security sets.

### **Domain ID**

User defined number that identifies the switch in the fabric.

### **Event Log**

Log of messages describing events that occur in the fabric.

### **Expansion Port**

E\_Port that connects to another FC-SW-2 compliant switch.

### **Fabric Database**

The set of fabrics that have been opened during a SANsurfer Switch Manager session.

### **Fabric Device Management Interface**

An interface by which device host bus adapters can be managed through the fabric.

### **Fabric Management Switch**

The switch through which the fabric is managed.

### **Fabric Name**

User defined name associated with the file that contains user list data for the fabric.

### **Fabric Port**

An F\_Port or FL\_Port.

### **Fabric Security**

The functions that provide security for fabric users and devices including user account security, and fabric services.

### **Fabric Services**

A component of fabric security that provides for the control of inband management and SNMP on a switch.

### **Fabric View File**

A file containing a set of fabrics that were opened and saved during a previous SANsurfer Switch Manager session.

### **FDMI**

See Fabric Device Management Interface.



**Flash Memory**

Memory on the switch that contains the chassis control firmware.

**Frame**

Data unit consisting of a start-of-frame (SOF) delimiter, header, data payload, CRC, and an end-of-frame (EOF) delimiter.

**FRU**

Field Replaceable Unit

**Group**

A list of device worldwide names that are authorized to attach to a switch. There are three group types: one for other switches (ISL), another for devices (port), and a third for devices issuing management server commands (MS).

**Heartbeat LED**

A chassis LED that indicates the status of the internal switch processor and the results of the Power-On Self-Test.

**Inactive Firmware**

The firmware image on the switch that is not in use.

**Inband Management**

The ability to manage a switch through another switch over an inter-switch link.

**Initiator**

The device that initiates a data exchange with a target device.

**In-Order-Delivery**

A feature that requires that frames be received in the same order in which they were sent.

**Input Power LED**

A chassis LED that indicates that the switch logic circuitry is receiving proper DC voltages.

**Inter-Switch Link**

The connection between two switches using E\_Ports.

**IP**

Internet Protocol

**LIP**

Loop Initialization Primitive sequence

**Logged-In LED**

A port LED that indicates device login or loop initialization status.

**Maintenance Button**

Formerly known as the Force PROM button. Momentary button on the switch used to reset the switch or place the switch in maintenance mode.

**Maintenance Mode**

Formerly known as force PROM mode. Maintenance mode sets the IP address to 10.0.0.1 and provides access to the switch for maintenance purposes.

**Management Information Base**

A set of guidelines and definitions for SNMP functions.

**Management Workstation**

PC workstation that manages the fabric through the fabric management switch.

**Mesh Topology**

A fabric in which each chassis has at least one port directly connected to each other chassis in the fabric.

---

**MIB**

Management Information Base

**Multistage Topology**

A fabric in which two or more edge switches connect to one or more core switches.

**Network Time Protocol**

A network protocol that enables a client to synchronize its time with a server.

**NL\_Port**

Node Loop Port. A Fibre Channel device port that supports arbitrated loop protocol.

**N\_Port**

Node Port. A Fibre Channel device port in a point-to-point or fabric connection.

**NTP**

Network Time Protocol

**Pending Firmware**

The firmware image that will be activated upon the next switch reset.

**POST**

Power-On Self Test

**Power-On Self Test**

Diagnostics that the switch chassis performs at start up.

**Principal Switch**

The switch in the fabric that manages domain ID assignments.

**SANsurfer Switch Manager**

Switch management application.

**Simple Network Management Protocol**

An application protocol that manages and monitors network communications and functions. It also controls the Management Information Base (MIB).

**Security Set**

A set of up to three groups with no more than one of each group type: ISL, Port, or MS. The active security set defines the device security for a switch.

**SFP**

Small Form-Factor Pluggable.

**Small Form-Factor Pluggable**

A transceiver device, smaller than a GigaBit Interface Converter, that plugs into the Fibre Channel port.

**SNMP**

Simple Network Management Protocol

**Target**

A storage device that responds to an initiator device.

**User Account**

An object stored on a switch that consists of an account name, password, authority level, and expiration date.

**User Account Security**

A component of fabric security that provides for the administration and authentication of account names, passwords, expiration dates, and authority level.

**VCCI**

Voluntary Control Council for Interference

**Voluntary Control Council for Interference**

A consortium of Japanese electronics industry associations that have established voluntary standards for controlling electromagnetic interference (EMI).

**Worldwide Name (WWN)**

A unique 64-bit address assigned to a device by the device manufacturer.

**WWN**

Worldwide Name

**XPAK**

A specification authored by a consortium of companies to govern the development of small form factor 10 Gigabit modules.

**Zone**

A set of ports or devices grouped together to control the exchange of information.

**Zone Set**

A set of zones grouped together. The active zone set defines the zoning for a fabric.

**Zoning Database**

The set of zone sets, zones, and aliases stored on a switch.

---

## Notes

# Index

## Numerics

10/100 Base-T straight cable 4-10  
10-Gbps port 2-5

## A

account name  
  default 4-14  
  FTP 4-20  
  maintenance mode 5-13  
active zone set 3-2  
Activity LED 2-6, 2-8  
air flow A-5  
altitude A-5  
Application Programming Interface 2-12  
authorization 3-19

## B

bandwidth 3-5, A-3  
boot loader 5-16  
browser 4-2  
buffer credit 3-4, A-2

## C

cable  
  10/100 Base-T 4-10  
  10/100 Base-T crossover 4-10  
  fibre optic 3-1  
  length 3-4  
  null modem F/F DB9 4-10  
  XPAK switch stacking 4-7  
cascade topology 3-12  
certificate 3-17

chassis  
  air flow A-5  
  diagnostics 5-1  
  LEDs 2-3  
  marking A-6  
  shock A-5  
  vibration A-5  
classes of service A-1  
command line interface 2-12  
Common Information Model 3-16  
configuration  
  file system error 2-2, 5-5, 5-6  
  remove 5-15  
  restore default 5-15  
controls 2-2  
credits 3-4, A-2  
critical error 5-3

## D

device  
  access 3-2  
  authentication 3-19  
  authorization 3-19  
  cabling 4-16  
  description 3-1  
  performance 3-7  
  security 3-19  
  security example 3-20  
diagnostics 5-1, 5-3, A-3  
dimensions A-4  
disk space 4-2  
distance 3-4  
domain ID  
  conflict 5-8  
  description 3-8  
  lock 3-8  
donor port 3-4

## E

- E\_Port 2-7, 5-8
- emissions standards A-6
- Enterprise Fabric Suite 2007 2-12
- environmental
  - conditions 4-2
  - specifications A-5
- error
  - critical 5-3
  - fatal POST 5-4
  - port 5-9
- Ethernet
  - direct connection 4-10
  - indirect connection 4-10
  - port 2-8
- extended credit
  - cable length 3-4
  - example 3-4

## F

- F\_Port 2-7
- fabric
  - management 3-29, A-4
  - management switch 2-8
  - management workstation 4-2
  - point-to-point bandwidth A-3
  - port 2-7
  - security 3-16
- factory defaults 5-15
- fiber optic cable 3-1
- Fibre Channel
  - ports 2-5
  - protocols A-1
- Field Replaceable Unit 6-1, A-3
- File Transfer Protocol
  - account name 4-20
  - description 2-13
  - service 3-16

- firmware
  - description 4-16
  - failure 5-4
  - install with CLI 4-18
  - install with QuickTools 4-18
  - non-disruptive activation 4-17
  - unpack image 5-14
- five-switch stacking 3-10
- FL\_Port 2-7
- flash memory 2-2
- four-switch stacking 3-10
- frame size A-2
- FRU - See Field Replaceable Unit
- FTP - See File Transfer Protocol

## G

- G\_Port 2-7
- GBIC - See GigaBit Interface Converter
- generic ports 2-7
- Gigabit Interface Converter 3-1
- GL\_Port 2-7

## H

- harmonics A-6
- HBA - See Host Bus Adapter
- Heartbeat LED 2-4, 5-3
- heat output A-5
- host authentication example 3-27
- host bus adapter 3-1
- humidity 4-2, A-5
- HyperTerminal application 4-9

## I

- immunity A-6
- inband management 3-15
- Input Power LED 5-2
- installation 4-3
- internal firmware failure 5-4
- internet browser 4-2

**L**

latency 3-5, A-2  
LED  
  Activity 2-6, 2-8  
  Heartbeat 2-4, 5-3  
  Input Power 2-4, 5-2  
  Link Status 2-8  
  Logged-In 2-6, 5-7  
  power supply 2-10  
  System Fault 2-4, 5-2  
license key 2-5, 4-21  
Link Status LED 2-8  
log file 5-15  
Logged-In LED 2-6, 5-7  
login limit 3-29

**M**

maintainability A-3  
maintenance  
  interface A-4  
  menu 5-14  
  mode 2-2, 2-3, 5-3, 5-13  
Maintenance button 2-2, 2-3, 5-13  
Management Server 3-16  
management workstation 2-8, 4-10  
marking A-6  
media type A-2  
memory  
  flash 2-2  
  workstation 4-2  
mesh topology 3-13  
minicom 4-9  
multiple chassis fabrics 3-7

**N**

new features 1-3  
non-critical error 5-3  
non-disruptive activation 4-17  
NTP - See Network Time Protocol  
null modem F/F DB9 cable 4-10

**O**

operating systems 4-2  
over temperature 5-6

**P**

password  
  file reset 5-15  
  maintenance mode 5-13  
  restore default 5-15  
performance  
  device 3-7  
  switch 3-3  
planning 3-1  
port  
  10-Gbps 2-5  
  binding 3-18  
  buffer credits 3-4  
  characteristics A-1  
  diagnostics 5-7  
  Ethernet 2-8  
  fabric 2-7  
  Fibre Channel 2-5  
  generic 2-7  
  LEDs 2-6  
  maximum number of ports/users A-2  
  number of A-2  
  security 3-18  
  serial 2-9  
  speed A-2  
  types 2-7, A-1  
POST - See Power On Self Test  
power  
  consumption A-5  
  requirements 4-2  
  source loading A-5  
  supply 6-2  
  supply diagnostics 5-12  
Power Supply Fault LED 2-10, 5-12  
Power Supply Status LED 2-10, 5-12

Power-on Self Test  
  description 5-3  
  fatal error 5-4  
principal  
  priority 3-8  
  switch 3-8  
processor 4-2, A-2

## Q

QuickTools  
  service 3-15  
  web applet 2-11

## R

rack mount 4-4, 4-5, 4-6  
RADIUS - See Remote Dial-In User Service.  
recovering a switch 5-13  
regulatory certifications A-6  
remake filesystem 5-16  
Remote Dial-In User Service  
  server authentication 3-18, 3-19  
  server example 3-23  
removal/replacement 6-1  
RS-232 port 2-9  
rubber feet 4-3

## S

safety standards A-6  
scalability A-2  
Secure Shell  
  description 3-17  
  service 3-15  
Secure Socket Layer service 3-15

security  
  certificate 3-17  
  connection 3-17  
  database limits 3-19  
  device 3-19  
  fabric 3-16  
  user account 3-17  
serial port 2-9, 4-9, 4-10  
SFP - See Small Form-Factor Pluggable  
shock A-5  
Simple Network Management Protocol  
  description 2-13  
  service 3-15  
site requirements 4-1  
six-switch stacking 3-11  
small form-factor pluggable 2-7, 4-6, 6-1  
SMI-S - See Storage Management  
  Initiative-Specification  
SNMP See - Simple Network Management  
  Protocol  
soft zone 3-2  
SSH - See Secure Shell  
SSL - See Secure Socket Layer  
stacking 3-7, 3-9  
Storage Management Initiative-Specification  
  2-13  
switch  
  add to fabric 4-21  
  configuration 4-14  
  management 2-11  
  management service 3-15  
  power up 4-13  
  recovery 5-13  
  reset 2-2, 5-16  
  services 3-15  
  specifications A-1  
  upgrade 2-5  
System Fault LED 2-4, 5-2  
system processor A-2

## T

table mount 4-4



Telnet service 3-15  
temperature  
    error 5-6  
    operating range 4-2, A-5  
three-switch-stacking 3-9  
timeout values 5-9  
topology  
    cascade 3-12  
    mesh 3-13  
transceiver 2-7, 4-6, 6-1  
transmission rate 3-3, 3-5  
two-switch stacking 3-9

## U

upgrade 2-5  
user account security 3-17  
user interface A-3

## V

vibration A-5  
voltage  
    fluctuations A-6  
    operating A-5

## W

web applet  
    description 2-11  
    service 3-15  
workstation  
    configuration 4-8  
    connect 4-10  
    IP address 4-8  
    requirements 4-2  
WWN - See Worldwide Name

## Z

zone  
    conflict 5-9  
    definition 3-2  
zone set  
    active 3-2  
    definition 3-2  
zoning  
    database 3-3  
    hardware enforced 3-2  
    limits 3-3

---

## Notes