


(760) 438-7000 • FAX (760) 438-7043 & Canada (800) 421-1587 & (800) 392-0123 Toll Free FAX (800) 468-1340

3. COMPONENT LOCATIONS



1. PRODUCT DESCRIPTION

The Model AL-1 is a wireless personal alert receiver designed for use with existing nurse call annunciation systems. In a typical installation, the receiver is used in the place of, or in conjunction with, a standard pull cord to activate a corridor light, bed light, room light, and any audible devices to indicate the need for assistance. Up to 32 wireless transmitters can be programmed to activate each receiver.


Three indicators on the front of the receiver display the system status. The green POWER indicator lights when power for the receiver is present. The yellow SERVICE indicator lights if a transmitter has sent a low battery signal. The red ALERT indicator lights when a transmitter has been triggered, showing that the receiver's outputs have been activated.

Pressing the RESET button on the top of the receiver for less than two seconds will reset any transmitter low battery indications. Pressing the RESET button for more than three seconds will clear the ALERT indication and reset the relay outputs if in


The receiver contains four normally open 1-amp relay contacts that close when activated. One relay provides an isolated output. The three other relays are isolated when open and have a common return. The receiver relays can operate in "normal" or "failsafe" mode. In normal mode, the relays will energize when the receiver is triggered In failsafe mode, the relays are energized continuously until the receiver is triggered. Failsafe mode supervises the system by causing the outputs to activate if power is removed from the receiver. Both modes provide normally open outputs.

Power for the receiver is supplied by a plug-in transformer. The receiver can be mounted directly to a wall or to a single-gang electrical box with the hardware supplied


2. OPEN THE CASE



4. SET THE MODE



5. INSTALL THE MOUNTING PLATE



6. CONNECT THE OUTPUTS

CONNECT THE OUTPUTS TO E LOCAL CALL ANNUNCIATION

CONNECTIONS WILL VARY DEPENDING ON THE INSTALLATION

WIRE NUTS ARE SUPPLIED FOR MAKING CONNECTIONS

SERVICE RELAY LATCHES WHEN ONE OR MORE STORED TRANSMITTERS INDICATE A LOW


A MOMENTARY OR LATCHED ALERT RELAY OUTPUT IS SELECTED BY THE "LATCH" ON PINS = LATCH OFF PINS - MOMENTARY

> A CAUTION A MAXIMUM CURRENT FOR EACH RELAY CONTACT IS 1 AME

AL-1 OUTPUT WIRE COLORS


SERVICE OUTPUT MAXIMUM LOAD - 28 V @ 1 A

ORANGE 0




7. CONNECT THE TRANSFORMER

CONNECT THE RED AND BLACK



8. TRANSMITTER SETUP



PRESS AND RELEASE THE LEARN BUTTON, STATUS INDICATOR WILL LIGHT (IF NOT, THE MEMORY IS ALREADY FULL)


ACTIVATE A TRANSMITTER, THE STATUS INDICATOR WILL FLASH WHEN THE TRANSMITTER IS ACCEPTED (UP TO 32 TRANSMITTERS ALLOWED)

TO CHECK THE TOTAL NUMBER OF TRANSMITTERS IN MEMORY

PRESS AND HOLD THE LEARN BUTTON FOR ABOUT 5 SECONDS. THE STATUS INDICATOR WILL BLINK ONCE FOR EACH TRANSMITTER IN MEMORY

TO ERASE ALL TRANSMITTERS

CONTINUE TO HOLD THE LEARN BUTTON FOR ABOUT 10 SECONDS AFTER THE TRANSMITTER COUNT.THE STATUS INDICATOR WILL BLINK ONCE WHEN THE RECEIVER MEMORY IS ERASED




ACTIVATING

TRANSMITTER \ /

9. CLOSE AND SECURE THE CASE

TAB FITS ALIGN TOP OF CASE INTO THE SLOT SQUEEZE THE CASE SIDES AND SNAP THE COVER ONTO THE MOUNTING PLATE SECURE THE CASE BY INSERTING THE TWO SHORT SCREWS INTO THE BOTTOM TABS

10. SYSTEM TEST & OPERATION



LINEAR LIMITED WARRANTY

This Linear product is warranted against defects in material and workmanship for twelve (12 months. The Warranty Expiration Date is labeled on the product. This warranty extends only to wholesale customers who buy direct from Linear or through Linear's normal distribution channels Linear does not warrant this product to consumers. Consumers should inquire from their selling dealer as to the nature of the dealer's warranty, if any. There are no obligations or liabilities on the part of Linear Corporation for consequential damages arising out of or in connection with use or performance of this product or other indirect damages with respect to loss of property, revenue, or profit, or cost of removal, installation, or reinstallation. All implied warranties, including implied warranties for merchantability and implied warranties for fitness, are valid only until Warranty Expiration Date as labeled on the product. This Linear Corporation Warranty is in lieu of all other arranties express or implied. All products returned for warranty service require a Return Product Authorization Number (RPA#)

Contact Linear Technical Service at 1-800-421-1587 for an RPA# and other important details IMPORTANT !!!

Linear radio controls provide a reliable communications link and fill an important need in portable wireless signalling. However, there are some limitations which must be observed.

- releass signaling. Involver, there are some limitations which must be observed. For U.S. installations only: The radios are required to comply with FCC Rules and Regulations as Part 15 devices. As such, they have limited transmitter power and therefore limited range. A receiver cannot respond to more than one transmitted signal at a time and may be blocked
- by radio signals that occur on or near their operating frequencies, regardless of code settings. Changes or modifications to the device may void FCC compliance. Infrequently used radio links should be tested regularly to protect against undetected
- A general knowledge of radio and its vagaries should be gained prior to acting as a wholesale tributor or dealer, and these facts should be communicated to the ultimate

Copyright © 2002 Linear Corporation