




# **MAGELLAN** **WORLD PHONE**

User  
Manual

GLOBAL  
SATELLITE  
TELEPHONE



148 x 195 mm



## **RADIATION WARNING**

High levels of radio frequency radiation are considered health hazardous. Although no single value of "safe radiation level" has been agreed upon by all countries, the American National Standards Institute (ANSI/IEEE C95.1-1992) recommends that people should not be exposed to radiation stronger than 1 milliwatt per square centimetre at the frequencies used in the WORLDPHONE terminal. Accordingly, the operator of the terminal should ensure that the area extending 1 metre from the front of the antenna be kept clear of personnel when the terminal is transmitting.

## **OBTAINING LICENSING FOR INMARSAT TERMINALS**

Under rights given under ITU Radio Regulations, local telecommunications administrations establish and enforce national rules and regulations governing types of emissions, power levels, and other parameters that effect the purity of signal, which may be radiated in the various frequency bands of the radio spectrum.

To legally operate an Inmarsat terminal, it is necessary to obtain permission from the local telecommunications regulatory authorities of the country you are operating within. Using your terminal in any country without permission causes you to run the risk of confiscation of the terminal or legal action from local authorities. Normal practice for taking telecommunications into another country is to apply for a license before travel. If a license has not been obtained before travel, the equipment may be put into storage by local authorities until such time as a license is obtained.

All specifications are subject to change without notice.

<b>Chapter 1. Getting Started</b>	
Introduction	1.1
Telephone Unit (TPU)	1.3
WorldPhone Portable	1.6
WorldPhone Provident	1.12
WorldPhone Marine	1.13
WorldPhone Voyager	1.16
<b>Chapter 2. Operation</b>	
Introduction	2.1
Making a call	2.2
Call from telephone	2.8
Special calls	2.9
Receiving a call	2.10
Functions	2.13
Last number redialing	2.15
Phone book	2.16
Key lock	2.18
Selecting default Net service provider	2.19
User access	2.20
Data/printer port setup	2.23
Phone setup	2.26
Setting default contrast and ringing volume	2.27
Setting date and time	2.28
Setting key lock	2.29
Language setup	2.30
Language reset	2.31
Mailbox access numbers	2.32
Call charge setup	2.33
Traffic log	2.34
Precharge	2.37
Precharge on SIM card	2.42
<b>Advanced functions:</b>	
Access control	2.44
Restricted dialing	2.45
Restricted dialing setup	2.46
Access code	2.47
Access code setup	2.48
Restricted SIM usage	2.49
Checking SIM restrictions	2.50
Setting SIM restrictions	2.51
Satellite setup	2.52
Net service provider and terrestrial network	2.52
S/A operator and terrestrial network	2.52
Configuration	2.53
Port configuration	2.53
Net service providers	2.54
Power conservation	2.55
Set diagnostics	2.55
Storing of Preferred/Allowed Net service provider and Stand Alone operator on the SIM Card	2.56
Charge tone	2.58
Information available	2.59
IMN numbers	2.59
Misc. version ID information	2.60
Oscillator compensation	2.60
Network status	2.60
Installation	2.61
Paid functions	2.61
Phone name setup	2.61
<b>Chapter 3. Telefax Service</b>	
Setting up	3.1
Using telefax with the WorldPhone	3.2
<b>Chapter 4. Data Service</b>	
Setting up	4.1
<b>Chapter 5. Appendices / Index</b>	
Appendix A	
Telephone country codes	A-1
Service address codes	A-5
Appendix B	
Installation of Marine Antenna	B-1
Installation of Voyager Antenna	B-9
Installation of Provident Antenna	B-16
Optional antenna cable	B-21
Connecting up optional equipment	B-22
Appendix C (WorldPhone Portable/Provident only)	
Battery charging	C-1
Charger	C-2
Battery replacement	C-3
Appendix D	
AT commands	D-1
DTE interface	D-17
Appendix E	
Secure voice (option)	E-1
Aero functions (option)	E-2
Appendix F	
Character map	F-1
Appendix G	
List of terms	G-1
Appendix H	
System description	H-1
Appendix I	
Troubleshooting	I-1

# 1. Getting Started

# 2. Operation

# 3. Telefax Service

# 4. Data Service

# 5. Appendices



Introduction ..... 1.1  
Telephone Unit (TPU) ..... 1.3  
WorldPhone Portable ..... 1.6  
WorldPhone Provident ..... 1.12  
WorldPhone Marine ..... 1.13  
WorldPhone Voyager ..... 1.16

The design and specifications of the equipment may be changed without notice.




## General

The WorldPhone communication terminal provides access to the international dial-up telephone, facsimile and data networks via the INMARSAT satellite system.


- The terminal **Telephone Unit (TPU)** can be operated with any of the below six WorldPhone antennas:




- **WorldPhone Portable** antenna with RF transceiver built into the lid. The antenna also allows semi- or fixed mounting on a flat surface, or tripod.



- **WorldPhone Marine**, a tracking antenna designed for use on marine crafts, leisure yachts and work boats alike.




- **WorldPhone Voyager**, a tracking antenna designed for use on vehicles, trains or riverboats.




## Introduction cont'd


- **WorldPhone Provident**, a fixed mounted antenna designed to provide telecommunication services for remote villages, farms, businesses, construction sites etc.



- **WorldPhone Expander**, which allows simultaneous operation of up to six WorldPhone Telephone Units through a one meter parabolic dish antenna.  
*See separate information.*



- **WorldPhone Aero**, intended for use on the small to medium size aircraft.  
*See separate information.*



**Note!**

*It is advisable to turn off the equipment prior to switching antenna.*






Figure 1.1 WorldPhone Telephone Unit (TPU).

## Telephone Unit (TPU) cont'd

### **SIM card**

The SIM card (Subscriber Identity Module) carries subscription information from your Inmarsat Service Provider (ISP) or Net service provider on an integrated circuit. The WorldPhone used with the SIM card assumes the identity of the SIM card.

The SIM card has its own set of numbers on which the user can be contacted irrespective of the WorldPhone used. All outgoing calls will be billed to the owner of the SIM card.

The SIM card is protected by means of a lock code. When buying a SIM card you will receive a Personal Identification Number (PIN) that will contain up to 8 digits. Contact your dealer if you do not have your PIN code.

If the PIN code entered does not match the PIN code on the SIM card, operation with that particular SIM card will lock-up after three failed attempts. You must then use the SIM un-block code (PUK code) provided by your ISP to un-lock the card. Contact your dealer if you do not have the PUK code.

*Note! When using the PUK, the SIM PIN is set to 1 2 3 4.*

To change or disable the PIN code, see "**User access**" in chapter 2. *Operation.*

The SIM card can store miscellaneous information, f.ex.:

- PIN code (Personal Identification Number)
- Last number list (previously called numbers)
- Phone book
- Allowed and preferred Net service providers

*Note! When using SIM card, the accessibility of the functions described in this manual will depend on the card supplier.*

### **PIN code**

The user is prompted for the 4-8 digit Personal Identification Number each time the WorldPhone is switched on:

- SIM PIN? (with SIM card).
- Phone PIN? (without SIM card).

*Be aware that the PIN protection may have been disabled, see "**User access**" in chapter 2. *Operation.**

### **Mail service**

The Internet Messages Service (**NIMS**) allows a message of maximum 1024 characters to be sent to the WorldPhone from a website, or from the WorldPhone to an e-mail address or another WorldPhone. NIMS messages are addressed to a response NIMS IMN number. See also **appendix G**.

## Telephone

A DTMF telephone, cordless base station or PABX may be connected to the WorldPhone. This additional telephone is assigned a separate incoming call number.

## Telex service

The **Telex** facility supports Group 3 fax transmission at a rate of 2.4 Kbps. The telex is assigned a separate incoming call number.

## Data service

The built in **Data Transmission Service** is capable of transferring data at 2.4 Kbps. It allows the WorldPhone to interface with a PC without the aid of a modem or data card.

The Asynchronous Data (ASD) system provides data transfer between two WorldPhones, or between a WorldPhone and the fixed international network.

The data facility is assigned a separate incoming call number.




Figure 1.2 Telephone Unit connector panel

## WorldPhone Portable

### General

The WorldPhone Portable terminal consists of two main units housed in a lightweight and portable carrying case:

- The antenna and RF transceiver integrated into the lid.
- The Telephone Unit (and battery pack) that is detachable and rain resistant.

The WorldPhone uses a coax cable to link the two units together. The case is equipped with a handle for transport. The screw socket in the lid allows the antenna to be tripod mounted, or attached to a window using a suction fitting. The total weight of the WorldPhone is 2.7 kgs (including battery pack).

The **Telephone Unit** can easily be shifted for operation with any of the other WorldPhone antennas, see "[Introduction](#)" in this chapter.




Figure 1.3 WorldPhone Portable, complete.

**Internal battery**

The battery indicator on the display indicates the internal charge level:  
The amount of shading represents the current charge level.



A completely shaded indicator indicates a fully charged battery.  
As the battery charge level decreases the amount of shading on the battery indicator will also decrease.

A flashing battery indicator indicates that the battery level is low.



Figure 1.4 WorldPhone Portable, identification.

## WorldPhone Portable cont'd

The WorldPhone turns off automatically once the battery has discharged, to avoid damaging the cells. It must now be powered from an external source for operation and recharging of the battery. The WorldPhone may be connected to an AC source using the Universal AC Adapter, or directly to a 12-32 V rated DC source. The battery is charged even if the WorldPhone is turned off. The indicator shading increases as the battery re-charges.

*For charging and replacement of the battery, see [appendix C](#).*

*Warning! Problems with the transmission may occur when the battery charge level is low.*

*Avoid exposing the WorldPhone to extreme heat or cold. Very high or low temperatures reduce the battery capacity.*






Figure 1.5 WorldPhone Portable connected up.

**Setting up**

**1** Open the WorldPhone.




**2** If needed, release the telephone and lift it out. Check that the antenna coax cable is properly connected. *Swing out the handle in the lid for antenna support. The coax cable permits the antenna to be placed up to 3 metres away from the Telephone Unit.*



**3** Insert the SIM card (if SIM operated).

**4** Press and hold the ON/OFF key for 2 seconds.




The display should light up.

**5** Check for sufficient battery capacity. If low, connect the WorldPhone for recharging from external source, see **appendix C**.

**6a** Enter the SIM PIN code, and press **Ok**:



If necessary, adjust display brightness:



*When selecting another display language, **Eng** appears for easy restoring of English, see "Phone setup: Language setup and Language reset" in chapter 2. Operation.*

**6b** If no SIM card is inserted, the "Phone PIN" will be prompted for. *Default Phone PIN: 1 2 3 4 5 6*





**10** A shaded signal strength bar will appear in the display. The longer the signal bar or higher the signal strength indicator value, the better the signal quality. The bar becomes solid when the signal strength value reaches 400. The maximum marker indicates the highest signal strength achieved during the current search.

Maximum marker

Low → high signal strength

Signal strength indication

Pressing **Mute** turns **OFF** the search tone. (Mute ↔ Tone).

"Volume" indicator appears when the **Tone** is **ON**. Adjust level with arrow keys.

**11** Pressing the **Seek** function key starts the search again.

**New** allows selection of a specific satellite:

Scroll down to desired satellite and select:

Pressing **Selct** enters chosen satellite

*Note!* Searching for a **New** satellite should be done under special circumstances only. Searching for **any satellite** is the normal mode of operation (default).

**12** Pressing **Ok** initializes the system.

**13** The equipment is ready for use when the **Main window** appears:

Battery indicator  
Replaced by **DC** symbol when adapter power only

## WorldPhone Provident

### General

WorldPhone Provident comprises:

- **Outdoor Equipment – ODE**  
including fixed mounted antenna and RF transceiver.
- **Indoor Equipment – IDE**  
including Telephone Unit and Power Supply.

A single coax cable links the ODE and IDE.

*For installation, see appendix B.*

*For operation of the Telephone Unit, see "WorldPhone Portable: Setting up" step 1 through 6.*




Figure 1.6 WorldPhone Provident terminal.

## General

WorldPhone Marine comprises:

- **Above Deck Equipment – ADE**  
including stabilized antenna and RF transceiver.
- **Below Deck Equipment – BDE**  
including Telephone Unit and Power Supply.

A single coax cable links the ADE and BDE.

For installation, see [appendix B](#).




Figure 1.7 WorldPhone Marine terminal.

## WorldPhone Marine cont'd

### Setting up

**1** Insert the SIM card (if SIM operated):


**2** Switch ON the power supply:



**3** Press and hold the telephone ON/OFF key for 2 seconds:



The display should light up.



**4a** Enter the SIM PIN code, and press **Ok**:

Adjust display brightness:




When selecting another display language, **Eng** appears for easy restoring of English see "[Phone setup: Language setup and Language reset](#)" in chapter 2. Operation.

**4b** If no SIM card is inserted, the "Phone PIN" will be prompted for.

**5** A shaded signal strength bar will appear in the display.

The longer the signal bar or higher the signal strength indicator value, the better the signal quality. The bar becomes solid when the signal strength value reaches 400.

The maximum marker indicates the highest signal strength achieved during the current search.




**6** Pressing **Ok** initializes the system with the displayed satellite.

**7** Pressing the **Seek** function key starts the search again.

**New** allows selection of a specific satellite:

Scroll down to  
desired satellite  
and select:




*Note! Searching  
for a **New** satellite  
should be done under  
special circumstances only.*

Pressing **Selct**  
enters chosen satellite



*Searching for **any satellite** is the normal mode of operation (default).*

**8** The equipment is  
ready for use when the  
**Main window** appears:



## WorldPhone Voyager

### General

The WorldPhone Voyager comprises:

- **Outdoor Equipment – ODE**  
including Antenna Unit and magnetic mounting bracket.
- **Indoor Equipment – IDE**  
including Telephone Unit and Power Supply.

A single coax cable links the ODE and IDE.

For installation, [see appendix B](#).

### Setting up

Apply the setting up and satellite search procedure described for WorldPhone Marine. *See previous pages.*




Figure 1.8 WorldPhone Voyager terminal.

Introduction .....	2.1
Making a call .....	2.2
Call from telephone .....	2.8
Special calls .....	2.9
Receiving a call .....	2.10
Functions .....	2.13
Last number redialing .....	2.15
Phone book .....	2.16
Key lock .....	2.18
Selecting default Net service provider .....	2.19
User access .....	2.20
Data/printer port setup .....	2.23
Phone setup .....	2.26
<i>Setting default contrast and ringing volume</i> .....	2.27
<i>Setting date and time</i> .....	2.28
<i>Setting key lock</i> .....	2.29
<i>Language setup</i> .....	2.30
<i>Language reset</i> .....	2.31
<i>Mailbox access numbers</i> .....	2.32
<i>Call charge setup</i> .....	2.33
Traffic log .....	2.34
Precharge .....	2.37
<i>Precharge on SIM card</i> .....	2.42
<b>Advanced functions:</b>	
Access control .....	2.44
<i>Restricted dialing</i> .....	2.45
<i>Restricted dialing setup</i> .....	2.46
<i>Access code</i> .....	2.47
<i>Access code setup</i> .....	2.48
<i>Restricted SIM usage</i> .....	2.49
<i>Checking SIM restrictions</i> .....	2.50
<i>Setting SIM restrictions</i> .....	2.51
Satellite setup .....	2.52
<i>Net service provider and terrestrial network</i> .....	2.52
<i>S/A operator and terrestrial network</i> .....	2.52
Configuration .....	2.53
<i>Port configuration</i> .....	2.53
<i>Net service providers</i> .....	2.54
<i>Power conservation</i> .....	2.55
<i>Set diagnostics</i> .....	2.55
<i>Storing of Preferred/Allowed Net service provider and Stand Alone operator on the SIM Card</i> .....	2.56
<i>Charge tone</i> .....	2.58
Information available .....	2.59
<i>IMN numbers</i> .....	2.59
<i>Misc. version ID information</i> .....	2.59
Installation .....	2.60
<i>Paid functions</i> .....	2.60
<i>Phone name setup</i> .....	2.60

The design and specifications of the equipment may be changed without notice.





**General**


The display and all controls on the WorldPhone are accessible via the front telephone panel. See figure 1.1.

The light in the display and the screen picture may be timed for automatic switching off for power saving. Pressing any key turns the display on again.


The display contrast can be altered using the arrow keys when the PIN window or main window appears. See "[Phone setup](#)" for further details.

**Function keys**


The text in the display shows the function currently assigned to each function key:




**Help**

Whenever needed, press the  key for assistance.

*Example with window above displayed:*



Press **Keys** to go direct to the explanation  of the various tasks performed by the four function keys.

**PIN code**


The user is prompted for the 4-8 digit Personal Identification Number each time the WorldPhone is switched on:

- SIM PIN? (with SIM card).
- Phone PIN? (without SIM card).

*Be aware that the PIN protection may have been disabled, see "[User access](#)" in this chapter.*

**Keying letters**

The three letters on each number key are accessible when on display lines requiring letters. Press the desired key for the first letter, and continue rapid selection of following letters/numbers:




# Making a call

## Procedure

**1** Dial 00 and the country code, followed by the subscriber number (max. 22 digits).

For explanation of call numbers and list of country codes, see [appendix A](#).



See also  
**"Call via alternative  
Net service provider  
or terrestrial network"**.

**2** Pressing the **Del** function key deletes the digit to the left of cursor:

**3** Pressing the **Call** function key sends the dialed number:  
(or press the **#** -key)

**4** If the subscriber is listed in the phone book, enter the short number in the **Number** field and press **Short** to make the call:

The **Short** function key is only visible when less than 3 digits have been entered (max short number).


**5** Lift handset and wait for answer.  
**Handsfree** mode with handset in place.

**6** Pressing the **Esc** key restores number field (if edited), or reverts to main window.

**7** Use up/down arrow keys to adjust **Volume** during the call.




The **call duration** is displayed when connected.




For **handsfree mode**, and use of **loudspeaker** etc, see "**Modes of operation**".

**8** Pressing **Menu** displays IMN numbers:



**Book** then opens phone book, allowing selection of subscriber:



**Edit** allows editing subscriber data.

**New** allows entering new data:

See **Phonebook**

**9** To disconnect the call, put down the handset. In **Handsfree mode**, press **Clear**.

## To call the WorldPhone

Dial the international prefix (normally 00) followed by **87X** IMN number, f.ex. 00 **871** 762420510.

Depends on which satellite the WorldPhone is currently using:

- 1 – AOR-E** (Atlantic Ocean Region East)
- 2 – POR** (Pacific Ocean Region)
- 3 – IOR** (Indian Ocean Region)
- 4 – AOR-W** (Atlantic Ocean Region West)

Note! Some Net service providers support the common Ocean Region access no. **870**, which connects the call to the dialed WorldPhone regardless of the Ocean Region the user currently communicates through.

Making a call cont'd

# Making a call cont'd


## Modes of operation

### Call with handset lifted

When in handset mode, placing handset down terminates the call.




The WorldPhone switches to **handsfree** mode if the handset is put down with the loudspeaker **on** (loudspeaker mode).



### Handsfree call mode

Handset in place



## Call via an alternative Net service provider or terrestrial network

Although default settings normally can be used, a different Net service provider, or an other terrestrial network, may be selected as follows:


### Alternative Net service provider:

*Note! The WorldPhone must have been commissioned by the selected provider; the call may otherwise be rejected.*

**1** Dial subscriber number.




**2** Scroll down to **Net provider** and key in reference number, or press **right arrow** to display list of accessible Net service providers:



**4** and press **Select**:

### Alternative terrestrial network:

**1** Scroll down to **terrestrial network** and key in reference number.



Continue with "**Making a call**", step 3

*NB! A Net service provider may also be specified by starting the telephone number with its reference code, e.g. BT:*



Making a call cont'd



**Note!**  
Sending and receiving NIMS messages is only possible through service providers that support the NIMS service.

## Sending NIMS message

20 Sep 1998 15:20  
Telenor in AOR-E  
Dial 00 + country code + subscriber no  
470 [SIM] [Book] [Last] [Menu] [Seek]

Press **Menu** and then **Mail** to open Mail manager.

Function menu  
001▶Set default Net provider  
Set access level  
Data/printer port setup  
Phone setup menu  
Traffic log  
470 [SIM] [Lock] [Mail] [Selct] [Quit]

Mail manager  
In Box : 6 mail 3 unread  
Out Box : 2 mail 1 unsent  
You have new mail  
470 [SIM] [In] [Out] [Setup] [Quit]

Out Box  
001▶\* Have a nice day  
002 Happy Birthday  
470 [SIM] [Remov] [Edit] [New] [Print]

**Remov** erases selected message.  
**Print** outputs message to printer. Appears only if a printer is enabled, see "Data/printer port setup".

Setup for sending mail  
User name : Kari Nordmann  
NIMS center : 004767244445  
470 [SIM] [Edit] [Ok]

Pressing **Edit** changes the function keys to allow modifications: **Ok** reverts to mail manager

**ABC/abc** selects lower/uppercase letters.  
**Save** stores changes.

### Example:

You have received 6 messages, 3 are not read

One message is not sent

Pressing **In** opens In Box, see **Receiving a call: Receiving NIMS message**.


Indicates that the message is not yet **Sent**

message details

See next page

## Sending NIMS message cont'd

*Note!*  
The @ character appears after z on the [0yz]-key.



*Note!*  
The IMN number of the NIMS service must have been entered into the WorldPhone to allow communication, see [Advanced functions: Information available.](#)

Making a call cont'd

## Call from telephone

### General

A telephone is used for basic telephone calls. Control of functions and other facilities must be done from the WorldPhone.

### Call through default Net service provider

0 0 4 7 6 7 2 4 4 7 0 0 # routes the call via the default Net service provider for the satellite (Ocean Region) you are using.

### Call through selected Net service provider

4 \* 0 0 4 7 6 7 2 4 4 7 0 0 # routes the call via the Net service provider Telenor (4) in Norway.

### Last number redialing

0 # retransmits the last number.

### Last number redialing through selected Net service provider

4 \* 0 # retransmits the last number via the selected Net service provider (Telenor=4).

### Short number dialing (prefix 23)

2 3 1 0 5 # fetches and sends the telephone number stored on the SIM card under short number 105.

### Short number dialing (prefix 23) through selected Net service provider

4 \* 2 3 1 0 5 # fetches and sends the telephone number stored under short number 105 via the selected Net service provider (Telenor=4).




**Call through selected Net service provider and terrestrial network**

Dialing via a terrestrial network is only possible using a selected Net service provider.

The number may be in the range 0 to 127.

*Example of a call through selected Net, e.g. Telenor, and terrestrial network 1:*

**Service calls**

Special information services are accessible with 2-digit service address code. See [appendix A](#).

*Example of obtaining assistance from the International Operator:*

Dial: 1 1 #

# Receiving a call

## Telephone call

Incoming call.  
Status : Ringing

---

470 █ SIM Answr MuteR

Pressing **Answr** connects call (handsfree mode)

Pressing **MuteR** turns off ringing signal

Call duration

Incoming call. 00:04:15  
Status : Connected Handsfree

---

470 █ SIM on Mute Menu Clear

Loudspeaker on / off

Microphone muted/ active (**Mute/Mic**)

Pressing **Clear** terminates call



Lifting handset connects call (handset mode)

## Fax call (and 2-wire telephone call)

20 Sep 1998 15:20

Telenor in AOR-E  
Busy with call

---

470 █ SIM Book Last Menu Seek

See also [chapter 3. Telefax Service](#)

## Data call

Data call in progress – Non-ARQ

Received bytes: 12111  
Transmitted bytes: 1433333

---

470 █ SIM Keep / Hide Clear

When in **Keep** mode, the data call window will remain even if the call is cleared.

Pressing **Hide** or **Esc** removes the window

Default: **Hide** mode.

Pressing **Clear** terminates call

See also [chapter 4. Data Service](#)

## Receiving NIMS message



20 Sep 1998 15:20

Telenor in AOR-E  
Dial 00 + country code + subscriber no

---

470 [SIM] [ ] [ ] [ ] Book Last Menu Seek

Flashing symbol indicates that **NIMS message or mail alert** has been received.

Press **Menu** and then **Mail** to open mail manager.

Function menu

001▶ Set default Net provider ▶  
Set access level  
Data/printer port setup  
Phone setup menu  
Traffic log

---

470 [SIM] [ ] [ ] [ ] Lock Mail Selct Quit

Mail manager

In Box : 6 mail 3 unread  
Out Box : 2 mail 1 unsent  
You have new mail

---

470 [SIM] [ ] [ ] [ ] In Out Setup Quit

Indicates that the message is not yet **Read**

See "Making a call: sending NIMS message".

In Box

001▶ \* Hello ! ▶  
002 Voice mailbox message  
003 Fax mailbox message  
004 \* Mail me !  
▼ 005 \* Information from Service Provider

---

470 [SIM] [ ] [ ] [ ] Print Remove Read Get

**Print** outputs message to printer. Appears only if a printer is enabled, see "Data/printer port setup".  
**Remove** erases message

See next page

In Box message details

Type: NIMS  
From: Knut Knutsen  
Sent: 03 Jan 1998 15:57  
Arrived: 03 Jan 1998 15:58  
▼ Status: Unread

---

470 [SIM] [ ] [ ] [ ] Read Ok

**Ok** reverts to In Box

See next page

# Receiving a call cont'd

## Receiving NIMS message cont'd

Get  
I

Get calls the NIMS server to read out stored NIMS messages.

Get new mail  
 ▶NIMS center : 004767244445

---

470 [SIM] [Del] [Ok]

Modify the server number if required: [I] [I]

Checking for new mail  
 Calling NIMS center at 004767244445  
 Dialing the NIMS center

---

470 [SIM] [Abort]

Read  
I

Readout example: 001 Hello !

Date: 03 Jan 1998 15 : 57  
 From : Knut Knutsen  
 Reply - to : kk@nera.com  
 Subject : Hello !  
 How are you my friend ?  
 ▼Here in Norway the sun is shining and

---

470 [SIM] [Reply] [Remov] [Next] [Ok]

▼

Remov erases message [I] [I] [I] [I]

Next displays next message

Ok reverts to In Box

▶To : kk@nera.com  
 Subject : Re : Hello

---

470 [SIM] [Del] [abc] [CR/LF] [Send]

abc/ABC toggles between lower and uppercase letters

CR/LF provides carriage return or line feed in the text

Send returns mail, see "Making a call: sending NIMS message".

Read  
I

Readout example: 002 Voice mailbox message

Mailbox access  
 Voice mail at Telenor  
 Call to : 57

---

470 [SIM] [Del] [Remov] [Call] [Ok]

Remov erases alert message [I] [I] [I] [I]


Call dials the mailbox to read out the voice message

Ok reverts to In Box

Receiving a call cont'd

## General


The WorldPhone provides the following functions:




See also overview of functions on next page

Ref.	Function	Features
001	<b>Set default Net provider</b>	Allows changing Net service provider and terrestrial network. See " <b>Selecting default Net service provider</b> ".
002	<b>Set access level</b>	Allows shifting between • user level, and • owner / CHV2 level (non-SIM / SIM operation), changing phone / SIM PIN code and owner / CHV2 password. See " <b>User access</b> ".
003	<b>Data/printer port setup</b>	Enables port for connection of printer or PC, and sets transfer bit rate. See " <b>Data/printer port setup</b> ".
004	<b>Phone setup menu</b>	Sets display backlight and contrast, receive volume, system clock, key lock code, language and mailbox access numbers. See " <b>Phone setup</b> ".
006	<b>Traffic log</b>	Logs outgoing calls and provides detailed printout. See " <b>Traffic log</b> ".
008	<b>Precharge</b>	Allows preprogramming of total call duration. See " <b>Precharge</b> ".
009	<b>Advanced functions</b>	See overview on next page.

## Overview of menu functions



Functions cont'd



**General**

The last **10 numbers** called are stored in the WorldPhone memory or on the SIM card. Each number may comprise up to **22 digits**.


If the number is already stored in the phone book, the subscriber's name appears in the list.

Any extra telephone or fax can only redial its own most recent number dialed.


*The last used number list stored on the SIM card replaces that of the phone when inserting the card. (It is restored when removing the SIM).*

**Redialing:**

**1** Press the **Last** function key to open the last number list window:



**2** Scroll up/down to the wanted number:




**3** Call sends the selected number:


**4** Save copies the number to the phone book. Name will be prompted.

**5** Erase deletes all entries in Last used number list.

**6** Apnd permits modifying selected number before making the Call:



Call sends the selected number



**7** Del deletes the digit to the left of cursor:

**8** Call sends the modified number:

Modify using Del and press Call key to send it.

*Note! To call via another net or network, see "Making a call: Call via an alternative Net service provider or terrestrial network".*

General

The following may be stored for abbreviated dialing:


- **99 entries** with names of up to **29 characters** in the WorldPhone.
- Up to **100 entries** (no.100 and up) with names of up to **10 characters** on the SIM card (varies with type).

The list is sorted by name. The SIM card entries and "phone" entries merge when the card is inserted.


Phone book

Abbreviated dialing

**1** Press the **Book** function key to open the phone book:




**2** Scroll up/down or search for first letter(s) of subscriber name:




**3** Call sends the selected number:

Sends selected telephone number → [Call] Short number 100 and up when stored on SIM card

**4** Right arrow displays all data:



**5** Apnd opens the entry window for modification before making a **Call**:



Modify data using **Del** and press **Call** key to send it.



**Editing entry**

**6 New** opens new entry window:



**7 Edit** opens existing entry window.

**8 Del** deletes the digit to left of cursor.

**9 Save** stores phone book entry.

**10 Remov** deletes phone book entry.

New entry in Phone book

▶Name :    ◀  
 Number :  
 Net provider: Default Net  
 Terrestrial network: 00

---

no. (SIM): 102

470    SIM    ◀Del    Save

Edit mode in Phone book

▶Name : Nera\_SatCom\_AS ◀  
 Number : 004767244700  
 Net provider: Default Net  
 Terrestrial network: 00

---

no. : 4

470    SIM    ◀Del Remov    New    Save

Edit mode in Phone book

▶Name : Nera\_SatCom\_AS ◀  
 Number : 004767244700  
 Net provider: Default Net  
 Terrestrial network: 00

---

no. (SIM): 102

470    SIM    ◀Del Remov    New    Save

**Copying entry from f.ex. non-SIM book to SIM book**

**11 Press New** with entry in Edit mode.  
 The entry is assigned the first free short number on the SIM card.



Phone book cont'd

## General

The key lock function prevents unauthorized use when the WorldPhone is on, but still allows reception of incoming calls.

When the lock is set no dial tone is produced, and PC AT commands are unavailable.

Entering a login password (Phone PIN / SIM PIN) will still unlock the phone. *(If Phone PIN / SIM PIN is disabled, turning power off and then on will not unlock the phone.)*

The facility is only accessible when the WorldPhone is restricted for use with a **specific SIM**, or with **no SIM**. See [Advanced functions: Access control](#).

To initiate the key lock and enter or change the unlock code, see [Phone setup: setting key lock](#).

## Locking

**1** Press the **Menu** function key:


and then **Lock**:

*A warning is displayed in the main window:*

## Unlocking

**2** Press **Open** and enter the unlock code:

**3** Pressing **OK** opens the normal main window:



**General**


The default Inmarsat Net service provider (ISP) for a satellite (Ocean Region) is automatically used if the user does not select another one when making a call.

*When using SIM card, selection of an ISP is restricted to one of the allowed Net service providers!*


*When the Restricted Net function is enabled, and with some SIM cards, selection of default Net service provider is not possible. The entry "001 Set default Net provider" will then not appear in the Function menu.*

**Setting default Net service provider**


**1** Press the **Menu** function key:




**2** Select or right arrow opens **Set default Net provider** window:



**3** Key in Net service provider code, or press **right arrow** to display list of available Nets:



**4** Scroll up/down to select Net:



**5** Select enters the chosen Net:

**6** Return to step 3, scroll down and key in Terrestrial network code.

**7** Save stores the selected Net service provider and Terrestrial network as default.

General

The WorldPhone user program is accessible from two levels:

- **USER LEVEL** – accessed by Phone PIN or SIM PIN.

*Note! If the Phone PIN is accidentally lost, it is possible to reset the user's password to default by logging in as owner:*

"Phone PIN: \* + owner's password"  
(Resetting is not possible on SIM card.)


- **CHV2 LEVEL / OWNER LEVEL** – accessed by CHV2 or owner level passwords. With a SIM card inserted, the password allows access to **CHV2 level SIM** functions. Without a SIM card the password allows access to **owner level** phone resident functions.

*Warning!*


To prevent misuse, passwords other than default must be entered before putting the WorldPhone in operation.

**User level / changing PIN code (SIM or Phone PIN):**


**1** Press the **Menu** function key and scroll down to **Set access level:**



**2** Select or right arrow opens the Set access level window:



**3** Edit opens the PIN code window:



**4** Key in:  
• Current PIN code  
• New PIN code  
• Retype to confirm

Press **Ok** following each entry, and to store new PIN code:


*Pressing Ok without entering any numbers for New PIN and Retype new PIN disables SIM PIN/Phone PIN.*

*NB! "Old" PIN code must be entered to reactivate the SIM PIN/Phone PIN.*


To shift to CHV2/OWNER level and change password, continue on following pages . . . . . ➔

**Shifting to CHV2 level / changing password:**


**1** Press the **Menu** function key:




**2** Scroll down to **Set access level**:



**3** Select or right arrow opens the Set access level window:



**4** Key in **2002** to open the window for entering password:




**5** Key in password. Pressing **OK** activates the **CHV2 level**:



**Changing password:**

**6** Open set access level window again:



**7** **Edit** opens password window:



Key in:

- Current password
- New password
- Retype to check



Press **Ok** following each entry:




To revert to **User level**, reselect the **"Set access level"** function and press **User**


User access cont'd

**Shifting to owner level / changing password:**


**1** Press the **Menu** function key:



**2** Scroll down to **Set access level**:




**3** Selct or right arrow opens the Set access level window:



**4** **Owner** opens the window for entering the password:


*Note! The default password is:*  
**1 2 3 4 5 6 7 8 9 0**



**5** Key in password. Pressing **OK** activates the **Owner level**:

**Changing password:**


**6** Open set access level window again:



**7** **Edit** opens password window:

Key in:

- Current password
- New password (10 – 12 digits)
- Retype to check



Press **OK** following each entry:

To revert to **User level**, reselect the **"Set access level"** function and press **User**

## General

The **DATA** port may be set to operate with a PC or, for instance, to output a Traffic log directly to a printer.

*Note! The bit rate setting applies for both PC and printer transfer.*

## Setup for data communication

- Speed as selected on next page, normally 9600 bps.  
*Note! The bit rate set between the PC and the WorldPhone must be higher than the nominal 2400 bps WorldPhone-to-satellite bit rate to ensure maximum speed transfer.*
- No parity \*
- 8 data bits \*
- 1 stop bit \*

*\* These parameters can only be changed using AT commands, see [appendix D](#).*


## Setup for output to printer

*A printer must have serial interface, and is set as follows:*


- Speed as selected on next page, i.e. the bit rate specified for the printer to be connected.
- No parity
- 8 data bits
- 1 stop bit

## Procedure


**1** Press the **Menu** function key:



**2** Scroll down to **Data/printer port setup**:




**3** Select or right arrow selects the **Data/printer port setup** window:



*Bit rate:*

**4** Edit or right arrow opens list of bit rates:

**5** Scroll up/down to required data/printer bit rate:



**6** Select enters the chosen rate:


*Note! It is recommended to use 9600 bps for data communication.*

*Printer:*

*For output to printer, select **bit rate** according to printer specifications.*

**7** Scroll down to printer and

**Enable/Disable** the port for printing:



*AT modem:*

**8** Scroll down and **Enable/Disable** the port for AT modem:


Recommended port setup			
Mode	Output to printer	Data com. (AT)	Data com. (DTR dialing)
Printer:	Enabled	Disabled	Disabled
AT modem:	Disabled	Enabled	Disabled
Hot dial:	Disabled	Disabled	Enabled



**Hot dial:**


When enabled, this function monitors the DTR-pin on the DATA port. When the DTR-pin is pulled high by equipment connected to the DATA port, a data call is automatically initiated to a pre-programmed number. The number is automatically stored under short number 99.

**9** Scroll down to Hot Dial:



**10** Setup opens the Phone book editing window.

Enter name, f.ex. "Hot".  
Fill in required number, and change provider and network, if needed.



**Initial mode:**

The mode is set to AT modem as default.

With a PC running a terminal program connected to the WorldPhone (f.ex. Windows HyperTerminal), the menu is displayed on the screen. When selecting any of the MMI (Man Machine Interface) settings, the PC screen automatically displays the WorldPhone picture.

**11** Scroll down to Initial mode (step 9).

Pressing **Selct** allows choosing MMI interface:



**12** Save stores the chosen settings.




General

This function sets as follows:


- The ON-time of the display illumination and the screen picture. When OFF, pressing any key turns the display back ON.
- Default display contrast, *see following pages*.
- Default level of ringing tone and loudspeaker, *see following pages*.
- Date and time, *see following pages*.
- Key lock, which prevents unauthorized use, *see following pages*.
- Language
- Mailbox access numbers

Procedure

**1** Press the **Menu** function key and scroll down to **Phone setup menu**:




**2** Select or right arrow opens the **Phone setup menu** window:



**3** Press **Select** or **right arrow** again to open the **Backlight control** window:


*Timing of display light and screen picture:*



Pressing **Edit** or **right arrow** opens the list of choices.


*Example when powered by battery pack:*

*(Light 30 / Screen 60 automatically switches OFF display light after 30 secs, and screen picture after 60 secs.)*



*Example applicable when powered by external adapter:*


*(Light and screen permanently ON).*




Pressing **Save** stores the selected settings and returns to phone setup menu.

## Setting default contrast and ringing volume

**1** Press the **Menu** function key:




**2** Scroll down to **Phone setup menu**:




**3** Select or right arrow opens **Phone setup menu** window:

**4** Scroll down to **Contrast control**:



**5** Press **Select** or **right arrow** to open the **Contrast control** window. Adjust with arrow keys. **Save** stores the setting.





**6** Repeat step 4 for **Volume control**:

Press **Edit** or **right arrow** to set **ringing tone** level.

Scroll up/down to required setting and press **Select**:

Repeat procedure for **loudspeaker** volume.

Pressing **Save** stores the selected levels.



**Setting date and time**


The date and time is set to UTC (GMT) at the factory. It is recommended to leave this setting if correct.

*Warning!*


*The system is automatically restarted when accepting new time settings. All calls will be disconnected.*

**Example**


**1** Press the **Menu** function key:



**2** Scroll down to **Phone setup menu**:




**3** Press **Select** or **right arrow** and scroll down to **Set system clock**:




**4** Continue with **Select** or **right arrow** to select function and key in new data:

Move down using **down arrow**.



**5** Press **OK** and confirm with **Yes** if settings are correct.



*Note! The WorldPhone is now restarted.*


Phone setup cont'd

**Setting key lock**


The WorldPhone must be set for use with a **specific SIM**, or with **no SIM**. See *Advanced functions: Access control*.

**Procedure**


**1** Press the **Menu** function key:




**2** Scroll down to **Phone setup menu**:



**3** Press **Selct** or **right arrow** and scroll down to **Key lock**:




**4** Continue with **Selct** or **right arrow** to **Key lock** window.



Enter unlock code: (1 - 6 digits)

and press **OK**:

**5** Repeat code to confirm:



and press **OK** again:


Phone setup cont'd

Language setup


The display language may be changed as described below.

Example


1 Press the **Menu** function key:




2 Scroll down to **Phone setup menu**:




3 Press **Select** or **right arrow** and scroll down to **Language setup**:



4 Continue with **Select** or **right arrow** to select function.



5 Press **Edit** and scroll up/down to wanted language:



Pressing **Select** reads out the selected language in the setup window:


Pressing **Save** changes the display text to the selected language.

To easy restore English, see next page.

Phone setup cont'd

### Language reset

When starting the WorldPhone with the display language set to f.ex. Portuguese, the **Eng** function key provides an easy way to restore the default English display language:




**Mailbox access numbers**

When receiving a mail alert (voice, fax or data), the user must call the server mailbox to retrieve the message. To call the mailbox, normally the default number 57 can be used.


The mailbox dial-up number may be changed as described below.

**Example**


**1** Press the **Menu** function key:




**2** Scroll down to **Phone setup menu**:



**3** Press **Selct** or **right arrow** and scroll down to **Mailbox access numbers**:



**4** Continue with **Selct** or **right arrow** to select function and key in new numbers:



**5** Pressing **OK** stores the new mailbox number(s).

Phone setup cont'd




**Call charge setup**


With the Call charge function enabled the cost of the call will be displayed during the call and for 10 seconds after the call is terminated. Later the charge can be fetched using the Traffic log function. The price per unit and minimum charge time is set as described below.

**Example**


**1** Press the **Menu** function key:



**2** Scroll down to **Phone setup menu**:



**3** Press **Select** or **right arrow** and scroll down to **Call charge setup**:





**4** Continue with **Select** or **right arrow** to select the **Call charge** function.

**Enab** activates the values set below. See **Making a call** previously in this chapter.

**Disab** disables the Call charge indication.

**Ok** activates the call charge indication.

**5** Press **Setup** to modify entries:



**Save** stores the new values:

Phone setup cont'd

General

This function logs all outgoing calls both with and without SIM card inserted. Every call is logged with:

- subscriber number, start time and duration
- service (voice, fax, data, NIMS)
- Net provider and satellite
- user name (if access code is enabled) / SIM card FWD

The WorldPhone *owner* may set the log output mode as follows, (see "**Traffic log settings**"):

- off (stops logging)
- cleared (stops logging and clears the log)
- for automatic printout after 1 or 10 calls (auto print limit).
- for display on the screen
- logging of incoming calls

Traffic log


Traffic log readout

**1** Press the **Menu** function key and scroll down to **Traffic log**:

**2** Right arrow or **select** opens the **Traffic log window**:

**3** **View** displays the list of call data: Scroll up/down to wanted call:

**4** Pressing **right arrow** shows detailed call data:



*Only appears when log mode is set for output to printer. See next page.*

Minutes:seconds

# : entry tagged for printout by owner  
\* : entry not yet printed

*Appears when "Access code" is enabled. (For SIM card call - SIM id: ABCDF) See **Advanced functions: Access control.***

*When call charge is enabled, the "Charge" field appears showing the cost of the viewed call.*

Ref. no. #: record printed previously. "No hash" when printed first time. Subscriber number Start date and time Call duration in minutes and seconds Port Net service provider WorldPhone user (only appears when access code is enabled)

Ref	Dialed number	Call start	Dur.	Port	Net	User
001 #	004767243669	980711 09:20	4:05	H.set	CMC	Aslaug
002	0044222534555	980711 10:56	2:33	H.set	BT	Bob
003 #	004722259024	980711 13:24	11:22	TEL	Telenor	John
004	00494088251	980711 15:46	10:05	TEL	Teleglobe	IDG Franz
005 #	00871765421392	980712 08:45	5:32	H.set	AOR-E	Charlie
006	Incoming call	980712 09:33	6:14	H.set	BT	Bob
007 #	00494088251	980712 10:47	9:11	TEL	Teleglobe	IDG Franz
008 #	0044816865701	980712 13:55	5:20	TEL	BT	George
009	004722259024	980712 16:09	15:44	TEL	Telenor	John
010 #	044222534555	980712 16:53	9:10	H.set	BT	Bob
Total duration is 2:05:28 (125.46 minutes)						
10 records printed						
98.07.12 17:34						

Number of records

Duration in hours, minutes and seconds

Accumulated time in minutes and 1/100 of a minute


Note! When call charge is enabled, the duration field will be replaced by a call charge field showing the cost of each call.

Traffic log cont'd

Example of traffic log printout.

Traffic log settings (owner level only)


**1** Open the Traffic log window:



Print outputs all unprinted and tagged entries. See previous page.


Only appears when log mode is set for output to printer.

**2** Press Edit or right arrow for setting of Log mode. Scroll up/down and press Select at wanted output mode:




No calls are logged when set to Off or Cleared. All existing entries are deleted when set to Cleared.


Auto print limit can easily be toggled between 1 and 10:



Logging of incoming calls can be enabled/disabled:



**3** View displays the list of calls:




Scroll to wanted call and press Tag to tag entry: Press again to untag.

Not printed

Tag for printout

Pressing right arrow shows detailed call data of selected number:



Print outputs the selected entry to the printer without header and footer.

Remove erases the entry from the log.

Quit reverts to main window.

Hours:minutes:seconds  
Appears when "Access code" is enabled. See [Advanced functions: Access control](#).

Traffic log cont'd

**General**

For use with SIM, see "**Precharge on SIM card**".

The WorldPhone can be preprogrammed with a total call duration limit of up to **44640 minutes** (744 hours).


The owner stores a special telephone number under short number **00**. This allows the user to call the owner to buy more time even when having exceeded the time limit.

During a call the remaining time is displayed next to the call duration in hours and minutes (seconds for the last minute).


For users, the Precharge function only appears in the menu when enabled, i.e when bought time is loaded, see following pages.

**Precharge readout**


**1** Press the **Menu** function key:




**2** Scroll down to **Precharge**:



**3** Select or right arrow opens the **Precharge** window which displays the time used and remaining in hours, minutes and seconds:



*Example of call window with call duration and remaining time displayed in hours and minutes:*




**Buying more remaining time**

There are three ways to load precharge time:


- **Call the owner** via short number 00 and get the buy code during the conversation. (*Calling short number 00 can be done even if exceeding the remaining time limit and does not influence the limit value*). See below.
- **Fax or mail** the Forward ID and Index to the owner who generates the buy code and returns this by fax, mail, etc. See next page.
- **The owner** loads the new Precharge limit into the WorldPhone.

**Buying time by calling the owner**


1 Dial 00:




and press **Short**:



2 Pressing the **Menu** function key displays IMN numbers:




3 Pressing **Time** opens the **Precharge** window displaying the Forward ID, Index and user code entry field:



*Read the Forward ID, Index and the new call duration you want to buy to the owner.*

*Then key in the code he reads back to you. The code contains the time information.*

Pressing **Ok** loads the new remaining time limit:




4 Press **Ok** again and then **Esc** to return to the conversation window:


Esc

**Buying time via fax or mail**


**1** Press the **Menu** function key and scroll down to **Precharge**:



**2** Select or right arrow opens the **Precharge** window:



**3** Pressing **Code** opens the Forward ID, Index and user code entry field:



*Fax or mail the Forward ID, Index and the new call duration you want to buy to the owner.*

*Key in the code he faxes or mails back to you.  
The code contains the time information.*


Pressing **Ok** loads the new remaining time limit.

Precharge cont'd


**Owner loads Precharge time**

The WorldPhone must be set in **owner level**.


**1** Press the **Menu** function key and scroll down to **Precharge**:




**2** Selct or right arrow opens the **Precharge** window:



**3** Pressing **Buy** allows keying in a new time limit:



**4** Pressing **Clear** disables the Precharge function:  
The Precharge menu entry is now no longer visible from user level.



Precharge is *enabled* when buying minutes.

**NB!** Remember to revert to **user level**.




**Key readout**


The WorldPhone must be set in **owner level**.

Using the Precharge Administrator program (QPRG 9110039) to generate a buyer's Precharge code requires both the owners password and a "key" generated by the WorldPhone, as follows:


**1** Press the **Menu** function key and scroll down to **Precharge**:



**2** Selct or right arrow opens the **Precharge** window:



**3** A new "key" is generated every time **NewK** is pressed:



*Precharge code handling:*

OWNER	USER
<ul style="list-style-type: none"> <li>• Before a WorldPhone may be rented, the owner must derive its specific key (<b>NewK</b>) and store it in the data base of the Precharge Administrator program, which is used to generate more precharge minutes for the user. <i>See above.</i> At changes, the NewK must be updated in the data base. The owner also needs to register the WorldPhone's owner password with the Precharge Administrator program.</li> <li>• The owner uses the Precharge Administrator program to generate the <b>Precharge code</b> for the user on basis of the above <b>NewK</b>, owner's password and the information received from the user.</li> <li>• The owner reads or sends the new <b>Precharge code</b> to the user.</li> </ul>	<p><i>More call time is needed:</i></p> <p>When wanting to buy more call time, the user conveys the <b>Forward ID</b>, <b>Index</b> and the requested <b>call time</b> to the owner:</p> <ul style="list-style-type: none"> <li>• the user calls the owner via short number 00,</li> <li>• or sends telefax or mail.</li> </ul> <p>The user keys in the new <b>Precharge code</b> provided by the owner.</p>


Precharge cont'd

**Precharge on SIM card**

When using SIM card, any Precharge set on the telephone itself is overridden. If no Precharge is set on the SIM card, the WorldPhone may be used freely.

**Readout on SIM**

The procedure is the same as described previously for the telephone (except for the Code function which now is not required), see "**Precharge readout**":



During a conversation, the time remaining and call duration are displayed as for calls without using SIM card.

Some SIM cards may have a prepaid option. Contact your SIM vendor for more information on how to upgrade your SIM card.

**Overview**

Some of the Advanced functions are accessible from **Phone OWNER LEVEL** or **CHV2 LEVEL** only.

The OWNER LEVEL and CHV2 levels are protected by passwords.

For shifting to owner/CHV2 level and assignment of password, see "[User access](#)".

The Advanced functions include as follows:

- **Access control:**

- Restrict dial

- Access code

- Restrict SIM usage

- **Satellite setup**

- **Configuration:**

- Port configuration

- Net service providers

- Power conservation

- Set diagnostics

- Set preferred Nets *(with SIM card only)*

- Set allowed Nets *(with SIM card only; CHV2 level or higher)*

- Set S/A preferred Nets *(with SIM card only)*

- Set S/A allowed Nets *(with SIM card only; CHV2 level or higher)*

- Charge tone

- **Information available:**

- IMN numbers

- Misc. version Id information

- Oscillator Compensation

- Network status information

*(owner level, or in user level  
when diagnostics is ON, see  
[Configuration: Set diagnostics](#))*

- **Install: Installation and debug menu:**

- Paid functions *(owner level)*

- Phone name setup *(owner level)*

## Introduction

The following functions are available for controlling the use of the WorldPhone:

- **Restrict dial** which allows the owner to establish a Barred list of subscriber numbers that cannot be called, or set the WorldPhone for dialing from Phone Book only. *See next page.*
- **Access code** which opens the WorldPhone for up to 25 authorized users. *See following pages.*
- **Restrict SIM usage** which permits controlling the use of SIM card with the WorldPhone. *See following pages.*

*The functions are editable in owner level only.*


*Procedure:*

**1** Press the **Menu** function key and scroll down to **Advanced functions**:

**2** **Select** or **right arrow** opens the **Advanced functions menu**:

**3** Pressing **Select** or **right arrow** again opens the **Access control menu**:

*allowing selection of the submenus:*



- Restricted dialing**, see next page
- Access code**, see following pages
- Restricted SIM usage**, see following pages.

**Restricted dialing**

The WorldPhone provides three choices of controlling calls:

- No restrictions.
- **Barred list**, which may contain up to 10 phone numbers or part of numbers that **can not** be called. F.ex. the entry "0087" in the barred list prevents all mobile-to-mobile calls.
- **Dial from Book only**, which restricts calls to the numbers in the Phone Book (in the WorldPhone). It is still possible to append, i.e. a short number entry with number field "0047" means that it is possible to dial all Norwegian numbers. When a SIM card is inserted, the SIM entries will **not** be merged with the "phone" entries.

The function is active for non-SIM operation and for one specific SIM card, see "**Restricted SIM usage**". It applies to all ports of the WorldPhone. Only one of the lists can be activated at one time.


*The list to be active is selected by the owner, see next page.*

**Checking the dialing setup:**

**1** Press **Select** or **right arrow** via **Advanced functions** to open the **Access control menu**:

**2** Pressing **Select** or **right arrow** again opens the **Restricted dialing** window which shows the active list:

- *No restrictions*
- *Barred list*
- *Dial from Book only*




*Similar to **Phone book**, see this chapter.*


**Restricted dialing setup (owner level only)**

The "barred list" and the phone book are established as follows:


**1** Press **Select** or **right arrow** via **Advanced functions** to open the **Access control menu**:




**2** Pressing **Select** or **right arrow** again opens the **Restricted dialing** window which shows the active list:




**3** Press **Edit** to select mode of restriction. Scroll up/down to select: **Select** enters chosen mode.



**4** Pressing **List** displays the blocked phone numbers:




**5** Pressing **Edit** allows the selected number to be modified: The field is empty when pressing **New** to add a phone number to the barred list.



**Remove** deletes number. **Save** stores the changes.

**6** When the restriction mode "Dial from Book only" is selected, pressing **Book** allows short numbers to be entered:



*NB! Remember to revert to user level.*

*Similar to Phone book See this chapter.*

Access control cont'd

**Access code**

When the access code function has been enabled, the user is prompted for a 1 - 8 digit personal code when making a call.



The code opens the WorldPhone for one call. Up to 25 authorized users can be allocated access codes.

The function is active for non-SIM use and for one specific SIM card, see **"Restricted SIM usage"**. It applies to all ports of the WorldPhone.


*The access code can only be entered from owner level, see next page.*

**Making a call:**

**1** At hook-off or when attempting to dial a phone number from the main window, the **Access code login** window opens, prompting the user to enter the access code:




**2** Pressing **Phone** opens the window for entering the phone number:




See **Making a call** in this chapter.


Pressing **Fax** or **Data** shows which users are allowed to make a telefax or data call:

**Checking the setup:**

**1** Press **Select** or **right arrow** via **Advanced functions** to open the **Access control menu**:



**2** Pressing **Select** or **right arrow** again opens the window which indicates whether **Access code** is **Enabled** or **Disabled**:



Calling from external phone


- 1 Lift handset; enter access code + "#" on external phone.
- 2 If access code is accepted, a dial tone is heard and the number to be dialed can be entered. Press "#" to initiate the call.

Access control cont'd


Access code setup (owner level only)

Access code is edited or entered as follows:


- 1 Press **Select** or **right arrow** via **Advanced functions** to open the **Access control menu**:



- 2 Pressing **Select** or **right arrow** again opens the **Access code** window: Pressing **Enab/Disab** enables/disables the access code function.




- 3 Pressing **Setup** displays the list of authorized users:



Scroll down to wanted user and press **Edit** to modify the code, or press **New** to add a user to the list:

Use **Del** to modify. Press **ABC** or **abc** to enter uppercase/lowercase letters as required.



**Ok** stores the modified user name.

*NB! Remember to revert to user level.*



**Restricted SIM usage****Allowed SIM**

The WorldPhone can be set to operate from:

- one specific SIM card. Any other SIM users will be rejected.
- no SIM card. All SIM users will be rejected.
- any SIM card.

**Restricted SIM**

The restrictions "Restrict dial" and "Access code" can be set to be active for:

- one specific SIM card (in addition to non-SIM usage)
- no SIM card (only active for non-SIM usage).

*The setting can only be made from owner level, see [Setting SIM restrictions](#). See also [Restricted dialing](#) and [Access code](#).*


**When restricted to SIM provider**

The service provider can lock the WorldPhone to a specific type of card, e.g. a "MOBIQ" SIM card. The restrictions will then be :


- any "MOBIQ" SIM card.
- one specific "MOBIQ" card.
- no SIM card at all.

Checking SIM restrictions



1 Press the **Menu** function key and scroll down to **Advanced functions**:




2 Press **Select** or **right arrow** to open the **Access control menu**:



3 Pressing **Select** or **right arrow** again opens the **SIM restrictions window**:



Alternatives: see below



Appears if card is locked by SIM provider

Alternative restrictions:

When **Allowed SIM** is set to:

- **Any**, no restrictions apply
- **No SIM**, SIM cards are not accepted.
- **Locked to one**, one specific card is allowed.


When **Restricted SIM** is set to:

- **No restrictions**, Access code and Restricted dial only apply for non-SIM operation.
- **Locked to one**, Access code and Restricted dial apply for non-SIM operation and operation with the specified SIM card.


Access control cont'd

**Setting SIM restrictions (owner level only)**


**1** Press **Select** or **right arrow** via **Advanced functions** to open the **Access control menu**:





**2** Pressing **Select** or **right arrow** again opens the **SIM restrictions** window:

**\* Restricted SIM:**


**3** Scroll down to **Restricted SIM**:



**4** Press **Lock** and insert the actual SIM card. The WorldPhone can now be operated with that specific card only:



When retracting the card, the Id of the SIM provider is displayed:



**Ok** stores the settings.

*Appears if card is locked by SIM provider*

**\* Allowed SIM:**


Follow the same procedure as for **Restricted SIM** with the marker remaining at **Allowed SIM**.

**General**


Allows preprogramming of **default Net service provider, S/A operator** (Stand Alone operator) and **terrestrial network** for each satellite region (Ocean Region).

**Net service provider and terrestrial network**


**1** Press the **Menu** function key and scroll down to **Advanced functions:**




**2** Pressing **Selct** or **right arrow** opens the list of Satellites and Default Net providers. Scroll up/down to wanted satellite:




**Selct** initiates search for the specified satellite. (and a new spot beam selection)




**Right arrow** displays satellite info:



**3** **Edit** opens the setting window for the selected satellite:



**4** **Right arrow** opens the list of available Net service providers.



**5** Scroll up/down to wanted Net:  
Pressing **Selct** enters the new default Net service provider:

**6** Return to step 4, scroll down and key in Terrestrial network code. **Save** stores the selected Net service provider and Terrestrial network as the default for that particular satellite.

**S/A operator and terrestrial network**


Repeat steps 4 - 6 for selection of S/A operator and terrestrial network.

**Port configuration**


- Displays current configuration. *Reconfiguration can be made in "owner" level only (non-SIM operation).*
- With **Broadcast On**, incoming calls initiate ringing on all ports configured for voice communication.
- The secure voice function allows selected port(s) to be used with encrypted telephone. See [appendix E – Secure voice option](#).

**Example**


**1** Press the **Menu** function key and scroll down to **Advanced functions**:




**2** Press **Select** or **right arrow** and scroll down to **Configuration**:



**3** **Select** or **right arrow** opens the **Configuration menu**:



**4** Pressing **Select** or **right arrow** again displays the **Port configuration** window which shows the present service of the ports, and the incoming call response.



For enabling/disabling of secure voice, see [appendix E](#).

Secure voice appears when bought.

For port details, see [appendix B – Connecting up optional equipment](#).

Net service providers

Each Net service provider has a station code. The "Net service provider" window displays a list which matches the codes to the station owners. *Names can be edited in "owner" level (non-SIM operation).*


Example:

**1** Press the **Menu** function key and scroll down to **Advanced functions:**

**2** Press **Select** or **right arrow** and scroll down to **Configuration:**

**3** **Select** or **right arrow** selects the **Configuration menu:** Press **Select** or **right arrow** again for **Net service providers.**

**4** Scroll up/down to wanted service provider:



Configuration cont'd

**Power conservation**

Battery power can be conserved during voice calls and/or telefax calls. The conservation can be enabled for voice and/or telefax. When set in **Auto** mode, the conservation facility is automatically enabled when using the internal battery supply and disabled when connected to an external power supply. The speech quality at the remote end may be slightly impaired with power conservation enabled.

**Example**

**1** Press the **Menu** function key and scroll down to **Advanced functions**:  
Press **Selct** or **right arrow** and continue down to **Configuration**:

**2** **Selct** or **right arrow** selects the **Configuration menu**:


**3** Scroll down and press **Selct** or **right arrow** to open the **Power conservation** window:

**4** **Enable/Disable** power reduction during voice/fax calls, as required. **Auto** reduces drain when using battery. **Save** stores new entries or modifications:

**Set diagnostics**

Additional system information is displayed when diagnostics is turned **On**.

*Note! Not necessary for normal telephone usage.*




**Storing of Preferred/Allowed Net service provider and Stand Alone operator on the SIM Card**

These functions allow you to store the **preferred** and **allowed Net service provider** and **preferred** and **allowed Stand Alone operator** for each satellite region on a SIM card. *Note! The access level required to operate the functions depend on the SIM card supplier.*


Configuration cont'd

**Preferred Net service provider**


**1** Press the **Menu** function key and scroll down to **Advanced functions**:



**2** Press **Select** or **right arrow** and scroll down to **Configuration**:




**3** **Select** or **right arrow** selects the **Configuration menu**:  
Scroll down to **Set preferred Nets**:




**Select** or **right arrow** opens the list of **Set preferred Net providers**.

Scroll up/down to wanted satellite:



**4** **Select** or **right arrow** shows the current Net and TNID for the selected satellite:  
(TNID=Terrestrial Network Identification Digits)



**Remove** deletes the the Net entry.


Removes entry from list → See next page



**5 Edit** opens list of available Nets:

**6** Scroll up/down to wanted Net:

**Select** enters new default Net service provider:




*If the SIM card is not "restricted":*

**5b Edit** opens **satellite preferred list** window:

**Select** or **right arrow** opens list of available Nets.

**6b** Scroll up/down to wanted Net:

**Select** enters new default Net service provider:



### Set S/A preferred Net (Stand Alone operator)

Repeat steps 3 through 6.

### Set allowed Nets / Set S/A allowed Nets

*Restricted to "CHV2" or higher, depending on Net service provider.*

Repeat steps 3 through 6.


**Charge tone**

When the charge tone function is enabled, a single frequency tone or DTMF is transmitted once the call has been established. The tone informs an external debiting system, f.ex. a pay phone (connected to the TEL port), that charging can start.


*Settings can only be made in **owner** level.*

**Setup:**


**1** Press the **Menu** function key and scroll down to **Advanced functions:**




**2** Select or right arrow opens the **Configuration Menu:**



**3** Scroll down to **Charge tone**, and press **Select** or **right arrow** to open the **Charge tone** window:




**4** Selecting **Setup** opens the **Charge tone setup** window, which allows setting the required single frequency tone or DTMF, and its duration in milliseconds.



Key no. when selecting DTMF.

*Valid settings:  
Frequency: 400 - 3400 Hz  
Duration: 10 - 5000 ms  
DTMF key: 0 - 15*

**Select** enters the chosen settings:



Configuration cont'd

**General**

The following information and facilities are provided:


- The IMN numbers assigned to the WorldPhone.  
*Access level must be set to "owner" or "CHV2" for editing of the numbers on the telephone or SIM card respectively.*
- Forward ID number which identifies your particular WorldPhone and SIM card if installed.
- System version numbers of the internal software programs. See *next page*.
- Restoring communication with the satellite when receiving the alarm: **Not available**, see *"Oscillator compensation" on next page*. (The function only appears when **"Set diagnostics" is On**).
- Network status information (*only appears when "Set diagnostics" is On, or the access level is set to "owner"*), see *next page*.

**IMN numbers**

**1** Press the **Menu** function key and scroll down to **Advanced functions**: Press **Select** or **right arrow** and continue down to **Information available**:

**2** Select or right arrow opens the **Information available** window:



**3** Pressing **Select** or **right arrow** again opens the **IMN numbers** window:



Information available cont'd

**Misc. version ID information**

**4** Scroll down and press **Select** or **right arrow** to open **Version information** window.






**Oscillator compensation**

**5** Scroll down and press **Select** or **right arrow** to open **Oscillator compensation** window:

Press **Scan** with the antenna pointed towards the satellite.  
(*Pointing is automatic on Marine & Voyager antennas. Will take 10-15 minutes.*)


If several choices, scroll down to preferred frequency. Press **Select**:

When **Verification succeeded** is displayed, press **Save** to update the WorldPhone oscillator.



**Network status**

**6** Scroll down and press **Select** or **right arrow** for readout of network data.



**Paid functions**

Only appears in owner level (non-SIM operation).

An enhanced WorldPhone function is activated by entering the "Opening key" provided when purchased:


**1** Press the **Menu** function key and scroll down to **Advanced functions**.

**2** Select or right arrow opens the **Installation** menu window:

**3** Pressing **Select** or right arrow again opens the **Paid functions** window:

The list only shows purchased functions.


**4** Pressing **New** opens the **Open new paid functions** window:  
Enter the "Opening key" and press **Ok**.

**Phone name setup**

Only appears in owner level (non-SIM operation).

Repeat steps 1 and 2 to open **Phone name setup** window:

Use **Del** to modify. Press **ABC** or **abc** to enter uppercase/lowercase letters as required. **Save** stores the modified phone name.





Setting up ..... 3.1  
Using telefax with the WorldPhone ..... 3.2

The design and specifications of the equipment may be changed without notice.





## General

The WorldPhone provides access to a telefax service at a transmission rate of 2.4 Kbps.

## Limitations

The WorldPhone is fully compatible with the world's leading telefax machines and telefax software standards. However, transmission may not be possible through some of the telefax machines available on the market. Please check with your Net service provider before purchasing a telefax for use with the WorldPhone.

## Installation

Connect the telefax cable to the **FAX** port on the WorldPhone telephone unit. For wiring details, see [appendix B – Connecting up optional equipment](#).

Verify that the FAX port is configured for telefax service, see ["Advanced functions: Port configuration"](#) in chapter 2. Operation.




Figure 3.1 Telefax communication with the WorldPhone.

## Using telefax with the WorldPhone

### Transmission

Telefax calls made by the WorldPhone are *telefax only*. Any telephone handset connected to the telefax machine is for dialing purposes only.

To send a fax, use the same dialing sequence as when making a call, either through the default Net or a selected one.

See "**Making a call**" in chapter 2. Operation.

*Note! On a telefax with keypad, enter  as the last digit before starting transmission.*

Telefax transmissions normally take 1.5 minutes per standard text page using standard resolution. Using superfine or halftone resolution will double the transmission time. To save time, avoid using a separate cover page.

If a call failure should occur while sending a multi-page document, re-send only the failed pages.

Setting up ..... 4.1

The design and specifications of the equipment may be changed without notice.



## General

The WorldPhone provides access to asynchronous data services through its built-in modem capability. The transmission rate over the satellite is 2.4 Kbps, and any standard PC with a serial port can be used.

For configuration from the PC using AT commands, see [appendix D](#).

## Installation

Connect the RS-232 serial cable between the serial port on the PC and the 9-pin **DATA** port on the WorldPhone telephone unit.

For configuration, see [chapter 2. Operation: "Data/printer port setup"](#).

For wiring details, see [appendix B – Connecting up optional equipment](#), or [appendix D – DTE interface](#).




Figure 4.1 The PC is connected to the DATA port.

## Setting up cont'd

### *Testing the installation*

Use a PC terminal program.

Entering a command on the PC keyboard (f.ex. `ATJ`) should cause "OK" to be displayed on the screen.

If there is no response, check that the baud rate setting is the same both for the PC and the WorldPhone.

See *chapter 2. Operation: "Data/printer port setup"*.

**Appendix A**

*Telephone country codes* ..... A-1  
*Service address codes*..... A-5

**Appendix B**

*Installation of Marine Antenna* ..... B-1  
*Installation of Voyager Antenna* ..... B-9  
*Installation of Provident Antenna* ..... B-16  
*Optional antenna cable* ..... B-21  
*Connecting up optional equipment* ..... B-22

**Appendix C (WorldPhone Portable/Provident only)**

*Battery charging*..... C-1  
*Charger* ..... C-2  
*Battery replacement*..... C-3

**Appendix D**

*AT commands* ..... D-1  
*DTE interface* ..... D-17

**Appendix E**

*Secure voice (option)* ..... E-1  
*Aero functions (option)* ..... E-2

**Appendix F**

*Character map* ..... F-1

**Appendix G**

*List of terms* ..... G-1

**Appendix H**

*System description*..... H-1

**Appendix I**

*Troubleshooting* ..... I-1







## Appendix A – Telephone country codes

### Explanation with examples:


*Mobile - to - fixed subscriber, telephone call through **default Net**:*



*Mobile - to - fixed subscriber, telephone call through **selected Net service provider**:*



*Fixed/mobile - to - Mobile telephone call:*



*Note! Some Net service providers support the common Ocean Region access no. 870, which connects the call to the dialed WorldPhone regardless of the Ocean Region the user currently communicates through.*

## Appendix A – Telephone country codes cont'd

Afghanistan (Islamic State of) .....	93	Cuba .....	53
Albania (Republic of) .....	355	Cyprus (Republic of) .....	357
Algeria (People's Democratic Republic of) ....	21b1)	Czech Republic .....	420 c)
American Samoa .....	684		
Angola (Republic of) .....	244	Democratic People's Republic of Korea .....	850
Anguilla .....	1 a)	Denmark .....	45
Antigua and Barbuda .....	2 a)	Diego Garda .....	246
Argentine Republic .....	54	Djibouti (Republic of) .....	253
Armenia (Republic of) .....	374 d)	Dominican Republic .....	1 a)
Aruba .....	297		
Ascension .....	247	Ecuador .....	593
Atlantic Ocean East Region (AOR-E) (Inmarsat) .....	871	Egypt (Arab Republic of) .....	20
Atlantic Ocean West Region (AOR-W) (Inmarsat) ...	874	El Salvador (Republic of) .....	503
Australia .....	61	Equatorial Guinea (Republic of) .....	240
Australian External Territories .....	672	Eritrea .....	291
Austria .....	43	Estonia (Republic of) .....	372
Azerbaijani Republic .....	994	Ethiopia .....	251
Bahamas (Commonwealth of the) .....	1 a)	Falkland Islands (Malvinas) .....	500
Bahrain (State of) .....	973	Faroe Islands (Denmark) .....	298
Bangladesh (People's Republic of) .....	380	Fiji (Republic of) .....	679
Barbados .....	1 a)	Finland .....	358
Belarus (Republic of) .....	375 d)	France .....	33 c)
Belgium .....	32	French Polynesia .....	68
Belize .....	501		
Benin (Republic of) .....	223	Gabonese Republic .....	241
Bermuda .....	1 a)	Gambia (Republic of the) .....	220
Bhutan (Kingdom of) .....	975	Georgia (Republic of) .....	7 d)
Bolivia (Republic of) .....	591	Germany (Federal Republic of) .....	49
Bosnia and Herzegovina (Republic of) .....	387	Ghana .....	233
Botswana (Republic of) .....	267	Gibraltar .....	350
Brazil (Federative Republic of) .....	55	Greece .....	30
British Virgin Islands .....	1 a)	Greenland (Denmark) .....	299
Brunei Darussalam .....	673	Grenada .....	1 a)
Bulgaria (Republic of) .....	859	Guadeloupe (French Department of) .....	590
Burkina Faso .....	226	Guam .....	671
Burundi (Republic of) .....	257	Guatemala (Republic of) .....	502
		Guiana (French Department of) .....	594
Cambodia .....	355	Guinea (Republic of) .....	224
Cameroon (Republic of) .....	237	Guinea-Bissau (Republic of) .....	245
Canada .....	1 a)	Guyana .....	592
Cape Verde (Republic of) .....	238		
Cayman Islands .....	1 a)	Haiti (Republic of) .....	509
Central African Republic .....	236	Honduras (Republic of) .....	504
Chad (Republic of) .....	235	Hongkong .....	852
Chile .....	56	Hungary (Republic of) .....	36
China (People's Republic of) .....	86 e)		
Colombia (Republic of) .....	57	Iceland .....	354
Comoros (Islamic Federal Republic of the) ..	269	India (Republic of) .....	91
Congo (Republic of the) .....	242	Indian Ocean Region (IOR)(Inmarsat) .....	873
Cook Islands .....	682	Indonesia (Republic of) .....	62
Costa Rica .....	506	Iran (Islamic Republic of) .....	98
Croatia (Republic of) .....	385	Iraq (Republic of) .....	964

## Appendix A – Telephone country codes cont'd

Ireland .....	353	New Zealand .....	64
Israel (State of) .....	972	Nicaragua .....	505
Italy .....	39	Niger (Republic of the) .....	227
Ivory Cost (Republic of) .....	225	Nigeria (Federal Republic of) .....	234
Jamaica .....	1 a)	Niue .....	683
Japan .....	81	Northern Mariana Islands (Commonwealth of the) ..	670
Jordan (Hashemite Kingdom of) .....	962	Norway .....	47
Kazakhstan (Republic of) .....	7 d)	Oman (Sultanate of) .....	968
Kenya (Republic of) .....	254	Pacific Ocean Region (POR)(Inmarsat) .....	872
Kiribati Republic of) .....	686	Pakistan (Islamic Republic of) .....	92
Kuwait (State of) .....	965	Palau (Republic of) .....	680
Kyrgyzstan (Republic of) .....	996 d)	Panama (Republic of) .....	507
Lao People's Democratic Republic .....	856	Papua New Guinea .....	675
Latvia (Republic of) .....	371	Paraguay (Republic of) .....	595
Lebanon .....	961	Peru .....	51
Lesotho (Kingdom of) .....	266	Philippines (Republic of the) .....	63
Liberia (Republic of) .....	231	Poland (Republic of) .....	48
Libya (Socialist People's Ubyan Arab Jamahiriya) ...	21b2)	Portugal .....	351
Liechtenstein (Principality of) .....	41 c)	Qatar (State of) .....	974
Lithuania (Republic of) .....	370	Reunion (French Department of) .....	262
Luxembourg .....	352	Romania .....	40
Macau .....	853	Russian Federation .....	7 d)
Macedonia (the former Yugoslav Republic of) ..	389	Rwandese Republic .....	250
Madagascar (Republic of) .....	261	Saint Vincent and the Grenadines .....	1 a)
Malawi .....	265	Saint Luda .....	1 a)
Malaysia .....	60	Saint Kitts and Nevis .....	1 a)
Maldives (Republic of) .....	960	Saint Helena .....	290
Mali (Republic of) .....	223	Saint Pierre and Miquelon (French Department of) .	508
Malta .....	356	San Marino (Republic of) .....	378
Marshall Islands (Republic of the) .....	692	Sao Tome and Principe (Democratic Republic of) ..	239
Martinique (French Department of) .....	596	Saudi Arabia (Kingdom of) .....	966
Mauritania (Islamic Republic of) .....	222	Senegal (Republic of) .....	221
Mauritius (Republic of) .....	230	Seychelles (Republic of) .....	248
Mexico .....	52	Sierra Leone .....	232
Micronesia (Federated States of) .....	691	Singapore (Republic of) .....	65
Moldova (Republic of) .....	373	Slovak Republic .....	421 c)
Monaco .....	377 c)	Slovenia (Republic of) .....	386
Mongolia .....	976	Solomon Islands .....	677
Montserrat .....	1 a)	Somali Democratic Republic .....	252
Morocco (Kingdom of) .....	21b3)	South Africa (Republic of) .....	27
Mozambique (Republic of) .....	258	Spain .....	34
Myanmar (Union of) .....	95	Sri Lanka (Democratic Socialist Republic of) .	94
Namibia (Republic of) .....	264	Sudan (Republic of the) .....	249
Nauru (Republic of) .....	674	Suriname (Republic of) .....	597
Nepal .....	977	Swaziland (Kingdom of) .....	268
Netherlands Antilles .....	599	Sweden .....	46
Netherlands (Kingdom of the) .....	31	Switzerland (Confederation of) .....	41 c)
New Caledonia .....	687	Syrian Arab Republic .....	963

## Appendix A – Telephone country codes cont'd

Tajikistan (Republic of) .....	7 d)	Uruguay (Eastern Republic of) .....	598
Tanzania (United Republic of) .....	255	Uzbekistan (Republic of) .....	7 d)
Thailand .....	66		
Togolese Republic .....	228	Vanuatu (Republic of) .....	678
Tokelau .....	690	Vatican City State .....	379
Tonga (Kingdom of) .....	676	Venezuela (Republic of) .....	58
Trinidad and Tobago (Code actually used: +1) ..	296	Viet Nam (Socialist Republic of) .....	84
Tunisia .....	21b4)		
Turkey .....	90	Wallis and Futuna .....	681
Turkmenistan .....	993 d)	Western Samoa (Independent State of) .....	685
Turks and Caicos Islands .....	1 a)		
Tuvalu .....	688	Yemen (Republic of) .....	967
		Yugoslavia (Federal Republic of) .....	381
Uganda (Republic of) .....	256		
Ukraine .....	380 d)	Zaire (Republic of) .....	243
United Arab Emirates .....	971 h)	Zambia (Republic of) .....	260
United States of America, + Puerto Rico, Virgin Islands .....	1 a)	Zanzibar (Tanzania) .....	259
United Kingdom of Great Britain and Northern Ireland .....	44	Zimbabwe (Republic of) .....	263

### Notes

- a): Integrated numbering area.
- b1): Integrated numbering area with subdivisions: 213, 214 and 215 for Algeria.
- b2): Integrated numbering area with subdivisions: 218 and 219 for Libya.
- b3): Integrated numbering area with subdivisions: 210, 211, 212 (212 in service) for Morocco.
- b4): Integrated numbering area with subdivisions: 216, 217 for Tunisia.
- c): Integrated numbering plan.
- d): Will form part of numbering zone 7.
- e): Code 866 has been allocated to the province of Taiwan.
- h): United Arab Emirates (U.A.E.) incl: Abu Dhabi, Ajman, Dubai, Fujairah, Ras Al Khaimah, Sharjah, Umm al Qaiwain.

## Appendix A – Service address codes

Abbreviated dialing .....	23	Mail retrieval .....	57
Access to maritime packet assembly/ disassembly .....	20	Maritime assistance .....	39
Administration specialized use .....	6(X)	Maritime enquiries .....	31
Automatic .....	00	Medical advice .....	32
Automatic line test .....	91	Medical assistance .....	38
Collect call .....	35	Meteorological reports .....	41
Credit card call .....	36	Navigational hazards and warnings .....	42
Commissioning tests .....	92	National operator .....	13
Databases .....	70	National information service .....	14
Faxmail .....	26	Person-to-person call .....	34
International outgoing operator .....	11	Ship position reports .....	43
International information service .....	12	Technical assistance (on network) .....	33
		Telephone call booking .....	17
		Time and duration .....	37
		Time announcement .....	50



## Appendix B – Installation of Marine Antenna

### Location of Antenna Unit

#### *Avoid obstructions*

The Antenna ideally requires a free line of sight in all directions above an elevation angle of 5 degrees.

Any obstruction will cause blind sectors, and may result in degradation or even loss of communication with the satellite.

Degrading of the communication is only completely avoided by placing the antenna higher than any obstructions. This is often not feasible and a compromise must be made to reduce the number of blind sectors.

The degree of communication degradation depends on the size of the obstructions; the distance to them must therefore be considered.

Preferably, all obstructions within 3 m of the antenna should be avoided. Obstructions less than 15 cm in diameter can be ignored beyond this distance.


Installation of Antenna Unit on top of mast must be avoided.

#### *Compass safe distance*

For installation on Norwegian or British vessels, the Antenna Unit should be located at a distance of at least 1.0 metre from the magnetic steering compass. Be aware that requirements may vary from one country to another.

#### *Radiation precautions*

Persons should not be near the antenna when transmitting for periods of more than 1 hour per day.



**MICROWAVE RADIATION !  
NO ADMITTANCE WITHIN 1 M**

## Appendix B – Installation of *Marine Antenna* cont'd

### *Avoid interference*

The Antenna Unit should be separated as far as possible from other communication and navigation antennas onboard such as Radar, Satellite, HF/VHF/UHF, GPS antennas etc.. Preferably by 5 metres.

The Antenna Unit should be installed so that severe vibration and shock are avoided. If installed on top of a pipe or signal/radar mast, the mast must be supported by stays.

The equipment is supplied with gasket and a flange for mounting of the Antenna Unit on top of a 42.4 mm outer diameter pipe.

Other installation bracket is optional.

### **Coax cable**

A 12 metre coaxial cable type RG-223 (QRPM 911084-12000) is supplied as standard.

*For greater lengths, see "Optional antenna cable".*

The coax cable should be secured by laying the cable in a tube and/or by fastening the cable to avoid damage.

### **Telephone Unit (TPU) and Power Supply (PS)**

The PS is provided with holes for mounting on desktop or bulkhead with the TPU snapped on top of PS by fastening clips.

The TPU may be installed separately by using 3 metre extension cables between PS and TPU:

- coaxial cable, QRPM 911087-3000
- DC cable, QRPM 911079-3000

### **Source of energy**

The equipment operates from 10 to 32 Volts DC from any 12V or 24V battery.

Power supply for operation from 230 VAC may be supplied as an option, QBMJ 101002.

### **Note!**


*The antenna has been delivered with 3 different types of radomes. The latest version (type 3) is mounted as illustrated on page B-4.*

*The earlier versions (type 1 and 2) are mounted as shown on page B-6. Be aware of the condensation drainage through the area around the coax connector for these versions, see illustration.*



## Appendix B – Installation of Marine Antenna cont'd

### Connecting up



Installation of Marine Antenna cont'd

## Appendix B – Installation of Marine Antenna cont'd

### Mounting the Antenna Unit with radome type 3


#### Procedure:

Thread coax cable through sockets and tube prior to final assembling and installing Antenna Unit


**Note!**  
**Condensation drainage.**  
*Do not cover!*

#### Mounting flange

Lock screw (2)  
Use 6 mm  
unbrako key



#### Mounting flange dimensions:




DIMENSIONS IN MILLIMETRES

**Mounting the radome top of radome type 3**

**1** Place gasket on radome base.

**2** Lower radome top down onto the base with alignment mark across for alignment area on the base.

**3** Turn radome top approx 30° clockwise until the snap function locks.




## Appendix B – Installation of Marine Antenna cont'd


### Mounting the Antenna Unit with radome type 1 and 2

#### Mounting:

Thread coax cable through sockets and tube prior to final assembling and installing Antenna Unit




#### Mounting flange dimensions:



DIMENSIONS IN MILLIMETRES

## Appendix B – Installation of *Marine Antenna* cont'd

### Mounting the Power Supply




*Underside view*


## Appendix B – Installation of *Marine Antenna* cont'd

### Outline dimensions


**Antenna Unit**  
QUFF 911980  
(antenna only)  
Weight: 3.8 kg




**Telephone Unit (TPU)**  
QUFC 911936  
Weight: 1.0 kg



**Power Supply (PS)**  
QUFC 911932  
Weight: 1.6 kg



**Optional 230 VAC power supply w/AC and DC cables connected.**  
QBMJ 101002  
Weight: 0.65 kg



### **Antenna Unit**

The Antenna Unit should be installed so that severe vibration and shock are avoided.

The equipment is supplied with a magnetic mounting bracket for installation on cars with magnetic-holding roof top.

#### *Mounting option:*

Load Carrier Base Assembly for installation on cars with non-magnetic roof material, or for installation on trains.

*See illustration on next page.*

### **Coax cable**

A 5 metre coaxial cable type GO2232D (QRPM 911086-5000) is supplied as standard.

*For greater lengths, see "Optional antenna cable".*

### **Telephone Unit (TPU) and Power Supply (PS)**

The PS is provided with holes for mounting on wall or dash board with the TPU snapped on top of PS by fastening clips. A tripod mount allows the unit to be mounted on the optional suction adapter.

The TPU may be installed separately by using 3 metre extension cables between PS and TPU:

- coaxial cable, QRPM 911087-3000
- DC cable, QRPM 911079-3000


### **Source of energy**

The equipment operates from 10 to 32 Volts DC from any 12V or 24V battery.

## Appendix B – Installation of Voyager Antenna cont'd

### Connecting up


**ODE**  
Outdoor Equipment  
-----  
**IDE**  
Indoor Equipment



#### Antenna coax cable

Standard:  
type GO2232D  
Length 5 m.

**WorldPhone**  
Telephone Unit  
TPU



**Power Supply PS**

Power cable type  
QRPM 911080-2000  
10-32V DC

RF cable to/from  
WorldPhone  
QRPM 911081-0150  
Length: 15 cm

Power cable to WorldPhone  
QRPM 911079-0150  
Length: 15 cm

*NB! Polarity dependent:  
The positive lead is tagged.  
(The NEGATIVE pole is connected  
to the CENTRE PIN of the 3-pin plug.)  
Fuse: 15 A slow blow*



## Appendix B – Installation of Voyager Antenna cont'd

### Mounting on magnetic-holding surface

The Antenna Unit may be attached to the roof top with a magnetic plate inside the antenna mounting bracket. On a flat, clean metal surface the antenna will stay in place at highway speeds up to 150 km/hour.


*Note!* A protection plate is supplied to keep the magnetic plate clean during shipment of the equipment. Remove the protection plate from the magnetic plate prior to attaching the Antenna Unit.

See "[Assembling the Antenna Unit for magnetic mount](#)".

The antenna may be loosened by carefully bending a screwdriver as indicated.


### Mounting on load carrier

The Antenna Unit may also be attached to the roof using load carrier as indicated. See "[Assembling the Antenna Unit for load carrier mount](#)".




## Appendix B – Installation of Voyager Antenna cont'd

### Assembling the Antenna Unit for magnetic mount




### Assembling the Antenna Unit for load carrier mount




## Appendix B – Installation of Voyager Antenna cont'd

### Mounting the Power Supply



### Outline dimensions

**Power Supply**  
QUFC 911932  
Weight: 1.6 kg




## Appendix B – Installation of Voyager Antenna cont'd

### Outline dimensions

#### Telephone Unit

QUFC 911936


Weight: 1.0 kg



#### Antenna Unit


QUFF 911905

Weight: 3.0 kg



#### Load carrier mount (option)

QSXA 811990



### **Satellite search**

Before mounting the WorldPhone Provident antenna, look up the relative position of the satellite, see *coverage map in appendix H – System description*.

The antenna must be pointed at the satellite with free line of sight for optimum receiving and transmitting conditions. The beam is perpendicular to the antenna.

When during adjustment of the antenna a satellite signal is received, a short tone will sound. If it is an Inmarsat satellite, a continuous tone will sound with varying frequency. When closing in on a satellite, turning the antenna horizontally and adjusting its vertical angle, the tone should increase in frequency.

See *setup procedure for WorldPhone Portable in chapter 1. Getting Started*.

### **Coax cable**

A 10 metre coaxial cable type RG-223 (QRPM 911091-10000) is supplied as standard.

For greater lengths, see "**Optional antenna cable**".

A bracket is available with N-connector receptacle for connection of extended antenna cable, see "**Optional bracket**".

### **Source of energy**

The equipment operates from 10 to 32 Volts DC from any 12V or 24V battery, using the 2 m DC power cable, QRPM 911080-2000. The positive lead of the power cable is tagged.


An adapter is included for operation from 90-264 VAC, QBMA 901001 (1.8 m mains cable).

A 2 m car lighter cable can also be supplied, QRPM 911090.

The TPU is delivered with an internal rechargeable battery pack, see "**Internal battery**" in *chapter 1. Getting Started*.

## Appendix B – Installation of *Provident Antenna* cont'd


### Connecting up



Installation of Provident  
Antenna cont'd

## Appendix B – Installation of *Provident Antenna* cont'd


### *Mounting the Antenna Unit*





## Appendix B – Installation of *Provident Antenna* cont'd

### Optional bracket



Installation of Provident  
Antenna cont'd


## Appendix B – Installation of *Provident Antenna* cont'd

### *Outline dimensions*

#### **Telephone Unit**

QUFC 911936


Weight: 1.0 kg



#### **Antenna Unit**

QUFC 911906

Weight: 3.0 kg  
(antenna only)



### General

Double screen 50 Ω coaxial cable must be used for connection between the TPU and the various Antenna Units.

The coax cable should be secured by laying the cable in a tube and/or by fastening the cable to avoid damage.

A "pigtail" is normally required for connection to the TPU.


The maximum length of the coax cable is limited by the DC and RF loss through the cable:

**Maximum DC loss:** R loop 0.6 ohm

**Maximum RF attenuation at 1525-1660 MHz:** < 10 dB

The table below lists suitable double screened coax cables:

*Antenna cable	Reference	Diameter	max. length for 10 dB/0.6	Suitable coaxial connectors	
				at the TPU	at the antenna
RG214	MIL-C-17	10.8 mm	25 m	11N-50-7-5 + "pigtail"	11N-50-7-5
S 10172 B-10 (QTZC 502 012)	—	12.9 mm	75 m	11N-50-10-4 + "pigtail"	11N-50-10-4
RF 1/2" 50	—	16.0 mm	95 m	11N-50-12-115 + "pigtail"	11N-50-12-115
RF 7/8" 50	—	27.5 mm	172 m	11N-50-23-101 + "pigtail"	11N-50-23-101




### Ready-made cables

The following cable extensions are delivered with coax connectors mounted:

10 m cable	QRPM 911091-10000
28 m cable	QRPM 911057-28000
80 m cable	QRPM 911058-80000

# Appendix B – Connecting up optional equipment



Connecting up optional equipment

## Appendix C – Battery charging

(WorldPhone Portable/Provident only)

### Handling

A new battery, or a battery that has not been used for a long time, will require 2 - 3 charge/discharge cycles to achieve its maximum performance with normal use of the WorldPhone.

To discharge the battery use the phone until it shuts down.

*Avoid charging a fully charged or nearly charged battery.*

*Never leave the battery in hot sunlight. Extreme temperatures may cause permanent reduction of the battery capacity.*


### Charging

The charging starts automatically once the universal AC adapter or the car lighter cable is connected to the power source, and terminates automatically when the battery is fully charged.

*Note! When running the WorldPhone on the universal adapter alone (no battery installed), the battery symbol in the display is replaced by "DC".*

### Calibration

To ensure correct monitoring of the battery state, it must be fully discharged before charging the battery pack for the first time.



## Appendix C – Battery charging cont'd

### Charger


The WorldPhone Charger allows separate charging of a single battery pack.

#### Operation:

- 1** The indicator lights green when connecting the charger to the power source without battery inserted.  
No light indicates that power is not supplied to the charger: check cables.
- 2** When inserting a battery that is not fully charged, red light indicates that charging takes place.
- 3** Green light indicates that the battery is fully charged. A fully discharged battery is charged in approximately 3 hours.

#### Note!

*The battery may be stored or transported in the charger without any risk of drainage apart from self-discharge.*



## Appendix C – Battery replacement

(WorldPhone Portable/Provident only)

Slide back lock to release battery pack



Battery pack  
QSXK 911944-2







### General

The **AT** command set allows you to configure the WorldPhone ASD function directly from your PC keyboard. The AT characters are a prefix to the commands you issue to the WorldPhone's ASD service. *Most communication applications do not require knowledge of AT commands.*

Every time you type AT, you are essentially asking for the WorldPhone ASD's **AT**tention. For instance, if you want to answer an incoming data call, you would type ATA to answer: `A T A ↵`

When a value associated with a command is not entered, it is assumed to be 0, f.ex.: `A T & D` equals `A T & D 0`.

### Hanging up – escape sequence

Once the the WorldPhone ASD is online to another system, the only command it recognises is an **escape code** that contains three typed pluses, (+) which forces the WorldPhone ASD back to **command mode**.

The following should be done, when issuing the escape command:

- Wait one second after sending the last item of data.
- Type `+ + +` with less than one second between the characters.
- Wait one second, an "OK" response should appear.

Do not type the AT prefix or Carriage Return. The guard time of one second before and after the code prevents the WorldPhone ASD from misinterpreting the occurrence of +++ in the transmitted data stream.

If necessary, the character used in the escape code or the duration of the guard time can be changed by altering Register S2 or S12, see [S-register commands](#).

- In response to `+ + +`, the WorldPhone ASD returns to command mode.
- To hang up, key `A T H ↵`
- To return to online mode, key `A T O ↵`

### *Operating modes*

The WorldPhone ASD function may operate in three modes:

- **Command mode**  
The WorldPhone ASD responds to AT commands. No remote communication occurs.
- **Online command mode**  
A data call is taking place and an escape sequence has been initiated, after which the WorldPhone ASD will respond to **AT** commands during the call.
- **Online data mode**  
Once the WorldPhone ASD is connected up, anything arriving from the PC is interpreted as data and sent to the remote end and vice versa.

### Basic AT commands

Note! AT commands may be entered in **either** upper or lower case (not mixed).

**A T A ↵**

*instructs the WorldPhone ASD to connect the line and start the answer sequence of the incoming call. Used when not configured for auto answer.*

**A T D 0 0 4 7 6 7 2 4 4 7 0 0 ↵**

*instructs the WorldPhone ASD to dial the number **00 47 67 24 47 00** via the default Net service provider.*

**A T D 4 \* 0 0 4 7 6 7 2 4 4 7 0 0 ↵**

*instructs the WorldPhone ASD to dial the number **00 47 67 24 47 00** via the selected Net service provider, e.g. Telenor (Norwegian Telecom, code no.4).*

**A T D 2 3 1 1 ↵**

*dials the telephone number stored under short number 11.*

**A T E [n] ↵**

*sets local echo of keyboard commands on/off:*

**A T E 0 ↵** turns local echo **OFF**.

*Default*

**A T E 1 ↵** turns local echo **ON**.

**A T H ↵**

*hook control:*

**A T H ↵** sets the WorldPhone ASD ON-hook when in Online Data Mode. Disconnects the line and terminates the call.

**A T O ↵**

*returns to Online Data Mode when in Online Command Mode during a data call.*

## Appendix D – AT commands cont'd

**A T Q[n] ⏎**

sets responses sent by the WorldPhone ASD:

*Default* **A T Q 0 ⏎** : the WorldPhone ASD **returns** responses like OK or ERROR.

**A T Q 1 ⏎** : the WorldPhone ASD does not return responses.

**A T S**

sets and displays S register values. See "**S-Register Commands**".

**A T V[n] ⏎**

sets the WorldPhone ASD response format to words or numbers:

**A T V 0 ⏎** selects **numeric** response.

*Default* **A T V 1 ⏎** selects **verbal** response.

**A T X[n] ⏎**

selects CONNECT result code format (dial tone detection – busy detection):

**A T X 0 ⏎**

basic message set: OK, CONNECT, RING, NO CARRIER, ERROR.

**A T X 1 ⏎**

basic message set extended with CONNECT xxxx-yyyy.

**A T X 2 ⏎**

basic message set extended with NO DIALTONE.

**A T X 3 ⏎**

basic message set extended with BUSY.

*Default* **A T X 4 ⏎**

basic message set extended with all of the above.

## Appendix D – AT commands cont'd

**A** **T** **Z** **↵** **R**

*resets the WorldPhone ASD configuration to last saved command. Also clears the call if used when in Online Command Mode.*

**A** **/**

*repeats last command.*

Re-executes the last AT command string issued to the WorldPhone ASD, including redialing a telephone number.

## Appendix D – AT commands cont'd

### Extended AT commands

`AT & C[n] \r`

*determines the Data Carrier Detect (DCD) behaviour:*

`AT & C0 \r` sets DCD always ON.

*Default* `AT & C1 \r` sets DCD, only when connected.

`AT & D[n] \r`

*selects the Data Terminal Ready (DTR) behaviour:*

`AT & D0 \r` the WorldPhone ASD ignores DTR.

`AT & D1 \r` the WorldPhone ASD enters Online Command Mode when DTR goes inactive.

*Default* `AT & D2 \r` the WorldPhone ASD **clears call** when DTR goes inactive.

`AT & F \r`

*resets the WorldPhone ASD to factory **default**. The factory default is not saved as with the AT&W command, so ATZ revokes to last saved values.*

`AT & S[n] \r`

*selects the Data Set Ready (DSR) behaviour:*

*Default* `AT & S0 \r` sets DSR permanently ON.

`AT & S1 \r` sets DSR ON when satellite link is established.

`AT & V \r`

*displays stored configuration profile.*

`AT & W \r`

*saves active configuration profile.  
(May be recalled using `ATZ \r`).*

### Extended AT+I, +G and +W commands

The extended AT+I, AT+G and AT+W commands are non-standard features some of which are designed specially for the Inmarsat Mini-M system.

`AT+GCAP` `↵`

*displays capabilities supported by WorldPhone terminals.*

`AT+GMI` `↵`

*displays manufacturer identification.*

`AT+GMM` `↵`

*displays equipment identification.*

`AT+GMR` `↵`

*displays software revision.*

`AT+ICF` `=` `[n<format>]` `[,m<parity>]` `↵`

*specifies the local serial port start-stop (asynchronous) character framing between the PC and the WorldPhone.*

`AT+ICF?` `↵`

*displays current settings.*

`AT+ICF` `=` `?` `↵`

*displays available settings.*

Format reference number **n** :

**1** = 8 data bits, 2 stop bits

*Default* **3** = 8 data bits, 1 stop bit

**4** = 7 data bits, 2 stop bits

**5** = 7 data bits, 1 parity bit, 1 stop bit

## Appendix D – AT commands cont'd

Parity reference number **m** :

**0** = odd

**1** = even

**2** = mark

*Default* **3** = space

Example:

```
AT+ICF=3,3
```

*specifies a data format of 8 data bits, 1 stop bit and space parity.*

```
AT+IFC=[n<WP-to-PC>],[m<PC-to-WP>]
```

*specifies the local flow control between the PC and the WorldPhone.*

```
AT+IFC?
```

*displays current settings.*

```
AT+IFC=?
```

*displays available settings.*

WorldPhone - to - PC, reference number **n** :

**0** = no flow control

**1** = XON/XOFF (software flow control stripped of control characters.)

*Default* **2** = RTS (hardware flow control)

**3** = XON/XOFF (software flow control with pass-through of control characters.)

PC - to - WorldPhone, reference number **m** :

**0** = no flow control

**1** = XON/XOFF (software flow control)

*Default* **2** = CTS (hardware flow control)

```
AT+IPR=[r(PC-to-WP rate)]
```

*specifies the data rate at which PC - WorldPhone interface accepts commands.*



## Appendix D – AT commands cont'd

`AT+IPR=?`

*displays current settings.*

`AT+IPR=?`

*displays available settings.*

Selectable data rates, r :

1200 bps

2400 bps

4800 bps

9600 bps

19200 bps

38400 bps

Example:

`AT+IPR=9600`

*specifies a data rate of 9600 bps between the PC and the WorldPhone telephone unit.*

`AT+W`

*indicates which PCCA standard the WorldPhone ASD complies with.*

`AT+WKSIZEN`

*sets the maximum ARQ window size for subsequent data calls using ARQ mode. The ARQ window determines the size of the buffer that keeps in memory data not yet acknowledged by the other end.*

`AT+WKSIZ=?`

*displays current settings.*

`AT+WKSIZ=?`

*displays available settings.*

Valid value of n = 1 - 63

**Default WorldPhone : n = 15**

## Appendix D – AT commands cont'd

**A T + W I N M A R S A T ␣ R**

*lists Inmarsat specific functions supported by the World-Phone ASD.*

**A T + W L E S = [n] ␣ R**

*selects the Net service provider for the next outgoing call.*

The parameter **nnn** specifies the Net service provider Access Code. Three digits must be keyed in. If omitted, the default Net service provider set from the WorldPhone is selected.

Range = 0 - 255

**nnn** = 000, default Net service provider.

**A T + W N E R A H S H A K E = [n] ␣ R**

*selects handshake setup.*

**n** = 1 fills the WorldPhone buffer before handshaking with the Net service provider.

*Default* **n** = 0 routes handshake transitions from the PC directly to the Net service provider. Minimizes transmission delays when handshake is used seldom.

**A T + W R A T E = [<sat\_rate>] [<ter\_rate>] ␣ R**

*sets the wanted satellite data rate, and the terrestrial data rate used for outgoing data calls.*

**A T + W R A T E ? ␣ R**

*displays selected rates.*

**A T + W R A T E = ? ␣ R**

*displays available rates.*

**Sat\_rate**, i.e. requested data rate to use over satellite channel, for WorldPhone permanently set to:

2400 bps

**Ter\_rate**, i.e. data rate to use on terrestrial modem:

1200 bps

2400 bps

4800 bps

*Default* 9600 bps

14400 bps

Example:

```
AT+WRATE=2400,2400␣
```

sets both the satellite rate and the terrestrial modem rate to 2400 bps.

```
AT+WRTL=<low> [<high>]␣
```

sets the lower and upper threshold level in bytes of the buffer used in the Net service provider-to-WorldPhone direction (**WorldPhone receive buffer**).

```
AT+WRTL?␣
```

displays selected threshold levels.

```
AT+WRTL=?␣
```

displays available threshold levels.

The **low** parameter specifies the lower threshold at which point the WorldPhone ASD should issue an RR (Receiver Ready) packet signalling that it is ready to receive data from Net service provider:

Valid value: 0-511

Default value: 120

The **high** parameter specifies the upper threshold at which point the WorldPhone ASD should issue an RNR (Receiver Not Ready) packet signalling that it is not ready to receive any more data from Net service provider:

Valid value: 1-512

Default value: 240

*Note!* The high value must be larger than the low value. When the high value is omitted, it becomes low value + 120.

## Appendix D – AT commands cont'd

`AT+W S45=[n]␣R`

sets the requested satellite and terrestrial error correction scheme for data calls.

`AT+W S45 ?␣R`

displays current setting.

`AT+W S45 = ?␣R`

displays available setting.

Parameter reference number

Default

<i>n</i> :	Sat. err.corr.	Terr. err.corr.	End-to-end
<b>0</b>	non-ARQ	non-V.42	NARQ
<b>1</b>	ARQ	V.42	ARQ
<b>200</b>	non-ARQ	V.42	NARQ
<b>201</b>	ARQ	non-V.42	NARQ

`AT+W S46 ?␣R`

shows that the Inmarsat Mini-M ASD standard is to be used for data communication. This is fixed and may not be changed.

`AT+W T N I D = [<nnn>]␣R` sets the terrestrial network for the next outgoing data call.

`AT+W T N I D ?␣R`

displays selected TNID.

`AT+W T N I D = ?␣R`

displays available TNIDs.

The parameter **nnn** specifies the terrestrial network ID. If omitted, it is set to **000**.

Range = 0 - 255

**nnn** = 000, terrestrial network unspecified.

## Appendix D – AT commands cont'd

**AT** **+** **WTTTL** **=** [**<low>**] [**,<high>**] **↵** **R** sets the lower and upper threshold level in bytes of the buffer used in the **WorldPhone-to-Net** service provider direction (**WorldPhone transmit buffer**).

**AT** **+** **WTTTL** **?** **↵** **R**  
displays selected threshold levels.

**AT** **WTTTL** **=** **?** **↵** **R**  
displays available threshold levels.

The **low** parameter specifies the lower threshold at which point the WorldPhone ASD should issue an XON, or raise the CTS line signalling that it is ready to receive data from the PC:

Valid value: 0-511

Default value: 120

The **high** parameter specifies the upper threshold at which point the WorldPhone ASD should issue an XOFF, or lower the CTS line signalling that it is not ready to receive data from the PC:

Valid value: 1-512

Default value: 240

*Note! The high value must be larger than the low value. When the high value is omitted, it becomes low value + 120.*

**AT** **+** **WXR** **=** [**n**] **↵** **R**  
determines the format of a **CONNECT** response from the **WorldPhone ASD**.

**AT** **+** **WXR** **?** **↵** **R**  
displays selected format.

**AT** **+** **WXR** **=** **?** **↵** **R**  
displays available formats.

Format reference number **n** :

**0** = **CONNECT** <see below\* >

## Appendix D – AT commands cont'd

**1** = +WXSr:<satellite rate>,<ARQ I NARQ>  
+WXTR:<terrestrial rate>,<ARQ I NARQ>  
+WXKR:<ARQ window size>  
CONNECT <PC-WP rate>

*Default* **2** = CONNECT <see below\* >,<ARQ I NARQ>  
**3** = CONNECT <ARQ I NARQ>

\* *The lowest value of PC-WP rate, satellite rate and terrestrial rate.*

### S-Register commands

S-registers are special memory locations in the WorldPhone for storing specific configuration and operating parameters.

`AT S0=[n] JR`

*specifies automatic answer at the  $n^{\text{th}}$  ring.  
0=OFF, 1-255=ON.*

`AT S0=<n> JR`

*sets value of register.*

`AT S0? JR`

*displays current value of register.*

*Default* `AT S0=0 JR` turns automatic answer **OFF**.

`AT S0=1 JR` answers after 1 ring.

*the WorldPhone ASD will terminate incoming calls after 95 secs.*

`AT S2=[n] JR`

*stores the ASCII decimal code for the escape character.  
Authorized codes within: 0 to 255.  
 $n \geq 128$  disables the escape sequence.*

`AT S2=<n> JR`

*sets value of register.*

`AT S2? JR`

*displays current value of register.*

*Default* `AT S2=43 JR` sets the ESCAPE code to **43** (+-key).

`AT S3=[n] JR`

*stores the ASCII decimal code for the carriage return character. Authorized codes within: 0 to 127.*

`AT S3=<n> JR`

*sets value of register.*

`AT S3? JR`

*displays current value of register.*

## Appendix D – AT commands cont'd

*Default*     `AT S3 =13 CR` sets the CARRIAGE RETURN code to **13** (`CR`-key).

`AT S4 =[n] CR`

*stores the ASCII decimal code for the line feed character. Authorized codes: 0 to 127.*

`AT S4 =<n> CR`

*sets value of register.*

`AT S4 ? CR`

*displays current value of register.*

*Default*     `AT S4 =10 CR` sets the LINE FEED code to **10**.

`AT S5 =[n] CR`

*stores the ASCII decimal code for the editing character. Authorized codes: 0 to 127.*

`AT S5 =<n> CR`

*sets value of register.*

`AT S5 ? CR`

*displays current value of register.*

*Default*     `AT S5 =8 CR` sets the BACK SPACE code to **8**.

`AT S25 =[n] CR`

*sets delay before examining DTR (108/2) after dialing and when online with a WorldPhone-to-Net call.*

*Range: 0-255 hundredths of a second.*

`AT S25 =<n> CR`

*sets delay value.*

`AT S25 ? ; CR`

*displays current delay value.*

*Default*     `AT S25 =5 CR` sets delay to **5** (corresponding to 50 milliseconds).




### Pin assignments

Pin number	Mnemonic	Circuit	DIN	CCITT circuit	Signal source	Description
1	CD			109	DCE	Carrier detect
2	RXD	BB	D1	104	DTE	Received Data
3	TXD	BA	D2	103	DCE	Transmitted Data
4	DTR			108	DTE	Data terminal ready
5	GND			102		Signal ground
6	DSR			107	DCE	Data set ready
7	RTS	CA	S2	105	DTE	Request To Send
8	CTS	CB	M2	106	DCE	Clear To Send
9	RI			125	DCE	Ring indicator

Signal source DTE means the signal goes from the PC to the WorldPhone.

Signal source DCE means the signal goes from the WorldPhone to the PC.



### *Signal descriptions*

**102 Signal Ground**

Digital ground, return line.

**103 Send Data**

Data transmitted from DTE (PC) to DCE (WorldPhone).

**104 Receive data**

Data Received from DCE (WorldPhone) to DTE (PC).

**105 Request To Send**

OFF requests DCE (WorldPhone) to suspend transmission to DTE (PC).  
ON requests DCE (WorldPhone) to resume transmission to DTE (PC).

**106 Clear to send**

OFF indicates that DCE (WorldPhone) cannot accept data from DTE (PC).  
ON indicates that DCE (WorldPhone) is prepared to accept data from DTE (PC).

**107 Data Set Ready**

Signal from WorldPhone that when ON indicates that a data call setup is in progress.

**108 Data Terminal Ready**

Signal from PC. This signal is used in the Hotline mode and indicate when going from OFF to ON that the PC wants to make a data call. The PC clears the call by setting the signal from ON to OFF.

**109 Receive Signal Indicator**

Signal from WorldPhone that when ON indicates that connection is established and received data will be delivered on circuit 104, Received Data.

**125 Ring Indicator**

Signal from WorldPhone. This signal is used in the Auto answer OFF mode and when ON indicates that an incoming call is in progress. The signal will go OFF when the call is answered by the PC by turning circuit 108 Data Terminal Ready ON.

## General

The WorldPhone can be programmed to allow operation of encrypted speech through the TEL port and the FAX port when this is configured for voice service. *Settings can only be made in Owner level.*


The STU IIB/III is *enabled as default* on ports configured for voice service.

## STU enabling/disabling

**1** Press the **Menu** function


key and scroll down to

**Advanced functions:**




**2** Press **Select** or **right arrow** and scroll down to


**Configuration:**



**3** **Select** or **right arrow** opens the **Configuration menu:**




**4** Pressing **Select** or **right arrow** again displays which ports are enabled/disabled for use with secure voice:




**5** Press **Edit** or **right arrow** for enabling/disabling secure voice.

Scroll up/down and press **Select** at wanted mode:



**6** Repeat steps 4 and 5 to select mode for fax port:




Secure voice

# Appendix E – Aero functions (option)


## Magnetometer calibration

**1** Press the **Menu** function and scroll down to


**Advanced functions:**



**2** **Select** or **right arrow** opens the **Advanced functions menu:**




**3** Scroll down to **Aero functions** and press **Select** or **right arrow** to open the **Aero functions window:**



**4** **Select** or **right arrow** opens the **Magnetometer calibration window:**

**Start** initiates calibration.


**Abort** stops the procedure.



## Configure landing speed

**5** Scroll down in the menu and press **Select** or **right arrow** to open the **Configure landing speed window:**

Key in anticipated speed.




## Satellite locations

**6** Scroll down in the menu and press **Select** or **right arrow** to open the **Satellite locations window:**


**Prev/Next** lists the position of available satellite regions.

(For possible new satellites, key in position and scroll down to select location)



# Appendix F – Character map


## Latin languages

	Key strokes: 1	2	3	4	5	6	7	8	9	10	11	12
Lower case 	1/?	!	/	?	ı	ı	ı					
UPPER CASE		!	/	?	ı	ı	ı					
2abc	a	b	c	à	á	â	ã	ä	å	æ	ç	2
	A	B	C	À	Á	Â	Ã	Ä	Å	Æ	Ç	2
3def	d	e	f	ð	è	é	ê	ë	3			
	D	E	F	Ð	È	É	Ê	Ë	3			
4ghi	g	h	i	ì	í	î	ï	4				
	G	H	I	Ì	Í	Î	Ï	4				
5jkl	j	k	l	5								
	J	K	L	5								
6mno	m	n	o	ñ	ò	ó	ô	õ	ö	ø	6	
	M	N	O	Ñ	Ò	Ó	Ô	Õ	Ö	Ø	6	
7pqr	p	q	r	þ	7							
	P	Q	R	Þ	7							
8stu	s	t	u	ß	ù	ú	û	ü	8			
	S	T	U	Ù	Ú	Û	Ü	8				
9vwX	v	w	x	9								
	V	W	X	9								
*	.	,	(	*								
	.	,	(	*								
0yz	y	z	@	ý	0							
	Y	Z	@	Ý	0							
#		-	+	)	#							
Space		-	+	)	#							

# Appendix F – Character map cont'd

## Cyrillic

Key strokes: 1 2 3 4 5 6 7 8 9 10 11 12

Lower case 

1!/? ! / ? i z 1

UPPER CASE

2abc А Б В 2

3def Г Д Е 3

4ghi Ж З И 4

5jkl Й К Л 5

6mno М Н О 6

7pqr П Р С 7

8stu Т У Ф 8

9vwx Х Ц Ч Ш Щ 9

\* . , ( \*

0yz Ъ Ы Ь Э Ю Я @ 0

# | - + ) #

Space

**AOR-E** Atlantic Ocean Region East, *see map in appendix H.*

**AOR-W** Atlantic Ocean Region West, *see map in appendix H.*

**ARQ** automatic repeat request, protocol for error detection and automatic retransmission of defective blocks of data.

**ASD** asynchronous data transmission

**ASD function/service** the built-in capability of the WorldPhone for asynchronous data transmission.

**AT command** used to control modem functions from the PC keyboard (ATtention).

**AT modem** the built-in modem of the WorldPhone that performs the modulation and demodulation required for data communication.

**Azimuth** horizontal direction angle between north and, e.g. the direction to the satellite.

**Bit rate** the number of bits transmitted per second (bps).

**Bps** Bits per second

**CHV2** higher access level on the SIM card, corresponding to WorldPhone "owner" level.

**DC** Direct Current

**DCE** data circuit terminal equipment

**Deg** degrees

**DTE** data terminal equipment

**DTMF** Dual-Tone Multifrequency Dialing, pulsing in which each digit is represented by a specific pair of audio frequencies (one tone below 1000 Hz and another above 1200 Hz).

**Elevation** vertical angle to the satellite, e.g. the height of the satellite above the horizon.

**FWD ID** forward Id, telephone network identity

**IMN** Inmarsat Mobile Number, a unique 9-digit number which identifies each port of the WorldPhone.

**Inmarsat** International Maritime Satellite Organisation.

**IOR** Indian Ocean Region, *see map in appendix H.*

**ISN** Inmarsat Serial Number, individual number assigned to each WorldPhone terminal.

**ISP** Inmarsat Service Provider

**Kbps** Kilobits per second

## Appendix G – List of terms cont'd

**LES** Land Earth Station, a station that interconnects fixed telecommunications networks with the Inmarsat system; may also be called a CES (Coast Earth Station) or a GES (Ground Earth Station).

**MES** Mobile Earth Station, a user terminal for an Inmarsat system; the WorldPhone terminal is an MES for the Inmarsat Mini-M system; MES may also be called SES (Ship Earth Station) or, if on aircraft, AES (Aeronautical Earth Station).

**NCS** Network Coordination Station, station that supervises all messages and signals sent in the Inmarsat system; one in each Ocean Region.

**NIMS** Nera Internet Messages Service, allows a message of maximum 1024 characters to be sent to the WorldPhone from a website, or to an e-mail address from the WorldPhone.

**Non-ARQ** non-automatic repeat request, see ARQ

**Ocean Region** the coverage area of an Inmarsat satellite within which the WorldPhone may communicate, [see map in appendix H](#).

**PABX** private automatic branch exchange

**PCCA** Portable Computer & Communications Association Modem Standards Committee.

**PIN** Personal Identification Number

**POR** Pacific Ocean Region, [see map in appendix H](#).

**PUK** Personal Unblocking Key, code that allows unblocking a SIM card.

**RF** Radio Frequency

**RNR** Receiver Not Ready data signal

**RR** Receiver Ready data signal

**S/A operator** StandAlone operator who maintains connectivity in the event of Network Coordinating Station failure.

**SIM** Subscriber Identity Module

**SMS** Short Message System

**Spot Beam** an Ocean Region is divided into sub-regions, each “spotlighted” by a beam from the region satellite.

**Terrestrial Network** a fixed telecommunications network, such as a telephone network or a data network, which connects to the Inmarsat system at an LES/NCS.

**TNID** Terrestrial Network Identification Digits

**UTC** Coordinated Universal Time, referenced to Greenwich Mean Time (GMT)




### *Inmarsat Mini-M system*

Inmarsat Mini-M is a satellite communications system that provides highly-reliable telephone, data and facsimile communication to and from mobile subscribers anywhere within the worldwide coverage area of the Inmarsat 3 Spot Beam system, *see map on next page*.

**NCS:** *Network Coordinating Station*

**LES:** *Land Earth Station  
(w/Net service providers)*

**MES:** *Mobile Earth Station  
(WorldPhone terminal)*



*Figure 1 Overview of the Inmarsat Mini-M system.*

## Appendix H – System description cont'd

### System satellites

The satellites are positioned in a geostationary orbit above the equator at approximately 35700 km altitude. See figure.

In geostationary orbit, each satellite moves at the same rate as the earth, and so remains in the same relative position to the earth.

The satellites cover approximately 1/4 of the earth each, called Ocean Regions:

- AOR-W** Atlantic Ocean West Region
- AOR-E** Atlantic Ocean East Region
- IOR** Indian Ocean Region
- POR** Pacific Ocean Region





Figure 2  
Satellite positions

The coverage area of the satellites for WorldPhone (Mini-M) is shown on the map below. Communication is possible in areas marked with grey.



### General

The WorldPhone terminal provides direct telephony, telefax, NIMS and data connection to international public networks via the Inmarsat 3 Spot Beam satellite system.

The WorldPhone terminal consists of:

- Telephone Unit (TPU).
- Universal AC adapter (WorldPhone Portable only).
- Antenna Unit (AU) including RF transceiver.
- Power Supply (WorldPhone Marine and Voyager only).

The operating functions are conducted on the telephone panel. Only a single coax cable links the Telephone Unit and the Antenna.

### Net service provider

The Net service provider issues your user licence and an IMN (Inmarsat Mobile Number) phone number. It is also responsible for the billing of calls (charges).

To make an outgoing call, you use a standard international telephone number with the 00 prefix. The WorldPhone terminal receives incoming calls via the IMN phone number.




Figure 3 Communication path.

### ***Calls from Mobiles***

To make an outgoing call, you use a standard international telephone number with the 00 prefix. The mobile automatically includes information to identify the MES and the particular port that originates the call.

The WorldPhone has four ports: the basic Telephone Unit w/handset, and three connectors that are configured for telephone, data and telefax.

The LES uses the end terminal identifying information (OI) for billing purposes.

The mobile transmits the dialing information on a channel specially assigned by the NCS, to the LES, which also has been instructed to tune to the same channel. LES routes the call over the public telecommunications networks to the intended destination. When the called party responds, the call proceeds.

### ***Calls to Mobiles***

The WorldPhone terminal receives incoming calls via the IMN phone numbers. IMN numbers are assigned to the following ports:

- *Basic Telephone Unit (handset)*
- *Telephone (TEL port)*
- *Telefax service (FAX port)*
- *Data service (DATA port)*
- *NIMS service*

Calls are made as ordinary international (Satellite) calls where each Ocean Region has an international country code. If an area is covered by more than one satellite, it is necessary that the caller knows which satellite (Ocean Region) the mobile is tuned to, or if not known try the other satellite(s).

The international codes to the four Ocean Regions are as follows:

- *Atlantic Ocean East Region: 871*
- *Pacific Ocean Region: 872*
- *Indian Ocean Region: 873*
- *Atlantic Ocean West Region: 874*

*Note! Some Net service providers support the common Ocean Region access no. 870, which connects the call to the dialed WorldPhone regardless of the Ocean Region the user currently communicates through.*

### ***Services***

- Telephone calls – basic telephony services.
- Telefax – CCITT Group 3 facsimile services, 2.4 kbps.
- Data communication – Hayes compatible 2.4 kbps data service.
- Mail service – NIMS

### 1. *The WorldPhone display does not light up:*

*Portable/Provident:*

- Is the Telephone Unit turned on?  
Press the ON/OFF key for 2 seconds.
- Does the battery need recharging? If needed, connect the universal adapter for powering/charging.
- Is the battery inserted properly, or contacts dirty or damaged?  
Check the battery (accessible underneath the telephone unit).

*Marine/Voyager:*

- Is the Power Supply turned on?
- Is the Telephone Unit turned on?  
Press the ON/OFF key for 2 seconds.
- Is the Power Supply properly connected?

### 2. *The access PIN code appears to be invalid:*

- The code may have been changed. The access Phone PIN is reset to default by logging in as owner:

\* + owner's password

*Note! The SIM card can only be unblocked using a PUK code (Pin Unblock Key). Contact the agent.*

### 3. *The WorldPhone cannot find the satellite:*

- Check for correct position of the antenna. Check that no obstacles block the free sight to the satellite.  
Be aware that a window glass may reduce the signal level significantly. The signal strength indicator should preferably exceed 415.
- Check that the coax cable is connected properly.
- If accessible, try another antenna unit.
- The warning "Not available" appears in the display.  
To restore communication with the satellite,  
see chapter 2. Operation: **Advanced functions: Information available: Oscillator compensation.**

### 4. *The WorldPhone functions abnormally:*

- Turn off power and disconnect power cable/battery.
- Connect power cable/battery, and switch on again.

### 5. *Unsuccessful call attempt:*

- The called party is busy ("Subscriber busy" appears on the display).
- Call the Net service provider. If unsuccessful, wait for some time and try again.
- The WorldPhone is not properly commissioned. Check with the Net service provider.

### 6. *Problems with telefax:*

- Remember to press "#" as last digit before starting transmission.
- Verify that the service is commissioned, *see step 5*.
- Connect an external standard telephone to the FAX port and verify that you have a dial tone.
- Be aware of system transmission delays. The OFF-HOOK time should therefore be as long as possible (e.g. 2 minutes). When the fax machine is called, ringing time should be set to minimum (e.g. immediate answer).
- Try a different fax machine.
- Check that the port is configured for telefax service (and not voice), *see chapter 2. Operation: **Advanced functions: Configuration***.

### 7. *Problems with data communication:*

- Verify correct bit rate on PC and telephone unit, *see chapter 2. Operation: **Data/printer port setup***.
- Try to connect to the server through a terminal emulator.
- Check the PC program settings, and if necessary extend the timeout intervals.
- Contact the PC applications vendor for help.

**A**

Above Deck Equipment 1.12, 1.13  
 Access  
   code 2.44  
   control 2.49, 2.50  
   level 2.13, 2.20  
 Adapter 1.6, 2.26, C-1  
 ADE  
   Above Deck Equipment 1.12, 1.13  
 Advanced functions 2.13, 2.43  
 Aero functions E-2  
   configure landing speed E-2  
   magnetometer calibration E-2  
   satellite locations E-2  
 Allowed SIM 2.49  
 Answer call 2.10, 2.11, 2.12  
 Antenna 1.6, 1.10  
   coax cable 1.6  
   connector 1.6  
 Antenna Unit  
   location B-1  
   Marine B-1, B-16  
   mounting B-4, B-6, B-11, B-12, B-13  
   Voyager B-9  
 Apnd 2.15, 2.16  
 Arrow keys 1.6  
 AT commands D-1  
 AT modem 2.24  
 Azimuth G-1

**B**

Bag w/antenna cable 1.6  
 Battery 1.7  
   charging C-1, C-2  
   indicator 1.7  
   pack 2.26, C-2, C-3  
   replacement C-2, C-3  
 Baud rate 2.23, 4.2  
 BDE  
   Below Deck Equipment 1.12, 1.13  
 Bit rate 2.23, 4.1  
 Book 2.3, 2.13  
 Brightness 2.27  
 Buying more time 2.38

**C**

Cable  
   coax 1.6  
 Call 2.15, 2.16  
   charge 2.33  
   country codes A-2  
   data 2.10, D-1  
   explanation A-1

fax 2.10, 3.2  
 from telephone 2.8  
 from/to mobiles H-4  
 making a call 2.2  
 receiving 2.10, 2.11, 2.12  
 service address codes A-5  
 to WorldPhone 2.3  
 voice 2.2

**Calls**

  service 2.9  
 Case lock 1.6  
 Character map F-1, F-2  
 Charge tone 2.58  
 Charger C-2  
 Charging C-1, C-2  
 CHV2 2.13, 2.20, G-1  
 Clear 2.3  
 Coax cable 1.6, B-2, B-3, B-9, B-10, B-16  
 Compass 1.6  
 Compass safe distance B-1  
 Configuration 2.43, 2.53  
 Connecting up  
   Marine Antenna B-3  
   optional equipment B-21, B-22  
   Voyager Antenna B-10  
 Connector panel 1.6  
 Contrast 2.27  
 Country codes A-1, H-4

**D**

Data 1.5  
   bits 2.23  
   networks 1.1  
   service 2.10, 4.3  
 DATA connector 1.6, 4.1  
 Data/printer port setup 2.13, 2.23  
 Date and time 2.28  
 Default Net service provider 2.13, 2.19  
 Del 2.2  
 Diagnostics 2.55  
 Dimensions B-8, B-14, B-15, B-20  
 Display 1.6  
   contrast 2.27  
 DTE interface D-17, D-18  
 DTMF telephone  
   call from 2.8

**E**

Editing entry in phone book 2.17  
 Elevation G-1  
 Eng(lish)-key 2.31  
 Equipment 1.1  
 Erase 2.15  
 Escape 2.2

# Index

## F

Facsimile 1.1  
Fax call 2.10  
FAX connector 1.6, 3.1  
Flat antenna 1.6  
Forward ID 2.59  
Function keys 1.6  
Functions 2.13  
    overview 2.14  
FWD 2.60, G-1

## G

Geostationary orbit H-2

## H

Handset 1.6  
Handsfree 2.2, 2.3  
Help 2.1  
HELP key 1.6, 2.1  
Hot dial 2.25

## I

IMN  
    Inmarsat Mobile Number 2.59, G-1  
In box 2.11  
Incoming call 2.10  
Information available 2.59, 2.60  
Inmarsat G-1  
    Mini-M system H-1  
Installation  
    Marine Antenna B-1, B-16  
    Voyager Antenna B-9  
Interference B-2  
Internal battery 1.7, C-1, C-2, C-3  
International  
    codes A-2, H-4  
    dial-up telephone 1.1  
Internet message 2.11  
ISN G-1

## K

Key lock 2.18, 2.29  
Keypad 1.6

## L

Land Earth Station, LES  
    description G-2  
Language 2.30  
    reset 2.31  
    setup 2.30  
Last number  
    list 1.4, 2.15  
    redialing 2.13, 2.15

Letters 2.1  
Level  
    CHV2 2.20, G-1  
    owner 2.22  
    user 2.13, 2.20  
Lock 2.18, 2.29  
Loudspeaker 1.6  
Lowercase 2.48, 2.61

## M

Mail 1.4, 2.11  
Mailbox access numbers 2.32  
Making a call 2.2  
Menu 2.3, 2.13  
MES  
    description G-2  
Mobile Earth Station G-2  
Mobile-to-LES Call H-4  
Modem 4.1  
Mounting  
    Antenna Unit B-4, B-6, B-11, B-12, B-13  
    Power Supply B-5, B-7, B-14  
Mute 1.11, 1.14

## N

Net service  
    provider 1.4, 2.5, 2.19, 2.52, 2.54, 2.56, H-3  
Network 1.1  
Network status 2.60  
NIMS 1.4, 2.11  
    mail service 1.4  
Numbers. See *IMN numbers*

## O

Ocean Region 2.19, 2.52  
    codes H-4  
ON/OFF key 1.6  
Oscillator compensation 2.60  
Out box 2.6  
Owner  
    access 2.13  
    level 2.20  
    level password 2.22  
    setting level 2.22

## P

Paid functions 2.61  
Parity 2.23  
Password 2.21, 2.22  
PCCA D-9, G-2  
Phone  
    name setup 2.61  
    setup 2.13, 2.26



Phone book 1.4, 2.16, 2.17  
 new entry 2.16  
 PIN code 1.4, 2.1, 2.20  
 Port configuration 2.53  
 Power  
   conservation 2.55  
   reduction 2.55  
   Supply B-2, B-9  
 Precharge 2.37  
   on SIM card 2.42  
 Printer 2.23

## R

Radiation precautions B-1  
 Receiving a call 2.10  
 Redialing 2.15  
 Reply 2.12  
 Restricted  
   dialing 2.44  
   SIM 2.49  
 RF transceiver 1.6  
 Ringing volume 2.27

## S

Satellite  
   altitude H-2  
   coverage H-2  
   find 2.13  
   geostationary positions H-2  
   Ocean Region 2.19  
   positions H-2  
   setup 2.52  
 Secure voice E-1, F-1  
 Seek 2.13  
 Sending NIMS message 2.6  
 Service  
   address codes A-5  
   calls 2.9  
 Services  
   list of H-4  
 Set diagnostics 2.55  
 Setting  
   date and time 2.28, 2.29, 2.32  
   key lock 2.29  
 Short number 2.16  
 SIM  
   card 1.4, 1.6, 1.9, 2.44, 2.56  
   restrictions 2.49, 2.51

Spot beam  
   term G-2  
 Stand Alone operator 2.56, G-2  
 Stop bit 2.23  
 STU E-1  
 System  
   description H-1  
   information 2.55, 2.59, 2.60  
   satellites H-2

## T

TEL 1.6  
 Telefax  
   service 2.10, 3.1  
 Telephone  
   handset 1.6  
   keypad 1.6  
   lock 1.6  
   unit B-2, B-9  
 Terms  
   list of G-1  
 Terrestrial network 2.5, 2.9, 2.52  
 Text message 1.4, 2.11  
 Time 2.28. *See also Date and time*  
 TNID G-2  
 Traffic log 2.34  
 Transceiver 1.6, 1.12, 1.13  
 Transmission rate  
   data 1.5, 4.1  
   telefax 1.5, 3.1

## U

Universal AC adapter 1.6  
 Uppercase 2.48, 2.61  
 User  
   access 2.13  
   level 2.20

## V

Volume 2.2, 2.3, 2.27

## W

WorldPhone  
   Voyager 1.16



## LIMITED WARRANTY

This product is a radio transmitting and receiving device. It is the responsibility of the user to insure that they are meeting all local regulatory requirements which vary from country to country.

### 1. MAGELLAN SYSTEMS CORPORATION LIMITED WARRANTY

Magellan Systems Corporation warrants this product and accessories to be free of defects in material and workmanship for a period of one year from the date of original purchase. This warranty applies only to the original purchaser of this product.

In the event of a defect, Magellan Systems Corporation will, at its option, repair or replace the product with no charge to the purchaser for parts or labor. The repaired or replaced product will be warranted for ninety (90) days from the date of return shipment, or for the balance of the original warranty, whichever is longer.

### 2. PURCHASER'S REMEDY

Purchaser's Exclusive Remedy under this warranty or any implied warranty shall be limited to the repair or replacement, at Magellan Systems Corporation's option, of any defective part of the product or accessories which are covered by this warranty. Repairs under this warranty shall only be made at an authorized Magellan Service Center.

### 3. PURCHASER'S DUTIES

To obtain warranty service, the purchaser must return the product or accessories postpaid, with proof of the date of original purchase, nature of defect, and purchaser's return address to Magellan Authorized Service Centers.

Magellan Systems Corporation will not be responsible for losses or damage to the product incurred while the product is in transit or is being shipped for repair. Insurance is recommended.

### 4. LIMITATION OF IMPLIED WARRANTIES

Except as set forth in item 1 above, all other expressed or implied warranties, including those of fitness for any particular purpose and merchantability, are hereby disclaimed.

Some states do not allow limitations on warranties, so the above limitation may not apply.

### 5. EXCLUSIONS

This warranty does not cover the following:

- Installation
- Batteries
- Finishes
- Defects resulting from installation
- Any damage, loss, liability or expense resulting from unavailability, delay, interruption, disruption or degradation of the communication service.
- Any damage due to shipping, misuse, negligence, tampering or improper use.
- Servicing performed or attempted by anyone other than an Authorized Magellan Service Center representative.

Opening of this product by anyone other than an Authorized Magellan Service Center representative will void this warranty.

### 6. EXCLUSION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES

Magellan Systems Corporation shall not be liable to purchaser or any other person for any incidental, special, indirect, or consequential damages whatsoever, including but not limited to lost profits, damages resulting from delay or loss of use, loss or damages arising out of the use or inability to use this product, or breach of this warranty even though caused by negligence or other fault. In no event will Magellan Systems Corporation be responsible for such damages, even if Magellan Systems Corporation has been advised of the possibility of such damages.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

### 7. MERGER

This written warranty is the complete, final, and exclusive agreement between Magellan Systems Corporation and the purchaser with respect to the quality of performance of all the goods and any and all warranties and representations. This warranty sets forth all of Magellan Systems Corporation's responsibilities regarding this product.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

### 8. FOR PURCHASERS OUTSIDE OF THE UNITED STATES

This warranty gives you specific rights. You may have other rights which vary from province to province and certain limitations contained in this limited warranty may not apply to you.

If you purchased this product outside of the United States, this limited warranty is governed by the laws of the State of California and shall benefit Magellan Systems Corporation, its successors, and assigns.

For further information concerning this limited warranty, please call or write: Magellan Systems Corporation, 960 Overland Court, San Dimas, California 91773, Phone: 909-394-5000 FAX: 909-394-7050

MAGELLAN SYSTEMS CORPORATION ASSUMES NO LIABILITY FOR ANY CRIMINAL/CIVIL PENALTIES RESULTING FROM ILLEGAL USE OF THIS GLOBAL SATELLITE TELEPHONE.

148 x 195 mm



960 Overland Court  
San Dimas, CA 91773  
Phone (909) 394-5000, Fax (909) 394-7050

P/N# 22-80048-000

Doc. No. QLZB911084-3 Rev. B Copytema 05/99

**Orbital**  
*An Orbital Company*