



# **SuperStack® 3**

## Switch 4400 Series

### Getting Started Guide

Switch 4400 (3C17203)  
Switch 4400 (3C17204)  
Switch 4400 PWR (3C17205)  
Switch 4400 SE (3C17206)  
Switch 4400 FX (3C17210)

<http://www.3com.com/>

Part No. DUA1720-3AAA07  
Published March 2004



**3Com Corporation**  
**350 Campus Drive**  
**Marlborough,**  
**MA 01752-3064**

Copyright © 2004, 3Com Corporation. All rights reserved. No part of this documentation may be reproduced in any form or by any means or used to make any derivative work (such as translation, transformation, or adaptation) without written permission from 3Com Corporation.

3Com Corporation reserves the right to revise this documentation and to make changes in content from time to time without obligation on the part of 3Com Corporation to provide notification of such revision or change.

3Com Corporation provides this documentation without warranty, term, or condition of any kind, either implied or expressed, including, but not limited to, the implied warranties, terms or conditions of merchantability, satisfactory quality, and fitness for a particular purpose. 3Com may make improvements or changes in the product(s) and/or the program(s) described in this documentation at any time.

If there is any software on removable media described in this documentation, it is furnished under a license agreement included with the product as a separate document, in the hard copy documentation, or on the removable media in a directory file named LICENSE.TXT or !LICENSE.TXT. If you are unable to locate a copy, please contact 3Com and a copy will be provided to you.

#### **UNITED STATES GOVERNMENT LEGEND**

*If you are a United States government agency, then this documentation and the software described herein are provided to you subject to the following:*

All technical data and computer software are commercial in nature and developed solely at private expense. Software is delivered as "Commercial Computer Software" as defined in DFARS 252.227-7014 (June 1995) or as a "commercial item" as defined in FAR 2.101(a) and as such is provided with only such rights as are provided in 3Com's standard commercial license for the Software. Technical data is provided with limited rights only as provided in DFARS 252.227-7015 (Nov 1995) or FAR 52.227-14 (June 1987), whichever is applicable. You agree not to remove or deface any portion of any legend provided on any licensed program or documentation contained in, or delivered to you in conjunction with, this User Guide.

Unless otherwise indicated, 3Com registered trademarks are registered in the United States and may or may not be registered in other countries.

3Com, the 3Com logo and SuperStack are registered trademarks of 3Com Corporation.

Intel and Pentium are registered trademarks of Intel Corporation. Microsoft, MS-DOS, Windows, and Windows NT are registered trademarks of Microsoft Corporation. Novell and NetWare are registered trademarks of Novell, Inc. UNIX is a registered trademark in the United States and other countries, licensed exclusively through X/Open Company, Ltd.

IEEE and 802 are registered trademarks of the Institute of Electrical and Electronics Engineers, Inc.

Netscape Navigator is a registered trademark of Netscape Communications.

JavaScript is a trademark of Sun Microsystems.

All other company and product names may be trademarks of the respective companies with which they are associated.

#### **ENVIRONMENTAL STATEMENT**

It is the policy of 3Com Corporation to be environmentally-friendly in all operations. To uphold our policy, we are committed to:

Establishing environmental performance standards that comply with national legislation and regulations.

Conserving energy, materials and natural resources in all operations.

Reducing the waste generated by all operations. Ensuring that all waste conforms to recognized environmental standards. Maximizing the recyclable and reusable content of all products.

Ensuring that all products can be recycled, reused and disposed of safely.

Ensuring that all products are labelled according to recognized environmental standards.

Improving our environmental record on a continual basis.

#### **End of Life Statement**

3Com processes allow for the recovery, reclamation and safe disposal of all end-of-life electronic components.

#### **Regulated Materials Statement**

3Com products do not contain any hazardous or ozone-depleting material.

#### **Environmental Statement about the Documentation**

The documentation for this product is printed on paper that comes from sustainable, managed forests; it is fully biodegradable and recyclable, and is completely chlorine-free. The varnish is environmentally-friendly, and the inks are vegetable-based with a low heavy-metal content.

#### **ENCRYPTION**

This product contains encryption and may require U.S. and/or local government authorization prior to export or import to another country.

# CONTENTS

---

## ABOUT THIS GUIDE

Before You Start	7
Release Notes	7
About Your CD-ROM	8
Conventions	8
Related Documentation	9
Accessing Online Documentation	10
Documentation Comments	10
Product Registration	11

---

## 1 INTRODUCING THE SUPERSTACK 3 SWITCH 4400

About the Switch 4400	14
Summary of Hardware Features	14
Switch 4400 — Front View Detail	15
10BASE-T/ 100BASE-TX Ports	16
100BASE-FX Ports	16
LEDs	17
Switch 4400 — Rear View Detail	19
Power Socket	19
Redundant Power System Socket	19
Console Port	19
Expansion Module Slots	19
Default Settings	20

---

## 2 INSTALLING THE SWITCH

Package Contents	24
Choosing a Suitable Site	24
Rack-mounting	25
Placing Units On Top of Each Other	27
Stacking Units	27

How To Stack Units	27
Rules For Stacking Units	28
The Power-up Sequence	30
Powering-up the Switch 4400	30
Checking for Correct Operation of LEDs	30
Connecting a Redundant Power System	30
Using Power over Ethernet	31
Choosing the Correct Cables (Switch 4400, 4400 SE and 4400 PWR)	32
Choosing the Correct Cables (Switch 4400 FX)	33

---

### **3 SETTING UP FOR MANAGEMENT**

Setting Up Overview	36
IP Configuration	37
Preparing for Management	38
Manually Configuring IP Information	39
Connecting to a Front Panel Port	39
Connecting to the Console Port	42
Viewing Automatically Configured IP Information	46
Using 3Com Network Supervisor	46
Connecting to the Console Port	46
Methods of Managing a Switch	49
Command Line Interface Management	49
Command Line Interface Management using SSH	50
Web Interface Management	50
SNMP Management	50
Setting Up Command Line Interface Management	50
CLI Management via the Console Port	51
CLI Management over the Network	51
Setting Up Command Line Interface Management using SSH	52
Setting Up Web Interface Management	53
Pre-requisites	53
Web Management Over the Network	54
Setting Up SNMP Management	54
Pre-requisites	55
Default Users and Passwords	55
Changing Default Passwords	55

---

## **4 PROBLEM SOLVING**

- Solving Problems Indicated by LEDs 58
- Solving Hardware Problems 59
- Solving Communication Problems 62
- Solving Software Upgrade Problems 63

---

## **A SAFETY INFORMATION**

- Power Cord Set — Japan 65
- Important Safety Information 66
- L'information de Sécurité Importante 68
- Wichtige Sicherheitsinformationen 70

---

## **B PIN-OUTS**

- Null Modem Cable 73
- PC-AT Serial Cable 73
- Modem Cable 74
- RJ-45 Pin Assignments 74

---

## **C TECHNICAL SPECIFICATIONS**

- Switch 4400 (24-port) and Switch 4400 SE 77
- Switch 4400 PWR (24-port) 79
- Switch 4400 (48-port) 80
- Switch 4400 FX 81

---

## **D OBTAINING SUPPORT FOR YOUR PRODUCT**

- Register Your Product to Gain Service Benefits 83
- Purchase Value-Added Services 83
- Troubleshoot Online 83
- Access Software Downloads 84
- Contact Us 84
- Telephone Technical Support and Repair 84

---

**INDEX**

---

**REGULATORY NOTICES**

# ABOUT THIS GUIDE

This guide provides all the information you need to install and use the following switches in their default state:

- SuperStack® 3 Switch 4400 (3C17203)
- SuperStack® 3 Switch 4400 (3C17204)
- SuperStack® 3 Switch 4400 PWR (3C17205)
- SuperStack® 3 Switch 4400 SE (3C17206)
- SuperStack® 3 Switch 4400 FX (3C17210)

All procedures described in this guide apply to all models except where stated.

The guide is intended for use by network administrators who are responsible for installing and setting up network equipment; consequently, it assumes a basic working knowledge of LANs (Local Area Networks).

---

## Before You Start

This section contains information about the documents and CD-ROM that accompany your Switch 4400.

## Release Notes

The Release Notes provide important information about the current software release, including new features, modifications, and known problems. You should read the Release Notes before installing the Switch in your network.



*If the information in the Release Notes differ from the information in this guide, follow the instructions in the Release Notes.*

**About Your CD-ROM**

The CD-ROM contains the following:

- Online documentation for the Switch 4400 — refer to Related Documentation on page 9 for details.
- 3Com Network Supervisor — a powerful and easy-to-use network management platform.
- A number of other useful applications.




Most user guides and release notes are available in Adobe Acrobat Reader Portable Document Format (PDF) or HTML on the 3Com World Wide Web site:

<http://www.3com.com/>

**Conventions**

Table 1 and Table 2 list conventions that are used throughout this guide.

**Table 1** Notice Icons

Icon	Notice Type	Description
	Information note	Information that describes important features or instructions
	Caution	Information that alerts you to potential loss of data or potential damage to an application, system, or device
	Warning	Information that alerts you to potential personal injury

**Table 2** Text Conventions

Convention	Description
Screen displays	This typeface represents information as it appears on the screen.
Syntax	The word “syntax” means that you must evaluate the syntax provided and then supply the appropriate values for the placeholders that appear in angle brackets. Example:  To change your password, use the following syntax: <pre>system password &lt;password&gt;</pre> In this example, you must supply a password for <password>.
Commands	The word “command” means that you must enter the command exactly as shown and then press Return or Enter. Commands appear in bold. Example:  To display port information, enter the following command: <pre><b>bridge port detail</b></pre>



**Table 2** Text Conventions (continued)

Convention	Description
The words "enter" and "type"	When you see the word "enter" in this guide, you must type something, and then press Return or Enter. Do not press Return or Enter when an instruction simply says "type."
Keyboard key names	If you must press two or more keys simultaneously, the key names are linked with a plus sign (+). Example:  Press Ctrl+Alt+Del
Words in <i>italics</i>	Italics are used to: <ul style="list-style-type: none"> <li>■ Emphasize a point.</li> <li>■ Denote a new term at the place where it is defined in the text.</li> <li>■ Identify menu names, menu commands, and software button names. Examples:  From the <i>Help</i> menu, select <i>Contents</i>.  Click <i>OK</i>.</li> </ul>

---

## Related Documentation

In addition to this guide, each Switch documentation set includes the following:

- *SuperStack 3 Switch Implementation Guide*

This guide contains information on the features supported by your Switch and how they can be used to optimize your network. It is supplied in PDF format on the CD-ROM that accompanies the Switch.

- *SuperStack 3 Switch Management Quick Reference Guide*

This guide contains:

- a list of the features supported by the Switch.
- a summary of the web interface and command line interface commands for the Switch.

- *SuperStack 3 Switch Management Interface Reference Guide*

This guide provides detailed information about the web interface and command line interface that enable you to manage the Switch. It is supplied in HTML format on the CD-ROM that accompanies the Switch.

- *Release Notes*

These notes provide information about the current software release, including new features, modifications, and known problems. The Release Notes are supplied in hard copy with your Switch.

There are other publications you may find useful, such as:

- Documentation accompanying the Advanced Redundant Power system.
- Documentation accompanying the Expansion Modules.
- Documentation accompanying 3Com Network Supervisor. This is supplied on the CD-ROM that accompanies the Switch.

### Accessing Online Documentation

To access the documentation on the CD-ROM supplied with your Switch, do the following:

- 1 Insert the CD-ROM into your CD-ROM drive. If your PC has auto-run enabled, a splash screen will be displayed automatically.
- 2 Select the Documentation section from the contents page.

If the online documentation is to be accessed from a local drive or server, you will need to access the CD-ROM contents via the root directory and copy the files from the CD-ROM to a suitable directory.

- The HTML Reference Guide is stored in the `Docs/reference` directory on the CD-ROM. The documentation is accessed using the `contents.htm` file.
- The PDF Implementation Guide is stored in the `Docs/implementation` directory of the CD-ROM.



*3Com recommends that you copy the `Docs/reference` directory as a whole to maintain the structure of the files.*

---

### Documentation Comments

Your suggestions are very important to us. They will help make our documentation more useful to you. Please e-mail comments about this document to 3Com at:

**[pddtechpubs\\_comments@3com.com](mailto:pddtechpubs_comments@3com.com)**

Please include the following information when commenting:

- Document title
- Document part number (on the title page)
- Page number (if appropriate)

Example:

Part Number DUA1720-3AAA07

SuperStack 3 Switch 4400 Series Getting Started Guide

Page 21



*Please note that we can only respond to comments and questions about 3Com product documentation at this e-mail address. Questions related to technical support or sales should be directed in the first instance to your network supplier.*

---

## **Product Registration**

You can now register your SuperStack 3 Switch on the 3Com web site to receive up-to-date information on your product:

**<http://www.3com.com/register>**



# 1

## INTRODUCING THE SUPERSTACK 3 SWITCH 4400

This chapter contains introductory information about the Switch 4400 and how it can be used in your network. It covers summaries of hardware and software features and also the following topics:

- About the Switch 4400
- Switch 4400 — Front View Detail
- Switch 4400 — Rear View Detail
- Default Settings

## About the Switch 4400

The Switch 4400 is a stackable 10/100 Mbps Ethernet switch and provides high-performance workgroups with a backbone to server connection. The Switch 4400 allows Cascade, Gigabit Ethernet or Fast Ethernet Fiber connections when expansion modules are installed in the expansion slots on the rear of the unit. You can also add the Switch 4400 to any SuperStack® system as your network grows.

The Switch 4400 PWR (3C17205) supports Power over Ethernet on all front panel ports. If you plug in a compatible (IEEE 802.3af compliant) device, it will be automatically detected and power supplied to it. Power over Ethernet is enabled on each port by default.

The Switch 4400 FX (3C17210) has 24 100BASE-FX MT-RJ ports. These allow easy connection of 100 Mbps fiber-optic links.

## Summary of Hardware Features


Table 3 summarizes the hardware features that are supported by the Switch 4400.

**Table 3** Hardware features


Feature	Switch 4400
<b>Addresses</b>	<ul style="list-style-type: none"> <li>■ Up to 8000 supported</li> <li>■ Up to 64 permanent entries</li> </ul>
<b>Auto-negotiation</b>	<ul style="list-style-type: none"> <li>■ Supported on all ports</li> <li>■ Auto MDI/MDI-X (not 3C17210)</li> </ul>
<b>Forwarding Modes</b>	Store and Forward
<b>Duplex Modes</b>	Half and full duplex on all front panel ports
<b>Flow Control</b>	In full duplex operation all ports are supported
<b>Smart Auto-sensing</b>	Supported on all ports
<b>Traffic Prioritization</b>	Supported (using the IEEE Std 802.ID, 1998 Edition): 4 queues per port
<b>Power over Ethernet</b>	Supported on all front panel ports (3C17205 only).
<b>Ethernet and Fast Ethernet Ports</b>	Auto-negotiating 10BASE-T/100BASE-TX ports or 100BASE-FX ports (3C17210)
<b>RPS Support</b>	Connects to SuperStack 3 Advanced Redundant Power System (ARPS) (3C16071B)
<b>Mounting</b>	19-inch rack or stand-alone mounting
<b>Stacking</b>	All Switch units in the stack can be managed as a single entity with one IP address

**Switch 4400 — Front View Detail**


**Figure 1** Switch 4400 FX — front view




**Figure 2** Switch 4400 (24-port) / Switch 4400 SE — front view



**Figure 3** Switch 4400 PWR — front view



**Figure 4** Switch 4400 (48-port) — front view



**WARNING:** RJ-45 Ports. These are shielded RJ-45 data sockets. They cannot be used as standard traditional telephone sockets, or to connect the unit to a traditional PBX or public telephone network. Only connect RJ-45 data connectors, network telephony systems, or network telephones to these sockets.

*Either shielded or unshielded data cables with shielded or unshielded jacks can be connected to these data sockets.*

**10BASE-T/  
100BASE-TX Ports**

The Switch 4400, 4400 SE and 4400 PWR have 24 or 48 auto-negotiating 10BASE-T/100BASE-TX ports configured as Auto MDIX (cross-over). These ports automatically provide the appropriate connection. Alternatively, you can manually set these ports to 10BASE-T half duplex, 10BASE-T full duplex, 100BASE-TX half duplex or 100BASE-TX full duplex. The maximum segment length is 100 m (328 ft) over Category 5 twisted pair cable.

The 4400 PWR will supply up to 15.4W of power through any of the 24 front panel ports in conformance to the 802.3af specification. The Switch 4400 PWR incorporates a LED Mode Button on the front panel, which when pressed changes the mode of the front panel port LEDs functionality between Switch and Power mode.

**100BASE-FX Ports**

The Switch 4400 FX has 24 100BASE-FX MT-RJ ports. These are 100 Mbps fiber-optic ports that can use standard multi-mode fiber-optic cable of up to 2 kilometers (1.2 miles). They use the standard MT-RJ



connector that allows both the transmit and the receive fibers to be connected in the same space as an RJ-45 port.


**LEDs** Table 4 lists LEDs visible on the front of the Switch, and how to read their status according to color. For information on using the LEDs for problem solving, see “Solving Problems Indicated by LEDs” on page 58.

**Table 4** LED behavior

LED	Color	Indicates
<b>Power/Self Test LED</b>		
	Green	The Switch is powered-up and operating normally.
	Green flashing	The Switch is either downloading software or is initializing (which includes running a Power On Self Test).
	Yellow	The Switch has failed its Power On Self Test or A port has failed and has been automatically disabled. You can verify this by checking that the Port Status LED is quickly flashing Yellow. If a port fails the Switch passes its Power On Self Test and continues to operate normally.
	Off	The Switch is not receiving power or there is a fault with the Power Supply Unit.
<b>Port LEDs</b>		
Packet	Green	Full duplex packets are being transmitted/received on the port.
	Yellow	Half duplex packets are being transmitted/received on the port.
	Off	No packets are being transmitted/received on the port.
Status	Green	A high speed (100 Mbps) link is present, and the port is enabled.
	Green flashing	A high speed (100 Mbps) link is present, but the port is disabled.
	Yellow	A low speed (10 Mbps) link is present, and the port is enabled (not 4400 FX).
	Yellow flashing	A low speed (10 Mbps) link is present, but the port is disabled (not 4400 FX).
	Yellow flashing (fast)	The port has failed and has been automatically disabled. The Switch passes its Power On Self Test and continues to operate normally even if one or more ports are disabled.
	Off	No link is present.

LED	Color	Indicates
<b>Port LEDs — Power over Ethernet mode (3C17205 only)</b>		
Packet	Green	Power is being delivered to the port.
	Green flashing	Exceeded port power limit (overCurrent MIB state) or unable to supply power due to unit over budget (denyLowPriority MIB state).
	Yellow	Power over Ethernet error, no power supplied on port.
	Off	No power is being delivered.
Status	Yellow flashing	Power over Ethernet POST error on port. Flash rate is 4 Hz
<b>Module LEDs</b>		
	Packet	Refer to the user documentation accompanying the module, if installed.
	Status	Refer to the user documentation accompanying the module, if installed.
	Off	There is no module installed in the expansion module slot.
	Yellow flashing (fast)	The module has failed and has been automatically disabled. The Switch passes its Power On Self Test and continues to operate normally even if one or more modules are disabled.
<b>Unit LEDs</b>		
1–8	Green	When the Switch forms a stack with other Switch 4400 units, the LED indicates the position of the unit in the stack and that a link is present.  When the Switch is stand-alone and not part of a stack, LED 1 is on.
	Green/Yellow rotational	When a software upgrade is in progress, the LEDs of the unit that is being upgraded 'rotate' in an clockwise and anti-clockwise sequence.
	Green flashing	The Switch physically forms a stack with other Switch 4400 units, but cannot be managed as part of that stack until all units have been upgraded to software version 2.0 or later.
	Off	A fault has occurred.
<b>Port LED Status LED (3C17205 only)</b>		
	Green	Port LEDs are operating in power mode
	Yellow flashing	Port LEDs are operating in normal mode. One or more ports has a Power over Ethernet error.
	Off	Port LEDs are operating in normal mode.
<b>Power Utilization LEDs (3C17205 only)</b>		
	Green	4 LEDs showing total power being delivered as a percentage of maximum possible.

**Switch 4400 — Rear View Detail**     **Figure 5** Switch 4400 (all models) — rear view



**Power Socket**     The Switch automatically adjusts its power setting to any supply voltage in the range 90-240 VAC.

**Redundant Power System Socket**     To protect against internal power supply failure, you can use this socket to connect a Switch 4400 to a SuperStack 3 Advanced Redundant Power System (RPS). See “Connecting a Redundant Power System” on page 30.

**Console Port**     The console port allows you to connect a terminal and perform remote or local out-of-band management. The console port uses a standard null modem cable and is set to auto-baud, 8 data bits, no parity and 1 stop bit.

**Expansion Module Slots**     You can use these slots to install Expansion Modules. These allow the Switch to support various forms of connection and add extra functionality to your Switch. For example you can install a Cascade module to enable the Switch to be stacked with other Switches. Please note that Power over Ethernet is not supported on expansion modules on the Switch 4400 PWR (3C17205). Contact your supplier for more information.



**WARNING:** When an Expansion Module is not installed, ensure the blanking plate is fitted by tightening all screws with a suitable tool.

## Default Settings

Table 5 shows the default settings for the Switch 4400:

**Table 5** Default Settings

Feature	Switch 4400
<b>Automatic IP Configuration</b>	Enabled
<b>Port Status</b>	Enabled
<b>Port Speed</b>	10/100 Mbps ports are auto-negotiated MT-RJ ports (3C17210) are fixed at 100 Mbps
<b>Duplex Mode</b>	All fixed 10BASE-T and 100BASE-TX ports are auto-negotiated  100BASE-FX ports default to full-duplex mode (100 FD) and must be manually set to half-duplex mode (100 HD) if required.
<b>Power over Ethernet</b>	Enabled (3C17205 only)
<b>Flow Control</b>	<ul style="list-style-type: none"> <li>■ Enabled in half-duplex mode</li> <li>■ Auto-negotiated in full-duplex mode</li> </ul>
<b>Broadcast Storm Control</b>	Enabled
<b>Virtual LANs (VLANs)</b>	All ports belong to the untagged Default VLAN (VLAN 1) with IEEE Std 802.1Q-1998 learning operational
<b>Management VLAN</b>	VLAN 1
<b>Trust IP</b>	Disabled
<b>Link Aggregation Control Protocol (LACP)</b>	Disabled per port
<b>IP Multicast Filtering</b>	Filtering enabled
<b>Rapid Spanning Tree Protocol</b>	Enabled
<b>Fast Start</b>	<ul style="list-style-type: none"> <li>■ Enabled on front panel ports</li> <li>■ Disabled on rear panel port</li> </ul>
<b>RMON Alarm</b>	Enabled
<b>Smart Auto-Sensing</b>	Enabled
<b>Webcache Support</b>	Disabled
<b>Traffic Prioritization</b>	All ports prioritize NBX VoIP traffic (LAN and IP). All ports set to "best effort" for all other traffic.
<b>Port Security</b>	Disabled per port
<b>Configuration Save and Restore</b>	Disabled



*To make SSH, Webcache redirection, RADIUS (including 802.1x Network Login), Auto VLAN assignment, and Traffic Prioritization available on the SuperStack 3 Switch 4400 SE, upgrade the product to the Switch 4400 SE Enhanced Software Upgrade (3C17207).*

If you initialize a Switch unit by selecting *System > Control > Initialize* in the Web interface or by entering **system control initialize** in the Command Line Interface, the following settings are retained to allow you to connect to and manage the Switch:

- IP Address
- Subnet Mask
- Default Router



# 2

## INSTALLING THE SWITCH

This chapter contains the information you need to install and set up the Switch 4400. It covers the following topics:

- Package Contents
- Choosing a Suitable Site
- Rack-mounting
- Placing Units On Top of Each Other
- Stacking Units
- The Power-up Sequence



**WARNING: Safety Information.** Before installing or removing any components from the Switch 4400 or carrying out any maintenance procedures, you must read the safety information provided in Appendix A of this guide.



**AVERTISSEMENT: Consignes de sécurité.** Avant d'installer ou d'enlever tout composant du Switch 4400 ou d'entamer une procédure de maintenance, lisez les informations relatives à la sécurité qui se trouvent dans l'Appendice A de ce guide.



**VORSICHT: Sicherheitsinformationen.** Bevor Sie Komponenten aus dem Switch 4400 entfernen oder dem Switch 4400 hinzufuegen oder Instandhaltungsarbeiten verrichten, lesen Sie die Sicherheitsanweisungen, die in Appendix A (Anhang A) in diesem Handbuch aufgefuehrt sind.

---

## Package Contents

- Switch unit
- CD-ROM (includes documentation related to your Switch)
- Getting Started Guide (this guide)
- Management Quick Reference Guide
- Release Notes
- Unit Information Labels
- Warranty Information
- Power Cord
- 2 x Mounting brackets
- 4 x Screws
- 4 x Rubber feet

---

## Choosing a Suitable Site

The Switch is suited for use on a desktop, either free standing or mounted in a standard 19-inch equipment rack. Alternatively, the Switch can be mounted in a wiring closet or equipment room, as an aggregator for other Hubs and Switches. A rack-mounting kit containing two mounting brackets is supplied with the Switch.



**CAUTION:** *Ensure that the ventilation holes are not obstructed.*

When deciding where to position the Switch, ensure that:

- Cabling is located away from:
  - sources of electrical noise such as radios, transmitters and broadband amplifiers.
  - power lines and fluorescent lighting fixtures
- The Switch is accessible and cables can be connected easily.
- Water or moisture cannot enter the case of the Switch.
- Air flow is not restricted around the Switch or through the vents in the side of the Switch. 3Com recommends that you provide a minimum of 25mm (1in.) clearance.
- Air temperature around the Switch does not exceed 40 °C (104 °F).



*If the Switch is installed in a 19-inch rack or closed assembly its local air temperature may be greater than room ambient temperature.*



- The air is as free from dust as possible.
- The unit is installed in a clean, air conditioned environment.
- No more than eight Switch units are placed on top of one another, if the units are free-standing.
- The Switch is situated away from sources of conductive (electrical) dust, for example laser printers.
- The AC supply used by the Switch is separate to that used by units that generate high levels of AC noise, for example air conditioning units and laser printers.

---

## Rack-mounting


The Switch 4400 is 1U high and will fit in most standard 19-inch racks.



**CAUTION:** *Disconnect all cables from the Switch before continuing. Remove all self adhesive pads from the underside of the Switch if they have been fitted.*

To rack-mount your Switch:

- 1 Place the Switch the right way up on a hard flat surface, with the front facing towards you.
- 2 Locate a mounting bracket over the mounting holes on one side of the Switch, as shown in Figure 6.

**Figure 6** Fitting a bracket for rack-mounting

- 3 Insert the two screws and tighten with a suitable screwdriver.



*You must use the screws supplied with the mounting brackets. Damage caused to the unit by using incorrect screws invalidates your warranty.*

- 4 Repeat steps 2 and 3 for the other side of the Switch.
- 5 Insert the Switch into the 19-inch rack and secure with suitable screws (not provided). Ensure that ventilation holes are not obstructed.
- 6 Connect network cabling.
- 7 Finally place a unit information label on the unit in an easily accessible position. The unit information label shows the following:
  - The 3Com product name of the Switch
  - The 3Com 3C number of the Switch
  - The unique MAC address (Ethernet address) of the Switch
  - The serial number of the Switch

You may need this information for fault reporting purposes.

## Placing Units On Top of Each Other

If the Switch units are free-standing, up to eight units can be placed one on top of the other. If you are mixing a variety of SuperStack® 3 Switch and Hub units, the smaller units must be positioned at the top.

If you are placing Switch units one on top of the other, you must use the self-adhesive rubber pads supplied. Apply the pads to the underside of each Switch, sticking one in the marked area at each corner. Place the Switch units on top of each other, ensuring that the pads of the upper unit line up with the recesses of the lower unit.

## Stacking Units

Switch 4400 units can be stacked together and then treated as a single manageable unit with one IP address. Any combination of 24-port and 48-port units is allowed in a single stack.




*The SuperStack 3 Switch 4400 SE can only be stacked with non-SE Switches if it has been upgraded using the Switch 4400 SE Enhanced Software Upgrade (3C17207). An upgraded Switch 4400 SE cannot be stacked with a normal Switch 4400 SE.*

## How To Stack Units

To stack two Switch 4400 units you will need to order the SuperStack 3 Switch Cascade Stacking Kit (3C17227). The kit consists of two Cascade Modules and a Cascade Cable. Both Switches must have an unused expansion slot to allow a Cascade Module to be fitted.


**Figure 7** Stacking two Switch 4400 units



To stack more than two Switch units you will need to order one SuperStack 3 Cascade Extender Kit (3C17228) for each additional unit. This Kit consists of one Cascade Module, one Cascade Cable and one

Cascade Extender Unit. The Cascade Module is installed into the expansion slot at the rear of the Switch and the Cascade Extender Unit plugs into the Cascade Module.

**Figure 8** Stacking more than two Switch 4400 units



For information on ordering the Cascade Kits contact your supplier. For illustrations and information on how to install the Cascade Kits, refer to the user documentation that accompanies these Kits.

### Rules For Stacking Units

This information is also provided in the user documentation that accompanies the Cascade Kits.

- The maximum number of Switch units in a stack is limited to 8. The stack may contain a combination of 24 and 48 port units.
- Only one Cascade Module can be installed per Switch. If Cascade Modules are fitted to both expansion slots in a Switch then both Modules will be disabled.
- Cascade Modules are NOT hot-swappable or hot-insertable. Ensure that the Switch is powered off before inserting or removing a Cascade Module.

- The Cascade Extender Unit is hot-insertable. This allows its host Switch unit to be removed and replaced without disturbing the rest of the stack.
- Only 3Com® Cascade Cables can be used to connect between Cascade Modules/Cascade Extender Units.
- Due to the length of the Cascade Cables, you must insert all of the Cascade Modules into Expansion Module Slot 1 or all of the Cascade Modules into Expansion Module Slot 2 on the Switches.
- It is not possible to stack a Switch 4400, Switch 4400 SE, Switch 4400 PWR or Switch 4400 FX unit with SuperStack II or other SuperStack 3 products using the Cascade Stacking Kit (3C17227) or Cascade Extender Kit (3C17228).
- 3Com strongly recommends that you upgrade all Switch 4400 units (24-port and 48-port) in a stack to the latest software agent.
- 3Com recommends that you initialize a Switch 4400, Switch 4400 SE, Switch 4400 PWR or Switch 4400 FX unit that has previously been used elsewhere in your network before you add it to an existing stack. If you do not initialize the unit, problems may be caused by conflicting Switch configurations.
- When the Switch 4400s are stacked together they are assigned a unit number from bottom-to-top for management purposes. When further Switches are added to the stack, they can be positioned at the bottom of the stack or at the top. Either way, the Switch management software will re-order the Switch unit numbers into a logical order again (from bottom to top).

## The Power-up Sequence

The following sections describe how to get your Switch 4400 powered-up and ready for operation.

### Powering-up the Switch 4400

Use the following sequence of steps to power-up the Switch.

- 1 Plug the power cord into the power socket at the rear of the Switch.
- 2 Plug the other end of the power cord into your power outlet.

The Switch powers-up and runs through its Power On Self Test (POST), which takes approximately 10 seconds.

### Checking for Correct Operation of LEDs

During the Power On Self Test, all ports on the Switch are disabled and the LEDs light in a set sequence.

When the POST has completed, check the Power/Self Test LED to make sure that your Switch is operating correctly. Table 6 shows possible colors for the LED.

**Table 6** Power/Self Test LED colors

Color	State
Green	The Switch is powered-up and operating normally.
Yellow	The Switch has failed its Power On Self Test.
Off	The Switch is not receiving power.

If there is evidence of a problem, see “Solving Problems Indicated by LEDs” on page 58.

### Connecting a Redundant Power System

You can connect a SuperStack 3 Advanced Redundant Power System (3C16071B) to the Switch. This unit, which is also known as an RPS, is designed to maintain the power to your Switch if a power supply failure occurs.

For normal redundancy, the Switch 4400, Switch 4400 SE, and Switch 4400 FX require one Type 2A Power Module (3C16074A). For full redundancy, the Switch 4400, Switch 4400 SE, and Switch 4400 FX require two type 2A Power Modules combined using a Type 2 Y-Cable. The Switch 4400 PWR (3C17205) requires one Type 3 Power Module (3C16075) for normal redundancy and two Type 3 Power Modules for full redundancy.



**CAUTION** *The Switch has no ON/OFF switch; the only method of connecting or disconnecting mains power is by connecting or disconnecting the power cord.*



**CAUTION:** *The Switch can only use a SuperStack Advanced Redundant Power System output.*

## Using Power over Ethernet

The Switch 4400 PWR can power any IEEE 802.3af compliant device through any of its front panel ports. The Switch will support the following 3Com 802.3af equipment:

- Wireless:
  - 3Com 11 Mbps Wireless LAN Access Point 8000 (3CRWE80096B)
  - 3Com 11 Mbps Wireless LAN Access Point 8200 (3CRWE820096A)
  - 3Com 11 Mbps Wireless LAN Access Point 8500 (3CRWE850096A)
  - 3Com 11 Mbps Wireless LAN Access Point 8700 (3CRWE870096A)
  - 3Com Wireless LAN Building to Building Bridge (3CRWE91096B)
- Voice Over IP Telephones:
  - 3Com 11 Mbps Wireless LAN Access Point 8000 (3CRWE80096B)
  - 3Com 11 Mbps Wireless LAN Access Point 8200 (3CRWE820096A)
  - 3Com 11 Mbps Wireless LAN Access Point 8500 (3CRWE850096A)
  - 3Com 11 Mbps Wireless LAN Access Point 8700 (3CRWE870096A)
  - 3Com Wireless LAN Building to Building Bridge (3CRWE91096B)
- The following 3Com NBX phones are also supported using the 3Com NBX VoIP Phone Module (3CNJVOIPMOD-NBX):
  - 3Com NBX 1102 Business Phone (3C10121)
  - 3Com NBX 1102B Business Phone (3C10281B)
  - 3Com NBX 1102PE Business Phone (3C10281PE)
  - 3Com NBX 2101Basic Phone (3C10248B)
  - 3Com NBX 2101PE Basic Phone (3C10248PE)
  - 3Com NBX 2102 Business Phone (3C10226A)
  - 3Com NBX 2102IR Business Phone with IR (3C10228IRA)
  - 3Com NBX 2102B Business Phone (3C10226B)
  - 3Com NBX 2102IRB Business Phone with IR (3C10228IRB)

- 3Com NBX 2102PE Business Phone (3C10226PE)
- 3Com NBX 2102PEIR Business Phone with IR (3C10228RPE)
- 3Com NBX 3102 Business Phone (3C10402A)
- 3Com NBX ATA Business Phone (3C10400)
- Network Jacks:
  - 3Com NJ90 (3CNJ90)
  - 3Com NJ95 (3CNJ95)
  - 3Com NJ100 (3CNJ100, 3CNJ100-CRM)
  - 3Com NJ105 - 3CNJ105
  - 3Com NJ105 + forwarding (3CNJ105)
  - 3Com NJ200 (3CNJ200, 3CNJ200-CRM)
  - 3Com NJ200 + forwarding (3CNJ200)
  - 3Com NJ205 (3CNJ205)
  - 3Com NJ205 + forwarding (3CNJ205)



*For the latest list of supported devices, go to the product page on the 3Com web site <http://www.3com.com/>.*

For further information about Power Over Ethernet, refer to “Power Management and Control” in the Switch Implementation Guide supplied on the CD-ROM that accompanies your Switch. Power over Ethernet management is available using the web interface or the command line interface (CLI).

### **Choosing the Correct Cables (Switch 4400, 4400 SE and 4400 PWR)**

All of the ports on the front of the Switch 4400, 4400 SE and 4400 PWR are Auto-MDIX, that is they have a cross-over capability. The port can automatically detect whether it needs to operate in MDI or MDIX mode. Therefore you can make a connection to a port with a straight-through (MDI) or a cross-over cable (MDIX).



*The Auto-MDIX feature only operates when enabled per port and if auto-negotiation is enabled.*

If auto-negotiation is disabled, all the Switch ports are configured as MDIX (cross-over). If you want to make a connection to another MDIX port, you need a *cross-over* cable. Many ports on workstations and servers are configured as MDI (straight-through). If you want to make a



connection to an MDI port, you need to use a standard *straight-through* cable. See Table 7.



**WARNING:** The 4400 PWR (3C17205) supports Power over Ethernet on all front ports. These ports should only be used for Ethernet wiring within the same building. The Rear Module ports of the Switch 4400 PWR can be used for ethernet wiring between buildings.

3Com recommends that you use Category 5 twisted pair cable — the maximum segment length for this type of cable is 100 m (328 ft).

**Table 7** Cables required to connect the Switch 4400 to other devices if auto-negotiation is disabled

	Cross-over Cable	Straight-through Cable
Switch to Switch (MDIX to MDIX)	✓	✗
Switch to Hub (MDIX to MDIX)	✓	✗
Switch to PC (NIC) (MDIX to MDI)	✗	✓



**CAUTION:** If you want to install the Switch using a Category 5E or Category 6 cable, 3Com recommends that you briefly connect the cable to a grounded port before connecting network equipment. If you do not, the cable's Electrostatic Discharge (ESD) may damage the Switch's port.

You can create a grounded port by connecting all wires at one end of a UTP cable to an earth ground point, and the other end to a female RJ-45 connector located, for example, on a Switch rack or patch panel. The RJ-45 connector is now a grounded port.

### Choosing the Correct Cables (Switch 4400 FX)

All of the ports on the front of the Switch 4400 FX are 100BASE-FX MT-RJ multi-mode ports. The MT-RJ port is a small form factor fiber-optic port with the transmit and receive fibers in the same cable. Unlike many fiber-optic systems, only one MT-RJ cable is needed to connect two MT-RJ ports together.

To connect a front-panel port to another 100BASE-FX MT-RJ multi-mode port, or to a patch panel, a single MT-RJ multi-mode pinless jumper cable is required. Since standard MT-RJ cables are cross-over cables, no

Auto-MDIX sensing is required. The maximum cable length is 2 kilometers (1.24 miles).



**CAUTION:** *Do not connect pinned MT-RJ connectors into any port on the Switch 4400 FX as this may damage the unit. The ports have locator pins fitted and are designed for standard (pinless) connectors.*

To connect a front-panel port to a 100BASE-FX single mode port, or to a port that does not have an MT-RJ connector, an adaptor will be required. It is not possible to connect a front panel port to a 1000BASE-FX port.

# 3

## SETTING UP FOR MANAGEMENT

Your Switch can operate in its default state, that is, you can install it and it will work straight away (plug-and-play). However, to make full use of the features offered by the Switch, and to change and monitor the way it works, you have to access the management software that resides on the Switch. This is known as managing the Switch.

Managing the Switch can help you to improve the efficiency of the Switch and therefore the overall performance of your network.

This chapter explains the initial set up of the Switch and the different methods of accessing the management software to manage a Switch. It covers the following topics:


- Setting Up Overview
- Manually Configuring IP Information
- Viewing Automatically Configured IP Information
- Methods of Managing a Switch
- Setting Up Command Line Interface Management
- Setting Up Command Line Interface Management using SSH
- Setting Up Web Interface Management
- Setting Up SNMP Management
- Default Users and Passwords

## Setting Up Overview

This section gives an overview of what you need to do to get your Switch set up and ready for management when it is in its default state. The whole setup process is summarized in Figure 9. Detailed procedural steps are contained in the sections that follow. In brief, you need to:

- Configure IP information manually for your Switch or view the automatically configured IP information
- Prepare for your chosen method of management

**Figure 9** Initial Switch Setup and Management Flow diagram





**CAUTION:** *To protect your Switch from unauthorized access, you must change all three default passwords as soon as possible, even if you do not intend to actively manage your Switch. For more information on default users and changing default passwords, see “Default Users and Passwords” on page 55.*

## IP Configuration

You can use one of the following methods to allocate IP information to your Switch (essential if you wish to manage your Switch across the network).

### Manual IP Configuration

You can choose to configure the IP information yourself. The Switch remembers the information that you enter until you change it again or set the configuration method to Automatic.

You should use the Manual IP configuration method if:

- you do not have a DHCP or BootP server on your network, or
- you want to remove the risk of the IP address ever changing, or
- your DHCP or BootP server does not allow you to allocate static IP addresses. (Static IP addresses are necessary to ensure that the Switch is always allocated the same IP information.)



*For most installations, 3Com recommends that you configure the Switch IP information manually. This makes management simpler and more reliable as it is not dependent on a DHCP or BootP server, and eliminates the risk of the IP address changing.*

If you wish to manually enter IP information for your Switch, work through the “Manually Configuring IP Information” section on page 39.

### Automatic IP Configuration

By default the Switch tries to configure itself with IP information without requesting user intervention. It tries to obtain an IP address from a DHCP or BootP server on the network.

If neither server is found, the Switch will configure itself with its default IP address 169.254.100.100 if it is operating in a standalone mode, and/or no other Switches on the network have this IP address. If this default IP address is already in use on the network then the Switch detects this and configures itself with an IP address in the range 169.254.1.0 to 169.254.254.255.

This process is known as Auto-IP and is the same mechanism used by Windows 98 and Windows 2000. IP addresses configured by Auto-IP are temporary as they cannot be routed but are useful for small networks which are not connected to other networks, or for initial configuration.

However, as soon as a DHCP or BootP server is detected, the Switch will configure itself with the IP address allocated by that server.

When using automatic IP configuration it is important that the IP address of the Switch is static, otherwise you will not know what the IP address is and it will be difficult to manage. Most DHCP and BootP servers allow static IP addresses to be configured so that you know what IP address will be allocated to the Switch. Refer to the documentation that accompanies your DHCP/BootP server.



*For a detailed description of how automatic IP configuration operates, please refer to the Implementation Guide on the CD-ROM that accompanies your Switch or on the 3Com Web site.*

You should use the automatic IP configuration method if:

- your network uses DHCP or BootP to allocate IP information, or
- flexibility is needed. If the Switch is re-deployed onto a different subnet, it will automatically reconfigure itself with an appropriate IP address, instead of you having to manually reconfigure the Switch.

If you use the automatic IP configuration method, you need to discover the automatically allocated IP information before you can begin management. Work through the “Viewing Automatically Configured IP Information” section on page 46.

### **Preparing for Management**

Once your Switch’s initial set up is complete you can set up your chosen management method as described in “Methods of Managing a Switch” on page 49.



*For detailed information about the specific web interface operations and command line interface commands and problem solving, refer to the “SuperStack 3 Switch Management Interface Reference Guide” on the CD-ROM that is supplied with the Switch or on the 3Com Web site.*

---

## Manually Configuring IP Information

You can manually configure the Switch IP information in the following ways:

- Connecting to a front panel port — Connect a workstation using an Ethernet cable to a front panel port of the Switch. You can then manually enter IP information using the web interface or the command line interface (CLI).
- Connecting to the console port — Connect a workstation using a console cable to the console port of the Switch. You can then manually enter IP information using the command line interface (CLI).

### Connecting to a Front Panel Port

To set up your Switch manually you can make a connection to a front panel port. You must do this whilst the Switch is offline, that is, before you connect the Switch to a network.



*The procedure described in this section assumes the unit has been powered up in standalone mode and has the default IP address of 169.254.100.100.*


#### Pre-requisites

- A workstation running Windows 95/98/2000, Windows NT or Windows XP.
- A Network Interface Card (NIC).
- A Category 5 twisted pair Ethernet cable with RJ-45 connectors.
- A suitable Web browser — refer to “Choosing a Browser” on page 53.
- You need to have the following so that you can manually set up the Switch with IP information:
  - IP address
  - subnet mask
  - default gateway
  - management VLAN ID, normally set to the default value (1)

## Connecting the Workstation to the Switch

- 1 Connect the workstation to a front panel port using an Ethernet cable as shown in Figure 10.

**Figure 10** Connecting a workstation to the Switch via a front panel port



To connect the cable:

- a Attach an RJ-45 connector at one end of the Ethernet cable to the Network Interface Card (NIC) in the workstation.
- b Connect the RJ-45 connector at the other end of the cable to one of the front panel ports on the Switch.



*Do not interconnect the Switch to any other unconfigured Switch.*

## Configuring the Workstation with IP Information

You need to change the IP address and subnet mask of the workstation that you have connected to the Switch. Make a note of the existing settings so you can return to them later. Change the workstation to the following settings:

- IP address — **169.254.100.99**
- Subnet mask — **255.255.0.0**

## Setting Up the Switch with IP Information

You are now ready to manually set up the Switch with IP information. You can do this using the Web interface or the command line interface (CLI) via telnet.

### *Using the Web Interface*

- 1 Power-up the Switch. This takes approximately one minute.
- 2 Open a suitable Web browser and enter **169.254.100.100** in the *Location Address* field. This is the default IP address that is automatically assigned to an offline unit.





*If there is no response, wait for one minute then re-enter the default IP address.*

- 3 At the login and password prompts, enter **admin** as your user name and press Return at the password prompt (default user name and password). If you have logged on correctly, a set of Getting Started pages are displayed.
- 4 The Getting Started pages allow you to enter basic setup information for the Switch. Select **Manual** and then enter the IP address, subnet mask, and default gateway that you want the Switch to use when it is connected to the network. The final page displays a summary of the information entered.

The initial set up of your Switch is now complete and the Switch is ready for you to set up your chosen management method. See "Methods of Managing a Switch" on page 49.

### ***Using Command Line Interface via Telnet***

- 1 To start a Telnet session to the unit, click *Start* in Microsoft Windows 95/98/2000/NT/XP.
  - a Click *Run*.
  - b In the dialogue box that appears type the default IP address of the unit, that is: **Telnet 169.254.100.100**
  - c Click *OK*.
- 2 Press *Enter* to open a login prompt.



*If the login prompt does not begin immediately, press Return a few times until it starts.*

- 3 At the login and password prompts, enter **admin** as your user name and press Return at the password prompt. If you have logged on correctly, the top-level menu of the command line interface is displayed as shown in the example in Figure 11.

**Figure 11** Example top-level command line interface menu

```

Menu options: -----3Com SuperStack 3 Switch 4xxx-----
bridge          - Administer bridge-wide parameters
feature         - Administer system features
gettingStarted  - Basic device configuration
logout         - Logout of the Command Line Interface
physicalInterface - Administer physical interfaces
protocol        - Administer protocols
security        - Administer security
system         - Administer system-level functions
trafficManagement - Administer traffic management

Type ? for help
----- (2)-----
Select menu option: █

```

- 4 At the Select menu option prompt you can either:
  - enter the **protocol ip basicConfig** command. At the Enter configuration method prompt enter **manual**. The screen prompts you to enter IP information.

or

- enter the **gettingStarted** command. At the Enter configuration method prompt enter **manual**. The screen prompts you to enter IP information.
- 5 Enter the IP address, subnet mask, and gateway IP address for the Switch. The screen displays a summary of the information entered.

If using the `gettingStarted` command you will then be prompted to enter system information, change passwords, and then given the option to carry out advanced configuration.



*The **protocol ip basicConfig** command will prompt you for the management VLAN ID. If the unit is new there is only one VLAN (VLAN 1) to choose from.*

The initial set up of your Switch is now complete and the Switch is ready for you to set up your chosen management method. See “Methods of Managing a Switch” on page 49.

## Connecting to the Console Port

To set up your Switch manually you can alternatively make a connection to the console port (this example describes a local connection to the console port, rather than a remote one via a modem). You can do this whilst the Switch is offline, that is, before you connect the Switch to a network, or whilst the Switch is online, that is, connected to a network.

### Pre-requisites

- A workstation with terminal emulation software installed, such as Microsoft Hyperterminal. This software allows you to communicate with the Switch via the console port directly, or through a modem.
- Documentation supplied with the terminal emulation software.
- A suitable cable:
  - A standard null modem cable — if you are connecting directly to the console port, or
  - A standard modem cable — if you are connecting to the console port using a modem.




You can find pin-out diagrams for both cables in Appendix B on page 73.

- You need to have the following so that you can manually set up the Switch with IP information:
  - IP address
  - subnet mask
  - default gateway
  - management VLAN ID, normally set to the default value (1)

### Connecting the Workstation to the Switch

- 1 Connect the workstation to the console port using a standard null modem cable as shown in Figure 12.

**Figure 12** Connecting a workstation to the Switch via the console port



To connect the cable:

- a Attach the female connector on the cable to the male connector on the console port of the Switch.
- b Tighten the retaining screws on the cable to prevent it from being loosened.
- c Connect the other end of the cable to one of the serial ports (also known as a COM port) on your workstation.

- 2 Open your terminal emulation software and configure the COM port settings to which you have connected the cable. The settings should be set to match the default settings for the Switch, which are:
  - 19,200 baud
  - 8 data bits
  - no parity
  - 1 stop bit
  - no hardware flow control

Refer to the documentation that accompanies the terminal emulation software for more information.

### Setting Up the Switch with IP Information

You are now ready to manually set up the Switch with IP information using the command line interface.

- 1 The command line interface login sequence begins as soon as the Switch detects a connection to its console port.



*If the login prompt does not begin immediately, press Return a few times until it starts.*

- 2 At the login and password prompts, enter **admin** as your user name and press Return at the password prompt. If you have logged on correctly, the top-level menu of the command line interface is displayed as shown in the example in Figure 13.

**Figure 13** Example top-level command line interface menu

```

Menu options: -----3Com SuperStack 3 Switch 4xxx-----
bridge          - Administer bridge-wide parameters
feature         - Administer system features
gettingStarted  - Basic device configuration
logout         - Logout of the Command Line Interface
physicalInterface - Administer physical interfaces
protocol        - Administer protocols
security        - Administer security
system         - Administer system-level functions
trafficManagement - Administer traffic management

Type ? for help
----- (2)-----
Select menu option: █

```

**3** At the Select menu option prompt you can either:

- enter the **protocol ip basicConfig** command. At the `Enter configuration method` prompt enter **manual**. The screen prompts you to enter IP information.

or

- enter the **gettingStarted** command. At the `Enter configuration method` prompt enter **manual**. The screen prompts you to enter IP information.

**4** Enter the IP address, subnet mask, and gateway IP address for the Switch. The screen displays a summary of the information entered.

If using the `gettingStarted` command you will then be prompted to enter system information, change passwords, and then given the option to carry out advanced configuration.



*The **protocol ip basicConfig** command will prompt you for the management VLAN ID. If the unit is new there is only one VLAN (VLAN 1) to choose from.*

The initial set up of your Switch is now complete and the Switch is ready for you to set up your chosen management method. See “Methods of Managing a Switch” on page 49.

If you do not intend to use the command line interface via the console port to manage the Switch, you can disconnect the serial cable and close the terminal emulator software.

## Viewing Automatically Configured IP Information

If you allow the Switch to automatically configure its own IP information you need to discover and view the IP information before you can begin to manage the Switch. You can discover the IP information in two ways:

- Using 3Com Network Supervisor — This application will auto-discover the Switch and display the automatically allocated IP information assigned to the Switch.
- Connecting to the Console Port — Connect a workstation using a console cable to the console port of the Switch. You can then view the IP information automatically assigned to the Switch using the command line interface (CLI).

## Using 3Com Network Supervisor

You can use the 3Com Network Supervisor application provided on the CD-ROM that accompanies your Switch to discover the automatically allocated IP information.

- 1 Connect your Switch to the network.
- 2 Power-up the Switch and wait for two minutes.
- 3 Launch 3Com Network Supervisor and run the Auto-discovery wizard.

3Com Network Supervisor will auto-discover the new Switch and display the IP information that has been automatically allocated to the Switch.



*Most DHCP and BootP servers allow static IP addresses to be configured so that you know what IP address the Switch will be given. Refer to the documentation that accompanies your DHCP or BootP server.*



*If your network does not have a DHCP or BootP server, the workstation running 3Com Network Supervisor must be on the same subnet as the Switch, because Auto-IP addresses are non-routable.*

## Connecting to the Console Port

Alternatively, you can view the automatically configured IP information via the command line interface (CLI) through a connection to the console port. (This example describes a local connection to the console port, rather than a remote one via a modem.)

### Pre-requisites

- A workstation with terminal emulation software installed, such as Microsoft Hyperterminal. This software allows you to communicate with the Switch via the console port directly, or through a modem.
- Documentation supplied with the terminal emulation software.

- A suitable cable:
  - A standard null modem cable — if you are connecting directly to the console port, or
  - A standard modem cable — if you are connecting to the console port using a modem.




You can find pin-out diagrams for both cables in Appendix B on page 73.

- A Category 5 twisted pair Ethernet cable with RJ-45 connectors to connect your Switch to the network.

### Connecting the Workstation to the Switch

- 1 Connect the workstation to the console port using a standard null modem cable as shown in Figure 14.

**Figure 14** Connecting a workstation to the Switch via the console port



To connect the cable:

- a Attach the female connector on the cable to the male connector on the console port of the Switch.
  - b Tighten the retaining screws on the cable to prevent it from being loosened.
  - c Connect the other end of the cable to one of the serial ports (also known as a COM port) on your workstation.
- 2 Open your terminal emulation software and configure the COM port settings to which you have connected the cable. The settings should be set to match the default settings for the Switch, which are:
    - 19,200 baud
    - 8 data bits
    - no parity
    - 1 stop bit
    - no hardware flow control

Refer to the documentation that accompanies the terminal emulation software for more information.

## Viewing IP Information via the Console Port

You are now ready to view the automatically allocated IP information using the command line interface.

- 1 Connect your Switch to the network using an Ethernet cable. As soon as a network connection is made the Switch begins the automatic IP configuration process.



*The automatic IP configuration process usually completes within one minute.*



*If there is no response from a DHCP server within 30 seconds, the Auto-IP configuration mechanism attempts to allocate the default IP address 169.254.100.100. If this address is not available, it then allocates an IP address in the range of 169.254.x.y (where x is in the range 1 to 254, and y is in the range 0 to 255).*

- 2 The command line interface login sequence begins as soon as the Switch detects a connection to its console port.



*If the login prompt does not begin immediately, press Return a few times until it starts.*

- 3 At the login and password prompts, enter **admin** as your user name and press Return at the password prompt. If you have logged on correctly, the top-level menu of the command line interface is displayed as shown in the example in Figure 15.

**Figure 15** Example top-level command line interface menu

```
Menu options: -----3Com SuperStack 3 Switch 4xxx-----
bridge          - Administer bridge-wide parameters
feature         - Administer system features
gettingStarted  - Basic device configuration
logout          - Logout of the Command Line Interface
physicalInterface - Administer physical interfaces
protocol        - Administer protocols
security        - Administer security
system          - Administer system-level functions
trafficManagement - Administer traffic management

Type ? for help
----- (2)-----
Select menu option: █
```

- 4 At the Select menu option prompt enter the **protocol ip interface summary** command. At the Select IP interfaces prompt enter **all**. A summary of the automatically allocated IP information is displayed. Make a note of the Network IP Address.



The initial set up of your Switch is now complete and the Switch is ready for you to set up your chosen management method. See “Methods of Managing a Switch” on page 49.

If you do not intend to use the command line interface via the console port to manage the Switch, you can logout, disconnect the serial cable and close the terminal emulator software.

## Methods of Managing a Switch


Once you have completed the initial set up of your Switch, you can decide how you wish to manage the Switch. You can use one of the following methods:

- Command line interface management
- Command line interface management using SSH
- Web interface management
- SNMP management


## Command Line Interface Management

Each Switch has a command line interface (CLI) that allows you to manage the Switch from a workstation, either locally via a console port connection (see Figure 16), or remotely over the network (see Figure 17).

**Figure 16** CLI management via the console port



**Figure 17** CLI management over the network



Refer to “Setting Up Command Line Interface Management” on page 50.

### Command Line Interface Management using SSH


The Switch 4400 supports Secure Shell version 2 (SSHv2), allowing secure access to the Command Line Interface of the Switch.

If you use SSH to administer your Switch and the network traffic is intercepted, no passwords or configuration information will be visible in the data. To securely administer the Switch using the Command Line Interface you need a third party SSH client.

### Web Interface Management

Each Switch has an internal set of web pages that allow you to manage the Switch using a Web browser remotely over an IP network (see Figure 18).

**Figure 18** Web interface management over the network




Refer to “Setting Up Web Interface Management” on page 53.

### SNMP Management

You can manage a Switch using any network management workstation running the Simple Network Management Protocol (SNMP) as shown in Figure 19. For example, you can use the 3Com Network Supervisor software that is provided on the CD-ROM that accompanies your Switch.

**Figure 19** SNMP management over the network



Refer to “Setting Up SNMP Management” on page 54.

---

## Setting Up Command Line Interface Management

This section describes how you can set up command line interface management using a local console port connection or over the network.

**CLI Management via the Console Port**

To manage a Switch using the command line interface via the local console port connection:

- 1 Ensure you have connected your workstation to the console port correctly as described in “Connecting to the Console Port” on page 42.
- 2 Your Switch is now ready to continue being managed and/or configured through the CLI via its console port.

**CLI Management over the Network**

To manage a Switch using the command line interface over a network using Telnet:

- 1 Ensure you have already set up the Switch with IP information as described in “Setting Up Overview” on page 36.
- 2 Check that you have the IP protocol correctly installed on your management workstation. You can check this by trying to browse the World Wide Web. If you can browse, the IP protocol is installed.
- 3 Check you can communicate with the Switch by entering a **ping** command at the DOS prompt in the following format:

```
c:\ ping xxx.xxx.xxx.xxx
```

(where xxx.xxx.xxx.xxx is the IP address of the Switch)

If you get an error message, check that your IP information has been entered correctly and the Switch is powered up.

- 4 To open a Telnet session via the DOS prompt, enter the IP address of the Switch that you wish to manage in the following format:

```
>telnet xxx.xxx.xxx.xxx
```

(where xxx.xxx.xxx.xxx is the IP address of the Switch)



*If opening a Telnet session via third party software you will need to enter the IP address in the format suitable for that software.*

- 5 At the login and password prompts, enter **admin** as your user name and press Return at the password prompt (or the password of your choice if you have already modified the default passwords).



*If the login prompt does not display immediately, press Return a few times until it starts.*

- 6 If you have logged on correctly, the top-level menu of the command line interface for the Switch you wish to manage is displayed as shown in Figure 13 on page 45.

---

## Setting Up Command Line Interface Management using SSH

This section describes how you can set up Command Line Interface management using SSH over a network.

To manage a Switch using the command line interface over a network using SSH:

- 1 Ensure you have already set up the Switch with IP information as described in “Setting Up Overview” on page 36.
- 2 Check that you have the IP protocol correctly installed on your management workstation. You can check this by trying to browse the World Wide Web. If you can browse, the IP protocol is installed.
- 3 Check you can communicate with the Switch by entering a **ping** command at the DOS prompt in the following format:

```
c:\ ping xxx.xxx.xxx.xxx
```

(where xxx.xxx.xxx.xxx is the IP address of the Switch)

If you get an error message, check that your IP information has been entered correctly and the Switch is powered up.



*The switch automatically generates a host key pair when it is powered up for the first time, or after any reset to factory defaults. Host key generation may take a while, during which time SSH connections to the switch will be refused.*

- 4 Install an SSH client application on the workstation you want to use to access the switch.



*3Com recommends the following SSH clients; PuTTY, OpenSSH and SSH Communications Security Corp Secure Shell.*

- 5 Open an SSH session and access the switch using the switch's IP address and port number.



*The first time you connect to the switch the client will ask you to confirm that the host key is correct for the device.*

- 6 The switch and the SSH client will authenticate each other and a secure connection will be established.
- 7 Enter your usual username and password to access the CLI commands.



*For increased security please change the default password when using SSH for the first time.*



For further information on generating a host key on your switch and transferring keys to the Switch using TFTP server please refer to Chapter 11 of the “SuperStack 3 Switch Implementation Guide”.

## Setting Up Web Interface Management

This section describes how you can set up web interface management over the network.

- Pre-requisites**
- Ensure you have already set up the Switch with IP information as described in “Setting Up Overview” on page 36.
  - Ensure that the Switch is connected to the network using a Category 5 twisted pair Ethernet cable with RJ-45 connectors.
  - A suitable Web browser.

### Choosing a Browser

To display the web interface correctly, use one of the following Web browser and platform combinations:

**Table 8** Supported Web Browsers and Platforms

	Windows 95	Windows 98	Windows NT 4	Windows 2000	Windows XP	Solaris 2.6
Netscape 4.76	✓	✗	✗	✗	✗	✓
Netscape 6.2	✗	✓	✓	✓	✓	✗
Netscape 7.0	✗	✓	✓	✓	✓	✗
Internet Explorer 5.5	✓	✓	✓	✓	✓	✗
Internet Explorer 6.0	✗	✓	✓	✓	✓	✗

For the browser to operate the web interface correctly, JavaScript™ and Cascading Style Sheets must be enabled on your browser. These features are enabled on a browser by default. You will only need to enable them if you have changed your browser settings.

To enable style sheets in Netscape Navigator 4.76 on Solaris 2.6, open Netscape Navigator and select *Edit > Preferences > Fonts*. Select the *Use document-specified fonts, including Dynamic Fonts* radio button. You should also set the font sizes as follows:

- Variable Width Font - Size 10.0
- Fixed Width Font - Size 12.0

This ensures that the text spacing is correct. Finally in the *Advanced* category ensure that *Enable Java Script* and *Enable style sheets* are checked.

### Web Management Over the Network

To manage a Switch using the web interface over an IP network:

- 1 Check that you have the IP protocol correctly installed on your management workstation. You can check this by trying to browse the World Wide Web. If you can browse, the IP protocol is installed.
- 2 Check you can communicate with the Switch by entering a **ping** command at the DOS prompt in the following format:
 

```
c:\ ping xxx.xxx.xxx.xxx
```

 (where xxx.xxx.xxx.xxx is the IP address of the Switch)
 

If you get an error message, check that your IP information has been entered correctly and the Switch is powered up.
- 3 Open your web browser and enter the IP address of the Switch that you wish to manage in the URL locator, for example, in the following format:
 

```
http://xxx.xxx.xxx.xxx
```
- 4 At the login and password prompts, enter **admin** as your user name and press Return at the password prompt (or the password of your choice if you have already modified the default passwords).
- 5 Click on the *Device View* button to display the web management options.

---

### Setting Up SNMP Management

Any network management application running the Simple Network Management Protocol (SNMP) can manage a Switch if:

- The correct Management Information Bases (MIBs) are installed on the management workstation.
- The management workstation is connected to the Switch using a port in VLAN 1 (the Default VLAN). By default, all ports on the Switch are in VLAN 1.



*You can use the 3Com Network Supervisor application that is provided on the CD-ROM that accompanies your Switch to provide SNMP management for your Switch. If you use 3Com Network Supervisor it*

automatically loads the correct MIBs and necessary files onto your workstation.

- Pre-requisites**
- Documentation supplied with the SNMP network management application software.



To manage your Switch using an SNMP network management application, you need to specify SNMP community strings for the users defined on the Switch. You can do this using the command line interface **system management snmp community** command — refer to the command line interface section of the “SuperStack 3 Switch Management Interface Reference Guide” for more information.

---

## Default Users and Passwords

If you intend to manage the Switch using the web interface or the command line interface, or to change the default passwords, you need to log in with a valid user name and password. The Switch has three default user names, and each user name has a different password and level of access. These default users are listed in Table 9.



**CAUTION:** To protect your Switch from unauthorized access, you must change all three default passwords as soon as possible, even if you do not intend to actively manage your Switch

**Table 9** Default Users

User Name	Default Password	Access Level
monitor	monitor	monitor — the user can view all manageable parameters, except special/security features, but cannot change any manageable parameters
manager	manager	manager — the user can access and change the operational parameters but not special/security features
admin	(no password)	security — the user can access and change all manageable parameters



Use the admin default user name (no password) to login and carry out initial Switch setup.

## Changing Default Passwords

- You can change the default passwords using either:
- The **gettingStarted** command on the CLI, or

- The **security device user modify** command on the CLI, or
- The *Security > Device > User > Modify* operation on the web interface.



*For more information about default users and passwords, refer to the “Superstack 3 Switch Management Interface Reference Guide” on the Switch CD-ROM.*



# 4

## PROBLEM SOLVING

This chapter helps you to diagnose and solve problems you may have with the operation of your Switch. There is also an explanation of IP addressing.

The topics covered are:

- Solving Problems Indicated by LEDs
- Solving Hardware Problems
- Solving Communication Problems
- Solving Software Upgrade Problems

If you experience a problem that is not listed here, it may be included in the Support section of the Superstack 3 Switch Management Interface Reference Guide on the CD-ROM that accompanies your Switch.

For Technical Support information, see Appendix D.

---

## Solving Problems Indicated by LEDs

If the LEDs on the Switch indicate a problem, refer to the list of suggested solutions below.

### **The Power LED does not light**

Check that the power cable is firmly connected to the Switch and to the supply outlet. If the connection is secure and there is still no power, you may have a faulty power cord or an internal fault. Firstly, check the power cord by:

- testing it in another device
- connecting a working power cord to the 'problem' device

then contact your supplier for advice.

### **On powering-up, the Power/Self Test LED lights yellow**

Either:

- The Switch unit has failed its Power On Self Test (POST) because of an internal problem. The fault type will be indicated on the unit LEDs. Contact your supplier for advice.  
or
- A port has failed and has been automatically disabled. You can verify this by checking that the Port Status LED is quickly flashing Yellow. If a port fails the Switch passes its Power On Self Test and continues to operate normally.

### **A Port Status LED is quickly flashing yellow**

The port has failed and has been automatically disabled. The Switch passes its Power On Self Test and continues to operate normally, even if one or more ports are disabled.

### **A link is connected and yet the Status LED for the port does not light**

Check that:

- The Switch and the device at the other end of the link (or cable) are connected securely.
- The devices at both ends of the link are powered-up
- The quality of cable is satisfactory

- Auto-negotiation settings are the same at both ends.  
Auto-negotiation problems will occur with 10BASE-T or 100BASE-T where auto-negotiation is disabled and incorrect cables are being used (cross-over or straight)  
Auto-negotiation problems will occur with fiber if:
  - The Receiver (RX) and Transceiver (TX) cable connectors are swapped
  - Fibers are broken
  - Auto-negotiation differs at either end (a link appears at the 'fixed' end and not at the auto-negotiation end)

### **The Unit LED is flashing green**

The Switch unit physically forms a stack with other Switch 4400 units, but cannot be managed as part of that stack because one or more units have not been upgraded to software version 2.0 or later. You must upgrade each unit in the stack to this software version, which is available on the CD-ROM that accompanies your Switch.

### **Port LED Status LED is flashing yellow (3C17205 only)**

The Switch has a Power over Ethernet error. You must press the LED Mode button to see which ports are affected and to see whether it is a fault or a power budget issue. If there is a fault, then the Packet LED of the affected port will be yellow. If a port exceeds its power limit, then the Packet LED of the port will flash green. If a port has a Power over Ethernet POST error then the Status LED of the affected port will flash yellow.

---

## **Solving Hardware Problems**

In the rare event of your Switch unit experiencing a hardware failure, refer to the list of suggested solutions below.

### **An expansion module is installed and the unit will not power up**

Ensure that the expansion module is fully seated in the slot and the connectors are engaged so that the securing screws can be tightened.

### **A fan failure warning message is received**

Your Switch has a fan monitoring system that will generate fan failure warning messages. Fan failure could potentially reduce the lifetime of the

Switch. The monitoring system polls the fan status at periodic intervals while the unit is powered up.

If one fan has failed in the Switch, a warning message will be generated in the following ways:

- **RMON Email Notification** — If configured, you will receive notification of the fan failure via email, SMS (Short Message Service), or pager.
- **RMON Trap** — If configured, an RMON trap is generated and sent to the management workstation.



*For further information about RMON, refer to “Chapter 7: Status Monitoring and Statistics” in the Switch Implementation Guide supplied in PDF format on the CD-ROM that accompanies the Switch.*

If more than one fan has failed in the Switch, a warning message will be generated by RMON Email Notification, RMON Trap and also in the following ways:

- **Command Line Interface** — An indication of a general hardware failure is provided through the Top level menu displayed when logging on to the CLI. For more detailed information about the failure select the **system summary** command.
- **Web interface** — An indication of fan failure is provided through the Device Summary table for the specific unit. In addition all Summary tables turn red to indicate the fan failure.

If a fan failure warning message is generated:

- 1 Power off the unit.
- 2 Check that the air vents are not obstructed.
- 3 Power cycle the unit. To do this, remove and reconnect the AC mains supply. If the unit has no AC main supply, remove and reconnect the DC RPS supply.
- 4 If another fan failure warning message is generated via the Command Line Interface or the Web interface, return the unit.

### Unit fails, no SNMP fan failure message is received

- 1 Power cycle the unit. To do this, remove and reconnect the AC mains supply. If the unit has no AC mains supply, remove and reconnect the DC RPS supply.
- 2 Check the command line interface (**system summary** command) to determine whether a thermal shutdown has occurred.
- 3 If no, return the unit:  
If yes, check that:
  - The air vents are not obstructed.
  - The ambient temperatures and environmental conditions meet those specified in Appendix C.
- 4 Power cycle the unit. If a further thermal shutdown occurs, and all environmental conditions are satisfactory, return the unit to 3Com.

### A device is connected to a Switch 4400 PWR but power is not being supplied

If power is not being supplied to a device connected to a Switch 4400 PWR, you should do the following checks:

- Check that the device is compliant with the 802.3af standard ref. [18].  
The 4400 PWR will only supply power through the front panel ports to 802.3af compliant devices.
- Check that the power budget for the Switch has not been exceeded.  
If the power budget has been exceeded, then by default, the powered device connected to the Power over Ethernet port with the lowest priority port will lose power. However, if all the devices connected to the Switch have equal priority levels, then the port with the highest number will lose power.  
  
By default the Switch will allow a device to receive power as long as the Power over Ethernet power supply has 18 watts spare in its power budget. If this much power is not available the device will not be powered (unless it has a higher priority than existing powered ports) and a Power over Ethernet fault will be reported for that port. If enough power subsequently becomes available the port will be powered.
- Check that the port has not had a power limit imposed upon it.

## Solving Communication Problems

If you experience communication problems with the Switch, ensure that:

- The Switch IP address and Management VLAN ID has been configured as described in Chapter 3.
- If the Switch is separated from your management application by a router, ensure that the default gateway IP address within the Switch is the same as the IP address of the router.
- The Switch's IP address has been entered correctly in your network management application (such as 3Com Network Supervisor).

The following is a brief overview of IP addressing, and how to obtain a registered IP address.

### IP Addressing

To be managed correctly, each device on your network (for example a Switch or Hub) must have a unique IP address. IP addresses have the format  $n.n.n.n$  where  $n$  is a decimal number between 0 and 255. An example IP address is 192.168.100.8.

The IP address is split into two parts:

- The first part ('192.168.100' in the example) identifies the network on which the device resides
- The second part ('.8' in the example) identifies the device within the network

The natural subnet mask for this example is 255.255.255.0.



*If your network has a connection to the external IP network, that is, you access the Internet, you must apply for a registered IP address.*

### How do you obtain a registered IP Address?

The IP registration system ensures that every IP address used is unique; if you do not have a registered IP address, you may be using an identical address to someone else and your network will not operate correctly.

InterNIC Registration Services is the organization responsible for supplying registered IP addresses. The following contact information is correct at time of publication:

World Wide Web site: <http://www.internic.net>

If your IP network is internal to your organization only, that is, you do not access the Internet, you may use any arbitrary IP address as long as it is not being used by another device on your network. 3Com suggests you use addresses in the range 192.168.0.0 to 192.168.255.255 with a subnet mask of 255.255.255.0.



*These suggested IP addresses are part of a group of IP addresses that have been set aside specially for use 'in house' only.*

---

## Solving Software Upgrade Problems

You can upgrade the management software of the Switch by using the *System > Control > Software Upgrade* operation in the Web Interface, or the **system control softwareUpgrade** command in the command line interface. For details on these options, refer to the Management Interface Reference Guide supplied in HTML format on the CD-ROM that accompanies your Switch.

If you have problems with your software upgrade, refer to the Problem Solving section in the Management Interface Reference Guide.





# A

## SAFETY INFORMATION

You must read the following safety information before carrying out any installation or removal of components, or any maintenance procedures on the Switch 4400.



**WARNING:** Warnings contain directions that you must follow for your personal safety. Follow all directions carefully.

You must read the following safety information carefully before you install or remove the unit.



**AVERTISSEMENT:** Les avertissements présentent des consignes que vous devez respecter pour garantir votre sécurité personnelle. Vous devez respecter attentivement toutes les consignes.

Nous vous demandons de lire attentivement les consignes suivantes de sécurité avant d'installer ou de retirer l'appareil.



**VORSICHT:** Warnhinweise enthalten Anweisungen, die Sie zu Ihrer eigenen Sicherheit befolgen müssen. Alle Anweisungen sind sorgfältig befolgen.

Sie müssen die folgenden Sicherheitsinformationen' sorgfältig durchlesen, bevor Sie das Gerät installieren oder ausbauen.

---

### Power Cord Set — Japan

電源コードを接続する場合は、アース接続がされていることを確認してから行ってください。  
アース線ははずす場合は、電源コードが接続されていないことを確認してから行ってください。

## Important Safety Information



**WARNING:** Installation and removal of the unit must be carried out by qualified personnel only.



**WARNING:** If installing the Switch 4400 in a stack with SuperStack II or SuperStack 3 units that are narrower than the 4400, the Switch 4400 unit must be installed below the narrower units.



**WARNING:** The unit must be earthed (grounded).



**WARNING:** Connect the unit to an earthed power supply to ensure compliance with safety standards.



**WARNING:** Power Cord Set:  
This must be approved for the country where it is used:

U.S.A. and  
Canada

- The cord set must be UL-approved and CSA certified.
- The minimum specification for the flexible cord is:  
No. 18 AWG  
Type SV or SJ  
3-conductor
- The cord set must have a rated current capacity of at least 10A.
- The attachment plug must be an earth-grounding type with a NEMA 5-15P (15A, 125V) or NEMA 6-15P (15A, 250V) configuration.

United  
Kingdom only

- The supply plug must comply with BS1363 (3-pin 13 amp) and be fitted with a 5A fuse which complies with BS1362.
- The mains cord must be <HAR> or <BASEC> marked and be of type H03VVF3GO.75 (minimum).

Europe only:

- The supply plug must comply with CEE 7/7 ("SCHUKO").
- The mains cord must be <HAR> or <BASEC> marked and be of type H03VVF3GO.75 (minimum).

Denmark

- The supply plug must comply with section 107-2-D1, standard DK2-1a or DK2-5a.

Switzerland

- The supply plug must comply with SEV/ASE 1011.



**WARNING:** The appliance coupler (the connector to the unit and not the wall plug) must have a configuration for mating with an EN60320/IEC320 appliance inlet.



**WARNING:** The socket outlet must be near to the unit and easily accessible. You can only remove power from the unit by disconnecting the power cord from the outlet.



**WARNING:** This unit operates under SELV (Safety Extra Low Voltage) conditions according to IEC 60950. The conditions are only maintained if the equipment to which it is connected also operates under SELV conditions.



**WARNING:** France and Peru only:  
This unit cannot be powered from IT<sup>+</sup> supplies. If your supplies are of IT type, this unit must be powered by 230V (2P+T) via an isolation transformer ratio 1:1, with the secondary connection point labelled Neutral, connected directly to earth (ground).  
†Impédance à la terre.



**WARNING:** U.K. only:  
If connecting a modem to the console port of the Switch 4400, only use a modem which is suitable for connection to the telecommunications system.




**WARNING:** RJ-45 Ports. These are shielded RJ-45 data sockets. They cannot be used as standard traditional telephone sockets, or to connect the unit to a traditional PBX or public telephone network. Only connect RJ-45 data connectors, network telephony systems, or network telephones to these sockets.

*Either shielded or unshielded data cables with shielded or unshielded jacks can be connected to these data sockets.*



**WARNING: Fiber Optic ports – Optical Safety**



*Never look at the transmit LED through a magnifying device while it is powered on. Never look directly at the fiber TX port and fiber cable ends when they are powered on.*



**WARNING:** The 4400 PWR (3C17205) supports Power over Ethernet on all front ports. These ports should only be used for ethernet wiring within the same building.



**WARNING:** When an Expansion Module is not installed ensure the blanking panel is fitted by tightening all screws with a suitable tool.

## L'information de Sécurité Importante



**AVERTISSEMENT:** L'installation et la dépose de ce groupe doivent être confiés à un personnel qualifié.



**AVERTISSEMENT:** Si vous entassez l'unité Switch avec les unités SuperStack 3 Hub, l'unité Switch 4400 doit être installée en dessous des unités Hub plus étroites.



**AVERTISSEMENT:** Vous devez mettre l'appareil à la terre (à la masse) ce groupe.



**AVERTISSEMENT:** Brancher l'unité à une source de courant mise à la terre pour assurer la conformité aux normes de sécurité.



**AVERTISSEMENT:** Cordon électrique:  
Il doit être agréé ans le pays d'utilisation:

Etats-Unis et  
Canada

- Le cordon doit avoir reçu l'homologation des UL et un certificat de la CSA
- Le cordon souple doit respecter, à titre minimum, les spécifications suivantes :
  - calibre 18 AWG
  - type SV ou SJ
  - à 3 conducteurs
- Le cordon doit être en mesure d'acheminer un courant nominal d'au moins 10 A
- La prise femelle de branchement doit être du type à mise à la terre (mise à la masse) et respecter la configuration NEMA 5-15P (15 A, 125 V) ou NEMA 6-15P (15 A, 250 V)

Danemark

- La prise mâle d'alimentation doit respecter la section 107-2 D1 de la norme DK2 1a ou DK2 5a

- |        |  |
|--------|--|
| Europe | <ul style="list-style-type: none"> <li>■ La prise secteur doit être conforme aux normes CEE 7/7 ("SCHKO")</li> <li>■ LE cordon secteur doit porter la mention &lt;HAR&gt; ou &lt;BASEC&gt; et doit être de type HO3VVF3GO.75 (minimum).</li> </ul> |
| Suisse | <ul style="list-style-type: none"> <li>■ La prise mâle d'alimentation doit respecter la norme SEV/ASE 1011</li> </ul>  |



**AVERTISSEMENT:** Le coupleur d'appareil (le connecteur du groupe et non pas la prise murale) doit respecter une configuration qui permet un branchement sur une entrée d'appareil EN60320/CEI 320.



**AVERTISSEMENT:** La prise secteur doit se trouver à proximité de l'appareil et son accès doit être facile. Vous ne pouvez mettre l'appareil hors circuit qu'en débranchant son cordon électrique au niveau de cette prise.



**AVERTISSEMENT:** L'appareil fonctionne à une tension extrêmement basse de sécurité qui est conforme à la norme CEI 60950. Ces conditions ne sont maintenues que si l'équipement auquel il est raccordé fonctionne dans les mêmes conditions.



**AVERTISSEMENT:** France et Pérou uniquement:  
Ce groupe ne peut pas être alimenté par un dispositif à impédance à la terre. Si vos alimentations sont du type impédance à la terre, ce groupe doit être alimenté par une tension de 230 V (2 P+T) par le biais d'un transformateur d'isolement à rapport 1:1, avec un point secondaire de connexion portant l'appellation Neutre et avec raccordement direct à la terre (masse).



**AVERTISSEMENT:** Points d'accès RJ-45. Ceux-ci sont protégés par des prises de données. Ils ne peuvent pas être utilisés comme prises de téléphone conventionnelles standard, ni pour la connection de l'unité à un réseau téléphonique central privé ou public. Raccorder seulement connecteurs de données RJ-45, systèmes de réseaux de téléphonie ou téléphones de réseaux à ces prises.

*Il est possible de raccorder des câbles protégés ou non protégés avec des jacks protégés ou non protégés à ces prises de données.*

**AVERTISSEMENT: Ports pour fibres optiques – sécurité sur le plan optique.**



Ne regardez jamais le voyant (DEL) d'émission en utilisant un dispositif d'agrandissement, tant qu'il est sous tension. Ne regardez jamais directement le port TX (Transmission) à fibres optiques et les embouts de câbles à fibres optiques tant qu'ils sont sous tension.



**AVERTISSEMENT:** Le 4400 PWR (3C17205) prend en charge la mise sous tension par Ethernet au niveau de tous les ports frontaux. Ces ports ne doivent être utilisés que pour le câblage Ethernet au sein d'un même bâtiment.



**AVERTISSEMENT:** Si le module d'expansion n'est pas installé, veillez à bien installer la plaque d'obturation et serrez toutes les vis à l'aide d'un outil approprié.

---

## Wichtige Sicherheitsinformationen



**VORSICHT:** Die Installation und der Ausbau des Geräts darf nur durch Fachpersonal erfolgen.



**VORSICHT:** Wenn die Switch 4400 Einheit in einer Stapel mit anderen SuperStack 3 Hub Einheiten eingebaut werden soll, muß die Switch 4400 Einheit unter die schmalere Hub Einheiten eingebaut werden.



**VORSICHT:** Das Gerät muß geerdet sein.



**VORSICHT:** Das Gerät muß an eine geerdete Steckdose angeschlossen werden, die europäischen Sicherheitsnormen erfüllt.



**VORSICHT:** Der Anschlußkabelsatz muß mit den Bestimmungen des Landes übereinstimmen, in dem er verwendet werden soll.



**VORSICHT:** Der Gerätestecker (der Anschluß an das Gerät, nicht der Wandsteckdosenstecker) muß eine passende Konfiguration für einen Geräteeingang gemäß EN60320/IEC320 haben.



**VORSICHT:** Die Netzsteckdose muß in der Nähe des Geräts und leicht zugänglich sein. Die Stromversorgung des Geräts kann nur durch Herausziehen des Gerätenetzkabels aus der Netzsteckdose unterbrochen werden.



**VORSICHT: Europe**

- Das Netzkabel muß vom Typ HO3VVF3GO.75 (Mindestanforderung) sein und die Aufschrift <HAR> oder <BASEC> tragen.
- Der Netzstecker muß die Norm CEE 7/7 erfüllen ("SCHUKO").



**VORSICHT:** Der Betrieb dieses Geräts erfolgt unter den SELV-Bedingungen (Sicherheitskleinstspannung) gemäß IEC 60950. Diese Bedingungen sind nur gegeben, wenn auch die an das Gerät angeschlossenen Geräte unter SELV-Bedingungen betrieben werden.



**VORSICHT:** RJ-45-Porte. Diese Porte sind geschützte Datensteckdosen. Sie dürfen weder wie normale traditionelle Telefonsteckdosen noch für die Verbindung der Einheit mit einem traditionellem privatem oder öffentlichem Telefonnetzwerk gebraucht werden. Nur RJ-45-Datenanschlüsse, Telefonnetzsysteme or Netztelefone an diese Steckdosen anschließen.

Entweder geschützte oder ungeschützte Buchsen dürfen an diese Datensteckdosen angeschlossen werden.



**VORSICHT: Faseroptikanschlüsse – Optische Sicherheit**



*Niemals mit einem Vergrößerungsgerät ein Übertragungs-LED betrachten, während dieses eingeschaltet ist. Niemals direkt auf den Faser-TX-Anschluß und auf die Faserkabelenden schauen, während diese eingeschaltet sind.*



**VORSICHT:** Das 4400 PWR (3C17205) unterstützt die Stromversorgung per Ethernet an allen vorderen Ports. Diese Ports dürfen nur für die Ethernet-Verkabelung im gleichen Gebäude verwendet werden.




**VORSICHT:** Ist kein Erweiterungsmodul installiert, überprüfen Sie bitte den Sitz der Stanzplatte, indem Sie alle Schrauben mit einem geeigneten Werkzeug anziehen.




# B

# PIN-OUTS

## Null Modem Cable 9-pin to RS-232 25-pin



## PC-AT Serial Cable 9-pin to 9-pin



**Modem Cable**

9-pin to RS-232 25-pin

Switch 4400 Series  
Cable connector: 9-pin femaleRS-232 Modem Port  
Cable connector: 25-pin male

Screen	Shell	●	●	1	Screen
TxD	3	●	●	2	TxD
RxD	2	●	●	3	RxD
RTS	7	●	●	4	RTS
CTS	8	●	●	5	CTS
DSR	6	●	●	6	DSR
Ground	5	●	●	7	Ground
DCD	1	●	●	8	DCD
DTR	4	●	●	20	DTR

**RJ-45 Pin Assignments**

Pin assignments are identical for 10BASE-TX and 100BASE-T RJ-45 connectors.

**Table 10** Pin assignments

Pin Number	Signal	Function
<i>Ports configured as MDI</i>		
1	Transmit Data +	Bidirectional Data A+
2	Transmit Data +	Bidirectional Data A-
3	Receive Data +	Bidirectional Data B+
4	Not assigned	Bidirectional Data C+
5	Not assigned	Bidirectional Data C-
6	Receive Data –	Bidirectional Data B-
7	Not assigned	Bidirectional Data D+
8	Not assigned	Bidirectional Data D-

**Table 11** Pin assignments

<b>Pin Number</b>	<b>Signal</b>	<b>Function</b>
<i>Ports configured as MDIX</i>		
1	Receive Data +	Bidirectional Data B+
2	Receive Data -	Bidirectional Data B-
3	Transmit Data +	Bidirectional Data A+
4	Not assigned	Bidirectional Data A-
5	Not assigned	Bidirectional Data D+
6	Transmit Data	Bidirectional Data D-
7	Not assigned	Bidirectional Data C+
8	Not assigned	Bidirectional Data C-





# TECHNICAL SPECIFICATIONS

---

## Switch 4400 (24-port) and Switch 4400 SE

---

<b>Physical Dimensions</b>	Height: 44 mm (1.7 in.) x Width: 440 mm (17.3 in.) x Depth: 274 mm (10.8 in.) Weight: 2.8 kg (6.2 lbs)
<b>Environmental Requirements</b>	
Operating Temperature	0 ° to 40 °C (32 ° to 104 °F)
Storage Temperature	-40 ° to +70 °C (-40 ° to 158 °F)
Operating Humidity	10–95% relative humidity, non-condensing
Standards	EN60068 to 3Com schedule (Package testing: paras 2.1, 2.2, 2.30, and 2.32. Operational testing: paras 2.1, 2.2, 2.30 and 2.13).
<b>Safety</b>	
Agency Certifications	UL 1950, EN60950, CSA 22.2 No. 950, IEC 60950
<b>EMC</b>	
Emissions	CISPR22 Class A, EN55022 Class A, FCC Part 15 Subpart B Class A, ICES-003 Class A, AS/NZS 3548 Class A, EN61000-3-2, EN61000-3-3
Immunity	EN 55024
<b>Heat Dissipation</b>	
80 watts maximum (275 BTU/hour maximum)	
<b>Power Supply</b>	
AC Line Frequency	50/60 Hz
Input Voltage Options	90–240 VAC
Current Rating	2.3 A (amps)(maximum)

(continued)

---

Standards Supported	<b>SNMP</b>	<b>Terminal Emulation</b>
	SNMP protocol (RFC 1157)	Telnet (RFC 854)
	MIB II Traps (RFC 1215)	<b>Protocols Used for Administration</b>
	MIB-II (RFC 1213)	UDP (RFC 768)
	Bridge MIB (RFC 1493)	IP (RFC 791)
	Bridge extensions (RFC 2674)	ICMP (RFC 792)
	RMON MIB II (RFC 2021)	TCP (RFC 793)
	Remote Monitoring MIB (RFC 1757)	ARP (RFC 826)
	RS232 (RFC 1659)	TFTP (RFC 783)
	Interfaces (RFC 2233)	DHCP (RFC 2131, RFC 2132, RFC 1534)
	MAU MIB (RFC 2239)	BOOTP (RFC 951, RFC 1497)
	Ether-like MIB (RFC 2665)	Link aggregation (IEEE 802.3ad)
	MAU MIB (RFC 2668)	Network Login (IEEE 803.1x) *
		RADIUS (RFC 2618, 2620)*
		* Supported on a Switch 4400 and an upgraded Switch 4400 SE.

---

## Switch 4400 PWR (24-port)

<b>Physical Dimensions</b>	Height: 44 mm (1.7 in.) x Width: 440 mm (17.3 in.) x Depth: 295 mm (11.4 in.) Weight: 4.4 kg (9.7 lbs)	
<b>Environmental Requirements</b>		
Operating Temperature	0 ° to 40 °C (32 ° to 104 °F)	
Storage Temperature	-20 ° to +70 °C (-4 ° to 158 °F)	
Operating Humidity	10–95% relative humidity, non-condensing	
Standards	EN60068 to 3Com schedule (Package testing: paras 2.1, 2.2, 2.30, and 2.32. Operational testing: paras 2.1, 2.2, 2.30 and 2.13).	
<b>Safety</b>		
Agency Certifications	UL60950, EN60950, CSA 22.2 No. 60950, IEC 60950	
<b>EMC</b>		
Emissions	CISPR 22 Class A, EN55022 Class A, FCC Part 15 Subpart B Class A, ICES-003 Class A, AS/NZS 3548 Class A, EN61000-3-2, EN61000-3-3	
Immunity	EN 55024	
<b>Heat Dissipation</b>	170 watts maximum (580 BTU/hour maximum)	
<b>Power Supply</b>		
AC Line Frequency	50/60 Hz	
Input Voltage Options	100–240 VAC	
Current Rating	2.5 A (amps)(maximum)	
Standards Supported	<b>SNMP</b>	<b>Terminal Emulation</b>
	SNMP protocol (RFC 1157)	Telnet (RFC 854)
	MIB-II (RFC 1213)	<b>Protocols Used for Administration</b>
	Bridge MIB (RFC 1493)	UDP (RFC 768)
	RMON MIB II (RFC 2021)	IP (RFC 791)
	Remote Monitoring MIB (RFC 1757)	ICMP (RFC 792)
	MAU MIB (RFC 2239)	TCP (RFC 793)
	MAU MIB (RFC 2668)	ARP (RFC 826)
	MIB II Traps (RFC 1215)	TFTP (RFC 783)
	RS232 (RFC 1659)	DHCP (RFC 2131, RFC 2132, RFC 1534)
	Interfaces (RFC 2233)	BOOTP (RFC 951, RFC 1497)
	Ether-like MIB (RFC 2665)	Network Login (IEEE 803.1x)
	Bridge extensions (RFC 2674)	RADIUS (RFC 2618, 2620)
		Link aggregation (IEEE 802.3ad)

---

## Switch 4400 (48-port)

---

<b>Physical Dimensions</b>	Height: 44 mm (1.7 in.) x Width: 440 mm (17.3 in.) x Depth: 274 mm (10.8 in.) Weight: 3.2 kg (7.1 lbs)
----------------------------	---

---

### Environmental Requirements

Operating Temperature	0 ° to 40 °C (32 ° to 104 °F)
Storage Temperature	-40 ° to +70 °C (-40 ° to 158 °F)
Operating Humidity	10–95% relative humidity, non-condensing
Standards	EN60068 to 3Com schedule (Package testing: paras 2.1, 2.2, 2.30, and 2.32. Operational testing: paras 2.1, 2.2, 2.30 and 2.13).

---

### Safety

Agency Certifications	UL60950, EN60950, CSA 22.2 No. 60950, IEC 60950
-----------------------	---

---

### EMC

Emissions	CISPR 22 Class A, EN55022 Class A, FCC Part 15 Subpart B Class A, ICES-003 Class A, AS/NZS 3548 Class A, VCCI Class A, EN61000-3-2, EN61000-3-3
Immunity	EN 55024

---

<b>Heat Dissipation</b>	80 watts maximum (275 BTU/hour maximum)
-------------------------	---

---

### Power Supply

AC Line Frequency	50/60 Hz
Input Voltage Options	90–240 VAC
Current Rating	2.3 A (amps)(maximum)



Standards Supported	SNMP	Terminal Emulation
	SNMP protocol (RFC 1157)	Telnet (RFC 854)
	MIB-II (RFC 1213)	<b>Protocols Used for Administration</b>
	Bridge MIB (RFC 1493)	UDP (RFC 768)
	RMON MIB II (RFC 2021)	IP (RFC 791)
	Remote Monitoring MIB (RFC 1757)	ICMP (RFC 792)
	MAU MIB (RFC 2239)	TCP (RFC 793)
	MIB II Traps (RFC 1215)	ARP (RFC 826)
	RS232 (RFC 1659)	TFTP (RFC 783)
	Interfaces (RFC 2233)	DHCP (RFC 2131, RFC 2132, RFC 1534)
	Ether-like MIB (RFC 2665)	BOOTP (RFC 951, RFC 1497)
	MAU MIB (RFC 2668)	Network Login (IEEE 803.1x)
	Bridge extensions (RFC 2674)	RADIUS (RFC 2618, 2620)
		Link aggregation (IEEE 802.3ad)

## Switch 4400 FX

<b>Physical Dimensions</b>	Height: 44 mm (1.7 in.) x Width: 440 mm (17.3 in.) x Depth: 274 mm (10.8 in.) Weight: 2.8 kg (6.2 lbs)
<b>Environmental Requirements</b>	
Operating Temperature	0 ° to 40 °C (32 ° to 104 °F)
Storage Temperature	-40 ° to +70 °C (-40 ° to 158 °F)
Operating Humidity	10–95% relative humidity, non-condensing
Standards	EN60068 to 3Com schedule (Package testing: paras 2.1, 2.2, 2.30, and 2.32. Operational testing: paras 2.1, 2.2, 2.30 and 2.13).
<b>Safety</b>	
Agency Certifications	UL60950, EN60950, CSA 22.2 No. 60950, IEC 60950
<b>EMC</b>	
Emissions	CISPR 22 Class A, EN55022 Class A, FCC Part 15 Subpart B Class A, ICES-003 Class A, AS/NZS 3548 Class A, EN61000-3-2, EN61000-3-3
Immunity	EN 55024
<b>Heat Dissipation</b>	80 watts maximum (275 BTU/hour maximum)
<b>Power Supply</b>	
AC Line Frequency	50/60 Hz
Input Voltage Options	90–240 VAC
Current Rating	2.3 A (amps)(maximum)

(continued)

Standards Supported	<b>SNMP</b>	<b>Terminal Emulation</b>
	SNMP protocol (RFC 1157)	Telnet (RFC 854)
	MIB-II (RFC 1213)	<b>Protocols Used for Administration</b>
	Bridge MIB (RFC 1493)	UDP (RFC 768)
	RMON MIB II (RFC 2021)	IP (RFC 791)
	Remote Monitoring MIB (RFC 1757)	ICMP (RFC 792)
	MAU MIB (RFC 2239)	TCP (RFC 793)
	MIB II Traps (RFC 1215)	ARP (RFC 826)
	RS232 (RFC 1659)	TFTP (RFC 783)
	Interfaces (RFC 2233)	DHCP (RFC 2131, RFC 2132, RFC 1534)
	Ether-like MIB (RFC 2665)	BOOTP (RFC 951, RFC 1497)
	MAU MIB (RFC 2668)	Network Login (IEEE 803.1x)
	Bridge extensions (RFC 2674)	RADIUS (RFC 2618, 2620)
		Link aggregation (IEEE 802.3ad)

# D

## OBTAINING SUPPORT FOR YOUR PRODUCT

---

### Register Your Product to Gain Service Benefits

To take advantage of warranty and other service benefits, you must first register your product at <http://eSupport.3com.com/>. 3Com eSupport services are based on accounts that you create or have authorization to access. First time users must apply for a user name and password that provides access to a number of eSupport features including Product Registration, Repair Services, and Service Request.

---

### Purchase Value-Added Services

To enhance response times or extend warranty benefits, contact 3Com or your authorized 3Com reseller. Value-added services can include 24x7 telephone technical support, software upgrades, onsite assistance or advance hardware replacement. Experienced engineers are available to manage your installation with minimal disruption to your network. Expert assessment and implementation services are offered to fill resource gaps and ensure the success of your networking projects. More information on 3Com Extended Warranty and Professional Services is available at <http://www.3com.com/>

Contact your authorized 3Com reseller or 3Com for additional product and support information.

---

### Troubleshoot Online

You will find support tools posted on the 3Com web site at <http://www.3com.com/>

- **3Com Knowledgebase** helps you troubleshoot 3Com products. This query-based interactive tool is located at <http://knowledgebase.3com.com> and contains thousands of technical solutions written by 3Com support engineers.

- **Connection Assistant** helps you install, configure and troubleshoot 3Com desktop and server NICs, wireless cards and Bluetooth devices. This diagnostic software is located at:  
[http://www.3com.com/prodforms/software/connection\\_assistant/ca\\_thankyou.html](http://www.3com.com/prodforms/software/connection_assistant/ca_thankyou.html)

---

## Access Software Downloads

**Software Updates** are the bug fix / maintenance releases for the version of software initially purchased with the product. In order to access these Software Updates you must first register your product on the 3Com web site at <http://eSupport.3com.com/>.

First time users will need to apply for a user name and password. A link to software downloads can be found at <http://eSupport.3com.com/>, or under the Product Support heading at <http://www.3com.com/>

**Software Upgrades** are the software releases that follow the software version included with your original product. In order to access upgrades and related documentation you must first purchase a service contract from 3Com or your reseller.

---

## Contact Us

3Com offers telephone, e-mail and internet access to technical support and repair services. To access these services for your region, use the appropriate telephone number, URL or e-mail address from the list below. You will find a current directory of support telephone numbers posted on the 3Com web site at <http://csoweb4.3com.com/contactus/>

---

## Telephone Technical Support and Repair

To obtain telephone support as part of your warranty and other service benefits, you must first register your product at <http://eSupport.3com.com/>

When you contact 3Com for assistance, please have the following information ready:

- Product model name, part number, and serial number
- A list of system hardware and software, including revision level
- Diagnostic error messages
- Details about recent configuration changes, if applicable

To send a product directly to 3Com for repair, you must first obtain a return authorization number (RMA). Products sent to 3Com, without authorization numbers clearly marked on the outside of the package, will be returned to the sender unopened, at the sender's expense. If your product is registered and under warranty, you can obtain an RMA number online at <http://eSupport.3com.com/>. First time users will need to apply for a user name and password.

Telephone numbers are correct at the time of publication. Find a current directory of support telephone numbers posted on the 3Com web site at <http://csoweb4.3com.com/contactus/>

Country	Telephone Number	Country	Telephone Number
<b>Asia, Pacific Rim Telephone Technical Support and Repair</b>			
Australia	1 800 678 515	Philippines	1235 61 266 2602 or
Hong Kong	800 933 486		1800 1 888 9469
India	+61 2 9424 5179 or	P.R. of China	10800 61 00137 or
	000800 650 1111		021 6350 1590 or
Indonesia	001 803 61009		00800 0638 3266
Japan	00531 616 439 or	Singapore	800 6161 463
	03 5977 7991	S. Korea	080 333 3308
Malaysia	1800 801 777	Taiwan	00801 611 261
New Zealand	0800 446 398	Thailand	001 800 611 2000
Pakistan	+61 2 9937 5083		

You can also obtain support in this region using the following e-mail: [apr\\_technical\\_support@3com.com](mailto:apr_technical_support@3com.com)

Or request a repair authorization number (RMA) by fax using this number: + 65 543 6348

#### Europe, Middle East, and Africa Telephone Technical Support and Repair

From anywhere in these regions, call: +44 (0)1442 435529

From the following countries, you may use the numbers shown:

Austria	01 7956 7124	Luxembourg	342 0808128
Belgium	070 700 770	Netherlands	0900 777 7737
Denmark	7010 7289	Norway	815 33 047
Finland	01080 2783	Poland	00800 441 1357
France	0825 809 622	Portugal	707 200 123
Germany	01805 404 747	South Africa	0800 995 014
Hungary	06800 12813	Spain	9 021 60455
Ireland	01407 3387	Sweden	07711 14453
Israel	1800 945 3794	Switzerland	08488 50112
Italy	199 161346	U.K.	0870 909 3266

You can also obtain support in this region using the following URL:

<http://emea.3com.com/support/email.html>

Country	Telephone Number	Country	Telephone Number
<b>Latin America Telephone Technical Support and Repair</b>			
Antigua	1 800 988 2112	Guatemala	AT&T +800 998 2112
Argentina	0 810 444 3COM	Haiti	57 1 657 0888
Aruba	1 800 998 2112	Honduras	AT&T +800 998 2112
Bahamas	1 800 998 2112	Jamaica	1 800 998 2112
Barbados	1 800 998 2112	Martinique	571 657 0888
Belize	52 5 201 0010	Mexico	01 800 849CARE
Bermuda	1 800 998 2112	Nicaragua	AT&T +800 998 2112
Bonaire	1 800 998 2112	Panama	AT&T +800 998 2112
Brazil	0800 13 3COM	Paraguay	54 11 4894 1888
Cayman	1 800 998 2112	Peru	AT&T +800 998 2112
Chile	AT&T +800 998 2112	Puerto Rico	1 800 998 2112
Colombia	AT&T +800 998 2112	Salvador	AT&T +800 998 2112
Costa Rica	AT&T +800 998 2112	Trinidad and Tobago	1 800 998 2112
Curacao	1 800 998 2112	Uruguay	AT&T +800 998 2112
Ecuador	AT&T +800 998 2112	Venezuela	AT&T +800 998 2112
Dominican Republic	AT&T +800 998 2112	Virgin Islands	57 1 657 0888

You can also obtain support in this region using the following:

Spanish speakers, enter the URL:

**<http://lat.3com.com/lat/support/form.html>**

Portuguese speakers, enter the URL:

**<http://lat.3com.com/br/support/form.html>**

English speakers in Latin America should send e-mail to:

**[lat\\_support\\_anc@3com.com](mailto:lat_support_anc@3com.com)**

---

### **US and Canada Telephone Technical Support and Repair**

1 800 876 3266

---

# INDEX

---

## Numbers

3C number 26

---

## A

access levels of default users 55  
 automatic setup 46  
     3Com Network Supervisor 46  
     console port 46

---

## B

browsers  
     choosing 53

---

## C

cable  
     choosing the correct 32  
     pin-outs 73  
 cascade cable 27  
 Cascade Extender Kit 27  
 Cascade Stacking Kit 27  
 CD-ROM 10  
 command line interface  
     management 49  
 console port 19  
 conventions  
     notice icons, About This Guide 8  
     text, About This Guide 8  
 cross-over configuration 32

---

## D

default  
     settings 20  
     users 55  
 documentation  
     related 9

---

## E

Ethernet address of the Switch 26

---

## F

factory defaults 20

---

## H

hardware features 14

---

## I

installing the Switch 23  
     prerequisites 24  
 IP addressing  
     registered 62  
 IP configuration 37

---

## L

LEDs 17  
 logging in as a default user 55

---

## M

MAC address of the Switch 26  
 management  
     methods 49  
     preparing for 38  
     setting up 35, 36  
 manual setup  
     console port 42  
     front panel port 39  
 MDI configuration 32  
 MDIX configuration 32

---

## P

passwords  
     of default users 55  
 pin assignments  
     modem cable 74  
     null modem cable 73  
     RJ45 74  
     serial cable 73  
 pin-outs 73  
 ports 16  
     console 19  
 power over ethernet  
     using 31  
 power socket 19  
 powering-up a Switch 4400 30  
 problem solving 57  
     communication problems 62  
     hardware problems 59

- IP addressing 59
- LEDs 58
- product name 26

---

## R

- rack mounting a Switch 4400 25
- Redundant Power System. *See* RPS
- related documentation 9
- RPS 19
  - connecting 30
  - socket 19

---

## S

- safety information
  - English 66
  - French 68
  - German 70
- serial number of the Switch 26
- serial port. *See* console port
- Simple Network Management Protocol. *See* SNMP
- SNMP 54
- SNMP management 50
  - setting up 54
- socket
  - power 19
  - RPS 19
- specifications, system 77
- SSH 52
- straight-through configuration 32
- Switch
  - automatic setup 46
- Switch 4400
  - 3C number 26
  - console port 19
  - dimensions 77
  - Ethernet address 26
  - features 14
  - installation 23, 24
  - MAC address 26
  - power socket 19
  - powering-up 30
  - product name 26
  - rack mounting 25
  - RPS socket 19
  - serial number 26
  - size 77
  - stacking 27
    - unit information label 26
  - weight 77
- system specifications 77

---

## T

- troubleshooting 57

---

## U

- unit information label 26

---

## W

- Web browsers
  - choosing 53
- web interface
  - choosing a browser 53
- web interface management 50
  - setting up 53



## REGULATORY NOTICES

---

### FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference to radio communications, in which case the user will be required to correct the interference at their own expense.

### INFORMATION TO THE USER

If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient the receiving antenna.
- Relocate the equipment with respect to the receiver.
- Move the equipment away from the receiver.
- Plug the equipment into a different outlet so that equipment and receiver are on different branch circuits.

If necessary, the user should consult the dealer or an experienced radio/television technician for additional suggestions. The user may find the following booklet prepared by the Federal Communications Commission helpful:

*How to Identify and Resolve Radio-TV Interference Problems*

This booklet is available from the U.S. Government Printing Office, Washington, DC 20402, Stock No. 004-000-00345-4.

In order to meet FCC emissions limits, this equipment must be used only with cables which comply with IEEE 802.3.

### CSA STATEMENT

This Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe A respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

### CE STATEMENT (EUROPE)

This product complies with the European Low Voltage Directive 73/23/EEC and EMC Directive 89/336/EEC as amended by European Directive 93/68/EEC.

Warning: This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

### VCCI STATEMENT

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

