



## MODEL G0513X2 17" BANDSAW MANUAL INSERT


The Model G0513X2 is the same machine as the Model G0513X except for the cast iron trunnion assembly. Except for details given in this insert, the content in the Model G0513X owner's manual is the same for both machines. Before operating your new machine, you **MUST** read and understand this insert and the entire Model G0513X manual to reduce the risk of injury from improper use or setup.

*If you have any further questions about this manual insert or the differences between the Model G0513X2 and the Model G0513X, contact our Technical Support at (570) 546-9663 or email [techsupport@grizzly.com](mailto:techsupport@grizzly.com).*




COPYRIGHT © MAY, 2007 BY GRIZZLY INDUSTRIAL, INC.  
**WARNING: NO PORTION OF THIS MANUAL MAY BE REPRODUCED IN ANY SHAPE  
OR FORM WITHOUT THE WRITTEN APPROVAL OF GRIZZLY INDUSTRIAL, INC.**  
#BL9289 PRINTED IN TAIWAN

# G0513X2 Main Parts



## G0513X2 Fence/Guides Parts



# G0513X2 Parts List

REF	PART #	DESCRIPTION
1	P0513X001	BUSHING
2	PSS01M	SET SCREW M6-1 X 10
3	P0513X003	BUSHING
4	P0513004	LIFTING EYE BOLT M10-1.5
5	P0513005	MACHINE BODY
6	PSS07M	SET SCREW M5-.8 X 5
7	P0513X007	BUSHING
8	PW03M	FLAT WASHER 6MM
9	PWRCRD220L	POWER CORD
10	PN01M	HEX NUT M6-1
11	P0513011	POINTER
12	P0513012	SHOULDER SCREW M4-.7 X 5
13	P0513013	UPPER SHAFT
14	PRP10M	ROLL PIN 5 X 36
15	P0513015	UPPER WHEEL SHAFT HINGE
16	P0513016	UPPER WHEEL SHAFT
17	P0513017	BUSHING
18	P6204LLU	BALL BEARING 6204LLU
19	P0513X019	UPPER WHEEL 17"
20	PR25M	INT RETAINING RING 47MM
21	P0513X021	SPECIAL WASHER 8MM
22	PSB11M	CAP SCREW M8-1.25 X 16
23	P0513023	SAW BLADE 1/2" X 131.5"
24	PLW04M	LOCK WASHER 8MM
25	PSB14M	CAP SCREW M8-1.25 X 20
26	P0513X026	TIRE
27	P0513X027	LOWER WHEEL 17"
28	P0513X028	IDLE PULLEY
29	PN32	HEX NUT 1-14
30	PLW09	LOCK WASHER 1"
31	PWRCRD220S	MOTOR CORD
32	P0513032	COMPRESSION SPRING
33	PRP02M	ROLL PIN 3 X 16
34	P0513034	LOCATE BLOCK
35	P51201	THRUST BEARING 51201
36	P0513036	SWITCH
37	P0513037	HANDWHEEL
38	P0513038	ADJUSTING BOLT
39	PFS07M	FLANGE SCREW M5-.8 X 10
40	PTLW02M	EXT TOOTH WASHER 5MM
41	PN06M	HEX NUT M5-.8
42	PFS08M	FLANGE SCREW M5-.8 X 16
43	P0513043	SWITCH PLATE
44	PSB11M	CAP SCREW M8-1.25 X 16
45	P0513X045	FENDER WASHER 8MM
46	P0513046	UPPER WHEEL SLIDING BRACKET
47	PSB05M	CAP SCREW M6-1 X 50
48	P0513048	RIVET 3.2 X 10
49	PSB04M	CAP SCREW M6-1 X 10
50	P0513050	CLEAR WINDOW
51	P0513X051	TRUNNION PLATE
52	PLW04M	LOCK WASHER 8MM
53	PB03M	HEX BOLT M8-1.25 X 16

REF	PART #	DESCRIPTION
54	PCB23M	CARRIAGE BOLT M8-1.25 X 80
55	P0513055	UPPER WHEEL COVER
56	PB10M	HEX BOLT M6-1 X 25
57	PW03M	FLAT WASHER 6MM
58	P0513058	BRUSH
59	PSB06M	CAP SCREW M6-1 X 25
60	P0513X060	STAR HANDLE
61	PLN03M	LOCK NUT 6MM
62	P0513062	STRAIN RELIEF 16MM
63	P0513063	HEIGHT POINTER
64	PN03M	HEX NUT M8-1.25
65	PB124M	HEX BOLT M8-1.25 X 90
66	P0513066	KNOB SCREW M10-1.5 X 20
67	P0513067	KNOB SCREW M10-1.5 X 55
68	P0513068	THREADED HANDLE 10MM
69	P0513069	CAM
70	P0513070	PILLOW BLOCK
71	P0513071	HANDLE M10-1.5
72	P0513072	LEVER ROD
73	PN09M	HEX NUT M12-1.75
74	P0513074	SHAFT
75	PSBS01M	BUTTON HD CAP SCR M8-1.25 X 20
76	PLW04M	LOCK WASHER 8MM
77	PSB02M	CAP SCREW M6-1 X 20
78	P0513078	COVER
79	PSS09M	SET SCREW M8-1.25 X 20
80	PN03M	HEX NUT M8-1.25
81	P0513081	LOWER WHEEL SHAFT
82	P0513082	MOTOR 2HP 110/220V
82-1	P0513X082-1	MOTOR FAN COVER
82-2	P0513X082-2	MOTOR FAN
82-3	P0513X082-3	CAPACITOR COVER
82-4	P0513X082-4	R. CAPACITOR 40M 250VAC
82-5	P0513X082-5	WIRING BOX
82-6	P0513X082-6	CAPACITOR COVER
82-7	P0513X082-7	S. CAPACITOR 200M 250VAC
83	PB32M	HEX BOLT M10-1.5 X 25
84	PLW06M	LOCK WASHER 10MM
85	P0513085	MOTOR BRACKET
86	PSBS01M	BUTTON HD CAP SCR M8-1.25 X 20
87	P0513087	PLATE
88	PFS07M	FLANGE SCREW M5-.8 X 10
89	P0513089	PILLOW BLOCK
90	PK15M	KEY 5 X 5 X 35
91	PB81M	HEX BOLT M8-1.25 X 20 LH
92	P0513092	MOTOR PULLEY
93	PVA42	V-BELT A-42 4L420
94	PSB04M	CAP SCREW M6-1 X 10
95	P0513095	LOWER WHEEL COVER
96	PFH31M	FLAT HD SCR M4-.7 X 8
97	P0513X045	FENDER WASHER 8MM
98	PSB84M	CAP SCREW M10-1.5 X 35





REF	PART #	DESCRIPTION
99	PN02M	HEX NUT M10-1.5
100	P0513100	SMALL GEAR
101	P0513X101	LOCK HANDLE
102	P0513102	TRUNNION SUPPORT BRACKET
103	PLW06M	LOCK WASHER 10MM
104	PW04M	FLAT WASHER 10MM
105	PB18M	HEX BOLT M6-1 X 20
106	PSB37M	CAP SCREW M6-1 X 50
107	P0513107	PILLOW BLOCK
108	PN01M	HEX NUT M6-1
109	P0513109	ADJUST BOLT M6
110	P6000	BALL BEARING 6000ZZ
111	PSB02M	CAP SCREW M6-1 X 20
112	PW01M	FLAT WASHER 8MM
113	PW01M	FLAT WASHER 8MM
114	PS17M	PHLP HD SCR M4-.7 X 6
115	P0513115	GEAR PLATE
116	PLN04M	LOCK NUT M8-1.25
117	PS17M	PHLP HD SCR M4-.7 X 6
118	P0513118	LOCK HANDLE
119	PW05M	FLAT WASHER 4MM
120	P0513120	POINTER
121	P0513X121	FENCE SET ASSY L=590
121-1	PH7588001	FIXED BASE 640MM
121-2	PH7587002	ADJUST BASE
121-3	PH7587003	FIXED SHAFT
121-4	PH7587004	SHAFT
121-5	PH7587005	SPRING PIECE
121-6	PH7528004	LOCK HANDLE M8 X 44
121-7	PH7588007	SUPPORT TUBE 590MM
121-8	PW01M	FLAT WASHER 8MM
121-9	PH7587009	FENCE HANDLE M8-1.25 X 22
121-10	PH7587010	RAIL PAD
121-11	PH7587011	CONVEX
121-12	PSB69M	CAP SCREW M6-1 X 25
121-13	PH7587013	FIXED LUMP
121-14	PH7588014	SQUARE TUBE 640MM
121-15	PN03M	HEX NUT M8-1.25
121-16	PFS04M	FLANGE SCREW M4-.7 X 6
121-17	PH7587017	GUARD PIECE
121-18	PH7528002	MOVING PLATE
121-19	PH7587019	PLUG
121-20	PHTEK3M	TAP SCREW M3.5 X 8
121-21	PH7587021	SCALE
121-22	PN01M	HEX NUT M6-1
121-23	PLW03M	LOCK WASHER 6MM
121-24	PSB01M	CAP SCREW M6-1 X 16
121-25	PB08M	HEX BOLT M6-1 X 20
121-26	PFB13M	FLANGE BOLT M4-.7 X 8
121-27	PW03M	FLAT WASHER 6MM
121-28	PH7588028	RESAW FENCE (AL) 590MM
121-29	PH7587029	SPACER PLATE
122	P0513X122	GEAR
123	P0513X123	FIXED BOLT
124	P0513X124	COVER
125	PSB11M	CAP SCREW M8-1.25 X 16
126	P0513X126	TABLE 17" X 24"

REF	PART #	DESCRIPTION
127	P0513X127	TABLE INSERT
128	P0513X128	TABLE PIN
129	P0513X129	LOCATE BUSHING
130	P0513X130	BUSHING
131	PSBS01M	BUTTON HD CAP SCR M8-1.25 X 20
132	PLW04M	LOCK WASHER 8MM
133	P0513X133	GUIDE BRACKET
134	P0513X134	WORM CYLINDER
135	P0513X135	FIXED PLATE
136	PSB50M	CAP SCREW M5-.8 X 10
137	PW02M	FLAT WASHER 5MM
138	P0513X138	PROTECTIVE COVER ASSY
139	PSB72M	CAP SCREW M10-1.5 X 30
140	P0513X140	SHOULDER SCREW
141	P0513X141	FIBER WASHER
142	P0513X142	SLIDING PLATE
143	PN04M	HEX NUT M4-.7
144	P0513X144	RACK
145	P0513X145	UPPER GUIDE HOSE
146	P0513X146	HANDWHEEL
147	PSB02M	CAP SCREW M6-1 X 20
148	PCB10M	CARRIAGE BOLT M8-1.25 X 85
149	PSB01M	CAP SCREW M6-1 X 16
150	P0513X150	BLADE ADJUSTMENT ASSY
150-1	PSB01M	CAP SCREW M6-1 X 16
150-2	P0513X150-2	UPPER GUIDE SUPPORT BLOCK
150-3	PSS01M	SET SCREW M6-1 X 10
150-4	P0513X150-4	ADJUST BAR
150-5	P0513X150-5	UPPER BLADE GUIDE SUPPORT
150-6	P0513X150-6	BIAS SHAFT
150-7	PR05M	EXT RETAINING RING 15MM
150-8	P6202	BALL BEARING 6202ZZ
150-9	P0513X150-9	HANDLE BUSHING
150-10	PSB48M	CAP SCREW M6-1 X 35
150-11	P0513X150-11	UPPER SPACING SLEEVE
151	P0513X151	BLADE ADJUSTMENT ASSY
151-5	P0513X151-5	LOWER BLADE GUIDE SUPPORT
151-6	PSB01M	CAP SCREW M6-1 X 16
151-7	P0513X151-7	BIAS SHAFT
151-8	PR05M	EXT RETAINING RING 15MM
151-9	P6202	BALL BEARING 6202ZZ
151-10	P0513X151-10	HANDLE BUSHING
151-11	PSB48M	CAP SCREW M6-1 X 35
152	P0513X152	MITER GAUGE ASSY
154	PS38M	PHLP HD SCR M4-.7 X 10
155	P0513X2155	CAST IRON TRUNNION ASSEMBLY
156	PW01M	FLAT WASHER 8MM
157	PLN04M	LOCK NUT M8-1.25
158	PS17M	PHLP HD SCR M4-.7 X 6
159	P0513115	GEAR PLATE
160	PFH32M	FLAT HD SCR M4-.7 X 6
161	PCB10M	CARRIAGE BOLT M8-1.25 X 85
162	P0513X2162	UPPER TRUNNION
163	PCB23M	CARRIAGE BOLT M8-1.25 X 80
164	P0513118	LOCK HANDLE M8-1.25
165	P0513X2165	ANGLE LABEL
166	PW01M	FLAT WASHER 8MM




REF	PART #	DESCRIPTION
167	PB07M	HEX BOLT M8-1.25 X 25
168	P0513X101	LOCK HANDLE M8-1.25
169	PW05M	FLAT WASHER 4MM
170	P0513120	POINTER
171	PS17M	PHLP HD SCR M4-.7 x 6
172	P0513109	ADJUST BOLT M6-1
173	PN01M	HEX NUT M6-1
174	P0513X2174	ADJUST PLATE
175	PFH01M	FLAT HD SCR M5-.8 X 15
176	PSB01M	CAP SCREW M6-1 X 16
177	PSB37M	CAP SCREW M6-1 X 50

REF	PART #	DESCRIPTION
178	P0513X2178	TRUNNION SUPPORT BRACKET
179	P0513100	SMALL GEAR
180	PSBS19M	BUTTON HD CAP SCR M10-1.5 X 30
181	P0513X2181	RIGHT COVER
182	P6000	BALL BEARING 6000ZZ
183	PW04M	FLAT WASHER 10MM
184	P0513X2184	LEFT COVER
185	P0513X2185	ADJUST BLOCK
186	PLW04M	LOCK WASHER 8MM
187	PSB97M	CAP SCREW M5-.8 X 6

## G0513X2 Labels

### WARNING

Safety labels warn about machine hazards and ways to prevent injury. The owner of this machine **MUST** maintain the original location and readability of the labels on the machine. If any label is removed or becomes unreadable, **REPLACE** that label before using the machine again. Contact Grizzly at (800) 523-4777 or [www.grizzly.com](http://www.grizzly.com) to order new labels.



REF	PART #	DESCRIPTION
201	P0513X2201	G0513X2 MODEL # LABEL
202	G8588	GRIZZLY LOGO PLATE
203	PLABEL-20	OPEN DOOR LABEL
204	P0513X204	GUARD ADJ LABEL
205	P0513X205	SCALE DIRECTIONS LABEL
206	PLABEL-11	SAFETY GLASSES LABEL
207	PLABEL-19	HANDS/BLADE LABEL
208	PLABEL-12	READ MANUAL LABEL

REF	PART #	DESCRIPTION
209	PLABEL-14	ELECTRICITY LABEL
210	P0513X210	EXTREME SERIES PLATE
211	PLABEL-18	DISCONNECT POWER LABEL
212	PLABEL-20	OPEN DOOR LABEL
213	PPAINT-11	"PUTTY" PAINT
214	P0513X214	TENSION ADJ LABEL
215	PPAINT-1	"GRIZZLY GREEN" PAINT
216	P0513X2216	MACHINE ID LABEL





# MACHINE DATA SHEET

Customer Service #: (570) 546-9663 • To Order Call: (800) 523-4777 • Fax #: (800) 438-5901

## MODEL G0513X2 17" BANDSAW w/CAST IRON TRUNNIONS

### Product Dimensions:

Weight ..... 345 lbs.  
Length/Width/Height ..... 32" x 32" x 73"  
Foot Print (Length/Width)..... 27" x 17<sup>3</sup>/<sub>4</sub>"

### Shipping Dimensions:

Type ..... Wood Slat Crate  
Content..... Machine  
Weight..... 414 lbs.  
Length/Width/Height..... 31" x 20" x 81"

### Electrical:

Switch..... ON/OFF Push Button  
Switch Voltage ..... 110/220V  
Cord Length ..... 6 ft.  
Cord Gauge ..... 14 gauge  
Recommended Breaker Size ..... 30 amps at 110V, 15 amps at 220V  
Recommended Plug Type ..... L5-30 at 110V, 6-15 at 220V  
Plug Included ..... No

### Motor:

Type ..... TEFC Capacitor Start Induction  
Horsepower..... 2 HP  
Voltage ..... 110/220V  
Prewired..... 220V  
Phase..... Single  
Amps..... 20/10A  
Speed..... 1725 RPM  
Cycle ..... 60 Hz  
Number Of Speeds ..... 1  
Power Transfer ..... Belt Drive  
Bearings..... Shielded and Permanently Lubricated

### Main Specifications:

#### Operation Information

Blade Speed..... 1700, 3500 FPM  
Table Tilt..... Left 5°, Right 45°

#### Cutting Capacities

Maximum Cutting Height..... 12"  
Throat Capacity Left of Blade..... 16<sup>1</sup>/<sub>4</sub>"

#### Blade Information

Standard Blade Length..... 131<sup>1</sup>/<sub>2</sub>"  
Blade Width Range ..... <sup>1</sup>/<sub>8</sub>"-1"  
Blade Guides..... Ball Bearing



**Table Information**

Table Length .....	23 <sup>5</sup> / <sub>8</sub> "
Table Width .....	17 <sup>1</sup> / <sub>4</sub> "
Table Thickness .....	1 <sup>1</sup> / <sub>2</sub> "
Floor to Table Height.....	37 <sup>1</sup> / <sub>2</sub> "

**Fence Information**

Locks in Front.....	Yes
Locks in Rear .....	No
Adjustable for Blade Lead .....	Yes
Resaw Fence Plate Height.....	6"

**Dust Collection**

Number of Dust Ports.....	2
Size of Dust Ports .....	4"
Required CFM at Each Dust Port .....	400 CFM

**Construction Materials**

Table.....	Precision Ground Cast Iron
Table Trunnions .....	Cast Iron
Rip Fence .....	Cast Iron
Resaw Fence .....	Deluxe Extruded Aluminum
Wheels.....	Computer Balanced Cast Iron
Tire Material .....	Rubber
Wheel Cover.....	Pre-Formed Steel
Body .....	One Piece Reinforced Steel
Paint .....	Powder Coated

**Other Specifications:**

Country Of Origin .....	Taiwan
Warranty.....	1 Year
Serial Number Location .....	ID Label on Upper Wheel Cover
Assembly & Setup Time .....	1 Hour

**Features:**

Cast Iron Table Trunnions  
Ball Bearing Blade Guides  
Quick Change Blade Release/Tensioner  
Micro-Adjusting Rack & Pinion Table Tilt  
Rack & Pinion Upper Blade Guide Height Adjustment  
Computer Balanced Cast Iron Wheels  
Blade Tension Indicator  
Magnifying Window over Fence Scale  
Height Scale for Upper Blade Guides  
Blade Tracking Window  
Hinged Wheel Covers  
Deluxe Cast Iron Fence with Extruded Aluminum Resaw Fence Attachment  
Included Miter Gauge  
Included 1/2" Blade  
Two 4" Dust Ports





# MODEL G0513X/G0514X/G0514X3 EXTREME SERIES BANDSAW OWNER'S MANUAL



COPYRIGHT © JANUARY, 2006 BY GRIZZLY INDUSTRIAL, INC. REVISED FEBRUARY, 2007 (TR)

**WARNING: NO PORTION OF THIS MANUAL MAY BE REPRODUCED IN ANY SHAPE  
OR FORM WITHOUT THE WRITTEN APPROVAL OF GRIZZLY INDUSTRIAL, INC.**

#EWTR7787 PRINTED IN TAIWAN



## **WARNING!**

**This manual provides critical safety instructions on the proper setup, operation, maintenance and service of this machine/equipment.**

**Failure to read, understand and follow the instructions given in this manual may result in serious personal injury, including amputation, electrocution or death.**

**The owner of this machine/equipment is solely responsible for its safe use. This responsibility includes but is not limited to proper installation in a safe environment, personnel training and usage authorization, proper inspection and maintenance, manual availability and comprehension, application of safety devices, blade/cutter integrity, and the usage of personal protective equipment.**

**The manufacturer will not be held liable for injury or property damage from negligence, improper training, machine modifications or misuse.**



## **WARNING!**

**Some dust created by power sanding, sawing, grinding, drilling, and other construction activities contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm. Some examples of these chemicals are:**

- **Lead from lead-based paints.**
- **Crystalline silica from bricks, cement and other masonry products.**
- **Arsenic and chromium from chemically-treated lumber.**

**Your risk from these exposures varies, depending on how often you do this type of work. To reduce your exposure to these chemicals: Work in a well ventilated area, and work with approved safety equipment, such as those dust masks that are specially designed to filter out microscopic particles.**



# Table of Contents

<b>INTRODUCTION .....</b>	<b>3</b>
Foreword .....	3
Contact Info .....	3
G0513X Machine Data Sheet .....	4
G0514X Machine Data Sheet .....	6
G0514X3 Machine Data Sheet .....	8
Identification .....	10
<b>SECTION 1: SAFETY .....</b>	<b>11</b>
Safety Instructions for Machinery .....	11
Additional Safety Instructions for Bandsaws .....	13
<b>SECTION 2: CIRCUIT REQUIREMENTS .....</b>	<b>14</b>
Operation .....	14
Grounding .....	15
Extension Cords .....	15
Phase Converter .....	15
<b>SECTION 3: SET UP .....</b>	<b>16</b>
Set Up Safety .....	16
Items Needed for Set Up .....	16
Unpacking .....	16
Inventory .....	17
Hardware Recognition Chart .....	18
Clean Up .....	19
Site Considerations .....	19
Moving & Placing Base Unit .....	20
Mounting .....	20
Table .....	21
Blade Tracking .....	22
Positive Stop .....	23
Dust Collection .....	24
Installing Fence .....	25
Test Run .....	26
Tensioning Blade .....	27
Adjusting Support Bearings .....	27
Adjusting Blade Guide Bearings .....	29
Aligning Table .....	30
Aligning Fence .....	31
Miter Gauge .....	31
<b>SECTION 4: OPERATIONS .....</b>	<b>32</b>
Operation Safety .....	32
Overview .....	32
START/STOP Switch .....	33
Guide Post .....	33
Fine Tune Tracking .....	34
Blade Lead .....	34
Table Tilt .....	35
Ripping .....	36
Crosscutting .....	36
Resawing .....	37
Cutting Curves .....	38
Stacked Cuts .....	38
Blade Speed .....	39
Blade Information .....	40
Blade Changes .....	42

<b>SECTION 5: ACCESSORIES .....</b>	<b>43</b>
<b>SECTION 6: MAINTENANCE .....</b>	<b>45</b>
Schedule .....	45
Cleaning .....	45
Unpainted Cast Iron .....	45
Lubrication.....	45
Wheel Brush.....	45
<b>SECTION 7: SERVICE .....</b>	<b>46</b>
Troubleshooting.....	46
Checking V-Belt .....	48
Tensioning V-Belt.....	48
Replacing V-Belt .....	49
Adjusting Tension Lever.....	50
Adjusting Wheel Brush.....	50
Wheel Alignment .....	51
G0513X Electrical Components .....	53
G0513X Wiring Diagram .....	54
G0514X Electrical Components .....	55
G0514X Wiring Diagram .....	56
G0514X3 Electrical Components .....	57
G0514X3 Wiring Diagram .....	58
G0513X Main Parts.....	59
G0513X Fence/Guide Parts .....	60
G0513X Parts List.....	61
G0513X Labels .....	63
G0514X/G0514X3 Main Parts.....	64
G0514X/G0514X3 Fence/Guide Parts.....	65
G0514X/G0514X3 Labels .....	66
G0514X/G0514X3 Parts List.....	67
<b>WARRANTY AND RETURNS .....</b>	<b>70</b>

# INTRODUCTION

---

## Foreword

---

We are proud to offer the Model G0513X/G0514X/G0514X3 Extreme Series Bandsaw. This machine is part of a growing Grizzly family of fine wood-working machinery. When used according to the guidelines set forth in this manual, you can expect years of trouble-free, enjoyable operation and proof of Grizzly's commitment to customer satisfaction.

We are pleased to provide this manual with the Model G0513X/G0514X/G0514X3. It was written to guide you through assembly, review safety considerations, and cover general operating procedures. It represents our effort to produce the best documentation possible.

The specifications, drawings, and photographs illustrated in this manual represent the Model G0513X/G0514X/G0514X3 as supplied when the manual was prepared. However, owing to Grizzly's policy of continuous improvement, changes may be made at any time with no obligation on the part of Grizzly. For your convenience, we always keep current Grizzly manuals available on our website at **[www.grizzly.com](http://www.grizzly.com)**. Any updates to your machine will be reflected in these manuals as soon as they are complete. Visit our site often to check for the latest updates to this manual!

## Contact Info

---

If you have any comments regarding this manual, please write to us at the address below:

Grizzly Industrial, Inc.  
c/o Technical Documentation Manager  
P.O. Box 2069  
Bellingham, WA 98227-2069

We stand behind our machines. If you have any service questions or parts requests, please call or write us at the location listed below.

Grizzly Industrial, Inc.  
1203 Lycoming Mall Circle  
Muncy, PA 17756  
Phone: (570) 546-9663  
Fax: (800) 438-5901  
E-Mail: [techsupport@grizzly.com](mailto:techsupport@grizzly.com)  
Web Site: <http://www.grizzly.com>





# MACHINE DATA SHEET

Customer Service #: (570) 546-9663 · To Order Call: (800) 523-4777 · Fax #: (800) 438-5901

## MODEL G0513X 17" 2 HP EXTREME SERIES BANDSAW

### Product Dimensions:

Weight..... 345 lbs.  
Length/Width/Height..... 32 x 32 x 73 in.  
Foot Print (Length/Width)..... 27 x 17-3/4 in.

### Shipping Dimensions:

Type..... Wood Slat Crate  
Content..... Machine  
Weight..... 414 lbs.  
Length/Width/Height..... 31 x 20 x 81 in.

### Electrical:

Switch..... On/Off Push Button  
Switch Voltage..... 110/220V  
Cord Length..... 6 ft.  
Cord Gauge..... 14 gauge  
Recommended Breaker Size..... 30 amps at 110V, 15 amps at 220V  
Plug..... No

### Motors:

#### Main

Type..... TEFC Capacitor Start Induction  
Horsepower..... 2 HP  
Voltage..... 110/220V  
Prewired..... 220V  
Phase..... Single  
Amps..... 20/10A  
Speed..... 1725 RPM  
Cycle..... 60 Hz  
Number Of Speeds..... 1  
Power Transfer..... Belt Drive  
Bearings..... Shielded and Permanently Lubricated

### Main Specifications:

#### Operation

Blade Speeds..... 1700, 3500 FPM  
Table Tilt..... Left 5, Right 45 deg.

#### Cutting Capacities

Height Capacity At Blade..... 12 in.  
Overall Height Capacity..... 12 in.  
Throat Capacity Left of Blade..... 16-1/4 in.

#### Blade Information

Standard Blade Length..... 131-1/2 in.  
Blade Width Range..... 1/8 - 1 in.  
Upper Blade Guides..... Ball Bearing  
Lower Blade Guides..... Ball Bearing

The information contained herein is deemed accurate as of 2/9/2007 and represents our most recent product specifications.  
Due to our ongoing improvement efforts, this information may not accurately describe items previously purchased.



**Table Information**

Table Length.....	23-5/8 in.
Table Width.....	17-1/4 in.
Table Thickness.....	1-1/2 in.
Floor to Table Height.....	37-1/2 in.

**Fence Information**

Locks in Front.....	Yes
Locks in Rear.....	No
Adjustable for Blade Lead.....	Yes

**Construction**

Table Construction.....	Precision Ground Cast Iron
Rip Fence .....	Cast Iron Fence with Extruded Aluminum Resaw Fence
Base Construction.....	Formed Steel
Body Construction.....	Formed Steel
Upper Wheel.....	Computer Balanced Cast Iron
Lower Wheel.....	Computer Balanced Cast Iron
Tire Material.....	Polyurethane
Wheel Cover .....	Pre-Formed Steel
Paint.....	Powder Coated

**Other Related Information**

Wheel Diameter.....	16-3/4 in.
Wheel Width.....	1-1/4 in.
Number of Dust Ports.....	2
Dust Port Size.....	4 in.
Mobile Base.....	G7314

**Other Specifications:**

ISO Factory .....	ISO 9001
Country Of Origin .....	Taiwan
Warranty .....	1 Year
Serial Number Location .....	Label on Top Cover
Assembly Time .....	1 hour

**Features:**

Ball Bearing Blade Guides  
Quick Change Blade Release/Tensioner  
Magnifying Window Over Fence Scale  
Micro Adjusting Geared Table  
Height Scale Measurement  
Blade Tracking Window  
Hinged Wheel Covers  
Deluxe Cast Iron Fence with Extruded Aluminum Resaw Fence  
Miter Gauge  
Includes 1/2" Blade

*The information contained herein is deemed accurate as of 2/9/2007 and represents our most recent product specifications.  
Due to our ongoing improvement efforts, this information may not accurately describe items previously purchased.*





# MACHINE DATA SHEET

Customer Service #: (570) 546-9663 · To Order Call: (800) 523-4777 · Fax #: (800) 438-5901

## MODEL G0514X 19" 3 HP EXTREME SERIES BANDSAW

### Product Dimensions:

Weight..... 383 lbs.  
Length/Width/Height..... 36 x 32 x 76 in.  
Foot Print (Length/Width)..... 29-1/2 x 17-3/4 in.

### Shipping Dimensions:

Type..... Wood Slat Crate  
Content..... Machine  
Weight..... 460 lbs.  
Length/Width/Height..... 21 x 33 x 85 in.

### Electrical:

Switch..... Magnetic with Thermal Overload Protection  
Switch Voltage..... 220V  
Cord Gauge..... 14 gauge  
Recommended Breaker Size..... 20 amp  
Plug..... No

### Motors:

#### Main

Type..... TEFC Capacitor Start Induction  
Horsepower..... 3 HP  
Voltage..... 220V  
Prewired..... 220V  
Phase..... Single  
Amps..... 16A  
Speed..... 1725 RPM  
Cycle..... 60 Hz  
Number Of Speeds..... 1  
Power Transfer ..... Belt Drive  
Bearings..... Shielded and Permanently Lubricated

### Main Specifications:

#### Operation

Blade Speeds..... 1700, 3500 FPM  
Table Tilt..... Left 5, Right 45 deg.

#### Cutting Capacities

Height Capacity At Blade..... 12 in.  
Overall Height Capacity..... 12 in.  
Throat Capacity Left of Blade..... 18-1/4 in.

#### Blade Information

Standard Blade Length..... 143 in.  
Blade Width Range..... 1/8 - 1-1/4 in.  
Upper Blade Guides..... Ball Bearing  
Lower Blade Guides..... Ball Bearing

The information contained herein is deemed accurate as of 2/9/2007 and represents our most recent product specifications.  
Due to our ongoing improvement efforts, this information may not accurately describe items previously purchased.





**Table Information**

Table Length.....	26-3/4 in.
Table Width.....	19 in.
Table Thickness.....	1-1/2 in.
Floor to Table Height.....	37-1/2 in.

**Fence Information**

Locks in Front.....	Yes
Locks in Rear.....	No
Adjustable for Blade Lead.....	Yes

**Construction**

Table Construction.....	Precision Ground Cast Iron
Rip Fence .....	Cast Iron Fence with Extruded Aluminum Resaw Fence
Base Construction.....	Formed Steel
Body Construction.....	Formed Steel
Upper Wheel.....	Computer Balanced Cast Iron
Lower Wheel.....	Computer Balanced Cast Iron
Tire Material.....	Polyurethane
Wheel Cover .....	Pre-Formed Steel
Paint.....	Powder Coated

**Other Related Information**

Wheel Diameter.....	18-7/8 in.
Wheel Width.....	1-1/4 in.
Number of Dust Ports.....	2
Dust Port Size.....	4 in.

**Other Specifications:**

ISO Factory .....	ISO 9001
Country Of Origin .....	Taiwan
Warranty .....	1 Year
Serial Number Location .....	Label on Top Cover
Assembly Time .....	1 hour

**Features:**

Blade Tension Indicator  
Micro Adjusting Gear Table  
Height Scale Measurement  
Fence with Scale and Magnifying Window  
Deluxe Cast Iron Fence with Extruded Aluminum Resaw Fence  
Miter Gauge  
Quick Change Blade Release/Tensioning  
Rack and Pinion Upper Guide Adjustment  
Includes 3/4" Blade  
Hinged Wheel Covers

*The information contained herein is deemed accurate as of 2/9/2007 and represents our most recent product specifications.  
Due to our ongoing improvement efforts, this information may not accurately describe items previously purchased.*





# MACHINE DATA SHEET

Customer Service #: (570) 546-9663 · To Order Call: (800) 523-4777 · Fax #: (800) 438-5901

## MODEL G0514X3 19" 3 HP 3-PHASE EXTREME SERIES BANDSAW

### Product Dimensions:

Weight..... 378 lbs.  
Length/Width/Height..... 36 x 32 x 76 in.  
Foot Print (Length/Width)..... 29-1/2 x 17-3/4 in.

### Shipping Dimensions:

Type..... Wood Slat Crate  
Content..... Machine  
Weight..... 456 lbs.  
Length/Width/Height..... 21 x 33 x 85 in.

### Electrical:

Switch..... Magnetic with Thermal Overload Protection  
Switch Voltage..... 220V  
Cord Gauge..... 14 gauge  
Recommended Breaker Size..... 10 amp  
Plug..... No

### Motors:

#### Main

Type..... TEFC Induction  
Horsepower..... 3 HP  
Voltage..... 220/440V  
Prewired..... 220V  
Phase..... Three  
Amps..... 9/4.5A  
Speed..... 1725 RPM  
Cycle..... 60 Hz  
Number Of Speeds..... 1  
Power Transfer ..... Belt Drive  
Bearings..... Shielded and Permanently Lubricated

### Main Specifications:

#### Operation

Blade Speeds..... 1700, 3500 FPM  
Table Tilt..... Left 5, Right 45 deg.

#### Cutting Capacities

Height Capacity At Blade..... 12 in.  
Overall Height Capacity..... 12 in.  
Throat Capacity Left of Blade..... 18-1/4 in.

#### Blade Information

Standard Blade Length..... 143 in.  
Blade Width Range..... 1/8 - 1-1/4 in.  
Upper Blade Guides..... Ball Bearing  
Lower Blade Guides..... Ball Bearing

The information contained herein is deemed accurate as of 2/9/2007 and represents our most recent product specifications.  
Due to our ongoing improvement efforts, this information may not accurately describe items previously purchased.



### Table Information

Table Length.....	26-3/4 in.
Table Width.....	19 in.
Table Thickness.....	1-1/2 in.
Floor to Table Height.....	37-1/2 in.

### Fence Information

Locks in Front.....	Yes
Locks in Rear.....	No
Adjustable for Blade Lead.....	Yes

### Construction

Table Construction.....	Precision Ground Cast Iron
Rip Fence .....	Cast Iron Fence with Extruded Aluminum Resaw Fence
Base Construction.....	Formed Steel
Body Construction.....	Formed Steel
Upper Wheel.....	Computer Balanced Cast Iron
Lower Wheel.....	Computer Balanced Cast Iron
Tire Material.....	Polyurethane
Wheel Cover .....	Pre-Formed Steel
Paint.....	Powder Coated

### Other Related Information

Wheel Diameter.....	18-7/8 in.
Wheel Width.....	1-1/4 in.
Number of Dust Ports.....	2
Dust Port Size.....	4 in.

### Other Specifications:

ISO Factory .....	ISO 9001
Country Of Origin .....	Taiwan
Warranty .....	1 Year
Serial Number Location .....	Label on Top Cover
Assembly Time .....	1 hour


### Features:

Blade Tension Indicator  
Micro Adjusting Gear Table  
Height Scale Measurement  
Fence with Scale and Magnifying Window  
Deluxe Cast Iron Fence with Extruded Aluminum Resaw Fence  
Miter Gauge  
Quick Change Blade Release/Tensioning  
Rack and Pinion Upper Guide Adjustment  
Includes 3/4" Blade

*The information contained herein is deemed accurate as of 2/9/2007 and represents our most recent product specifications.  
Due to our ongoing improvement efforts, this information may not accurately describe items previously purchased.*




# Identification



**Figure 1.** Bandsaw front view.

- A. Tension Indicator Window
- B. ON/OFF Switch
- C. Rip Fence
- D. Fence Locking Lever
- E. Dust Port 4"
- F. Miter Gauge
- G. Blade Tension Handwheel
- H. Ball Bearing Roller Guides
- I. Guide Post
- J. Guide Post Handwheel
- K. Blade Tracking Window



**Figure 2.** Bandsaw back view.

- L. Quick Release Blade Tension Lever
- M. Blade Tracking Knob
- N. Guide Post Lock Knob
- O. Dust Port 4"
- P. Motor
- Q. Table Tilt Controls
- R. Lower Wheel Adjustment Control



# SECTION 1: SAFETY

## WARNING

### For Your Own Safety, Read Instruction Manual Before Operating this Machine

The purpose of safety symbols is to attract your attention to possible hazardous conditions. This manual uses a series of symbols and signal words which are intended to convey the level of importance of the safety messages. The progression of symbols is described below. Remember that safety messages by themselves do not eliminate danger and are not a substitute for proper accident prevention measures.



Indicates an imminently hazardous situation which, if not avoided, **WILL** result in death or serious injury.



Indicates a potentially hazardous situation which, if not avoided, **COULD** result in death or serious injury.



Indicates a potentially hazardous situation which, if not avoided, **MAY** result in minor or moderate injury. It may also be used to alert against unsafe practices.

### **NOTICE**

This symbol is used to alert the user to useful information about proper operation of the machine.

## WARNING

### Safety Instructions for Machinery

- 1. READ THROUGH THE ENTIRE MANUAL BEFORE STARTING MACHINERY.** Machinery presents serious injury hazards to untrained users.
- 2. ALWAYS USE ANSI APPROVED SAFETY GLASSES WHEN OPERATING MACHINERY.** Everyday eyeglasses only have impact resistant lenses—they are NOT safety glasses.
- 3. ALWAYS WEAR AN ANSI APPROVED RESPIRATOR WHEN OPERATING MACHINERY THAT PRODUCES DUST.** Wood dust is a carcinogen and can cause cancer and severe respiratory illnesses.
- 4. ALWAYS USE HEARING PROTECTION WHEN OPERATING MACHINERY.** Machinery noise can cause permanent hearing damage.
- 5. WEAR PROPER APPAREL. DO NOT** wear loose clothing, gloves, neckties, rings, or jewelry which may get caught in moving parts. Wear protective hair covering to contain long hair and wear non-slip footwear.
- 6. NEVER OPERATE MACHINERY WHEN TIRED, OR UNDER THE INFLUENCE OF DRUGS OR ALCOHOL.** Be mentally alert at all times when running machinery.



# WARNING

## Safety Instructions for Machinery

7. **ONLY ALLOW TRAINED AND PROPERLY SUPERVISED PERSONNEL TO OPERATE MACHINERY.** Make sure operation instructions are safe and clearly understood.
8. **KEEP CHILDREN AND VISITORS AWAY.** Keep all children and visitors a safe distance from the work area.
9. **MAKE WORKSHOP CHILD PROOF.** Use padlocks, master switches, and remove start switch keys.
10. **NEVER LEAVE WHEN MACHINE IS RUNNING.** Turn power **OFF** and allow all moving parts to come to a complete stop before leaving machine unattended.
11. **DO NOT USE IN DANGEROUS ENVIRONMENTS.** DO NOT use machinery in damp, wet locations, or where any flammable or noxious fumes may exist.
12. **KEEP WORK AREA CLEAN AND WELL LIT.** Clutter and dark shadows may cause accidents.
13. **USE A GROUNDED EXTENSION CORD RATED FOR THE MACHINE AMPERAGE.** Undersized cords overheat and lose power. Replace extension cords if they become damaged. DO NOT use extension cords for 220V machinery.
14. **ALWAYS DISCONNECT FROM POWER SOURCE BEFORE SERVICING MACHINERY.** Make sure switch is in OFF position before reconnecting.
15. **MAINTAIN MACHINERY WITH CARE.** Keep blades sharp and clean for best and safest performance. Follow instructions for lubricating and changing accessories.
16. **MAKE SURE GUARDS ARE IN PLACE AND WORK CORRECTLY BEFORE USING MACHINERY.**
17. **REMOVE ADJUSTING KEYS AND WRENCHES.** Make a habit of checking for keys and adjusting wrenches before turning machinery **ON**.
18. **CHECK FOR DAMAGED PARTS BEFORE USING MACHINERY.** Check for binding and alignment of parts, broken parts, part mounting, loose bolts, and any other conditions that may affect machine operation. Repair or replace damaged parts.
19. **USE RECOMMENDED ACCESSORIES.** Refer to the instruction manual for recommended accessories. The use of improper accessories may cause risk of injury.
20. **DO NOT FORCE MACHINERY.** Work at the speed for which the machine or accessory was designed.
21. **SECURE WORKPIECE.** Use clamps or a vise to hold the workpiece when practical. A secured workpiece protects your hands and frees both hands to operate the machine.
22. **DO NOT OVERREACH.** Keep proper footing and balance at all times.
23. **MANY MACHINES WILL EJECT THE WORKPIECE TOWARD THE OPERATOR.** Know and avoid conditions that cause the workpiece to "kickback."
24. **ALWAYS LOCK MOBILE BASES (IF USED) BEFORE OPERATING MACHINERY.**
25. **BE AWARE THAT CERTAIN DUST MAY BE HAZARDOUS** to the respiratory systems of people and animals, especially fine dust. Make sure you know the hazards associated with the type of dust you will be exposed to and always wear a respirator approved for that type of dust.





## **WARNING**

# Additional Safety Instructions for Bandsaws

1. **BLADE CONDITION.** Do not operate with dull, cracked or badly worn blade. Dull blades require more effort to use and are difficult to control. Inspect blades for cracks and missing teeth before each use, and replace as required.
2. **HAND PLACEMENT.** Never position fingers or thumbs in line with the cut. Serious personal injury could occur.
3. **GUARDS.** Do not operate this bandsaw without the blade guard in place or with the doors open.
4. **BLADE REPLACEMENT.** When replacing blades, make sure teeth face toward the workpiece and the blade is properly tensioned before operating.
5. **WORKPIECE HANDLING.** Never hold small workpieces with your fingers during a cut. Always support/feed the workpiece with push stick, table support, vise, or some type of clamping fixture.
6. **CUTTING TECHNIQUES.** Plan your cuts so you always cut out of the wood. **DO NOT** back the workpiece away from the blade while the saw is running. If you need to back the work out, turn the bandsaw **OFF** and wait for the blade to come to a complete stop, and **DO NOT** twist or put excessive stress on the blade while backing work away.
7. **BLADE SPEED.** Allow blade to reach full speed before cutting.
8. **LEAVING WORK AREA.** Never leave a machine running and unattended. Allow the bandsaw to come to a complete stop before you leave it unattended.
9. **FEED RATE.** Always feed stock evenly and smoothly. **DO NOT** force or twist blade while cutting, especially when sawing small radii.
10. **WORKPIECE MATERIAL.** This machine is designed to cut wood only. It is not designed to cut metal or use cutting fluid.
11. **MAINTENANCE/SERVICE.** All inspections, adjustments, and maintenance are to be done with the power **OFF** and the plug removed from the outlet. Wait for all moving parts to come to a complete stop.
12. **BLADE CONTROL.** Do not attempt to stop or slow the blade with your hand or a workpiece. Allow the blade to stop on its own, unless your machine is equipped with a brake.
13. **EXPERIENCING DIFFICULTIES.** If at any time you are experiencing difficulties performing the intended operation, stop using the machine! Contact our Technical Support Department at (570) 546-9663.

## **WARNING**

Like all machinery there is potential danger when operating this machine. Accidents are frequently caused by lack of familiarity or failure to pay attention. Use this machine with respect and caution to lessen the possibility of operator injury. If normal safety precautions are overlooked or ignored, serious personal injury may occur.

## **CAUTION**

No list of safety guidelines can be complete. Every shop environment is different. Always consider safety first, as it applies to your individual working conditions. Use this and other machinery with caution and respect. Failure to do so could result in serious personal injury, damage to equipment, or poor work results.



# SECTION 2: CIRCUIT REQUIREMENTS

## Operation

### **!WARNING**

Serious personal injury could occur if you connect the machine to the power source before you have completed the set up process. **DO NOT** connect the machine to the power source until instructed to do so.

### Amperage Draw

The motor for your machine may draw the following amps at maximum load.

G0513X at 220V Single-Phase .....	10 Amps
G0513X at 110V* .....	20 Amps
G0514X at 220V Single-Phase .....	16 Amps
G0514X3 at 220V 3-Phase .....	9 Amps
G0514X3 at 440V 3-Phase** .....	4.5 Amps

### Circuit Requirements

We recommend connecting this machine to a dedicated circuit with a verified ground, using the circuit breaker size given below. Never replace a circuit breaker with one of higher amperage without consulting a qualified electrician to ensure compliance with wiring codes. **If you are unsure about the wiring codes in your area or you plan to connect your machine to a shared circuit, you may create a fire hazard—consult a qualified electrician to reduce this risk.**

G0513X at 220V .....	15 Amp Circuit Breaker
G0513X at 110V* .....	30 Amp Circuit Breaker
G0514X .....	20 Amp Circuit Breaker
G0514X3 at 220V .....	15 Amp Circuit Breaker
G0514X3 at 440V** .....	15 Amp Circuit Breaker


**\* To run on 110V, you MUST rewire the motor. Refer to the wiring diagram on Page 54.**

**\*\* To run on 440V, you must rewire the motor and replace the 220V magnetic switch assembly with the 440V magnetic switch assembly (Part #P0514X3161A). Refer to the wiring diagram on Page 58 for wiring details.**


### Plug Type

The cord set enclosed does not have a plug as the style of plug you require will depend upon the type of service you currently have or plan to install. We recommend using the following plugs for your machine on a dedicated circuit only (see **Figures 3–6** for examples):

G0513X at 220V .....	NEMA 6-15 Plug
G0513X at 110V* .....	NEMA 5-30 Plug
G0514X .....	NEMA 6-20 Plug
G0514X3 at 220V .....	NEMA L15-20 Plug
G0514X3 at 440V** .....	NEMA L16-20 Plug




**Figure 3.** NEMA 6-15 plug and receptacle.




**Figure 4.** NEMA 5-30 plug and receptacle.






**Figure 5.** NEMA 6-20 plug and receptacle.



**Figure 6.** NEMA L15-20 plug and receptacle.



## ⚠ CAUTION

This machine must have a ground prong in the plug to help ensure that it is grounded. **DO NOT** remove ground prong from plug to fit into a two-pronged outlet! If the plug will not fit the outlet, have the proper outlet installed by a qualified electrician.

## Grounding

In the event of an electrical short, grounding reduces the risk of electric shock. The grounding wire in the power cord must be properly connected to the grounding prong on the plug; likewise, the outlet must be properly installed and grounded. All electrical connections must be made in accordance with local codes and ordinances.

## Extension Cords

We do not recommend the use of extension cords. Instead, arrange the placement of your equipment and the installed wiring to eliminate the need for extension cords.

If you find it absolutely necessary to use an extension cord with your machine, the extension cord must also contain a ground wire and plug pin.

### 110V Operation

Use at least a 10 gauge cord that does not exceed 50 feet in length!

### 220V Operation

Use at least a 12 gauge cord that does not exceed 50 feet in length!

### 440V Operation

Do not use an extension cord with 440V!


## Phase Converter

When using a phase converter for 3-phase, the power from the manufactured power leg (sometimes called the wild wire) can fluctuate. Connect the manufactured power leg to the S terminal to prevent damage. The wire from the S terminal can handle some fluctuation because it goes directly to the motor. The power going to the R and T terminals must be consistent to prevent damage.




# SECTION 3: SET UP

## Set Up Safety




### **!WARNING**

This machine presents serious injury hazards to untrained users. Read through this entire manual to become familiar with the controls and operations before starting the machine!




### **!WARNING**

Wear safety glasses during the entire set up process!



### **!WARNING**

This is an extremely heavy machine. Serious personal injury may occur if safe moving methods are not followed. To be safe, you will need assistance and a forklift or pallet jack when moving the shipping crate.



### **!CAUTION**

Unsupervised children and visitors inside your shop could cause serious personal injury to themselves. Lock all entrances to the shop when you are away and **DO NOT** allow unsupervised children or visitors in your shop at any time!

## Items Needed for Set Up

The following items are needed to complete the set up process, but are not included with your machine:

DESCRIPTION	Qty
• Safety Glasses (for each person) .....	1
• Machinist's Square .....	1
• Feeler Gauge 0.016" .....	1
• Straightedge .....	1
• Fine Ruler .....	1
• Dust Collector .....	1
• Dust Hoses 4" .....	2
• Hose Clamps .....	2
• Forklift .....	1
• 1000 Lb Capacity Chain or Strap w/Hook..	1

## Unpacking

The Model G0513X/G0514X/G0514X3 was carefully packed when it left our warehouse. If you discover the machine is damaged after you have signed for delivery, *please immediately call Customer Service at (570) 546-9663 for advice.*

Save the containers and all packing materials for possible inspection by the carrier or its agent. *Otherwise, filing a freight claim can be difficult.*

When you are completely satisfied with the condition of your shipment, you should inventory the contents.




# Inventory


After all the parts have been removed from the crate, you should have the following items:

<b>Crate Contents (Figure 7 &amp; 8):</b>	<b>Qty</b>
<b>A.</b> Bandsaw (not shown).....	1
<b>B.</b> Table.....	1
<b>C.</b> Miter Gauge.....	1
<b>D.</b> Back Square Tube.....	1
<b>E.</b> Resaw Fence.....	1
<b>F.</b> Front Rail.....	1
<b>G.</b> Fence Assembly.....	1

<b>Hardware and Tools:</b>	<b>Qty</b>
• Eye Bolt M10-1.5 (may be installed) .....	1
• Flat Washers 8mm (Table, Pos. Stop, Fence) .....	7
• Lock Washers 8mm (Table) .....	4
• Hex Bolts M8-1.25 x 16 (Table) .....	4
• Hex Bolt M8-1.25 x 90 (Pos. Stop) .....	1
• Hex Nuts M8-1.25 (Pos. Stop, Fence) .....	2
• Table Pin .....	1
• Table Insert .....	1
• Cap Screws M6-1 x 16 (Fence) .....	2
• Hex Bolts M6-1 x 20 (Fence) .....	2
• Fence Handle M8-1.25 x 22 (Fence) .....	1
• Lock Washers 6mm (Fence) .....	2
• Flat Washers 6mm (Fence).....	2
• Rail Pad M6 x 18 (Fence) .....	1
• Hex Nut M6-1 (Fence).....	1
• Lock Handle M8-1.25 x 44 (Fence).....	1
• Moving Plate (Fence) .....	1
• Hex Wrench 5mm & 8mm.....	1 Ea
• Open End Wrench 10 x 13mm.....	1



**Figure 7.** Bandsaw components.



**Figure 8.** Fence components.

In the event that any nonproprietary parts are missing (e.g. a nut or a washer), we would be glad to replace them, or for the sake of expediency, replacements can be obtained at your local hardware store.

## NOTICE

Some hardware/fasteners on the inventory list may arrive pre-installed on the machine. Check these locations before assuming that any items from the inventory list are missing.





# Hardware Recognition Chart

USE THIS CHART TO MATCH UP  
HARDWARE DURING THE ASSEMBLY  
PROCESS.

MEASURE BOLT DIAMETER BY PLACING INSIDE CIRCLE

○ #10

○ 1/4"

○ 5/16"

○ 3/8"

○ 7/16"

○ 1/2"



Key

4mm ○

6mm ○


8mm ○

10mm ○

12mm ○


16mm ○

LINES ARE 1MM APART




5mm  
10mm  
15mm  
20mm  
25mm  
30mm  
35mm  
40mm  
45mm  
50mm  
55mm  
60mm  
65mm  
70mm  
75mm


LINES ARE 1/16" INCH APART




1/4"  
3/8"  
1/2"  
5/8"  
5/16"  
7/16"  
9/16"  
3/4"  
7/8"  
1"  
1 1/4"  
1 1/2"  
1 3/4"  
2  
2 1/4"  
2 1/2"  
2 3/4"  
3




Hex Wrench




Phillips Head Screw




Flat Head Screw




Cap Screw




Carriage Bolt




Flange Bolt




Button Head Screw



External Retaining Ring




Internal Retaining Ring




Setscrew




E-Clip



Flat Washer



Lock Washer




Hex Nut




Lock Nut




Wing Nut



WASHER DIAMETER  
5/8"



WASHER DIAMETER  
9/16"



WASHER DIAMETER  
1/2"



WASHER DIAMETER  
7/16"



WASHER DIAMETER  
3/8"




WASHER DIAMETER  
5/16"




WASHER DIAMETER  
1/4"




WASHER DIAMETER  
3/16"



WASHER DIAMETER  
12mm



WASHER DIAMETER  
10mm



WASHER DIAMETER  
8mm



WASHER DIAMETER  
4mm



WASHER DIAMETER  
6mm



WASHERS ARE MEASURED BY THE INSIDE DIAMETER





# Clean Up

The unpainted surfaces are coated with a waxy oil to protect them from corrosion during shipment. Remove this protective coating with a solvent cleaner or citrus-based degreaser such as Grizzly's G7895 Degreaser. To clean thoroughly, some parts may need to be removed. **For optimum performance from your machine, make sure you clean all moving parts or sliding contact surfaces that are coated.** Avoid chlorine-based solvents, such as acetone or brake parts cleaner, as they may damage painted surfaces should they come in contact. Always follow the manufacturer's instructions when using any type of cleaning product.



# Site Considerations

## Floor Load

Refer to the **Machine Data Sheet** for the weight and footprint specifications of your machine. Some floors may require additional reinforcement to support both the machine and operator.

## Working Clearances

Consider existing and anticipated needs, size of material to be processed through each machine, and space for auxiliary stands, work tables or other machinery when establishing a location for your new machine. See **Figures 9 & 10** for the minimum working clearances.




Figure 9. G0513X minimum working clearances.




Figure 10. G0514X and G0514X3 minimum working clearances.



# Moving & Placing Base Unit


## **!WARNING**

This is an extremely heavy machine. Serious personal injury may occur if safe moving methods are not followed. To be safe, you will need assistance and a forklift or a hoist when removing the machine from the crate. Use a chain or a lifting strap with a minimum of 1000 lbs. lifting capacity. If the chain or lifting strap breaks, serious personal injury may occur.

Special care should be taken when moving this bandsaw. Only use the following methods to lift or move this bandsaw.

### To move and place the bandsaw:

1. Use a forklift to move the bandsaw on the pallet to its final location.
2. Unbolt the bandsaw from the pallet.
3. Install the eye bolt shown in **Figure 11** if it is not already installed (make sure it is threaded all the way in), then place the lifting hook through the eye bolt and lift slowly with a forklift.
4. Remove the pallet and slowly set the bandsaw into position.




**Figure 11.** Lifting the bandsaw.

# Mounting


We recommend mounting your new machine to the floor. Because floor materials may vary, floor mounting hardware is not included. You may also mount your machine to a mobile base that has wheel locking or wheel retracting capabilities that keep the mobile base from rolling when not in use.

## Bolting to Concrete Floors

Lag shield anchors with lag bolts (**Figure 12**) and anchor studs (**Figure 13**) are two popular methods for anchoring an object to a concrete floor. We suggest you research the many options and methods for mounting your machine and choose the best that fits your specific application.



**Figure 12.** Typical lag shield anchor and bolt.



**Figure 13.** Typical anchor stud.

## **NOTICE**

Anchor studs are stronger and more permanent alternatives to lag shield anchors; however, they will stick out of the floor, which may cause a tripping hazard if you decide to move your machine.




# Table

The table is heavy and requires two people to lift it onto the trunnions. The saw blade should also be removed to make table installation easier.

Components and Hardware Needed:	Qty
Table.....	1
Hex Bolts M8-1.25 x 16.....	4
Lock Washers 8mm.....	4
Flat Washers 8mm.....	4
Table Pin.....	1
Table Insert.....	1

## To install the table:

1. Loosen blade tension by rotating the quick release tension lever clockwise as shown in **Figure 14**.



**Figure 14.** Quick release tension lever.


2. Adjust the upper and lower blade guides away from the blade. Refer to **Adjusting Blade Guide Bearings** on **Page 29** for more details.



3. Open the upper and lower wheel covers, and slide the blade off of both wheels.



4. With the help of another person, lift the table onto the trunnions.
5. Secure the table to the trunnions as shown in **Figure 15** with the supplied hex bolts and washers.




**Figure 15.** Mounting the table.

6. With the blade teeth pointing downward, slide the blade through the table slot.
7. Slide the blade through the upper and lower blade guides, and mount it over the upper and lower wheels.
8. Tighten the quick release tension lever, then install the table insert and table pin.
9. Keep the upper and lower blade guides adjusted away from the blade until the blade tracking and tension have been adjusted.



# Blade Tracking




The blade tracking is primarily affected by the tilt of the upper wheel, also known as "Center Tracking"; and the alignment of both wheels, also known as "Coplanar Tracking." (For Coplanar Tracking, see the **Wheel Alignment** instructions on **Page 51**.)

The wheels on this bandsaw were aligned at the factory, so Center Tracking is the only adjustment that needs to be performed when the saw is new.

## To center track the blade:


1. DISCONNECT BANDSAW FROM POWER!
2. Make sure the upper and lower blade guides are adjusted away from the blade.
3. Engage the quick tension lever and turn the blade tension handwheel until the tension scale (**Figure 16**) reads between 4 and 6.



**Figure 16.** Blade tensioning controls.

4. Spin the upper wheel by hand at least three times and watch how the blade rides on the crown of the wheel. Refer to **Figure 17** for an illustration of this concept.


- If the blade rides in the center of the upper wheel and is centered on the peak of the wheel crown, then the bandsaw is already tracked properly and no further adjustments are needed at this time.
- If the blade does not ride in the center of the upper wheel and is not centered on the peak of the wheel crown, then continue with the following steps.



**Figure 17.** Center tracking profiles.



5. Loosen the lock lever (**Figure 18**) so that the blade tracking knob can rotate.



**Figure 18.** Blade tracking controls.


6. Spin the upper wheel with one hand and rotate the tracking control knob with the other hand to make the blade ride in the center of the bandsaw wheel tire.
7. Tighten the tracking control lock knob and close the upper wheel cover.

*For the best performance from your saw, regularly maintain proper tracking of the blade.*

## NOTICE

Changes in the blade tension may change the blade tracking.

## Positive Stop




The positive stop allows the table to be quickly and accurately returned to the horizontal (0°) position after being adjusted to a different angle.

Components and Hardware Needed:	Qty
Hex Bolt M8-1.25 x 90.....	1
Hex Nut M8-1.25 .....	1

### To install the positive stop:

1. Thread the M8-1.25 hex nut halfway onto the M8-1.25 x 90 hex bolt (this is the positive stop bolt).
2. Thread the positive stop bolt into the threaded hole on bandsaw body as shown in **Figure 19**.




**Figure 19.** Installed positive stop bolt.





### To set the positive stop:

1. DISCONNECT BANDSAW FROM POWER!
2. Adjust the blade tension until the mark on the blade tension scale is between 4 and 6.
3. Loosen the hex nut that locks the positive stop bolt in place.
4. Raise the guide post and place a machinist's square on the table next to the side of the blade as illustrated in **Figure 20**. Adjust the table square with the blade, then secure with the table tilt knobs.



**Figure 20.** Squaring table to blade.

5. Adjust the positive stop bolt to the table and secure it by tightening the hex nut against the trunnion bracket.
6. Check the adjustment for accuracy once you have tightened the hex nut.
7. Loosen the screw on the pointer, but do not remove it.
8. Align the tip of the pointer with the 0° mark on the table tilt scale.
9. Tighten the screw on the pointer so that the pointer is locked in place.

## Dust Collection

### CAUTION

**DO NOT** operate this bandsaw without an adequate dust collection system. This saw creates substantial amounts of wood dust while operating. Failure to use a dust collection system can result in short and long-term respiratory illness.

#### **Recommended CFM at Each Dust Port: 400**

*Do not confuse this CFM recommendation with the rating of the dust collector. To determine the CFM at the dust port, you must take into account many variables, including the CFM rating of the dust collector, the length of hose between the dust collector and the machine, the amount of branches or wyes, and the amount of other open lines throughout the system. Explaining this calculation is beyond the scope of this manual. If you are unsure of your system, consult an expert or purchase a good dust collection "how-to" book.*

#### **To connect a dust collection hose:**

1. Fit a 4" dust hose over each dust port, as shown in **Figure 21**, and secure in place with a hose clamp.
2. Tug each hose to make sure it does not come off. **Note:** A tight fit is necessary for proper performance.



**Figure 21.** Dust hose attached to dust port.

3. Attach the dust hoses to a dust collector.




# Installing Fence

Components and Hardware Needed:	Qty
Fence Assembly.....	1
Back Square Tube.....	1
Front Rail .....	1
Resaw Fence.....	1
Cap Screws M6-1 x 16.....	2
Hex Bolts M6-1 x 20.....	2
Lock Washers 6mm.....	2
Flat Washers 6mm .....	2
Fence Handle M8-1.25 x 22.....	1
Hex Nut M8-1.25 .....	1
Rail Pad M6-1 x 18.....	1
Hex Nut M6-1 .....	1
Flat Washer 8mm.....	1
Lock Handle M8-1.25 x 44 .....	1
Moving Plate.....	1


## To install the fence:

1. Attach the back square tube to the table with the cap screws as shown in **Figure 22**.
2. Attach the front rail with the hex bolts, lock washers, and flat washers as shown in **Figure 22**.




**Figure 22.** Rail installation.

3. Install an M8-1.25 hex nut on the fence handle, then thread the handle into the fence assembly (**Figure 23**). Tighten the hex nut against the fence pivot block to secure the handle.



**Figure 23.** Handle installed on fence assembly.

4. Thread the M6-1 hex nut onto the rail pad, then thread the rail pad into the fence (see **Figure 24**).




**Figure 24.** Installed rail pad.

5. Place the 8mm flat washer on the lock handle, slide it through the hole in the fence, then thread the moving plate onto the end of the lock handle threads.






- Slide the resaw fence over the moving plate, as shown in **Figure 25**, so the moving plate fits inside the channel of the resaw fence.



**Figure 25.** Attaching resaw fence to standard fence.

- Tighten the lock handle.
- Pull the fence handle up and place the fence assembly on the fixed rail as shown in **Figure 26**.




**Figure 26.** Correctly installed fence.

- Push the fence handle down to lock the fence assembly in place.
- Adjust the rail pad until there is an even gap between the bottom of the fence and the table, then tighten the hex nut against the fence.

## Test Run

Once the assembly is complete and you have finished the **Blade Tracking** procedure, you need to test run the machine to continue with the remainder of the adjustments.

If, during the test run, you cannot easily locate the source of an unusual noise or vibration, stop using the machine immediately, then contact our service department for further assistance.



**WARNING**  
Wear safety glasses during the entire test run process. Failure to comply may result in serious personal injury.

### To test run the machine:

- Make sure that you have completed the **Blade Tracking** procedure before continuing.
- Make sure that the blade guides are adjusted as far away from the blade as possible, and that the blade is not touching the table or table insert.
- Refer to **CIRCUIT REQUIREMENTS** on **Page 14**, and connect the plug to the power cord.
- Make sure that any tools or foreign objects have been removed from the machine.
- Plug the machine into the power source.
- Turn the bandsaw **ON**.
- Listen to and watch the bandsaw for abnormal noises or actions. The bandsaw should run smoothly with little or no vibration or rubbing noises. Strange or unusual noises **MUST** be investigated and corrected before operating the machine further—always turn **OFF** and unplug the machine when investigating or correcting potential problems.



# Tensioning Blade

A properly tensioned blade is essential for making accurate cuts and is required before making many bandsaw adjustments. (Everytime you replace the blade, you should perform this procedure because all blades tension differently.)

## To tension the bandsaw blade:

1. Complete the **Test Run** procedure and make sure the blade is tracking properly.
2. Raise the upper blade guide assembly as high as it will go, and adjust the upper and lower guide blocks as far away from the blade as possible. **Note:** *This procedure will NOT work if the guide blocks have any contact with the blade.*
3. Engage the quick tension lever to the tightened position and turn the blade tension handwheel until the tension scale reads between 4 and 6.
4. Turn the bandsaw **ON**.
5. Slowly release the tension one quarter of a turn at a time. When you see the bandsaw blade start to flutter, stop decreasing the tension.
6. Now, slowly increase the tension until the blade stops fluttering, then tighten the tension another quarter turn.
7. Look at what the tension gauge reads and use that as a guide for tensioning that blade in the future. **Note:** *Always detension the blade after use to increase blade life and reduce strain on the bandsaw components.*
8. Re-adjust the blade tracking as instructed on **Page 22**.

# Adjusting Support Bearings


## NOTICE

**Whenever changing a blade or adjusting tension and tracking, the upper and lower blade support bearings and blade guide bearings must be properly adjusted before cutting operations.**

The support bearings are positioned behind the blade for support during cutting operations. Proper adjustment of the support bearings is an important part of making accurate cuts and also keeps the blade teeth from coming in contact with the guide bearings while cutting.

## To adjust the upper support bearings:


1. DISCONNECT BANDSAW FROM POWER!
2. Make sure the blade is tracking properly and that it is correctly tensioned.
3. Familiarize yourself with the upper support bearing controls shown in **Figure 27**.



**Figure 27.** Upper support bearing controls.


4. Loosen the guide block assembly cap screw and rotate the blade guide assembly side-to-side, until the blade is perpendicular with the face of the support bearing as illustrated in **Figure 28**.






**Figure 28.** Blade should be perpendicular (90°) to the face of the support bearing.

5. Tighten the assembly cap screw.
6. Loosen the cap screw on the support bearing adjustment shaft.
7. Place a 0.016" feeler gauge between the support bearing and the blade, and position the bearing 0.016" away from the back of the blade as illustrated in **Figure 29**.



**Figure 29.** Blade should be aligned approximately 0.016" away from the bearing edge.

**Note:** For a quick gauge, fold a dollar bill in half twice (four thicknesses of a dollar bill is approximately 0.016") and place it between the support bearing and the blade as shown in **Figure 30**.




**Figure 30.** Dollar bill folded twice to make an approximate 0.016" gauge.

8. Tighten the cap screw to keep the support bearing locked in place.

#### To adjust the lower support bearings:

1. DISCONNECT BANDSAW FROM POWER!
2. Make sure that the blade is tracking properly and is correctly tensioned.
3. Familiarize yourself with the lower support bearing controls shown in **Figure 31**.



**Figure 31.** Lower support bearing controls.



4. Check to make sure the guide block assembly is perpendicular with the face of the support bearing as illustrated in **Figure 28**.

—If the guide block assembly is perpendicular to the face of the support bearing, continue on to the next step.

—If the guide block assembly is not perpendicular to the support bearing, loosen the guide block assembly cap screws and rotate the blade guide assembly side-to-side until the blade is perpendicular with the face of the support bearing, then re-tighten the cap screws. **Note:** *The table must be re-aligned with the blade after the lower guide block assembly is adjusted. Refer to **Page 30**.*

5. Loosen the cap screw on the support bearing adjustment shaft.
6. Place a 0.016" feeler gauge between the support bearing and the blade, and position the bearing 0.016" away from the back of the blade as illustrated in **Figure 29** or use a dollar bill as shown in **Figure 30**.
7. Tighten the cap screw to keep the support bearing locked in place.


## Adjusting Blade Guide Bearings

The blade guides provide side-to-side support to help keep the blade straight while cutting. The blade guides are designed to be adjusted in two ways—forward/backward and side-to-side.

### To adjust the upper and lower blade guides:

1. Make sure the blade is tracking properly and that it is correctly tensioned.
2. DISCONNECT BANDSAW FROM POWER!


3. Familiarize yourself with the blade guide controls shown in **Figure 32**.



**Figure 32.** Blade guide controls.

4. Loosen the cap screw on the lateral adjustment rod and adjust the blade guides until the edges of the bearings are  $\frac{1}{16}$ " behind the blade gullets as illustrated in **Figure 33**.

**Note:** *The  $\frac{1}{16}$ " spacing is ideal, although with larger blades it may not be possible. In such cases, adjust the guide bearings as far forward as possible to the blade gullets, and still maintain the proper support bearing spacing adjustment.*



**Figure 33.** Lateral adjustment of blade guides.



## NOTICE

Make sure that the blade teeth will not contact the guide bearings when the blade is against the rear support bearing during the cut or the blade teeth will be ruined.

5. Tighten the cap screw on the lateral adjustment rod.
6. Loosen the bearing rotation adjustment cap screws.
7. Rotate the knurled knob to position the bearings 0.004" away from the blade. **Note:** 0.004" is approximately the thickness of a dollar bill.
8. Tighten the cap screw to lock the blade guide bearings in position.
9. Repeat this procedure for the lower guides.

## NOTICE


Whenever changing a blade or adjusting tension and tracking, the upper and lower blade support bearings and guide bearings must be properly adjusted before cutting operations.

## Aligning Table

To ensure cutting accuracy when the table is first installed, the table should be aligned so that the miter slot is parallel to the bandsaw blade. This procedure works best with a  $\frac{3}{4}$ " blade installed.

### To align the table so the miter slot is parallel to the bandsaw blade:

1. Make sure that the blade is tracking properly and that it is correctly tensioned.
2. DISCONNECT BANDSAW FROM POWER!
3. Loosen the trunnion bolts that secure the trunnions to the table.
4. Place an accurate straightedge along the blade. The straightedge should lightly touch both the front and back of the blade. **Note:** Make sure the straightedge does not go across a tooth.
5. Use a fine ruler to gauge the distance between the straightedge and the miter slot. The distance you measure should be the same at both the front and the back of the table (see **Figure 34**).
6. Adjust the table as needed for proper alignment.
7. Tighten the trunnion bolts.



**Figure 34.** Measuring for miter slot to be parallel with blade.





# Aligning Fence

To ensure cutting accuracy when the fence is first installed, the fence should be aligned with the miter slot.

## To align the fence parallel with the miter slot:

1. If the fence is mounted on the left-hand side of the blade, remove it and remount it next to the miter slot.
2. Loosen the four cap screws located on the top face of the fence (**Figure 35**).



**Figure 35.** Four fence cap screws.

3. Adjust the fence face parallel with the edge of the miter slot.
4. Tighten the four cap screws, being careful not to move the fence.

## NOTICE


Adjusting the fence parallel to the miter slot does not guarantee straight cuts. The miter slot may need to be adjusted parallel to the side of the blade. Refer to the "Aligning Table" instructions.

# Miter Gauge

The miter gauge needs to be calibrated to the blade when it is first mounted in the miter slot.

## To calibrate the miter gauge:

1. Use a machinist's square with one edge against the face of the miter gauge and the other against the blade face as shown in **Figure 36**.



**Figure 36.** Squaring miter gauge to blade.

2. Loosen the lock knob on the miter gauge and adjust it flush with the edge of the square.
3. Tighten the lock knob, and verify the setting.

**Note:** Sometimes the tightening procedure can affect the adjustment.

4. Loosen the screw that secures the angle pointer and adjust the pointer to the 0° mark on the scale.
5. Retighten the screw that secures the angle pointer.




# SECTION 4: OPERATIONS

## Operation Safety


### **WARNING**

Damage to your eyes, lungs, and ears could result from using this machine without proper protective gear. Always wear safety glasses, a respirator, and hearing protection when operating this machine.



### **WARNING**

Loose hair and clothing could get caught in machinery and cause serious personal injury. Keep loose clothing and long hair away from moving machinery.



### **NOTICE**

If you have never used this type of machine or equipment before, **WE STRONGLY RECOMMEND** that you read books, trade magazines, or get formal training before beginning any projects. Regardless of the content in this section, Grizzly Industrial will not be held liable for accidents caused by lack of training.

## Overview

The bandsaw is one of the most versatile wood cutting tools in the shop. It is capable of performing many different cutting functions including:

### Straight Cuts

- Miters
- Angles
- Compound Angles
- Resawing
- Ripping
- Crosscutting

### Irregular Cuts

- Simple and Complex Curves
- Duplicate Parts
- Circles
- Beveled Curves

A properly adjusted and tuned bandsaw can be safer to operate than most other saws and performs many functions with ease and accuracy.

### Basic Cutting Tips

Here are some basic tips to follow when operating the bandsaw:

- Replace, sharpen, and clean blades as necessary and make adjustments periodically to keep the saw always running in top condition.
- Use light and even pressure while cutting. Light contact with the blade will permit easier line following and prevent undue friction.
- Avoid trying to turn tight corners because this will twist the blade. Remember, you must saw around corners.
- Misuse of the saw or using incorrect techniques is unsafe and results in frustration and poor cuts. Remember—the blade does the cutting with the operator's guidance.





# START/STOP Switch

The START/STOP switch on the Model G0513X/G0514X/G0514X3 is located on the column for easy access (**Figures 37 & 38**). Immediately turn the machine **OFF** if there becomes a safety hazard.



**Figure 37.** G0513X START/STOP switch.




**Figure 38.** G0514X/G0514X3 START/STOP switch.

The Model G0514X/G0514X3 features a switch disabling lock to prevent unauthorized starting of the machine. To disable the switch, turn the key to "0". To enable the switch, turn the key to "1".

# Guide Post

The guide post, shown in **Figure 39**, connects the upper blade guide assembly to the bandsaw. The guidepost allows the blade guide assembly to move up or down via a rack and pinion. In order to cut accurately, the blade guide assembly must be no more than 1" from the top of the workpiece at all times—this positioning provides the best support for the blade.



**Figure 39.** Guide post controls.

## To adjust guide post:

1. Make sure that the blade tension, blade tracking, support bearing, and blade guides are adjusted correctly.
2. Loosen the guide post lock knob shown in **Figure 39**.
3. Turn the guide post handwheel to raise or lower the guide post until the upper blade guide assembly is within 1" from the top of the workpiece.
4. Lock the guide post in place with the lock knob.




# Fine Tune Tracking

## NOTICE

Adjusting the final blade tracking setting requires the machine to be turned **ON**.

### To fine tune the tracking:

1. Close the wheel covers and turn the bandsaw **ON**.
2. Observe the blade tracking path through the clear window on the right edge of the bandsaw as shown in **Figure 40**.



**Figure 40.** Blade tracking window.

3. Using the tracking controls (**Page 23, Figure 18**), adjust the blade so it tracks on the center of the wheel.
4. Tighten the tracking lock so the knob cannot move.

# Blade Lead

Bandsaw blades commonly wander off the cut line when sawing, as shown in **Figure 41**. This is called blade lead. Blade lead is commonly caused by too fast of a feed rate, a dull or abused blade, or improper tension. If your blade is sharp/undamaged and you still have blade lead, perform the following instructions.



**Figure 41.** Blade leading away from line of cut.

### To correct blade lead:

1. Use less pressure when feeding the workpiece through the cut.
2. Check that the miter slot or fence is parallel to the blade line, and correct if necessary.
3. Check for proper blade tension. If the blade tension is correct and it is not convenient to replace the blade, compensate for lead by skewing the fence or adjusting the table.

### To skew your fence:

1. Cut a piece of scrap wood approximately  $\frac{3}{4}$ " thick x 3" wide x 17" long. On a wide face of the board, draw a straight line parallel to the long edge.
2. Cut halfway through the board on the line by pushing it into the blade. Turn the bandsaw **OFF** and wait for the blade to stop.




3. Clamp the board to the bandsaw table without moving it. Now slide the fence over to the board so it barely touches one end of the board.
4. Loosen the four cap screws on top of the fence.
5. Skew the fence so it is parallel to the edge of the scrap piece. You may need to re-adjust the fence locking mechanisms to gain maximum adjustment.
6. While maintaining the skew, tighten the cap screws.

#### To shift the table:

1. On a scrap piece of wood, mark a line that is perpendicular to the front edge.
2. Cut halfway through the board on the line by pushing it into the blade.
3. Turn the bandsaw **OFF** and wait for the blade to stop.
4. Loosen the table mounting bolts. Shift the table to compensate for the blade lead, then retighten the table bolts.
5. Repeat **Steps 1–4** until the blade cuts straight.


## Table Tilt



The bandsaw table will tilt 5° left and 45° right to provide a wide range of cutting options. Remove the positive stop bolt to tilt the table to the left.

#### To tilt the table:

1. DISCONNECT BANDSAW FROM POWER!
2. Loosen the lock handle on the table trunnion shown in **Figure 42**.



**Figure 42.** Table tilt controls.

3. Turn the table tilt knob to position the table to the desired angle of tilt. Refer to the angle gauge on the front table trunnion for the tilting angle.
4. Retighten the lock handle to secure the table.



# Ripping

Ripping is the process of cutting with the grain of the wood stock. For plywood and other processed wood, ripping simply means cutting down the length of the workpiece.

## To make a rip cut:

1. Adjust the fence to match the width of the cut on your workpiece and lock the fence in place.
2. Adjust the blade guide assembly to the correct height.
3. After all safety precautions have been met, turn the bandsaw **ON**. Slowly feed the workpiece into the blade and continue with the cut until the blade is completely through the workpiece. **Figure 43** shows a typical ripping operation. **Note:** *If you are cutting narrow pieces, use a push stick to protect your fingers.*



**Figure 43.** Ripping with a push stick.

## WARNING


**NEVER** place fingers or hands in the line of cut. In the event that something unexpected happens, your hands or fingers may be pulled into the blade. **ALWAYS** use a push stick when ripping narrow pieces. Failure to follow these warnings may result in serious personal injury!

# Crosscutting

Crosscutting is the process of cutting across the grain of wood. For plywood and other processed wood, crosscutting simply means cutting across the width of the material.

## To make a 90° crosscut:

1. Mark the workpiece on the edge where you want to begin the cut.
2. Adjust the blade guide assembly to the correct height and make sure the miter gauge is set to 90°.
3. Move the fence out of the way. Place the workpiece evenly against the miter gauge.
4. Hold the workpiece against the miter gauge and line up the mark with the blade.
5. After all safety precautions have been met, turn the bandsaw **ON**. Slowly feed the workpiece into the blade and continue the cut until the blade is all the way through the workpiece. **Figure 44** shows a typical crosscutting operation.



**Figure 44.** Crosscutting with miter gauge.






# Resawing

Resawing (**Figure 45**) is the process of cutting a board into two or more thinner boards. The maximum board width that can be resawn is limited by the maximum cutting height of the bandsaw.

One of the most important considerations when resawing is blade selection. Generally, the wider blade, the better. In most applications, a hook or a skip tooth style will be desirable. Choose blades with fewer teeth-per-inch (from 3 to 6), because they offer larger gullet capacities for clearing sawdust, reducing heat buildup and reducing strain on the motor.



**Figure 45.** Resawing lumber.

## **WARNING**

When resawing thin pieces, a wandering blade (blad lead) can tear through the surface of the workpiece, exposing your hands to the blade teeth. Always use push blocks when resawing and keep your hands clear of the blade.

### To resaw a workpiece:

1. Verify that the bandsaw is setup properly and that the table is perpendicular to the blade.
2. Use the widest blade your bandsaw will accept. **Note:** *The blade must also be sharp and clean.*
3. Install the resaw fence and set it to the desired width of cut and lock it in place.

## **NOTICE**

**The scale on the front rail will NOT be accurate when using the resaw fence.**

4. Support the ends of the board if necessary.
5. Turn the bandsaw **ON**.
6. Using push paddles and a push stick, keep pressure against the fence and table, and slowly feed the workpiece into the moving blade until the blade is completely through the workpiece (see **Figure 45**).



# Cutting Curves

When cutting curves, simultaneously feed and turn the stock carefully so that the blade follows the layout line without twisting. If a curve is so abrupt that it is necessary to repeatedly back up and cut a new kerf, use either a narrower blade or a blade with more TPI (teeth per inch), or make more relief cuts.

Always make short cuts first, then proceed to the longer cuts. Relief cuts will also reduce the chance that the blade will be pinched or twisted. Relief cuts are cuts made through the waste portion of the workpiece and are stopped at the layout line. As you cut along the layout line, waste wood is released from the workpiece, alleviating any pressure on the back of the blade. Relief cuts also make backing the workpiece out easier, if needed.

## NOTICE

The list below displays blade widths and the corresponding minimum radii for those blade widths.


Width	Radius
1/8" .....	1/8"
3/16" .....	3/8"
1/4" .....	5/8"
3/8" .....	1 1/4"
1/2" .....	2 1/2"
5/8" .....	3 3/4"
3/4" .....	5 1/2"

# Stacked Cuts

One of the benefits of a bandsaw is its ability to cut multiple copies of a particular shape by stacking a number of workpieces together. Before making stacked cuts, ensure that both the table and the blade are properly adjusted to 90°. Otherwise, any error will be compounded.

## To complete a stacked cut:

1. Align your pieces from top to bottom to ensure that each piece has adequate scrap to provide a clean, unhampered cut.
2. Secure all the pieces together in a manner that will not interfere with the cutting. Hot glue on the edges works well, as do brad nails through the waste portion. (Be careful not to cut into the brads or you may break the blade!)
3. On the face of the top piece, lay out the shape you intend to cut.
4. Make relief cuts perpendicular to the outline of your intended shape in areas where changes in blade direction could strain the woodgrain or cause the blade kerf to bind.
5. Cut the stack of pieces as though you were cutting a single piece. Follow your layout line with the blade kerf on the waste side of your line as shown in **Figure 46**.



**Figure 46.** Typical stacked cut.




# Blade Speed

The blade speed can be adjusted to 1700 or 3500 FPM. Speed adjustments are made by moving the V-belt position on the motor and wheel pulleys.

Most woodcutting can be performed successfully at the higher blade speeds. Slower blade speeds generally produce better results when cutting hardwoods, intricate curves, or when an exceptionally smooth cut is desired.


## To adjust the blade speed:

1. DISCONNECT BANDSAW FROM POWER!
2. Loosen the motor mount cap screws shown in **Figure 47** and rotate the motor to loosen the V-belt.




**Figure 47.** Motor mount cap screws.

3. Refer to **Figure 48** to locate the correct V-belt position for the desired blade speed.



**Figure 48.** V-belt speeds.

4. Move the V-belt to the desired pulley.
5. Rotate the motor to tension the V-belt, then tighten the motor mount cap screws.
6. Check the V-belt tension. When tensioned correctly, the V-belt can be deflected approximately  $\frac{3}{4}$ " (see **Figure 49**).



**Figure 49.** V-belt deflection.





# Blade Information

Selecting the right blade requires a knowledge of the various blade characteristics to match the blade with the particular cutting operation.

## Blade Length


Measured by the circumference, blade lengths are usually unique to the brand of your bandsaw and the distance between wheels. The Model G0513X is designed for blades that are 131½" long and the Model G0514X/G0514X3 is designed for blades that are 143" long. Refer to **Page 43** for blade replacements.

## Blade Width

Measured from the back of the blade to the tip of the blade tooth (the widest point), blade width is often the first consideration given to blade selection. Blade width dictates the largest and smallest curve that can be cut, as well as how accurately it can cut a straight line.

The Model G0513X can use blades from ⅛" to 1" in width. The Model G0514X/G0514X3 can use blades from ⅛" to 1¼" in width. Always pick the size of blade that best suits your application.

- **Curve Cutting:** Use the chart in **Figure 50** to determine the correct blade for curve cutting. Determine the smallest radius curve that will be cut on your workpiece and use the corresponding blade width.




**Figure 50.** Blade width radii.

- **Straight Cutting:** Use the largest width blade that you own. Narrow blades can cut tight curves (a small radius) but are not very good at cutting straight lines because they naturally wander (blade lead). However, larger blades are much better at cutting straight lines, but function poorly at cutting small curves because of their size.

## Tooth Style

When selecting blades, another option to consider is the shape, gullet size, teeth set and teeth angle—otherwise known as “Tooth Style.”

**Figure 51** shows the three main categories of tooth style:



**Figure 51.** Raker, Skip & Hook tooth styles.

- **Raker:** This style is considered to be the standard because the tooth size and shape are the same as the tooth gullet. The teeth on Raker blades usually are very numerous, have no angle, and produce cuts by scraping the material; these characteristics result in very smooth cuts, but do not cut fast and generate more heat while cutting.
- **Skip:** This style is similar to a raker blade that is missing every other tooth. Because of the design, skip toothed blades have a much larger gullet than raker blades, and therefore, cut faster and generate more heat. However, these blades also leave a rougher cut than raker blades.



- **Hook:** The teeth on this style have a positive angle (downward) which makes them dig into the material, and the gullets are usually rounded for easier waste removal. These blades are excellent for the tough demands of resawing and ripping thick material.

## Tooth Pitch

Usually measured as TPI (teeth per inch), tooth pitch determines the size of the teeth. More teeth per inch (fine pitch) will cut slower, but smoother; while fewer teeth per inch (coarse pitch) will cut rougher, but faster. As a general rule, choose blades that will have at least three teeth in the material at all times. Use fine pitched blades on harder woods and coarse pitched blades on softer woods.

## Blade Care

A bandsaw blade is a delicate piece of steel that is subjected to tremendous strain. You can obtain longer use from a bandsaw blade if you give it fair treatment and always use the appropriate feed rate for your operation.

Be sure to select blades with the proper width, style, and pitch for each application. The wrong choice of blades will often produce unnecessary heat which will shorten the life of your blade.

A clean blade will perform much better than a dirty blade. Dirty or gummed up blades pass through the cutting material with much more resistance than clean blades. This extra resistance also causes unnecessary heat.

## Blade Breakage



Many conditions may cause a bandsaw blade to break. Blade breakage is unavoidable, in some cases, since it is the natural result of the peculiar stresses that bandsaw blades are subjected to. Blade breakage is also due to avoidable circumstances. Avoidable breakage is most often the result of poor care or judgement on the part of the operator when mounting or adjusting the blade or support guides.

### The most common causes of blade breakage are:

- Faulty alignment and adjustment of the guides.
- Forcing or twisting a wide blade around a curve of short radius.
- Feeding the workpiece into the blade too fast.
- Tooth dullness or absence of sufficient set.
- Incorrect tension.
- Top blade guide assembly set too high above the workpiece.
- Using a blade with a lumpy or improperly finished braze or weld.
- Continuously running the bandsaw when not in use.



# Blade Changes



## To remove a blade:

1. DISCONNECT BANDSAW FROM POWER!
2. Release the blade tension by turning the blade tension quick release lever to the left.
3. Remove the table insert and the table pin. Adjust the upper and lower guide bearings as far away as possible from the blade.
4. Open the upper and lower wheel covers, and with gloved hands, slide the blade off of both wheels.
5. Rotate the blade 90° and slide it through the slot in the table.

## To replace a blade:

1. Slide the blade through the table slot, ensuring that the teeth are pointing down toward the table. **Note:** If the teeth will not point downward in any orientation, the blade is inside-out. Put on heavy gloves, remove the blade, and twist it right side-out.
2. Slip the blade through the guides, and mount it on the upper and lower wheels (**Figure 52**).



**Figure 52.** Placing blade on the wheels.

3. Tighten the blade tension lever.
4. Apply tension to the blade by turning the tension control knob. Rotate the upper wheel slowly by hand as tension is applied to allow the blade to center itself on the wheel. Adjust tracking if needed.
5. Adjust tension as described **Page 27**.
6. Adjust the upper/lower guide bearings and the support bearings.
7. Close the wheel covers.
8. Replace the table insert and table pin, being sure not to use excessive force when inserting the table pin.



# SECTION 5: ACCESSORIES

## Replacement Blades

These replacement blades are milled for exact tooth set and are made with high quality tool steel.

### 131½" Carbon Steel Replacement Blades for the Model G0513X

MODEL	WIDTH	TPI
H4803	1/8"	14 RAKER
H4804	1/4"	6 HOOK
H4805	1/4"	18 RAKER
H4806	3/8"	10 RAKER
H4807	1/2"	6 HOOK
H4808	1/2"	10 RAKER
H4809	3/4"	3 HOOK
H4810	1"	6 HOOK
H4811	1"	2 HOOK

### 131½" Carbide Tipped Replacement Blades for the Model G0513X.

MODEL	WIDTH	TPI
H4897	3/8"	3-4 VP
H4898	1/2"	3
H4899	3/4"	3
H4900	1"	2-3 VP
H4901	1"	3-4 VP

### 143" Carbon Steel Replacement Blades for the Model G0514X and Model G0514X3.

MODEL	WIDTH	TPI
H4826	1/8"	14 RAKER
H4827	1/4"	6 HOOK
H4828	1/4"	18 RAKER
H4829	3/8"	10 RAKER
H4830	1/2"	6 HOOK
H4831	1/2"	10 RAKER
H4832	3/4"	3 HOOK
H4833	1"	6 HOOK
H4834	1"	2 HOOK
H4835	1-1/4"	1.3 HOOK

### 143" Carbon Steel Replacement Blades for the Model G0514X and Model G0514X3.

MODEL	WIDTH	TPI
H4907	3/8"	3-4 VP
H4908	1/2"	3
H4909	3/4"	3
H4910	1"	2-3 VP
H4911	1"	3-4 VP
H4912	1-1/4"	2-3 VP
H4913	1-1/4"	3-4 VP

**Call 1-800-523-4777 To Order**



- G7984—Face Shield**
- H1298—Dust Sealed Safety Glasses**
- H1300—UV Blocking, Clear Safety Glasses**
- H2347—Uvex® Spitfire Safety Glasses**
- H0736—Shop Fox® Safety Glasses**

Safety Glasses are essential to every shop. If you already have a pair, buy extras for visitors or employees. You can't be too careful when it comes to shop safety!



**Figure 53.** Our most popular safety glasses.

- H1302—Standard Earmuffs**
  - H4979—Deluxe Twin Cup Hearing Protector**
  - H4977—Work-Tunes Radio Headset Earmuffs**
- Protect yourself comfortably with a pair of cushioned earmuffs. Especially important if you or employees operate for hours at a time.



**Figure 54.** Our most popular earmuffs.

- H2499—Small Half-Mask Respirator**
- H3631—Medium Half-Mask Respirator**
- H3632—Large Half-Mask Respirator**
- H3635—Disposable Cartridge Filter Pair P100**

Wood dust is now considered a known carcinogen and has been linked to nasal cancer and severe respiratory illnesses. If you work around dust everyday, a half-mask respirator can be a lifesaver. Also compatible with safety glasses!



**Figure 55.** Half-mask respirator and disposable cartridge filters.

- G5562—SLIPIT® 1 Qt. Gel**
- G5563—SLIPIT® 12 oz Spray**
- G2871—Boeshield® T-9 12 oz Spray**
- G2870—Boeshield® T-9 4 oz Spray**
- H3788—G96® Gun Treatment 12 oz Spray**
- H3789—G96® Gun Treatment 4.5 oz Spray**



**Figure 56.** Recommended products for protecting unpainted cast iron/steel on machinery.

**Call 1-800-523-4777 To Order**



# SECTION 6: MAINTENANCE

---



## Schedule

---

For optimum performance from your machine, follow this maintenance schedule and refer to any specific instructions given in this section.

### Daily Check:

- Loose mounting bolts.
- Damaged saw blade.
- Worn or damaged wires.
- Any other unsafe condition.

### Monthly Check:

- V-belt tension, damage, or wear.
- Clean/vacuum dust buildup from inside cabinet and off motor.

## Cleaning

---

Cleaning your bandsaw is relatively easy. Vacuum excess wood chips and sawdust, and wipe off the remaining dust with a dry cloth. If any resin has built up, use a resin dissolving cleaner to remove it. Treat all unpainted cast iron and steel with a non-staining lubricant after cleaning.

## Unpainted Cast Iron

---

Protect the unpainted cast iron surfaces on the table by wiping the table clean after every use—this ensures moisture from wood dust does not remain on bare metal surfaces.

Keep tables rust-free with regular applications of products like G96® Gun Treatment, SLIPIT®, or Boeshield® T-9 (see **SECTION 5: ACCESSORIES** on **Page 43** for more details).

## Lubrication

---

Sealed and pre-lubricated ball bearings require no lubrication for the life of the bearings. All bearings are standard sizes, and replacements can be purchased from our parts department or a bearing supply store.

For adjustment controls, an occasional “shot” of light oil is just about all that is necessary. Wipe off any sawdust with a clean cloth, towel, or dry paint brush, and spray on the lubricant. Do not get oil on the pulleys or V-belt because it could cause belt deterioration and slipping.

## Wheel Brush

---

The bandsaw is equipped with a lower wheel brush. The brush should be checked daily and cleaned when it becomes dirty. There is an adjustment bracket that allows the brush to be adjusted for bristle wear. Refer to **Adjusting Wheel Brush** on **Page 50** for adjustment details.






# SECTION 7: SERVICE

This section is provided for your convenience—it is not a substitute for the Grizzly Service Department. If you need help troubleshooting, you need replacement parts, or you are unsure of how to perform the procedures in this section, then feel free to call our Technical Support at (570) 546-9663.

## Troubleshooting



### Motor & Electrical

Symptom	Possible Cause	Possible Solution
Machine does not start or a breaker trips.	<ol style="list-style-type: none"> <li>1. Plug/receptacle is at fault or wired incorrectly.</li> <li>2. Motor connection wired incorrectly.</li> <li>3. Power supply is at fault/switched OFF.</li> <li>4. Motor ON/OFF switch is at fault.</li> <li>5. Centrifugal switch is at fault.</li> <li>6. Wiring is open/has high resistance.</li> <li>7. Start capacitor is at fault.</li> <li>8. Motor is at fault.</li> </ol>	<ol style="list-style-type: none"> <li>1. Test for good contact or correct the wiring.</li> <li>2. Correct motor wiring connections (<b>Page 54</b>).</li> <li>3. Ensure hot lines have correct voltage on all legs and main power supply is switched ON.</li> <li>4. Replace faulty ON/OFF switch.</li> <li>5. Adjust/replace the centrifugal switch if available.</li> <li>6. Check for broken wires or corroded/disconnected connections, and repair/replace as necessary.</li> <li>7. Test/replace if faulty.</li> <li>8. Repair/replace.</li> </ol>
Machine stalls or is underpowered.	<ol style="list-style-type: none"> <li>1. Wrong workpiece material (wood).</li> <li>2. Processing speed too fast for task.</li> <li>3. V-belt slipping.</li> <li>4. Blade is slipping on wheels.</li> <li>5. Low power supply voltage.</li> <li>6. Run capacitor is at fault.</li> <li>7. Plug/receptacle is at fault.</li> <li>8. Motor connection is wired incorrectly.</li> <li>9. Motor bearings are at fault.</li> <li>10. Motor has overheated.</li> <li>11. Motor is at fault.</li> <li>12. Centrifugal switch is at fault.</li> </ol>	<ol style="list-style-type: none"> <li>1. Use wood with correct moisture content, without glues, and little pitch/resins.</li> <li>2. Decrease processing speed. See <b>Basic Cutting Tips</b> on <b>Page 32</b>.</li> <li>3. Replace bad V-belt, align pulleys, and re-tension (<b>Page 49</b>).</li> <li>4. Adjust blade tracking and tension to factory specifications. See <b>Page 22 or 27</b>.</li> <li>5. Ensure all hot lines have correct voltage on all legs.</li> <li>6. Repair/replace.</li> <li>7. Test for good contacts and correct wiring.</li> <li>8. Correct motor wiring connections (<b>Page 54</b>).</li> <li>9. Test by rotating shaft; rotational grinding/loose shaft requires bearing replacement.</li> <li>10. Clean off motor, let cool, and reduce workload.</li> <li>11. Repair/replace.</li> <li>12. Adjust/replace centrifugal switch if available.</li> </ol>

### ! WARNING


Disconnect power to the machine when performing any troubleshooting. Failure to do this may result in serious personal injury.





Symptom	Possible Cause	Possible Solution
Machine has vibration or noisy operation when running.	<ol style="list-style-type: none"> <li>1. Blade weld hits guides or teeth are broken.</li> <li>2. Bent or worn out blade.</li> <li>3. Motor or component is loose.</li> <li>4. V-belt worn or loose.</li> <li>5. Motor fan is rubbing on fan cover.</li> <li>6. Pulley is loose.</li> <li>7. Machine is incorrectly mounted or sits unevenly on floor.</li> <li>8. Motor bearings are at fault.</li> <li>9. Worn arbor bearings.</li> <li>10. Wheels not coplanar/aligned correctly.</li> <li>11. Tires incorrectly installed on wheels.</li> <li>12. Wheels out of balance.</li> </ol>	<ol style="list-style-type: none"> <li>1. Replace blade (<b>Page 42</b>).</li> <li>2. Replace blade (<b>Page 42</b>).</li> <li>3. Inspect/replace stripped or damaged bolts/nuts, and re-tighten with thread locking fluid.</li> <li>4. Inspect/replace belts with matched set (<b>Page 49</b>).</li> <li>5. Replace dented fan cover and loose/damaged fan.</li> <li>6. Realign/replace shaft, pulley, setscrew, and key as required.</li> <li>7. Adjust the feet on the bottom of the stand; relocate machine.</li> <li>8. Test by rotating shaft — rotational grinding/loose shaft requires bearing replacement.</li> <li>9. Check/replace arbor bearings.</li> <li>10. Adjust wheel alignment to coplaner (<b>Page 51</b>).</li> <li>11. Re-install tires on wheels.</li> <li>12. Replace wheels.</li> </ol>

## Cutting Operations



Symptom	Possible Cause	Possible Solution
Machine slows when operating.	<ol style="list-style-type: none"> <li>1. Feeding workpiece too fast.</li> <li>2. Blade is dull.</li> </ol>	<ol style="list-style-type: none"> <li>1. Reduce feed rate. See <b>Basic Cutting Tips</b> on <b>Page 32</b>.</li> <li>2. Replace blade (<b>Page 42</b>).</li> </ol>
Ticking sound when the saw is running.	<ol style="list-style-type: none"> <li>1. Blade weld contacting support bearing.</li> <li>2. Blade weld may be failing.</li> </ol>	<ol style="list-style-type: none"> <li>1. Use file or stone to smooth and round the back of the blade.</li> <li>2. Inspect and replace blade if necessary (<b>Page 42</b>).</li> </ol>
Blade contacting table insert.	<ol style="list-style-type: none"> <li>1. Excessive side pressure when cutting.</li> <li>2. Table improperly adjusted.</li> </ol>	<ol style="list-style-type: none"> <li>1. Reduce side pressure.</li> <li>2. Adjust table (<b>Page 30</b>).</li> </ol>
Vibration when cutting.	<ol style="list-style-type: none"> <li>1. Loose or damaged blade.</li> </ol>	<ol style="list-style-type: none"> <li>1. Tighten or replace blade. See <b>Page 27 or 42</b>.</li> </ol>
Burn marks on the edge of the cut.	<ol style="list-style-type: none"> <li>1. Too much side pressure when feeding workpiece.</li> <li>2. Blade too wide for size of radius being cut.</li> </ol>	<ol style="list-style-type: none"> <li>1. Feed workpiece straight into the blade. See <b>Basic Cutting Tips</b> on <b>Page 32</b>.</li> <li>2. Install a smaller width blade/increase blade tension. See <b>Page 27 or 42</b>.</li> </ol>
Rough or poor quality cuts.	<ol style="list-style-type: none"> <li>1. Feeding workpiece too fast.</li> </ol>	<ol style="list-style-type: none"> <li>1. Reduce feed rate. See <b>Basic Cutting Tips</b> on <b>Page 32</b>.</li> </ol>
Sawdust buildup inside cabinet.	<ol style="list-style-type: none"> <li>1. Clogged dust port.</li> <li>2. Low CFM (airflow) from dust collection system.</li> </ol>	<ol style="list-style-type: none"> <li>1. Clean out dust port.</li> <li>2. Three options: <ul style="list-style-type: none"> <li>—Check dust lines for leaks or clogs.</li> <li>—Move dust collector closer to saw.</li> <li>—Install a stronger dust collector.</li> </ul> </li> </ol>
Blade wanders or won't follow line of cut.	<ol style="list-style-type: none"> <li>1. Blade lead.</li> </ol>	<ol style="list-style-type: none"> <li>1. Refer to Blade Lead on <b>Page 34</b>.</li> </ol>




# Checking V-Belt

To ensure optimum power transmission from the motor to the blade, the V-belt must be in good condition and operate under proper tension. The belt should be checked for cracks, fraying, and wear. Belt tension should be checked at least every 3 months—more often if the bandsaw is used daily.

## To check the V-belt:

1. DISCONNECT BANDSAW FROM POWER!
2. Open the lower wheel cover.
3. Note the condition of the V-belt. If the V-belt is cracked, frayed, or glazed; it should be replaced as soon as convenient.
4. Push the center of the V-belt. Note the amount of deflection (**Figure 57**). If deflection is more than  $\frac{3}{4}$ ", tighten the V-belt.




**Figure 57.** V-belt deflection.

# Tensioning V-Belt

Tools Needed:	Qty
Hex Wrench 6mm.....	1

## To tension the V-belt:

1. DISCONNECT BANDSAW FROM POWER!
2. Open the lower wheel cover.
3. Loosen the motor mount screws shown in **Figure 58**.



**Figure 58.** Motor mount screws.

4. Rotate the motor to tension the V-belt, then tighten the motor adjustment screw.
5. Push the center of the V-belt. If deflection is approximately  $\frac{3}{4}$ " with moderate pressure from your thumb or finger, then the tension is correct. If the deflection is more than  $\frac{3}{4}$ ", repeat **Steps 3 & 4**.
6. When the V-belt tension is correct, tighten the motor hinge screw and close the lower wheel cover.




# Replacing V-Belt

Tools Needed:	QTY
Hex Wrench 6mm.....	1
Wrench 13mm .....	1

## To replace the V-belt:

1. DISCONNECT BANDSAW FROM POWER!
2. Open both wheel covers, and remove the blade.
3. Loosen the motor mount screws shown in **Figure 58**.
4. Unthread the wheel mount bolt shown in **Figure 59** and slide the lower wheel off of the bearing shaft.
5. Rotate the motor to release the tension on the V-belt and pull it off of the motor pulley.
6. Slip the old V-belt off of the wheel pulley and install the new V-belt in its place.
7. Install the lower wheel back onto the bearing shaft and replace/tighten the wheel mount bolt.
8. Rotate the motor to tension the V-belt, then tighten the motor adjustment screw.
9. Check the V-belt tension and adjust if necessary as described in the **Tensioning V-Belt** instructions.
10. When the V-belt tension is correct, tighten the motor hinge bolt and close the lower wheel cover.



**Figure 59.** Wheel mount bolt.




# Adjusting Tension Lever

The tension lever has an adjustment screw that allows you to adjust how much tension is released when the lever is used.

Tools Needed:	QTY
Hex Wrench 6mm.....	1
Hex Wrench 5mm.....	1

## To adjust the tension lever:

1. DISCONNECT BANDSAW FROM POWER!
2. Loosen the tension lever and remove the blade.
3. Remove the upper wheel by taking out the cap screw at the center of the wheel.
4. Move the tension lever to the tightened position.
5. Turn the adjustment screw shown in **Figure 60** until the gap between the screw and the wheel shaft hinge is  $\frac{1}{16}" - \frac{3}{16}"$ .




**Figure 60.** Tension lever adjustment components.

6. Reassemble the removed components and tension and track the blade as normal.

# Adjusting Wheel Brush

The lower wheel compartment contains the wheel brush shown in **Figure 61**. This brush is designed to sweep sawdust off the wheel tire as the bandsaw is operating. In order to work properly the brush must be making contact with the wheel.



**Figure 61.** The wheel brush.

Tools Needed:	QTY
Wrench/Socket 10mm .....	2

## To adjust the wheel brush:

1. DISCONNECT BANDSAW FROM POWER!
2. Open the lower wheel cover.
3. Loosen the bolt/nut that secures the wheel brush in place.
4. Adjust the wheel brush so it makes good contact with the wheel.
5. Tighten the bolt/nut to secure the wheel brush in place.



# Wheel Alignment

Components and Hardware Needed:	Qty
60" Long 2x4 .....	1

## Tools Needed:

Wrench 13mm .....	1
Tape Measure .....	1
Coplanarity Gauge (see <b>Figure 62</b> ) .....	1

Wheel alignment is one of the most critical factors for optimal performance from your bandsaw.


Heat, vibration, wandering, blade wear, tire wear and overall bandsaw wear are considerably decreased when the wheels are properly aligned or "coplanar."

Coplanar wheels automatically track the blade by balancing it on the crown of the wheel. This is known as coplanar tracking.


## To check if your wheels are coplanar:

1. Make the "Coplanarity Gauge" shown in **Figure 62**. **Note:** For best results, straighten the 2x4 with a jointer before cutting.
2. Remove the fence and table, then open both wheel covers.
3. Make sure the guide blocks and rear support bearings are away from the blade, then tighten your blade to the tension that it will be used during operation.
4. Place your coplanarity gauge up against both wheels in the positions shown in **Figure 63**.

Continued on next page →




**Figure 62.** Dimensions of coplanarity gauge.



**Figure 63.** Checking for coplanarity.




5. Adjust the tracking knob to get both wheels parallel. If the wheels won't go parallel to each other, then move the lower wheel at the adjustment hub (**Figure 64**) so they line up.
6. If the wheels will go parallel but not coplanar, shim the required wheel out as necessary, using thin  $\frac{3}{4}$ " washers on the shaft behind the wheel.
7. **Figure 65** shows the positions of the wheels when coplanar. When your wheels are coplanar, readjust the guide blocks and rear support bearings, and replace the wheel covers.



**Figure 64.** Lower wheel adjustment control.

**Note:** The blade may track slightly off-center when the wheels are coplanar. This is natural because the blade will be balanced on the crown of the tire, rather than just in the center of the tire. This will be more noticeable with larger blades.




**Figure 65.** Coplanarity diagram.






# G0513X Electrical Components



# G0513X Wiring Diagram








## MODEL G0513X






# G0514X Electrical Components



# G0514X Wiring Diagram




## MODEL G0514X






# G0514X3 Electrical Components






Power Supply Junction Block



Motor Wiring (220V)


Control Panel Wiring



# G0514X3 Wiring Diagram




## MODEL G0514X3






# G0513X Main Parts



# G0513X Fence/Guide Parts



# G0513X Parts List

REF	PART #	DESCRIPTION
1	P0513X001	BUSHING
2	PSS01M	SET SCREW M6-1 X 10
3	P0513X003	BUSHING
4	P0513004	LIFTING EYE BOLT M10-1.5
5	P0513005	MACHINE BODY
6	PSS07M	SET SCREW M5-.8 X 5
7	P0513X007	BUSHING
8	PW03M	FLAT WASHER 6MM
9	PWRCRD220L	POWER CORD
10	PN01M	HEX NUT M6-1
11	P0513011	POINTER
12	P0513012	SHOULDER SCREW M4-.7 X 5
13	P0513013	UPPER SHAFT
14	PRP10M	ROLL PIN 5 X 36
15	P0513015	UPPER WHEEL SHAFT HINGE
16	P0513016	UPPER WHEEL SHAFT
17	P0513017	BUSHING
18	P6204LLU	BALL BEARING 6204LLU
19	P0513X019	UPPER WHEEL 17"
20	PR25M	INT RETAINING RING 47MM
21	P0513X021	SPECIAL WASHER 8MM
22	PSB11M	CAP SCREW M8-1.25 X 16
23	P0513023	SAW BLADE 1/2" X 131.5"
24	PLW04M	LOCK WASHER 8MM
25	PSB14M	CAP SCREW M8-1.25 X 20
26	P0513X026	TIRE
27	P0513X027	LOWER WHEEL 17"
28	P0513X028	IDLE PULLEY
29	PN32	HEX NUT 1-14
30	PLW09	LOCK WASHER 1"
31	PWRCRD220S	MOTOR CORD
32	P0513032	COMPRESSION SPRING
33	PRP02M	ROLL PIN 3 X 16
34	P0513034	LOCATE BLOCK
35	P51201	THRUST BEARING 51201
36	P0513036	SWITCH
37	P0513037	HANDWHEEL
38	P0513038	ADJUSTING BOLT
39	PFS07M	FLANGE SCREW M5-.8 X 10
40	PTLW02M	EXT TOOTH WASHER 5MM
41	PN06M	HEX NUT M5-.8
42	PFS08M	FLANGE SCREW M5-.8 X 16
43	P0513043	SWITCH PLATE
44	PSB11M	CAP SCREW M8-1.25 X 16
45	P0513X045	FENDER WASHER 8MM
46	P0513046	UPPER WHEEL SLIDING BRACKET
47	PSB05M	CAP SCREW M6-1 X 50
48	P0513048	RIVET 3.2 X 10
49	PSB04M	CAP SCREW M6-1 X 10
50	P0513050	CLEAR WINDOW
51	P0513X051	TRUNNION PLATE
52	PLW04M	LOCK WASHER 8MM
53	PB03M	HEX BOLT M8-1.25 X 16

REF	PART #	DESCRIPTION
54	PCB23M	CARRIAGE BOLT M8-1.25 X 80
55	P0513055	UPPER WHEEL COVER
56	PB10M	HEX BOLT M6-1 X 25
57	PW03M	FLAT WASHER 6MM
58	P0513058	BRUSH
59	PSB06M	CAP SCREW M6-1 X 25
60	P0513X060	STAR HANDLE
61	PLN03M	LOCK NUT 6MM
62	P0513062	STRAIN RELIEF 16MM
63	P0513063	HEIGHT POINTER
64	PN03M	HEX NUT M8-1.25
65	PB124M	HEX BOLT M8-1.25 X 90
66	P0513066	KNOB SCREW M10-1.5 X 20
67	P0513067	KNOB SCREW M10-1.5 X 55
68	P0513068	THREADED HANDLE 10MM
69	P0513069	CAM
70	P0513070	PILLOW BLOCK
71	P0513071	HANDLE M10-1.5
72	P0513072	LEVER ROD
73	PN09M	HEX NUT M12-1.75
74	P0513074	SHAFT
75	PSBS01M	BUTTON HD CAP SCR M8-1.25 X 20
76	PLW04M	LOCK WASHER 8MM
77	PSB02M	CAP SCREW M6-1 X 20
78	P0513078	COVER
79	PSS09M	SET SCREW M8-1.25 X 20
80	PN03M	HEX NUT M8-1.25
81	P0513081	LOWER WHEEL SHAFT
82	P0513082	MOTOR 2HP 110/220V
82-1	P0513X082-1	MOTOR FAN COVER
82-2	P0513X082-2	MOTOR FAN
82-3	P0513X082-3	CAPACITOR COVER
82-4	P0513X082-4	R. CAPACITOR 40M 250VAC
82-5	P0513X082-5	WIRING BOX
82-6	P0513X082-6	CAPACITOR COVER
82-7	P0513X082-7	S. CAPACITOR 200M 250VAC
83	PB32M	HEX BOLT M10-1.5 X 25
84	PLW06M	LOCK WASHER 10MM
85	P0513085	MOTOR BRACKET
86	PSBS01M	BUTTON HD CAP SCR M8-1.25 X 20
87	P0513087	PLATE
88	PFS07M	FLANGE SCREW M5-.8 X 10
89	P0513089	PILLOW BLOCK
90	PK15M	KEY 5 X 5 X 35
91	PB81M	HEX BOLT M8-1.25 X 20 LH
92	P0513092	MOTOR PULLEY
93	PVA42	V-BELT A-42 4L420
94	PSB04M	CAP SCREW M6-1 X 10
95	P0513095	LOWER WHEEL COVER
96	PFH31M	FLAT HD SCR M4-.7 X 8
97	P0513X045	FENDER WASHER 8MM
98	PSB84M	CAP SCREW M10-1.5 X 35



# G0513X Parts List

REF	PART #	DESCRIPTION
99	PN02M	HEX NUT M10-1.5
100	P0513100	SMALL GEAR
101	P0513X101	LOCK HANDLE
102	P0513102	TRUNNION SUPPORT BRACKET
103	PLW06M	LOCK WASHER 10MM
104	PW04M	FLAT WASHER 10MM
105	PB18M	HEX BOLT M6-1 X 20
106	PSB37M	CAP SCREW M6-1 X 50
107	P0513107	PILLOW BLOCK
108	PN01M	HEX NUT M6-1
109	P0513109	ADJUST BOLT M6
110	P6000	BALL BEARING 6000ZZ
111	PSB02M	CAP SCREW M6-1 X 20
112	PW01M	FLAT WASHER 8MM
113	PW01M	FLAT WASHER 8MM
114	PS17M	PHLP HD SCR M4-.7 X 6
115	P0513115	GEAR PLATE
116	PLN04M	LOCK NUT M8-1.25
117	PS17M	PHLP HD SCR M4-.7 X 6
118	P0513118	LOCK HANDLE
119	PW05M	FLAT WASHER 4MM
120	P0513120	POINTER
121	P0513X121	FENCE SET ASSY L=590
121-1	PH7588001	FIXED BASE 640MM
121-2	PH7587002	ADJUST BASE
121-3	PH7587003	FIXED SHAFT
121-4	PH7587004	SHAFT
121-5	PH7587005	SPRING PIECE
121-6	PH7528004	LOCK HANDLE M8 X 44
121-7	PH7588007	SUPPORT TUBE 590MM
121-8	PW01M	FLAT WASHER 8MM
121-9	PH7587009	FENCE HANDLE M8-1.25 X 22
121-10	PH7587010	RAIL PAD
121-11	PH7587011	CONVEX
121-12	PSB69M	CAP SCREW M6-1 X 25
121-13	PH7587013	FIXED LUMP
121-14	PH7588014	SQUARE TUBE 640MM
121-15	PN03M	HEX NUT M8-1.25
121-16	PFS04M	FLANGE SCREW M4-.7 X 6
121-17	PH7587017	GUARD PIECE
121-18	PH7528002	MOVING PLATE
121-19	PH7587019	PLUG
121-20	PHTEK3M	TAP SCREW M3.5 X 8
121-21	PH7587021	SCALE
121-22	PN01M	HEX NUT M6-1
121-23	PLW03M	LOCK WASHER 6MM
121-24	PSB01M	CAP SCREW M6-1 X 16
121-25	PB08M	HEX BOLT M6-1 X 20
121-26	PFB13M	FLANGE BOLT M4-.7 X 8
121-27	PW03M	FLAT WASHER 6MM
121-28	PH7588028	RESAW FENCE (AL) 590MM


REF	PART #	DESCRIPTION
121-29	PH7587029	SPACER PLATE
122	P0513X122	GEAR
123	P0513X123	FIXED BOLT
124	P0513X124	COVER
125	PSB11M	CAP SCREW M8-1.25 X 16
126	P0513X126	TABLE 17" X 24"
127	P0513X127	TABLE INSERT
128	P0513X128	TABLE PIN
129	P0513X129	LOCATE BUSHING
130	P0513X130	BUSHING
131	PSBS01M	BUTTON HD CAP SCR M8-1.25 X 20
132	PLW04M	LOCK WASHER 8MM
133	P0513X133	GUIDE BRACKET
134	P0513X134	WORM CYLINDER
135	P0513X135	FIXED PLATE
136	PSB50M	CAP SCREW M5-.8 X 10
137	PW02M	FLAT WASHER 5MM
138	P0513X138	PROTECTIVE COVER ASSY
139	PSB72M	CAP SCREW M10-1.5 X 30
140	P0513X140	SHOULDER SCREW
141	P0513X141	FIBER WASHER
142	P0513X142	SLIDING PLATE
143	PN04M	HEX NUT M4-.7
144	P0513X144	RACK
145	P0513X145	UPPER GUIDE HOSE
146	P0513X146	HANDWHEEL
147	PSB02M	CAP SCREW M6-1 X 20
148	PCB10M	CARRIAGE BOLT M8-1.25 X 85
149	PSB01M	CAP SCREW M6-1 X 16
150	P0513X150	BLADE ADJUSTMENT ASSY
150-1	PSB01M	CAP SCREW M6-1 X 16
150-2	P0513X150-2	UPPER GUIDE SUPPORT BLOCK
150-3	PSS01M	SET SCREW M6-1 X 10
150-4	P0513X150-4	ADJUST BAR
150-5	P0513X150-5	UPPER BLADE GUIDE SUPPORT
150-6	P0513X150-6	BIAS SHAFT
150-7	PR05M	EXT RETAINING RING 15MM
150-8	P6202	BALL BEARING 6202ZZ
150-9	P0513X150-9	HANDLE BUSHING
150-10	PSB48M	CAP SCREW M6-1 X 35
150-11	P0513X150-11	UPPER SPACING SLEEVE
151	P0513X151	BLADE ADJUSTMENT ASSY
151-5	P0513X151-5	LOWER BLADE GUIDE SUPPORT
151-6	PSB01M	CAP SCREW M6-1 X 16
151-7	P0513X151-7	BIAS SHAFT
151-8	PR05M	EXT RETAINING RING 15MM
151-9	P6202	BALL BEARING 6202ZZ
151-10	P0513X151-10	HANDLE BUSHING
151-11	PSB48M	CAP SCREW M6-1 X 35
152	P0513X152	MITER GAUGE ASSY
154	PS38M	PHLP HD SCR M4-.7 X 10



# G0513X Labels

## ⚠ WARNING

Safety labels warn about machine hazards and ways to prevent injury. The owner of this machine **MUST** maintain the original location and readability of the labels on the machine. If any label is removed or becomes unreadable, **REPLACE** that label before using the machine again. Contact Grizzly at (800) 523-4777 or [www.grizzly.com](http://www.grizzly.com) to order new labels.



REF	PART #	DESCRIPTION
201	P0513X201	G0513X MODEL # LABEL
202	G8588	GRIZZLY LOGO PLATE
203	PLABEL-20	OPEN DOOR LABEL
204	P0513X204	GUARD ADJ LABEL
205	P0513X205	SCALE DIRECTIONS LABEL
206	PLABEL-11	SAFETY GLASSES LABEL
207	PLABEL-19	HANDS/BLADE LABEL
208	PLABEL-12	READ MANUAL LABEL

REF	PART #	DESCRIPTION
209	PLABEL-14	ELECTRICITY LABEL
210	P0513X210	EXTREME SERIES PLATE
211	PLABEL-18	DISCONNECT POWER LABEL
212	PLABEL-20	OPEN DOOR LABEL
213	PPAINT-11	"PUTTY" PAINT
214	P0513X214	TENSION ADJ LABEL
215	PPAINT-1	"GRIZZLY GREEN" PAINT
216	P0513X216	MACHINE ID LABEL




Exploded view diagram of a 100-watt, 120-volt incandescent bulb. The diagram shows the following components and their assembly order:

- 82-1**: The glass bulb with the filament.
- 82-2**: The base cap (screw-in base).
- 82-3**: The base cap gasket (seal).
- 82-4**: The base cap nut (screw).
- 82-5**: The base cap washer (washer).
- 82-6**: The base cap lock (lock).
- 82-7**: The base cap lock washer (washer).






## G0514X/G0514X3 Fence/Guide Parts



# G0514X/G0514X3 Labels



## WARNING

Safety labels warn about machine hazards and ways to prevent injury. The owner of this machine **MUST** maintain the original location and readability of the labels on the machine. If any label is removed or becomes unreadable, **REPLACE** that label before using the machine again. Contact Grizzly at (800) 523-4777 or [www.grizzly.com](http://www.grizzly.com) to order new labels.



# G0514X/G0514X3 Parts List

REF	PART #	DESCRIPTION
1	PSS01M	SET SCREW M6-1 X 10
2	PFS07M	FLANGE SCREW M5-.8 X 10
3	P0513X003	BUSHING
4	P0513004	LIFTING EYE BOLT M10-1.5
5	P0514005	MACHINE BODY
6	PSS07M	SET SCREW M5-.8 X 5
7	P0513X007	BUSHING
8	PW03M	FLAT WASHER 6MM
10	PN01M	HEX NUT M6-1
11	P0513011	POINTER
12	P0513012	SHOULDER SCREW M4-.7 X 5
13	P0513013	UPPER SHAFT
14	PRP10M	ROLL PIN 5 X 36
15	P0513015	UPPER WHEEL SHAFT HINGE
16	P0513016	UPPER WHEEL SHAFT
17	P0513017	BUSHING
18	P6204LLU	BALL BEARING 6204LLU
19	P0514X019	UPPER WHEEL 19"
20	PR25M	INT RETAINING RING 47MM
21	P0514X021	SPECIAL WASHER 8MM
22	PSB11M	CAP SCREW M8-1.25 X 16
23	P0514023	SAW BLADE 6TPI 143"
24	PLW04M	LOCK WASHER 8MM
25	PSB14M	CAP SCREW M8-1.25 X 20
26	P0514X026	TIRE
27	P0514X027	LOWER WHEEL 19"
28	P0514X028	IDLE PULLEY
29	PN32	HEX NUT 1-14
30	PLW09	LOCK WASHER 1"
32	P0513032	COMPRESSION SPRING
33	PRP02M	ROLL PIN 3 X 16
34	P0513034	LOCATE BLOCK
35	P51201	THRUST BEARING 51201
37	P0513037	HANDWHEEL
38	P0513038	ADJUSTING BOLT
39	P0514X039	SWITCH PLATE
40	PHTEK15M	TAP SCREW M4 X 10
41	P0514X041	KEY SWITCH 22
42	P0514X042	STOP SWITCH 22
43	P0514X043	START SWITCH 22
44	PSB11M	CAP SCREW M8-1.25 X 16
45	P0513X045	FENDER WASHER 8MM
46	P0513046	UPPER WHEEL SLIDING BRACKET
47	PSB05M	CAP SCREW M6-1 X 50
48	P0514X048	RIVET 3.2 X 6

REF	PART #	DESCRIPTION
49	PSB04M	CAP SCREW M6-1 X 10
50	P0513050	CLEAR WINDOW
51	PSB02M	CAP SCREW M6-1 X 20
52	P0514X052	BUSHING
53	PFH31M	FLAT HD SCR M4-.7 X 8
54	PSB11M	CAP SCREW M8-1.25 X 16
55	P0514055	UPPER WHEEL COVER
56	PSB06M	CAP SCREW M6-1 X 25
57	PW03M	FLAT WASHER 6MM
58	P0513058	BRUSH
59	PSB06M	CAP SCREW M6-1 X 25
60	P0513060	STAR HANDLE
61	PLN03M	LOCK NUT 6MM
62	P0513062	STRAIN RELIEF 16MM
63	P0513063	HEIGHT POINTER
64	PN03M	HEX NUT M8-1.25
65	PB124M	HEX BOLT M8-1.25 X 90
66	P0513066	KNOB SCREW M10-1.5 X 20
67	P0513067	KNOB SCREW M10-1.5 X 55
68	P0513068	THREADED HANDLE 10MM
69	P0513069	CAM
70	P0513070	PILLOW BLOCK
71	P0513071	HANDLE M10-1.5
72	P0513072	LEVER ROD
73	PN09M	HEX NUT M12-1.75
74	P0513074	SHAFT
75	PSBS01M	BUTTON HD CAP SCR M8-1.25 X 20
76	PLW04M	LOCK WASHER 8MM
77	P0514X077	COVER
78	P0513078	COVER
79	PSS09M	SET SCREW M8-1.25 X 20
80	PN03M	HEX NUT M8-1.25
81	P0513081	LOWER WHEEL SHAFT
82	P0514X082	MOTOR 3HP 1-PHASE (G0514X)
82	P0514X3082	MOTOR 3HP 3-PHASE (G0514X3)
82-1	P0514X082-1	FAN COVER (G0514X)
82-1	P0514X3082-1	FAN COVER (G0514X3)
82-2	P0514X082-2	FAN (G0514X)
82-2	P0514X3082-2	FAN (G0514X3)
82-3	P0514X082-3	START CAPACITOR COVER
82-4	PC300C	S. CAPACITOR 300MFD/250VAC
82-5	P0514X082-5	CAPACITOR COVER
82-6	PC060A	R. CAPACITOR 60MFD/250VAC
82-7	P0514X082-7	ELECTRICAL BOX COVER (G0514X)
82-7	P0514X3082-7	ELECTRICAL BOX COVER (G0514X3)



# G0514X/G0514X3 Parts List

REF	PART #	DESCRIPTION
83	PB32M	HEX BOLT M10-1.5 X 25
84	PLW06M	LOCK WASHER 10MM
85	P0513085	MOTOR BRACKET
86	PSBS01M	BUTTON HD CAP SCR M8-1.25 X 20
87	P0513087	PLATE
88	PFS07M	FLANGE SCREW M5-.8 X 10
89	P0513089	PILLOW BLOCK
90	PK15M	KEY 5 X 5 X 35
91	PB81M	HEX BOLT M8-1.25 X 20 LH
92	P0514X092	MOTOR PULLEY
93	PVA42	V-BELT A-42 4L420
94	PSB04M	CAP SCREW M6-1 X 10
95	P0514X095	LOWER WHEEL COVER
96	P0514X096	FIXED BOLT
97	P0513X045	FENDER WASHER 8MM
98	PSB84M	CAP SCREW M10-1.5 X 35
99	PN02M	HEX NUT M10-1.5
100	P0513100	SMALL GEAR
101	P0513X101	LOCK HANDLE
102	P0513102	TRUNNION SUPPORT BRACKET
103	PLW06M	LOCK WASHER 10MM
104	PW04M	FLAT WASHER 10MM
105	PB18M	HEX BOLT M6-1 X 20
106	PSB30M	CAP SCREW M6-1 X 45
107	P0513107	PILLOW BLOCK
108	PN01M	HEX NUT M6-1
109	P0513109	ADJUST BOLT M6
110	P6000	BALL BEARING 6000ZZ
111	PSB61M	CAP SCREW M10-1.5 X 20
112	PW01M	FLAT WASHER 8MM
113	PW01M	FLAT WASHER 8MM
114	PS17M	PHLP HD SCR M4-.7 X 6
115	P0513115	GEAR PLATE
116	PLN04M	LOCK NUT M8-1.25
117	PS17M	PHLP HD SCR M4-.7 X 6
118	P0513118	LOCK HANDLE
119	PW05M	FLAT WASHER 4MM
120	P0513120	POINTER
121	P0514X121	TRUNNION PLATE
122	PLW04M	LOCK WASHER 8MM
123	PB03M	HEX BOLT M8-1.25 X 16
124	PCB23M	CARRIAGE BOLT M8-1.25 X 80
125	P0514X125	FENCE SET ASSY
125-1	PH7589001	FIXED BASE 710mm
125-2	PH7587002	ADJUST BASE

REF	PART #	DESCRIPTION
125-3	PH7587003	FIXED SHAFT
125-4	PH7587004	SHAFT
125-5	PH7587005	SPRING PIECE
125-6	PH7528004	ADJUSTMENT HANDLE M8 X 44
125-7	PH7589007	SUPPORT TUBE 640mm
125-8	PW01M	FLAT WASHER 8MM
125-9	PH7587009	FENCE HANDLE M8-1.25 X 22
125-10	PH7587010	ADJUST SCREW
125-11	PH7587011	CONVEX
125-12	PSB07M	CAP SCREW M6-1 X 30
125-13	PH7587013	FIXED LUMP
125-14	PH7589014	SQUARE TUBE 710mm
125-15	PN03M	HEX NUT M8-1.25
125-16	PFS04M	FLANGE SCREW M4-.7 X 6
125-17	PH7587017	GUARD PIECE
125-18	PH7528002	MOVING PLATE
125-19	PH7587019	PLUGGED
125-20	PHTEK3M	TAP SCREW M3.5 X 8
125-21	PH7588021	SCALE
125-22	PN01M	HEX NUT M6-1
125-23	PLW03M	LOCK WASHER 6MM
125-24	PSB01M	CAP SCREW M6-1 X 16
125-25	PB08M	HEX BOLT M6-1 X 20
125-26	PFB11M	FLANGE BOLT M4-.7 X 10
125-27	PW03M	FLAT WASHER 6MM
125-28	PH7589028	RESAW FENCE (AL) 640mm
125-29	PH7587029	SPACER PLATE
126	P0514X126	TABLE 26-3/4" X 19"
127	P0513X127	TABLE INSERT
128	P0513X128	TABLE PIN
129	PSB50M	CAP SCREW M5-.8 X 10
130	PW02M	FLAT WASHER 5MM
131	P0514X131	PROTECT COVER ASSY
132	P0514X132	STEP SCREW
133	P0513X140	SHOULDER SCREW
134	P0513X141	FIBER WASHER 13MM
135	P0513X142	SLIDING PLATE
136	PSB01M	CAP SCREW M6-1 X 16
137	PSB02M	CAP SCREW M6-1 X 20
138	PS38M	PHLP HD SCR M4-.7 X 10
139	P0513X122	GEAR
140	PN04M	HEX NUT M4-.7
141	P0513X144	RACK
142	P0513X145	UPPER GUIDE TUBE
143	P0513X146	HANDWHEEL



# G0514X/G0514X3 Parts List

REF	PART #	DESCRIPTION
144	PSB02M	CAP SCREW M6-1 X 20
145	P0514X145	LOCATE BUSHING
146	P0513X130	BUSHING
147	PSBS01M	BUTTON HD CAP SCR M8-1.25 X 20
148	PLW04M	LOCK WASHER 8MM
149	P0513X133	GUIDE BRACKET
150	P0513X134	WORM CYLINDER
151	P0513X135	FIXED PLATE
152	P0514X152	BLADE ADJUSTMENT ASSY
152-1	PSB01M	CAP SCREW M6-1 X 16
152-2	P0513X150-2	UPPER GUIDE SUPPORT BLOCK
152-3	PSS01M	SET SCREW M6-1 X 10
152-4	P0513X150-4	ADJUST BAR
152-5	P0513X150-5	UPPER BLADE GUIDE SUPPORT
152-6	P0513X150-6	BIAS SHAFT
152-7	PR05M	EXT RETAINING RING 15MM
152-8	P6202	BALL BEARING 6202ZZ
152-9	P0513X150-9	HANDLE BUSHING
152-10	PSB48M	CAP SCREW M6-1 X 35
152-11	P0513X150-11	UPPER SPACING SLEEVE
153	P0514X153	BLADE ADJUSTMENT ASSY
153-5	P0513X151-5	LOWER BLADE GUIDE SUPPORT
153-6	PSB01M	CAP SCREW M6-1 X 16
153-7	P0513X151-7	BIAS SHAFT
153-8	PR05M	EXT RETAINING RING 15MM
153-9	P6202	BALL BEARING 6202ZZ
153-10	P0513X151-10	HANDLE BUSHING
153-11	PSB48M	CAP SCREW M6-1 X 35
154	P0513X152	MITER GAUGE ASSY
155	PFS09M	FLANGE SCREW M5-.8 X 50
156	P0514X156	TERMINAL BOX
157	P0514X157	TERMINAL HOUSE

REF	PART #	DESCRIPTION
158	PN04M	HEX NUT M4-.7
159	PS23M	PHLP HD SCR M5-.8 X 12
160	P0514X160	STRAIN RELIEF 20MM
161	P0514X161	MAG SWITCH 3HP/1PH/60HZ/220V
161	P0514X3161	MAG SWITCH 3HP/3PH/60HZ/220V
161A	P0514X3161A	MAG SWITCH 3HP/3PH/60HZ/440V
162	PS52M	PHLP HD SCR M4-.7 X 20
163	PFS07M	FLANGE SCREW M5-.8 X 10
165	P0514X165	SWITCH CORD
166	P0514X166	SWITCH CORD
167	P0514X167	CORD
168	P0514X168	CORD CLAMP
169	PFS12M	FLANGE SCREW M5-.8 X 12
170	PTLW02M	EXT TOOTH WASHER 5MM
201	P0514X201	G0514X MODEL # LABEL
201	P0514X3201	G0514X3 MODEL # LABEL
202	G8589	GRIZZLY LOGO PLATE
203	PLABEL-11	SAFETY GLASSES LABEL
204	PLABEL-20	OPEN DOOR LABEL
205	P0513X205	GUARD ADJ LABEL
206	PLABEL-12	READ MANUAL LABEL
207	PLABEL-14	ELECTRICITY LABEL
208	PLABEL-19	HANDS/BLADE LABEL
209	PLABEL-21	BS MOVING/ADJUST LABEL
210	PPAINT-1	"GRIZZLY GREEN" PAINT
211	P0513X210	EXTREME SERIES PLATE
212	PPAINT-11	"PUTTY" PAINT
213	PLABEL-18	DISCONNECT POWER LABEL
214	PLABEL-20	OPEN DOOR LABEL
215	P0513X214	TENSION ADJ LABEL
216	P0514X216	G0514X MACHINE ID LABEL
216	P0514X3216	G0514X3 MACHINE ID LABEL



# WARRANTY AND RETURNS

---

Grizzly Industrial, Inc. warrants every product it sells for a period of **1 year** to the original purchaser from the date of purchase. This warranty does not apply to defects due directly or indirectly to misuse, abuse, negligence, accidents, repairs or alterations or lack of maintenance. This is Grizzly's sole written warranty and any and all warranties that may be implied by law, including any merchantability or fitness, for any particular purpose, are hereby limited to the duration of this written warranty. We do not warrant or represent that the merchandise complies with the provisions of any law or acts unless the manufacturer so warrants. In no event shall Grizzly's liability under this warranty exceed the purchase price paid for the product and any legal actions brought against Grizzly shall be tried in the State of Washington, County of Whatcom.

We shall in no event be liable for death, injuries to persons or property or for incidental, contingent, special, or consequential damages arising from the use of our products.

To take advantage of this warranty, contact us by mail or phone and give us all the details. We will then issue you a "Return Number," which must be clearly posted on the outside as well as the inside of the carton. We will not accept any item back without this number. Proof of purchase must accompany the merchandise.

The manufacturers reserve the right to change specifications at any time because they constantly strive to achieve better quality equipment. We make every effort to ensure that our products meet high quality and durability standards and we hope you never need to use this warranty.

Please feel free to write or call us if you have any questions about the machine or the manual.

Thank you again for your business and continued support. We hope to serve you again soon.







# WARRANTY CARD

Name \_\_\_\_\_

Street \_\_\_\_\_

City \_\_\_\_\_ State \_\_\_\_\_ Zip \_\_\_\_\_

Phone # \_\_\_\_\_ Email \_\_\_\_\_ Invoice # \_\_\_\_\_

Model # \_\_\_\_\_ Order # \_\_\_\_\_ Serial # \_\_\_\_\_

The following information is given on a voluntary basis. It will be used for marketing purposes to help us develop better products and services. **Of course, all information is strictly confidential.**

1. How did you learn about us?

\_\_\_\_\_ Advertisement

\_\_\_\_\_ Friend

\_\_\_\_\_ Catalog

\_\_\_\_\_ Card Deck

\_\_\_\_\_ Website

\_\_\_\_\_ Other:

2. Which of the following magazines do you subscribe to?

\_\_\_\_\_ Cabinet Maker

\_\_\_\_\_ Popular Mechanics

\_\_\_\_\_ Today's Homeowner

\_\_\_\_\_ Family Handyman

\_\_\_\_\_ Popular Science

\_\_\_\_\_ Wood

\_\_\_\_\_ Hand Loader

\_\_\_\_\_ Popular Woodworking

\_\_\_\_\_ Wooden Boat

\_\_\_\_\_ Handy

\_\_\_\_\_ Practical Homeowner

\_\_\_\_\_ Woodshop News

\_\_\_\_\_ Home Shop Machinist

\_\_\_\_\_ Precision Shooter

\_\_\_\_\_ Woodsmith

\_\_\_\_\_ Journal of Light Cont.

\_\_\_\_\_ Projects in Metal

\_\_\_\_\_ Woodwork

\_\_\_\_\_ Live Steam

\_\_\_\_\_ RC Modeler

\_\_\_\_\_ Woodworker West

\_\_\_\_\_ Model Airplane News

\_\_\_\_\_ Rifle

\_\_\_\_\_ Woodworker's Journal

\_\_\_\_\_ Modeltec

\_\_\_\_\_ Shop Notes

\_\_\_\_\_ Other:

\_\_\_\_\_ Old House Journal

\_\_\_\_\_ Shotgun News

3. What is your annual household income?

\_\_\_\_\_ \$20,000-\$29,000

\_\_\_\_\_ \$30,000-\$39,000

\_\_\_\_\_ \$40,000-\$49,000

\_\_\_\_\_ \$50,000-\$59,000

\_\_\_\_\_ \$60,000-\$69,000

\_\_\_\_\_ \$70,000+

4. What is your age group?

\_\_\_\_\_ 20-29

\_\_\_\_\_ 30-39

\_\_\_\_\_ 40-49

\_\_\_\_\_ 50-59

\_\_\_\_\_ 60-69

\_\_\_\_\_ 70+

5. How long have you been a woodworker/metalworker?

\_\_\_\_\_ 0-2 Years

\_\_\_\_\_ 2-8 Years

\_\_\_\_\_ 8-20 Years

\_\_\_\_\_ 20+ Years

6. How many of your machines or tools are Grizzly?

\_\_\_\_\_ 0-2

\_\_\_\_\_ 3-5

\_\_\_\_\_ 6-9

\_\_\_\_\_ 10+

7. Do you think your machine represents a good value?

\_\_\_\_\_ Yes

\_\_\_\_\_ No

8. Would you recommend Grizzly Industrial to a friend?

\_\_\_\_\_ Yes

\_\_\_\_\_ No

9. Would you allow us to use your name as a reference for Grizzly customers in your area?

**Note:** We never use names more than 3 times.

\_\_\_\_\_ Yes

\_\_\_\_\_ No

10. Comments: \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

CUT ALONG DOTTED LINE

FOLD ALONG DOTTED LINE

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_



Place  
Stamp  
Here



GRIZZLY INDUSTRIAL, INC.  
P.O. BOX 2069  
BELLINGHAM, WA 98227-2069



FOLD ALONG DOTTED LINE

Send a Grizzly Catalog to a friend:

Name\_\_\_\_\_

Street\_\_\_\_\_

City\_\_\_\_\_State\_\_\_\_\_Zip\_\_\_\_\_

TAPE ALONG EDGES--PLEASE DO NOT STAPLE





Buy Direct and Save with Grizzly® – Trusted, Proven and a Great Value!  
~Since 1983~

*Visit Our Website Today For  
Current Specials!*

**ORDER  
24 HOURS A DAY!  
1-800-523-4777**

