

AAM6000EV ADSL Modem User's Manual

Copyright Information

Copyright © 2000 ASUSTeK Computer Inc.

All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written consent of ASUSTeK Computer Inc.

Disclaimer

ASUSTeK Computer Inc. makes no representations or warranties with respect to the contents hereof and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose. Furthermore, ASUSTeK Computer Inc. reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation to notify any person of such revisions or changes.

Trademarks

Products and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe.

Product Name:AAM6000EV ADSL ModemManual Revision:1.00 E585Release Date:August 2000

Contents

1. Introduction

	1.1	Overview	4
	1.2	Features	4
2	. Pre	parations	
	2.1	System Requirements	5
	2.2	Installing a Network Card	5
	2.3	Installing the TCP/IP Protocol	6
	2.4	Changing TCP/IP Settings	6
3	. Ins	talling the ADSL Modem	
	3.1	Front Panel	7
	3.2	Rear Panel	8
	3.3	Connecting the ADSL Modem	. 10
	3.4	Powering Up	. 10
4	. Coi	nfiguring the ADSL Modem	
	4.1	COM Port Configuration	11
	4.2	Operation Mode Configuration	. 12
	4	.2.1 MPoA/Bridged <rfc-1483></rfc-1483>	. 14
	4	.2.2 MPoA/Routed <rfc-1483></rfc-1483>	. 15
	4	.2.3 IPoA <rfc-1577></rfc-1577>	. 16
	4	.2.4 PPPoA/Bridged <rfc-2364></rfc-2364>	. 17
	4	.2.5 PPPoA/Routed <rfc-2364></rfc-2364>	. 18
	4	.2.6 PPPoE <rfc-2516></rfc-2516>	. 19
	4	.2.7 PPPoE Relay <rfc-2516></rfc-2516>	. 20

4.2.8 PPTP Access Concentrator <pac> 4.3 Load Factory Default</pac>	21 21
5. Software Upgrade5.1 System Update Procedure	22
Appendix A: Product Certifications FCC UL CE	26 26 26
Appendix B: Product Specifications ADSL Specifications ATM Specifications Basic Protocol and RFC	27 27 28
Appendix C: ADSI Acronyms	29 30 31
	01

1. Introduction

1.1 Overview

Thank you for purchasing the ASUS AAM6000EV ADSL modem. This ADSL modem delivers the highest performance in Asymetric Digital Subscriber Line technology, allowing you to simultaneously enjoy the telephone and Internet service using existing copper phone lines. Ideal for home and small business users, this easy-to-use communication device offers reliable connectivity as well as remarkable data transfer rates--up to 8Mbps downstream and 640Kbps upstream. Once the ADSL Modem is powered up, you are always online to enjoy real-time 3D animation, video conferencing, or perform other data intensive operations.

1.2 Features



Standards Compliance

- ANSI T1.413 Issue 2 compliant
- ITU-T G.992.1 (G.dmt) compliant: up to 8Mbps downstream and 640Kbps upstream data rate
- ITU-T G.992.2 (G.lite) compliant: supports splitter-less implementation and up to 1.5Mbps downstream and 512Kbps upstream data rate
- ITU-T G.994.1 (G.hs), G.996.1 (G.test), and G.997.1 (G.ploam) support via software upgrade as standards approved by ITU-T

Hardware Features

- Interoperable with Alcatel, Cisco, Lucent, and other DSLAMs
- Supports 8 bits of VPI and 16 bits of VCI address range
- Capable of transmitting data up to 19,000 feet

Software Features

- Supports RFC 2364 protocol (PPP over ATM), RFC 1483 encapsulation, RFC 2516 protocol (PPP over Ethernet), and RFC 1577 protocol (classical IP over ATM)
- Firmware upgrade and configuration restoration over TFTP

2.1 System Requirements

2.2 Installing a Network Card

Before connecting the ADSL modem to your PC, make sure your system is equipped with an Ethernet controller and supports the TCP/IP protocol.

If your system does not have an embedded Ethernet controller, you must install a network interface card as instructed below (assuming that you are using the ASUS PCI-L101 Fast Ethernet card under the operating system of Windows 98):

- 1. Install the PCI-L101 card on your motherboard.
- 2. Power up your PC and follow the Add New Hardware Wizard's instructions to install the driver. When asked to restart your computer at the end of the installation, click Yes.
- 3. After restarting the system, right-click My Computer on the desktop, select Properties, click the Device Manager tab, and then double-click Network adapters to confirm that the Ethernet driver is properly installed.



stem Pr	operties							?
General	Device Mar	nager Ha	rdware Pr	rofiles	Perf	ormano	æ]	
€ Vie	w devices by	type	C Viev	v dev	ices by	conne	ection	
	omputer							
	Disk drives							
	Display ad Elegended	apters						
0.0	g nioppy aisr S Hard diek :	controller	8					
) Infrared de	vices						
i i a	Keyhnard	1000						
- ÷-È	Monitors							
-€	Mouse							
÷	Network a	dapters						
	Intel 8	2558-basei	d Integrate	ed Eti	nemet	with W	ake o	n LAN
- ÷ 2	Ports (CDN	l & LPT)						
비민물	System de	vices	19.22					
	Universal S	ierial Bus d	controllers					
Pro	operties	Refres	h	Rg	move		P	rint
						OK		Cancel
					_			

2. Preparations



2.4 Changing TCP/IP Settings

After the TCP/IP protocol is installed, restart your computer and consult the installation guide provided by your telephone company to complete TCP/IP configurations.

3. Installing the ADSL Modem

5

3.1 Front Panel

		ADCL-MODEM	POWER STATUS LINE PC TEST			
LE	D Indicator	State	Description			
1.	Power LED	ON OFF	Modem is powered ON Modem is powered OFF			
2.	Status LED (ADSL Line Status)	ON	"Showtime"–successful connection between ADSL modem and telephone company's network			
		Flashing	"Handshaking"-modem is trying to establish a connection to telco's network			
		OFF	"Down"-ADSL line is inactivated			
3.	Line LED (WAN Traffic LED)	ON Flashing OFF	Successful connection to telco's network; ready for data transmission Data transmitting between modem and telco's network Disconnected from ADSL line; not ready for data transmission			
4.	PC Link LED (LAN Traffic LED)	ON Flashing OFF	Successful connection between LAN and PC Data transmitting between LAN and PC No connection between LAN and PC*			
5.	Test	ON OFF	Error (Resetting the ADSL modem may help; if not, contact customer support) Normal operation			
		-				

1

2

2

Л

* Check if the Ethernet cable is properly connected and the HUB-PC switch is in the correct position.

3.2 Rear Panel



1. DC +5V/2A Power Input Jack

The provided power adapter converts AC power to DC power for use with this jack. Power supplied through this jack will supply power to the ADSL Modem.

2. Line Connector

The RJ-11 connector allows ADSL data communication between the modem and the PSTN through a twisted-pair phone wire.

3. Console Port

The 9-pin D-sub serial port supports the RS-232 terminal interface for advanced ADSL modem management.

4. Reset Switch

The reset button, when pressed, resets the modern without the need to unplug the power cord.

5. USB Port (optional)

The optional USB port allows the modem to be connected to your computer through the USB interface.

6. 10/100-BaseT Ethernet Port

The RJ-45 Ethernet port supports 10Base-T networks. (100Base-TX networks will be supported in the near future.) This port allows your PC or Ethernet hub to be connected to the ADSL Modem through a Cat. 5 Ethernet cable.

3.2 Rear Panel (Cont')

7. HUB-PC Switch

The HUB-PC switch controls the crossover function. Modem-to-PC connection must contain crossovers. When connecting the modem to a PC, leaving the switch on the default position **PC** allows you to implement crossover cabling without using a crossover cable. When connecting the modem to an Ethernet hub's RJ-45 downlink port, use a pen or screwdriver to slide the switch to **HUB** and implement straight-through cabling. If you run out of the hub's downlink ports and connect the modem to the uplink port, you must slide the switch to the position of **PC**.

Example 1. Modem to PC

Example 2. Modem to Hub (Downlink)

0000000

Example 3. Modem to Hub (Uplink)



When using a PC with the modem, adjust the HUB-PC switch to the position of **PC**.

When connecting the modem to an Ethernet hub's downlink port, adjust the HUB-PC switch to the position of **HUB**.

When connecting the modem to an Ethernet hub's uplink port, adjust the HUB-PC switch to the position of **PC**.

3. Installing the ADSL Modem

3.3 Connecting the ADSL Modem

Take the following steps to accomplish the installation procedure:

- 1. Connect the ADSL cable to the line connector of an ADSL POTS splitter.
- 2. Connect a telephone cable from the phone connector of the splitter to your telephone.
- **3.** Use another telephone cable to connect the modem connector of the splitter and the **Line** connector on the rear panel of the ADSL modem.
- **4.** Connect the Ethernet cable from the RJ-45 port on your computer to the Ethernet port on the ADSL Modem. Make sure the HUB-PC switch is in the correct position.
- Connect the AC power adapter to the DC +5V/2A input jack on the ADSL Modem. Plug in the AC power adapter to an electrical outlet.

NOTE: If you are not using a telephone or fax machine on the ADSL line, skip steps 1 to 3 and connect the ADSL cable directly to the **Line** connector on the rear panel of the ADSL Modem.



3.4 Powering Up

When all connections have been properly made and the power is ON, the ADSL modem will automatically start the self-test and log on to your phone company's ADSL network. For new modems, please go through the configuration as detailed in the following section, and then you are all set and ready to enjoy the Internet services at a marvelous speed!

4.1 COM Port Configuration



Hypertrm

Recommended COM Port Settings:

Bit Rate: 9600 bps Data Bits: 8 Parity Check: None Stop Bit: 1 Flow Control: None For advanced modem management, use a serial cable to connect the Console port on the ADSL modem to your PC's empty COM port. (See the illustration in *3.3 Connecting the ADSL Modem*.) Open a VT100 terminal emulation program such as NetTerm or Windows' HyperTerminal to configure the COM port. (The setup under HyperTerminal is given as an example below.)

In Windows, click **Start**, **Programs**, **Accessories**, **Communications**, and then select **HyperTerminal**. When the HyperTerminal window appears, double click on the HyperTerminal icon to run it. If you cannot find it, add the program using **Add/Remove Programs** in Control Panel.

1. When HyperTerminal is started, you will be prompted to establish a new connection. Follow the onscreen instruction.



- 2. For ADSL connections, you do not have to enter dial-up information. Simply choose the COM port that you are using and then click OK.
- **3.** Configure the COM port as shown below.



4.2 Operation Mode Configuration



NOTE: Because the software for the AAM6000EV is constantly being updated, the following console screens and descriptions are for reference purposes only and may not reflect your console screens exactly. After the COM port is properly configured, select an operation mode for the ADSL modem in the terminal emulation program. If you have established an ADSL connection as demonstrated in *4.1 COM Port Configuration*, you may evoke the Main Menu of the AAM6000EV ADSL Modem Console by placing the pointer in the white area of HyperTerminal and then pressing <Enter>. The Main Menu of the Console will appear as follows:



Key in 3 in the Main Menu to start the Quick Setup Wizard.

Troubleshooting: If the Main Menu does not show up after pressing <Enter>, reset the modem and then try again.

4.2 Operation Mode Configuration (Cont') Note Configuration (Cont')



• Symbols

To complete certain configurations, you should be aware of two symbols used throughout this manual.



Telco Define: Information should be provided by your phone company.



User Define: You may enter the information required either as you wish or according to your own environment.

4.2.1 MPoA/Bridged <RFC-1483>

MPoA/Bridged mode complies with IETF RFC-1483 Multiprotocol Encapsulation over ATM Adaptation Layer 5. In this mode, the modem acts as a bridging device.

🗞 ADSL - HyperTerminal						
<u>File Edit View Call Iransfer H</u> elp						
[
1. MPoA/Bridged (RFC-1483) Setup Wizard. 2. MPoA/Routed (RFC-1483) Setup Wizard. 3. IPoA (RFC-1577) Setup Wizard. 4. PPPoA/Bridged(RFC-2364) Setup Wizard. 5. PPPoA/Routed (RFC-2364) Setup Wizard. 6. PPPoE (RFC-2516) Setup Wizard. 8. PPTP Access Concentrator(PAC) Setup Wizard. 8. PPTP Access Concentrator(PAC) Setup Wizard. Press '.' to Back, Step 1 Press '.' to Back, Step 1 Fress '.' to Back, Step 1 Step 1 Step 2 Press '.' to Back, Step 2						
Do you really want to setup as MPoA Bridged(y/n,Default:n,ESC:Cancel)? y						
Enter UPI < 0 ^{~255} , ESC: Cance 1>: 8 < Step 3 Enter UCI < 32 ^{~4095} , ESC: Cance 1>: 38 < Step 4 Step 5						
Do you want to Save Configuration and Restart Modem(y/n,Default:y)? y Saving configuration						
Connected 0:05:41 Auto detect 9600 8-N-1 SCROLL CAPS NUM Capture Print echo						

Bridged Enter 1 in the Quick Setup Wizard to set up MPoA/Bridged mode.

4.2.2 MPoA/Routed <RFC-1483>

MPoA/Routed mode complies with IETF RFC-1483 Multiprotocol Encapsulation over ATM Adaptation Layer 5. In this mode, the modem acts as a routing device, and, when configured to, implements a NAT function for users to assign virtual IPs to their PCs.

🗞 ADSL - HyperTerminal
<u>File Edit View Call Iransfer Help</u>
MODEM ACTIVATING. Press '.' to Back, ESC' of Main Menu. Enter Your Selection[1-8]: 2 Do you really want to setup as MPoA Routed(y/n,Default:n,ESC:Cancel)? y
Enter Ethernet IP Address(Example 192.168.1.1,ESC to Cancel): 192.168.1.1
Enter Subnet Address(Example ff:ff:60,ESC to Cancel): ff:ff:60 Enter UPI(0~255,ESC:Cancel): 8 < Step 5 Enter UCI(32~4095,ESC:Cancel): 38 < Step 6 Step 6
Step 7 Enter MPoA WAN IP Address(Example 192.168.1.1,ESC to Cancel): 192.72.126.1
Step 8 > Enter Subnet Address(Example ff:ff:ff:00,ESC to Cancel): ff:ff:ff:00
Do you want to use NAT(y/n,Default:n,ESC to Cancel)? y Step 9 Do you want to Save Configuration and Restart Modem(y/n,Default:y)? y
Saving configuration Step 10
Connected 3:46:14 Auto detect 9600 8-N-1 SCROLL CAPS NUM Capture Print echo

Note for Step 8: The subnet address must consist of hexadecimal numbers.

Enter 2 in the Quick Setup Wizard to set up MPoA/Routed mode.

4.2.3 IPoA <RFC-1577>

IPoA mode complies with the IETF RFC-1577 IP over ATM. In this mode, the modem acts as a routing device and, when configured to, implements a NAT function for PCs to share a single real IP. Enter 3 in the Quick Setup Wizard to set up IPoA mode.



Note for Step 7: The subnet address must consist of hexadecimal numbers.

4.2.4 PPPoA/Bridged Enter **4** in the Quick Setup Wizard to set up PPPoA/Bridged mode. **<RFC-2364>**

PPPoA/Bridged mode complies with IETF RFC-2364 PPP over ATM. In this mode, the modem acts as a bridging device, and allows users to enter their user names and passwords to log on to the server's network. This mode also supports authentication protocols (PAP, CHAP) and different IP control protocols (IPCP, DHCP).

🗞 ADSL - HyperTerminal 📃 🖂
<u>File Edit View Call Iransfer Help</u>
MODEM ACTIUATING. Press '.' to Back, 'ESC' to Main Menu. Enter Your Selection[1-8]: 4 Do you really want to setup as PPPoA Bridged(y/n,Default:n,ESC:Cancel)? y Enter UPI(0~255,ESC:Cancel): 8 < Step 3 Enter UCI(32~4095,ESC:Cancel): 38 < Step 4 Enter User Name(ESC to Cancel): xxxx < Step 5 Enter Password: ****** < Step 6 ReEnter Password: ****** < Step 7 Authentication Type:(1)PAP.(2)CHAP.(3)None. < Step 8 Enter Your Selection: 1 Do you want to Save Configuration and Restart Modem(y/n,Default:y)? y < Step 9 Saving configuration
Connected 4:02:15 Auto detect 9600 8-N-1 SCROLL CAPS NUM Capture Print echo

4.2.6 PPPoA/Routed Enter **5** in the Quick Setup Wizard to set up PPPoA/Routed mode. **<RFC-2364>**

PPPoA/Routed mode complies with IETF RFC-2364 PPP over ATM. In this mode, the modem acts as a routing device, and allows users to enter their user names and passwords to log on to the server's network. This mode also supports authentication protocols (PAP, CHAP), different IP control protocols (IPCP, DHCP), and a NAT function for PCs to share a real IP.

🗞 ADSL - HyperTerminal
<u>File Edit View Call Transfer Help</u>
Enter Your Selection[1-8]: 5
Do you really want to setup as PPPoA Routed(y/n,Default:n,ESC:Cancel)? y
Enter Ethernet IP Address(Example 192.168.1.1,ESC to Cancel): 192.168.1.1 Step 3
Enter Subnet Address(Example ff:ff:60,ESC to Cancel): ff:ff:ff:00 < Step 4
Enter UPI(0~255,ESC:Cancel): 8 < Step 5
Enter UCI(32~4095,ESC:Cancel): 38 < Step 6
Enter User Name(ESC to Cancel): xxxxxx < Step 7
Enter Password: ****** < Step 8
ReEnter Password: ****** < Step 9
Authentication Type:(1)PAP.(2)CHAP.(3)None. Step 10
Get IP Address Type from:(1)IPCP.(2)DHCP.(3)Customize. < Step 11
Do you want to use NAT(y/n,Default:n, ESC to Cancel>? y < Step 12
Do you want to Save Configuration and Restart Modem(y/n,Default:y)? y
Saving configuration Step 13
Connected 0:07:00 Auto detect 9600 8-N-1 SCROLL CAPS NUM Capture Print et

Note for Step 4: The subnet address must consist of hexadecimal numbers.

4.2.7 PPPoE <RFC-2516>

PPPoE mode complies with IETF RFC-2516 PPP over Ethernet. In this mode, the modem allows users to enter their user names and passwords to log on to the server's network. This mode also supports authentication protocols (PAP, CHAP), different IP control protocols (IPCP, DHCP), and a NAT function for PCs to share a real IP. Enter 6 in the Quick Setup Wizard to set up PPPoE mode.



Note for Step 4: The subnet address must consist of hexadecimal numbers.

4.2.8 PPPoE Relay RFC-2516>

PPPoE mode complies with IETF RFC-2516 PPP over Ethernet. In this mode, the modem allows users to use other software solutions to implement the PPPoE client function.

Real ADSL - HyperTerminal	_ 🗆 🗵
<u>File Edit View Call Transfer H</u> elp	
1. MPoA/Bridged (RFC-1483) Setup Wizard. 2. MPoA/Routed (RFC-1483) Setup Wizard. 3. IPoA (RFC-1577) Setup Wizard. 4. PPPoA/Bridged(RFC-2364) Setup Wizard. 5. PPPoA/Routed (RFC-2364) Setup Wizard. 6. PPPoE (RFC-2516) Setup Wizard. 8. PPIP Access Concentrator(PAC) Setup Wizard. MODEM ACTIVATING. Press '.' to Back, 'F ^{CC-1} More Menu. Enter Your Selection[1-8]: 7 Step 1 Do you really want to setup as PPPoE Relay(y/n, Default:n, ESC:Cancel)? y Enter UPI(0°255, ESC:Cancel): 8 Step 3 Enter UCI(32~4095, ESC:Cancel): 38 < Step 4 Do you want to Save Configuration and Restart Modem(y/n, Default:y)? y < S	{Step 2 Step 5
Saving configuration	
Connected 17:52:07 Auto detect 9600 8-N-1 SCROLL CAPS NUM Capture Print echo	

Enter 7 in the Quick Setup Wizard to set up PPPoE Relay mode.

4.2.9 PPTP Access Concentrator <PAC

Default

Menu.

Step 1

Enter 8 in the Quick Setup Wizard to set up PPTP Access Concentrator mode.

Concentrator <pac></pac>	🗞 ADSL - HyperTerminal
PPTP Access Concentrator mode supports Virtual Private Network (VPN) with the latest PPTP technology. It allows remote users to log on to a private network through the Internet or other networks.	File Edit View Call Iransfer Help 2. MPOA/Routed (RFC-1483) Setup Wizard. 3. IPOA (RFC-1577) Setup Wizard. 4. PPPOA/Routed (RFC-2364) Setup Wizard. 5. PPPOE (RFC-2364) Setup Wizard. 6. PPPOE (RFC-2516) Setup Wizard. 7. PPPOE Relay (RFC-2516) Setup Wizard. 8. PPIP Recess Concentrator(PAC) Setup Wizard. MODEM ACTIVATING. Press '.' to Back, 'FSC' tn M Menu. Enter Your SelectionII-81: 8 Step 1 Do you really want to setup as PAC(y/n, Default:n, ESC:Cancel)? y Enter Ethernet IP Address(Example 192.168.1.1, ESC to Cancel): 192.168.1.1 Step 2 Enter UPI(0°255, ESC:Cancel): 8 Step 3 Enter UCI(32°4095, ESC:Cancel): 38 Step 4 Do you want to Save Configuration and Restart Modem(y/n, Default:y)? y Saving configuration Connected 17:54:10 Auto detect 9600 8N-1 SCPOLL CAPS NUM Capture Print echo
4.3 Load Factory	Enter 5 in GOODEU ADSL MODEM Console 3.1 [No Operation Main Menu Enter 2 in the Main

Maintenance -

Menu.

Display Version.

twork Status

5. System Maintenance

2.

Ь.

ADSL Line Status.

Quick Setup Wizard.

Screen Display Mode.

System Maintenance Menu

View All Configuration

Restore Factory Default

2

Step 2

FILTEWOT

4. BootROM Update.

5.1 System Update Procedure

- 1. Download an updated software image file from the Internet (see ASUS Contact Information on the inside of the back cover for details) and save it to your hard drive.
- 2. Make sure the modem is connected to your PC through the Ethernet interface and the Console port on the modem is connected to your PC's COM port.
- 3. Run a terminal emulation program such as HyperTerminal.
- 4. Run a BOOTP server program such as Weird Solutions' BOOTP Server95, which works on Windows 95/98 as well as Windows NT. Configure your BOOTP server as shown below.

BOOTP Server95 properties	Enter the MAC address labeled on the back of you ADSL modem.	
Hardware Address 00-20-28-00-47-40	Total: 3 New Del	ete Select Boot file and IP address from Avalable options.
Available options Home directory Host name IEN-116 Name servers Impress servers Interface MTU IP Forwarding	Configured options Boot file IP address <	Click Edit to enter the IP
Log servers I PR servers Template <no template=""></no>	Value 210.66.16.168	address of your computer.
Copyright © 1396 \	Veird s Click Close when you	are done.

- 5.1 System Update Procedure (Cont')
- 5. Run a TFTP server program such as Cisco TFTP Server.

Options		×	
☑ Show file transfer progress			
Enable logging			
Log filename:			
C:\PROGRAM FILES\CISCO S	YSTEMS\CISCO TFTP	Browse	
<u>M</u> aximum log file size (KB):	20 •	Browse to th the updated	e location of FLASH file you
<u>IFTP</u> server root directory:			
S:\AAM6000EV\flashX.bin	13	Browse	
OK	Cancel		

- 5.1 System Update Procedure (Cont')
- Press the reset button on the modem and at the same time press the asterisk key <*> in your terminal emulation program. When a question appears asking you to "Boot from Ethernet, USB or Flash", enter E since the modem is connected to your computer through the Ethernet interface.



7. The modem will then boot from the Ethernet and automatically start downloading the software image file from the computer.

5.1 System Update Procedure (Cont')

🗞 com 2 - HyperTerminal
Eile Edit View Call Iransfer Help
Ďone! (0x00200000 bytes)
Starting mkflash image
NBn Helium Family PP flash boot 6.1.0.25 (20 Jan 2000) (c) Copyright ASUSTek Computer 2000. SDRAM size = 0x800000, type = 0x2 ASUS-CPTBCODES.20000526 ASUS-CPTECODES.20000526 NPARSUS ADSL Modem 6000EV version Ver 1.0.5.2.6 (26 May 2000) ADSL Modem SW 4.5.1 Copyright (c) 2000 ASUSTek Inc.
NP software version is 0x06010019 (reply took 23us)
Connected 21247 Auto detect 9500 RN-1 SCROLL CAPS NUM Costure Print scho

- When the file is successfully downloaded, the main menu of the updated console will be launched.
- 9. In Main Menu, enter **5** for System Maintenance.
- In System Maintenance Menu, enter 3 for Firmware Update. The software update is now completed.

NOTE: If Boot ROM update is required as part of the software upgrade, it will be specified on the ASUS web site where you download the updated software image. Then please refer to the web site for detailed Boot ROM update procedures.



FCC (Federal Communications Commission Statement)

This ASUS AAM6000EV ADSL Modem has been tested and found to comply with the limits for a class B personal computer and peripherals, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this unit does cause harmful interference to radio or television reception, which can be determined by turning the unit off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

UL This product meets all safety requirements per UL-1950 Type 3 standard.

This certificate of conformity is based on an evaluation of the AAM6000EV product that is in compliance with the Low Voltage Directive 73/23/EEC and the Amendment Directive 93/68/ EEC.

CE

ADSL Specifications		
Line Coding	Discrete Multi-Tone (DMT)	
Standards Compliance	Full rate ADSL ANSI T1.413 Issue 2	
	• ITU G.992.1 (G.dmt)	
	Splitterless ITU G.992.2 (G.lite)	
Data Rate	Maximum transmission rate: Downstream up to 8Mbps	
	Upstream up to 800Kbps	
Rate Adaption	Data rate auto-negotiation in 32Kbps increments	

ATM Specifications		
ATM Adaption Layer	Supports AAL5	
ATM Signaling	ATM Forum UNI3.0, 3.1, and UNI4.0	
VCs	Supports multiple Permanent Virtual Circuits (PVCs)	
Service Class	• CBR, UBR	
OAM	 ITU-T I.610 OAM Principles and Functions (including F4/F5) loop 	

Basic Protocol & RFC		
RFC 1483	Multiple protocol encapsulation over AAL5	
	 Supports Logical Link Control (LLC) encapsulation 	
	Supports VC-based multiplexing	
RFC 2364	PPP over AAL5	
	Supports LLC encapsulation	
	 Supports VC-based multiplexing 	
	Supports VPN	
RFC 2516	PPP over Ethernet	
	Supports VPN	
RFC 1577	Classical IP and ARP over ATM	
RFC 1661	PPP Link Control Protocol (LCP)	
RFC 1332	Internet Protocol Control Protocol (IPCP)	
RFC 1334	PPP Authentication Protocol (PAP)	
RFC 1994	PPP Challenge Handshake Authentication Protocol (CHAP)	
RFC 792	Internet Control Message Protocol (ICMP)	
802.1 d	Spanning-tree bridge	

Routing Function		
RFC 1058, 1723	Routing Information Protocol (RIP, RIPv2)	
	 Packet Filtering for the In/Out Packets 	
RFC 1631	Network Address Translation (NAT)	
	Supports FTP, mail, Telnet, HTTP	
	Supports Netmeeting	
RFC 2131	31 Dynamic Host Configuration Protocol (DHCP)	
	Supports DHCP server and client	
VPN Virtual I • Suppo	Virtual Private Networks	
	 Supports Point-to-Point Tunneling Protocol (PPTP) 	

Hardware Specification		
Console Interface	Menu-driven user interface	
Console Access	Via RS-232 interface	
Interface port	 LAN: 10Base-T Ethernet (RJ-45) 	
	WAN: ADSL line (RJ-11)	
	USB (optional)	
	Console management: RS-232	
Dimensions (H x W x D)	• 34.60 x 202.95 x 182.50mm	
Weight	• 470g	
Power Consumption	• 10W (max.)	
DC Input Voltage	• DC +5V	
Operating Temperature	• 32° ~ 104° F (0° ~ 40° C)	
Non-operating Temp.	• -4° ~ 149° F (-20° ~ 65° C)	

Appendix C: ADSL Acronyms

ADSL	Asymmetric Digital Subscriber Line	
ANSI	American National Standards Institute	
ARP	Address Resolution Protocol	
АТМ	Asynchronous Transfer Mode	
СНАР	Challenge-Handshake Authentication Protocol	
DHCP	Dynamic Host Configuration Protocol	
DMT	Discrete Multi-Tone	
DSLAM	Digital Subscriber Line Access Multiplexer	
IETF RFC	Internet Engineering Task Force Request for Comments	
IPCP	Internet Protocol Control Protocol	
IPoA	IP over ATM	
ITU	International Telecommunication Union	
ITU-T	ITU Telecommunication Standardization Sector	
МРоА	Multiprotocol Encapsulation over ATM Adaptation Layer 5 (AAL5	
NAT	Network Address Translation	
PAC	PPTP Access Concentrator	
PAP	Password Authentication Protocol	

Appendix C: ADSL Acronyms

POTS	Plain Old Telephone Service
PPP	Point-to-Point Protocol
PPPoA	PPP over ATM Adaptation Layer 5
PPTP	Point-to-Point Tunneling Protocol
PPPoE	PPP over Ethernet
PSTN	Public Switched Telephone Network
Telco	Telephone Company
VCI	Virtual Circuit Identifier
VPI	Virtual Path Identifier
VPN	Virtual Private Network