

# **User Manual**

# **ADAM-5560 Series**

**Programmable Automation Controllers** 



# Copyright

The documentation and the software included with this product are copyrighted 2012 by Advantech Co., Ltd. All rights are reserved. Advantech Co., Ltd. reserves the right to make improvements in the products described in this manual at any time without notice. No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written permission of Advantech Co., Ltd. Information provided in this manual is intended to be accurate and reliable. However, Advantech Co., Ltd. assumes no responsibility for its use, nor for any infringements of the rights of third parties, which may result from its use.

# **Acknowledgements**

ADAM is a trademark of Advantech Co., Ltd.

IBM and PC are trademarks of International Business Machines Corporation.

MULTIPROG is a trademark of KW-Software Gmbh.

All other product names or trademarks are properties of their respective owners.

# **Product Warranty (2 years)**

Advantech warrants to you, the original purchaser, that each of its products will be free from defects in materials and workmanship for two years from the date of purchase.

This warranty does not apply to any products which have been repaired or altered by persons other than repair personnel authorized by Advantech, or which have been subject to misuse, abuse, accident or improper installation. Advantech assumes no liability under the terms of this warranty as a consequence of such events.

Because of Advantech's high quality-control standards and rigorous testing, most of our customers never need to use our repair service. If an Advantech product is defective, it will be repaired or replaced at no charge during the warranty period. For outof-warranty repairs, you will be billed according to the cost of replacement materials, service time and freight. Please consult your dealer for more details.

If you think you have a defective product, follow these steps:

- 1. Collect all the information about the problem encountered. (For example, CPU speed, Advantech products used, other hardware and software used, etc.) Note anything abnormal and list any onscreen messages you get when the problem occurs.
- 2. Call your dealer and describe the problem. Please have your manual, product, and any helpful information readily available.
- 3. If your product is diagnosed as defective, obtain an RMA (return merchandize authorization) number from your dealer. This allows us to process your return more quickly.
- 4. Carefully pack the defective product, a fully-completed Repair and Replacement Order Card and a photocopy proof of purchase date (such as your sales receipt) in a shippable container. A product returned without proof of the purchase date is not eligible for warranty service.
- 5. Write the RMA number visibly on the outside of the package and ship it prepaid to your dealer.

Part No. XXXXXXXXXX Printed in Taiwan Edition 1 February 2014

# **Declaration of Conformity**

#### CE

This product has passed the CE test for environmental specifications when shielded cables are used for external wiring. We recommend the use of shielded cables. This kind of cable is available from Advantech. Please contact your local supplier for ordering information.

#### FCC Class A

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

# **Technical Support and Assistance**

- 1. Visit the Advantech web site at www.advantech.com/support where you can find the latest information about the product.
- 2. Contact your distributor, sales representative, or Advantech's customer service center for technical support if you need additional assistance. Please have the following information ready before you call:
  - Product name and serial number
  - Description of your peripheral attachments
  - Description of your software (OS, version, application software, etc.)
  - A complete description of the problem
  - The exact wording of any error messages

# **Safety Precaution - Static Electricity**

Follow these simple precautions to protect yourself from harm and the products from damage.

- To avoid electrical shock, always disconnect the power from your PC chassis before you work on it. Don't touch any components on the CPU card or other cards while the PC is on.
- Disconnect power before making any configuration changes. The sudden rush of power as you connect a jumper or install a card may damage sensitive electronic components.

# **Safety Instructions**

- 1. Read these safety instructions carefully.
- 2. Keep this User Manual for later reference.
- 3. Disconnect this equipment from any AC outlet before cleaning. Use a damp cloth. Do not use liquid or spray detergents for cleaning.
- 4. For plug-in equipment, the power outlet socket must be located near the equipment and must be easily accessible.
- 5. Keep this equipment away from humidity.
- 6. Put this equipment on a reliable surface during installation. Dropping it or letting it fall may cause damage.
- 7. The openings on the enclosure are for air convection. Protect the equipment from overheating. DO NOT COVER THE OPENINGS.
- 8. Make sure the voltage of the power source is correct before connecting the equipment to the power outlet.
- 9. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
- 10. All cautions and warnings on the equipment should be noted.
- 11. If the equipment is not used for a long time, disconnect it from the power source to avoid damage by transient overvoltage.
- 12. Never pour any liquid into an opening. This may cause fire or electrical shock.
- 13. Never open the equipment. For safety reasons, the equipment should be opened only by qualified service personnel.
- 14. If one of the following situations arises, get the equipment checked by service personnel:
- 15. The power cord or plug is damaged.
- 16. Liquid has penetrated into the equipment.
- 17. The equipment has been exposed to moisture.
- 18. The equipment does not work well, or you cannot get it to work according to the user's manual.
- 19. The equipment has been dropped and damaged.
- 20. The equipment has obvious signs of breakage.
- 21. DO NOT LEAVE THIS EQUIPMENT IN AN ENVIRONMENT WHERE THE STORAGE TEMPERATURE MAY GO BELOW -20° C (-4° F) OR ABOVE 60° C (140° F). THIS COULD DAMAGE THE EQUIPMENT. THE EQUIPMENT SHOULD BE IN A CONTROLLED ENVIRONMENT.
- 22. CAUTION: DANGER OF EXPLOSION IF BATTERY IS INCORRECTLY REPLACED. REPLACE ONLY WITH THE SAME OR EQUIVALENT TYPE RECOMMENDED BY THE MANUFACTURER, DISCARD USED BATTERIES ACCORDING TO THE MANUFACTURER'S INSTRUCTIONS.
- 23. The sound pressure level at the operator's position according to IEC 704-1:1982 is no more than 70 dB (A).

DISCLAIMER: This set of instructions is given according to IEC 704-1. Advantech disclaims all responsibility for the accuracy of any statements contained herein.

# Contents

Chapter	1	Overview	1
	11	Introduction	2
	1.2	Features	2
		Table 1.1: Programming Languages Table	4
		Figure 1.1 Cross-Language Programming	4
		Table 1.2: I/O Module Support List	6
		Figure 1.2 ADAM-5560 Communication Ports	7
	1.3	Specifications	8
		1.3.1 System	8
		1.3.2 USB Ports	8
		1.3.3 VGA Port	8
		1.3.4 Ethernet Ports	8
		1.3.5 RS-232/485 interface (COM1)	8
		1.3.6 RS-485 interface (COM2)	9
		1.3.7 ES-232/485 interface (COM3) (Suitable for touchscreen)	9
		1.3.8 RS-232/485 interface (COM4)	9
		1.3.9 Isolation	9
		1.3.10 Power	9
		1.3.11 Mechanical	10
		1.3.12 EIIVIIOIIIIeIII	10
	1 /	Dimensions	10 10
	1.4	Figure 1.3 ADAM-5560 Dimensions	10
	15	I FD Status	10
	1.6	Limitations	11
		1.6.1 Remote I/O Quantity	11
		1.6.2 Modbus/RTU Slave Function	11
		1.6.3 TCP/IP Connections	11
		1.6.4 Firmware Upgrade Notice	11
		1.6.5 Boot-up Time	11
Chapter	2	Installation	.13
	2.1	Overview	1/
	2.1	System Requirements	14 1/
	2.2	2.2.1 Host Computer Requirements	14 14
		2.2.1 Those computer requirements	14
		2.2.2 //DAM 5566 Genes Requirements	14
	23	Hardware Installation	15
	2.0	2.3.1 Selecting I/O Module	15
		Table 2.1: Discrete and Analog I/O Selection Guidelines	15
		2.3.2 Selecting Power Supply Module	18
		Table 2.2: Power Consumption of ADAM-5000 series (Main L	Jnits)
		Table 2.3: Power Consumption of ADAM-5000 series (IO Mo	od-
		Ules)	19
		Table 2.4. Fower Supply Specification Table	20
		2.3.3 INStall Wall Unit and Woodules	20
		2.3.4 I/O SIUS AND I/O CHAINEI NUMBENNY	∠U 21
		2.0.0 Mounting Figure 2.1 Panel Mount for ADAM-5560 Series	∠1 21
		Figure 2.2 DIN-rail Mounting	21 21
		2.3.6 Jumper and DIP Switch Settings	
		Figure 2.3 COM Port Location	22
		<b>U</b>	

0.0		105
6.5	Changing the Language Interface	163
0.3 64	Save and Unload Project Source	154
0.Z 63	Example of Configuring Touch Screep	151 157
り.1 6つ	Auvantech Utilities	150
6 4	Advantach Litilitica	450
6	Miscellaneous Functions	149
5.4		145
ວ.ປ ຣາ	Email Alarm Function	143
5.2 5.2	FIP Server Function	131
<b>F</b> 0	5.1.1 Configure Web Server	124
5.1	Web Server Functions	124
		IZJ
5	Network Functions	123
	4.4.2 Example	108
	4.4.1 Modbus Address Mapping	107
4.4	Modbus/TCP Server Functions	107
	4.3.1 Modbus/RTU Master Function Example	80
43	Modbus/RTU Master Function	80
	4.∠.1 An example to demonstrate how to connect to ADAM-6050 Modbus/TCP client function	v tor ca
4.2	Modbus/TCP Client Function	62
4.1	Introduction	62
4		01
	Madhua Eurotiana	64
3.5	Special Module Support in KW	59
3.4	Create a Project and Test the System	39
3.3	Multiprog Installation	39
3.1 3.2	Configure ADAM-5000 Local I/O	31 35
- 3 1	Set IP Address to ADAM-5560KW	21
3	Quick Start	29
	Figure 2.13Ethernet Network Connection	27
	2.4.4 Ethernet Network Connection	27
	Figure 2.12Remote I/O Wiring	27
	2.4.3 Connection of Communication Ports	26
	2.4.2 I/O Module Wiring	
	2.4.1 Fower Supply Willing Figure 2 11ADAM-5560 Series Controller Power Wiring	20 26
2.4	System Wiring and Connections	26
<i></i>	Figure 2.10RS-485 Port Pin Assignment	25
	Figure 2.9 RS-232 Port Pin Assignment	25
	2.3.7 COM Port Pin Assignments	25
	Table 2.5: Device ID DIP Switch Table	24
	Figure 2.8 ADAM-5560 Series DIP Switch	
	FIGURE 2.0 CONTRACTOR AND A CONTRACT Setting Figure 2.7 COM4 RS-232/485 and Terminal Resistor Setting	ings. 23
	Figure 2.5 COM1 RS-232/485 and Terminal Resistor Setti	ngs. 23
	Figure 2.4 COM1/COM4 R5-232/485 Settings	
	2.4 3 3.1 3.2 3.3 3.4 3.5 4 4.1 4.2 4.3 4.4 5 5.1 5.2 5.3 5.4 6 6.1 6.2 6.3 6.4 6.5	Figure 2.5 COM RS-232/485 and Terminal Resistor Setti         Figure 2.6 COM RS-232/485 and Terminal Resistor Setti         Figure 2.8 ADAM-5560 Series DIP Switch         Table 2.5: Device ID DIP Switch Table         2.3.7 COM Port Pin Assignment.         Figure 2.10RS-485 Port Pin Assignment.         Figure 2.11ADAM-5560 Series Controller Power Wiring.         2.4         System Wiring and Connections.         2.4.1         Power Supply Wiring.         2.4.2         VM dodule Wiring.         2.4.3         Connection of Communication Ports.         Figure 2.13Ethernet Network Connection.         Figure 2.13Ethernet Network Connection.         Figure 2.13Ethernet Network Connection         3.1       Set IP Address to ADAM-5560KW.         3.2       Configure ADAM-5000 Local I/O         3.3       Multiprog Installation         3.4       Create a Project and Test the System         3.5       Special Module Support in KW         4       Modbus/TCP Client Function         4.2.1       An example to demonstrate how to connect to ADAM-6050 Modbus/TCP Client function         4.3.1       Modbus/TCP Client function         4.4.1       Modbus/TCP Server Functions         5.1.1       Configure Web Server

	A.1 A.2 A.3 A.4	RS-485 Networks Basic Network Layout Figure A.1 Daisychaining Figure A.2 Star Structure Figure A.3 Random structure Line Termination Figure A.4 Signal Distortion Figure A.5 Termination Resistor Locations RS-485 Data Flow Control Figure A.6 RS-485 Data Flow Control with RTS	168 169 169 170 170 170 171 172 172
Chapter	В	Grounding Reference	173
	B.1 B.2 B.3	<ul> <li>Field Grounding and Shielding Applications</li></ul>	174 174 174 174 175 175 175 176 176 176 176 177 177 177 177 178 178 178
		Figure B.9 Single Isolated Cable Figure B.10Double Isolated Cable B.3.2 System Shielding Figure B.11System Shielding Figure B.12Cable Characteristics Figure B.13System Shielding (1) Figure B.14System Shielding (2)	178 179 180 180 180 181 181
	В.4	Figure B.15Noise Reduction Techniques	182
Chapter	в.5 <b>С</b>	Check Point List	182 183
	_		

C.1	Reference Documents	. 184
C.2	Topics for Getting Familiar with Multiprog	. 184



Overview

# 1.1 Introduction

ADAM-5560 Series Controller is Programmable Automation Controller designed for control tasks which require Industrial PC computing performance with the PLC's robustness. ADAM-5560 Series Controller offers Intel ATOM Z510P CPU along with control specific features such as watchdog timer, battery backup RAM and deterministic I/O.

ADAM-5560KW Controller features 5 standard IEC61131-3 programming languages in CE 5.0, so PLC users can develop control strategies with their own familiar programming languages. The powerful Multiprog KW Software and stable ProCon OS have allowed ADAM-5560KW Controller to become the best choice for a Programmable Automation Controller on the market today. With the optional HMI Software and built-in VGA port. User will no longer be required to build up additional SCADA PC's in their applications. This compact and powerful PAC is ideal for a variety of applications ranging from Machine Automation to SCADA applications.

The ADAM-5560 Series Controller includes two models as following:

ADAM-5560CE 7-slot PC-based Programmable Controller

ADAM-5560KW 7-slot Programmable Automation Controller

# **1.2 Features**

The hardware system of ADAM-5560 Series Controller consists of two major components: the main unit and I/O modules. The main unit includes a CPU card, a power module, an 7-slot backplane and four serial communication ports. ADAM-5560 Series Controller also embeds two Ethernet ports, two USB ports and VGA port. The .NET class Library is needs for developing the program for ADAM-5560CE. The Multiprog software is also needed for developing the control program for ADAM-5560 Series Controller. Following are the major features:

- Designed for control tasks that meet robust and computing performance requirements of PLC and Industrial PC's
- Built-in VGA Port
- Support Storage Function by Battery Backup RAM and SD Card I/O Module
- Built-in real-time clock and watchdog timer
- Support .NET class library (For ADAM-5560CE)
- SoftLogic support in CE 5.0
- Process IEC-61131-3 standard with rich development environment (For ADAM-5560KW)
- Cross-Language programming (For ADAM-5560KW)
- Deterministic I/O
- Real time multi-task engine
- Custom Function Block (For ADAM-5560KW)
- Pre-defined function library (For ADAM-5560KW)
- Powerful debug / diagnostic / simulation / force tools
- Online editing & partial download
- Rich support to ADAM-5560 I/O Modules
- Dual Ethernet Ports
- Remote maintenance via FTP Server
- Built-in SQL Mobile Server
- RS-232/485 communication ability
- Remote I/O expansibility

# Designed for control tasks that meet robust and computing performance requirements of PLC and Industrial PC's

ADAM-5560 Series Controller is designed for control tasks which need Industrial PC's computing performance and PLC's robustness. Its multiple functionalities include discrete, analog and motion functions. The well-integrated programming tool and optional HMI software provide a flexible and easy-to-use software solution for versatile applications.

## **Built-in VGA port**

ADAM-5560 Series Controller has a built-in VGA port which can directly connect to a display. So HMI function can be integrated into this controller. ADAM-5560 Series Controller can be operated with or without display and/or keyboard/mouse which can meet different requirements of applications.

## Support atorage function by battery backup rAM and SD card I/O module

ADAM-5560 Series Controller has built-in 1GB DDR2 SDRAM with 1MB battery backup RAM for saving important data. The ADAM-5030 I/O Module supports two SD cards and two USB ports. So users can use SD cards or USB sticks for large amount of data storage requirement.

#### Built-in real-time clock and watchdog timer

The ADAM-5560 Series Controller also includes a real-time clock and watchdog timer. The real-time clock records events while they occur. The watchdog timer is designed to automatically reset the microprocessor if the system fails. ADAM-5560 Series Controller provides two types of watchdog timers. They are Operating System Watchdog and KW application watchdog. It will increase the reliability of system and make the ADAM-5560 Series Controller ideal for use in applications which require high system stability.

#### SoftLogic Support in Windows CE 5.0

ADAM-5560KW Controller supports IEC-61131-3 programming in WinCE 5.0. The five programming languages of Ladder Diagram, Function Block, Sequential Function Chart, Structured Text and Instruction List cover most of the PLC programming languages in the market. The reliable PROCONOS runtime engine and powerful MULTIPROG software from KW-Software empower ADAM-5560KW Controller as the best solution of Programmable Automation Controller.

#### Process IEC 61131-3 standard with rich development environment

The standard IEC 61131-3 has been established to standardize the multiple languages, sets of instructions and different concepts existing in the field of automation systems. The great variety of control concepts has led to an incompatibility between the different control platforms and manufacturers. The result was a great effort to be made for training, hardware and software investments.

IEC 61131-3 defines the syntax of 5 programming languages, defines a certain representation and describes the different elements which can be used in the language.

The programming languages can be differentiated by the physical appearance into 2 textual languages and 3 graphical languages.

Table 1.1: Programming Languages Table					
Textual Languages	Graphical Languages				
Instruction List (IL) Structured Text (ST)	Function Block Diagram (FBD) Ladder Diagram (LD) Sequential Function Chart (SFC)				

#### **Cross-Language Programming**

For some project integrate and scalable issues, cross-language can help you to choose the different language for your project. For example, you can use ladder (LD) on the simple I/O module control or simple logical expression and use Function Block (FB) on process control for more advanced expression and use Sequential Function Chart (SFC) for system configuration in hybrid control system such as Water Treatment.



Figure 1.1 Cross-Language Programming

#### **Deterministic I/O**

ADAM-5560 Series Controller can guarantee deterministic I/O at 1ms. The feature guarantees control and response speed at I/O level so HMI software or operations of other application programs cannot affect the I/O control performance.

### Real time multi-task engine

ADAM-5560 Series Controller provides the multi-task and multi-program environment. ADAM-5560 Series Controller's communication, data process and I/O access tasks are working independent, so the system performance and efficiency are better than traditional PLC.

#### **Custom Function Block for complex control**

ADAM-5560KW Controller allows custom function block for advanced control algorithm such as fuzzy logic control or neural network control function. Users can define their own function block for common use function or special domain know-how. The control kernel also provides powerful floating point calculation and rich memory for complex control.

#### **Pre-defined function library**

Advantech Multiprog provides many pre-defined function library such as maximum of strings as string function block, Convert REAL to INT as type convert function block. It helps you to build up your program more conveniently. It is more convenient than the traditional control programming tools. With this pre-defined function, you can make your project easier in timer control, variable type conversion or strings conversion, etc.

#### Powerful debug / diagnostic / simulation / force tools

Advantech Multiprog provides lots of powerful tools for debug, diagnostic, simulation and force function. It shows friendly interfaces when you use these tools. With debug / diagnostic tools, you can make it easier on trouble-shooting. Advantech Multiprog simulator supports program verification offline directly on your PC. This is great in case you are developing logic and you do not have access to a controller. To activate an I/O simply click on the LED you want to energize and your logic executes as if it was a real I/O. The program operation is the same as if you actually were connected to the controller, so all the debug tools are fully functional: power and logic flow, I/O force and overwriting. With force tools, you can check more exception situations and check if the project handling right or wrong. It prevents the damage for you.

#### **Online editing & partial download**

Online editing is a MUST even though many packages do not support it. It is unacceptable to shut down the machine or process to perform maintenance, not to mention how difficult it is to debug when you have to switch back and forth from program to run mode. Multiprog supports online editing so you can make changes and then download the changes to the controller WITHOUT stopping the machine or process. It helps you to maintain your system easier and save the cost for your system process.

#### Rich support to ADAM-5560 I/O Modules

Most of the ADAM-5560 I/O modules are supported by ADAM-5560 Series Controller including analog I/O modules, digital I/O modules and motion control module. All the operations of supported modules are the same with the operations of ADAM-5510 series.

The ADAM-5560 Series Controller uses a convenient backplane system for supporting versatile I/O modules. Advantech's complete line of ADAM-5560 I/O modules integrates with the ADAM-5560 Series Controller to support your applications. Following table is the latest I/O module support list we provided for user's choice.

Table 1.2: I/O Module Support List								
Function	Module	Description	Reference					
	ADAM-5013	3-ch RTD Input	Isolated					
	ADAM-5017	8-ch Al	Isolated					
Analog Input	ADAM-5017P	8-ch AI w/Independent Input Range	Isolated					
	ADAM-5017H	8-ch High Speed AI (1KHz)	Isolated					
	ADAM-5017UH	8-ch Ultra High Speed AI (200KHz)	Isolated					
	ADAM-5018	7-ch TC Input	Isolated					
	ADAM-5018P	7-ch TC Input w/Independent Input Range	Isolated					
Analog Output	ADAM-5024	4-ch AO	Isolated					
	ADAM-5051	16-ch DI	Non-isolated					
	ADAM-5051D	16-ch DI w/LED	Non-isolated					
Digital Input	ADAM-5051S 16-ch Isolated DI w/LED		Isolated					
	ADAM-5052	8-ch Isolated DI w/LED	Isolated					
	ADAM-5053S	32-ch Isolated DI	Isolated					
	ADAM-5056	16-ch DO	Non-isolated					
	ADAM-5056D	16-ch DO w/LED	Non-isolated					
Digital Output	ADAM-5056S	16-ch Isolated DO w/LED	Isolated					
	ADAM-5056SO	16-ch Source Type Isolated DO w/LED	Isolated					
	ADAM-5057S	32-ch Isolated DO	Isolated					
Digital I/O	ADAM-5050	16-ch DI/O	Non-isolated					
Digital I/O	ADAM-5055S	16-ch Isolated DI/O w/LED	Isolated					
	ADAM-5060	6-ch Relay Output	Isolated					
	ADAM-5069	8-ch Power Relay Output w/LED	Isolated					
Counter/ Frequency	ADAM-5081	4-ch/8-ch High Speed Counter/Frequency	Isolated					
Communication	ADAM-5091	4-port RS-232 Module	Non-isolated					
Communication	ADAM-5095	2-port CAN Module	Isolated					
Storage	ADAM-5030	2-slot SD Storage Module	Non-isolated					
	ADMA-5202	2-port AMONet Master Module	Isolated					
Motion	ADAM-5240	4-axis Stepping/Servo Motor Control Module	Isolated					



For details, refer to ADAM-5000 I/O Module User's Manual.

### **Dual Ethernet Ports**

ADAM-5560 Series Controller provides two Ethernet ports for different application requirements such as redundant Ethernet connection for reliability concern or separated network connections for security concern. Both of the functions are possible to be implemented by customer's application program.

## Remote maintenance via FTP Server and DiagAnywhere Software

For remote maintenance function, the built-in FTP server provides service for uploading application program or downloading data logging files. DiagAnywhere Software is also supported for remote control, download and upload functions.

#### **Built-in SQL Mobile Server**

ADAM-5560KW Controller embeds SQL server so it is very easy to exchange data between enterprise database/local HMI software and SQL server by SQL query functions. Following is the Architecture of ADAM-5560KW Controller Kernel.



#### RS-232/485 communication ability

The ADAM-5560 Series Controller has four serial communication ports, giving it excellent communication abilities. This facilitates its ability to control networked devices. ADAM-5560 Series Controller COM1/COM3/COM4 are RS-232/485 selectable port and COM2 is a dedicated RS-485 por. These four ports allow the ADAM-5560 Series Controller to satisfy diverse communication and integration demands. With this communication ports, you should not buy more I/O communication device and save more costs. You can also extend your system by using these communication ports. Please refer to following figure and check the location of COM ports.





## Remote I/O Expansibility

ADAM-5560 Series Controller supports not only Modbus/RTU Master function via serial ports, but also the Modbus/TCP Client to retrieve data from remote I/O, and Modbus/TCP Server to exchange data with other Modbus devices via Ethernet port. This Modbus features are very useful when the control system needs expand the remote I/O modules or connect to other controllers.

# 1.3 Specifications

## 1.3.1 System

- CPU: Intel ATOM Z510P Processor
- Operating system: Windows CE 5.0
- Memory: 1 GB DDR2 SDRAM with 1MB Battery Backup One CompactFlash® Card (Internal)
- Real-time clock: Yes
- Watchdog timer: Yes
  - Operating System Watchdog
  - KW application watchdog
  - Modbus server communication watchdog
- USB Port: USB 2.0 ports \* 2
- VGA Port: 1024 X 768 Resolution
- Ethernet Port: 10M/100M bps \* 2 RJ-45 connectors
- COM1: RS-232/485 selectable, DB-9 connector
- COM2: RS-485, Terminal Block
- COM3: RS-232/485 selectable, DB-9 connector
- COM4: RS-232/485 selectable, DB-9 connector
- I/O capacity: 7 slots
- Maximum number of nodes: 256 nodes
- System power consumption: 17 W (without I/O modules)

## 1.3.2 USB Ports

USB 2.0

## 1.3.3 VGA Port

1024 X 768 Resolution

## **1.3.4 Ethernet Ports**

- 10M/100M bps x 2
- RJ-45 connectors
- Transmission Speed 10M/100M bps (10/100 Base-T)

## 1.3.5 RS-232/485 interface (COM1)

- RS-232/485 Mode selectable by jumper
- RS-232 Mode: Asynchronous full duplex, point to point Signals: TxD, RxD, RTS, CTS, DTR, DSR, DCD, RI, GND
- RS-485 Mode: Half duplex, multi-drop Signal: DATA+, DATA-

- Connector: DB-9 pin
- Transmission speed: Up to 115.2 Kbps
- Max transmission distance:
  - RS-232: 50 feet (15.2 m)
  - RS-485: 4,000 feet (1220 m)

## 1.3.6 RS-485 interface (COM2)

- Signals: DATA+, DATA-
- Mode : Half duplex, multi-drop
- Connector: Screw terminal
- Transmission speed: Up to 115.2K bps
- Max transmission distance: 4000 feet (1220 m)

## **1.3.7** ES-232/485 interface (COM3) (Suitable for touchscreen)

- RS-232/485 Mode selectable by jumper RS-485 Signal: DATA+, DATA-
- RS-232 Mode: Asynchronous full duplex, point to point Signals: TxD, RxD, RTS, CTS, DTR, DSR, DCD, RI, GND
- RS-485 Mode: Half duplex, multi-drop RS-485 Signal: DATA+, DATA-
- Connector: DB-9
- Transmission speed: Up to 115.2K bps
- Max transmission distance:
  - RS-232: 50 feet (15.2 m)
  - RS-485: 4000 feet (1220 m)

## **1.3.8** RS-232/485 interface (COM4)

- RS-232/485 Mode selectable by jumper RS-485 Signal: DATA+, DATA-
- RS-232 Mode: Asynchronous full duplex, point to point Signals: TxD, RxD, RTS, CTS, DTR, DSR, DCD, RI, GND
- RS-485 Mode: Half duplex, multi-drop RS-485 Signal: DATA+, DATA-
- Connector: DB-9
- Transmission speed: Up to 115.2K bps
- Max transmission distance:
  - RS-232: 50 feet (15.2 m)
  - RS-485: 4000 feet (1220 m)

## 1.3.9 Isolation

- COM2: 2500 Vrms
- COM1/COM3/COM4: 1000 Vrms (RS-485 only)

#### 1.3.10 Power

- Unregulated +10 to +30 VDC
- Protected against power reversal
- Power consumption: 17 W (not including I/O modules)

## 1.3.11 Mechanical

- Case: ABS+PC with captive mounting hardware
- Plug-in screw terminal block: Accepts 0.5 mm<sup>2</sup> to 2.5 mm<sup>2</sup>, 1 - #12 or 2 - #14 to #22 AWG

## 1.3.12 Environment

- Operating temperature: 0 ~ 55° C (32 ~ 122° F)
- Storage temperature: -25° to 85° C (-13° to 185° F)
- Humidity: 5 to 95 %, non-condensing
- Atmosphere: No corrosive gases

Note!

Equipment will operate below 30% humidity. However, static electricity problems occur much more frequently at lower humidity levels. Make sure you take adequate precautions when you touch the equipment. Consider using ground straps, anti-static floor coverings, etc. if you use the equipment in low humidity environments.

## 1.3.13 Software Specifications

- Real Time O.S: KW ProConOS (Up to 16 cycle tasks)
- Programmable Code/Data Size: up to 710 KB

# **1.4 Dimensions**

The following diagrams show the dimensions of the system unit and an I/O unit. All dimensions are in millimeters.



Figure 1.3 ADAM-5560 Dimensions

## 1.5 LED Status

There are two LEDs on the front panel of ADAM-5560 Series Controller. The LEDs indicate operating status, as explained below:

**PWR:** Power indicator. This LED is on whenever the ADAM-5560 Series Controller is powered on.

**RUN:** Blinking while project is running, off while project is stopped.

There are two LEDs besides each Ethernet port. The LEDs indicate operating status, as explained below:

**TX (Green):** This LED blinks whenever the ADAM-5560 Series Controller transmitting data to Ethernet.

**Link (Orange):** This LED is on whenever the ADAM-5560 Series Controller connecting to Ethernet.

# **1.6 Limitations**

## 1.6.1 Remote I/O Quantity

ADAM-5560 Series Controller can connect to ADAM-4000 Modbus I/O modules through COM1/COM2/COM3/COM4 RS-485 port by Modbus protocol. (COM2 is also workable if a RS-232 to RS-485 converter is used.) The typical quantity of remote I/O connection is 128.

## 1.6.2 Modbus/RTU Slave Function

ADAM-5560 Series Controller support Modbus/RTU slave function.

## **1.6.3 TCP/IP Connections**

- Multiprog via Ethernet connection: maximum 4 connections
- Modbus/TCP Server connection: maximum 64 connections
- Modbus/TCP Client connection: maximum 128 connections

## **1.6.4 Firmware Upgrade Notice**

When you would like to upgrade the firmware of ADAM-5560 Series Controller, please do contact with Advantech Technical Support Team for support. Wrong procedures will possibly cause potential problem to your system.

## 1.6.5 Boot-up Time

The boot-up time of ADAM-5560 Series Controller is around 40 seconds.



Installation

## 2.1 Overview

This chapter describes how to install an ADAM-5560 Series Controller. A quick hookup scheme is provided that let you easily configure your system before implementing it into your application.

# 2.2 System Requirements

Before you start installing the ADAM-5560 Series Controller, make sure the system requirements are met as below:

## 2.2.1 Host Computer Requirements

- 1. IBM PC compatible computer with Pentium II 350MHz processor.
- 2. Microsoft Windows 95/98/NT4.0 SP5/Windows 2000 SP2 or Windows XP.
- 3. At least 64 MB RAM.
- 4. 200 MB of hard disk space available
- 5. VGA 256 colors monitor, 800x600 resolutions
- 6. CD-ROM.
- 7. Mouse or other pointing devices.
- 8. One Ethernet port

## 2.2.2 ADAM-5560 Series Requirements

- 1. 1 x ADAM-5560 Series main unit, i.e., ADAM-5560CE or ADAM-5560KW
- 2. ADAM-5560 Series User's Manual
- 3. One Advantech Multiprog CD.
- 4. Power supply for ADAM-5560 Series (+10 to +30 VDC unregulated)
- 5. One Ethernet Hub or Switch like ADAM-6520 or ADAM-6510

## 2.2.3 I/O Module Requirements

At least one I/O module is needed to use the system. A variety of I/O modules are available to meet different application requirements. Table 1.2 gives a current listing of these modules for your reference. In following example, we will use ADAM-5051D in Slot 0 and ADAM-5056D in Slot 1 on ADAM-5560KW.

# 2.3 Hardware Installation

## 2.3.1 Selecting I/O Module

To organize an ADAM-5560 Series control system, you need to select I/O modules to interface the main unit with field devices or processes that you have previously determined. There are several things should be considered when you select the I/O modules.

- What type of I/O signal is applied in your system?
- How many I/O is required to your system?
- How will you concentrate the I/O points of an entire process?
- What is the required voltage range for each I/O module?
- What isolation environment is required for each I/O module?
- What are the noise and distance limitations for each I/O module?

Refer to discrete & analog I/O module selection guidelines as below.

Table 2.1: Discrete and Analog I/O Selection Guidelines							
Choose this type of I/O module:	For these types of field devices or operations (examples):	Explanation:					
Discrete input module and block I/O module	Selector switches, push buttons, photoelectric eyes, limit switches, circuit breakers, proximity switches, level switches, motor starter con- tacts, relay contacts, thumbwheel switches	Input modules sense ON/OFF or OPENED/CLOSED sig- nals. Discrete signals can be either AC or DC.					
Discrete output module and block I/O module	Alarms, control relays, fans, lights, horns, valves, motor starters, sole- noids	Output module signals inter- face with ON/OFF or OPENED/CLOSED devices. Discrete signals can be either AC or DC.					
Analog input module	Thermocouple signals, RTD signals, temperature transducers, pressure transducers, load cell transducers, humidity transducers, flow transduc- ers, potentiometers.	Convert continuous analog signals into input values					
Analog output module	Analog valves, actuators, chart recorders, electric motor drives, analog meters	Interpret output value to ana- log signals (generally through transducers) for field devices.					

Advantech provides 28 types of ADAM-5560 I/O modules for various applications so far. The Table 1.2 will help you to select the ADAM-5560 I/O modules quickly and easily.

Module		ADAM- 5013	ADAM- 5017	ADAM- 5017UH	ADAM- 5018	ADAM- 5024
	Resolution	16 bit	16 bit	12 bit	16 bit	-
	Input Channel	3	8	8	7	-
	Sampling Rate	10	10	8K (Total)	10	-
Analog Input	Voltage Input	-	±150 mV ±500 mV ±1 V ±5 V ±10 V	±10 V 0~10V 0~20mV	±15 mV ±50 mV ±100 mV ±500 mV ±1 V ±2.5 V	-
	Current Input	-	±20 mA	4~20mA	±20 mA	-
	Direct Sensor Input	Pt or Ni RTD	-	-	J, K, T, E, R, S, B	-
	Resolution	-	-	-	-	12 bit
Analog	Voltage Output	-	-	-	-	0~10 V
Output	Current Output	-	-	-	-	0~20 mA 4~20 mA
Digital Input	Digital Input Channels	-	-	-	-	-
Output	Digital Output Channels	-	-	-	-	-
Counter	Channels	-	-	-	-	-
(32-bit)	Input Frequency	-	-	-	-	-
	Mode	-	-	-	-	-
Isolation		3000 VDC	3000 VDC	3000 VDC	3000 VDC	3000 VDC

Module	ADAM- 5050	ADAM- 5051	ADAM- 5051D	ADAM- 5051S	
	Resolution	-	-	-	-
	Input Channel	-	-	-	-
	Sampling Rate	-	-	-	-
Analog input	Voltage Input	-	-	-	-
	Current Input	-	-	-	-
	Direct Sensor Input	-	-	-	-
	Resolution	-	-	-	-
Analog	Voltage Output	-	-	-	-
Output	Current Output	-	-	-	-
Digital Input and	Digital Input Channels	16 DIO	16	16 W/LED	16 W/LED
Digital Output	Digital Output Channels	selectable)	-	-	-
	Channels	-	-	-	-
Count-er (32-bit)	Input Frequency	-	-	-	-
	Mode	-	-	-	-
Isolation		-	-	-	2500 VDC

Module	ADAM- 5052	ADAM- 5055S	ADAM- 5056	ADAM- 5056D	ADAM- 5056S / 5056SO	
	Resolution	-	-	-	-	-
	Input Channel	-	-	-	-	-
	Sampling Rate	-	-	-	-	-
Analog Input	Voltage Input	-	-	-	-	-
	Current Input	-	-	-	-	-
	Direct Sensor Input	-	-	-	-	-
	Resolution	-	-	-	-	-
Analog Output	Voltage Output	-	-	-	-	-
	Current Output	-	-	-	-	-
Digital Input and	Digital Input Channels	8	8 W/LED	-	-	-
Digital Output	Digital Output Channels	-	8 W/LED	16	16 W/LED	16 W/LED
	Channels	-	-	-	-	-
Count-er (32-bit)	Input Frequency	-	-	-	-	-
	Mode	-	-	-	-	-
Isolation		5000 V <sub>RMS</sub>	2500 V <sub>DC</sub>	-	-	2500V <sub>DC</sub>

Module		ADAM-5060	ADAM-5069
	Resolution	-	-
Analog Input	Input Channel	-	-
	Sampling Rate	-	-
	Voltage Input	-	-
	Current Input	-	-
	Direct Sensor Input	-	-
Analog Output	Resolution	-	-
	Voltage Output	-	-
	Current Output	-	-
Digital Input and	Digital Input Channels	-	-
Digital Output	Digital Output Channels	6 relay (2 form A/ 4 form C)	8 power relay (8 form A)
	Channels	-	-
Counter (32-bit)	Input Frequency	-	-
	Mode	-	-
RS-232	Channels	-	-
Isolation		-	-

Module	ADAM-5030
SD Card Slot	2
USB 2.0 Slot	2

## 2.3.2 Selecting Power Supply Module

ADAM-5560 Series Controller works under unregulated power source between +10 and +30 VDC. When you arrange different I/O modules on ADAM-5560 Series Controller's backplane, it may require comparable power supply. Use the following steps as guidelines for selecting a power supply for your ADAM-5000 Series control system.

Refer to Table 2.2 to check the power consumption of ADAM-5000 Series Controller and each I/O module.

Table 2.2: Power Consumption of ADAM-5000 series (Main Units)					
Main Units	Description	Power Consumption			
ADAM-5000/485	Distributed Data Acquisition and Control System based on RS-485	1.0 W			
ADAM-5000	Distributed Data Acquisition and Control System based on RS-485	4.0 W			
ADAM-5000/TCP	Distributed Data Acquisition and Control System based on Ethernet	5.0 W			
ADAM-5510	PC-Based Programmable Controller (With Battery Backup)	1.0 W			
ADAM-5510M	Enhanced PC-Based Programmable Controller (With Battery Backup)	1.2 W			
ADAM-5511	PC-Based Programmable Controller with Modbus	1.0 W			
ADAM-5510E	8-slot PC-Based Programmable Controller	1.2 W			
ADAM-5510/TCP	Ethernet-enabled PC-Based Programmable Controller	2.0 W			
ADAM-5510E/TCP	8-slot Ethernet-enabled PC-Based Programmable Controller	2.0 W			
ADAM-5510KW	PC-based SoftLogic Controller	1.2 W			
ADAM-5510EKW	8-slot PC-based SoftLogic Controller	1.2 W			
ADAM-5510EKW/TP	8-slot Ethernet-enabled SoftLogic Controller	2.0 W			
ADAM-5560	8-slot Programmable Automation Controller	17 W			

Table 2.3: Power	Consumption of ADAM-5000 series (IO Mod	dules)
ADAM-5013	3-Channel RTD Input Module	1.1 W
ADAM-5017	8-Ch Analog Input Module (mV, mA or High Voltage)	1.25 W
ADAM-5017UH	8-CH Ultra High speed Analog Input Module (mV, mA or High Voltage)	2.2 W
ADAM-5018	7-Channel Thermocouple Input Module (mV, V, mA, Thermocopule)	0.63 W
ADAM-5024	4-Channel Analog Output Module (V, mA)	2.9 W
ADAM-5050	16-Channel Universal DIO	1.2 W
ADAM-5051	16-Channel Digital Input Module	0.53 W
ADAM-5051D	16-Channel Digital Input w/LED Module	0.84 W
ADAM-5056S	16-Channel Isolated Digital Input w/LED Module	0.8 W
ADAM-5056SO	16-Channel Digital Input w/LED Module	0.84 W
ADAM-5052	8-Channel Isolated DI	0.27 W
ADAM-5055S	16-Channel Isolated DIO w/LED Module	0.68 W
ADAM-5056	16-Channel Digital Output Module	0.53 W
ADAM-5056D	16-Channel Digital Output w/LED Module	0.84 W
ADAM-5056S	16-Channel Isolated Digital Output w/LED Module	0.6 W
ADAM-5060	6-Ch Relay Output Module ( 2 of Form A, 4 of Form C)	1.8 W
ADAM-5068	8-Channel Relay Output Module (8 Form A)	1.8 W
ADAM-5069	8-Channel Power Relay Output Module (8 Form A)	2.2 W
ADAM-5202	2-Ring AMONet Motion Control Module	2.5 W

Calculate the Summary of the whole system's power consumption.

For example, there are following items in your system.

ADAM-5550KW \* 3 & ADAM-5024 \* 2 & ADAM-5017 \* 4 &

ADAM-5068 \* 2 & ADAM-5056D \* 2

The power consumption is:

17 W \* 3 + 2.9 W \* 2 + 1.25 \* 4 + 1.8 W \* 2 + 0.84 W \* 2 = 67.08 W

Select a suitable power supply from Table 2.4 or other comparable power resource for system operation.

Table 2.4: Power S	upply Specificatio	n Table	
Specification	PWR-242	PWR-243	PWR-244
Input			
Input Voltage	90 ~ 264 VAC	85 ~ 132 VAC 170 ~ 264 VAC	100 ~ 240 VAC
Input Frequency	47 ~ 63 Hz	47 ~ 63 Hz	47 ~ 63 Hz
Input Current	1.2 A max.	1.4 A max	25 A/110 Vac 50 A/220 Vac (Inrush current)
Short Protection	Yes	Yes	Yes
Output			
Output Voltage	+24 VDC	+24 VDC	+24 VDC
Output Current	2.1 A	3 A	4.2 A
Overload Protection	Yes	Yes	Yes
General			
Dimension	181mm x 113 mm x 60 mm (L x W x H)	181mm x 113 mm x 60 mm (L x W x H)	181mm x 113 mm x 60 mm (L x W x H)
Operating Temperature	0 ~ 50°C (32 ~ 122°F)	0 ~ 50°C (32 ~ 122°F)	0 ~ 50°C (32 ~ 122°F)
DIN-rail Mountable	Yes	No	No

## 2.3.3 Install Main Unit and Modules

While inserting modules into the system, align the PC board of the module with the grooves on the top and bottom of the system. Push the module straight into the system until it is firmly seated in the backplane connector. Once the module is inserted into the system, push in the retaining clips (located at the top and bottom of the module) to firmly secure the module to the system.

## 2.3.4 I/O Slots and I/O Channel Numbering

The ADAM-5560 Series provides 7 slots for I/O modules. The I/O slots are numbered 0 through 6, and the channel numbering of any I/O module in any slot starts from 0. For example, the ADAM-5017 is an 8-channel analog input module. Its input channel numbering is 0 through 7.

## 2.3.5 Mounting

The ADAM-5560 Series Controller can be installed on a panel or on a DIN rail.

#### 2.3.5.1 Panel Mount

Mount the system on the panel horizontally to provide proper ventilation. You cannot mount the system vertically, upside down or on a flat horizontal surface. A standard #7 tatting screw (4 mm diameter) should be used.



Figure 2.1 Panel Mount for ADAM-5560 Series

#### 2.3.5.2 DIN-rail Mounting



Figure 2.2 DIN-rail Mounting

The system can also be secured to the cabinet by using mounting rails. If you mount the system on a rail, you should also consider using end brackets at each end of the rail. The ended brackets help keep the system from sliding horizontally along the rail. This minimizes the possibility of accidentally pulling the wiring loose. If you examine the bottom of the system, you will notice two small retaining clips. To secure the system to a DIN rail, place the system on to the rail and gently push up on the retaining clips. The clips lock the system on the rail. To remove the system, pull down on the retaining clips, lift up on the base slightly, and pull it away from the rail.

## 2.3.6 Jumper and DIP Switch Settings

This section tells you how to set the jumpers and DIP switches to configure your ADAM-5560 Series Controller. It gives the system default configuration and your options for each jumper and dip switch. The backplane has one 8-pin DIP switch and twelve jumpers on it.

## 2.3.6.1 RS-232/485 Selectable Jumper Setting

Following figure shows the COM1 to COM4 location.



COM3,RS-232/ Isolated RS-485

Figure 2.3 COM Port Location

The Communication mode of COM1, COM3 and COM4 are set by jumpers on the backplane. Please refer to Figure 2.4 to get the jumper locations.





## **COM1 Jumper Setting**

The Communication port of COM1 is set by CN4, CN5, CN6 (Mode) and CN7 (Terminal Resistor).

COM1 Setting	CN4	CN5	CN6	
RS-232 (Default)	(1-2)	(1-2)	(1-2)	
RS-485	(2-3)	(2-3)	(2-3)	

COM1 RS-485 TR Setting	CN7
120 ohm	(1-2)
300 ohm	(2-3)

## Figure 2.5 COM1 RS-232/485 and Terminal Resistor Settings

#### **COM3 Jumper Setting**

The Communication port of COM3 is set by CN9, CN10, CN11 (Mode) and CN12 (Terminal Resistor).

COM3 Setting	CN9	CN10	CN11
RS-232 (Default)	(1-2)	(1-2)	(1-2)
RS-485	(2-3)	(2-3)	(2-3)

COM3 RS-485 TR Setting	CN12
120 ohm	(1-2)
300 ohm	(2-3)

#### Figure 2.6 COM3 RS-232/485 and Terminal Resistor Settings

#### **COM4 Jumper Setting**

The Communication port of COM4 is set by CN14, CN15, CN16 (Mode) and CN1 7(Terminal Resistor).

COM4 Setting	CN14	CN15	CN16	
RS-232 (Default)	(1-2)	(1-2)	(1-2)	
RS-485	(2-3)	(2-3)	(2-3)	

COM4 RS-485 TR Setting	CN17
120 ohm	(1-2)
300 ohm	(2-3)

Figure 2.7 COM4 RS-232/485 and Terminal Resistor Settings

## 2.3.6.2 DIP Switch Setting



Figure 2.8 ADAM-5560 Series DIP Switch

#### **Device ID Setting:**

You can set up your device ID by changing DIP Switch 1-8. The available ID for ADAM-5560 Series Controller is from 0 to 255. Please refer to the Table 2.6 Device ID DIP Switch Table to set up your Device ID.

Table 2.5: Device ID DIP Switch Table								
DIP 8 (2 <sup>7</sup> )	DIP 7 (2 <sup>6</sup> )	DIP 6 (2 <sup>5</sup> )	DIP 5 (2 <sup>4</sup> )	DIP 4 (2 <sup>3</sup> )	DIP 3 (2 <sup>2</sup> )	DIP 2 (2 <sup>1</sup> )	DIP 1 (2 <sup>0</sup> )	Device ID
Off	Off	Off	Off	Off	Off	Off	Off	0
Off	Off	Off	Off	Off	Off	Off	On	1
Off	Off	Off	Off	Off	Off	On	Off	2
Off	Off	Off	Off	Off	Off	On	On	3
Off	Off	Off	Off	Off	On	Off	Off	4
Off	Off	Off	Off	Off	On	Off	On	5
Off	Off	Off	Off	Off	On	On	Off	6
Off	Off	Off	Off	Off	On	On	On	7
Off	Off	Off	Off	On	Off	Off	Off	8
On	On	On	On	On	On	Off	Off	252
On	On	On	On	On	On	Off	On	253
On	On	On	On	On	On	On	Off	254
On	On	On	On	On	On	On	On	255

# 2.3.7 COM Port Pin Assignments

Pin No.	Description
Pin 1	DCD
Pin 2	Rx
Pin 3	Tx
Pin 4	DTR
Pin 5	GND
Pin 6	DSR
Pin 7	RTS
Pin 8	CTS
Pin 9	RI



Figure	2.9	RS-232	Port Pin	Assignment
--------	-----	--------	----------	------------

Pin No.	Description		
Pin 1	DATA-		
Pin 2	No Connection		
Pin 3	No Connection		
Pin 4	DATA+		
Pin 5	No Connection		
Pin 6	No Connection		
Pin 7	No Connection		
Pin 8	No Connection		
Pin 9	No Connection		



Figure	2.10	<b>RS-485</b>	Port P	Pin A	Assign	ment

# 2.4 System Wiring and Connections

This section provides basic information on wiring the power supply, I/O modules and communication port connection.

## 2.4.1 Power Supply Wiring

Although the ADAM-5560 Series Controller is designed for a standard industrial unregulated 24 V<sub>DC</sub> power supply, they accept any power unit that supplies within the range of +10 to +30 V<sub>DC</sub>. The power supply ripple must be limited to 200 mV peak-to-peak, and the immediate ripple voltage should be maintained between +10 and +30 V<sub>DC</sub>. Screw terminals +Vs and GND are for power supply wiring.

Note!

The wires used should be sized at least 2 mm.





Figure 2.11 ADAM-5560 Series Controller Power Wiring

## 2.4.2 I/O Module Wiring

The system uses a plug-in screw terminal block for the interface between I/O modules and field devices. The following information must be considered when connecting electrical devices to I/O modules.

- 1. The terminal block accepts wires from 0.5 mm 2 to 2.5 mm.
- 2. Always use a continuous length of wire. Do not combine wires to make them longer.
- 3. Use the shortest possible wire length.\
- 4. Use wire trays for routing where possible.
- 5. Avoid running wires near high energy wiring.
- 6. Avoid running input wiring in close proximity to output wiring where possible.
- 7. Avoid creating sharp bends in the wires.

## 2.4.3 Connection of Communication Ports

The ADAM-5560 Series Controller has four communication ports. These ports allow you to integrate the remote devices.

## 2.4.3.1 Remote I/O Wiring

Modbus/RTU Master Function via COM1/COM2/COM4 RS-485:



Modules

## Figure 2.12 Remote I/O Wiring

You can connect typical 128 ADAM-4000 Modbus Remote I/O modules via COM1/ COM2/COM4. Please set the COM1 and COM4 as RS-485 mode.

## 2.4.4 Ethernet Network Connection

The ADAM-5560 Series Controller provides Ethernet interfaces for network integration. Usually, you will need to prepare an ADAM-6520 Ethernet switch or hub for connecting to other network devices as following figure.



Figure 2.13 Ethernet Network Connection


Quick Start

This chapter will help you get familiar with ADAM-5560KW Controller and Multiprog Programming Software by following step by step examples. In this chapter, you need to prepare the system configuration as below. Main Module: ADAM-5560KW X1, IP Address: 192.168.1.5

Local I/O Modules: ADAM-5051D in Slot 0 ADAM-5056D in Slot 1

Advantech Multiprog CD: Advantech Multiprog Software with license key.

Note!

In following chapters of step by step examples, you will see the screen of ADAM-5560KW in Windows CE with **[PAC Device]** description and the screen of PC in Windows XP.

### **Power wiring**



### **System Wiring**



# Chapter 3 Quick Start

### 3.1 Set IP Address to ADAM-5560KW

1. [PAC Device] Power up ADAM-5560KW and click "Start".



2. [PAC Device] Click "Settings" and "Network and Dial-up Connections".



3. [PAC Device] Right click "PCI-RTL81391" icon and then click "Properties".



4. **[PAC Device]** Type IP Address like "192.168.1.5" and Subnet Mask "255.255.255.0".

Elle Edit View Advanced 🗙 🕢 🖬 🖂	<b>k</b> ?	×
Make New     ActiveSync     PCI-       Connection     RTL81391     RTL81392		
PCINTL81391' Settings OK X		
An IP address can be automatically assigned to this computer. If your network does not automatically assign IP addresses, ask your network administrator for an address, and then type it in the space provided.		
影 Start ProConOS WinCE 🔊 Network Connections 🖉 ふみ 🛞 💷 🏓	10:16 AM	) 🗭

5. **[PAC Device]** Right click "PCI-RTL81392" icon and then click "Properties".

Elle Edit View Advanced 🗙 🕢 🗔 🖸	N?	×
😼 🦻 શું		
Make New ActiveSync PCI- Connection RTL81391 RTL81392		
Disable Oct or Defende		
Deskton Shorta it		
Delete		
Rename		
Propercies		
	中	半
🐉 Start ProConOS WinCE 💽 Network Connections	AM 😡	

6. **[PAC Device]** Type IP Address like "192.168.1.6" and Subnet Mask "255.255.255.0". Now the IP address configuration has been finished.

Eile Edit View Advan		<b>№?</b> ×
Make New Connection	PCI- RTL81391         PCI- RTL81392	
	IP Address       Name Servers         An IP address can be automatically assigned to this computer. If your network does not automatically assign IP addresses, ask your network administrator for an address, and then type it in the space provided.	
	Natwork Connections	10-18 AM

7. If your PC has installed DiagAnywhere Software, you can search the ADAM-5560KW and check the Ethernet connection. Please click the "Remote device" and click "Search" button.

🚔 Advantech DiagAnywhere Utility Version	1.00.01 - [FormTCPIP]			_ 8 ×
File Tools Setup Help				
Bemote device     192.168.1.21     Others	Host name:	a		
	Adapter:	192.168.1.21	E.	
	Connection timeout:	2000 ms		
			Арріу	
	Support Device: [1] ADAM Controller Ser	ies	· · · · · · · · · · · · · · · · · · ·	
	[2] UNO Series [3] TPC Series			
, It is ready!				

8. Click "ADAM-5560" and then click OK button without entering any password.



9. The screen of ADAM-5560KW will be shown in the window. Now it is possible to remotely control the ADAM-5560KW by PC's mouse.



# 3.2 Configure ADAM-5000 Local I/O

1. **[PAC Device]** Click "Start" -> "Programs" -> "Advantech" -> "Adam.NET Utility".



2. **[PAC Device]** Click "Local system" to view the local I/O modules.



3. [PAC Device] ADAM-5051 and ADAM-5056 are listed. Select "ADAM-5051".

Advantech Adam.NET U	Utility (WinCE) Version 1.00.08	
File Tools Setup Hel	Þ 🧀 🖳 🔍 🌾 📽 🕨	
<ul> <li>➡ ➡ ADAM4000_5000</li> <li>➡ ➡ ➡ ADAM5000TCP_600</li> </ul>	ADAM-5550	
E-Q Local system	Firmware version: Download	
5056(S1)	Scan interval: 500 ms Apply	
	Description       Slot     Module     Description       0     5051     ADAM-5051 16-channel Digital input module       1     5056     ADAM-5056 16-channel digital output module       2     3       4     5       6     7	
< >		
It is ready!		
Start ProConOS WinCE	E 👘 Advantech Adam.NET 👘 🕹 🤹 🛞 🖽 🎐 12:11	ам 🞯 🏴

4. [PAC Device] Check the state of DI 0 is "ON".

Advantech Adam.NET U	Itility (WinCE) Version 1.00.08		
File Tools Setup Hel;	o 😥 🔜 🔍 🍠 📽 🕨		
ADAM4000_5000	ADAM-5051		
E- Q Local system	Channel setting		
- 00 5051(S0) - 01 5056(S1) - 61 Favorites group		DI 8	
	DI 1	DI 9	
	DI 2	DI 10	
	DI 3	DI 11	
	DI 4	DI 12	
	DI 5	DI 13	
	DI 6	DI 14	
	DI 7	DI 15	
<			
Polling (Interval=500ms):	108 times		
💦 Start   ProConOS WinCE	Advantech Adam.NET	🎯 🕹 🔌 🔕 대 🍠 12:3	2 AM 🞯 🏴

5. **[PAC Device]** Change the state of DI 0 to "OFF" and check the display.

Advantech Adam.NET U	Itility (WinCE) Version 1.00.08		
File Tools Setup Help	o 😥 🔚 🔍 🍠 📽 🕨		
■ ■ ADAM4000_5000	ADAM-5051		AMA:
E Q Local system	Channel setting		
- 00 5051(S0) - 01 5056(S1) ⊡- 02 Favorites group		DI8	
	DI 1	DI 9	
	DI 2	DI 10	
	DI 3	DI 11	
	DI 4	DI 12	
	DI 5	DI 13	
	DI 6	DI 14	
	DI 7	DI 15	
	170 Harris		
Polling (Interval=500ms): :	1/8 times		
Start ProConOS WINCE	: Advantech Adam.NET	<b>፼↓↓※% CH ]</b> <sup>12</sup>	:13 AM 🔯 🏸

6. [PAC Device] Select "ADAM-5056".

Advantech Adam.NET U	Itility (WinCE) Version 1.00.08		
File Tools Setup Help	o 😥 🔜 🔍 🖋 📽 🕨		
DAM4000_5000	ADAM-5056		
ADAM5000TCP_600	Channel setting		
5051(S0)			
- Sose(S1) 	DOD	DO 8	
	D01	D0 9	
	D0 2	DO 10	
	D0 3	DO 11	
	D0 4	DO 12	
	DO 5	DO 13	
	D0 6	DO 14	
	D0 7	DO 15	
<			
Polling (Interval=500ms): 2	25 times		
🛃 Start ProConOS WinCE	Advantech Adam.NET	🎯 🕹 🌺 🏈 CH 🍠 12:14	4 AM 🞯 🏴

7. **[PAC Device]** Change the state of DO 0, DO 2, DO 4, DO 6, DO 8, DO 10,DO 12, DO 14 to "ON" and check the display.

Advantech Adam.NET U	Itility (WinCE) Version 1.00.08		E 📃
File Tools Setup Hel;	o 😥 🔜 🔍 🍠 📽 🕨		
ADAM4000_5000	ADAM-5056		
⊕ ADAM5000TCP_600     ⊖ Local system     ∫ 5051(S0)     ∮ 5056(S1)     ⊕ S Favorites group	Channel setting DO 0 DO 1 DO 2 DO 2 DO 3 DO 4 DO 5 DO 6 DO 7	D08 D09 D010 D011 D012 D013 D014 D015 0015	
<			
Polling (Interval=500ms):	464 times		
Start ProConOS WinCE	Advantech Adam.NET	🎯 🕹 🔌 🚷 CH 🍠 12	::18 AM 📴 🏸

## 3.3 Multiprog Installation

Following will guide you how to setup Multiprog IEC-61131-3 development environment on your PC.

- 1. Please use your web browser to visit Advantech web site. (www.advantech.com)
- 2. Type "ADAM-5560" on the search box which is on the right-up corner of the web page.
- 3. Enter the "Utility" category in the download page.
- 4. Advantech provide customer a 30 days free trial version Multiprog with full function support. You can download it directly from the web site or from the FTP site.
- 5. After download all the software package from the web site, please follow the instructions to install them one by one to setup the development environment.
- 6. Please contact your sales representative to buy the license, Advantech will send you a letter with registration code.

### 3.4 Create a Project and Test the System

In following demonstration, a simple project of performing DI and DO function by ladder diagram is shown. After finish this section, you can ensure the system is workable.

1. Open Advantech Multiprog by clicking Multiprog item.



2. Click "OK" to enter the DEMO Mode.



3. Click "Register" to enter the Registration Code.



4. Enter the Registration Code which comes with Advantech Multiprog Software License Sheet.

Ele Edit View Project Build Online Extras ?
1211212121001000000000000000000000000
Register X
Enter registration code:
· · · · · · Cancel
Variable / POU/Wc Build (Errors ) Warnings ) Infos ) PLC Errors ) Print /
For Help, press F1

5. Click "OK" to finish the registration.

Eile Edit View Project Build Online Extras 2
▋◘☞▋◨ॖॖॖॖॖॖॖॖॖॖॖॖॖऺॖढ़ॖॖॖॖॖॖऺढ़ॖॖॖॖॖॖढ़ॖॖॖॖॖॖॖॖ
12112121220 1
MULTIPROG     Registration succeeded!     Ok
Variable / POU/Wc X Build / Errors / Warnings / Infos / PLC Errors / Print /
For Help, press F1

6. Open a new project and start to create the test project.



7. Select "ADAM-5560KW" item and then click "OK".

Bite Edit View Broket Build Other Extrem         Die Die State Die Richt Willicher         Project Willicher         Project Willicher         Die Die State Die Richt Willicher         Verdale         Project Willicher         Jahr Verdale         Verdale         Poull Die Nutzer         Jahr Verdale         Verdale         Poull Die Nutzer		_ 8 >
Image: Section	Elle Edit View Project Build Online Extras ?	
Image: Second		
Image: Second state     Image: Second state       Imag	Image: Section of the section of t	
Build / Errors > Warnings > Infos > PLC Errors > Print /	X POU/Worksheet X I	
	Build (Errors \ Warnings \ Infos \ PLC Errors \ Print /	

Chapter 3 Quick Start

8. Double click "Advantech DAQ" item.



9. Check the folder is at "Input".

iver Name	Driver Name	Board ID	I/O Group Name	Task	Start Address	Size
DI     A3752FDI     A3756FDI     ADAM-5000/Local     ADAM-5000/Local     ADAM-5017UH     ADAM5013     ADAM5013     ADAM5018     DI     ADAM5051     ADAM5051     ADAM5052     ModBus Protocol						
MODBUSRTU	1		11			1
DEMOIO	Add	Insert	Remove C	onfig	Create All Input Vari	ables

10. Select "ADAM5051" and then click "Add".

river Name	Driver Name	Board ID	I/O Group Name	Task	Starl Address	Size
🖻 - DI 🛛						
A3752FDI	1	-				-
A3/5EFDI		8				
는 ADAM-5000/Local						
AD30 70H						_
ADAM5017		-				
ADAM5018						
🖻 DI						_
ADAM5051						
ADAM5052		1				
∃ ModBus Protocol						
MODBUSKIU						
	Add 1	Incart	Bemove Co	opfiq	Create All Input Vari	ables

11. Select "0" for "Board ID". Set "0" to "Start Address" and then click "OK".

neral Low Byte		General
High Byte	IO Group Name	035D10
	Board ID	0
	Start Address	0
	Task	<default></default>
	Variables Prefix	ADAM5051 _BxxCyyy_I
		<note> xx : Board ID yyy : Channel Number</note>

12. Click "Create All Input Variables" and then click "OK".

iver Name	Driver Name	Board ID	I/O Group Name	Task	Starl Address	Size
DI     A3752FDI     A3752FDI     A3752FDI     A3752FDI     A3752FDI     A3752FDI     A3752FDI     A375070/Local     ADAM-5000/Local     ADAM5013     ADAM5013     ADAM5013     ADAM5018     DI     ADAM5051	ADAM5051		1035D10		0	2
ADAM5052 ModBus Protocol MODBUSRTU MODBUSTCP						

13. Click "Output" folder. Select "ADAM5056" and then click "Add".

river Name	Driver Name	Board ID	1/0 Group Name	Task	Star: Address	Size
A3754FDO	▲					
- A3756FDO						1
- ADAM-5000/Local	-					-
E-AU						
ADAM5024						
ADAM5050						
ADAMSUSS						5
						-
ADAM5060						
ADAM5060		16				1
ModBus Protocol						
MODBUSTCP	1					
- Other			2. <u>2</u> 22	11.527		
		Incort	Pomous C		Veste Al Output Va	riables

14. Select "1" for "Board ID". Set "0" to "Start Address" and then click "OK".

General
IO Group Name 0201D01
Board ID
Start Address 0
Task (default)
Variables Prefix ADAME056 _BxxCyyy_
<note> xx : Board ID yyy : Channel Number</note>

15. Click "Create All Input Variables" and then click "OK".

Iriver Name	Driver Name	Board ID	1/0 Group Name	Task	Star: Address	Siz
	ADAM5056		0201D01		0	2
ModBus Protocol MoDBUSRTU MODBUSRTU MODBUSTCP Other DEMOIO		Insert	Bemove C		Create Al Output Va	l

16. Double click "main" and graphical worksheet will be shown.



17. Click on the graphical editor and ladder objects will be activated.

Image: Image			@ @			1.55			ൺപ		30	1444	x	et. 6		10	- 1	LD	- ka	-						_
Project         Ubdrains		~~~ ·	e -	-   U						0 1-11	+0	n-n: T	ր պո			410	-1왕-	ne.		<u> </u>						
Project         U2 AdvMotion_A1*         U2 AdvAdvMotion_A1*         U2 AdvAdvAdvAdvAdvAdvAdvAdvAdvAdvAdvAdvAdvA		l r		- Server	LTT.		erenden.	Losse	LTD.					1000			044.5	<u> </u>								
Advision_A1*     Data Types     Logoal POUs     main*	Project		10		16	ø	10		16	æ	10		16	÷	10		16	÷	10		-	ø	10		-85	Ċ
W ● ● Ø       Data Types         Data Types       Data Types         Immain <sup>**</sup> Immain <sup>***</sup> Immain <sup>***</sup> I	AdvMotion_A1*		10		18		10		16		10		15	ø	10		15	8	10	22	16	Ø	15		16	ø
	- 🔐 AdvToolPack* - 🫅 Data Types		10		10	ø	20		18	8	2		15	0	10		10	8	2	23	10	0	10	2	12	Ċ
Imain T       Imain T	Logical POUs		10		10	0	2		15	8	22	2	10	0	15		10	3	2	2	10	0			12	Ċ
Prysical Hadware*      Prysical Hadware*      Prysical Hadware*      Grigation: IPC_32*      Tasks      Grigation: IPC_32*      Grigation: IPC_32	⊡- <u>u</u> main — <mark>()</mark> mainT		10		18	0	+	23	16	9	10		16	0	10		16	9	10	21	16	Ø	10	21	16	Ø
Prysical Hadvare*     Prysical Hadvare*	mainV*		20		19	$\otimes$	10		10	9	10	21	19	$\otimes$	25	21	16	9	10	23	15	Ø	$\sim$	21	16	Ø
Configuration: IPC, 32° ■ Tests ■ Tests ■ Tests ■ Advantech_DAD ■ Mill 100 ■ mair.main	Physical Hardware*		12	21	15	9	10	21	10	8	12	21	85	9	10	21	85	Ø	10	21	85	0		21	10	Ø
Tasks Tasks Tasks Tasks Sidobel Vaisber Advantech DAQ main:main main:main	Configuration : IPC_32*     Besource : ADV_CE*		10	20	25	9	10	21	25	8	12	21	83	0	10	21	85	Ø	10	21	85	0		21	15	Ø
Imain: main         Imain: main	E Tasks		10	21	19	Ø	16	21	10	9	10	21	88	9	10	20	88	9	10	21	16	Ø	10	21	16	Ø
Global Variables* Advartech_DAQ	main : main*		20	21	10	9	10	21	20	9	10	21	81	9	10	21	88	8	12	21	88	Ø	10	21	16	
	Global_Variables*		10	21	26	8	10		20	8	10	21	88	0	10	21	87	8	10	- 51	- 66	8	10	21	18	8
				-	20	8	10		20	8	- 10	81	100	8		- 21	88	8			88	8		21 	200	8
				21	- 20		- 20	- 21				- 21	- 20		- 20		- 20		- 20	- 21	- 20		-	21	100	
					-	ă.				ũ.		10				10		a						201 201	-	
				8	-	ä	20		-	ä			10	ä			10	ä		30	52	æ		20	12	
			10	81	-		25	2	-			8	-							8	50			21	12	
		Π.																								
		12	•		Г																					
		3	l• ma	in:mai	n _																					
		Ī																								
			L																							

18. Add a contact network.



19. Double click "C000".

MULTIPROG - Untitled - [main File Edit View Project Build	n:main*] I <u>O</u> bjects <u>L</u> ay	out i	O <u>n</u> line	Extra	is <u>W</u> ir	idow 2			_				-												- 8
) 🚅 🔒 🚨 🛃 🖬	n 🖻 🗠 🔉		Q			< 🔞	<b>.</b>		6	8	<b>**</b>	*	¢ (					<b>.</b> 17	ī						
1 11 18 18 IQ 🗛 -	- (**) 🖓 🗸	•> ¥*		-	-	<b>•</b> •	11	-     He	o  <b></b>	11-0-1	⊩⊪ T	# @	-		¢۵	-181-									
		-			101			- Noles																	-
Project			8	-	8 0			10	Ċ			16	Ċ	10		16	Ċ			10	÷	1		19	
AdvMotion_A1*			8	21	8			8	Ø	12		10	Ø	25		18	Ø	2	21	16	Ø	2		16	
- Data Types			8	21	81 - 6	- 12	21	85	ø	12		88	0	12		22	Ø	2		10	8	$\mathbb{R}^{2}$	2	20	1
🖨 🔄 Logical POUs			25	21	85 - 6	001	0	000		COL	21 <sup>00</sup>	101	1	12	21	10	ø	22		10	8	10	<u>e</u> 1	10	8
i main	- 11		19	2	18 0		Ľ	Ĩ			<u>;</u>	_	Ċ	15	61	10	ø	10		12	÷	10	21	10	-
iii main∀*			10	25	8		-	16	Ċ	12			Ċ	12	-	12	Ċ	22	21	16	÷	12	21	12	3
Physical Hardware*			8	21	16 6	y - 35		16	Ø	10		10	Ø	12		15	3	20		18	Ø	20		15	8
E Configuration : IPC E Besource : AD	_32* V CE*		16	21	85 - 6	2	23	85	Ø	10	21	88	$\odot$	12	21	22	Ø	25	21	10	$\otimes$	2	21	88	1
E- Tasks	·		10	21	88 - 8	20	20	87	Ø	10		87	Ø	15	<u>8</u> 1	20	8	25	21	50	$\otimes$	20	21	88	0
⊟ 🙆 Task:	CYCLIC sin : main*		10	21	85 - 8	2 18	21	85	Ċ	12	21	10	Ċ	12	21	18	Ċ	12	21	16	×.	12		18	0
Global_Va	iables*		10	21	16 (	2 18		16	Ċ	1	21	16	Ċ	10		15	Ť	10		10	S.			10	0
- Advantech			1	÷.:	18 (C	, se	0	10	ં	10		<b>:</b> 6	Ċ	15	20	10	Ċ	10		16	Ø	10	2	10	9
			16	21	85 - 6	10	2	85	Ø	10	1	87	$\odot$	15	21	82	Ø	2	21	16	0	2	2	10	0
			10	21	88 - 8	20	21	88	0	10		85	Ø	15	<u>8</u> 1	20	Ø	10	21	55	$\otimes$	20	21	85	0
			10	21	85 - 8	10	21	85	Ċ	12	21	10	Ċ	12	21	10	Ċ	12	21	16	×.	12	21	18	8
			10	21	81 (8	7 16	0	16	Ċ	10		10	Ċ	12	2	10	Ċ	10	21	16	Ξ.	10	2	18	8
			10	22	81 (d	7 No.	0	16	Ċ	10		10	Ċ	10	÷1	12	Ċ	10	21	-81	S.	10	21	15	- S -
		11	Í.	10	<u>15</u> 6	9 - 30.	13	25	ð		73	15													È
() 🖻 🛄 🗐 🗐		Ð	main	cmain																					
Variable 🕢 POU/	Worksheet	×																							

Chapter 3 Quick Start

20. Dialog box of "Contact/Coil Property" will be shown.

Name:	
Scope:	
Description:	<< Undefined >>
Description.	

21. Click "Global scope". Select "In\_ADAM5051\_0\_0" and then click "Apply".

Contact   Com	mon   Local scop	Global scop	$\supset$
Phys	ical Hardware		
	Configuration		
	Default	051 0 0	
		5056 1 0	
		2000 A 17 A 17 A 17 A 10	

22. "Common" folder will be shown. Click "Contact" folder.

contact/Loil Pro	perties	Global scope	
Name:	C000		
Usage: Data Type:			RETAIN
Initial value:			
I/O address: Description:			
	I PDD	C OPC	
ОК	Cancel	Apply	Help

23. Click "Global". Select "ADAM5051\_B00C000\_I" and then click "Apply".

Name:	ADAM5051 B00C000 I
	ADAM5051_800C000_1 ADAM5051_800C001_1 ADAM5051_800C002_1 ADAM5051_800C003_1 ADAM5051_800C004_1 ADAM5051_800C005_1
Scope:	C Local Global
Description:	ADAM5051 Board ID 0 Digital Input 0
Contact/Coil	Type:

24. Click "OK".

Name:	ADAM5051_B00C000_1
	ADAM5051_800C000_I
Scope:	C Local 📀 Global
Description:	ADAM5051 Board ID 0 Digital Input 0
- Contact/Coil	
<ul> <li>Contact</li> </ul>	Tune:

25. Double click "C001".

(@MULTIPROG - Untitled - [main:main*]																								_ 8 ×
Eile Edit View Project Build Objects La	yout On	line E;	tras	₩indo	w <u>2</u>																			_ 8 ×
	≥ .	QI	RE	×			1	6		-	x	۵ (			(m)	1H		i						
	(∞) ¥□ +				। तर्गत	-	<sub>he</sub>	of and		4-0 T	tr da	. Here			-121-									
						1	III	91 							49									1
Project							- 22				- 2				- 22				•2					. =
AdvMotion_A1*							-					ä											50	
AdvToolPack*							-	ø				ø			-				-				-	
Data Types		21	16	e.				29 - L	-	-		æ	12	21	- 25	æ	12	2	12	æ	12	21	- 19	8
⊡ main* ⊡ ] mainT		-	10	e	UU1AL	AMSU	Б <u>1_</u> В	· (					10		10	e	10		10	e	10		10	8
ii main∀*			10		١.	-	10	÷		-		÷	10		10	÷	15		10	e.	10		10	8
main     Physical Hardware*	- 25	2	10	8	10		16	0	10		10				10	Ø	10		12	0	10		19	0
Configuration : IPC_32*	- 2	2	10	0	22	21	18	$\otimes$	22	21	10	$\otimes$	12	21	22	8	10	21	12	$\otimes$	22	21	25	0
i asks	- 25	22	38	0	15		38	0	12	21	38	0	10	21	38	ø	12		38	0	10	<u>61</u>	32	0
⊡ Task : CYCLIC	- 20	23	10	÷	15		38	8	12	<u>e</u> 1	16	8	10		10	÷	10		10	S.	10	<u>8</u> 1	10	0
Global_Variables*	- 23	23	10	S.	12	-	10	÷	12	-	10	S.	12	21	10	÷	15	-	12	8	15	21	19	8
Advantech_DAU	10	2	10	9	10	21	10	9	10	20	16	9	10		10	÷	10		10	9	10	21	16	0
	1	21	10	9	10	21	16	9	10	21	10	9	10	21	16	Ø	10		16	9	10	21	16	0
	100	21	-	8	10		361	0	10	21	36	8	10	2	38	8	10	21	19	8	10	<u>e</u> 1	86	0
			10	8	1	81 	10	8	10	÷.	10	8	- 10		10	8	1	2	10	8	18 		10	
			38 •*	8		- 2	- 20	8				8		2							- 10	- 21		
				~																				
		main:m	ain																					
X Variable / POU/Worksheet	×	▶\ B	uild "	Error	sλw	/amin	gs X	Infos	λpl	CEn	ors $\lambda$	Print	1											
Object marked																						1	60,27	D: >2GB

26. Click "Global". Select "ADAM5056\_B01C000\_O" and then click "Apply".

Name:	ADAM5056_801C000_0
	ADAM5051_000C015_L
	ADAM5056 BUID000 0
	ADAM5056 B01C002 0
	ADAM5056_B01C003_0
Scope:	🔿 Local 🛛 🧿 Global
Description:	[Slot1]ADAM5056 Digital Output 0
	<b>T</b>
- Contact/Coil-	1
C Contact	
Coil.	Туре: -{ ]-

27. Click "OK".

Name:	ADAM5056_B01C000_0
	ADAM5056_B01C000_0 ADAM5056_B01C001_0 ADAM5056_B01C002_0 ADAM5056_B01C003_0 ADAM5056_B01C004_0 ADAM5056_B01C005_0
Scope:	C Local 📀 Global
Description:	[Slot1]ADAM5056 Digital Output 0
Contact/Coil	Туре: -( )-

Chapter 3 Quick Start

28. Back to graphical editor.



29. Right click "Resource: ADV\_CE" and then click "Settings".



30. Type IP Address of ADAM-5560KW as "192.168.1.5".

MULTIPROG - Untitled - [1	main:main*]															- 5
Eile Edit View Project	Build Objects Layo	ut O <u>n</u> line E <u>x</u> tras <u>W</u> indow <u>?</u>									-					- 8
∬ D 📽 🖬   🗟 💩   🐰		🔍 Q 🖪 🗖 🏹 🔞 I	▫▫▫║	۵ 😢	• ×	¢ و	]    ●			<b>.</b> W						
100000	(**) \$*** <***	· 11 - 4	1	⊪ no n	바다다	1	- C -	-121-								
		r -	a la fei						2							12
E S Project			8 8 C	15	a s	10	s - 5	10	8	15		10	8	15	-	5 a 🛉
Resource settings for	IPC_32		×	8	8 - 8	0	8 8	10	0	15	8	10	0	15	8	8 8 <b>-</b>
Port		119200	Ok	- 10	n = n	35	$S_{i} = S$	20	12	351	22	$\mathbb{S}^{2}$	25	351	21	21 - 21 - 21
C COM1		1	Cancel	DAM505	6_B*	35	8. 8	22	35	351	20	22	35	81	25	29 - 26 - 12
C COM2		8				- 35	8 2	22	35	81	25	22	35	81	20	22 25
C COM4	Parity:	None 👻	Data area	10	N 88		8 8	20	35	81	25	22	35	100	20	9 B
C Simulation 1	Timeout:	2000 ms	Help	10	N N	35	8 8	22	10	351	20	22	35	191	25	2 2
C Simulation 2					N 10 			2		18	2	2		8	2	2 2
	Stack chec	k on PLC				325			30	585	~		35 	- 25		
6 DU	Force BOOL	lary check on PLC 8 for boolean variables			5 5 5 5				22					20		50 00 00 50 02
	Generate bo	potproject during compile									2	-		2		
	P/IP		-		<u>n n</u>	25	a 1	22	25	15	22	22	2	8	2	8 8
Dumates (int	02 160 1 5 T0 2000	<hr/>		35	<u>n n</u>	35	81 12	20	35	851	21	22	25	331	21	92 - 38 - <sup>1</sup>
Parameter:	32.166.1.3 -102000			- 32	2 2	35	8 2	22	35	32	22	22	15	8	21	22 - 26
				- 10	8 8	35	S = S	22	35	8	20	22	35	8	21	22 23
All network variable	5	All network variables		- 10	8 - 8	35	8 8	22	35	81	25	22	35	81	21	9 8
Marked variables		Marked variables			N N											•
All POUs	C Marke	d POUs C No reserv	ve													
					-											
			Narnings ) Info	s / PLC	Errors )	Print	(									
Object settings																1,40 D:>

31. Click "Make" to build the execution file. Check the project has been compiled successfully.



32. Click "Project Control Dialog" and then click "Download".



33. Check "Include boot project" and then click "Download".

	X 🖻 尾   🗠 9 Download	≥   @, €			× @	<b>1</b> 3 E				<b>8</b> 2	× 2			-121-	#4   		ž					
	Project	-			Bootp	project-	_				_	_	1911 24	a 99								
Project	D	wnload	>				Do	ownloa	d					10		15	21	8	0	10		8
AdvMotior	Include Bootp	roject					A	.ctivate				- 2		- 23		25	01	20	8	25	8	20
Data Types	Include Source	xes data					Delet	a on T	arnet			- 2		- 10	8	15	21	20	8	15	21	20
⊡ — 🔄 Logical POUs ⊡⊡ main	Down	load Source	4						2			- 8	1	- 33	8	15	61	20	8	15	6	20
i mainT	Include User-	Libraries												10	8	15	1	8	8	15		8
- 🛅 main	I Include Page	ayouts end-Code														10			2			-
E S Configurati	Delete So	rurce on Ta	get	1			Dow	nload	File		T.	8				15				15		-
⊟ - 🏙 Resou ⊡ - 🍘 T∢												3		- 10	e	15	-	-10	e	15		-
<u>o</u> e			Clo	se		Help						- 2		10		15	61	10	0	15	8	10
ි බෙ	oal_Variables											5 8		10	8	25	61	20	8	15	81	20
Adv	antecn_DAQ	10	21	10		21	10	8	10	21	10	с и 		10	8	15	61	10	8	10	21	10
					с в. с. с.		- 20		-			с с с с				10			8	10		- 20
		8		8			10			8						10	17	esour	TR			
		25	21	10	e	8	28		25	21	10	e		10		15		State:	Or	n		
		- 15	8	30 - O	e	8	10	8	15	21	10	e - 8		- 23	8	15	÷	St	op	1_	Cold	
		11	<i>3</i> 0	2	e		-23	3			**	l						Re	set	┛	Warn	
• • • •		(D m	ain:maii																		Hot	
Variable /	POU/Worksheet	×	Cre	ating	data	tenpl	ates										=	Dowr	nload	4_	Uploa	d
			Pro	cessi	ng cod	e												En Ck	ior ise		Help	
			Pro	cessi eting	ng dat task	a info											1	CIU	ne O		Treip	

34. Downloading execution file to ADAM-5560KW.

🙆 MULTIPROG - Untitled - [main:main]																								- 8 ×
Ele Edit View Project Build Objects Lay	yout O <u>n</u> li	ne E <u>x</u> t	ras <u>₩</u>	/indov	v Z																		į.	_ @ ×
	2		30	1	() ()		1		9		*	-	I		( <b>1</b> 11)	A	8. 50	i						
00000	ono 🐑 🐗	-	-		<b></b>	臣	Нн	of 11-11	+0	e-i 1	<b>ت</b> ت	L He	-11-1		-181-			_						
	-		1.33			1	1,332									2								
Project     F		2	15	1	16		18		10		16	Ø	12	2	10	Ø	10	21	18	0	12	2	10	· -
AdvMotion_A1		21	16	1	10		15	2	12	21	88	Ø	22	21	18	Ø	22	21	18	ø	12	8	18	
- Data Types	- 22	21	10	2	25		10	$\otimes$	22	21	88	0	20	21	10	$\otimes$	12	21	28	9	22	21	16	0
🖻 🔄 Logical POUs	- 22	21	36	° 0	01AD	AM50	51_E	* AD	AM5	056_1	8*	8	20	21	10	2	15	21	26	0	22	21	16	0
i mainT	- 22	21	36	0		-	-	-		>		0	20	21	16	0	15	<u>0</u> 1	88 195	0	10	21	16	
ainv 💼 main	- 22		36) 1	8	100	21	10	8	12	21	187	0	20	21	16	1	25		88 1	8	10	21	16	0
Physical Hardware	8		36 	8	10	21	-	8	10	21	-	×.	20		10	8	10	21	- 10	8	10	21	16	
E Besource : ADV_CE			- 20 - 22	~	- 10	-	-22				- 20				- 20				-20				-20	
⊟ · 🔄 Tasks ⊟ · 🕑 Task : CYCLIC		-	-	a.			-52	ä																
🔄 🔲 main : main			-12	a l			-10	æ			-	æ	10			e			-10				-	-
Advantech_DAQ			10	67	10		10	æ	10	23	16	Ċ	10		10	Ċ	10		10	÷	12		-6	
	- 8		10	×.	10		10	÷	10	-	10	Ċ			10	Ċ	10		10	÷	12		16	e -
	- 25	2	10	1	10		18				16	Ť	15	2	10	Ċ	15	21	15		10	2	10	e -
	- 8	2	10	Ċ	10		16	0	10	2	16	Ø	10	21	10	0	15	R	esou	rce		_	×	ŀ
	- 22	<u>8</u> ]	10	8	10		25	8	10	21	19	Ċ		21	10	Ø	15	: S	State:	E	ownlo	ad	-	
	- 25	<u>8</u> ]	16	8	10	21	26	8	10	21	88	Ø	10	21	10	Ø	15	÷.,	2	rop		Loid		· •
	<u>III</u>	24	100	0	14	92	100	0	10	32	- 22								- 14	0901		Hot		5
	<b>1</b>	ain:mai	in																		÷	Union		
🗏 🎍 Variable 🕢 POU/Worksheet	×	Cre	ating	g da	ta te	empla	tes											=	Day	vniuau		Upita		-
	1-1	Pro	ocessi	ing	code	•••													0	Inse		Help		
		Cre	eating	g ta:	uaca sk ir	nfo .																		
		Cre Frre	eating	g in	itia] Marni	lizat	ion	code	•••															
	1	Bu	ild 🖌 F	rrors	λ W	arnin	, as λ	Infos	λPI	CEn	ors <b>λ</b>	Prin	17		_	_		_	_				_	-
Downloading project	عدي				~~~		9- J(			49	%				_	_		_	_				_	

35. Click "Cold" to execute a cold start. During a cold start all data are initialized.



36. Click "Debug On/Off" to turn on the debug function. The ADAM-5560KW is running correctly when you see the status bar turns green color. You can see the DI0 and DO0 are turned blue color. It means the state is FALSE.

MULTIPROG - Untitled - [main:main - Con	figuration	Resour	ce.Task	.main.	main]																_ 8 ×
Eile Edit View Project Build Objects La	ayout O <u>n</u> lin	ie E <u>x</u> tra	as <u>W</u> indo	ow <u>?</u>						_											_ 8 ×
🗋 D 🚅 🖬 🖪 💁 🐇 🖻 🛍 🗠 🤅	2 🔍 🤅	2 🗖			-			2 (**	≚(	-					<b>.</b>						
	~ 🛍 🐗	I de l	*		世	HEOR	aler alex	> -II-II:	क्षी क	1		0-ru Cp-ru 	- \$ -			-					
			de-		10	201							-								
E Libraries	2	27	e s	23	27	e i	s - 2	10	1	8	2	30	10	15.	2	37	-	8	22	5 - S	. –
AdvMotion_A1	- 2	$\mathbb{N}^{-1}$	e - 18	25	20	2	s. – 2	20	2	2	12	$\mathbb{R}^{2}$	82	12	23	22	10	8	22	S = S	
Data Types	- 2	20	8 - 38	23	27	1	s – 2	20	12	8	23	28	102	12	22	20	85	8	22	8 8	
E-G Logical POUs	- 25	27	e s	001	DAM505	51_B*	ADAM	5056	B*	8	13	39	12	15	2	22	15	8	22	5 - S	÷
mainT	- 2	27	8 - X					<del>-</del>		2	12	27	12	12	21	22	10	35	12	S - 8	1
main	- 2	10	8 - 18 -	8. N	27	15	e 2	10	1	8	20	22	15	15	*	22	95	8	22	39 - 9	
Physical Hardware     Physical Hardware	8	27	8 - S.	25	37	1	8 2	37	1	2	28	10	1	1	2	20	22	80	22	5 V	1
E- Resource : ADV_CE	- 2	20	11 II.	25	27		8 - 2i	20	12	22		27	12	12	23	20	25	35	10	S - 8	1
E Tasks	*	20	a 18	20	201		8 2	20	10	20	28	28	102	18	22	32	85	8	20	S 8	
main : main		17		28 28	27		6 9 6 8	17 16	10	1	12	27 30	25 63	10	2	22	95 24	8 8	22 12		
Global_Variables		22	a. a	12	22	s. :	8 B	10	55	14	12	12	5 <u>2</u>	14	1	20	84	8	1	10 A	
		22	a a	13	55	S. 1	8 13	50	<i>8</i> .	12	13	38	6 <u>5</u> .	12	1	33	83	8	1	10 0	
		20	a a	12	35	5. I	a 18	35	15	14	12	55	65	15	8	33	81	8	1	10 - 61	
	- 2	22	a a	2	20	s	8 13	20	55	14	12	22	54.	14	1	1.0		1000			जिन्
	~	20	a a	12	35	8. I	a 13	30	12	12	12	38	18 <b>.</b>	12	8	. 9	State:	B	un		
	1.1	28	8 - 8	32	28	5	8 N	30	8	14	12	35	15	14	8		S	top		Cold	
										-							Be	eset		Warm	<u> </u>
		88	-													_				Hot	
	- er m	ain:main														_1	Dow	nload	1	Upload	
🗶 🖕 Variable 🖉 POU/Worksheet	×	Crea	ating d	ata t	emplat	ces .											E	rron		Info	
		Proc	essing essing	code data													CI	ose		Help	
		Crea	ating t	ask i	nfo											_					
	1	Crea Error	ating i :(s), O	nitia Warn	lizat: ing(s)	lon c	ode	•													
		Buil	d / Erro	rs λ V	Varning	s λ In	fos λ P	LC Er	rors λ	Print	/										<u>·</u>
For Help, more F1			~				1.0		~											75	27 D: 52GE

37. When you change the state of ADAM-5051D CH0 as ON, ADAM-5056 CH0 turns ON correctly. The DI0 and DO0 on graphical editor are turned red color too. It means the state is TRUE.



38. Finish the test project and do not forget to save it properly.

	actoriate	esour	ce.Task	.main.	main <sub>.</sub>																		_ 8 ×
Eile Edit View Project Build Objects Layout	Opline	Extra	s <u>W</u> indo	w 2																			_ @ ×
D New Project Ctrl+N     Open Broject / Unzip Project As     Ctrl+O     Save Project As / Zip Project As	Q 4	-			3 E			€ (# +0	₩ ••• T	<u>ل</u> ة الح الم	<b>0</b>	<b>1</b>	•	-181-	<b> </b> 4	<b>.</b> W							
E Close r joject																	•						
Save As Te <u>m</u> plate Delete <u>T</u> emplate		8		12	27		10	2	30			2	20	S.	8	2	3	1	8	2	3	8	<u>.</u> _
Export Import			ся. ся	001A0	DAM5	051_E	* AD	AMS	)56_E	3*		25 25	20 20	2 2		N N	55	9 9		2	55	15 15	2 2
Enter password		87 - X	: x		-	H			<u> </u>		10	*	20	1	8	22	22	8	8	2	2	8	
E Save Ctrl+S	ŀ			3	27 27	8	8	*	20	2		28	10	1	100	2	2	15	8	2	2	10	:
Glose	_	8 1 8 1	e e e e	2	27		28 12	2	20 20			2	10 10	1	10	20 20	20	10 10	2	2	20	95 95	
Print Ctrl+P		5 - 1 2 - 1		2	27 26		2	2	27	2	2	2	20			2	2			2	10	13 14	
Print Project		n (		12	20	5	14	2	20	-	24	12	10	54 1	14	10	20	84	8	2	20	8	5
1 D:\KW-Software\\Test.mwt 2 D:\KW-Software\\Demo.MWT		n s n s		24 23	20 20	54 54	24 22	а 3	92 22	54 54	а 12	20 20	20 20	54 54	24 22	20 20	2	14 14	31 53	20 21	20	24 22	34 54
E <u>x</u> it		98 - S	1 12	3	20	×.	22	8	10	54. 1	2	12	20.	<i>1</i> 2.	12	20	33	82	82	25	20	2	4
	1	36 - X		10	35	25	17	12	32	10	27	12	10	×.	12	3% 	33	82	8	20	30	82	ж. Т
	iai -	2		4	-		÷.		2		1	i T	i i	4	3	r T	10	- 14 - 14	4	-	10	а 3	
	<b>]-</b> mair	rmain																					<u> </u>
X Variable / POU/Worksheet X	v 0 1	Crea Proc Proc Crea Crea Crea	ting d essing essing ting t ting i (s), 0	ata t code data ask i nitia Warn	empl  nfo liza ing(	ates  tion s)																	*
•		Build	K Erro	rs∧V	Varnir	igs X	Infos	λPL	CErr	ors A	Print	1											

## 3.5 Special Module Support in KW

ADAM-5050 is one of mix digital input/output module and each channel can be independently configured to be an input or an output channel by the setting of its DIP switch (Please refer the user manual of ADAM-5000 IO Module to get more detail).

For the ADAM-5050 configuration in MultiProg KW, we define it as an output module only. The IO address will show as %QX by channel.

I/O Configuration V3.0.0.27				23
Input Output Motion COM	ADAM-5050 Digital Output Con	figuration(v1.0.0.6)		
Driver Name	General DO Port 0 DO Port 1	IO Group Name	General O201DO0	
<u>ADAM5050</u> <u>ADAM5050</u> <u>ADAM5055</u> <u>ADAM5056</u> <u>ADAM5057</u> <u>ADAM5060</u>		Board ID Start Address %QE	0 <b>•</b>	
ADAM5068 ADAM5069 ODM = BackupSys		Task Variables Prefix	<default>       ADAM5050       BxxCyyy_0</default>	
ModBus Protocol     MODBUSR TU     MODBUSS TCP     Other     MODEMOIO			<note> xx : Board ID yyy : Channel Number</note>	•
share memory: 🔲 all retain when	Kennas F	OK	Cancel Description	el

In program, you still can read the status of the output as the input signal that you define it as an input by hardware DIP switch.

Change -									1.2	-	-	_
main:main - Configuration.	Resource.Task.m	ain.main										23
	A	DAM5050_D00- 0	L	—%QX0.0 0	(*[S	lot1]ADA	M5055 I	Digit	al Ou	ıtput	0*)	* III
(*[Slot0]ADAM5055 D	9igital Input O*	) %QX1.0— 1		-ADAM505 1	50_DI0							
🔝 Global_Variables:Configur	ation.Resource -	Configuration.Reso	urce.Global_Variab	les					-	- 0		x
Name	Usage	Description			Address	Init	Retain	P	0	TB	Hi	-
□ Out_ADAM5055_0_0	·											
ADAM5055_B00C000_O	VAR_GL	[Slot0]ADAM5055	Digital Output 0		%QX0.0				1			
ADAM5055_B00C001_O	VAR_GL	[Slot0]ADAM5055	Digital Output 1		%QX0.1							
ADAM5055_B00C002_O	VAR_GL	[Slot0]ADAM5055	Digital Output 2		%QX0.2							
ADAM5055_B00C003_O	VAR_GL	[Slot0]ADAM5055	Digital Output 3		%QX0.3							
ADAM5055_B00C004_O	VAR_GL	[Slot0]ADAM5055	Digital Output 4		%QX0.4							
ADAM5055_B00C005_O	VAR_GL	[Slot0]ADAM5055	Digital Output 5		%QX0.5							
ADAM5055_B00C006_O	VAR_GL	[Slot0]ADAM5055	Digital Output 6		%QX0.6							
ADAM5055_B00C007_O	VAR_GL	[Slot0]ADAM5055	Digital Output 7		%QX0.7							
ADAM5055_B00C008_O	VAR_GL	[Slot0]ADAM5055	Digital Input 8		%QX1.0							
ADAM5055_B00C009_O	VAR_GL	[Slot0]ADAM5055	Digital Input 9		%QX1.1							-
ADAM5055_B00C010_O	VAR_GL	[Slot0]ADAM5055	Digital Input 10		%QX1.2							-
ADAM5055_B00C011_O	VAR_GL	[Slot0]ADAM5055	Digital Input 11		%QX1.3							Ξ
ADAM5055_B00C012_O	VAR_GL	[Slot0]ADAM5055	Digital Input 12		%QX1.4							
ADAM5055_B00C013_O	VAR_GL	[Slot0]ADAM5055	Digital Input 13		%QX1.5							
ADAM5055_B00C014_O	VAR_GL	[Slot0]ADAM5055	Digital Input 14		%QX1.6							
ADAM5055_B00C015_O	VAR_GL	[Slot0]ADAM5055	Digital Input 15		%QX1.7							
•			III								Þ	a



**Modbus Functions** 

### 4.1 Introduction

The Modbus functions of ADAM-5560KW Controller are powerful features which provide high expansibility and flexibility for user's applications. The supported modbus functions include following items.

- Modbus/RTU Master Function: Connect to Modbus/RTU remote I/O modules such as Modbus modules of ADAM-4000 series.
- Modbus/TCP Client Function: Connect to Modbus/TCP remote I/O modules such as ADAM-6000 series.
- Modbus/TCP Server Function: Connect to HMI/SCADA software via Ethernet port.

### 4.2 Modbus/TCP Client Function

The Modbus/TCP client function can connect to Modbus devices with Modbus/TCP server function, for example, ADAM-5560/TCP and ADAM-6000 series I/O modules.

Following example can show how to connect to ADAM-6050 by Modbus/TCP client function.

ADAM-6050 settings: IP address: 192.168.1.12

ADAM-5560 Series Controller settings: Slot 0: ADAM-5051D Slot 1: ADAM-5056D IP address: 192.168.1.5

System Wiring:



# 4.2.1 An example to demonstrate how to connect to ADAM-6050 for Modbus/TCP client function

 [PAC Device] Run ADAM.NET utility by clicking "Start" -> "Programs" -> "Advantech" -> AdamNET Utility.



2. **[PAC Device]** Select "ADAM5000TCP\_6000" item.

Advantech Adam.NET	Utility (WinCE) Version	1.00.08			
File Tools Setup He	Þ 🖗 🔜 🔍 🖉 📲				
ADAM4000 5000     ADAM5000TCP_600	Host name:	ADAM-5550			]
Electric System     Electric System	Adapter:	192.168.1.5			]
	Connection timeout:	2000 "	S		
	Send timeout:	2000 "	s		
	Receive timeout:	2000 "	s		
	Scan interval:	1000 "	s	Apply	
	Support Module:				,
	ADAM-5000 Series		ADAM-6000 Series		
	ADAM-5013 ADAM-5017 ADAM-5017H ADAM-5018 ADAM-5024 ADAM-5050	<ul> <li>•</li> </ul>	ADAM-6015 ADAM-6017 ADAM-6018 ADAM-6022 ADAM-6024 ADAM-6050	<ul> <li>×</li> </ul>	
<					
It is ready!			-		
Start ProConOS WinCl	E 🛃 Advant	ech Adam.NET Ut			🕹 🌉 🍓 🍠 12:01 AM 🛛 🕑

3. **[PAC Device]** Click "Search" button.

Advantech Adam.NET Utility (WinCE) Version 1.00.08									
File Tools Setup Help 😥 💽 🔍 🖉 隆 🕨									
	14000_5000 15000TCP_600	Host name:		ADAM-5550					
Othe Local s	hers system	Adapter :		192.168.1.5					
e sa ravon	ites group	Connection Send timeo	timeout: ut:	2000 r	ns				
		Receive tim	eout: <mark>Sear</mark>	ching the net.	•				
		Scan interva	al:	0	2	Apply			
		Support Mo	dule: Series						
		ADAM-5013 ADAM-5017 ADAM-5017H ADAM-5018 ADAM-5024 ADAM-5050	1	×	ADAM-6015 ADAM-6017 ADAM-6018 ADAM-6022 ADAM-6024 ADAM-6050	~			
< It is ready!	>								
Start Pro	Start ProConOS WinCE		🚰 Advante	ch Adam.NET Uti	😡 Searching th	e net	1 党 🛞 🧶 🕹 🗊	2:01 AM	<b>B</b>

4. **[PAC Device]** Click "192.168.1.12" item and then "6050" item will show.

Advantech Adam.NET U	Jtility (WinCE) Version	1.00.08	
File Tools Setup Hel	p 💋 🔚 🔍 🍠 📽 🕨		
	Host name:	ADAM-5550	
@ 0thers	Adapter:	192.168.1.5	
Local system	Connection timeout:	2000 ms	
	Send timeout:	2000 ms	
	Receive timeout:	2000 ms	
	Scan interval:	1000 ms Apply	
	Support Module:		
	ADAM-5000 Series	ADAM-6000 Series	
	ADAM-5013 ADAM-5017 ADAM-5017H ADAM-5018 ADAM-5024 ADAM-5050	ADAM-6015 ADAM-6017 ADAM-6018 ADAM-6022 ADAM-6024 ADAM-6024 ADAM-6050	
K Start ProConOS WinCB	- Advant	tach Adam NET I #	
5. [PAC Device] Click "6050" item to see the channel setting.

Advantech Adam.NET U	tility (WinCE) Version 1.	.00.08		
File Tools Setup Help	Ø 🗔 🔍 🖉 📽 🕨			
ADAM4000_5000     ADAM500UTCP_600     ADAM500UTCP_600     192.168.1.5     9 192.168.1.12     6050     00thers     Local system     Favorites group	Information Network F Firmware version: Device name: Device description:	RS-485/WDT Stream/Event F 1.27 6050-DEMObox1	Password Firmware Apply change	
	Slot Module 6050	Description ADAM-6050 18-ch isolated	d digital I/O module	
< >>				
RefreshModuleInfo:	1			
Start ProConOS WinCE	Advantec	h Adam.NET Ut	🚉 🕹 🎎 🚷 🍠 12:02 i	АМ 😡 🗭

6. **[PAC Device]** Enter "00000000" and then click "OK" button.

Advantech Adam.NET Utility	(WinCE) Version 1.00.08	
File     Tools     Setup     Help       ADAM4000_5000       ADAM5000TCP_600       Image: Setup     192.168.1.1       Image: Setup     Image: Setup       Image: Setup     Image: Setup	Resevent Kord	
Start ProConOS WinCE	🚰 Advantech Adam.NET Uti 🥥 Password	📴 🕹 🔌 🏈 🍠 12:04 AM [ 🎯 🏸

7. [PAC Device] Check ADAM-6050 DI bit 0 is OFF.

Advantech Adam.NET U	tility (WinCE) Version 1.0	0.08		
File Tools Setup Help	0 🕞 🔍 🖉 📽 🕨			
ADAM5000TCP_600	ADAM-6050 18-ch isolated o	digital I/O module		
□ ↓ 192.168.1.5	Channel setting Modbus	h		
⊕ <u>80</u> 6050 @ Others		DI 6		
- local system ⊡- 💁 Favorites group		DI 7	DO 1 WDT	
	DI 2	DI 8	DO 2	
	DI 3	DI 9	DO 3 O WDT	
	DI 4	DI 10	DO 4	
	DI 5	DI 11	DO 5 WDT	
	Turn on WDT checkde	d channel when WDT triggered	Apply WDT	
< >				
Polling (Interval=1000ms):	3 times			
Start ProConOS WinCE	Advantech	Adam.NET Ut	🚉 🕹 🌞 🌏 🍃 12:04 .	AM 🞯 🏴

8. **[PAC Device]** Turn on ADAM-6050 DI bit 0 and make sure the status is ON in the utility.

Advantech Adam.NET U	Itility (WinCE) Version 1.00.	.08		
File Tools Setup Help	o 😥 🔜 🔍 🍠 📽 🕨			
ADAM4000_5000     ADAM5000TCP 600	ADAM-6050 18-ch isolated dig	gital I/O module		
192.168.1.5	Channel setting Modbus			
	DIO	DI 6		
- local system ⊕ _ 🛃 Favorites group	DI 1	DI 7	DO 1 WDT	
	DI 2	DI 8	D0 2 WDT	
	DI 3	DI 9	DO 3 WDT	
	DI 4	DI 10	D0 4	
	DI 5	DI 11	DO 5 WDT	
	Turn on WDT checkded	channel when WDT triggered	Apply WDT	
Colling (Interval=1000ms);	49 times			
Start ProConOS WinCE	Advantech Advantech	dam.NET Ut	🞯 🕹 🏨 🏈 🍠 12:05 AM	и 🞯 🏴

9. **[PAC Device]** ADAM-6050 setting is correct. Exit from the ADAM.NET utility.

n dataset xml file		l digital I/O module		
dataset xml file	Channel setting Modbus			
	DIO	DI 6		
Local system Favorites group	DI 1		DO 1 WDT	
	DI 2	DI 8	DO 2 WDT	
	DI 3	DI 9	DO 3 WDT	
	DI 4	DI 10	DO 4 WDT	
	DI 5	DI 11	DO 5 WDT	
	Turn on WDT checke	led channel when WDT triggered	Apply WDT	
>				

10. Open "Test.mwt" and follow the example in section 3.4.

Elle Edit View Project Build Opline Extras 2
「「「「「「「」」」」「「」」」」「「」」」」「「「」」」」「「」」」」「「」」」」
Open/Unzip project       2 ×         Look in:       Projects         AMOMet_1-Axis       Sed/SqDEMO.zwt         Autodemo       Butwide         Autodemo       Butwide         Autodemo       Butwide         Commo       Butwide         Demo       With Electory         File name:       Test:         File name:       Test:         Files of type:       Project Files (*mwt,*zwi)         Cancel       X
X POU/Worksheet X

11. Double-click "main" to show the program in graphical editor.



12. Double-click "Advantech\_DAQ" to show the "I/O Configuration" dialog box.

MULTIPROG - Test - [main:main]																								_ 8 ×
Eile Edit View Project Build Objects La	yout On	line E <u>x</u>	tras ⊻	∕indov	νZ																			_ 8 ×
000000000000000000000000000000000000000	2 🔍	0		*	<b>(</b>	3 🔜	1			<b>#</b>	×	🔹 (	1		-	4	<b>.</b> ka	ī						
1 <b>8 8 8</b> 1 9 5 - 1 10 2 -	~ 🛍 -			•		1	+++	्र स्र	460	n-n-T	밖 대	ı  ⊣⊩	-6	바라	- \$ -									
	-																							
E-G Libraries	2	22	12	2	12	27	12	18	12	$\overline{v}$	22	2	25	20	12	12	22	20	-	35	22	22	-	
AdvMotion_A1	- 2	10	12	22	25	27	12	12	22	$\mathbb{R}^{2}$	12	12	28	$2^{\circ}$	12	12	$\sim$	22	-95	80	22	22	-05	·
	2	10	105	22	22	20	12	18	28	27	25	2	28	$\overline{w}$	12	12	2	27	-95	8	22	22	15	
E-G Logical POUs	2	27	105	2.5		AMSOS	51 E	8* AF	AMSC	156 F	8* <sup>-</sup>	12	25	20	82	22	20	22	-95	83	22	22	-05	2
inani mainT	2	10	105	8		-	F		-(	>		12	28	10	12	15	22	22	35	8	22	22	15	2
	2	10	100	12 6	1	20	1	18	12	39	1		28	10	10	15	22	22	-	8	22	20	95	2
Physical Hardware		29	18 <u>6</u>	12	14	20	×.	14	1	20	S.		1	20	<i>8</i> 4			20	-	2			-92	
⊡ - 📷 Configuration : IPC_32 ⊡ - 📾 Resource : ADV CE*		20	82 <b>.</b>	10	2	28. 	24 	14	100	- 20	-	2		8	- 22	12	25	- 25	- 22		1	- 25	- 64	
E- 🗃 Tasks		22	72 <b>.</b>	10	- 22	20	894. 		- 42 	- 20	- 22				72 <b>.</b>			255		-		- 255	- 22	
⊡ main : main		20	204 20		8	20	84 22	14	-				- 42	20		14				99 - 10	29 10	89 12	- 24	
Global Variables		20	24 27	2	- 2	20	84 27	14	4	- 20				40		14	-			99 - 20	10	89 22	- 14	
Advantech DAU				2	42	20	94 22	14	47 10	- 20		-	42							54 27	471 100	20	- 24	
				2			94 83						10					20		14 27		20		
			2			(2)	2			-														
						6	-				2		-	6										
				12		2	3. 3.	12		- 20				2	32			20				-		
												i												<u>.</u>
	in.	main ma	in [																					<u> </u>
X b Variable / POU/Worksheet	×	BI	iild <u>/</u> E	Errors	sλW	arning	IS Y	Infos	λPL	0 Err	ors ).	Print	/											
For Help, press F1																							24,4	) D: >2GB

13. Click "MODBUSTCP" item and then click "Add" button.

river Name	Driver Name	Board ID	1/0 Group Name	Task	Start Address	Size
- DI     - A3752FDI     - A3756FDI     - A3756FDI     - A07507/Uccal     - AD     - AD5017UH     - ADAM5013     - ADAM5017     - ADAM5018     - DI     - ADAM5051     - ADAM5052     ModBus Protocol	ADAM5051					2
MODBUSETU MODBUSTCP						•

14. Set Modbus Command: "1X", Slave ID: 1, Slave IF: "192.168.1.12", Data Type: "BOOL", Start Address: "1", No. of points: 12.

10 Group Name	I15MBU
Modbus Command	1X: Input status(FC:2)
Slave ID	1
Slave IF	192.168.1.12
Data Type	BOOL
Start Address	1
No. of Point:	12
Task	<default></default>
Variables Prefix	MBTR

15. Click "Create All Input Variables" then click "OK" button.

iver Name	Driver Name	Board ID	1/0 Group Name	Task	Start Address	Size
⊡ DI .	ADAM5051	0	1035D10	1	0	2
- A3752FDI	MBTCPDRV	0	115MB0		2	2
A3756FDI						
ADAM-5000/Local				1		-
ė- Al				1		-
- AD5017UH						
- ADAM5013				1		
- ADAM5017		2		1		
ADAM5018						
🖻 DI						
- ADAM5051						-
ADAM5052						
ModBus Protocol				-		-
MODBUSRTU				1		
MODBUSTCP						
- Other		- î	1	-		
	Add	Insert	Remove Co	onfig 【	Create All Input Vari	ables

16. Click "Contact Network" button.

🙆 MULTIPROG - Test - [main:main]																									_ 8 ×
Eile Edit View Project Build Objects	Layou	it O <u>r</u>	line E	xtras	Wind	low <u>2</u>																			_ 8 ×
0 📽 🖬 🖪 🚭 🕺 🖻 🛍 의	24	۲	Q			. 😨	<b>I B</b>	1 16		9	<b>**</b>	×	-			-	14		ž						
1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	(11)	1	-	F	<u>به</u>	• m	1	6	H (M	HI-O	n-r T	<u>ل</u> ت ب	L H+++		CH-D	내라									
	!	3.50	- 044 - 044 - 044 - 044	, LUI	10000		Sulfasses.	1.00	-					111200		1 201									1
Project			2			2	2	- 22		2	22			*	22			2	22		15	2	27		. 🔺
AdvMotion_A1		8	2			8	2	22		2	29	-	15.	*	29		1	\$	22		12	2	22	at a	
		3	2	2		2	2	2	1	2	20	10	15.	25	20	1	12	2	22	1	1	13	22	1	
E Logical POUs		3	2	2		0016	DAMS	051	R* 60		156 P	*	1.0	25	22	1	1	2	22	1	12	2	22	1	
i⊟ i main i mainT			2		s (t		- I	I-	p AL	-C	>	-	18	25	27	22	12	12	27	22	13	13	27	22	2
→ main			2		9 - 9	. Ante	2	32	10	2	29	22	8	12	27	12	12	25	$\mathbb{N}^{2}$	22	12	13	27	22	
Physical Hardware			2		9 - 9 <u>1</u>	81	2	39	10	2	27	12	12	12	27	12	12	12	22	22	12	13	27	22	
E - Configuration : IPC_32 È - Securce : ADV_CE <sup>×</sup>			2			, 8	2	32	10	12	27	22	12	12	27	12	12	12	22	12	12	15	29	22	
E- Tasks			12		1		2	20		2	27	12	1	12	27	1	12	25	27	12	12	15	27	10	12
					21 - 55 26 - 62	20 20		20 20	10 10		27 53	12			27 55	22 23	12		27 55	22 55	38. 32		27 55	22 22	
Global_Variables*					a 14	84	2	- 20	11		- 25			3	38	55		3	20	55	12		20	-	
			23		8 44	52	2	33	64	2	28	14	24	12	35	54	24	12	35	54	12	12	22	54	12
		32	2	į	8 14	52	2	33	14	12	28	25	14	12	20	55	12	12	20	55.	12	12	22	54 1	12
			2		8 8	37	2	20	8	2	55	-	24	12	30	-54	37	12	30	55	14	12	20	54	14
			2		8 - 84	57	2	10	8	12	28	25	14	12	20	-	14	12	22	-	12	12	22	-	14
			2		8 8	8	2	20	8	2	35	15	14	1	30	54	14	3	30	54	14	12	20	54	- S
		La Ú											1												الحج
	.	- -	mainum	nin	_			_			_														<u> </u>
			martin	ari	]			_			_														
Xi a Variable / POU/Worksheet		X	Б	uild	<u>√ Err</u>	ors à l	/Varnir	nas )	\ Infos	λPL	CErr	ors )	Print	1											
For Help, press F1	-0.18																							17,	4 D: >2GB

17. Double-click "C002".



18. Click "Gloabal scope" folder.

Contact Comm	on Local scope Global scope
Name:	0002
	ADAM5051_B00C000_I ADAM5056_B01C000_0
Scope:	⊡ Local     ○ Global
Description:	<< Undefined >>
Contact/Coil	Туре:

19. Select "In\_MBTCPDRV\_0\_1" and then click "Apply".



20. Click "Contact" folder.

Contact/Coil Pro	perties		×
Contact Commo	on Local scope	e   Global scope	
Name:	C002		
Usage:	VAR	<b>•</b> [	RETAIN
Data Type:	BOOL		•
Initial value:			
1/0 address:			
Description:	-		
	F PDD	C OPC	31
ОК	Cancel	Apply	Help

Chapter 4 Modbus Functions

21. Select "MBTR\_1X0001\_BOOL\_00" and then click "Apply".

Contact Commo	on   Local scope   Global scope
Name:	MBTR_1X0001_BOOL_00
	ADAM5056_B01C014_0 ADAM5056_B01C015_0
	MBTR 1X0001_BOOL_00
	MBTR_1X0002_600L_00
	MBTR_1×0004_BOOL_00
Scope:	🔿 Local 📀 Global
Description:	ModBusTCP IP: "192.168.1.12" Register Address 1X0001
Contact/Coil- C Contact	Туре:

22. Check the setting is correct and then click "OK".

Maara	
Name:	
	MBTB 1X0002_600L_00
	MBTB 1×0004 BOOL 00
	MBTR_1X0005_BOOL_00
	MBTR_1X0006_BOOL_00
Scope:	🔿 Local 💿 Global
Description:	ModBusTCP IP: "192.168.1.12"
- Contact/Coil-	
Contact	-
C. Coil	Type: [-1]-

23. Double-click "C003".



24. Select "ADAM5056\_B01C001\_0" and then click "Apply".

annaar 1 aanna	
Name:	ADAM5056_B01C001_0
	ADAM5051_B00C014_I
	ADAM5051_B00C015_I
	ADAM5056_B01C001_0
	ADAM5056_001C002_0 ADAM5056_001C003_0
Scope:	🔿 Local 📀 Global
Description:	[Slot1]ADAM5056 Digital Output 1
Contact/Coil C Contact C Coil	Туре: [-[-]-

Chapter 4 Modbus Functions

25. Check the setting is correct and then click "OK".

Name:	ADAM5056_801C001_0
	ADAM5056_B01C001_0 ADAM5056_B01C002_0 ADAM5056_B01C003_0 ADAM5056_B01C004_0 ADAM5056_B01C005_0 ADAM5056_B01C006_0
Scope:	C Local 📀 Global
Description:	[Slot1]ADAM5056 Digital Output 1
<ul> <li>Contact/Coil</li> <li>Contact</li> <li>Coil</li> </ul>	, Туре: <mark>-{ }</mark>

26. Click "Make" button to make the execution file.

Chautopor Tet Lettering																									a la
File Edit View Project Build Objects Lav	wout	Online	e Extr	ras M	mdow	7	_			_				_											_ 8 ×
	×   6	<u>م</u>			14 de	5 12		1	1		144	×.	<b>ch</b> 1	m		-	44		7						
		3.8						Land Land	 			er da	Luc		(tH)	Jol	THE S	, para	-						
	1	E) 'W		] <b>*</b>		-	P .	Tiered				H -11.	1.44			1Å1									
E-S Project	IΓ																								_
E 🔄 Libraries		ж			-		×.		10 	28				- 25			~	8				28		22 	
AdvToolPack		285 24			9 1 1					- 22									- CC - 60						
Data Types     Grant Logical POUs		20 20				т. Алган	den en e	ar Annan							20				20				20		
🖻 🔲 main*			2		. 00	1ADA	M505	1_B*	AD/	AM50	56_E	*											22		
			2		. 1		2	10	a.	12	27		1.1	*	8			2	10		12	2	20		
		2	23	~	a .	2	z	20	15	22	27	10	10	23	59	10	12	23	20	85	10.	23	20		
E- Configuration : IPC_32		82	21	22					INFO				18	25	27	12	22	2	22	105	22	23	28	S.	
Hesource : AUV_CE"		10	$\mathcal{D}_{i}$	$\simeq$	- H			000	AD)		) ) )		135	25	27	12	2	2	20	22	12	28	$\mathbb{R}^{2}$	22	2
E Task : CYCLIC		32	2	28	a .	2	22	50	10	25	27	10	25	25	57	22	32	25	27	82	12	25	27	22	2
		2	2	3	84 - S	2			82	12	50	12	2	14	20	84. -	1	2	20	52.	12	12	20	5% <u>.</u>	
Advantech_DAQ		8	1	1	64 - S	2	10	200 		4	22	124	14	10	18	-	24	4	10	24	14	12	28	84 -	
		×.	21	20	44 1	÷	1	.83	32	12	20	0%. 	1	12	28	24	14	1	50	<i>5</i> 2	14	12	28	84. 	·
			25	- 20	24 - 3 	2	28	200	82 	12	20	84 		- 2	28	- SA 	- 25		- 20	-	- 22	12	8	84 	
		99 - 10	-	10	84 - 3 	2		200 - 1 100		4	20	- 14	- 24	-	- 20		14		- 20		14	-	28		
		24 22	-	20	an 1	e v	-	200 224					-					-			194 192	-			
				-							-						-	- *							
		•[																							
		ן ma	iin:mair	ſ																					
X Variable / POU/Worksheet	×																			_			_		
	Ť																								
		4	Bui	Id / E	rrors )	VVa	arnings	sλlr	nfos )	PLC	Ern	ors )	Print	1											
Object settings	all sets		a. 20						-					22										61.50	DI N2CR

27. Check compile result is correct.



28. Click "Project Control Dialog" and then click "Stop" and "Reset".



29. Click "Download" button. Check the "Include Bootproject" item and then click "Download" button to proceed with the download process.

MULTIPROG - Test - [main	n:main]																_ # ×
Contract in the second	Bound Opjects Fay	vout Unine Extras			11.45	10 1085	× 1.	•	111.0			- kers	-				크믹스
<u>በ ଜେଲା</u> ରୁ କୋଳ ମାନ ଲୋଲା ରୁ ଅଲେ	wnload		∃ ~   <b>®</b> "	3 5 6						-131-		Be (XXV					
	Project		Bootpr	oject						1 197							1
E-G Project	Do	wnload	]	D	ownicad		1						50 D.S	12		20 10	. 4
AdvMotior	Include Bootpr	roject		,	Activate				1	12	10.	12	10 10	12	18	32 - 52	
🙀 Advi oolPa	Include Source Include OPC d	es lata		Dala	e on Law	un)			8 - 8	12	12	25	N - 12	12	25	N = 0	
🖻 🔄 Logical POUs	Downlo	pad Source		Dele	eoniai	ler			8 20	12	12	25	N - 12	12	25	N=0!	
- i mainT	Include User-L	.ibraries	-						8 - 30	102	25	12	20 10	15	20	32 - 32	*
- D main	Include Pagela	ayouts md-Code						2	8 80	12	12	12	10 V.	12	25	NI 18	
🖻 📸 Physical Hardv 🖻 🍘 Configurati		urce on Target		Do	vnload Fi	e	Î.					*			2		
E Besou		in the second second	J			-							50 - 50 50 - 50	12		N 10	
0 e		Close	н	elp					1	12	12	2	82 - 182 182	12	25	N 18	
Global	Variables							2	3 32	54.	12	1	98 - SS	22	12	90 - M	
Advant	tech_DAQ	- + ·	N 12	20 - 20 	24		54 	14 I I	2 10 	- 64	24	10	10 A	14	192 	20 04	N
	- 11				194		84 - 12		 	- 104 - 105		12		24 12		20 04. 10 02	
	- 11																
	- 11	10 IN 10	N 82	20 - 20	24	11 IN	15	12		15.	22	12	Rest	ource Printf	In		<u>×</u>
	- 11		N 8	31 33	32		65. 1	12 I	. 10	14	12	13		Stop		Cold	
		lat												Reset		Warm	리고민
0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0			) mainV ma	ain									-			Hot	
				<u> </u>										ownload	$\supset$	Upload	
Yariable / PC	OU/Worksheet	Creati Proces	ng data t sing code	emplates										Error		Info	
		Proces	sing data											Close		Help	
		Creati	ng task 1. ng initia	lization	code .												
		✓ 0 Error(s	), O Warn	ing(s)													-
Eor Halo, press E1	Þ	Build	Errors X M	/arnings }	Infos $\lambda$	PLC Erro	ors } F	Print /								51	50 Dr >268

30. Execution file is downloading.

(MULTIPROG - Test - [main:main]																								_ 8 ×
Eile Edit View Project Build Objects L	ayout	Online	Extra	is <u>W</u> ini	dow 2																			_ 8 ×
D ≠ B   B ⊕   X № B   ⊆	2	ÐQ			( (a)		1 (P)	112	9 12	(**)	*	0	T			HA		i.						
nmmm  Q  - ++===	(11)	1 de				10		ol are	+0	n-n T		- Here		dHD	-181-									
		1 (TR)		]] ~		14	l]]t.	3			a. 28				1.02									
E- Project												1.4												. =
Libraries				200 - 200 200 - 200					*							-						20		
- 🚇 AdvToolPack			2			2		a.	*	22		12		2			28	20			*	10	2	
E Gal Appendix		8	2	8 - 8	0010			* 05					15	27	at the	1	25	20	a.		25	10	2	
⊡ main ⊡ [] mainT		8	20	8 - 8	UUIA			~ AL	C	)		18	28	22	82	15.	28	20	12	12	28	20	12	
mainV			2	$\omega = \omega$	1.00	2	52	1	15	22	12	18	25		12	12	28	22	2	2	25	22	2	2
E B Physical Hardware		8	20	8 8	20	2	20	1	23	20	12	1	22	20	15	15	22	20	15	2	22	10	1	2
🖻 🚔 Configuration : IPC_32		8	22	8 - 8	002M	BTR_1	LXOOO	* AE	AM50	056_8	*	18	20	27	12	10	22	20	105	12	22	20	12	3
E Tasks		8	22	8 - S	-	-	-		-(	<u> </u>		22	25	27	15	15	12	27	25	2	25	27	2	3
- O Task: LYLLIL main: main		81 22	22	10 10 20 40		22	22 22	95 22	20	20 10	100		- 58 58	27	35 65	88. 192	28 18	20	35 55	12	22 13	20 <sup>7</sup> 55	22 23	
Global_Variables		* 87.75	Ĺ.	10 10 10 10									12		12		18				13	10		
		8	Ţ.	a a	8		24	4	12	- 20	-	14	12	- 22	-	14	12	10	54		10	10	-	
1 1		8	25	10 82	~	21	33	21	12	35	12	12	12	35	12	12	12	30.	12	12	12	36	85.	
1 1		8	20	2 3	84	8	22	8	12	20	52	24	12	32	52	12	12			and the				al-
1 1		8	20	20 - A	82	8	22	8	12	20	25	24	12	30	65	14	52		State:	E	ownlo	ad		<u>ч</u> .
1 1		8	20	3 - S	$\approx$	35	28	2	12	35	<i>5</i> 2	12	12	35	15	12	12		9	itop		Colo	i i	ſ.
		ď										1						- 1	R	eset		Wan	n	나는
		mai	main	1	main\∕∵m	ain												_				Ho		F
		- Titali	iandin	<u>_</u>	1141111.111													_	Dov	vnload		Uploa	ad	
Variable / POU/Worksheet			Crea	ting	data t g code	empl	ates	••••											E	rron		Info	(	
			Proc	essin	g data	·												1	Ċ	lose		Help		
			Crea	ting	task i initis	info liza	tion	ende																
		<b>V</b> 0 1	Error	(s),	0 Warr	ning(:	в)																	-
			Build	Err	ors ) V	Varnir	igs )	Infos	λPL	C Erro	ors )	Print	1											
Downloading project										39 5	%													

31. Click "Cold" to run the project.



32. Check the status of ADAM-6050 DI bit 0 and ADAM-5056D DO bit 1 are OFF.



33. Turn on ADAM-6050 DI bit 0 and check the status of ADAM-5056D DO bit 1 is turned ON correctly.

🙀 MULTIPROG - Test - [main:main - Configura	n.Resource.Task.main.main]	_ <del>_</del>
Eile Edit View Project Build Objects Lay	Online Extras Window ?	X
000.000	@ @ [⊑ ⊑ Ҳ @ 등 ⊟ 🚳 🖉 🖄 🖽 🛣 🚺 🔍 • ■   А हा छ	ž
Ĵoððð    Q k -  m=~		
Project Chranes Chr		
Variable / POU/Worksheet	<pre>Maintain maint/main Creating data templates Processing code Processing data Creating initialization code Creating initialization code O Error(s), 0 Warning(s) I h Build / Errors &gt; Warning &gt; Infos &gt; PLC Errors &gt; Print /</pre>	State: Run Stop Cold Peset: Warm Hot Download Uploed Error Info
Par Male Inverse Et		50 52 Di >2CB

34. Save the project properly.

ale Edit View Project Build Objects Lavout	Online	Extra	- w	ndow	2																		1
D New Project Ctrl+N				1100	1 0 🗔	. 🔜 I	6	1	2 🖱	Ľ	۵	1		-	4		į						
gpen Project / Unzip Project Ctrl+O     Save Project <u>As</u> / Zip Project As     Close Project     Delete Project	-8	*	<b>*</b>		¢	Þ.	Hed	8-11- 11-(	n-n-	th th	l þe	-11	¢	181-									
Save As Template Delete Template		12 12	92 19	a a	it it	12 12					12	常志	10 10	10	25 25	** **	10 10	2		28 28	10 10	22 22	12
Export Import		22 22	90 - 1 90 - 1			M505:	1 B*	ADAM	5056	В*	e N	2 2	10 10	2	2	20 20	10 10	10	2 2	2 2	10 10	87 10	2
Enter password		10 10	80 70	Î		-1 1		1 2	0			力	10 10	2	2. 2.	*	10 10	2	2 2	*	10 10		2
Save All		10 20	5 5		12MPT	R 110	100*	anaM	5056	B*		2) 2)	10 20	2	2	25 25	10 10	2 2	2	*	10 10	2 2	2
- Ctrl+P		20 20 30		Ĩ	,			MDAM	0	р		大	10 10 10	2 2 2	1	2 25 25	10 10 10	1 1 1 1 1		21 22 13	20 20 20		2
Print Setyp Print Project	-	┢			а 81 82	24 25				4	1	12	8	5	1	3	2	5	14	3	10	24 25	1
2 Demo.MWT			3	2	8	1	20 A			-	2	12	2		1	*	2	1	1	3	20	2	1
Exit		99 79	3	14 12	99 92	91 21	20 8 20 8	1 1		24 25	14	1	10 20	24 25	1	4	10 20	24 25	14	4	98 38	24 25	2
		76 76	2		N N	76 78			1		1	v V	r V	4	4	7	10 10	4	4	4	in V	4	
	<b>)</b> mair	cmain		main	V:main	J																	_
Variable A POU/Worksheet A	↓ ✓0 I	Crea Proc Proc Crea Crea	ating cessi cessi ating ating c(s),	dat ng c ng d tas ini 0 W	a ten ode . ata . k inf tiali arnir	nplat  fo izati ng(s)	es on co	de															
		Buil	dE	rrors	λWa	rnings	i λ Inf	os } F	PLC E	rors )	Print	t/											

# 4.3 Modbus/RTU Master Function

The Modbus/RTU master function is supported by COM1/COM2/COM4 RS-485 Ports of ADAM-5560 Series Controller. There are typical 128 I/O modules can be connected to each COM port. So far, there are 12 modules of ADAM-4000 Series support modbus protocol as following list. (Please refer to ADAM-4000 User's Manual for latest support list.)

Module Name	Description
ADAM-4015	6-channel RTD Input Module
ADAM-4015T	6-channel Thermistor Input Module
ADAM-4017+	8-channel Analog Input Module
ADAM-4018+	8-channel Thermocouple Input Module
ADAM-4022T	Dual-loop PID Controller
ADAM-4024	4-channel Analog Output Module

Module Name	Description
ADAM-4051	16-channel Isolated Digital Input Module
ADAM-4055	16-channel Isolated Digital Input/Output Module
ADAM-4056S	12-channel Sink Type Isolated Digital Output Module
ADAM-4056SO	12-channel Source Type Isolated Digital Output Module
ADAM-4068	8-channel Relay Output Module
ADAM-4069	8-channel Power Relay Output Module

## 4.3.1 Modbus/RTU Master Function Example

ADAM-4018+ settings: ID address: 01 Typr K thermocouple applied to CH0 (0~1370°C)

ADAM-6050 settings: (for following previous example) IP address: 192.168.1.12

ADAM-5560 Series Controller settings: Slot 0: ADAM-5051D Slot 1: ADAM-5056D IP address: 192.168.1.5

### System Wiring:



### COM4 Jumper Settings:



COM4 Setting	CN14	CN15	CN16
RS-232 (Default)	(1-2)	(1-2)	(1-2)
RS-485	(2-3)	(2-3)	(2-3)

COM4 RS-485 TR Setting	CN17
120 ohm	(1-2)
300 ohm	(2-3)

#### Note!

After changing the jumper settings, please reset the ADAM-5560 Series Controller.

RS-485 Port Pin Assignment:

Pin No.	Description
Pin 1	DATA-
Pin 2	No Connection
Pin 3	No Connection
Pin 4	DATA+
Pin 5	No Connection
Pin 6	No Connection
Pin 7	No Connection
Pin 8	No Connection
Pin 9	No Connection



1. **[PAC Device]** Run ADAM.NET utility by clicking "Start" -> "Programs" -> "Advantech" -> AdamNET Utility.



2. [PAC Device] Select "ADAM4000\_5000" item.

Advantech Adam.NET U	Itility (WinCE) Version 1.00.08		
File Tools Setup Hel	P 😥 🖃 🔍 🍠 📽 🕨		
⊕			
E-Steven Even System	Support ADAM Module		
	ADAM-4000 Series	ADAM-5000/485 Series (Modbus)	
	ADAM-4011 ADAM-4011D ADAM-4012 ADAM-4013 ADAM-4015 ADAM-4015 ADAM-4016 ADAM-4017 ADAM-4017 ADAM-4017 ADAM-4018 ADAM-4018 ADAM-4018 ADAM-4019	ADAM-5013 ADAM-5017 ADAM-5017 ADAM-5018 ADAM-5024 ADAM-5050 ADAM-5051 ADAM-5055 ADAM-5056 ADAM-5066 ADAM-5068 ADAM-5068	
< >			
It is ready!			
Start ProConOS WinCE	Advantech Adam.N	NET 🕅 🛃 🕹 🕹 12:23 AM	<b>B</b>

3. [PAC Device] Select "COM4" and then click "Search" button.

Advantech Adam.NET U	tility (WinCE) Ve	rsion 1.00.08		E 🗐
File Tools Setup Help		Pê 🕨		
COM2	Port:	COM4		
	Baudrate:	9600		
@ ADAM5000TCP_600     Gocal system	Parity:	None		
🗄 📓 Favorites group	Databits:	8		
	Stopbits:	1		
	Timeout:	500 🔹 ms	Default	
	Scan interval:	500 🛉 ms	Apply	
< >				
It is ready!				
Start ProConOS WinCE	Ac	wantech Adam.NET		🗄 🕹 🏨 🕲 СН 🍠 12:51 АМ 🛛 🎯 🏸

4. *[PAC Device]* Click "Start" button and "4018P" will be shown.

Advantech Adam.NET U	Itility (WinCE) Version 1.00.08	×
File Tools Setup Help	2 😥 🖃 🔍 🖋 📽 📂	
ADAM4000_5000     GOM1     COM2	Port: COM4	
	Baudrate: 9600	
4018P(01) 	Parity: None V	
Local system ⊡_∯ Favorites group	Databits: 8	
	Starting address: 0 Start Tim Scancel	
	Sca 2 (DEC)	
It is ready!		
Chart DraCanOC March	(iii) adumtaria televi MTTU (iii) and a con co. (iii) a A 🚥 A core au	
Start Proconus WINCE	Search module from CO   🔤 🕹 💥 🕲 🖽 🍠 12:52 AM	<u> </u>

5. **[PAC Device]** Click "4018P" to see the module setting.

Advantech Adam.NET U	tility (WinCE) Version	1.00.08		X
File Tools Setup Help	) 😥 🗔 🔍 🖉 📽 🕨			
ADAM4000_5000	ADAM-4018+			
	Module setting Data	area		
	Address:	01 Hex 1 + Dec	Apply change	
€ CADAMSOOOTCP_600	Baudrate:	9600 bps		
- 🥪 Local system ∙ 🛃 Favorites group	Checksum:	Enabled		
	Firmware version:	A2.05 F/W Update		
	Integration time:	50/60 50/60Hz		
	Comm. WDT:	0 Sec (0.0~999.9)		
	Protocol:	Advantech		
	Data format:	Engineering Unit		
	47			
<				
ADAM-4018+:GetModuleCC	MConfig() failed;GetMo	duleCOMConfig() failed;		
Start ProConOS WinCE	Advante	ech Adam.NET	🎯 🕹 🌲 🚷 CH 🍠 12:54 AM [ 🚱	1

6. **[PAC Device]** Click "Data area" to check the reading of Channel 0 is correct. This channel will be used by following demonstration.

Advantech Adam.NET Ut	tility (WinCE) Version 1.00.08				
File Tools Setup Help					
P 2 ADAM4000_5000	ADAM-4018+				
	Module setting Data area				
COM4	Channel: Input range:	Zero calibration			
ADAM5000TCP_600     Local system	0 🔍 Т/С Турек 0~1370 'С 🔍 Арріу	Span calibration			
	All follow CHD	CJC calibration			
	Channel setting				
<	Channel         Value         Intput Range           ✓ 0         21.6 'C         T/C TypeK 0~1370 'C           ✓ 1         Burn         T/C TypeK 0~1370 'C           ✓ 2         Burn         T/C TypeK 0~1370 'C           ✓ 3         Burn         T/C TypeK 0~1370 'C           ✓ 4         Burn         T/C TypeK 0~1370 'C           ✓ 5         Burn         T/C TypeK 0~1370 'C           ✓ 6         Burn         T/C TypeK 0~1370 'C           ✓ 7         Burn         T/C TypeK 0~1370 'C	Apply change Enable all chann WaveScan			
Polling (Interval=500ms): 2	21 times				
Start ProConOS WinCE	👹 Advantech Adam.NET	🎯 🕹 🏨 🊷 대 🍠 12:57 AM 🛛 🚱 🏸			

7. **[PAC Device]** Select "COM4" and then click "Adam Commander" button.

Advantech Adam.NET U	tility (WinCE) Ve	rsion 1.00.08			
File Tools Setup Help		18 <b>&gt;</b>			
COM1	Port:	COM4			
	Baudrate:	9600 💌			
2 4018P(01) ⊕ @ ADAM5000TCP_600	Parity:	None 💌			
	Databits:	8			
	Stopbits:	1			
	Timeout:	500 🔹 ms	Default		
	Scan interval:	500 <b>*</b> ms	Apply		
<					
It is ready!					
Start ProConOS WinCE	Ac	Ivantech Adam.NET		🚉 🕹 🤹 🕲 СН 🍠 12:59 /	M 🞯 🗭

8. **[PAC Device]** Input "#010" and click "Send". Check the response of the CH0 reading is correct.

Advantech A	dam.NET Utility (	WinCE) Version 1.00.08	
File Tools	Setup Help 😥		
	Adam Commande		
	Port:	COM4	
	Baudrate:	Baud_9600 Databits: Eight Timeout: 500 ms	
⊕ @ ADAM5 -@ Local s	Parity:	None Stopbits: One Scan interval: 500 ms	
🕀 🥵 Favorit	[		
	Advantech ASCII	MODBUS	
	Command:	#010 Checksum	
	Response:	>+0026.3 Continuously	
	History:	#010 01:01:07:330 Send	
		>+0026.3 01:01:07:380	
<	>		
It is ready!			
Start ProC	opOS WinCE	🖓 Advantech Adam NET II. 🥰 Adam Commander 👘 👌 👻 🕸 🏧 😤 1:00 Ab	a 🔞 🖬
- Juan Proc			

9. **[PAC Device]** Set the ADAM-4018+ to initial mode by changing the switch position to "Init" side and then resetting the module. The switch is at the left side of the module. After that, select "COM4" and then click "Search" button again.

Advantech Adam.NET U	tility (WinCE) V	ersion 1.00.08			
File Tools Setup Help					
ADAM4000_5000     GOM1     COM2	Port:	COM4			
	Baudrate:	9600			
ADAM5000TCP_600     Gocal system	Parity:	None			
⊕ ▲ Favorites group	Databits:	8			
	Stopbits:	1			
	Timeout:	500 <b>*</b> ms	Default		
	Scan interval:	500 <b>*</b> ms	Apply		
< >					
It is ready!				-	
Start ProConOS WinCE	( <b>3</b>	Advantech Adam.NET U		🚊 🕹 🌉 🚷 СН 🎘 1:42 /	XM 🚱 🗭

10. **[PAC Device]** Click "Start" and "4018(\*)" will be shown. "\*" represents the module is at initial mode.

Advantech Adam.NET Utility (WinC	E) Version 1.00.08
File Tools Setup Help 😥 🔙 🔍	8 °g >
ADAM4000_5000     OM1     Port:     OM2	COM4
COM3 Baudrate:	9600
	None
Elecal system Databits: □ Databits:	8
Sto <mark>Searc</mark>	h madule from COM4
Tim	ng address:
Scan Sca	hing address: 04 (HEX) Cancer
	5 (000)
< >	
It is ready!	
Start ProConOS WinCE	🚰 Advantech Adam.NET U 🕕 Search module from COM4 📴 🕹 🔌 🕲 党 1:24 AM 🔞 🏸

11. **[PAC Device]** Select "4018P(\*)" and then change the Protocol setting to "Modbus".

Advantech Adam.NET U	ility (WinCE) Version	1.00.08	
File Tools Setup Help	D 🗔 🔍 🖉 📽 🕨		
File     Tools     Setup     Help       Image: ADAM4000_5000     Image: ADAM4000_5000     Image: ADAM4000_5000       Image: ADAM4000_5000     Image: ADAM4000_5000       Image: ADAM5000TCP_600       Image: ADAM5000       Imag	ADAM-4018+ Module setting Data a Address: Baudrate: Checksum: Firmware version: Integration time: Comm. WDT:	area *01 Hex 1 + Dec 9600 bps Enabled A2.05 F/W Update 50/60 50/60Hz Sec (0.0-999.9)	Apply change
ADAM-4018+:GetModuleCO	Protocol: Data format: (	Modbus	
Start ProConOS WinCE	Advante	ch Adam.NET U	🕅 🕹 🗶 🔕 🗂 🐡 1:48 AM 🔞 🔽

12. [PAC Device] Click "OK" to change the setting.



13. **[PAC Device]** Select "Data area" and check the CH0 reading. Click "WaveScan" to see the wavescan window.

ile Tools Setup Help	i 🖉 🔜 🖉 📽		
ADAM4000_5000	ADAM-4018+		
COM1		ta area	
	Would setting		
E-40 COM4	Channel: Inpu	trange:	Zero calibration
ADAM5000TCP_600 Local system	0 💌 T/C	TypeK 0~1370 'C 🔽 Apply	Span calibration
Favorites group		All follow C	CJC calibration
	Channel setting		
	Channel Valu	e Intput Range	
	0 26.9	C T/C TypeK 0~1370 'C	Apply change
	✓1 Burr	T/C TypeK 0~1370 'C	Apply change
	III2 Burr	n T/C TypeK 0~1370 'C	Enable all chann
	III III 3 Burr	n T/C TypeK 0~1370 'C	
	III III 4 Burr	n T/C TypeK 0~1370 'C	
	III III 5 Burr	n T/C TypeK 0~1370 'C	100 million (1997)
	III 6 Burr	n T/C TypeK 0~1370 'C	
	III 7 Burr	n T/C TypeK 0~1370 'C	WaveScan
>			
ling (Interval=500ms); 1	15 times		

14. [PAC Device] Check CH0 reading and then close the window.

Advante	ech Adam.NET U	Utility (WinC	E) Version 1.00.	08				
File To	ools Setup Helj	p 🥟 🖪 🍳	8 °8 🕨					
	DAM4000_5000	ADAM-4018	+					
	COM1	[	U Data area 1					
	Adam.NET W	/aveScan fo	Adam4018P					
	c1370.00	ی ی ی و و ی و ی و و و و و و و و				1370.00	Channel	
I.	🧕 🔛	C Trial					Ch0	
🕀 🥷 AD							ch1	
	ca						C ch2	
🖽 🖓 Fa	100							
	685.00					685.00		
							Cn4	
							ch5	
							Ch6	
							ch7	
	0.00					0.00		
	ch0:'C 💌 🛸					9.00 ch0:'C 💌		
	27.200 <				> 90	27,200	BufferSize	
			1				30000 -	
	History	Clear Histo	ry Clear Graph	StepSize: 1	¥.		PollingTime	
		Recidual C	anacity is 1 79 5	Mb/free) / 122.0	Mb(total)		100 +	
	Save Histo	ry Current Ei	apacity is . 76.5	140(1166) / 122.5	mb(wai)			
	Save to file		e Length O Bytes			Stop	Apply	
	Save to file							
<	>							
Polling (I	nterval=100ms):	8736 times						
ಶ Start	ProConOS WinCE		🚰 Advantech Ada	am.NET U 🔽 /	dam.NET WaveS	can fo 🔯 🕹 🗳	🖌 🛞 СН 🍠 3:06 АМ	и 🔞 🗭

15. **[PAC Device]** Set the ADAM-4018+ to normal mode by changing the switch position to "Normal" side and then resetting the module. After that, select "COM4" and then click "Search" and "Start" buttons.

Advantech Adam.NET U	tility (WINCE) Version 1.00.08
File Tools Setup Help	
ADAM4000_5000     ADAM4000      ADAM4000	Port: COM4
	Baudrate: 9600
4018P(01)     € @ ADAM5000TCP_600	Parity: None ⊻
Qo Local system ⊡ A Favorites group	Databits: 8
	Sto Search module from COM4
	Starting address: 0 Start
	Scanning address: 09 (HEX) Cancel
	9 (DEC)
<	
It is ready!	
🐉 Start ProConOS WinCE	👹 Advantech Adam.NET U 🜉 Search module from COM4 🔯 🕹 🏨 🛞 🖽 🍠 3:08 AM 🛛 😥 🏸

16. **[PAC Device]** Click "4018P(01)" to see the module setting.

Advantech Adam NET Utility	y (WinCE) Version 1.00.08	
File Tools Setup Help 😥		
ADAM4000_5000 ADA COM1 MC	AM-4018P (MODBUS)	
	Address: 01 Hex 1 Dec	
	Firmware version: A2.05	
ADAM-4018P:		

17. [PAC Device] Select "Data area" folder and check CH0 reading.

Advantech Adam.NET U	tility (WinCE) Version 1.00.	08	
File Tools Setup Help	0 😥 🗔 🔍 🍠 📽 🕨		
P 2 ADAM4000_5000	ADAM-4018P (MODBUS)		
	Module setting Data area		
COM3	Channel: Input range:		
⊕	0 V T/C TypeK 0-	-1370 'C 🗸 🖌 Apply	
E Cocal system			
		All follow CHD	
	Channel setting Modbus		
	Channel Value	Intput Range	
	Ø 25.5 ℃	T/C TypeK 0~1370 'C	Apply change
	I Burn	T/C TypeK 0~1370 'C	
	I I I I I I I I I I I I I I I I I I I	T/C TypeK 0~1370 'C	Enable all chann
	I 4 Burn	T/C TypeK 0~1370 'C	
	III III 5 Burn	T/C TypeK 0~1370 'C	
	I I I I I I I I I I I I I I I I I I I	T/C TypeK 0~1370 'C	WaveScan
	1		-
< >			
Polling (Interval=500ms): 2	24 times		
Start ProConOS WinCE	Advantech Ada	am.NET U	🎯 🕹 🙏 🆓 🖽 🎘 4:28 AM 🛛 🚱 死

18. [PAC Device] Select "COM4" and then click "Adam Commander".

Advantech Adam.NET U	tility (WinCE) Ve	rsion 1.00.08			
File Tools Setup Help		P8 ᠵ			
COM1	Port:	COM4			
	Baudrate:	9600 💌			
4018P(01) ⊕ @ ADAM5000TCP_600	Parity:	None			
- Stewart - Ste	Databits:	8			
	Stopbits:	1			
	Timeout:	500 <b>*</b> ms	Default		
	Scan interval:	500 <b>*</b> ms	Apply		
< >					
(t is ready!					
Start ProConOS WinCE	<b>S</b> A	dvantech Adam.NET U.		📴 🕹 🏨 🚷 🖽 🍠 3:21 Al	и 🕑 🗭

19. [PAC Device] Change to "MODBUS" folder.

Advantech Ad	dam.NET Utility (W	inCE) Version 1.00.08	
File Tools	Setup Help 😥 🔚 Adam Commander		
	Port:	COM4	
	Baudrate:	3aud_9600 Databits: Eight Timeout: 500 ms	
⊕-@ ADAM5 ⊕-@ Local s ⊕-	Parity:	None Stopbits: One Scan interval: 500 ms	
	Advantech ASCII	MODBUS	
	Command:	Checksum	
	Response:	Continuously	
	History:	Send	
<	>		
Start ProC	onOS WinCE	🚰 Advantech Adam.NET U 隆 Adam Commander 🛛 👰 🕹 🤞 🖽 🍠 4:29 AM	<u></u>

20. **[PAC Device]** Check the reading of CH0. The formula is (1215\*1370) / 65536 = 25.4 °C.

Advantech Ada	am.NET Utility (	WinCE) Version 1	.00.08			
File Tools Se	etupHelp 😥	▋ୣୣୣ୵୲୶ୡ୲ୄୖ				
	dam Commander					
	Port:	COM4				
	Baudrate:	Baud_9600	Databits:	Eight Timeout:	500 ms	
⊕ @ ADAM5 ⊕ @ Local s	Parity:	None	Stopbits:	One Scan interval:	500 ms	
🕀 🔛 Favorit	· · · · · · · · · · · · · · · · · · ·					
	Advantech ASCII	MODBUS				
	Device ID:	1 *	Address 30001	Value 1215	Stop	
L I	MODBUS type:		30002	65535		
	04: Input regis	ter 💟	30004	65535		
	Address:	1 *	30005	65535		
	Length:	8 *	30007	65535		
	Number of poll	13				
	Valid response	13				
	No_Error					
<	>					
It is ready!						
🐉 Start ProCor	nOS WinCE	🚰 Advantech	n Adam.NET U	😢 Adam Commander	🎯 🕹 🏨 🔕 대 🍠 4:30 Al	м 🞯 🏴

21. Open the "Test.mwt" project and then double-click "main".

e Edit View Project Build Objects L	ayou	it O <u>n</u> l	ine E <u>s</u>	tras	Wind	<u>2</u> wc																			_ 6
3 8 8 6 X 6 8 9	<u>C</u>	Ð	0  [		1			1		8	-	×	🗢 (			-	H		į.						
1 😫 😫 🗍 🤉 🕼 🖛 🕬 🕮	1400)	1 1	•		÷.	•	<b>P</b>	HH-	area (	- neo	n⊣r tj	바따	Hŀ	-1	C0-01	- \$ -									
				-aliceres				dbic																	2
🔄 Libraries		83	22	23	25	8	21	22	105	25	$\mathbb{R}^{2}$	22	22	28	$\mathcal{D}$	12	12	23	$\mathbb{R}^{2}$	12	12	25	$\mathcal{D}$	32	2
- AdvMotion_A1		8	22	22	15	8	23	22	15	25	27	12	12	28	$\mathcal{W}$	12	12	22	$\mathcal{D}^{2}$	22	12	25	$\mathbb{R}^{2}$	32	2
- Data Types		10	$\mathcal{R}$	22	- 95	8	20	20	35	22	28	32	12	25	$2^{\circ}$	10	12	22	22	12	22	25	$\mathbb{R}^{2}$	32	8
- 🔄 Logical POUs		8	22	32	- 25	001AI	DAMS	151 B	* AD	AMSC	56 E	*	12	28	20	82	18	$\approx$	22	12	22	28	20	32	8
		2	20	20	- 15	F	-1	1-		-(	<u> </u>	-	10	20	27	85	15	2	22	10	2	28	27	15	8
mainV		2	20	20	-	1	20	20	15	2	28	20	12	20	27	85	15	2	28	10	1	18	27	15	8
Physical Hardware		8	20	23	-	8	2	20	15	12	10	25	22	*	10	10	8	12	22	10	8	28	10	10	8
Configuration : IPC_32		82	20	20	1	002M	BTR 1	xooo	* AD	AMSC	56 E	*	12	25	10	25	1	12	22	10	2	28	10	10	2
E Tasks		8	10	20	8	F	-	-		-(	<u> </u>	-	12	25	$\mathbb{N}$	25	1	12	$\mathbb{R}^{2}$	12	2	25	$\mathbb{N}$	10	3
E Task : CYCLIC		8	23	23	10	. And	12	55	10	念	${\mathbb N}^{2}$	2.1	12	25	$\mathcal{D}$	22	12	23	${\mathbb N}^{2}$	12	22	25	$\mathcal{D}$	12	2
Global_Variables		4	10	20	-84	34 1	1	10	84	12	28	53 <b>.</b>	14	12	10	<i>84</i>	14	14	28	1	14	12	10	12	24
Advantech_DAQ		4	10	24	-84	94 1	1	10	64	1	28	54	14	12	10	124	14	1	28	1	14	10	10	12	24
		34	10	14	-54	S4	1	10	64	1	22	54	14	12	10	54 -	14	1	28	14	14	W.	10	12	14
		4	10	1	84	84	1	10	4	14	10	52	14	10	10	54	14	14	20	24	14	10	10	64	24
		14	1	24	84	8	100	1	64	14	10	52.	14	10	10	53 <b>.</b>	14	14	20	S.	14	1	10	63 <b>.</b>	24
		8	1	2	8	~	1	2	81	3	20	55	1	1	20	<i>84</i> ,	12	2	30	S.	1	2	2	82. 1	14
		8	100	20	32	2	20	20	62	2	20	55 <b>.</b>	12	3	20	<i>54</i> .	14	3	35	S.	14	3	20	12.	24
		8	1	20	82	2	20	20	32	2	50	12	1	10	20	<i>88</i> ,	12	2	35	S.		10	20	112	14
		8	100	33	22	8	30	10	<i>82</i>	2	35	12	1	12	30	<i>8</i> 2.	12	1	35	<i>8</i> 2	1	12	30	82 <b>.</b>	12
		1																							•
🖻 🔟 🖩 💋		<b>.</b>	nain:ma	ain [																					
Variable / DOLI/Worksheet	- 1	×		_																					
	- 1	•																							

Chapter 4 Modbus Functions

22. Double-click "Advantech\_DAQ".



23. Select "MODBUSRTU" and then click "Add" button.

🖻 DI 🖉			n o aroup mano	Idsk	atan Address	JIZE
	ADAM5051	0	1035D10		0	2
- A3752FDI	MBTCPDRV	0	115MB0		2	2
A3756FDI						
ADAM-5000/Local				_		-
😑 Al		- 1				
- AD5017UH						
ADAM5013						1
- ADAM5017						
- ADAM5018						-
🖻 DI						
ADAM5051		_				-
ADAM5052						1
- ModBus Protocol						
Contracting on the Contraction of the Contraction o				1		
MODBUSRTU						
ADAM5052						

24. Set COM: "COM4", Modbus Command: "3X", Slave ID: 1, Start Address: "1", No. of points: 8, Data Type: "INT".

10 Group Name	1004MBRTU
СОМ	COM4
Modbus Command	3X: Read Input Register(FC:0x4)
Slave ID	1
Start Address	1
No. of Points	8
Data Type	INT
Task	(default)

25. Click "Create All Input Variables" and then click "OK".

river Name	Driver Name	Board ID	1/0 Group Name	Task	Start Address	Siz
E-CI	ADAM5051	0	1035D10		0	2
- A3752FDI	M3TCPDRV	0	115MB0		2	2
A3756FDI	M3RTUDRV	769	I004MBRTU		4	16
- ADAM-5000/Local		0.000-0800	Contrato del Societo del California		120	
 Δ						-
						-
AD3017011			-			-
ADAM5013						-
ADAME010						-
						-
						1
ADAM5051		4	2			-
ADAM5052						
- ModBus Protocol						
MODBUSRTU						
MODBUSTCP						-
∃ Othei		1		~ V	O	
EEMOIO	Add	Insert	Remove Co	ontig 🚺	Create All Input Vari	ables

Chapter 4 Modbus Functions

26. Click "Edit Wizard" to see the function blocks.

🙆 MULTIPROG - Test - [main:main]																							_ 8 ×
Eile Edit View Project Build Objects La	ayout Online	Extras	: <u>₩</u> ind	ow 2																			_ & ×
Project Tree Window	F2 Ctrl+F2			. 🔞 🛙	3 🔜	1			<b>**</b>	*	<b>\$</b> (		•		HA I		į						
Edit Wizard	Shift+F2		분비		<b>P</b>	HIO		<del>II-O</del> I	⊢⊦ Tj	р цр	.  +1+		C.	-lŝŀ-									
Cross References Window	Alt+F2					6727									Ň.								1
Projec Statch Window	Alt+F10	Į.,	a a	12	~	•2	a.		50				-		28		-				-	-	
Elitetus Bar	AIC+F11					10	8		0	33			8	8			8	37			0	33	
Dr      Open Variables Worksheets			s 0	15		16	1	8	0	33		2	0	33			8	38	10	2	۲	13	
E Sical POUs	TT -	! .		12		10.0				1		2	0	-			0	3	10	2	0	3	
i ⊡ main				001AD	AM50	51_B*	' AD/		56_8	*							0		10		(3)	12	
- iii mainV				1.			a						10								10		
- D main							a																
Physical Hardware     Configuration : IPC 32																						- 10	
E-M Resource : ADV_CE*				002ME		K000*	AD/	AMSO	56_B	*													
⊡  Tasks			S ()			-		- · ·		-	10	2	0	10	12	2	8	10	12	2	0	18	
		<u>e</u> l :	S ()	1997	21	16	1	2	8	8	10	22	0	38		2	8	38	12	20	۲	18	12
Global_Variables*	8	21	8 - 8	35	22	<u> </u>	10	15	27	12	12	12	20	12	12	10	37	100	18	18	20	12	1
Advantech_DAU	*	21	8 - 8		22	<u>89</u>	95	25	27	12	12	12	20	22	12	10	27	22	12	12	20	22	
	2	2	87 - 88	+	2	20	10	12	27	22	12	25	20	22	12	12	20	12	12	12	20	12	12
	*	2	87 - 98	80	21	<u>%</u> 2	95	25	$2^{\circ}$	22	12	25	20	22	12	25	22	22	12	25	27	12	12
	- X -	2 3	8 - 8	35	21	- 20	85	22	$\mathbb{R}^{2}$	12	12	12	20	12	12	20	$\mathcal{D}^{2}$	12	12	25	27	12	12
	*	2 3	8 - 8	10	22	*2	10	2	$\mathbb{R}^{2}$	12	12	12	20	12	12	22	22	12	12	12	20	12	12
	*		8 - 8	32	25	*22	15	2	22	12	12	12	20	12	12	22	22	12	12	12	20	12	
	2			32	22	-	15	2	22		12	22	20	12	12	22	22	12	12	22	27	12	
	*		82 88	22			1	2	22	22	12	2	27	22	12	-	22	22	12	-	20	12	
											-1												- <b>-</b>
			r																				
		main	J																				
Variable 🔶 POU/Worksheet	×																						
			2	155		12				- 2		18											
		Build	( Erro	irs X M	aming	as ∕ Ir	nfos j	V PLC	Erro	ors A	Print	/											
Shows or hides the Edit Wizard																						29,0	) D: >2GB

27. Find the "GT" Greater Than Function Block.



28. Add one "GT" function block.

🙆 MULTIPROG - Test - [main:main*]																						_ 8 >
Eile Edit View Project Build Objects L	ayout O <u>n</u> lin	e E <u>x</u> tra	s <u>W</u> indor	w Z																		_ 8 >
02803082	2 0 6	1 🗖		<b>(</b>	. 🖬 🔞			<b>#</b>	6	<b>\$</b> []				HA	. 1							
<b>*1 *1 *1 *1</b> *1    4 🕼 **    60 #*			*	<b></b>	£    +	eo) aear	ilico il	HE T₀J	T <sup>b</sup> T		-H		-1양 -									
		222			URACE.																	
E C Libraries	2	21	86 - 97	10	51 - 55	9	22	21	85	Ø	2	21	16		25	21	10	$\odot$	25	61	88	ି 🕇
AdvMotion_A1	- 20	21	85 - 18	25	81 - 38	0	12	21	88	Ċ	20	21	36	0	15	21	38	0	25		10	©
Data Types	2	21	98 - 18 19	20	81 - 83	8	10	21	-67	Ċ	10	21	-86	8	22	21	36	Ω.	10	21	10	8
E- Main	- 2	<u>e</u> 1	· · · ·		M5051_	B* AD	AM50	56_B*	1	Ť	15	21	38	Ċ	10	<u>0</u> 1	35	÷	10	61	1	8
mainT		<u>e</u> 1	86 - 89 - 188 - 188 - 188 - 188 - 188 - 188 - 188 - 188 - 188 - 188 - 188 - 188 - 188 - 188 - 188 - 188 - 188 -				- (.	)		Ċ	10		16	8	20	-	10	8	1	÷	1	8
1 main		-	16 G <b>1</b> 8	•	8 8	8	10	-	8. <b>*</b>	©	10		-65	Ċ	10	-	28	8	10	÷.	-81	
Physical Hardware     Dontinuration : IPC 32			10 07 		8 8 				10	8	10	-	10	8			10	8			10	8
E Resource : ADV_CE*				оогмвт	FR_1X00	D* AD	AM50	56_B*	5													
E Tasks				1.															- 22		~	
- 🗇 main : main			50 50 50 50 50 50 50 50 50 50 50 50 50 5			a			52	æ			-				-22	ä			52	
Advantech_DAQ						ä			-	æ			100				-	ä		8	52	
						10	10	61	10	æ	10		10		15		-		18		10	
· · · · · · · · · · · · · · · · · · ·		21	. 1	•	· -	1.	12	21	18	¢.	10	21	-26	æ	12	21	- 25	e	12	21	10	8
		21	. 1	•	10	1.	12	-	-	Ċ	15		16	ø	10	21	10	8	10		8	0
Group:						0.	10	-	:8	¢.			-	Ċ	12		18	e	12		-87	8
<favorites></favorites>			8 e	-		S.		-	•6	Ċ	8	2	18	Ċ	10		18	S.	10		16	0
Name Description	- 20	21	8 Ø	10	8 8		10		16	Ċ	10		15		10		18	÷	10		16	8
F_TRIG Falling Edge Detection	- 20	0	8 8	10	8 8	0	10	-	:8	0		2	10	Ø	10		18	0	10		16	· •
GEGreater Than Equal >=			1.0																			•
LE Less Than Equal: <=	🔁 ma	ain:main																				
🗶 🖕 Variable 🛛 🔺 🛛 POU/Worksheet									_		_		_			_	_	_			_	
	1																					
		Build	Frrom	s∖Wa	arnings )	Infos	λPLC	Error	sλ	Print /	(											
For Help, press F1																					20,76	D: >2G

29. Add one coil by clicking "Add Coil Right" button.



Chapter 4 Modbus Functions

30. Connect "C004" coil to "GT" output.

🙆 MULTIPROG - Test - [main:main*]			
Eile Edit View Project Build Objects Lay	O <u>n</u> line E <u>x</u> tras <u>W</u> indow <u>?</u>		X
0 🖉 🖬 🖪 🚳 👗 🖬 🛱 🗠 🤉		🕸 🖀 🛎   💠 🗊 📗 🔹     + 📰 🖾	
<u>]</u> ∩1018860 ]Q	·₩ = = = = = =  ++	╡╡	- ^^
	and drawn and the second se		=
E-🔄 Project			
AdvMotion_A1			
E Logical POUs	A to the standardshared	and the second	
E-D main	001ADAM5051_B*	ADAM5056_B*	
main/			
- 🕀 main			
E Besource : ADV_CE*	002MBTR_1X000*	ADAM5056_B*	
E asks			
i main : main			
Global_Variables*			
Advancu_DAd			
	GT	C004	
	· · · · · · · · · · · · · · · · · · ·	•••••••••••••••••••••••••••••••••••••••	
	a a a <mark>terra a</mark> a a		
Group:	<u></u>	<u></u>	
(Favorites)	a a a <sup>6</sup> 6 a a a a	<u> </u>	
FO Equal:=		2 1 1 1 1 1 1 1 1 1 1 1	
F_TRIG Falling Edge Detection			
GE Greater Than Equal: >=			
LE Less Than Equal: <=	main:main		
X Variable / POU/Worksheet	■ Build	os à PLC Errors à Print∫	
connect objects			71,41 D: >2GB

31. Double-click the first input of "GT" function block.



32. Select "Global scope" folder.

ariable Propert	ies
Variables Comm	non Local scope Global scope
Name:	X000 ADAM5051_B00C000_I ADAM5056_B01C000_0 ADAM5056_B01C001_0 MBTR_1X0001_B00L_00
Scope: Description:	Local     Global        (< Undefined >>
ОК	Cancel Apply Help

33. Select "In\_MBRTUDRV\_769\_772" and then click "Apply".

Variables Com	mon Local scope Global scope	; ]
⊡∰ Physi È∰ C	cal Hardware onfiguration Resource Out_ADAM5056_1_0 In_ADAM5051_0_0 In_MBTCPDBV_0_1 In_MBRTUDRV_769_772	>

34. Select "MBR\_3X0001\_INT\_769\_I" to read CH0 of ADAM-4018+ module and then click "Apply".

Name:	MBR_3X0001_INT_769_I	
	ADAM5056_B01C014_0	
	MBR_3X0001_INT_769_1	
	MBR_3X0002_INT_769_1 MBR_3X0003_INT_769_1	
	MBR_3×0004_INT_769_I	
Cases		_
Scope.		_
Description:	[MBSRTU,COM4,ID=1]Register Address3X0001	*
		-

35. Double-click on the second input of "GT" function block.

@MULTIPROG - Test - [main:main*]											_ 8 ×
Eile Edit View Project Build Objects L	yout Online E	tras <u>W</u> indow	2								_ 5 ×
D 😅 🖬 🖪 🎒 🐇 🛍 💼 😖			<b>B B B</b>	🧶 🕾 👜	* 🔹		• •  A				
] 🗅 🛍 🛍   ] Q 🔖   (e) 🐲				1HP 1HO <b>1F0</b>	da da Hu		1   - Ş -				
Project     Demonstration_A1     Demonstration_A1		10 0 0 10 0 0	21 22 21 22	0 2 5 0 2 5	8 8 8 8	a 1 a 1		2 5 2 5	8 8 8 8	а в а в	
Data Types	5 5 5 5	001			<b>⊳</b> ∗	8 1 8 1	n ar ar Na ar	8 6 8 6	87 18 18 18	а в а в	* *
⊡ main" ↓ mainT ↓ mainV*	5 5 5 5					a 1 2 1		21 D	a a a a	а с 2 с	* *
main     main     Physical Hardware     Configuration : IPC 32								a 5	87 18 	8 5	
E Besource : ADV_CE* E Saks Tasks				ADAM5056_	B*	8 9 8		8 D	8 B	8 5	
Global_Variables*		5 8 8 8 8 5 8 8 8		4 A A	8 <b>8</b> 8	2 A		21 D 21 D		2 D	
Advantech_DAQ		n a s n a s	GT	C004	a a a ja	2 A 2 A	e a a e a a	21 D 21 D	e e e e	2 N 2 N	
	MBR_3X0	0001_INT_769				2 A 2 A	e e e e e e	21 X 21 X	a a a a	2 N 2 N	
Group: <favorites></favorites>								2 N 2 N	8 8. 	2 P	
Name Description				4 A A		2 2		2 N		2 N	
F_TRIG Falling Edge Detection     GE Greater Than Equal: >=     GT Greater Than : >								2 2	<i></i>	2 2	• •
LE Less Than Equal <=	🔁 main:ma	ain									
Vanable A POU/Worksheet		uild / Errors /	Warnings <b>λ</b> I	nfos 入 PLC Er	rors 入 Prir	t/					
Object marked											33,73 D: >2GB

36. Type "1196" and then Click "Apply" and "OK".

🏩 MULTIPROG - Test - [main:main*]				_ 8 ×
Eile Edit View Project Build Objects La	t O <u>n</u> line E <u>x</u> tras <u>Wi</u> ndow <u>?</u>			_ 8 ×
0 🗃 🖬 🖪 🎒 🐇 🛍 🛍 🗠 🤅	€ Q ББҲ҈Ҩ҄ББҞ҄ ҂҈҂Ҽ҄҂ ѻ҄҄ ।	•     A 🖬 🚾		
]□111111111111111111111111111111111111	🕲 🖷 📲 📗 👳 📾 💩 📑 🗍 Hell Her eeo 🕶 파 파 Her eef 🗳 🛛	- \$ -		
Project	* * * * * * * * * * * * * * * * * * *	* * *		
Data Types		N N N	8 8 B 3	
i - i main"	Variable Properties			
mainV"	Variables Common Local scope Global scope			
main	Name: 1196	17 18 N	N N N I	
E B Configuration : IPC_32	ADAM5051_B00C000_I ADAM5056_B01C000_0	8 8 A		
	MBR_3X007LINT_769.1	N N N		
Task : LYLLIC     Main : main	MB1A_1A001_000L_00	N N N		
Global_Variables"	Scope: C Local C Global			
		8 8 8	N 18 N 1	
	MBR_3X00	18 18 18 1	N 10 N 1	
Group:				
<favorites></favorites>				
Name Description				
F_TRIG Falling Edge Detection		19 18 18	N 12 N 1	
The GE Greater Than Equal >= GT Greater Than : >	•			
📲 LE Less Than Equal: <= 🗾	🕒 main:main			
X Variable / POU/Worksheet	s ■ Build & Errors & Warnings & Infos & PLC Errors & Print /			
Object marked				28,60 D: >2GB

37. Check the setting "1196" is correct. (1196\*1370)/65536 = 25°C


38. Double-click "C004".



39. Select "ADAM5056\_B01C002\_O" to connect the "GT" function block output to ADAM-5056D DO bit 2. Click "Apply" and "OK".



40. Click "Make" button to make the execution file.

File Edit View Project Build Objects La	vout Online I	Extras Windo	w ?		_		-	_	-		_									
	≥ @ @		- -	<b>N</b>		S (		<b>1</b>	m											
	∞ 🛍 🖷 4	-			<u> </u>  -     -	HO ##	цт ц:	⊨⊩			-+같-			-0						
	-	14																		
Project			<u>.</u>						22	20	a:	-	*	:0			*	10	10	
AdvMotion_A1	2. 2		35	8 - 8	15	20 20	10	2	28	20	2	2	12	10	22	12	12	10	12	12
	2. 2		8		15	2 X	10	2	28	10	12	2	22	10	12	83	2	27	10	12
🖻 🔄 Logical POUs		5 N				incre			12	10	10	2	2	10	20	8	12	10	10	82
E main*		. 10 M	UU1ADAI	MSUS1_B	I* ADA	M5056	jB.↓	12	28	10	2	2	12	10	12	2	12	27	102	10.
mainV*			١.		15	11 N			2	20		12	-	20		*	2	20	102	100
					15				2	27			2	20			\$	20		
E Configuration : IPC_32				n inden		den en el			12	10	a.		22	50	2		2	52		12
E Besource : ADV_CE*			002MBTI	R_1X000	* ADA	M5056	_B*		22	20		2	*	20		82	2	20		32
Task : CYCLIC			Ι.		at.					20								82		
Global Variables		10 14	32 12	8 2	14	17 V	15	14	12	39	54	14	12	38	24	14	12	28	54	14
Advantech_DAQ	- 1 - 1	10 14	34 1	2 2	2	17 - 17	55	2	12	20	54	22	12	20	54	24	12	20	54 -	24
	3 3	28 12	~	GT			and the	12	12	30	<i>8</i> 2	12	12	50	<i>8</i> 2	24	12	22	1% <u>.</u>	24
	MBR_3)	(0001_INT_	769_I—	- Gi	ADA	M5056	_B*	12	12	10	-	14	12	55	25	24	12	25	24	14
	1 1 1	10 11	1196—	5	52	17 I.	- S.	14	12	20	<i>5</i> 4	12	12	20	53		12	20	55 <u>.</u>	14
		- 38 <i>- 8</i> 2	14		102	2 - 2	- S.	8	12	50	<i>8</i> 2	12	12	55	<i>8</i> 2	12	12	55	<i>8</i> 2,	22
orites>	- X - X	10 10	32 14	2 P.	14 134	17 V	12	2	12	30	55	12	12	33	54	14	12	20	<i>6</i> 4	14
e Description		- 20 A	S2	s - 2	32	2 X	10	2	12	20	52	22	13	22	52	24	12	20	54.	24
Equal: =     TDIC: Editor: Education		12 14	82	8 8	32	2 S	10	2	12	32	<i>8</i> 2	12	13	55	25	24	12	25	<i>8</i> 2	24
E Greater Than Equal: >=								-												
T Greater Than : >								_												-
E Less Than Equal: <= 🖉	eur marri																			
Variable 🖉 POU/Worksheet	×																			
								100000												
		Build / Erro	rs <u>}</u> War	nings λ	Infos $\lambda$	PLCE	rors )	Print	/										_	

41. Check compile result is correct.



42. Click "Project Control Dialog" button and then click "Stop" and "Reset".

🙀 MULTIPROG - Test - [main:main]			- 8
The Edit View Project Build Objects La	ut Ogline Extras Window ?		_ 8
▋▋▆▐▋▐▓▝▋▕▓▝₿▐▋▏₽▝			
10088 Q - H	월콜콜 <mark>후</mark> 로 @ 문		
⊟ Project ⊟ Libraries		n a a n	<b>^</b>
AdvMotion_A1		n a a n	<u>.</u>
- Data Types		N 18 18 19	
🖨 🔁 Logical POUs	0014D4M5051 B* 4D4M5056 B*	10 11 11 11 11	n a a
i mainT		N 11 N 1	n n n n
		10 12 12 12	1 N 12 13
Physical Hardware		N N N N	
E · · · · · · · · · · · · · · · · · · ·	002MBTR_1X000* ADAM5056_B*	N 12 N 1	n n n n
🗄 📷 Tasks		N VI VI VI	i ni ut ut
			N 12 12
Global_Variables			
Maraneer_DAg			
	MBR 3Y0001 INT. 769 I		
	1106	-	
Group:		Resource State: Bun	
<favorites></favorites>		Stop	Cold .
Name Description		Reset	Warm .
TO Division			Hot .
E F_TRIG Falling Edge Detection		Download	
GE Greater Than Equal: >=	main:main     mainT:main     mainV:main	Error	Info
		Close	Help
Variable // POU/Worksheet	Processing data Creating task info Creating initialization code		
	Build / Errors / Warning(s)		
For Help, press F1			109,59 D: >2

43. Click "Download" button. Check the "Include bootproject" item and then click "Download" to proceed with download process.



44. Project is downloading.

🙆 MULTIPROG - Test - [main:main]			_ 5
Eile Edit View Project Build Objects	out Ogline Extras <u>W</u> indow <u>?</u>		_ 5
0 # 8 8 4 8 8 9			
00000  00- ++=	> 猶 書 書  ] 字 ■ 幸   母    Hel Hel Hel Hel Hel   中    中    中    中    中    中    中	р.	
		n n n n	਼ ਨ ਕ ਕ 着
AdvMotion_A1		10 10 10 10	: x a x 📕
- Data Types		n n n n	
⊟-⊡ Logical POUs	001ADAM5051_B* ADAM5056_B*	10 10 10 10 10	
mainT	a s s a <mark>e d le O</mark> a s s a s a s	te et et et	i to st st
Di main	a a a al <mark>l</mark> a a a a a a <mark>a</mark> a a a a a a	10 10 10 10 10	1 10 12 12
Physical Hardware     Configuration (IDC 22)			
E- Resource : ADV_CE	002MBTR_1X000* ADAM5056_B*	N N N N	
E Tasks			
Global_Variables			
	<u></u>	8 6. N Y	
- • • • • • • • • • • • • • • • • • • •	MBR 3X0001 INT 769 I	8 6 8 8 8	a a a
د		Destaura	- Inited
Group:		State: Down	nload
<favorites></favorites>		Stop	Cold .
Name Description		Reset	Warm .
EQ Equal: =			Hot
F_TRIG Falling Edge Detection		Download	Upload 1
GE Greater Than Equal: >=	The main/main III main/I:main III main/I:main	Error	Info
×		Close	Help
Variable / POU/Worksheet	Processing data Creating task info		
	Creating initialization code		2
	✓ 0 Error(s), 0 Warning(s) A Build & Errors & Warnings & Infos & PLC Errors & Print /		
Downloading project	70 %		

45. Click "Cold" button to run the project.



Chapter 4 Modbus Functions

46. Click "Debug on/off" button.



47. Check the reading of ADAM-4018+ CH0 is "1088" which is less than "1196". The ADAM-5056D DO CH2 is OFF.



48. Heating the thermocouple of ADAM-4018+ CH0. When the reading is greater than "1196", the ADAM-5056D DO CH2 will turn ON.



49. Save the project for following demonstration.



## 4.4 Modbus/TCP Server Functions

ADAM-5560 Series Controller supports Modbus/TCP server function for connecting to HMI/SCADA software. The Modbus/TCP server function is supported by using Ethernet port of ADAM-5560 Series Controller.

#### 4.4.1 Modbus Address Mapping

ADAM-5560 Series Controller reserves 16K Bytes memory space for Modbus function. The memory block can store user's data and exchange it through Modbus protocol. The unit in Modbus 4X registers is Word so there are totally 8K Words available.

The Modbus address is defined from 42001 to 49999. In order to exchange the data through Modbus, users need to move the data onto this memory block by setting the memory address in "I/O Address" field manually. The memory address of this memory block is defined from mw3.0 to mw3.15996. The mapping table of I/O Address and Modbus Address is as following table.

I/O Address	Modbus Address
%mw3.0	42001
%mw3.2	42002
%mw3.4	42003

Since unit of mw3.0 is Byte, users need to map the I/O Address and Modbus Address as following.

For Bool data type:

	I/O Address	Modbus Address	Length
Data 1	mw3.0.0	02001	1 Bit
Data 2	mw3.0.1	02002	1 Bit
Data 3	mw3.0.2	02003	1 Bit

For Byte and Word data type:

	I/O Address	Modbus Address	Length
Data 1	mw3.0+ mw3.1	42001	2 Bytes
Data 2	mw3.2+mw3.3	42002	2 Bytes
Data 3	mw3.4+mw3.5	42003	2 Bytes

#### For Dword and Real data type:

	I/O Address	Modbus Address	Length
Data 1	mw3.0+mw3.1+mw3.2+mw3.3	42001+42002	4 Bytes
Data 2	mw3.4+mw3.5+mw3.6+mw3.7	42003+42004	4 Bytes
Data 3	mw3.8+mw3.9+mw3.10+mw3.11	42005+42006	4 Bytes

#### 4.4.2 Example

1. Open the "Test.mwt" and add one "Move" function block.



2. "Move" function block will be shown on graphical editor.



 Double-click the input of "Move" function block. Select "MBTR\_1X0001\_BOOL\_00" (ADAM-6050 DI bit 0) and then click "Apply" and "OK".



4. Double-click output of "Move" function block.



5. Type "MB0X0001" and click "Apply" button.

¥ariable Propert	ies X
Variables Com	non   Local scope   Global scope
Name:	MB0×0001
	ADAM5051_B00C000_I ADAM5056_B01C000_0 ADAM5056_B01C001_0 ADAM5056_B01C002_0 MBR_3X0001_INT_769_I MBTR_1X0001_B00L_00
Scope:	C Local C Global
Description:	<< Undefined >>
ОК	Cancel Apply Help

6. Select "BOOL" for Data Type. Type "%mw3.0.0" for "I/O address" and then click "Apply" and "OK".

/ariables Comn	ion Local scope	Global scope	
Name:	MB0×0001		
Usage:	VAR	• F	RETAIN
Data Type: 🛛 🌘	BOOL	76 - 55	•
Initial value:			
I/O address:	%mw3.0.0		
Description:			
		🗖 ОРС	
ОК	Cancel 1	Applu	Help

Chapter 4 Modbus Functions

7. Click "Make" button to make the execution file.

🙆 MULTIPROG - Test - [main:main*]		
Ele Edit View Project Build Objects Lay	vout Ogline Extras Window 2	5 ×
Q <b>   _</b>		
		=1
E Libraries		-
AdvMotion_A1		
- Data Types		
⊟-⊡ main*	001ADAM5051_B* ADAM5056_B*	
mainT	MBTR_1X0001_BOOL_00-MBDX0001	
main*	a n nada n na nada na na a serena a se	
Physical Hardware     Configuration : IBC 32		
E Besource : ADV_CE	002MBTR_1X000* ADAM5056_B*	
⊟ · 🗃 Tasks ⊟ · 🕐 Task : CYCLIC		
a main : main		
Advantech_DAQ		
· · • • • • • • • • • • • • • • • • • •	MBR_3X0001_INT_769_I	
	<u> </u>	
Group:		
<pre><favorites></favorites></pre>		
Name Description		
HOD Modulo Division		•
MUL Multiplication		
The Not Equal: <>	C main:main	
Variable     POU/Worksheet	Build (Errors ) Warnings ) Infos ) PLC Errors ) Print /	
For Help, press F1	[73,15] D:	>2GB

8. Check compile result is correct.



9. Click "Project Control Dialog" button and then click "Stop".



10. Click "Reset" button.



11. Click "Download" button. Check the "Include bootproject" item and then click "Download" to proceed with download process.

🚺 MULTIPROG - Test - [main:main]												_ 8 ×
Ele Edit View Project Build Objects Layout Online	Extras Window ?											_ 8 ×
] <b>□ ☞ ■  <b>3  ●</b>   <b>3 ● ●</b>   <b>0 ○ ○</b>   <b>0 0</b></b>		i   🤹					<b>.</b> 100					
1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		×										
Project	Bootproject		_									
B-G Libraries	Download		- 23	20	12	12	25	N = M	8	N N	12	· -
AdvMotior Vinclude Bootproject	Activate		- 2	20	12	12	25	N = M	8	N N	12	
Data Types	Delete on Target	1	- 23	20	12	12	12	N 12	10	N N	12	12
E main Download Source		-		TD 11	(0001		00	MOVE	MDO	VODD1	12	17
mainT Include User-Libraries			MB	TK_L	0001	_BOOL	_00—		-MBU	XUUUI	10	8. IS
main Include Pagelayouts			*	20	Ĺ.	14. 1	22		2/34	N N	1	
Physical Hardy     Delete Source on Lata	et Download File	T.	*	30	T	20 - 22 	125			8 80 	32 	
		_		20	82 10	100	28 ex				- 22 1.2	
	Close Help			20		10		50 50 50 50		20 10 20 10	12	
Global Variables				38	15	12	10	20 - 20	12	2 20	12.	14
Advantech_DAQ			r 18	20	83.	12	10	2 5	12	20 20	84. -	22
	GT ADAM5056 B*	Ĩ.	1 13	20	84. -	12	15	20 N	22	22 20	14	22
	3X0001_INT_769_I		1 33 	20	100	12	10	36 62	22	22 30	12	22
	1196-			20			122	Resou	rce	Ŀ		<u>د</u> ا .
<pavonites></pavonites>				20			127	State:	On		old	r i
Name Description				30	14	12	12	E	eset	W	arm	
The Greater Than : >			r 18	20	65	14	NR.			- F	lot	
TLT Less Than: <			1					Do	bedre	Un	oad	
MOD Modulo Division	a main								rior	li	fo	i F
			_			_		=	lose	Н	elp	
Variable / POU/Worksheet	Processing data Creating task info									13		· ·
	Creating initialization code											-
	Error(s), U Warning(s) \ Build / Errors λ Warnings λ Infos λ PLC Errors	λPr	int /									-
For Help, press F1											57,5	D: >2GE

12. Project is downloading.



- MULTIPROG Test [main:main Configuration.Resource.Task.main.main] \_ 8 × File Edit View Project Build Objects Layout Online Extras Window ? - 8 × -1× • 🔄 Project Froject
   Libraries
   Libraries
   Libraries
   AdvMotion\_A1
   Libraries
   AdvToolPack
   Data Types on, .opeck .ypes urcal POUs main TimainT Prysical Hardware Compared Hardware Compar 001 MBTR\_1X0001\_BOOL\_00-n () 🖻 🛄 🗓 MBR\_3X0001\_INT\_76 1193 1196-\_ 🗆 🗙 Resource Group: State Ru Stop Name Description -GT CT LE LT MOD MOVE Greater Than : > Less Than Equal: <= Less Than: < Modulo Division Assigns Value 11 Download -Info main:main -1 Close Help 🗶 👆 Variable Processing data ...
   Creating task info ...
   Creating initialization cods ...
   ✓ 0 Error(s), 0 Warning(s)
   Build (Errors \ Warnings \ Infos \ PLC Errors \ Print/ • × A POU/Worksheet 1 1 F 72,41 D: >2G
- 13. Click "Cold" to run the project. Click "Debug on/off" button to see the result.

14. Run Modbus/TCP Client utility Modscan and check the value of I/O address mw3.0.0 and Modscan I/O address 00001 are the same.



15. Change the status of ADAM-6050 DI bit 0 to "1". Check the values of I/O address mw3.0.0 and Modscan I/O address 00001 are all changed to "1".



16. Add one more "Move" function block for analog measurement.



 Double-click the input of the 2<sup>nd</sup> "Move" function block. Select "MBR\_3X0001\_INT\_769\_I" (ADAM-4018+ CH0) and then click "Apply" and "OK".



18. Double-click the output.



Chapter 4 Modbus Functions

19. Type "MB4X0001" and then click "Apply".

	ADAM5051_B00C000_I
	ADAM5056_B01C001_0 ADAM5056_B01C002_0 MB0×0001 MBR_3×0001_INT_769_I MBTR_1×0001_B00L_00
Scope:	Local     C Global
Description:	<< Undefined >>

20. Select "INT" for Data Type. Type "%mw3.2" for "I/O address" and then click "Apply" and "OK".

/ariables Comm	on Local scope Global	scope
Name:	MB4X0001	
Usage:	VAR	💌 🗖 RETAIN
Data Type: (	INT	•
Initial value:		
1/O address: (	%mw3.2	
Description:		
	PDD 🗆	OPC

21. Click "Make" button to make the execution file and check the compile result is correct.



22. Click "Project Control Dialog" button.



Chapter 4 Modbus Functions

23. Click "Stop" and "Reset" button.



24. Click "Download" button. Check the "Include bootproject" item and then click "Download" to proceed with download process.



25. Project is downloading.



26. Click "Cold" to run the project . Click "Debug on/off" button to see the result.



27. Run Modbus/TCP Client utility Modscan and check the values of I/O address mw3.2 and Modscan I/O address 40002 are the same.



28. Save the project and the test is finished.





**Network Functions** 

## **5.1 Web Server Functions**

ADAM-5560 Series Controller features built-in web server function of Windows CE 5.0. Before you using the web server function, please do follow the steps in section 7.1.1 to configure the basic settings properly.

For monitoring and controlling the local I/O modules on ADAM-5560 Series Controller, the "Web5550" library, which is based on ISAPI extension, are useful. It has been pre-installed on the WinCE of ADAM-5560 Series Controller.

By using the library, the web applications can be developed without coding any program like C or C++. It is possible to develop it as simple webpage design like html. If you would like to make your applications more flexible, JavaScript is a good solution. Please refer to section 7.1.2 for detail technical information.

### 5.1.1 Configure Web Server

1. Type ADAM-5560 IP Address "http://192.168.1.5" in Internet Explorer.

🗿 about:blank - Microsoft Internet Explorer	×
File Edit View Favorites Tools Help	🥂
🕜 Back 👻 🕑 🖍 💋 Search 👷 Favorites 🤣 🍰 🌭 🔜 🛄 🏭 🦓	
Addres 1 192.168.1.5	💌 🛃 Go 🛛 Links 🄌 📆 🗸
	1×
© Done	

2. The NAS Admin page will be shown. Type in the password, for example, "admin" and then click "Apply".

AS Admin - Microsoft Internet Explorer	_ 8 ×
File Edit View Favorites Tools Help	27
🌀 Back + 🕥 - 🖹 📓 🏠 🔎 Search 🤺 Favorites  🧭 🎭 💹 + 📒 🏭 🖄	
Address 🙋 http://192.168.1.5/remoteadmin/DeviceConfig.htm	💌 🋃 Go 🛛 Links 🎬 📆 🔹
Windows CE Remote Management Tool	×
NAS Admin	
Device Log On:         To access the device, type your password and then click Log On. Your base station password is case sensitive.         Password:         verification:	
Apply Cancel	
Done	Tinternet

3. Gateway is resetting.



4. Internet Explorer will connect to server automatically and ask to type the user name and password again.

🗿 Gateway is Resetting - Microsoft Internet Explorer	_ (5) ×
File Edit View Favorites Tools Help	
🔇 Back + 🕥 - 💌 😰 🐔 🔎 Search ☆ Favorites 🤣 🔗 - 🦕 🔟 + 📴 🏭 🦓	
Address 💩 http://192.168.1.5/remoteadmin/RestartNetwork.htm?delay=308.Redirect=http://192.168.1.5/remoteadmin/DeviceConfig.htm	💌 🎅 Go 🛛 Links 🍟 🏦 👻
Windows CE Remote Management Tool	×
Gateway is Resetting	
Please wait a moment, your Gateway is resetting. Once completed you may be asked for a username and password.	
Opening page http://192.168.1.5/remoteadmin/DeviceConfig.htm	🗾 🔮 Internet

5. Change the Device Name like "ADAM-5510-1" and then click "Apply".

NAS Admin - Microsoft Internet Explorer	
le Edit View Favorites Tools Help	A
🕽 Back + 🕥 + 🖹 📓 🏠 🔎 Search 👷 Favorites 🤗 🔗 + 🌽 🔟 + 🛄 🎇 🦓 👘	
dress 🕘 http://192.168.1.5/remoteadmin/DevizeConfig.htm	💌 🋃 Go 🛛 Links 🄌 📆
/indows CE Remote Management Tool	
NAS Admin	
Please assign your device a network name	
Device Name:	
JADAM-5550-1	
Apply Cancel	
Done	Internet

6. Click "Add/Del Users" to change the password of user name "admin", if necessary.

http://192.168.1.5/remoteac	min/DeviceConfig.htm - Microsoft Internet Explorer	_6
ile Edit View Favorites To	ols Help	
🌖 Back 🔹 🕥 🖌 🗾 🛃	🏠 🔎 Search 🤺 Favorites 🚱 🗟 • 🎍 🔟 • 📙 🎎 🦓	
ddress 🙋 http://192.168.1.5/rem	oteadmin/DeviceConfig.htm	💌 🛃 Go 🛛 Links や 📆
ddress Arten (1/192.168.1.5/ren Vindows CE Remote ome Device Nanagement Configure Hetwork HostName Config Add/Del Network Adapter SMB Server Stabistics Configure TFLNET Server Configure TFLNET Server Configure TELNET Server Configure TELNET Server Configure TELNET Server Configure TELNET Server Configure TELNET Server Configure TELNET Server	Apply Cancel	

7. Type "admin" in "User" field. In following example, please type "admin" in "Password" field and then click "Apply New".

🚈 NAS Admin - Microsoft Inter	net Explorer	_ 8 ×
File Edit View Favorites	Tools Help	1
🌀 Back 🔹 💮 🖌 🗾 💈	😚 🔎 Search 🧙 Favorites  🙆 - چ 🔟 + 🛄 🏭 🦓	
Address 🕘 http://192.168.1.5/re	moteadmin/UserManager.htm	💌 🄁 Go 🛛 Links » 🐑 🔹
Windows CE Remot	e Management Tool	<u> </u>
Pome Device Management	Use this page to Add/Delete users.	
Add/Del Users	Add/Modify User	
Add/Del Share	User admin	
D Printer	Password •••••	
	Password Verify	
	Add New	
	Delete Users	
	ADMIN	
		<u>v</u>
Done		Internet

8. The message "Add/Modify User Success" will be shown.



9. Run "Configuration Utility".



10. Click "Misc" folder.

My Device	
Internet Explorer Remote Desktop	Advantech Configurator (Ver 1.0)       OK         General       Network       Watchdog       Misc         System       OS Image Version:       Windows CE 500 V2.02 Build 135         Boot Loader Version:       2006-3-28 14:40       CPU Type:       AMD Inc., AMD Geode GX2, 300 MHz         CPU Type:       AMD Inc., AMD Geode GX2, 300 MHz       CPU Temperature:       N/A         Disk & Memory       Total       In Use       Free         CF Disk       125,800 KBytes       45,674 KBytes       80,126 KBytes         Memory 82,084 KBytes       14,880 KBytes       67,204 KBytes
Start ProConOS WinCE	OK       Cancel       Apply         OK       Cancel       Apply         Image: Advantech Configurator (       Image: Advantech Configurator (       Image: Advantech Configurator (

11. Change to "Misc" folder and "Web Server Root" will be modified.

My Device Recycle Bin Internet Explorer Remote Desktop	Advantech Configurator (Ver 1.0) OK General Network Watchdog Misc Startup Programs Program Path: <u>Add Delete</u> HardDisk/Proconos/PCWCE3.EXE Reboot Registry Reboot Servers Web Servers Web Server Root: \$Advantech Configurator (Ver 1.0) <u>QK Cancel Apply</u>	
Start ProConOS WINCE	Advantech Configurator (	해고, · · · · · · · · · · · · · · · · · · ·

12. User can put the developed web page in the specific folder in ADAM-5560 and link the webpage by change the Web Server Root.

13. Click "OK" to reboot the ADAM-5560.

![](_page_137_Picture_1.jpeg)

# 5.2 FTP Server Function

ADAM-5560 Series Controller features built-in FTP Server function of Windows CE 5.0. Before you using the FTP Server function, please do follow the steps as below to configure the basic settings properly. The default setting of FTP Server function in Windows CE 5.0 is disabled. If you enable the FTP Server function and do not configure the settings properly, please be noted that it is possible that malicious user gain completely control of the files on the ADAM-5560 Series Controller.

1. Type IP address "http://192.168.1.5". Enter user name: "admin", password: "admin" and then click "OK".

![](_page_138_Picture_4.jpeg)

2. Click "Device Management".

🚰 http://192.168.1.5/RemoteA	dmin/ - Microsoft Internet Explorer	_8×
File Edit View Favorites To	pols Help	
🕞 Back + 🕞 + 🗾 🛃	🎧 🔎 Search 🤺 Favorites  🧭 🔌 🔟 🔹 📙 🎎 🖄	
Address 🕘 http://192.168.1.5/Rer	noteAdmin/	🛫 🛃 Go 🛛 Links 🎽 🔩 🕈
Windows CE Remote	: Management Tool	-
Home	Please name your device	
Device Management Add/Del Users Add/Del Share P Printer	Device Name: ADAM-5550-1	
	Apply Cancel	
Done		🗾 🚺 Internet

3. Click "Configure FTP Server".

![](_page_139_Picture_3.jpeg)

Chapter 5 Network Functions

4. Enter the "FTP Server Configuration" page.

![](_page_140_Picture_2.jpeg)

5. Check "FTP Server Enabled", un-check "Allow Anonymous Users", change "Default Directory" as "HardDisk\FTP". Click "Submit" button.

![](_page_140_Picture_4.jpeg)

6. Click "Reboot" button.

![](_page_141_Picture_1.jpeg)

7. After the ADAM-5560 was rebooted, following page will be shown again.

FTP Server Configuration - M	icrosoft Internet Explorer		_ 8 :
File Edit View Favorites T	ools Help		
🌀 Back 🔹 💮 🖌 🗾 🛃	🐔 🔎 Search 🤺 Favorites 🥝 🎯 - 嫨 🔟 - 🛄	2 3	
Address 🕘 http://192.168.1.5/Re	moteAdmin/FTPConfig.htm		🝷 🛃 Go 🛛 Links 🎽 📆
Windows CE Remote	e Management Tool		
<ul> <li>Device Management Configure Network HostName Config Add/Del Network Adapter SMB Server Statistics Configure FTP Server Configure FTP Server Add/Del Users Add/Del Users</li> <li>Add/Del Share</li> <li>Printer</li> </ul>	The ftp server accepts ftp connections and allows the device to Basic Configurations for FTP Server: We extreme caution when configuring the ftp server missonfigured, a malicious user could gain complete control server is intended for advanced users only. The Ftp server mill be restarted after any changes to the the roots. That will terminate any Ftp connections currently activ FTP server Enabled: Will the ftp server accept incoming connections? Require Authentication: Will the ftp server accept incoming connections? Allow Anonymous Users: Allow Anonymous Ubloads: Allow Anonymous users to upload and change files? Allow Anonymous users to virtual roots: Allow Anonymous users to virtual roots: Allow Anonymous users to view and access files in virtual in Default Directory The default directory that anonymous FTP users will log in t	<ul> <li>be configured remotely.</li> <li>should the ftp server be of the files on your gateway. The ftp basic configuration or the virtual ree.</li> <li>Image: Image: Im</li></ul>	
	ETD Server Virtual Roots:		

8. Scroll down the page. Check the "Home Directory" for all users and then click "Submit" button.

e Lac new raverices re-	XIS Help	
Back 🔹 🕥 🖌 🔀 👔	🏠 🔎 Search 🥋 Favorites 🕢 🔗 🌭 🔟 + 📴 🏭 🦓	
dress 🙋 http://192.168.1.5/Rem	oteAdmin/FTPConfig.htm	💌 🄁 Go 🛛 Links 🏾 👮
	FTP Server Virtual Roots:         Use this section to add/delete virtual roots to the FTP server. Virtual roots allow you to map a physical directory to an directory with a different name.         If the user has permissions to see virtual roots, these roots will appear as folders under the user's home directory.         The virtual directory name cannot contain of the following characters:         Virtual Directory Name         The name of the directory to display under the users home directory         directory         The name of the directory to display under the users home directory         Add	
	Use this section to control access to the FTP server for each user. To add new users go to the Add Users page. You can configure a separate home directory for each user by appending the user's name to home directory. Denying read permission to a user, denies complete access to the ft; server for that user. UserName Home Directory The login name of the user The path to user's home directory ADNIN NHardDisk/FTP User1 NHardDisk/FTP Submit	

9. Wait for a moment for resetting.

![](_page_142_Picture_4.jpeg)

10. After resetting, following page will be shown again. The basic settings for FTP Server have been configured.

![](_page_143_Picture_1.jpeg)

11. Right-click the mouse and then add a new directory "New Folder" under "HardDisk" directory of ADAM-5560 Series Controller.

<u>File Edit View Go Favorites</u>	4	) 🌶 🗙 🗹	-	<b>№?</b> ×
Address WardDisk			a	×
Name	Size	Туре	Date Modified	
CAdam.NET Utility		File Folder	1/1/2003 12:05 AM	
🗁 Bin		File Folder	7/14/2006 11:35 AM	
Cabinet		File Folder	7/7/2006 3:03 PM	
C DiagAnywhere		File Folder	1/1/2003 12:06 AM	
C Documents and Settings		File Folder	2/13/2003 11:20 PM	
Drv		File Folder	7/14/2006 11:35 AM	
C Proconos		File Folder	7/7/2006 4:45 PM	
STARTUP		File Folder	7/7/2006 2:45 PM	
STUDIO		File Folder	7/14/2006 11:44 AM	
C Web5550		File Folder	1/1/2003 12:14 AM	
Advantech Web5550	513KB	CAB File	10/16/2006 5:13 PM	
BOOT	301KB	Bitmap Image	7/4/2006 2:49 PM	
E CEApp	pytes	INI File	7/14/2006 1:21 PM	
CEServer	_ 77KB	Application	9/29/2004 9:39 AM	
CEServer Arrange Icons By	<ul> <li>bytes</li> </ul>	INI File	7/14/2006 1:20 PM	
KERNEL Refresh	.6KB	SYS File	11/23/2005 11:21 PM	
LOAD	- 39KB	Application	3/28/2006 2:40 PM	
Paste				
Paste Shortcut				
Now Folder				
New Folder				
Properties				
Start ProConOS WinCE	9	HardDisk		🔌 🕹 🎯 🏈 🍠 3:13 AM 🛛 🕼 🎔
12. Enter the name for the new folder as "FTP".

<u>File Edit View Go Favo</u>	rites 🕴 💠	🕨 🔰 🗙 🖸 🕷	-	<b>k</b> ?
Address HardDisk	61 m.			
Name	Size	Туре	Date Modified	
Adam.NET Utility		File Folder	1/1/2003 12:05 AM	
🔁 Bin		File Folder	7/14/2006 11:35 AM	
Cabinet		File Folder	7/7/2006 3:03 PM	
DiagAnywhere		File Folder	1/1/2003 12:06 AM	
Documents and Settings		File Folder	2/13/2003 11:20 PM	
Drv		File Folder	7/14/2006 11:35 AM	
Proconos		File Folder	7/7/2006 4:45 PM	
STARTUP		File Folder	7/7/2006 2:45 PM	
STUDIO		File Folder	7/14/2006 11:44 AM	
🕽 Web5550		File Folder	1/1/2003 12:14 AM	
Advantech Web5550	513KB	CAB File	10/16/2006 5:13 PM	
BOOT	301KB	Bitmap Image	7/4/2006 2:49 PM	
CEApp	110 bytes	INI File	7/14/2006 1:21 PM	
CEServer	177KB	Application	9/29/2004 9:39 AM	
CEServer	103 bytes	INI File	7/14/2006 1:20 PM	
KERNEL	45.6KB	SYS File	11/23/2005 11:21 PM	
LOAD	139KB	Application	3/28/2006 2:40 PM	
FTP D		File Folder	1/1/2003 3:13 AM	
			-,-,	
				-
Start ProConOS WinCE	9	HardDisk		🔽 🕹 🛱 🔕 🏺 3:13 AM 🕝 🛙

13. Enter "HardDisk\FTP" directory.

le <u>E</u> dit <u>V</u> iew	<u>Go</u> F <u>a</u> vorites	8 🔹 🏚 🗙 🕻	2 🔤 🔹		<b>k</b> ?	×
Address HardDis	:KVFTP					~
me		Size Type	Date Modified			
	0.000-000	~				
Start Proconc	15 WINCE	FTP		₩ <b>₩</b> ₩₩	14 AM	12

14. Add "Test FTP" directory.

<u>File E</u> dit <u>V</u> iew	<u>Go</u> F <u>a</u> vorites	🔹 🔹 🔰 🗶 🚺	-	<b>№?</b> ×
Address HardD	isk¥FTP			~
Name		Size Type	Date Modified	
Test FTP		File Folder	1/1/2003 3:16 AM	
🐉 Start ProCon	OS WinCE	FTP		🔌 🕹 🎯 🍠 3:17 AM 🔀 🗭

15. Type "ftp://192.168.1.5" to login the FTP Server. You will see the warning message because anonymous login is not allowed now.

le Edit View Favorites Tools Help	
Back + 🕑 - 🏂 🔎 Search 🎼 Folders 🛄 +	
ldres 1 ftp://192.168.1.5/	🗾 🔁 Go 🛛 Links 🎽 📆

FTP Fold	er Error X
i	(Windows cannot access this folder) Make sure you typed the file name correctly and that you have permission to access the folder.
	Details: 220 Service ready for new user. 530 Anonymous access not allowed.
	ОК

o Internet

Chapter 5 Network Functions

16. Click "Login As" item to enter the user name and password.

			<u>_ 8 ×</u>
File Edit View Favorites Tools Help			# <u>#</u>
New · D Search Folders			
Create Shortcut	Size Tupe	Modified	So Links " 📆 🗸
Rename	Jize Type	Hodined	
Properties			
Work Offline Pr			
Close Shared Documents			
🤤 My Network Places			
ogin using a different user name and password.			

17. Login the FTP Server by username: user1 and password: "user1".

rtp://192.168.1.5/ - Microsoft In	nternet Explorer					_ <u>8</u> ×
File Edit View Favorites Tool	s Help					
🕝 Back + 🕥 + 🏂 🔎 Se	earch 🜔 Folders					
Address 1 ftp://192.168.1.5/						💽 🛃 Go 🛛 Links » 👘 🔹
	Name 🔺		Size Type	Modified		
Other Places 🕆						
🥭 Internet Explorer	Los On L				vil	
My Documents Shared Documents My Network Places		To log on to th	nis FTP server, type a user r	ame and password.		
		FTP server:	192.168.1.5			
		User name:	user1		•	
		Password:	••••			
	A	FTP does not a server. To pr (WebDAV) ins Learn more ab	encrypt or encode passworn utect. Une security of your p tead.	s or data before an electric territorio ( is or data before sending the passwords and data, use Web	no to the Pullers	

18. The "Test FTP" directory can be accessed now.



19. Try to upload files onto FTP Server.



Chapter 5 Network Functions

20. Upload the directory of "OPC" onto FTP Server.



21. Uploading process is proceeding.



22. The uploaded "OPC" directory will be shown.



23. Check the files under "OPC" directory in FTP client.

🚔 ftp://192.168.1.5/Test FTP/OPC/ - Microsoft Internet	Explorer						- 8 ×
File Edit View Favorites Tools Help							
🕒 Back 🔹 💮 🖌 🏂 🔎 Search 🜔 Folders [	<b></b> .						
Address 1 ftp://192.168.1.5/Test%20FTP/OPC/	- Martin				💌 🔁 Go	Links *	• 📆 •
Folders	X Name	Size	Гуре	Modified			
<ul> <li>Desktop</li> <li>M Jocuments</li> <li>Advantch Studio vé.0 Projects</li> <li>Advantch Studio vé.0 Projects</li> <li>My Books</li> <li>My Pictures</li> <li>My Computer</li> <li>My Recycle Bin</li> <li>Recycle Bin</li> <li>Iterate Explorer</li> <li>Iterate Explorer</li> <li>Iterate For Project</li> <li>Iterate For Project</li> <li>Iterate Project</li> <li>Itera</li></ul>	Alarm Corfig Detabase Fist Screen Symbol MoPC. APP	2.43KB	ile Folder ile Folder ile Folder ile Folder ile Folder ile Folder ile Folder ile folder ile folder ile folder	1/12003 3:37 AM 1/12003 3:37 AM			

Chapter 5 Network Functions

24. Check the files under "OPC" directory on the ADAM-5560.

<u>File Edit View Go Favor</u>	ites 🕴 💠 🗼	🏂 🗙 🛃 🖬 🗸		<b>№?</b> ×
	TPIOPC		10-	~
Name	Size Typ	be Da	te Modified	
Alarm	File	Folder 1/:	L/2003 3:37 AM	
Config	File	Folder 1/:	L/2003 3:37 AM	
🗁 Database	File	Folder 1/:	L/2003 3:37 AM	
🗁 Hst	File	Folder 1/:	L/2003 3:37 AM	
🗁 Screen	File	Folder 1/:	L/2003 3:37 AM	
C Symbol	File	Folder 1/:	L/2003 3:37 AM	
🗁 Web	File	Folder 1/:	L/2003 3:37 AM	
OPC .	2.44KB AP	P File 1/:	L/2003 3:37 AM	
Start ProConOS WinCE	C OPC			🌲 🕹 🌉 🊷 🍠 3:39 AM 🛛 📝 🏸

# 5.3 Email Alarm Function

There is an example for demonstrating how to send an email from ADAM-5560 Series Controller. Please refer to following info.

1. Open "AdvMailDemo.mwt".



2. The function block is included by "AdvToolPack" library. Double-click "main" to see the function block.



3. Type the correct settings in the "Init" fields as below and try to run this example directly.

MULTIPROG - UNTITLED - [main¥:main]							_ 5
III Eile Edit View Project Build Layout Online	Extras Window ?				New York Contraction		- 0'
		b 🖬 📫 🖉 🖆	2 🛗 👗 🗳	• 🖪 🛛 •			
1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	18 4 4    ♥ ■ ☎	🔁 📗 मरु मन मन्द्र	이 바라 지하고 나라 누		-181-		
		Tree	Lusses ID		1.14	Datala	
Project	Name Name	Type	Usage Di	es   Addr	Init	Retain	PDD OPC
AdvMotion A1*	Aduttail Sond 1	Aduttail Sand	NAD			-	
AdvToolPack*	Auviviaii_Seriu_1	ROOL	VAR	-	0		
🖻 🔄 Data Types	Conjornemo	STOINC	VAR	6	CMTD Contor Address'	h 🔚	
E test*	servername	STRING	VAR	-	'Empil Appaunt '		
E- Cogical PUUs	mailto	STRING	VAR	8	"Destination Email Address"		
	aubiect	STRING	VAR	-	'oubject'		
(iii mainV*)	subject	STRING	VAR	-	'content'		
- 10- main	done	BUU	VAR	-	content		
Physical Hardware*	huev	BOOL	VAR				
E Becource : ADV_CE*	error	BOOL	VAR		<u></u>	-	
E-M Tasks	errorid	DWORD	VAR	0		E E	
🗄 🚺 Task : CYCLIC	R TRIG	R TRIG	VAR			F	
Advantech_DAQ							
<u>* 5 4 6 9</u>	 main:main main	iV:main					
Variable / POU/Worksheet	5						
	Build Errors A W	arnings $\lambda$ Infos $\lambda$ P	LC Errors 👌 Pr	int/			

### Note!



The sending email function is only supported by mail server via intranet within enterprise network. The free mail box cannot support the sending email function.

# 5.4 SQL Server Function

There is an example for demonstrating how to use the built-in SQL Server function on ADAM-5560 Series Controller. Please refer to following info.

1. Open "AdvSQLDemo.mwt".

Ele Edit View Project Build Ogline Extras 2
Open/Unzip project       Image: Status in the image:
Image: State of the state o
For Help, press F1 0,31

2. Type to run this example directly.



# SQL Function Block Reference: AdvSQL Init



Function: Initialize SQL mobile database.

- 1. Enable: (BOOL), Enable AdvSQL function blocks.
- 2. DataBaseName: (STRING), SQL mobile database name.
- 3. TableName: (STRING), SQL mobile database table name.
- 4. ColumnTotal: (INT), Total number of fields in SQL mobile database. Maximum number is 10.
- 5. PrimaryIndex: (INT) KEY Index of SQL mobile database.
- 6. ClearDataBase: (BOOL), Clear SQL mobile database.

### AdvSQL\_InsertLastData



Function: Append one record to SQL mobile database.

- 1. Enable: (BOOL), Enable AdvSQL function blocks.
- 2. DataBaseName: (STRING), SQL mobile database name. Rreserved for handling more than one SQL mobile database in the future.
- 3. ColumnIndex: (INT), The column index in SQL mobile database.
- 4. ColumnName: (STRING), Name of SQL mobile database.
- 5. ValLength: (INT), Maximum length of data field.
- 6. Value:(STRING), Content of data field.

### AdvSQL\_SelectLastData

2	AdvSQL SelectL AdvSQL_SelectL	astData astData	1
	Enable	Value	_
-	DataBaseName	Done	-
	ColumnIndex	Busy	-
8	ColumnName	Error	-
80	ValLength	ErrorID	

Function: Read the last record from SQL mobile database.

- 1. Enable: (BOOL), Enable AdvSQL function blocks.
- 2. DataBaseName: (STRING), SQL mobile database name. Rreserved for handling more than one SQL mobile database in the future.
- 3. ColumnIndex: (INT), The column index in SQL mobile database.
- 4. ColumnName: (STRING), Name of SQL mobile database.
- 5. ValLength: (INT), Maximum length of data field.
- 6. Value:(STRING), Content of data field.



Miscellaneous Functions

### 6.1 Advantech Utilities

There are four Advantech utilities which are pre-installed on ADAM-5560 Series Controller. The major functions are as below.

Adam.NET Utility: CE version of ADAM Utility for configuring ADAM-5560 Series Local ADAM-5560 I/O Modules, ADAM-4000 Remote I/O Modules, ADAM-6000 and ADAM-5560/TCP Ethernet I/O Modules. Most of the functions are mentioned in Chapter 3 and Chapter 5.

**Configuration Utility:** Configure Auto-startup Programs, Web Server Root Directory and Watchdog Timer, etc. Chapter 4 has mentioned how to configure Auto-startup Programs.

**Touchscreen Configure Utility:** Configure the pre-installed touch screen driver. Please refer to section 7.3.

**Version Information:** Record installed software programs with respective version information. Chapter 4 has an example for reference.

A My Device 2 6 Internet Explorer 0 Remote Desktop **AD\ANTECH** indows<sup>®</sup> SActiveSync 🗦 AdamNET Utility 🛃 CE NotepadPlus 🛅 Programs 🔹 🕨 🗁 Advantech Configuration Utility Services Communication 💣 Registry Editor 🛅 Documents 🔸 🔣 Command Prompt Registry Saver 🚱 Settings 🔹 🕨 🎯 Internet Explorer Remote Display Application 🧼 <u>H</u>elp Semote Desktop Connection 🚆 Resolution Utility 🖾 <u>R</u>un.. 🐉 Windows Explorer 🚲 Touch Screen Config Start ProConOS WinCE K1 Version Information 👰 🕹 🔌 🏈 🍠 12:36 AM 🛛 📝 🏸

All the utilities can be run by following path.

# 6.2 Change Language Interface of CE

1. Enter "Control Panel".



2. Run "Regional Settings".

<u>File View</u>	]				11.0			192		₩?	×
Ö	-		8	9	<b>Ø</b>	1	Õ		. 🤶		
Certificates	Date/Time	Dialing	Display	Input Panel	Internet Options	Keyboard	Mouse	Network and Dial-up Co	Owner		
P		4	3		2	0			2		
Password	PC Connection	Power	RAS Server	Regional Settings	Remove Programs	Storage Manager	Stylus	System	Terminal Server Clie		
20				$\bigcirc$							
Volume & Sounds											
🐉 Start 🛛 Pr	oConOS WinCE		Contro	l Panel				₫ <b>↓*</b> &	👙 1:44 AM		7

3. Click "User Interface Language" folder and select "Chinese (Taiwan)" item.



4. Click "OK" to finish the change.

Eile Vie	3W									<b>№?</b> ×
0	P		8	9	<b>9</b>		Õ		<u> </u>	
Certificate	es Date/Time	Dialing	Display	Input Panel	Internet Options	Keyboard	Mouse	Network and Dial-up Co	Owner	
P		-	31	->	4	0			97	
Passwor	d PC Connection	Power	RAS Server	Regional Settings	Remove Programs	Storage Manager	Stylus	System	Terminal Server Clie	
30					-	-	_			
Volume	&	Regional					? 0	К×		
Sounds		Region	al Settings	User Inter	face Languag	e Input	Language			
1		User Int	erface <mark>UI cha</mark>	nge request		OK	×			
1		-	The of the surd	an fan blan 117 al			s, dialogs			
1		ä	and all the de	vice must be r	eset. Please s	e enect shutdown you	r			
1			applica	tions and rese	t the device.		~			
1										
1										
1										
1										
1										
1										
1										
ಶ Start	ProConOS WinCE		Control	Panel	/ Re	egional and La	nguage S	<u>@</u>	🏓 1:45 AM	1

5. Click "OK" to reboot the ADAM-5560.

Eile View										<b>k</b> ?	×
Ö	P		8	9	ø		Ċ		<u> </u>		
Certificates	Date/Time	Dialing	Display	Input Panel	Internet Options	Keyboard	Mouse	Network and Dial-up Co	Owner		
P	222	4	3	2	2	0		5	23		
Password	PC Connection	Power R	AS Server	Regional Settings	Remove Programs	Storage Manager	Stylus	System	Terminal Server Clie		
30											
Volume & Sounds											
				Reboot Da yau w	vant to reboo	k2					
🎝 Start Pr	cConOS WinCE		Control	Panel				₫ <b>-1</b> *&	🎐 1:46 AM		7

6. The Language Interface has been changed correctly.



# 6.3 Example of Configuring Touch Screen

1. Run the "Touch Screen Config" utility.



2. Select COM port as COM3, for example.



Chapter 6 Miscellaneous Functions

3. Click "OK" and reboot the ADAM-5560 system.

My Device	You have to reboot for the DMC9X00 Utility COM Port Select COM3:	changes to take effect, reboot ri	OR X ght now?	
Start ProConOS WinCE	SDMC9X00 Utility			

4. Enter "Control Panel".



5. Run "Stylus" to set the properties.

Certificates       Date/Time       Dialing       Display       Input Panel       Internet Options       Internet Connection       Internet Dialing       Internet Owner       Internet Dialing       Internet Diali	Eile Vi	ew									<b>N?</b>	×
Certificates       Date/Time       Dialing       Display       Input Panel       Internet Options       Keyboard       Mouse       Network and Dia/up Co       Owner         Password       PC Connection       Power       RAS Server       Regional Settings       Remove Programs       Storage Manager       Imput Panel       Imput Pane       Imput Pane	Ô	P		<u>s</u>	9	<b>9</b>	1	Ć		<u> </u>		
Password       PC       Power       RAS Server       Regional Settings       Programs       Storage       Power       System       Terminal Server Cle         Volume 8. Sounds       Volume 8.       Sounds       Programs       Start       Programs	Certificat	tes Date/Time	Dialing	Display	Input Panel	Internet Options	Keyboard	Mouse	Network and Dial-up Co	Owner		
Password PC Power RAS Server Regional Settings Programs Manager Storage System Terminal Server Cle Volume & Sounds *Start Procenos Wince Programs			4	31	1	1	0					
Volume & Sounds	Passwoi	rd PC Connection	Power	RAS Server	Regional Settings	Remove Programs	Storage Manager	Stylus	System	Terminal Server Clie		
Volume & Sounds	30											
Start ProConOS WinCE	Volume	&										
*Start ProConOS WinCE Control Panel		~										
* Start   ProConOS WinCE Control Panel												
* Start   ProConOS WinCE Control Panel												
* Start   ProConOS WinCE Control Panel												
Notart ProConOS WinCE Control Panel 商語 1、 金 条 音 2:31 AM で計算												
Notat ProConOS WinCE Control Panel 商語 し、 火 約 音 2:31 AM 「ほ」 🖼												
W Start   ProConOS WinCE   Control Panel   商語 J. 金 約 音 2:31 AM 「ほ) 🗃												
W Start   ProConOS WinCE   Control Panel   「読し、 火 & 音 2:31 AM 「ほ) 🖼												
Winder Control Panel (語) ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・												
ジStart   ProConOS WinCE   @ Control Panel   「語人、文、公 音 2:31 AM 「ほ」   ■												
	<b>8</b> Start	ProConOS WinCE		Contro	Panel				ALL X	🖶 2:31 AM		7

6. Click "Recalibrate" button.

Eile Viev	N									<b>\?</b>	×
Ö	P	No.	8	9	9	-	Ċ		<u>8</u> 2		
Certificate	s Date/Time	Dialing	Display	Input Panel	Internet Options	Keyboard	Mouse	Network and Dial-up Co	Owner		
	222	4	3	2	4	0		<b>9</b>	<b>2</b>		
Password	PC Connection	Power	RAS Server	Regional Settings	Remove Programs	Storage Manager	Stylus	System	Terminal Server Clie		
30											
Volume 8	e	Stylus Pre	perties				?	IK 🔀			
Sounds		Double-Tap	Calibration	۱ <u> </u>							
		Re ce an	your window ay need to re calibration in nter, keep t d then lift th	volves tapping he stylus on the stylus. To st	screen. I the center of he screen, slid tart, tap Reca ecalibrate	of a target. If y de it over the t alibrate.	you miss the target's ceni	ter,			
ಶ Start	ProConOS WinCE		Control	Panel	[ 🛛 S	tylus Propertie:	s	@=*&	🍠 2:31 AM	0	7

Chapter 6 Miscellaneous Functions

7. Follow the instructions and use finger to press the target on the screen.



8. Follow the instructions and use finger to press the target on the screen.



9. Follow the instructions and use finger to press the target on the screen.



10. Follow the instructions and use finger to press the target on the screen.



Chapter 6 Miscellaneous Functions

11. Follow the instructions and use finger to press the target on the screen.

Carefully press and briefly hold stylus on the center of the target. Repeat as the target moves around the screen. Press the Esc key to cancel.	
	$\bigoplus$

12. Press "Enter" key to accept the new settings.



13. Click "OK" to finish the recalibration.



# 6.4 Save and Upload Project Source

1. Open a project and click "Program Control Dialog".

MULTIPROG - UNTITLED - [main:m	iain]	* 0	oline	Este	nc W	indou																				
Chiefer Terr Terr Band Co	Jetts Layou			CZU A		undov act i		_			0 1	2001	-	-	2	11		I.D.	- hre	-						
	1 52 52		Q			~	<b>(2</b> ) II	3 🖻	3 10			i 🛄		w	IJ		-	H I	<u>8.</u> (14)	1						
101686880   ⊂  8	A Ber Ker	箱	- <b>H</b>	響			中	1		нн чнв	- IHO	HHF 1	바대	1  +++		dep.	니와									
	<u> </u>	4	<u> </u>		310			_	0.00029		_		_		_			11V								=
E G Libraries				10	đ	1	12	27	1	10	2	29	2	12	25	19	1	33	22	20	- 15	8	20	20	1	
AdvMotion_A1				10	<i>.</i>	1	2	20		10	*	29	2	12	25	20			12	22	35	8	2	-		. —
- We AdvToolPack							-	20	- 22		*	20			2	20				20	15		23	- 201	-	
E G Logical POUs															a.											
🗄 🔲 main					е	- 25	8				8	59					~				~					
i mainT										V000		ADD		000												
- main					1	1	18	30	10	VUUU	2		E,	000	12	29	10	10	25	55	10	25	2	32	1	8
🖻 🍘 Physical Hardware					1	1	18	30	12	· 1·			2	12	12	37	2	10	25	55	10	25	8	39	10	
Configuration : IPU_32	ř.			10	1	1	12	27	12	12	<u> </u>		1	12	25	19	2	10	12	50	-95	25	25	22	10	
🖻 📸 Tasks	E			10	8	1	12	27	$\otimes$	12	25	$\mathbb{N}$	2	12	25	39	2	2	20	52	10	20	21	20	10	
E D Task : CYCL	JIC			80	e.	2	12	27	22	12	12	27	2	12	25	59	2	22	10	52	10	33	21	20	10	
🛁 main : m n Giobal Variables	hain s			\$8 I	54 - E	2	122	30	25	14	1	28	14	14	12	20	15	14	38	12	-22	32	121	88	64	14
Advantech_DA0	2			90 - I	Si	14	12	20	25	12	12	25	5	14	12	28	55	24	181	22	24	82	31	285	84	S
					54.	12	12	35	55	14	12	28	55	14	12	28	24	14	38	33	22	32	33	22	64	
				2	S.	3	12	20	55	12	12	22	5	14	12	28	54	~	181	22	14	8	1	10	14	
																				-						-
																				R	esou	'ce		_		1
			1				48	10	- 24		47	10									State:	0	n		. 3	Ŀ
() A () A ()		1.	-	mair	omain	Ē														-	5	top		Cold	ł	
هقطق																				_	Ri	eset		Wan	m	
👔 Variable 🛛 🛆 POU/Works	sheet	×		Buil	lding	y in	stan	ce t	ree	for R	ESOU	RCE	Res	ource	'	•								Ho		
	1	ī	1.000			Gen	erat	ing	spec	ific	Code	for	CON	FIGUR	ATIO	N Cor	nfigu	urati	or		Dov	nload	1		ad 1	
			0.23	Crea	ating	u da	ta t	enpl	ates	1110	Lode	LOL	RED	JURCE	Res	ource	0.3 8				F	1101		lofe		
				Proc	cess	ing	code													Contraction of the	0	000		Hele		
				Proc	cess:	ing	data															0.6		neij	-	
				Crea	atino	g ta T in	itia	nro liza	 tion	code																
		9	0 E	rroi	(3)	2	Warn	ing(	s)																	
•	×	4		Buil		rrors	sλM	/amir	igs )	Infos	λPL	C En	ors )	Print	1											
(mor(s) 2 Warping(s)																									73.47	D: >20

2. Click "Download" button. Check the "Include Sources" item and then click "Download".

🙍 MULTIPROG - UNTITLED - [main:main]											_ 8 ×
Ele Edit View Project Build Objects Layout Opline Extras Window 2											_ 8 ×
	<u>i</u> 🛃	4		<b>a</b> 10	4						
1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	योग दी	1 ⊣⊩		5   - ş -			2				
		20129480112									1
B-G Projec Download	12	10	15	N 12	12	20	20 - 26	323	20	50	. 🔺
Project Bootproject	12	12	10	10 10	12	20	20 20	10	22	20	
Download Download	10	85.	15	10 10	12	20	20 10	10	20	10	
E - Lockude Bootproject Activate	100	85.	(2)	10 NZ	12	28	20 10	10	20	52	
□ I Include Socies		85.	23	10 UZ	12	78	20 10		20	50 - 00	
Download Source	-	000	28	10 UT	15	78	20 10		20	50 M	
E PL Duckude Liseri ibraries		85	28		12	28	20 10	10	20	50 05	
Include Pagelayouts		85.	25	8 9 W	12	22	2 2	10	20	50 00	
E I Include Backend-Code	10	12	12	10 UT	12	22			20	50	
Delete Source on Target Download File		12	23	10 IV	12	12	9 B		20	50	
	55.	24	12	10 - 25	14	28	23 - 34	30	20	70 - 26	
<u>Close</u> Help	84 1	$\sim$	12	10 - 24	14	22	N = N	37	3N	70 - 76	14 - E
	5 65	24	10	10 - 54	14	10	21 - 31	17	78	10 - 34	4
	- 54	14	12	20 - Si	14	10	2 3	12	20	10 10	4
	5 - Si	14	10	20 - Si	22	20	Res	ource		- 0	×
		-		e 6.			Stat	e: C	In		- L
		_						Stop		Cold	
							_	Reset		Warm	
X Variable / POU/Worksheet X Building instance tree for RESOURCE	'Res	ource								Hot	
Generating specific Code for	r CON	FIGURA	TION	Config	urati	or	- C	ownload	7	Upload	
Creating data templates	1. 1.6.0	JONOL	NCDOU.					Error	1	Info	
Processing code								Close	1	Help	
Creating task info											
Creating initialization code											
V U Error(s), Z Warning(s)	more )	Drint	/								-
	nois /	(runt)									42 0 000
u crror(s), 2 warning(s)										51	,40 D: >2GB

3. The "Upload" button will be activated when project source code has been downloaded correctly.

	×
Ele Edit View Project Build Opline Extras 2	
Project     Dearies     AdvMoion_A1     AdvMoion_A1     AdvTooPack     Daa Types     DooglaPOUs     main     main/     main/     main/     main/     Projucal Hardware     Configuration: PC_32     Market DAV CE     Market DAV	
Resource     Image: State       State     State       State     State	
Heset Waim	_
X       Building instance tree for RESOURCE '       Hor         Building instance tree for RESOURCE '       Generating specific Code for CONFIGURATION Configuration       Download         Creating data tamplates       Processing code       Error       Info         Processing data       Creating that info       Creating initialization code       0 Error(s), 2 Warning(s)	
Image: Second Secon	

4. Click "Upload" button and then click "Project Source" to test uploading source function.



5. Click "OK" to proceed with uploading the project source.



Chapter 6 Miscellaneous Functions

6. Uploading project source has been finished.



# 6.5 Changing the Language Interface

1. Click "Extras\Options" item.



2. Select "Trad. Chinese" item.



3. Click "Apply" and "OK" buttons.

🎦 MUL TIPROG	_ B
Eile Edit View Project Build	ptons X
_ <b>C # .</b>   <b>L #</b>   <b></b>	Backup Cross References Logic Analyzer Colors Variables Grid Text editor Text colors Graphical editor Graphical editor colors Toolbars Commands General Build Directories Pagelayouts Debug
	Language: Trad Chiness Workbook Style Restore Default Toolber Configuration on Program Start Open Last Project on Program Start MULTIPROG Project th Changes will take effect after rectarting MUL TIPROG. The project the Changes will take effect after rectarting MUL TIPROG.
Group: All Name Description	Image: Pol       Image: Pol
Variable POU/V	

4. Close Multiprog and then reload it. The Language Interface will change to Traditional Chinese correctly.

🕼 MULTIPROG
文件 (正)编辑 (正) 親圖 (Y) 工程 (P) 建立 (B) 聯機 (M) 附加 (M) 2
◆ [1] [1] [1] [1] [2] [2] [2] [2] [2] [2] [2] [2] [2] [2
租: 全部
名稱     描述     ▲            ●         用戶         田         ·····         ····
● 變量     / POU/I:       ●     ●    <
幫助信息,請按FI



**RS-485 Networks** 

# A.1 RS-485 Networks

EIA RS-485 is the industry's most widely used bidirectional, balanced transmission line standard. It is specifically developed for industrial multi-drop systems that should be able to transmit and receive data at high rates or over long distances.

The specifications of the EIA RS-485 protocol are as follows:

- Maximum line length per segment: 1200 meters (4000 feet)
- Throughput of 10 Mbaud and beyond -Differential transmission
- (balanced lines) with high resistance against noise
- Maximum 32 nodes per segment
- Bi-directional master-slave communication over a single set of twisted-pair cables
- Parallel connected nodes, true multi-drop

ADAM-5560 Series Controller is fully isolated and use just a single set of twisted pair wires to send and receive! Since the nodes are connected in parallel they can be freely disconnected from the host without affecting the functioning of the remaining nodes. An industry standard, shielded twisted pair is preferable due to the high noise ratio of the environment. When nodes communicate through the network, no sending conflicts can occur since a simple command/response sequence is used. There is always one initiator (with no address) and many slaves (with addresses). In this case, the master is a personal computer that is connected with its serial, RS-232, port to an ADAM RS-232/RS-485 converter. The slaves are the ADAM-5560 Series Controller. When systems are not transmitting data, they are in listen mode. The host computer initiates a command/response sequence with one of the systems. Commands normally contain the address of the module the host wants to communicate with. The system with the matching address carries out the command and sends its response to the host.

### A.2 Basic Network Layout

Multi-drop RS-485 implies that there are two main wires in a segment. The connected systems tap from these two lines with so called drop cables. Thus all connections are parallel and connecting or discon- necting of a node doesn't affect the network as a whole. Since ADAM-5560 Series Controller use the RS-485 standard, they can connect and communicate with the host PC. The basic layouts that can be used for an RS-485 network are:

### Daisychain

The last module of a segment is a repeater. It is directly connected to the main-wires thereby ending the first segment and starting the next segment. Up to 32 address-able systems can be daisychained . This limitation is a physical one. When using more systems per segment the IC driver current rapidly decreases, causing communication errors. In total, the network can hold up to 64 addressable systems. The limitation on this number is the two-character hexadecimal address code that can address 64 combinations. The ADAM converter, ADAM repeaters and the host computer are non addressable units and therefore are not included in these numbers.



Figure A.1 Daisychaining

### Star Layout

In this scheme the repeaters are connected to drop-down cables from the main wires of the first segment. A tree structure is the result. This scheme is not recommended when using long lines since it will cause a serious amount of signal distortion due to signal reflections in several line-endings.





#### Random

This is a combination of daisychain and hierarchical structure.



Figure A.3 Random structure

### A.3 Line Termination

Each discontinuity in impedance causes reflections and distortion. When a impedance discontinuity occurs in the transmission line the immediate effect is signal reflection. This will lead to signal distortion. Specially at line ends this mismatch causes problems. To eliminate this discontinuity, terminate the line with a resistor.



**Figure A.4 Signal Distortion** 

The value of the resistor should be a close as possible to the charac- teristic impedance of the line. Although receiver devices add some resistance to the whole of the transmission line, normally it is sufficient to the resistor impedance should equal the characteristic impedance of the line. **Example:** Each input of the receivers has a nominal input impedance of 18 k feeding into a diode transistor- resistor biasing network that is equivalent to an 18 k input resistor tied to a common mode voltage of 2.4 V. It is this configuration, which provides the large common range of the receiver required for RS-485 systems! (See Figure D-5 below).



Figure A.5 Termination Resistor Locations

Because each input is biased to 2.4 V, the nominal common mode voltage of balanced RS-485 systems, the 18 k on the input can be taken as being in series across the input of each individual receiver. If thirty of these receivers are put closely together at the end of the transmission line, they will tend to react as thirty 36k resistors in parallel with the termination resistor. The overall effective resistance will need to be close to the characteristics of the line. The effective parallel receiver resistance RP will therefore be equal to:

 $R_P = 36 \times 10^3 / 30 = 1200 \Omega$ 

While the termination receptor RT will equal:

 $R_{T} = R_{O} / [1 - R_{O}/R_{P}]$ 

Thus for a line with a characteristic impedance of 100 resistor  $R_T = 100/[1 - 100/(1 - 100)] = 110\Omega$ 

Since this value lies within 10% of the line characteristic impedance.

Thus as already stated above the line termination resistor RT will normally equal the characteristic impedance  $Z_0$ . The star connection causes a multitude of these discontinuities since there are several transmission lines and is therefore not recommend.

### Note!

The recommend method wiring method, that causes a minimum amount of reflection, is daisy chaining where all receivers tapped from one transmission line needs only to be terminated twice.

# A.4 RS-485 Data Flow Control

The RS-485 standard uses a single pair of wires to send and receive data. This line sharing requires some method to control the direction of the data flow. RTS (Request To Send) and CTS (Clear To Send) are the most commonly used methods.



#### Intelligent RS-485 Control

ADAM-4510 and ADAM-4520 are both equipped with an I/O circuit which can automatically sense the direction of the data flow. No handshaking with the host (like RTS, Request to Send) is necessary to receive data and forward it in the correct direction. You can use any software written for half-duplex RS-232 with an ADAM network without modification. The RS-485 control is completely transparent to the user.


**Grounding Reference** 

# **B.1 Field Grounding and Shielding Applications**

Unfortunately, it's impossible to finish a system integration task at one time. We always meet some trouble in the field. A communication network or system isn't stable, induced noise or equipment is damaged or there are storms. However, the most usual issue is just simply improper wiring, ie, grounding and shielding. You know the 80/20 rule in our life: we spend 20% time for 80% work, but 80% time for the last 20% of the work. So is it with system integration: we pay 20% for Wire / Cable and 0% for Equipment. However, 80% of reliability depends on Grounding and Shielding. In other words, we need to invest more in that 20% and work on these two issues to make a highly reliable system. This application note brings you some concepts about field grounding and shielding. These topics will be illustrated in the following pages.

## **B.2 Grounding**

#### **B.2.1** The 'Earth' for reference



Figure B.1 Think the EARTH as GROUND

As you know, the EARTH cannot be conductive. However, all build- ings lie on, or in, the EARTH. Steel, concrete and associated cables (such as lighting arresters) and power system were connected to EARTH. Think of them as resistors. All of those infinite parallel resistors make the EARTH as a single reference point.

#### **B.2.2** The 'Frame Ground' and 'Grounding Bar'



Figure B.2 Grounding Bar

Grounding is one of the most important issues for our system. Just like Frame Ground of the computer, this signal offers a reference point of the electronic circuit inside the computer. If we want to communicate with this computer, both Signal Ground and Frame Ground should be connected to make a reference point of each other's electronic circuit. Generally speaking, it is necessary to install an individual grounding bar for each system, such as computer networks, power systems, telecommunication networks, etc. Those individual grounding bars not only provide the individual reference point, but also make the earth a our ground!

### Normal Mode & Common Mode



Normal Mode: refers to defects occurring between the live and neutral conductors. Normal mode is sometimes abbreviated as NM, or L -N for live - to-neutral. Common Mode: refers to defects occurring between alther conductor and ground. It is sometimes abbreviated as CM, or N-G for neutral - to-ground.

#### Figure B.3 Normal and Common Modes

#### **B.2.3 Normal Mode and Common Mode**

Have you ever tried to measure the voltage between a live circuit and a concrete floor? How about the voltage between neutral and a concrete floor? You will get nonsense values. 'Hot' and 'Neutral' are just relational signals: you will get 110VAC or 220VAC by measuring these signals. Normal mode and common mode just show you that the Frame Ground is the most important reference signal for all the systems and equipments.



Figure B.4 Normal and Common Modes

- Ground-pin is longer than others, for first contact to power system and noise bypass.
- Neutral-pin is broader than Live-pin, for reducing contact imped- ance.

#### **B.2.4 Wire Impedance**



Referring to <u>OHM rule</u>, above diagram shows that how to reduce the power loss on cable.

Figure B.5 High Voltage Transmissions

What's the purpose of high voltage transmissions? We have all seen high voltage transmission towers. The power plant raises the voltage while generating the power, then a local power station steps down the voltage. What is the purpose of high voltage transmission wires ? According to the energy formula, P = V \* I, the current is reduced when the voltage is raised. As you know, each cable has impedance because of the metal it is made of. Referring to Ohm's Law, (V = I \* R) this decreased current means lower power losses in the wire. So, high voltage lines are for reducing the cost of moving electrical power from one place to another.



Figure B.6 Wire Impedance

### **B.2.5 Single Point Grounding**



Figure B.7 Single Point Grounding (1)

What's Single Point Grounding? Maybe you have had an unpleasant experience while taking a hot shower in Winter. Someone turns on a hot water faucet somewhere else. You will be impressed with the cold water! The bottom diagram above shows an example of how devices will influence each other with swift load change. For example, normally we turn on all the four hydrants for testing. When you close the hydrant 3 and hydrant 4, the other two hydrants will get more flow. In other words, the hydrant cannot keep a constant flow rate.



Figure B.8 Single Point Grounding (2)

The above diagram shows you that a single point grounding system will be a more stable system. If you use thin cable for powering these devices, the end device will actually get lower power. The thin cable will consume the energy.

## **B.3 Shielding**

#### **B.3.1 Cable Shield**



Figure B.9 Single Isolated Cable

Single isolated cable The diagram shows the structure of an isolated cable. You see the isolated layer which is spiraled Aluminum foil to cover the wires. This spiraled structure makes a layer for shielding the cables from external noise.

### **Double Isolated Cable**



Figure B.10 Double Isolated Cable

Double isolated cable Figure 10 is an example of a double isolated cable. The first isolating layer of spiraled aluminum foil covers the conductors. The second isolation layer is several bare conductors that spiral and cross over the first shield layer. This spiraled structure makes an isolated layer for reducing external noise. Additionally, follow these tips just for your reference.

- The shield of a cable cannot be used for signal ground. The shield is designed for carrying noise, so the environment noise will couple and interfere with your system when you use the shield as signal ground.
- The higher the density of the shield the better, especially for communication network.
- Use double isolated cable for communication network / AI / AO.
- Both sides of shields should be connected to their frame while inside the device. (for EMI consideration)
- Don't strip off too long of plastic cover for soldering.

### **B.3.2 System Shielding**



Figure B.11 System Shielding

- Never stripping too much of the plastic cable cover. This is improper and can destroy the characteristics of the Shielded-Twisted-Pair cable. Besides, the bare wire shield easily conducts the noise.
- Cascade these shields together by soldering. Please refer to follow- ing page for further detailed explanation.
- Connect the shield to Frame Ground of DC power supply to force the conducted noise to flow to the frame ground of the DC power supply. (The 'frame ground' of the DC power supply should be connected to the system ground)



Don t strip off too long of plastic cover for soldering, or will influence the characteristic of twistedpair cable.

Figure B.12 Cable Characteristics

The characteristic of the cable Don't strip off too much insulation for soldering. This could change the effectiveness of the Shielded-Twisted-Pair cable and open a path to introduce unwanted noise.

### System Shielding



### A difficult way for signal.

Figure B.13 System Shielding (1)

#### Shield connection (1)

If you break into a cable, you might get in a hurry to achieve your goal. As in all electronic circuits, a signal will use the path of least resis- tance. If we make a poor connection between these two cables we will make a poor path for the signal. The noise will try to find another path for easier flow.



- Figure B.14 System Shielding (2)
- Shield Connection (2) The previous diagram shows you that the fill soldering just makes an easier way for the signal.

# **B.4 Noise Reduction Techniques**

- Isolate noise sources in shielded enclosures.
- Place sensitive equipment in shielded enclosure and away from computer equipment.
- Use separate grounds between noise sources and signals.
- Keep ground/signal leads as short as possible.
- Use Twisted and Shielded signal leads.
- Ground shields on one end ONLY while the reference grounds are not the same.
- Check for stability in communication lines.
- Add another Grounding Bar if necessary.
- The diameter of power cable must be over 2.0 mm<sub>2</sub>.
- Independent grounding is needed for A/I, A/O, and communication network while using a jumper box.
- Use noise reduction filters if necessary. (TVS, etc)
- You can also refer to FIPS 94 Standard. FIPS 94 recommends that the computer system should be placed closer to its power source to eliminate loadinduced common mode noise.

#### Noise Reduction Techniques



Separate Load and Device power. Cascade amplify/isolation circuit before I/O channel.

#### Figure B.15 Noise Reduction Techniques

### **B.5 Check Point List**

- Follow the single point grounding rule?
- Normal mode and common mode voltage?
- Separate the DC and AC ground?
- Reject the noise factor?
- The shield is connected correctly?
- Wire size is correct?
- Soldered connections are good?
- The terminal screw are tight?



**Reference Documents** 

Following resources are helpful for understanding how to use Multiprog Software and IEC-61131-3 programming languages.

## **C.1** Reference Documents

- Multiprog Quick Start Manual
- Multiprog User's Manual
- Mulitprog On-line Help
- ADAM-5550KW Series User's Manual (under Advantech Multiprog CD-ROM "Documentation" directory)
- ADAM-5000 I/O Module User"s Manual (under Advantech Multiprog CD-ROM "Documentation" directory)

# **C.2** Topics for Getting Familiar with Multiprog

- User Interfaces
- Basic Project Handling
- Text Editor, Graphical Editor and Edit Wizard
- Developing a Project
- Understanding the Architecture of Project
- POUs
- Instantiate
- Task
- IEC-61131-3 Programming Languages
- Function Blocks and Functions
- PLC Help



### www.advantech.com

Please verify specifications before quoting. This guide is intended for reference purposes only.

All product specifications are subject to change without notice.

No part of this publication may be reproduced in any form or by any means, electronic, photocopying, recording or otherwise, without prior written permission of the publisher.

All brand and product names are trademarks or registered trademarks of their respective companies.

© Advantech Co., Ltd. 2014