

See your user's guide – for more information about using your dock, visit www.kodak.com/go/hdtvdocksupport.

Remote control




Remove the tab to start using the remote.




Button	Press to
ON/OFF	turn on/off the HDTV dock.
DISPLAY	turn on/off picture/video status information bar.
Home	return to the home screen.
BACK	return to the previous screen. stop a slide show, display thumbnails.
MENU	display menu choices.
OK	accept the current selection.
4-way	navigate through pictures or menus.
ZOOM +	increase picture magnification.
ZOOM -	decrease picture magnification.
✓	select mark pictures for an operation.
SLIDE	play a slide show.
▶	play/pause play/pause a video or slide show.
◀◀	rewind fast rewind a video.
▶▶	fast forward fast forward a video.
■	stop stop a video, display the first frame. stop a slide show, display thumbnails.
PAGE UP	display the previous page of images.
PAGE DOWN	display the next page of images.



Front/Side View




- | | |
|-------------------------|------------------------------|
| 1 Remote control sensor | 4 Memory card slot - SD, MMC |
| 2 Charging light | 5 USB connector |
| 3 Power light | 6 Dock connector |

Back View




- | | |
|------------------------|---|
| 1 USB connector | 3 Audio out connectors |
| 2 Video out connectors | 4 DC-In (5 V)    |


1 Connecting the dock power, HDTV



2 Inserting a card or USB device



3 Attaching the camera insert




4 Turning on the dock; Home screen

Press
ON/OFF.




-OR-




Power light

Make sure the camera is set to the appropriate regional format (NTSC or PAL). See your camera user's guide for details.

The Home screen appears.
(Use the remote control buttons to make your selections.)

Press  then OK to choose an Input Source.






Thumbnails
(pictures/videos/
folders on a
selected Input
Source)


Note: Devices connected to the dock are listed as Input Sources.
Press BACK to move between the Input Source list and thumbnails window.

5 Setting your language

On the remote control:

- 1 Press MENU.
- 2  to highlight Settings, press OK.
- 3  to highlight Language, press OK.
- 4  to select your language, press OK.




6 Charging the camera battery



- 1 Connect the dock power.
- 2 Insert the battery in the camera (Kodak Ni-MH or Li-Ion rechargeable battery). Turn off the camera.
- 3 Place the camera on the dock.

Charging begins. Full charging takes up to 3 hours.

Charging light:


Blinking green 	Charging
Steady green 	Fully charged
Blinking red 	Error, see Troubleshooting


1

Working with pictures/videos

Viewing pictures and videos

Use your high definition television to view pictures and videos from a docked camera (see [page 5](#)), memory card, or USB drive (see [page 4](#)).

- The Home screen displays your pictures and videos as thumbnails (see [page 5](#)).
- Use the remote control  and OK buttons to navigate through your pictures/videos and to make your selections.



Home screen features

Input sources



Camera



SD card



USB device

Pictures, videos and folders are displayed from:

The camera that's placed on the dock.

A card inserted in the dock memory card slot.

A USB device (flash drive, card reader, etc.) inserted in the dock USB connectors. Each device is shown as a separate source. Each card in a card reader is shown as a separate USB device. The device inserted into the side USB connector is shown first.

Icons on thumbnails



Video (see [page 8](#))



Picture has a sound tag (see [page 9](#))



Multimedia slide show (see [page 8](#))



Selected picture/video/folder (see [page 11](#))




View-only Favorites (see your camera user's guide)

Thumbnails view








- To navigate through the thumbnails, press
- To play a video (), highlight the video thumbnail, then press OK. Press or OK when the first frame appears (single view).

- To play a multimedia slide show (), highlight an MMS folder, then press OK.
- To view folder contents, highlight the folder, then press OK.

NOTE: Press BACK to move between the Input Source list and thumbnails window.

Single view










Begin working with your pictures and videos in Single view.

- **To view** a single, full-screen picture, highlight the thumbnail, then press OK.
- **To magnify** a picture 2X - 4X, press ZOOM+. Press ZOOM- to return to 1X. To view other parts of the picture, press .
- **To play a sound tag** () that is associated with a picture, press .
- Press DISPLAY to turn on/off the picture information.
- Press  to view previous/next picture.
- Press BACK or  to return to the Home screen.


Using the menu

Use the Menu button on the remote control to work with your pictures/videos and change your dock settings.

Display in Single view and press MENU to:

- **Rotate** a picture. Press  to highlight a rotation option (Clockwise or Counterclockwise), then press OK. You can only rotate pictures that are unprotected and are larger than 2.0 MP.
- **Enhance** a picture. See [page 12](#).
- **Crop** a picture. Press  to highlight Crop, then press OK. Press the ZOOM buttons to size the crop box and press  to move it. Press OK. You can only crop pictures that are larger than 2.0 MP.
- **Print** a picture. (Available when a printer is connected to your dock.) See [page 14](#).
- **Make picture**. (Available for videos only). See [page 12](#).
- **Copy** a picture/video to another connected device. Press  to highlight Copy, then press OK. Press  to highlight the location you want to copy to, then press OK.
- **Protect/Unprotect** a picture/video from deletion. Press  to highlight Protect (or Unprotect), then press OK.
- **Delete** a picture/video. Press  to highlight Delete, then press OK. Press  to highlight your choice, then press OK. Press  to highlight Yes, then press OK.

Press MENU, then Settings to change:


- **Slide show duration.** See [page 13](#).
- **Language.** See [page 6](#).
- **Video Out resolution** (HDTV output format). Press  to highlight 720p or 1080i, then press OK.

About displays your dock model number and firmware version.


Selecting pictures/videos

Use the multi-select feature to copy, delete, or protect two or more pictures/videos.

Selecting one at a time




- 1 In thumbnails view, press  to highlight a picture/video, then press .
- 2 Continue selecting pictures/videos.
A check mark appears on the selected pictures. Press  again to remove a check mark.

Selecting all

- 1 Press the MENU button after accessing the Home screen (see [page 5](#)).
- 2 Press  to highlight Select All, then press OK.
A check mark appears on all pictures/videos in your current location.
To remove the check marks, press MENU, highlight Unselect all, then press OK.


Using Kodak Perfect Touch technology


Kodak Perfect Touch technology helps to ensure better, brighter pictures, and can only be applied to pictures that are larger than 2.0 MP.

- 1 In single picture view, press MENU.
- 2 Press  to highlight KPT, then press OK.
A confirmation message then a split screen with the original and the enhanced image appear.
- 3 Press  to highlight your preference (the Original or the Kodak Perfect Touch image), then press OK.
- 4 Press  to view other parts of the picture.
- 5 Press OK. Follow the screen prompts to replace the original picture or to save the enhanced picture as a new one.

Making a picture from a video

You can choose a single frame from a video, then save it as a new picture.





- 1 Press  on the remote control to pause the video.
- 2 Press the Menu button.
- 3 Highlight Make Picture, then press OK.

Running a slide show

- To start a slide show from any selected picture (in thumbnail or single view), press the SLIDE button.
- To pause a slide show, press ►||. Press again to play.
- To end a slide show, press ■.

Changing the slide show display interval


The default interval setting displays each picture for 5 seconds. You can set the display interval at 3, 5, 10, 15, 30, or 60 seconds.



- 1 On the Slide Show menu, press  to highlight Interval, then press OK.
- 2 Press  to highlight a display interval, then press OK.

NOTE: The interval setting remains until you change it.

Printing pictures

You can print pictures from a docked camera, memory card, or USB device such as a flash drive (see [page 4](#)). Printing is available only for images larger than 2.0 MP.



- 1 Turn on the dock (see [page 5](#)).
- 2 Connect the USB cable from the dock to the printer.
- 3 Turn on the printer.
- 4 Select a picture in Single view (see [page 9](#)), then press MENU.
- 5 Press  to highlight Print, then press OK.
- 6 Press  to select the print quantity (1-39), then press OK to begin printing.
To cancel printing, press BACK.

Learning more about your dock

www.kodak.com/go/hdtvdock

www.kodak.com/go/hdtvdocksupport

dock accessories

Extended user's guide

Interactive troubleshooting and repairs

Interactive tutorials

FAQs

Downloads


Product registration

2

Solving HDTV dock problems

For step-by-step product support, visit www.kodak.com/go/hdtvdocksupport and select Interactive Troubleshooting & Repairs.

HDTV dock problems

If...	Try one or more of the following
Dock does not turn on.	<ul style="list-style-type: none"> ■ Make sure the power cable that was included with your dock is securely connected (see page 3). ■ Make sure you are pressing the ON/OFF power button on the remote control.
Remote control does not function.	<ul style="list-style-type: none"> ■ Change the remote control battery: CR2025, 3V lithium cell.  <p style="text-align: center;">Release tab (push down and hold while sliding out the battery holder)</p> <p style="text-align: center;">Battery</p> <p style="text-align: center;">Battery holder (slide in until it clicks)</p>
Dock does not recognize memory card.	<ul style="list-style-type: none"> ■ Insert a certified SD/MMC card into the slot, then push to seat (see page 4). For certified card reader memory cards, see its user's guide.

3 Appendix

Important safety instructions

CAUTION:

Do not disassemble this product; there are no user-serviceable parts inside. Refer servicing to qualified service personnel. Kodak AC adapters and battery chargers are intended for indoor use only. The use of controls, adjustments, or procedures other than those specified herein may result in exposure to shock and/or electrical or mechanical hazards.

- The use of an accessory that is not recommended by Kodak may cause fire, electric shock, or injury. For approved accessories, visit www.kodak/go/accessories.
- Use only a USB-certified computer equipped with a current-limiting motherboard. Contact your computer manufacturer if you have questions.
- When removing the battery from the remote, allow it to cool; it may be hot.
- Follow all warnings and instructions supplied by the battery manufacturer.
- Use only batteries approved for this product to avoid risk of explosion.
- Keep batteries out of the reach of children.
- Do not allow batteries to touch metal objects, including coins. Otherwise, a battery may short circuit, discharge energy, become hot, or leak.
- Do not disassemble, install backward, or expose batteries to liquid, moisture, fire, or extreme temperature.
- Remove the battery when the product is stored for an extended period of time. In the unlikely event that battery fluid leaks inside the product, contact Kodak customer support.
- In the unlikely event that battery fluid leaks onto your skin, wash immediately with water and contact your local health provider. For additional health-related information, contact your local Kodak customer support.
- Dispose of batteries according to local and national regulations. Visit www.kodak.com/go/kes.
- Do not charge non-rechargeable batteries.

For more information on batteries, visit www.kodak.com/go/batterytupes.

- Remote control battery may include perchlorate material. Special handling may apply in California.
- Read and follow all warnings and instructions supplied by the battery manufacturer.

Additional care and maintenance

- Wipe the dock gently with a soft, lint-free cloth. Do not allow chemicals, such as suntan lotion, to contact painted surfaces.
- Service agreements are available in some countries. Contact a dealer of Kodak products for more information.
- For HDTV dock disposal or recycling information, contact your local authorities. In the US, visit the Electronics Industry Alliance Web site at www.eiae.org or visit www.kodak.com/go/hdtdocksupport.

Limited warranty

Kodak warrants Kodak consumer electronic products and accessories ("Products"), excluding batteries, to be free from malfunctions and defects in both materials and workmanship for one year from the date of purchase. Retain the original dated sales receipt. Proof of the date of purchase will be required with any request for warranty repair.

Limited warranty coverage

Warranty service is only available from within the country where the Products were originally purchased. You may be required to ship Products, at your expense, to the authorized service facility for the country where the Products were purchased. Kodak will repair or replace Products if they fail to function properly during the warranty period, subject to any conditions and/or limitations stated herein. Warranty service will include all labor as well as any necessary adjustments and/or replacement parts. If Kodak is unable to repair or replace a Product, Kodak will, at its option, refund the purchase price paid for the Product provided the Product has been returned to Kodak along with proof of the purchase price paid. Repair, replacement, or refund of the purchase price are the sole remedies under the warranty. If replacement parts are used in making repairs, those parts may be remanufactured, or may contain remanufactured materials. If it is necessary to replace the entire Product, it may be replaced with a remanufactured Product. Remanufactured Products, parts and materials are warranted for the remaining warranty term of the original Product, or 90 days after the date of repair or replacement, whichever is longer.

Limitations

This warranty does not cover circumstances beyond Kodak's control. This warranty does not apply when failure is due to shipping damage, accident, alteration, modification, unauthorized service, misuse, abuse, use with incompatible accessories or attachments, failure to follow Kodak's operation, maintenance or repacking instructions, failure to use items supplied by Kodak (such as adapters and cables), or claims made after the duration of this warranty. Kodak makes no other express or implied warranty for this product, and disclaims the implied warranties of merchantability and fitness for a particular purpose. In the event that the exclusion of any implied warranty is ineffective under the law, the duration of the implied warranty will be one year from the purchase date or such longer period as required by law. The option of repair, replacement, or refund is Kodak's only obligation. Kodak will not be responsible for any special, consequential or incidental damages resulting from the sale, purchase, or use of this product regardless of the cause. Liability for any special, consequential or incidental damages (including but not limited to loss of revenue or profit, downtime costs, loss of the use of the equipment, cost of substitute equipment, facilities or services, or claims of your customers for such damages resulting from the purchase, use, or failure of the Product), regardless of cause or for breach of any written or implied warranty is expressly disclaimed.

Your rights

Some states or jurisdictions do not allow exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. Some states or jurisdictions do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. This warranty gives you specific rights, and you may have other rights which vary from state to state or by jurisdiction.

Outside the United States and Canada

In countries other than the United States and Canada, the terms and conditions of this warranty may be different. Unless a specific Kodak warranty is communicated to the purchaser in writing by a Kodak company, no warranty or liability exists beyond any minimum requirements imposed by law, even though defect, damage, or loss may be by negligence or other act.

FCC compliance and advisory

Kodak EasyShare HDTV dock

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful

interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed or used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Where shielded interface cables have been provided with the product or specified additional components or accessories elsewhere defined to be used with the installation of the product, they must be used in order to ensure compliance with FCC regulation.

FCC and Industry Canada

This device complies with Industry Canada RSS-210 and FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

MPEG-4

Use of this product in any manner that complies with the MPEG-4 visual standard is prohibited, except for use by a consumer engaging in personal and non-commercial activities.

Canadian DOC statement

DOC Class B Compliance—This Class B digital apparatus complies with Canadian ICES-003.

Observation des normes-Classe B—Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Australian C-Tick



N137

Waste Electrical and Electronic Equipment labeling



In Europe: For human/environmental protection, it is your responsibility to dispose of this equipment at a collection facility established for this purpose (separate from municipal waste). For more information, contact your retailer, collection facility, or appropriate local authorities; or visit www.kodak.com/go/recycle. (Product weight: 170 g.)

Kodak

Eastman Kodak Company

Rochester, New York 14650

© Eastman Kodak Company, 2007

Kodak, EasyShare, and Perfect Touch are trademarks of Eastman Kodak Company.

Eastman Kodak Company is an authorized licensee of the CompactFlash trademark.

2F6571_en