


WASHER-DRYER ZWD 1682 W



Quick Installation Guide:
visit our WEB SITE to view an install video
www.video.uk.electrolux.com

Important Safety Information

It is most important that this instruction book should be retained with the appliance for future reference. Should the appliance be sold or transferred to another owner, or should you move house and leave the appliance, always ensure that the book is supplied with the appliance in order that the new owner can get to know the functioning of the appliance and the relevant warnings.

These warnings have been provided in the interest of safety. You MUST read them carefully before installing or using the appliance.

Installation

- This appliance is heavy. Care should be taken when moving it.
- It is dangerous to alter the specifications or attempt to modify this product in any way.
- All packing and transit bolts must be removed before use. Serious damage can occur to the product and to property if this is not adhered to. See relevant section in instructions.
- Any plumbing work required to install this appliance should be carried out by a qualified plumber or competent person.
- Any electrical work required to install this appliance should be carried out by a qualified electrician or competent person.
- Care must be taken to ensure that the appliance does not stand on the electrical supply cable.
- If the machine is situated on a carpeted floor, please adjust the feet in order to allow air to circulate freely.

Child Safety

- This appliance is designed to be operated by adults. Children should not be allowed to tamper with the controls or play with the product.
- Pets and children have been known to climb into washer-dryers. Please check your drum before use.
- The glass door becomes very hot during the washing and drying cycle. Keep children away from the vicinity of the appliance whilst it is in operation.
- Keep all packaging well away from children.
- Keep all detergents in a safe place out of children's reach.

Use

- Always unplug the appliance and turn off the water supply after use.
- Do not overload the appliance. See relevant section in the instruction book.
- Only wash and dry fabrics which are designed to be machine washed and dried. If in doubt, consult the care label on the clothes.

- Before washing, ensure that all pockets are empty and buttons and zips are fastened. Avoid washing frayed or torn articles and treat stains such as paint, ink, rust, and grass before washing. Underwired bras must NOT be machine washed.
- Any objects such as coins, safety pins, nails, screws, stones or any other hard, sharp material can cause extensive damage and must not be placed into the machine.
- Garments which have been in contact with volatile petroleum products should not be machine washed. If volatile cleaning fluids are used, care should be taken to ensure that the fluid is removed from the garment before placing in the machine.
- Wash small items such as socks, laces, washable belts etc in a washing bag or pillow case as it is possible for such items to slip down between the tub and the inner drum.
- Only use the advised quantities of fabric softener. Damage to the fabric can ensue if you over-fill. Refer to the manufacturer's recommendations of quantities.
- As some duvets and eiderdowns should be washed/dried in large commercial machines because of their bulk, please check with the manufacturer of the item before washing in a domestic machine.
- The users should always check that they have not left their gas lighters (disposable or otherwise) in their clothing.
- Never tumble dry items that have had contact with chemicals such as dry cleaning fluid. These are of a volatile nature and could cause an explosion. Only tumble dry items which have been washed in water or require airing.
- Plastic detergent dispensers should not remain in the drum during the drying cycle, as the plastic used is not designed to withstand the heat. If you wish to wash-through-to-dry you should use the conventional detergent dispenser drawer.
- Leave the porthole door slightly ajar between washes to preserve the door seal.
- Under no circumstances should you attempt to repair the machine yourself. Repairs carried out by inexperienced persons may cause injury or serious malfunctioning. Contact your local Service Force Centre. Always insist on genuine spare parts.

Contents

For the User		Special Programmes	18
Important Safety Information	2	Drying Programmes	19
-		Maintenance and Cleaning	20-21
Your New Washer-Dryer	4	Descaling	20
Description of the Appliance	5	After each wash	20
Detergent dispenser drawer	5	Maintenance wash	20
Child safety feature	5	External cleaning	20
The Control Panel	6-9	Cleaning the dispenser drawer	20
Programma information	9	Cleaning the drawer recess	20
Programme information	9	Cleaning the pump	20-21
Operating Sequence	10-12	Cleaning the water inlet filter	21
Washing	10	The dangers of freezing	21
Load the laundry	10	Emergency emptying out	21
Measure out the detergent	10	Something Not Working	22-23
Measure out the fabric softener	10	9	_
Select the required programme/fabric	10	Service and Spare Parts	23-24
Select the temperature	10	Guarantee Conditions	24
Select the spin speed or the "Rinse Hold" option Select the desired options	10 11		
Select the "Delay Start"	11	For the Installer	
Start the programme	11		
How to change an option or a programme		Installation Instructions	25
during its cycle	11	Technical Specifications	25
How to cancel a programme during its cycle	11	Unpacking	26
How to open the door during the cycle of		Positioning	26
a programme	11	Water inlet	27
End of programme	12	Water drainage	27-28
Drying 3 kg of cotton	12-13	Levelling	28
Autodrying 2 kg of synthetics	13	Special conditions	28
Washing and Drying Hints	14	In the interest of the environment	28-29
Which detergent to use?	15	Electrical connection	29
And in which form?	15	Permanent connection	29
Wash Care Symbols	16		
Washing Programmes	17		

Guide to use the Instruction Book

The following symbols will be found in the text to guide you throughout the instructions:

 \triangle Safety instructions

i Hints and tips

Environmental information

i Your New Washer-Dryer

This new machine, which is fitted with the New Jet System, meets all modern requirements for effective treatment of laundry with low water, energy and detergent consumption.

Even small loads are washed "economically" because the amount of water used is regulated automatically according to the load and type of fabric.

- The special wool programme with its new delicate wash system treats your woollens with extreme care.
- The balance control device ensures that the machine remains stable when spinning.
- Automatic cooling of the wash water to 60°C before draining, with the 95°C programme. This reduces thermal shock to fabrics, helping to prevent creasing
- The two drying programmes will give your wash that soft, relaxed feel whatever the weather.

Ecological hints

To save water and energy and help protect the environment, we recommend that you follow these hints:

- Adjust the quantity of detergent according to the hardness of your water supply, the amount of laundry and the degree of soiling.
- Select the "Economy" programme for lightly soiled laundry.
- A programme without prewash is sufficient for normally soiled laundry.
- Try to load the maximum drying capacity of the machine as small loads are **uneconomical**.
- Always load well spun laundry. The higher the spin speed, the lower the electricity consumption and the shorter the drying times.

In the interest of the environment

- Materials marked with the symbol
 are recyclable.
- Check with your local Council or Environmental Health Office to see if there are facilities in your area for re-cycling this appliance.
- When the appliance is to be scrapped, cut off the power supply cable and make the door lock device unusable to prevent young children from being trapped inside.
- Help to keep your country tidy use authorised disposal sites for your old appliance.

The symbol on the product or on its packaging indicates that this product may not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.


How do we help to protect the environment? We use recycled paper!

Important

Your machine is fitted with a balance control device, which ensures the machine is stable during the spin. If the wash load appears not to have been spun sufficiently at the end of the wash cycle, it is because it is not evenly distributed in the drum, the balance control device may have operated. It will therefore be necessary to redistribute the wash load manually and select a spin programme. For more detailed information see the section headed "Something Not Working".

Description of the Appliance

- 1 Detergent dispenser drawer
- 2 Control Panel
- 3 Door opening handle
- 4 Drain pump
- 5 Adjustable feet




Detergent dispenser drawer

L Prewash

Ⅲ Main wash

S Fabric softener




Child safety feature


This machine incorporates a special child safety feature to prevent small children from being trapped inside the machine.

To activate this device, rotate the button (without pressing it) inside the door clockwise until the groove is horizontal. If necessary use a coin.

To disable this device and restore the possibility of closing the door, rotate the button anti-clockwise until the groove is vertical.




The Control Panel



I Programme selector dial

The selector is divided into the following sections:

- Cottons (Whites/Coloureds)
- Synthetics
- Delicates
- Handwash
- Wool
- Special programmes (from "Mini 30"... to "Gentle Spin")
- **Off** = Reset programme/Switching the machine off



Position "Cottons Eco" at 60°C and 40°C corresponds to the ENERGY SAVING programme, position "**Dry**" corresponds to the drying programme.

Turn the dial **clockwise or anticlockwise** to select the required wash and drying programme.

Before setting the dial to any position ensure that the machine is switched off.

IMPORTANT!

At the end of the programme the selector dial must be turned to position "Off".

2 "Temp." button

Press this button repeatedly to increase or decrease the temperature, if you want your laundry to be washed at a temperature different from the one proposed by the

washing machine. The relevant light will light up. Maximum temperatures are 95°C for white cotton, 60°C for synthetic fabrics and Cottons Coloureds, 40°C for delicate fabrics, Synthetics Eco, Wool and fabrics to be hand-washed, 30°C for «Mini 30», while $\frac{1}{X}$ corresponds to cold wash.

3 "Spin Speed" button

Press this button repeatedly to change the spin speed, if you want your laundry to be spun at a speed different from the one proposed by the machine. The relevant light will light up.

The following speeds are available for the different fabrics.

- Cotton, linen: 700/900/1200 max 1600 r.p.m.
- Synthetics and Wool: 700 max 900 r.p.m.
- Delicate and «Mini 30»: 700 r.p.m.

"Rinse Hold" :

When you choose this option, the machine will not drain the water of the last rinse, so as not to crease the laundry.

At the end of the cycle, the "Start/Pause" button light goes out, the (Rinse Hold) is alight and the door is locked to indicate that the water must be drained. A flashing zero will appears on the display.

To complete the cycle, choose one of the following options:

- Select programme "Drain" and depress the "Start/Pause" button:
 The water is emptied out without spinning.
- Select the programme "Spin" or "Gentle Spin":
 Select the spin speed by means of the relevant button and then depress the "Start/Pause" button.

 After emptying, the machine performs the spin cycle at the speed previously selected.

Attention!

Before selecting programme "**Drain**", **Spin**" or " **Gentle Spin**", the selector dial has to be positioned on **Off** (cancelling).

The Rinse Hold option **cannot** be selected for the automatic WASHING & DRYING programme.

Programme Option buttons

Depending on the programme, different functions can be combined. These must be selected after choosing the desired programme and before depressing the "**Start/Pause**" button.

When these buttons are pressed, the corresponding pilot lights come on. When they are pressed again, the pilot lights go out.

If an incorrect option is selected, the corresponding pilot light flashes for about 2 seconds and the message *Err* is displayed.

4 "Prewash" button

With this option the machine performs a prewash cycle at 30°C max. The prewash cycle ends with a short spin at 650 r.p.m. in programmes for Cottons and Synthetics, and with emptying of the water for Delicate.

This option is **not** available with the Wool, Handwash and the **«Mini 30»**.

For use when washing heavily soiled laundry.

5 "Extra Rinse" button

Can be used with all programmes **except the Wool, Handwash programmes and «Mini 30»**. The machine will add 2 rinses to the Cottons programmes and 1 to the Synthetics and Delicate programmes.

This option is recommended for people who are allergic to detergents and in areas where the water is very soft.

6 "Auto Dry" button

This button allows you to choose the required degree of drying for cottons and synthetics:

- Extra dry (only for cottons)
- Store dry (cottons and synthetics)
- Iron dry (only for cottons)

The relevant light illuminates.

The drying time is automatically adjusted by the machine: the laundry will be dried to the selected degree of dryness.

7 "Drying Time" button

If you wish to carry out a timed programme instead of an electronic programme push the button until the drying time you want appears in the display according to the fabrics (cotton or synthetics) you have to dry.

For **COTTONS** and **SYNTHETICS** you can select a time from 10 minutes to 130 minutes.

At the end of the drying programme, the "**Drying**" pilot light goes out and a flashing zero appears on the display.

8 "Delay Start" button

This button makes it possible to delay the starting of the programme selected from 30 min - 60 min - 90 min, 2 hours and then by 1 hour up to a maximum of 23 hours. The delay you have selected is shown on the display for about 3 seconds; afterwards, the duration of the programme reappears.

You must select this option **after** you have set the programme and **before** you press the "**Start/Pause**" button.

The time value shown on the display will decrease by one unit every hour.

You can change the delay time at any moment, before you press the "Start/Pause" button.

If you have already pressed the "**Start/Pause**" button, and you wish to **cancel** the delay time, proceed as follows:

- set the machine to PAUSE by pressing the "Start/Pause" button;
- press the "Delay Start" button until the display shows the symbol «"".
- press the "Start/Pause" button again.

Important!

• The door will be locked throughout the delay time. If you need to open the door, you must first set the machine to PAUSE by pressing the "Start/Pause" button. After you have closed the door, press the "Start/Pause" button again.

The "Delay Start" cannot be selected with "**Drain**", "**Gentle Spin**" and "**Spin**" programmes.

9 "Start/Pause" button

This button has two functions:

• **Start**: after you have selected the desired programme and options, press this button to start the machine. The light above the button will stop flashing and remain lit.

If you have selected a delay start by means of the "**Delay Start**" button, the countdown will begin and will be shown on the display.

• **Pause**: when you press this button again, the programme in progress is interrupted. The light above the button will start flashing. To restart the programme, press the button again.

Important! You must set the washing machine to PAUSE before you make any change in the programme in progress.

10 Display

The following pieces of information are shown on the display:


• **Duration of washing programme** in hours and minutes, after you have selected a programme (for example 2.05)



The duration is calculated automatically on the basis of the maximum recommended load for each type of fabric.


After the programme has started, the time remaining is updated every minute.

- The washing machine has completed the programme: this is indicated by a flashing zero. The door can be opened.
- The washing machine has stopped with water in the tub, at the end of a programme with the "Rinse Hold" option : this is indicated by a flashing zero. The door is locked.
- Selected drying time in minutes or hours and minutes.




After starting the programme, the remaining time is updated every minute.

• **Delay start**, a time value indicated in hours and selected by means of the relevant button (max 23 hours).



The delay time is displayed for 3 seconds, then the duration of the selected programme reappears. After you have pressed the "**Start/Pause**" button, the countdown begins, and the delay time value decreases by one unit every hour and then, when 2 hours remain, the time decreases in 30 minute intervals. You can delay the start of the selected programme by up to 23 hours in one hour intervals.

• An incorrect option selection has been made: this is indicated by the message *Err* when a function incompatible with the current programme is selected.




• An alarm code indicates a fault in the machine operation (see the relevant chapter on page 22-23).



I I Programme phase indicator lights

When you select a programme, the lights relevant to the phases that form the programme light up.



After you have started the programme, only the light relevant to the phase that is currently being carried out will remain lit.

When the programme has finished, a flashing zero appears on the display .

Programme information

(Handwash

Washing programme for hand washable delicate fabrics with the "hand washing" care symbol 🐠.

M Wool

Specially tested programme for wool garments bearing the "Pure new wool, non-shrink, machine washable" label.

Mini 30

This is a complete programme that can be combined with the following options: (**Rinse hold**) \square and "**Delay Start**".

To be used for laundry which is lightly soiled or which needs freshening up.

Max load 3 kg.

Washing temperature 30°C (2 rinses)

Programme duration 30 minutes

Final spin speed 700 r.p.m.

Rinses

With this programme it is possible to rinse and spin cotton garments which have been washed by hand. The machine performs 3 rinses, followed by a final spin at the max speed.

The spin speed can be reduced by depressing the "**Spin Speed**" button.

Drain

For emptying out the water of the last rinse in programmes with the Rinse Hold option. Turn first the programme selector dial to "Off", then select programme "Drain" and depress the "Start Pause" button.

Spin

Separate long spin at the maximum speed for hand washed garments. To be used for hand washed cotton items. You can reduce the speed by means of "**Spin Speed**" button to adapt it to the fabrics to be spun.

Gentle Spin

Separate short spin at max. 700 rpm. speed for hand washed garments. To be used for synthetic, delicate, wool/ and handwashed, items.

Off

To reset a programme or switch the machine off turn the selector dial to "Off". Now a new programme can be selected.

i Operating Sequence

WASHING only

Before the first wash we recommend that you run a cotton cycle at 95°C, without any laundry in the machine to remove any manufacturing residue from the drum and tub.

Pour 1/2 a measure of detergent into the main wash compartment of the dispenser drawer and start up the machine.

I.Load the laundry

Open the door.

Place the laundry in the drum, one item at a time, shaking them out as much as possible.


Close the door.




2. Measure out the detergent

3. Measure out the fabric softener

If required, pour fabric softener into the compartment marked 8, without exceeding the «MAX» mark.






Close the drawer gently.

4. Select the required programme/fabric


Turn the programme selector dial to the desired position to switch the appliance on, the lights corresponding to the different phases making up the selected programme light on. To switch the appliance off turn it to **Off**.



The "**Start/Pause**" button light flashes. The display shows the duration of the programme.

5. Select the temperature


Press the "**Temp.**" button if you wish to select a temperature value different from the one proposed by the washing machine.



6. Select the spin speed or the Rinse Hold option □

Press the "**Spin Speed**" button repeatedly, in order to select the desired spin speed or the "**Rinse Hold**" option \Box . The relevant light will light up.


If you select the "Rinse Hold" option, the machine will stop at the end of the programme with the water still in the tub.



7. Select the desired options


If your laundry is very dirty, it may be advisable to select the "**Prewash**" option.

If your laundry needs an extra rinse, select the "Extra Rinse" option. The relevant light illuminates.



8. Select the "Delay Start"

Before you start the programme, if you wish the starting to be delayed, press the "**Delay Start**" button repeatedly, or keep it pressed, to select the desired delay. The selected delay time value (up to 23 hours) will appear on the display for 3 seconds, then the duration of the programme will appear again.




9. Start the programme

Press the "Start/Pause" button. The relevant light will stop flashing and only the light relevant to the phase that is in progress will remain lit.

If you have chosen a delayed start, the washing machine will begin the countdown.

The display will show the duration of the programme or the selected delay.



10. How to change an option or a programme during its cycle

Before you make any change, you must pause the machine by pressing the "**Start/Pause**" button. It is possible to change any option before the programme carries it out.

Changing a running programme is possible only by cancelling it and selecting a new programme. Turn the programme selector dial to "Off" and then to the selected programme. Start it by depressing the "Start/Pause" button.

The machine will resume the cycle **from the beginning** and the washing water in the tub will not empty out.

II.How to interrupt a programme

Depress the "**Star/Pause**" button to interrupt a programme which is running, the corresponding light starts to flash.

12. How to cancel a programme during its cycle

Turn the selector dial to "Off" to cancel a programme which is running. Now you can select a new programme.

13. How to open the door during the cycle of a programme

First set the machine to PAUSE by pressing the "**Start/Pause**" button.

If the door does not open, this means that the machine is already heating, that the water level is above the bottom edge of the door or that the drum is turning.

If you cannot open the door but you need to open it you have to switch the machine off by turning the programme selector dial to "**Off" position**.

After about 3 minutes the door can be opened.

Pay attention to the level and temperature of the water in the machine!

After closing the door, turn the programme selector dial to the programme previously selected and start it by depressing the "**Start/Pause**" button.

14. End of the programme

The machine stops automatically, the "Start/Pause" button light goes out and the display shows a flashing zero.

If the Rinse Hold \Box option has been selected, the \Box light remains lit and the door is locked to indicate that the water must be emptied out before opening the door. The display shows a blinking zero.

To complete the cycle, choose one of the following options:

- Select programme "**Drain**" and depress the "**Start/Pause**" button:

 The water is emptied out without spinning.
- Select the programme "Spin" or "Gentle Spin": Select the spin speed by means of the relevant button and then depress the "Start/Pause" button.

 After emptying, the machine performs the spin cycle at the speed previously selected.

Attention!

Before selecting programme "**Drain**", **Spin**" or "**Gentle Spin**", the selector dial has to be positioned on **Off** (cancelling).

When the programme has been completed, a flashing zero appears on the display and it will be possible to open the door.

Turn the programme selector dial to "**Off**" position to switch the machine off.

Remove the laundry from the drum and carefully check that the drum is empty so as to avoid any forgotten items being damaged in a subsequent wash (e.g. shrinking) or their colour running into a load of whites.

If you do not intend to carry out another wash, close the water tap.

Leave the door open to prevent the formation of mildew and unpleasant smells.

DRYING 3 KG OF COTTON


You have for example just machine-washed and spun at 1600 rpm 6 kg of laundry.

They are cotton fabrics of medium weight which you want to iron as soon as they are dry.


Remove the laundry from the appliance and divide the items to obtain two loads of approx. 3 kg each.

The water tap must be open and the drain hose must be positioned in the sink or connected to the drain pipe.


- 1. Load the laundry.
- 2. Turn the programme selector dial to the drying programme "Cottons Dry"
- 3. If you wish to carry out the electronic drying, depress "Auto Dry" button until the light "Iron Dry" illuminates.



If you want a timed drying, depress the "**Drying Time**" button until the time you want appears on the display.



4. Press the "**Start Pause**" button to start the programme.



- 5. At the end of the programme turn the programme selector dial to "Off" to switch the machine off.
- 6. Remove the laundry.

Note:

The programme time will automatically increase by up to 1 minute, this is quite normal.

During drying the door can only be opened for the first 10 minutes and at the end of drying (after the cooling phase).

AUTODRYING 2 KG OF SYNTHETICS

Warning! For NON-STOP programmes, it is also essential not to exceed the maximum load sizes of 3.5 kg for cotton and 2 kg for synthetics.

You intend to wash and dry automatically 2 kg of synthetics which do not need ironing.

Do not use a dosing device/ball when carrying out a washing & drying programme.

- 1. Load the laundry.
- 2. Add detergent and fabric softener.
- **3.** Switch the machine on by turning the selector dial to a programme for Synthetics.
- 4. Select the drying time or degree of drying.

- 5. Select the required options by means of the relevant buttons. If possible, do not select a spin speed lower than that proposed by the appliance to avoid a too long drying time so saving energy.
 In any case the reduction of the spin speed is only possible after selecting drying. The lowest values you can select are the following:
 - 900 r.p.m. for cottons with electronic or timed drying
 - 900 r.p.m. for synthetics with electronic drying or 700 r.p.m. with timed drying
- **6.** Start the programme by depressing the "**Start Pause**" button.
- 7. At the end of the programme turn the programme selector dial to "Off" to switch the machine off.
- **8.** Remove the laundry.

Washing and Drying Hints

Do **NOT** overload the machine. Weigh the laundry the first few times you use the appliance.

The average weights of the most common items are listed below as a guide:

1000g = 1 kg

Sheet	700-1000 g
Pillow case	100-200 g
Tablecloth	400-500 g
Serviette	50-100 g
Tea towel	70-120 g
Linen hand towel	100-150 g
Towelling hand towel	150-250 g
Towelling bath towel	700-1000 g
Bath robe	1000-1500 g
Man's shirt	200-300 g
Apron	150-200 g

- Load the laundry loosely alternating large items with small ones.
- Sort the laundry according to the type of fabric, colour-fastness and how dirty it is.
- Avoid washing unhemmed or torn items as they may unravel.
- Before washing, empty all pockets of small objects which may have been left inside (coins, keys, screws etc). as these could damage the drain pump.
- When washing curtains, remove the hooks.
- Close poppers and zips and fasten loose buttons.
- It is essential to wash new coloured items separately when washing for the first time.
- When washing fabrics requiring different wash temperatures together, always select the lowest temperature.
- White items should not be washed with coloured items.
- Very small items (handkerchiefs, ribbons, socks etc) should be washed in a washing bag or a pillow case.
- Use a good quality detergent suitable for automatic washing machines.
- Use the correct quantities of detergent.
- For wool, use gentle detergent only in small quantities.
- Bleach is very corrosive; it should be used with care and kept out of reach of children.

- Some stains such as fruit, wine, grass, rust etc. are difficult to remove and should be treated before washing with specific products, which can be found in most household shops. In some cases it may help to soak the stain before washing with a special presoak product or biological detergent.
- If you have used the machine to wash, rinse or spin only non-colour fast garments, there may be dye left in the sump. To ensure any subsequent wash is not contaminated with the dye, select and carry out a rinse and spin programme, without any garments, to ensure that any dye is removed from the sump.
- Do not leave the damp laundry load in a heap too long before drying.
- Avoid drying dark clothes with light coloured fluffy items such as towels as these can attract the fluff.
- If you overdry the laundry, besides wasting energy, any subsequent ironing may become more difficult because the fabric could be heavily crumpled.
- Remove the laundry when the appliance has finished drying.
- To avoid a static charge when drying is completed, use either a fabric softener when you are washing the laundry or a fabric conditioner specifically for tumble dryers.
- Particularly delicate items such as synthetic curtains, woollen and silk, garments with metal inserts, nylon stockings, bulky garments such as anoraks, bedcovers, quilts, sleeping bags and duvets must not be machine dried.
- Garments padded with foam-rubber or materials similar to foam-rubber must not be machine dried; they represent a fire hazard.
- Also, fabrics containing residues of setting lotions or hair sprays, nail solvents or similar solutions must not be machine dried in order to avoid the formation of harmful vapours.
- For drying, follow the indications given on the manufacturer's labels.

$\overline{}$			_	_	
ĸ	May	he	tumb	sle.	dried
	IVIUY	\sim	tuille	,10	uricu

Drying at high temperature

Drying at reduced temperature

Do not tumble dry

Important:

As a dryer, the machine works on the condensation principle.

Therefore, the water tap must be open and the drain hose must drain water into a sink or into the drain pipe, even during the drying cycle.

Which detergent?....

To ensure you obtain the best wash results from your appliance, it is important to use the right detergent in your everyday wash, and only detergents recommended for use in automatic machines.

To maintain the appearance of your clothes and household textiles and to make them last longer you should use different types of detergent for different washes, whether for whites, colours or delicates.

WHITES

We recommend the Ariel product range which is biological and designed to provide excellent cleaning and stain removal even at low temperatures.







NON BIOLOGICAL

If you prefer to use a non biological detergent, which does not contain enzymes we recommend Fairy. Fairy provides good cleaning and stain removal.




COLOURS

For coloured items you should use a detergent which is designed to clean while maintaining the original colour. Ariel Color does not contain bleach and therefore helps to preserve colours.



DELICATE ITEMS

When washing delicates such as woollens, you should use a product which is specially designed to care for fine fabrics.





LAUNDRY BLEACH

For additional stain removal you may wish to use a product such as Ace Gentle Bleach which is used in addition to vour chosen detergent. Ace is suitable for all washable fabrics including silks, woollens and colours.



And in which form?

Not only are there different types of detergent, but they are also available in different forms. Whether you chose a powder or liquid in traditional or compact form is your own personal choice.

TRADITIONAL POWDERS

Pour the powder directly into the dispenser drawer. Do not sprinkle powder onto clothes in the machine drum.

TRADITIONAL LIQUIDS

Liquid can be placed in the main wash compartment of the detergent drawer marked with the symbol [1], start the machine immediately upon placing the detergent in the dispenser drawer.

Alternatively the detergent is measured into the specially designed dosing device* which should be placed on top of the laundry, and at the back of the machine drum.

COMPACT POWDERS AND LIQUIDS

Compact detergents (or concentrates as they are also known) are available in liquid or powder form, and generally require a smaller dosage. Follow the manufacturer's instructions to ensure the most economical usage. Pour the detergent directly into the dispenser drawer, or alternatively measure the detergent into the specially designed dosing device* which should be placed on top of the laundry, and at the back of the machine drum.

If you use a dosing device in a washer dryer, please ensure the dosing device/ball is removed before carrying out a drying programme.

FABRIC CONDITIONERS

These are ideal for improving 'softness', and also reduce static cling on synthetics and make ironing easier. They are available in two types:

For example Lenor liquid fabric softener, for use in the washing machine/washer dryer. The liquid fabric softener should be poured into the compartment marked with the symbol \aleph . Follow the manufacturer's dosage instructions and never exceed the MAX level.



Bounce conditioning sheets for use in a tumble dryer. We recommend the conditioning sheets are pinned (using a safety pin) to an article of laundry and placed in the tumble dryer.



Wash Care Symbols

WASHING SYMBOL

Wash care labels inside garments recommend how to launder your clothes with the best results. The care labelling code is in line with care labelling used in the rest of Europe. The symbols used make it easy to select the correct programme on your washing machine.

WASH ACTION

WASHING SYMBOL	WASH ACTION	FABRIC	
957	Normal (Maximum)	White Cotton or Linen without Special Finishes	
\607	Normal (Maximum)	Cotton, Linen or Viscose without Special Finishes Colourfast at 60°C.	
<u> </u>	Reduced (Medium)	Nylon, Polyester/Cotton, Viscose with Special Finishes, Cotton/Acrylic Mix.	
407	Normal (Maximum)	Cotton, Linen or Viscose Colourfast at 40°C but not 60°C.	
<u>740</u> 7	Reduced (Medium)	Acrylics, Acetate, Triacetate, Wool mixes, Polyester/wool blends.	
ZãO.	Much Reduced (Minimum)	Wool, wool mixtures, Silks	
No.	Hand wash only	Do not machine wash	
BLEACHING			
<u>A</u>	Chlorine bleach may be used		
IRONING			
	Hot iron	Cotton, Linen, Viscose	
	Warm iron	Polyester mixtures, Wool	
	Cool iron	Acrylic, Nylon, Polyester	
DRY CLEANING			
P	May be dry cleaned. Other letters and indicate the required process to the d		
TUMBLE DRYING			
0	with high heat setting		
O	with low heat setting		
	May be tumble dried		
X	A cross through any symbol means «DO NOT»		

Important Notes

For best results, always use the dispenser drawer for dispensing detergents and liquid additives.

Once the dispenser has been filled, close it by pushing it in gently. This is particularly important if you are using fabric conditioner to avoid the conditioner entering the machine prematurely.

When using liquid detergent and a prewash programme, place the detergent into the correct compartment in the dispenser drawer, after the prewash has finished.

FARRIC

Washing programmes

Wash programme/ Washing symbol	Type of laundry	Description	Possible options	Max. load	Energy kWh*	Water litres*
Whites	White cotton: e.g. sheets, tablecloths, household linen	Main wash at (cold) - 95°C 3 rinses Long spin	Prewash Spin speed/ Extra rinse	7 kg	2.4	63
Colours	White and coloured cotton: e.g. sheets, tablecloths, household linen	Main wash at X (cold) - 60°C 3 rinses Long spin	Prewash Spin speed/ Extra rinse	7 kg	1.4	59
Cottons Eco	White and coloured cotton Economy: e.g. shirts, blouses, underwear, towels, house-hold linen	Main wash at 60° - 40°C 3 rinses(*) Long spin	Prewash Spin speed/ Extra rinse	7 kg	1.19	56
Synthetic	Synthetic fabrics: e.g. shirts, blouses, underwear	Main wash at (cold) - 60°C 3 rinses Short spin	Prewash Spin speed/ Extra rinse	3 kg	0.95	53
Synthetic Eco	Synthetic fabrics Economy: e.g. shirts, blouses, underwear	Main wash at 40°C 3 rinses Short spin	Prewash Spin speed/ Extra rinse	3 kg	0.6	53
Delicate	Delicate fabrics: e.g. acrylic fabrics, viscose, polyester, synthetic blends	Main wash at ★ (cold) - 40°C 3 rinses Short spin	Prewash Extra rinse	3 kg	0.5	57
Handwash 🕲	Special programme for hand washing fabrics	Main wash at (cold) - 40°C 3 rinses Short spin	Prewash Spin speed/	2 kg	0.35	50
Wool 🚳	Special programme for wool garments bearing the "Pure new wool, non-shrink, machine washable" label.	Main wash at ★ (cold) - 40°C 3 rinses Short spin	Prewash Spin speed/	2 kg	0.35	50
Mini 30	Special short programme for lightly soiled fabrics	Main wash at 30°C 2 rinses Short spin	D	3 kg	0.35	45

The "Cotton Eco" at 60°C is the reference programme for the data entered in the energy label, in compliance with EEC 92/75 standards. (** = This programme performs only 2 rinses)

^{*} This data is given purely as an indication: the consumption values may vary in relation to the quantity and type of laundry, the temperature of the water supply and the ambient temperature. The data refers to the highest temperature provided for each programme.

Special programmes

Programme dial position	Wash programme	Description	Possible options	Max. load	Energy kWh*.	Water litres*
Rinses	Separate rinse cycle for hand washed items of cotton fabric	3 rinses with liquid additive, if required. Long spin at max. speed	Spin speed/ Extra rinse	7 kg	0.08	48
Drain	For emptying out the water of the last rinses of programmes with option (Rinse Hold)	Water draining		/	/	/
Spin	Separate spin for cottons	Drain and long spin at the max. speed	Spin speed	7 kg	/	/
Gentle Spin	Separate short spin for synthetic or mixed fabrics, handwashed, wool and delicate items	Drain and delicate spin at max 700 r.p.m.		3 kg	/	/
Off	For cancelling the wash programme which is running and for switching the machine off			-	-	-

^{*} This data is given purely as an indication: the consumption values may vary in relation to the quantity and type of laundry, the temperature of the water supply and the ambient temperature. The data refers to the highest temperature provided for each programme.

Drying Programmes

Timed drying

Degree of drying	Type of fabric	Max. load	Spin speed	Drying time mins
		3.5 kg	1600	95-105
Extra dry Ideal for	Cotton and linen (bathrobes, bath	5.5 Kg	1200	105-115
towelling materials	towels, etc.)	1.51	1600	40-50
		1.5 kg	1200	55-65
		3.5 kg	1600	85-95
	Cotton and linen		1200	95-105
Store dry (*)	(towels, T-shirts, bathrobes)		1600	35-45
			1200	45-55
	Synthetics and mixed fabrics (jumpers, blouses, underwear, household linen)	2 kg	900	70-80
		1 kg	900	35-45
		3.5 kg	1600	65-75
Iron dry	Cotton and linen (sheets, tablecloths,		1200	75-85
Suitable for ironing	shirts, etc.)	1.5 lea	1600	30-40
	1.5 kg		1200	40-50

^(*) The STORE DRY drying programme for cotton is the reference programme for the Energy Label data, in compliance with EC directive 92/75.

Maintenance and Cleaning

Before any maintenance or cleaning is carried out you must **DISCONNECT** the appliance from the electricity supply.

Descaling

The water we use normally contains lime. It is a good idea to periodically use a water softening powder in the machine. Do this separately from any laundry washing, and according to the softening powder manufacturer's instructions. This will help to prevent the formation of lime deposits.

After each wash

Leave the door open for a while. This helps to prevent mould and stagnant smells forming inside the appliance. Keeping the door open after a wash will also help to preserve the door seal.

Maintenance Wash

With the use of low temperature washes it is possible to get a build up of residues inside the drum.

We recommend that a maintenance wash be performed on a regular basis.

To run a maintenance wash:

- The drum should be empty of laundry.
- Select the hottest cotton wash programme.
- Use a normal measure of detergent, must be a powder (such as Ariel Futur).

External cleaning


Clean the exterior cabinet of the appliance with soap and water only, and then dry thoroughly.

Cleaning the dispenser drawer


The washing powder and additive dispenser drawer should be cleaned regularly.


Remove the drawer by pressing the catch downwards and by pulling it out. Flush it out under a tap, to remove any traces of accumulated powder.






To aid cleaning, the top part of the additive compartment should be removed.





Cleaning the drawer recess

Having removed the drawer, use a small brush to clean the recess, ensuring that all washing powder residue is removed from the upper and lower part of the recess. Replace the drawer and run the rinse programme without any clothes in the drum.




Cleaning the pump

The pump should be inspected if

- the machine does not empty and/or spin
- the machine makes an unusual noise during draining due to objects such as safety pins, coins etc. blocking the pump.


Proceed as follows:

- Disconnect the appliance.
- If necessary wait until the water has cooled down.
- Open the pump door.



 Place a container close to the pump to collect any spillage.

- Pull out the emergency emptying hose, place it in the container and remove its cap.
- When no more water comes out, unscrew the pump cover and remove it. Always keep a rag nearby to dry up spillage of water when removing the cover.



• Remove any objects from the pump impeller by rotating it.



• Put the cap back on the emergency emptying hose and place the latter back in its seat.




- Screw the pump cover fully in.
- Close the pump door.

⚠ Warning

When the appliance is in use and depending on the programme selected there can be hot water in the pump. Never remove the pump cover during a wash cycle, always wait until the appliance has finished the cycle, and is empty. When replacing the cover, ensure it is securely retightened so as to stop leaks and young children being able to remove it.

Cleaning the water inlet filter

If your water is very hard or contains traces of lime deposit, the water inlet filter may become clogged. It is therefore a good idea to clean it from time to time. Turn off the water tap. Unscrew the water inlet hose. Clean the filter using a hard bristle brush. Tighten up the inlet hose.



The dangers of freezing

If the machine is exposed to temperatures below 0°C, certain precautions should be taken.

- Turn off the water tap.
- Unscrew the inlet hose.
- Place the end of the emergency emptying hose and that of the inlet hose in a bowl placed on the floor and let water drain out.
- Screw the water inlet hose back on and reposition the emergency emptying hose after having put the cap on again.
- When you intend to start the machine up again, make sure that the room temperature is above 0°C.

Emergency emptying out

If the water is not discharged, proceed as follows to empty out the machine:

- pull out the plug from the power socket;
- close the water tap;
- if necessary, wait until the water has cooled down;
- open the pump door;
- place a bowl on the floor and place the end of the emergency emptying hose into the bowl. Remove its cap. The water should drain by gravity into the bowl. When the bowl is full, put the cap back on the hose.
 Empty the bowl. Repeat the procedure until water stops flowing out;
- clean the pump if necessary as previously described;
- replace the emergency emptying hose in its seat after having plugged it;
- screw the pump cover again and close the door.

Something Not Working

Certain problems are due to lack of simple maintenance or oversights, which can be solved easily without calling out an engineer. Before contacting your local Service Force Centre, please carry out the checks listed below.

IMPORTANT: if you call out an engineer to a fault listed below, or to repair a fault caused by incorrect use or installation, a charge will be made even if the appliance is under guarantee.

During machine operation it is possible that one of the following alarm codes appears on the display:

- **E10**: problem with the water supply
- **E20**: problem with water draining
- **E40** : door open

Once the problem has been eliminated, press the "Start/Pause" button to restart the programme. If after all checks, the problem persists, contact your local Service Force Centre.

Symptom	Possible causes
The machine does not start	 The door has not been closed. (E40) The plug is not properly inserted in the power socket. There is no supply at the socket. The main fuse or the fuse in the plug has blown. The "Start Pause" button has not been depressed. The "Delay Start" option has been selected.
The machine does not fill	 The water tap is closed. (<i>EI0</i>) The filter in the inlet hose is blocked. (<i>EI0</i>) The inlet hose may be squashed or kinked. (<i>EI0</i>) The door has not been closed. (<i>EY0</i>)
The machine fills then empties immediately	 The end of the drain hose is too low. The end of the drain hose is submerged in water. There is no vent in the end of the drain hose.
The machine does not empty and/or does not spin	 The drain hose may be squashed or kinked. (E20) The "Rinse Hold" option has been selected. The drain pump may be blocked (E20) The drain hose extension, if fitted, is not correct. Follow the instructions for connecting to the waste. The drainage system pipes are blocked. The wash load is unbalanced: redistribute the clothes inside the drum to allow the machine to spin.
There is water on the floor	 Too much detergent or unsuitable detergent has been used (creates too much foam). Check whether there are any leaks from the inlet hose fittings. It is not always easy to see this as the water runs down the hose; check to see if it is damp. The drain hose may be damaged or not securely positioned. The detergent dispenser drawer or recess is clogged. The drainage system pipes are blocked. The cap on the emergency emptying hose has not been replaced after cleaning the pump.
Unsatisfactory washing results	 Too little detergent or unsuitable detergent has been used. An insufficient amount of detergent leaves the laundry looking grey and causes lime scale to form. Stubborn stains have not been treated prior to washing The correct wash programme/temperature has not been selected. Too much laundry has been placed in the drum.

Symptom	Possible causes
The machine vibrates when spinning	 The internal packing has not been removed. The machine is in contact with the wall or furniture. The machine is not level and stable (check diagonally). The washing load is badly distributed in the drum. Maybe there is very little laundry in the drum.
The door will not open	 The water level is above the bottom edge of the door. The machine is heating the water or drying the clothes. The drum is turning.
Spinning starts late or the machine does not spin	• The electronic balance control device has cut in because the laundry is not evenly distributed in the drum. The laundry is redistributed by reverse rotation of the drum. This may happen several times before the unbalance disappears and normal spinning can resume. If, after a few minutes, the laundry is still not evenly distributed in the drum, the machine will spin at a lower spin or will not spin. In this case, redistribute the load manually and select the spin programme.
The machine makes an unusual noise	The machine is fitted with a type of motor which makes an unusual noise compared with other traditional motors. This new motor ensures a softer start and more even distribution of the laundry in the drum when spinning, as well as increased stability of the machine.
No water is visible in the drum	Machines based on modern technology operate very economically using very little water without affecting performance.
The machine does not dry or does not dry properly	 The drying time or degree of drying has not been selected The water tap is not turned on (EIO) The drain pump is clogged (E2O) The machine is overloaded The selected programme, drying time or degree of dryness was not suitable for the laundry.

Service & Spare Parts SERVICE (FORCE

In the event of your appliance requiring service, or if you wish to purchase spare parts, please contact your local Service Force Centre by telephoning:

0870 5 929929

Your telephone call will be automatically routed to the Service Force Centre covering your post code area.

For the address of your local Service Force Centre and further information about Service Force, please visit the website at www.serviceforce.co.uk.

To buy accessories, consumables and spare parts at our online shop please visit: http://www.zanussielectrolux.co.uk


Before calling out an engineer, please ensure you have read the details under the heading "Something Not Working".

When you contact the Service Force Centre you will need to give the following details:

- 1. Your name, address and post code
- 2. Your telephone number

- 3. Clear and concise details of fault
- 4. The model and serial number of the appliance (found on the rating plate see picture)
- 5. The purchase date.

Please note that a valid purchase receipt or guarantee documentation is required for inguarantee service calls.



Customer Care Department

For general enquiries concerning your Zanussi Electrolux appliance or for further information on Zanussi Electrolux products, please contact our Customer Care Department by letter or telephone at the address below or visit our website at www.zanussi.co.uk Customer Care Department - Zanussi/Electrolux

Major Appliances

Addington Way, Luton Bedfordshire LU4 9QQ Tel 08705 727727*

* calls to this number may be recorded for training purposes.



Guarantee Conditions

Standard guarantee conditions

We, Zanussi Electrolux, undertake that if, within 12 months of the date of the purchase, this ZANUSSI ELECTROLUX appliance or any part thereof is proved to be defective by reason only of faulty workmanship or materials, we will, at our option repair or replace the same FREE OF ANY CHARGE for labour, materials or carriage on condition that:

- The appliance has been correctly installed and used only on the electricity supply stated on the rating plate.
- The appliance has been used for normal domestic purposes only, and in accordance with the manufacturer's instructions
- The appliance has not been serviced, maintained, repaired, taken apart or tampered with, by any person not authorised by us.
- All service work under this guarantee must be undertaken by a Service Force Centre.
- Any appliance or defective part replaced shall become the Company's property.
- This guarantee is in addition to your statutory and other legal rights.

Home visits are made between **8.30am** and **5.30pm** Monday to Friday. Visits may be available outside these hours in which case a **premium** will be charged.

Exclusions

This guarantee does not cover:

- Damage or calls resulting from transportation, improper use or neglect, the replacement of any light bulbs or removable parts of glass or plastic.
- Costs incurred for calls to put right an appliance which is improperly installed or calls to appliances outside the United Kingdom.

- Appliances found to be in use within a commercial environment, plus those which are subject to rental agreements.
- Products of Zanussi Electrolux manufacture which are NOT marketed by Zanussi Electrolux.

European guarantee


If you should move to another country within Europe then your guarantee moves with you to your new home subject to the following qualifications:

- The guarantee starts from the date you first purchased your product.
- The guarantee is for the same period and to the same extent for labour and parts as exists in the new country of use for this brand or range of products.
- The guarantee relates to you and cannot be transferred to another user.
- Your new home is within the European Community (EC) or European Free Trade Area.
- The product is installed and used in accordance with our instructions and is only used domestically, i.e. a normal household.
- The product is installed taking into account regulations in your new country.

Before you move please contact your nearest Customer Care Centre, listed below, to give them details of your new home. They will then ensure that the local Service Organisation is aware of your move and able to look after you and your appliances.

France	Senlis	+33 (0) 344 62 29 29
Germany	Nurnberg	+49 (0) 800 234 7378
Italy	Pordenone	+39 0434 39 4700
Sweden	Stockholm	+46 (0) 8 672 53 90
UK	Luton	+44 (0) 8705 727 727
Ireland	Dublin	+353 (0)1 4090751

Installation Instructions



Care must be taken to ensure that the appliance does not stand on the electrical supply cable.

Any electrical work required to install this appliance should be carried out by a qualified electrician or competent person.

Any plumbing work required to install this appliance should be carried out by a qualified plumber or competent person.

Should the appliance power supply cable need to be replaced, this should be carried out by our Service Force Centre.

Technical Specifications

DIMENSIONS	Height Width Depth	85 cm 60 cm 60 cm
POWER SUPPLY VOLTAGE TOTAL POWER ABSORBED		230-240 V/50 Hz 2050 W (10A)
WATER PRESSURE	Minimum Maximum	0.05 MPa 0.8 MPa
MAX LOAD CAPACITY	Washing Cottons, linen Synthetics and Miniprogramme Delicate fabrics Wool and HandWash Drying Cotton, linen Synthetics	7 kg 3 kg 3 kg 2 kg 3.5 kg 2 kg
SPIN SPEED	Maximum	1600 rpm
CONSUMPTION DATA for washing 7 kg of normally soiled cotton items with the programme "Cottons Eco" at 60°C	Energy Water Time	1.19 kWh 56 litres 115 minutes

This appliance complies with the following E.E.C. Directives:

- 73/23 EEC of 19.2.73 (Low Voltage Directive) and subsequent modifications;
- 89/336 EEC of 3.5.89 (Electromagnetic Compatibility Directive) and subsequent modifications.

Unpacking


 Λ


All transit bolts and packing must be removed before using the appliance.

You are advised to keep all the packaging for re-use in case the machine is to be transported again.

Using a spanner unscrew and remove the two rear bottom screws. Slide out the two plastic pins.

Lay the machine gently on its back, making sure that the hoses are not squashed.







Remove the polystyrene block from the bottom of the machine and release the two plastic bags.


Very carefully slide out the left polythene bag removir.

Very carefully slide out the left polythene bag, removing it towards the right and then downwards.






Repeat the operation for the right polythene bag, removing it towards the left and then upwards.




Remove the polystyrene base.

Set the machine upright and unscrew the remaining rear screw. Slide out the relevant pin.

Fill all the holes with the plastic plugs supplied with the instruction booklet.





Important!

You are advised to keep all the packaging for re-use in case the machine is to be transported again. In case of moving out the same precautions as per paragraph "The dangers of freezing" must be taken i.e. the residual water in the hoses must be pumped out.

Positioning

Install the machine on a flat hard floor.

Make sure that air circulation around the machine is not impeded by carpets, rugs etc. Check that the machine does not touch the wall or other kitchen units.

Never place cardboard, wood or similar materials under the machine to compensate for any unevenness in the floor.

Your new washing machine has been designed to be permanently plumbed in to your home's water supply and drainage system. However, if this is not possible, it may be connected to a suitable existing tap with the drain hose discharging into a sink.

The appliance has an inlet hose, with female 3/4" BSP thread connector. If this connection is not compatible with the plumbing of the existing installation, a variety of connectors are available from good hardware stores and plumbers merchants to suit most domestic plumbing. Any alteration to your existing plumbing must be carried out by a competent person, or qualified plumber.

Installation on a Suspended Floor

Suspended wooden floors are particularly susceptible to vibration. To help prevent vibration we recommend you place a waterproof wood panel, at least 15 mm thick under the appliance, secured to at least 2 floor beams with screws. If possible install the appliance in one of the corners of the room, where the floor is more stable.

Water inlet

Connect the hose supplied with the machine to a tap with a 3/4" thread.

Do not use already employed hoses.



Installation should comply with local water authority and building regulations' requirements.


The appliance must be connected to a cold water supply.

A minimum water pressure of 0.05 MPa (0.5 bar) is required for safe operation of the appliance.

If you cannot make the cold water connection direct from the rising mains, you may be able to operate the appliance from your cold water storage system.

There should be a minimum distance of 5.02m (161/2 ft) between the appliance's inlet and the bottom of the water storage tank.

Set the hose correctly by loosening the ring nut. After positioning the inlet hose, be sure to tighten the ring nut again to prevent leaks.



Water drainage


This appliance is designed to be permanently plumbed into your home's drainage system using one of the following methods.

1. Into a drainage standpipe.


Firstly form a hook in the end of the drain hose using the "U" piece" supplied.



Place the drain hose into your standpipe, which should have an internal diameter of approximately 38mm thus ensuring there is an air break between the drain hose and standpipe.




When discharging into a standpipe ensure that the top of the standpipe is no more than 90cm (35.4") and no less than 60cm (23.6") above floor level.




The drain hose may be extended to a maximum of 4 metres. An additional drain hose and joining piece is available from your local Service Force Centre. The joining piece must have an internal diameter of 18mm.

If your drain hose looks like this (see below) you do not require the "U" piece". Just push the hose firmly into the standpipe.




2. Onto a sink outlet spigot.

If the outlet spigot has not been used before, remove any blanking plug that may be in place.



Push the drain hose onto the spigot and secure with a clip if required, ensure a loop is formed in the drain hose (see diagram) to prevent waste from the sink entering the washing machine.




The drain hose may be extended to a maximum of 4 metres. An additional drain hose and joining piece is available from your local Service Force Centre. The joining piece must have an internal diameter of 18mm.

Important

Before connecting up the machine to new pipework or to pipework that has not been used for some time, run off a reasonable amount of water to flush out any debris that may have collected in the pipes.

Levelling

Level the washing machine by raising or lowering the feet. The feet may be tight to adjust as they incorporate a self locking nut, but the machine MUST be level and stable (check diagonally).



Any necessary adjustment can be made with a spanner. Accurate levelling prevents vibration, noise and displacement of the machine during operation.

Some vibration is inevitable, especially if mounted on a wooden floor.

Sprung wooden floors are particularly susceptible to vibration. For advice, consult a builder. If possible, always place the machine on a solid floor.

Special conditions

If the floor is carpeted or covered with crumbly or soft material, insert a rigid support base under the feet to prevent noise, vibration or displacement. The base should protrude a few centimetres beyond the edges of the machine.



Warning

The machine should NOT be placed on deep pile carpeting.


Note

Please ensure that when the appliance is installed it is easily accessible for the engineer in the event of a breakdown.

In the interest of the environment

Washing machines and dishwashers should be connected to the FOUL drainage system, the water will then be taken to a sewage works for treatment before being discharged safely into a river.

It is essential that these appliances are not connected to the surface water drainage system as this water is discharged directly into a river or stream and may cause pollution. If you require any further advice please contact your local water authority.



Electrical connection


Any electrical work required to install this appliance should be carried out by a qualified electrician or competent person.



WARNING: THIS APPLIANCE MUST BE **! ** EARTHED.

The manufacturer declines any liability should this safety measure not be observed.

Before switching on, make sure the electricity supply voltage is the same as that indicated on the appliance's rating plate. The rating plate is located at the top of the rim of the open door.




The appliance is supplied with a 13amp plug fitted. In the event of having to change the fuse in the plug supplied, a 13amp ASTA approved (BS1363/A) fuse must be used.

Should the plug need to be replaced for any reason, proceed as described below.

The wires in the mains lead are coloured in accordance with the following code:

Green and Yellow - Earth - Neutral Blue - Live Brown



The wire coloured green and yellow must be connected to the terminal marked with the letter «E» or by the earth symbol $\stackrel{\bot}{=}$ or coloured green and yellow.

The wire coloured blue must be connected to the terminal marked «N» or coloured black.

The wire coloured brown must be connected to the terminal marked «L» or coloured red.

Upon completion there must be no cut, or stray strands of wire present and the cord clamp must be secure over the outer sheath.



WARNING:

 $\stackrel{\frown}{\mathbb{N}}$ A cut off plug inserted into a 13 amp socket is a serious safety (shock) hazard. Ensure that the cut off plug is disposed of safely. Should the appliance power supply cable need to be replaced, this must be carried out by our Service Force Centre.

Note

When the appliance is installed the power supply cable must be accessible.

Permanent connection

In the case of permanent connection it is necessary that you install a double pole switch between the appliance and the electricity supply (mains), with a minimum gap of 3mm between the switch contacts and of a type suitable for the required load in compliance with the current electrical regulations.

The switch must not break the yellow and green earth cable at any point.

