



Sun Fire™ X4140, X4240, and X4440 Servers Diagnostics Guide

Sun Microsystems, Inc.
www.sun.com

Part No. 820-3067-11
August 2008, Revision A

Submit comments about this document at: <http://www.sun.com/hwdocs/feedback>

Copyright © 2008 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, California 95054, U.S.A. All rights reserved.

Unpublished - rights reserved under the Copyright Laws of the United States.

THIS PRODUCT CONTAINS CONFIDENTIAL INFORMATION AND TRADE SECRETS OF SUN MICROSYSTEMS, INC. USE, DISCLOSURE OR REPRODUCTION IS PROHIBITED WITHOUT THE PRIOR EXPRESS WRITTEN PERMISSION OF SUN MICROSYSTEMS, INC.

This distribution may include materials developed by third parties.

Sun, Sun Microsystems, the Sun logo, Java, Solaris, Sun Fire 4140, Sun Fire 4240 and Sun Fire 4440 are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries.

AMD Opteron and Opteron are trademarks of Advanced Micro Devices, Inc.. Intel is a registered trademark of Intel Corporation.

This product is covered and controlled by U.S. Export Control laws and may be subject to the export or import laws in other countries. Nuclear, missile, chemical biological weapons or nuclear maritime end uses or end users, whether direct or indirect, are strictly prohibited. Export or reexport to countries subject to U.S. embargo or to entities identified on U.S. export exclusion lists, including, but not limited to, the denied persons and specially designated nationals lists is strictly prohibited.

Use of any spare or replacement CPUs is limited to repair or one-for-one replacement of CPUs in products exported in compliance with U.S. export laws. Use of CPUs as product upgrades unless authorized by the U.S. Government is strictly prohibited.

Copyright © 2008 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, California 95054, Etats-Unis. Tous droits réservés.

Non publiée - droits réservés selon la législation des Etats-Unis sur le droit d'auteur.

CE PRODUIT CONTIENT DES INFORMATIONS CONFIDENTIELLES ET DES SECRETS COMMERCIAUX DE SUN MICROSYSTEMS, INC. SON UTILISATION, SA DIVULGATION ET SA REPRODUCTION SONT INTERDITES SANS L'AUTORISATION EXPRESSE, ECRITE ET PREALABLE DE SUN MICROSYSTEMS, INC.

Cette distribution peut inclure des éléments développés par des tiers.

Sun, Sun Microsystems, le logo Sun, Java, Solaris et Sun Fire 4140, Sun Fire 4240, and Sun Fire 4440 sont des marques de fabrique ou des marques déposées de Sun Microsystems, Inc. aux Etats-Unis et dans d'autres pays.

AMD Opteron et Opteron sont marques déposées de Advanced Micro Devices, Inc. Intel est une marque déposée de Intel Corporation

Ce produit est soumis à la législation américaine sur le contrôle des exportations et peut être soumis à la réglementation en vigueur dans d'autres pays dans le domaine des exportations et importations. Les utilisations finales, ou utilisateurs finaux, pour des armes nucléaires, des missiles, des armes biologiques et chimiques ou du nucléaire maritime, directement ou indirectement, sont strictement interdites. Les exportations ou reexportations vers les pays sous embargo américain, ou vers des entités figurant sur les listes d'exclusion d'exportation américaines, y compris, mais de manière non exhaustive, la liste de personnes qui font objet d'un ordre de ne pas participer, d'une façon directe ou indirecte, aux exportations des produits ou des services qui sont régis par la législation américaine sur le contrôle des exportations et la liste de ressortissants spécifiquement désignés, sont rigoureusement interdites.

L'utilisation de pièces détachées ou d'unités centrales de remplacement est limitée aux réparations ou à l'échange standard d'unités centrales pour les produits exportés, conformément à la législation américaine en matière d'exportation. Sauf autorisation par les autorités des Etats-Unis, l'utilisation d'unités centrales pour procéder à des mises à jour de produits est rigoureusement interdite.



Please
Recycle



Adobe PostScript

Contents

Preface	vii
1. Initial Inspection of the Server	1
Service Troubleshooting Flowchart	1
Gathering Service Information	2
System Inspection	3
Troubleshooting Power Problems	3
Externally Inspecting the Server	3
Internally Inspecting the Server	4
2. Using SunVTS Diagnostic Software	7
Running SunVTS Diagnostic Tests	7
SunVTS Documentation	8
Diagnosing Server Problems With the Bootable Diagnostics CD	8
Requirements	8
Using the Bootable Diagnostics CD	9
3. Troubleshooting DIMM Problems	11
DIMM Population Rules	11
DIMM Replacement Policy	12
How DIMM Errors Are Handled by the System	12

Uncorrectable DIMM Errors	12
Correctable DIMM Errors	14
BIOS DIMM Error Messages	15
DIMM Fault LEDs	15
Isolating and Correcting DIMM ECC Errors	18
A. Event Logs and POST Codes	21
Viewing Event Logs	21
Power-On Self-Test (POST)	25
How BIOS POST Memory Testing Works	25
Redirecting Console Output	26
Changing POST Options	28
POST Codes	31
POST Code Checkpoints	33
B. Status Indicator LEDs	37
External Status Indicator LEDs	37
Front Panel LEDs	38
Back Panel LEDs	38
Hard Drive LEDs	39
Internal Status Indicator LEDs	39
C. Using the ILOM Service Processor GUI to View System Information	43
Making a Serial Connection to the SP	44
Viewing ILOM SP Event Logs	45
Interpreting Event Log Time Stamps	47
Viewing Replaceable Component Information	48
Viewing Sensors	50
D. Error Handling	53

Handling of Uncorrectable Errors	53
Handling of Correctable Errors	56
Handling of Parity Errors (PERR)	59
Handling of System Errors (SERR)	61
Handling Mismatching Processors	63
Hardware Error Handling Summary	64
Index	69

Preface

The *Sun Fire X4140, X4240, and X4440 Servers Diagnostics Guide* contains information and procedures for using available tools to diagnose problems with the servers.

Before You Read This Document

It is important that you review the safety guidelines in the *Sun Fire X4140, X4240, and X4440 Safety and Compliance Guide*.

Related Documentation

The document set for the Sun Fire X4140, X4240, and X4440 Servers is described in the *Where To Find Sun Fire X4140, X4240, and X4440 Servers Documentation* sheet that is packed with your system. You can also find the documentation at <http://docs.sun.com>.

Translated versions of some of these documents are available at <http://docs.sun.com>. Select a language from the drop-down list and navigate to the Sun Fire X4140, X4240, and X4440 Servers document collection using the Product category link. Available translations for the Sun Fire X4140, X4240, and X4440 Servers include Simplified Chinese, Traditional Chinese, French, Japanese, and Korean.

English documentation is revised more frequently and might be more up-to-date than the translated documentation. For all Sun documentation, go to the following URL:

<http://docs.sun.com>

Typographic Conventions Third-Party

Typeface*	Meaning	Examples
AaBbCc123	The names of commands, files, and directories; onscreen computer output	Edit your <code>.login</code> file. Use <code>ls -a</code> to list all files. % You have mail.
AaBbCc123	What you type, when contrasted with onscreen computer output	% su Password:
<i>AaBbCc123</i>	Book titles, new words or terms, words to be emphasized. Replace command-line variables with real names or values.	Read Chapter 6 in the <i>User's Guide</i> . These are called <i>class</i> options. You <i>must</i> be superuser to do this. To delete a file, type <code>rm filename</code> .

* The settings on your browser might differ from these settings.

Web Sites

Sun™ is not responsible for the availability of third-party web sites mentioned in this document. Sun does not endorse and is not responsible or liable for any content, advertising, products, or other materials that are available on or through such sites or resources. Sun will not be responsible or liable for any actual or alleged damage or loss caused by or in connection with the use of or reliance on any such content, goods, or services that are available on or through such sites or resources.

Sun Welcomes Your Comments

Sun is interested in improving its documentation and welcomes your comments and suggestions. You can submit your comments by going to:

<http://www.sun.com/hwdocs/feedback>

Please include the title and part number of your document with your feedback:

Sun Fire X4140, X4240, and X4440 Servers Diagnostics Guide, part number 820-3067-11

Initial Inspection of the Server

This chapter includes the following topics:

- [“Service Troubleshooting Flowchart”](#) on page 1
- [“Gathering Service Information”](#) on page 2
- [“System Inspection”](#) on page 3



Service Troubleshooting Flowchart

Use the following flowchart as a guideline for using the subjects in this book to troubleshoot the server.

TABLE 1-1 Troubleshooting Flowchart

To perform this task	Refer to this section
Gather initial service information.	“Gathering Service Information” on page 2
Investigate any powering-on problems.	“Troubleshooting Power Problems” on page 3
Perform external visual inspection and internal visual inspection.	“Externally Inspecting the Server” on page 3 “Internally Inspecting the Server” on page 4 Chapter 3
View BIOS event logs and POST messages.	“Viewing Event Logs” on page 21 “Power-On Self-Test (POST)” on page 25

TABLE 1-1 Troubleshooting Flowchart (Continued)

To perform this task	Refer to this section
View service processor logs and sensor information...	“Using the ILOM Service Processor GUI to View System Information” on page 43
...or view service processor logs and sensor information.	“Using IPMItool to View System Information” on page 55
Run SunVTS diagnostics	“Diagnosing Server Problems With the Bootable Diagnostics CD” on page 8

Gathering Service Information

The first step in determining the cause of a problem with the server is to gather information from the service-call paperwork or the onsite personnel. Use the following general guideline steps when you begin troubleshooting.

To gather service information:

1. Collect information about the following items:

- Events that occurred prior to the failure
- Whether any hardware or software was modified or installed
- Whether the server was recently installed or moved
- How long the server exhibited symptoms
- The duration or frequency of the problem

2. Document the server settings before you make any changes.

If possible, make one change at a time in order to isolate potential problems. In this way, you can maintain a controlled environment and reduce the scope of troubleshooting.

3. Take note of the results of any change that you make. Include any errors or informational messages.

4. Check for potential device conflicts before you add a new device.

5. Check for version dependencies, especially with third-party software.

System Inspection

Controls that have been improperly set and cables that are loose or improperly connected are common causes of problems with hardware components.

Troubleshooting Power Problems

- If the server will power on, skip this section and go to [“Externally Inspecting the Server” on page 3](#).
- If the server will not power on, check the following:
 1. **Check that AC power cords are attached firmly to the server’s power supplies and to the AC sources.**
 2. **Check that the main cover is firmly in place.**

There is an intrusion switch on the motherboard that automatically shuts down the server power to standby mode when the cover is removed.

Externally Inspecting the Server

To perform a visual inspection of the external system:

1. **Inspect the external status indicator LEDs, which can indicate component malfunction.**

For the LED locations and descriptions of their behavior, see [“External Status Indicator LEDs” on page 37](#).
2. **Verify that nothing in the server environment is blocking air flow or making a contact that could short out power.**
3. **If the problem is not evident, continue with the next section, [“Internally Inspecting the Server” on page 4](#).**

Internally Inspecting the Server

To perform a visual inspection of the internal system:

1. **Choose a method for shutting down the server from main power mode to standby power mode.** See [FIGURE 1-1](#) and [FIGURE 1-2](#).
 - **Graceful shutdown** – Use a ballpoint pen or other stylus to press and release the Power button on the front panel. This causes Advanced Configuration and Power Interface (ACPI) enabled operating systems to perform an orderly shutdown of the operating system. Servers not running ACPI-enabled operating systems will shut down to standby power mode immediately.
 - **Emergency shutdown** – Use a ballpoint pen or other stylus to press and hold the Power button for four seconds to force main power off and enter standby power mode.



Caution – Performing an emergency shutdown can cause open files to become corrupt. Use an emergency shutdown only when necessary.

When main power is off, the Power/OK LED on the front panel will begin flashing, indicating that the server is in standby power mode.



Caution – When you use the Power button to enter standby power mode, power is still directed to service processor and power supply fans, indicated when the Power/OK LED is flashing. To completely power off the server, you must disconnect the AC power cords from the back panel of the server.

FIGURE 1-1 X4140 Server Front Panel





FIGURE 1-2 X4440 Server Front Panel



2. Remove the server cover.

For instructions on removing the server cover, refer to your server’s service manual.

3. Inspect the internal status indicator LEDs. These can indicate component malfunction.

For the LED locations and descriptions of their behavior, see [“Internal Status Indicator LEDs” on page 39](#).

Note – The server must be in standby power mode for viewing the internal LEDs.

You can hold down the Locate button on the server back panel or front panel for 5 seconds to initiate a “push-to-test” mode that illuminates all other LEDs both inside and outside of the chassis for 15 seconds.

4. Verify that there are no loose or improperly seated components.

5. Verify that all cable connectors inside the system are firmly and correctly attached to their appropriate connectors.

6. Verify that any after-factory components are qualified and supported.

For a list of supported PCI cards and DIMMs, refer to your server’s service manual.

7. Check that the installed DIMMs comply with the supported DIMM population rules and configurations, as described in [“DIMM Population Rules” on page 11](#).

8. Replace the server cover.

9. To restore the server to main power mode (all components powered on), use a ballpoint pen or other stylus to press and release the Power button on the server front panel. See [FIGURE 1-1](#) and [FIGURE 1-2](#).

When main power is applied to the full server, the Power/OK LED next to the Power button lights and remains lit.

10. If the problem with the server is not evident, you can obtain additional information by viewing the power-on self test (POST) messages and BIOS event logs during system startup. Continue with [“Viewing Event Logs”](#) on [page 21](#).

Using SunVTS Diagnostic Software

This chapter contains information about the SunVTS™ diagnostic software tool.

Running SunVTS Diagnostic Tests

The servers are shipped with a Bootable Diagnostics CD that contains the Sun Validation Test Suite (SunVTS) software.

SunVTS provides a comprehensive diagnostic tool that tests and validates Sun hardware by verifying the connectivity and functionality of most hardware controllers and devices on Sun platforms. SunVTS software can be tailored with modifiable test instances and processor affinity features.

The following tests are supported on x86 platforms:

- CD DVD Test (cddvdtest)
- CPU Test (cputest)
- Cryptographics Test (cryptotest)
- Disk and Diskette Drives Test (disktest)
- Data Translation Look-aside Buffer (dtlbtest)
- Emulex HBA Test (emlxtest)
- Floating Point Unit Test (fputest)
- InfiniBand Host Channel Adapter Test (ibhcatest)
- Level 1 Data Cache Test (l1dcachetest)
- Level 2 SRAM Test (l2sramtest)
- Ethernet Loopback Test (netlbttest)
- Network Hardware Test (nettest)
- Physical Memory Test (pmemtest)

- QLogic Host Bus Adapter Test (qlctest)
- RAM Test (ramtest)
- Serial Port Test (serialtest)
- System Test (systest)
- Tape Drive Test (tapetest)
- Universal Serial Board Test (usbtest)
- Virtual Memory Test (vmemtest)

SunVTS software has a sophisticated graphical user interface (GUI) that provides test configuration and status monitoring. The user interface can be run on one system to display the SunVTS testing of another system on the network. SunVTS software also provides a TTY-mode interface for situations in which running a GUI is not possible.

SunVTS Documentation

For the most up-to-date information on SunVTS software, go to:

<http://docs.sun.com/app/docs/prod/test.validate>

Diagnosing Server Problems With the Bootable Diagnostics CD

SunVTS 6.4 or later software is preinstalled on your server. The server is also shipped with the Bootable Diagnostics CD. This CD is designed so that the server will boot from the CD. This CD boots and starts SunVTS software. Diagnostic tests run and write output to log files that the service technician can use to determine the problem with the server.

Requirements

- To use the diagnostics CD you must have a keyboard, mouse, and monitor attached to the server on which you are performing diagnostics, or available through a remote KVM.

Using the Bootable Diagnostics CD

To use the diagnostics CD to perform diagnostics:

1. **With the server powered on, insert the CD into the DVD-ROM drive.**
2. **Reboot the server, and press F2 during the start of the reboot so that you can change the BIOS setting for boot-device priority.**
3. **When the BIOS Main menu appears, navigate to the BIOS Boot menu.**
Instructions for navigating within the BIOS screens appear on the BIOS screens.
4. **On the BIOS Boot menu screen, select Boot Device Priority.**
The Boot Device Priority screen appears.
5. **Select the DVD-ROM drive to be the primary boot device.**
6. **Save and exit the BIOS screens.**
7. **Reboot the server.**
When the server reboots from the CD in the DVD-ROM drive, the Solaris Operating System boots and SunVTS software starts and opens its first GUI window.
8. **In the SunVTS GUI, press Enter or click the Start button when you are prompted to start the tests.**
The test suite will run until it encounters an error or the test is completed.

Note – The CD will take approximately nine minutes to boot.

9. **When SunVTS software completes the test, review the log files generated during the test.**

SunVTS provides access to four different log files:

- SunVTS test error log contains time-stamped SunVTS test error messages. The log file path name is `/var/opt/SUNWvts/logs/sunvts.err`. This file is not created until a SunVTS test failure occurs.
- SunVTS kernel error log contains time-stamped SunVTS kernel and SunVTS probe errors. SunVTS kernel errors are errors that relate to running SunVTS, and not to testing of devices. The log file path name is `/var/opt/SUNWvts/logs/vtsk.err`. This file is not created until SunVTS reports a SunVTS kernel error.
- SunVTS information log contains informative messages that are generated when you start and stop the SunVTS test sessions. The log file path name is `/var/opt/SUNWvts/logs/sunvts.info`. This file is not created until a SunVTS test session runs.

- Solaris system message log is a log of all the general Solaris events logged by syslogd. The path name of this log file is /var/adm/messages.
- a. **Click the Log button.**

The Log file window is displayed.
- b. **Specify the log file that you want to view by selecting it from the Log file window.**

The content of the selected log file is displayed in the window.
- c. **With the three lower buttons you can perform the following actions:**
 - **Print the log file** – A dialog box appears for you to specify your printer options and printer name.
 - **Delete the log file** – The file remains on the display, but it will not be available the next time you try to display it.
 - **Close the Log file window** – The window is closed.

Note – If you want to save the log files: When you use the Bootable Diagnostics CD, the server boots from the CD. Therefore, the test log files are not on the server's hard disk drive and they will be deleted when you power cycle the server. To save the log files, you must save them to a removable media device or FTP them to another system.

Troubleshooting DIMM Problems

This chapter describes how to detect and correct problems with the server's Dual Inline Memory Modules (DIMM)s. It includes the following sections:

- [“DIMM Population Rules” on page 11](#)
 - [“DIMM Replacement Policy” on page 12](#)
 - [“How DIMM Errors Are Handled by the System” on page 12](#)
 - [“Isolating and Correcting DIMM ECC Errors” on page 18](#)
-

DIMM Population Rules

The DIMM population rules for the server are as follows:

- Each CPU can support a maximum of eight DIMMs.
- The DIMM slots are paired and the DIMMs must be installed in pairs (0-1, 2-3, 4-5, and 6-7). See [FIGURE 3-1](#) and [FIGURE 3-2](#). The memory sockets are colored black or white to indicate which slots are paired by matching colors.
- DIMMs are populated starting from the outside (away from the CPU) and working toward the inside.
- CPUs with only a single pair of DIMMs must have those DIMMs installed in that CPU's outside white DIMM slots (6 and 7). See [FIGURE 3-1](#) and [FIGURE 3-2](#).
- Only DDR2 800 Mhz, 667Mhz, and 533Mhz DIMMs are supported.
- Each pair of DIMMs must be identical (same manufacturer, size, and speed).

DIMM Replacement Policy

Replace a DIMM when one of the following events takes place:

- The DIMM fails memory testing under BIOS due to Uncorrectable Memory Errors (UCEs).
- UCEs occur and investigation shows that the errors originated from memory.

In addition, a DIMM should be replaced whenever more than 24 Correctable Errors (CEs) originate in 24 hours from a single DIMM and no other DIMM is showing further CEs.

- If more than one DIMM has experienced multiple CEs, other possible causes of CEs have to be ruled out by a qualified Sun Support specialist before replacing any DIMMs.

Retain copies of the logs showing the memory errors per the above rules to send to Sun for verification prior to calling Sun.

How DIMM Errors Are Handled by the System

This section describes system behavior for the two types of DIMM errors: UCEs and CEs, and also describes BIOS DIMM error messages.

Uncorrectable DIMM Errors

For all operating systems (OS's), the behavior is the same for UCEs:

1. When an UCE occurs, the memory controller causes an immediate reboot of the system.
2. During reboot, the BIOS checks the Machine Check registers and determines that the previous reboot was due to an UCE, then reports this in POST after the memtest stage:

`A Hypertransport Sync Flood occurred on last boot`

3. BIOS reports this event in the service processor's system event log (SEL) as shown in the sample IPMITool output below:

```
# ipmitool -H 10.6.77.249 -U root -P changeme -I lanplus sel list
8 | 09/25/2007 | 03:22:03 | System Boot Initiated #0x02 | Initiated by warm
  | reset | Asserted
9 | 09/25/2007 | 03:22:03 | Processor #0x04 | Presence detected | Asserted
a | 09/25/2007 | 03:22:03 | OEM #0x12 | | Asserted
b | 09/25/2007 | 03:22:03 | System Event #0x12 | Undetermined system hardware
  | failure | Asserted
c | OEM record e0 | 000000020000000000029000002
d | OEM record e0 | 00000004000000000000b00006
e | OEM record e0 | 00000048000000000011110322
f | OEM record e0 | 00000058000000000000030000
10 | OEM record e0 | 000100440000000000fefff000
11 | OEM record e0 | 000100480000000000ff3efa
12 | OEM record e0 | 10ab000000010000006040012
13 | OEM record e0 | 10ab0000001111002011110020
14 | OEM record e0 | 0018304c00f200002000020c0f
15 | OEM record e0 | 0019304c00f200004000020c0f
16 | OEM record e0 | 001a304c00f45aa10015080a13
17 | OEM record e0 | 001a3054000000000320004880
18 | OEM record e0 | 001b304c00f200001000020c0f
19 | OEM record e0 | 8000000200000000029000002
1a | OEM record e0 | 800000040000000000b00006
1b | OEM record e0 | 8000004800000000011110322
1c | OEM record e0 | 800000580000000000030000
1d | OEM record e0 | 80010044000000000fefff000
1e | OEM record e0 | 80010048000000000ff3efa
1f | 09/25/2007 | 03:22:06 | System Boot Initiated #0x03 | Initiated by warm
  | reset | Asserted
20 | 09/25/2007 | 03:22:06 | Processor #0x04 | Presence detected | Asserted
21 | 09/25/2007 | 03:22:15 | System Firmware Progress #0x01 | Memory
  | initialization | Asserted
22 | 09/25/2007 | 03:22:16 | Memory | Uncorrectable ECC | Asserted | CPU 2 DIMM 0
23 | 09/25/2007 | 03:22:16 | Memory | Uncorrectable ECC | Asserted | CPU 2 DIMM 1
24 | 09/25/2007 | 03:22:16 | Memory | Memory Device Disabled | Asserted | CPU
  | 2 DIMM 0
25 | 09/25/2007 | 03:22:16 | Memory | Memory Device Disabled | Asserted | CPU
  | 2 DIMM 1
```

The lines in the display start with event numbers (in hex), followed by a description of the event. TABLE 3-1 describes the contents of the display:

TABLE 3-1 Lines in IPMI Output

Event (hex)	Description
8	UCE caused a Hypertransport sync flood which lead to system's warm reset. #0x02 refers to a reboot count maintained since the last AC power reset.
9	BIOS detected and initiated 4 processors in system.
a	BIOS detected a Sync Flood caused this reboot.
b	BIOS detected a hardware error caused the Sync Flood.
c to 1e	BIOS retrieved and reported some hardware evidence, including all processors' Machine Check Error registers (events 14 to 18).
1f	After BIOS detected that a UCE had occurred, it located the DIMM and reset. 0x03 refers to reboot count.
21 to 25	BIOS off-lined faulty DIMMs from system memory space and reported them. Each DIMM of a pair is being reported, since hardware UCE evidence cannot lead BIOS any further than detection of a faulty pair.

Correctable DIMM Errors

If a DIMM has 24 or more correctable errors in 24 hours, it is considered defective and should be replaced.

At this time, CEs are not logged in the server's system event logs. They are reported or handled in the supported OS's as follows:

- Windows Server:

- a. A Machine Check error-message bubble appears on the task bar.
- b. The user must manually open Event Viewer to view errors. Access Event Viewer through this menu path:

Start-->Administration Tools-->Event Viewer

- c. The user can then view individual errors (by time) to see details of the error.

- Solaris:

Solaris FMA reports and (sometimes) retires memory with correctable Error Correction Code (ECC) errors. See your Solaris Operating System documentation for details. Use the command:

```
fmddump -eV
```


to view ECC errors

- Linux:

The HERD utility can be used to manage DIMM errors in Linux. See the *x64 Servers Utilities Reference Manual* for details.

- If HERD is installed, it copies messages from `/dev/mcelog` to `/var/log/messages`.
- If HERD is not installed, a program called `mcelog` copies messages from `/dev/mcelog` to `/var/log/mcelog`.

The Bootable Diagnostics CD described in [Chapter 2](#) also captures and logs CEs.

BIOS DIMM Error Messages

The BIOS displays and logs the following DIMM error messages:

`NODE-# Memory Configuration Mismatch`

The following conditions will cause this error message:

- The DIMMs mode is not paired (running in 64-bit mode instead of 128-bit mode).
- The DIMMs' speed is not same.
- The DIMMs do not support ECC.
- The DIMMs are not registered.
- The MCT stopped due to errors in the DIMM.
- The DIMM module type (buffer) is mismatched.
- The DIMM generation (I or II) is mismatched.
- The DIMM CL/T is mismatched.
- The banks on a two-sided DIMM are mismatched.
- The DIMM organization is mismatched (128-bit).
- The SPD is missing Trc or Trfc information.

DIMM Fault LEDs

When you press the Press to See Fault button on the motherboard or the mezzanine board, LEDs next to the DIMMs flash to indicate that the system has detected 24 or more CEs in a 24-hour period on that DIMM.

Note – The DIMM Fault and Motherboard Fault LEDs operate on stored power for up to a minute when the system is powered down, even after the AC power is disconnected, and the motherboard (or mezzanine board) is out of the system. The stored power lasts for about half an hour.

Note – Disconnecting the AC power removes the fault indication. To recover fault information look in the SP SEL, as described in the *Sun Integrated Lights Out Manager 2.0 User's Guide*.

- DIMM fault LED is off – The DIMM is operating properly.
- DIMM fault LED is flashing (amber) – At least one of the DIMMs in this DIMM pair has reported 24 CEs within a 24-hour period.
- Motherboard Fault LED on mezzanine is on – There is a fault on the motherboard. This LED is there because you cannot see the motherboard LEDs when the mezzanine board is present.

Note – The Motherboard Fault LED operates independently of the Press to See Fault button, and does not operate on stored power.

See [FIGURE 3-1](#) for the locations of DIMMs and LEDs on the motherboard. See [FIGURE 3-2](#) for the locations of DIMMs and LEDs on the mezzanine board.

FIGURE 3-1 DIMMs and LEDs on Motherboard





FIGURE 3-2 DIMMs and LEDs on Mezzanine Board



Isolating and Correcting DIMM ECC Errors

If your log files report an ECC error or a problem with a DIMM, complete the steps below until you can isolate the fault.

In this example, the log file reports an error with the DIMM in CPU0, slot 7. The fault LEDs on CPU0, slots 6 and 7 are on.

To isolate and correct DIMM ECC errors:

1. If you have not already done so, shut down your server to standby power mode and remove the cover.
2. Inspect the installed DIMMs to ensure that they comply with the [“DIMM Population Rules”](#) on page 11.

3. Press the **PRESS TO SEE FAULT** button, and inspect the DIMM fault LEDs. See [FIGURE 3-1](#) and [FIGURE 3-2](#).

A flashing LED identifies a component with a fault.

- For CEs, the LEDs correctly identify the DIMM where the errors were detected.
- For UCEs, both LEDs in the pair flash if there is a problem with either DIMM in the pair.

Note – If your server is equipped with a mezzanine board, the motherboard DIMMs and LEDs will be hidden beneath it. However, the Motherboard Fault LED lights to indicate that there is a problem on the motherboard (only while AC power is still connected). If the Motherboard Fault LED on the mezzanine board lights, remove the mezzanine board as described in your server’s service manual, and inspect the LEDs on the motherboard.

4. Disconnect the AC power cords from the server.



Caution – Before handling components, attach an ESD wrist strap to a chassis ground (any unpainted metal surface). The system’s printed circuit boards and hard disk drives contain components that are extremely sensitive to static electricity.

Note – To recover fault information look in the SP SEL, as described in the *Sun Integrated Lights Out Manager 2.0 User’s Guide*.

5. Remove the DIMMs from the DIMM slots in the CPU.

Refer to your server’s service manual for details.

6. Visually inspect the DIMMs for physical damage, dust, or any other contamination on the connector or circuits.
7. Visually inspect the DIMM slot for physical damage. Look for cracked or broken plastic on the slot.
8. Dust off the DIMMs, clean the contacts, and reseal them.



Caution – Use only compressed air to dust DIMMs.

9. If there is no obvious damage, replace any failed DIMMs.

For UCEs, if the LEDs indicate a fault with the pair, replace both DIMMs. Ensure that they are inserted correctly with ejector latches secured.

10. Reconnect AC power cords to the server.

11. Power on the server and run the diagnostics test again.

12. Review the log file.

If the tests identify the same error, the problem is in the CPU, not the DIMMs.

Event Logs and POST Codes

This appendix contains information about the BIOS event log, the BMC system event log, the power-on self-test (POST), and console redirection. It contains the following sections:

- “Viewing Event Logs” on page 21
- “Power-On Self-Test (POST)” on page 25

Viewing Event Logs

Use this procedure to view the BIOS event log and the BMC system event log.

- 1. To turn on main power mode (all components powered on) if necessary, use a ball point pen or other stylus to press and release the Power button on the server front panel. See [FIGURE 1-1](#).**

When main power is applied to the full server, the Power/OK LED next to the Power button lights and remains lit.

- 2. Enter the BIOS Setup utility by pressing the F2 key while the system is performing the power-on self-test (POST).**

The BIOS Main menu screen is displayed.

- 3. View the BIOS event log.**

- a. From the BIOS Main Menu screen, select Advanced.**

The Advanced Settings screen is displayed:

```
Main      Advanced  PCIPnP    Boot     Security  Chipset   Exit
*****
* Advanced Settings                               * Configure CPU. *
* ***** *
* WARNING: Setting wrong values in below sections *
*           may cause system to malfunction.      *
* * * * * * * * * * * * * * * * * * * * * * * * * * *
* * CPU Configuration                             *
* * IDE Configuration                             *
* * Hyper Transport Configuration                 *
* * ACPI Configuration                           *
* * Event Log Configuration                       *
* * IPMI 2.0 Configuration                       *
* * MPS Configuration                             *
* * PCI Express Configuration                    * *   Select Screen *
* * Remote Access Configuration                  * **   Select Item  *
* * USB Configuration                            * Enter Go to Sub Screen *
* * * * * * * * * * * * * * * * * * * * * * * * * * *
* * * * * * * * * * * * * * * * * * * * * * * * * * *
* * * * * * * * * * * * * * * * * * * * * * * * * * *
* * * * * * * * * * * * * * * * * * * * * * * * * * *
* * * * * * * * * * * * * * * * * * * * * * * * * * *
* * * * * * * * * * * * * * * * * * * * * * * * * * *
* * * * * * * * * * * * * * * * * * * * * * * * * * *
*****
v02.61 (C)Copyright 1985-2006, American Megatrends, Inc.
```


b. From the Advanced Settings screen, select Event Log Configuration.

The Advanced Menu Event Logging Details screen is displayed.

```
Advanced
*****
* Event Logging details                                * View all unread events *
* ***** * on the Event Log.                        *
* View Event Log                                     *
* Mark all events as read                             *
* Clear Event Log                                     *
*                                                     *
*                                                     *
*                                                     *
*                                                     *
*                                                     *
*                                                     *
*                                                     *
* *          Select Screen                            *
* **         Select Item                              *
* Enter Go to Sub Screen                             *
* F1         General Help                             *
* F10        Save and Exit                            *
* ESC        Exit                                     *
*                                                     *
*                                                     *
*****
v02.61 (C)Copyright 1985-2006, American Megatrends, Inc.
```

c. From the Event Logging Details screen, select View Event Log.

All unread events are displayed.

4. View the BMC system event log:

a. From the BIOS Main Menu screen, select Advanced.

The Advanced Settings screen is displayed.

b. From the Advanced Settings screen, select IPMI 2.0 Configuration.

The Advanced Menu IPMI 2.0 Configuration screen is displayed:

```

Advanced
*****
* IPMI 2.0 Configuration                               * View all events in the *
* ***** * BMC Event Log.                            *
* Status Of BMC                                     Working          *
* * View BMC System Event Log                       * It will take up to    *
* Reload BMC System Event Log                       * 60 Seconds approx.  *
* Clear BMC System Event Log                        * to read all         *
* * LAN Configuration                               * BMC SEL records.    *
* * PEF Configuration                               *                      *
* BMC Watch Dog Timer Action      [Disabled]        *                      *
* * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * *
* * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * *
* * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * *
* * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * *
* * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * *
* * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * *
* * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * *
* * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * *
*****
v02.61 (C)Copyright 1985-2006, American Megatrends, Inc.

```

c. From the IPMI 2.0 Configuration screen, select View BMC System Event Log.

The log takes about 60 seconds to generate, then it is displayed on the screen.

- 5. If the problem with the server is not evident, continue with [“Using the ILOM Service Processor GUI to View System Information”](#) on page 43, or [“Viewing ILOM SP Event Logs”](#) on page 45.**

Power-On Self-Test (POST)

The system BIOS provides a rudimentary power-on self-test. The basic devices required for the server to operate are checked, memory is tested, the LSI 1064 disk controller and attached disks are probed and enumerated, and the two Intel dual Gigabit Ethernet controllers are initialized.

The progress of the self-test is indicated by a series of POST codes. These codes are displayed at the bottom right corner of the system's VGA screen (once the self-test has progressed far enough to initialize the system video). However, the codes are displayed as the self-test runs and scroll off of the screen too quickly to be read. An alternate method of displaying the POST codes is to redirect the output of the console to a serial port (see [“Redirecting Console Output”](#) on page 26).

How BIOS POST Memory Testing Works

The BIOS POST memory testing is performed as follows:

1. The first megabyte of DRAM is tested by the BIOS before the BIOS code is shadowed (that is, copied from ROM to DRAM).
2. Once executing out of DRAM, the BIOS performs a simple memory test (a write/read of every location with the pattern 55aa55aa).

Note – Enabling Quick Boot causes the BIOS to skip the memory test. See [“Changing POST Options”](#) on page 28 for more information.

Note – Because the server can contain up to 64 MB of memory (128 MB for the X4440), the memory test can take several minutes. You can cancel POST testing by pressing any key during POST.

3. The BIOS polls the memory controllers for both correctable and uncorrectable memory errors and logs those errors into the service processor.

Redirecting Console Output

Use the following instructions to access the service processor and redirect the console output so that the BIOS POST codes can be read.

1. **Initialize the BIOS Setup utility by pressing the F2 key while the system is performing the power-on self-test (POST).**

The BIOS Main menu screen is displayed.

2. **Select the Advanced menu tab.**

The Advanced Settings screen is displayed.

3. **Select IPMI 2.0 Configuration.**

The IPMI 2.0 Configuration screen is displayed.

4. **Select the LAN Configuration menu item.**

The LAN Configuration screen displays the service processor's IP address.

5. **To configure the service processor's IP address (optional):**

- a. **Select the IP Assignment option that you want to use (DHCP or Static).**

- If you choose *DHCP*, the server's IP address is retrieved from your network's DHCP server and displayed using the following format:
Current IP address in BMC : xxx.xxx.xxx.xxx
- If you choose *Static* to assign the IP address manually, perform the following steps:

- i. **Type the IP address in the IP Address field.**

You can also enter the subnet mask and default gateway settings in their respective fields.

- ii. **Select Commit and press Return to commit the changes.**

- iii. **Select Refresh and press Return to see your new settings displayed in the Current IP address in BMC field.**

6. **Start a web browser and type the service processor's IP address in the browser's URL field.**

7. **When you are prompted for a user name and password, type the following:**

- User Name: **root**
- Password: **changeme**

The Sun Integrated Lights Out Manager main GUI screen is displayed.

8. **Click the Remote Control tab.**

9. **Click the Redirection tab.**

10. Set the color depth for the redirection console at either 6 or 8 bits.
11. Click the **Start Redirection** button.
12. When you are prompted for a user name and password, type the following:
 - User Name: **root**
 - Password: **changeme**The current POST screen is displayed.

3. Select Boot Settings Configuration.

The Boot Settings Configuration screen is displayed.

```
Boot
*****
**
* Boot Settings Configuration          * Allows BIOS to skip      *
* *****                            * certain tests while      *
* Quick Boot                          [Disabled]                * booting. This will       *
* Quiet Boot                          [Disabled]                * decrease the time       *
* AddOn ROM Display Mode              [Force BIOS]              * needed to boot the     *
* Bootup Num-Lock                     [On]                      * system.                 *
* Wait For 'F1' If Error               [Disabled]                *                         *
* Interrupt 19 Capture                 [Enabled]                 *                         *
*                                     *                         *
*                                     *                         *
*                                     *                         *
*                                     * *      Select Screen    *
*                                     * **      Select Item     *
*                                     * +-      Change Option   *
*                                     * F1      General Help    *
*                                     * F10     Save and Exit   *
*                                     * ESC     Exit           *
*                                     *                         *
*                                     *                         *
*****
**
v02.61 (C)Copyright 1985-2006, American Megatrends, Inc.
```

4. On the Boot Settings Configuration screen, there are several options that you can enable or disable:

- **Quick Boot** – This option is disabled by default. If you enable this, the BIOS skips certain tests while booting, such as the extensive memory test. This decreases the time it takes for the system to boot.
- **Quiet Boot** – This option is disabled by default. If you enable this, the Sun Microsystems logo is displayed instead of POST codes.
- **Add On ROM Display Mode** – This option is set to Force BIOS by default. This option has effect only if you have also enabled the Quiet Boot option, but it controls whether output from the Option ROM is displayed. The two settings for this option are as follows:
 - **Force BIOS** – Remove the Sun logo and display Option ROM output.
 - **Keep Current** – Do not remove the Sun logo. The Option ROM output is not displayed.

- **Boot Num-Lock** – This option is On by default (keyboard Num-Lock is turned on during boot). If you set this to off, the keyboard Num-Lock is not turned on during boot.
- **Wait for F1 if Error** – This option is disabled by default. If you enable this, the system will pause if an error is found during POST and will only resume when you press the F1 key.
- **Interrupt 19 Capture** – This option is reserved for future use. Do not change.
- **Default Boot Order** – The letters in the brackets represent the boot devices. To see the letters defined, position your cursor over the field and read the definition in the right side of the screen.

POST Codes

TABLE A-1 contains descriptions of each of the POST codes, listed in the same order in which they are generated. These POST codes appear as a four-digit string that is a combination of two-digit output from primary I/O port 80 and two-digit output from secondary I/O port 81. In the POST codes listed in TABLE A-1, the first two digits are from port 81 and the last two digits are from port 80.

TABLE A-1 POST Codes

Post Code	Description
00d0	Coming out of POR, PCI configuration space initialization, enabling 8111's SMBus.
00d2	Disable cache, full memory sizing, and verify that flat mode is enabled.
00d3	Memory detections and sizing in boot block, cache disabled, IO APIC enabled.
01d4	Test base 512KB memory. Adjust policies and cache first 8MB.
01d5	Bootblock code is copied from ROM to lower RAM. BIOS is now executing out of RAM.
01d6	Key sequence and OEM specific method is checked to determine if BIOS recovery is forced. If next code is E0, BIOS recovery is being executed. Main BIOS checksum is tested.
01d7	Restoring CPUID; moving bootblock-runtime interface module to RAM; determine whether to execute serial flash.
01d8	Uncompressing runtime module into RAM. Storing CPUID information in memory.
01d9	Copying main BIOS into memory.
01da	Giving control to BIOS POST.
0004	Check CMOS diagnostic byte to determine if battery power is OK and CMOS checksum is OK. If the CMOS checksum is bad, update CMOS with power-on default values.
00c2	Set up boot strap processor for POST. This includes frequency calculation, loading BSP microcode, and applying user requested value for GART Error Reporting setup question.
00c3	Errata workarounds applied to the BSP (#78 & #110).
00c6	Re-enable cache for boot strap processor, and apply workarounds in the BSP for errata #106, #107, #69, and #63 if appropriate.
00c7	HT sets link frequencies and widths to their final values.
000a	Initializing the 8042 compatible Keyboard Controller.
000c	Detecting the presence of Keyboard in KBC port.
000e	Testing and initialization of different Input Devices. Traps the INT09h vector, so that the POST INT09h handler gets control for IRQ1.
8600	Preparing CPU for booting to OS by copying all of the context of the BSP to all application processors present. NOTE: APs are left in the CLI HLT state.

TABLE A-1 POST Codes (Continued)

Post Code	Description
de00	Preparing CPU for booting to OS by copying all of the context of the BSP to all application processors present. NOTE: APs are left in the CLI HLT state.
8613	Initialize PM regs and PM PCI regs at Early-POST. Initialize multi-host bridge, if system supports it. Setup ECC options before memory clearing. Enable PCI-X clock lines in the 8131.
0024	Uncompress and initialize any platform specific BIOS modules.
862a	BBS ROM initialization.
002a	Generic Device Initialization Manager (DIM) - Disable all devices.
042a	ISA PnP devices - Disable all devices.
052a	PCI devices - Disable all devices.
122a	ISA devices - Static device initialization.
152a	PCI devices - Static device initialization.
252a	PCI devices - Output device initialization.
202c	Initializing different devices. Detecting and initializing the video adapter installed in the system that have optional ROMs.
002e	Initializing all the output devices.
0033	Initializing the silent boot module. Set the window for displaying text information.
0037	Displaying sign-on message, CPU information, setup key message, and any OEM specific information.
4538	PCI devices - IPL device initialization.
5538	PCI devices - General device initialization.
8600	Preparing CPU for booting to OS by copying all of the context of the BSP to all application processors present. NOTE: APs are left in the CLI HLT state.

POST Code Checkpoints

The POST code checkpoints are the largest set of checkpoints during the BIOS pre-boot process. [TABLE A-2](#) describes the type of checkpoints that might occur during the POST portion of the BIOS. These two-digit checkpoints are the output from primary I/O port 80.

TABLE A-2 POST Code Checkpoints

Post Code	Description
03	Disable NMI, Parity, video for EGA, and DMA controllers. At this point, only ROM accesses go to the GPNV. If BB size is 64K, turn on ROM Decode below FFFF0000h. It should allow USB to run in the E000 segment. The HT must program the NB specific initialization and OEM specific initialization, and can program if it need be at beginning of BIOS POST, similar to overriding the default values of kernel variables.
04	Check CMOS diagnostic byte to determine if battery power is OK and CMOS checksum is OK. Verify CMOS checksum manually by reading storage area. If the CMOS checksum is bad, update CMOS with power-on default values and clear passwords. Initialize status register A. Initialize data variables that are based on CMOS setup questions. Initialize both the 8259-compatible PICs in the system.
05	Initialize the interrupt controlling hardware (generally PIC) and interrupt vector table.
06	Do R/W test to CH-2 count reg. Initialize CH-0 as system timer. Install the POSTINT1Ch handler. Enable IRQ-0 in PIC for system timer interrupt. Traps INT1Ch vector to "POSTINT1ChHandlerBlock."
C0	Early CPU Init Start--Disable Cache--Init Local APIC.
C1	Set up boot strap processor information.
C2	Set up boot strap processor for POST. This includes frequency calculation, loading BSP microcode, and applying user requested value for GART Error Reporting setup question.
C3	Errata workarounds applied to the BSP (#78 & #110).
C5	Enumerate and set up application processors. This includes microcode loading and workarounds for errata (#78, #110, #106, #107, #69, #63).
C6	Re-enable cache for boot strap processor, and apply workarounds in the BSP for errata #106, #107, #69, and #63 if appropriate. In case of mixed CPU steppings, errors are sought and logged, and an appropriate frequency for all CPUs is found and applied. NOTE: APs are left in the CLI HLT state.
C7	The HT sets link frequencies and widths to their final values. This routine gets called after CPU frequency has been calculated to prevent bad programming.
0A	Initializes the 8042 compatible Keyboard Controller.
0B	Detects the presence of PS/2 mouse.
0C	Detects the presence of Keyboard in KBC port.

TABLE A-2 POST Code Checkpoints *(Continued)*

Post Code	Description
0E	Testing and initialization of different Input Devices. Also, update the Kernel Variables. Traps the INT09h vector, so that the POST INT09h handler gets control for IRQ1. Uncompress all available language, BIOS logo, and Silent logo modules.
13	Initialize PM regs and PM PCI regs at Early-POST, Initialize multi-host bridge, if system will support it. Setup ECC options before memory clearing. REDIRECTION causes corrected data to written to RAM immediately. CHIPKILL provides 4 bit error det/corr of x4 type memory. Enable PCI-X clock lines in the 8131.
20	Relocate all the CPUs to a unique SMBASE address. The BSP will be set to have its entry point at A000:0. If less than 5 CPU sockets are present on a board, subsequent CPUs entry points will be separated by 8000h bytes. If more than 4 CPU sockets are present, entry points are separated by 200h bytes. CPU module will be responsible for the relocation of the CPU to correct address. NOTE: APs are left in the INIT state.
24	Uncompress and initialize any platform-specific BIOS modules.
30	Initialize System Management Interrupt.
2A	Initializes different devices through DIM.
2C	Initializes different devices. Detects and initializes the video adapter installed in the system that have optional ROMs.
2E	Initializes all the output devices.
31	Allocate memory for ADM module and uncompress it. Give control to ADM module for initialization. Initialize language and font modules for ADM. Activate ADM module.
33	Initializes the silent boot module. Set the window for displaying text information.
37	Displaying sign-on message, CPU information, setup key message, and any OEM specific information.
38	Initializes different devices through DIM.
39	Initializes DMAC-1 and DMAC-2.
3A	Initialize RTC date/time.
3B	Test for total memory installed in the system. Also, Check for DEL or ESC keys to limit memory test. Display total memory in the system.
3C	By this point, RAM read/write test is completed, program memory holes or handle any adjustments needed in RAM size with respect to NB. Test if HT Module found an error in BootBlock and CPU compatibility for MP environment.
40	Detect different devices (parallel ports, serial ports, and coprocessor in CPU,... etc.) successfully installed in the system and update the BDA, EBDA,... etc.
50	Programming the memory hole or any kind of implementation that needs an adjustment in system RAM size if required.
52	Updates CMOS memory size from memory found in memory test. Allocates memory for Extended BIOS Data Area from base memory.

TABLE A-2 POST Code Checkpoints *(Continued)*

Post Code	Description
60	Initializes NUM-LOCK status and programs the KBD typematic rate.
75	Initialize Int-13 and prepare for IPL detection.
78	Initializes IPL devices controlled by BIOS and option ROMs.
7A	Initializes remaining option ROMs.
7C	Generate and write contents of ESCD in NVRam.
84	Log errors encountered during POST.
85	Displays errors to the user and gets the user response for error.
87	Execute BIOS setup if needed/requested.
8C	After all device initialization is done, program any user selectable parameters relating to NB/SB, such as timing parameters, non-cacheable regions and the shadow RAM cacheability, and do any other NB/SB/PCIX/OEM specific programming needed during Late-POST. Background scrubbing for DRAM, and L1 and L2 caches are set up based on setup questions. Get the DRAM scrub limits from each node.
8D	Build ACPI tables (if ACPI is supported).
8E	Program the peripheral parameters. Enable/Disable NMI as selected.
90	Late POST initialization of system management interrupt.
A0	Check boot password if installed.
A1	Clean-up work needed before booting to OS.
A2	Takes care of runtime image preparation for different BIOS modules. Fills the free area in F000h segment with 0FFh. Initializes the Microsoft IRQ Routing Table. Prepares the runtime language module. Disables the system configuration display if needed.
A4	Initialize runtime language module.
A7	Displays the system configuration screen if enabled. Initializes the CPUs before boot, which includes the programming of the MTRRs.
A8	Prepare CPU for OS boot including final MTRR values.
A9	Wait for user input at configuration display if needed.
AA	Uninstall POST INT1Ch vector and INT09h vector. Deinitializes the ADM module.
AB	Prepare BBS for Int 19 boot.
AC	Any kind of Chipsets (NB/SB) specific programming needed during End- POST, just before giving control to runtime code booting to OS. Program the system BIOS (0F0000h shadow RAM) cacheability. Ported to handle any OEM specific programming needed during End-POST. Copy OEM specific data from POST_DSEG to RUN_CSEG.

TABLE A-2 POST Code Checkpoints *(Continued)*

Post Code	Description
B1	Save system context for ACPI.
00	Prepares CPU for booting to OS by copying all of the context of the BSP to all application processors present. NOTE: APs are left in the CLI HLT state.
61-70	OEM POST Error. This range is reserved for chipset vendors and system manufacturers. The error associated with this value may be different from one platform to the next.

Status Indicator LEDs

This appendix contains information about the locations and behavior of the LEDs on the server. It describes the external LEDs that can be viewed on the outside of the server and the internal LEDs that can be viewed only with the main cover removed.

External Status Indicator LEDs

See the following figures and tables for information about the LEDs that are viewable on the outside of the server.

- [FIGURE B-1](#) shows and describes the front panel LEDs.
- [FIGURE B-2](#) shows and describes the back panel LEDs.
- [FIGURE B-3](#) shows and describes the hard drive LEDs.
- [FIGURE B-4](#) and [FIGURE B-5](#) show the location of the internal LEDs.

Front Panel LEDs

FIGURE B-1 Front Panel LEDs (X4140 shown)




Figure Legend

- | | | | |
|---|-----------------------------------|---|--|
| 1 | Locator LED/Locator button: White | 4 | Rear PS LED: (Amber) Power supply fault |
| 2 | Service Required LED: Amber | 5 | System Over Temperature LED: (Amber) |
| 3 | Power/OK LED: Green | 6 | Top Fan LED: (Amber) Service action required on fan(s) |

Back Panel LEDs

FIGURE B-2 Back Panel LEDs (X4140 shown)




Figure Legend

- | | | | |
|---|--|---|---|
| 1 | Power Supply LEDs:
Power Supply OK: Green
Power Supply Fail: Amber
AC OK: Green | 3 | Service Required LED |
| 2 | Locator LED Button | 4 | Power OK LED |
| | | 5 | Ethernet Port LEDs
Left side: Green indicates link activity
Right side:
Green indicates link activity
Amber indicates link is operating at less than maximum speed. |

Hard Drive LEDs

FIGURE B-3 Hard Drive LEDs



Figure Legend

-
- | | |
|---|---|
| 1 | Ready to remove LED: Blue – Service action is allowed |
| 2 | Fault LED: Amber – Service action is required |
| 3 | Status LED: Green – Blinks when data is being transferred |
-

Internal Status Indicator LEDs

The server has internal status indicators on the motherboard, and on the mezzanine board. For motherboard locations, see [FIGURE B-4](#). For mezzanine board locations, see [FIGURE B-5](#).

- The DIMM Fault LEDs indicate a problem with the corresponding DIMM. They are located next to the DIMM ejector handles.

When you press the Press to See Fault button, if there is a problem with a DIMM, the corresponding DIMM Fault LED flashes. See [“DIMM Fault LEDs” on page 15](#) for details.

- The CPU Fault LEDs indicate a problem with the corresponding CPU.

When you press the Press to See Fault button, if there is a problem with a CPU, the corresponding CPU Fault LED flashes.

Note – The DIMM Fault and Motherboard Fault LEDs operate on stored power for up to a minute when the system is powered down, even after the AC power is disconnected, and the motherboard (or mezzanine board) is out of the system. The stored power lasts for about half an hour.

- The Motherboard Fault LED on the mezzanine board indicates that there is a problem with the motherboard.

Note – The mezzanine board, when present, obscures part of the motherboard, including the LEDs. The Motherboard Fault LED indicates that one or more of the LEDs on the motherboard is active.

FIGURE B-4 DIMMs and LEDs on Motherboard





FIGURE B-5 DIMMs and LEDs on Mezzanine Board



Using the ILOM Service Processor GUI to View System Information

This appendix contains information about using the Integrated Lights Out Manager (ILOM) Service processor (SP) GUI to view monitoring and maintenance information for your server.

- [“Making a Serial Connection to the SP” on page 44](#)
- [“Viewing ILOM SP Event Logs” on page 45](#)
- [“Viewing Replaceable Component Information” on page 48](#)
- [“Viewing Sensors” on page 50](#)

For more information on using the ILOM SP GUI to maintain the server (for example, configuring alerts), refer to the *Integrated Lights Out Manager Administration Guide*.

- If any of the logs or information screens indicate a DIMM error, see [Chapter 3](#).
- If the problem with the server is not evident after viewing ILOM SP logs and information, continue with [“Running SunVTS Diagnostic Tests” on page 7](#).

Making a Serial Connection to the SP

To make a serial connection to the SP:

1. **Connect a serial cable from the RJ-45 Serial Management port on server to a terminal device.**
2. **Press ENTER on the terminal device to establish a connection between that terminal device and the ILOM SP.**

Note – If you are connecting to the serial port on the SP before it has been powered up or during its power-up sequence, you will see boot messages.

The service processor eventually displays a login prompt. For example:

```
SUNSP0003BA84D777 login:
```

The first string in the prompt is the default host name for the ILOM SP. It consists of the prefix `SUNSP` and the MAC address of the ILOM SP. The MAC address for each ILOM SP is unique.

3. **Log in to the SP and type the default user name, `root`, with the default password, `changeme`.**

Once you have successfully logged in to the SP, it displays its default command prompt.

```
->
```

4. **To start the serial console, type the following commands:**

```
cd /SP/console  
start
```

To exit console mode and return to the service processor, type (escape/shift 9)

- Continue with the following procedures:
 - [“Viewing ILOM SP Event Logs” on page 45](#)
 - [“Viewing Replaceable Component Information” on page 48](#)
 - [“Viewing Sensors” on page 50](#)

Viewing ILOM SP Event Logs

Events are notifications that occur in response to some actions. The IPMI system event log (SEL) provides status information about the server's hardware and software to the ILOM software, which displays the events in the ILOM web GUI. To view event logs:

1. Log in to the SP as Administrator or Operator to reach the ILOM web GUI:

a. Type the IP address of the server's SP into your web browser.

The Sun Integrated Lights Out Manager Login screen is displayed.

b. Type your user name and password.

When you first try to access the ILOM SP, you are prompted to type the default user name and password. The default user name and password are:

Default user name: **root**

Default password: **changeme**

2. From the System Monitoring tab, select Event Logs.

The System Event Logs page is displayed. See [FIGURE C-1](#) for a page that shows sample information.

FIGURE C-1 System Event Logs Page

ABOUT REFRESH LOG OUT

Role (User): Administrator (root) SP Hostname : SUNSP00144F8D2DB7

Sun™ Integrated Lights Out Manager

Sun™ Microsystems, Inc.

System Information System Monitoring Configuration User Management Remote Control Maintenance

Sensor Readings Indicators Event Logs

Event Log

Displays every event in the SP, including IPMI, Audit, and FMA events. Click the *Clear Log* button to delete all current log entries.

Event Log

Clear Log

Event ID	Class	Type	Severity	Date/Time	Description
162	Audit	Log	minor	Wed Nov 28 09:39:10 2007	root : Open Session : object = /session/type : value = www : success
161	Audit	Log	minor	Wed Nov 28 09:23:06 2007	root : Open Session : object = /session/type : value = shell : success
160	IPMI	Log	critical	Wed Nov 28 09:21:01 2007	ID = 81 : pre-init timestamp : Entity Presence : hdd7.prsnt : Device Absent
159	IPMI	Log	critical	Wed Nov 28 09:20:57 2007	ID = 80 : pre-init timestamp : Entity Presence : hdd2.prsnt : Device Absent

3. Select the category of event that you want to view in the log from the drop-down list box.

You can select from the following types of events:

- Sensor-specific events. These events relate to a specific sensor for a component, for example, a fan sensor or a power supply sensor.
- BIOS-generated events. These events relate to error messages generated in the BIOS.
- System management software events. These events relate to events that occur within the ILOM software.

After you have selected a category of event, the Event Log table is updated with the specified events. The fields in the Event Log are described in [TABLE C-1](#).

TABLE C-1 Event Log Fields

Field	Description
Event ID	The number of the event, in sequence from number 1.
Time Stamp	The day and time the event occurred. If the Network Time Protocol (NTP) server is enabled to set the SP time, the SP clock will use Universal Coordinated Time (UTC). For more information about time stamps, see “Interpreting Event Log Time Stamps” on page 47 .
Sensor Name	The name of a component for which an event was recorded. The sensor name abbreviations correspond to these components: sys: System or chassis <ul style="list-style-type: none"> • p0: Processor 0 • p1: Processor 1 • io: I/O board • ps: Power supply • fp: Front panel • ft: Fan tray • mb: Motherboard
Sensor Type	The type of sensor for the specified event.
Description	A description of the event.

4. To clear the event log, click the Clear Event Log button.

A confirmation dialog box is displayed.

5. Click OK to clear all entries in the log.

6. If the problem with the server is not evident after viewing ILOM SP logs and information, continue with [“Running SunVTS Diagnostic Tests” on page 7](#).

Interpreting Event Log Time Stamps

The system event log time stamps are related to the service processor clock settings. If the clock settings change, the change is reflected in the time stamps.

When the service processor reboots, the SP clock is set to Thu Jan 1 00:00:00 UTC 1970. The SP reboots as a result of the following:

- A complete system unplug/replug power cycle
- An IPMI command; for example, `mc reset cold`
- A command-line interface (CLI) command; for example, `reset /SP`

- ILOM web GUI operation; for example, from the Maintenance tab, selecting Reset SP
- An SP firmware upgrade

After an SP reboot, the SP clock is changed by the following events:

- When the host is booted. The host's BIOS unconditionally sets the SP time to that indicated by the host's RTC. The host's RTC is set by the following operations:
 - When the host's CMOS is cleared as a result of changing the host's RTC battery or inserting the CMOS-clear jumper on the motherboard. The host's RTC starts at Jan 1 00:01:00 2002.
 - When the host's operating system sets the host's RTC. The BIOS does not consider time zones. Solaris and Linux software respect time zones and will set the system clock to UTC. Therefore, after the OS adjusts the RTC, the time set by the BIOS will be UTC.
 - When the user sets the RTC using the host BIOS Setup screen.
- Continuously via NTP if NTP is enabled on the SP. NTP jumping is enabled to recover quickly from an erroneous update from the BIOS or user. NTP servers provide UTC time. Therefore, if NTP is enabled on the SP, the SP clock will be in UTC.
- Via the CLI, ILOM web GUI, and IPMI

Viewing Replaceable Component Information

Depending on the component you select, information about the manufacturer, component name, serial number, and part number can be displayed. To view replaceable component information:

1. Log in to the SP as Administrator or Operator to reach the ILOM web GUI:

a. Type the IP address of the server's SP into your web browser.

The Sun Integrated Lights Out Manager Login screen is displayed.

b. Type your user name and password.

When you first try to access the ILOM Service Processor, you are prompted to type the default user name and password. The default user name and password are:


Default user name: **root**

Default password: **changeme**

2. From the System Information tab, select Components.

The Replaceable Component Information page is displayed. See [FIGURE C-2](#).

FIGURE C-2 Replaceable Component Information Page



3. Select a component from the drop-down list.

Information about the selected component is displayed.

4. If the problem with the server is not evident after viewing replaceable component information, continue with [“Running SunVTS Diagnostic Tests”](#) on [page 7](#).

Viewing Sensors

This section describes how to view the server temperature, voltage, and fan sensor readings.

For a complete list of sensors, see [Appendix D](#).

To view sensor readings:

1. Log in to the SP as Administrator or Operator to reach the ILOM web GUI:

a. Type the IP address of the server's SP into your web browser.

The Sun Integrated Lights Out Manager Login screen is displayed.

b. Type your user name and password.

When you first try to access the ILOM Service Processor, you are prompted to type the default user name and password. The default user name and password are:

Default user name: **root**

Default password: **changeme**

2. From the System Monitoring tab, select Sensor Readings.

The Sensor Readings page is displayed. See [FIGURE C-3](#).

FIGURE C-3 Sensor Readings Page

Sensor Readings

View readings for system sensors. Click on a sensor name for more information, including threshold values.


Name	Type	Reading
/SYS/MB/P0/PRSNT	Entity Presence	Present
/SYS/MB/P0/T_CORE	Temperature	16.000 degrees C
/SYS/MB/P0W_VDDCORE	Voltage	1.140 Volts
/SYS/MB/P0W_+1V8	Voltage	1.836 Volts
/SYS/MB/P0W_+0V9	Voltage	0.912 Volts
/SYS/MB/P0/PROCHOT	Entity Fault	State Deasserted
/SYS/MB/P1/PRSNT	Entity Presence	Present
/SYS/MB/P1/T_CORE	Temperature	16.000 degrees C
/SYS/MB/P1W_VDDCORE	Voltage	1.140 Volts

3. Click the Refresh button to update the sensor readings to their current status.

4. Click a sensor to display its thresholds.

A display of properties and values appears. See the example in [FIGURE C-4](#).

FIGURE C-4 Sensor Details Page



5. If the problem with the server is not evident after viewing sensor readings information, continue with [“Running SunVTS Diagnostic Tests”](#) on page 7.

Error Handling

This appendix contains information about how the servers process and log errors. See the following sections:

- “Handling of Uncorrectable Errors” on page 53
- “Handling of Correctable Errors” on page 56
- “Handling of Parity Errors (PERR)” on page 59
- “Handling of System Errors (SERR)” on page 61
- “Handling Mismatching Processors” on page 63
- “Hardware Error Handling Summary” on page 64

Handling of Uncorrectable Errors

This section lists facts and considerations about how the server handles uncorrectable errors.

Note – The BIOS ChipKill feature must be disabled if you are testing for failures of multiple bits within a DRAM (ChipKill corrects for the failure of a four-bit wide DRAM).

- The BIOS logs the error to the SP system event log (SEL) through the board management controller (BMC).
- The SP's SEL is updated with the failing DIMM pair's particular bank address.
- The system reboots.
- The BIOS logs the error in DMI.

Note – If the error is on low 1MB, the BIOS freezes after rebooting. Therefore, no DMI log is recorded.

- An example of the error reported by the SEL through IPMI 2.0 is as follows:
 - When low memory is erroneous, the BIOS is frozen on pre-boot low memory test because the BIOS cannot decompress itself into faulty DRAM and execute the following items:

```
ipmitool> sel list
100 | 08/26/2005 | 11:36:09 | OEM #0xfb |
200 | 08/26/2005 | 11:36:12 | System Firmware Error | No usable system memory
300 | 08/26/2005 | 11:36:12 | Memory | Memory Device Disabled | CPU 0 DIMM 0
```

- When the faulty DIMM is beyond the BIOS's low 1MB extraction space, proper boot happens:

```
ipmitool> sel list
100 | 08/26/2005 | 05:04:04 | OEM #0xfb |
200 | 08/26/2005 | 05:04:09 | Memory | Memory Device Disabled | CPU 0 DIMM 0
```

- Note the following considerations for this revision:
 - Uncorrectable ECC Memory Error is not reported.
 - Multi-bit ECC errors are reported as Memory Device Disabled.
 - On first reboot, BIOS logs a HyperTransport Error in the DMI log.
 - The BIOS disables the DIMM.
 - The BIOS sends the SEL records to the BMC.
 - The BIOS reboots again.
 - The BIOS skips the faulty DIMM on the next POST memory test.
 - The BIOS reports available memory, excluding the faulty DIMM pair.

FIGURE D-1 shows an example of a DMI log screen from BIOS Setup Page.

FIGURE D-1 DMI Log Screen, Uncorrectable Error




Handling of Correctable Errors

This section lists facts and considerations about how the server handles correctable errors.


- During BIOS POST:
 - The BIOS polls the MCK registers.
 - The BIOS logs to DMI.
 - The BIOS logs to the SP SEL through the BMC.
- The feature is turned off at OS boot time by default.
- The following Linux versions report correctable ECC syndrome and memory fill errors in `/var/log`, if kernel flag `mce` is indicated at boot time, or if `mce` is enabled through kernel compile or installation:
 - RH3 Update5 single core
 - RH4 Update1+
 - SLES9 SP1+
- The Linux kernel (`x86_64/kernel/mce.c`) repeats a report every 30 seconds until another error is encountered and an 8131 flag is reset.
- Solaris support provides full self-healing and automated diagnosis for the CPU and Memory subsystems.
- [FIGURE D-2](#) shows an example of a DMI log screen from BIOS Setup Page:

FIGURE D-2 DMI Log Screen, Correctable Error



- If during any stage of memory testing the BIOS finds itself incapable of reading/writing to the DIMM, it takes the following actions:
 - The BIOS disables the DIMM as indicated by the Memory Decreased message in the example in [EXAMPLE D-1](#).
 - The BIOS logs an SEL record.
 - The BIOS logs an event in DMI.

EXAMPLE D-1 DMI Log Screen, Correctable Error, Memory Decreased



Handling of Parity Errors (PERR)

This section lists facts and considerations about how the server handles parity errors (PERR).

- The handling of parity errors works through NMIs.
- During BIOS POST, the NMI is logged in the DMI and the SP SEL. See the following example command and output:

```
[root@d-mpk12-53-238 root]# ipmitool -H 129.146.53.95 -U root -P changeme -I lan sel list -v
SEL Record ID          : 0100
Record Type            : 00
Timestamp              : 01/10/2002 20:16:16
Generator ID          : 0001
EvM Revision          : 04
Sensor Type           : Critical Interrupt
Sensor Number         : 00
Event Type            : Sensor-specific Discrete
Event Direction       : Assertion Event
Event Data            : 04ff00
Description           : PCI PERR
```

- [FIGURE D-3](#) shows an example of a DMI log screen from BIOS Setup Page, with a parity error.

FIGURE D-3 DMI Log Screen, PCI Parity Error



- The BIOS displays the following messages and freezes (during POST or DOS):
 - NMI EVENT!!
 - System Halted due to Fatal NMI!
- The Linux NMI trap catches the interrupt and reports the following NMI “confusion report” sequence:

```
Aug 5 05:15:00 d-mpk12-53-159 kernel: Uhhuh. NMI received for unknown reason 2d
on CPU 0.
Aug 5 05:15:00 d-mpk12-53-159 kernel: Uhhuh. NMI received for unknown reason 2d
on CPU 1.
Aug 5 05:15:00 d-mpk12-53-159 kernel: Dazed and confused, but trying to continue
Aug 5 05:15:00 d-mpk12-53-159 kernel: Do you have a strange power saving mode
enabled?
Aug 5 05:15:00 d-mpk12-53-159 kernel: Uhhuh. NMI received for unknown reason 3d
on CPU 1.
Aug 5 05:15:00 d-mpk12-53-159 kernel: Dazed and confused, but trying to continue
Aug 5 05:15:00 d-mpk12-53-159 kernel: Do you have a strange power saving mode
enabled?
Aug 5 05:15:00 d-mpk12-53-159 kernel: Uhhuh. NMI received for unknown reason 3d
on CPU 0.
Aug 5 05:15:00 d-mpk12-53-159 kernel: Dazed and confused, but trying to continue
Aug 5 05:15:00 d-mpk12-53-159 kernel: Do you have a strange power saving mode
enabled?
Aug 5 05:15:00 d-mpk12-53-159 kernel: Dazed and confused, but trying to continue
Aug 5 05:15:00 d-mpk12-53-159 kernel: Do you have a strange power saving mode
enabled?
```


Note – The Linux system reboots, but does not inform the BIOS of this incident.

Handling of System Errors (SERR)

This section lists facts and considerations about how the server handles system errors (SERR).

- System error handling works through the HyperTransport Synch Flood Error mechanism on 8111 and 8131.
- The following events happen during BIOS POST:
 - POST reports any previous system errors at the bottom of screen. See [FIGURE D-4](#) for an example.

FIGURE D-4 POST Screen, Previous System Error Listed



The screenshot shows a BIOS POST screen with the following text:

```
www.ami.com
American Megatrends
Sun microsystems®
BMC Firmware Revision : 1.00
Checking NURAM..
Initializing USB Controllers .. Done.
Press F2 to run Setup (CTRL+E on Remote Keyboard)
Press F12 to boot from the network (CTRL+N on Remote Keyboard)

USB Device(s): 3 Keyboards, 3 Mice, 2 Storage Devices
Auto-Detecting Pri Master..ATAPI CDROM
Pri Master: DU-28SL 1.0A DE78
Ultra DMA Mode-2
Auto-detecting USB Mass Storage Devices ..
Device #01 : AMI Virtual CDROM
Device #02 : AMI Virtual Floppy
02 USB mass storage devices found and configured. 0085

BMC Responding
A Hyper Transport sync flood error occurred on last boot.
PCI System Error
```


- SERR and Hypertransport Synch Flood Error are logged in DMI and the SP SEL. See the following sample output:

SEL Record ID	: 0a00
Record Type	: 00
Timestamp	: 08/10/2005 06:05:32
Generator ID	: 0001

EvM Revision	: 04
Sensor Type	: Critical Interrupt
Sensor Number	: 00
Event Type	: Sensor-specific Discrete
Event Direction	: Assertion Event
Event Data	: 05ffff
Description	: PCI SERR

- FIGURE D-5 shows an example DMI log screen from the BIOS Setup Page with a system error.

FIGURE D-5 DMI Log Screen with Error



Handling Mismatching Processors

This section lists facts and considerations about how the server handles mismatching processors.

- The BIOS performs a complete POST.
- The BIOS displays a report of any mismatching CPUs, as shown in the following example:

```
AMIBIOS(C)2003 American Megatrends, Inc.
BIOS Date: 08/10/05 14:51:11 Ver: 08.00.10
CPU : AMD Opteron(tm) Processor 254, Speed : 2.4 GHz
Count : 3, CPU Revision, CPU0 : E4, CPU1 : E6
Microcode Revision, CPU0 : 0, CPU1 : 0
DRAM Clocking CPU0 = 400 MHz, CPU1 Core0/1 = 400 MHz
Sun Fire Server, 1 AMD North Bridge, Rev E4
1 AMD North Bridge, Rev E6
1 AMD 8111 I/O Hub, Rev C2
2 AMD 8131 PCI-X Controllers, Rev B2
System Serial Number : 0505AMF028
BMC Firmware Revision : 1.00
Checking NVRAM..
Initializing USB Controllers .. Done.
Press F2 to run Setup (CTRL+E on Remote Keyboard)
Press F12 to boot from the network (CTRL+N on Remote Keyboard)
Press F8 for BBS POPUP (CTRL+P on Remote Keyboard)
```

- No SEL or DMI event is recorded.
- The system enters Halt mode and the following message is displayed:

```
***** Warning: Bad Mix of Processors *****
Multiple core processors cannot be installed with single core
processors.
Fatal Error... System Halted.
```

Hardware Error Handling Summary

TABLE D-1 summarizes the most common hardware errors that you might encounter with these servers.

TABLE D-1 Hardware Error Handling Summary

Error	Description	Handling	Logged (DMI Log or SP SEL)	Fatal?
SP failure	The SP fails to boot upon application of system power.	<p>The SP controls the system reset, so the system may power on, but will not come out of reset.</p> <ul style="list-style-type: none">• During power up, the SP's boot loader turns on the power LED.• During SP boot, Linux startup, and SP sanity check, the power LED blinks.• The LED is turned off when SP management code (the IPMI stack) is started.• At exit of BIOS POST, the LED goes to STEADY ON state.	Not logged	Fatal
SP failure	SP boots but fails POST.	The SP controls the system RESET, so the system will not come out of reset.	Not logged	Fatal
BIOS POST failure	Server BIOS does not pass POST.	<p>There are fatal and non-fatal errors in POST. The BIOS does detect some errors that are announced during POST as POST codes on the bottom right corner of the display on the serial console and on the video display. Some POST codes are forwarded to the SP for logging.</p> <p>The POST codes do not come out in sequential order and some are repeated, because some POST codes are issued by code in add-in card BIOS expansion ROMs.</p> <p>In the case of early POST failures (for example, the BSP fails to operate correctly), BIOS just halts without logging.</p> <p>For some other POST failures subsequent to memory and SP initialization, the BIOS logs a message to the SP's SEL.</p>		

TABLE D-1 Hardware Error Handling Summary (Continued)

Error	Description	Handling	Logged (DMI Log or SP SEL)	Fatal?
Single-bit DRAM ECC error	With ECC enabled in the BIOS Setup, the CPU detects and corrects a single-bit error on the DIMM interface.	The CPU corrects the error in hardware. No interrupt or machine check is generated by the hardware. The polling is triggered every half-second by SMI timer interrupts and is done by the BIOS SMI handler. The BIOS SMI handler starts logging each detected error and stops logging when the limit for the same error is reached. The BIOS's polling can be disabled through a software interface.	SP SEL	Normal operation
Single four-bit DRAM error	With CHIP-KILL enabled in the BIOS Setup, the CPU detects and corrects for the failure of a four-bit-wide DRAM on the DIMM interface.	The CPU corrects the error in hardware. No interrupt or machine check is generated by the hardware. The polling is triggered every half-second by SMI timer interrupts and is done by the BIOS SMI handler. The BIOS SMI handler starts logging each detected error and stops logging when the limit for the same error is reached. The BIOS's polling can be disabled through a software interface.	SP SEL	Normal operation
Uncorrectable DRAM ECC error	The CPU detects an uncorrectable multiple-bit DIMM error.	The “sync flood” method is used to prevent the erroneous data from being propagated across the Hypertransport links. The system reboots, the BIOS recovers the machine check register information, maps this information to the failing DIMM (when CHIPKILL is disabled) or DIMM pair (when CHIPKILL is enabled), and logs that information to the SP. The BIOS will halt the CPU.	SP SEL	Fatal
Unsupported DIMM configuration	Unsupported DIMMs are used, or supported DIMMs are loaded improperly.	The BIOS displays an error message, logs an error, and halts the system.	DMI Log SP SEL	Fatal
HyperTransport link failure	CRC or link error on one of the Hypertransport Links.	Sync floods on HyperTransport links, the machine resets itself, and error information gets retained through reset. The BIOS reports, A Hyper Transport sync flood error occurred on last boot, press F1 to continue.	DMI Log SP SEL	Fatal

TABLE D-1 Hardware Error Handling Summary (Continued)

Error	Description	Handling	Logged (DMI Log or SP SEL)	Fatal?
PCI SERR, PERR	System or parity error on a PCI bus.	Sync floods on HyperTransport links, the machine resets itself, and error information gets retained through reset. The BIOS reports, A Hyper Transport sync flood error occurred on last boot, press F1 to continue.	DMI Log SP SEL	Fatal
BIOS POST Microcode Error	The BIOS could not find or load the CPU Microcode Update to the CPU. The message most likely appears when a new CPU is installed in a motherboard with an outdated BIOS. In this case, the BIOS must be updated.	The BIOS displays an error message, logs the error to DMI, and boots.	DMI Log	Non-fatal
BIOS POST CMOS Checksum Bad	CMOS contents failed the Checksum check.	The BIOS displays an error message, logs the error to DMI, and boots.	DMI Log	Non-fatal
Unsupported CPU configuration	The BIOS supports mismatched frequency and steppings in CPU configuration, but some CPUs might not be supported.	The BIOS displays an error message, logs the error, and halts the system.	DMI Log	Fatal
Correctable error	The CPU detects a variety of correctable errors in the MCi_STATUS registers.	The CPU corrects the error in hardware. No interrupt or machine check is generated by the hardware. The polling is triggered every half second by SMI timer interrupts, and is done by the BIOS SMI handler. The SMI handler logs a message to the SP SEL if the SEL is available, otherwise SMI logs a message to DMI. The BIOS's polling can be disabled through software SMI.	DMI Log SP SEL	Normal operation
Single fan failure	Fan failure is detected by reading tach signals.	The Front Fan Fault, Service Action Required, and individual fan module LEDs are lit.	SP SEL	Non-fatal

TABLE D-1 Hardware Error Handling Summary (Continued)

Error	Description	Handling	Logged (DMI Log or SP SEL)	Fatal?
Multiple fan failure	Fan failure is detected by reading tach signals.	The Front Fan Fault, Service Action Required, and individual fan module LEDs are lit.	SP SEL	Fatal
Single power supply failure	When any of the AC/DC PS_VIN_GOOD or PS_PWR_OK signals are deasserted.	Service Action Required, and Power Supply Fault LEDs are lit.	SP SEL	Non-fatal
DC/DC power converter failure	Any POWER_GOOD signal is deasserted from the DC/DC converters.	The Service Action Required LED is lit, the system is powered down to standby power mode, and the Power LED enters standby blink state.	SP SEL	Fatal
Voltage above/below threshold	The SP monitors system voltages and detects voltage above or below a given threshold.	The Service Action Required LED and Power Supply Fault LED blink.	SP SEL	Fatal
High temperature	The SP monitors CPU and system temperatures, and detects temperatures above a given threshold.	The Service Action Required LED and System Overheat Fault LED blink. The motherboard is shut down above the specified critical level.	SP SEL	Fatal
Processor thermal trip	The CPU drives the THERMTRIP_L signal upon detecting an overtemp condition.	CPLD shuts down power to the CPU. The Service Action Required LED and System Overheat Fault LED blink.	SP SEL	Fatal
Boot device failure	The BIOS is not able to boot from a device in the boot device list.	The BIOS goes to the next boot device in the list. If all devices in the list fail, an error message is displayed, retry from beginning of list. SP can control/change boot order.	DMI Log	Non-fatal

Index

B

BIOS

- changing POST options, 28
- event logs, 21
- POST code checkpoints, 33
- POST codes, 31
- POST overview, 25
- redirecting console output for POST, 26

Bootable Diagnostics CD, 8

C

- comments and suggestions, x
- component inventory
 - viewing with ILOM SP GUI, 48
- console output, redirecting, 26
- correctable errors, handling, 56

D

- diagnostic software
 - Bootable Diagnostics CD, 8
 - SunVTS, 7

DIMMs

- error handling, 12
- fault LEDs, 15
- isolating errors, 18
- population rules, 11

E

- emergency shutdown, 4
- error handling
 - correctable, 56
 - DIMMs, 12

- hardware errors, 64
 - mismatching processors, 63
 - parity errors, 59
 - system errors, 61
 - uncorrectable errors, 53

- event logs, BIOS, 21
- external inspection, 3
- external LEDs, 37

F

- faults, DIMM, 15
- FRU inventory
 - viewing with ILOM SP GUI, 48

G

- gathering service visit information, 2
- general troubleshooting guidelines, 2
- graceful shutdown, 4
- guidelines for troubleshooting, 2

H

- hardware errors, handling, 64

I

ILOM SP GUI

- general information, 43
- serial connection, 44
- time stamps, 47
- viewing component inventory, 48
- viewing sensors, 50
- viewing SP event log, 45

inspection

- external, 3
- internal, 4
- Integrated Lights-Out Manager Service Processor,
See ILOM SP GUI
- internal inspection, 4
- isolating DIMM ECC errors, 18

L

- LEDs
 - external, 37
- LEDs, ports, and slots illustrated, 38, 39
- locations of ports, slots, and LEDs (illustration), 38, 39

M

- mismatching processors, error handling, 63

P

- parity errors, handling, 59
- PERR, 59
- population rules for DIMMs, 11
- ports, slots, and LEDs illustrated, 38, 39
- POST
 - changing options, 28
 - code checkpoints, 33
 - codes table, 31
 - overview, 25
 - redirecting console output, 26
- Power button, 4, 5
- Power button location, 4, 5
- power off procedure, 4
- power problems, troubleshooting, 3
- power-on self test, see POST
- processors mismatched, error, 63

R

- redirecting console output, 26
- related documentation, viii

S

- safety guidelines, vii
- sensors
 - viewing with ILOM SP GUI, 50
- serial connection to ILOM SP, 44
- SERR, 61

- Service Processor system event log, See SP SEL
- service visit information, gathering, 2
- shutdown procedure, 4
- slots, ports, and LEDs illustrated, 38, 39
- SP event log
 - viewing with ILOM SP GUI, 45
- SP SEL
 - time stamps, 47
- SunVTS
 - Bootable Diagnostics CD, 8
 - documentation, 8
 - logs, 9
 - overview, 7
- system errors, handling, 61

T

- third-party Web sites, ix
- time stamps in ILOM SP SEL, 47
- troubleshooting
 - guidelines, 2
- typographic conventions, ix

U

- uncorrectable errors, handling, 53