

Walker Rider Lawnmowers

OWNER'S MANUAL

Safety, Assembly, Operating, and Maintenance Instructions

and ILLUSTRATED PARTS MANUAL

Model MBSSD (27 HP)



CE

TM

Please Read and Save These Instructions

For Safety, Read All Safety and Operation
Instructions Prior to Operating Machine

Effective Date: 03-31-08

P/N 2000-1



Foreword

Thank you. . .for purchasing a Walker mower. Every effort has been made to provide you with the most reliable mower on the market, and we are sure you will be among our many satisfied customers. If for any reason this product does not perform to your expectations, please contact your local dealer. Every customer is important to us. Your satisfaction is our goal.

Please. . .read this manual thoroughly! This manual is to be used in conjunction with the engine manufacturer's manual for the specific engine on the mower model you have purchased. Before you operate your new mower, please read this entire manual. Some of the information is crucial for proper operation and maintenance of this mower - it will help protect your investment and ensure that the mower performs to your satisfaction. Some of the information is important to your safety, and must be read and understood to help prevent possible injury to the operator or others. If anything in this manual is confusing or hard to understand, please call our service department, at (970) 221-5614, for clarification before operating or servicing this mower.

This manual covers Model MBSSD with the Kohler Command CH740 (27 HP) gasoline engine.

All shields and guards must be in place for the proper and safe operation of this machine. Where they are shown removed in this manual, it is for illustration purposes only. **Do not operate this machine unless all shields and guards are in place.**

Specifications given are based on the latest information available at the time this manual was produced.

Walker Mfg. Co. is continually striving to improve the design and performance of its products. We reserve the right to make changes in specifications and design without thereby incurring any obligation relative to previously manufactured products.

Sincerely,
WALKER MANUFACTURING COMPANY

A handwritten signature in cursive script that reads "Bob Walker".

Bob Walker, President

Table of Contents

Owner's Manual

General Information _____ 1

HIGHLIGHTED INFORMATION _____ 1

GLOSSARY _____ 1

IDENTIFYING NUMBER LOCATIONS _____ 1

ENGINE SERIAL NUMBER LOCATION _____ 2

SERVICING OF ENGINE AND

DRIVETRAIN COMPONENTS _____ 2

Specifications _____ 3

Component Identification _____ 6

Safety Instructions _____ 9

BEFORE OPERATING _____ 9

OPERATING _____ 10

MAINTENANCE _____ 12

SAFETY, CONTROL, AND

INSTRUCTION DECALS _____ 13

Assembly Instructions _____ 15

SETUP INSTRUCTIONS _____ 15

Battery Service _____ 15

Wet Battery Service _____ 15

Dry Battery Service _____ 15

Battery Charging _____ 16

Mower Deck Assembly _____ 16

Deck Caster Wheels Installation _____ 16

Deck Discharge Shield Installation _____ 16

PTO Shaft Guard Installation _____ 17

Tilt-Up Roller Wheel Installation _____ 17

Mower Deck Installation on Tractor _____ 17

Deck Installation _____ 17

Deck Leveling _____ 19

PREOPERATING CHECKLIST _____ 20

Operating Instructions _____ 22

CONTROL IDENTIFICATION, LOCATION, AND FUNCTION _____ 22

Ignition Switch _____ 22

Engine Choke _____ 23

Engine Throttle _____ 23

Forward Speed Control (FSC) _____ 23

Steering Levers _____ 23

Blade Clutch (PTO) _____ 23

Parking Brake _____ 24

Transaxle Lockout Rods _____ 24

Hourmeter _____ 24

STARTING THE ENGINE _____ 26

ADJUSTING GROUND _____ 26

SPEED AND STEERING _____ 26

ENGAGING THE MOWER _____ 28

STOPPING THE MACHINE _____ 29

FUEL SELECTOR VALVE _____ 29

ADJUSTING CUTTING HEIGHT _____ 30

Transport Position _____ 30

TRANSAXLE LOCKOUTS _____ 31

RECOMMENDATIONS FOR MOWING _____ 31

RECOMMENDATIONS FOR TILT-UP DECK

OPERATION/TRANSPORT _____ 32

Maintenance Instructions _____ 33

MAINTENANCE SCHEDULE CHART _____ 33

IMPORTANT TIPS FOR CARE OF THE

KOHLER ENGINE _____ 34

Fuel System _____ 34

Starting/Stopping _____ 34

Cooling System _____ 34

Air Cleaner System _____ 34

Oil _____ 34

LUBRICATION _____ 35

Engine Oil _____ 35

Engine Break-In Oil _____ 35

Checking Engine Crankcase Oil Level _____ 35

Changing Engine Crankcase Oil/Oil Filter _____ 35

Mower Deck Spindle Lubrication _____ 37

DSD60 Mower Deck Lubrication _____ 37

Transaxle Lubrication _____ 37

Grease Fitting and Oil Point Lubrication _____ 37

Transaxle Oil and Filter Change _____ 40

CLEANING _____ 41

Engine Air Cleaner System _____ 41

Cummins/Fleetguard OptiAir™

Air Cleaner _____ 41

Engine Cooling System _____ 43

Air Intake System _____ 43

Cylinder Head Cooling Fins _____ 43

Grass Buildup in Mower Housing _____ 44

Transaxle Cooling Fins _____ 46

Table of Contents

CHECKING/SERVICING	47
Security of Air Filtration Components	47
Battery	47
<i>Cleaning the Terminals</i>	47
<i>Charging the Battery</i>	47
Tire Pressure	47
Wheel Nuts Torque	47
Sharpen Mower Blades	47
Drive Belts	49
Spark Plugs	49
Fuel Lines and Clamps	49
Blade Brake Action	49
REPLACING/REPAIRING	49
Drive Belts	49
<i>Engine/PTO Belt</i>	50
<i>Ground Drive Belt</i>	51
Fuel Filter	52
Mower Blades	52
ADJUSTMENTS	53
Transmission Control	53
<i>Steering Lever Position Adjustment</i>	53
<i>Steering Handles Adjustment</i>	54
<i>Neutral Position Adjustment</i>	54
<i>Full Forward Speed Adjustment</i>	55
<i>Straight Tracking Adjustment</i>	55
<i>FSC Switch - Neutral Adjustment</i>	56
<i>Forward Speed Control</i>	
<i>Friction Adjustment</i>	56
PTO Belt Tension	56
PTO Clutch	57
Clutch Rod	57
ELECTRICAL SYSTEM	57

Illustrated Parts Manual

TRACTOR AND DECK DECALS	58
BODY / CHASSIS ASSEMBLY	60
MAIN COMPONENT	
POWER TRANSMISSION	62
ENGINE GROUP	64
HYDROSTATIC GROUND	
DRIVE ASSEMBLIES	66
STEERING CONTROL ASSEMBLIES	68
ELECTRICAL ASSEMBLY	70
60 INCH COMPLETE CARRIER	
FRAME ASSEMBLY	72
DSD60 DECK ASSEMBLY	74
MULCH KIT	76
WIRING SCHEMATIC	78
Warranty	79

General Information

HIGHLIGHTED INFORMATION

Walker Manufacturing recommends that any service requiring special training or tools be performed by an authorized Walker Mower Dealer. There are several general practices to be aware of in the area of safety. Most accidents associated with the operation or maintenance of a Walker Mower are caused by disregarding basic safety precautions or specific warnings. Such accidents, in most cases, can be prevented by being aware of the dangers present.

Information of special importance has been highlighted in bold type in this manual. Refer to **Safety Instructions** for the meanings of **DANGER, WARNING, CAUTION, IMPORTANT, and NOTE.**

GLOSSARY

There are many terms that are either unique to this equipment or that are used as acronyms. The following terms and their definitions will help while using this manual:

- **DECK** is the mowing attachment mounted on the front of the tractor which includes the carrier frame, deck housing, blade spindles, and cutter blades.
- **FORWARD SPEED CONTROL (FSC)** controls the maximum forward speed of the tractor; functioning as a cruise control.
- **GROUND DRIVE** refers to the dual transaxles which drive the main wheels.
- **LEFT HAND (LH)** refers to the left-hand side of the tractor when the operator is seated facing forward in the tractor seat.
- **POWER TAKE-OFF (PTO)** transmits engine power to run the cutter blades.
- **RIGHT HAND (RH)** refers to the right-hand side of the tractor when the operator is seated facing forward in the tractor seat.
- **SIDE DISCHARGE (SD)** mows but does not collect the mowed material.
- **STEERING LEVERS** steer the tractor by controlling the two transaxles.

- **TRACTOR** is the prime mover, including the engine, drive train, operator seat, and controls to operate the mower.
- **TRANSAXLE** transmits and controls power from the ground drive belt to the main drive wheel.
- **TRANSAXLE LOCKOUT RODS** release the transaxles to permit freewheeling the tractor.


IDENTIFYING NUMBER LOCATIONS

The tractor serial number plate is affixed to the tractor body just below the left rear corner of the seat. The mower deck serial number plate is affixed alongside the angle iron framing on the LH side of the LH mower blade drive. Model and serial numbers are helpful when obtaining replacement parts and maintenance assistance. For ready reference, please record these numbers in the space provided.


Tractor Model No.	_____
Tractor Serial No.	_____
Deck Serial No.	_____
Engine Model No.	_____
Engine Serial No.	_____
Date of Purchase	_____

Fill In By Purchaser

General Information



Tractor Serial Number Location



Mower Deck Serial Number Location

ENGINE SERIAL NUMBER LOCATION

Refer to the engine manual that accompanies this manual for the location of the engine serial number. For the mower model covered by this manual, an engine manual is available from Kohler covering the Kohler Command CH740 engine.



Engine Serial Number Location

SERVICING OF ENGINE AND DRIVETRAIN COMPONENTS

The detailed servicing and repair of the engine and transaxle are not covered in this manual. Only routine maintenance and general service instructions are provided. For the service of these components during the limited warranty period, it is important to find a local, authorized servicing agent of the component manufacturer. **Any unauthorized work done** on these components during the warranty period **may void the warranty**. If you have any difficulty finding an authorized outlet or obtaining warranty service, please contact our Service Department for assistance:

Walker Manufacturing Company

5925 E. Harmony Road
Fort Collins, CO 80528
1-970-221-5614

Service manuals are available for each of these components from their respective manufacturers as follows:

Kohler Engines

Kohler Company

Kohler, WI 53044
800-544-2444
www.kohlerengines.com

Transaxles

Hydro-Gear

1411 South Hamilton St.
Sullivan, IL 61951

Specifications

MODEL	MBSSD
ENGINE	
Manufacturer/Model	Kohler Command CH740, 2 Cyl. OHV (Air-Cooled)
Displacement	44.0 cu. in. (725 cc)
HP (@ 3600 RPM)	27.0
Max. RPM (No Load)	3600 ± 100
Governed RPM	3600 ± 100
Max. Torque [ft-lb (N·m) @ RPM]	42.7 (57.9) @ 3000
Idle RPM	1200 ± 75
Spark Plug Type	Champion RC14YC
Spark Plug Gap	.030 in. (0.76 mm)
Crankcase Capacity	1.9 qts (1.8 liters)
Crankcase Lubricant	SG/SH/SJ or Higher Grade Oil Only with 10W-30 Viscosity Above 0° F (-18° C) or 5W20 or 5W30 below 32° F (0° C)
Oil Filter	12 050 01 5 (2-1/2)
Fuel Tank Capacity	10 Gallons (38 liters) Two Independent Five (5) Gallon Tanks with Selector Valve
Fuel	Automotive Grade Unleaded Gasoline (87 Octane) or Gasohol (Up to 10% Ethyl Alcohol, 90% Unleaded Gasoline by Volume)
Cooling System	Air Cooled
ELECTRICAL SYSTEM	
Battery	12 Volt (340 CCA)
Charging System	15 Amp Alternator
Charging Output	15 Amp DC (Regulated)
System Polarity	Negative Ground
Ignition	Electronic Capacitive Discharge
Starter	12 Volt Electric Key and Solenoid Operated
Interlock Switch	Ignition Lockout by Seat Switch, Transmission Neutral and Blade Clutch
Circuit Breaker	Manual Reset (30A)
TRANSMISSION	
Manufacturer/Model	Dual, Independent Hydro-Gear Integrated Transaxles
Steering	Hand Lever Control / Individual Wheel
Forward Speed Control	Precision Friction Lock Lever, Cruise Control, with Neutral-Park Position

Specifications

MODEL	MBSSD
TRANSMISSION (continued)	
Service Brake	Dynamic Braking through Transaxles
Parking Brake	(Internal) Mechanical Lockout for each Transaxle (Single Lever Control)
Neutral	Transmission Release by Manual Dump Valve
Final Drive	Direct Drive Axle from Transaxle
Transmission Fluid	
Factory Service	20W-50 Multi-Viscosity Motor Oil (Minimum SL Grade Oil)
Transmission Fluid Capacity	79 fl oz (2336 ml)
Transmission Cooling	Cooling Fan Mounted on Drive Pulley
Ground Travel Speed	
Forward m.p.h. (km/h)	0-9 (0-14) Infinitely Variable
Reverse m.p.h. (km/h)	0-5 (0-8) Infinitely Variable
BLADE DRIVE	
PTO Shaft	Sliding Spline Shaft with Two (2) High-Speed U-Joints
Blade Spindle	Each Blade (3) Mounts Directly on Belt Driven Spindles
Blade Drive Clutch and Brake	Manual Mechanical Clutch with Internal Brake [Stops Blades within Five (5) Seconds of Disengagement]
Max. Blade Speed [20-1/2 in. (52 cm) Blade] @ 3600 RPM Engine	3200 RPM [18300 FPM (5578 m/min)]
TIRE SIZE	
Deck Caster Wheel	13 x 5.00-6 Pneumatic (4-Ply)
Drive	22 x 10.50-12 (4-Ply Low-Profile)
Rear	13 x 5.00-6 (4-Ply)
TIRE PRESSURE	
Deck Caster Wheel	20 PSI (137 kPa)
Drive	15 PSI (103 kPa)
Rear	20 PSI (137 kPa)
DIMENSIONS (Tractor and Mower)	
Length	
	100-1/4 in. (255 cm)
Width	
60 in. (152 cm) SD Model (with Deflector)	62 in. (158 cm)
Height	
Wheel Base (Tractor)	43-1/4 in. (110 cm)
	42-5/8 in. (109 cm)
Tread Width (Tractor)	36-1/2 in. (93 cm)

Specifications

MODEL

MBSSD

MOWER DECK

Width of Cut	60 in. (152 cm)
Cutting Height	1 to 5 in. (3 to 13 cm)
Height Adjustment	17 Positions - 1/4 in. (1 cm) Increments

Blade Size

60 in. (152 cm) SD Model	20-1/2 in. (52 cm) Three (3) Clockwise-Rotating Blades
Deck Suspension	Torsion-Flex Frame with Caster Wheels and Counterweight Springs

CURB WEIGHT (Approximate)

Tractor Only	730 lb (331 kg)
SD Tractor and 60 in. SD Deck	1110 lb (503 kg)

DRIVE BELTS

Engine PTO	Walker P/N 2230
Ground Drive	Walker P/N 2248

SEAT

Contour-Molded, with Nylon Backed Vinyl Cover and Integral Foam Cushion (Suspension)


FRAME/BODY CONSTRUCTION

Frame/Body	3/16 Plate Steel/14 Gauge Sheet Steel
Deck	11 Gauge Steel

NOTE: The manufacturer reserves the right to make changes in specifications shown herein at any time without notice or obligation.


Component Identification

NOTE: Control Identification shown in **Operating Instructions** section.




Front View and Right Side View

Component Identification



Rear View and Left Side View


Component Identification



Top View (Body Raised)

Safety Instructions

Pay particular attention to any information labeled **DANGER, WARNING, CAUTION, IMPORTANT,** and **NOTE** in this manual.

When you see the Safety Alert Symbol (), read, understand, and follow the instructions. Failure to comply with safety instructions may result in personal injury.

The seriousness or degree of importance of each type of information is defined as follows:



DANGER

An **IMMEDIATE** hazard that **WILL** result in severe personal injury or **DEATH**, if warning is ignored and proper safety precautions are not taken.



WARNING

A **POTENTIAL** hazard that **COULD** result in severe personal injury or **DEATH**, if warning is ignored and proper safety precautions are not taken.



CAUTION

Possible hazards or unsafe practices that **MAY** result in **MODERATE** personal injury or property damage, or machine damage, if warning is ignored and proper safety precautions are not taken.

IMPORTANT: Identifies mechanical information demanding special attention, since it deals with the possibility of damaging a part or parts of the machine.

NOTE: Identifies information worthy of special attention.

Walker Manufacturing cannot predict every potentially dangerous situation. Therefore, items labeled as such in this manual do not cover all conceivable situations. Any person using procedures, tools, or control techniques not recommended by Walker Manufacturing must take full responsibility for safety.

The Walker Rider Lawnmower has been designed with many safety features to protect the operator from personal harm or injury. However, it is necessary for the operator to use safe operating procedures at all times. **Failure to follow safety instructions contained in this manual may result in personal injury or damage to equipment or property.**

If you have any questions concerning setup, operation, maintenance, or safety, please contact your authorized Walker Mower Dealer or call Walker Manufacturing Company at (970) 221-5614.

BEFORE OPERATING

1. **Read and understand the contents of this Owner's Manual before starting and operating the machine.** Become thoroughly familiar with all machine controls and how to stop the machine and disengage the controls quickly. Replacement Owner's Manuals are available by sending the Model and Serial Number to:

Walker Manufacturing Company
5925 East Harmony Road
Fort Collins, CO 80528
2. **Never allow children to operate rider mower.** Do not allow adults to operate without proper instruction.
3. **Clear the area to be mowed of any foreign objects** which may be picked up and thrown by cutter blades. Pick up all sticks, stones, wire, and any other debris.
4. Keep everyone, especially children and pets, a safe distance away from the area being mowed. **Do not mow with bystanders in the area.**
5. Do not operate the machine barefoot or wearing sandals, sneakers, tennis shoes, or similar lightweight footwear. **Wear substantial protective footwear.**

Safety Instructions

6. Do not wear loose fitting clothing that could get caught in moving parts. Do not operate this machine while wearing shorts; **always wear adequate protective clothing**, including long pants. Wearing safety glasses, safety shoes, and a helmet is advisable and required by some local ordinances and insurance regulations.
7. Prolonged exposure to loud noise can cause impairment or loss of hearing. **Operator hearing protection is recommended.** Wear a suitable hearing protective device, such as ear-muffs or earplugs.
8. **Keep all protective shields and safety devices in place.** If a protective shield, safety device, or decal is damaged, unusable, or missing, repair or replace it **before** operating the machine.
9. **Be sure interlock switches are functioning correctly**, so the engine cannot be started unless the Forward Speed Control lever is in the **NEUTRAL-PARK** position, and the PTO clutch is in the **DISENGAGED** position. Also, the engine should stop if the operator lifts off the seat with either the Forward Speed Control (FSC) out of the **NEUTRAL-PARK** position or the PTO clutch in the **ENGAGED** position.

NOTE: There is a 1 to 1-1/2 second time delay function on the seat switch to avoid engine power interruption when driving over bumps.

10. **Handle gasoline with care.** Gasoline is highly flammable and its vapors are explosive:
 - a. Use an approved fuel container.
 - b. Never add fuel to a running engine or hot engine (allow hot engine to cool several minutes).
 - c. Keep matches, cigarettes, cigars, pipes, open flames, or sparks away from the fuel tanks and fuel container.
 - d. Always fill the fuel tank(s) outdoors using care. Fill to about one inch from the top of the tank. Use a funnel or spout to prevent spilling.
 - e. Replace the machine fuel cap(s) and container cap securely and clean up any spilled fuel before starting the engine.

11. **Never attempt to make any adjustments while the engine is running**, except where specifically instructed to do so.
12. The electrical system battery contains sulfuric acid. Avoid any contact with skin, eyes, and clothing. Keep the battery and acid out of reach of children.



WARNING

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

OPERATING

1. **Operate the mower only in daylight** or in good artificial light with good visibility of the area being mowed.
2. Sit on the seat when starting the engine and operating the machine. Keep feet on the deck footrests at all times when the tractor is moving and/or mower blades are operating. **Never operate the tractor without deck or implement installed.**
3. For a beginning operator, **learn to steer (maneuver) the tractor with a slow engine speed before attempting any mowing operation.** Be aware that, with the front mounted mower configuration, the back of the tractor swings to the outside during turns.
4. Remember, for an emergency stop, the forward motion of the tractor can always be stopped by pulling the Forward Speed Control (FSC) into the **NEUTRAL-PARK** position.
5. In case the transmission drive belt breaks during operation, and if the machine is on a slope, the machine will freewheel down the slope. **To maintain control**, immediately (1) Release the steering levers and simultaneously (2) Move the FSC to the NEUTRAL-PARK position. When the machine is stopped or moving slowly, engage the parking brake.

NOTE: This is exactly the same procedure used to normally stop and park the machine.

Safety Instructions

6. Disengage the blade clutch and put the FSC in the **NEUTRAL-PARK** position before starting the engine (an ignition interlock switch normally prevents starting of the machine if these controls are in the **OPERATING** position).
7. **Do not run the engine in a confined area without adequate ventilation.** Exhaust fumes are hazardous and can be deadly.
8. **Do not carry passengers** - maximum seating capacity is one (1) person.
9. Watch for holes, rocks, and roots in the terrain and for other hidden hazards. When mowing tall grass, mow higher than desired to expose any hidden obstacles. Then, clean the area and mow to the desired height.
10. **Avoid sudden starts or stops.** Before backing the machine up, look to the rear to be sure no one is behind the machine. Watch carefully for traffic when crossing or working near roadways.
11. Disengage the blade drive when transporting the machine across drives, sidewalks, etc. **Never raise the mower deck while blades are rotating.**
12. **The maximum recommended side slope operating angle is 20 degrees or 33% grade.** When operating the machine on a slope, reduce speed and use caution to start, stop, and maneuver. To prevent tipping or loss of control of the machine, avoid sharp turns or sudden changes in direction.
13. **Never adjust cutting height while the mower is moving. Before** adjusting cutting height or servicing, move the Forward Speed Control (FSC) into the NEUTRAL-PARK position, engage the parking brake, and disengage the blade clutch (PTO). Tractor should **not** be moving while adjusting cutting height.

NOTE: The clutch brake should normally stop drive line rotation within five (5) seconds of disengaging the PTO clutch.
14. **Do not operate with the grass deflector chute removed.** Keep the deflector in the lowest possible position.
15. When using the tilt-up deck, **observe the following recommendations:**
 - a. Do not move tractor with deck in tilt-up position.
 - b. Never tilt body forward with deck in tilt-up position.
16. **In case of a clogged or plugged mower deck:**
 - a. Disengage the blade clutch (PTO), set the parking brake, and turn the engine off before leaving the seat.
 - b. **LOOK** to make sure blade drive shaft movement has stopped before trying to unclog the system.
 - c. Disconnect the spark plug wires.
 - d. Never place hands under the deck - use a stick or similar tool to remove clogged material.
17. If the cutting blades strike a solid object or the machine begins to vibrate abnormally, **immediately disengage the blade clutch (PTO), stop the engine, and wait for all moving parts to stop.** To prevent accidental starting, disconnect the spark plug wires. Thoroughly inspect the mower and repair any damage before restarting the engine and operating the mower. Make sure cutter blades are in good condition and blade bolts are torqued to 64 ft-lb (86.8 N·m).
18. **Do not touch the engine or muffler while the engine is running** or immediately after stopping the engine. These areas may be hot enough to cause serious burns.
19. When leaving the machine unattended, **disengage the blade clutch (PTO), stop the engine, and remove the key.**

Safety Instructions

MAINTENANCE

1. To prevent accidental starting of the engine when servicing or adjusting the machine, remove the key from the ignition switch and disconnect the spark plug wires.
2. **To reduce fire hazards**, keep the engine free of grass, leaves, excessive grease, and dirt.
3. Keep all nuts, bolts, and screws tight to ensure the machine is in a safe, working condition. Check the blade mounting bolts frequently, making sure they are tight.
4. **Perform only maintenance instructions described in this manual.** Unauthorized maintenance operations or machine modifications may result in unsafe operating conditions.
5. If the engine must be running to perform a maintenance adjustment, keep hands, feet, and clothing away from moving parts. **Do not wear jewelry or loose clothing.**
6. **Always use the proper engine service manual when working on the engine.** Unauthorized maintenance operations or modifications to the engine may result in unsafe operating conditions.
7. Altering the equipment or engine in any manner which adversely affects its operation, performance, durability, or use will **VOID the warranty** and may cause hazardous conditions.
8. Never attempt to disconnect any safety devices or defeat the purpose of these safety devices.
9. Do not change the engine governor settings or overspeed the engine. The governor has been factory-set for maximum-safe engine operating speed.
10. **Use genuine factory replacement parts.** Substitute parts may result in product malfunction and possible injury to the operator and/or others.
11. **Use care when charging the battery** or performing maintenance on the battery and electrical system:
 - a. Make sure the battery charger is unplugged before connecting or disconnecting cables to the battery.
 - b. Charge the battery in a well-ventilated space, so gases produced while charging can dissipate. Make sure the battery vents in the caps are open.
 - c. Keep sparks, flames, and smoking materials away from the battery at all times. To avoid sparks, use care when removing battery cables from posts.
 - d. Disconnect both battery cables before unplugging any wiring connectors or making repairs on the electrical system.

IMPORTANT: Keep all applicable manuals immediately accessible to anyone who may operate or service this machine.

Safety Instructions

SAFETY, CONTROL, AND INSTRUCTION DECALS

Safety, Control, and Instruction Decals are installed on the machine; if any are missing, illegible, or damaged, a replacement should be ordered and installed before putting the machine into operation. The Decal Part Number is listed below and in the Parts Section.

DESIGNED AND BUILT BY
WALKER MFG COMPANY
FORT COLLINS, CO 80528

FAST
THROTTLE
IDLE

WARNING

READ AND UNDERSTAND
OWNER MANUAL BEFORE
OPERATING THE MOWER.

KEEP ALL GUARDS IN PLACE.

OPERATE MOWER WITH
SHIELD IN LOWEST POSITION
FOR BEST PERFORMANCE AND
SAFETY.

DO NOT OPERATE MOWER WITHOUT
SHIELD OR MOWER BATTERY COVER.

ON
CHOKE
OFF

WALKER

PARKING BRAKE

PARK
RELEASE

LH Fender (2802-1)

! DANGER

ROTATING CUTTING BLADES

• DO NOT PUT HANDS OR FEET UNDER OR INTO ANY PART OF THIS MOWER DECK OR DISCHARGE CHUTE

• OBJECTS MAY BE THROWN FROM MOWER

▶ CLEAR LAWN OF DEBRIS AND OBJECTS
▶ DO NOT MOW WITH BYSTANDERS IN AREA

NO STEP

5808

Each End of Mower Deck (5808)

! DANGER

• KEEP SHIELD IN LOWEST POSSIBLE POSITION

• DO NOT REMOVE THIS DISCHARGE SHIELD

THROWN OBJECTS

5848

SD Deck Discharge Shield (5848)

IMPORTANT - ENGINE COOLING SYSTEM MAINTENANCE

CHECK AND CLEAN ENGINE ROTATING INLET SCREEN AND STATIC SCREEN GUARD DAILY (EVERY 8 HOURS) OR MORE OFTEN IN DIRTY CONDITIONS. CYLINDER HEAD COOLING FINS SHOULD BE CHECKED AND CLEANED BY REMOVING ENGINE SHROUD EVERY 100 HOURS.

5855

Engine Shroud (5855)

TO START

TRANSMISSION MUST BE IN NEUTRAL AND BLADE CLUTCH ENGAGED.

○ TO GO
ADJUST LEVER FORWARD TO DESIRED GROUND SPEED

○ TO STOP
PULL STEERING LEVERS TO NEUTRAL BEFORE MOVING SPEED CONTROL TO NEUTRAL.

FORWARD SPEED CONTROL

FAST
SLOW

NEUTRAL-PARK

WALKER

RAISE LEVER TO RELEASE BODY LOCK

BODY LOCK

BLADE CLUTCH
PULL LEVER FORWARD TO ENGAGE

ON
PTO
OFF

RH Fender (2802-2)

4-3/4 4-1/4 3-3/4 3-1/4 2-3/4 2-1/4 1-3/4 1-1/4

LOCK 5 4-1/2 4 3-1/2 3 2-1/2 2 1-1/2 1

CUTTING HEIGHT INCHES

OFF ON

CAUTION
STOP ENGINE BEFORE ADJUSTING CUTTING HEIGHT

CUTTING HEIGHT ADJUSTMENT

2748

Deck Carrier Frame (2748)

IMPORTANT

GREASE FRONT AND REAR PTO U-JOINTS EVERY 8 HOURS OF OPERATION


8746

PTO Guard (8746)


Safety Instructions

SAFETY, CONTROL, AND INSTRUCTION DECALS

Safety, Control, and Instruction Decals are installed on the machine; if any are missing, illegible, or damaged, a replacement should be ordered and installed before putting the machine into operation. The Decal Part Number is listed below and in the Parts Section.




Deck Housing (2749)



Rear Body, Underside (2107-4)




On Precleaner Mount (4107-1)




On Transfer Mount (2010-4)




Rear Body, Above Muffler (5805)



Deck Housing (8653-1)



Front Body Adjacent to RH Steering Lever (2807-1)




On Engine (6810)



Deck Carrier Frame (8653)



Deck Carrier Frame (8647)



Center Body Behind Transaxles (9804)

Assembly Instructions

SETUP INSTRUCTIONS

Walker Mowers are shipped partially assembled to our distribution network, and are typically assembled by the selling dealer. For any additional assembly besides the following, contact your Walker dealer.

Battery Service

Raise mower body up for battery access. Check the battery for electrolyte level and charge. The electrolyte level should be at the bottom of the vent wells [1/4 to 1/2 in. (6 to 13 mm) above plates]. If the specific gravity is less than 1.225, the battery needs charging. If the battery has been shipped dry, or is wet but needs service, refer to the following instructions.

IMPORTANT: Make sure battery is securely mounted in the frame. A loose battery may cause damage to the case resulting in acid leakage and severe damage to the machine. A hazard may be created by damage to critical working parts and safety systems.

Wet Battery Service

If the battery has been shipped wet, but the electrolyte level is low or the battery needs to be charged then:

1. Fill each battery cell with drinking water to the bottom of the vent wells.
2. Charge battery. Refer to *Battery Charging* in this section.

Dry Battery Service



DANGER

Activating a battery can be dangerous. The battery should be taken to a reliable service station, battery store, or power equipment dealer where a trained technician can activate the battery safely. **DO NOT attempt to activate the battery unless you are experienced in battery service work. The following activation and charging instructions are provided for use by a trained battery technician.**



DANGER

Battery electrolyte is a poisonous and corrosive sulfuric acid solution.

- Avoid spillage and contact with skin, eyes, and clothing - causes severe burns.
- To prevent accidents, wear safety goggles and rubber gloves when working with electrolyte.
- Neutralize acid spills with baking soda and water solution.

To fill (activate) battery with electrolyte (if battery has been shipped dry):

1. Remove the battery hold-down bar, disconnect the battery cables and lift the battery out of the tray.

IMPORTANT: Battery must be removed from the mower before filling with electrolyte.

IMPORTANT: Obtain and use only battery grade sulfuric acid electrolyte with a 1.265 specific gravity to activate the battery. **DO NOT** use water or any other liquid during initial activation.

2. Remove the filler caps and carefully fill each cell until the electrolyte is just above the plates.
3. After the battery is filled with electrolyte, replace the filler caps and charge the battery. Refer to *Battery Charging*.

Assembly Instructions

Battery Charging

DANGER

BATTERIES PRODUCE EXPLOSIVE GASES


- Charge the battery in a well-ventilated area, so that gases produced while charging can dissipate.
- Keep sparks, flames, and smoking materials away from the battery at all times.
- Make sure the battery cap vents are open after the battery is filled with acid (check manifold vent on each cap).
- Make sure the battery charger is unplugged before connecting or disconnecting cables to the battery.

1. Charge the battery at 15 amps for 10 minutes. **DO NOT** exceed 20 amps maximum recommended charging rate. Charge until specific gravity is at least 1.250. Total charging time should not exceed one (1) hour.
2. After charging the battery, adjust the electrolyte level to the bottom of the vent wells [1/4 to 1/2 in. (6 to 13 mm) above the plates].
IMPORTANT: DO NOT overfill the battery. Electrolyte will overflow through the vented caps onto parts of the machine and **WILL** result in severe corrosion.
3. Install battery.

Mower Deck Assembly

Deck Caster Wheels Installation

1. Remove the bolts and washers from each deck caster wheel.
2. Install wheel on fork using bolts and washers.
NOTE: Valve stem and grease zerk should face to the inside of machine.
3. Tighten the bolts and washers.




Deck Caster Wheel Installation

Deck Discharge Shield Installation

Attach the deck side discharge shield by positioning the shield hinge lug in front of the deck mount and fastening with two 3/8-16 x 1-1/4 in. bolts, 3/8-16 ESNA nuts, and 3/8 in. wave spring washers. The wave washers fit between the two hinging surfaces. Tighten the nuts until the shield moves freely but is not loose.

WARNING

DO NOT operate the machine without the grass deflector chute attached and in the lowest possible position.




Deck Discharge Shield Installation

Assembly Instructions

PTO Shaft Guard Installation


Position the shaft guard as shown and mount with two 1/4-20 x 1/2 in. bolts.



PTO Shaft Guard Installation

Tilt-Up Roller Wheel Installation

Mount the two (2) tilt-up roller wheels on the brackets on the rear skirt of the deck housing using the P/N 8490 axle bolt, 3/8 in. wave spring washer and 3/8-16 in. Whiz locknut. Tighten the axle bolt until the wheel rolls freely, but is not loose.



Roller Wheel Installation

Mower Deck Installation on Tractor


Deck Installation

1. Lightly grease each deck support arm (2) on the tractor. Refer to **Mower Deck Installation** photo for location of deck support arm.
2. Engage the LH deck carrier frame tube socket first on the tractor support arms and then the RH tube socket, slide the deck onto the support arms approximately 3 in. (76 mm).



Retract Coupler Ring


3. Retract spring-loaded coupler ring on the PTO Tube (provided in Owner's Packet) and insert coupler tool. Refer to **Quick Coupler Installation Tool** photo.



Quick Coupler Installation Tool


Assembly Instructions

4. Reaching under the tractor, join the PTO tube to the PTO shaft (align arrow decals). Slide the PTO tube onto the spline shaft on the tractor PTO drive shaft.



**Mower Deck Installation
(PTO Shaft Connection)**

5. Slide the deck the rest of the way on the deck arms.




Mower Deck Installation

6. Install the lynch pin through the hole on the end of each support arm to lock the deck in place (refer to **Deck Counterweight Spring Installation** photo). Two (2) lynch pins are included in the owner's packet of materials.
7. Remove Installation Tool from coupler ring and make sure the ring has "snapped" securely on the spline shaft.


IMPORTANT: DO NOT operate tractor with Quick Coupler Installation Tool installed.

IMPORTANT: To prevent damage to the mower, make sure the PTO shaft assembly is securely locked on the tractor, with the locking balls fully seated in the groove and the ring in the full forward position (refer to the **Coupler Ring "Locked" Position** photo). After installation, pull on the shaft to check for security.



Coupler Ring "Locked" Position

8. Raise the mower body (instead of lifting the front of deck) and clip the counterweight springs to the receptacle on front of body. Lower the body to tension the springs. (Refer to **Deck Counterweight Spring Installation** Photo.)
9. With the counterweight springs connected, the weight on the deck caster wheels should be 15 to 25 lb (6.8 to 11.3 kg). Check this weight by lifting on the front of the deck carrier frame. If required, the spring tension can be adjusted by tightening or loosening the elastic stop nuts located underneath the lower spring hook. Refer to **Deck Counterweight Spring Installation** photo.



Deck Counterweight Spring Installation

Assembly Instructions

Deck Leveling

1. Position mower on a smooth, level surface. Set the cutting height to the highest position - 5 in. (127 mm) - for easy access under the deck to measure blade height. Refer to **ADJUSTING CUTTING HEIGHT** in **Operating Instructions**.

NOTE: A block of wood cut **5 in. (127 mm)** high is a convenient gauge to measure blade height above ground during the leveling process.




WARNING

The machine must be shut off during this procedure.

2. Check the side-to-side level. **Rotate the outside blades sideways** and measure the distance from blade tip to ground on each side. If measurements vary more than 1/8 in. (3 mm), adjust the height adjustment rod on the high side to level the deck.
3. Check the front-to-rear level. **Rotate the center blade to point forward.** Measure the distance from blade tip to ground on the front and rear. The rear of the blade should be 1/8 to 1/4 in. (3 to 6 mm) higher than the front of the blade; remove the chain from the deck height adjuster clevis and adjust equally to achieve **at least** 1/8 in. (3 mm) difference. Reinstall chains.

NOTE: The mower deck and support frame are jig welded; within normal tolerances, very little, if any, adjustments should be required to level the deck. Tire pressure will influence the levelness of the deck. Check the tire pressure as a possible cause of the deck not being level.



Deck Leveling

Assembly Instructions

PREOPERATING CHECKLIST

Before operating the mower for the first time, and as a routine before daily operations, it is important to make sure the mower is properly prepared and ready for operation. The following is a list of items to be checked. (For a mower with frequent operation, some of these items will not need to be checked every day, but the operator should be aware of the condition of each.)

For proper fuel and lubricants refer to **Specifications**.

FILL FUEL TANK(S)

Fill the fuel tank(s) using clean, fresh, automotive grade **unleaded** gasoline (87 octane rating minimum) or gasohol (up to 10% ethyl alcohol, 90% unleaded gasoline by volume). See engine manual for complete fuel recommendations.



DANGER

Handle gasoline with care. Gasoline is highly flammable and its vapors are explosive. Use safe refueling procedures:

- **DO NOT** fill fuel tank(s) with the engine running.
- If the engine is hot, allow to cool before refueling.
- Use an approved fuel container.
- Fuel the mower outdoors.
- **DO NOT** smoke while refueling.
- Avoid spilling fuel; use a funnel or spout.
- **DO NOT** overfill the fuel tank(s); fill up to about 1 in. (25 mm) below the top of tank.

IMPORTANT: **DO NOT** permit dirt or other foreign matter to enter the fuel tanks. Wipe dirt from around the filler cap(s) before removing. Use a clean fuel storage container and funnel.

IMPORTANT: **DO NOT** mix oil with gasoline. Always use fresh, automotive grade unleaded gasoline or gasohol. **DO NOT** use premium, white, or high-test gasoline. **DO NOT** use additives, such as carburetor cleaners, deicers, or moisture removing agents. **DO NOT** use gasoline blended with methyl alcohol.

CHECK ENGINE CRANKCASE OIL LEVEL

Check the engine crankcase oil level before use and **after each 8 hours** of continuous operation. Refer to **LUBRICATION** for *Checking Engine Crankcase Oil Level* in **Maintenance Instructions**.

CHECK AND SERVICE ENGINE AIR CLEANER SYSTEM

- Check air restriction gauge to make sure there is no red indication showing.
- Check condition, cleanliness, and security of the complete air cleaner system (inspect air filter **every 100 hours**). For detailed procedures, refer to **CLEANING** the **Engine Air Cleaner System** in **Maintenance Instructions**.

CHECK ENGINE COOLING SYSTEM

Check that the engine cooling air intake screen is free of obstruction by grass clippings or debris and clean if required. Also, cylinder head cooling fins should be inspected and cleaned if any build-up of debris is noted [remove two (2) cylinder head access panels to inspect and clean].

CHECK SECURITY OF DRIVE TIRE MOUNTING NUTS

The eight (8) Drive Tire mounting nuts should each be torqued to 75-85 ft-lbs. (101.7-115.2 N·m).

INSPECT FOUR (4) DRIVE BELTS

Engine/PTO and Ground Drive.

CHECK HYDROSTATIC TRANSAXLE OIL LEVEL

Refer to **LUBRICATION** for **Transaxle Lubrication** in **Maintenance Instructions**.

CHECK TIRE PRESSURE

Deck Caster Wheel = 20 PSI (137 kPa)
Drive = 15 PSI (103 kPa)
Rear = 20 PSI (137 kPa)

Assembly Instructions

- CHECK FUNCTION OF SAFETY INTERLOCK SWITCHES

Refer to **Operating Instructions** to check for proper operation of safety switches, both during engine starting and with the operator leaving the seat with tractor moving forward or with mower blades engaged.


- CHECK AND CLEAN GRASS BUILDUP UNDERNEATH MOWER DECK

Refer to **CLEANING the Grass Buildup in Mower Housing** in **Maintenance Instructions** for deck tilt-up and deck cleaning information.

DANGER

Never operate cutter blades with deck in raised position because it is hazardous.

The tilt-up deck can be secured in the raised position by disengaging the locking arms on each side of the carrier frame and inserting the deck hook into the tilt-up latch on the tractor body. Before operating the tractor, make sure to re-engage the locking arms after lowering the deck to the normal operating position.



Deck Secured in Tilt-Up Position

CAUTION

Do not operate machine with locking arms disengaged.

DANGER

Do not operate the mower with deck in tilt-up position. Do not move the tractor with the deck in the tilt-up position.

- CHECK MOWER BLADE CONDITION, SHARPNESS, BALANCE, AND SECURITY OF MOUNTING

The blade mounting bolt should be tightened to 64 ft-lb (86.8 N·m). If blade sharpening is required, refer to **CHECKING/SERVICING for Sharpen Mower Blades** in **Maintenance Instructions**.

- ADJUST MOWER CUTTING HEIGHT, IF REQUIRED

Refer to **ADJUSTING CUTTING HEIGHT** in **Operating Instructions**.

- PERFORM ANY ADDITIONAL PROCEDURES called for on the **MAINTENANCE SCHEDULE CHART** in **Maintenance Instructions**.

Operating Instructions

CONTROL IDENTIFICATION, LOCATION, AND FUNCTION




CAUTION

Before operating the mower, become familiar with the location and function of all operator controls. Knowing the location, function, and operation of these controls is important for safe and efficient operation of the mower.


Ignition Switch

The ignition switch is located on the right front of the body and is used to start and stop the engine. The switch has three positions: "O" is the **OFF** position, **RUN** is the position the key returns to after starting, and "S" is the **START** position. When starting the engine, turn the key clockwise to the "S" position. Do not hold the key in the "S" position longer than 10

seconds. If the engine does not start, return the key to the "O" position for at least 60 seconds before making a restart attempt. Prolonged cranking can damage the starter motor and shorten battery life. Release the key when the engine starts, and it will return to the **RUN** position. To stop the engine, rotate the key counterclockwise to the "O" position.



Ignition Switch



Operating Controls

Operating Instructions


Engine Choke

The choke control lever (black knob) is located on the left side of the seat. To start a cold engine, move the choke control forward to the **ON** position. After engine starts, move choke control toward the **OFF** position, keeping enough choke to allow the engine to run smoothly as it warms up. As soon as possible, move the choke to the **OFF** position. A warm engine requires little or no choke for starting.

IMPORTANT: Make sure the choke is in the **OFF** position during normal engine operation; running with the choke in the **ON** position **CAN** damage the engine.

Engine Throttle

The throttle control lever (red knob) is located on the left side of the seat and is used to control engine speed. Moving the lever **forward** toward the **FAST** position **increases** engine speed; moving it **backward** toward the **IDLE** position **decreases** engine speed.



Choke and Throttle Location

Forward Speed Control (FSC)

Forward Speed Control (FSC) has two functions: One is to set forward travel speed, and the other is to establish the **NEUTRAL-PARK** position. When the FSC lever is moved into the **FORWARD** position, a friction lock holds any forward speed setting from 0 to 9 mph (0 to 14 km/h). The ground speed is proportional to the lever position; the further the lever is advanced forward, the faster the tractor moves. It is not necessary to hold the FSC in position since the friction lock maintains the selected lever position. Pulling back on the steering levers overrides the FSC setting and slows or stops forward travel. Releasing the steering levers allows the tractor to resume forward travel at the speed set by the FSC lever. To stop and park the machine, the FSC lever is moved backward to the **NEUTRAL-PARK** position.

Steering Levers

Each drive wheel is controlled by its own independent steering lever, for both steering function and **FORWARD/REVERSE** motion. The FSC lever sets the maximum forward speed, and also sets the forward position of the steering levers. The steering levers operate **only with a backward pulling** movement of the lever, which causes the drive wheel for that lever to first slow down, stop, and then reverse with a full backward lever stroke. The levers are released to the **FORWARD** position for "straight-ahead" ground travel.

NOTE: Pushing forward on the steering levers will not cause **any** change in tractor motion - there will be no steering lever reaction and there will be no machine damage.

Blade Clutch (PTO)

The blade clutch lever has two positions. Pulling the lever **FORWARD engages** the PTO that drives the mower blades. Pulling the lever **BACKWARD disengages** the PTO and engages the blade brake.

Operating Instructions

Parking Brake

The parking brake functions by locking a detent arm internally into the transaxle. Moving the lever **FORWARD engages** the parking brake; moving the lever **BACKWARD releases** the brake.


IMPORTANT: Stop the tractor completely before engaging the parking brake. The parking brake uses a positive mechanical lock similar to the **PARK** position on an automotive automatic transmission. If the tractor is moving when the brake is engaged, it will result in sudden stoppage and possible internal damage to the transaxle.

NOTE: If pressure on the parking brake pin (e.g. parked on a hill) makes it impossible to release the parking brake with the parking brake lever, move the mower gently forward or backward to allow the brake detent to release.

Transaxle Lockout Rods

The transaxle lockout rods disengage the transaxles. By lifting the rods up and locking them into place with the shoulder on the rod in the chassis notch, the transaxles are released to permit freewheeling. By releasing the rods and recessing them back toward the chassis, the transaxles are engaged for normal operation. The transaxle rods in the **LOCKOUT** position are used to enable moving the machine without the engine running (e.g., for service). Refer to **TRANSAXLE LOCKOUTS** in this section for operating instructions.

NOTE: The transaxle lockout rods ends should be completely retracted against the chassis, otherwise operation of the transaxle may be erratic.



Hydro Lockout Rod Location

Hourmeter

The hourmeter, which is located on the right front of the body, displays **operating time** accumulated while the ignition switch is in the **ON** position.

The hourmeter provides maintenance reminders after certain hours of operation. The hourmeter screen will start flashing the reminder one hour prior to the recommended interval and will continue until one hour after the recommended interval (two hours). The hourmeter **does not have a manual reset function**.


Procedure	Interval*	Reminder
Oil Change (Break-In)**	4-6 Hours	C H G OIL
Lubricate and Check Levels	24-26 Hours	LUBE
Oil Change	49-51 Hours***	C H G OIL

* These intervals reflect the actual time that the reminder will flash (one hour prior to and one hour after the recommended interval).

** This reminder is only used one time.


*** In normal operating conditions, oil changes in 100-hour intervals are acceptable. Walker and the engine manufacturers recommend engine oil changes every 50 hours in extremely dirty or dusty conditions or for units with less than 100 hours annual use.

NOTE: The blinking hour glass on the display means that the meter is operating properly.



Hourmeter

Operating Instructions



Operating Instructions

STARTING THE ENGINE



CAUTION

Before operating the mower, read and understand all Safety Instructions and Operating Instructions.



WARNING

NEVER run the engine in an enclosed or poorly ventilated area. Engine exhaust contains carbon monoxide, an odorless and deadly gas.

1. Before attempting to start the engine, make sure the operator is in the seat, the Forward Speed Control is in **NEUTRAL-PARK** position, and the blade clutch and parking brake are **DISENGAGED**.

NOTE: Release parking brake to prevent extra load on the starter if the transmission neutral is slightly out of adjustment.



CAUTION

A safety interlock switch system **PREVENTS CRANKING** the engine with either the Forward Speed Control or the blade clutch (PTO) out of neutral. If the engine cranks otherwise, the safety system is not working and should be repaired or adjusted before operating the mower. **DO NOT** disconnect safety switches; they are for the operator's protection.

2. Move the choke lever to the **ON** position and move the throttle 1/4 to 1/2 open (toward **FAST**). Turn the ignition switch to the **START** position to start the engine. Release the key to **RUN** position as soon as the engine starts.

NOTE: The choke may not be required if the engine is warm.

IMPORTANT: DO NOT crank the engine continuously for more than 10 seconds at a time. If the engine does not start, turn the key to the **OFF** position and allow a 60 second cool-down period between starting attempts. Failure to follow these guidelines can damage the starter motor and shorten battery life.

3. After the engine starts, gradually move the choke to the **OFF** position, keeping enough choke on to allow the engine to run smoothly as it warms up. As soon as possible, move the choke to the **OFF** position.

IMPORTANT: Make sure the choke is in the **OFF** position during normal engine operation; running with the choke in the **ON** position **CAN** damage the engine.

ADJUSTING GROUND SPEED AND STEERING



CAUTION

Learn to **START, STOP, and MANEUVER** the mower in a large, open area.

If the operator has not operated a machine with **LEVER STEERING OR DUAL TRAN-SAXLES**, steering and ground operation should be learned and practiced until the operator is completely comfortable handling the machine **BEFORE ATTEMPTING TO MOW**.



DANGER

Keep feet on footrest at all times when the machine is moving. Never operate the tractor without a deck or implement installed.

Operating Instructions

Beginning Recommendations are:

- ◆ Learn operation of the mower in an open area away from buildings, fences, and obstructions. Learn operation on flat ground **BEFORE** operating on slopes.
- ◆ Start maneuvering the mower with **SLOW** engine speed and **SLOW Forward Speed Control** setting until familiar with all operating characteristics.
- ◆ Remember it is not necessary to hold the steering levers forward (a unique Walker feature); always **PULL** on the levers for steering or for reverse motion of the mower.
- ◆ Learn to operate the mower with your left hand on the steering levers and right hand on Forward Speed Control. The use of two hands on the steering levers tends to cause overcontrol.
- ◆ Learn to operate the steering levers with smooth action. Jerky movements are hard on the transmission and lawn. For sharp turns, do not allow the inside wheel to stop and twist on the grass. Pull the steering lever controlling the inside wheel into reverse for a smooth “rolling” turn (one wheel rolling forward while the other rolls backward).
- ◆ Practice maneuvering the mower until you can make it go exactly where you are aiming.
- ◆ Remember, for an emergency stop, or in case of loss of control, machine movement can always be stopped quickly by pulling the Forward Speed Control into the **NEUTRAL-PARK** position.

1. Move the FSC out of **NEUTRAL-PARK** position to the desired forward speed. **DO NOT** hold forward on steering levers. It is not necessary to hold the FSC lever in position since a friction lock maintains the selected lever position (and forward travel speed).



WARNING

In case the transmission drive belt breaks during operation, and if the machine is on a slope, the machine will freewheel down the slope. To maintain control, immediately (1) Release the steering levers and simultaneously (2) Move the FSC to the **NEUTRAL-PARK** position. When the machine is stopped or moving slowly, engage the parking brake.

NOTE: This is exactly the same procedure used to normally stop and park the machine.

NOTE: If the FSC lever will not stay in the selected position, the friction lock needs to be adjusted. Contact your Walker Dealer.




CAUTION

A safety interlock switch (seat switch) will cause the engine to stop if the FSC is out of the **NEUTRAL-PARK** position and the operator is not in the seat. The function of this switch should be checked by the operator raising off the seat with the tractor moving forward (allow 1 to 1-1/2 seconds off the seat for the time delay function); the engine should stop. If the safety system is not working, it should be repaired or replaced before operating the mower. **DO NOT** disconnect the safety switches; they are for the operator's protection.

2. Steer by pulling the lever on the side of desired direction of turn, e.g., pull the **LH** lever to **turn left**. To minimize the possibility of overcontrol, use only one hand on both steering levers.

Operating Instructions



Correct Operator Hand Position on the Controls

3. Reverse direction of the mower by pulling both levers backward.

NOTE: Smooth action on the steering levers will produce smooth mower operation. Remember to keep the engine and ground speed slow until learning the control response.

4. The FSC may be adjusted forward for faster ground speed and backward for slower ground speed. When mowing, ground speed should be adjusted to match the load on the cutter blades, i.e., as the engine pulls down in heavy cutting, pull back on the FSC lever to reduce ground speed. Adjusting ground speed helps maintain a balance between engine power and blade speed for high-quality cutting action.
5. Stop ground travel by pulling both steering levers backward to the **NEUTRAL-PARK** position (tractor not moving) and then moving the FSC lever to the **NEUTRAL-PARK** position.

NOTE: If the tractor creeps forward or backward with the FSC lever in the **NEUTRAL-PARK** position, the transmission control needs to be adjusted. Contact your Walker Dealer.

ENGAGING THE MOWER

1. Set the engine throttle at about 1/3 speed. **Do not attempt to engage the blade clutch at high engine speeds.** This will drastically shorten drive belt life. Use only moderate engine speed when engaging the blade clutch.
2. Engage the mechanical clutch by pulling the blade clutch lever forward **quickly**. **DO NOT** engage slowly. For disengagement, push the blade clutch lever backward **quickly**.



CAUTION

A safety interlock switch (PTO switch) will cause the engine to stop if the PTO is in the engaged position and the operator is not in the seat. The function of this switch should be checked by the operator raising off the seat with the PTO engaged (allow 1 to 1-1/2 seconds off the seat for the time delay function); the engine should stop. If the safety system is not working, it should be repaired or replaced before operating the mower. **DO NOT** disconnect the safety switches; they are for the operator's protection.

IMPORTANT: **DO NOT** engage the blade clutch when transporting the mower across drives, sidewalks, loose materials, etc. **DO NOT** engage the blade clutch with the PTO shaft disconnected (the mower deck removed from tractor).



Blade Clutch Engaged

Operating Instructions



Blade Clutch Disengaged

CAUTION

If the cutting blades strike a stationary object while mowing, stop the mower immediately, disconnect the spark plug wires, lift the deck, and inspect the deck and blades thoroughly for damage. Also, make sure the blade retaining bolts are torqued to 64 ft-lb (86.8 N·m).

STOPPING THE MACHINE

1. Slow the engine to idle; put the throttle in the **IDLE** position.
2. Pull the steering levers to the **NEUTRAL-PARK** position and then move the FSC lever backward to the **NEUTRAL-PARK** position.
3. Disengage the blade clutch.

IMPORTANT: **DO NOT** disengage the blade clutch with high engine speed (above 1/2 throttle) since the brake action on the blade drive will cause premature wear of the Engine/PTO Belt and internal braking mechanism (or system).

WARNING

A brake stops the cutter blades from free-wheeling within five (5) seconds after disengaging the clutch. If the brake system malfunctions and the blades do not stop within five (5) seconds, the brake should be repaired or replaced before operating the mower. Contact your Walker Dealer.

4. Turn the ignition switch **OFF**.

WARNING

Remove the key from the ignition switch when leaving the mower unattended. This will prevent children and inexperienced operators from starting the engine.

5. Engage the parking brake.

IMPORTANT: The transaxles lock to prevent the mower from rolling freely with the engine stopped. However, if the mower is parked on a slope, it is necessary to **ENGAGE** the parking **BRAKE** to prevent the mower from creeping. This is due to a small amount of slippage in the transaxles, especially when transmission fluid is warm.

FUEL SELECTOR VALVE

The tractor is equipped with dual fuel tanks. A fuel selector valve regulates which tank is being utilized. The valve is located on the right hand side of the engine. The valve switches between the LH and RH gas tanks. **DO NOT** run tank dry before switching tanks.



Fuel Selector Valve

Operating Instructions

ADJUSTING CUTTING HEIGHT



WARNING

Never adjust cutting height while the mower is moving. Before adjusting cutting height or servicing, move the Forward Speed Control (FSC) into the NEUTRAL-PARK position, engage the parking brake, and disengage the blade clutch (PTO). Tractor should not be moving while adjusting cutting height.

Cutting height is adjusted from operators seat using the height peddle to assist in raising the deck while positioning the height adjustment lever and hitch pin.


1. Disengage PTO and stop tractor.
2. Push down on height peddle until it latches in the full up position.
3. Select desired height by moving the hitch pin to the desired height.
4. Push down on the height peddle and lift up on the height adjustment lever. Slowly release the height peddle while lifting the lever until there is no pressure on the peddle.



Cutting Height Adjustment

Transport Position

1. Disengage the PTO.
2. Push down on height peddle until it latches in the full up position.



Cutting Height Adjustment Components


Operating Instructions

TRANSAXLE LOCKOUTS

IMPORTANT: DO NOT TOW this mower with the transmission lockout engaged. Towing can produce excessive internal pressure and damage the transaxle(s).


To move the mower with the engine **NOT** running (dead battery, maintenance, etc.), the transaxles are unlocked (released).

1. Raise the body.
2. Pull up the transaxle lockout rods on both the RH and LH transaxles and secure into place by shouldering both rods in the chassis notch area.
3. The mower will “freewheel” with the rods in the **LOCKOUT** position. The levers must be in the highest position to completely unlock the transmissions.



Hydro Lockout Rod - Freewheel Position

4. After moving the mower, release the rods, placing them in the normal **OPERATING** position. The transmission rod ends should be completely retracted against the chassis, otherwise operation of the transmission maybe erratic.



Hydro Lockout Rod - Normal Operating Position


RECOMMENDATIONS FOR MOWING

IMPORTANT: Operate the engine at **full speed** when mowing, to allow the engine to produce full horsepower and to increase efficiency of the engine cooling system.

- Keep the mower deck clean.
- Mow with **sharp blades**. A dull blade tears the grass (resulting in poor lawn appearance) and uses extra power (slowing the mowing speed).
- It is preferable to cut grass when it is **dry** and **not too tall**. Mow frequently and do not cut grass too short. (For best appearance, cut off 1/3 or less of existing grass height.)
- When mowing, operate the engine at or near **full throttle** for the best cutting action. Mowing with a lower engine RPM causes the mowing blade to not cut clean and tear the grass. The engine is **designed to be operated at full speed**.
- When mowing in adverse conditions (tall and/or wet grass), mow the grass twice. Raise the mower to the highest setting - 5 in. (127 mm) - for the first pass and then make a second pass cutting to the desired height.
- Use a **slow** setting on the FSC for **trimming** operations.


Operating Instructions

- Make sure the mower is **leveled properly** for a smooth cut. Refer to *Deck Leveling* in **Assembly Instructions**.
- Use an alternating **stripe mowing pattern** for **best appearance** and vary the direction of the stripe each time the grass is mowed to avoid wear patterns in the grass.
- Avoid damage to the grass by slipping and skidding of the drive tires. Use **smooth control movements** of the steering levers since the transaxles are “power boosted controls” and jerking the levers can easily slip the tires. For sharp turns, do not allow the inside wheel to stop and twist on grass; pull inside steering lever into reverse for a smooth “rolling” turn (one wheel rolling forward while the other rolls backward).
- The side discharge shield **must not be removed** and must be kept in the lowest possible position to deflect grass clippings and thrown objects downward. Orient the side discharge away from sidewalks or streets to minimize cleanup of clippings. When mowing close to obstacles, orient the side discharge away from obstacles to reduce the chance of damage to property by thrown objects.



Side Discharge Shield in Lowest Position

- When operating on a slope, **reduce speed and use caution** to start, stop, and maneuver. Avoid sharp turns or sudden changes in direction. The **maximum recommended side slope operating angle is 20 degrees or 33% grade**.



Maximum Recommended Side Slope

RECOMMENDATIONS FOR TILT-UP DECK OPERATION/TRANSPORT

To avoid potential deck and/or tractor damage while using the tilt-up deck, the following recommendations are offered:

- **Do not move the tractor** with the deck in the tilt-up position since both the roller wheels (on the back of the deck) may be damaged by moving the tractor. The tilt-up configuration should only be used when the tractor is parked.
- The tractor **body should never be tilted forward** with the deck in the tilt-up position. This can cause the deck to unhook from the tractor and fall with considerable force, potentially causing deck or tractor damage and/or bodily injury.
- When transporting a tractor with the deck in the tilt-up position (on a truck or trailer), the **deck should be secured** to the vehicle with a strap or rope (stop vertical movement). This will prevent the deck from bouncing on the rear roller wheels (causing breakage). This will also prevent the deck from unhooking from the tractor and falling, potentially causing deck or tractor damage. Damage to other items parked in front of the deck may also occur.

Maintenance Instructions



CAUTION

Maintenance procedures requiring special training or tools should be performed by a trained technician.

MAINTENANCE SCHEDULE CHART - RECOMMENDED SERVICE INTERVALS - MODEL MBSSD

Service Item	Daily	25 Hours	100 Hours	200 Hours	400 Hours	Yearly	Every 2 Years	Ref. Page
Check Engine Crankcase Oil Level	x							35
Check/Clean Engine Air Cooling System*	x							43
Check Air Filter Restriction Gauge	x							41
Clean Grass Buildup Under Deck	x							44
Service Mower Blades	x							47
Check Security of Air Filtration Components	x							47
Lubricate Grease Fittings and Oil Points*		x						37
Check Transaxle Fluid		x						37
Check Tire Pressure		x						47
Check Drive Belts (Engine/PTO, Ground Drive)		x						49
Change Engine Crankcase Oil**			x ^Δ					35
Check Air Filter Element ***			x					42
Clean Engine Cooling Fins			x					43
Check Security of Drive Tire Mounting Nuts (75-85 ft-lbs.)			x					20
Clean Transaxle Cooling Fins			x					46
Change Engine Oil Filter				x				35
Check/Regap Spark Plugs				x				49
Change Transaxle Oil and Filter					x ^{ΔΔ}			40
Check Fuel Lines and Clamps						x		49
Replace Air Filter Element and Dust Ejection Valve ***						x		42
Service Battery						x		47
Replace Fuel Filter						x		52
Replace Fuel Lines and Clamps							x	49

* More often in extremely dusty or dirty conditions (Refer to notes about air cleaner element under IMPORTANT TIPS FOR CARE OF KOHLER ENGINE)

** Change engine oil and filter after first 8 hours of operation of a new engine (break-in period)

*** Air cleaner is remote mounted Cummins/Fleetguard OptiAir™ unit, replace filter every year

Δ Change oil every 50 hours when operating in dry, dirty conditions

ΔΔ Initial oil and filter change at 75-100 hours



CAUTION

When performing maintenance with the mower body raised, a safety prop should be installed from back of body to chassis frame (fail-safe protection in case of failure of body lift support).

IMPORTANT TIPS FOR CARE OF THE KOHLER ENGINE

Fuel System

- Fuel must be clean - free from water, dirt, and organic material.
- Change fuel filter on a regular basis and when contamination is suspected or found in the fuel.

Starting/Stopping

- Start engine with the throttle advanced off idle (1/4 to 1/2 throttle). This will aid starting, especially in cold weather.
- Keep the battery fully charged.
- Match crankcase oil viscosity to the ambient temperature, allowing the engine to crank faster and start easier.
- Position the throttle control between half and full throttle, then stop the engine.

Cooling System

- Keep engine air intake screen and cylinder head fins free of grass clippings, chaff, and dirt. Inspect intake screen and cooling fins for cleanliness and no damage.
- Periodically remove two access panels in the engine shroud to inspect and clean cylinder head cooling fins.
- Check performance of the cooling system by starting the engine, holding a hand adjacent to the cylinder head, and feeling the cooling airflow.



DANGER

Make sure to keep hands clear of exhaust pipe, muffler, and moving parts when checking airflow.

- Operate the engine at full speed when mowing. This allows the engine to produce full horsepower and move more cooling air through the engine cooling fins.

Air Cleaner System

- Use **only** Cummins/Fleetguard air cleaner elements. Aftermarket elements may not seal in the air cleaner housing, allowing dirt to enter the engine. Also, aftermarket filters often skimp on the filtration media and require more frequent replacement (see following instructions).

- Use the air flow restriction gauge to indicate the need to service the air filter.

- **DO NOT overservice** or frequently “disturb” the **air filter**. A dirty air filter actually cleans better than a new one. Changing the air filter too often can actually reduce filter efficiency and increase the opportunity for traces of dust to enter the engine. Wait until the element really needs servicing as indicated by the air flow restriction gauge.

- When the air filter element is removed or replaced, make sure all **dust is cleaned out of the air cleaner housing and hose**. Use a damp cloth and wipe the interior of the canister and hose clean (a little dirt left here will be sucked into the engine and reduce engine life). When the filter is reinstalled, make sure the **element is held tight and straight** in the canister for proper seating and sealing.

- Periodically check the air intake hose for cuts, nicks, etc., and the hose clamps for tightness.

Oil

- Use only multi-viscosity oils as specified with the viscosity matching ambient temperatures for the engine operating conditions. This will **aid starting** in cold weather and assure proper lubrication in hot weather.

- Use only Kohler oil filters. **Aftermarket filters may not seal properly** and/or have the incorrect pressure relief valve for proper lubrication.

LUBRICATION



WARNING

DO NOT attempt to lubricate the machine with the engine running. Disengage the PTO clutch, shut off the machine, and remove the ignition key.

Proper lubrication is an important maintenance procedure. It reduces wear and makes the machine quieter and easier to operate.

Engine Oil

Engine Break-In Oil

No special break-in oil is required. The engine is serviced with 10W-30, Service Class SG oil from the factory. The oil should be changed after the initial engine **break-in period** of **5-8 hours**. Thereafter, change oil **after every 100 hours** of operation.

Checking Engine Crankcase Oil Level

Check the engine crankcase oil level before use and **after each 8 hours** of continuous operation.


IMPORTANT: The importance of checking and maintaining the proper crankcase oil level cannot be overemphasized. Check the oil level **BEFORE EACH USE**.

1. Park the mower on a **level surface with the engine stopped**. Also, make sure the engine is cool and oil has had time to drain into the sump [allow **at least five (5) minutes** after stopping the engine].

IMPORTANT: NEVER check or add oil with the engine running.

2. Before removing the dipstick, clean the area around the dipstick to keep any dirt or debris out of the engine.
3. Remove the dipstick, wipe off with a clean rag, then reinsert the dipstick into the tube and tighten.
4. Remove the dipstick again and check the oil level on the dipstick. The oil level should be within the "Operating Range" on the dipstick (between the **LOW** mark and the **FULL** mark).

IMPORTANT: DO NOT operate engine without sufficient oil supply in the crankcase. **DO NOT** operate with oil level below the **LOW** mark or above the **FULL** mark on the dipstick.



Dipstick Operating Range

5. If additional oil is needed, refer to **Specifications** for proper crankcase lubricant. **Fill to the FULL mark**.


IMPORTANT: DO NOT overfill crankcase (oil above **FULL** level) as this **CAN** result in engine overheating, loss of power, and possible engine damage.

Changing Engine Crankcase Oil/Oil Filter


Change the engine crankcase oil **after every 100 hours** of operation and the oil filter **after every 200 hours** of operation as follows:

1. Park the mower on a **level surface with the engine stopped**. The engine oil should be warm before draining. If not warm from operation, start the engine and run a few minutes to warm the oil.
2. Before removing the dipstick, clean the area around it to keep any dirt or debris out of the engine.

3. Remove the dipstick and oil drain plug, and drain oil into a suitable container. Be sure to allow ample time for complete drainage.
4. Before removing the oil filter, clean the area around the filter to keep dirt and debris out of the engine.
5. Remove the old oil filter and wipe off the filter mounting surface on the engine.



Dipstick and Oil Fill
(view from above left side of tractor)



Oil Drain and Oil Filter Locations
(view from above right side of tractor)

6. Apply a thin coating of new oil to the rubber gasket on the replacement oil filter.

IMPORTANT: Use **ONLY** oil filters from the engine manufacturer. Aftermarket oil filters may not seal properly and/or may not have the correct pressure relief valve for proper lubrication.

7. Install the new oil filter on the engine. Turn the oil filter clockwise until the rubber gasket contacts the sealing surface, then tighten the filter an additional **1/2 to 3/4 turn**.
8. Reinstall the drain plug.
9. Fill the crankcase with new, clean oil. Use only crankcase lubricants recommended by the engine manufacturer. Refer to **Specifications** in this manual or the engine owner's manual. Use the recommended oil viscosity for the expected ambient temperature. Oil with the correct viscosity will aid starting in cold weather and assure proper lubrication in hot weather. **Fill to FULL mark** on the dipstick; crankcase capacity is 1.9 quarts (1.8 liters) when changing oil and filter.

IMPORTANT: Check the dipstick reading before pouring in the last 1/2 pint of oil and **fill only to the FULL mark**. The oil level should never be over the **FULL** mark on the dipstick; overfilling can result in engine overheating and loss of power.

10. Start the engine and check for oil leaks around the oil filter. Stop the engine, recheck the oil level, and add oil if necessary. (When the engine is first operated with a new oil filter, the oil level will drop slightly as the filter is filled with oil.)

Mower Deck Spindle Lubrication


These spindles are permanently sealed and require no lubrication.

DSD60 Mower Deck Lubrication

Lubricate the U-Joint in the drive shaft **every 8 hours** with SAE general purpose lithium or molybdenum base grease.

Transaxle Lubrication

- The transaxle oil lubrication is SAE 20W-50 (API Service Class SL or higher) engine oil.
- Inspect both transaxle cases and hoses **after every 100 hours** of operation for visible leaks.
- The fluid levels for each transaxle can be checked visually by looking at the fluid levels in each expansion reservoir. When the transaxles are cold, the fluid level in the expansion reservoirs should be between 1/4 and 1/2 in. (0.64 cm and 1.27 cm).



Expansion Reservoir Location

Grease Fitting and Oil Point Lubrication

Lubricate the grease fittings and oil points after **every 25 hours** of operation. Lubricate **more often** when operating in **dusty or dirty conditions**. Use SAE general purpose lithium or molybdenum base grease for grease fittings and light machine oil (SAE 10) to lubricate oil points. **Lubricate the locations shown in the Chassis and Deck Lubrication Points illustration.**

NOTE: PTO universal joints (on the deck and tractor) require routine lubrication **after every 8 hours** of running time.

NOTE: The best way to lubricate the PTO tube half of the universal joint assembly is to remove it from the tractor. See instructions for removing and installing PTO quick coupler, refer to *Deck Installation* in **Mower Deck Installation on Tractor** in the **Assembly Instructions**.


Maintenance Instructions

LUBRICATION

Ident No.	Location	Lubrication Type	No. Places	Ident No.	Location	Lubrication Type	No. Places
1	Deck Caster Wheel Fork Pivot	Grease	2	16	PTO Clutch Lever Pivot	Grease	1
2	Deck Caster Wheel Bearing	Grease	2	17	PTO Belt Tightener Pivot	Grease	1
3	Deck Belt Tensioner Pivot	Grease	1	18	Throttle Control Cable Ends	Oil	2
4	Front Deck Lift Pivot	Grease	2	19	Choke Control Cable Ends	Oil	2
5	Rear Deck Lift Pivot	Grease	2	20	Tail Wheel Caster Fork Pivot	Grease	2
6	Pivot Assembly, Tilt-Up Deck	Grease	2	21	Rear Wheel Pivot	Grease	1
7	Deck Support Arm Socket	Grease	2	22	Rear Wheel Bearing	Grease	2
8	Steering Lever Pivot	Grease	2	23	Engine / Oil Filler	Oil**	1
9	Transaxle Oil Reservoir	Oil	2	24	Parking Brake Pivot	Grease	1
10	Deck-to-PTO Coupling (Grease Slide Area)	Grease	1	25	Choke Control Pivot	Oil	1
11	Deck Support Arm Pivot	Grease	2	26	Throttle Control Pivot	Oil	1
12	Universal Joint Tube Assembly	Grease*	1	27	Universal Joint Shaft Assembly	Grease*	1
13	FSC Lever Pivot	Grease	1				
14	Hydro Idler Arm Pivot	Grease	1				
15	Body Latch	Oil	2				

* Grease every eight (8) hours.

** Refer to **Engine Oil** located on page 35.




Chassis and Deck Lubrication Points

Transaxle Oil and Filter Change

Change the transaxle oil after the initial **break-in period of 75-100 hours**. Thereafter, change oil **every 400 hours** of operation as follows:

1. Thoroughly clean the exterior of the transmission housing before servicing. Using a 1/4 in. hex wrench, remove the plug on the lower inside of each transaxle allowing the oil to drain.
2. Remove and replace the oil filters using a 3/8 in. hex wrench. (Refer to **Transaxle Oil Drain Plug, Filter, and Guard Location** illustration.)



Transaxle Oil Drain Plug, Filter, and Guard Location
(Shown with Deck Support Arms Removed for Clarity)

3. Reinstall drain plugs.
4. Remove the oil reservoir hose attached to the elbow on top of the transaxles and remove the elbows to access the oil fill openings.
5. Fill the transaxles with 20W-50 (API Service Class SL or higher) oil through the opening where the elbows were. Fill up to the opening.
6. Before reinstalling the elbows, screw the locking nut on the elbows down until they are snug (the o-ring on the elbow will be to the bottom of the o-ring groove).
7. Reinstall the elbows. When the elbow begins to be snug, position the elbow as it was when removed and tighten the locknut.
8. Fill both reservoirs to 1/4-1/2 in. (6-13 mm) with 20W-50 (API Service Class SL or higher) oil.
9. Start and drive the unit for 1- 2 minutes.
10. If the transaxles sound noisy or have poor steering response, recheck oil level in both transaxles by removing the elbows (check oil level at fill opening).
11. If oil needs to be added refer back to steps 4-10.


CLEANING

Engine Air Cleaner System

Cummins/Fleetguard OptiAir™ Air Cleaner


A remote mounted Cummins/Fleetguard OptiAir™ air cleaner provides the air filtering function. The paper filter element slides over an outlet tube inside the air cleaner canister with **radial** sealing action, eliminating the possibility of dust leaks due to improper filter installation. Intake design, internal baffling, and a dust ejection valve provide dust separation and automatic precleaning action. Daily or frequent servicing of the air cleaner is **not required**. Use the air restriction gauge on the air cleaner outlet to indicate when the air filter needs servicing -- a red flag will appear when the filter is overly restricting airflow into the engine.

IMPORTANT: Use **only** Cummins/Fleetguard air filter elements for replacement (Walker 2090-1 or 2090-3). Aftermarket filters may not seal properly or filter efficiently.




**Air Cleaner Components
(shown with cover being removed)**

IMPORTANT: The Cummins/Fleetguard air cleaner uses a dry paper-type air filter element. **NEVER** apply oil to the paper element.



Engine Air Cleaner System Components



Air Restriction Gauge Location

Inspect the paper element **after every 100 hours** of service and **replace** the element and safety filter **yearly** (or when dirty or damaged). More frequent replacement may be required when operating in extremely dusty conditions as indicated by the air restriction gauge. Service the air cleaner as follows:

1. Lift Mono Latch Twist Lock™ and twist the OptiAir™ cover to the left into the "open" position to remove the air cleaner cover. Wash the cover and dust ejection valve. Check that these components are in good condition. The dust ejection valve is subject to wear and deterioration and should be replaced **yearly** or when damaged. The lips of the valve should close and fit together; any cracks, deformation, or wear in the valve is cause for replacement.
2. Remove the filter element by pulling it out of the canister. There will be some initial resistance as the filter seal breaks loose and slides off of the outlet tube. **Gently** move the end of the filter up and down and side to side or twist to loosen the seal. Use gentle action to minimize the amount of dust dislodged as the filter is removed.
3. Replace the filter element.


NOTE: Washing the element in water or cleaning solution is **not recommended**. Do not try to clean the element with compressed air.
4. Use a bright light inside the element to inspect for damage. Check the element very carefully for **pin holes or other damage** that will allow dirt to leak through the paper media. Replace element if necessary.

5. Without removing, visually inspect the condition of the safety filter for damage or holes. The safety filter should only be removed for yearly replacement (or when dirty or damaged).
6. Check the condition and resilience of the radial sealing surface (inside of the open end) of the filter. Replace the filter if any cracks, tears, or other damage to the sealing surface are noted.
7. Use a clean, damp cloth and wipe the interior of the air cleaner canister clean. Use special care to clean **both the inside and outside** surfaces of the outlet tube.

IMPORTANT: Any dust left on the inside of the outlet tube will go into the engine and cause wear.


8. Check the outside surface of the outlet tube for smoothness and cleanness (this is the sealing surface).
9. Insert and seat the safety filter and OptiAir™ element carefully into the canister, applying pressure at the outer rim of the filter; not at the flexible center. Make sure the filter element is completely in place before installing the cover.

NOTE: DO NOT use petroleum based lubricants on the sealing surfaces of the filter; use talcum powder or dry silicone lubricants if required for filter installation.



Air Filter Element Replacement

10. Install the cover with the word "DOWN" properly oriented to the bottom of the canister. Twist the OptiAir™ cover to the right and put into the "closed" position.



Proper Orientation of Air Cleaner Cover

11. Check the air intake hose for cuts, nicks, cracks, etc., and the hose clamps for tightness.
12. Reset the air restriction indicator (press button on the end of indicator).


Engine Cooling System

Air Intake System

To prevent engine overheating and possible engine damage, clean grass clippings, chaff, and dirt from the rotating engine air intake screen **after every 8 hours of operation**. In certain mowing conditions (dry grass, leaves, tree "cotton", etc.), it may be necessary to check and clean the screen several times each day to prevent engine overheating.

CAUTION

Operating the engine with a blocked air intake screen, dirty or plugged cooling fins, and/or cooling shrouds removed will cause engine damage from overheating.



Rotating Engine Screen


Keep Engine Screen Clean

Cylinder Head Cooling Fins

It is essential for performance and longevity of the air-cooled engine to keep the cylinder head cooling fins clean and free of obstruction. After **every 8 hours** of operation, check the performance of the cooling system by starting the engine, holding a hand adjacent to the cylinder head, and feeling the cooling airflow. If there is little or no airflow, clean the cooling fins as described on the next page.


DANGER

Make sure to keep hands clear of exhaust pipe, muffler, and moving parts when checking airflow.



Cooling System Airflow

Every 100 hours, inspect and clean the cooling fins (more often when operating in extremely dusty, dirty conditions). Remove the two (2) cooling fin access panels in the engine shroud and clean the cooling fins and external surfaces using compressed air. Make sure to reinstall the access panels before operating the engine.




Engine Air Intake Screen and Cooling Fin Access Panels

Grass Buildup in Mower Housing




Before raising or removing the mower deck for cleaning, stop the engine, remove the ignition key, and disconnect the spark plug wires.

1. Release hood latch assembly (2) and remove footrest.
2. Rotate locking arms **upward** on each side of the carrier frame to release carrier frame for tilting action.




Locking Arm Rotation

3. Install tilt bar into front of deck.



Tilt Bar Installed

- Using the tilt bar, raise deck to the **TILT-UP** position and insert the deck hook into the tilt-up latch on the tractor body.



Deck Secured in Tilt-Up Position

- Clean grass buildup underneath the deck using a pressure washer (and scraper if required).

NOTE: If the buildup is severe, it may be easier to clean the deck by removing the deck assembly from the tractor and standing the desk assembly on its “nose”.


NOTE: While some degree of material buildup in the mower deck housing can be tolerated, a point is finally reached **where cutting quality deteriorates and clogging begins to occur** because of too much buildup on the baffling and housing.

DANGER

Do not operate the mower with deck in tilt-up position. Do not move the tractor with the deck in the tilt-up position.

- Lower the deck to the normal operating position and rotate locking arms **downward**.
- Remove tilt bar and store on carrier frame.

- Reinstall footrest by inserting locking fingers under deck plate and reattaching hood latch assembly.



Footrest Installation



CAUTION

Do not operate machine with deck locking arms disengaged.


Transaxle Cooling Fins

Keeping the cooling fins on the transaxles clean and free of obstruction is **essential to avoid overheating** the transmission fluid and shortening transmission life. The cooling fins should be checked **every 100 hours**; and cleaned if necessary.

To clean the fins, use compressed air and/or a pressure washer. The cooling fins extend all the way around the housing -- the fins underneath need to be clean as well as the more visible fins above. Also, pay close attention to the area under the drive pulley.

IMPORTANT: In case an oil leak develops on the input shaft, the cooling fan blowing dusty air and oil on the transmission will **quickly** pack the cooling fins with **oily dirt**. If this condition occurs, contact your dealer immediately to avoid overheating and damaging the transaxle.

An additional procedure in maintaining transaxle cooling is to inspect the cooling fans. Replace the fan(s) if blades are missing or damaged.



Transaxle Cooling Fans

CHECKING/SERVICING



To prevent accidental starting of the engine when servicing or adjusting the machine, remove the key from the ignition switch and disconnect the spark plug wires.

Security of Air Filtration Components

NOTE: The following inspection is **only an external inspection** and should be done without “disturbing” the filtration components.

On a daily basis, visually inspect the external condition of the complete air cleaner system. The following items should be inspected:

1. Check the Cummins/Fleetguard OptiAir™ air cleaner canister for damage. Make sure the cover is in place and the cover latch is secure - do not run the engine without the air cleaner cover in place and secure.
2. Inspect the air intake hose for cracks, nicks, cuts, etc., and check the hose clamps for tightness.
3. Check to make sure the air flow indicator is in place and tight.

Battery

NOTE: For initial battery service during setup, refer to **Battery Service** in **Assembly Instructions**.

IMPORTANT: Make sure battery is securely mounted in the frame. A loose battery may cause damage to the case resulting in acid leakage and severe damage to the machine. A hazard may be created by damage to critical working parts and safety systems.

Cleaning the Terminals

If battery terminals are corroded, **remove battery** from the mower. Using a wire brush, remove corrosion with a solution of **one part baking soda and four parts water**. Rinse with clean water. Coat the terminals with petroleum jelly or terminal protector spray to retard further corrosion.

Charging the Battery



BATTERIES PRODUCE EXPLOSIVE GASES

- Charge the battery in a well-ventilated area, so that gases produced while charging can dissipate.
- Keep sparks, flames, and smoking materials away from the battery at all times.
- Make sure the battery cap vents are open (check manifold vent on each cap).
- Make sure the battery charger is unplugged before connecting or disconnecting cables to the battery.

Check the battery charge by measuring the specific gravity of electrolyte; if specific gravity is less than 1.225, the battery will need to be charged as follows:

- Charge the battery at 15 amps for 10 minutes. **DO NOT** exceed 20 amps maximum recommended charging rate. Charge until specific gravity is at least 1.250. Total charging time should not exceed one (1) hour.

Tire Pressure

Inflate tires to pressures shown below:

Deck Caster Wheel = 20 PSI (137 kPa)
 Drive = 15 PSI (103 kPa)
 Rear = 20 PSI (137 kPa)

Wheel Nuts Torque

Check **every 100 hours** the eight (8) Drive Tire mounting nuts. They should each be torqued to 75-85 ft-lbs. (101.7-115.2 N·m).

Sharpen Mower Blades

Check mower blade(s) for **straightness, sharpness, condition of the cutting edge**, and **balance every 10 hours** of operation (or more often when mowing abrasive type grass or operating on sandy soils). **Replace blades if worn, bent, cracked, or otherwise damaged** (refer to **REPLACING/REPAIRING the Mower Blades** in this section). Use the following procedure to check and sharpen blades:

NOTE: Keep blades sharp - cutting with dull blades not only yields a poor mowing job but slows the cutting speed of the mower and causes extra wear on the engine and blade drive by pulling hard.

1. Stop the engine, remove ignition key, and disconnect the spark plug wires **before** raising the mower deck to service blades.
2. Raise the deck and **secure it** in the **tilt-up** position (refer to **Deck Secured in Tilt-Up Position** photo in **CLEANING of Grass Buildup in Mower Housing** in this section).

DANGER

NEVER operate cutter blades with the deck in the raised position.

NOTE: PTO shaft must be **disconnected** before checking blades for straightness.

3. Check the blades for **straightness** by marking the blade tip position inside the deck housing, and then rotating the opposite end of the blade to the same position and comparing. If the difference in blade tip track is **more than 1/8 in. (3 mm)**, the blade is bent and **should be replaced**.

WARNING

DO NOT try to straighten a blade that is bent. NEVER weld a broken or cracked blade. ALWAYS replace with a new blade to assure safety.


4. If the blade cutting edge is **dull or nicked**, it should be sharpened. Remove blades for sharpening by grasping the end of the blade using a rag or a thick, padded glove, while loosening and removing the bolt and washer that mounts the blade.
5. Grind cutting edge at the same bevel as the original. Sharpen only the top of the cutting edge to maintain sharpness.

NOTE: Blades can be sharpened with an electric blade sharpener, conventional electric grinder, or a hand file.


CAUTION

ALWAYS wear eye protection and gloves when sharpening a blade.

6. Check blade balance by positioning the blade **horizontally** on a blade balancer or use a nail or shaft through the center hole. If either end of the blade rotates downward, grind (remove) metal on that end until the blade will balance. The blade is properly balanced when neither end drops. Balance of a blade is generally maintained by removing an equal amount of material from each end of the blade when sharpening.



Mower Blade Profile For Sharpening



Blade Balanced on Magnetic Wall-Mounted Balancer

7. Mount the blade with wing tips pointing up into the housing. Reinstall the blade, washer, and bolt. **Tighten the bolt to 64 ft-lb (86.8 N·m).**

Drive Belts

Raise the body and inspect the condition of the four (4) drive belts **after every 25 hours** of operation -- engine/PTO drive and ground drive. If the belts show **signs of cracking or deteriorating**, the belts should be **replaced**. Refer to **REPLACING/REPAIRING the Drive Belts** in this section.

Spark Plugs

Every 200 hours, remove the spark plugs, inspect, clean, and reset the gap (or replace with a **new plug**). Clean spark plug with a wire brush. If the electrodes are burned short or pitted, replace the plug (refer to **Specifications** for the proper type of replacement plug). Check the spark plug gap with a wire-type feeler gauge and set the gap to 0.030 in. (0.76 mm). Reinstall and tighten to 18 ft-lb (24.4 N·m). Both spark plugs should be replaced yearly.

Fuel Lines and Clamps

Every year, inspect the fuel lines from the tanks to engine for deterioration or damage. Also, inspect the fuel line **clamps for tightness**. Good preventive maintenance calls for complete **replacement** of fuel lines and clamps **every two (2) years**.

Blade Brake Action

WARNING

It is important to check and maintain blade brake action for safe operation of the machine.

Check the function of the cutter blade brake by engaging the blade clutch (PTO), operating the engine at full throttle, then disengaging the clutch and measuring how quickly the blades stop. Watch the rotation of the blade drive shaft as a visual indication that movement has stopped. If the brake is **working properly, all rotation will stop five (5) seconds after disengagement** of the clutch. If the brake system malfunctions -- blades do not stop in five (5) seconds -- repair the brake before operating the mower.

REPLACING/REPAIRING

DANGER

To prevent accidental starting of the engine when replacing parts or repairing the machine, remove the key from the ignition switch and disconnect the spark plug wires.


IMPORTANT: ALWAYS use genuine factory replacement parts. Substitute parts **CAN** result in product malfunction and possible injury to the operator and/or others.

Drive Belts

There are **four (4) individual belts** on the machine:

- Engine/PTO Belt [Matched Set (3)]
- Ground Drive Belt


The belts may be removed and replaced using the **procedures described on the following pages**.



Belt Locations (Engine Hidden for Clarity)


Engine/PTO Belt

1. To remove the engine/PTO belt:
 - a. Loosen and remove idler tension bolt and jam nut.
 - b. Relax belt by depressing idler arm.
 - c. Roll the belts off the pulley and remove the belts.



**Engine/PTO Belt (Disengaged)
(Engine Hidden for Clarity)**

2. Reverse the removal procedure to replace the engine belts.




**Engine/PTO Belt (Engaged)
(Engine Hidden for Clarity)**

Ground Drive Belt

1. To remove the ground drive belt:


a. Raise the spring-loaded idler to relax belt.

b. Slide belt off pulleys, then release the idler.



Ground Drive Belt Assembly (Disengaged)


2. Reverse the procedure to install the ground drive belt.



Ground Drive Belt Assembly (Engaged)

Fuel Filter

Model MBSSD is equipped with in-line fuel filters. Visually inspect the filter periodically, and replace the filter **yearly**.



Fuel Filter Location

IMPORTANT: Replace the fuel filter only in a clean area where the fuel line and connections will not be contaminated by any dust and dirt.



DANGER

Gasoline is extremely flammable and can be highly explosive. To minimize danger:

- Use only an approved fuel container for gasoline.
- **DO NOT** allow open flames or sparks near the machine while performing maintenance or refueling; **DO NOT** smoke while working with fuel.
- Wipe up spilled gasoline immediately and completely.

1. Expand and slide clamps on either side of the filter away from filter and pull fuel lines off filter.
2. Replace filter.

Mower Blades

Mower blades are removed and remounted as described in the **Sharpen Mower Blades** instructions (refer to **CHECKING/SERVICING to Sharpen Mower Blades** in this section). During the course of sharpening and inspecting mower blades, if there are **any of the following conditions of wear or damage, blades should be replaced** for reasons of safety and performance of the machine:

- An excessive amount of the **flat section** of the blade has been **ground away** (removed) when the blade is sharpened. Replace the blade **when less than a 3/4 in. (19 mm) flat section remains** at the blade tip.
- Examine ends of the blade carefully, especially the intersection where the flat section of the blade turns up to form the “wing tip” (refer to **Mower Blade Profile For Sharpening** illustration in **Sharpen Mower Blades** instructions). Since sand and abrasive material can wear metal away in this area, the blade should be **replaced when metal thickness has worn to 1/16 in. (1.6 mm) or less**.



DANGER

When blades are operated over sandy soil, and if blades are allowed to wear, a “slot” may be worn into the wing tip of blade. Eventually a piece of the blade may break off creating a serious potential for injury or damage.

- Check the blades for **straightness** by marking blade tip position inside the deck housing and then rotating the opposite end of the blade to the same position and comparing. If the difference in blade tip track is **more than 1/8 in. (3 mm)**, the blade is bent and **should be replaced**.
- Inspect the blade surface, especially in formed areas, for **cracks**. Replace the blade if any cracks are found.



WARNING

DO NOT try to straighten a blade that is bent. **NEVER** weld a broken or cracked blade. **ALWAYS** replace with a new blade to assure safety.

Reinstall the blades following procedure from **Sharp-en Mower Blades** instructions. If blades are replaced, always use **Walker original equipment blades** to ensure safety and optimum performance. The quality and performance of **replacement blades offered by other manufacturers** cannot be guaranteed, they **could be dangerous**.



CAUTION

ALWAYS use genuine factory replacement parts. Substitute parts CAN result in product malfunction and possible injury to the operator.

ADJUSTMENTS

Transmission Control

IMPORTANT: The proper adjustment of the transaxle control stops is essential for efficient operation and life of the transaxle. These stops are properly adjusted at the factory and should only require readjustment if the transaxle or related control linkage is removed or changed.


NOTE: It would not be unusual for a new machine, after initial 5 or 10 hours of operation, to begin to not travel straight (this is due to the break-in of the transaxles).

Steering Lever Position Adjustment - Step 1

NOTE: For proper operation, the steering levers should be adjusted to sit evenly using the following procedure.


1. Examine the steering levers to make sure they are parallel front to back in relation to one another. If they are not equal, adjust accordingly. (The handles may or may not be even at this point.)

NOTE: The LH steering lever is non-adjustable. This procedure will require adjustment of the RH lever to make it even with the LH lever.



Lever Alignment


2. Adjust the position of the RH lever by turning the stop bolt in the Speed Control Actuator in or out. Turning the stop bolt in will make the RH lever move back, and turning it out will make it move forward. Tighten the locknut.



Stop Bolt Location

Steering Handles Adjustment - Step 2

1. An adjustment range of approximately 3 in. (76.2 mm) is available on the steering handles - the handles can be adjusted forward or aft depending on the arm length of the operator. The handles can be adjusted by loosening the locknut at the pivot point and the locknut holding the handle in position in the adjustment slide. Adjust the handles into the most comfortable position and tighten both locknuts.




Steering Lever Adjustment

Neutral Position Adjustment - Step 3

1. With the Forward Speed Control (FSC) in neutral, the lever should be straight up. Adjust by loosening the jam nuts on the FSC Rod and turn the rod to attain the straight up position. Tighten the jam nuts.



FSC Position



Steering Adjustment

2. The initial adjustment for neutral is to loosen the jam nuts on each end of the Hydro-Gear Control Rods and turn the rods to achieve a measurement of 4 in. (101.6 mm) between the jam nuts. Be sure to tighten jam nuts before making the measurement.




Actuator Rod Length Adjustment

3. Block the tractor up so the drive tires are off the ground.
4. With the FSC in neutral, start the engine. (Operate first at idle and then normal operating speed) and check for movement of drive wheels.

NOTE: If the engine will not start, check and adjust the neutral safety switch (refer to *Neutral Switch Adjustment - Step 6*).

5. With the FSC in the neutral position and the engine running, the wheels should not move. If a drive tire is moving, the Control Rod on that side is out of adjustment. Adjust that side to achieve neutral. Now both transaxles are in the neutral window.




**Neutral Window
(Front Body Hidden for Clarity)**

6. One at a time adjust the left and right Control Rods to find the center of the neutral window. Shorten the rods until the drive tire turns forward then lengthen it until the drive tire turns in reverse (approximately 1 turn). Position the rods halfway between forward and reverse. Tighten the jam nuts.
7. Lower drive tires onto ground.

Full Forward Speed Adjustment - Step 4

1. Move the FSC to the full forward speed position.
2. Raise the body. The set screws in the left and right Transmission Control Arms should not be contacting the locating stud in the transaxle. If they are, back the set screws out until they do not touch.



**Neutral Travel End
(Shown with Parts Removed for Clarity)**

Straight Tracking Adjustment - Step 5


1. Sit in the seat, start the engine, set throttle at full speed, and with the FSC in the NEUTRAL-PARK position check for movement of either drive wheel (if either wheel moves backward or forward, refer to the *Neutral Position Adjustment - Step 3* and readjust).
2. Check for straight ground tracking on a level surface (with hands off the steering levers). Set the FSC at several different speeds and observe if the mower moves in a straight line (use cement joint or other line on ground for reference).
3. If travel is not straight, shorten the control rod of the slow side (adjust in 1/8 turn increments) to match the faster side while maintaining the neutral position. If straight tracking and neutral can not be achieved, turn the control rod back to where neutral can be achieved.
4. Lengthen the control rod of the faster side (adjust in 1/8 turn increments) to match the slower side while maintaining the neutral position.
5. If the forward travel is straight throughout the speed range, except at maximum speed - place the FSC in full forward, turn the set screw in the Transmission Control Arm, of the faster side, in until it contacts the hydro stud. (Turning the set screw in slows the wheel.) Turn the set screw in an additional 1/8 turn. Recheck for equal full forward speed. Adjust this set screw until equal full forward speed is achieved. Tighten the jam nut.




Neutral Travel End Adjust

FSC Switch - Neutral Adjustment - Step 6

1. Place the FSC in neutral position. Loosen mounting screws and adjust switch up or down accordingly.



FSC Switch Location



**FSC Switch Adjustment
(Side View Through Chassis)**

Forward Speed Control Friction Adjustment - Step 7




FSC Position With Levers

1. Place the FSC in the full forward position and pull both steering levers back; the FSC lever should not move. If the FSC lever moves back the friction needs to be increased.
2. With the steering levers held back, move the FSC lever back from the forward position. With a proper amount of friction adjusted, the FSC lever should move back with a slight amount of resistance (friction). If the FSC lever movement is "stiff", the friction needs to be decreased.
3. The FSC friction is increased or decreased by tightening or loosening the friction adjustment nut. Loosen or tighten the nut and check the control function until the conditions of both steps 1 and 2 are met.

PTO Belt Tension

PTO belt tension can be adjusted by lengthening or shortening the position of the adjustment bolt on the idler adjuster (above idler pulley). Optimum adjustment will result in a 1/2 in. (1.27 cm) deflection of the belt.



PTO Belt Tension Adjustment


PTO Clutch




WARNING

It is important to check and maintain blade brake action for safe operation of the machine.

The declutched or disengaged position of the PTO clutch is adjustable and is set to completely release spring tension on the mechanical clutch. The spring in the linkage that engages the clutch should not have any tension on it when the clutch is disengaged. Adjust the PTO clutch engagement adjustment bolt up or down to allow minimal free movement in the disengaged position. If this can not be achieved, the clutch rod will need to be adjusted.



PTO Clutch Adjustment - Disengaged




PTO Clutch Adjustment - Engaged

NOTE: When making any of the PTO clutch adjustments, it is important that the overall length from the top of the clutch engagement spring to the lower mounting of the clutch actuator link be 5-1/4 in. (13.3 cm) when engaged.

Clutch Rod

The clutch rod and ball joints are factory adjusted to 10-1/4 in. (26.0 cm) overall length. Increasing the length will increase the free movement of the spring on the clutch engagement arm. Decreasing the length will increase the amount of spring stretch in the engaged position. (Refer to **PTO Clutch Adjustment - Engaged** illustration.)



Clutch Rod Adjustment

ELECTRICAL SYSTEM

For troubleshooting, refer to the **WIRING SCHEMATIC**.


IMPORTANT: Disconnect both battery cables before unplugging any wiring connectors or making repairs on the electrical system.

TRACTOR AND DECK DECALS

ITEM NO.	PART NO.	DESCRIPTION	LOCATION	NO. REQ'D SD
Walker Product and Operation Decals				
1	2802-2	RH Fender	Body, RH near Seat	1
2	2010-4	Fuel Transfer	Transfer Mount	1
3	5800-6	Decal, Walker 6-3/4"	Rear Body (one on each side)	2
4	2802-1	LH Fender	Body, LH near Seat	1
5	9804	Axle Lockout	Chassis	2
6	5856	Made in USA	Body	1
7	5803	Walker Manufacturing Logo	Body	1
8	2748	Cutting Height Adjustment	Carrier Frame	1
9	5800-5	Decal, Walker 8"	Deck Footrest, Front	1
Danger Decals Warning Decals Caution Decals				
10	5805	Caution, Engine Exhaust	Rear Body	1
11	6810	Danger, Engine Exhaust	Engine, LH Side	1
12	2107-4	Decal, Belt Routing	Rear Body, Underside	1
13	4107-1	Danger, Rotating Components	Air Cleaner Bracket	1
14	5808	Danger, Rotating Blades	Deck Housing (one on each end)	2
15	8647	Danger, Tilt-Up	Carrier Frame	1
16	8653-1	Transport Warning	Deck Housing	1
17	8653	Caution, Pivot Joint	Carrier Frame	2
18	2749	Decal, Drive Belt Routing	Deck Housing	1
19	5848	Danger, Side Discharge Shield	Side Discharge Shield	1
Maintenance Decals				
20	2105-8	RH Decal, 27 HP	Rear Body, RH Side	1
21	2105-9	LH Decal, 27 HP	Rear Body, LH Side	1
22	5855	Important, Engine Cooling	Engine	1
23	2807-1	Decal, Oil Pressure/Head Temp.	Body	1
24	6875	PTO Alignment Arrow	Universal Joint Tube Assembly	1
25	8746	Universal Joint Lube	Mount Bracket / PTO Guard	1
26	2732	Decal (60")	Deck Housing, Front	1
Option Decals (applied only to units with corresponding Options installed)				
27	5877	Lights, On-Off	Body	1

NOTE: All parts requiring decals are shipped with decals applied.

TRACTOR AND DECK DECALS




BODY / CHASSIS ASSEMBLY

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Body & Seat Assembly				Deck Arm Adapter Kit*			
1	2103-1	Seat	1	44	2431-1	Deck Arm Adapter, LH	1
2	2105-1	Rear Body (Includes Item # 3)	1	45	5775-2	Hitch Pin (#6)	2
3	2190-1	Insulation Foam Pad	1	46	2430-1	Deck Arm Adapter, RH	1
4	5845	Rubber Bumper (1.50 x 1.25)	2	47	2744-2	Counter Weight Spring Extension	1
5	5146	10mm Ball Stud	2	48	2744-4	1/4" Quick Link	1
6	2145	Gas Spring	1	49	2744-5	Chain	1
7	5180	Edge Molding, Lever Opening	2	Tilt-Up Latch Assembly**			
8	2100-3	Front Body Doubler	1	50	5847	Plastic Tip	1
9	2504-4	Hinge (22.5)	1	51	5744-20	Spring Arm, Tilt-Up Latch	1
10	2100-1	Front Body	1	52	5744-10	Spring Pivot Bushing	1
11	5989-5	Dome Plug (7/16)	1	53	5744-15	Compression Spring (3/8 x 5/8)	1
12	2383	Body Latch Hook	1	54	5744-13	Mount Angle, LH	1
13	7854	Plastic Tip, Red	1	55	5744-12	Hook, Tilt-Up Latch	1
14	7222	Extension Spring (1/4 x 3)	1	56	5744-14	Mount Angle, RH	1
15	5989-4	Dome Plug (3/8)	2	Fasteners			
16	5989-3	Dome Plug (5/16)	2	F002	10-24 Keps Nut		5
Chassis Assembly				F004	1/4-20 Keps Nut		11
17	2390-1	Battery Pan	1	F005	1/4-20 ESNA Nut		2
18	2046-1	Gas Tank Mount, LH	1	F009	5/16-18 Whiz Locknut		16
19	2300-3	Chassis Frame	1	F013	3/8-16 Whiz Locknut		2
20	2046	Gas Tank Mount	1	F020	5/16-18 ESNA Nut		1
Tail Wheel Assembly				F025	10-24 x 3/8 PPHMS		5
21	5830	Grease Fitting	4	F029	1/4-20 x 1/2 Hex Bolt		2
22	2201-2	Fiberglide Thrust Washer	2	F034	5/16-18 x 3/4 Hex Bolt		8
23	2201-3	Fiberglide Bearing (1-5/8)	2	F093	5/16-18 x 1 Hex Bolt		1
24	2300-6	Tail Wheel Pivot (Includes Items # 21 & 25)	1	F151	3/8-16 x 7/8 Hex Bolt		2
25	5830-3	Grease Fitting (45 Deg.)	1	F183	.312 x .700 x .074 Washer		4
26	2201-4	Washer (2-1/4 x 7/16 x 1/4 Thk)	1	F205	5/16-18 x 1/4 Set Screw (Knurl Point)		2
27	8769-8	Dust Cap, Deck Caster	2	F218	7/16 Split Lock Washer		5
28	8769-6	Bearing Cone (1" ID)	4	F219	7/16-14 x 1-1/4 Hex Bolt		5
29	8769-5	Bearing Cup (2 x 1-5/8)	4	F236	1/4-20 x 1-3/4 Hex Bolt		2
30	8769-7	Seal	2	F246	1/4-20 x 1/2 PTHMS		4
31	2770	Caster Wheel Fork	2	F256	7/16 SAE Washer		1
32	8039	Nut, Tail Wheel Axle	2	F341	Coil Roll Pin (7/64 x 9/16)		1
33	8038-1	Spacer, Tail Wheel Axle (.750 x ID x 1.125 OD)	2	F342	5/16 Conical Washer		2
34	8768-2	Seal, Reverse Lip	2	F344	3/4-16 Slotted Hex Nut		2
35	8037	Bearing Cone (3/4 ID)	4	F347	3/4 SAE Washer		2
36	8035	Tail Wheel & Tire (13 x 5.00-6) (W/Bearing Race)	2	F348	1/8 x 1-1/2 Cotter Pin		2
37	8037-1	Seal, Outer (1-3/4 x 1-1/8)	2	F430	7/16-20 ESNA Nut		2
38	7038	Tail Wheel Axle (3/4 x 5-9/16)	2	F442	1/4-20 x 5/8 PTHMS		5
Deck Support Arm & Hitch Assemblies				F446	7/16-20 x 3-1/2 Grd 8 Bolt		2
39	2300-9	Deck Arm Support Mount	1	* Complete Deck Arm Adapter Kit available by ordering kit 2430-10. This kit allows the use of all Side Discharge Decks with the MBSSD Tractor.			
40	6840-1	Support Arm Bushing (2-1/16)	2	** Complete Tilt-Up Latch Assembly Kit available by ordering kit # 5747.			
41	2775	Lynch Pin (5/16 x 1-1/4)	2				
42	2431	Deck Support Arm, LH (Includes Item # 21)	1				
43	2430	Deck Support Arm, RH (Includes Item # 21)	1				

Use only genuine Walker® replacement parts.

Effective Date 03-31-08

BODY / CHASSIS ASSEMBLY



Effective Date 03-31-08

Use only genuine Walker® replacement parts.

MAIN COMPONENT POWER TRANSMISSION

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
PTO Drive Assembly				Fasteners			
1	4850	Handle Grip	1	F004		1/4-20 Keps Nut	5
2	2358	Clutch Lever (Includes Item # 1)	1	F008		5/16-24 Keps Nut	2
3	5830-4	Grease Fitting (90 Deg.)	1	F009		5/16-18 Whiz Locknut	12
4	5214-2	Ball Joint (5/16-24) (Nylon Lined)	2	F012		3/8-16 Keps Nut	1
5	4358-1	Clutch Rod	1	F013		3/8-16 Whiz Locknut	3
6	5229	Extension Spring (1/2 x 2-1/4)	1	F020		5/16-18 ESNA Nut	1
7	2358-5	Clutch Actuator	1	F024		5/16-24 Jam Nut	2
8	5103-2	Pivot Bushing (5/16 ID)	2	F029		1/4-20 x 1/2 Hex Bolt	1
9	2358-6	5/16-18 x 1-3/4 Stud	2	F031		1/4-20 x 5/8 Hex Bolt	5
10	2349-2	Bearing Mount Plate	1	F034		5/16-18 x 3/4 Hex Bolt	5
11	2349-3	Switch Pivot Mount	1	F046		3/8-16 x 3-1/2 Hex Bolt	1
12	7407	Clevis Pin (3/16 x 1/2)	2	F091		5/16-18 x 5/8 Hex Bolt	1
13	2358-4	Clutch Actuator Link	2	F093		5/16-18 x 1 Hex Bolt	4
14	4358-5	Clutch Linkage Spring	1	F114		5/16-18 x 5/8 SQH Set Screw	1
15	2236	PTO Pulley (Includes Items # F075, F114 & F435)	1	F127		1/16 x 1/2 Cotter Pin	2
16	5268	Bearing W/Collar (3/4)	2	F163		5/16-18 x 3/4 SQH Set Screw	1
17	2274-6	PTO Drive Shaft (1")	1	F168		5/16 Split Lock Washer	1
	2274-5	PTO Drive Shaft Assembly	*	F170		5/16 x 1 x 7/64 Flat Washer (Zinc Plate)	1
18	7275-9	Quick Coupler Installation Tool	**	F178		1/4 x 1 Fender Washer	1
19	7275-16	Universal Joint Tube Assembly / Spline	1	F185		1/4 Int. Star Lock Washer/SS	1
20	2274-7	PTO Bearing Housing	1	F241		.375 x .875 x .10 Washer	2
21	4325-3	Clutch Stop	1	F336		3/8-16 Jam Nut	1
22	2325-1	Clutch Retainer	1	F388		3/8-16 x 2-1/2 Hex Bolt	1
23	2325-4	Idler Adjustment	1	F435		1/4 x 1/4 x 1-1/4 Key	1
24	2265	Bearing (20mm)	4				
25	2406-7	Pivot Shaft Spacer	1				
26	2236-1	Idler Pulley (4.5/AAA)	2				
27	7201-7	Inner Race (2-5/8)	1				
28	7201-3	DU Bearing	2				
29	2230	Engine PTO Belt/Set (3)	1				
30	2236-4	Idler Pulley Shaft	1				
31	2325-3	Idler Adjuster	1				
32	2325-2	Tensioner Bolt	1				
33	5830-3	Grease Fitting (45 Deg.)	1				
34	2325	Idler Arm (Includes Item # 33)	1				
35	5841	Retainer Washer (3/8 x 1-1/4)	1				
36	2410	Mechanical Clutch	1				

* Service Part Only

** The Quick Coupler Installation Tool is used to assist the installation of the Quick Coupler Tube and PTO Shaft connection by holding the disconnect ring in the retracted position when joined to the tractor spline shaft on the PTO Drive Shaft.


ENGINE GROUP

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Fuel Tank Assembly				Choke and Throttle Assemblies			
1	8046-9	Fuel Tank, 5.0 Gallon, Gas (Includes Item # 3)	2	34	2109-4	Control Cable (65-1/4")	1
2	5082-2	Fuel Cap Seal	2	35	2108-4	Control Cable (71")	1
3	5082	Fuel Tank Cap (Includes Item # 2)	2	36	8123	Insulating Sleeve (3/8 x 6)	1
4	5083-5	Tank Tube Elbow	2	37	5975-3	Cable Tie (50# x 7")	2
5	5083-1	Bushing, Rubber (Fits 5083)	2	38	5108-6	Choke Control Knob, Black	1
6	5086-7	Hose (3/8 x 6)	2	39	5108-5	Throttle Control Knob, Red	1
7	5020-2	Fuel Filter, In Tank	2	40	5108-1	Control Lever, Throttle / Choke	2
8	5879-3	Hose Clamp (1/2)	7	41	7108	Control Assembly (Includes Items # 40, 42-44 & F201)	2
9	5086-10	Hose (1/4 x 9)	1		2108-3	Throttle Control and Cable Assembly (Includes Items # 39, 40, 42-45, F002, F005, F050, F164 & F201)	*
10	2010-3	Fuel Valve	1		2109-3	Choke Control and Cable Assembly (Includes Items # 38, 40, 42-45, F002, F005, F050, F164 & F201)	*
11	2010-2	Fuel Transfer Mount	1	42	5108-8	Control Bracket	2
12	NS	Kohler Hose	*	43	5108-10	Friction Washer (.125)	2
13	5020	Fuel Filter	1	44	5108-7	Control Lock Tab	2
14	5086-11	Hose (1/4 x 12)	1	45	5172	Bearing, Nylon (.255 ID x .379 OD x .250)	1
15	5086-12	Hose (1/4 x 46)	1				
16	7833-2	Cable Clamp (1 x 1/4)	2				
Engine Assembly				Fasteners			
17	NS	27 HP Engine (Kohler)	*				
18	NS	Muffler	*	F002	10-24 Keps Nut		12
19	2104	Body Support	1	F004	1/4-20 Keps Nut		2
20	4845	Rubber Bumper (1.0 x .625)	2	F005	1/4-20 ESNA Nut		2
21	NS	Kohler Nut	*	F009	5/16-18 Whiz Locknut		8
22	2013-4	Shield Side	2	F025	10-24 x 3/8 PPHMS		8
23	2013-3	Muffler Heat Shield	1	F026	10-24 x 1/2 PPHMS		2
Precleaner Assembly				F031	1/4-20 x 5/8 Hex Bolt		2
24	7840	Hose Clamp (1-5/16 to 2-1/4)	2	F034	5/16-18 x 3/4 Hex Bolt		6
25	2012	Flex Hose (1-3/4 x 2)	1	F050	1/4 SAE Washer		3
26	2088-10	Air Cleaner Assembly (Includes Items # 27-32)	*	F164	10-24 x 1/4 x 3/8 SHL Bolt		1
27	5091-11	Air Flow Indicator & Nipple	1	F175	1/2 Split Lock Washer		4
28	2088-1	Air Cleaner Band	1	F184	1/4-20 x 1/2 Hex Bolt, SS		4
29	2090-3	Safety Filter Insert	1	F185	1/4 Internal Star Lock Washer		4
30	2090-1	Air Cleaner Cartridge	1	F201	1/4 Belleville Spring Washer		4
31	2088-2	Air Cleaner Cap	1	F439	1/2-13 x 1-3/4 Hex Bolt		4
32	2090-2	Vacuator Valve	1				
33	2010	Pre Cleaner / Guard Mount	1				
				*	Service Part Only		

Use only genuine Walker® replacement parts.

Effective Date 03-31-08

ENGINE GROUP



Effective Date 03-31-08

Use only genuine Walker® replacement parts.

HYDROSTATIC GROUND DRIVE ASSEMBLIES

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Parking Brake Assembly				40	2024-5	Oil Expansion Reservoir	2
1	2358-6	5/16-18 x 1-3/4 Stud	2	41	2024-7	Oil Reservoir Mount, LH	1
2	2300-2	Parking Brake Hydro Mount, RH	1	42	2024-6	90° Degree Fitting	2
3	5103-2	Pivot Bushing (5/16 ID)	2	43	5879-3	Hose Clamp (1/2)	2
4	2406-3	Parking Brake Actuator Tube	1	44	2024-3	Reservoir Hose	2
5	5222	Extension Spring (1/2 x 3-1/4)	1	45	5879-6	Hose Clamp (3/4)	2
6	2280	Clevis (3/8)	1	46	9430-1	Spacer Tube (9/16 x 5/8 x 5/16)	4
7	2406-4	Clevis Pin (5/16 x 1-1/8)	1	47	2024-8	Oil Reservoir Mount, RH	1
8	4407-4	Bow Tie Cotter Pin	5	48	2300-5	Spring Mount Plate	1
9	2406-1	Brake Actuator Pull	1	49	NS	Hydro-Gear W/Charge Pump, RH	1
10	8655-4	Clevis Pin (5/16 x 3/4)	1	Wheel Assembly			
11	5830-4	Grease Fitting (90 Deg.)	1	50	2070	Wheel & Tire (22 x 10.50-12)	2
12	2850	Handle Grip, Red	1	Fasteners			
13	2406-8	Parking Brake Lever Idler Mount (Includes Items # 11 & 12)	1	F003		1/4-28 Hex Nut	2
14	2406-5	Parking Brake Stop	1	F004		1/4-20 Keps Nut	12
15	2300-1	Parking Brake Hydro Mount, LH	1	F009		5/16-18 Whiz Locknut	17
16	5281-5	Clevis Pin (1/4 x 0.80)	2	F010		5/16-24 ESNA Nut	4
17	5280	Clevis (1/4)	2	F012		3/8-16 Keps Nut	1
18	2406-2	Parking Brake Rod	2	F013		3/8-16 Whiz Locknut	4
19	5665-1	Compression Spring (2-1/2)	2	F014		3/8-16 ESNA Nut	8
20	5463	Steering Lever Actuator	2	F015		1/2-20 Wheel Lug Nut	8
Ground Drive Assemblies				F031		1/4-20 x 5/8 Hex Bolt	8
21	2248	Ground Drive Belt	1	F034		5/16-18 x 3/4 Hex Bolt	4
22	2028-4	Hydro Lockout Rod, RH	1	F035		5/16-18 x 1-1/4 Hex Bolt	1
23	2240-2	Drive Pulley (Includes Item # F171)	1	F040		3/8-16 x 1-1/2 Hex Bolt	1
24	5267	Retainer Collar (3/4)	2	F043		3/8-16 x 3 Hex Bolt	1
25	4349-6	Flanged Bearing (1")	2	F051		3/8 SAE Washer	1
26	2350-13	3/18-16 x 1-3/4 Bolt Grade 5	8	F054		AN960616 Washer	10
27	2350-1	Hub, Coupler End	4	F169		5/16-18 x 1 Carriage Bolt	2
28	6325-2	Spacer Bushing (5/16)	16	F171		5/16-18 x 3/8 Set Screw	6
29	2350-9	Flex Plate	8	F173		5/16-18 x 3/4 Carriage Bolt	2
30	2350-12	Coupling Shaft	1	F182		1/4 x 5/8 x 1/8 Washer	4
31	5221	Extension Spring (3/4 x 4)	1	F183		.312 x .700 x .074 Washer	1
32	4245	Idler Pulley (3/A)	1	F211		1/4-20 x 7/8 Hex Bolt	1
33	5841	Retainer Washer (3/8 x 1-1/4)	1	F231		1/4 x 3/4 Woodruff Key (#806)	1
34	2349-1	Hydro Idler Arm (Includes Item # 35)	1	F336		3/8-16 Jam Nut	1
35	5830-3	Grease Fitting (45 Deg.)	1	F388		3/8-16 x 2-1/2 Hex Bolt	4
36	7201-5	Inner Race (2-1/4)	1	F434		5/16-18 x 3-1/2 Hex Bolt	4
37	7201-3	DU Bearing	2				
38	2028-3	Hydro Lockout Rod, LH	1				
39	NS	Hydro-Gear W/Charge Pump, LH	1				

Use only genuine Walker® replacement parts.

Effective Date 03-31-08










STEERING CONTROL ASSEMBLIES

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Steering Lever & FSC Assemblies				Transmission Spring Assemblies			
1	5862	FSC Knob	1	36	4199	Transmission Spring Assembly (Includes Items # 37-43, F004, F032, F320 & F352)	*
2	4170	FSC Lever Assembly (Includes Item # 4)	*	37	4552	Ball Joint (1/4-28)	2
3	2170-1	Step Washer	1	38	5194	Plunger Sleeve	2
4	5830	Grease Fitting	1	39	5192-2	Spring Plunger (Female)	2
5	5214-5	Ball Joint (5/16-24/LH) W/O Stud	1	40	5193	Washer (3/4 x 1 x .085)	2
6	4213	Hydro-Gear Control Rod	1	41	6191	Spring Slide (4-3/4)	2
7	5214-4	Ball Joint (5/16-24) W/O Stud	1	42	5195	Compress Spring (1 x 5-1/8)	2
8	5214-3	Ball Joint (5/16-24 LH) (Nylon Lined)	2	43	6196	Spring Slide Cap	2
9	4173	FSC Rod	2	Fasteners			
10	2212	Transmission Control Arm Stop	2		F003	1/4-28 Hex Nut	2
11	2212-2	Transmission Control Arm, RH	1		F004	1/4-20 Keps Nut	6
12	2025-10	TWHCS 5/16-24 x 1.0 (Patch)	2		F005	1/4-20 ESNA Nut	2
13	5214-2	Ball Joint (5/16-24) (Nylon Lined)	2		F008	5/16-24 Keps Nut	4
14	2212-1	Transmission Control Arm, LH	1		F009	5/16-18 Whiz Locknut	6
15	2451-1	Steering Pivot Shaft With Stop	1		F024	5/16-24 Jam Nut	3
16	5830-3	Grease Fitting (45 Degree)	1		F032	1/4-20 x 3/4 Hex Bolt	2
17	8201-3	Fiberglide Bearing	4		F035	5/16-18 x 1-1/4 Hex Bolt	1
18	2451-3	Speed Control Actuator, LH (Includes Items # 16 & 17)	1		F059	3/8 Wave Spring Washer	1
19	5146	10mm Ball Stud	4		F093	5/16-18 x 1 Hex Bolt	2
20	2215-1	Steering Lever Dampener	2		F121	5/16-18 x 3/8 x 1 SHL Bolt	1
21	2451-2	Speed Control Actuator, RH (Includes Items # 17 & 22)	1		F146	1/4-20 Jam Nut	2
22	5830-4	Grease Fitting (90 Deg.)	1		F167	5/16-18 Hex Nut	1
23	4451-4	FSC Friction Actuator	1		F183	.312 x .700 x .074 Washer	2
24	4219	Extension Spring (3/4 x 6-1/2)	1		F188	1/4-20 Self-Locking Nut	4
25	5850-2	Handle Grip, Foam (5-1/2)	2		F192	3/8-24 Self-Locking Nut	1
26	5453-20	Steering Lever Handle (+1") Adjustable / SS (Includes Items # 25, F188, F198 & F345)	2		F198	.250 x .625 x .040 Washer, SS	2
27	4452-4	Steering Lever Tube W/Tab	2		F209	.765 ID x 1.312 OD x .032 Washer	2
28	5450	D-Clip	2		F211	1/4-20 x 7/8 Hex Bolt	1
29	5222	Extension Spring (1/2 x 3-1/4)	2		F320	1/8 x 3/4 Split Spring Pin	2
30	4452-6	Steering Pivot (1/4-20 x 1-1/2)	2		F345	1/4-20 x .770 Knurled Bolt	4
31	4142-1	FSC Cam	1		F352	5/32 x 1 Heavy Duty Roll Pin	2
32	5141	FSC Friction Washer (1-1/2 x 3/8 x 1/16)	1		F373	5/16-24 Hex Nut/LH	3
33	4142-2	FSC Friction Washer (1-1/2 x 1-1/32 x 1/16)	1		F385	1/4 x 1-1/4 Roll Pin	1
34	9704-3	Pivot Rod Bushing, Plastic	2		F386	5/16-18 x 1-1/2 x 3/8 Shoulder Bolt	1
35	2451-4	Steering Shaft Spacer	1		F391	1/4-20 x 1/2 Set Screw, SS	2
					F407	Belleville Washer 3/8 x 1.187, SS	1
					F427	5/16-18 Flange Nut	1
				* Service Part Only			

ELECTRICAL ASSEMBLY

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Electrical Assembly				21	5932	Battery Terminal Insl., Blk (-)	1
1	8960-15	Ignition Switch W/Keys (Includes Items # 2, 3 & F349)	1	22	5933	Battery Terminal Insl., Red (+)	1
2	7854	Plastic Tip, Red	1	23	5844	Battery Hold-Down Bar	1
3	8960-3	Key Set W/Umbrella	1	24	2910-1	Battery Shield	1
4	7941-3	Boot, Circuit Breaker	1	25	5839	Hook Bolt	2
5	7941-6	Circuit Breaker (15 Amp)	1	26	7938	Lead Wire, Battery Charge (Alternator to Starter)	1
6	8990-1	Hourmeter (Sendec)	1	27	8941	Circuit Breaker (30 Amp) (Auto Reset/Sealed)	1
7	8996-2	Red Indicator Light Assembly (Includes Items # 8 & 9)	2	28	5833	Cable Clamp (1/4)	1
8	8996-4	Red Indicator Lens	2	29	2940-1	Wire Harness	1
9	8996-3	Indicator Bulb (Replacement for P/N 8996-2)	*	30	5942-4	PTO Safety Switch (NO)	1
10	8536-2	Warning Horn Assembly	1	31	6941-6	Relay Switch 30/40AMP (NC)	*
11	6105-3	Harness Clip	3	32	6941-7	Relay Mount	*
12	6942	Relay Switch 30/40 Amp (NC) (Includes Items # 31 & 32)	3	Fasteners			
13	7948-1	Time Delay Module (Less Harness)	1	F002	10-24 Keps Nut		15
14	7948-5	Time Delay Harness	1	F004	1/4-20 Keps Nut		3
15	7833-2	Cable Clamp (1 x 1/4)	2	F019	1/4-20 ESNA Wing Nut		2
16	2941-5	Safety Switch (NO)	1	F025	10-24 x 3/8 PPHMS		3
17	7203-6	Riser Plate, Seat Switch	1	F026	10-24 x 1/2 PPHMS		10
18	2940-3	Battery Cable (14")	2	F031	1/4-20 x 5/8 Hex Bolt		3
19	7910	Battery (12V/340CCA/Dry)	1	F050	1/4 SAE Washer		4
20	5975-1	Cable Tie (18# x 3-3/4")	2	F349	Washer .835 ID 1.122 OD, SS		1
				* Service Part Only			

ELECTRICAL ASSEMBLY



Effective Date 03-31-08

Use only genuine Walker® replacement parts.

60 INCH COMPLETE CARRIER FRAME ASSEMBLY (P/N 2911)

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Spring and Pivot Mount Components				36	2214-10	Rod End, Female (3/8-24)	4
1	2744-1	Spring Clip Bracket	1	37	2722-3	Pivot Shaft	2
2	5975-3	Cable Tie (50# x 7")	2	38	2655	Lift Chain	4
3	5743-1	Spring Cover	2	39	4407-4	Bow Tie Cotter Pin	2
4	5743-6	Extension Spring (1-1/2 x 7-3/4) (Includes Items # 2, F117 & F166)	2	40	2215-4	Height Adjustment Rod	2
5	5743-4	Eye Bolt (3/8-16 x 2-3/4)	2	41	5146	10mm Ball Stud	4
6	2723	Counter Weight Spring Mount	2	42	2215	Gas Spring Assembly	2
7	2723-5	Locking Arm, LH (Includes Item # F432)	1	43	2721	Lifting Arm (Includes Item # 8)	1
8	5830	Grease Fitting	10	44	2721-2	Lifting Cross Tube	1
9	2667-1	Pivot Mount, LH (Includes Item # 8)	1	45	2723-3	Height Adjustment Arm (Includes Item # 46)	1
10	2723-4	Pivot Shaft	2	46	5850-3	Handle Grip, Foam (3-1/4)	1
11	2667-2	Pivot Mount, RH (Includes Item # 8)	1	47	2722-2	Deck Height Adjustment Trigger (Includes Item # 8)	1
12	2723-6	Locking Arm, RH (Includes Item # F432)	1	Fasteners			
Carrier Frame Components					F004	1/4-20 Keps Nut	6
13	2215-2	Gas Spring Cover, RH	1	F009	5/16-18 Whiz Locknut	12	
14	2723-2	Outer Height Adjustment Plate	1	F013	3/8-16 Whiz Locknut	14	
15	7775-5	Lock Pin (5/16)	2	F014	3/8-16 ESNA Nut	2	
16	2720-3	Height Adjustment Spacer	4	F035	5/16-18 x 1-1/4 Hex Bolt	2	
17	2723-1	Inner Height Adjustment Plate	1	F038	3/8-16 x 1 Hex Bolt	2	
18	2215-3	Gas Spring Cover, LH	1	F039	3/8-16 x 1-1/4 Hex Bolt	2	
19	8740	Deck Pin Bushing (3/4 ID)	4	F040	3/8-16 x 1-1/2 Hex Bolt	5	
20	2911-2	60SD Carrier Frame	1	F048	1/2 SAE Washer	2	
21	8811-25	Tilt Bar W/Grip (35") (Includes Item # 22)	1	F050	1/4 SAE Washer	6	
22	5850-5	Handle Grip (1 x 1 x 3-3/4)	1	F071	3/4 External Snap Ring	2	
Caster Wheel Components					F090	1/4-20 x 2-1/2 Hex Bolt	4
23	8769-8	Dust Cap, Deck Caster	2	F117	Retainer Ring	2	
24	8769-6	Bearing Cone (1" ID)	4	F132	1/4-20 x 2-3/4 Hex Bolt	2	
25	8769-5	Bearing Cup (2 x 1-5/8)	4	F166	Retainer Ring	2	
26	8769-7	Seal	2	F205	5/16-18 x 1/4 Set Screw (Knurl Point)	2	
27	2770	Caster Wheel Fork	2	F215	3/8-16 x 1/2 x 1/2 S Bolt	2	
28	7038	Tail Wheel Axle (3/4 x 5-9/16)	2	F218	7/16 Split Lock Washer	4	
29	8037-1	Seal, Outer (1-3/4 x 1-1/8)	2	F219	7/16-14 x 1-1/4 Hex Bolt	4	
30	8037	Bearing Cone (3/4 ID)	4	F226	5/16-18 x 7/8 Hex Bolt	4	
31	8035	Tail Wheel & Tire (13 x 5.00-6) (W/Bearing Race)	2	F241	.375 x .875 x .10 Washer	18	
32	8768-2	Seal, Reverse Lip	2	F263	1-1/4 External Snap Ring	6	
33	8038-1	Spacer, Tail Wheel Axle (.750 x ID x 1.125 OD)	2	F268	5/16-18 x 3 Hex Bolt	1	
34	8039	Nut, Tail Wheel Axle	2	F298	3/8-24 Jam Nut	4	
Deck Lift Components					F344	3/4-16 Slotted Hex Nut	2
35	2722-1	Deck Height Adjustment, LH (Includes Item # 8)	1	F347	3/4 SAE Washer	2	
				F348	1/8 x 1-1/2 Cotter Pin	2	
				F378	3/8-16 x 6 Hex Bolt	1	
				F432	3/16 x 1/2 Split Spring Pin	2	
				F436	3/16 x 1-1/8 Spring Pin	4	
				F437	Clevis Pin (1/4 x 1)	2	
				F438	5/16-18 x 2-3/4 Hex Bolt	1	

Use only genuine Walker® replacement parts.

Effective Date 03-31-08


DSD60 DECK ASSEMBLY (P/N 2910)

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Deck Housing Components				46	7201-5	Inner Race (2-1/4)	1
1	2110	Hood Latch Assembly	2	47	2724-4	5/16 x 3/8 SHL Bolt	1
2	2786-4	Locking Finger	2	48	2350-4	Washer (1/2 OD x 5/16 ID x .030)	1
3	2786-1	Footrest, DSD60 (Includes Items # 4 & 5)	1	49	2725-3	Cam Tensioner	1
4	2786-3	Rubber Mat (2 x 7)	2	50	6235	Spring, Belt Tension Cam	1
5	2786-2	Rubber Mat (7 x 9-1/2)	2	51	2350-2	Idler Cam Spring Washer (Includes Item # 52)	1
6	4845	Rubber Bumper (1.0 x .625)	4	52	2350-3	Idler Cam Washer (2" OD)	1
7	2703-5	Knob, 10-24 x 1/2	4	53	2221	Extension Spring (1 x 4)	1
8	2724-1	Spindle Cover	2	54	2724-3	Idler Arm (Includes Item # 44)	1
9	2731-1	Belt Guide Roller	1	Blade Spindle Components			
10	5162-11	Roller Wheel (5") (Includes Item # F059)	2	55	2052	Blade Spindle	3
11	8490	Roller Wheel Axle Bolt	2	56	7705-11	Blade 20.5" (RH Rotation)	3
12	NS	Deck Serial Number Plate	1	Fasteners			
13	8735-10	Rubber Mat (5 x 6)	2	F002	10-24 Keps Nut		12
14	2910	60SD Deck Assembly / Tilt	1	F004	1/4-20 Keps Nut		8
15	2720-5	Deck Height Adjustment Clevis	2	F005	1/4-20 ESNA Nut		8
16	6682-13	Axle Spacer	4	F009	5/16-18 Whiz Locknut		14
17	6715	Roller Wheel (3-7/8)	4	F012	3/8-16 Keps Nut		2
18	2725-5	Tensioner Mate	1	F013	3/8-16 Whiz Locknut		24
19	8910-5	Tie Down Strap	2	F014	3/8-16 ESNA Nut		2
20	2705-4	End Backup Plate	2	F025	10-24 x 3/8 PPHMS		10
21	2705-3	Center Backup Plate	1	F028	10-24 x 3/4 PPHMS		2
22	2809-1	Rubber Shield	1	F029	1/4-20 x 1/2 Hex Bolt		4
23	2705-6	Chute Frame / Outer	1	F031	1/4-20 x 5/8 Hex Bolt		4
24	8670	Tilt-Up Hook	1	F033	1/4-20 x 1 PTH Bolt		8
Blade Drive Components				F034	5/16-18 x 3/4 Hex Bolt		6
25	2618-1	Cover, PTO Shaft Guard	1	F039	3/8-16 x 1-1/4 Hex Bolt		18
26	2620-3	Rubber Flap	1	F041	3/8-16 x 1-3/4 Hex Bolt		3
27	2620-2	Backing Plate	1	F043	3/8-16 x 3 Hex Bolt		1
28	2619-1	PTO Shaft Guard	1	F045	3/16 x 3/16 x 3/4 Key		3
	2618-2	PTO Shaft Guard Assembly (Includes Items # 25-28, F002, F025 & F028)	*	F048	1/2 SAE Washer		3
29	5270	Bearing W/Collar (1")	2	F049	5/16 SAE Washer		2
30	2726	PTO Bearing Housing	1	F050	1/4 SAE Washer		3
31	2726-1	PTO Drive Shaft	1	F051	3/8 SAE Washer		2
32	2240-1	Drive Pulley (Includes Items # F075 & F435)	1	F055	5/8 SAE Washer		3
33	2265	Bearing (20mm)	1	F059	3/8 Wave Spring Washer		4
34	2245-4	Idler Pulley Shaft	1	F067	3/16 x 3/16 x 1 Key		1
35	2725-1	Tilted Idler Mount	1	F075	5/16-18 x 1/2 SQH Set Screw		2
36	8285-15	U-Joint Shaft Assembly, Spline (Includes Item # F318)	1	F108	3/8-16 x 2 Hex Bolt		1
37	4245-1	Idler Pulley (4/Flat)	1	F131	5/16-18 x 1/2 Hex Bolt		2
38	2240	Blade Drive Pulley (3-1/2)	3	F206	#2 x 3/16 Drive Pin		2
39	8245	Idler Pulley (6")	2	F236	1/4-20 x 1-3/4 Hex Bolt		1
40	2350-5	Washer (3/8-16 Tap 1/4 Thk)	2	F241	.375 x .875 x .10 Washer		2
41	2731	Blade Drive Belt (R3VX1250)	1	F265	1/2-20 x 1-1/2 Hex Bolt		3
42	5841	Retainer Washer (3/8 x 1-1/4)	1	F268	5/16-18 x 3 Hex Bolt		4
43	2245-1	Idler Pulley	1	F276	5/8-11 Jam Nut		3
	2245	Idler Pulley Assembly (Includes Items # 33, 34, 43 & F445)	*	F318	3/8-16 x 3/4 SQH Set Screw		1
44	5830	Grease Fitting	1	F405	3/8-16 x 1-1/2 FHA Screw SS		2
45	7201-3	DU Bearing	2	F408	7/16-20 Jam Nut		2
				F435	1/4 x 1/4 x 1-1/4 Key		1
				F445	1-7/8 Internal Snap Ring		1
				* Service Part Only			

Use only genuine Walker® replacement parts.

Effective Date 03-31-08

DSD60 DECK ASSEMBLY (P/N 2910)




Effective Date 03-31-08


MULCH KIT

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Mulch Kit				Fasteners			
1	2691-4	Baffle, RH	1	F004		1/4-20 Keps Nut	16
2	2691-2	Vee, RH	1	F029		1/4-20 x 1/2 Hex Bolt	16
3	2691-5	Center Skirt	1				
4	2691-1	Vee, LH	1				
5	2691-3	Skirt, LH	1				

MULCH KIT



WIRING SCHEMATIC



LIMITED WARRANTY FOR WALKER MODEL MBSSD RIDER MOWER

1. WHAT THIS WARRANTY COVERS, AND FOR HOW LONG:

Walker Manufacturing company will, at its option, repair or replace, without charge, any part covered by this warranty which is found to be defective in material and/or workmanship within one (1) year after date of sale to the original retail purchaser unless the product is used for rental purposes, in which case this warranty is limited to ninety (90) days. At Walker's request, customer will make the defective part available for inspection by Walker and/or return the defective part to Walker, transportation charges prepaid. All parts and components of the Walker Mower are covered by this warranty **except** the following components which are warranted separately by their respective manufacturers:

Kohler Engine
Hydro-Gear Transaxles
Battery
Tires

The available warranties covering these items are furnished with each mower. Walker does not assume any warranty obligation, liability or modification for these items, which are covered exclusively by the stated warranty of the respective manufacturers noted above.

2. WHAT THIS WARRANTY DOES NOT COVER:

- A. This warranty does not cover defects caused by depreciation or damage caused by normal wear, accidents, improper maintenance, improper use or abuse of the product, alterations, or failure to follow the instructions contained in the Owner's Manual for operation and maintenance.
- B. The customer shall pay any charges for making service calls and/or for transporting the mower to and from the place where the inspection and/or warranty work is performed.

3. HOW TO OBTAIN SERVICE UNDER THIS WARRANTY:

Warranty service can be arranged by contacting the dealer where you purchased the mower or by contacting Walker Manufacturing Company, 5925 East Harmony Road, Ft. Collins, CO 80528. Proof of the date of purchase may be required to verify warranty coverage.

4. WARRANTY LIMITATION:

- A. **THERE IS NO OTHER EXPRESS WARRANTY. ANY WARRANTY THAT MAY BE IMPLIED FROM THIS PURCHASE INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE IS HEREBY LIMITED TO THE DURATION OF THIS WARRANTY AND TO THE EXTENT PERMITTED BY LAW ANY AND ALL IMPLIED WARRANTIES ARE EXCLUDED.** Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.
- B. **WALKER WILL NOT BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, OR SPECIAL DAMAGES AND/OR EXPENSES IN CONNECTION WITH THE PURCHASE OR USE OF THE MOWER.** Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation(s) or exclusion(s) may not apply to you.
- C. Only the warranty expressed in this limited warranty shall apply and no dealer, distributor, or individual is authorized to amend, modify, or extend this warranty in any way. Accordingly, additional statements such as dealer advertising or presentations, whether oral or written, do not constitute warranties by Walker, and should not be relied upon.
- D. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Sound - Model MBS

Sound Test

**Lwa
100**

Sound test conducted was in accordance with 2000/14/EC and was performed on 6 July 07 under the conditions listed:

General Condition: Clear

Temperature: 90 (F)^o 32 (C)^o

Wind Speed: < 5 mph (< 8 kmh)

Humidity: 20%

Barometric Pressure: 83.8 kPA

Vibration - Model MBS

Vibration Level

0.2g

Vibration levels at the operators handles were measured in the vertical, lateral, and longitudinal directions using calibrated vibration test equipment.

Tests were performed on 6 July 07 under the conditions listed:

General Condition: Clear

Temperature: 90 (F)^o 32 (C)^o

Wind Speed: < 5 mph (< 8 kmh)

Humidity: 20%

Barometric Pressure: 83.8 kPA

WALKER MOWERS™

WALKER MFG. CO. • 5925 E. HARMONY ROAD, FORT COLLINS, CO 80528 • (970) 221-5614
FORM NO. 033108 PRINTED IN USA www.walkermowers.com ©2008 WALKER MFG. CO