



## INDEX

---

### A

access control **1-2**  
access levels **3-2**  
ACT LED **2-2, 2-3**  
Add ISDN Information Elements dialog box **3-51, 3-53, 3-56**  
Add peer dialog box **3-18**  
address information **3-7**  
Addressing tab **3-6, 3-7**  
Add User dialog box **3-2**  
administrator access level **3-2**  
Administrator interface **2-27**  
advanced commands **3-40 to 3-41**  
Advanced Commands dialog box **3-41**  
Advanced dialog box **3-44, 3-47, 3-48, 3-49, 3-50**  
advanced settings **3-33**  
AES See encryption  
alert indications **3-26**  
ALRM LED **2-2, 2-3**  
audio codecs **1-4, 3-21**  
    enable **3-23**  
audio messages available **6-2**  
Audio Message Utility procedures  
    exit **6-5**  
    install and launch utility **6-2**  
    play message **6-3**  
    record message **6-3**  
    replace message **6-4**  
    upload message **6-4**  
    use Express Setup **6-6**  
    view message details **6-5**  
audio transcoding **1-4, 3-13, 3-21, 3-23, 3-31, 3-61**

auto-boot **2-10**  
auto dial **3-34**  
autoswitching power supply **2-26**

---

### B

bandwidth **3-31, 3-42, 3-49, 3-60**  
call overhead **1-13**  
resource allocation **1-14**  
    supported **1-4**  
basic settings **3-15**  
Basics tab **3-3, 3-4, 3-5, 3-6**  
board basic settings **3-6**  
bonding  
    calls **1-6**  
    synchronization **3-44**  
boot configuration menu **2-10**

---

### C

cables  
    DCE **2-15**  
    DTE **2-15**  
    EIA449/RS366-DCE **2-20**  
    EIA449/RS366-DTE **2-17**  
    EIA530/RS366-DCE **2-21**  
    EIA530/RS366-DTE **2-17**  
    EIA530/RS366-DTE-LOS **2-18**  
    EIA530A/RS366-DTE **2-18**  
    KIV7/RS366-DTE **2-19**  
    V.35/RS366-DCE **2-20**  
    V.35/RS366-DTE **2-16**  
    call bandwidth overhead **1-13**

- call bearer rate **3-33**  
 call details **3-61 to 3-62**  
 call handling  
   capabilities **1-5**  
   PRI gateway capacity **1-13**  
 Calls tab **3-60, 3-62**  
 CD LED **2-2**  
 Change Time dialog box **3-5**  
 Choose file dialog box **3-64**  
 conceal caller ID **1-3, 3-33, 3-34**  
 configuration procedures  
   add interface users **3-2**  
   add service **3-43**  
   change address settings **3-7**  
   change Administrator interface web server port **3-8**  
   configure advanced commands **3-41**  
   configure advanced settings **3-33**  
   configure basic port settings **3-45**  
   configure basic settings **3-15**  
   configure bonding synchronization **3-44**  
   configure downspeeding **3-24**  
   configure DTMF settings **3-39**  
   configure encoding and decoding protocols **3-23**  
   configure encryption settings **3-32**  
   configure fractional channels **3-47**  
   configure framing **3-47**  
   configure incoming call routing methods **3-58**  
   configure IVR **3-20**  
   configure line coding **3-47**  
   configure NSF settings **3-57**  
   configure outgoing call delimiters **3-21**  
   configure peer- to-peer connectivity **3-17**  
   configure port call policies **3-58**  
   configure port physical line properties **3-46**  
   configure port supported services **3-59**  
   configure QoS settings **3-26**  
   configure security **3-8**  
   configure signaling type **3-47**  
   delete interface users **3-3**  
   delete ISDN information elements **3-58**  
   delete services **3-44**  
   detect DTMF **3-39**  
   disconnect calls **3-62**  
   edit interface users **3-2**  
   edit service **3-43**  
   import configuration files **3-64**  
   refresh call information **3-60**  
   refresh information **3-14**  
   refresh System section **3-11**  
   register with gatekeeper **3-15**  
   reserve resources **3-31**  
   restore board basic settings **3-6**  
   save configuration settings **3-64**  
   select events for SNMP traps **3-26**  
   set chassis temperature **3-10**  
   set location **3-6**  
   set time and date **3-5**  
   update license **3-4**
- connectors  
   Ethernet **2-2**  
   PORT **2-3**  
   PRI line **2-3**  
   serial **2-2**
- 
- D**
- data collaboration **1-2, 3-22, 3-30**  
 enable T.120 **3-23**  
 DB-60 **2-3, 3-48**  
 DB-9 **1-6, 2-2**  
 DCE **3-48**  
 D-Ch LED **2-3**  
 decoding **3-23**  
 default bit rate **3-34**  
 default extension **1-2, 3-59, 4-5**  
 default services **3-42**  
 delimiters  
   outgoing calls **3-21**

second number **3-21, 4-2**

DES See encryption

Details dialog box **3-13**

diagnostics **1-2**

dialing

indirectly through an operator **4-6**

into IP **4-3**

out from IP **4-1**

through IVR **4-6**

dialing examples **4-1 to 4-6**

dial plan **1-2**

DID **1-2, 3-35, 3-59, 4-4**

direct dialing **1-2**

Discovered Gatekeepers dialog box **3-16**

downspeeding **1-3, 3-23, 3-28, 3-40**

DTE **3-48**

DTMF **1-3, 3-28, 3-29, 3-37**

convert signals **3-38**

detection **3-38**

tone assignments **3-37**

dual video **1-3, 3-36, 3-61, 3-62**

## E

E1/T1 **1-9, 1-14, 3-46, 3-47**

Edit ISDN Information Elements dialog box **3-51, 3-56**

Edit peer dialog box **3-18**

Edit User dialog box **3-2**

EIA-530 **2-15**

EIA-530/EIA-530A **3-48**

encoding **3-23**

encryption **3-31**

H.235 **1-3, 3-32**

interoperability **1-6**

serial gateway **1-11**

via satellite **1-11**

Ethernet

10/100Base-T **1-6**

connector **2-2**

Ethernet LED **2-2**

Event Log tab **3-62**

Express Setup **6-5**

external program access **3-8**

## F

fast start **1-3, 3-35**

feature summary

general features **1-2**

FECC **3-23**

File Download dialog box **3-64**

first-time installation **2-27**

fractional channels **3-47**

Fractional dialog box **3-47**

framing **3-47**

front panel **2-2**

FTP **3-8**

## G

gatekeeper

registering **3-15**

GK LED **2-2**

## H

H.239 **1-3, 3-36**

H.243 **1-3**

H.323

call disconnect reason **3-19, 3-41**

fast start **1-3, 3-35**

version 1 **3-16**

version 2 or later **3-16**

hot swap **1-3**

**I**

---

ICMP **3-8**  
importing files **3-64**  
incoming call routing methods **3-58, 4-3**  
initial configuration **2-10**  
installation procedures  
    access Administrator interface **2-27**  
    change default password **2-13**  
    connect a serial cable **2-15**  
    connect gateway to LAN **2-14**  
    connect to a PC **2-11**  
    connect to power supply **2-26**  
    insert gateway in chassis **2-8**  
    insert RTM in chassis **2-7**  
    install online help files **2-26**  
    mount chassis on a 19-inch rack **2-5**  
    register online help **2-28**  
    set IP address **2-12**  
installation requirements **2-4**  
interoperability **1-2**  
IP address assign **2-11**  
IP network connection **1-4, 1-6**  
ISDN  
    connection failure **1-3**  
    rollover **1-3**  
IVR **1-2, 3-20, 3-35**  
    corrupt files **3-28, 3-29**  
    internal capacity **1-6**  
    operator **4-5**  
    routing **3-59, 4-5**

---

**L**

LAN **2-14**  
    10/100Base-T **1-6**  
leased lines  
    serial gateway **1-12**  
LED indicators **2-2, 2-3**

troubleshooting **5-2**  
LED Monitoring tab **3-3**  
license  
    update **3-4**  
Licensing and Registration dialog box **3-4**  
line coding **3-47**  
line quality **1-6**  
location **3-6**

---

**M**

maintenance mode **3-63**  
Maintenance tab **3-63**  
MCU **1-12, 3-36**  
media + signaling combinations **1-6**  
media protocols **1-6**  
MSN **1-2, 4-4**  
multimedia conferencing **1-7**  
multipoint conferencing **1-8**

---

**N**

Netscape Navigator **2-28**  
network jitter tolerance field **3-35**  
network load balancing **1-2**  
Network Specific Facility (NSF) **1-3, 3-57**  
NSF Configuration dialog box **3-52, 3-57**

---

**O**

online help **2-26, 2-28**  
operator access level **3-2**

---

**P**

package contents **2-4**  
password  
    default login user **2-13**

- peer-to-peer  
 connectivity **1-4, 1-14, 3-15, 3-17**  
 disconnect **3-19, 3-41**  
 hunting module **3-19**  
 peer hunting mode **3-17**
- physical description  
 DCE cable **2-19**  
 gateway module **2-2**  
 Rear Transition Module (RTM) **2-3**
- pin layout  
 DB-25 **2-24, 2-25**  
 DB-37 **2-23**  
 M-34 **2-22**  
 serial gateway cable connectors **2-22**  
 serial gateway signaling cable connector **2-25**
- pin-out configuration  
 serial gateway data interface cable **2-21**  
 serial gateway signaling interface cable **2-24**
- point-to-point conferencing **1-8**
- PORT connectors **2-3**
- ports  
 physical line properties **3-46**  
 PRI **3-46**  
 settings **3-45**  
 supported **1-4**  
 supported services **3-59**
- Port Specific tab **3-44**
- Port tabs **3-45**
- power supply **2-26**
- presentation restriction **3-33, 3-34, 3-36**
- PRI  
 call handling capacity **1-13**  
 connecting gateway directly to central office switch **1-10**  
 connecting gateway to a PBX **1-10**  
 interface features **1-6**  
 ISDN connections **1-9**  
 ports **3-46**
- PRI LINE connector **2-3**
- PRI Port tab **3-51**
- 
- Q**
- Q.931 **1-2, 3-33, 3-34, 3-35, 3-52, 3-57**  
 Quality of Service (QoS) **1-2, 3-24**
- 
- R**
- rack mounting **2-5**  
 read-only access level **3-2**  
 Rear Transition Module (RTM) **2-3**  
 refresh **3-11, 3-14**  
 requirements **2-11**  
 installation **2-4**  
 resources **3-31**  
 RJ-45 **2-2, 2-3**  
 rollover **1-3, 3-28, 3-36**  
 routing **1-2, 3-58, 4-3**  
 RS-232  
 DTE 9-pin D-type connection **1-6**  
 RS-366 **3-48**  
 RS-449 **2-15, 3-48**  
 RST button **2-2**  
 RTM panel components **2-3**
- 
- S**
- saving configuration settings **3-64**  
 second number delimiter **3-21, 4-2**  
 security **3-8**  
 Security tab **3-8**  
 serial control port **1-6**  
 serial lines **2-15**  
 serial port connector **2-2**  
 services **3-42, 3-59**  
 default **3-42**  
 prefix **3-42, 3-59, 4-1**

user defined **3-42**  
**Services tab** **3-33, 3-42, 3-43**  
**Settings tab** **3-14, 3-15, 3-17, 3-20, 3-21, 3-22, 3-23, 3-26, 3-30, 3-32, 3-33, 3-39, 3-43, 3-44**  
 signaling protocols **1-6, 3-46, 3-48**  
 signaling type **3-47**  
**SNMP** **3-8**  
 management **1-2**  
 trap events **3-26, 3-27, 3-29**  
 trap servers **1-3**  
 trap severity enumerations **3-30**  
 software upgrade utility procedures  
   install and launch **7-1**  
   use utility **7-2**  
**Statistics tab** **3-62**  
**Status tab** **3-13, 3-14**  
 stripping **3-56**  
 sub-addressing **3-35, 4-4**  
**SWAP RDY LED** **2-2**  
 switch information **1-6**

**T**

**T.120** **3-22, 3-30**  
 data collaboration **1-2**  
 enable **3-35**  
**TCS4** **1-2, 3-21, 3-59, 4-3, 4-4**  
 temperature **3-10**  
 time and date **3-5**  
 top slot **2-6**  
 troubleshooting  
   echo cancellation **5-9**  
   Ethernet port settings **5-8**  
   Ethernet port speed **5-11**  
   factory defaults **5-8, 5-10**  
   global user name and password **5-8, 5-9**  
   IP address problems **5-1**  
   LED indication problems **5-2**  
   making calls **5-4**

networking information **5-8**  
 receiving calls **5-5**  
 remote monitoring **5-7**  
 T.120 data collaboration **5-10**  
 web server port setting **5-10**  
 troubleshooting procedures  
   access device commands through serial port **5-8**  
   assign IP address to a new gateway **5-2**  
   change global user name and password **5-9**  
   configure speed of Ethernet port **5-11**  
   configure web server port **5-10**  
   monitor gateway functions from remote site **5-7**  
   restore factory default settings **5-10**  
   set echo cancellation **5-9**  
   set T.120 data collaboration capability **5-10**  
**Type of Number (TON) fields** **3-56**  
**Type of Service (TOS)** **3-25**

**U**

upgrade software **7-1**  
 user-defined services **3-42**  
**Users tab** **3-2, 3-3**

**V**

**V.35** **2-15, 3-48**  
**Version Details dialog box** **3-5**  
 video conferencing protocols **1-4**  
 video protocols **1-4**  
   enable H.263, H.263+, H.264 **3-23**  
 video resolutions **1-4**  
 viewing  
   audio message details **6-5**  
   B channel status **3-13**  
   call details **3-60**  
   call information **3-60**  
   general information **3-3**

LED information [3-3](#)  
reported alarm events [3-62](#)  
service details [3-42](#)  
services on each port [3-59](#)  
software version details [3-5](#)  
System section [3-9](#)  
system-specific information [3-62](#)

---

## W

web-based management [1-2](#)  
web files [3-28, 3-29](#)  
web server [3-8](#)  
Web tab [2-28, 3-8](#)

