

# 2 In 4 Out DVI Matrix Switch

## User's Guide



Models

SW-DVI-2X4



© 2008 **Avenview Inc.** All rights reserved.

The contents of this document are provided in connection with Avenview Inc. ("Avenview") products. Avenview makes no representations or warranties with respect to the accuracy or completeness of the contents of this publication and reserves the right to make changes to specifications and product descriptions at any time without notice. No license, whether express, implied, or otherwise, to any intellectual property rights is granted by this publication. Except as set forth in Avenview Standard Terms and Conditions of Sale, Avenview assumes no liability whatsoever, and disclaims any express or implied warranty, relating to its products including, but not limited to, the implied warranty of merchantability, fitness for a particular purpose, or infringement of any intellectual property right.

Reproduction of this manual, or parts thereof, in any form, without the express written permission of Avenview Inc. is strictly prohibited.

## Table of Contents

Section 1: Getting Started .....	3
1.1    Important Safeguards .....	3
1.2    Safety Instructions .....	3
1.3    Regulatory Notices Federal Communications Commission (FCC) .....	4
1.4    Introduction .....	4
1.5    Features .....	4
1.6    Package Contents.....	5
1.7    Before Installation.....	5
1.8    Panel Description .....	6
1.9    DIP Switch .....	7
1.10   IR Remote Control.....	8
Section 2: Installation.....	8
Section 3: Specifications.....	9

## Section 1: Getting Started

### 1.1 Important Safeguards

**Please read all of these instructions carefully before you use the device. Save this manual for future reference.**

#### **What the warranty does not cover**

- Any product, on which the serial number has been defaced, modified or removed.
- Damage, deterioration or malfunction resulting from:
  - Accident, misuse, neglect, fire, water, lightning, or other acts of nature, unauthorized product modification, or failure to follow instructions supplied with the product.
  - Repair or attempted repair by anyone not authorized by us.
  - Any damage of the product due to shipment.
  - Removal or installation of the product.
  - Causes external to the product, such as electric power fluctuation or failure.
  - Use of supplies or parts not meeting our specifications.
  - Normal wear and tear.
  - Any other causes which does not relate to a product defect.
- Removal, installation, and set-up service charges.

### 1.2 Safety Instructions

The SW-DVI-2X4 DVI Matrix has been tested for conformance to safety regulations and requirements, and has been certified for international use. However, like all electronic equipments, the SW-DVI-2X4 should be used with care. Please read and follow the safety instructions to protect yourself from possible injury and to minimize the risk of damage to the unit.

- Do not dismantle the housing or modify the module.
- Dismantling the housing or modifying the module may result in electrical shock or burn.
- Refer all servicing to qualified service personnel.
- Do not attempt to service this product yourself as opening or removing housing may expose you to dangerous voltage or other hazards
- Keep the module away from liquids.
- Spillage into the housing may result in fire, electrical shock, or equipment damage. If an object or liquid falls or spills on to the housing, unplug the module immediately.
- Have the module checked by a qualified service engineer before using it again.
- Do not use liquid or aerosol cleaners to clean this unit. Always unplug the power to the device before cleaning.


## 1.3 Regulatory Notices Federal Communications Commission (FCC)

This equipment has been tested and found to comply with Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

Any changes or modifications made to this equipment may void the user's authority to operate this equipment.

## 1.4 Introduction

The SW-DVI-2X4 allows you to switch between two DVI sources and four DVI displays independently with compact pattern generator functionality. Any input can be switched into any output through a remote control. To simplify the switching process, SW-DVI-2X4 comes with an IR remote control. If you don't have an IR remote control nearby, SW-DVI-2X4 can also be configured by two DIP switches (one rotary switch and one DIP switch). Furthermore, the SW-DVI-2X4 is designed to regenerate every signal carried to itself so that every signal sent out from the SW-DVI-2X4 is as crystal clear as the original.



## 1.5 Features

- Pixel Rate up to 165MHz.
- Maintains highest resolution digital video with no loss of quality
- Configured by IR remote control with OSD display.
- Embedded Pattern Generator.
- Supports EDID learning. The SW-DVI-2X4 can get the EDID information for the output device and pass it to the input equipment.
- DIP switch configuration. Without IR remote control, the switcher can also be configured by the DIP switch and the rotary switch.
- Can be cascaded more than two tiers. The signal carried to the SW-DVI-2X4 will be decoded and encoded.
- Compact size.

## 1.6 Package Contents

Before you start the installation of the converter, please check the package contents.


-	SW-DVI-2X4	x 1
-	DVI Y Cable	x 3
-	IR Remote Control	x 1
-	Power Adapter (+5VDC)	x 1
-	User's Manual	x 1

## 1.7 Before Installation


- Put the product in an even and stable location. If the product falls down or drops, it may cause an injury or malfunction.
- Don't place the product in too high temperature (over 50°C), too low temperature (under 0°C) or high humidity.
- Use the DC power adapter with correct specifications. If inappropriate power supply is used then it may cause a fire.
- Do not twist or pull by force ends of the optical cable. It can cause malfunction.

1.8 Panel Description

FRONT PANEL




REAR PANEL



## 1.9 DIP Switch

When remote control is not available, the SW-DVI-2X4 can be configured by DIP Switch:



- DIP Switch 1 should always be set to ON
- When you need to configure the SW-DVI-2X4 by DIP switch, set the DIP Switch 2 at ON. Set it to OFF only when you need to control the device with provided remote control


DIP Switch	3 ON	3 OFF
4 ON	Output 4	Output 3
4 OFF	Output 2	Output 1

Rotary switch allows you to select an Input Source or a test pattern.



Rotary Switch	Function
0	Source 1
1	Source 2
2	Pattern 1
3	Pattern 2
4	Reserved
5	Pattern 4
6	Pattern 5
7	Reserved

## 1.10 IR Remote Control



- Press “Menu” to launch OSD and use arrow buttons to select options in the OSD menu.
- Right arrow button allows you to confirm your selection
- Press “Menu” again to exit the OSD menu

**Note:** Only four arrow buttons and the menu buttons are currently active.



## Section 2: Installation

Follow these instructions for installation of SW-DVI-2X4:

1. Connect DVI Y Cable to DVI Input
2. Connect DVI Y Cable to DVI Output 2 and DVI Output 3
3. Connect source 1 and source 2 to the Y Cable that is plugged in to DVI Input
4. Connect display 1 and display 2 to the Y Cable that is plugged in to DVI Output 1
5. Connect display 3 and display 4 to the Y Cable that is plugged in to DVI Output 2
6. Turn the source and output displays ON
7. Plug in power to SW-DVI-2X4



### Section 3: Specifications

Item	Description
Model	SW-DVI-2X4 (DVI Matrix Switch)
Supported Input / Output	DVI
Video Bandwidth	1.65 Gbps
Resolutions	1080p60, WUXGA (1920x1200@60)
Input	1 x DVI
Output	2 x DVI
DVI Connector	DVI-I 29 pin female (digital only)
Input Selection	IR Remote
Dimensions	5.1" x 4.3" x 1" (L x W x H)
Weight	2 lbs
Power Supply	5V 4A DC
Power Consumption	10 Watts (max)
Operating Temperature	0~40°C [32~104°F]
Storage Temperature	-20~60°C [-4~140°F]
Relative Humidity	20~90% RH [no condensation]



#### **Disclaimer**

While every precaution has been taken in the preparation of this document, Avenview Inc. assumes no liability with respect to the operation or use of Avenview hardware, software or other products and documentation described herein, for any act or omission of Avenview concerning such products or this documentation, for any interruption of service, loss or interruption of business, loss of anticipatory profits, or for punitive, incidental or consequential damages in connection with the furnishing, performance, or use of the Avenview hardware, software, or other products and documentation provided herein.

Avenview Inc. reserves the right to make changes without further notice to a product or system described herein to improve reliability, function or design. With respect to Avenview products which this document relates, Avenview disclaims all express or implied warranties regarding such products, including but not limited to, the implied warranties of merchantability, fitness for a particular purpose, and non-infringement.