

WXI3077 User's Guide

What's in the box?



WXI3077 base
with waterproof
cordless handset

Not pictured:

- Factory installed rechargeable battery
- AC adapter (PS-0035)
- Telephone cord
- Belt Clip

- If any items are missing or damaged, contact our Customer Care Line immediately. Never use damaged products!
- Need help? Get answers 24/7 at our website: www.uniden.com.

If You...	Contact Uniden's...	Phone Number
have a question or problem	Customer Care Line*	817-858-2929 or 800-297-1023
need a replacement part or an accessory	Parts Department*	800-554-3988
need special assistance due to a disability	Accessibility Help Line	800-874-9314 (voice or TTY)

* During regular business hours, Central Standard Time; see our website for detailed business hours.

What's in the manual?

Important Safety Instructions!.....	2	Setting Up MULTIRANGE	
Understanding the		Chargers	17
Waterproof Handset	3	Registering Handsets	17
Getting Started	4	Using Multi-Handset	
Installing Your Phone	4	Features	18
Understanding Your Phone.....	5	Solving Multi-Handset	
Parts of the Handset	5	Problems	20
Parts of the Base.....	7	Important Information	20
Using the Menus.....	9	Solving Problems	20
Using Your Phone	11	Changing from Tone to Pulse	
Learning the Basics	11	Dialing	23
Using Caller ID and Redial		Resetting Your Handset	24
Lists	13	AC Adapter and Battery	
Using the Phonebook	14	Information	24
Voice Message Notification	15	Compliance Information	26
Finding a Lost Handset.....	16	Warranty (Limited, 1 Year)	29
Expanding Your Phone.....	16		
Compatible Accessory			
Handsets	16		

IMPORTANT SAFETY INSTRUCTIONS!

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

- The base unit is NOT waterproof. Do not use or place the base unit near water, for example, near a bath tub, wash bowl, kitchen sink or laundry tub, in a wet basement, or near a swimming pool.
- If the base unit falls into the water, unplug both the AC adapter and the telephone cord before removing it from the water. After you remove the base from the water, contact Customer Service (see the front cover for contact information).
- Wipe excess water off of the handset before returning it to the base.

- Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning.
- Do not use the telephone to report a gas leak near the actual leak.
- Use only the power cord and batteries indicated in this manual.
- Do not dispose of batteries in a fire. They may explode. Check with local codes for possible special disposal instructions.
- Do not place the handset in any charging cradle without the battery installed and the battery cover securely in place.

SAVE THESE INSTRUCTIONS!

CAUTION! Risk of explosion if battery is replaced by an incorrect type! Dispose of used batteries according to the instructions. Do not open or mutilate the battery. Disconnect the battery before shipping this product.

For more details, see the Important Information section.

Understanding the Waterproof Handset

- The handset complies with JIS7 water submersion specifications. It can remain submerged under 3 feet of water for up to 30 minutes without damage or loss of functionality.
- If the handset falls into the water, just remove it; you can continue using the handset as normal.
- The handset will still receive calls even if it is under water, but you probably won't be able to hear the ringer or the earpiece. To avoid any accidents, do not try to use the handset while it is still under water.
- If you notice that the sound is distorted after your handset was submerged in water, there might still be water around the speaker and microphone. Just shake the handset to clear the water, and the sound should return to normal.
- Don't place the handset where it will be subjected to direct sunlight for long periods of time.


GETTING STARTED

Installing Your Phone

Charge the battery

The handset's rechargeable battery is already installed. Before you can charge the battery, you have to activate it.

1. Remove the cardboard spacer.
2. Press the activation pin according to the direction on the label.
3. Remove the label once the handset is activated.



✂ **Save the activation pin in case you need to change the handset's activation status later (i.e., to deactivate the handset when it will not be used for a long time). Use the plastic activation pin or a blunt-tipped object like an uncurled paper clip to press the activation toggle through the rubber seal. Do not use a sharp object; sharp objects might puncture the rubber seal and jeopardize the handset's waterproof status.**

4. Connect the AC adapter to the charger's **AC IN 8V** jack. (This adapter might already be connected.)
5. Plug the other end of the adapter into a standard 120V AC power outlet.
6. Place the handset in the charger with the display facing forward. The display on the handset should turn on.

If...	Try...
the display on the handset does not turn on	- checking the AC adapter connection. - seeing if the outlet is controlled by a wall switch.

✂ **Charge the handset completely (about 16 hours) before using it.**

Connect the telephone cord


Connect the **TEL LINE** jack to a standard telephone wall jack.

Test the connection

1. Pick up the handset from the cradle and press **TALK/FLASH**. You should hear a dial tone and the display should say *Talk*.
 - If you don't hear a dial tone or the display says *Check Tel Line*, check the connection between the base and the phone jack.
2. Make a quick test call. (Press **END** to hang up.)
 - If the tone doesn't stop when you dial, try changing to pulse dialing mode (see page 23).
 - If there's a lot of noise or static on the call, see page 21 for tips on avoiding interference.

UNDERSTANDING YOUR PHONE

Parts of the Handset



Handset keys and how they work

Key name (and icon)	What it does
UP (▲)	<ul style="list-style-type: none"> - In standby: increase the ringer volume. - During a call: increase the call volume. - In a menu or any list: move the cursor up one line.
CID/RIGHT ([ID])	<ul style="list-style-type: none"> - In standby or during a call: open the Caller ID list. - During text entry: move the cursor to the right.
DOWN (▼)	<ul style="list-style-type: none"> - In standby: decrease the ringer volume. - During a call: decrease the call volume. - In a menu or any list: move cursor down one line.
MENU/SELECT	<ul style="list-style-type: none"> - In standby: open the menu. - In a menu or any list: select the highlighted item.
END (⏏)	<ul style="list-style-type: none"> - During a call: hang up. - In a menu or any list: exit and go to standby.
CLEAR/INTERCOM	<ul style="list-style-type: none"> - While entering text: delete one character, or press and hold to delete all the characters. - In standby: page another handset using the intercom (if expansion includes a minimum of 2 handsets). - During a call: put a call on hold (to start a call transfer with minimum of 2 handsets).
PHONEBOOK/LEFT ([📖])	<ul style="list-style-type: none"> - In standby or during a call: open the phonebook. - In a menu: go back to the previous screen. - During text entry: move the cursor to the left.
TALK/FLASH (📞)	<ul style="list-style-type: none"> - In standby: start a telephone call (get a dial tone). - While the phone is ringing: answer incoming call. - During a call: switch to a waiting call.

Key name (and icon)	What it does
SPEAKER (🔊)	- Switch a call to the speakerphone (and back).
REDIAL/PAUSE (⏪)	<ul style="list-style-type: none"> - In standby: open the redial list. - While entering a phone number: insert a 2-second pause.
MESSAGES ([✉])	- In standby: access your voice mail (see page 16).
MUTE	<ul style="list-style-type: none"> - During a call: mute the microphone. - While the phone is ringing: mute the ringer for this call only.

Parts of the Base



Base key and what it does


Key name	What it does
FIND	In standby: pages the handset to find it.

Display icons and what they mean

Since the icons appear based on what you're doing with the phone, you won't ever see all of these icons at the same time.

Icon	What it means
	The ringer is turned off: this handset will not ring when a call comes in.
	Privacy Mode is on: no other handset can join your call (for multiple handset configuration).
	You have a voice message waiting (see page 16).
	The speakerphone is on.
	The microphone is muted, and the caller can't hear you.
	T-coil mode is on (see page 22).
	The battery is 1) empty, 2) getting low, 3) half charged, or 4) fully charged.
	The signal from the base is 1) weak, 2) low, 3) strong, or 4) very strong.
[Aa]	The handset enters capital letters first (see page 10).
[aA]	The handset enters lower-case letters first (see page 10).

Using the Menus



- If you open the menu during a call, use **PHONEBOOK/LEFT** to back out of the menu without hanging up.
- If you don't press any keys for 30 seconds, the handset exits the menu.

The Handset Setup Menu

You can change these settings separately for each handset.

<i>T-coil</i>	Turn on T-coil mode to reduce noise on some hearing aids (see page 22).
<i>Ringer Tones</i>	Set the handset's ringtone. As you highlight each ring tone, the phone plays a sample. When you hear the tone you want, press MENU/SELECT .
<i>Personal Ring</i>	Turn on the personal ring feature. If you have Caller ID, this feature lets you assign special ringtones to anyone in your phonebook; this handset will use the special ringtone when that person calls.
<i>AutoTalk</i>	Have the handset answer a call when you pick it up from the cradle (without pressing any buttons).
<i>Any Key Answer</i>	Have the handset answer a call when you press any key on the 12-key dialpad.

<i>Banner</i>	Change the name used on the handset's display.
<i>Handset Language</i>	Change the display language.
<i>Key Touch Tone</i>	Have the keypad sound a tone when you press a key.

The Day and Time menu

If you subscribe to Caller ID, the phone automatically sets the day and time when it receives Caller ID information from your phone company. If you want to set the clock manually, just open the menu and select *Day and Time*. The phone prompts you to select the day, enter the time, and select *AM/PM*. (When prompted for the time, use the number keypad to enter 2 digits for the hour and 2 digits for the minutes, e.g., 0530 for 5:30.)

The Global Setup menu

The settings on this menu affect all handsets and the base. Before changing these settings, make sure the phone is in standby and all handsets are within range of the base. (Only one handset at a time can change these settings.)

<i>Dial Mode</i>	Change the way your phone communicates with the telephone network (see page 23).
<i>Set Line Mode</i>	Do not change this setting unless instructed to by customer service.
<i>Edit V-Mail No.</i>	Program a number to dial for voice mail access (see page 15).
<i>VMWI Reset</i>	Reset the message waiting indicator if it gets out of sync with your voice mail service (see page 16).

How to enter text on your phone

Use the 12-key dial pad when you want to enter text into your phone (i. e., a name in the phonebook, the handset banner).

- The phone defaults to a capital letter for the first letter and any letter after a space; otherwise, it uses small letters.

- To switch to all capital letters, press *****. The phone displays *[Aa]* and defaults to all capital letters first (e. g. ABCabc2) until you enter a blank space or press ***** again. Pressing ***** again will change to lowercase letters first (*[aA]*). Any time you want to change case, just press *****.
- If two letters in a row use the same number key, enter the first letter and wait a few seconds (or press **RIGHT**); the cursor will move to the next space. Enter the next letter.
- Press **#** to enter a blank space.
- To change a letter, move the cursor to that letter and press **CLEAR** to erase the letter. Then, enter the next letter.
- To erase the entire entry, press and hold **CLEAR**.
- Press **0** to cycle through all available symbols and punctuation.

USING YOUR PHONE

You can control the features in this section through the handset.

Learning the Basics

To...	Do this	
	From the earpiece...	From the speaker...
make a call: Dial the number, then	Press TALK/FLASH .	Press SPEAKER .
answer a call	Press TALK/FLASH .	Press SPEAKER .
hang up	Press END or put the handset in the cradle.	
mute the microphone during a call	Press MUTE . Press again to turn the microphone back on.	
put a call on hold	Press CLEAR/INTERCOM . After 5 minutes on hold, the call will be disconnected.	
return to a call on hold	Press TALK/FLASH .	Press SPEAKER .

To...	Do this	
	From the earpiece...	From the speaker...
switch between the speakerphone and earpiece	Press SPEAKER .	
mute the ringer for this call only	While the phone is ringing, press MUTE .	

Change the volume

Speaker and earpiece volume	Ringer volume
<ul style="list-style-type: none"> - You can change the speaker volume of each cordless handset separately. - You can change the volume of the earpiece on each handset; this does not affect the handset's speaker volume. - Anytime you are listening to a speaker or earpiece, press UP to increase the volume and DOWN to decrease it. 	<ul style="list-style-type: none"> - You can change the ringer volume of each handset separately. - When the phone is in standby, press UP to increase the volume and DOWN to decrease it. - If you turn the ringer volume all the way down, the ringer turns off.

Call waiting

Call Waiting is a service available from your telephone provider that lets you receive calls while you are on another call. Caller ID on Call Waiting (CIDCW) service displays Caller ID information for a waiting call. Contact your telephone provider for more information.

If you get a Call Waiting call, the phone sounds a tone and displays any CID information received for the waiting call. To switch between the current call and the waiting call, press **TALK/FLASH**. Remember, each time you switch, there is a short pause before you're connected to the other caller.

Using Caller ID and Redial Lists

Caller ID (CID) is a service available from your telephone provider that shows the phone number (and sometimes the caller's name) of incoming calls. Contact your telephone provider for more information.

Caller ID (CID) list	Redial list
<ul style="list-style-type: none"> - The phone saves the information for the last 30 received calls to the CID list. When the phone's in standby, each handset shows how many calls came in since the last time you checked the CID list. - New records have an asterisk next to the received time. - Only one handset can access the CID list at a time, and you can't access the CID list while another handset is on a call. 	<ul style="list-style-type: none"> - Each cordless handset remembers the last 5 numbers you dialed on it. - The redial list is separate for each handset.

To...	Follow these steps...
open the CID list	Press CID/RIGHT .
open the Redial list	Press REDIAL/PAUSE .
scroll through the list	Press DOWN to scroll through the list from newest to oldest. Press UP to scroll from oldest to newest.
dial a number	Highlight the number you want* and press TALK/FLASH .
close the list	Press PHONEBOOK/LEFT .

* If the number is a toll or long distance call, but there's no 1 at the front of the CID record, press ***** to add the 1 before you dial the number.

To select a number, highlight the number and press **MENU/SELECT**. The phone gives you the following options:

<i>Delete Entry</i>	Erase the number from the list.
<i>Store Into Pb</i>	Add the number to the phonebook. The handset prompts you to edit the name and number and select a personal ringtone.
<i>Delete All</i>	(Caller ID list only.) Erase all numbers from the list.

Using the Phonebook

- The phone can store up to 70 entries in its central phonebook; the phonebook is shared by all cordless handsets.
- Only one handset can access the phonebook at a time, and you can't access the phonebook while another handset is on a call.

To...	Do this...
open/close the phonebook	Press PHONEBOOK/LEFT .
scroll through the entries	Press DOWN to scroll through the phonebook from A to Z or UP to scroll from Z to A.
jump to entries that start with a certain letter	Press the number key corresponding to the letter you want to jump to.
dial an entry	Find the entry you want to dial, and press TALK/FLASH .

To select a number, highlight the number and press **MENU/SELECT**. The phone gives you the following options:

<i>Edit</i>	Edit this entry. The handset prompts you to edit the name and number and select a personal ring.
<i>Delete</i>	Erase this entry.

Phonebook menu options


With the phone in standby, open the phonebook. From the main phonebook screen (instead of an individual entry), press **MENU/SELECT**. The phone gives you the following options:

<i>Create New</i>	Add an entry to your phonebook. The handset prompts you to enter a name and number and select a personal ring.
<i>Delete All</i>	Erase all the entries in the phonebook.

Chain dialing

If you often have to enter a series of digits or a code number during a call, you can save that code number to a phonebook entry and use the phonebook to send the code number.

1. Enter the code number (up to 20 digits) into the phonebook just like a regular phonebook entry. Be sure to enter the code number into the phonebook exactly as you would enter it during a call.
2. During a call, when you hear the prompt that tells you to enter the number, open the phonebook and find the entry that contains your code number.
3. Press **MENU/SELECT** to transmit the code.

 **If you change your mind, use PHONEBOOK/LEFT to close the phonebook.**

Voice Message Notification

This feature supports Frequency-Shift Keying (FSK) message notification. Contact your voice mail provider for more details.

If you subscribe to a voice mail service, your phone can notify you when you have a new message waiting.


Program voice mail access number/tone

You can program your voice mail service access number so you can quickly access your messages.

1. With the phone in standby, open the menu.
2. Select *Global Setup*, then select *Edit V-Mail No.*
3. Enter your access number exactly as you would dial it. You can enter a total of 20 digits. If you need the phone to wait a few seconds between digits (to wait for the service to answer, for


example), press **REDIAL/PAUSE** to insert a 2-second pause. You can insert as many pauses as you need, but each pause counts as one digit. Press **MENU/SELECT** when you're finished.

Retrieve your messages

When you have new messages, the voice message icon () appears in the display, and the light at the top of the handset blinks. Press **MESSAGES** to dial the programmed access number for this handset.

Reset message waiting indicator

The voice message icon should disappear after you listen to all your new messages. If it doesn't, you can reset it manually.

1. With the phone in standby, open the menu and select *Global Setup*.
2. Select *VMWI Reset*, then select *Yes*.
3. The blinking light will turn off and  disappears.
4. Press **END**.

Finding a Lost Handset

With the phone in standby, press **FIND** on the base. All the handsets will beep for 1 minute; to end the page, press **FIND** again or press any key on any handset.

EXPANDING YOUR PHONE

Compatible Accessory Handsets

Your base supports a total of six cordless handsets: the one that came with the base and up to five other compatible accessory handsets. The following accessory handsets are compatible with this phone:

- DCX330 accessory handset with charger
- DRX332 accessory handset with MULTIRANGE™ charger
- DWX337 waterproof accessory handset with water-resistant charger


Refer to the individual Owner's Manuals for detailed information about each handset.

Setting Up MULTIRANGE Chargers

- If you expand your phone system by purchasing a separate MULTIRANGE charger, you will have a separate manual discussing the charger in detail, including how it works, how to reset it, how to attach the wall mount bracket, etc.
- Your base can support a total of 2 DRX332 MULTIRANGE chargers.
- The MULTIRANGE charger extends the range of your base in all directions, including up and down. Each handset will automatically connect to the charger or the base, depending on which signal is stronger.

To place a MULTIRANGE charger

- Make sure you have a strong signal from the base (at least 3 bars in the handset display).
- Put the charger at least 35 feet away from the base or any other MULTIRANGE charger. (If you put the charger on a different floor from the base, don't forget to allow 35 feet vertically, also.)

 **For more information, see the DRX332 Owner's Manual.**

Registering Handsets

The handset that came packaged with the base is already registered to the base for you.

However, if you purchase any accessory handsets separately, you must register the handsets to the base before you can use them. Handsets that aren't registered display a *Handset not registered* message.

1. With the phone in standby, press and hold **FIND** on the base for about 5 seconds.
2. On the handset you want to register, press and hold **#** until the display says *Handset Registering* (about 2 seconds).
3. After the handset displays *Registration Complete* (about 30 seconds), press **TALK/FLASH** and make sure you get a dial tone.

If...	Try...
<ul style="list-style-type: none"> - you don't hear a dial tone - The display says <i>Registration Failed</i> 	Making sure the handset is fully charged, then starting over from the beginning of this section.

If a handset was previously registered to a base, you have to reset it so you can register it to a new base (see page 24 or the manual for the accessory handset).

Using Multi-Handset Features

To use the features in this section, you must have at least two cordless handsets.

Conference calling

- When an outside call comes in, two handsets can join in a conference call with the outside caller.
- To join an ongoing call, press **TALK/FLASH** or **SPEAKER**.
- To leave the conference call, hang up normally; the other handset remains connected to the call.

Privacy mode

You can prevent other handsets from joining a call. Start your call as usual, then press **MENU/SELECT**; the display shows *Call Privacy*. Press **MENU/SELECT** again to turn privacy mode on (you'll see **F** in the display). When you hang up, privacy mode turns off automatically.

As long you have privacy mode on, no other handsets can interrupt your call. To allow another handset to join the call, press **MENU/SELECT** twice to turn privacy mode off.

Call transfer

To...	Do this...
transfer a call	Press CLEAR/INTERCOM , then select the handset you want to transfer the call to (select <i>All</i> to page all the handsets). When the other handset accepts the call, you'll be disconnected.
cancel a transfer and leave the call on hold	Press END .
cancel a transfer and return to the call	Press TALK/FLASH .
answer a call transfer page	<ol style="list-style-type: none"> 1. Press CLEAR/INTERCOM. You can speak to the transferring handset. 2. To speak to the outside caller, press TALK/FLASH.

Intercom call

- Whenever the phone is in standby, you can make an intercom call between handsets without using the phone line.
- You can make an intercom call from any handset, but only two handsets can be in an intercom call at any time.
- If an outside call comes in during an intercom page, the phone sounds a tone and shows any received CID information. If another handset hasn't answered the page yet, the phone cancels the page to let you can answer the incoming call.

To...	Do this...
make an intercom page	Press CLEAR/INTERCOM , then select the handset you want to talk with (select <i>All</i> to page all handsets at the same time).
cancel a page	Press END .
answer an intercom page	Press CLEAR/INTERCOM or TALK/FLASH .
leave an intercom call	Press END .

To...	Do this...
answer an outside call during an intercom call	Press TALK/FLASH . The phone automatically disconnects the intercom call and connects you to the outside line.

Solving Multi-Handset Problems

If...	Try...
I can't transfer calls.	Resetting all handsets.
Two handsets can't talk to the caller.	Making sure no handset is in Privacy Mode.
I can't get my handset to switch to the MULTIRANGE charger.	<ul style="list-style-type: none"> - Re-registering the MULTIRANGE charger. - Making sure the MULTIRANGE charger and handset are registered to the same base.
The LINK light on the MULTIRANGE charger randomly starts blinking.	Moving the MULTIRANGE charger closer to the base.

IMPORTANT INFORMATION

Solving Problems

If you have any trouble with your phone, try these simple steps first. If you need help, call our Customer Care Line listed on the front cover.

If...	Try...
No handsets can make or receive calls.	<ul style="list-style-type: none"> - Checking the telephone cord connection. - Disconnecting the base AC adapter. Wait a few minutes, then reconnect it. - Making sure the base is plugged in.
A handset can't make or receive calls.	Moving the handset closer to the base.

If...	Try...
A handset can make calls, but it won't ring.	<ul style="list-style-type: none"> - Making sure the ringer is turned on.
A handset is not working.	<ul style="list-style-type: none"> - Charging the battery for 16-20 hours. - Checking that the handset battery is activated (see page 4). - Resetting the handset.
A handset says <i>Unavailable</i> .	<ul style="list-style-type: none"> - Moving the handset closer to the base. - Seeing if another handset is in Privacy Mode.
The handset does not display Caller ID information.	<ul style="list-style-type: none"> - Letting calls ring twice before answering. - Making sure your Caller ID service is active.
Caller ID displays briefly and then clears.	<ul style="list-style-type: none"> - You may have to change the line mode. Contact customer service.

Weak or hard to hear audio

If a caller's voice sounds weak or soft, the signal might be blocked by large metal objects or walls; you might also be too far from the base, or the handset's battery may be weak.

- Try moving around while you're on a call or moving closer to the base to see if the sound gets louder.
- Make sure the handset's battery is fully charged.
- Try adjusting the earpiece volume.

Noise or static on the line

Interference is the most common cause of noise or static on a cordless phone. Here are some common sources of interference:

- electrical appliances, especially microwave ovens
- computer equipment, especially wireless LAN equipment and DSL modems
- radio-based wireless devices, such as room monitors, wireless controllers, or wireless headphones or speakers

- fluorescent light fixtures (especially if giving off a buzzing noise)
- other services that use your phone line, like alarm systems, intercom systems, or broadband Internet service

If static is on 1 handset or in 1 location:	If static is on all handsets or in all locations:
<ul style="list-style-type: none"> - Check nearby for one of the common interference sources. - Try moving the handset away from a suspected source, or try moving the suspected source so it's not between the handset and the base. - There is always more noise at the edges of the base's range. If an <i>Out of Range</i> message displays, try moving closer to the base. 	<ul style="list-style-type: none"> - Check near the base for the source of interference. - Try moving the base away from a suspected source, or turn off the source if possible. - If the base has an adjustable antenna, try raising the antenna so it stands straight up. - If you have any service that uses the phone line, you might need a filter (see following).

Installing a line filter or DSL filter

Sometimes, broadband Internet services that use the telephone line can interfere with phones. One of these services—DSL—often causes static on telephones. A DSL filter or telephone line filter usually solves this problem. The technician who installed your DSL service might have left some filters for you; if not, call your DSL provider or look in any electronics store.

Plug the DSL filter into the telephone wall jack and plug your phone's base into the filter. Make a test call to make sure the noise is gone.


Do you use a T-coil hearing aid?

- If you have a hearing aid equipped with a telecoil (T-coil) feature, the interaction between the hearing aid and digital cordless phones can cause noise in the handset. If you have a T-coil hearing aid and you have problems with noise on the line, try turning on *T-coil* mode. Open the menu. Select *Handset Setup*, then select *T-coil*.
- Using T-coil mode can shorten the handset's talk time; make sure to watch the battery status and keep the battery charged.

Liquid damage

Moisture and liquid can damage your cordless phone. If the exterior housing of the handset or base is exposed to moisture or liquid, wipe off the liquid, and use as normal. If moisture or liquid is inside the plastic housing (i.e. liquid can be heard in the phone or liquid has entered the handset battery compartment or vent openings on the base), follow these steps:

Handset	Base
<ul style="list-style-type: none"> - Remove the battery cover and disconnect the battery. - Let dry for at least 3 days with the battery disconnected and the cover off for ventilation. - After the handset dries, reconnect the battery and replace the cover. Recharge the battery fully before using. 	<ul style="list-style-type: none"> - Disconnect the AC adapter to cut off the power. - Disconnect the telephone cord. - Let dry for at least 3 days before reconnecting.

 **CAUTION! DO NOT use a microwave oven to speed up the drying process. This will cause permanent damage to the handset, base, and the microwave oven.**

Changing from Tone to Pulse Dialing

Your phone communicates with the telephone network two ways: tone dialing or pulse dialing. Most telephone companies use tone dialing. If your phone company uses pulse dialing, you will need to change your phone's dial mode.

1. From a handset, open the menu and select *Global Setup*.
2. Select *Dial Mode*, then select *Pulse*. The phone sounds a confirmation tone.

If you use pulse dialing and you need to send DTMF tones during a call (if you're using an automated response system, for example), press ***** to temporarily switch to tone dialing. When the call ends, the phone automatically returns to pulse dialing mode.

Resetting Your Handset

If you are having trouble with a cordless handset or if you want to replace one, you need to clear the registration information from the base and the handset:

Do you have the base the handset is registered to?	
Yes	No
<ol style="list-style-type: none">1. Press and hold END and # until the <i>System Reset</i> menu appears (about 5 seconds).2. Select <i>Deregister HS</i>. The display lists all registered handsets.3. Select the handset you want to reset.4. When the handset asks you to confirm, select <i>Yes</i>. The handset clears its information from the base and deletes its own link to the base.	<ol style="list-style-type: none">1. Press and hold END and # until the <i>System Reset</i> menu appears (about 5 seconds).2. Select <i>Base Unavailable</i>.3. When the handset asks you to confirm, select <i>Yes</i>. The handset deletes its own link without contacting the base.

Once you have reset a handset (or if you buy a new one), that handset displays a *Handset Not Registered* message. If you see this message on a handset, you need to register it to a base before you can use it (see page 17).

AC Adapter and Battery Information

AC Adapter

Part Number	Input Voltage	Output Voltage
PS-0035	120V AC, 60 Hz	8V AC @ 300mA

Battery Pack

Part Number	Capacity
BT-1018	500mAh, 2.4V DC

- Use only the supplied AC adapter. Be sure to use the proper adapter for the base and charger.
- Do not place the power cord where it creates a trip hazard or where it could become chafed and create a fire or electrical hazard.
- Do not place the unit in direct sunlight or subject it to high temperatures.
- Fully charged, the battery should provide about 8 hours of talk time and about 7 days of standby time. For best results, return the handset to the cradle after each call to keep it fully charged.
- When the battery gets too low, the handset shows a low battery alert. If you hear a strange beep during a call, check the display: if you see the low battery alert, finish your conversation as quickly as possible and return the handset to the cradle. If the handset is in standby, none of the keys will operate.
- With normal use, the battery should last about one year. Replace the battery when the talk time becomes short even when the battery is charged. To buy a replacement battery, call the Parts Department listed on the front cover.

Rechargeable Nickel-Metal-Hydrate battery warning


- This equipment contains a rechargeable Nickel-Metal-Hydrate battery.
 - Nickel is a chemical known to the state of California to cause cancer.
 - Do not short-circuit the battery.
 - The rechargeable batteries contained in this equipment may explode if disposed of in a fire.
 - Do not charge the battery used in this equipment in any charger other than the one designed to charge this battery as specified in the owner's manual. Using another charger may damage the battery or cause it to explode.
- Rechargeable Batteries Must Be Recycled or Disposed of Properly.**
Uniden works to reduce lead content in PVC coated cords in our products and accessories.

Warning! The cords on this product and/or accessories contain lead, a chemical known to the state of California to cause birth defects or other reproductive harm. Wash hands after handling.

Replace the Rechargeable Handset Battery Pack

Follow these steps to replace the battery:

1. Unscrew the four screws holding the battery cover and remove it.
2. Remove the old battery pack from the battery compartment.
3. Line up the new battery's connector with the jack inside the battery compartment (the connector only fits one way).
4. Push the connector in firmly. Tug on the battery wires gently to make sure you have a good connection.
5. Before replacing the battery cover, check the rubber seal located on the under side of the cover: make sure that the seal is set in the groove and that there is no foreign matter under the seal.

 **Note: If the rubber seal appears worn, nicked, or dried out, you must replace it. New seals are available through the Parts Department (see the cover page for contact information).**

6. Replace the battery cover; use the four screws to secure the cover to the back of the handset.

Compliance Information

FCC Part 68 Information

This equipment complies with Part 68 of the FCC rules and the requirements adopted by the ACTA. On the bottom of this equipment is a label that contains, among other information, a product identifier in the format US: AAAEQ##TXXXX. If requested, this number must be provided to the phone company.

An applicable Universal Service Order Codes (USOC) certification for the jacks used in this equipment is provided (i.e., RJ11C) in the packaging with each piece of approved terminal equipment. A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.

The REN is used to determine the number of devices that may be connected to a phone line. Excessive RENs on a phone line may result in devices not ringing in response to an incoming call. In most but not all areas, the sum of RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact the

telephone provider. The REN for this product is part of the product identifier that has the format US:AAAEQ##TXXXX. The digits represented by ## are the REN without a decimal point (e.g., 03 is a REN of 0.3).

If this equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. But if advance notice isn't practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary. The telephone company may make changes in its facilities, equipment, operations or procedures that could affect the operation of the equipment. If this happens the telephone company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service.

Please follow instructions for repairing, if any (e.g. battery replacement section); otherwise do not substitute or repair any parts of the device except as specified in this manual. Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission or corporation commission for information. This equipment is hearing aid compatible.

If you experience trouble with this equipment, contact the manufacturer (see the cover of this manual for contact information) or an authorized agent. If the equipment is causing harm to the telephone network, the telephone company may request that you disconnect the equipment until the problem is resolved.

If your home has wired alarm equipment connected to a phone line, be sure that installing the system does not disable your alarm equipment. If you have questions about what will disable alarm equipment, contact your telephone company or a qualified installer.

Any changes or modifications to this product not expressly approved by the manufacturer or other party responsible for compliance could void your authority to operate this product.

NOTICE: According to telephone company reports, AC electrical surges, typically resulting from lightning strikes, are very destructive to telephone equipment connected to AC power sources. To minimize damage from these types of surges, a surge arrester is recommended.

FCC Part 15 Information

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Privacy of communications may not be ensured when using this phone.

FCC PART 15.105(b): Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF Exposure Information

This product complies with FCC radiation exposure limits under the following conditions:

- The base must be placed to allow a minimum of 20 cm (8 inches) between the antenna and all persons during normal operation.
- The base must not be collocated or operated in conjunction with any other antenna or transmitter.
- The handset is designed for body-worn operation and meets FCC RF exposure guidelines when used with any belt clip, carrying case, or other accessory supplied with this product. (All necessary accessories are included in the package; any additional or optional accessories are not required for compliance with the guidelines.) Third party accessories (unless approved by the manufacturer) should be avoided as these might not comply with FCC RF exposure guidelines.

Industry Canada (I.C.) Notice

Terminal equipment

NOTICE: This equipment meets the applicable **Industry Canada Terminal Equipment Technical Specifications**. This is confirmed by the registration number. The abbreviation *IC* before the registration number signifies that registration was performed based on a Declaration of Conformity indicating that Industry Canada technical specifications were met. It does not imply that Industry Canada approved the equipment.

NOTICE: The Ringer Equivalence Number (REN) for this terminal equipment is marked on the equipment itself. The REN assigned to each terminal equipment provides an indication of the maximum number of terminals allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the Ringer Equivalence Numbers of all the devices does not exceed 5.

Radio equipment

The term *IC* before the radio certification number only signifies that Industry Canada technical specifications were met. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. "Privacy of communications may not be ensured when using this telephone".

Warranty (Limited, 1 Year)

Evidence of original purchase is required for warranty service.

WARRANTOR: UNIDEN AMERICA CORPORATION ("Uniden")

ELEMENTS OF WARRANTY: Uniden warrants, for one year, to the original retail owner, this Uniden Product to be free from defects in materials and craftsmanship with only the limitations or exclusions set out below.

WARRANTY DURATION: This warranty to the original user shall terminate and be of no further effect 12 months after the date of original retail sale. The warranty is invalid if the Product is (A) damaged or not maintained as reasonable or necessary, (B) modified, altered, or used as part of any conversion kits, subassemblies, or any configurations not sold by Uniden, (C) improperly installed, (D) serviced or repaired by someone other than an authorized Uniden service center for a defect or malfunction covered

by this warranty, (E) used in any conjunction with equipment or parts or as part of any system not manufactured by Uniden, or (F) installed or programmed by anyone other than as detailed by the owner's manual for this product.

STATEMENT OF REMEDY: In the event that the product does not conform to this warranty at any time while this warranty is in effect, warrantor will either, at its option, repair or replace the defective unit and return it to you without charge for parts, service, or any other cost (except shipping and handling) incurred by warrantor or its representatives in connection with the performance of this warranty. Warrantor, at its option, may replace the unit with a new or refurbished unit. THE LIMITED WARRANTY SET FORTH ABOVE IS THE SOLE AND ENTIRE WARRANTY PERTAINING TO THE PRODUCT AND IS IN LIEU OF AND EXCLUDES ALL OTHER WARRANTIES OF ANY NATURE WHATSOEVER, WHETHER EXPRESS, IMPLIED OR ARISING BY OPERATION OF LAW, INCLUDING, BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. THIS WARRANTY DOES NOT COVER OR PROVIDE FOR THE REIMBURSEMENT OR PAYMENT OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. Some states do not allow this exclusion or limitation of incidental or consequential damages so the above limitation or exclusion may not apply to you.

LEGAL REMEDIES: This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. This warranty is void outside the United States of America and Canada.

PROCEDURE FOR OBTAINING PERFORMANCE OF WARRANTY: If, after following the instructions in the owner's manual you are certain that the Product is defective, pack the Product carefully (preferably in its original packaging). Disconnect the battery from the Product and separately secure the battery in its own separate packaging within the shipping carton. The Product should include all parts and accessories originally packaged with the Product. Include evidence of original purchase and a note describing the defect that has caused you to return it. The Product should be shipped freight prepaid, by traceable means, to warrantor at:

Uniden America Service
4700 Amon Carter Blvd.
Fort Worth, TX 76155

• Uniden® is a registered trademark of Uniden America Corporation.

• The pictures in this manual are for example only. Your phone may not look exactly like the pictures.

May be covered under one or more of the following U.S. patents:

7,206,403 7,310,398 7,460,663

Other patents pending.

