


iHome®

Model iH150
**LED Color Changing
Stereo System to Charge
and Play Your iPod**



Questions? Visit www.ihomeaudio.com

Table of Contents

Controls and indicators -----	1
Quick Start -----	2
Getting Started / Maintenance -----	3
Playing and Charging iPod -----	3
Color Change mode -----	3
A Consumer Guide to Product Safety -----	4
Trouble Shooting -----	5
Warranty Information -----	6

FCC Information

This device complies with Part 15 of the FCC Rules, operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

- Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This Class B digital apparatus complies with Canadian ICES-003.


Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada

Controls and Indicators

Top panel




Back panel




Adapter Jack
Plug in AC adapter cable and
connect to outlet to power unit

iH150 Quick Start




Attach AC adaptor cable to jack on back of the iH150 and plug the other end into a wall socket to play and charge iPod.

2: inserts



Select the dock insert for your iPod model from the table below and place insert in dock. To remove insert, place thumbnail in slot and gently pull upwards.

3: iPod



Insert playing iPod into the dock (must not be in a "skin" or case). iPod will charge while docked. Press the **Power Button** on the unit to listen to your iPod.

Use this insert

iPod touch 2G
insert 16

nano 6G/touch 4G
insert 20

For this iPod

iPod touch 2G/3G

nano 6G
iPod touch 4G

NOTE: If you do not have an insert for your iPod, you can safely dock your iPod without one provided you always do so gently and carefully. If you prefer to use an insert, please visit www.ihomeaudio.com or call iHome toll free at 800-288-2792 to purchase one.

Getting Started

Thank you for purchasing the iHome iH150 Color Change Speaker System for your iPod. Designed specifically to work with your iPod, this system provides high quality audio performance combined with relaxing colored mood lights. Please read this instruction carefully before operating the unit and keep it for future reference.

Install iPod Insert

Your iH150 comes with 2 removable inserts for popular iPod models to ensure your iPod fits properly in the Dock (please see the table in Quick Start Section). If there is no insert for your particular iPod model, you can still dock your iPod safely provided you always dock and remove it from the dock gently and carefully.

Connect Power

Plug the AC adaptor cable into the AC Adaptor Jack on the back of the unit and the other end into a standard 120V wall outlet.

Maintenance

- Place the unit on a level surface away from sources of direct sunlight or excessive heat.
- Protect your furniture when placing your unit on a natural wood and lacquered finish. A cloth or other protective material should be placed between it and the furniture.
- Clean your unit with a soft cloth moistened only with mild soap and water. Stronger cleaning agents, such as Benzene, thinner or similar materials can damage the surface of the unit.

Playing and Charging your iPod

1. Place proper insert for your iPod (see insert table on Quick Start Section) in Dock, then gently dock playing iPod. The unit will turn on and in a moment you will hear your music. When docked, iPod will charge until fully charged. The iPod will not overcharge.
2. If iPod is not in play mode, press the **⏻ Button** on the iH150 to play your iPod. The power on indicator will light up to show the unit is on.
3. Press the **⏮** or **⏭ Button** Volume to adjust the volume.
4. To switch off the unit, press the **⏻ Button** again.

Color Change Mode

There are four color mode settings. Press the **⚡ Color Button** to cycle through them. The settings are: slow color change (default), fixed color (press the **⚡ Color Button** when the desired color is showing to select that color), fast color change and light off.

IMPORTANT SAFETY INSTRUCTIONS

When used in the directed manner, this unit has been designed and manufactured to ensure your personal safety. However, improper use can result in potential electrical shock or fire hazards. Please read all safety and operating instructions carefully before installation and use, and keep these instructions handy for future reference. Take special note of all warnings listed in these instructions and on the unit.

1. **Water and Moisture** – The unit should not be used near water. For example: near a bathtub, washbowl, kitchen sink, laundry tub, swimming pool or in a wet basement.
2. **Ventilation** – The unit should be situated so that its location or position does not interfere with its proper ventilation. For example, it should not be situated on a bed, sofa, rug or similar surface that may block ventilation openings. Also, it should not be placed in a built-in installation, such as a bookcase or cabinet, which may impede the flow of air through the ventilation openings.
3. **Heat** – The unit should be situated away from heat sources such as radiators, heat registers, stoves or other appliances (including amplifiers) that produce heat.
4. **Power Sources** – The unit should be connected to a power supply only of the type described in the operating instructions or as marked on the appliance.
5. **Power-Cable Protection** – Power supply cables should be routed so that they are not likely to be walked on or pinched by items placed upon or against them. It is always best to have a clear area from where the cable exits the unit to where it is plugged into an AC socket.
6. **Cleaning** – The unit should be cleaned only as recommended. See the Maintenance section of this manual for cleaning instructions.
7. **Objects and Liquid Entry** – Care should be taken so that objects do not fall and liquids are not spilled into any openings or vents located on the product.
8. **Attachments** – Do not use attachments not recommended by the product manufacturer.
9. **Lightning and Power Surge Protection** – Unplug the unit from the wall socket and disconnect the antenna or cable system during a lightning storm or when it is left unattended and unused for long periods of time. This will prevent damage to the product due to lightning and power-line surges.
10. **Overloading** – Do not overload wall sockets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.
11. **Damage Requiring Service** – The unit should be serviced by qualified service personnel when:
 - A. the power supply cable or plug has been damaged.
 - B. objects have fallen into or liquid has been spilled into the enclosure.
 - C. the unit has been exposed to rain.
 - D. the unit has been dropped or the enclosure damaged.
 - E. the unit exhibits a marked change in performance or does not operate normally.
12. **Antenna** – Do not connect an external antenna to the unit (other than that provided).
13. **Periods of Nonuse** – If the unit is to be left unused for an extended period of time, such as a month or longer, the power cable should be unplugged from the unit to prevent damage or corrosion.
14. **Servicing** – The user should not attempt to service the unit beyond those methods described in the user's operating instructions. Service methods not covered in the operating instructions should be referred to qualified service personnel.

Questions? Visit www.ihomeaudio.com

Trouble Shooting

Symptom	Possible Problem	Solution
Unit doesn't respond (no power)	AC adaptor isn't plugged to a wall outlet or the connector is not plugged into the power supply jack on the back of the unit	Plug the AC adaptor into a wall outlet and plug the connector into the power supply jack on the unit
	Wall outlet is not functioning	Plug another device into the same outlet to confirm the outlet is working
iPod cannot dock properly	Using wrong insert	Make sure the dock insert is the proper fit for your iPod
	Possible obstruction in dock area or on iPod (skin or case is in the way)	Remove your iPod from the connector and check for any obstruction on the connectors in the dock. Try removing case or skin from your iPod. Then reseal it in the dock.
Playing iPod but there is no sound	iPod is not docked properly	Remove your iPod from the connector and check for any obstruction on the connectors in the dock and on your iPod. Then reseal it in the dock.
	Your iPod is not playing	Press play button on your iPod to play it manually.
	iPod is locked up	Please make sure your iPod is working properly before docking it to the unit. Please refer to your manual for details.
iPod didn't charge up	iPod is not docked properly	Remove your iPod from the connector and check for any obstruction on the connectors in the dock and on your iPod. Then reseal it in the dock.
	iPod is locked up/frozen	Please make sure your iPod is working properly before docking it to the unit. Please refer to your manual for details.
	iPod battery has problem	
Sound is distorted	Volume level is set too high	Decrease the unit volume

Limited 90-Day Warranty Information

iHome Products, a division of SDI Technologies Inc. (hereafter referred to as SDI Technologies), warrants this product to be free from defects in workmanship and materials, under normal use and conditions, for a period of 90 days from the date of original purchase.

Should this product fail to function in a satisfactory manner, it is best to first return it to the store where it was originally purchased. Should this fail to resolve the matter and service still be required by reason of any defect or malfunction during the warranty period, SDI Technologies will repair or, at its discretion, replace this product without charge (except for a \$10.00 charge for handling, packing, return UPS/postage, and insurance). This decision is subject to verification of the defect or malfunction upon delivery of this product to the Factory Service Center listed below. The product must include proof of purchase, including date of purchase. The fee for service without proof of purchase is \$25.00.

Before returning this product for service, please first replace the batteries (if applicable) with fresh ones, as exhausted or defective batteries are the most common cause of problems encountered.

If service is still required:

1. Remove the batteries (if applicable) and pack the unit in a well padded, heavy corrugated box.
2. Enclose a photocopy of your sales receipt, credit card statement, or other proof of the date of purchase, if within the warranty period.
3. Enclose a check or money order payable to the order of SDI Technologies, for the sum of \$10.00 (\$25.00 without proof of purchase).
4. Send the unit prepaid and insured, to the Factory Service Center listed below.

Consumer Repair Department

*SDI Technologies Inc.
1330 Goodyear Drive
El Paso, TX 79936-6420*

Disclaimer of Warranty

NOTE: This warranty is valid only if the product is used for the purpose for which it was designed. It does not cover (i) products which have been damaged by negligence or willful actions, misuse or accident, or which have been modified or repaired by unauthorized persons; (ii) cracked or broken cabinets, or units damaged by excessive heat; (iii) damage to digital media players, CD's or tape cassettes (if applicable); (iv) the cost of shipping this product to the Factory Service Center and its return to the owner.

This warranty is valid only in the United States of America and does not extend to owners of the product other than to the original purchaser. In no event will SDI Technologies or any of its affiliates, contractors, resellers, their officers, directors, shareholders, members or agents be liable to you or any third party for any consequential or incidental damages, any lost profits, actual, exemplary or punitive damages. (Some states do not allow limitations on implied warranties or exclusion of consequential damages, so these restrictions may not apply to you.) This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Your acknowledgement and agreement to fully and completely abide by the above mentioned disclaimer of warranty is contractually binding to you upon your transfer of currency (money order, cashier's check, or credit card) for purchase of your SDI Technologies product.

© 2012 SDI Technologies, Inc. All rights reserved

**Questions? Visit www.ihomeaudio.com
or call 1-800-288-2792 Toll Free**