

AVerMedia[®]
AVer MediaCenter 3D

User Manual

Disclaimer

All the screen shots in this documentation are only example images. The images may vary depending on the product and software version. Information presented in this documentation has been carefully checked for reliability; however, no responsibility is assumed for inaccuracies. The information contained in this documentation is subject to change without notice.

Copyright

©2011 by AVerMedia Technologies, Inc. All rights reserved.

No part of this document may be reproduced or transmitted in any form, or by any means without the prior written permission of AVerMedia Technologies Inc. AVerMedia Technologies Inc. reserves the right to modify its models, including their characteristics, specifications, accessories and any other information stated herein without notice. The official printout of any information shall prevail should there be any discrepancy between the information contained herein and the information contained in that printout.

"AVerMedia" is a trademark (or registered trademark) of AVerMedia Technologies, Inc. Other trademarks used herein for description purpose only belong to each of their companies.

International Headquarter

Address	No.135, Jian 1st Rd., Zhonghe Dist., New Taipei City 23585, Taiwan (R.O.C.)
Website	www.avermedia.com
Telephone	886-2-2226-3630

US Office

Address	423 Dixon Landing Road – Milpitas, CA - 95035
Website	www.avermedia-usa.com/avertv
Telephone	(408) 457-3359
Fax	(408) 263-1687
Tech Support	(408) 942-2121 or (877) 774-4543
Telephone	(408)-263-3828

Table of Contents

Chapter 1	Introduction	5
1.1	Device Introduction	6
1.2	System Requirements	7
1.3	Activating AVer MediaCenter 3D	7
1.4	Overview of AVer MediaCenter 3D	8
	AVer MediaCenter 3D Console	8
	Control Buttons On Title Bar	9
	Control Buttons On Playback Window Control Panel	9
	Navigation Tree	10
1.5	Running AVer MediaCenter 3D for the First Time	11
Chapter 2	Getting Started	13
2.1	Capture	14
	Capture in Live	15
	Operations of TimeShift	16
	Operations of Recorded Files	17
	Using Schedule Recording	18
2.2	Capture in 3D	20
	Recording a 3DTV Program	20
	Playing a Recorded 3DTV Program	21
2.3	Video	23
	Playing Video Files	23
2.4	Music	24
	Adding Music to your Playlist	24
	Playing Music	25
2.5	Images	26
	Viewing the Captured Images	26
	Playing Slide Show	26
Chapter 3	Advanced Operations	27

3.1 General Settings	28
Configure Recording.....	28
Configure Snapshot.....	29
More Options	30
3.2 Capture Settings	31
Configure SD Input Source > SD recording format.....	31
Configure SD Input Source > SD Timeshift & Color Adjustment.....	32
Configure SD Input Source > SD Color Adjustment	32
Configure HD Input Source	33
Video Standards	34
Closed Caption.....	34
3.3 Video Settings	35
Picture-in-Picture (PIP) / Picture-by-Picture (PBP) Display.....	35
3.4 Images Settings	36
3.5 About	37

Appendix	39
-----------------	-----------

Hot Keys	40
Glossary	41

Chapter 1

Introduction

Thanks for purchasing **DarkCrystal HD Capture Pro/AVerTV HD DVR(USA)**. This high quality capture card is especially designed for professional players with high standards towards image/ video quality.

DarkCrystal HD Capture Pro/AVerTV HD DVR(USA) also comes with a powerful application **AVer MediaCenter 3D**, allowing you to capture high resolution images, record HD video clips, create your own slideshows with both the captured and images of other sources, and even create your own music library for both audio and video luxury.

Each function of **AVer MediaCenter 3D** goes further with detailed options for a more professional taste. There is no more need to compromise yourself with all fixed default settings using a capture card.

This Chapter will guide you through the essential information of **AVer MediaCenter 3D**. Please read this chapter before using **AVer MediaCenter 3D**.

Device Introduction	6
System Requirement	7
Activating AVer MediaCenter 3D	7
Overview of AVer MediaCenter 3D	8
Running AVer MediaCenter 3D for the First Time ...	11

1.1 Device Introduction

What is video capture card and what can it do?

Video capture cards are a class of video capture devices designed to plug directly into expansion slots in personal computers and servers.

A video capture card product typically includes a driver to get the device going and a bundled software to bring out the best features of it. The bundled software usually further processes the video for specific purposes. The functions of the video capture cards vary from one another. Some are used to capture base band analog composite video, S-Video, some are equipped with tuners, RF-modulated video, some others are specialized cards that support digital video via digital video delivery standards including Serial Digital Interface (SDI) and some, with the emerging hi-tech HDMI standard becoming more popular, support both standard definition (SD) and high definition (HD) variants, and this **DarkCrystal HD Capture Pro/AVerTV HD DVR(USA)** you just purchased belongs to the last model.

The functions of the supplied **AVer MediaCenter 3D** for video capture cards include converting a live analog source into some type of analog or digital media, (such as a VHS tape to a DVD), archiving, video editing, scheduled recording (such as a DVR), etc.

Product Name	DarkCrystal HD Capture Pro/AVerTV HD DVR(USA)
Model No.	C027
Supported Signal Sources	S-Video / Composite (RCA) / Component (YPbPr, 1080i) / HDMI (HDCP support, 1080i) / Analog Audio L/R *HDCP content recording is not supported.



1.2 System Requirements

System requirements are described in details below. Before using **AVer MediaCenter 3D**, please verify that your PC meets the requirements below.

	SD Video Capturing	HD Video Capturing (MPEG-2)	HD Video Capturing (H.264)	3D Content Capturing
CPU	Intel® Pentium® 4 3.0 GHz AMD Athlon™ 64 3200+	Intel® Core™ Duo 2.4 GHz AMD Athlon™ 64x2 Dual Core 2.8 GHz	Intel® Core™2 I5 750 or AMD equivalent	Intel® Core™ 2 Duo or AMD Athlon™ X2 or above
VGA Card	VGA card with support for DirectX 9.0 or above.		VGA card* with 512M memory supports DirectX 9.0 or above. For HDTV, VGA card should support DXVA. For HD Input Source, standalone graphics card is recommended for HD video capturing.	
RAM	512MB RAM or above		1G RAM or above	1 GB or above
OS	Windows® XP SP2/ Windows® Vista™ / Windows® 7 32/64 bit			Windows® Vista™ or Windows 7 32/64 bit

*Anaglyph, polarized, and shutter display modes are all supported. To watch 3DTV or videos without any hardware upgrade, choose anaglyph display mode. To get the best 3D effect, we strongly recommend to use NVIDIA® 3D Vision™ Kit, 3D-supported graphics card (NVIDIA® GeForce® GT 240 recommended or above) and 3D-ready display.

1.3 Activating AVer MediaCenter 3D

To launch **AVer MediaCenter 3D**, double-click shortcut  on desktop, or go to **Start -> Programs -> AVerMedia**. If **AVer MediaCenter 3D** is launched already, double-click **AVer Quick**  icon on the lower right of the system tray to bring up the main screen to your desktop.

1.4 Overview of AVer MediaCenter 3D

The functions of **AVer MediaCenter 3D** are categorized into five buttons on the main menu, including “**Capture**”, “**Video**”, “**Music**”, “**Images**” and “**Settings**”. This section briefly introduces main menu, sub menus and initial setups. For more information on advanced operations, please refer to contents from Chapter 2.

➤ AVer MediaCenter 3D Console



Description

- ❶ Title bar: Control over AVerMedia Console
- ❷ Main function menu: Capture, Video, Music, Images, Settings
- ❸ Playback window: Display of the selected source/ file
- ❹ Playback window control panel: Control over the Playback window
- ❺ System time display: indication of current time

➤ Control Buttons On Title Bar



Click	To ...
	Go back to the main menu
	Go back to a previous level
	Bring out the user's manual
	Minimize AVerMedia Console to system tray
	Restore AVerMedia Console to previous size
	Exit AVerMedia Console


➤ Control Buttons On Playback Window Control Panel



Click	To ...
	Switch from real-time video to TimeShift mode. / Pause the playback temporarily.
	Stop playback, recording, TimeShift, etc.
	Play the selected file.
	Record the current program.
	Play the previous/next file on the playlist.
	Move backward or skip forward in intervals.
	Capture a single image or a sequence of images.
	Enable the PIP function.
	Switch to different aspect ratios.
	Mute/ Unmute the audio volume.
	Increase or decrease the audio Volume.

➤ Navigation Tree


This is an overview of the operations under each main function. For specific operation of each function, please refer to the table of contents and go to its according page.



1.5 Running AVer MediaCenter 3D for the First Time

When you run the **AVer MediaCenter 3D** for the first time, the **Setup Wizard** will automatically pop up and take you through all the necessary steps for a complete setup.


1. When Setup Wizard dialog box appears, click **Yes**.



2. Select **AVerMedia C027 PCIe HD Capture Device** under **Primary Device** dropdown menu and click **Next** to continue.




3. Select from the dropdown menu of **Country/ S-Video/ Composite Video/ HD Input** according to the place you use this device, the signals provided in your region, and the signals of the equipment connected to your PC. Then click **Next**.



4. The wizard will guide you through to complete the setups for the available signals. Click **Next** to continue or click **Skip** to ignore the setups.

5. Click **Finish** to complete the initial settings or click **Next** to set up other devices if any.

Note: To re-configure all the settings, go to **“Settings”** → **“General”** → **“Run Wizard Again.”**



Chapter 2

Getting Started


This Chapter includes descriptions of the five main functions on **AVer MediaCenter 3D** main menu. Each basic operation is followed by more detailed information on sub menu under each function.

Before using the **AVer MediaCenter 3D**, it is highly recommended to read through the contents of this chapter.



- Capture14
- Capture in 3D20
- Video.....23
- Music24
- Images26

2.1 Capture

You can capture a high quality still image, a sequence of continuous images, or record a video clip when watching videos either from live or previously recorded sources or playing games in **AVer MediaCenter 3D**.



Basic Operations


1. Select a video source from the left menu and then the desired input signal source from the dropdown menu on the upper right.
2. Click  to capture a still image or  to record a clip of video during the video playback.





The captured/ recorded files are saved under **Recorded Files**.

➤ Capture in Live

Live video refers to any available current video source ready for playback. This can refer to any supported signal coming from the connected device, such as a DVD player or a video gaming device.

Note : Video source setup is supposed to be completed when running **AVer MediaCenter 3D** for the first time. If not, please go to **Settings** -> **General** for reconfiguration.



1. Select an input source from the dropdown menu on top of the main playback window.
2. Click  on the control panel to start the playback.
3. Click  to get a still image or  to start recording a clip of video. Click  again to stop the recording. The captured images/ video clips are saved in Recorded Files.



Note

1. To find the captured/ recorded files, click **Recorded File** button on the left.
2. To change the storage location of the captured/ recorded files, go to **Settings** -> **General** -> **Configure Storage**.


➤ Operations of TimeShift

The **TimeShift** function performs background recording of a video playback, and allows you return to any part of the recorded program. At the same time, the live program continues to be recorded and played back so you won't miss any part of the show. You can also advance forward to skip commercials or rewind to replay scenes again.



1. Select an input source from the dropdown list on the right. When the playback starts, click **TimeShift** on the left menu.
2. Click  on the control panel. Both the background recording time and the current-show time are shown on the upper-right of the main playback window.
3. Click  to move backward in fixed intervals until reaching the part where you left off.

Note

The application will create a temporarily recorded file when the **TimeShift** function is on for an ongoing video. This file will be removed when you select .

➤ Operations of Recorded Files

All the recorded files are listed with recording time and date. Reorganize the files with the menu on the left.




1. Go to **Capture** -> **Recorded Files**.
2. Reorganize the recorded files by checking the options provided on the left menu.
3. Select the desired file from the list and then click **Play** on the control panel to start playback.

➤ Using Schedule Recording

The TimeShift function performs background recording of a program, and lets you return to any part of the recorded program.

1. Go to **Capture -> Schedule Recording**.
2. Click **New Schedule** to go to detail setting window.
3. Edit a name for the schedule, and select the desired option from the dropdown menu under **Task** and **After Playback Mode**.
Click **Save** on the left menu to save your settings and bring up the next edit window.





4. Select the desired signal Source under **Source**.
5. Check the desired recurrent frequency and enter the date of the program for the schedule. Click **Save** on the left menu to save your settings and bring up the next edit window.



6. Enter the airing time of the program to be recorded.
7. Select the file format for the program to be recorded.
8. Enter the duration of the program to be recorded.





9. Check Split file Size if the file size of the program to be recorded is estimated to be over the capacity of one DVD. This is useful if you want to burn the file onto DVD disks.
10. Click  to change the default destination folder for recorded files.



2.2 Capture in 3D

▶ Recording a 3DTV Program

To record a 3DTV program

1. If the screen hasn't gone into 3D watching full screen mode, click  /  on the control bar at the lower right of the screen and select **Record** to start.




2. To end 3D recording, double click on the screen, press **Esc** key on your keyboard, or use the **Back** key on the remote control.

Note:

1. The screen goes into full screen mode after you start recording.
2. Please **DO NOT** exit full screen mode during 3D video recording or the recording will be stopped.
3. Any system messages will end 3D video recording or 3DTV viewing.


▶ Playing a Recorded 3DTV Program


1. Select **TV** → **Recorded Files**.
2. All the recorded files are listed here.
3. You can view those file by date, title or status.
4. Select the desired file.



OR,

1. Select **Video**.
2. You may see some recorded video files are listed on the right hand section of the screen. Or you can select **More Videos** to choose other folders.
3. Select the file you want.




- Click  on the control bar at the lower right of the screen and the **3D Setting** dialogue box appears.



- Select **3D Red/Cyan**, **Micro-polarized 3D**, or **NVIDIA® 3D Vision™** from the **Display Mode** drop-down menu according to your 3D watching equipments and click **OK** to confirm and go back to **AVer MediaCenter 3D** main TV screen.



- Click  on the control bar at the lower right of the screen to start. Now you can put on the 3D glasses and enjoy the vivid 3D program.

- To end 3D watching, double click on the screen, press **Esc** key on your keyboard, or use the **Back** key on the remote control.




2.3 Video

You can watch video files besides the recorded files in **Video**.

▶ Playing Video Files

1. Go to “Video”.
2. The video files recorded by **AVer MediaCenter 3D** are listed on the right. Double click to start playing the selected file. Use the main playback window control panel to control the playback.



3. To find more videos, click **Change Disk** on the left menu, all available disks on your PC are shown in thumbnail icons on the right.
4. Click on the icon to locate where other video files are.







2.4 Music

You can add, delete, and reorganize your music files and create your own library for enjoyment in **Music**.

➤ Adding Music to your Playlist

1. Go to **“Music”** → **“Add Music”** and then the desired folder of music files.
2. Select the tracks you wish to add to the playlist.
3. Select **OK** to go back to the previous level.




4. The selected files are added to the blanks on the right of the window.
5. Click  /  to reorder the playback sequence.
6. Click  to remove one track or select **Remove All** to delete all tracks in the playlist.










▶ Playing Music

To play music:

1. Go to “**Music**”.
2. Check **Sequential** to play tracks in order or **Random** for shuffle playback.
3. Check **Loop** for repeat playback.



4. Click  to start playing music.
5. Click on the following buttons to control your playback.

-  Advance the playback.
-  Rewind the playback.
-  Play the next track.
-  Play the previous track
-  Freeze the playback.
-  End the playback



2.5 Images

Images allows you not only to view captured images/ pictures but create and playback a slide show.

➤ Viewing the Captured Images

1. Go to “**Images**”.
2. The captured images are displayed in matrix on the right of the window.
3. Click on the thumbnails to view the images in full screen.
4. Click **More Pictures** to locate the folder of the desired pictures and add them to the **Images**.



Note: You can view thumbnails and enjoy live music at the same time

➤ Playing Slide Show

1. Go to “**Images**”.
2. Click **Play Slide Show** to start a slide show.
3. To stop the slide show and go back to the previous page, click  on Title Bar.



Chapter 3

Advanced Operations



Beyond basic usage, what else you can do with **AVer MediaCenter 3D** in this chapter; we take you to the next level and explain the advanced features of this application.

- General Settings28**
- Capture Settings31**
- Video Settings35**
- Images Settings36**
- About37**

3.1 General Settings


In **General Settings**, you can change the destination folder for recorded files, edit recording time and file size, assign the number of image you want to capture, and reset the Windows power options, etc.


➤ Configure Recording

1. Go to “Settings” → “General” → “Configure Recording”.
2. Click  to locate a preferable folder for recorded files as desired.
3. Click  to go back to the previous level or Click **Change Disk** on the left menu to relocate from hard drives.
4. Click **OK** to confirm the selection.
5. Enter the desired length of recording time, or the recording continues until the hard drive of recording storage folder reaches its maximum capacity.
6. **AVer MediaCenter 3D** allows you to divide the recorded files in segments for burning onto **CD** (650 MB) and **DVD** (4096 MB). Check **Split File Size** and select the appropriate video file size from the drop-down menu so that CD/ DVD burning doesn't fail due to over-sized files. Or you can click **Customize** to assign the file size you want.
7. Click **Save** to save the settings or click **Cancel** to abort without saving. To change back to factory default settings, click **Default**.




➤ Configure Snapshot

1. Go to “Settings” → “General” → “Configure Snapshot”.
2. Click  to locate a preferable folder for captured images.
3. Enter the desired number of images to be captured, the interval between each image taken, and the format of the captured image to be saved.



➤ More Options

1. Go to “Settings” → “General” → “More Options”.
2. Select the language for the application.
3. Click **Save** to confirm the selection.




3.2 Capture Settings

In **Capture** settings, you can select SD (Standard Definition) or HD (High Definition) sources for capture/ recording results.

SD input sources usually refer to signals coming from analog TV systems, VCR (Video Cassette Recorder)/ VHS or older video game stations, connected by composite RCA connectors or S-Video (Separate Video) 4-pin mini-DIN connectors.

➤ Configure SD Input Source > SD recording format

1. Go to “Settings” → “Capture” → “Configure SD Input Source”.
2. Click **Configure Recording**.
3. Select a desired file format from the dropdown menu for the recorded file.



4. Click **Edit** to bring out an edit page on more detailed settings of the file to be recorded.




➤ Configure SD Input Source > SD Timeshift & Color Adjustment

1. Go to “Settings” → “Capture” → “Configure SD Input Source”
2. Click **Configure Timeshift**.
3. Check to decide on the video quality of SD Timeshift.



➤ Configure SD Input Source > SD Color Adjustment

1. Go to “Settings” → “Capture” → “Configure SD Input Source”
2. Click **Configure Color Adjustment**.
3. Use **+** / **-** to adjust the values for SD color brightness, contrast, hue, saturation and sharpness.
4. Check **Apply All** to confirm all your settings.



➤ Configure HD Input Source


In **Capture** settings, you can select SD (Standard Definition) or HD (High Definition) sources for capture/ recording results.

HD signal sources usually refer to any video system of higher resolution than standard-definition (SD) video, and most commonly indicates resolutions of 1,280×720 pixels (720p) or 1,920×1,080 pixels (1080i/1080p). HD signals sources usually come from digital TV systems, set-top boxes, the optical disc delivery system such as upconvert DVD players, HD DVD players, and Blu-ray Disc players, the video tape format D-VHS or latest video game stations, connected by component connectors or HDMI cables.

1. Go to “Settings” → “Capture” → “Configure HD Input Source”.
2. Select **Configure Recording**.
3. Select the desired format for the recorded file from the dropdown menu.





4. Click **Edit** to bring out an **Edit** page.
5. Click ▼ to select an option from the dropdown menu, and use + / - to adjust the values for HD recording sizes, rate and audio quality.



➤ Video Standards


In **Video Standards**, you can change the settings that were made when you first ran the **AVerMedia Center**. Click to select from the dropdown menu and then **Save** to confirm your changes.

1. Go to “Settings” → “Capture” → “Video Standards”.
2. Click  to select the desired options from the dropdown menu for from **Country/Region** to **HD Input Source**.



➤ Closed Caption

The "closed" in **Closed Caption** means that only those who choose to decode or activate this function can see the captions of the audio script on the programs, and sometimes non-audio descriptions or information of the programs are included as well. This function is initially designed for the hard of hearing, and then extended its service for people whose first language is not the spoken language, for most of the time it refers to English.









1. Go to “Settings” → “Capture” → “Closed Caption”.
2. Click  to select the desired closed captioning channels from the dropdown menu.



3.3 Video Settings

➤ Picture-in-Picture (PIP) / Picture-by-Picture (PBP) Display

With the PIP/PBP feature, you are able to playback recorded video files, and at the same time, watch video.


1. Go to **"Video" → "More Videos"**.
2. Select the desired file, or select  to locate the desired video files.
3. When playing the video file, click  on the control panel to enable the PIP function.
4. Click  to switch between Full screen mode, PIP mode and PBP mode (as shown on the right).
5. By default, the selected recorded video is displayed on the main screen, and the live video source is on the PIP/PBP screen.
6. To switch and listen to the sound of either video, click on the arrow buttons to switch between the PIP/PBP screens.
7. In PIP mode, to change the size of the PIP screen, click   to shrink the image or click   to enlarge the image.
8. To exit the PIP-sizing mode, click .




(Full Screen Mode)



(PIP Mode)





(PBP Mode)



3.4 Images Settings

In **Images** settings, you can set up the playback details for the captured images, or even add in other images of your previous collection to edit your own slide show.


1. Go to “**Settings**” → “**Images**”.
2. From **Play Settings** dropdown menu, select **Sequential** to play a slide show in order or **Random** for shuffle playback.
3. Enter a number under **Interval Time** for each image to be shown.
4. Select the transition effect between image shift under **Transition Effect**.
5. Click  to locate a preferable folder for recorded files as desired.
6. During the location of a desired folder for the recorded files, click  to go back to the previous level or Click **Change Disk** on the left menu to relocate from hard drives.
7. Click **OK** to confirm the selection.
8. Check **Including Sub-Folder Pictures** to create a slide show with all the pictures in the current folder and its subfolder.
9. Check **Hide window on slide show mode** to view pictures without frames.
10. Click **Save** to confirm your settings or click **Cancel** to abort without saving. Click **Default** on the left menu to restore to factory default settings.



3.5 About

AVer MediaCenter 3D provides a convenient tool, allowing users to access to our customer after sale service via **AVerMedia's** website easily.

1. Go to **"Settings" → "About"**.
2. Connect to the Internet and then click **Product Information** to access the product information webpage. Or Click **Technical Support** to connect to our technical support webpage.
3. Please leave the information on your product model and driver version on the webpage for us to solve your problems more efficiently.



Ps. All the screenshots in this documentation are only example images.

Appendix

More tips and explanations are included in this chapter.

Hot Keys	39
Glossary	40

► Hot Keys

Hot Keys	Description
Up/Down/Left/Right arrow	Move up, down, left or right to select the desired item.
Tab	Move to next item.
Space	Confirm the selected tracks or folders when under the main menu -Music .
F1	Open the user manual.
F8	Turn off / on the sound.
F9	Volume Down
F10	Volume Up
Back	Back to previous page
Ctrl + A	Choose between available audio modes.
Ctrl + Shift + A	Change aspect ratio
Ctrl + D	Display the OSD.
Ctrl + E	A shortcut to your main menu-- "Video".
Ctrl + Shift + F	Skip forward in intervals.
Ctrl + I	A shortcut to your main menu-- "Images"
Ctrl + M	A shortcut to your main menu-- "Music"
Ctrl + N	Capture an image or a continuous sequence of images.
Ctrl + Shift + N	Play next file in the playlist.
Ctrl + O	View the recorded file list.
Ctrl + P	Freeze the playback temporarily.
Ctrl + Shift + P	Play the selected file.
Ctrl + S	Stop the playback, recording, TimeShift, etc.
Ctrl + Shift + S	Enable the TimeShift function.
Ctrl + T	A shortcut to your main menu-- "Capture"
Ctrl + Shift + T	Show Video programs in full screen.
Alt + Home	Go to the main page of AVer MediaCenter 3D
Ctrl + R	Record the current program.
Ctrl + Shift + R	Play previous file in the playlist.
Alt + T	View Teletext information.
Alt + B	Jump to the Blue Teletext page.
Alt + G	Jump to the Green Teletext page.
Alt + R	Jump to the Red Teletext page.
Alt + Y	Jump to the Yellow Teletext page.
Alt + Shift + S	Set the time to put your computer into Stand By/Hibernate mode, exit the application or turn off the computer.
Alt + S	Turn on/off the PIP-sizing function.
Alt + P	Turn on/off the PIP-positioning function.
Alt + M	Activate the Picture in Picture function (PIP).
Ctrl + Shift + C	Switch between available signal sources.

AVI

AVI is the most common video file format for playback on the computer. It can be saved in uncompressed form if you want high quality video, or compressed using any of the available codecs if you want to minimize the file size.

Aspect Ratio

Aspect ratio indicates the ratio of the width of an image to its height. The two most common aspect ratio of home video is 4:3 and 16:9.

DVD

When you choose this format, the recorded video file will be saved in MPEG-2 format that is compliant with DVD standards. Standard DVD frame size and frame rate are 720 x 480 pixels at 29.97 fps for NTSC and 720 x 576 at 25 fps for PAL.

H.264

Videos compressed using MPEG-4 standard are two or three times more efficient than MPEG-2. This format can be applied to a wide variety of applications or networks and systems like HD-DVD, Digital TV, Broadcast and Streaming applications.

Hibernate

Hibernation is a state in which your computer shuts down to save power but first saves everything in memory on your hard disk.

iPod

A video format base on H.264 standard but has smaller video bit rate. It's an iPod -compatible format.

MPEG-2

Videos compressed using MPEG-2 have extremely high quality pictures and full CD-quality sound. Choose MPEG-2 format for video files that are intended for DVD-ROM playback on a computer or if you want broadcast quality videos.

PIP (Picture in Picture)

PIP allows you to view two or more video sources at the same time wherein the small inset screens overlaid on the main screen.

PBP (Picture by Picture)

PBP allows you to view two or more video sources side by side on a display so that all channels are visible.

Stand By

Stand By is a state in which your monitor and hard disks turn off, so that your computer uses less power.

