



PARKING SENSOR SYSTEM



For more information or to see the complete
line of PYLE products please visit our website
www.pyleaudio.com

- PLPSE8WL
- PLPSE9WL

GENERAL INTRODUCTION

● Features:

- ◆ The parking sensor system will start automatically after the gear on the “R”
- ◆ High-clear display show the digital distance and left and right direction.
- ◆ Four steps of alarm sound to alert the distance
- ◆ Identify itself automatically and take priority of the dangerous distance alarm
- ◆ Design for the whole day and anti- electromagnetism disturb

● Technical parameters


- ◆ Supply voltage: + 12V ± 2V(DC)
- ◆ Power consumption:3.5W(max)
- ◆ Work temperature:-40~+80°C
- ◆ Detecting distance:2.0 M~0.3M
- ◆ Display distance: 2.0 M~0.3M
- ◆ Alarming distance: ≤ 1.5 M
- ◆ Alarming volume: ≥ 75dB

CONDITION DIAGNOSIS AND TROUBLE SHOOTING

Phenomenon	Reason	Inspection
No reaction after installation	1.No power supply or low voltage. 2.Lose connection of wire. 3.Fail to test any obstacle when driving backwards.	1.If the voltage of battery is normal, and control wire is correctly connected. 2.If each wire is well connected.
Mute, unclear voice or low volume	1.Mute status has been set in monitor. 2.The installing surrounding of the display and the speaker have been blocked by something. 3.Low voltage of battery.	1.According to the operation of specification, absolve the setting of mute. 2.Cheak if the display and the speaker have been blocked by something . 3.Timely recharging battery to ensure the normal working of main unit.
Haste alarming sound	1.Incorrect installation or loosening of sensor. 2.Damage of sensor. 3.Bad installing environment of main unit.	Correctly install according to specification. If necessary, turn to the guidance of professional persons and periodical inspection. Please change on time the sensor if it is damaged manually.
Unusual phenomenon of probing distance	1.Abnomaly of battery. 2.Loosening of the wire of sensor or with dirt. 3.Dirt in the surface of sensor. 4.Incorrect installation of sensor.	1.Check if the voltage of battery is normal. 2.Correctly connect wires according to specification and check if the connecting points are dirty. 3.Retain the cleanliness of sensor. 4.Correctly install according to the specification.


CAUTION

Circumstances showed under will affect the probing result




- 1) Be careful reading the instruction before usage.
- 2) The speed should be less than 5km/hr when parking in order to avoid collision with obstacle because of inertia.
- 3) Probing distance varies according to different object. For example, such obstacles as slippery inclination, ball shape objects, irregular object, sound-absorbed object will affect the probing result.
- 4) The damage of sensor, or its being dirt, covered by snow, frost, earth, will also affect the probing result.
- 5) During installation, please be careful not to mangle, prick, break and lengthen the wire of sensor.
- 6) **This product is only for the purpose of assistance and reminder and we will not take any responsibility for any accident.**

GENERAL INSTALLATION CHART




※ All interfaces must be connected carefully and correctly. Wiring distribution must be in a distance as far as possible from ignition coil and high-voltage wire.

GENERAL INSTALLATION CHART




3

CHECK UP THE DISTANCE




12

DETECTIVE RANGE




2 sensors







4 sensors

SENSOR POSITION



INSTALLATION FOR STICK-UP SENSOR




WORKING PRINCIPLE

After entering “R” grade, the system will working automatically. When the barrier distance is more than 2m, the monitor will not display digital distance left and right direction. When less than 2m, the monitor will display digital distance left and right direction. When less than 1.5m, the system will alarming and the tempo will gradually quick with the distance short.


The design of this system takes priority of danger distance alarming. From the information we know the impact direction . When more information on the left, it means the impact is on the left, contrarily, the barrier is on the right, when the left information equalize the right information, it means the impact is in the middle.

INSTRUCTION OF DETECTING BARRIER



9

INSTALLATION FOR EMBED SENSOR



6

LCD DISPLAY

PLPSE9WL



Digital display and 2 sides 4-Colour & 4-stage LED indicator with beeper

Stage	The distance between car and the barrier	Alarm sound	The colour of LED light	Remark
1	2.0-1.5M safe	Without	Blue	Reversing safely
2	1.5-1.0M safe	Bi--Bi--Bi--	Green	
3	1.0-0.6M cautious	Bi--Bi--Bi--	Orange	Reversing slowly
4	0.6-0.4M dangerous	Bi-Bi-Bi-	Red	Stop reversing
5	0.4-0.1M dangerous	Bi-----		

7

LCD DISPLAY

PLPSE8WL



Digital display and 2 sides 4-Colour & 4-stage LED indicator with beeper

Stage	The distance between car and the barrier	Alarm sound	The colour of LED light	Remark
1	2.0-1.5M safe	Without	Blue	Reversing safely
2	1.5-1.0M safe	Bi--Bi--Bi--	Green	
3	1.0-0.6M cautious	Bi--Bi--Bi--	Orange	Reversing slowly
4	0.6-0.4M dangerous	Bi-Bi-Bi-	Red	Stop reversing
5	0.4-0.1M dangerous	Bi-----		

8