




User's Guide



<http://www.omega.com>
e-mail: info@omega.com



DRA-RTM-8
ANALOG MULTIPLEXER



OMEGAnetSM On-Line Service
<http://www.omega.com>

Internet e-mail
info@omega.com

Servicing North America:

USA:
ISO 9001 Certified
One Omega Drive, Box 4047
Stamford, CT 06907-0047
Tel: (203) 359-1660
FAX: (203) 359-7700
e-mail: info@omega.com

Canada: 976 Bergar
Laval (Quebec) H7L 5A1
Tel: (514) 856-6928
FAX: (514) 856-6886
e-mail: canada@omega.com

For immediate technical or application assistance:

USA and Canada: Sales Service: 1-800-826-6342 / 1-800-TC-OMEGASM
Customer Service: 1-800-622-2378 / 1-800-622-BESTSM
Engineering Service: 1-800-872-9436 / 1-800-USA-WHENS M
TELEX: 996404 EASYLINK: 62968934 CABLE: OMEGA

Mexico and Latin America: Tel: (95) 800-TC-OMEGASM FAX: (95) 203-359-7807
En Espanol: (95) 203 359-7803 e-mail: espanol@omega.com

Servicing Europe:

Benelux: Postbus 8034, 1180 LA Amstelveen, The Netherlands
Tel: (31) 20 6418405 FAX: (31) 20 6434643
Toll Free in Benelux: 06 0993344
e-mail: nl@omega.com

Czech Republic: Ostravska 767,733 01 Karvina
Tel:42(69)6311899 FAX:42(69) 6311114
e-mail: czech@omega.com

France: 9, rue Denis Papin, 78190 Trappes
Tel: (33) 130-621-400 FAX: (33) 130-699-120
Toll Free in France: 0800-4-06342
e-mail: france@omega.com

Germany/Austria: Daimlerstrasse 26, D-75392 Deckenpfronn, Germany
Tel: 49 (07056) 3017 FAX: 49 (07056) 8540
Toll Free in Germany: 0130 11 21 66
e-mail: germany@omega.com

United Kingdom: 25 Swannington Road, P.O. Box 7, Omega Drive,
ISO 9002 Certified Broughton Astley, Leicestershire, Irlam, Manchester,
LE9 6TU, England M44 5EX, England
Tel: 44 (1455) 285520 Tel: 44 (161) 777-6611
FAX: 44 (1455) 283912 FAX: 44 (161) 777-6622
Toll Free in England: 0800-488-488
e-mail: uk@omega.com

It is the policy of OMEGA to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification. The information contained in this document is believed to be correct but OMEGA Engineering, Inc. accepts no liability for any errors it contains, and reserves the right to alter specifications without notice. **WARNING:** These products are not designed for use in, and should not be used for, patient connected applications.

Contents

1. GENERAL DESCRIPTION
2. MOUNTING INSTRUCTIONS
3. REPLACING FUSES
4. ASSEMBLY
5. CURRENT INPUTS
6. CONNECTING TRANSMITTERS TO THE MULTIPLEXER
7. CONNECTING Pt-100 TO THE MULTIPLEXER
8. CONNECTING THE MULTIPLEXER TO A PLC
9. CONTROL
 - 9.1 Enable
 - 9.2 Address
 - 9.3 Address Polarity
 - 9.4 Control Tables
10. CALIBRATION
 - 10.1 Calibration Procedure
 - 10.2 Calibration Tables
 - 10.2.1 "ZERO" - Coarse Calibration Tables
 - 10.2.2 "SPAN" - Coarse Calibration Tables
11. MULTIDROP CONFIGURATION
12. SPECIFICATIONS

1. GENERAL DESCRIPTION

The DRA-RTM-8 is a multiplexer for 16 analog inputs - eight of which, marked 1-8, are direct inputs for Pt-100 sensors, while the remaining (9-16), are for 4-20mA current loops.

The DRA-RTM-8 output format is a 4-20mA current loop, with a 28mA limitation.

Each Pt-100 input has its own signal conditioner, allowing each input to be calibrated separately. Each signal conditioner includes six DIP switches for coarse calibration and two potentiometers for fine tuning.

2. MOUNTING INSTRUCTIONS

The DRA-RTM-8 is designed for standard DIN rail mounting.

Place the unit on the upper part of the mounting rail with the fastening tab facing down. Using a suitable flat screwdriver loosen the tab slightly and attach the unit to the rail. Once the tab is loosened, ensure that the unit is fastened securely in place.

3. REPLACING FUSES

To replace a blown fuse, disassemble the unit as follows:

- a. Take off both terminal strips by removing the four screws at the edges.

Note: This does not require disconnecting the cables connected to the strips.

- b. Remove the front panel using a suitable flat screwdriver. Press down gently on the plastic springloaded tabs located in the slots on either side of the unit.
- c. Disconnect the flat connectors which connects the front panel printed circuit.
- d. Replace the blown fuse.

WARNING: Never install a fuse rated more than 800mA

4. ASSEMBLY

The DRA-RTM-8 unit includes two printed circuit cards designated as P.N 7020 and P.N 7021. The two printed circuit cards should occupy the slots in the enclosure according to fig 1.

Insert the two printed cards into their slots. Connect the flat cable between them. Connect the front panel flat cables. The panel must be inserted into the grooves on both sides of the case while pressing down until a distinct "click" is heard. Assembly is completed by laying the terminal strips on place.




Figure 1.

Note: The terminal strips are polarized and must not be placed backwards.

5. CURRENT INPUTS

The eight 4-20mA current inputs are marked as channels 9-16. These inputs are for current only. The "COM" input is the return for all the current channels. It is possible to connect any current source, as long as a closed loop is maintained.

WARNING: Voltage sources should not be connected to the current inputs, as permanent damage might occur.

6. CONNECTING TRANSMITTERS TO THE MULTIPLEXER

6.1 TWO WIRE TRANSMITTER

A Two-Wire transmitter is connected so that its positive terminal is connected to the positive terminal of the power supply, and its negative terminal is connected to the "I" terminal.

(see fig 2)




Figure 2.

6.2 FOUR WIRE TRANSMITTER

A Four-Wire transmitter is connected so that its positive terminal is connected to the "I" terminal, and its negative terminal is connected to the "COM" terminal. (see fig 3)




Figure 3.

7. CONNECTING Pt-100 TO THE MULTIPLEXER

The Pt-100 probe should be connected according to fig 4. The three wires connecting the probe should be identical. The distance of the probe can be up to 200 meters. A shielded cable is recommended. The shield should be grounded at one point. When possible, connect the ground at the multiplexer's end.




Figure 4.

8. CONNECTING THE DRA-RTM-8 TO A PLC

The multiplexer output should be connected to 4-20mA input of the PLC analog module (see fig 5).

The DRA-RTM-8 multiplexer generates the output current, therefore the PLC analog module should be configured for four wire transmitter connection.

WARNING: NEVER apply 24Vdc to the DRA-RTM-8's +I_o terminal as in two-wire connection, and make sure that the PLC's analog module is configured as a passive input.

9. CONTROL

The DRA-RTM-8 unit is controlled via four address lines and one E (Enable) line. The control terminals (Address and Enable), were designed to receive control signals from TTL levels up to 60V so that almost any PLC's DC output module can be used. (see fig 5)




Figure 5.

9.1 ENABLE

The unit is enabled when a logical "1" ($5V < E < 60V$) is connected to the E Terminal. In a disabled state, the DRA-RTM-8 outputs no current and reflects a Hi-Z state. This feature allows the connection of several DRA-RTM-8 units by tying their outputs and control in parallel and addressing them by controlling the individual Enable terminals.

9.2 ADDRESS

The required channel is selected by four address lines.

The operating voltages are:

Logical "1" $5V < V_i < 60V$

Logical "0" $0V < V_i < 0.5V$




Figure 6.

9.3 ADDRESS POLARITY (see fig 6)

Address polarity is controlled by three internal pins and a jumper over two of them, located on PN 7021 printed circuit board, accessible behind the Enable terminal. The unit is supplied with the jumper set for "true high" control logic, i.e. "0000" selects channel #1, and "1111" selects channel #16.

Moving the jumper to the second alternative, reverses the logic.

Note: If the address control voltages are generated from different power supplies, then its negative terminal should be connected to the DRA-TM-8's "COM" terminal.

9.4 CONTROL TABLES

9.4.1 "TRUE LOW" SETTING

ADDRESS BUS				E	OUTPUT CHANNEL
A3	A2	A1	A0		
0	0	0	0	1	16
0	0	0	1	1	15
0	0	1	0	1	14
0	0	1	1	1	13
0	1	0	0	1	12
0	1	0	1	1	11
0	1	1	0	1	10
0	1	1	1	1	9
x	x	x	x	0	NO OUTPUT

ADDRESS BUS				E	OUTPUT CHANNEL
A3	A2	A1	A0		
1	0	0	0	1	8
1	0	0	1	1	7
1	0	1	0	1	6
1	0	1	1	1	5
1	1	0	0	1	4
1	1	0	1	1	3
1	1	1	0	1	2
1	1	1	1	1	1
x	x	x	x	0	NO OUTPUT

9.4.2 "TRUE HIGH" SETTING

ADDRESS BUS				E/T	OUTPUT CHANNEL
A3	A2	A1	A0		
0	0	0	0	1	1
0	0	0	1	1	2
0	0	1	0	1	3
0	0	1	1	1	4
0	1	0	0	1	5
0	1	0	1	1	6
0	1	1	0	1	7
0	1	1	1	1	8
x	x	x	x	0	TEST MODE

ADDRESS BUS				E/T	OUTPUT CHANNEL
A3	A2	A1	A0		
1	0	0	0	1	9
1	0	0	1	1	10
1	0	1	0	1	11
1	0	1	1	1	12
1	1	0	0	1	13
1	1	0	1	1	14
1	1	1	0	1	15
1	1	1	1	1	16
x	x	x	x	0	TEST MODE

Note: The unit includes three internal potentiometers. These potentiometers are carefully adjusted and sealed in the factory. It is not recommended to alter these calibration potentiometers.

10. CALIBRATION

To calibrate the DRA-RTM-8, the limits must be defined.

Tmin is the temperature at which the output current is 4mA.

Tmax is the temperature at which the output current is 20mA.

Tspan is the difference between Tmax and Tmin.

10.1 CALIBRATION PROCEDURE

- Remove the terminal strips to get access to the coarse calibration switches.
- Set the channels DIP switches to the desired calibration ranges according to the calibration tables.
- Re-install the terminals strips. The terminal strips are polarized and should be returned to their original position.
- Connect a Pt-100 calibrator* set for Tmin to the proper input terminals.
- Apply the proper channel selection code by connecting those which according the table should be "1" to the +PWR terminal.
- Start calibrating by adjusting the proper "Z" potentiometer to obtain an output current of 4.000mA.
- Set the calibrator for Tmax and adjust the "S" potentiometer to obtain an output current of 20.000mA.
- Repeat this procedure until satisfactory results are obtained.

i. Change the address to the next channel to be calibrated.

j. Repeat steps b to h

* The calibrator is set according to DIN 43760 Pt-100 table ($\alpha = 0.00385$)

10.2 CALIBRATION TABLES

Note: Logic state of "0" is when the DIP switch lever is down.

10.2.1 "ZERO" - COARSE CALIBRATION TABLES

	CHANNELS 1-4		
ZERO TEMP °C	SW6	SW5	SW4
-50.....10	1	1	1
8.....75	0	1	1
74...140	1	0	1
139...206	0	0	1
205...272	1	1	0
270...338	0	1	0
336...404	1	0	0
401...470	0	0	0

CHANNELS 5-8		
SW1	SW2	SW3
1	1	1
0	1	1
1	0	1
0	0	1
1	1	0
0	1	0
1	0	0
0	0	0

10.2.2 "SPAN" - COARSE CALIBRATION TABLES

	CHANNELS 1-4		
SPAN °C	SW1	SW2	SW3
50.....76	1	1	1
65...115	1	0	1
110...180	0	1	1
135...225	0	1	0
215...440	0	0	1
400...800	0	0	0

CHANNELS 5-8		
SW6	SW5	SW4
1	1	1
1	0	1
0	1	1
0	1	0
0	0	1
0	0	0

11. MULTIDROP CONFIGURATION

In the disabled state ($E=0$), the multiplexer outputs no current and exhibits a high Z state. This mode allows the connection of several DRA-RTM-8 units to one PLC's analog input, by tying their output terminals and the address lines in parallel, and applying individual Enable lines to select the desired multiplexer by disabling all but one (see fig 7).




Figure 7.

12. SPECIFICATIONS

ANALOG INPUTS:	8, Pt-100 Channels $\alpha=0.00385$ 8, 0/4-20mA Channels
RTD INPUT:	
Zero adjustability:	50 to +200 °C
Span adjustability:	50 to 750 °C
Lead Compensation Error:	± 0.025 °C for 10 Ω lead resistance
Max Lead Resistance:	120 Ω two ways
Pt-100 linearization:	$\pm 0.1\%$ of span max.
CURRENT INPUT	
Max Input Current:	30 mA
Reverse Polarity Protection:	Yes
Output Accuracy (Refer to Current Input):	$\pm 0.1\%$ of span max.
CONTROL INPUTS:	4 Address 1 Enable input
Logic:	True High or True Low (User selectable)
Logic Levels:	Low: "0" < 0.5V High: 5 < "1" < 60V
OUTPUT:	4-20mA, Current Loop
SWITCHING TIME:	< 20 μ Sec (into a resistive load)
INDICATORS:	1 Yellow LED, Power-On indicator 8 Red LEDs, current activity indicators
SUPPLY VOLTAGE:	24 $\pm 10\%$ Vdc (regulated)
SUPPLY CURRENT CONSUMPTION:	120 mA ± 10 mA
FUSE:	150 mA, Fast Blow (5x20mm)
TEMPERATURE STABILITY:	$\pm 0.01\%$ of span/1 °C
OPERATING TEMPERATURE:	0 to 60 °C (32 to 140 °F)
STORAGE TEMPERATURE:	-25 to +85 °C (-13 to 185 °F)
HUMIDITY:	5 to 95% Relative humidity, non-condensing
HOUSING:	Plastic Polycarbonate
Box:	According to IP50 DIN 40050
Terminal:	According to IP20 DIN 40050
WEIGHT:	0.9 Kg. (2.0 lb.)
DIMENSIONS:	73Hx200Wx121mmD (2.88"x7.88"x4.76")

WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of 13 months from date of purchase. OMEGA Warranty adds an additional one (1) month grace period to the normal one (1) year product warranty to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product. If the unit should malfunction, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of being damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components which wear are not warranted, including but not limited to contact points, fuses, and triacs.

OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by it will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY / DISCLAIMER language, and additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

RETURN REQUESTS / INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR WARRANTY RETURNS, please have the following information available BEFORE contacting OMEGA:

1. P.O. number under which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

FOR NON-WARRANTY REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

1. P.O. number to cover the COST of the repair,
2. Model and serial number of product, and
3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

OMEGA is a registered trademark of OMEGA ENGINEERING, INC.

© Copyright 1996 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without prior written consent of OMEGA ENGINEERING, INC.

Where Do I Find Everything I Need for
Process Measurement and Control?
OMEGA...Of Course!

TEMPERATURE

- Thermocouple, RTD & Thermistor Probes, Connectors, Panels & Assemblies
- Wire: Thermocouple, RTD & Thermistor
- Calibrators & Ice Point References
- Recorders, Controllers & Process Monitors
- Infrared Pyrometers

PRESSURE, STRAIN AND FORCE

- Transducers & Strain Gauges
- Load Cells & Pressure Gauges
- Displacement Transducers
- Instrumentation & Accessories

FLOW/LEVEL

- Rotameters, Gas Mass Flowmeters & Flow Computers
- Air Velocity Indicators
- Turbine/Paddlewheel Systems
- Totalizers & Batch Controllers

pH/CONDUCTIVITY

- pH Electrodes, Testers & Accessories
- Benchtop/Laboratory Meters
- Controllers, Calibrators, Simulators & Pumps
- Industrial pH & Conductivity Equipment

DATA ACQUISITION

- Data Acquisition & Engineering Software
- Communications-Based Acquisition Systems
- Plug-in Cards for Apple, IBM & Compatibles
- Datalogging Systems
- Recorders, Printers & Plotters

HEATERS

- Heating Cable
- Cartridge & Strip Heaters
- Immersion & Band Heaters
- Flexible Heaters
- Laboratory Heaters

ENVIRONMENTAL
MONITORING AND CONTROL

- Metering & Control Instrumentation
- Refractometers
- Pumps & Tubing
- Air, Soil & Water Monitors
- Industrial Water & Wastewater Treatment
- pH, Conductivity & Dissolved Oxygen Instruments