

Service Manual

iPF5000 series

iPF5000

Canon

May 9 2006

Application

This manual has been issued by Canon Inc. for qualified persons to learn technical theory, installation, maintenance, and repair of products. This manual covers all localities where the products are sold. For this reason, there may be information in this manual that does not apply to your locality.

Corrections

This manual may contain technical inaccuracies or typographical errors due to improvements or changes in products. When changes occur in applicable products or in the contents of this manual, Canon will release technical information as the need arises. In the event of major changes in the contents of this manual over a long or short period, Canon will issue a new edition of this manual.

The following paragraph does not apply to any countries where such provisions are inconsistent with local law.

Trademarks

The product names and company names used in this manual are the registered trademarks of the individual companies.

Copyright

This manual is copyrighted with all rights reserved. Under the copyright laws, this manual may not be copied, reproduced or translated into another language, in whole or in part, without the written consent of Canon Inc.

COPYRIGHT © 2001 CANON INC.










Printed in Japan

Caution



Use of this manual should be strictly supervised to avoid disclosure of confidential information.

Symbols Used

This documentation uses the following symbols to indicate special information:

Symbol	Description
	Indicates an item of a non-specific nature, possibly classified as Note, Caution, or Warning.
	Indicates an item requiring care to avoid electric shocks.
	Indicates an item requiring care to avoid combustion (fire).
	Indicates an item prohibiting disassembly to avoid electric shocks or problems.
	Indicates an item requiring disconnection of the power plug from the electric outlet.
 Memo	Indicates an item intended to provide notes assisting the understanding of the topic in question.
 REF.	Indicates an item of reference assisting the understanding of the topic in question.
	Provides a description of a service mode.
	Provides a description of the nature of an error indication.

The following rules apply throughout this Service Manual:

1. Each chapter contains sections explaining the purpose of specific functions and the relationship between electrical and mechanical systems with reference to the timing of operation.
In the diagrams,  represents the path of mechanical drive; where a signal name accompanies the symbol, the arrow  indicates the direction of the electric signal.
The expression "turn on the power" means flipping on the power switch, closing the front door, and closing the delivery unit door, which results in supplying the machine with power.
2. In the digital circuits, '1' is used to indicate that the voltage level of a given signal is "High", while '0' is used to indicate "Low". (The voltage value, however, differs from circuit to circuit.) In addition, the asterisk (*) as in "DRMD*" indicates that the DRMD signal goes on when '0'.
In practically all cases, the internal mechanisms of a microprocessor cannot be checked in the field. Therefore, the operations of the microprocessors used in the machines are not discussed: they are explained in terms of from sensors to the input of the DC controller PCB and from the output of the DC controller PCB to the loads.

The descriptions in this Service Manual are subject to change without notice for product improvement or other purposes, and major changes will be communicated in the form of Service Information bulletins.

All service persons are expected to have a good understanding of the contents of this Service Manual and all relevant Service Information bulletins and be able to identify and isolate faults in the machine."

Contents

Chapter 1 PRODUCT DESCRIPTION

1.1 Product Overview	1- 1
1.1.1 Product Overview	1- 1
1.2 Features	1- 1
1.2.1 Printhead	1- 1
1.2.2 Ink Tank	1- 2
1.2.3 Cutter	1- 2
1.2.4 Auto Roll Feed Unit	1- 2
1.2.5 Consumables	1- 3
1.3 Product Specifications	1- 4
1.3.1 Product Specifications	1- 4
1.4 Detailed Specifications	1- 5
1.4.1 Printing Speed and Direction	1- 5
1.4.2 Interface Specifications	1- 5
1.5 Names and Functions of Components	1- 7
1.5.1 Front	1- 7
1.5.2 Rear	1- 7
1.5.3 Carriage	1- 8
1.5.4 Inside	1- 8
1.6 Basic Operation	1- 9
1.6.1 Operation Panel	1- 9
1.6.2 Printer Stats Transition	1- 10
1.6.3 Main Menu	1- 10
1.7 Safety and Precautions	1- 17
1.7.1 Safety Precautions	1- 17
1.7.1.1 Moving Parts	1- 17
1.7.1.2 Adhesion of Ink	1- 17
1.7.1.3 Electric Parts	1- 18
1.7.2 Other Precautions	1- 19
1.7.2.1 Printhead	1- 19
1.7.2.2 Ink Tank	1- 20
1.7.2.3 Handling the Printer	1- 20
1.7.3 Precautions When Servicing Printer	1- 22
1.7.3.1 Notes on the Data Stored in the Printer	1- 22
1.7.3.2 Confirming the Firmware Version	1- 22
1.7.3.3 Precautions against Static Electricity	1- 22
1.7.3.4 Precautions for Disassembly/Reassembly	1- 22
1.7.3.5 Self-diagnostic Feature	1- 22
1.7.3.6 Disposing of the Lithium Battery	1- 22

Chapter 2 TECHNICAL REFERENCE

2.1 Basic Operation Outline	2- 1
-----------------------------------	------

2.1.1 Printer Diagram	2- 1
2.1.2 Print Driving	2- 2
2.2 Firmware	2- 2
2.2.1 Operation Sequence at Power-on.....	2- 2
2.2.2 Operation Sequence at Power-off.....	2- 2
2.2.3 Print Control.....	2- 3
2.2.4 Print Position Adjustment Function.....	2- 4
2.2.5 Head Management.....	2- 4
2.2.6 Printhead Overheating Protection Control.....	2- 4
2.2.7 Pause between Pages.....	2- 4
2.2.8 White Raster Skip	2- 4
2.2.9 Sleep Mode.....	2- 4
2.3 Printer Mechanical System	2- 6
2.3.1 Outline	2- 6
2.3.1.1 Outline	2- 6
2.3.2 Ink Passage.....	2- 6
2.3.2.1 Ink Passage	2- 6
2.3.2.2 Ink Tank Unit	2- 7
2.3.2.3 Carriage Unit	2- 9
2.3.2.4 Printhead	2- 12
2.3.2.5 Purge Unit	2- 12
2.3.2.6 Maintenance Cartridge.....	2- 16
2.3.2.7 Air Flow.....	2- 16
2.3.3 Paper Path.....	2- 17
2.3.3.1 Outline	2- 17
2.3.3.2 Paper Path	2- 18
2.3.3.3 Cutter Unit.....	2- 29
2.4 Printer Electrical System	2- 30
2.4.1 Outline	2- 30
2.4.1.1 Overview	2- 30
2.4.2 Main Controller	2- 31
2.4.2.1 Main controller components	2- 31
2.4.3 Carriage Relay PCB.....	2- 33
2.4.3.1 Carriage PCB components	2- 33
2.4.4 Motor Driver.....	2- 33
2.4.4.1 Cutter driver PCB components.....	2- 33
2.4.4.2 Roll feed unit PCB components	2- 33
2.4.5 Maintenance Cartridge Relay PCB	2- 34
2.4.5.1 Maintenance cartridge relay PCB components	2- 34
2.4.6 Power Supply	2- 34
2.4.6.1 Power supply block diagram.....	2- 34
2.5 Detection Functions with Sensors.....	2- 35
2.5.1 Sensors for covers.....	2- 35
2.5.2 Ink passage system.....	2- 36
2.5.3 Carriage system	2- 38
2.5.4 Paper path system.....	2- 40
2.5.5 Others	2- 42

Chapter 3 INSTALLATION

3.1 Installation.....	3- 1
3.1.1 Making Pre-Checks	3- 1
3.1.1.1 Making Pre-Checks.....	3- 1
3.1.2 Unpacking and Installation	3- 1
3.1.2.1 Unpacking and Installation.....	3- 1
3.1.3 Checking the Images/Operations	3- 7
3.1.3.1 Checking the Images /Operations	3- 7
3.2 Transporting the Printer.....	3- 8
3.2.1 Transporting the Printer	3- 8
3.2.1.1 Transporting the Printer.....	3- 8
3.2.2 Reinstalling the Printer.....	3- 9
3.2.2.1 Reinstalling the Printer	3- 9

Chapter 4 DISASSEMBLY/REASSEMBLY

4.1 Service Parts	4- 1
4.1.1 Service Parts	4- 1
4.2 Disassembly/Reassembly	4- 1
4.2.1 Disassembly/Reassembly.....	4- 1
4.3 Points to Note on Disassembly and Reassembly	4- 3
4.3.1 Note on assemblies (or units) prohibited from disassembly.....	4- 3
4.3.2 Moving the carriage manually	4- 3
4.3.3 Units requiring draining of ink.....	4- 3
4.3.4 External Covers	4- 4
4.3.5 Driving Unit	4- 11
4.3.6 Cutter.....	4- 12
4.3.7 Carriage Unit	4- 13
4.3.8 Feeder Unit.....	4- 18
4.3.9 Roll Feed Unit	4- 22
4.3.10 Purge Unit.....	4- 25
4.3.11 Waste Ink Collection Unit.....	4- 26
4.3.12 Ink Tank Unit	4- 29
4.3.13 Head Management Sensor	4- 31
4.3.14 Multi Sensor	4- 32
4.3.15 PCBs	4- 33
4.3.16 Opening the Cap/Moving the Wiper Unit.....	4- 33
4.3.17 Opening/Closing the Ink Supply Valve.....	4- 34
4.3.18 Draining the Ink.....	4- 34
4.4 Applying the Grease	4- 35
4.4.1 Applying the Grease	4- 35
4.5 Adjustment and Setup Items	4- 38
4.5.1 Procedure after Replacing the Feed Roller HP Sensor or Feed Roller Encoder.....	4- 38
4.5.2 Procedure after Replacing the Carriage Unit or Multi Sensor	4- 38
4.5.3 Procedure after Replacing the Head Management Sensor.....	4- 40

Chapter 5 MAINTENANCE

5.1 Periodic Replacement Parts	5- 1
5.1.1 Periodic Replacement Parts	5- 1
5.2 Consumable Parts	5- 1
5.2.1 Consumable Parts	5- 1
5.3 Periodic Maintenance.....	5- 1
5.3.1 Periodic Maintenance.....	5- 1

Chapter 6 TROUBLESHOOTING

6.1 Troubleshooting	6- 1
6.1.1 Outline	6- 1
6.1.1.1 Outline of Troubleshooting	6- 1
6.1.2 Troubleshooting When Warnings Occur.....	6- 1
6.1.2.1 Ink Lvl: Chk XX (1000,1001,1002,1003,1004,1005,1006,1008,1009,100A,100B,100C)	6- 1
6.1.2.2 MTCart Full Soon (1100)	6- 1
6.1.2.3 Mist Full Soon (1101)	6- 1
6.1.2.4 GARO W12xx: xx stands for digits (1221,1222,1223,1225,1231,1232,1233,1234,1235)....	6- 1
6.1.2.5 Feed Limit... (100F)	6- 1
6.2 Location of Connectors and Pin Arrangement.....	6- 2
6.2.1 Main controller PCB	6- 2
6.2.2 Carriage relay PCB.....	6- 13
6.2.3 Cutter driver PCB.....	6- 20
6.2.4 Power supply	6- 21
6.2.5 Roll feed unit PCB	6- 22
6.3 Version Up	6- 22
6.3.1 Firmware Update Tool	6- 22
6.4 Service Tools.....	6- 23
6.4.1 Tool List.....	6- 23

Chapter 7 SERVICE MODE

7.1 Service Mode.....	7- 1
7.1.1 Service Mode Operation	7- 1
7.1.2 Service Mode Map.....	7- 1
7.1.3 Details of Service Mode.....	7- 5
7.2 Special Mode.....	7- 11
7.2.1 Special Modes for Servicing	7- 11

Chapter 8 ERROR CODE

8.1 Outline	8- 1
8.1.1 Outline	8- 1
8.2 Warning Table	8- 1
8.2.1 Warnings	8- 1
8.3 Error Table	8- 1
8.3.1 Error Code List	8- 1
8.4 Service Call Table	8- 4
8.4.1 Service call errors	8- 4

Chapter 1 PRODUCT DESCRIPTION


Contents

1.1 Product Overview	1-1
1.1.1 Product Overview	1-1
1.2 Features	1-1
1.2.1 Printhead	1-1
1.2.2 Ink Tank	1-2
1.2.3 Cutter	1-2
1.2.4 Auto Roll Feed Unit	1-2
1.2.5 Consumables	1-3
1.3 Product Specifications	1-4
1.3.1 Product Specifications	1-4
1.4 Detailed Specifications	1-5
1.4.1 Printing Speed and Direction	1-5
1.4.2 Interface Specifications	1-5
1.5 Names and Functions of Components	1-7
1.5.1 Front	1-7
1.5.2 Rear	1-7
1.5.3 Carriage	1-8
1.5.4 Inside	1-8
1.6 Basic Operation	1-9
1.6.1 Operation Panel	1-9
1.6.2 Printer Stats Transition	1-10
1.6.3 Main Menu	1-10
1.7 Safety and Precautions	1-17
1.7.1 Safety Precautions	1-17
1.7.1.1 Moving Parts	1-17
1.7.1.2 Adhesion of Ink	1-17
1.7.1.3 Electric Parts	1-18
1.7.2 Other Precautions	1-19
1.7.2.1 Printhead	1-19
1.7.2.2 Ink Tank	1-20
1.7.2.3 Handling the Printer	1-20
1.7.3 Precautions When Servicing Printer	1-22
1.7.3.1 Notes on the Data Stored in the Printer	1-22
1.7.3.2 Confirming the Firmware Version	1-22
1.7.3.3 Precautions against Static Electricity	1-22
1.7.3.4 Precautions for Disassembly/Reassembly	1-22
1.7.3.5 Self-diagnostic Feature	1-22
1.7.3.6 Disposing of the Lithium Battery	1-22

1.1 Product Overview

1.1.1 Product Overview

This printer is capable of printing on A4- to A2-size cut sheets and its maximum print width is 17 inches. This printer is a desktop large-format printer twelve-color (dye- and pigment-based colors) printer that can be used to print office documents as well as handy POP and posters. An auto roll feed unit holder is optionally available for printing on roll media.



- | | |
|---------------------------------|-----------------------------|
| [1] Top Cover | [10] Power Supply Connector |
| [2] Ink Tank Cover | [11] Ethernet Connector |
| [3] Cassette | [12] USB Port |
| [4] Operation Panel | [13] IEEE1394 Board(option) |
| [5] Paper Tray Unit | [14] Printhead |
| [6] Output Stacker | [15] Ink Tank |
| [7] Auto Roll Feed Unit(option) | [16] Cleaning Brush |
| [8] Roll Holder Set(option) | |
| [9] Back Cover | |


1.2 Features

1.2.1 Printhead

Printhead set on the carriage is a 6-color integral disposable type.

On the printhead, two rows of 1,280 nozzles (total 2,560 nozzles) are arranged in a staggered pattern. .

If print quality does not improve despite carrying out the specified cleaning, the printhead must be replaced with a new one. Generally, it is recommended that the printhead be replaced about 12 months after you have opened the package.



F-1-2


1.2.2 Ink Tank

The ink tank is disposable.

There are twelve pigment-based ink colors (matte black,black,photo cyan,cyan,photo magenta,magenta,yellow,red,blue,green,gray,and photo gray).


This printer features a mechanism by which only the correct color ink tank will fit in the given slot.

When the message No Ink is displayed, replace the ink tank with a new one. Also, each ink tank should generally be replaced six months after you have opened the package.



1.2.3 Cutter


A round-blade cutter comes with the cutter unit.



1.2.4 Auto Roll Feed Unit

Auto Roll Feed Unit (option)


The auto roll feed unit is optionally available to use roll media with this printer.




Roll holder set (option)

This set consists of roll holder, holder stopper, 3-inch paper tube attachment (two), and borderless printing spacer (commonly used for 2-inch paper tube and 3-inch paper tube).


[Roll holder]



[Holder stopper]



[3-inch paper tube attachment](2 pcs.)




[Borderless printing spacer]



1.2.5 Consumables


Printhead

The consumable print head is the same as that supplied with the printer.




Ink Tanks

The consumable ink tanks are available in twelve colors (matte black, black, photo cyan, cyan, photo magenta, magenta, yellow, red, blue, green, photo gray, and gray). They are the same as those supplied with the printer. Each ink tank must be replaced with a new one six months after you have opened the package.



Maintenance cartridge

The consumable maintenance cartridge is the same as that supplied with the printer.



1.3 Product Specifications

1.3.1 Product Specifications

Type	Bubble jet large-sized paper printer
Feeding system	Automatic feeding of one roll media (option)/Cassette paper feeding/ One cut sheet (manual feed from front)/One cut sheet (manual feed from top)
Feeding capacity	- Roll media (option) One roll at the back/Outer diameter of roll: 150 mm or less/Inner diameter of paper tube: 2 or 3 inches - Cut sheet Cassette: 250 sheets(A4), 100 sheets(A3), 50 sheets(A2)
Delivery method	Delivers the media with its printed side up in the forward direction.
Sheet delivery capability	- Roll media (option) 1 sheet - Cut sheet 50 sheets (plain paper of A3 or smaller) or 20 sheets (plain paper of larger than A3)
Cutter	Automatically cuts paper laterally. Cartridge-type (with round blade)
Type of media	Plain paper, plain paper (high quality), plain paper (vivid color), coated paper, extra heavy coated paper, premium matte paper, high-quality dedicated paper, matte photo paper, photo glossy paper, photo semi-glossy paper, photo glossy paper (heavy), photo semi-glossy paper (heavy), professional photo paper, super photo paper, super photo paper (silky), glossy paper, synthetic paper, adhesive synthetic paper, proofing paper, newspaper proofing paper, tracing paper (CAD), semi-translucent matte film (CAD), POP board
Supported thickness	Roll media: 0.07 to 0.8 mm Cassette: 0.08 to 0.3 mm Manual feed from top: 0.08 to 0.5 mm Manual feed from front: 0.5 to 1.5 mm
Media size (Roll media)	Maximum size: 432 mm x 18 m Minimum size: 203.2 mm x 203.2 mm Maximum outside diameter: 150 mm
Media size (Cut sheet)	- Manual feed from top Maximum size: 432 mm x 609.6 mm (W x L) Minimum size: 203.2 mm x 279 mm (W x L) - Manual feed from front Maximum size: 432 mm x 609.6 mm (W x L) Minimum size: 203.2 mm x 520 mm (W x L)
Printable area (Roll media)	Area excluding 3mm from the top, 3 mm from the bottom, and 3 mm from the left and right edges. Borderless printing: 0 mm from the top, bottom, and left and right edges. Width of media allowing borderless printing: 10inches, JIS B4, A3+, 14inches, 16inches, 17inches, ISO A2/A3 Media type allowing borderless printing: Coated paper (heavy), photo glossy paper, photo semi-glossy paper, photo glossy paper (heavy), photo semi-glossy paper (heavy), photo glossy paper, photo semi-glossy paper, fine art (photo), fine art (photo heavy), fine art (painting), premium matte, fine art (watercolor), fine art (block print)
Printable area (Cut sheet)	Area excluding 3 mm from the top, 23 mm from the bottom (3 mm when supplied from the cassette), and 3 mm from the left and right edges.
Printing assurance area (Roll media)	Printing assurance area (Roll sheet) Area excluding 20 mm from top, 20 mm from the bottom and 5 mm from the left and right edges (standard size).
Printing assurance area (Cut sheet)	Printing assurance area (cut sheet) Area excluding 20 mm from the top, 23 mm from the bottom (20 mm when fed from the cassette), and 5 mm from the left and right edges (standard size).
Interface	USB2.0, Ethernet, IEEE1394 (option)
Printhead/Ink Tank type	Printhead and separate ink tanks
Printhead	[PF-01] Number nozzles: 2560 nozzles per color
Ink tank	[PFI-102]MBK,BK,GY,PGY,R,G,B,C,M,Y,PC,PM Capacity: 130 ml per color (Ink tanks supplied with the printer contain 90 ml of each color.)
Detection functions (Cover system)	Detects opening/closing of the top cover and ink cover.
Detection functions (Ink passage system)	Detects presence/absence of ink tank, ink level, presence/absence of the maintenance cartridge, waste ink full level, presence/absence of the printhead, and opening/closing of the supply valve.
Detection functions (Carriage system)	Detects the ambient temperature, head temperature, presence/absence of the head, and no ink ejection.

Detection functions (Paper path system)	Detects presence/absence of paper, remaining paper, cutter position, presence/absence of the cassette, leading/trailing edge of paper, paper width, and skew.
Operating noise	During printing: Approx. 53 dB (A) or less During standby: Approx. 35 dB (A) or less
Operating environment	Temperature: 15 oC to 30oC Humidity: 10% to 80% without dew condensation
Print quality guaranteed environment	Temperature: 15 oC to 30oC Humidity: 10% to 80%RH
Power supply	100-120 VAC (50/60 Hz), 220-240 VAC (50/60 Hz)
Power consumption (Maximum)	During printing: Max. 100 W
Power consumption	In power save (sleep) mode: 6 W or less(220-240 VAC: 7W or less) During standby: 1 W or less
Printer unit dimensions (WxDxH)	Without roll media unit (option): 999 x 733 x 317 mm With roll media unit (option): 999 x 810 x 344 mm
Weight	Without roll media unit (option): Approx. 45 kg With roll media unit (option): 49 kg

1.4 Detailed Specifications

1.4.1 Printing Speed and Direction

T-1-2

Media Type	Print Priority	Print Quality	Print-pass	Printing direction(*1)	Print resolution
Plain Paper Plain Paper(High Quality) Plain Paper(High Grade)	Image	Draft	2-pass	Bi-directional	1200x1200dpi
		Standard	4-pass	Bi-directional	1200x1200dpi
		High	8-pass	Bi-directional	1200x1200dpi
	Line Drawing/ Text	Draft	2-pass	Bi-directional	1200x1200dpi
		Standard	4-pass	Bi-directional	1200x1200dpi
	Office Document	Standard	4-pass	Bi-directional	1200x1200dpi
High Resolution Paper Coated Paper Heavyweight Coated Paper	Image	Standard	4-pass	Bi-directional	1200x1200dpi
		High	8-pass	Bi-directional	1200x1200dpi
		Highest	12-pass	Bi-directional	2400x1200dpi
Premium Matte Paper Matte Photo Paper	Image	Standard	6-pass	Bi-directional	1200x1200dpi
		High	8-pass	Bi-directional	2400x1200dpi
		Highest	16-pass	Bi-directional	2400x1200dpi
Glossy Photo Paper Semi-Glossy Photo Paper Heavyweight Glossy Photo Paper Heavyweight SemiGlos Photo Paper Glossy Paper Photo Paper Plus Photo Paper Plus Semi-Glos Synthetic Paper Adhesive Synthetic Paper Backlit Film Backprint Film Thin Fabric Banner 2 Proofing Paper Fine Art Photo Fine Art Heavyweight Photo Fine Art Textured Fine Art Watercolor Fine Art Block Print Canvas Matte 2 Japanese Paper Washi POP Board	Image	Standard	6-pass	Bi-directional	1200x1200dpi
		High	8-pass	Bi-directional	2400x1200dpi
		Highest			
	Line Drawing/ Text		16-pass	Bi-directional	2400x1200dpi
CAD Tracing Paper CAD Translucent Matte Film	Line Drawing/ Text	Draft	2-pass	Bi-directional	1200x1200dpi
		Standard	4-pass	Bi-directional	1200x1200dpi
		High	8-pass	Bi-directional	2400x1200dpi

*1 The print engine may automatically select 1-way printing depending on the printing image type (graphic image, etc.). The printing direction can be selected using the printer driver.

1.4.2 Interface Specifications

a. USB (standard)

- (1) Interface type
USB 2.0, Full speed (12 Mbps/sec), High speed (480 Mbps/sec)
- (2) Data transfer system
Control transfer
Bulk transfer
- (3) Signal level
Compliant with the USB standard.
- (4) Interface cable

Twisted-pair shielded cable, 5.0 m max.
Compliant with the USB standard.
Wire materials: AWG No.28, data wire pair (AWF: American Wire Gauge)
AWG No.20 to No.28, power distribution wire pair

- (5) Interface connector
 - Printer side: Series B receptacle compliant with USB standard
 - Cable side: Series B plug compliant with USB standard

b. Network (standard)


- (1) Interface type
 - Interface compliant with IEEE802.3
- (2) Data transfer system
 - 10Base-T/100Base-TX
- (3) Signal level
 - Input: Threshold
 - 10Base-T: Max. +585 mV, Min. +300 mV
 - 100Base-TX: Turn-on +1000 mV diff pk-pk, Turn-off +200 mV diff pk-pk
 - Output:
 - 10Base-T: +2.2 V to +2.8 V
 - 100Base-TX: +0.95 to +1.05 V
- (4) Interface cable
 - Category 5 (UTP or FTP) cable, 100 m or shorter
 - Compliant with ANSI/EIA/TIA-568A or ANSI/EIA/TIA-568B
- (5) Interface connector
 - Printer side: Compliant with IEEE802.3, ANSI X3.263, ISO/IEC60603-7

c. IEEE1394 (option)

- (1) Interface type
 - Interface compliant with IEEE1394-1995, P1394a (Version 2.0)
- (2) Data transfer system
 - Asynchronous transfer
- (3) Signal level
 - Input:
 - Differential input voltage:
 - During S100 settlement: +173 mV to +260 mV
 - During data reception: +142 mV to +260 mV
 - During S200 settlement: +171 mV to +262 mV
 - During data reception: +132 mV to +260 mV
 - During S400 settlement: +168 mV to +265 mV
 - During data reception: +118 mV to +260 mV
 - Output:
 - Differential output voltage: +172 mV to +265 mV
- (4) Interface cable
 - Twisted-pair shielded cable, 4.5 m max.
 - Compliant with IEEE1394-1995 standard or P1394a (Version 2.0) standard
- (5) Interface connector
 - Printer side: 6-pin connector (socket) compliant with IEEE1394 standard
 - Cable side: 6-pin connector (plug) compliant with IEEE1394 standard
 - Cable side: RJ-45 type compliant with ANSI/EIA/TIA-568A or ANSI/EIA/TIA-568B


1.5 Names and Functions of Components

1.5.1 Front




- [1] Top cover
Open this cover when installing the printhead or remove the paper jammed inside the printer.
- [2] Ink tank cover
Open this cover when replacing ink tanks.
- [3] Cassette
Load paper in this tray
- [4] Operation panel
This panel includes the Power button, Online button, and display.
- [5] Paper tray unit
This is a standard unit used to feed cut sheets manually.
It can be replaced with the optional auto roll feed unit.
- [6] Output tray
The ejected prints are stacked in this tray.

1.5.2 Rear



- [1] Auto roll feed unit (option)
Load cut sheets or roll media in this unit.
- [2] Power connector
Connect the power cord to this connector.
- [3] USB port
Connect the USB cable to this port.
- [4] Ethernet connector
Connect the Ethernet cable to this connector.
- [5] Expansion board slot
Insert the IEEE1394 board (option) in this slot.

1.5.3 Carriage



F-1-15

[1] Carriage

[2] Printhead lock cover

This cover is used to lock the printhead. Open this cover when installing the printhead.

[3] Printhead

The printhead incorporated nozzles. It is an important part for printing.


[4] Printhead lock lever

This lever is used to lock the printhead. Open this lever when installing the printhead.

[5] Ink tube guide

This stay is used as an ink tube guide.

1.5.4 Inside




F-1-16

[1] Maintenance cartridge

1.6 Basic Operation

1.6.1 Operation Panel

This section explains the functions of the buttons and the meanings of the LEDs on the operation panel.



[1] Display

This display shows the printer menus, statuses, and messages.

[2] Data lamp (green)

Flashing: When the printer is printing, this lamp indicates that the printer is receiving or processing a print job.
When the printer is not printing, this lamp indicates that the print job is paused or firmware data is being received.
Off: This indicates that there is no print job.

[3] Message lamp (orange)

On: This indicates that a warning message is displayed.
Flashing: This indicates that an error message is displayed.
Off: This indicates that the printer is normal or the power is turned off.

[4] Auto Feed lamp (green)

On: This indicates that the cassette or roll media is selected as the paper source.
Off: This indicates that the paper tray or thick paper feed slot is selected as the paper source.

[5] Paper Tray lamp (green)

On: This indicates that the paper tray or thick paper feed slot is selected as the paper source.
Off: This indicates that the cassette or roll media is selected as the paper source.

[6] Paper Source button

This button is used to select a paper source. Pressing this button toggles between the automatic pickup and manual feed.
The [Auto Feed] lamp or [Paper Tray] lamp goes on.

[7] Online button

This button switches between online and offline modes.
On: This indicates that the printer is in the online status.
Off: This indicates that the printer is in the offline mode.

[8] Menu button

This button displays the main menu of the printer.

[9] Information button

This button displays a submenu. Information about the ink and media each time you press this button.
Head cleaning is carried out when this button is held pressed for at least 3 seconds.

[10] ▲ ▼ ◀ ▶ buttons
(In the menu mode)

▲ button: Displays the next higher-level menu.

▼ button: Displays the next lower-level menu.

◀ button: Displays the previous item or setting.

▶ button: Displays the next item or setting.

(In the offline mode)

▲ button: Feeds the roll media in the reverse direction.

▼ button: Feeds the roll media in the normal direction.

[11] OK button

This button sets or executes the selected operation or value.

[12] Stop/Eject button

This button aborts the job in progress and ejects the media.

[13] Power button


This button turns on/off the printer.

[14] Color label

This label indicates the ink tank colors and names that correspond to the ink level indications shown on the display.

1.6.2 Printer Stats Transition

The following chart shows various printer states and how they are transited by button operations.



F-1-18

1.6.3 Main Menu

The printer has a Main menu which includes a menu related to maintenance such as adjustment of ink ejection position of each nozzle and head cleaning, a menu related to printing settings such as auto cutting and ink drying time, and a menu related to parameters such as a message language.

a. Main menu operations

(1) How to enter the Main menu

To enter the Main menu, press the [Menu] button on the operation panel.

(2) How to exit the Main menu

To exit the Main menu, press the [Online] button.


(3) Buttons used with the Main menu

- Selecting menus and parameters: [◀] or [▶] button
- Going to the next lower-level menu: [▼] button
- Going to the next higher-level menu: [▲] button
- Determining a selected menu or parameter: [OK] button

2. Main Menu

Hierarchical levels and parameters of the Main menu are shown below.

MAIN MENU




- *1 Displayed even when printing
 *2 Displayed only when roll media is loaded
 *3 Displayed only when Auto Roll Feed Unit is attached
 *4 Displayed only during printing

F-1-19

Media detail setup menu

Med.Detail Set.


(Media type)



F-1-20


Printing adjustment menu

Adjust Printer



F-1-21

Interface setup menu




*1 Displayed when "Automatic" is selected for "IP mode"

*2 Displayed when "Off" is selected for "Auto Detect"

F-1-22

System setup menu



*1 Displayed only when Auto Roll Feed Unit is attached

*2 Display method depends on "Date Format"

*3 Returns settings of "Med. Detail Set" to the state of factory shipment

I-1-23

Time Zone setting menu

Time Zone

- 0 : London (GMT)
- +1 : Paris , Rome
- +2 : Athens , Cairo
- +3 : Moscow
- +4 : Eerevan , Baku
- +5 : Islamabad
- +6 : Dacca
- +7 : Bangkok
- +8 : Hong Kong
- +9 : Tokyo , Seoul
- +10 : Canbera
- +11 : NewCaledonia
- +12 : Wellington
- 12 : Eniwetok
- 11 : Midway Is.
- 10 : Hawaii (AHST)
- 9 : Alaska (AKST)
- 8 : Oregon (PST)
- 7 : Arizona (MST)
- 6 : Texas (CST)
- 5 : New York (EST)
- 4 : Santiago
- 3 : Buenos Aires
- 2 :
- 1 : Cape Verde

Meaning of code address

GMT : Greenwich Mean Time
 AHST : Alaska-Hawaii Std Time
 AKST : Alaska Standard Time
 PST : Pacific Std Time
 MST : Mountain Standard Time
 CST : Central Std Time
 EST : Eastern Standard Time
 F-1-24

Information menu

Information

- Version
 - Firm : ##.##
 - Boot : ##.##
- RAM
 - ### MB
- Ext. Interface
 - Disable
 - IEEE1394
- MAC Address
 - 000085#####
- Error Log
 - 1 : #####
 - 2 : #####
- Job Log
 - Job Log No.1
 - Document Name
 - User Name
 - Page Count
 - Job Status
 - Print Start Time
 - Print End Time
 - Print Time
 - Print Size
 - Media Type
 - Interface
 - Ink Consumption
 - Job Log No.2
 - Job Log No.3
- Counter
 - Cut Count #

F-1-25


1.7 Safety and Precautions

1.7.1 Safety Precautions

1.7.1.1 Moving Parts

Moving parts of the printer include the carriage unit driven by the carriage motor, the carriage belt, the ink tube, the flexible cable, the feed roller drives the feed motor, the pinch roller, and the purge unit driven by the purge motor.

To prevent accidents, the top cover of the printer is locked during printing. If the top cover is opened in the online/offline mode, the carriage motor, feed motor, and other driving power supplies are turned off.




F-1-26

1.7.1.2 Adhesion of Ink

(1) Ink passages

Be careful not to touch the ink passages of the printer to prevent the printer, workbench, and clothes from being stained with ink.

The ink flows through the ink tank unit, carriage unit, purge unit, maintenance jet tray, maintenance cartridge, and the ink tubes that relay ink to individual units.



F-1-27




- Although the ink is not harmful to the human body, it contains organic solvents. Ink may contaminate the surrounding parts. Carry out the work with due caution. If your hands are stained with ink, wash them with a plenty of water. Be careful not to allow the ink to get into your mouth or eyes. If the ink gets into your eyes, flush them with water well and see a doctor. In case of accidental ingestion of a large quantity of ink, see a doctor immediately.

Since this ink contains pigment, stains will not come out of clothing.

(2) Ink Mist

Since the printhead prints by squirting ink onto the media, a minute amount of ink mist is generated in the printing unit during printing. The generated ink mist is collected in the printer by the airflow. However, uncollected ink mist may stain the platen, carriage unit, exterior, and purge unit. These stains may soil the print media or hands and clothes when servicing the printer. Wipe them off carefully with a soft, well-wrung cloth.




F-1-28

1.7.1.3 Electric Parts

The electric parts of the printer are activated when the printer is connected to the AC power supply.

At the left rear of the printer are the main controller, power supply, and interface connector. The carriage relay PCB is incorporated in the carriage unit, and the operation panel is on the upper right top cover.

When servicing the printer with the cover removed, be extremely careful to avoid electric shock and shorting electrical devices.



F-1-29

1.7.2 Other Precautions

1.7.2.1 Printhead

1. How to Handle the Printhead

Do not open the printhead package until you are ready to install the head.

When installing the printhead in the printer, hold the knob[1] and then remove the protective cap 1[2] and protective cap 2[3] in that order.

Do not reattach the protective cap 2[3] to the printhead because the cap may damage the nozzles[4].

To prevent the nozzles from getting clogged with foreign matter or dried ink, install the printhead immediately after you remove the protective caps.

Also make sure to press down the locking lever of the printhead until you feel a click.


In addition, to prevent clogging of the nozzles with foreign matter and improper supply of ink, never touch the nozzles[4] or ink port[6], or wipe it with tissue paper or anything else.

Do not touch Electrical contact[5].

Also, never attempt to disassemble/reassemble the printhead or wash it with water.

MEMO:

If the nozzles are clogged or an ink suction problem occurs, white lines can appear on the printout a constant frequency or color dulling can occur. If this problem is not resolved by cleaning operations, replace the printhead with a new one.



2. Capping

The printer will perform the capping operation when printing has ended or during standby due to an error, in order to protect the printhead and avoid ink leakage. If the power cord is accidentally unplugged, turn off the Power button, reconnect the power cord, and then turn on the Power button. Confirm that the printer starts up properly and enters to the "Online" or "Offline" status, and then power off the printer using the Power button.



Improper "capping operation" may cause clogged nozzles due to dried ink or ink leakage from the printhead.

3. When the printer is not used for a long time

Keep the printhead installed in the printer even when it is not used for an extended period of time.



If the printhead is left uninstalled, a printing failure may arise from closed nozzles due to depositing of foreign matter or dried ink when it is reinstalled. Even if the head remains installed, the nozzle may dry out and cause a printing failure if the ink is drained for transport.

4. Conductivity of Ink

The ink used in this printer is electrically conductive. If ink leaks into the mechanical unit, wipe clean with a soft, well-wrung damp cloth. If ink leaks onto electrical units, wipe them completely using tissue paper. If you cannot remove ink completely, replace the electrical units with new ones.



If electrical units are powered with ink leaked onto them, the units may damage. Never connect the power cord when ink has leaked onto the electrical units.

1.7.2.2 Ink Tank

1. Unpacking the Ink Tank

Do not unpack the ink tank until you are ready to install it.


When installing the ink tank, be sure to shake it slowly 7 to 8 times before unpacking it. Otherwise, the ink ingredients may precipitate and degrade the print quality. To prevent foreign matter from entering the ink port, installed the unpacked ink tank in the printer immediately.

2. Handling the Ink Tank

To prevent foreign matter from entering the ink flow path and causing ink suction and printing problems, never touch the ink port and contacts of the ink tank.

When you press down the ink tank cover, the needle enters the ink port, allowing ink to flow between the printer and ink tank.

Do not raise or lower the ink tank cover except when replacing the ink tank.




1.7.2.3 Handling the Printer

1. Precautions against Static Electricity

Certain clothing may generate static electricity, causing an electrical charge to build up on your body. Such a charge can damage electrical devices or change their electrical characteristics.

In particular, never touch the printhead contacts.

- [1] Carriage unit
- [2] Printhead contacts




F-1-32

2. Fixing the Carriage

After completion of printing, the carriage is mechanically locked by the lock arm in the purge unit at the same moment the printhead is capped.

Before transporting the printer, secure the carriage at its home position using belt stoppers[1] so that the carriage does not become separated from the lock arm and damage or ink does not leak.



F-1-33

3. Handling the Maintenance Cartridge

When removing the maintenance cartridge from the printer, use caution so that waste ink does not spatter.

4. Refilling the Printer with Ink

After removing the ink from inside the printer using the automatic or manual ink draining procedure to disassemble/reassemble or transport the printer, refill the printer with ink as soon as possible upon completion of the work.

If the ink remaining in the printer dries up, mechanical parts may be seized and malfunction may result.

1.7.3 Precautions When Servicing Printer

1.7.3.1 Notes on the Data Stored in the Printer

This printer counts the print length, number of ink tank replacements, carriage driving time, number of cleaning operations, number of cutter operations, and so on and stores them in the main controller's EEPROM as a service mode counter.

This counter provides important information about the printer usage status.

You can check this information by printing it in the service mode or displaying it on the display.

Following the precautions below when servicing the printer.

(1) Repairing/replacing the PCB

When replacing the main controller, follow the specified replacement procedure.

Reference:

For the main controller replacement procedure, see Disassembly/Reassembly > Points to Note on Disassembly and Reassembly > Boards.

(2) After replacing the carriage unit

The information about the carriage driving time arises in the carriage unit. After replacing the carriage unit, select INITIALIZE > CARRIAGE in the service mode to initialize (clear) the information about the carriage driving time.

(3) After replacing the purge unit

The information about the number of cleanings arises in the purge unit. After replacing the purge unit, select INITIALIZE > PURGE in the service mode to initialize (clear) the information about the number of cleanings.



You cannot check the counter information once it is initialized (cleared). Be careful not to initialize the counter information before checking it. You cannot modify the counter information from the operation panel.

1.7.3.2 Confirming the Firmware Version

Firmware has been downloaded to the main controller.

When you have replaced the main controller, check that the firmware is the latest version. If not, update it to the latest version.

Reference:

For how to update the main controller, refer to TROUBLESHOOTING > Update.

1.7.3.3 Precautions against Static Electricity

Certain clothing may generate static electricity, causing an electrical charge to build up on your body. Such a charge can damage electrical devices or change their electrical characteristics.

Before disassembling the printer for servicing, discharge any static buildup by touching a grounded metal fitting or the like.

1.7.3.4 Precautions for Disassembly/Reassembly

The precautions for disassembly/reassembly are described in Disassembly/Reassembly.

1.7.3.5 Self-diagnostic Feature

The printer has a self-diagnostic feature to analyze hardware problems.

The self-diagnosis result is shown on the display and indicated by lamps.

For detailed information, see "Error Codes".

1.7.3.6 Disposing of the Lithium Battery

The main controller PCB of this printer is equipped with a lithium battery to back up various data.



Replacing the lithium battery with a wrong type can result in explosion. Dispose of the used lithium battery according to the instruction manual.

Chapter 2 TECHNICAL REFERENCE

Contents


2.1 Basic Operation Outline	2-1
2.1.1 Printer Diagram	2-1
2.1.2 Print Driving	2-2
2.2 Firmware	2-2
2.2.1 Operation Sequence at Power-on	2-2
2.2.2 Operation Sequence at Power-off	2-2
2.2.3 Print Control	2-3
2.2.4 Print Position Adjustment Function	2-4
2.2.5 Head Management	2-4
2.2.6 Printhead Overheating Protection Control	2-4
2.2.7 Pause between Pages	2-4
2.2.8 White Raster Skip	2-4
2.2.9 Sleep Mode	2-4
2.3 Printer Mechanical System	2-6
2.3.1 Outline	2-6
2.3.1.1 Outline	2-6
2.3.2 Ink Passage	2-6
2.3.2.1 Ink Passage	2-6
2.3.2.1.1 Overview of Ink Passage	2-6
2.3.2.2 Ink Tank Unit	2-7
2.3.2.2.1 Structure of Ink Tank Unit	2-7
2.3.2.3 Carriage Unit	2-9
2.3.2.3.1 Functions of Carriage Unit	2-9
2.3.2.3.2 Structure of Carriage Unit	2-10
2.3.2.4 Printhead	2-12
2.3.2.4.1 Structure of Printhead	2-12
2.3.2.5 Purge Unit	2-12
2.3.2.5.1 Functions of Purge Unit	2-12
2.3.2.5.2 Structure of Purge Unit	2-14
2.3.2.6 Maintenance Cartridge	2-16
2.3.2.6.1 Maintenance cartridge	2-16
2.3.2.7 Air Flow	2-16
2.3.2.7.1 Air flow	2-16
2.3.3 Paper Path	2-17
2.3.3.1 Outline	2-17
2.3.3.1.1 Overview of Paper Path	2-17
2.3.3.2 Paper Path	2-18
2.3.3.2.1 Structure of Cassette Pick-up Unit	2-18
2.3.3.2.2 Cassette Pick-up Sequence	2-22
2.3.3.2.3 Structure of Roll Media Pick-up Unit	2-22
2.3.3.2.4 Roll Media Pick-up Sequence	2-23
2.3.3.2.5 Structure of the Manual Feed Unit	2-24
2.3.3.2.6 Manual Feed (from Front) Sequence	2-26
2.3.3.2.7 Manual Feed (from Rear) Sequence	2-26
2.3.3.2.8 Structure of Feed Roller Unit	2-27
2.3.3.2.9 Feed Roller Eccentricity Detection Function	2-28
2.3.3.2.10 Structure of Ejection Sour	2-28
2.3.3.3 Cutter Unit	2-29
2.3.3.3.1 Structure of the cutter unit	2-29

2.4 Printer Electrical System.....	2-30
2.4.1 Outline.....	2-30
2.4.1.1 Overview.....	2-30
2.4.2 Main Controller	2-31
2.4.2.1 Main controller components.....	2-31
2.4.3 Carriage Relay PCB	2-33
2.4.3.1 Carriage PCB components.....	2-33
2.4.4 Motor Driver	2-33
2.4.4.1 Cutter driver PCB components.....	2-33
2.4.4.2 Roll feed unit PCB components	2-33
2.4.5 Maintenance Cartridge Relay PCB	2-34
2.4.5.1 Maintenance cartridge relay PCB components.....	2-34
2.4.6 Power Supply	2-34
2.4.6.1 Power supply block diagram	2-34
2.5 Detection Functions with Sensors.....	2-35
2.5.1 Sensors for covers	2-35
2.5.2 Ink passage system.....	2-36
2.5.3 Carriage system.....	2-38
2.5.4 Paper path system.....	2-40
2.5.5 Others	2-42

2.1 Basic Operation Outline

2.1.1 Printer Diagram

Shown below is a printer diagram.



F-2-1

2.1.2 Print Driving

During printing, print signals and control signals are issued to the printhead via the carriage PCB in order to discharge ink from the nozzles. On a printhead, six arrays of nozzles are provided in six arrays in a staggered pattern.

This printer uses a pair of printheads.

(The Y, PC, C, PGy, Gy, MBk, PM, M, Bk, R, G, B nozzles are mounted in this order from the left.)

Even-numbered nozzle data and odd-numbered nozzle data -- which are print signals -- are sent to each nozzle array in sync with the data sending clock and data latch pulse timings.


Drive control signals include a Heat Enable signal and a Sub Heat Enable signal. The Heat Enable signal is used to discharge ink from nozzles. The Sub Heat Enable signal is used to raise the printhead temperature to a suitable value to maintain the ink discharge amount constant.

2.2 Firmware

2.2.1 Operation Sequence at Power-on

Shown below is the flowchart of the initialization sequence from the moment the power is turned on to the moment the printer enters the online state. The time required for initialization is less than 1 minute*.

* This time does not include the time required for supplying ink and cleaning which takes place after the printer has been left unused for an extended period of time.



F-2-2


2.2.2 Operation Sequence at Power-off

Turning off the power cuts off the voltage to all drive systems. At this time, the firmware starts the power-off sequence as shown below.



This printer immediately suspends all operations in progress and stops whenever the power cord is unplugged or a cover such as the top cover is opened. In this

case, the printer may stop without capping the print head. If the power was turned on by unplugging the power cord, plug the power cord into the outlet, turn on the power again so that the printer enters the online state, and then press the Power button to turn off the power.



2.2.3 Print Control

1. Print mode

This printer is capable of fast, high-quality printing without blur and non-uniform density by changing the carriage operation, media feeding, other printing methods according to the selected media type, print quality, print data and so on.

Printing is performed for each color using a maximum of 16 paths in each print mode according to the selected print quality.

This reduces density irregularities caused by the variation in the amounts of ink discharged from individual nozzles. In addition, it shifts the printing timing so that the current ink layer is nearly fixed before the next ink layer is applied, thus minimizing bleeding.

Even in the same mode, the printer operates in a different way depending on the media setting made using the printer driver.

a) Draft mode

In the draft mode, image data is thinned out and a single band (equivalent to the width of a nozzle array) is printed using one or two paths.

To use this mode, select "Draft" under "Print Quality" in the printer driver.

b) Standard mode

In the standard mode, a single band (equivalent to the width of a nozzle array) is printed using 1-6 (1, 2, 4, or 6) paths.

To use this mode, select "Standard" under "Print Quality" in the printer driver.

c) High quality mode

In the high quality mode, a single band is printed using 2, 4, or 8 paths.

To use this mode, select "High" under "Print Quality" in the printer driver.

d) Highest quality mode

In the high quality mode, a single band is printed using 8 or 16 paths.

To use this mode, select "Highest" under "Print Quality" in the printer driver.

T-2-1

Printing Modes

T-2-2

Media Type	Print Priority	Print Quality	Print-pass	Printing direction(*1)	Print resolution
Plain Paper Plain Paper(High Quality) Plain Paper(High Grade)	Image	Draft	2-pass	Bi-directional	1200x1200dpi
		Standard	4-pass	Bi-directional	1200x1200dpi
		High	8-pass	Bi-directional	1200x1200dpi
	Line Drawing/ Text	Draft	2-pass	Bi-directional	1200x1200dpi
		Standard	4-pass	Bi-directional	1200x1200dpi
	Office Document	Standard	4-pass	Bi-directional	1200x1200dpi
High Resolution Paper Coated Paper Heavyweight Coated Paper	Image	Standard	4-pass	Bi-directional	1200x1200dpi
		High	8-pass	Bi-directional	1200x1200dpi
		Highest	12-pass	Bi-directional	2400x1200dpi
Premium Matte Paper Matte Photo Paper	Image	Standard	6-pass	Bi-directional	1200x1200dpi
		High	8-pass	Bi-directional	2400x1200dpi
		Highest	16-pass	Bi-directional	2400x1200dpi

Media Type	Print Priority	Print Quality	Print-pass	Printing direction(*1)	Print resolution
Glossy Photo Paper	Image	Standard	6-pass	Bi-directional	1200x1200dpi
Semi-Glossy Photo Paper		High	8-pass	Bi-directional	2400x1200dpi
Heavyweight Glossy Photo Paper		Highest	16-pass	Bi-directional	2400x1200dpi
Heavyweight SemiGlos Photo Paper					
Glossy Paper					
Photo Paper Plus					
Photo Paper Plus Semi-Glos					
Synthetic Paper					
Adhesive Synthetic Paper					
Backlit Film					
Backprint Film					
Thin Fabric Banner 2					
Proofing Paper					
Fine Art Photo					
Fine Art Heavyweight Photo					
Fine Art Textured					
Fine Art Watercolor					
Fine Art Block Print					
Canvas Matte 2					
Japanese Paper Washi					
POP Board					
CAD Tracing Paper	Line Drawing/ Text	Draft	2-pass	Bi-directional	1200x1200dpi
CAD Translucent Matte Film		Standard	4-pass	Bi-directional	1200x1200dpi
		High	8-pass	Bi-directional	2400x1200dpi

*1 The print engine may automatically select 1-way printing depending on the printing image type (graphic image, etc.). The printing direction can be selected using the printer driver.

2.2.4 Print Position Adjustment Function

This printer has a printing position adjusting function to adjust the lateral and longitudinal printing positions and bidirectional printing position of the printhead mounted on the carriage as well as the media feed amount.

The printing position can be adjusted in two ways: "automatic adjustment" by which the multi sensor installed at the lower left of the carriage reads the printing position adjusting pattern and "manual adjustment" by which a print position adjusting pattern is printed with the printing conditions changed little by little to allow the user to enter the visually checked adjustment value from the operation panel.

Printing position adjustment requires A4-size or larger roll media or cut sheet.

2.2.5 Head Management

This printer has a nozzle check function to detect any non-discharging nozzle. When a non-discharging nozzle is detected, the printer performs the print head cleaning operation. If the problem persists after completion of the print head cleaning operation, the non-discharged nozzles are automatically backed up by other nozzles.

Detection timing (auto):

Non-discharging nozzles are checked at the following timings:

- Power-on
- When the carriage cover is opened
- When printing starts (The check timing can be changed by selecting System Setup > Nozzle Check from the main menu.

2.2.6 Printhead Overheating Protection Control

This printer performs printhead overheating protection control when an abnormally high temperature is detected in the printhead.

The printhead can overheat, for instance, when the print operation continues for some time with no ink supplied to the nozzles.

The overheating protection control function prevents a print head nozzle from becoming clogged or damaged due to excessive heat.

Overheating protection control is performed based on the temperatures detected by the head temperature sensors in the nozzle arrays. If overheating is detected in a single nozzle array, overheating protection control is performed at either of the following levels according to the temperature.

Protection level 1:

If the printhead temperature sensor detects a temperature above the limit, the carriage stops at the scan end position printer in the direction of travel according to the carriage's scan status.

Then, wait control is performed to allow the printhead to cool naturally. When the printhead temperature drops below the prescribed value or 30 seconds have lapsed since detection of the abnormal temperature, printing resumes.

Protection level 2:

When the head temperature sensor detects an abnormally high temperature, printing stops immediately, the carriage is moved to the home position, and the printhead is capped. In this case, an error code is shown on the display.

2.2.7 Pause between Pages

To prevent ink blots from forming, this printer has a "pause between pages" function to hang down the printed paper from the platen to dry it and delivers it after lapse of the specified wait time.

The user can set the wait time using the printer drive. This function is particularly useful for printing on film-type sheets that requires extra long time to dry.

For borderless printing, 30 seconds of drying time is automatically set.

2.2.8 White Raster Skip

To improve the printing throughput, this printer has a white raster skip function to skip the carriage scan operation for continuous blank segments in print data.

2.2.9 Sleep Mode

This printer has a Sleep mode to reduce the standby power.

The printer automatically enters the Sleep mode (Power Save mode) when neither user operation nor data reception occurs for a preset period of time in the online

or offline mode.

The printer wakes from the Sleep mode when the user presses any button on the operation panel or data is received from the host computer. The time until the printer enters the Sleep mode can be changed from the operation panel. (Default: 15 minutes)

2.3 Printer Mechanical System

2.3.1 Outline


2.3.1.1 Outline

The printer mechanism can be broadly divided into two major components: the ink passage and paper path.

The ink passage consists of an ink tank, a carriage unit having a printhead, a purge unit, and a maintenance cartridge unit which are used to supply, circulate, and suck ink.

The paper path consists of a cassette pick-up unit, roll feed unit, paper feed unit to support four types of media feeding, transport, and ejection.

This section provides an overview of these mechanical components.



2.3.2 Ink Passage


2.3.2.1 Ink Passage

2.3.2.1.1 Overview of Ink Passage

The ink passage consists of ink tanks, printhead, cap, waste ink collection unit, ink tubes for connecting the mechanical components, and an ink suction pump which is operated to suck ink. These components are used to supply, circulate, and suck ink.

A schematic diagram of the ink passage (for one color) and the ink flow are shown below.

0013-4299



a) Ink supply from ink tank to ink supply valve

The ink tank contains ink to be supplied to the printhead.
Ink flow from the ink tank to the ink tank supply valve due to the fluid level difference.

b) Ink flow from ink tank to sub-buffer

Ink flows from the ink tank to the sub-buffer due to the fluid level difference, and air enters the ink tank through the air passage of the sub-buffer, maintaining the pressure inside the ink tank constant.
If the ink in the sub-buffer exceeds the predetermined level, the excessive ink flows to the absorbent material under the ink tank.

c) Ink supply from ink supply valve to printhead

Ink is supplied from the ink tank to the printhead by opening the ink supply valve, capping the head, and operating the suction pump.
The ink sucked from the caps flows to the maintenance cartridge or the waste ink absorbent material under the purge unit.

d) Ink supply during printing

During printing, the ink supply valve is held open to allow ink to flow from the ink tank to the printhead constantly due to the negative pressure generated by discharging of ink.
The waste ink used for printhead cleaning and borderless printing flows to the waste ink absorbent materials under the maintenance cartridge and purge unit in addition to the waste ink box.



If all of ink passages are opened (no ink tank is installed, the ink supply valve is opened, and the printhead fixer lever is opened) when the ink tube is filled with ink, the ink in the ink tube may reverse-flow due to the fluid level difference and ink may leak from the hollow needle of the ink tank.
Do not open all of the ink passages at the same time when the ink tube is filled with ink.

e) Agitation of ink in the ink tank

Ink in the ink tank is agitated to prevent precipitation of pigment-based ink in the ink tank.
This function is implemented by reverse-flowing ink to the ink tank by opening and closing the supply valve in succession. Inside the ink tank is provided with an agitation plate to assist agitation of ink. (The agitation plate is also provided in the
- Operation timing: When a new ink tank is installed or when 168 hours have lapsed since the previous agitation (the agitation is performed irrespective of the whether the printer is printing or cleaning its head)
- Ink supply valve opening/closing count: 30 times (every 30 seconds)
If 336 or more hours have lapsed, the ink valve opening/closing count and the time until the next agitation are changed according to the length of the time lapsed.

2.3.2.2 Ink Tank Unit

2.3.2.2.1 Structure of Ink Tank Unit

0013-4300

a) Ink tank

Each ink tank contains 130 ml of ink (the starter ink tank supplied with the printer contains 90 ml of ink) for each color. The amount of ink is memorized in the EEPROM mounted to the ink tank.

The amount of the ink remaining in the ink tank is detected as a dot count according to the data memorized in the EEPROM.

When the electrodes mounted to the hollow needle detect a non-conductive state, a message appears on the display to indicate that the ink is nearly empty. If the dot count reaches the prescribed value, the ink tank is considered to be empty.

b) Ink port

When the ink tank lock lever is pressed down, the hollow needle enters the ink port (covered with a rubber plug), establishing an ink passage between the printer and ink tank.

c) Air passage


When the ink tank lever of the printer is pressed down, the hollow needle enters the air passage (covered with a rubber plug) and thus the internal pressure of the ink tank is released, maintaining the internal pressure constant.

d) Notches for preventing incorrect insertion

The ink tanks have notches for preventing insertion. Wrong ink tanks cannot be installed in place due to these notches. The ink tank lock lever can lowered to start ink supply only when the ink tank has been installed in place.

e) Agitation plate

The agitation plate assists the ink agitation which is performed to prevent precipitation of ink.



F-2-6


f) Ink supply valve

The ink supply valve is located between the ink tank and ink tube to prevent ink leakage from occurring when the ink tube on the ink tank side is opened during replacement of the ink tank.

The ink supply valve is opened and closed by the valve open/close mechanism which is driven by the valve motor.

The ink tank unit consists of two tank bases each of which contains ink tanks for three colors and the ink tubes for six colors.

The ink supply valve for each color is driven by the valve cam through a link. Ink supply valves for all colors are opened and closed at the same time.



2.3.2.3 Carriage Unit

2.3.2.3.1 Functions of Carriage Unit

0013-4306

a) Printhead mounting function

The carriage mechanically locks the printhead and is connected to the printhead via the terminals on the carriage PCB.

b) Control function

The carriage incorporates a carriage PCB that relays the signal from the main controller, a linear encoder that generates a print timing signal based on the detected carriage position, and a multi sensor that detects the media width and skewing to adjust the registration and height.

The carriage PCB and main controller PCB are connected with a flexible cable.

c) Carriage drive function

The carriage motor moves the carriage back and forth on the platen via the carriage belt.

d) Printhead maintenance function

The printer performs the printhead cleaning operation such as printhead wiping and suction at the home position of the carriage.

The cleaning operation accompanied by ink suction is performed only at the left cap.

e) Nozzle check function

The printer detects a non-discharging nozzle using the head management sensor attached to the maintenance jet tray by discharging ink with the carriage stopped at the maintenance jet tray.

f) Media thickness adjustment function

If the gap between the printhead face and the media increases due to the difference in media thickness, cockling, curling, and so on, more ink mist is generated. In reverse, if the gap decreases, the head can touch the media surface more frequently.

To maintain the proper gap, the remote lifter is driven to adjust the head height automatically according to the selected media type, media supply method, printing conditions (borderless/priority print type), environmental conditions (temperature/humidity), and the result of measurement by the multi sensor.

The relationship between media types and head heights (from the platen) is summarized in the table below. Note that the head height is adjusted with priority given to the media gap measured by the multi sensor.

T-2-3

Head height (mm)	Media type (Value in parentheses:mm)
1.4	Glossy paper(0.2),plain paper(line drawing)(0.1)
1.8	Plain paper(0.1)
2	Coated paper(0.5)

2.2	Semi-glossy canvas(0.5)
3.2	Board paper(1.5)

g) Paper leading edge detection function/paper width detection function/skewing detection function

The leading edge, width, and skewing of the paper fed to the platen is detected by the multi sensor mounted at the lower left of the carriage.

h) Auto print head position adjustment function

The adjustment pattern printed on paper is read by the multi sensor mounted at the lower left of the carriage, thus adjusting the printing timings of each printhead automatically.

i) Remaining roll media detection function

The amount of the remaining roll paper can be detected using the multi sensor mounted at the lower left of the carriage by printing a barcode at delivery of the roll media.

j) Internal temperature detection function

The internal temperature around the printhead is detected using the thermistor mounted on the carriage PCB.

2.3.2.3.2 Structure of Carriage Unit


0013-4344

a) Printhead mounting unit

The printhead is secured to the carriage by the printhead fixer lever.

When the printhead is secured to the carriage, the signal contact of the carriage PCB touches the signal contact point of the printhead, allowing print signals to be transmitted.

The ink passage from the ink tank is connected to the printhead through the ink tube and joint.



b) Ink port

Ink is supplied to the printhead through the ink tubes.

Ink tube run through the ink tube guide mounted on the carriage and move in conjunction with the carriage.

c) Control unit

The carriage PCB is connected to the main controller PCB with a flexible cable. The flexible cable moves in conjunction with the carriage.

A photo-coupler-type encoder is mounted at the top of the rear of the carriage to detect the slit on the linear scale during carriage movement, thus controlling the print timing.


d) Carriage drive unit

Mechanical misalignment of the printhead in the vertical and horizontal direction and in bidirectional printing can be corrected by changing the print timing using the "Adjust Printer" option in the Main menu.

The carriage motor (DC motor) moves the carriage back and forth on the platen via the carriage belt.

The carriage home position is the capping position to which the carriage is slowly moved when the power is turned on.

When the position read on the linear scale is set as the home position for position control, the carriage motor moves based on control signal output from the main controller.



F-2-9

e) Printhead maintenance unit

The printer performs the printhead cleaning operation at the home position of the carriage.

The purge motor is used for wiping. When the carriage is stationary at the home position, the printhead installed in the carriage is wiped with the wiper blade. The wiper blade is pressed against the absorbent material soaked with glycerin so that the wiper blade is moistened with glycerin, thus improving the wiping performance.

Idle ejection of ink is performed on the cap, the borderless ink tray of the platen, and paper.

The suction operation is performed by rotating the pump motor after completion of capping. (Note that the cleaning operation accompanied by suction is performed only at the left cap.)

f) Media thickness adjustment unit

The gap between the printhead face and media is changed with the rotation of the carriage height changing cam driven by the lift motor.

The height of the printhead is detected by the multi sensor mounted at the lower left of the carriage.

g) Multi sensor unit

The multi sensor mounted at the lower left of the carriage is composed of four LEDs (red, blue, green, infrared) and two light-sensitive elements which are used to detect the leading edge, width, and skewing of paper and adjust the registration and head height.

The multi sensor reference plate is provided with a white plate. By measuring the quantity of the reflected light from the white plate, the reference value for gap measurement is computed.

(Service mode: SERVICE MODE>ADJUST>GAP CALIB)

h) Shaft cleaner units

The shaft cleaners mounted at the left and right of the carriage are used to clean the carriage and apply oil to the shaft.

i) Internal temperature detection

A thermistor for measuring the internal temperature is mounted on the carriage PCB on the rear of the head holder.

2.3.2.4 Printhead

2.3.2.4.1 Structure of Printhead


0013-4821

A printhead incorporates six nozzle arrays. Each nozzle can be controlled individually so that a six-color discharge action can be performed by a single printhead.

a) Nozzle arrays

A total of 2560 nozzles are arranged in a two-column staggered pattern.

In each column, 1280 nozzles are arranged in a staggered pattern at intervals of 600 dpi, forming a 2560-nozzle array arranged at intervals of 1200 dpi.




F-2-10

b) Nozzle structure

Ink supplied from the ink tank is filtered by a mesh ink filter, and the supplied to the nozzles.

Ink is supplied from the shared ink chamber to the nozzles. When the head driving current is applied to the nozzle heater, ink boils and form bubbles so that ink droplets are discharged from the nozzles.



F-2-11

2.3.2.5 Purge Unit

2.3.2.5.1 Functions of Purge Unit

0013-4347

To maintain high print quality, the purge unit performs maintenance of the nozzles on the printhead.

The purge unit supports a capping function, cleaning function, and ink supply function.

a) Capping function

The capping function presses the cap of the purge unit against the face plate on the nozzle section of the printhead to prevent nozzle drying and dust adhesion.

Capping is performed when printing is complete, at the start of the suction operation, and when switching to the standby state due to an error.

The capping function also establishes the ink passage between the printhead and purge unit.

b) Cleaning function

The cleaning function restores the printhead to the state where ink can be easily discharged from nozzles. This function includes the following three types of operations.

- Wiping operation

This operation is performed to remove paper fibers and dried ink from the face plate.

- Pumping operation

This operation is performed to remove ink from the nozzles and fill the nozzles with fresh ink.

- Maintenance jet operation

This operation is performed to spray ink from the nozzles to the cap, borderless ink jet tray, a paper to remove bubbles in the nozzles and dust and other foreign particles.

Details of the cleaning function are shown in the table below.

T-2-4

Cleaning mode	Name	Description of cleaning
Cleaning 1	Normal cleaning	Removes dried ink from nozzles, thick ink accumulated on the face, and paper particles.
Cleaning 2	Ink level adjustment cleaning	Adjust the ink level in the head by suction, and then performs normal cleaning.
Cleaning 3	Initial filling ink	Fills the empty tube (during initial installation) with ink, and then performs normal cleaning.
Cleaning 4	Ink drainage for head replacement	Drains ink to replace the head (drains only the ink in the head).
Cleaning 5	Ink drainage for secondary transport	Drains ink from the head and tube for secondary transport.
Cleaning 6	Normal (strong) cleaning	Performs suction stronger than when adjusting the ink filling amount in the head or normal cleaning to unclog nozzles.
Cleaning 7	Aging	Performs idle ejection after replacement of the head.
Cleaning 10	Ink filling after secondary transport	Fills the empty tube (during installation after secondary transport) with ink, and performs normal cleaning.
Cleaning 11	Ink filling after head replacement	Performs normal cleaning after head replacement and ink filling.
Cleaning 15	Dot count suction	Performs suction to remove ink adhered to dried nozzles and thick ink accumulated on the face when the dot count reaches the prescribed value.
Cleaning 16	Precipitated ink agitation	Performs the agitation (ink supply valve open/close) operation to prevent the ink ingredient from precipitating.
Cleaning 17	Cleaning (weak)	Performs cleaning weaker than normal cleaning to unclog nozzles.

Cleaning operation timings are as follows.

T-2-5

Printer status		Description of cleaning
During standby	Each time 120 minutes have elapsed with the nozzles capped	Cleaning 1 (normal cleaning)
	When 168 hours have elapsed since capping	Idle ejection
	When 360 hours have elapsed since capping	Cleaning 2 (ink level adjusting cleaning)
	When 720 hours have elapsed since capping	Cleaning (normal cleaning)
	When 2160 hours have elapsed since capping	Cleaning 6 (normal (strong) cleaning)
	When 168 hours have elapsed since initial installation or previous agitation of precipitated ink (cleaning 16)	Cleaning (precipitated ink agitation)
At power-on	During initial installation	Cleaning 3 (initial filling cleaning)
	When the power is turned on after less than 72 hours have elapsed since abnormal end of print operation (uncapped status)	Cleaning 1 (normal cleaning)
	When the power is turned on after at least 72 hours have elapsed since abnormal end of print operation (uncapped status)	Cleaning 6 (normal (strong) cleaning)
	When the power is turned on after the initial installation or previous precipitated ink agitation (cleaning 16)	Cleaning (precipitated ink agitation)
	When the power is turned on after at least 360 hours have elapsed since normal end of print operation (capped status)	Cleaning 2 (fluid level adjusting)
	When the power is turned on after at least 360 hours have elapsed since normal end of print operation (capped status)	Cleaning 6 (normal (strong) cleaning)
At power-off	When the power is turned off in the uncapped status	Wiping + Idle ejection + Idle suction + Capping
Before starting printing	Before printing after 168 hours have elapsed since capping	Idle ejection
	Before printing after 168 hours have elapsed since capping	Cleaning 1 (normal cleaning)
	Before cleaning after occurrence of an error	Cleaning 1 (normal cleaning)


Printer status		Description of cleaning
During printing	Between scan operations during scanning	Idle ejection + Wiping (idle suction)
After printing	After printing exceeding the prescribed dot count	Cleaning 16 (dot count suction) based on the count or cleaning 6 (normal (strong) cleaning)
	Each time 120 minutes have elapsed in the cap open status	Cleaning 1 (normal cleaning)
When "Head Cleaning" menu is selected	Manual cleaning (head cleaning A)	Cleaning 1 (normal cleaning)
	Manual cleaning (head cleaning B)	Cleaning 6 (normal (strong) cleaning)
When "Replace Head" menu is selected	After replacement of head	Cleaning 2 (fluid level cleaning) + Cleaning 4 (ink drainage after head replacement)
When "Move Printer" is selected	When "Move Printer" is selected	Cleaning 5 (ink drainage for secondary transport)
	After the power is turned on during secondary installation	Cleaning 10 (ink filling after secondary transport)

c) Ink supply function

The suction pump of the purge unit operates together with the ink supply valve to supply ink to the printhead during the initial filling and ink level adjustment.

2.3.2.5.2 Structure of Purge Unit

0013-4382



a) Cap unit


The cap unit is used to cap the print head nozzles during capping and cleaning. The portion that touches the face plate is made from rubber. Two left caps are arranged for the printhead (six arrays of nozzles) installed in the carriage.

During cleaning, the caps used for both suction and capping are used to suck ink from the printhead using the suction pump.

Each of the right caps is used to cap the six arrays of nozzles.

This cap is used only for capping.

During capping, the caps are raised by the cap cams operated by the purge motor to cover the arrays when the carriage has moved to the home position, thus protecting the nozzles.



b) Wiper unit

The wiper unit operated by the purge motor wipes the print head face.

The printer is provided with a pair of wiper blades for better wiping performance.

The wiping operation is performed by a "slide wipe" method by which the purge motor rotates (in the normal direction) to slide the wiper blade via the wiper cam.

It is performed by a constant-speed movement toward the front of the printer as viewed from the printer front.

The wiper blade, which is positioned at right angles to the print head, wipes the entire printhead face, and then the narrow blade is used to wipe the nozzle arrays.


After wiping, the wipe blades are cleaned before they are set at the wiping position so that the maximum wiping performance is obtained.

During the wiper blade cleaning, the ink removed from the head is rubbed off by the ink scraper.

Absorbent material soaked with glycerin is pressed against the wiper blades to enhance the wiping performance. The amount of glycerin used (tank capacity: 50 ml) is managed by counting the number of times the wiper blade is pressed against the absorbent material. When the count reaches the following value, an advance notice of replacement (printing can be continued) or a request for replacement (service call error) is displayed.

T-2-6

Advance notice of replacement	47,500times
Service call	50,000times




c) Pump unit

This printer uses tube pumps (suction pumps) that press on the ink tubes using rollers to produce negative pressure, thus sucking ink.

Two rollers are used to press on a single tube one after another to control the amount of ink sucked.

The roller rotation timing is detected by the pump cam sensor, and the amount of rotation is controlled by the driving of the purge motor.



F-2-15

2.3.2.6 Maintenance Cartridge

2.3.2.6.1 Maintenance cartridge

0013-4161

a) Maintenance cartridge

The maintenance cartridge can contain up to approximately 957 ml (approx. 1021 g) of waste ink (including the moisture evaporation in the waste ink).

b) Detection of waste ink in maintenance cartridge


The quantity of waste ink in the maintenance cartridge is measured by counting dots.

When the quantity of waste ink collected in the maintenance cartridge reaches 80% of the cartridge capacity, a warning message "MTCart Full Soon" appears to indicate that the maintenance cartridge is nearly full.

If printing is continued, an error message "Maint Cartridge Replace Cart" appears to indicate that the maintenance cartridge is full.

When this error occurs, the printer judges the maintenance cartridge as being full of waste ink and stops printing immediately. The printer stops even if printing is in progress, and it will not operate until the maintenance cartridge is replaced with a new one.

The maintenance cartridge incorporates an EEPROM. The engine firmware reads and writes the contents of the EEPROM to control the maintenance cartridge status.



F-2-16


2.3.2.7 Air Flow

2.3.2.7.1 Air flow


0013-4162

This printer has two fans, a mist fan used to collect mist and a suction fan used to suck media onto the platen.

Ink mist that floats inside the printer and ink splashes from the media are collected in the filter through the front duct and the air flow path inside the printer by the driving of the mist fan, thus preventing mist from discharged outside the printer.



During operation of the suction fan, suspended substances are collected in the filter through the airflow path inside the printer, preventing them from being emitted to outside of the printer.




2.3.3 Paper Path

2.3.3.1 Outline

2.3.3.1.1 Overview of Paper Path

The paper path consist of a cassette pick-up unit, roll media unit, feed roller unit, pinch roller drive unit that applies/releases pressure to/from the pinch roller, spur drive unit that moves the spur up/down, and various sensors that detect the media feed status, allowing media to be fed in four ways, fed, and ejected. 0013-4163




2.3.3.2 Paper Path


2.3.3.2.1 Structure of Cassette Pick-up Unit

The paper loaded in the cassette is fed by the pick-up roller, and then fed onto the platen via the feed roller.

The pick-up roller unit has a cassette separation roller to prevent multiple sheets from being fed at the same time. The excess sheets separated by the separation roller are returned to the cassette using the sheet return guide.

The sheet supplied from the cassette is detected by the cassette pick-up sensor and paper detection sensor. If no sheet is detected within the specified time, this problem is detected as a paper jam.






Cassette pick-up sensor

F-2-21

The cassette pick-up roller and cassette feed roller are driven by the cassette motor under the control of the cassette encoder.




cassette motor


cassette encoder

F-2-22


At the bottom of the cassette unit are mounted a cassette detection sensor and a cassette paper detection sensor to check whether a cassette is loaded and whether paper is present in the cassette. The pressure plate is moved up and down by the cam and the movement is detected by the cassette cam sensor.



F-2-23



F-2-24




F-2-25

2.3.3.2.2 Cassette Pick-up Sequence

0013-4172

When a Print command is received with paper loaded in the cassette, cassette pick-up operation starts. The paper supplied from the cassette is checked for normal feeding using the sensors provided along the paper feed path. When the paper is fed by the specified length, the multi sensor adjusts the light intensity and the head hight, detects the paper width, and then starts printing.

During feeding, paper is fed by the cassette pick-up roller and cassette feed roller. During printing, paper is fed by the feed rollers. In paper is fed from the cassette, the multi sensor does not detect the leading edge of paper and skewed feeding of paper.



F-2-26


2.3.3.2.3 Structure of Roll Media Pick-up Unit

0013-4170

When the roll media sensor detects media loaded with the printer powered, the roll media pick-up roller touches the media to rotate the roll media feed roller, thus feeding the roll media onto the platen. Roll media feeding is controlled by the roll motor and roll feed unit PCB.


The roll media pick-up roller is moved up and down by the cam, and the cam movement is detected by the roll media cam sensor.

When the printer is turned on with roll media loaded, the roll media pick-up operation starts automatically.



F-2-27

If the roll media sensor detects that there is no roll during roll media pick-up operation, the roll media is ejected.



F-2-28


2.3.3.2.4 Roll Media Pick-up Sequence

0013-4173

When the roll media detects the loaded roll media, roll media pick-up operation starts.

When media is fed from the auto roll feed unit by the specified length, the multi sensor performs the adjustments and detection shown below, thus completing the roll media pick-up operation.

Roll media is fed by controlling the roll motor and feed motor of the auto roll feed unit.



*1

- This operation is performed only when "ON" is selected for "Detect Remaining Roll Media".
- If the roll media does not have a bar code pattern on it, enter the length of the roll media using the menu on the operation panel.

*2

- The purpose of the first leading edge detection is to detect presence of media.
- The purpose of the second leading edge detection is to detect the printing start position.


F-2-29

2.3.3.2.5 Structure of the Manual Feed Unit

0013-4171

a) Manual feed (from front)


The cut sheet fed from the front (ejection unit) of the printer is fed to the rear of the printer [1], and then fed onto to platen [2] for printing.




F-2-30

This method of feeding paper can be used only when an accept media type is selected from the Manual Feed menu in the use mode. If you select the Manual Feed

menu, the pinch roller unit moves up to allow you to feed paper from the front of the printer according to the message shown on the operation panel. The pinch roller unit is moved up and down by the lift motor. The cam which is also operated by the lift motor via gears moves up and down the pinch roller.




The pick-up timing of the paper fed to the rear of the printer is controlled by the paper detection sensor.



b) Manual feed (from rear)

The paper loaded in the paper tray provided at the rear of the printer is fed onto the platen for printing.

This method of feeding paper can be used only when an acceptable media type is selected from the Manual Feed menu in the user mode. The pick-up timing of the paper loaded in the rear paper tray according to the message shown on the operation panel is controlled by the paper detection sensor.




2.3.3.2.6 Manual Feed (from Front) Sequence

0013-4174

This sequence can be performed according to the messages shown on the operation panel only when a specific type of media is selected after selecting the manual feed mode from the menu shown on the operation panel. When a cut sheet is loaded according to the message shown on the operation panel, the printer performs various adjustments and detection using the multi sensor and then feeds the cut sheet to the rear of the printer. At this time, the multi sensor detects skewed feeding and leading edge of the cut sheet, thus completing the paper pick-up operation.

During printing, the cut sheet is fed by controlling the rotation of the feed roller according to the selected print mode.




2.3.3.2.7 Manual Feed (from Rear) Sequence

0013-4176

This sequence can be performed according to the messages shown on the operation panel only when a specific type of media is selected after selecting the manual feed mode from the menu shown on the operation panel. When the cut sheet loaded at the back of the printer is detected by the sensor, the printer starts feeding the cut sheet. After this, the printer performs various adjustments and detection using the multi sensor, thus completing the paper pick-up operation.

During printing, the cut sheet is fed by controlling the rotation of the feed roller according to the selected print mode.



*1

The auto roll feed unit starts feeding the cut sheet when the roll media detection sensor detects the media. When the auto roll feed unit is not mounted, the printer starts feeding the media when the paper detection sensor detects the media.

F-2-35


2.3.3.2.8 Structure of Feed Roller Unit

0013-4178

The feed roller unit consists of media feeding mechanisms such as feed rollers driven by the feed motor and the pinch roller unit operating in conjunction with the feed rollers.

While being held flat on the platen, media is fed horizontally under the printhead.

The feed roller unit has a sensor that detects the media feed status and a sensor that detects the status of the mechanisms that constitute the paper path.



F-2-36

2.3.3.2.9 Feed Roller Eccentricity Detection Function


0013-4206

Media are fed by the feed roller at regular intervals.


Irregular feeding of media due to the feed roller eccentricity problem, irregular printing can occur in the media feeding direction periodically.

To prevent this, the feed error encoder and feed roller HP sensor detect the presence and amount of feed roller eccentricity every rotation of the feed roller.

This function is called the feed roller eccentricity detection function. If eccentricity is detected, the media feed mount is compensated for according to the amount of eccentricity.



F-2-37



F-2-38

2.3.3.2.10 Structure of Ejection Sour

0013-4208

a) Outline

The ejection spur unit consists of a spur, a spur motor that moves the spur, a spur cam sensor, and an eject roller.

b) Spur lift mechanism

The spur must be moved up and down according to the selected media type and feed mode. The spur motor and spur cam sensor are used to control the spur stop position.

- In case of manual feed from front


When the above mode is selected in the user mode, the spur moves to the upper limit position and then stops.

- Stop position depending on media type

To prevent the spur from damaging the media, the spur stops at a proper position according to the media type selected in the user mode.

c) Eject roller drive

The drive power of the eject roller is transmitted from the feed roller via the drive belt.




2.3.3.3 Cutter Unit

2.3.3.3.1 Structure of the cutter unit

0013-4209

When "Auto cut: Yes" is selected in the printer driver when roll media is used, the cutter unit mounted in front of the spur unit automatically cuts the roll media. The cutter unit is moved up and down by the cutter lift motor. When cut sheets are used, the cutter unit escapes to the specified position (moves up) to prevent the trailing edge of the ejected cut sheet from remaining in the cutter unit.

The cutter unit blade stands ready at the cutter home position except when cutting the roll media. The drive power of the cutter drive motor is transmitted to the loop belt to move the cutter blade from the left to the right for cutting the media.



F-2-40

2.4 Printer Electrical System

2.4.1 Outline

2.4.1.1 Overview

The printer electrical system consists of the main controller PCB and power supply PCB which are mounted on the left side of the printer, the cutter driver PCB, the carriage PCB and print head which are mounted in the carriage, and other electrical components such as the operation panel, sensors, and motors. The main controller PCB manages the image data processing and the entire electrical system, and controls relay PCBs and driver functions.



2.4.2.1 Main controller components

2.4.2.1 Main controller components



The ASIC with a 16-bit internal bus is driven in sync with the 66 MHz external clock. It supports the following functions:

2-31

This unit converts the RGB multi-value image data or CMYK multi-value data received from the host computer through the interface connector to the binary image data for the ink colors used.

DMA controller

This controller control DMA transfer of the data transferred through the input interfaces such as the USB and expansion card slot as well as DMA transfer of the data stored in the DIMM.

Image data generation/output function

This function generates image data for color printing from the received image data and the mask pattern (corresponding to print mode) stored in the DIMM, and stored the generated image data in another DIMM. It also outputs the generated image data to the carriage PCB.

Interrupt controller

This controller receives and processes internal interrupts and external interrupts from the USB, image processing unit, and expansion card slot.

Timer function

Even when the printer is turned off, the timer function is held on using the RTC and lithium battery to assist the cleaning function. When the power cord is plugged to the outlet, power is supplied to the RTC and therefore the lithium secondary battery power is not consumed.

Heat Enable signal control function

This function uses the pulse width to perform variable control of the time of application of the Heat Enable signal to the nozzle heater board for each printhead nozzle array.

Linear scale count function

This function reads the linear scale when the carriage moves, thus generating the ink discharge timing. It also counts the linear scale timing cycle using the reference clock to measure the carriage moving speed.

Dot count function

This function controls the discharge dots used as the information for Heat Enable signal control, maintenance jet control, cleaning control, and remaining ink level for each nozzle array.

Operation panel control function

This function controls serial communication with the operation panel.

PWM control function

This function controls driving of the suction fan and mist fan as well as the temperature of the printhead.

Remaining ink level detection function

This function detects the remaining level of each color of ink based on the signal received from the hollow needle mounted in the ink tank unit.

LED control function

This function controls the LEDs on the ink tank unit.

I/O port function

This function controls input signals from sensors.

Power ON/OFF control function

This function controls turning on/off of the drive power (26 V and 21.5 V) supplied from the power supply PCB.

Head DI sensor read control function

This function controls read operation by the head DI sensor.

Multi sensor control function

This function controls the LED, adjusts the gain, and controls obtainment of the reading for the multi sensor.

EEPROM control function

This function controls the EEPROMs of individual ink tanks, the maintenance cartridge EEPROM, the EEPROM on the maintenance cartridge relay PCB, and the head EEPROM in addition to the on-board EEPROM.

Motor control function

This function controls the carriage motor, feed motor, valve motor, spur motor, pump motor, cassette motor, lift motor, cutter motor, and roll motor based on the input signals from sensors.

b) Driver IC (IC3101)

This IC generates a carriage motor control signal based on the control signal from the ASIC.

c) Driver IC (IC2801)

This IC generates feed motor, valve motor, and spur motor control signals based on the control signal from the ASIC.

d) Driver IC (IC2901)

This IC generates pump motor and cassette motor control signals based on the control signal from the ASIC.

e) Driver IC (IC3001)

This IC generates a lift motor control signal based on the control signal from the ASIC.

f) Regulator IC (IC3301)

This IC generates the 3.3 V to be supplied to the tank ROM board.

g) DIMMs (IC301,IC302,IC601,IC602)

The DIMM comprising a 128-MB DDR-SDRAM and a 64-MB SDR-SDRAM is connected to the 32-bit data bus to be used as a work area. During print data reception, it is also used as an image buffer. It cannot be expanded.

h) FLASH ROM (IC701)

A 64-MB flash ROM is connected to the 8-bit data bus to store the printer control program.

i) EEPROM (IC802)


The 128-KB EEPROM stores various setting values, adjustment values, log data, counter values related to the user/servicing.

MEMO:

After replacement of the main controller PCB, the printer must be started up in the service mode to take over the setting and adjustment values to the new PCB properly (the service mode will be switched to the PCB replacement mode automatically).

2.4.3 Carriage Relay PCB

2.4.3.1 Carriage PCB components



a) Latch ICs (IC1 and IC3)

DI sensor reading control function

This function obtains the DI sensor value in the printhead and head rank for each color and sends it to the main controller PCB based on the control signals from the main controller.

Environmental temperature reading control

This function sends the environmental temperature detected by the thermistor on the board based on the main controller PCB based on the control signals from the main controller PCB.

Image data relay function

This function relays the image data from the main controller PCB to the printhead.


The function for processing image data is not supported.

b) Multi sensor control ICs (IC6 and IC7)

These ICs are used to generate the multi sensor LED control signal and adjust the gain.

2.4.4 Motor Driver

2.4.4.1 Cutter driver PCB components



a) Driver IC (IC1)


Cutter motor drive function

This function controls the cutter motor based on the control signals from the main controller.

Sensor relay function

This function relays the input signals from the cutter lift sensor, cutter HP sensor, and cutter right position sensor to the main controller PCB.

2.4.4.2 Roll feed unit PCB components




a) Driver IC (IC1)

Roll motor drive function

This function controls the roll motor based on the control signals from the main controller.

Sensor relay function


This function relays the input signals from the roll cam sensor and roll media sensor to the main controller PCB.

2.4.5 Maintenance Cartridge Relay PCB**2.4.5.1 Maintenance cartridge relay PCB components**

F-2-46

a) EEPROM (IC1)

The 128-KB EEPROM stores all information written to the EEPROM on the main controller PCB.


2.4.6 Power Supply**2.4.6.1 Power supply block diagram**

F-2-47

The power supply converts AC voltages ranging from 100 V to 240 V from the AC inlet to DC voltages for driving the ICs, motor, and others. The voltage generator circuits include the +26 V generation circuit for driving motors, fans, and sensors and a +21.5 V generation circuit for driving sensors, heads, logic circuits, and others. When the power is turned off, +26 V and +21.5 V are reduced to about 12 V and 9 V respectively (power save mode). Power ON/OFF operation is controlled by the main controller PCB.

2.5 Detection Functions with Sensors

2.5.1 Sensors for covers

**Top cover sensor**

The photo-interrupter-type top cover sensors detect opening and closing of the top cover.


When the top cover is closed, the sensor light is shielded by the sensor arm, thus notifying the sensor of closing the cover.

Ink tank cover switch

The micro-switch-type ink tank cover switch detects opening and closing of the ink tank cover.

When the ink tank cover is closed, the protrusion on the ink tank cover presses the switch, thus detecting closing of the ink tank cover.


2.5.2 Ink passage system



F-2-49

Pump cam sensor


The photo-interrupter-type pump cam sensor detects that the sensor light is shielded or unshielded by the rotary cam. The sensor detects the purge unit capping and wiping states with the combination of the state detected by the pump cam and the state of pump motor rotation control performed by the pump encoder.



F-2-50

Pump encoder

The pump encoder is a photo-interruptive type sensor. It reads the slits on the pump motor's encoder film to control the amount of pump motor rotation.



Valve open/closed detection sensor


The photo-interrupter-type valve open/closed detection sensor detects the valve cam state.

When the link that operates in conjunction with the valve cam shields light, this sensor detects that the ink supply valve has been opened.

Ink detection sensor

Presence or absence of ink in the ink tank is detected according to whether the two hollow needles are electrically connected.


When the ink level in the ink tank lowers below the wall around the hollow needle at the air passage, this hollow needle is electrically disconnected from the hollow needle located on the ink supply side, thus detecting that the printer has run out of ink.




Head management sensor

The photo-transmission-type sensor detects that the printhead is discharging ink.

The carriage moves to and stops at the detection positions for individual nozzle arrays. When the carriage is at a stop, nozzles discharge ink one after another. The sensor detects each nozzle due to the voltage change caused when ink discharged from the nozzle blocks the sensor light.




2.5.3 Carriage system



Multi sensor

The photo-reflection-type multi sensor is composed of four LEDs (red, blue, green and infrared) and two light-sensitive sensors. It detects the leading edge, skewing, and width of media and is used for adjustment of the registration, head height, and calibration. During head adjustment, the light reflected by the infrared LED is detected by two light-sensitive sensors to calculate the head height from the difference between the measurements.



Linear encoder

When the carriage moves, the linear encoder located at the rear of the carriage reads the slits on the linear encoder to detect the carriage position.

Lift cam sensor

This is a photo-interrupter-type sensor. The lift motor is driven by a predetermined number of pulses received after blocking of the sensor light by the flag, thus controlling the heights of the head and platen.

Environmental temperature sensor

The environmental temperature sensor installed on the carriage PCB detects the temperature around the carriage.

The resistance of the thermistor that changes with the temperature inside the printer is reported to the main controller via the carriage PCB. The environmental temperature is used to calibrate the head sensor and to detect abnormal head temperatures.

Head temperature sensor

The diode-type head temperature sensors installed at the top and bottom of the printhead nozzle unit are used to detect the head temperature. The diode voltage that changes with the nozzle unit temperature is reported to the main controller via the carriage PCB.


The detected head temperature is used to control the head operation and to detect abnormal head temperatures.

Printhead contact detection

The printhead contact status is detected by testing the electrical conductivity.

It is detected according to the voltage changes at the two terminals of the contact faces, power supply terminals, and GND terminal.

2.5.4 Paper path system



F-2-56

Cassette pick-up sensor

This is a photo-interrupter-type sensor. When paper supplied from the cassette, the sensor light is blocked by the sensor arm, thus detecting paper.

Cassette cam sensor

This is a photo-interrupter-type sensor. When the cassette camp rotates to block the sensor light, lowering of the pressure plate of the cassette is detected.

Cassette encoder

The cassette encoder detects the slits on the encoder film during cassette motor rotation, thus detecting the amount of rotation of the roller.

Paper detection sensor

This is a photo-interrupter-type sensor. When paper is supplied from the cassette, paper tray, or auto roll feed unit, the sensor light is blocked by the sensor arm, thus detecting paper.

Spur cam sensor

This is a photo-interrupter-type sensor.

When the sensor light is shielded by the rotation of the spur motor, the printer detects that the spur unit is at the upper-limit position.

When the sensor light is unshielded by the rotation of the spur motor, the printer detects that the spur unit is at the bottom position.

The spur height is controlled by driving the spur motor with a predetermined number of pulses.

Cutter lift sensor


This is a photo-interrupter-type sensor. When the cutter unit ascends, the sensor unit blocks the sensor light, thus detecting that the cutter unit is at the upper-limit position (escaped).

Cutter HP sensor

This is a photo-interrupter-type sensor. This sensor detects that the cutter is at the home position (left end).

Cutter right position sensor

This is a photo-interrupter-type sensor. This sensor detects that the cutter is at the right end.



F-2-57

Cassette detection sensor

This is a photo-interrupter-type sensor. When the cassette is installed, the protrusion at the back of the cassette blocks the sensor light to detect the cassette.

Cassette paper detection sensor


This is a photo-interrupter-type sensor. When media is loaded in the cassette, the sensor arm blocks the sensor light, thus detecting the media.

Feed roller HP sensor

The feed roller HP sensor detects the change from the white portion (unshielded sensor light) to black portion (shielded sensor light) of the encoder film on the feed roller, thus setting the home position for feed roller eccentricity compensation.

Feed roller encoder

The feed roller encoder detects the slits on the encoder film of the feed roller during feed motor rotation, thus detecting the amount of rotation of the feed roller (media feed amount).



F-2-58


Roll media sensor

This is a photo-interrupter-type sensor. When media is loaded, the the sensor arm blocks the sensor light, thus detecting the media.

Roll cam sensor

This is a photo-interrupter-type sensor. When the roll cam blocks the sensor light, lowering of the transport roller (contact with the roller) is detected.

2.5.5 Others



F-2-59

Temperature/humidity sensor

This sensor detects the temperature and humidity around the printer so that the measured values are used for head height adjustment, idle discharge control, waste

ink evaporation amount calculation, and suction fan control.

Chapter 3 INSTALLATION

Contents

- 3.1 Installation 3-1
 - 3.1.1 Making Pre-Checks 3-1
 - 3.1.1.1 Making Pre-Checks..... 3-1
 - 3.1.2 Unpacking and Installation..... 3-1
 - 3.1.2.1 Unpacking and Installation 3-1
 - 3.1.3 Checking the Images/Operations 3-7
 - 3.1.3.1 Checking the Images /Operations 3-7
- 3.2 Transporting the Printer 3-8
 - 3.2.1 Transporting the Printer 3-8
 - 3.2.1.1 Transporting the Printer 3-8
 - 3.2.2 Reinstalling the Printer..... 3-9
 - 3.2.2.1 Reinstalling the Printer 3-9

3.1 Installation


3.1.1 Making Pre-Checks

3.1.1.1 Making Pre-Checks

Carry out the installation work with reference to the "Quick Start Guide" supplied with the printer.

Package dimensions and weight are as follows.

Main body (with a palette): 1140(W) mm x 874(D) mm x 628(H) mm, Approx. 65 kg



Installation space

Main body only: 1299(W) mm x 1833(D) mm x 617(H) mm


Main body with an auto roll feed unit: 1299(W) mm x 1910(D) mm x 644(H) mm

3.1.2 Unpacking and Installation


3.1.2.1 Unpacking and Installation




The printer must be moved with it held by two or more persons on both sides. Be careful not to get your lower back and other regions hurt.



When moving the printer, grasp the carrying handles [1] on the left and right side of the bottom. Holding other portions can drop the printer and you may be injured.



(1) Check to see that none of the accessories is missing.




F-3-4

T-3-1

- | | |
|---------------------------------|-----------------------|
| [1] Main body | [7] Power Cord |
| [2] Paper Tray Unit | [8] Printhead |
| [3] Auto Roll Feed Unit(option) | [9] Ink Tank |
| [4] Roll Holder Set(option) | [10] Cleaning Brush |
| [5] Output Tray | [11] Reference guides |
| [6] Cassette | [12] CD-ROM |


(2) Take out the printer and accessories from the shipping box and remove cushioning materials.

First remove the cushioning materials at top of the printer. Next, remove the cushioning materials by raising the left and right sides of the printer one after another with your hand inserted in the clearance as indicated in the figure[1].




F-3-5

(3) Grasping the carrying handles[1] on the left and right side of the bottom, place the printer on a level place such as a table.



F-3-6


(4) Remove all cushioning materials and tape from the printer and accessories.



F-3-7


(5) Install the IEEE1394 Board(option).

(6) Open the top cover, raise the carriage shaft belt stopper[1], and then pull it forward to remove. (Keep the removed belt stopper for future transportation of the printer.)




F-3-8

(7) Connect the power cord to the power connector located at the back of the printer.




F-3-9

(8) Connect the power cord to the outlet.




F-3-10

(9) Set the printhead.
Press the Power button to power on the printer.




F-3-11

(10) When the message "Open Top Cover" is displayed, open the top cover.




F-3-12

(11) Pull the printhead fixer lever forward to open it fully.




F-3-13

(12) Raise the printhead fixer cover to open it fully.



F-3-14


(13) Holding the knobs [1], take out the printhead from the case.



F-3-15




- Do not touch the nozzles [2] and contacts [3] on the printhead [1]. The printhead can damage or a printing failure can occur. Do not reattach the removed protective caps.
- Dispose of these parts following the local regulation.




F-3-16

(14) Remove the orange protective cap 1 [1], and then pull the protective cap 2 [2] downward with the knob pressed.




F-3-17

- (15) Insert the print head in the carriage with the nozzles down and the contacts in the back. Insert it as far as it will go while taking care that the nozzles and contacts do not touch the carriage.




F-3-18

- (16) Turn the printhead fixer cover forward to lock the printhead.



F-3-19


- (17) Turn the printhead fixer lever backward until it clicks.



F-3-20


- (18) Repeat steps (11) to (17) to install the second printhead.

- (19) Close the top cover.




F-3-21

- (20) Open the ink tank cover according to the message shown on the display.




F-3-22


(21) Press the stopper at the top the ink tank lock lever,and then open the ink tank lock lever upward.




(22) Before unpacking the ink tank you want to install,shake it slowly 7-8 times.



(23) Open the package and take out the ink tank by holding its knobs.




- Never touch the ink port[1] and contacts[2]. The peripheral parts may be stained,the ink tank may be broken, or a printing failure may occur.




- Be careful not to drop the ink tank once it is unpacked . The leaked ink may stain the peripheral area.
- Do not remove and shake the ink once it is installed. Ink may spatter.

(24) Install the ink tank in the holder with the ink port facing down as shown.




I-3-27

(25) close the ink tank lock lever until it clicks.



I-3-28


(26) Check that the Ink lamp is light in red.



I-3-29

(27) Repeat steps(21)to(25)to install all ink tanks.

(28) Close the ink tank cover.



I-3-30

(29) When the printhead and all ink tanks have been installed,the message "Do Not Open Cover" appears on the display and initial ink filling requires about 10 minutes.

MEMO:

- Initial ink filling performed at printer installation consumes ink between the ink tanks and printhead.
 - "80%" may be displayed as the remaining ink level immediately after initial ink filling. This is not a failure.
-

3.1.3 Checking the Images/Operations

3.1.3.1 Checking the Images /Operations

Do the paper set and the driver installation, and do the test print.

3.2 Transporting the Printer

3.2.1 Transporting the Printer

3.2.1.1 Transporting the Printer



When transporting the printer, the printhead must be capped and stay in the carriage.

In spite of this precaution, shocks incurred during transportation can damage the printhead.

Print the nozzle check pattern before making preparations for transporting the printer, print the nozzle check pattern again after installing the printer at the new location, and then compare the two printouts.

If any problem such as nozzle clogging cannot be resolved by printhead cleaning, replace the printhead with a new one.

a. Moving the printer on the same floor having no step

(1) Turn off the Power button on the printer and check that the head is capped.

(2) Open the top cover and mount the belt stopper.

When mounting the belt stopper, be careful not to move the carriage by applying too much pressure to the carriage. If the carriage moves with the head capped, the rubber part of the cap may touch the nozzles on the head and damage the printhead.

(3) Close the upper cover.

(4) Remove the roll holder from the roll holder slot.

(5) Remove the interface cable, power cord from the printer.

(6) Hold the carrying handles at the bottom, and then slowly move the printer.

If the printer is subjected to strong vibrations when it is moved, it can cause ink leakage and damage to the printhead. Be sure to move the printer slowly and carefully.

b. Moving the printer on the same floor having a step(s)

When the printer is operating properly, follow the instructions described in "[When the printer is not operating](#)".

When the printer is operating properly

To prevent the waste ink from leaking, drain the ink, wait about 15 minute, and then remove the maintenance cartridge. Package the removed maintenance cartridge so that the waste ink does not leak.

(1) Turn on the Power button on the printer.

(2) Remove the roll holder from the roll holder slot

(3) Enter the Main menu, and then select "Maintenance" > "Move Printer". Remove all ink tanks following the displayed messages.

Put the removed ink tanks in the plastic bag with the ink port up and close the opening. It takes about 4 minutes to complete the "Move Printer" operation.

* "Move Printer" cannot be selected when "MT Cartridge Full Soon" is displayed.

In this case, replace the maintenance cartridge first.

* Never disconnect the power cord or open any cover while the "Move Printer" operation is in progress since this can cancel the operation.

If the "Move Printer" operation is canceled while in progress, the printer will remain in the offline mode and will not return to the online mode.

The "Ink Filling" operation is performed when the power is turned back on after canceling, so repeat the "Move Printer" operation from the beginning.

* The "Move Printer" operation will drain about 38 g of ink per color from the printer to the maintenance cartridge.

(4) When the "Move Printer" operation is completed, turn off the Power button.

(5) Open the top cover to check that the head is capped, and then secure the carriage with the belt stopper.

(6) Close the top cover.

(7) Disconnect the interface cable, power cord, and ground cable from the printer.

(8) Wait about 15 minutes after completion of the "Move Printer" operation, remove the maintenance cartridge, and then package it so that waste ink does not leak. Check that waste ink is no longer leaking after removing the maintenance cartridge. If it is leaking, install the maintenance cartridge and wait until waste ink no longer leaks.

(9) Attach the cushioning materials and tape.

(10) Pack the printer in the packing box, and then put the roll media, ink tank, and optional devices in another packing box for moving.

Use the original packing materials for the printer and other optional devices. If they are not available, pack them with a sufficient amount of cushioning materials.

When the printer is not operating properly

(1) Make sure that the printer is turned off.

(2) Disconnect the interface cable, power cord, and ground cable from the printer.

(3) Remove the roll holder from the roll holder slot.

(4) Drain ink from the printer.

(5) Manually cap the printhead.

* Manual capping is an emergency measure used when the printer does not operate properly, so it can damage the printhead.

(6) Remove the maintenance cartridge, and then package it so that waste ink does not leak.

(7) Attach all external covers.

(8) Open the top cover, and then secure the carriage with the belt stopper.

(9) Close the top cover.

(10) Attach the cushioning materials and tape.

(11) Pack the printer in the packing box, and then put the roll media, ink tank, and optional devices in another packing box for moving.

Use the original packing materials for the printer and other optional devices. If they are not available, pack them with a sufficient amount of cushioning materials.

Before transporting the printer, be sure to go through the following steps to protect the internal mechanism. For the printer packaging work and the installation work after transportation, refer to the "Quick Start Guide".

* When "Check Free Space in Maintenance C" or "Replace Maintenance Cartridge" is shown on the display, you cannot make preparations for transportation. First replace the maintenance cartridge, and then make preparations for transportation.

* Do not incline the printer during transportation. The internal ink may leak and the surrounding area may be stained. If it is necessary to place the printer with either side up or down or to incline the printer, contact your sales agent.

3.2.2 Reinstalling the Printer

3.2.2.1 Reinstalling the Printer

When installing the printer after moving it on the same floor having no step

If you have moved the printer to the installation site on the same floor having no step without draining ink, check the operation test pattern.

When installing the printer after moving it on the same floor having a step(s)

If you have moved the printer to the installation site on the same floor having a step(s) with ink drained, install it again in the same manner as that for initial installation after reception of the delivered printer.

- 1) Unpack the printer.
- 2) Remove the cushioning materials and tape from the printer.
- 3) Install the maintenance cartridge.
- 4) Remove the belt stopper.
- 5) Connect the power cord.
- 6) Turn on the Power button and install ink tanks according to the displayed messages. Ink filling will start.
Load paper and check for normal operation.

Chapter 4 DISASSEMBLY/REASSEMBLY

Contents

4.1 Service Parts	4-1
4.1.1 Service Parts	4-1
4.2 Disassembly/Reassembly	4-1
4.2.1 Disassembly/Reassembly	4-1
4.3 Points to Note on Disassembly and Reassembly	4-3
4.3.1 Note on assemblies (or units) prohibited from disassembly	4-3
4.3.2 Moving the carriage manually	4-3
4.3.3 Units requiring draining of ink	4-3
4.3.4 External Covers	4-4
4.3.5 Driving Unit	4-11
4.3.6 Cutter	4-12
4.3.7 Carriage Unit	4-13
4.3.8 Feeder Unit	4-18
4.3.9 Roll Feed Unit	4-22
4.3.10 Purge Unit	4-25
4.3.11 Waste Ink Collection Unit	4-26
4.3.12 Ink Tank Unit	4-29
4.3.13 Head Management Sensor	4-31
4.3.14 Multi Sensor	4-32
4.3.15 PCBs	4-33
4.3.16 Opening the Cap/Moving the Wiper Unit	4-33
4.3.17 Opening/Closing the Ink Supply Valve	4-34
4.3.18 Draining the Ink	4-34
4.4 Applying the Grease	4-35
4.4.1 Applying the Grease	4-35
4.5 Adjustment and Setup Items	4-38
4.5.1 Procedure after Replacing the Feed Roller HP Sensor or Feed Roller Encoder	4-38
4.5.2 Procedure after Replacing the Carriage Unit or Multi Sensor	4-38
4.5.3 Procedure after Replacing the Head Management Sensor	4-40

4.1 Service Parts

4.1.1 Service Parts

The service parts indicated below require careful handling.

1. Keep all packages with the warning not to turn over.

Pay careful attention to all individually packaged service part (carriage unit, purge unit, ink tank unit, and other parts) boxes marked "This side up" and handle appropriately.



F-4-1

4.2 Disassembly/Reassembly

4.2.1 Disassembly/Reassembly

For the procedure for disassembly/reassembly of the components excluding the major components, refer to the parts catalog.

For the major components, the disassembly flow and detailed disassembly procedures are shown below.

there are the following four major units:

1. Carriage unit
2. Purge unit
3. Cutter unit
4. Ink tank unit


Illustrations in the parts catalog are assigned illustration numbers according to the order in which parts are disassembled.

Major Units Disassembly Flow

* The ink drain operation enclosed in a dashed line must be carried out either manually or automatically.

1) Carriage unit disassembly flow


<Meanings of symbols> c:Connector h:Hook s:screw



F-4-2

2) Purge unit disassembly flow


<Meanings of symbols> c:Connector h:Hook s:screw



F-4-3

3) Cutter unit disassembly flow


<Meanings of symbols> c:Connector h:Hook s:screw



F-4-4

4) Ink tank unit disassembly flow

<Meanings of symbols> c:Connector h:Hook s:screw



F-4-5

4.3 Points to Note on Disassembly and Reassembly

4.3.1 Note on assemblies (or units) prohibited from disassembly

Assemblies that are prohibited from disassembly and their adjustment outside the factory cannot be conducted are indicated by red screws.



F-4-6

4.3.2 Moving the carriage manually



Move the carriage as required during disassembly/reassembly to prevent the carriage from contacting the parts to be removed. The carriage does not move when capped. When uncapping moving the carriage, refer to the procedures in DISASSEMBLY/REASSEMBLY>Points to Note on Disassembly and Reassembly>Opening the Caps and Moving the Wiper Unit.

4.3.3 Units requiring draining of ink


When disassembling the following units of the ink passage, drain ink completely to prevent it from leaking. For how to drain ink, refer to DISASSEMBLY/REASSEMBLY>Points to Note on Disassembly and Reassembly>Draining the Ink.

[1] Carriage unit

Refer to DISASSEMBLY/REASSEMBLY>Points to Note on Disassembly and Reassembly>Carriage Unit.

[2] Ink tank unit

Refer to DISASSEMBLY/REASSEMBLY>Points to Note on Disassembly and Reassembly>Ink Tank Unit.




4.3.4 External Covers


a) Left/right circle cover

Removing the left/right circle cover

- 1) When removing the left circle cover [1], turn it in the direction of the arrow.




- 2) When removing the right circle cover [1], turn it in the direction of the arrow.



Attaching the left/right circle cover


- 1) When attaching the left circle cover, fit it in place with the three hooks [1] up and turn it toward the rear side of the printer. when attaching the right circle cover, fit it in place with the two hooks [2] up and turn it toward the rear side of the printer.



b) Tank cover

Removing the left cover


- 1) When removing the tank cover[4], remove the left circle cover and then open the top cover.
- 2) Open the tank cover, remove the three screws[1], and then release the three hooks[2] while opening the hook[3] outward.



c) Left cover

Removing the left cover


- 1) When removing the left cover[3], remove the left circle cover, open the top cover, and then remove the tank cover.
- 2) Remove the screw[1], remove the hook[2], and slide the tank cover in the direction of arrow 2, and then slide it in the direction of arrow 3.



d) Lower rear cover

Removing the lower rear cover


- 1) When removing the lower rear cover [2], remove the two screws [1] and then remove it.



e) Left rear cover

Removing the left rear cover


- 1) When removing the left rear cover [2], open the top cover, and then remove the left circle cover, tank cover, and left rear cover.
- 2) Remove the three screws [1], and then remove the left rear cover [2].



f) Left front cover

Removing the left front cover

- 1) When removing the left front cover [2], open the top cover, and then remove the left circle cover, tank cover, cassette, and output tray unit.
- 2) Remove the three screws [1], and then remove the left front cover [2].




F-4-15

g) Right upper cover

Removing the right upper cover

- 1) When removing the right upper cover[2], open the top cover, and then remove the right circle cover.
- 2) Release the two hooks[1], and then remove the right upper cover[2].




F-4-16

h) Operation panel

Removing the operation panel

- 1) When removing the operation panel[3], open the top cover and right upper cover.
- 2) Release the two hooks[1] and the flexible cable[2].




F-4-17

i) Filter cover

Removing the filter cover


- 1) When removing the filter cover [1], push it in the direction of the arrow while pressing on the handhold.



j) Mist filter

Removing the mist filter


- 1) When removing the mist filter[2], open the top cover, and then remove the right circle.
- 2) Removing the screw[1], and then remove the mist filter[2].



k) Right cover

Removing the right cover


- 1) When removing the right cover[2], open the top cover, and then remove the right circle cover, right upper cover, operation panel, mist filter, filter cover, filter, and lower rear cover.
- 2) Remove the five screws[1] and hook[A], and then remove the right cover[2].



l) Right front cover

Removing the right front cover


- 1) When removing the right front cover[2], open the top cover, output tray unit, right circle cover, operation panel, mist filter, filter cover, filter, and right cover.
- 2) Remove the two screws[1], and then remove the right front cover[2].



m) Upper rear cover

Removing the upper rear cover


- 1) When removing the upper rear cover[2], open the top cover, left circle cover, tank cover, right circle cover, right upper cover, operation panel, mist filter, filter cover, filter, right cover, and rear lower cover.
- 2) Remove the three screws[1], and then remove the upper rear cover[2].



n) Upper front cover

Removing the upper front cover


- 1) When removing the upper front cover[3], open the top cover, left circle cover, tank cover, right circle cover, right upper cover, and operation panel.
- 2) Remove the two screws[1], and then remove the upper front cover while releasing the three hooks[2].



o) Lower front cover

Removing the lower front cover


- 1) When removing the lower front cover[3], open the top cover, left circle cover, tank cover, right circle cover, right upper cover, operation panel, and upper front cover.
- 2) Remove the screw[1], and then remove the lower front cover[2].



p) Rear cover

Removing the rear cover


- 1) When removing the rear cover[2], open the top cover, left circle cover, tank cover, left cover, left rear cover, right circle cover, right upper cover, operation panel, mist filter, filter cover, filter, right cover, and lower rear cover.
- 2) Remove the three screws[1], and then remove the rear cover[2].



q) Lower back cover

Removing the lower back cover


- 1) When removing the lower back cover[2], open the top cover, left circle cover, tank cover, left cover, left rear cover, right circle cover, right upper cover, operation panel, mist filter, filter cover, filter, right cover, and lower rear cover.
- 2) Remove the two screws[1], and then remove the lower back cover[2].



r) Cover guide

Removing the cover guide


- 1) When removing the cover guide[2], open the top cover, left circle cover, tank cover, right circle cover, right upper cover, operation panel, mist filter, filter cover, filter, right cover, and lower rear cover.
- 2) Remove the two screws[1], and then remove the cover guide[2].



s) Cover support plate (right)

Removing cover support plate (right)


- 1) When removing the cover support plate(right)[2], open the top cover, left circle cover, tank cover, right circle cover, right upper cover, operation panel, mist filter, filter cover, filter, right cover, lower rear cover, cover guide, and upper rear cover.
- 2) Remove the three screws[1], and then remove the cover support plate(right)[2].



t) Cover support plate (left)

Removing the cover support plate (left)

- 1) When removing the cover support plate (left)[2], open the top cover, left circle cover, tank cover, right circle cover, right upper cover, operation panel, mist filter, filter cover, filter, right cover, lower rear cover, and upper rear cover.
- 2) Remove the three screws[1], and then remove the cover support plate (left)[2].




4.3.5 Driving Unit

a) Feed motor

Removing the feed motor

- 1) When removing the feed motor[1], loosen the two screws[2], and then remove the timing belt[3] from the pulley.
- 2) Remove the two screws[4] and connector[5], and then remove the feed motor.



Mounting the feed motor

When mounting the feed motor, attach the timing belt[3] on the pulley, and then tighten the two screws[2].

b) Procedure after replacing the feed roller HP sensor or feed roller encoder

Feed roller eccentricity is Factory-adjusted(correction of variation in the paper feed amount per rotation). It is necessary to adjust feed roller eccentricity after replacing the feed roller HP sensor or feed roller encoder.

In the service mode, perform automatic adjustment of feed roller eccentricity.

Service mode : SERVICE MODE > ADJUST > PRINT PATTERN > LF TUNING


Media type : Photo glossy paper

Media size : Media having a width equal to or larger than that of A2-size paper


4.3.6 Cutter

a) Removing the cutter unit

- 1) When removing the cutter unit, open the top cover, and then remove the cassette, output tray unit, left and right circle covers, tank cover, lower rear cover, left and right covers, right upper cover, operation panel, left and right front cover, upper front cover, mist filter, filter cover, filter, and lower front cover. Refer to **DISASSEMBLY/REASSEMBLY > Points to note on Disassembly and Reassembly > External Cover**.
- 2) Turn the motor pulley[1] in the direction of the arrow to lower the cutter unit[2].




- 3) Remove the screw[1], shift the stopper[2] to the left, and the slide the cutter unit[3] to upper left to remove it.



Points to note on Disassembly an Reassembly of Cutter unit


- 1) When disassembling or reassembling the cutter unit, align the cutter unit roller with the grooves[1] in the cutter lifter unit and cutter drive unit.



F-4-33

b) Removing the cutter lifter unit


- 1) When removing the cutter lifter unit, open the top cover, and then remove the cassette, output tray unit, left and right circle covers, tank cover, lower rear cover, left and right covers, right upper cover, operation panel, left and right front cover, upper front cover, mist filter, filter cover, filter, and lower front cover. Refer to **DISASSEMBLY/REASSEMBLY > Points to note on Disassembly and Reassembly > External Cover**.
- 2) Remove the cutter unit.
- 3) Remove the belt[1], two screws[2], and harness, and then remove the cutter lifter unit[3].



F-4-34

c) Removing the cutter drive unit

- 1) When removing the cutter drive unit, open the top cover, and then remove the cassette, output tray unit, left and right circle covers, tank cover, lower rear cover, left and right covers, right upper cover, operation panel, left and right front cover, upper front cover, mist filter, filter cover, filter, and lower front cover. Refer to **DISASSEMBLY/REASSEMBLY > Points to note on Disassembly and Reassembly > External Cover**.
- 2) Remove the cutter unit.
- 3) Remove the two screws[1], and harness, and then remove the cutter drive unit[2].




F-4-35

4.3.7 Carriage Unit


a) Removing the carriage unit

- 1) Drain the ink. Refer to **DISASSEMBLY/REASSEMBLY > Points to Note on Disassembly and Reassembly > Draining the Ink**.
- 2) Turn off the power, and then move the carriage over the platen. Refer to **DISASSEMBLY/REASSEMBLY > Points to Note on Disassembly and Reassembly > Opening the Caps and Moving the Wiper Unit**.
- 3) Remove the printhead.
- 4) Remove the joint of the ink tube unit. Wrap the removed joint with a plastic bag or other covering so that ink does not splash, then close the plastic bag.



F-4-36

5) Remove the linear scale[1] from the right clamp plate's spring, and then remove it rightward.




F-4-37




When removing the linear scale, take care not to damage or stain it. The stained or damaged liner plate can cause malfunction.

6) While sliding the pulley[2] to the left, remove the carriage belt. Tie the removed belt lightly on the unit.



F-4-38

7) Disconnect the two connectors[1] and four connectors[2] of the flexible cables on the main controller PCB.




F-4-39




The flexible cable connectors[2] are provided with a locking mechanism. When disconnecting or reconnecting the flexible cable, be sure to release the lock. Otherwise, the flexible cable can damage, resulting in malfunction.

8) Release the hook[2], and then remove the flexible cable retainer[1].



F-4-40


- 9) Turn the gear [1] so that the sensor flag of the lift gear [2] leaves the interrupt position of the lift cam sensor [3], then remove the ring [4], the lift gear [2] and the lift cam [5]. Disconnect the connector [6], remove the two screws [7], and then remove the lift cam sensor [3]. Remove the two torsion springs [8], pull out the carriage rail [9] from the right side of the printer, and then remove the carriage.



F-4-41


b) Points to Note on disassembly and Reassembly of Carriage Unit

- 1) Align the mark on the gear [3] with the mark on the bushing [4]. Align the mark on the lift gear [1] with the mark on the gear [2] to remove the ring [5].



F-4-42

- 2) Mount the flexible cable holder retainer hooks at [A] [C] and [G].



c) Multi Sensor Recalibration

Since multi sensors have individual electrical specificity, the following are recalibrated at the factory, namely, the optical axis of the sensor, the sensor gain for measuring the printhead height and color reproduction. Accordingly, carry out the following adjustments in the service mode whenever replacing the carriage unit or multi sensor.

* The multi sensor reference plate must be replaced at the same time whenever the carriage or the multi sensor is being replaced.

- Service mode : SERVICE MODE > ADJUST > GAP CALIB

- Service mode : SERVICE MODE > ADJUST > SENSOR CALIB
Test chart : CL-7(Tool No. : FY9-9323 Use anew chart.)

- Service mode : SERVICE MODE > ADJUST > PRINT PATTERN > OPTICAL AXIS
Media type : Photo glossy paper
Media size : Media having a width equal to or larger than that of A2-size paper

d) Adjusting the wire roller

To prevent the wire roller mounted on the carriage from contacting the duct and others during carriage operation, perform the following adjustment whenever you have removed or replaced the carriage unit. This adjustment is not required when you have replaced only the multi sensor.




* Make adjustments with the carriage lock released.

* Make adjustments with the tube disconnected from the tube guide.


(1) Loosen the two screws[1].

(2) Turn the gear[2] until the lift cam flag[3] reaches the position shown below.

* Bottom position where the sensor[4] light is blocked by the flag (lowest position to which the carriage unit descends).



(3) Place the scale[5] on the mist fan as shown below, adjust the wire guide height so that the wire roller[6] touches the top surface of the scale, and then tighten the screw loosened in step (1).




* To prevent the wire roller from being disengaged, install the right cover with the carriage moved onto the platen.
 * After installing the right cover, check that the wire roller has not been disengaged.


4.3.8 Feeder Unit

a) Removing the pinch roller

- 1) Remove the back cover.
- 2) When removing the pinch roller, press down the pinch roller unit[1] in the direction of the arrow.




- 3) Remove the pinch roller[1].




b) Removing the cassette pick-up roller

- 1) When removing the cassette pick-up roller, first remove the back cover and cassette.
- 2) Then the gear [1] so that the pick-up cam [2] presses down the arm [3] to the lowest position. Release the hook [A], and then remove the cassette pick-up roller [4] while sliding it in the direction of the arrow.




c) Precaution for mounting the roller

When mounting the cassette pick-up roller, fit the projection [A] on the cassette pick-up roller holder [1] in the grooves in the cassette pick-up roller.




d) Removing the cassette separation roller


- 1) When removing the cassette separation roller, first open the top cover, and then remove the back cover, left and right covers, tank cover, right upper cover, operation panel mist filter, filter cover, filter, left and right covers, lower rear cover, and lower back cover.
- 2) Remove the cassette pick-up sensor[3] by removing the screw[1] and connector[2].




- 3) Then the gear[1] to make sure that the pick-up cam[2] is at the position shown below (the arm[3] is raised).




- 4) Remove one ring[1] and two gears[2].




- 5) Press up the guide[1] in the direction of the arrow.




6) Remove the bearing[1] and ring[3], and then remove the separation roller shaft[2].



7) Remove the lever[1] while turning it in the direction of the arrow.




8) Remove the two springs[1], and then remove the cassette separation roller[2].



e) Precaution for mounting the cassette separation roller


1) Align the mark on the gear[1] with the mark on the gear[2].




f) Removing the spur unit

1) When removing the spur unit, first open the top cover, and then remove the left and right circle covers, tank cover, right upper cover, operation panel, lower rear cover, right cover, right front cover, upper front cover, lower front cover, cover guide, upper rear cover, and left and right cover mounting plates. **Refer to DISASSEMBLY/REASSEMBLY > Points to Note on Disassembly and Reassembly > External Covers.**


2) Remove the three screws[1], and then remove the mist fan[2].




3) Remove the three screws[2], and then remove the two tube guides[1]. Remove the ink tube[3] from the front duct[4].




4) Remove the front duct[2] by removing the four screws[1].



5) Turn the pulley[1] in the direction of the arrow so that the spur unit[2] is at the top position.



6) While pressing down the protrusion[A], slide the spur unit[1] in the direction of the arrow to remove it.



g) Handling the Feed Roller



The feed roller is an important mechanical component of the printer. Follow the precaution below when handling it.

* Do not touch the feed roller surface(coated surface).

* Do not scratch or dent the feed roller.

h) Procedure after replacing the feed roller HP sensor or feed roller encoder

Feed roller eccentricity is factory-adjusted (correction of variation in the paper feed amount per rotation). It is necessary to adjust feed roller eccentricity after replacing the feed roller HP sensor or feed roller encoder.

In the service mode, perform automatic adjustment of feed roller eccentricity.

Service mode : SERVICE MODE > ADJUST > PRINT PATTERN > LF TYNING


Media type : Photo glossy paper

Media size : Media having awidth equal to or larger than that of A2-size paper


4.3.9 Roll Feed Unit

a) Removing the roll motor


1) When removing the roll motor, remove the roll feed unit[2] from the main body, and then remove the right cover[3] by removing the two screws[1]




2) Remove the four screws[1], and then remove the left cover[2] and paper tray[3].



3) Remove the three screws[1], and then remove the right inner cover[2].




4) Remove the two screws[1], and then remove the roll motor[2].




b) Removing the roll feed unit


1) When removing the roll motor, remove the roll feed unit[2] from the main body, and then remove the right cover[3] by removing the two screws[1].



2) Remove the four screws[1], and then remove the left cover[2] and paper tray[3].




3) Remove the three screws[1], and then remove the right inner cover[2].



I-4-69

4) Remove the two screws[1], and then remove the roll feed unit PCB[2].




I-4-70

4.3.10 Purge Unit


a) Removing the purge unit

1) Turn the gear[1] of the purge unit[3] in the direction of the arrow to unlock and uncap the carriage. Next, move the carriage[2] onto the platen.




I-4-71

2) Disconnect the connector[1], and then remove the harness from the harness guide.




3) Remove the three screws[3], remove the waste ink tube joint[1] by turning it in the direction of the arrow, and then remove the purge unit[2].



b) Precaution for mounting the purge unit


When mounting the purge unit, pull out the waste ink tube[1] from the back of the printer to the position where the marking is visible. If the waste ink tube is not pulled out to the marking position, it may bend and cause ink leakage.



4.3.11 Waste Ink Collection Unit


a) Removing the waste ink box

- 1) When removing the waste ink box, first remove the cassette and output tray.
- 2) Remove the two screws[1] and connector cover[2].



F-4-75

3) Disconnect the connector[2], and then remove the waste ink box[1].




F-4-76

b) Removing the mist fan

1) When removing the mist fan, first open the top cover, and then remove the output tray, right circle cover, right upper cover, operation panel, mist filter, filter cover, filter, right cover, and right front cover. **Refer to DISASSEMBLY/REASSEMBLY > Points to Note on Disassembly and Reassembly > External Cover.**

2) Remove the three screws[1] and disconnect the connector, and then remove the mist fan[2].




F-4-77


c) Removing the platen duct

1) When removing the platen duct, first open the top cover, and then remove the output tray, maintenance cartridge, waste ink box, left and right circle cover, tank cover, right upper cover, operation panel, mist filter, filter cover, filter, right cover, right front cover, and mist fan. **Refer to DISASSEMBLY/REASSEMBLY > Points to Note on Disassembly and Reassembly > External Cover.**


2) Remove the three screws[2], and then remove the two tube guide[1]. Remove the ink tube[3] from the guide of the front duct[4].




3) Remove the front duct[2] by removing the four screws[1].




4) Remove the platen(front)[2] by removing the four screws[1].



5) Remove the three screws[1].




- 6) Disconnect the two waste ink tubes[3], and then remove the platen duct[2] by removing the five screws[1] and five bushings[4].




4.3.12 Ink Tank Unit

a) Removing the ink tank unit


- 1) Drain the ink. **Refer to DISASSEMBLY/REASSEMBLY > Points to Note on Disassembly and Reassembly > Draining the ink.**
- 2) Remove the output tray, left and right circle covers, tank cover, left and right covers, left and right front covers, right upper cover, operation panel, mist filter, filter cover, filter, lower rear cover, upper front cover, and lower front cover. **Refer to DISASSEMBLY/REASSEMBLY > Points to Note on Disassembly and Reassembly > External Cover.**
- 3) Move the carriage unit to the center. **Refer to 1.1.9.a "Removing the Purge Unit".**
- 4) Remove the three screws[2], and then remove the two tube guide[1].




- 5) Remove the four link levers[2] from the carriage unit[1], and then remove the joint base[3].




Put the removed joint base in a plastic bag so that ink does not splash.




- 6) Remove the cutter unit and cutter lifter unit. **Refer to DISASSEMBLY/REASSEMBLY > Point to Note on Disassembly and Reassembly > Cutter**
 7) Remove the two screws[1], and then remove the support plate[2].



- 8) Remove the four screws[1] and one joint[3], and then remove the two ink tank unit R[2].




9) Remove the four screws[1] and one joint[3], and then remove the two ink tank unit F[2].



b) Removing the valve motor unit.


- 1) When removing the valve motor unit, remove the ink tank cover.
- 2) Remove the two screws[1], disconnect the the two connectors[2], and then remove the valve motor unit[3].



4.3.13 Head Management Sensor

a) Removing the head management sensor

- 1) Remove the screw[1], disconnect the connector[2], and then remove the head management sensor[3].



F-4-90

b) Procedure after replacing the head management sensor


Since the distance between the head management sensor and the carriage unit varies among printers, the optical axis is factory-adjusted to adjust the non-discharging detection position. When you have replaced the head management sensor or performed assembly/reassembly of surrounding parts that can change the distance between the head management sensor and the carriage unit, readjustment is required. Perform the readjustment in the service mode.

Service mode : SERVICE MODE > ADJUST > NOZZLE CHK POS.

4.3.14 Multi Sensor

Removing the multi sensor

1) Remove the screw[1], disconnect the flexible cable[2], and then remove the multi sensor[3].



F-4-91

Since multi sensors have individual electrical specificity, the following are recalibrated at the factory, namely, the optical axis of the sensor, the sensor gain for measuring the printhead height and color reproduction. Accordingly, carry out the following adjustments in the service mode whenever replacing the carriage unit or multi sensor.

- * The multi sensor reference plate must be replaced at the same time whenever the carriage or the multi sensor is being replaced.
- * When replacing the carriage unit, **refer to Adjustment and Setup > Procedure after Removing or Replacing the Carriage Unit.**

- Service mode : SERVICE MODE > ADJUST > GAP CALIB

- Service mode : SERVICE MODE > ADJUST > SENSOR CALIB
Test chart : CL-7(Tool No. : FY9-9323 Use anew chart.)

- Service mode : SERVICE MODE > ADJUST > PRINT PATTERN > OPTICAL AXIS
Media type : Photo glossy paper
Media size : Media having a width equal to or larger than that of A2-size paper

4.3.15 PCBs

Do not replace the main controller PCB and maintenance cartridge relay PCB(ROM board) at the same time.

These PCBs store important data such as settings and carriage drive time. Before replacement of either PCB, the data stored in it is move to the other PCB through internal communication so that it can be taken over to the new PCB automatically. This is the reason why the two PCBs should not be replaced at the same time. If you want to replace both PCBs at the same time, first carry out the procedure "a" and then carry out the procedure "b".

After replacing with the maintenance controller PCB or maintenance cartridge relay PCB which are supplied as service parts, check that the firmware to the latest version.

a) Procedure for replacing the maintenance cartridge relay PCB(ROM board)

- 1) Turn off the printer and unplug the power cord.
- 2) Replace the maintenance cartridge relay PCB.
- 3) Plug the power cord to the outlet, and then turn on the printer with the PAPER SOURCE button and INFORMATION button pressed down. (The printer will start up in the PCB Replacement mode.)
- 4) Check that "Initializing" appears on the display, and then release the buttons. (When the printer enters the PCB Replacement mode, the message lamp goes on.)
- 5) Wait until "REPLACE MODE" appears on the display.
- 6) Select "MC BOARD", and then press the ok button
- 7) Check that "TURN POWER OFF" appears on the display, and then turn off the printer.
- 8) Turn on the printer.
- 9) Check the firmware version. If the firmware is not the latest version, update.

a) Procedure for replacing the main controller PCB

- 1) Turn off the printer and unplug the power cord.
- 2) Replace the main controller PCB.
- 3) Plug the power cord to the outlet, and then turn on the printer with the PAPER SOURCE button and INFORMATION button pressed down. (The printer will start up in the PCB Replacement mode.)
- 4) Check that "Initializing" appears on the display, and then release the buttons. (When the printer enters the PCB Replacement mode, the message lamp goes on.)
- 5) Wait until "REPLACE MODE" appears on the display.
- 6) Select "MC BOARD", and then press the ok button
- 7) Check that "TURN POWER OFF" appears on the display, and then turn off the printer.
- 8) Turn on the printer.
- 9) Check the firmware version. If the firmware is not the latest version, update.


4.3.16 Opening the Cap/Moving the Wiper Unit

This section explains how to open the cap and ink supply valve manually.

To move the carriage with the power off, you need to release the carriage lock pin and cap manually.

1. Opening the Cap/Releasing the Carriage Lock Pin


- 1) Open the top cover, and then remove the output tray, right circle cover, right upper cover, operation panel, mist filter, filter cover, filter, and right cover. **Refer to DISASSEMBLY/REASSEMBLY > points to Note on Disassembly and Reassembly > External Cover.**
- 2) Turn the gear[1] of the purge unit[3] in the direction of the arrow. The cap[5] and lock pin[4] move down, allowing you to move the carriage[2].



F-4-92

2. Moving the Wiper Unit


- 1) Open the top cover, and then remove the output tray, right circle cover, right upper cover, operation panel, mist filter, filter cover, filter, and right cover. **Refer to DISASSEMBLY/REASSEMBLY > points to Note on Disassembly and Reassembly > External Cover.**
- 2) To move the wiper unit[3], turn the gear[1] of the purge unit[2] in the direction of the arrow.



F-4-93

4.3.17 Opening/Closing the Ink Supply Valve

- 1) Open the top cover, and then remove the left circle cover tank cover.
- 2) To open the ink supply valve, turn the cam[2] in the direction of the arrow and press the link[1].



F-4-94



- * If the tube is full of ink, releasing the printhead lock lever with the ink supply valve open can cause the ink to flow back to the ink supply unit, resulting in leakage of ink from the ink supply needle.
- * If the ink supply valve is held open due to a problem such as a valve motor error(E02D06), remove the valve motor unit(refer to DISASSEMBLY/REASSEMBLY > Points to Note on Disassembly and Reassembly > Ink Tank Unit) and close the ink supply valve.

4.3.18 Draining the Ink

There are two methods of removing the ink, a manual method and an automatic method.
 There the ink is drained, the ink inside the ink passage totaling about 72g (about 6g x 12 colors) is drained as waste ink.



To prevent ink leakage, be sure to drain the ink inside the ink passage before transporting the printer again.

1. Automatic ink drainage

To perform "automatic ink drainage", select "mainMenu" > "Maintenance" > "Move Printer".




Perform automatic ink drainage again if a power outage or other cause shuts off the power during the operation for automatic ink drainage.

2. Manual Ink Drainage

Perform manual ink drainage when the printer cannot be powered due to a printer's electrical part failure, firmware error, or power supply problem.


Manual Ink Drainage Procedure

- 1) Open the top cover, and then remove the left and right circle covers, tank cover, right upper cover, operation panel, mist filter, filter cover, filter, and right cover.
Refer to DISASSEMBLY/REASSEMBLY > Points to Note on Disassembly and Reassembly > External Cover.
- 2) Move the carriage onto the platen. **Refer to DISASSEMBLY/REASSEMBLY > Points to Note on Disassembly and Reassembly > Opening the Cap/Move the Wiper Unit.**
- 3) Turn the cam[2] in the direction of the arrow, and then press the link[1] to open the ink supply valve.



F-4-95

4) Release both printhead fixer levers[1] to flow the ink from inside the ink tube to the sub-buffer of the ink tank unit.



F-4-96



The sub-buffer can contain 22g of ink. About 6g of ink flows into the sub-buffer each time manual ink drainage is performed.

Make sure that the ink has been drained completely, turn the cam to close the ink supply valve.

4.4 Applying the Grease

4.4.1 Applying the Grease

Some parts require application of grease when replaced. Apply the grease(special tool) listed below. Smear the grease lightly and evenly with a flat brush or the like.

For the printer disassembly/reassembly method, refer to DISASSEMBLY/REASSEMBLY and parts catalog.





Do not apply the grease to locations in which not designated grease may cause poor print quality. Take particular care that grease do not get onto the wiper, cap, and linear scale.

T-4-1



No.	Location	Grease type	Quantity	Remarks
1	Joint base	molykote PG-641	Approx.6/12mg	
2	Wire roller	molykote PG-641	Approx.5mg	
3	Slide roller	molykote PG-641	Approx.12mg	
4	Eject roller bearing	molykote PG-641	Approx.12mg	
5	Eject roller center bearing	molykote PG-641	Approx.12mg	
6	Spur cam	molykote PG-641	Approx.20mg	
7	Pick-up cam	molykote PG-641	Approx.12mg	

a) Carriage unit


1) Joint



2) Wire roller




3) Slide roller




b) Eject roller unit


- 4) Eject roller bearing
- 5) Eject roller center bearing



- c) Spur unit**
- 6) Spur cam



d) Pick-up unit
7) Pick-up cam



4.5 Adjustment and Setup Items

4.5.1 Procedure after Replacing the Feed Roller HP Sensor or Feed Roller Encoder

Procedure after replacing the feed roller HP sensor or feed roller encoder

Feed roller eccentricity is factory-adjusted (correction of variation in the paper feed amount per rotation). It is necessary to adjust feed roller eccentricity after replacing the feed roller HP sensor or feed roller encoder.

In the service mode, perform automatic adjustment of feed roller eccentricity.

Service mode : SERVICE MODE > ADJUST > PRINT PATTERN > LF TYNING

Media type : Photo glossy paper

Media size : Media having a width equal to or larger than that of A2-size paper

4.5.2 Procedure after Replacing the Carriage Unit or Multi Sensor

a) Multi Sensor Recalibration

Since multi sensors have individual electrical specificity, the following are recalibrated at the factory, namely, the optical axis of the sensor, the sensor gain for measuring the printhead height and color reproduction. Accordingly, carry out the following adjustments in the service mode whenever replacing the carriage unit or multi sensor.



The multi sensor reference plate must be replaced at the same time whenever the carriage or the multi sensor is being replaced.

* Service mode : SERVICE MODE > ADJUST > GAP CALIB

* Service mode : SERVICE MODE > ADJUST > SENSOR CALIB
Test chart : CL-7(Tool No. : FY9-9323 Use anew chart.)

* Service mode : SERVICE MODE > ADJUST > PRINT PATTERN > OPTICAL AXIS
Media type : Photo glossy paper
Media size : Media having a width equal to or larger than that of A2-size paper

b) Adjusting the wire roller

To prevent the wire roller mounted on the carriage from contacting the duct and others during carriage operation, perform the following adjustment whenever you have removed or replaced the carriage unit. This adjustment is not required when you have replaced only the multi sensor.


* Make adjustments with the carriage lock released.

* Make adjustments with the tube disconnected from the tube guide.

(1) Loosen the two screws[1]


(2) Turn the gear[2] until the lift cam flag[3] reaches the position shown below.

* Bottom position where the sensor[4] light is blocked by the flag (lowest position to which the carriage unit descends)



F-4-103

(3) Place the scale[5] on the mist fan as shown below, adjust the wire guide height so that the wire roller[6] touches the top surface of the scale, and then tighten the screw loosened in step (1).



F-4-104

* To prevent the wire roller from being disengaged, install the right cover with the carriage moved onto the platen.

* After installing the right cover, check that the wire roller has not been disengaged.

4.5.3 Procedure after Replacing the Head Management Sensor

Since the distance between the head management sensor and the carriage unit varies among printers, the optical axis is factory-adjusted to adjust the non-discharging detection position. When you have replaced the head management sensor or performed assembly/reassembly of surrounding parts that can change the distance between the head management sensor and the carriage unit, readjustment is required. Perform the readjustment in the service mode.

Service mode : SERVICE MODE > ADJUST > NOZZLE CHK POS.

Chapter 5 MAINTENANCE

Contents

5.1 Periodic Replacement Parts 5-1

 5.1.1 Periodic Replacement Parts..... 5-1

5.2 Consumable Parts 5-1

 5.2.1 Consumable Parts 5-1

5.3 Periodic Maintenance 5-1

 5.3.1 Periodic Maintenance..... 5-1

5.1 Periodic Replacement Parts

5.1.1 Periodic Replacement Parts

T-5-1

Level	Periodic Replacement part
User	None
Service Personnel	None

5.2 Consumable Parts

5.2.1 Consumable Parts

T-5-2

Level	Consumable		Durability	Remarks
	Part name	Part No.		
User	-	-	-	See 1.2.6 "Consumable"
Service personnel	FAN UNIT, SUCTION	QM3-0179-000	25000sheets of paper	
	SCALE, LINEAR	QC2-0652-000	25000sheets of paper	
	LEVER, R, INK TUBE	QC2-0659-000	25000sheets of paper	
	LEVER, L, INK TUBE	QC2-0660-000	25000sheets of paper	
	LINK, LEVER, TUBE	QC2-0661-000	25000sheets of paper	
	WIRE(MECH), GUIDE, TUBE	QC2-0663-000	25000sheets of paper	
	PAD, OIL	QC2-0664-000	25000sheets of paper	
	HOLDER, B, FLAT CABLE	QC2-0672-000	25000sheets of paper	
	CAM, LIFTER	QC2-0675-000	25000sheets of paper	
	SPRING, TORSION	QC2-0676-000	25000sheets of paper	
	ROLLER, WIRE(MECH), GUIDE	QC2-1374-000	25000sheets of paper	
	SPRING, TENSION	QC2-1396-000	25000sheets of paper	
	CLEANER UNIT, L, RAIL, CARRIAGE	QM3-0542-000	25000sheets of paper	
	CLEANER UNIT, R, RAIL, CARRIAGE	QM3-0543-000	25000sheets of paper	
	CARRIAGE UNIT	QM3-0558-000	25000sheets of paper	
	JOINT, LEVER	QC2-0758-000	25000sheets of paper	
	SUPPLY UNIT, INK, FRONT	QM3-0554-000	25000sheets of paper	
	SUPPLY UNIT, INK, REAR	QM3-0555-000	25000sheets of paper	

5.3 Periodic Maintenance

5.3.1 Periodic Maintenance

T-5-3

Level	Periodic maintenance
User	Cleaning of ink mist and other substances
Service personnel	None

Chapter 6 TROUBLESHOOTING

Contents

6.1 Troubleshooting	6-1
6.1.1 Outline	6-1
6.1.1.1 Outline of Troubleshooting	6-1
6.1.2 Troubleshooting When Warnings Occur	6-1
6.1.2.1 Ink Lvl: Chk XX (1000,1001,1002,1003,1004,1005,1006,1008,1009,100A,100B,100C)	6-1
6.1.2.2 MTCart Full Soon (1100)	6-1
6.1.2.3 Mist Full Soon (1101)	6-1
6.1.2.4 GARO W12xx: xx stands for digits (1221,1222,1223,1225,1231,1232,1233,1234,1235)	6-1
6.1.2.5 Feed Limit... (100F)	6-1
6.2 Location of Connectors and Pin Arrangement	6-2
6.2.1 Main controller PCB	6-2
6.2.2 Carriage relay PCB	6-13
6.2.3 Cutter driver PCB	6-20
6.2.4 Power supply	6-21
6.2.5 Roll feed unit PCB	6-22
6.3 Version Up	6-22
6.3.1 Firmware Update Tool	6-22
6.4 Service Tools	6-23
6.4.1 Tool List	6-23

6.1 Troubleshooting

6.1.1 Outline

6.1.1.1 Outline of Troubleshooting

1. Outline

Troubles subject to troubleshooting are classified into those shown on the display (warning, error, and service call) and those not shown on the display.

2. Precautions for Troubleshooting

- 1) Check the environmental conditions and the media used for printing.
 - 2) Before performing troubleshooting, make sure that all connectors and cables are connected properly.
 - 3) When servicing the printer with the external cover removed and the AC power supplied, be extremely careful to avoid electric shock and shorting electrical devices.
 - 4) In the following sections, the troubleshooting steps are described such that the component related to the most probable cause of the problem will be repaired or replaced first, being followed by components with less problem probability. If multiple components have the same problem probability, the steps are described begging with the easiest one.
- After performing each step, check to see if the problem has been resolved by making test prints. If the problem persists, proceed to the next step.
- 5) After completion of the troubleshooting, check that all connectors and cables have been reconnected and screws have been tightened firmly.
 - 6) Whenever you have performed replacement or repair services, make test prints to check whether the problem has been resolved.

6.1.2 Troubleshooting When Warnings Occur

6.1.2.1 Ink Lvl: Chk XX (1000,1001,1002,1003,1004,1005,1006,1008,1009,100A,100B,100C)

XX stands for an ink name.

When a warning occurs, no code number is displayed. To view the warning history, select SERVICE MODE > DISPLAY > WARNING.

<Cause>

The electrodes attached to the hollow needle in the ink tank unit has detected that the ink level lowered below the specified one.

<Probable problem locations>

Ink tank, ink tank unit, main controller

<Remedy>

1. Check the ink level.
2. Replace the ink tank.
3. Check the connector of the ink tank unit.
4. Replace the ink tank unit.
5. Replace the main controller.

6.1.2.2 MTCart Full Soon (1100)

<Cause>

The maintenance cartridge is nearly full of waste ink (about 80% of the total capacity of the maintenance cartridge).

<Probable problem locations>

Maintenance cartridge, main controller

<Remedy>

1. Maintenance cartridge
Select SERVICE MODE > COUNTER > PRINTER > 1-INK to check the free space in the maintenance cartridge. If there is almost no free space, replace the maintenance cartridge.
2. Replace the main controller

6.1.2.3 Mist Full Soon (1101)

<Cause>

The waste ink in the waste ink box is nearly full (about 97% of the total capacity).

<Probable problem locations>

waste ink box, main controller

<Remedy>

1. Replace the waste ink box.
After replacing the waste ink box, select SERVICE MODE > INITIALIZE > PARTS COUNTER > PARTS VI to reset the waste ink counter.
2. Replace the main controller

6.1.2.4 GARO W12xx: xx stands for digits (1221,1222,1223,1225,1231,1232,1233,1234,1235)

<Cause>

The GARO command was erroneous during data reception.

<Probable problem locations>

Operation error, main controller

<Remedy>

1. Check the operation method and print again.
2. Replace the main controller.

6.1.2.5 Feed Limit... (100F)

<Cause>

The main controller has detected that the roll media was fed by the maximum amount in the manual feed mode.
Maximum feed amount in reverse feed mode: Printing standby position (on feed roller)

<Probable problem locations>


Main controller

<Remedy>

1. Replace the main controller.

6.2 Location of Connectors and Pin Arrangement

6.2.1 Main controller PCB



J801
Unused
T-6-2

J1001 (USB)			
Pin Number	Signal name	IN/OUT	Function
1	VBUS	IN	USB VBUS (+5V)
2	D-	IN/OUT	USB data (-)
3	D+	IN/OUT	USB data (+)
4	GND	-	USB GND
5	GND	-	GND (Connector shell)
6	GND	-	GND (Connector shell)
T-6-3			

J1001 (1394 board)			
Pin Number	Signal name	IN/OUT	Function
1	GND	-	GND
2	GND	-	GND
3	GND	-	GND
4	+3.3V	OUT	Power supply (+3.3V)
5	+3.3V	OUT	Power supply (+3.3V)
6	+3.3V	OUT	Power supply (+3.3V)
7	+3.3V	OUT	Power supply (+3.3V)
8	+3.3V	OUT	Power supply (+3.3V)
9	+3.3V	OUT	Power supply (+3.3V)
10	N.C.	-	N.C.
11	GND	-	GND
12	PME#	IN	Power management enable signal
13	INTA#	IN	interrupt signal
14	GND	-	GND
15	RST#	OUT	PCI reset signal
16	CLK	OUT	PCI clock signal
17	GNT#	OUT	Grant signal
18	GND	-	GND
19	REQ#	IN	Request signal

J1001 (1394 board)			
Pin Number	Signal name	IN/OUT	Function
20	AD31	IN/OUT	Address and data signal 31
21	AD30	IN/OUT	Address and data signal 30
22	AD29	IN/OUT	Address and data signal 29
23	AD28	IN/OUT	Address and data signal 28
24	GND	-	GND
25	AD27	IN/OUT	Address and data signal 27
26	AD26	IN/OUT	Address and data signal 26
27	AD25	IN/OUT	Address and data signal 25
28	AD24	IN/OUT	Address and data signal 24
29	CBE3#	IN/OUT	Bus command and byte enable signal 3
30	IDSEL	OUT	Initialization device select signal
31	GND	-	GND
32	GND	-	GND
33	AD23	IN/OUT	Address and data signal 23
34	AD22	IN/OUT	Address and data signal 22
35	AD21	IN/OUT	Address and data signal 21
36	AD20	IN/OUT	Address and data signal 20
37	GND	-	GND
38	AD19	IN/OUT	Address and data signal 19
39	AD18	IN/OUT	Address and data signal 18
40	AD17	IN/OUT	Address and data signal 17
41	AD16	IN/OUT	Address and data signal 16
42	CBE2#	OUT	Bus command and byte enable signal 2
43	GND	-	GND
44	FRAME#	IN/OUT	Cycle frame signal
45	IRDY#	IN/OUT	Initiator redy signal
46	TRDY#	IN/OUT	Target redy signal
47	DEVSEL#	IN/OUT	Device select signal
48	GND	-	GND
49	STOP#	IN/OUT	Stop signal
50	LOCK#	IN/OUT	Lock signal
51	PERP#	IN/OUT	Parity error signal
52	SERR#	IN/OUT	System error signal
53	PAR	IN/OUT	Parity signal
54	CBE1#	IN/OUT	Bus command and byte enable signal 1
55	GND	-	GND
56	GND	-	GND
57	AD15	IN/OUT	Address and data signal 15
58	AD14	IN/OUT	Address and data signal 14
59	AD13	IN/OUT	Address and data signal 13
60	AD12	IN/OUT	Address and data signal 12
61	GND	-	GND
62	AD11	IN/OUT	Address and data signal 11
63	AD10	IN/OUT	Address and data signal 10
64	AD9	IN/OUT	Address and data signal 09
65	AD8	IN/OUT	Address and data signal 08
66	CBE0#	IN/OUT	Bus command and byte enable signal 0
67	GND	-	GND
68	AD7	IN/OUT	Address and data signal 07
69	AD6	IN/OUT	Address and data signal 06
70	AD5	IN/OUT	Address and data signal 05
71	AD4	IN/OUT	Address and data signal 04
72	GND	-	GND
73	AD3	IN/OUT	Address and data signal 03
74	AD2	IN/OUT	Address and data signal 02
75	AD1	IN/OUT	Address and data signal 01
76	AD0	IN/OUT	Address and data signal 00
77	GND	-	GND
78	HDD_LED	-	N.C.
79	+5V	OUT	Power supply (+5V)
80	+5V	OUT	Power supply (+5V)
81	+5V	OUT	Power supply (+5V)

J1001 (1394 board)			
Pin Number	Signal name	IN/OUT	Function
82	+3.3V	OUT	Power supply (+3.3V)
83	+3.3V	OUT	Power supply (+3.3V)
84	+3.3V	OUT	Power supply (+3.3V)
85	GND	-	GND
86	GND	-	GND
87	GND	-	GND
88	GND	-	GND

T-6-4

J1201 (Network)			
Pin Number	Signal name	IN/OUT	Function
1	TX+	OUT	Ethernet data TX line (+)
2	TX-	OUT	Ethernet data TX line (-)
3	RX+	IN	Ethernet data RX line (+)
4	-	-	Not used
5	-	-	Not used
6	RX-	IN	Ethernet data RX line (-)
7	-	-	Not used
8	-	-	Not used
9	GREEN_LED_C	OUT	Link LED (green:100Mb/s) cathode terminal
10	GREEN_LED_A	OUT	Link LED (green:100Mb/s) anode terminal
11	YELLOW_LED_C	OUT	Link LED (yellow:10Mb/s) cathode terminal
12	YELLOW_LED_A	OUT	Link LED (yellow:10Mb/s) anode terminal

T-6-5

J1401			
Unused			

T-6-6

J1402			
Unused			

T-6-7

J1801 (Connect to power supply)			
Pin Number	Signal name	IN/OUT	Function
1	HD1_VHFBH	OUT	VH feedback voltage +
2	HD1_VHFBG	OUT	VH feedback voltage -
3	VH	IN	Power supply (+21.5V)
4	GND	-	GND
5	VH	IN	Power supply (+21.5V)
6	GND	-	GND
7	RGV20(VCC)	IN	Power supply (+21.5V)
8	GND	-	GND
9	VM	IN	Power supply (+26V)
10	GND	-	GND
11	VM2	IN	Power supply (+26V)
12	GND	-	GND
13	VH_ENB	OUT	VH power supply ON/OFF signal
14	PW_CONT	OUT	Normal/power saving switch signal

T-6-8

J2101			
Unused			

T-6-9

J2501 (Connect to Spur motor/spur cam sensor/Lift cam sensor/mist fan)			
Pin Number	Signal name	IN/OUT	Function
1	HAKUSHA_MOTOR_AM	OUT	Spur motor drive signal AM
2	HAKUSHA_MOTOR_AP	OUT	Spur motor drive signal AP
3	SNS_3V_1	OUT	Power supply (+3.3V)
4	GND	-	GND
5	HAKUSHA_CAM_SNS	IN	Spur cam sensor output signal
6	FAN_VM	OUT	Power supply (+26V)
7	MIST_FAN_LOCK	IN	Mist fan lock signal
8	MIST_FAN_PWM	OUT	Mist fan duty control signal
9	GND	-	GND

J2501 (Connect to Spur motor/spur cam sensor/Lift cam sensor/mist fan)			
Pin Number	Signal name	IN/OUT	Function
10	LIFT_CAM_3V	OUT	Power supply (+3.3V)
11	GND	-	GND
12	LIFT_CAM_SNS	IN	Lift cam sensor output signal

T-6-10

J2502 (Suction fan/maintenance cartridge relay PCB/cassette paper detection sensor/Feed roller HP sensor/feed roller encoder)			
Pin Number	Signal name	IN/OUT	Function
1	FAN_VM	OUT	Power supply (+26V)
2	PLATEN_FAN_LOCK	IN	suction fan lock signal
3	PLATEN_FAN_PWM	OUT	suction fan duty control signal
4	GND	-	GND
5	MENT_SDA	IN/OUT	Maintenance cartridge rom control signal (data)
6	MENT_SCL	IN/OUT	Maintenance cartridge rom control signal (clock)
7	GND	-	GND
8	MENT_3V		Power supply (+3.3V)
9	CST_PAPER_NONE_3V	OUT	Power supply (+3.3V)
10	GND	-	GND
11	CST_PAPER_NONE_SNS	IN	Cassette paper detection sensor output signal
12	LF_HP_3V	OUT	Power supply (+3.3V)
13	GND	-	GND
14	LF_HP_SNS	IN	Feed roller HP sensor output signal
15	GND	-	GND
16	LF_ENCA	IN	Feed roller encoder output signal A
17	RGV5	OUT	Power supply (+5V)
18	LF_ENCB	IN	Feed roller encoder output signal B

T-6-11

J2601 (Operation panel)			
Pin Number	Signal name	IN/OUT	Function
1	POWER_ON	IN	Power switch signal
2	PM_START	OUT	Power supply (+5V)
3	BUZZER	OUT	Buzzer control signal
4	PDODATA	OUT	Panel IC control signal
5	+3.3V	OUT	Power supply (+3.3V)
6	PDI_DATA	IN	Panel IC data signal
7	GND	-	GND
8	/PANEL RESET	OUT	Panel reset signal
9	GND	-	GND
10	PDOPCLK	OUT	Panel IC clock signal
11	PANEL_5V	OUT	Power supply (+5V)
12	/PDOCS_L	OUT	Panel supply chip select signal

T-6-12

J2701 (Cutter unit)			
Pin Number	Signal name	IN/OUT	Function
1	OPT_5V	OUT	Power supply (+5V)
2	GND	-	GND
3	CUTTER_L_SNS	IN	Cutter HP sensor signal
4	CUTTER_R_SNS	IN	Cutter right detection sensor signal
5	CUTTER_POS1_SNS	IN	Cutter lift sensor signal
6	CUTTER_UNIT	IN	Cutter unit detection signal
7	CUTTER_VM	OUT	Power supply (+26V)
8	/CUTTER_SLEEP	OUT	Cutter motor driver sleep signal
9	CUTTER_STB	OUT	Cutter motor driver strobe signal
10	CUTTER_DAT	OUT	Cutter motor driver data signal
11	CUTTER_CLK	OUT	Cutter motor driver clock signal
12	CUTTER_ENB	OUT	Cutter motor driver enable signal
13	CUTTER_PHS	OUT	Cutter motor driver phase signal
14	GND	-	GND

T-6-13

J2702 (Cassette)			
Pin Number	Signal name	IN/OUT	Function
1	CST_OUTB	OUT	Cassette motor drive signal B
2	CST_OUTA	OUT	Cassette motor drive signal A

J2702 (Cassette)			
Pin Number	Signal name	IN/OUT	Function
3	GND	-	GND
4	CST_ENCA	IN	Cassette encoder output signal A
5	SNS_5V	OUT	Power supply (+5V)
6	CST_ENCB	IN	Cassette encoder output signal B
7	SNS_3V_1	OUT	Power supply (+3.3V)
8	GND	-	GND
9	CST_CAM_SNS		Cassette cam sensor output signal
10	SNS_3V_1	OUT	Power supply (+3.3V)
11	GND	-	GND
12	CST_EARLY_SNS	IN	Cassette pick-up sensor output signal
13	SNS_3V_1	OUT	Power supply (+3.3V)
14	GND	-	GND
15	CST_UNIT_SNS	IN	Cassette detection sensor output signal

T-6-14

J2703 (Auto feed roll unit)			
Pin Number	Signal name	IN/OUT	Function
1	OPT_5V	OUT	Power supply (+5V)
2	GND	-	GND
3	ROLL_CAM_SNS	IN	Roll cam sensor signal
4	ROLL_PAPER_SNS	IN	Roll media sensor signal
5	ROLL_UNIT	IN	Roll unit detection signal
6	VM	OUT	Power supply (+26V)
7	VM	OUT	Power supply (+26V)
8	/ROLL_SLEEP	OUT	Roll motor driver sleep signal
9	ROLL_STB	OUT	Roll motor driver strobe signal
10	ROLL_DAT	OUT	Roll motor driver data signal
11	ROLL_CLK	OUT	Roll motor driver clock signal
12	GND	-	GND
13	GND	-	GND

T-6-15

J2801 (Feed motor)			
Pin Number	Signal name	IN/OUT	Function
1	LF_OUTB	OUT	Feed motor drive signal B
2	LF_OUTA	OUT	Feed motor drive signal A

T-6-16

J2901 (Purge unit)			
Pin Number	Signal name	IN/OUT	Function
1	PUMP_OUTB	OUT	Pump motor drive signal B
2	PUMP_OUTA	OUT	Pump motor drive signal A
3	GND	-	GND
4	PUMP_ENCA	IN	Pump encoder output signal A
5	SNS_5V		Power supply (+5V)
6	PUMP_ENCB	IN	Pump encoder output signal B
7	PUMP_CAM_3V	OUT	Power supply (+3.3V)
8	GND	-	GND
9	PUMP_CAM_SNS_OUT	IN	Pump cam sensor output signal

T-6-17

J3001 (Lift motor/head management sensor)			
Pin Number	Signal name	IN/OUT	Function
1	LIFTOUTCOM	OUT	Lift motor Power supply
2	LIFT_OUTAP	OUT	Lift motor drive signal AP
3	LIFT_OUTAM	OUT	Lift motor drive signal AM
4	LIFT_OUTBP	OUT	Lift motor drive signal BP
5	LIFT_OUTBM	OUT	Lift motor drive signal BM
6	GND	-	GND
7	FUTO_CLMP	OUT	Head management sensor unit clamp signal
8	FUTO_XLEDON	OUT	Head management sensor unit LED ON/OFF signal
9	SNS_5V		Power supply (+5V)
10	FUTO_XCMP0	IN	Head management sensor unit skew detection signal
11	SNS_3V_1	OUT	Power supply (+3.3V)
12	GND	-	GND

J3001 (Lift motor/head management sensor)			
Pin Number	Signal name	IN/OUT	Function
13	PE_SNS	IN	Paper detection sensor output signal

T-6-18

J3101 (Carriage motor)			
Pin Number	Signal name	IN/OUT	Function
1	CR_HWP	IN	Carriage motor hole device W-phase + signal
2	CR_HWM	IN	Carriage motor hole device W-phase - signal
3	CR_W	OUT	Carriage motor W-phase drive signal
4	CR_HVM	IN	Carriage motor hole device V-phase - signal
5	CR_U	OUT	Carriage motor U-phase drive signal
6	GND	-	GND
7	CR_V	OUT	Carriage motor V-phase drive signal
8	RGV5	OUT	Power supply (+5V)
9	N.C.	-	N.C
10	CR_HVP	IN	Carriage motor hole device V-phase + signal
11	CR_HUM	IN	Carriage motor hole device U-phase - signal
12	CR_HUP	IN	Carriage motor hole device U-phase + signal

T-6-19

J3201 (Valve motor, valve open/close detection sensor, top cover sensor, ink tank cover switch)			
Pin Number	Signal name	IN/OUT	Function
1	TANK_COVER_SW	IN	Ink tank cover fswitch output signal
2	GND	-	GND
3	TOP_COVER_3V	OUT	Power supply (+3.3V)
4	GND	-	GND
5	TOP_COVER_SNS	IN	Top cover sensor output signal
6	VALVE_DETECT_3V	OUT	Power supply (+3.3V)
7	GND	-	GND
8	VALVE_DETECT_SNS	IN	Valve open/close sensor output signal
9	VALVE_MOTOR_AM	OUT	Valve motor drive signal AM
10	VALVE_MOTOR_AP	OUT	Valve motor drive signal AP

T-6-20

J3202 (Ink tank ROM PCB)			
Pin Number	Signal name	IN/OUT	Function
1	TANK_DAT0	IN/OUT	Ink tank data signal 0
2	TANK_DAT1	IN/OUT	Ink tank data signal 1
3	TANK_3V	OUT	Power supply (+3.3V)
4	TANK_DAT2	IN/OUT	Ink tank data signal 2
5	GND	-	GND
6	TANK_CLK	OUT	Ink tank clock signal
7	TANK_DAT3	IN/OUT	Ink tank data signal 3
8	TANK_DAT4	IN/OUT	Ink tank data signal 4
9	TANK_3V	OUT	Power supply (+3.3V)
10	TANK_DAT5	IN/OUT	Ink tank data signal 5
11	GND	-	GND
12	TANK_CLK	OUT	Ink tank clock signal
13	GND	-	GND
14	INK_SNS0	IN	Ink detection sensor output signal 0
15	INK_SNS1	IN	Ink detection sensor output signal 1
16	INK_SNS2	IN	Ink detection sensor output signal 2
17	GND	-	GND
18	INK_SNS3	IN	Ink detection sensor output signal 3
19	INK_SNS4	IN	Ink detection sensor output signal 4
20	INK_SNS5	IN	Ink detection sensor output signal 5

T-6-21

J3301 (Ink tank ROM PCB)			
Pin Number	Signal name	IN/OUT	Function
1	TANK_DAT6	IN/OUT	Ink tank data signal 6
2	TANK_DAT7	IN/OUT	Ink tank data signal 7
3	TANK_3V	OUT	Power supply (+3.3V)
4	TANK_DAT8	IN/OUT	Ink tank data signal 8
5	GND	-	GND
6	TANK_CLK	OUT	Ink tank clock signal

J3301 (Ink tank ROM PCB)			
Pin Number	Signal name	IN/OUT	Function
7	TANK_DAT9	IN/OUT	Ink tank data signal 9
8	TANK_DAT10	IN/OUT	Ink tank data signal 10
9	TANK_3V	OUT	Power supply (+3.3V)
10	TANK_DAT11	IN/OUT	Ink tank data signal 11
11	GND	-	GND
12	TANK_CLK	OUT	Ink tank clock signal
13	GND	-	GND
14	INK_SNS6	IN	Ink detection sensor output signal 6
15	INK_SNS7	IN	Ink detection sensor output signal 7
16	INK_SNS8	IN	Ink detection sensor output signal 8
17	GND	-	GND
18	INK_SNS9	IN	Ink detection sensor output signal 9
19	INK_SNS10	IN	Ink detection sensor output signal 10
20	INK_SNS11	IN	Ink detection sensor output signal 11

T-6-22

J3401 (Carriage PCB J11)			
Pin Number	Signal name	IN/OUT	Function
1	GND	-	GND
2	GND	-	GND
3	GND	-	GND
4	GND	-	GND
5	GND	-	GND
6	GND	-	GND
7	GND	-	GND
8	VH	OUT	Power supply (+21.5V)
9	VH	OUT	Power supply (+21.5V)
10	VH	OUT	Power supply (+21.5V)
11	VH	OUT	Power supply (+21.5V)
12	VH	OUT	Power supply (+21.5V)
13	VH	OUT	Power supply (+21.5V)
14	VH	OUT	Power supply (+21.5V)
15	VH	OUT	Power supply (+21.5V)
16	VH	OUT	Power supply (+21.5V)
17	VH	OUT	Power supply (+21.5V)
18	VH	OUT	Power supply (+21.5V)
19	VH	OUT	Power supply (+21.5V)
20	VH	OUT	Power supply (+21.5V)
21	VH	OUT	Power supply (+21.5V)
22	VH	OUT	Power supply (+21.5V)
23	VH	OUT	Power supply (+21.5V)
24	GND	-	GND
25	GND	-	GND
26	GND	-	GND
27	GND	-	GND
28	GND	-	GND
29	GND	-	GND
30	GND	-	GND

T-6-23

J3402 (Carriage PCB J21)			
Pin Number	Signal name	IN/OUT	Function
1	GND	-	GND
2	GND	-	GND
3	GND	-	GND
4	GND	-	GND
5	GND	-	GND
6	GND	-	GND
7	VH	OUT	Power supply (+21.5V)
8	VH	OUT	Power supply (+21.5V)
9	VH	OUT	Power supply (+21.5V)
10	VH	OUT	Power supply (+21.5V)
11	VH	OUT	Power supply (+21.5V)

J3402 (Carriage PCB J21)			
Pin Number	Signal name	IN/OUT	Function
12	VH	OUT	Power supply (+21.5V)
13	VH	OUT	Power supply (+21.5V)
14	VH	OUT	Power supply (+21.5V)
15	VH	OUT	Power supply (+21.5V)
16	VH	OUT	Power supply (+21.5V)
17	HD1_VHFBH	IN	VH feed back voltage +
18	VH	OUT	Power supply (+21.5V)
19	VH	OUT	Power supply (+21.5V)
20	VH	OUT	Power supply (+21.5V)
21	VH	OUT	Power supply (+21.5V)
22	VH	OUT	Power supply (+21.5V)
23	GND	-	GND
24	GND	-	GND
25	GND	-	GND
26	GND	-	GND
27	HD1_VHFBG	IN	VH feed back voltage -
28	GND	-	GND
29	GND	-	GND
30	GND	-	GND

T-6-24

J3411 (Temperture/humidity sensor)			
Pin Number	Signal name	IN/OUT	Function
1	TH2_OUT	IN	Temperature/humidity sensor output signal 2
2	GND	-	GND
3	RHV_OUT	IN	Temperature/humidity sensor output signal
4	RGV5	OUT	Power supply (+5V)

T-6-25

J3501 (Carriage PCB J12)			
Pin Number	Signal name	IN/OUT	Function
1	GND	-	GND
2	GND	-	GND
3	H-DASH LICC2 B	OUT	Analogue switch A/D trigger signal
4	GND	-	GND
5	H0-D-DATA-7-OD	OUT	Odd head R data signal 7(D)
6	GND	-	GND
7	H0-E-HE-8	OUT	Head R heat enable signal 8(E)
8	GND	-	GND
9	H0-E-DATA-8-OD	OUT	Odd head R data signal 8(E)
10	GND	-	GND
11	H0-F-DATA-10-OD	OUT	Odd head R data signal 10(F)
12	GND	-	GND
13	H0-E-DATA-9-OD	OUT	Odd head R data signal 9(E)
14	GND	-	GND
15	H0-F-HE-10	OUT	Head R heat enable signal 10(F)
16	GND	-	GND
17	H0-F-DATA-11-OD	OUT	Odd head R data signal 11(F)
18	GND	-	GND
19	H0-F-HE-11	OUT	Head R heat enable signal 11(F)
20	GND	-	GND
21	H0-F-DATA-11-EV	OUT	Even head R data signal 11(F)
22	GND	-	GND
23	H0-F-DATA-10-EV	OUT	Even head R data signal 10(F)
24	GND	-	GND
25	H0-E-HE-9	OUT	Head R heat enable signal 9(E)
26	GND	-	GND
27	H0-E-DATA-9-EV	OUT	Even head R data signal 9(E)
28	GND	-	GND
29	GND	-	GND
30	GND	-	GND
31	GND	-	GND
32	GND	-	GND

J3501 (Carriage PCB J12)			
Pin Number	Signal name	IN/OUT	Function
33	GND	-	GND
34	GND	-	GND
35	H0-A-DATA-0-OD	OUT	Odd head R data signal 0(A)
36	GND	-	GND
37	H0-A-DATA-1-OD	OUT	Odd head R data signal 1(A)
38	GND	-	GND
39	H0-B-HE-2	OUT	Head R heat enable signal 2(B)
40	GND	-	GND
41	H0-B-DATA-2-OD	OUT	Odd head R data signal 2(B)
42	GND	-	GND
43	H0-B-DATA-3-OD	OUT	Odd head R data signal 3(B)
44	GND	-	GND
45	H0-C-HE-4	OUT	Head R heat enable signal 4(C)
46	GND	-	GND
47	H0-C-DATA-4-OD	OUT	Odd head R data signal 4(C)
48	SNS_5V	OUT	Power supply (+5V)
49	GND	-	GND
50	GND	-	GND

T-6-26

J3601 (Carriage PCB J13)			
Pin Number	Signal name	IN/OUT	Function
1	H0-E-DATA-8	OUT	Even head R data signal 8(E)
2	GND	-	GND
3	H0-D-HE-7	OUT	Head R heat enable signal 7(D)
4	GND	-	GND
5	H0-D-DATA-7-EV	OUT	Even head R data signal 7(D)
6	GND	-	GND
7	H0-D-DATA-6-EB	OUT	Even head R data signal 6(D)
8	GND	-	GND
9	H0-D-DATA-6-OD	OUT	Odd head R data signal 6(D)
10	GND	-	GND
11	H0-D-HE-6	OUT	Head R heat enable signal 6(D)
12	GND	-	GND
13	H0-C-HE-5	OUT	Head R heat enable signal 5(C)
14	GND	-	GND
15	H0-C-DATA-5-OD	OUT	Odd head R data signal 5(C)
16	GND	-	GND
17	H0-DSOUT2	IN	Head R temperature output 2
18	GND	-	GND
19	H0-DSOUT1	IN	Head R temperature output 1
20	GND	-	GND
21	GND	-	GND
22	LICSEL1	OUT	Head R analogue switch data signal
23	LICSEL2	OUT	Head R analogue switch latch signal
24	LICSEL0	OUT	Head R analogue switch clock signal
25	GND	-	GND
26	GND	-	GND
27	H0_CLK	OUT	Head R data clock signal
28	GND	-	GND
29	H0-LT	OUT	Head R data latch signal
30	GND	-	GND
31	HEAD_3V	OUT	Power supply (+3V)
32	GND	-	GND
33	H0-C-DATA-5-EV	OUT	Even head R data signal 5(C)
34	GND	-	GND
35	H0-B-HE-3	OUT	Head R heat enable signal 8(E)
36	GND	-	GND
37	H0-C-DATA-4-EV	OUT	Even head R data signal 4(C)
38	GND	-	GND
39	H0-B-DATA-3-EV	OUT	Even head R data signal 3(B)
40	GND	-	GND
41	H0-B-DATA-2-EV	OUT	Even head R data signal 2(B)


J3601 (Carriage PCB J13)			
Pin Number	Signal name	IN/OUT	Function
42	GND	-	GND
43	H0-A-DATA-1-EV	OUT	Even head R data signal 1(A)
44	GND	-	GND
45	H0-A-HE-1	OUT	Head R heat enable signal 8(E)
46	GND	-	GND
47	H0-A-DATA-0-EV	OUT	Even head R data signal 0(A)
48	GND	-	GND
49	H0-A-HE-0	OUT	Head R heat enable signal 8(E)
50	GND	-	GND

T-6-27

J3701 (Carriage PCB J22)			
Pin Number	Signal name	IN/OUT	Function
1	H1-D-DATA-7-OD	OUT	Odd head L data signal 7(D)
2	GND	-	GND
3	H1-E-HE-8	OUT	Head L heat enable signal8(E)
4	GND	-	GND
5	H1-E-DATA-8-OD	OUT	Odd head L data signal 8(E)
6	GND	-	GND
7	H1-F-DATA-10-OD	OUT	Odd head L data signal 10(F)
8	GND	-	GND
9	H1-E-DATA-9-OD	OUT	Odd head L data signal 9(E)
10	GND	-	GND
11	H1-F-HE-10	OUT	Head L heat enable signal10(F)
12	GND	-	GND
13	H1-F-DATA-11-OD	OUT	Odd head L data signal 11(F)
14	GND	-	GND
15	H1-F-HE-11	OUT	Head L heat enable signal11(F)
16	GND	-	GND
17	H1-F-DATA-11-EV	OUT	Even head L data signal11(F)
18	GND	-	GND
19	H1-F-DATA-10-EV	OUT	Even head L data signal10(F)
20	GND	-	GND
21	H1-E-HE-9	OUT	Head L heat enable signal9(E)
22	GND	-	GND
23	H1-E-DATA-9-EV	OUT	Even head L data signal9(E)
24	H1-DLD LICC2	OUT	Head L analogue switch latch signal
25	H1-DATA LICC2	OUT	Head L analogue switch data signal
26	H1-DASLK LICC2	OUT	Head L analogue switch clock signal
27	GND	-	GND
28	H1-DSOUT2	IN	Head L temperature output 2
29	H1-DSOUT1	IN	Head L temperature output 1
30	GND	-	GND
31	PWLED1_ON	OUT	Multi sensor LED 1 drive signal
32	PWLED2_ON	OUT	Multi sensor LED 2 drive signal
33	PWLED3_ON	OUT	Multi sensor LED 3 drive signal
34	PWLED4_ON	OUT	Multi sensor LED 4 drive signal
35	GND	-	GND
36	MLT_SNS_2IN	IN	Multi sensor signal2
37	MLT_SNS_1IN	IN	Multi sensor signal1
38	GND	-	GND
39	H1-B-DATA-2-OD	OUT	Odd head L data signal 2(B)
40	GND	-	GND
41	H1-B-DATA-3-OD	OUT	Odd head L data signal 3(B)
42	GND	-	GND
43	H1-C-HE-4	OUT	Head L heat enable signal8(E)
44	GND	-	GND
45	H1-C-DATA-4-OD	OUT	Odd head L data signal 4(C)
46	SNS_5V	OUT	Power supply (+5V)
47	ENCODER_B	IN	Carriage encoder output signalB
48	SNS_5V	OUT	Power supply (+5V)
49	ENCODER_A	IN	Carriage encoder output signalA
50	GND	-	GND

J3801 (Carriage PCB J23)			
Pin Number	Signal name	IN/OUT	Function
1	H1-E-DATA-8-EV	OUT	Even head L data signal 8(E)
2	GND	-	GND
3	H1-D-HE-7	OUT	Head L heat enable signal 7(D)
4	GND	-	GND
5	IO-ASIC_SDA	IN/OUT	Head ROM control signal (data)
6	GND	-	GND
7	H1-D-DATA-7-EV	OUT	Even head L data signal 7(D)
8	GND	-	GND
9	H1-D-DATA-6-EV	OUT	Even head L data signal 6(D)
10	GND	-	GND
11	H1-D-DATA-6-OD	OUT	Odd head L data signal6(D)
12	GND	-	GND
13	IO-ASIC_SCL	IN/OUT	Head ROM control signal (clock)
14	GND	-	GND
15	H1-D-HE-6	OUT	Head L heat enable signal 6(D)
16	GND	-	GND
17	H1-C-HE-5	OUT	Head L heat enable signal 5(C)
18	GND	-	GND
19	H1-C-DATA-5-OD	OUT	Odd head L data signal5(C)
20	GND	-	GND
21	H1_CLK	OUT	Head L clock signal
22	GND	-	GND
23	HEAD_3V	OUT	Power supply (+3V)
24	GND	-	GND
25	H1_LT	OUT	Head L latch signal
26	H-DASH_LICC2_B	OUT	Analogue switch/AD trigger
27	H1-C-DATA-5-EV	OUT	Even head L data signal 5(C)
28	GND	-	GND
29	H1-B-HE-3	OUT	Head L heat enable signal 3(B)
30	GND	-	GND
31	H1-C-DATA-4-EV	OUT	Even head L data signal 4(C)
32	GND	-	GND
33	H1-B-DATA-3-EV	OUT	Even head L data signal 3(B)
34	GND	-	GND
35	H1-B-DATA-2-EV	OUT	Even head L data signal 2(B)
36	GND	-	GND
37	H1-A-DATA-1-EV	OUT	Even head L data signal 1(A)
38	GND	-	GND
39	H1-A-HE-1	OUT	Head L heat enable signal 1(A)
40	GND	-	GND
41	H1-A-DATA-0-EV	OUT	Even head L data signal 0(A)
42	GND	-	GND
43	H1-A-HE-0	OUT	Head L heat enable signal 0(A)
44	GND	-	GND
45	H1-A-DATA-0-OD	OUT	Odd head L data signal0(A)
46	GND	-	GND
47	H1-A-DATA-1-OD	OUT	Odd head L data signal1(A)
48	GND	-	GND
49	H1-B-HE-2	OUT	Head L heat enable signal 2(B)
50	GND	-	GND

6.2.2 Carriage relay PCB



J3			
Pin Number	Signal name	IN/OUT	Function
1	ENCODER_B	IN	Linear encoder detection signal B
2	GND	-	GND
3	ENCODER_A	IN	Linear encoder detection signal A
4	H1_5V	OUT	Power supply (+5V)

T-6-30

J5			
Pin Number	Signal name	IN/OUT	Function
1	PWLED1	OUT	Multi sensor LED1 drive signal
2	PWLED2	OUT	Multi sensor LED2 drive signal
3	PWLED3	OUT	Multi sensor LED3 drive signal
4	PWLED4	OUT	Multi sensor LED4 drive signal
5	GND	-	GND
6	OUT1	IN	Multi sensor input signal 1
7	OUT2	IN	Multi sensor input signal 2
8	VH	OUT	Power supply (+21.5V)

T-6-31

J21 (Main controller PCB J3402)			
Pin Number	Signal name	IN/OUT	Function
1	GND	-	GND
2	GND	-	GND
3	GND	-	GND
4	HD1_VHFBG	OUT	VH feed back voltage -
5	GND	-	GND
6	GND	-	GND
7	GND	-	GND
8	GND	-	GND
9	VH	IN	Power supply (+21.5V)
10	VH	IN	Power supply (+21.5V)
11	VH	IN	Power supply (+21.5V)
12	VH	IN	Power supply (+21.5V)
13	VH	IN	Power supply (+21.5V)
14	HD1_VHFBH	OUT	VH feed back voltage +
15	VH	IN	Power supply (+21.5V)
16	VH	IN	Power supply (+21.5V)
17	VH	IN	Power supply (+21.5V)
18	VH	IN	Power supply (+21.5V)
19	VH	IN	Power supply (+21.5V)
20	VH	IN	Power supply (+21.5V)
21	VH	IN	Power supply (+21.5V)
22	VH	IN	Power supply (+21.5V)
23	VH	IN	Power supply (+21.5V)
24	VH	IN	Power supply (+21.5V)
25	GND	-	GND
26	GND	-	GND
27	GND	-	GND
28	GND	-	GND
29	GND	-	GND

J21 (Main controller PCB J3402)			
Pin Number	Signal name	IN/OUT	Function
30	GND	-	GND

T-6-32

J22 (Main controller PCB J3701)			
Pin Number	Signal name	IN/OUT	Function
1	GND	-	GND
2	ENCODER_A	OUT	Carriage encoder output signalA
3	SNS_5V	IN	Power supply (+5V)
4	ENCODER_B	OUT	Carriage encoder output signalB
5	SNS_5V	IN	Power supply (+5V)
6	H1-C-DATA-4-OD	IN	Odd head L data signal 4(C)
7	GND	-	GND
8	H1-C-HE-4	IN	Head L heat enable signal8(E)
9	GND	-	GND
10	H1-B-DATA-3-OD	IN	Odd head L data signal 3(B)
11	GND	-	GND
12	H1-B-DATA-2-OD	IN	Odd head L data signal 2(B)
13	GND	-	GND
14	MLT_SNS_1IN	OUT	Multi sensor signal1
15	MLT_SNS_2IN	OUT	Multi sensor signal2
16	GND	-	GND
17	PWLED4_ON	IN	Multi sensor LED 4 drive signal
18	PWLED3_ON	IN	Multi sensor LED 3 drive signal
19	PWLED2_ON	IN	Multi sensor LED 2 drive signal
20	PWLED1_ON	IN	Multi sensor LED 1 drive signal
21	GND	-	GND
22	H1-DSOUT1	OUT	Head L temperature output 1
23	H1-DSOUT2	OUT	Head L temperature output 2
24	GND	-	GND
25	H1-DASLK LICC2	IN	Head L analogue switch clock signal
26	H1-DATA LICC2	IN	Head L analogue switch data signal
27	H1-DLD LICC2	IN	Head L analogue switch latch signal
28	H1-E-DATA-9-EV	IN	Even head L data signal9(E)
29	GND	-	GND
30	H1-E-HE-9	IN	Head L heat enable signal9(E)
31	GND	-	GND
32	H1-F-DATA-10-EV	IN	Even head L data signal10(F)
33	GND	-	GND
34	H1-F-DATA-11-EV	IN	Even head L data signal11(F)
35	GND	-	GND
36	H1-F-HE-11	IN	Head L heat enable signal11(F)
37	GND	-	GND
38	H1-F-DATA-11-OD	IN	Odd head L data signal 11(F)
39	GND	-	GND
40	H1-F-HE-10	IN	Head L heat enable signal10(F)
41	GND	-	GND
42	H1-E-DATA-9-OD	IN	Odd head L data signal 9(E)
43	GND	-	GND
44	H1-F-DATA-10-OD	IN	Odd head L data signal 10(F)
45	GND	-	GND
46	H1-E-DATA-8-OD	IN	Odd head L data signal 8(E)
47	GND	-	GND
48	H1-E-HE-8	IN	Head L heat enable signal8(E)
49	GND	-	GND
50	H1-D-DATA-7-OD	IN	Odd head L data signal 7(D)

T-6-33

J23 (Main controller PCB J3801)			
Pin Number	Signal name	IN/OUT	Function
1	GND	-	GND
2	H1-B-HE-2	IN	Head L heat enable signal 2(B)
3	GND	-	GND
4	H1-A-DATA-1-OD	IN	Odd head L data signal 1(A)

J23 (Main controller PCB J3801)			
Pin Number	Signal name	IN/OUT	Function
5	GND	-	GND
6	H1-A-DATA-0-OD	IN	Odd head L data signal 0(A)
7	GND	-	GND
8	H1-A-HE-0	IN	Head L heat enable signal 0(A)
9	GND	-	GND
10	H1-A-DATA-0-EV	IN	Even head L data signal 0(A)
11	GND	-	GND
12	H1-A-HE-1	IN	Head L heat enable signal 1(A)
13	GND	-	GND
14	H1-A-DATA-1-EV	IN	Even head L data signal 1(A)
15	GND	-	GND
16	H1-B-DATA-2-EV	IN	Even head L data signal 2(B)
17	GND	-	GND
18	H1-B-DATA-3-EV	IN	Even head L data signal 3(B)
19	GND	-	GND
20	H1-C-DATA-4-EV	IN	Even head L data signal 4(C)
21	GND	-	GND
22	H1-B-HE-3	IN	Head L heat enable signal 3(B)
23	GND	-	GND
24	H1-C-DATA-5-EV	IN	Even head L data signal 5(C)
25	H-DASH_LICC2_B	IN	Analogue switch/AD trigger
26	H1_LT	IN	Head L latch signal
27	GND	-	GND
28	HEAD_3V	IN	Power supply (+3V)
29	GND	-	GND
30	H1_CLK	IN	Head L clock signal
31	GND	-	GND
32	H1-C-DATA-5-OD	IN	Odd head L data signal 5(C)
33	GND	-	GND
34	H1-C-HE-5	IN	Head L heat enable signal 5(C)
35	GND	-	GND
36	H1-D-HE-6	IN	Head L heat enable signal 6(D)
37	GND	-	GND
38	IO-ASIC_SCL	IN/OUT	Head ROM control signal (clock)
39	GND	-	GND
40	H1-D-DATA-6-OD	IN	Odd head L data signal 6(D)
41	GND	-	GND
42	H1-D-DATA-6-EV	IN	Even head L data signal 6(D)
43	GND	-	GND
44	H1-D-DATA-7-EV	IN	Even head L data signal 7(D)
45	GND	-	GND
46	IO-ASIC_SDA	IN/OUT	Head ROM control signal (data)
47	GND	-	GND
48	H1-D-HE-7	IN	Head L heat enable signal 7(D)
49	GND	-	GND
50	H1-E-DATA-8-EV	IN	Even head L data signal 8(E)

T-6-34

J24 (Head L)			
Pin Number	Signal name	IN/OUT	Function
1	VH	OUT	Power supply (+21.5V)
2	VH	OUT	Power supply (+21.5V)
3	VH	OUT	Power supply (+21.5V)
4	VHT2	OUT	Head L transistor drive power supply
5	H1-F-DATA-10-EV	OUT	Even head L data signal 10(F)
6	EEPROM_SDA	IN/OUT	EEPROM control signal (data)
7	EEPROM_SCL	OUT	EEPROM control signal (clock)
8	HEAD_3V	OUT	Power supply (+3V)
9	H1-C-DIA1	IN	Head L DI sensor signal 1(C)
10	H1-A-HE-1	OUT	Head L heat enable signal 1(A)
11	VH	OUT	Power supply (+21.5V)
12	VH	OUT	Power supply (+21.5V)
13	VH	OUT	Power supply (+21.5V)

J24 (Head L)			
Pin Number	Signal name	IN/OUT	Function
14	VH	OUT	Power supply (+21.5V)
15	VH	OUT	Power supply (+21.5V)
16	H1-E-DATA-9-OD	OUT	Odd head L data signal 9(E)
17	H1-F-HE-11	OUT	Head L heat enable signal11(F)
18	H1-E-DIA1	IN	Head L DI sensor signal 1(E)
19	H1-D-DIA1	IN	Head L DI sensor signal 1(D)
20	HEAD_3V	OUT	Power supply (+3V)
21	HEAD_3V	OUT	Power supply (+3V)
22	H1-B-DATA-3-EV	OUT	Even head L data signal 3(B)
23	H1-A-DATA-0-EV	OUT	Even head L data signal 0(A)
24	H1-B-HE-2	OUT	Head L heat enable signal 2(B)
25	VH	OUT	Power supply (+21.5V)
26	VH	OUT	Power supply (+21.5V)
27	H1-D-DIA2	IN	Head L DI sensor signal 2(D)
28	H1-E-HE-8	OUT	Head L heat enable signal8(E)
29	H1-E-DIA2	IN	Head L DI sensor signal 2(E)
30	H1-F-DIA2	IN	Head L DI sensor signal 2(F)
31	H1-E-HE-9	OUT	Head L heat enable signal9(E)
32	H1-D-DATA-7-EV	OUT	Even head L data signal 7(D)
33	H1-D-HE-6	OUT	Head L heat enable signal 6(D)
34	H1-C-DATA-5-OD	OUT	Odd head L data signal 5(C)
35	H1-C-DATA-4-EV	OUT	Even head L data signal 4(C)
36	H1-A-DATA-1-EV	OUT	Even head L data signal 1(A)
37	H1-A-DIA2	IN	Head L DI sensor signal 2(A)
38	H1-B-DIA2	IN	Head L DI sensor signal 2(B)
39	H1-C-HE-4	OUT	Head L heat enable signal8(E)
40	H1-D-DATA-7-OD	OUT	Odd head L data signal 7(D)
41	H1-E-DATA-8-OD	OUT	Odd head L data signal 8(E)
42	H1-F-HE-10	OUT	Head L heat enable signal10(F)
43	H1-F-DATA-11-EV	OUT	Even head L data signal11(F)
44	H1-F-DATA-8-EV	OUT	Even head L data signal 8(F)
45	H1-D-DATA-6-EV	OUT	Even head L data signal 6(D)
46	H1-C-DIA2	IN	Head L DI sensor signal 2(C)
47	H1-C-DATA-5-EV	OUT	Even head L data signal 5(C)
48	H1-B-DIA1	IN	Head L DI sensor signal 1(B)
49	H1-A-HE-0	OUT	Head L heat enable signal 0(A)
50	H1-B-DATA-2-OD	OUT	Odd head L data signal 2(B)
51	H1-B-DATA-3-OD	OUT	Odd head L data signal 3(B)
52	H1-C-DATA-4-OD	OUT	Odd head L data signal 4(C)
53	GND	-	GND
54	GND	-	GND
55	GND	-	GND
56	H1-F-DATA-11-OD	OUT	Odd head L data signal 11(F)
57	H1-E-DATA-9-EV	OUT	Even head L data signal9(E)
58	GND	-	GND
59	H1-D-DATA-6-OD	OUT	Odd head L data signal6(D)
60	H1-C-HE-5	OUT	Head L heat enable signal 5(C)
61	H1-B-HE-3	OUT	Head L heat enable signal 3(B)
62	H1-A-DIA1	IN	Head L DI sensor signal 1(A)
63	H1-A-DATA-1-OD	OUT	Odd head L data signal1(A)
64	GND	-	GND
65	GND	-	GND
66	GND	-	GND
67	GND	-	GND
68	H1-F-DATA-10-OD	OUT	Odd head L data signal 10(F)
69	H1-F-DIA1	IN	Head L DI sensor signal 1(F)
70	H1-D-HE-7	OUT	Head L heat enable signal 7(D)
71	GND	-	GND
72	H1-CLK	OUT	Head L clock signal
73	H1-LT	OUT	Head L latch signal
74	H1-B-DATA-2-EV	OUT	Even head L data signal 2(B)
75	H1-A-DATA-0-OD	OUT	Odd head L data signal0(A)

J24 (Head L)			
Pin Number	Signal name	IN/OUT	Function
76	GND	-	GND
77	GND	-	GND
78	GND	-	GND

T-6-35

J11 (Main controller PCB J3401)			
Pin Number	Signal name	IN/OUT	Function
1	GND	-	GND
2	GND	-	GND
3	GND	-	GND
4	GND	-	GND
5	GND	-	GND
6	GND	-	GND
7	GND	-	GND
8	VH	IN	Power supply (+21.5V)
9	VH	IN	Power supply (+21.5V)
10	VH	IN	Power supply (+21.5V)
11	VH	IN	Power supply (+21.5V)
12	VH	IN	Power supply (+21.5V)
13	VH	IN	Power supply (+21.5V)
14	VH	IN	Power supply (+21.5V)
15	VH	IN	Power supply (+21.5V)
16	VH	IN	Power supply (+21.5V)
17	VH	IN	Power supply (+21.5V)
18	VH	IN	Power supply (+21.5V)
19	VH	IN	Power supply (+21.5V)
20	VH	IN	Power supply (+21.5V)
21	VH	IN	Power supply (+21.5V)
22	VH	IN	Power supply (+21.5V)
23	VH	IN	Power supply (+21.5V)
24	GND	-	GND
25	GND	-	GND
26	GND	-	GND
27	GND	-	GND
28	GND	-	GND
29	GND	-	GND
30	GND	-	GND

T-6-36

J12 (Main controller PCB J3501)			
Pin Number	Signal name	IN/OUT	Function
1	GND	-	GND
2	GND	-	GND
3	SNS_5V	IN	Power supply (+5V)
4	H0-C-DATA-4-OD	IN	Odd head R data signal 4(C)
5	GND	-	GND
6	H0-C-HE-4	IN	Head R heat enable signal 4(C)
7	GND	-	GND
8	H0-B-DATA-3-OD	IN	Odd head R data signal 3(B)
9	GND	-	GND
10	H0-B-DATA-2-OD	IN	Odd head R data signal 2(B)
11	GND	-	GND
12	H0-B-HE-2	IN	Head R heat enable signal 2(B)
13	GND	-	GND
14	H0-A-DATA-1-OD	IN	Odd head R data signal 1(A)
15	GND	-	GND
16	H0-A-DATA-0-OD	IN	Odd head R data signal 0(A)
17	GND	-	GND
18	GND	-	GND
19	GND	-	GND
20	GND	-	GND
21	GND	-	GND
22	GND	-	GND

J12 (Main controller PCB J3501)			
Pin Number	Signal name	IN/OUT	Function
23	GND	-	GND
24	H0-E-DATA-9-EV	IN	Even head R data signal 9(E)
25	GND	-	GND
26	H0-E-HE-9	IN	Head R heat enable signal 9(E)
27	GND	-	GND
28	H0-F-DATA-10-EV	IN	Even head R data signal 10(F)
29	GND	-	GND
30	H0-F-DATA-11-EV	IN	Even head R data signal 11(F)
31	GND	-	GND
32	H0-F-HE-11	IN	Head R heat enable signal 11(F)
33	GND	-	GND
34	H0-F-DATA-11-OD	IN	Odd head R data signal 11(F)
35	GND	-	GND
36	H0-F-HE-10	IN	Head R heat enable signal 10(F)
37	GND	-	GND
38	H0-E-DATA-9-OD	IN	Odd head R data signal 9(E)
39	GND	-	GND
40	H0-F-DATA-10-OD	IN	Odd head R data signal 10(F)
41	GND	-	GND
42	H0-E-DATA-8-OD	IN	Odd head R data signal 8(E)
43	GND	-	GND
44	H0-E-HE-8	IN	Head R heat enable signal 8(E)
45	GND	-	GND
46	H0-D-DATA-7-OD	IN	Odd head R data signal 7(D)
47	GND	-	GND
48	H-DASH LICC2 B	IN	Analogue switch A/D trigger signal
49	GND	-	GND
50	GND	-	GND

T-6-37

J13 (Main controller PCB J3601)			
Pin Number	Signal name	IN/OUT	Function
1	GND	-	GND
2	H0-A-HE-0	IN	Head R heat enable signal 8(E)
3	GND	-	GND
4	H0-A-DATA-0-EV	IN	Even head R data signal 0(A)
5	GND	-	GND
6	H0-A-HE-1	IN	Head R heat enable signal 8(E)
7	GND	-	GND
8	H0-A-DATA-1-EV	IN	Even head R data signal 1(A)
9	GND	-	GND
10	H0-B-DATA-2-EV	IN	Even head R data signal 2(B)
11	GND	-	GND
12	H0-B-DATA-3-EV	IN	Even head R data signal 3(B)
13	GND	-	GND
14	H0-C-DATA-4-EV	IN	Even head R data signal 4(C)
15	GND	-	GND
16	H0-B-HE-3	IN	Head R heat enable signal 8(E)
17	GND	-	GND
18	H0-C-DATA-5-EV	IN	Even head R data signal 5(C)
19	GND	-	GND
20	HEAD_3V	IN	Power supply (+3V)
21	GND	-	GND
22	H0-LT	IN	Head R data latch signal
23	GND	-	GND
24	H0_CLK	IN	Head R data clock signal
25	GND	-	GND
26	GND	-	GND
27	LICSEL2	IN	Head R analogue switch latch signal
28	LICSEL1	IN	Head R analogue switch data signal
29	LICSEL0	IN	Head R analogue switch clock signal
30	GND	-	GND
31	GND	-	GND


J13 (Main controller PCB J3601)			
Pin Number	Signal name	IN/OUT	Function
32	H0-DSOUT1	OUT	Head R temperature output 1
33	GND	-	GND
34	H0-DSOUT2	OUT	Head R temperature output 2
35	GND	-	GND
36	H0-C-DATA-5-OD	IN	Odd head R data signal 5(C)
37	GND	-	GND
38	H0-C-HE-5	IN	Head R heat enable signal 5(C)
39	GND	-	GND
40	H0-D-HE-6	IN	Head R heat enable signal 6(D)
41	GND	-	GND
42	H0-D-DATA-6-OD	IN	Odd head R data signal 6(D)
43	GND	-	GND
44	H0-D-DATA-6-EB	IN	Even head R data signal 6(D)
45	GND	-	GND
46	H0-D-DATA-7-EV	IN	Even head R data signal 7(D)
47	GND	-	GND
48	H0-D-HE-7	IN	Head R heat enable signal 7(D)
49	GND	-	GND
50	H0-E-DATA-8	IN	Even head R data signal 8(E)

T-6-38

J14 (Head R)			
Pin Number	Signal name	IN/OUT	Function
1	VH	OUT	Power supply (+21.5V)
2	VH	OUT	Power supply (+21.5V)
3	VH	OUT	Power supply (+21.5V)
4	VHT	OUT	Head R Transistor drive Power supply
5	H0-F-DATA-10-EV	OUT	Even head R data signal 10(F)
6	EEPROM_SDA	IN/OUT	EEPROMcontrol signal (data)
7	EEPROM_SCL	OUT	EEPROMcontrol signal (clock)
8	HEAD_3V	OUT	Power supply (+3V)
9	H0-C-DIA1	IN	Head R DI sensor signal 1(C)
10	H0-A-HE-1	OUT	Head R heat enable signal 8(E)
11	VH	OUT	Power supply (+21.5V)
12	VH	OUT	Power supply (+21.5V)
13	VH	OUT	Power supply (+21.5V)
14	VH	OUT	Power supply (+21.5V)
15	VH	OUT	Power supply (+21.5V)
16	H0-E-DATA-9-OD	OUT	Odd head R data signal 9(E)
17	H0-F-HE-11	OUT	Head R heat enable signal 11(F)
18	H0-E-DIA1	IN	Head R DI sensor signal 1(E)
19	H0-D-DIA1	IN	Head R DI sensor signal 1(D)
20	GND	-	GND
21	HEAD_3V	OUT	Power supply (+3V)
22	H0-B-DATA-3-EV	OUT	Even head R data signal 3(B)
23	H0-A-DATA-0-EV	OUT	Even head R data signal 0(A)
24	H0-B-HE-2	OUT	Head R heat enable signal 2(B)
25	VH	OUT	Power supply (+21.5V)
26	VH	OUT	Power supply (+21.5V)
27	H0-D-DIA2	IN	Head R DI sensor signal 2(D)
28	H0-E-HE-8	OUT	Head R heat enable signal 8(E)
29	H0-E-DIA2	IN	Head R DI sensor signal 2(E)
30	H0-F-DIA2	IN	Head R DI sensor signal 2(F)
31	H0-E-HE-9	OUT	Head R heat enable signal 9(E)
32	H0-D-DATA-7-EV	OUT	Even head R data signal 7(D)
33	H0-D-HE-6	OUT	Head R heat enable signal 6(D)
34	H0-C-DATA-5-OD	OUT	Odd head R data signal 5(C)
35	H0-C-DATA-4-EV	OUT	Even head R data signal 4(C)
36	H0-A-DATA-1-EV	OUT	Even head R data signal 1(A)
37	H0-A-DIA2	IN	Head R DI sensor signal 2(A)
38	H0-B-DIA2	IN	Head R DI sensor signal 2(B)
39	H0-C-HE-4	OUT	Head R heat enable signal 4(C)
40	H0-D-DATA-7-OD	OUT	Odd head R data signal 7(D)

J14 (Head R)			
Pin Number	Signal name	IN/OUT	Function
41	H0-E-DATA-8-OD	OUT	Odd head R data signal 8(E)
42	H0-F-HE-10	OUT	Head R heat enable signal 10(F)
43	H0-F-DATA-11-EV	OUT	Even head R data signal 11(F)
44	H0-F-DATA-8-EV	OUT	Even head R data signal 8(F)
45	H0-D-DATA-6-EV	OUT	Even head R data signal 6(D)
46	H0-C-DIA2	IN	Head R DI sensor signal 2(C)
47	H0-C-DATA-5-EV	OUT	Even head R data signal 5(C)
48	H0-B-DIA1	IN	Head R DI sensor signal 1(B)
49	H0-A-HE-0	OUT	Head R heat enable signal 8(E)
50	H0-B-DATA-2-OD	OUT	Odd head R data signal 2(B)
51	H0-B-DATA-3-OD	OUT	Odd head R data signal 3(B)
52	H0-C-DATA-4-OD	OUT	Odd head R data signal 4(C)
53	GND	-	GND
54	GND	-	GND
55	GND	-	GND
56	H0-F-DATA-11-OD	OUT	Odd head R data signal 11(F)
57	H0-E-DATA-9-EV	OUT	Even head R data signal 9(E)
58	GND	-	GND
59	H0-D-DATA-6-OD	OUT	Odd head R data signal 6(D)
60	H0-C-HE-5	OUT	Head R heat enable signal 5(C)
61	H0-B-HE-3	OUT	Head R heat enable signal 8(E)
62	H0-A-DIA1	IN	Head R DI sensor signal 1(A)
63	H0-A-DATA-1-OD	OUT	Odd head R data signal 1(A)
64	GND	-	GND
65	GND	-	GND
66	GND	-	GND
67	GND	-	GND
68	H0-F-DATA-10-OD	OUT	Odd head R data signal 10(F)
69	H0-F-DIA1	IN	Head R DI sensor signal 1(F)
70	H0-D-HE-7	OUT	Head R heat enable signal 7(D)
71	GND	-	GND
72	H0-CLK	OUT	Head R data clock signal
73	H0-LT	OUT	Head R data latch signal
74	H0-B-DATA-2-EV	OUT	Even head R data signal 2(B)
75	H0-A-DATA-0-OD	OUT	Odd head R data signal 0(A)
76	GND	-	GND
77	GND	-	GND
78	GND	-	GND

6.2.3 Cutter driver PCB



F-6-3
T-6-39


J1 (Connect to main board)			
Pin Number	Signal name	IN/OUT	Function
1	GND	-	GND
2	CUTTER_PHS	IN	Cutter motor driver phase signal
3	CUTTER_ENB	IN	Cutter motor driver enable signal
4	CUTTER_CLK	IN	Cutter motor driver clock signal
5	CUTTER_DAT	IN	Cutter motor driver data signal
6	CUTTER_STB	IN	Cutter motor driver strobe signal
7	/CUTTER_SLEEP	IN	Cutter motor driver sleep signal

J1 (Connect to main board)			
Pin Number	Signal name	IN/OUT	Function
8	CUTTER_VM_ON	IN	Power supply (+26V)
9	CUTTER_UNIT	OUT	Cutter unit detection signal
10	CUTTER_POS1_SNS	OUT	Cutter lift sensor signal
11	CUTTER_R_SNS	OUT	Cutter right detection sensor signal
12	CUTTER_L_SNS	OUT	Cutter HP sensor signal
13	GND	-	GND
14	OPT_5V	IN	Power supply (+5V)

T-6-40

J2 (Cutter lift sensor/HP sensor/right detection sensor, Cutter motor/lift motor)			
Pin Number	Signal name	IN/OUT	Function
1	+5V	OUT	Power supply (+5V)
2	GND	-	GND
3	CUTTER POS1 SNS	IN	Cutter lift sensor signal
4	+5V	OUT	Power supply (+5V)
5	GND	-	GND
6	CUTTER L SNS	IN	Cutter HP sensor signal
7	CUTTER LIFT OUTB	OUT	Cutter lift motor drive signal B
8	CUTTER LIFT OUTA	OUT	Cutter lift motor drive signal A
9	+5V	OUT	Power supply (+5V)
10	GND	-	GND
11	CUTTER R SNS	IN	Cutter right detection sensor signal
12	CUTTER OUTB	OUT	Cutter motor drive signal B
13	CUTTER OUTA	OUT	Cutter motor drive signal A

6.2.4 Power supply




CN1			
Pin Number	Signal name	IN/OUT	Function
1	AC(H)	-	Power supply (AC 120V or AC 230V)
2	AC(H)	-	Power supply (AC 120V or AC 230V)

T-6-42

CN2 (Connect to main board)			
Pin Number	Signal name	IN/OUT	Function
1	HD1_VHFBH	IN	VH feedback voltage +
2	HD1_VHFBG	IN	VH feedback voltage -
3	VH	OUT	Power supply (+21.5V)
4	GND	-	GND
5	VH	OUT	Power supply (+21.5V)
6	GND	-	GND
7	RGV20(VCC)	OUT	Power supply (+21.5V)
8	GND	-	GND
9	VM	OUT	Power supply (+26V)
10	GND	-	GND
11	VM2	OUT	Power supply (+26V)
12	GND	-	GND
13	VH_ENB	IN	VH power supply ON/OFF signal
14	PW_CONT	IN	Normal/power saving switch signal

6.2.5 Roll feed unit PCB



F-6-5
T-6-43

J1 (Connect to main board)			
Pin Number	Signal name	IN/OUT	Function
1	GND	-	GND
2	GND	-	GND
3	ROLL_CLK	IN	Roll motor driver clock signal
4	ROLL_DAT	IN	Roll motor driver data signal
5	ROLL_STB	IN	Roll motor driver strobe signal
6	/ROLL_SLEEP	IN	Roll motor driver sleep signal
7	VM	IN	Power supply (+26V)
8	VM	IN	Power supply (+26V)
9	ROLL_UNIT	OUT	Roll unit detection signal
10	ROLL_PAPER_SNS	OUT	Roll media sensor signal
11	ROLL_CAM_SNS	OUT	Roll cam sensor signal
12	GND	-	GND
13	OPT_5V	IN	Power supply (+5V)

T-6-44

J2 (Roll media sensor)			
Pin Number	Signal name	IN/OUT	Function
1	+5V	OUT	Power supply (+5V)
2	GND	-	GND
3	ROLL_PAPER_SNS	IN	Roll media sensor signal

T-6-45

J3 (Roll cam sensor, roll motor)			
Pin Number	Signal name	IN/OUT	Function
1	+5V	OUT	Power supply (+5V)
2	GND	-	GND
3	ROLL_CAM_SNS	IN	Roll cam sensor signal
4	GND	-	GND
5	ROLL_OUTAP	OUT	Roll motor drive signal AP
6	ROLL_OUTAM	OUT	Roll motor power supply AM
7	ROLL_OUTBP	OUT	Roll motor drive signal BP
8	ROLL_OUTBM	OUT	Roll motor power supply BM

6.3 Version Up

6.3.1 Firmware Update Tool

Use of the following tools allows you to update the firmware of the system controller incorporated in the printer.

- GARO Firmware Update Tool
- L Printer Service Tool

1. GARO Firmware Update Tool

GARO Firmware Update Tool is the same as that for user.

Procedure

- 1) Start CARO Firmware Update Tool.
- 2) Place the printer in the online mode.
- 3) Transfer the firmware data to the printer according to the instructions shown on the display.
- 4) The data shown on the LCD on the operation panel changes and the firmware is updated automatically.
- 5) When firmware update is completed, the printer will start again.

File transfer route:
USB, IEEE1394, network

2. L Printer Service Tool

Procedure

- 1) Start L Printer Service Tool.
- 2) Place the printer in the online mode.
- 3) Specify the firmware file(jdl) and then transfer it.
- 4) The data shown on the LCD on the operation panel changes and the firmware is updated automatically.
- 5) When firmware update is completed, the printer will start again.

File transfer route:
USB, IEEE1394, network (directly connected using a cross cable)

6.4 Service Tools

6.4.1 Tool List

T-6-46

General-purpose tools	Application
Long Phillips screwdriver	Inserting and removing screws
Phillips screwdriver	Inserting and removing screws
Flat-head screwdriver	Removing the E-ring
Needle-nose pliers	Inserting and removing the spring parts
Hex key wrench	Inserting and removing hexagonal screws
Flat brush	Applying grease
Lint free paper	Wiping off ink
Rubber gloves	Preventing ink stains

T-6-47

Special-purpose tools	Application
Grease MOLYKOTE PG-641 (CK-0562-000)	Applying to specified locations

Chapter 7 SERVICE MODE

Contents

7.1 Service Mode 7-1

 7.1.1 Service Mode Operation..... 7-1

 7.1.2 Service Mode Map 7-1

 7.1.3 Details of Service Mode 7-5

7.2 Special Mode 7-11

 7.2.1 Special Modes for Servicing 7-11

7.1 Service Mode

7.1.1 Service Mode Operation

a) How to enter the Service mode

Enter the Service mode following the procedure below.

- 1) Turn off the printer.
- 2) Turn on the printer while holding down the [Paper Source] button and [Information] button.
- * Keep pressing the above buttons until "Initializing" appears on the display.
- 3) "S" is displayed in the upper right corner of the display showing the version.
- 4) After display of "Online", pressing the [Menu] button displays the SERVICE MODE top menu and the MESSAGE LED flashes.

* The Service mode is added to the options in the Main menu. The Service mode can be entered even in the error status (when an error message is shown on the display) by turning the power off and then using the above key operation.

b) How to exit the Service mode


Turn off the printer.

c) Key operation in the service mode


- Selecting menus and parameters: [◀] or [▶] button
- Going to the next lower-level menu: [▲] button
- Going to the next higher-level menu: [▼] key
- Determining a selected menu or parameter: [OK] button


7.1.2 Service Mode Map

The hierarchy of menus and parameters in the Service mode is shown below.





F-7-1





F-7-3





7.1.3 Details of Service Mode

This section provides details of the Service mode menus.

a) DISPLAY

Displays and prints the printer information.

1) PRINF INF

Prints adjustment values in the User menu and all of DISPLAY and COUNTER parameters on A4-size or larger paper. When a roll media is used, the layout is optimized according to the media width in order to save paper.

2) SYSTEM

Displays the printer information shown below.

T-7-1

Display	Description	Unit
S/N	Serial number of printer	-
TYPE	Type setting on main controller PCB * iPF5000 is represented by 17.	-
LF TYPE	Feed roller type	0 or 1
TMP	Ambient temperature	C
SIZE LF	Detected size of loaded media (feed direction) 0 is always detected for the roll media.	mm/inch
SIZE CR	Detected size of loaded media (carriage direction)	mm/inch

3) HEAD

Displays the following EEPROM information in the printhead.

T-7-2

Display	Description
S/N R	Serial number of printhead R
S/N L	Serial number of printhead L
LOT R	Lot number of printhead R
LOT L	Lot number of printhead L

4) INK

Displays the numbers of days passed since installation of the following ink tanks.

If any ink tank that does not allow the printer to count the number of days passed is installed, an error message is displayed.

T-7-3

Display	Description	Unit
BK	Number of days passed since the BK ink tank was installed	Day(s)
MBK	Number of days passed since the MBK ink tank was installed	Day(s)

7-6

Display position	Sensor name	LCD display contents
21	Cutter Hp Sensor	0: Sensor ON , 1: Sensor OFF
22	(Not Used)	-
23	(Not Used)	-
24	(Not Used)	-
25	(Not Used)	-
26	Roll unit detection	0: Roll unit not detected , 1: Roll unit detected
27	Cutter unit detection	0: Cutter unit not detected , 1: Cutter unit detected
28	(Not Used)	-
29	(Not Used)	-
30	(Not Used)	-
31	(Not Used)	-
32	(Not Used)	-

c) ADJUST

Performs adjustments and prints the adjustment and check patterns necessary for adjusting the printer parts.

- PRINT PATTERN > NOZZLE 1

1. This nozzle check pattern is used during servicing and is printed in the single direction using a single path. It is used to check for nozzles that are not injecting ink properly.

This pattern is printed on A4-size media in the landscape orientation.

The media type is optional.

- PRINT PATTERN > OPTICAL AXIS

This pattern is used to adjust the registration sensor optical axis. For details, refer to "Disassembly/Adjustment" > "Adjustment and Setup" > "Action to Take after Replacing the Carriage Unit or Multi Sensor".

Use photo glossy paper.

- PRINT PATTERN > LF TUNING

This pattern is used to adjust the cassette feed roller eccentricity. For details, refer to "Disassembly/Adjustment" > "Adjustment and Setup" > "Action to Take after Replacing the Cassette Feed Roller HP Sensor or Cassette Feed Roller Encoder".

Use photo glossy paper.

- PRINT PATTERN > LF & HAKUSYA

This pattern is used to adjust the LF pinch roller and spur.



LF & HAKUSYA is dedicated to the adjustment in the factory. This adjustment is not required during servicing

- HEAD ADJ.

This mode allows you to set or reset the registration adjustment values of individual heads.

T-7-7

Display	Description
AUTO HEAD ADJ	Prints and reads (adjusts) the auto head adjustment pattern. ROUGH: Enlargement and rough adjustment
MNUAL HEAD ADJ	Prints the manual head adjustment pattern. DETAIL: Fine adjustment BASIC: Simple adjustment
ADJ. SETTING	Allows you to enter any registration adjustment value within the range of -127 to +127.
RESET SETTING	Resets the registration adjustment values. Adjustment values A1 to F* are reset (to zeros).

- NOZZLE CHK POS.

This mode allows you to adjust the optical axis of the head management sensor. For details, refer to "Disassembly/Adjustment" > "Adjustment and Setup" > "Action to Take after Replacing the Head Management Sensor".

- GAP CLIB.

This mode measures the gap between the head and media using a multi sensor and updates the calibration value.

- SENSOR CALIB.

This mode adjusts the sensor for color calibration. Use a dedicated test chart.

- CHANGE LF TYPE

This mode allows you to change the LF roller type.

0: Old roller

1: New roller

d) REPLACE

Used when replacing the cutter unit. For details, refer to "Disassembly/Adjustment" > "Adjustment and Setup" > "Precautions for Disassembly/Adjustment" > "Cutter".

e) FUNCTION

Checks the operation of the buttons on the operation panel and printer parts.

T-7-8

Display	Description
PANEL LED/LCD	This checks the LEDs and LCD on the operation panel. The LEDs flash, and the squares in the LCD are displayed in a checkerboard pattern and flash alternately. This mode is automatically canceled after completion of the operation.
PANEL KEY	This checks the buttons on the operation panel. The name and symbol of the pressed button is displayed. Pressing the [▲] key allows you to exit this mode. Also, pressing the [Power] button turns off the printer.
PLATEN FAN	This checks the operation of the suction fan. The suction fan rotates for 5 seconds at the maximum speed, and then rotates for 5 seconds at the minimum speed.
AIR FLOW FAN R	This checks the operation of the mist fan R. The mist fan R rotates for 10 seconds.
INK VALVE	This checks the operation of the ink valve. The valve motor is driven, and the ink supply valve open/close cam by one turn.

f) COUNTER

Displays the service life (number of operation times and time) of each unit and print counts for each media type.
The count values discussed here can be printed using the "PRINT INF" option.

- PRINTER: Counters related to product life

T-7-9

Display	Description	Unit
LIFE TTL	Cumulative number of printed media (equivalent of A4)	sheets
LIFE ROLL	Cumulative number of printed roll media (equivalent of A4)(printing to PRINT INF only)	sheets
LIFE CUTSHEET	Cumulative number of printed cut sheets (equivalent to A4) (printing to PRINT INF only)	sheets
LIFE CASSETTE	Cumulative number of printed cassette sheets (equivalent to A4) (printing to PRINT INF only)	sheets
LIFE A-F	Cumulative number of printed media for environments A to F	sheets
POWER ON	Cumulative power-on time (excluding the sleep time)	Hours
W-INK	Maintenance cartridge tank full detection counter	%
CUTTER	Number of cutting operations	Times
WIPE	Number of wiping operations	Times

- CARRIAGE: Counters related to carriage unit

T-7-10

Display	Description	Unit
PRINT	Cumulative printing time	Hours
CR COUNT	Cumulative carriage scan count (one back-and-forth motion = 1)	Times
CR DIST.	Cumulative carriage scan distance (210 mm/scan)	Times
PRINTCOUNT	Cumulative print end count	Times

- PURGE: Counters related to purge unit

T-7-11

Display	Description	Unit
CLN-A-1	Cumulative number of automatic cleaning 1 (normal suction) operations	Times
CLN-A-2	Cumulative number of automatic cleaning 2 (ink level adjusting) operations	Times
CLN-A-3	Cumulative number of automatic cleaning 3 (initial filling) operations	Times
CLN-A-6	Cumulative number of automatic cleaning 6 (strong normal suction) operations	Times
CLN-A-7	Cumulative number of automatic cleaning 7 (aging) operations	Times
CLN-A-10	Cumulative number of automatic cleaning 10 (ink filling after secondary transportation) operations	Times
CLN-A-11	Cumulative number of automatic cleaning 11 (ink filling after head replacement) operations	Times
CLN-A-15	Cumulative number of automatic cleaning 15 (dot count small suction) operations	Times
CLN-A-16	Cumulative number of automatic cleaning 16 (sedimented ink agitation) operations	Times
CLN-A-17	Cumulative number of automatic cleaning 17 (small suction) operations	Times
CLN-A-TTL	Total number of automatic cleaning operations	Times
CLN-M-1	Cumulative number of manual cleaning 1 (normal suction) operations	Times
CLN-M-4	Cumulative number of manual cleaning 4 (ink draining from head after head replacement) operations	Times
CLN-M-5	Cumulative number of manual cleaning 5 (ink draining from head and tube before transportation) operations	Times
CLN-M-6	Cumulative number of manual cleaning 6 (normal strong suction) operations	Times
CLN-M-TTL	Total number of manual cleaning operations	Times

- CLEAR: Counters related to counter initialization

T-7-12

Display	Description	Unit
CLR-INK CONSUME	Cumulative count of ink section consumption amount clearing	Times
CLR-CUTTER EXC.	Cumulative count of cutter replacement count clearing	Times
CLR-MTC EXC.	Cumulative count of maintenance cartridge replacement count clearing	Times
CLR-HEAD L EXC.	Cumulative count of head L replacement count clearing	Times
CLR-HEAD R EXC.	Cumulative count of head R replacement count clearing	Times

Display	Description	Unit
CLR-UNIT A EXC.	Cumulative count of unit A(waste ink system) replacement count clearing	Times
CLR-UNIT B EXC.	Cumulative count of unit B(platen duct) replacement count clearing	Times
CLR-UNIT D EXC.	Cumulative count of unit D(carriage unit) replacement count clearing	Times
CLR-UNIT F EXC.	Cumulative count of unit F(ink supply system) replacement count clearing	Times
CLR-UNIT H EXC.	Cumulative count of unit H(purge) replacement count clearing	Times
CLR-UNIT L EXC.	Cumulative count of unit L(head management sensor) replacement count clearing	Times
CLR-UNIT P EXC.	Cumulative count of unit P(feed motor) replacement count clearing	Times
CLR-UNIT Q EXC.	Cumulative count of unit Q(feed roller) replacement count clearing	Times
CLR-UNIT R EXC.	Cumulative count of unit R(spur cam) replacement count clearing	Times
CLR-UNIT V EXC.	Cumulative count of unit V(mist fan unit) replacement count clearing	Times
CLR-FACTORY CNT.	For factory	Times

- EXCHANGE: Counters related to parts replacement

T-7-13

Display	Description	Unit
CUTTER EXC.	Cutter replacement count	Times
MTC EXC.	Maintenance cartridge replacement count	Times
HEAD R EXC.	Head R replacement count	Times
HEAD L EXC.	Head L replacement count	Times
BOARD EXC.(M/B)	Main controller PCB replacement count	Times
UNIT A EXC.	Unit A(waste ink system) replacement count	Times
UNIT B EXC.	Unit B(platen duct) replacement count	Times
UNIT D EXC.	Unit D(carriage unit) replacement count	Times
UNIT F EXC.	Unit F(ink supply system) replacement count	Times
UNIT H EXC.	Unit H(purge) replacement count	Times
UNIT L EXC.	Unit L(head management sensor) replacement count	Times
UNIT P EXC.	Unit P(feed motor) replacement count	Times
UNIT Q EXC.	Unit Q(feed roller) replacement count	Times
UNIT R EXC.	Unit R(spur cam) replacement count	Times
UNIT V EXC.	Unit V(mist fan unit) replacement count	Times

- DETAIL-CNT: Counters related to ink

T-7-14

Display	Description	Unit
MOVE PRINTER	Number of "Move Printer" operations	Times
N-INKCHECK(XX)	XX: Ink color Number of "Stop Ink Check" operations	Times
MEDIACONFIG-CNT	Number of times media was registered by media editor	Times

- INK-USE1: Counters related to ink

T-7-15

Display	Description	Unit
INK USE1(XX)	XX: Ink color Cumulative consumption amount of each color of generic ink	ml
INK USE1(TTL)	Total consumption amount of generic ink	ml
N-INK USE1(XX)	XX: Ink color Cumulative consumption amount of each color of refill ink	ml
N-INK USE1(TTL)	Total consumption amount of each color of refill ink	ml

- INK-USE2: Counters related to ink

T-7-16

Display	Description	Unit
INK USE2(XX)	XX: Ink color Cumulative consumption amount of each color of generic ink	ml
INK USE2(TTL)	Total consumption amount of generic ink	ml
N-INK USE2(XX)	XX: Ink color Cumulative consumption amount of each color of refill ink	ml
N-INK USE2(TTL)	Total consumption amount of each color of refill ink	ml

- INK-EXC: Counters related to ink

T-7-17

Display	Description	Unit
INK USE EXC(XX)	XX: Ink color Cumulative count of generic ink replacement	ml

Display	Description	Unit
INK USE EXC(TTL)	Total count of generic replacement of each color of ink	ml
N-INK USE EXC(XX)	XX: Ink color Cumulative count of refill ink replacement	ml
N-INK USE EXC(TTL)	Total count of replacement of each color of ink	ml

- MEDIA x (x: 1 to 7): Counters related to media

Cumulative print areas are displayed for media 1-7 beginning with the media with the maximum cumulative print area.

T-7-18

Display	Description	Unit
NAME	Media type	-
TTL	Cumulative print area of all media feed trays (metric)	m2
TTL	Cumulative print area of all media feed trays (inch)	Sq.f
ROLL	Cumulative print area of roll media (metric)	m2
ROLL	Cumulative print area of roll media (inch)	Sq.f
CUT SHEET	Cumulative print area of cut sheet (metric)	m2
CUT SHEET	Cumulative print area of cut sheet (inch)	Sq.f
CASSETTE	Cumulative print area of cassette paper (metric)	m2
CASSETTE	Cumulative print area of cassette paper (inch)	Sq.f

- MEDIA OTHER: Counters related to media

Cumulative print areas are displayed beginning with the media with the eighth-large cumulative print area.

T-7-19

Display	Description	Unit
NAME	Media type	-
TTL	Cumulative print area of all media feed trays (metric)	m2
TTL	Cumulative print area of all media feed trays (inch)	Sq.f
ROLL	Cumulative print area of roll media (metric)	m2
ROLL	Cumulative print area of roll media (inch)	Sq.f
CUT SHEET	Cumulative print area of cut sheet (metric)	m2
CUT SHEET	Cumulative print area of cut sheet (inch)	Sq.f
CASSETTE	Cumulative print area of cassette paper (metric)	m2
CASSETTE	Cumulative print area of cassette paper (inch)	Sq.f

- MEDIASIZE1 ROLL: Counters related to roll media printing

T-7-20

Display	Description	Unit
P-SQ 17-24	Cumulative print area of paper equal to or larger than 17 inches but smaller than 24 inches (physical size)	m2/Sq.f
P-SQ 17	Cumulative print area of paper smaller than 17 inches (physical size)	m2/Sq.f
P-CNT 17-24	Cumulative number of sheets of A4-equivalent paper equal to or larger than 17 inches but smaller than 24 inches (physical size)	sheets
P-CNT 17	Cumulative number of sheets of A4-equivalent paper smaller than 17 inches (physical size)	sheets

- MEDIASIZE2 ROLL: Counters related to roll media printing

T-7-21

Display	Description	Unit
D-SQ 17-24	Cumulative print area of paper equal to or larger than 17 inches but smaller than 24 inches (data size)	m2/Sq.f
D-SQ 17	Cumulative print area of paper smaller than 17 inches (data size)	m2/Sq.f
D-CNT 17-24	Cumulative number of sheets of A4-equivalent paper equal to or larger than 17 inches but smaller than 24 inches (data size)	sheets
D-CNT 17	Cumulative number of sheets of A4-equivalent paper smaller than 17 inches (data size)	sheets

- MEDIASIZE1 CUT: Counters related to cut sheet printing

T-7-22

Display	Description	Unit
P-SQ 17-24	Cumulative print area of paper equal to or larger than 17 inches but smaller than 24 inches (physical size)	m2/Sq.f
P-SQ 17	Cumulative print area of paper smaller than 17 inches (physical size)	m2/Sq.f
P-CNT 17-24	Cumulative number of sheets of A4-equivalent paper equal to or larger than 17 inches but smaller than 24 inches (physical size)	sheets
P-CNT 17	Cumulative number of sheets of A4-equivalent paper smaller than 17 inches (physical size)	sheets

- MEDIASIZE2 CUT: Counters related to cut sheet printing

T-7-23

Display	Description	Unit
D-SQ 17-24	Cumulative print area of paper equal to or larger than 17 inches but smaller than 24 inches (data size)	m2/Sq.f
D-SQ 17	Cumulative print area of paper smaller than 17 inches (data size)	m2/Sq.f

Display	Description	Unit
D-CNT 17-24	Cumulative number of sheets of A4-equivalent paper equal to or larger than 17 inches but smaller than 24 inches (data size)	sheets
D-CNT 17	Cumulative number of sheets of A4-equivalent paper smaller than 17 inches (data size)	sheets

- HEAD DOT CNT.1

Displays the counts of dots of individual colors of the currently installed print head.

- HEAD DOT CNT.2

Displays the cumulative count of dots of individual colors.

- PARTS CNT.

Displays the status of the consumable parts replacement counter.

g) SETTING

Allows you to make various settings.

T-7-24

Display	Description
Pth ON/OFF	Turns on/off the (Pth head pulse rank) control function. Default: On
RTC DATE	Set the RTC. The procedure is the same as in the user mode.
yyyy/mm/dd	The initial value is 00:00, January 1, 2006.
TIME hh:mm	* The display order of year, month, and day is defined in "Date Format".

- INITIALIZE

The DISPLAY histories, ADJUST settings, COUNTER values, and other parameters can be cleared individually.

T-7-25

Display	Description
WARNING	Initialization of DISPLAY > WARNING
ERROR	Initialization of DISPLAY > ERROR
ADJUST	Initialization of value of fine band adjustment by user and initialization of scale adjustment value The automatically adjusted value is not initialized.
W-INK	Initialization of COUNTER > PRINTER > W-INK
CARRIAGE	Initialization of COUNTER > CARRIAGE
PURGE	Initialization of COUNTER > PURGE
INK CHECK	* The refill ink usage history cannot be initialized.
INK-USE CNT	Initialization of COUNTER > INK-USE2
CUTTER-CHG CNT	Initialization of COUNTER > EXCHANGE > CUTTER EXC. Counting up of COUNTER > CLEAR
W-INK-CHG CNT	Initialization of COUNTER > EXCHANGE > MTC EXC. Counting up of COUNTER > CLEAR
HEAD-CHG R CNT	Initialization of COUNTER > EXCHANGE > HEAD R EXC.
HEAD-CHG L CNT	Initialization of COUNTER > EXCHANGE > HEAD L EXC.
PARTS-CHG CNT	Initialization of COUNTER > EXCHANGE > UNIT A EXC. Counting up of CLEAR > UNIT EXC.
PARTS COUNTER	Initialization of all COUNTER > PARTS CNT.

7.2 Special Mode

7.2.1 Special Modes for Servicing

This printer supports the following special modes in addition to the service mode:

- **PCB replacement mode**
- **Download mode**

1. PCB replacement mode

This mode is used when replacing the main PCB or MC relay PCB.

By executing this mode,

- Backup data of the settings and counter values stored in the MC relay PCB are moved to the new main PCB.
- The data such as the settings and counter values are copied to the MC relay PCB.

a) Entering the PCB replacement mode

Follow the same procedure as that for entering the service mode.

(With the "Paper Source" button and "Information" button pressed down, turn on the "Power" button.)

When the printer starts up, compare the serial number memorized in the main PCB's EEPROM with that memorized in the MC relay PCB's EEPROM. If they do not match, or no serial number is memorized in either EEPROM, enter the PCB replacement mode.

While you are in the PCB replacement mode, the MESSAGE LED, roll media LED, and ONLINE LED are lit.

b) Procedure

Select "CPU BOARD" or "MC BOARD" using the [◀] and [▶] buttons, and then press the [OK] button to determine it.

- CPU BOARD

Select this after replacing the main PCB.

The data in the MC relay PCB is copied to the main PCB.

- MC BOARD

Select this before replacing the main PCB.
The data in the main PCB is copied to the MC relay PCB.
Use this when the MC relay PCB is a new one.

c) Exiting the PCB replacement mode

Turning off the Power button of the printer allows you to exit the PCB replacement mode.

For details on how to replace the PCB, see Parts Replacement Procedure > Disassembly/Reassembly > Points to Note on Disassembly and Reassembly > Boards.

2. Download mode

Use this mode only when updating the firmware without performing initialization.

a) Entering the download mode

- 1) Turning off the Power button of the printer.
- 2) With the "Stop" and "Information" buttons pressed down, turn on the Power button of the printer.
 - * Keep pressing the above buttons until "Initializing" appears on the display.

b) Procedure

When "Download Mode/Send Firmware" is shown on the display, transfer the firmware.

When downloading of the firmware is completed, the printer is turned off automatically.

Chapter 8 ERROR CODE

Contents

8.1 Outline 8-1

 8.1.1 Outline 8-1

8.2 Warning Table 8-1

 8.2.1 Warnings 8-1

8.3 Error Table..... 8-1

 8.3.1 Error Code List..... 8-1

8.4 Sevice Call Table..... 8-4

 8.4.1 Service call errors..... 8-4

8.1 Outline

8.1.1 Outline

The printer indicates errors using the display and LEDs.

If an error occurs during printing, the printer status is also displayed on the status monitor of the printer driver.

The following three types of errors are displayed on the display:

- Warning

Status where the print operation can be continued without remedying the cause of the problem. This can, however, adversely affect the printing results.

- Error

Status where the print operation is stopped, and the regular operation cannot be recovered until the cause of the problem is remedied.

- Service call error

When a service call error occurs, the error is not cleared and the error indication remains on the operation panel even if the printer is powered off and on again.

(Occurrence of the service call error is indicated again at power-on.)

This measure is taken to prevent user's recovery of the service call error and damages to the printer.

Service call errors can be cleared, however, by starting up the printer in the service mode.

For how to take actions against warnings and errors, refer to "Troubleshooting".

Overview of warnings and error codes

T-8-1

Code*	Diagnosis
W100x	Ink warning
W110x	Waste ink warning
W12xx	GARO warning
03xxxxxx-20xx	Media feeding error
03xxxxxx-2Exx	Data mismatch error
03xxxxxx-25xx	Ink error
03xxxxxx-280x	Printhead error
03xxxxxx-281x	Maintenance cartridge error
03xxxxxx-282x	Adjustment error
03xxxxxx-2Fxx	Other errors
Exxx-40xx	Service call error

* "x" stands for a numeric or letter.

8.2 Warning Table

8.2.1 Warnings

The codes correspond to the numbers shown on the DISPLAY in the service mode.

T-8-2

Code	Display message	Status
1000	Ink Lvl: Chk BK	BK ink tank is almost empty
1001	Ink Lvl: Chk Y	Y ink tank is almost empty
1002	Ink Lvl: Chk M	M ink tank is almost empty
1003	Ink Lvl: Chk C	C ink tank is almost empty
1004	Ink Lvl: Chk PM	PM ink tank is almost empty
1005	Ink Lvl: Chk PC	PC ink tank is almost empty
1006	Ink Lvl: Chk MBK	MBK ink tank is almost empty
1008	Ink Lvl: Chk GY	GY ink tank is almost empty
1009	Ink Lvl: Chk PGY	PGY ink tank is almost empty
101A	Ink Lvl: Chk R	R ink tank is almost empty
101B	Ink Lvl: Chk B	B ink tank is almost empty
101C	Ink Lvl: Chk G	G ink tank is almost empty
1100	MTCart Full Soon	Maintenance cartridge is almost full
1101	Mist Full Soon	Mist count is almost full
1221	GARO W1221	Unsupported command in GARO image mode
1222	GARO W1222	Invalid number of parameters in GARO image mode (no parameter)
1223	GARO W1223	Required item was omitted in GARO image mode
1225	GARO W1225	Other warning in GARO image mode
1231	GARO W1231	Unsupported command in GARO setting mode
1232	GARO W1232	Invalid number of parameters in GARO setting mode
1233	GARO W1233	Required item was omitted in GARO setting mode
1234	GARO W1234	Data out of range in GARO setting mode
1235	GARO W1235	Other warning in GARO setting mode
100F	Feed Limit...	Force feed limit

8.3 Error Table

8.3.1 Error Code List

The codes correspond to the numbers shown on the DISPLAY in the service mode.

Code	Status
03060A00-2E1B	End of roll media
03010000-200A	Paper width not detected
03010000-200B	Incorrect position on platen
03010000-200C	Media leading edge not detected
03010000-200D	The trailing edge of cut sheet cannot be detected
03010000-200E	Too small media
03010000-200F	Too large media
03016000-2010	Skewed media
03130031-2F24	Cutter movement timeout
03870001-2015	Cutting failure
03010000-2017	Media right edge not detected
03010000-2018	Media left edge not detected
03862000-2E09	Roll paper running out
03010000-2E19	Media feeding error
03010000-2E1A	
03010000-2E1D	
03060A00-2E0E	
03010000-2E1C	Auto Roll Feed Unit not installed
03180101-2E17	Media cannot be ejected
03060200-201E	Cassette not loaded
03860002-2E0A	Job requiring cassette was received when "NO" is selected for cassette pick-up on MIT
03060A00-2E00	Manually fed cut sheet was already loaded even though received data indicated roll media
03861001-2405	Roll media was loaded even though the received data indicated roll media.
03861001-2406	Invalid paper position for borderless printing
03060000-2E14	Data that does not allow borderless printing was received
03060200-2E03	Width indicated by received data does not match width of paper
03061000-2E15	Cut sheets were not loaded in cassette even though the received data indicated cut sheets
03060000-2E16	Media type indicated by data does not match
03060200-2E0B	Media type and size indicated by data do not match (cassette only)
03010000-2E1F	Manually fed cut sheet was already loaded even though received data indicated cassette
03810104-2500	Too small media for internal printing was loaded
03810101-2501	No ink (BK)
03810102-2502	No ink (Y)
03810103-2503	No ink (M)
03810112-2504	No ink (C)
03810113-2505	No ink (PM)
03810106-2506	No ink (PC)
03810105-2508	No ink (MBK)
03810115-2509	No ink (GY)
03810107-250A	No ink (PGY)
03810109-250B	No ink (R)
03810108-250C	No ink (B)
03830104-2520	No ink (G)
03830101-2521	Ink tank not installed (BK)
03830102-2522	Ink tank not installed (Y)
03830103-2523	Ink tank not installed (M)
03830112-2524	Ink tank not installed (C)
03830113-2525	Ink tank not installed (PM)
03830106-2526	Ink tank not installed (PC)
03830105-2528	Ink tank not installed (MBK)
03830115-2529	Ink tank not installed (GY)
03830107-252A	Ink tank not installed (PGY)
03830109-252B	Ink tank not installed (R)
03830108-252C	Ink tank not installed (B)
03830204-2540	Ink tank not installed (G)
03830201-2541	Ink tank ID error (BK)
03830202-2542	Ink tank ID error (Y)
03830203-2543	Ink tank ID error (M)
03830212-2544	Ink tank ID error (C)
03830213-2545	Ink tank ID error (PM)
03830206-2546	Ink tank ID error (PC)
03830205-2548	Ink tank ID error (MBK)
	Ink tank ID error (GY)

Code	Status
03830215-2549	Ink tank ID error (PGY)
03830207-254A	Ink tank ID error (R)
03830209-254B	Ink tank ID error (B)
03830208-254C	Ink tank ID error (G)
03830304-2560	Ink tank EEPROM error (BK)
03830301-2561	Ink tank EEPROM error (Y)
03830302-2562	Ink tank EEPROM error (M)
03830303-2563	Ink tank EEPROM error (C)
03830312-2564	Ink tank EEPROM error (PM)
03830313-2565	Ink tank EEPROM error (PC)
03830306-2566	Ink tank EEPROM error (MBK)
03830305-2568	Ink tank EEPROM error (GY)
03830315-2569	Ink tank EEPROM error (PGY)
03830307-256A	Ink tank EEPROM error (R)
03830309-256B	Ink tank EEPROM error (B)
03830308-256C	Ink tank EEPROM error (G)
03810204-2580	Remaining ink low (BK)
03810201-2581	Remaining ink low (Y)
03810202-2582	Remaining ink low (M)
03810203-2583	Remaining ink low (C)
03810212-2584	Remaining ink low (PM)
03810213-2585	Remaining ink low (PC)
03810206-2586	Remaining ink low (MBK)
03810205-2588	Remaining ink low (GY)
03810215-2589	Remaining ink low (PGY)
03810207-258A	Remaining ink low (R)
03810209-258B	Remaining ink low (B)
03810208-258C	Remaining ink low (G)
03800100-2800	No printhead R
03800200-2802	Incorrect printhead R was installed
03800400-2803	Printhead R EEPROM error
03800200-2804	Printhead R has been installed on the left side
03800300-2801	Unable to correct printhead R DI
03800202-2807	Printhead L has been installed on the right side
03800101-2808	No printhead L
03800201-280A	Incorrect printhead L was installed
03800401-280B	Printhead L EEPROM error
03800301-2809	Unable to correct printhead L DI
01800500-1012	Many nozzles on printhead R did not inject ink
01800500-1013	Many nozzles on printhead L did not inject ink
03841201-2816	Maintenance cartridge EEPROM error
03841201-2817	Maintenance cartridge ID error
03841101-2818	Maintenance cartridge not installed
03841001-2819	Maintenance cartridge tank full
01841001-281A	Remaining capacity of maintenance cartridge is insufficient to execute each cleaning
03010000-2820	Unable to adjust printhead registration
03010000-2821	Unable to adjust band
03010000-2822	Unable to adjust eccentricity
03010000-2823	Printhead check error
03800500-2F2F	No ink ejection detection error
03800500-2F30	No ink ejection detection position adjustment error
03130031-2F32	Multi sensor faulty
03010000-2F33	Unable to adjust due to transparent media
03130031-2F25	Unable to detect CR motor HP
03130031-2F16	Mist fan error
03130031-2F3A	Ink supply valve motor error
03130031-2F2A	Feed roller HP sensor error
03130031-2F17	Platen fan error
03130031-2F28	Pump encode/Pump cam sensor error
03130031-2F20	
03130031-2F26	Carriage cannot operate
03130031-2F27	Carriage movement timeout
03030000-2E21	IEEE1394 interface error

Code	Status
03130031-2F22	Pump movement timeout
03130031-2F2B	Feed roller cannot operate
03130031-2F2D	Cassette cannot operate
03130031-2F23	Pump cannot operate
03130031-2F2E	Roll movement timeout
03130031-291B	Lift movement timeout
03130031-2E23	Cutter unit failure
03130031-2F13	A/D converter external trigger output stopped
03130031-2F14	Unable to write in ASIC register

8.4 Service Call Table

8.4.1 Service call errors

Codes correspond to the numbers shown on the DISPLAY in the service mode.

T-8-4

Code	Description	Display message
E141-4046	Recovery system rotation count reached 50,000.	ERROR Exxx-xxxx Call For Service
E144-4047	Feed system counting error	
E146-4001	Borderless/idle ejection/ mist recovery count full	
E194-404A	No ink ejection counting error	
E161-403E	Abnormally high printhead R temperature	
E161-403F	Abnormally high printhead L temperature	
E196-4040	Checksum error	
E196-4041	Flash memory clearing error	
E196-4042	Flash memory write error	
E196-4045	Engine EEPROM write error	
E196-4049	Transfer ROM data type error	
E196-4042	MIT Data transfer error	
E198-401C	RTC error	
E198-401D	RTC low battery error	
E198-401E	RTC clock stopped	

May 9 2006

Canon