

VAX 86XX System Maintenance Guide

For Internal Use Only

First Edition, December 1985
Second Edition, September, 1986
Third Edition, March 1987

Copyright © 1985, 1986, 1987 by Digital Equipment Corporation.
All Rights Reserved.
Printed in U.S.A.

The reproduction of this material, in part or whole, is strictly prohibited. For copy information, contact the Educational Services Department, Digital Equipment Corporation, Maynard, Massachusetts 01754.

The information in this document is subject to change without notice. Digital Equipment Corporation assumes no responsibility for any errors that may appear in this document.

The following are trademarks of Digital Equipment Corporation, Maynard, Massachusetts.

DEC	DIBOL	Rainbow	VAX
DECmate	MASSBUS	RSTS	VMS
DECUS	PDP	RSX	VT
DECwriter	P/OS	RT	Work Processor
	Professional	UNIBUS	

CONTENTS

PREFACE

CHAPTER 1 GENERAL INFORMATION

1.1	RELATED DOCUMENTATION	1-2
1.2	LITERATURE ORDERING INFORMATION	1-6
1.3	SOFTWARE AND DIAGNOSTIC ORDERING INFORMATION	1-7
1.4	FIELD SERVICE MICROFICHE LIBRARY	1-8
1.5	RELATED INFORMATION DISTRIBUTION	1-8
1.6	VAX STUFF PUBLICATION	1-9

CHAPTER 2 MODULE UTILIZATION AND BACKPLANE INFORMATION

2.1	VAX 8600/8650 BALL MODULE UTILIZATION	2-2
2.2	VAX 8600/8650 MEMORY ARRAY MODULE CONFIGURATIONS	2-3
2.3	CABINET CAGE MODULE UTILIZATION	2-4
2.4	CPU, ABUS, AND MEMORY BACKPLANE COMPONENTS AND PIN NUMBERING SCHEME	2-5
2.5	I/O BACKPLANE COMPONENTS AND PIN NUMBERING SCHEME	2-6
2.6	CABINET CAGE BACKPLANE - REAR VIEW	2-7
2.7	BACKPLANE INTERCONNECTIONS	2-9

CHAPTER 3 POWER

3.1	POWER SYSTEM COMPONENT DESCRIPTION	3-1
3.2	ENVIRONMENTAL SENSOR DESCRIPTIONS (AND LIMITS)	3-2
3.2.1	Air Temperature Sensors	3-2
3.2.1.1	Ambient Air Input Temperature Sensor (T1)	3-2
3.2.1.2	Module Card Cage Exhaust Temperature Sensors (T2, T3, T4)	3-3
3.2.1.3	Air Temperature Increase Across Modules (All Sensors)	3-3
3.2.1.4	Critical Cabinet Temperature Sensor (T3)	3-3
3.2.2	Air Flow Sensors	3-3
3.2.3	Ground Current Sensor	3-3
3.2.4	50-Hertz Transformer Temperature Sensor (Front End Cabinet)	3-4
3.2.5	CPU Cabinet Filter Sensor	3-4
3.3	ENVIRONMENTAL MONITORING AND EMERGENCY POWER OFF CONDITIONS	3-4
3.3.1	EMM Hardware Monitored and Controlled	3-4
3.3.2	EMM Software Monitored and Controlled	3-4
3.3.3	EMM Software Monitored and Console Software Controlled	3-8

3.3.4	876-A Power Controller Monitored and Controlled	3-8
3.4	REFERENCE DOCUMENTATION	3-8
3.5	SYSTEM ENVIRONMENTAL MONITORING - SOFTWARE CONTROL	3-8
3.5.1	Temperature Sensor (or Delta Temperature) Enters Yellow Zone	3-9
3.5.2	Temperature Sensor (or Delta Temperature) Enters Red Zone	3-9
3.5.3	Single Air-flow Fault	3-10
3.5.4	Double Air-flow Fault	3-10
3.5.5	MPS Status Change	3-10
3.6	MPS POWER DISTRIBUTION AND COLOR CODES	3-10
3.7	MPS POWER DISTRIBUTION COLOR CODE CHART	3-11
3.8	HOW TO MARGIN MPS REGULATORS	3-11
3.8.1	MPS Regulator Margining Procedure	3-14
3.9	H7170-A POWER SUPPLY - VISUAL INDICATORS	3-14
3.10	H7180-A, H7186-A, AND H7187-A POWER SUPPLY VISUAL INDICATORS	3-16
3.11	TOTAL OFF CODES - FAULT CONDITIONS	3-19
3.12	EMM LEDS AND SWITCHES	3-19
3.13	MPS POWER AND SENSOR READING	3-20
3.14	MPS STATUS MESSAGES	3-20
3.15	HOW TO ENABLE/DISABLE BATTERY BACKUP	3-20
3.16	HOW TO DETERMINE THE BATTERY CHARGE STATUS OF THE BBU	3-22
3.17	H7140-CA POWER DISTRIBUTION	3-22
3.17.1	H7140 Power Distribution Color Codes	3-22
3.17.2	H7140 Power Distribution/Interconnection Tables	3-23
3.18	RL02 (CVT) POWER INFORMATION	3-24

CHAPTER 4 INITIALIZATION AND BOOTSTRAP TROUBLESHOOTING PROCEDURES

4.1	INTRODUCTION	4-1
4.2	BOOT SEQUENCE TIME LINE FLOW DESCRIPTION	4-1
4.3	MODULE KEYING	4-6
4.3.1	Overview	4-6
4.3.2	Implementation	4-6
4.3.3	Parallel Key Loop	4-7
4.3.4	CPU Serial Key Loop	4-7
4.3.5	FBox Serial Key Loop	4-7
4.3.6	IOA Serial Key Loop	4-8
4.4	SCP LED SEQUENCING	4-20
4.5	CONSOLE SELF TESTS	4-22
4.6	VMB UNEXPECTED INTERRUPT TROUBLESHOOTING PROCEDURES	4-22
4.7	VMB GPR USAGE	4-24

CHAPTER 5 ERRORS AND ERROR ANALYSIS

5.1	SYSTEM FAULT ISOLATION	5-1
5.1.1	EBox Interrupt and Exception Arbitration Logic	5-1
5.1.2	Error Handling Microcode (EHM)	5-1
5.1.3	VMS Machine Check Handler	5-1
5.1.4	SPEAR (Standard Package for Error Analysis and Reporting)	5-3
5.1.5	Keep Alive Fail (KAF)	5-3

5.2	CONSOLE SNAPSHOT FILE INFORMATION	5-3
5.2.1	Guide to Decoding/Analysis of a SNAPSHOT	5-3
5.2.2	Reference Documentation	5-4
5.2.3	SNAPSHOT File Flowchart Notes	5-4
5.3	CONTROL STORE PARITY ERROR CORRECTION	5-7
5.4	SYSTEMATIC INFORMATION GATHERING PROCEDURES	5-9
5.4.1	Method 1	5-9
5.4.2	Method 2	5-10
5.4.3	Method 3	5-10
5.4.4	Method 4	5-10
5.4.5	Method 5	5-11
5.5	DUMP.COM	5-11
5.6	PROGRAM TO SCAN MEMORY FOR PARITY ERRORS (SCAN.COM)	5-15
5.7	VMS AND THE SYSTEM EVENT FILE (ERRLOG.SYS)	5-15
5.7.1	ANALYZE/ERRORLOG	5-16
5.7.2	SPEAR Library Functions	5-16
5.7.2.1	SPEAR Basic	5-16
5.7.2.2	SPEAR Extended	5-17

CHAPTER 6 DIAGNOSTICS

6.1	EMM SELF TEST	6-2
6.1.1	Prerequisites	6-2
6.1.2	EMM Self Test Descriptions	6-2
6.1.3	EMM Error Code Descriptions	6-6
6.2	T-11 (PROM) SELF TEST	6-6
6.2.1	Prerequisites	6-6
6.2.2	PROM Command Set	6-6
6.2.3	T-11 (PROM) Self Test Descriptions	6-8
6.3	CONSOLE MODULE DIAGNOSTIC (ED0BA)	6-12
6.3.1	Prerequisite	6-12
6.3.2	ED0BA Switch Register Options	6-12
6.3.3	ED0BA Control Characters	6-12
6.3.4	ED0BA Test Descriptions	6-12
6.4	EDKAA - MICRO-HARD-CORE DIAGNOSTIC (MHC)	6-17
6.4.1	Prerequisites	6-17
6.4.2	Loading and Starting MHC	6-17
6.4.3	Micro-Hard-Core Control Characters	6-17
6.4.4	Micro-Hard-Core Control Switches	6-17
6.4.5	Micro-Hard-Core Commands	6-18
6.4.6	Micro-Hard-Core Test Descriptions	6-20
6.5	MICRO DIAGNOSTIC CONTROL PROGRAM (DCP)	6-24
6.5.1	Overview	6-24
6.5.2	DCP Control Characters	6-24
6.5.3	DCP Command Summary	6-25
6.6	VAX 86XX MICRODIAGNOSTICS	6-31
6.7	STANDARD MICRODIAGNOSTIC COMMAND FILES	6-31
6.8	DIAGNOSTIC SUPERVISOR (ESSAA) OVERVIEW	6-34
6.8.1	Diagnostic Supervisor (ESSAA) Control	6-34
6.9	RL02 RESIDENT VAX MACRO-DIAGNOSTICS	6-41

CHAPTER 7 SYSTEM INFORMATION

7.1	VAX 8600 TO 8650 DIFFERENCES/UPGRADE	7-1
7.2	KA8600/8650 RAM AND MICROCODE LISTING INFORMATION	7-4
7.2.1	KA8600/8650 Common RAM and Microcode Listing Information	7-4
7.2.2	KA8600 Specific RAM and Microcode Listing Information	7-4

7.2.3	KA8650 Specific RAM and Microcode Listing Information	7-4
7.3	INTERRUPT LEVEL ASSIGNMENTS/SOURCES	7-6
7.4	VAX 8600/8650 SYSTEM CONTROL BLOCK	7-7
7.5	CONFIGURATION GUIDELINES	7-8
7.5.1	Kernel System	7-8
7.5.2	CPU Cabinet Expansion	7-9
7.5.2.1	CPU Backplane	7-10
7.5.2.2	Memory Backplane	7-10
7.5.2.3	ABUS Backplane	7-11
7.5.2.4	I/O Backplane	7-11
7.5.3	Front End Cabinet	7-12
7.5.4	Ball-AL/AM EXPANSION RULES	7-12
7.5.5	UNIBUS Expansion	7-14
7.5.6	SBI Expansion	7-15
7.5.6.1	SBI Configuration Rules	7-16
7.5.6.2	SBI TR Level Assignments	7-16
7.5.7	Cluster Rules	7-17
7.6	PM PROCEDURES	7-18
7.6.1	Summary of Quarterly PM Procedures	7-18
7.6.2	Summary of Annual PM Procedures	7-18
7.6.3	Quarterly PM Procedures	7-18
7.6.4	Annual PM Procedures	7-20
7.6.5	VAX8600/8650 PM Checklist	7-22

CHAPTER 8 SYSTEM CLOCKS

8.1	CLOCK INTRODUCTION	8-1
8.2	CLOCK CONSOLE COMMANDS	8-1
8.3	CLOCK OUTPUTS	8-1
8.4	CLOCK BLOCK DIAGRAMS	8-2

CHAPTER 9 CONSOLE HARDWARE

9.1	SYSTEM CONTROL PANEL	9-2
9.1.1	Console Operating Modes	9-2
9.1.2	SCP Switches and Indicators	9-2
9.2	CONSOLE (T11) INTERRUPT AND VECTOR INFORMATION	9-4
9.3	CBUS	9-6
9.4	QBUS	9-8
9.5	SDB	9-10
9.5.1	SDB Signal Name File Information	9-14
9.5.2	CADIF File Description	9-14
9.5.3	SDB ID	9-15
9.5.4	SDB Symbol	9-17
9.5.5	SDB Signal Name	9-17
9.5.6	CADIF File Revisions and the CONFIG.DAT file	9-17
9.6	REMOTE DIAGNOSIS	9-19
9.6.1	General	9-19
9.6.2	Setting-up the DF112 Modem	9-19
9.6.3	Using the Set Terminal Command	9-22

CHAPTER 10 CONSOLE SOFTWARE AND COMMANDS

10.1	CONSOLE COMMANDS	10-2
10.1.1	Control Characters	10-2
10.1.2	Console Command Syntax	10-2
10.1.3	Architecturally Defined Commands and Switches	10-3

10.2	GENERAL COMMANDS	10-3
10.2.1	The General Command Set	10-3
10.3	MACRO CONTEXT	10-15
10.3.1	MACRO Context Initialization	10-15
10.3.2	Console Support Microcode (CSM)	10-15
10.3.3	MACRO Context Command Set	10-16
10.4	THE HEX DEBUGGER	10-23
10.4.1	The HEX Command Set	10-23
10.4.2	Default Visibility Registers	10-37
CHAPTER 11	EBOX	
11.1	WBUS	11-1
11.1.1	WBus Signal Pin Location	11-8
11.2	EBOX GPR/SCRATCH PAD USAGE	11-9
11.3	EBOX MICROWORD	11-10
11.3.1	EBox Control Store	11-10
11.3.2	EBox Context	11-19
11.3.3	Memory Control Function (MCF)	11-19
11.4	EBOX MICROTRAP VECTOR ASSIGNMENTS	11-21
11.5	EHM FATAL ERROR LOOPS	11-22
11.6	CONSOLE SUPPORT MICROCODE (CSM)	11-23
11.7	EBOX MICROCODE LOCATIONS/REGIONS	11-25
11.8	EBOX UPC TESTPOINTS	11-26
CHAPTER 12	FBOX	
12.1	FBOX MICROCODE	12-4
12.1.1	FBox Adder (FBA) Microcode	12-4
12.1.2	FBox Multiplier (FBM) Microcode	12-10
12.1.3	FBox Dispatch RAM (FDRAM)	12-15
12.1.4	FBox Substitution Modules	12-15
12.1.5	Turning the FBox ON and OFF	12-16
12.1.5.1	To Disable the FBox	12-16
12.1.5.2	To Enable the FBox	12-16
12.1.5.3	To Determine the Status of the FBox	12-16
CHAPTER 13	IBOX	
13.1	IBOX MODULES	13-2
13.2	IBOX MICROCODE	13-4
13.3	IBOX DISPATCH RAM (IDRAM)	13-10
13.3.1	IDRAM Address Generation	13-11
13.3.2	IDRAM Microword	13-12
13.4	IBUFFER AND OPCODE TESTPOINTS	13-15
CHAPTER 14	MBOX	
14.1	MBOX MODULES	14-2
14.2	MBOX MICROCODE	14-7
14.3	MBOX MFORK ENTRIES	14-17
14.4	MBOX CYCLE CONDITION CODE MICROWORD	14-18
14.5	MBOX REGISTERS	14-22
14.6	ABUS INTERFACE	14-27
14.7	ABUS INTERFACE SIGNALS	14-31
14.8	MBOX TESTPOINTS	14-34
14.8.1	MBox MicroPC and ABUS Control Testpoints	14-35
14.8.2	ABus/SBIA Testpoints	14-35
14.8.3	CP Port Testpoints	14-36

CHAPTER 15	SBIA	
15.1	SBIA GENERAL INFORMATION	15-1
15.2	SBIA JUMPER SETTINGS	15-1
15.3	SBIA BLOCK DIAGRAM	15-2
15.4	VAX 86XX PHYSICAL MEMORY ADDRESS ALLOCATION	15-3
15.4.1	SBIA Register Addresses	15-5
15.5	SBI PROTOCOL	15-6
15.6	SBI -- I/O BACKPLANE INTERCONNECTIONS	15-10
15.7	SBI FAULT DEFINITIONS	15-14
15.8	SBI CONFIRMATION AND FAULT DECISION FLOW	15-14
CHAPTER 16	SBI	
16.1	SBI NEXUS ADDRESS INFORMATION	16-1
16.1.1	SBI Nexus Addressing	16-1
16.1.2	SBI Nexus Address Generation	16-1
16.1.3	SBI Nexus Interrupt Vector Generation	16-2
16.2	CI780	16-3
16.2.1	CI780 Backplane Jumper Settings	16-7
16.3	DR780	16-10
16.4	DW780	16-17
16.4.1	DW780 Jumper Settings	16-21
16.4.2	UDA 50 Module Utilization	16-23
16.4.3	Unibus Signals	16-24
16.4.4	Unibus Address to VAX Physical Address Conversion	16-28
16.4.5	VAX Physical Address (Hex) to Unibus Address (Octal) Conversion	16-28
16.4.6	DW780 Unibus Device Addresses	16-29
16.5	RH780	16-31
16.5.1	MAP Register Address Calculation	16-35
16.5.2	MASSBUS Register Address Calculation	16-35
CHAPTER 17	REVISION CONTROL	
17.1	VAX 8600/8650 REVISION INFORMATION	17-1
CHAPTER 18	REMOVAL AND REPLACEMENT PROCEDURES	
18.1	GENERAL	18-1
18.2	FRU PART NUMBERS	18-2
18.3	FRONT END CABINET ASSEMBLY	18-2
18.3.1	Preliminary Steps	18-3
18.3.2	Front End Cabinet Disconnection	18-5
18.3.3	Constant Voltage Transformer (CVT) Assembly Removal	18-5
18.3.4	RL02 Disk Drive Removal and Installation	18-6
18.3.4.1	RL02 Disk Drive Removal	18-6
18.3.4.2	RL02 Disk Drive Installation	18-8
18.3.5	Ball-A Unit Assembly Removal and Installation	18-12
18.3.5.1	Ball-A Unit Assembly Removal	18-12
18.3.5.2	Ball-A Unit Assembly Replacement	18-15
18.3.6	H7140 Power Supply Removal	18-15
18.3.7	Fan Panel Assembly Removal (50 Hz system)	18-19
18.3.8	Front Door Filter Removal	18-20
18.3.9	Rear Door Filter Removal	18-21
18.4	CPU CABINET ASSEMBLY	18-22
18.4.1	Preliminary Steps	18-22

18.4.2	Centrifugal 1500 CFM Blower Removal . .	18-23
18.4.3	Modular Power Supply Removal	18-26
18.4.4	CPU Module Replacement	18-27
18.4.5	Array Modules	18-29
18.4.6	Air Filter Removal	18-29
18.4.7	Air Flow Sensor Removal and Installation	18-30
18.4.7.1	Air Flow Sensor Removal	18-30
18.4.7.2	Air Flow Sensor Installation	18-30
18.4.8	Air Temperature Sensor Replacement . . .	18-30
18.4.8.1	Temperature Sensor Removal	18-30
18.4.8.2	Temperature Sensor Installation	18-30
18.4.9	876-A Power Controller Removal	18-32
18.4.10	H7231 BBU Power Supply Removal	18-34
18.5	MODULE PADDLE CONNECTOR CLEANING PROCEDURE	18-36
18.5.1	Introduction	18-36
18.5.2	Required Materials	18-36
18.5.3	Precautions	18-36
18.5.4	Cleaning Procedure	18-37

CHAPTER 19 TECHNOLOGY AND TOOLS

19.1	MCA DESCRIPTIONS, LOCATIONS, AND PRINT SET	
	CROSS REFERENCE	19-1
19.2	ECL TROUBLESHOOTING INFORMATION	19-6
19.2.1	Test Equipment	19-6
19.2.2	Termination	19-6
19.2.2.1	Single-ended ECL Signal Run	19-6
19.2.2.2	Bi-directional ECL Signal Run	19-6
19.2.2.3	Termination Components	19-7
19.2.2.4	How to Locate the Termination Point of a Given Signal	19-7
19.2.3	Troubleshooting ECL Signals	19-10

CHAPTER 20 VAX 8600/8650 REGISTER DESCRIPTION

EXAMPLES

6-1	End of Pass Report	6-23
7-1	Power consumption for the DMF32	7-13
9-1	Set Terminal Command	9-23
10-1	Help on Console Commands	10-2
10-2	LOAD/ECS KA8650	10-5
10-3	SET CLOCK	10-9
10-4	SET SOMM/ECS ON	10-11
10-5	SHOW SNAP1.DAT/ASCII	10-11
10-6	X command examples	10-14
10-7	CLEAR BREAK	10-23
10-8	DEPOSIT	10-24
10-9	DEPOSIT CSPE	10-27
10-10	DEPOSIT MARK	10-27
10-11	EXAMINE CONTROL STORE	10-28
10-12	EXAMINE/CHANNEL	10-29
10-13	EXAMINE/SDB	10-30
10-14	SET BREAK	10-32
10-15	SHOW DEFINE	10-33
10-16	SHOW NAME	10-33
10-17	TRACE ADD	10-35
10-18	TRACE DEFINE	10-36
10-19	TRACE DELETE	10-36
10-20	TRACE REMOVE	10-36

11-1	Determining which CSM overlay was loaded	11-25
13-1	Generating IDRAM Addresses	13-11
16-1	Nexus Address Calculation	16-2
16-2	Interrupt Vector generation	16-3
16-3	Conversion from Unibus address to VAX physical address	16-28
16-4	Calculating a physical byte address	16-35
19-1	Off Module Termination	19-9
19-2	Extract from CPU Backplane Wirelist BL-sort (70-19198)	19-9

FIGURES

2-1	Ball-AL Module Utilization as used in VAX 8600/8650	2-1
2-2	CPU Cabinet Cage Module Utilization	2-4
2-3	CPU, ABUS, and Memory Backplane Components - Side View	2-5
2-4	I/O Backplane Pin Numbering Scheme	2-6
2-5	Cabinet Cage Backplane (Sheet 1 of 2)	2-7
3-1	Power System Components	3-1
3-2	Power Shutdown Sequence	3-5
3-3	Power System Interconnect Diagram, Front End Cabinet	3-6
3-4	Power System Interconnect Diagram Power Controller	3-7
3-5	MPS Voltage Measurements	3-12
3-6	Module Power Connections	3-13
3-7	H7170-A Power Supply - Visual Indicators	3-15
3-8	H7180-A Power Supply	3-16
3-9	H7186-A (H7187-A) Power Supply	3-17
3-10	H7188-A EMM Module Visual Indications	3-18
3-11	EMM Module - Detailed Block Diagram	3-21
3-12	H7140-CA Power Interconnection Diagram	3-23
4-1	Boot Sequence Time Line Flow	4-2
4-2	AC Input Module (K and L) Troubleshooting Flow	4-5
4-3	Clock Module Key Fault LEDs	4-6
4-4	Parallel Key Loop Fault Troubleshooting Flow	4-8
4-5	Parallel Key Loop Circuit	4-9
4-6	Serial Key Loop Fault Troubleshooting Flow	4-10
4-7	CPU Key Fault Troubleshooting Flow	4-11
4-8	CPU Serial Key Loop Circuit	4-12
4-9	FBox Serial Key Loop Circuit	4-13
4-10	IOA Serial Key Loop Circuit	4-14
4-11	Regulator A (+5 Vdc) Initialization Troubleshooting Flow	4-15
4-12	Console Initialization and Self Test (1-10) Troubleshooting Flow	4-16
4-13	Console Self Test (11-35) Troubleshooting Flow	4-17
4-14	Console QBus (RL02) Troubleshooting Flow (Sheet 1 of 2)	4-18
5-1	System Fault Isolation - Functional Block Diagram	5-2
5-2	Console Snapshot File Information Flow Chart	5-5
5-3	Control Store Parity Error Simplified Flow Chart	5-8
7-1	System Block Diagram	7-2
7-2	CPU Block Diagram	7-3
7-3	Kernel System - Front View	7-9

7-4	CPU Cabinet - Front View	7-10
7-5	Ball-AL Front End Cabinet	7-12
7-6	Ball-AL/AM Backplane Diagram	7-13
7-7	UNIBUS Expansion Configurations	7-15
8-1	Clock Distribution System, L0217 Rev. C5	8-3
8-2	Clock Distribution System, L0231/L0217 Rev. E	8-3
8-3	L0217 Rev. C5 Block Diagram	8-4
8-4	L0231/L0217 Rev. E Block Diagram	8-6
8-5	Backplane Clock Distribution	8-8
8-6	Clock Control Logic, CLC MCA	8-10
9-1	Console Interconnect Block Diagram	9-1
9-2	System Control Panel Switches and LEDs	9-2
9-3	CBus Block Diagram	9-7
9-4	QBus Interconnect Block Diagram	9-8
9-5	SDB Interface	9-11
9-6	SDB ID Format	9-16
9-7	DF112-AA Switchpack Locations	9-21
9-8	KA86 Line Distribution Panel	9-21
9-9	DF112 Modem	9-22
9-10	Console Remote Port Control Flowchart	9-24
10-1	Console Software Modes	10-1
10-2	Console Mode Contexts	10-1
11-1	EBox Modules Block Diagram	11-2
11-2	WBus Data Path (Sheet 1 of 2)	11-4
11-3	WBus Physical Distribution	11-6
11-4	EBox Control Store Microword Worksheet	11-10
11-5	EBox Microword <91:80>	11-11
11-6	EBox Microword <79:64>	11-12
11-7	EBox Microword <63:48>	11-14
11-8	EBox Microword <47:32>	11-16
11-9	EBox Microword <31:16>	11-17
11-10	EBox Microword <15:00>	11-18
11-11	EBox Context (CTX) Microword Worksheet	11-19
11-12	MCF Microword Worksheet	11-19
12-1	FBox Basic Block Diagram	12-1
12-2	FBox Block Diagram	12-2
12-3	FBox Interface	12-3
12-4	FBox Adder Microcode Worksheet	12-4
12-5	FBA Microword <47:32>	12-4
12-6	FBA Microword <31:16>	12-6
12-7	FBA Microword <15:00>	12-9
12-8	FBox Multiplier Microcode Worksheet	12-10
12-9	FBM Microword <39:32>	12-11
12-10	FBM Microword <31:16>	12-12
12-11	FBM Microword <15:00>	12-14
12-12	FBox Dispatch RAM (FDRAM) Microword	12-15
13-1	IBox Module Block Diagram	13-2
13-2	IBox Data Paths Block Diagram	13-3
13-3	IBox Microword Worksheet	13-4
13-4	IBox Microword <50:48>	13-4
13-5	IBox Microword <47:32>	13-5
13-6	IBox Microword <31:16>	13-7
13-7	IBox Microword <15:00>	13-9
13-8	IDRAM Microword Worksheet	13-10
13-9	IDRAM Microword <19:16>	13-12
13-10	IDRAM Microword <15:00>	13-12
13-11	Fork Addresses Generation	13-13
14-1	MBox Physical Organization	14-2
14-2	MBox Address Path Block Diagram	14-3
14-3	MBox Data Path Block Diagram	14-4
14-4	MBox Interface Block Diagram	14-5
14-5	MBox Error Reporting Block Diagram	14-6
14-6	MBox Control Store Microword Worksheet	14-7

14-7	MBox Microword <79:64>	14-8
14-8	MBox Microword <63:48>	14-9
14-9	MBox Microword <47:32>	14-11
14-10	MBox Microword <31:16>	14-14
14-11	MBox Microword <15:00>	14-16
14-12	MBox Cycle Condition Code Microword Worksheet	14-18
14-13	MBox Cycle Condition Code Microword <31:16>	14-18
14-14	MBox Cycle Condition Code Microword <15:00>	14-19
14-15	MBox Register Read/Write Data Paths	14-22
14-16	MAP Module MBox Registers	14-23
14-17	MCC Module MBox Registers	14-23
14-18	MCD Module MBox Registers	14-24
14-19	EBox Microcode Assembly of MBox Registers	14-25
14-20	Physical Address Memory Map	14-26
14-21	ABus Interface Block Diagram	14-27
14-22	ABus CPU Command/Address Cycle Format	14-28
14-23	ABus DMA Command/Address Cycle Format	14-28
14-24	ABus Read/Write Cycle Format	14-28
15-1	SBIA Block Diagram	15-2
15-2	VAX 86XX Physical Memory Address Allocation	15-3
15-3	I/O Adapter Physical Address Allocation	15-4
15-4	SBI Signal Names	15-6
15-5	SBI Command/Address Format	15-8
15-6	SBI Command Codes	15-9
15-7	SBI Parity Field Configuration	15-9
15-8	SBI Read Data Formats	15-9
15-9	SBI Write Data Format	15-10
15-10	SBI Interrupt Summary Formats	15-10
15-11	I/O Backplane Assemblies	15-11
15-12	SBI Confirmation and Fault Decision Flow	15-15
16-1	SBI Nexus Address Generation	16-2
16-2	SBI Interrupt Vector Generation	16-2
16-3	CI780 I/O Backplane Module Utilization	16-3
16-4	CI780 Block Diagram (Sheet 1 of 2)	16-4
16-5	CI780 Backplane Jumper Locations	16-6
16-6	DR780 Module Utilization	16-10
16-7	DR780 Block Diagram (Sheet 1 of 4)	16-11
16-8	DR780 Backplane Jumper Location	16-15
16-9	DW780 I/O Backplane Module Utilization	16-17
16-10	DW780 Expander Cabinet Module Utilization	16-18
16-11	DW780 Block Diagram	16-19
16-12	DW780 I/O Backplane Jumper Locations	16-20
16-13	UDA 50 Module Utilization	16-23
16-14	Unibus Signals	16-24
16-15	RH780 Module Utilization	16-31
16-16	RH780 Block Diagram (Sheet 1 of 2)	16-32
16-17	RH780 Jumper Settings	16-34
16-18	Map Register Address Calculation	16-35
16-19	MASSBUS Register Address Calculation	16-36
18-1	System Control Panel	18-3
18-2	876-A Power Controller - Front View	18-3
18-3	Front End Cabinet Cable Connections - Rear View	18-4
18-4	RL02 Disk Drive - Rear View	18-6
18-5	RL02 Disk Drive Mounted in Slides	18-7
18-6	Slide Mounting Rail and Slide	18-7
18-7	RL02 Disk Drive with Exposed Drive Logic Module	18-9
18-8	RL02 with Covers Removed	18-10
18-9	RL02 Disk Drive - Front View	18-11
18-10	Cable Clamps	18-12
18-11	Release Latch	18-13


18-12	Ball-A Installed In Slide Mount	18-13
18-13	Slide to Index Plate Mounting	18-14
18-14	Power Supply Unit, Rear Mounting Screws	18-16
18-15	Power Supply Unit Removal	18-17
18-16	Mounting Box, Power Cable Connection	18-18
18-17	Fan Panel Assembly	18-19
18-18	Front End Cabinet - Front Door Filters	18-20
18-19	Front End Cabinet - Rear Door Filters	18-21
18-20	System Control Panel	18-22
18-21	CPU Cabinet - Top Cover Removal	18-23
18-22	CPU Blower Cable Removal	18-24
18-23	CPU Blower Removal - Rear View	18-25
18-24	Modular Power Supply Removal	18-26
18-25	Module Case Ground Connection	18-27
18-26	CPU Module Access Gate	18-28
18-27	CPU Card Cage Air Filter Removal	18-29
18-28	Temperature and Air Sensor Locations	18-31
18-29	Power Controller and BBU - Rear View	18-32
18-30	Power Controller Removal	18-33
18-31	BBU Cabling	18-34
18-32	BBU Removal - Top View	18-35
18-33	Paddle Finger Cleaning Action	18-37
19-1	Single-ended ECL Signal Run	19-6
19-2	Bi-directional ECL Signal Run	19-7
19-3	STERM Termination	19-8
19-4	VTERM Termination	19-8
19-5	UMCF 4 A L Signal Generation	19-9
19-6	UMCF 4 A L Signal Termination	19-9
19-7	Typical ECL Waveform	19-10
19-8	Flowchart, ECL Signal Troubleshooting	19-11
19-9	Improper Termination: Too low	19-12
19-10	Output Shorted to -2V	19-12
19-11	Unterminated Waveform, 56 Ohm Resistor Missing	19-13
19-12	Inverted Output Shorted to - 2V	19-13
19-13	Improper Termination: Too High	19-14
19-14	Capacitor in Signal Run	19-14
19-15	Open Etch, No Connection to - 2V	19-15
19-16	Impedance Mismatch	19-15
19-17	Signal Shorted to Ground	19-16
19-18	Open Input Etch	19-16
19-19	Two Shorted Signals	19-17
19-20	Complementary Outputs Shorted Together	19-17

TABLES

6-1	EMM Self Test	6-2
6-2	EMM Error Code Descriptions	6-6
6-3	PROM Command Set	6-7
6-4	T-11 (PROM) Self Test Descriptions	6-8
6-5	Micro-Hard-Core Commands	6-18
6-6	Clock Subtests	6-20
6-7	RL02 Disk Subtests	6-21
6-8	FBox Subtests	6-21
6-9	IBox Subtests	6-21
6-10	Last Box Subtests	6-22
6-11	MBox Logic Subtests	6-22
6-12	MBox Ucode Subtests	6-22
6-13	MCF, CTX, and MISC EBox Subtests	6-22
6-14	EBox, SDB, and C/S Subtests	6-23
6-15	EBox Ucode Subtests	6-23

6-16	VAX 86xx Microdiagnostics	6-32
6-17	Standard Microdiagnostic Command Files . . .	6-33
6-18	MHC/Module Quick Verify Command Files . . .	6-33
6-19	CPU Module Quick Verify Command Files . . .	6-34
6-20	Diagnostic Supervisor Control Character Summary	6-35
6-21	Diagnostic Supervisor Command Summary . . .	6-35
6-22	Device List for ATTACH, SELECT, and DESELECT Commands	6-41
6-23	RL02 Resident VAX Macrodiagnostics	6-42
8-1	WBus Enable Signals	8-2
8-2	Clock Reset Signals	8-2
9-1	System Control Panel Indicators	9-3
9-2	System Control Panel Switch Summary	9-4
9-3	Tll Interrupt Vectors	9-5
9-4	CBus Signal Description	9-6
9-5	CBus Signal Backplane Pin Location	9-7
9-6	QBus Signal Backplane Pin Locations	9-9
9-7	QBus Signal Descriptions	9-9
9-8	SDB Interconnect Chart A - SCP Interface . .	9-11
9-9	SDB Interconnect Chart B - SDB Control Signals	9-12
9-10	SDB Interconnect Chart C - SDB Clock and Data Out Connections	9-13
9-11	SDB ID Bit Descriptions	9-16
9-12	VAX 8600 CADIF File Revision Information . .	9-18
9-13	VAX 8650 CADIF File Revision Information . .	9-19
9-14	Set Terminal Syntax and Switch Description .	9-22
10-1	Console Command Control Characters	10-2
10-2	Architecturally Defined Commands and Switches	10-3
10-3	General Commands	10-3
10-4	Default System Microcode	10-5
10-5	Console Flags	10-7
10-6	MACRO Context Commands	10-16
10-7	Supported GPR Names	10-17
10-8	Supported IPR Names	10-18
10-9	Supported IR Names	10-19
10-10	Supported Miscellaneous Register Names . .	10-19
10-11	The HEX Command Set	10-23
10-12	SDB Control Channels	10-24
10-13	Control Channel Bit Positions	10-24
10-14	SDB Channel Numbers	10-29
10-15	Names of Default Visibility Registers . . .	10-30
10-16	Default Visibility Registers	10-37
11-1	WBus Signal Pin Location	11-8
11-2	Distribution of WBus Byte Parity Signals . .	11-8
11-3	EBox GPR/Scratch Pad Usage	11-9
11-4	Context <3:0>	11-19
11-5	MCF Microword Bit Description	11-20
11-6	EBox Microtrap Vectors	11-21
11-7	EHM Fatal Error Loops	11-22
11-8	Special CSM Microaddresses	11-23
11-9	CSM Overlays	11-24
11-10	EBox Microcode Locations/Regions	11-25
11-11	EBox Micro PC Testpoints	11-26
13-1	IDRAM Address Generation	13-11
13-2	IBUFFER Testpoints	13-15
13-3	OP CODE Testpoints	13-15
14-1	MBox Branch Conditions	14-16
14-2	MBox Entries on MFORK	14-17
14-3	ABus Signal Pin Location	14-29
14-4	ABus Commands	14-31

14-5	Length/Status for CPU Command/Address Cycle	14-31
14-6	Length/Status for DMA Command/Address Cycle	14-32
14-7	Address Control of the DC022 Register File	14-33
14-8	DC022 Register File Address Control	14-33
14-9	MBox MicroPC and ABUS Control Testpoints	14-35
14-10	ABUS/SBIA Testpoints	14-35
14-11	CP Port Testpoints	14-36
15-1	SBIA DC101 TR Jumpers	15-1
15-2	SBIA Register Addresses	15-5
15-3	SBI Signal Names and Description	15-7
15-4	SBI Cable Interconnections	15-10
15-5	SBI Signal and Backplane Pins	15-12
15-6	SBI Fault Definitions	15-14
16-1	SBI Nexus Base Address	16-1
16-2	SBI Nexus Address Generation Bit Descriptions	16-2
16-3	SBI Vector Generation Bit Description	16-2
16-4	CI780 Backplane Jumpers	16-7
16-5	DR780 Backplane Jumper Settings and Wirewrap Selection	16-16
16-6	DW780 Jumper Settings	16-21
16-7	Unibus Signal Descriptions	16-24
16-8	Unibus Pin Assignments - Standard and Modified	16-27
16-9	DW780 Unibus Device Addresses	16-29
16-10	MBA Base Addresses	16-36
16-11	MASSBUS Register Offset	16-36
17-1	VAX 8600 Revision Information	17-2
17-2	VAX 8650 Revision Information	17-4
17-3	VAX 8600 Diagnostic Media Revision Information	17-6
17-4	VAX 8650 Diagnostic Media Revision Information	17-6
19-1	MCA/Print Set Cross Reference	19-1
19-2	MCA Descriptions and Locations	19-3



PREFACE

The purpose of this guide is to provide a source of operating, maintenance, programming, and troubleshooting information for the VAX 8600/8650 System that is frequently referenced by DIGITAL Field Service, Manufacturing, Training, and Engineering personnel.

The main differences between this release and the previous release are as follows.

1. The format has been changed back to one volume.
2. The manual has been updated to include the MS86-DA.
3. The CSM.STATUS register has been added to Chapter 20, Register Description.
4. EHSR <24>, MBOX TRAP TO 4, was added to correct the EHSR register.
5. The syndrome was added to the description of MDECC <14:09>.
6. MSTAT2 <26:24> was updated to include the MS86-DA.
7. Minor technical errors have been corrected.

The following paragraphs provide a brief description of the contents of each chapter.

Chapter 1 General Information

This chapter contains a list of documents, documentation ordering information, microfiche information, and related publication information.

Chapter 2 Module Utilization and Backplane Information

Chapter 2 contains module locations within the CPU cabinet, front end cabinet and other equipment cabinets.

Chapter 3 Power

This chapter contains information on module keying, the power system, and the EMM.

Chapter 4 Power-up Initialization and Bootstrap Troubleshooting Procedures

This chapter provides a description of the events that occur during power-up and the bootstrap sequence. It also includes a set of troubleshooting procedures to aid in isolating faults that may occur during power-up and the bootstrap sequence.

Chapter 5 Errors and Error Analysis

This chapter includes an overview of system fault isolation, console snapshot file information, and a simplified flowchart of console control store parity error handling. Also included is systematic information gathering procedures, a list of CSM overlays, DUMP.COM, and a program to scan for memory parity errors.

Chapter 6 Diagnostics

This chapter contains a description of the EMM and T-11 self tests, Micro Hard Core tests, Micro Diagnostics, Macro Diagnostics, PROM commands and the commands for each of the diagnostic contexts.

Chapter 7 System

This chapter contains basic system block diagrams and system configuration guidelines.

Chapter 8 Clock

This chapter contains detailed clock block diagrams and clock signal information.

Chapter 9 Console Hardware

Included in this chapter are console block diagrams, system control panel descriptions, CBus and QBus information, and information pertaining to remote diagnosis.

Chapter 10 Console Software and Commands

This chapter contains the console commands for the various console contexts other than the diagnostic contexts.

Chapter 11 EBox

This chapter includes EBox module utilization, block diagrams, signal distribution, and microcode information.

Chapter 12 FBox

This chapter includes FBox module utilization, block diagrams, and microcode information.

Chapter 13 IBox

This chapter includes IBox module utilization, block diagrams, and microcode information.

Chapter 14 MBox

Chapter 14 contains information pertaining to the MBox module utilization, block diagrams, and microcode, as well as ABus signals and protocol.

Chapter 15 SBIA and SBI

This chapter provides the SBIA and SBI module utilization, SBIA block diagrams and jumpers, and SBI signals and protocol.

Chapter 16 SBI Nexus and Internal Options

Chapter 16 contains information on the CI780, DR780, DW780, and Unibus, including jumper installation. MAP Register and Massbus register address calculations are explained.

Chapter 17 Revision Control

Chapter 17 is a reduction and lift from the revision matrix to provide various CPU backplane and module revisions.

Chapter 18 Removal and Replacement Procedures


This chapter provides FRU part numbers and removal and replacement procedures for the front end cabinet and CPU.

Chapter 19 Technology and Tools

Chapter 19 contains MCA and RAM cross reference, part number, and print set information as well as normal and abnormal ECL waveforms.

Chapter 20 Registers

This chapter contains the register bit maps and register bit descriptions.



CHAPTER 1

GENERAL INFORMATION

1.1 RELATED DOCUMENTATION

DOCUMENT TITLE	ORDER NUMBER
Ball-A Mounting Box and Power Technical Manual	EK-BALLA-TM
Ball-A Unit Assembly Illustrated Parts Breakdown (IPB)	EK-BALLA-IP
CI780 Documentation Kit	FB-CI780-00
CI780 F.S. Maintenance Print Set	MP-01267
CI780 Technical Description	EK-CI780-TD
CI780 Users Guide	EK-CI780-UG
Communications Option Mini Reference Manual	EK-CMINI-RM
DB11-A Bus Repeater Change Notice	EK-DB11A-T1
DB11-A Bus Repeater Manual	EK-DB11A-TM
DELNI ETHERNET Local Network Interconnect Manual	EK-DELNI-TM
DELNI Installation Owners Manual	EK-DELNI-IN
DELNI Local Network Interconnect (IPB)	EK-DELNI-IP
DELNI Rackmount Option Installation Guide	EK-DEXRM-IN
DEREP-AA Local ETHERNET Repeater Manual	EK-DEREP-IN
DEREP-RA Remote ETHERNET Repeater Manual	EK-DERRP-IN
DEUNA F.S. Maintenance Print Set	MP-01378-00
DEUNA Technical Manual	EK-DEUNA-TM
DEUNA Technical Manual Update	EK-DEUNA-T2
DEUNA User's Guide	EK-DEUNA-UG
DF03 Modem Family Technical Manual	EK-ODF03-TM
DF03 Modem Unit Assembly (IPB)	EK-ODF03-IP
DF03 Modem Users Guide	EK-ODF03-UG
DF112 User Guide	EK-DF112-UG
DH11 Preventive Maintenance Manual	EK-ODH11-PM
DH11 Technical Manual	EK-ODH11-TM
DH11 Users Guide	EK-ODH11-UG
DHU11 Interface User Guide	EK-DHU11-UG
DMF32 F.S. Maintenance Print Set	MP-00965-00
DMF32 Maintenance Advisory	EK-DMF32-RM
DMF32 Multi Function Change Notice	EK-DMF32-T1
DMF32 Users Guide	EK-DMF32-UG

GENERAL INFORMATION

DOCUMENT TITLE -----	ORDER NUMBER -----
DMP Synchronous Controller Technical Manual	EK-DMP32-TM
DMP11 Synchronous Controller User Guide	EK-DMP11-UG
DMR-11 Users Guide	EK-DMR11-UG
DMR11 Synchronous Controller Technical Manual	EK-DMR11-TM
DMZ32 F.S. Maintenance Print Set	MP-00999-01
DMZ32 User Guide	EK-DMZ32-UG
DMZ32 User Guide Update Notice	EK-DMZ32-U1
DR11-C General Device Interface Manual	EK-DR11C-TM
DR11-C General Device Users Manual	EK-DR11C-OP
DR11-C Preventive Maintenance Manual	EK-DR11C-PM
DR11-W Direct Memory Users Manual	EK-DR11W-UG
DR780 Documentation Kit	FB-DR780-00
DR780 F.S. Maintenance Print Set	MP-00835-00
DR780 General Purpose Technical Manual	EK-DR780-TD
DR780 General Purpose Users Guide	EK-DR780-UG
DUP11 Bit Synchronous User Change Guide	EK-DUP11-01
DUP11 Bit Synchronous Change Notice	EK-DUP11-M1
DUP11 Interface Users Manual	EK-DUP11-OP
DUP11 Maintenance Manual	EK-DUP11-MM
DW780 Documentation Kit	EK-DW780-00
DW780 Field Service Maintenance Print Set (FSMPS)	MP-00497-00
DW780 Technical Description Manual	EK-DW780-TD
DZ11 Asynch MX Technical Manual	EK-DZ110-TM
DZ11 Users Guide	EK-DZ110-UG
DZ32 Asynchronous Multiplexer Change Sheet	EK-OD232-T1
DZ32 Asynchronous User Change Notice	EK-OD232-U1
DZ32 Technical Manual	EK-OD232-TM
ETHERNET Communications Server Installation Guide	EK-DECSA-IN
ETHERNET Installation Guide	EK-ETHER-IN
ETHERNET Operation and Maintenance	EK-DECSA-OP
ETHERNET Port Tester Technical Manual	EK-DEPTS-TM
ETHERNET Repeater Technical Manual	EK-DEREP-TM
H4000 ETHERNET Transceiver Installation Manual	EK-H4000-IN
H4000 DEC ETHERNET TRANSCEIVER Technical Manual	EK-H4000-TM
H9640 Series Cabinets Users Guide	EK-H9640-UG
HSC50 Field Service Maintenance Print Set (FSMPS)	MP-01422-00
HSC50 Installation Manual	EK-HSC50-IN
HSC50 Maintenance Guide	AA-P672A-TK
HSC50 Service Manual	EK-HSC50-SV
Introduction to VAX/VMS for Field Service Workbook	EY-DE163-WB
VAX 8600/8650 System Description and Processor Overview	EK-KA86S-TD
VAX 8600/8650 System Power Technical Description	EK-KA86P-TD
VAX 8600/8650 Console Technical Description	EK-KA86C-TD
VAX 8600/8650 EMM Technical Description	EK-KA86V-TD
VAX 8600/8650 System Clocks Technical Description	EK-KA86K-TD
VAX 8600/8650 MBox/Memory Technical Description	EK-KA86M-TD

DOCUMENT TITLE -----	ORDER NUMBER -----
VAX 8600/8650 IBox Technical Description	EK-KA86I-TD
VAX 8600/8650 EBox Technical Description	EK-KA86E-TD
VAX 8600/8650 FBox Technical Description	EK-FP86X-TD
VAX 8600/8650 SBIA Technical Description	EK-DB86X-TD
VAX 8600/8650 System Diagnostics User's Guide	EK-KA86D-UG*
VAX 8600 Console Commands Reference Card	EK-KA86D-RC*
VAX 8600/8650 System Hardware User's Guide	EK-8600H-UG
VAX 8600/8650 System Maintenance Guide	EK-86XVI-MG*
VAX 8600/8650 System Installation Manual	EK-8600I-IN
VAX 8600/8650 System Fault Isolation Manual	EK-8600S-MM*
VAX 8600/8650 Field Service Maintenance Print Set	MP-01714-00*
VAX 8600/8650 Customer Print Set	MP-01714-01
VAX 8650 Field Service 8650 Upgrade Print Set	MP-01990-01*
VAX 8650 Customer 8650 Upgrade Print Set	MP-01990-02
VAX 8600/8650 Illustrated Parts Breakdown (IPB)	EK-VENUS-IP
VAX 8600/8650 Advanced Maintenance Course	EY-1402E-001
VAX 8600/8650 Instructor Guide Package	EY-1402E-LA
VAX 8600/8650 Instructor Guide	EY-1402E-IG
VAX 8600/8650 Transparency Masters	EY-1402E-01
VAX 8600/8650 Answer Sheet/Solutions	EY-1402E-TA
VAX 8600/8650 Student Guide Package	EY-1402E-LS
VAX 8600/8650 Student Guide	EY-1402E-SG
KMS-11BD/BE Synchronous Comm Processor User Guide	EK-KMSBE-UG
KMS11 Synchronous Communication Proc Service Guide	EK-KMS11-PS
KMS11-P Synch Comm Processor Installation Manual	EK-KMSIP-IN
KMS11-P Synchronous Comm Proc Technical Manual	EK-KMSIP-TM
LA100 Head Lift Kit Installation Manual	EK-L10FF-IN
LA100 Programmer Reference Manual	EK-LA100-RM
LA100 Series Pocket Service Guide	EK-LA100-PS
LA100 Letter/Writer Letter Printer (IPB)	EK-LA100-IP
LA100 Series Technical Manual	EK-LA100-TM
LA12 DECwriter Correspondent (IPB)	EK-CPL12-IP
LA12-CA/LA12X-CB Installation Guide	EK-L12CA-IN
LN01 Electronic Printer Functional Description	EK-LN01S-TD
LN01 Electronic Printer Inst Guide	EK-LN01S-IN
LN01 Electronic Printer Oper Flip Card	EK-LN01S-RC
LN01 Electronic Printer Operator Guide	EK-LN01S-OP
LN01 Programmer Reference Manual	EK-LN01S-RM
LN01S Electronic Printer Documentation Pkg	EK-LN100-UG
LP11/LA11 Line Printer Manual	EK-OLP11-TM
LP11/LS11/LA11 Line Printer Manual	EK-1LP11-TM
LP11/LS/LA11 Line Printer Users Guide	EK-LP11S-OP
LP27 Line Printer Installation Manual	EK-OLP27-IN
LP27 Line Printer Technical Manual	EK-OLP27-TM
LP27 Line Printer Users Guide	EK-OLP27-UG
LP27 Pocket Service Guide	EK-OLP27-PS
LP27 Users Guide Update	EK-OLP27-U1
LPAll-K Lab Installation and Maintenance Guide	EK-LPA11-IN
LPAll-K Users Guide	EK-LPA11-UG

GENERAL INFORMATION

DOCUMENT TITLE

ORDER NUMBER

LXY12/LXY22 Impact Printer/Plotter Install Guide	EK-LXY22-IN
LXY12/LXY22 Impact Printer/Plotter User Guide	EK-LXY22-UG
PCL11-1 System Options Pocket Guide	EK-PCL1B-PS
PCL11-B Installation Manual	EK-PCL1B-IN
PCL11-B Technical Manual	EK-PCL1B-TM
PDP-11 Bus Handbook	EB-17525-20
RA60 Disk Drive Illustrated Parts Breakdown (IPB)	EK-ORA60-IP
RA60 Disk Drive Service Manual	EK-ORA60-SV
RA60 Disk Drive Technical Change Notice	EK-ORA60-U1
RA60 Disk Drive Users Guide	EK-ORA60-UG
RA60 Field Service Maintenance Print Set (FSMPS)	MP-01421-00
RA60 Maintenance Guide	AA-M880A-TC
RA60 Safety Manual	EK-ORA60-HB
RA60 Subsystem Fault Isolation Guide	EK-ORA60-FG
RA60 Tech Doc Change Notice	EK-ORA60-S1
RA80 Disk Drive Change Notice	EK-ORA80-U1
RA80 Disk Drive Service Manual	EK-ORA80-SV
RA80 Disk Drive User Guide	EK-ORA80-UG
RA80/RUA80 Disk Drive Illustrated Parts Breakdown (IPB)	EK-ORA80-IP
RA81 Customer Equip Care	EK-ORA81-EC*
RA81 Disk Drive Illustrated Parts Breakdown (IPB)	EK-ORA81-IP
RA81 Disk Drive Service Manual	EK-ORA81-SV
RA81 Disk Drive User Guide	EK-ORA81-UG
RA81 Field Service Maintenance Print Set (FSMPS)	MP-01359-00
RA81 Documentation Guide	AA-M879A-TC
RH780 Documentation Kit	FB-RH780-00
RH780 Technical Description Manual	EK-RH780-TD
RL01/02 P.M. Worksheet	EK-RL012-WS*
RL01/02 Pocket Service Guide	EK-RL012-PG
RL01/02 Users Guide	EK-RL012-UG
RL01/02 Technical Manual Vol 1	EK-RL121-TM
RL01/02 Technical Manual Vol 2	EK-RL122-TM
RL02 Disk Drive Illustrated Parts Breakdown (IPB)	EK-ORL02-IP
RL02 Documentation Kit	FB-RL02-00
RL11 Controller Technical Description	EK-ORL11-TD
RM05 Disk Drive Illustrated Parts Breakdown (IPB)	EK-ORM05-IP
RM05 Disk Drive Maint Manual	EK-ORM05-EC*
RM05 Disk Drive Service Manual	EK-ORM05-SV
RM05 Disk Subsystem Users Guide	EK-ORM05-UG
RM05 Fault Isolation Guide	EK-ORM05-FG
RM05 P.M. Worksheet	EK-ORM05-WS*
RP07 Documentation Kit	FB-RP07-00
RP07 Disk Drive Customer Equip Care	EK-ORP07-EC*
RP07 Disk Drive P.M. Worksheet	EK-ORP07-WS*
RP07 Field Maintenance Print Set #1	EK-ORP07-MP
RP07 Illustrated Parts Breakdown	EK-ORP07-IF
RP07 Microcode Listing	EK-ORP07-ML
RP07 Pocket Service Guide	EK-ORP07-PS
RP07 Service Manual	EK-ORP07-SV
RP07 Technical Description Manual	EK-ORP07-TD
RP07 Users Guide And Addendum	EK-ORP07-UG
RP07 Error Codes Troubleshooting Manual	EK-ORP07-HR

DOCUMENT TITLE	ORDER NUMBER
SC008 Star Coupler Users Guide	EK-SC008-UG
TA78 Magnetic Tape Drive Manual	EK-OTA78-SV
TA78 Magnetic Tape Drive User Guide	EK-OTA78-UG
TA78 Upgrade Procedure	EK-TA78U-IN
TE16 DEC Magtape Illustrated Parts Breakdown (IPB)	EK-OTE16-IP
TE16 Pocket Service Guide	EK-OTE16-PS
TE16/TE10W/TE10N Equipment Care	EK-OTE16-EC*
TE16/TE10W/TE10N Maintenance Manual	EK-OTE16-TM
TE16/TE10W/TE10N User Change Notice	EK-OTEWN-01
TE16/TE10W/TE10N Users Manual	EK-OTEWN-OP
TM02 Formatter Illustrated Parts Breakdown (IPB)	EK-OTM02-IP
TM78 Magnetic Tape Formatter Tech	EK-OTM78-TM
TU77 Documentation Kit	FB-TU77-00
TU77/78 P.M. Worksheet	EK-TU778-WS*
TU77/78 Magnetic Tape Transport Equip Care	EK-TU778-EC
TU77 Magnetic Tape Transport Tech Manual V1	EK-1TU77-TM
TU77 Magnetic Tape Transport (IPB)	EK-OTU77-IP
TU77 Magnetic Tape Transport Tech Manual V2	EK-2TU77-TM
TU77 Magnetic Tape Transport Users Guide	EK-OTU77-UG
TU77 Subsystem Pocket Service Guide	EK-OTU77-PS
TU78 Documentation Kit	FB-TU78-00
TU78 Magnetic Tape Transport Addendum	ED-2TU78-T2
TU78 Magnetic Tape Transport Tech Manual V1	EK-1TU78-TM
TU78 Magnetic Tape Transport Users Guide	EK-OTU78-UG
TU78 Magnetic Tape Transport Tech Manual V2	EK-2TU78-TM
TU78 Subsystem Pocket Service Guide	EK-OTU78-PS
TU78/TM78 Mag Tape Transport (IPB)	EK-OTU78-IP
TU80 Tape Drive Illustrated Parts Breakdown (IPB)	EK-OTU80-IP
TU80 Pocket Service Guide	EK-OTU80-PS
TU80 Subsystem Users Guide	EK-OTO80-UG
TU80 Tape Subsys Technical Manual	EK-OTO80-TM
TU81 Mag. Tape PS Guide	EK-OTU81-PS
TU81/TA81 Pathfinder	EK-TUA81-SV
TU81/TA81 Tape Subsys User Guide	EK-TUA81-UG
UDA50 Field Service Maintenance Print Set (FSMPS)	MP-01331-00
UDA50 Programmer's Documentation Kit	QP905-GZ
UDA50 Maintenance Guide	AA-M185B-TC
UDA50 Service Manual	EK-UDA50-SV
UDA50 User Guide	EK-UDA50-UG
VAX Architecture Handbook	EB-19580-20
VAX Hardware Handbook	EB-21710-20
VAX Software Handbook	EB-21812-20
VAX Maintenance Handbook, VAX Systems	EK-VAXV1-HB
VAX Maintenance Handbook, VAX-11/750	
VAX Maintenance Handbook, VAX-11/780	EK-VAXV2-HB
VAX11 Programming Card	AV-D827C-TE
VAX-11 Architecture Reference Manual	EK-VAXAR-RM

GENERAL INFORMATION

DOCUMENT TITLE

ORDER NUMBER

VAX/VMS Document Set
VAX/VMS Guides
VAX/VMS Quick Reference Guides
VAX/VMS Reference Shelf
VAX/VMS Internals and Data Structures
VAX/VMS License with Warranty (Includes VAX
8600/8650 Software Installation Guide)

QL001-GZ
QLY1-GZ
QLY2-GZ
QLZ0-GZ
Digital Press
QK001-UZ

NOTES

1. IPB means Illustrated Parts Breakdown
2. An asterisk (*) denotes for Field Service use only.

1.2 LITERATURE ORDERING INFORMATION

PREFERRED METHOD:

Use Form: EN-01878-05, Request for Literature/Technical Documents

Mail to:

Interdepartmental Mail: NR03/W03, P&CS Order Processing.

US Mail: Digital Equipment Corporation
10 Forbes Road
Northboro, MA 01532
Attn: PCS Order Processing

ALTERNATE METHODS

Required Information: All requests submitted on other than the standard form must contain the following information:

Name:
Badge Number:
Cost Center: (3-letter code)
Location: (mailstop)
Ship To Information: (if different from requisitioners location)

Please Use the Following Format:

Item	Quantity	Publication #	Title/Description
1.	50	EK-KS10L-MM	Maintenance Manual
2.	100	EN0-1245B-05	Medical Log Form
3.	25	EA-90724-18	Promotional Flyer

TWX: Use RCS Code NR12; also applicable to Europe

Send to:

Interdepartmental Mail: NR03/W03, P&CS Order Processing.

US Mail: Digital Equipment Corporation
10 Forbes Road
Northboro, MA 01532
Attn: P&CS Order Processing

LOS (LITERATURE ORDER SYSTEM): LOS Requires an account on the system. Call DTN 234-4208 or DTN 234-4429 to request an account.

The literature warehoused in Northboro is 'owned' by material sponsors associated with various product lines. Sponsors may place quantity limitations or other restrictions on their literature. You should contact the literature controllers for approval of all items which fall within the restrictions. This approval, with the controller's name, must be noted on the order submitted to Order Processing.

Restriction Codes:

1. L - A maximum quantity to be shipped per item has been set by the literature controller.
2. H - Item is currently on hold and the item ordered must be approved by the literature controller (see literature contact list for appropriate person).
3. B - No backorders will be taken on this literature.

INQUIRY SERVICE

To inquire if the desired literature is in stock before ordering, call DTN 234-4325.

1.3 SOFTWARE AND DIAGNOSTIC ORDERING INFORMATION

Use Form: EN-01740-07, Internal Software Order

Mail To:

Interdepartmental Mail: WM0, Software Distribution
Center

US Mail: Digital Equipment Corporation
Software Distribution Center
1 Digital Drive
Westminster, MA 01473

Diagnostic Updates: To be placed on automatic distribution for VAX diagnostic updates, contact:

Colorado Springs - DTN 522-5050, or
1-800-525-6570
European Locations - Contact IDS

GENERAL INFORMATION

Be prepared to furnish the following information:

Name
Badge Number
Cost Center
Address/Location
Diagnostic Media Type (or part number)

1.4 FIELD SERVICE MICROFICHE LIBRARY

There are four Field Service Microfiche libraries: LCG, KS10, PDP11/PDP8, and VAX. Each library contains information for each product within the group. This information includes hardware manuals, IPBs, PM Procedures, Diagnostic Listings, ECO/FCO information, TECH TIPS, wirelists and assembly data. Each library is maintained via quarterly updates and weekly SPEED BULLETIN distributions.

For additional information on these libraries, contact your local branch microfiche librarian or contact:

ESD&P Micropublishing
Information Management and Publishing
Digital Equipment Corporation
30 North Avenue
Burlington, MA 01803

Location code: FPO/B5
DTN: 283-6281
Outside line: (617)273-6281
ENET node: RAINBW::

1.5 RELATED INFORMATION DISTRIBUTION

Being the most complex system Digital has produced yet, the VAX 8600/8650 requires a more complete Information Distribution System than was in place before.

In addition to using all existing communication channels, we have decided to heavily use SID and the NOTES facility to allow for fast and efficient distribution of system related information.

SID lends itself towards fast, symptom based search of a Database scheduled to contain complete information on currently known 8600 related Problems, Fixes, Hints, Revision information, etc.. It will also contain copies of the distribution lists used to distribute system info to allow for timely and accurate update.

Should you feel that your Regional SID database might not contain the most current information towards the problem you are currently working on, then you may use the captive SID account on ENET node MENTOR: Username: SID Password: VENUS.

NOTES will serve as an interactive communications channel between all 8600 interested groups within Digital. The Venus CSSE group will monitor MENTOR::SYS\$NOTES: and work to resolve any upcoming issues.

Both these systems require that you can get access to the ENET, which seems desirable anyways. We assume that all Support functions do have access, so everybody should be able to get to the information.

As both systems contain HIGHLY CONFIDENTIAL information, we have to control all surrounding security issues. Accordingly you must not allow Customers any access to information published in there. Also, some entries in SID will only be readable by privileged users (Regional Support).

We encourage any feedback to MENTOR::POPIENIUICK

1.6 VAX STUFF PUBLICATION

VAX STUFF is an information newsletter published monthly by Customer Services Systems Engineering (CSSE). The document contains articles pertinent to all 32-bit VAX systems and peripherals from MicroVAX through the high end VAXs. VAX STUFF is available on microfiche in SPEED BULLETINS under the MISCELLANEOUS section and is also available in hardcopy.

Any Digital Employee (700 and 800 Cost Centers only) wishing to be added/deleted to the VAX STUFF distribution list must submit a memo, TWX, or electronic mail to:


Jutta Josbaecher
OG01-2/F16
DTN: 276-8950
Outside: (617)496-8950
TWX code: OGO
Enet: COIN::JOSBAECHER

Your memo should include the following information:

- your name
- your badge number
- cost center
- location code
- ENET node (if applicable)
- whether or not you wish to be added or deleted from the distribution list

Any articles which you feel should appear in VAX STUFF may be submitted to:

VAX STUFF Editorial Office
c/o Jutta Josbaecher
OG01-2/F16
DTN: 276-8950
TWX CODE: OGO
ENET node: COIN::JOSBAECHER



MODULE UTILIZATION AND BACKPLANE INFORMATION



Figure 2-1 BALL-AL Module Utilization as used in
VAX 8600/8650 Front-end Cabinet

MODULE UTILIZATION AND BACKPLANE INFORMATION

2.1 VAX 8600/8650 BALL MODULE UTILIZATION

1. The standard UNIBUS configuration installed in the front end cabinet, Ball expansion drawer, is as follows:

Qty	Option	Unibus Address	Vector	Module(s)
1	DMF32	760340	300	M8396
4	DMZ32	760540	340	M8398
		760600	370	
		760640	420	
		760700	450	
1	DEUNA	774510	120	M7792,M7793

2. The standard UNIBUS configuration listed above is included as part of every VAX 8600/8650 system. Due to environmental considerations (air flow and power supply load) this is the maximum allowable configuration on this UNIBUS. DO NOT EXPAND THE CONFIGURATION BEYOND THE STANDARD.
3. For additional configuration information, refer to Chapter 7, System Configurations Guidelines.
4. All unused UNIBUS slots have a G727 Grant Continuity module installed in row D.
5. All unused UNIBUS slots have an NPR jumper wired on the backplane from pin CA1 - CB1. Note that in the case of the DEUNA, the NPR jumper is removed from slot 4 (M7792) but installed in slot 5 (M7793).
6. Note that this BALL expansion drawer contains two separate buses: the Console QBus for the RL subsystem and a UNIBUS for the first DW780.
7. For power distribution information, refer to Chapter 3, H7140-CA Power Distribution.
8. For QBus cabling information, refer to Chapter 9, QBus Interconnect.
9. For DW780/UNIBUS cabling information refer to Chapter 16, SBI NEXUS AND INTERNAL OPTIONS and to the VAX 8600/8650 Installation Manual.
10. For UNIBUS Option information (DEUNA, DMF32, and DMZ32) refer to the VAX 8600/8650 Installation Manual and to the appropriate DEVICE manual (see Chapter 1 for a list of related documents).

2.2 VAX 8600/8650 MEMORY ARRAY MODULE CONFIGURATIONS

The following guidelines should be used to configure the VAX 8600/8650 Memory Subsystem. The memory modules used include the following:

Option Designation	Module Number	Revision Information	Module Capacity	Used On		Note
				8600	8650	
MS86-A	L0226	any	4 MBytes	xx	xx	
MS86-B	L0200	C1 and lower	4 MBytes	xx		
MS86-B	L0200	D1 and higher	4 MBytes	xx	xx	
MS86-C	L0225	any	16 MBytes	xx	xx	2
MS86-D	L0235	any	64 MBytes	xx	xx	3
N/A	L9200		N/A	xx	xx	4


NOTES

1. With the exception of the L0200 (Rev C1 and lower) Module all modules can be used interchangeably in either a VAX 8600 or VAX 8650 System.
2. The MS86-C is comprised of an L0225 mother board and 8 daughter boards (PN 54-16500-AA or 54-16500-BA). Each L0225 plugs into one slot on the backplane; however, each L0225 will occupy two slots.
3. The MS86-D is comprised of an L0235 mother board and 4 daughter boards (PN 54-17052-AA). Each L0235 plugs into one slot on the backplane; however, each L0235 will occupy two slots.
4. The L9200 Memory Backplane Module is used to balance power regulator loading.

Configuration Rules:

1. Populate the Memory Backplane in ascending order beginning with slot 1.
2. Install larger capacity memory boards first, installing 64 MByte modules and 16 MByte modules before 4 MByte Modules.
3. Follow the "Used On" column in the table above.
4. Install L9200 Memory Load Modules in slots 5 and 8 unless these slots are occupied by an Array Module.
5. Always install an L0222 Memory Terminator Module in slot 9 of the Memory Backplane.

2.3 CABINET CAGE MODULE UTILIZATION




5. FB86-AA - FLOATING POINT OPTION.
- IF THE FB0X OPTION IS NOT USED, INSTALL FTM AND FJM.
6. DB86-AA - SECOND SBA OPTION.
7. DWO AND DW1 HAVE EXTERNAL UNIBUS.
8. RB96-AA - VAX 9600 IDTC CONTROLLER.

NOTES:

1. VIEW FROM MODULE INSERTION SIDE.
2. MODELS SHOWN IN PARENTHESIS I ARE OPTIONAL, AND ARE SHOWN FOR CLARIFICATION ONLY.
3. MS86 MEMORY:
 $a = L0200/L0216/L0225/L0235$
 $b = L0200/L0226$
4. CPU BACKPLANE:
L0220, L0231 FOR VAX 8600
L0220, L0231 FOR VAX 8650

Figure 2-2 CPU Cabinet Cage Module Utilization

2.4 CPU, ABUS, AND MEMORY BACKPLANE COMPONENTS AND PIN NUMBERING SCHEME




MR-16600

Figure 2-3 CPU, ABUS, and Memory Backplane Components - Side View

MODULE UTILIZATION AND BACKPLANE INFORMATION

2.5 I/O BACKPLANE COMPONENTS AND PIN NUMBERING SCHEME




MR-15599

Figure 2-4 I/O Backplane Pin Numbering Scheme


2.6 CABINET CAGE BACKPLANE - REAR VIEW

Note: See backplane interconnect chart for a list of cables and interconnections.



MB-13812

Figure 2-5 Cabinet Cage Backplane (Sheet 1 of 2)



MS 15814


Figure 2-5 Cabinet Cage Backplane (Sheet 2 of 2)

2.7 BACKPLANE INTERCONNECTIONS

FROM			TO			PART NO.	QTY	DESCRIPTION
B/P	CONN	B/P	CONN					
CPU	J01-J06	MEM	J01-J06		17-00327-01	6		Cable assembly, 55 ohm, 2.6 inches (Array Bus)
CPU	J07-J08	M9403	J1-J2		70-19883-12	2		Console QBus
CPU	J09	FE BA11 Box			-			SID jumper
CPU	J10	Async panel on bulkhead	J6		BC05L-03	1		Console asynchronous interface cable (CTV and RTV)
CPU	J11	SC ²	J12		70-19895-8F	1		Cable assembly, Console-SC ²
CPU	J12	MPS B/P#2	J20-J19		70-20722-01	1		Cable assembly, Console-EMM
CPU	J13-J18	ABJs	J13-J18		17-00327-01	6		Cable assembly, 55 ohm, 2.6 inches (Array Bus)
ABus	J19-J24	I/O	J19-J24		17-00326-02	6		Cable assembly, 75 ohm, 5.0 inches (SBI-1)
ABus	J25-J30	I/O	J25-J30		17-00326-01	6		Cable assembly, 75 ohm, 2.5 inches (SBI-0)
I/O	J31	-	-		-			Configuration jumper, CI780
I/O	J32-J34	M9014	J1-J3		70-20540-12	3		UNIBUS cables (DW780-0 to FE-BA11)
I/O	J35	FE BA11 box	-		-			Configuration jumper (DW780-0)
I/O	J36-J38	M9014	J1-J3		70-20540-xx	3		UNIBUS cables (DW780-1 to UNIBUS expansion cabinet)
I/O	J39	-	-		-			Configuration jumper (DW780-1)
I/O	J40	NEXUS in SBI expansion cab	Jx-Jx+6		17-00087-04	6		Configuration jumper (DW780-2)
I/O	J41	NEXUS in SBI expansion cab	Jx-Jx+6		17-00087-04	6		SBI-0 expansion cables
I/O	J47-J52	MPS B/P#2	J20-J19		70-21434-01	1		Harness assembly, adapter AC/DC low
I/O	J53	Slot 10	-		-			DW780-2, M9044 UBA terminator
I/O	Row A,B	-	-		-			DW780-1, M9044 UBA terminator
I/O	Slot 15	-	-		-			DW780-0, M9044 UBA terminator
I/O	Row A,B	-	-		-			CI780 cable set assembly
I/O	Slot 20	CI connectors on bulkhead	-		70-19860-00	1		
I/O	BRX, ARX, ATX, BTX	-	-		-			Connector for optional external clock input
CPU	CX1	External clock source	-		-			


NOTE

Refer to schematics IC-7019219 and PL-7019219 in Volume 1 of the VAX 8600/8650 System Field Service Maintenance Print Set for more detailed information on KA86 interconnections.



CHAPTER 3

POWER



- LEGEND:
- (1) EXHAUST TEMPERATURE SENSORS
 - (2) AMBIENT TEMPERATURE SENSOR
 - (3) AIRFLOW SENSORS
 - (4) 50 HZ TRANSFORMER TEMPERATURE SENSOR
 - (5) GROUND CURRENT SENSOR
 - (6) FILTER PRESENT SENSOR

MR-15284

Figure 3-1 Power System Components

3.1 POWER SYSTEM COMPONENT DESCRIPTION

Part Number	Description
12-19526-01	Temperature Sensor.
12-22805-01	Air Flow Sensor (with red LED).
17-00932-01	Cable Assembly (for connecting Dranetz 626 Line Monitor to the System).
876-A	System Power Controller. Provides switched and unswitched ac power distribution as well as DEC power bus interconnections.
H7140-CA	Front end cabinet BALL-AL expansion drawer power supply. Provides the necessary dc power for all backplanes within this expansion drawer.

POWER

H7170-A	MPS ac Input Modules which provide 300 Vdc as input to the low voltage regulators. Also provide low power ± 12 and ± 15 volts.
H7180-A	MPS +5 V and -5.2 Vdc Regulators (200 Amps).
H7186-A	MPS +5 Vdc Regulator (85 Amps).
H7187-A	MPS -2 Vdc Regulator (100 Amps).
H7188-A	Environmental Monitor Module (EMM). Provides control of the MPS and monitors the environment of the CPU. Communicates with the console via an asynchronous interface.
H7231-A	Battery Back-up Unit which supplies +5 V for the TOY clock and 250 Vdc (@ 0.8 Amps) for 10 minutes minimum upon a power failure.
3023959-01	Constant Voltage Transformer (CVT) 60 Hz-Rev E1
3023959-02	Constant Voltage Transformer (CVT) 50 Hz-Rev E1

3.2 ENVIRONMENTAL SENSOR DESCRIPTIONS (AND LIMITS)

There are a number of sensors located within the system which monitor various aspects of the system environment. These monitoring devices work in conjunction with the hardware and software to ensure that abnormal environmental conditions get reported and, in some cases, power down the system to prevent pending damage from occurring.

The following sections describe the various sensors used, how they operate and what their thresholds are set at.

3.2.1 Air Temperature Sensors

There are four air temperature sensors installed in the VAX 8600 System CPU cabinet. These sensors are used to monitor four conditions of the CPU cabinet and module card cage.

3.2.1.1 Ambient Air Input Temperature Sensor (T1) - This sensor monitors the CPU cabinet input temperature. The programmable thresholds are currently set at 33 degrees C (yellow zone) and 35 degrees C (red zone).

If the sensor detects that the temperature has dropped below 16 degrees, an information message will be printed on the console terminal. Since this is a non-fatal condition, a pending shutdown will NOT be initiated.

3.2.1.2 Module Card Cage Exhaust Temperature Sensors (T2, T3, T4)
- These sensors measure the exhaust temperature at three separate locations above the CPU cabinet module card cage. The programmable thresholds are currently set at 48 degrees C (yellow zone) and 55 degrees C (red zone).

If the sensor(s) detects that the temperature has dropped below 16 degrees, an information message will be printed on the console terminal. Since this is a non-fatal condition, a pending shutdown will NOT be initiated.

3.2.1.3 Air Temperature Increase Across Modules (All Sensors) - This measurement is achieved by monitoring the difference (delta) between the card cage input temperature sensor (T1) and each of the exhaust temperature sensors. This results in three measurements as follows:

"Delta Temperature T1-T2"

"Delta Temperature T1-T3"

"Delta Temperature T1-T4"

The programmable thresholds are currently set at 15 degrees C (yellow zone) and 20 degrees C (red zone).

3.2.1.4 Critical Cabinet Temperature Sensor (T3) - In addition to providing a reading for the temperature measurements outlined previously, this sensor also feeds a hardware circuit in the EMM which forces a TOTAL OFF system power down when the temperature exceeds 60 degrees C.

3.2.2 Air Flow Sensors

There are two air flow sensors present in the CPU cabinet which are located directly below the module card cage. The outputs of these sensors feed the EMM which in turn will report when the air flow drops below a specific amount, allow a specified amount of time for an operator to correct the situation and, if not remedied, power down the system.

3.2.3 Ground Current Sensor

A ground current sensor is located in the front end cabinet which measures ground current on the main ground conductor where it enters the cabinet.

There is no "limit" set for this measurement. Rather, the reading will only be taken when requested by the operator (via the "SHOW POWER" console command). Field Service should use this sensor to verify that the ground current is within the specified tolerance (100 milliamps) and that the current does not change drastically over a period of time.

3.2.4 50-Hertz Transformer Temperature Sensor (Front End Cabinet)

There is a temperature sensor installed on the power transformer used in 50 Hertz systems. This temperature sensor is monitored continuously and will cause an Emergency Power off if the temperature rises above 175 degrees Celsius (+ 5 degrees).

3.2.5 CPU Cabinet Filter Sensor

A mechanical switch located at the right rear of the module card cage in the CPU cabinet detects the presence (or absence) of the cabinet filter. If the filter is not installed, the system will not power up. Furthermore, if the filter is removed while the system is up and running, the system will POWER DOWN.

3.3 ENVIRONMENTAL MONITORING AND EMERGENCY POWER OFF CONDITIONS

The System has a number of environmental monitoring schemes that are used to monitor and report specific ambient conditions and, under certain circumstances, power down the system due to pending critical environmental conditions. All the schemes fall into one of the following categories.

3.3.1 EMM Hardware Monitored and Controlled

When these monitored conditions reach a specified threshold, they immediately force an emergency power off of the entire system. The main circuit breaker on the 876-A power controller is tripped and the four walnuts (indicators), on the EMM, indicate the source problem.

Refer to "H7188-A EMM MODULE - VISUAL INDICATORS" for more information on the EMM Total Off codes.

Refer to "Environmental Sensor Descriptions (and Limits)" for more information on the sensors.

3.3.2 EMM Software Monitored and Controlled

This EMM mode of operation is referred to as ASD (Auto Shutdown). Refer to "ENVIRONMENTAL SENSOR DESCRIPTION (AND LIMITS)" for more information on the conditions monitored and thresholds.

If a monitored condition reaches a specified threshold, the console will be notified to warn the operator of a pending environmental fault. Various indicator LEDs will also be lit. If the condition is not rectified within a specific amount of time, or the condition reaches a second higher threshold, an emergency power off of the entire system is initiated and the main circuit breaker on the 876-A power controller is tripped.





Figure 3-2 Power Shutdown Sequence



MR-15847

Figure 3-3 Power System Interconnect Diagram




Figure 3-4 Power System Interconnect Diagram

3.3.3 EMM Software Monitored and Console Software Controlled

These conditions, under Console Software control, are monitored and reported to the Console Software. These conditions will not cause an emergency power off, rather they will be reported via an error message on the Console terminal.

This EMM mode of operation is referred to as DEFAULT mode. Refer to "ENVIRONMENTAL SENSOR DESCRIPTION (AND LIMITS)" for more information on the conditions monitored and thresholds.

3.3.4 876-A Power Controller Monitored and Controlled

These conditions, monitored by various sensors, are intended to prevent system power-up under unsafe conditions as well as forcing SWITCHED system shutdown when an unsafe condition is detected.

NOTE

With the exception of "EMM Software Monitored and Console Software Controlled", all these schemes may result in a system power down situation. To help illustrate the interaction of these systems, refer to the "Power Shutdown Sequence" flowchart. Also, the section titled "Environmental Monitoring - Software Control" gives additional information on the software timing of the air flow and temperature faults, as well as a description of the warning messages.

3.4 REFERENCE DOCUMENTATION

DEC STD 123 (Power Control Bus Standard)	EL-00132-00
KA86 EMM Technical Description	EK-KA86V-TD
KA86 System Power Technical Description	EK-KA86P-TD
VAX 8600/8650 Field Service Maintenance Print Set	MP-01714-00
VAX-11/780 Power System Technical Description	EK-PS780-TD

3.5 SYSTEM ENVIRONMENTAL MONITORING - SOFTWARE CONTROL

There are a number of environmental parameters monitored by the EMM software and in some cases controlled by the console software. When a change of status in any of these parameters is detected, the action taken will depend on whether or not the console is in CIO mode, and whether or not the status change is fatal.

Upon detection of a change of status:

- If the console is in CIO mode, a descriptive error message is printed on the console terminal detailing the status change.

- If the console is in PIO mode, the following "generic" console message will be printed:

"%SYSTEM, Environmental Alert - Environmental Monitor has detected an alert condition. Please check the error log."

As outlined in this message, it will be necessary to consult the error log to determine the source of the alert condition.

- If the status change is not corrected within a specified amount of time, a total system power down is initiated, and a software timer (Automatic Shutdown timer, or ASD) begins. If the situation is not corrected within the amount of time specified by the timer, then the system will be shutdown by the EMM. Furthermore, if the console is in PIO mode, the "generic" message outlined above will be appended by the following:

"Total system power shutdown pending if condition is not corrected."

- If the status change is not catastrophic in nature, then the only action taken by the software is to report the change via the messages outlined above.

Each of these conditions, with the action taken, is outlined below.

3.5.1 Temperature Sensor (or Delta Temperature) Enters Yellow Zone

When a monitored temperature parameter enters the yellow zone:

- a warning message is typed on the console terminal.
- the ALERT LED will be lit SOLID.

As this is considered a NON-FATAL situation, no other action is taken.

3.5.2 Temperature Sensor (or Delta Temperature) Enters Red Zone

When a monitored temperature parameter enters the RED zone:

- A warning message is typed on the console terminal.
- the ALERT LED flashes
- the Automatic ShutDown timer is set to one minute.

Since the ASD timer has been set to one minute, a pending shutdown has begun. If the RED ZONE temperature condition is not rectified within one minute, the EMM initiates a TOTAL-OFF condition which trips the 876-A main circuit breaker.

POWER

3.5.3 Single Air-flow Fault

When an AIR-FLOW fault is detected, the following occurs:

- a warning message is typed on the console terminal.
- the AIR-FLOW sensor LED lights solid.
- the ALERT LED (on the SCP) flashes.
- the Automatic shutdown timer is set to three minutes

Since the ASD timer has been set to three minutes, a pending shutdown has begun. If the air flow fault condition is not Rectified within three minutes, the EMM initiates a TOTAL-OFF condition which will trip the 876-A main circuit breaker.

3.5.4 Double Air-flow Fault

When a second AIR-FLOW fault is detected, the following occurs:

- a warning message is typed on the console terminal.
- the second AIR-FLOW sensor LED lights solid.
- the ALERT LED continues to flash.
- the Automatic shutdown timer is set to one minute.

Since the ASD timer has been set to one minute, a pending shutdown has begun. If the double air flow fault condition is not rectified within one minute, the EMM initiates a TOTAL-OFF condition which will trip the 876-A main circuit breaker.

3.5.5 MPS Status Change

When the EMM and/or console software detect a change in the status of the MPS system a message is printed on the console terminal outlining the status.

3.6 MPS POWER DISTRIBUTION AND COLOR CODES

Reg	Part	Voltages	Load (Backplane and/or Modules)
A	H7180-A	+5 V	EMM (H7188-A), CSL (L0201), I/O Backplane, Clock Module (L0217/L0231)
B	H7186-A	+5 V	Memory Backplane (this regulator has BBU)
C	H7186-A	+5 V	ABus Backplane, Memory Backplane
D	H7187-A	-2 V	CPU and ABus Backplanes (Note 1)
E	H7187-A	-2 V	CPU and Memory Backplanes (Note 1)
F	H7180-A	-5.2 V	CPU and Memory Backplanes (Note 2)
H	H7180-A	-5.2 V	CPU, ABus and I/O Backplanes (Note 2)
K	H7170-A	+ 15 V	I/O Backplane
		+ 300 V	Regulators F and H
L	H7170-A	+ 12 V	EMM (H7188-A), CLK (L0217 for VAX 8600, L0231 for VAX 8650), CSL (L0201)
		+ 300 V	Regulators A through E
BBU	H7231-A	+5 V	TOY (L0201)

NOTES

1. H7187-A Regulators D and E outputs (-2 V) are tied together on the backplane.
2. H7180-A Regulators F and H outputs (-5.2 V) are tied together on the backplane.
3. The H7180-A Regulator is used for both the -5.2 V and +5.0 V supplies. The actual regulator is the same in all cases with the output voltage being "selected" by insertion into the backplane (i.e., if plugged into slot A it will provide +5 V, whereas if plugged into slots F or H it will provide -5.2 V).
4. The H7170-A Regulator provides the 300 Vdc bus input to the other regulators as well as low power +12 V and +15 V. These two regulators are interchangeable; selection for the 12/15 V output is made by a jumper on the MPS backplane.

3.7 MPS POWER DISTRIBUTION COLOR CODE CHART

Color	Voltage
BLACK	GROUND
RED	+ 5 V
GRAY	- 2 V
VIOLET	- 5.2 V
GREEN	- 15 V
YELLOW	+ 15 V
ORANGE	+ 12 V
BROWN	- 12 V

3.8 HOW TO MARGIN MPS REGULATORS

It is possible to margin some of the MPS dc voltage regulators using a console command. The margining is actually controlled by the EMM. Of the voltage outputs from the MPS, the +5, -5.2 and -2 volt outputs are marginable, the +15 and +12 volt outputs are not. Also, as the -5.2 and -2 volt outputs are tied together on the backplane, these regulators must be margined in pairs; the +5 volt regulators can be margined separately.

To margin an MPS regulator, use the SET MARGIN command. For a detailed description of this command refer to the Console Software Specification. A brief description of the margining procedure follows.

CPU BACKPLANE

VOLTAGE	SILKSCREEN	B/P PIN	REGULATOR
GROUND	○		
+5 V	□	A02-91	A
+5 V TOY	□	A02-03	H7231-A
+12 V	◡	A0290, A1190	L
-12 V	◠	B11-02	L
-5.2 V		BUSBAR (VIOLET)	F, H*
-2 V		BUSBAR (GREY)	D, E*

MEMORY BACKPLANE

VOLTAGE	SILKSCREEN	B/P PIN	REGULATOR
GROUND	○		
+5 V	□	B* 04	C
+5 V BBU	□	B* 92	B
-2 V		BUSBAR (GREY)	D, E*
-5.2 V		BUSBAR (VIOLET)	F, H*

ABUS BACKPLANE

VOLTAGE	SILKSCREEN	B/P PIN	REGULATOR
GROUND	○		
+5 V	□		C
-2 V		BUSBAR (GREY)	D, E*
-5.2 V		BUSBAR (VIOLET)	F, H*
EMM3 SBIA AC LO L		B03-12	
EMM3 SBIA DC LO L		B03-10	

I/O BACKPLANE

VOLTAGE	SILKSCREEN	B/P PIN	REGULATOR
GROUND	○	*C2	
+5 V	□	*A2	A
-5.2 V	◊	E05K1-E06K1	F, H*
-15 V	◡	D02B2-D04B2	K
+15 V	◠	C02U1-C04U1	K
SUPPLY AC LO L		F09R1	
SUPPLY DC LO L		F09R2	


*REGULATOR OUTPUTS TIED TOGETHER

NOTE:

THE B/P PINS LISTED ARE FOR REFERENCE ONLY AND DO NOT NECESSARILY INDICATE ALL PINS WHERE VOLTAGE WILL BE PRESENT. REFER TO THE APPROPRIATE WIRE LIST FOR A LIST OF ALL CONNECTIONS.

Figure 3-5 MPS Voltage Measurements

MR 15815



NOTE:
VOLTAGE PADS REPRESENT GOLD ETCH ON MODULE

MR-15816

Figure 3-6 Module Power Connections

POWER

3.8.1 MPS Regulator Margining Procedure

1. Determine which regulator/voltages you wish to margin. Referring to the regulator location below, select one or more of the following:

Regulators H and F	-5.2 V
Regulators E and D	-2 V
Regulator C	+5 V
Regulator B	+5 V
Regulator A	+5 V

Reg	K	H	F	EMM	E	D	B	C	A	L
Vlt	+15 V	-5.2 V	-5.2 V		-2 V	-2 V	+5 V	+5 V	+5 V	+12 V

2. From CONSOLE I/O mode, enter one of the following commands to the VAX 8600 Console:

```
>>>SET MARGIN HIGH reg#    Increases the voltage, for the
                             selected regulator(s), by 5%.

>>>SET MARGIN LOW reg#     Decreases the voltage, for the
                             selected regulator(s), by 5%

>>>SET MARGIN NORMAL reg#   Returns the voltage, for the
                             selected regulator(s), to normal.
```

NOTE

Reg# refers to the selected regulator(s) (e.g., A, B, C, DE, FH, or ALL) and if omitted, all regulators (A through H) will be selected.

3. To verify/measure the margined voltage, use the SHOW POWER command (see example in section on MPS Power and Sensor Reading) or measure the voltage on the appropriate backplane (see MPS Voltage Measurements).
4. When completed, be sure to return the voltages to normal using either the SET MARGIN NORMAL command or the INIT/POWER command.

3.9 H7170-A POWER SUPPLY - VISUAL INDICATORS

LED CONDITIONS

BUS OK GREEN LED. Indicates when bus voltage is within 165 to 315 Vdc. The minimum voltage required for MPS regulator operation is 165 Vdc. The buses are supplied by H7170-A units K and L.

The Bus OK LED does not light when the H7170 units do not receive ac input power, and blinks when the ac power is less than specified (below 156 V RMS line to line based on a 208 Vac input).

MODULE OK GREEN LED. Indicates when the H7170-A unit is supplying voltages that are within proper regulation range, and no other faults are present.




Figure 3-7 H7170-A Power Supply - Visual Indicators

OVER VOLTAGE RED LED. Indicates when any, or all auxiliary voltages (in an H7170) crowbar. Input power must be removed to reset this signal.

Overtoltage trip operation is as follows:


+12 V output:	+12.8 to +13.6 Vdc
-12 V output:	-12.8 to -13.6 Vdc
+15 V output:	+16.2 to +16.9 Vdc
-15 V output:	-16.0 to -16.7 Vdc

OVER CURRENT YELLOW LED. Blinks when output current is above 2 Amps at either (or both), the 12 volt and 15 volt output.

3.10 H7180-A, H7186-A, AND H7187-A POWER SUPPLY VISUAL INDICATORS

LED	DESCRIPTION
MODULE OK	GREEN LED. Indicates that the regulator output voltage is within the regulation range and that no faults are present.

Regulator	Regulation range
H7180-A (A)	+5.0 V \pm .005 Vdc
H7180-A (F,H)	-5.2 V \pm .005 Vdc
H7186-A (B,C)	+5.0 V \pm .025 Vdc
H7187-A (D,E)	-2.0 V \pm .015 Vdc



MR-15819


Figure 3-8 H7180-A Power Supply

OVER VOLTAGE RED LED. Indicates that an overvoltage condition has occurred. This condition will latch and the voltage output will be crowbarred.

Regulator	Overvoltage limit
H7180-A (A)	+6.0 V
H7180-A (F,H)	-6.0 V
H7186-A (B,C)	+6.3 V
H7187-A (D,E)	-2.8 V


OVER CURRENT YELLOW LED. Blinking LED indicates that the regulator output current is above the maximum rating.

Regulator	Maximum output current
H7180-A (A)	200 A
H7180-A (F,H)	200 A
H7186-A (B,C)	85 A
H7187-A (D,E)	100 A



MR-15818

Figure 3-9 H7186-A (H7187-A) Power Supply



MR-14667

Figure 3-10 H7188-A EMM Module Visual Indications

3.11 TOTAL OFF CODES - FAULT CONDITIONS

Total Off Code 10 4 2 1	Octal	Condition
0 0 0 0	0	EMM program turns off ac power in response to a console initiated command (normal power off condition)
0 0 0 1	1	Overtemperature, Regulator A
0 0 1 0	2	Overtemperature, Regulator B
0 0 1 1	3	Overtemperature, Regulator C
0 1 0 0	4	Overtemperature, Regulator D
0 1 0 1	5	Overtemperature, Regulator E
0 1 1 0	6	Overtemperature, Regulator F
0 1 1 1	7	Overtemperature, Regulator H
1 0 0 0	10	Transformer OT (50 Hz only)
1 0 0 1	11	Overtemperature, Spare B (unused)
1 0 1 0	12	Bad ac input, Module K
1 0 1 1	13	Bad ac input, Module L
1 1 0 0	14	Cabinet overtemperature, Sensor T3*
1 1 0 1	15	Not used
1 1 1 0	16	Overtemperature, Spare C (unused)
1 1 1 1	17	EMM cannot communicate with the Console †

3.12 EMM LEDS AND SWITCHES

LED or Switch	Indication/Function
Key Fault	Red LED. Indicates a missing or misplaced module(s) in memory, CPU, or ABus backplanes of the VAX 8600/8650 System cabinet card cage.
AC Input	Indicates ac input errors detected during power up.
Module Fault	MPS modules K and/or L are not OK.
Electrical	This switch will override a SERIAL KEY FAULT,
Key Override	allowing the power-up sequence to continue.

* Temperature sensor T3 (below the EMM module) monitors the outlet temperature from the module cage and the inlet temperature to the EMM. In addition to providing temperature data to the EMM/Console (for yellow and red zone temperature monitoring), T3 also feeds a hardware circuit that shuts down the system when the temperature exceeds 60 degrees C. This hardware generated shutdown provides a failsafe circuit should the software monitoring cabinet temperatures fail.

† For this condition, the magnetic disk indicators will flash alternately; all on, and then all off.

POWER

3.13 MPS POWER AND SENSOR READING

Field	Description
Input	Indicates what parameter/unit is being measured (e.g., temperature or regulator).
Measured	The actual value read. Will be a voltage, current or temperature (in degrees C).
Margin	Listed only for the marginable regulators and will read: NORMAL - Voltage is not margined HIGH - Voltage has been margined high, + 5% LOW - Voltage has been margined low, - 5%

DC>>SH POWER

Input	Measured	Margin	Status	Input	Measured	Status
Regl A	+5.02 V	NORMAL	OK	Inlet		
Regl B	+5.02 V	NORMAL	OK	Temp1	22 Deg C	OK
Regl C	+5.02 V	NORMAL	OK			
Regl D	-1.98 V	NORMAL	OK	Outlet		
Regl E	-1.98 V	NORMAL	OK	Temp2	24 Deg C	OK
Regl F	-5.18 V	NORMAL	OK			
Regl H	-5.18 V	NORMAL	OK	Outlet		
Regl K	+15.16 V		OK	Temp3	22 Deg C	OK
	-14.92 V		OK			
Regl L	+12.19 V		OK	Outlet		
	-12.09 V		OK	Temp4	24 Deg C	OK
Gnd Cur	78 Milliamps					

Status Overall status of the unit being measured and will read:
- Normal status, all OK

3.14 MPS STATUS MESSAGES

When the Console is notified of an MPS Status change it will print a message on the Console Terminal. Refer to Chapter 4 of the System Fault Isolation Manual for a description of MPS Status Messages.

3.15 HOW TO ENABLE/DISABLE BATTERY BACKUP

The BBU Unit can be enabled/disabled via console commands. To enable the BBU, enter the following command:

>>>SET FLAG BBU ON

And to disable the BBU, enter the following command:

>>>SET FLAG BBU OFF

To determine the status of the BBU (whether or not it is enabled) use the SHOW POWER or SHOW FLAGS command. Refer to the section on MPS Power and Sensor Reading.




Figure 3-11 EMM Module - Detailed Block Diagram

3.16 HOW TO DETERMINE THE BATTERY CHARGE STATUS OF THE BBU

There is a red LED located on MPS backplane 2 (labeled D2) which indicates the current status of the BBU charging circuit and is read thus:

D2 Indicator	Status
OFF	BBU is either turned off or broken.
ON	BBU is fully charged.
FLASHING (once per sec)	BBU Batteries are charging.
FLASHING (10 times per sec)	BBU is supplying power to memory.

3.17 H7140-CA POWER DISTRIBUTION

The H7140-CA supplies power to all backplanes within the BALL-L UNIBUS expansion drawer in the Front End Cabinet. There is a total of 4 backplanes within the expansion drawer: two 9-slot DD11-DK and one 4-slot DD11-CK backplanes for the UNIBUS on DW780-0 ; one 4-slot DDV11-CK backplane for the Console QBus. The power connections for each of these backplanes is made via Mate-N-Lok connections to the H7140-CA. The interconnections are shown in the following figure.


The table below lists the color codes used on each of these power harnesses. The H7140 Power Distribution/Interconnection Tables list the interconnection and backplane test points where the voltages can be measured for each of the three different backplanes.

NOTE

The H7140-CA is an FRU as a complete unit. Voltage adjustments are done at the factory and should not be attempted in the field.

3.17.1 H7140 Power Distribution Color Codes

Color	Voltage
BLACK	GROUND
RED	+5 V
GRAY	+15 V
WHITE	+15 V
BLUE	-15 V
GREEN	-15 V
BROWN	-5 V or LTC
ORANGE	+20 V
VIOLET	DC Low
YELLOW	AC Low



MR-15820

Figure 3-12 H7140-CA Power Interconnection Diagram

3.17.2 H7140 Power Distribution/Interconnection Tables

DD11-DK Backplane

Color	Voltage	J1 & J3	J2 & J4	Backplane		
				Slot	Row	Pin
BLACK	GROUND	8,9	8,9	all	all	C2
RED	+5 V	1,4,12	1,4	all	all	A2
GRAY,WHITE	+15 V	2	6	all	C	U1
BLUE,GREEN	-15 V	N/C	13,15	all	C	B2

N/C = Not Connected.

DD11-CK Backplane

Color	Voltage	J14	Backplane		
			Slot	Row	Pin
BLACK	GROUND	7,8	all	all	C2
RED	+5 V	1,4,12	all	all	A2
GRAY,WHITE	+15 V	2,6	all	C	U1
BLUE,GREEN	-15 V	13,15	all	C	B2

POWER

DD11-DK / DD11-CK Backplane J19 Interconnections

Color	Item	J19	Backplane		
			Slot	Row	Pin
BLACK	GROUND	1	all	all	C2
BROWN	LTC	2	all	C	D1
VIOLET	DC LO	3	all	C	N1
YELLOW	AC LO	4	all	C	V1

NOTE

The backplane pins listed do not necessarily show where voltage is present for ALL pins. Refer to the appropriate W/L for all connections.

DDV11-CK Backplane

Color	Voltage	J12	Backplane		
			Slot	Row	Pin
BLACK	GROUND	7,8	all	all	C2
RED	+5 V	1,4,12	all	all	A2
GRAY	+15 V	2	A	01	S1
			B	01	S1
--	+12 V	*	A-D	02	D2

* +12 V is generated from +15 V on the QBus Connector module, M9403, which is installed in slot 1 of the backplane. Refer to drawing CS-M9403-0-1 for more details. There is a 3 Amp fuse mounted on this module at the + 12 V output.

NOTE

The following adjustment must be made when the H7140 power supply has been replaced. Measure the voltage level at pin AD2 (or BD2), of QBus slot 1 (where the M9403 paddle card is installed). Adjust the trimpot on the M9403 module until the voltage measures +12 Vdc \pm 0.05 V.

3.18 RL02 (CVT) POWER INFORMATION

The RL02 disk drive and Ball-AL expansion drawer requires a Constant Voltage Transformer (CVT) to condition the incoming ac power. The CVT is mounted in the front end cabinet at the top rear of the RL02 (refer to the Power System Component Location diagram). Switched ac power is the input to the CVT from the 876-A power controller and output ac power is provided for the RL02 disk drive and the H7140-CA (in the Ball-AL).

NOTE

The CVT provides 110V output for both 50HZ and 60HZ systems and as such, the input VOLTAGE SELECTOR at the rear of the RL02 disk drive MUST BE SET AT 110V and the VOLTAGE RANGE SELECTOR must be set at NOM in all cases.

The same is true for the H7140-CA power supply in the Ball-AL UNIBUS Expansion Drawer, which must always have the input voltage selector set at 110V.

CHAPTER 4

INITIALIZATION AND BOOTSTRAP TROUBLESHOOTING PROCEDURES

4.1 INTRODUCTION

This section has two objectives:

1. Describe the major events that occur during the system power-up and boot sequence.
2. Provide a set of troubleshooting procedures that will aid in isolating faults that may occur during the power-up and boot sequence.

The first objective is satisfied with a time line flow chart that illustrates the major visible events that take place during the power-up and bootstrap process, and the approximate time between events. Following the flow chart is a brief explanation of the internal (non-visible) events that take place between the major events, including pointers to the appropriate troubleshooting procedure. The second objective is satisfied by a set of troubleshooting flow charts and procedures.

NOTE

This section is still under development

4.2 BOOT SEQUENCE TIME LINE FLOW DESCRIPTION

1. POWER ON

- a. AC power is routed to the ac input modules (K and L) which in turn supply:
 - 300Vdc to the main power bus (from modules K & L).
 - ± 15 Vdc to the I/O backplane (from module K).
 - +12 Vdc to EMM and Clock Module (from module L).

If the ac input module fault LED is set on the EMM, see AC Input Unit Troubleshooting Flow.

INITIALIZE/BOOT TROUBLESHOOTING PROCEDURES

- b. The EMM and Clock Module Check the parallel and serial module keying circuits.
- If parallel key loop failure, set the EMM KEY FAULT LED and abort power-up. See Parallel Key Loop Troubleshooting Flow.
 - If serial key loop failure, set the appropriate Clock Module LED and the EMM KEY FAULT LED, and check the key override switch (EMM). If the EMM ELECTRICAL KEY OVERRIDE switch has been depressed, then continue. If not, then abort the power-up. See Serial Key Loop Troubleshooting Flow.




Figure 4-1 Boot Sequence Time Line Flow

INITIALIZE/BOOT TROUBLESHOOTING PROCEDURES

- c. Turn on Regulator A (+5Vdc to EMM, Console, and I/O backplane).
 - The EMM begins self initialization.
 - If error: loop on failing test (console will detect and report).

If Module OK LED is not lit, see Regulator A (+5 Vdc) Troubleshooting Flow.

- d. Console begins self initialization.
 - Initialize registers, disable external interrupts, and run Console PROM Self Test (01 through 10).
 - If Self Test fails: See Console Initialization and Self Test (1-10) Troubleshooting Flow and SCP LEDs Troubleshooting Chart.
2. DISPLAY PROM BANNER (Console PROM Self Test 11)
 - a. Execute Self Test (11-35)
 - Test 11 will print "VAX 8600" FOR PROM V36 or earlier, and "PROM Vnn", where nn is the PROM version number, for PROM V37 or higher.
 - If Self Test Fails: Print a failure message and loop on failing test. See Console Self Test (11-35) Troubleshooting Flow.

3. RING CTY BELL

- a. The operator has 5 seconds to interrupt the boot sequence and enter PROM Command Context by pressing any key on the CTY or RTY.
- b. Execute Console PROM RL02 Tests.
 - If Error: Print error message and abort sequence. See Console QBus troubleshooting flow chart.

4. DISPLAY INITIAL BANNER

- a. Read and perform checksum of RL02 Boot Block (Block 0).
- b. Initialize console mapping


5. DISPLAY CONSOLE BANNER and INIT MESSAGE

- a. Load SDB signal name overlays.
- b. Start KAF timer
- c. If REBOOT, restore console and remote port parameters.

INITIALIZE/BOOT TROUBLESHOOTING PROCEDURES

- d. Turn off all SCP LEDs.
- e. Initialize system (CPU) Clock
6. DISPLAY INIT POWER MESSAGE
 - a. Initialize Console/EMM Communications
 - b. Read EMM Status
 - If no EMM response: Display Message
 - c. Load EMM Voltage and Temperature parameters
 - d. Read Regulator K, L and A Status
 - If error: Display Message.
 - e. Read Regulator C, D, E, F, and H Status
 - If error: Display Message.
 - f. Clear all Margin Parameters
 - g. Turn on and check regulators: B, F and H, D and E, and C.
 - If error: Display Message.
 - h. Direct EMM to Deassert DC LO
 - If error: Display Message.
 - i. Direct EMM to Deassert AC LO
 - If error: Display Message.
 - j. Direct EMM to clear Magnetic Latches and Air Flow Fault Status.
 - If error: Display Message.
 - k. Direct EMM to enter Default Mode.
7. DISPLAY INIT CPU MESSAGE
 - TBS
8. DISPLAY PAMM MESSAGE
 - TBS
9. DISPLAY BOOT MESSAGE
 - TBS

10. DISPLAY VMB LOAD MESSAGE
 - TBS
11. DISPLAY VMS BANNER
 - TBS
12. DISPLAY STARTUP.COM TEXT
 - TBS
13. SYSTEM READY FOR LOGINS
 - TBS



MM-180/5

Figure 4-2 AC Input Module (K and L) Troubleshooting Flow

4.3 MODULE KEYING

4.3.1 Overview

The VAX 8600/8650 system implements an electrical module keying scheme to prevent the unintentional destruction of modules when they are inserted in an incorrect slot. The scheme is to detect the incorrect installation of a module prior to system power-on, inhibit system power-on, and flag the user of the condition. The hardware involved in this scheme includes the MPS (EMM), the clock module and the MEM/CPU/ABUS backplanes and modules.

NOTE

Modules within the I/O backplane are not verified under this scheme.

4.3.2 Implementation

Two separate types of module keying loops are used: a technology or parallel loop, and a serial key loop. The parallel loop verifies that modules of incompatible technology are not inserted into the wrong backplanes. The serial key loop verifies the correct slot locations of modules within a particular backplane. The parallel loop must be satisfied before testing the serial loops.

The serial loops are broken down into separate serial key loops, CPU, FBox, and one for each IOA. With the exception of the CPU SERIAL KEY LOOP, the other serial loops must be enabled before they are used (i.e., at least one of the option modules must be inserted in the correct B/P for the serial loop to be enabled).

Refer to the Module Keying Diagrams, or, for a more complete description, refer to the EMM Technical Description Manual for a detailed description of key loop operation.

Refer to the diagram of H7188-A EMM Module-Visual Indicators (Chapter 3) for the location of the KEY FAULT LED on the EMM. The following diagram illustrates the layout of the Serial Key Loop Fault LEDs on the clock module.




Figure 4-3 Clock Module
Key Fault
LEDs

4.3.3 Parallel Key Loop

If the module keying circuits sense a parallel key loop fault, the KEY FAULT LED on the H7188-A (EMM) will be lit and no clock module LEDs will be lit.

NOTE

This condition may also indicate a CPU serial key loop fault if the clock module is not inserted.

The parallel loop will be broken if any of the following conditions exist:

1. A CPU module is inserted in either the ABus or Memory backplanes.
2. A memory module (including the MTM) is inserted in the ABus backplane.
3. An ABus module is inserted in the Memory backplane.
4. The MTM module is missing from slot 9 of the Memory backplane.
5. The STM module is missing from slot 1 of the ABus backplane.

4.3.4 CPU Serial Key Loop

If the module keying circuits sense a CPU serial key loop fault, the KEY FAULT LED on the H7188-A (EMM) will be lit along with the top LED on the clock module.

The CPU serial loop will be broken if either of the following conditions exist:

1. The clock module is not inserted.
2. Any CPU module is installed in the incorrect slot or a module is not installed. This includes the STM module in slot 1 of the ABus backplane and either the FTM or FBA module in slot 8 of the CPU backplane. (The FJM and FBM modules are checked by the FBox serial loop).

4.3.5 FBox Serial Key Loop

If the module keying circuits sense an FBox serial key loop fault, the KEY FAULT LED on the H7188-A (EMM) will be lit along with the second LED from the top on the clock module.

The FBox serial loop will be broken if BOTH of the following conditions exist:

1. The FBox serial key loop is enabled - Any CPU module (B62 ground) is installed in slot 7 or 8 of the CPU backplane.
2. FBM (FJM) and FBA (FTM) are not installed in CPU backplane slots 7 and 8 respectively.

4.3.6 IOA Serial Key Loop


If the module keying circuits sense an IOA serial key fault, the KEY FAULT LED on the H7188-A (EMM) will be lit, along with either the 3rd (IOA0) or 4th (IOA1) LED from the top on the clock module.

The IOA serial loop will be broken if BOTH of the following conditions exist:

1. The IOA serial key loop is enabled - An ABUS module is installed in slot 2 or 3 of the ABUS backplane.
2. The SBA and SBS are installed in ABUS backplane slots 3 and 2 respectively.

NOTE

The above description is for SBIA0. For SBIA1, it would be slots 4 and 5



MR-16069

Figure 4-4 Parallel Key Loop Fault Troubleshooting Flow




Figure 4-5 Parallel Key Loop Circuit

UAT 14882






Figure 4-6 Serial Key Loop Fault Troubleshooting Flow



MR 16070


Figure 4-7 CPU Key Fault Troubleshooting Flow

INITIALIZE/BOOT TROUBLESHOOTING PROCEDURES



NOTES:
 1 ALL SIGNAL RUNS ARE DESIGNATED AS KEY LOOP 'N' L WHERE 'N' IS REPLACED BY THE NUMBER IN () PARENTHESIS. THE EXCEPTIONS TO THIS RULE ARE THE CLK MODULE RUNS WHICH ARE INDIVIDUALLY DESIGNATED.
 2 ϕ * PINS SHORTENED ON EACH MODULE (UNIQUE PAIR ON EACH MODULE). THE KEY LOOP IS COMPLETED IF ALL ϕ MODULES ARE INSTALLED IN THE CORRECT SLOTS.

Figure 4-8 CPU Serial Key Loop Circuit




NOTES:

1. THE SIGNAL ENA FBOX IS GROUNDED WHEN ANY CPU MODULE IS INSERTED IN SLOT 7 AND/OR SLOT 8.
2. THE KEY LOOP IS SATISFIED IF BOTH THE FBA (OR FTM) AND THE FBM (OR FJM) MODULES ARE PRESENT, OR IF NEITHER OF THESE MODULES ARE PRESENT.

MR-16958


Figure 4-9 FBox Serial Key Loop Circuit



NOTES:

1. FOR EACH SBA MODULE PAIR, THE KEY LOOP WILL BE SATISFIED IF BOTH MODULES OF A PAIR ARE INSERTED IN THE CORRECT SLOT OR IF NO MODULES OF A PAIR ARE INSERTED.
2. ENA IOA3 L OR ENA IOA1 L WILL BE GROUNDED IF SBA AND/OR SBS MODULE IS INSTALLED.
3. L0217 (VAX 8600)
L0231 (VAX 8650)


Figure 4-10 IOA Serial Key Loop Circuit



MR-16076

Figure 4-11 Regulator A (+5 Vdc) Initialization


INITIALIZE/BOOT TROUBLESHOOTING PROCEDURES



MR-16381

Figure 4-12 Console Initialization and Self Test (1-10) Troubleshooting Flow


INITIALIZE/BOOT TROUBLESHOOTING PROCEDURES



MR-16382

Figure 4-13 Console Self Test (11-35) Troubleshooting Flow

INITIALIZE/BOOT TROUBLESHOOTING PROCEDURES



MR-16383

Figure 4-14 Console QBus (RL02) Troubleshooting Flow (Sheet 1 of 2)




Figure 4-14 Console QBus (RL02) Troubleshooting Flow (Sheet 2 of 2)

4.4 SCP LED SEQUENCING



The following table outlines the System Control Panel (SCP) LED sequence that transpires during normal system initialization. A section on troubleshooting has been included. During initialization, if the SCP LEDs freeze in a specific state, this chart should assist in isolating the failure. The chart is intended to be used with the Power Up/Initialization flow charts.

NOTE

In the following chart, a "o" (bullet) indicates that the LED is not lit, and an * (asterisk) indicates that the LED is lit.

SCP (LED) Troubleshooting Chart

SCP LEDs	Action	Troubleshooting
o o o o	Initial condition: No power applied to system.	SCP didn't receive +5 V or console failed to INIT. If we have +5.0 V and EMM MODULE A OK H then swap L0201; check SCP connections or swap SCP.
* * * *	Console initialization: Power has been turned on; regulators K & L are OK; EMM/CLOCK have verified key loops and regulator A has been turned on which provides power to EMM and console. T-11 initializes the console, which lights all SCP LEDs.	The LEDs may all be lit from initial power up, not from CSL initialization. Check EMM MOD OK A H (C0256). If it is +5 V, swap L0201, CSL. If not +5 V, power didn't get to CSL from regulator A. EMM can pull +5 V down.
o o o * o o * o o * o o * o o o	Console self test # 1: the console verifies operation of the SCP by floating a one through the LEDs. This test should not fail as there are no checks made.	The pattern shifts very fast, too fast to see the pattern. Use a SHOW PANEL/TEST to verify SCP LEDs and switches. Problem could be in SCP, L0201, or cable.
o o * o o o * * o * o o o * o * o * * o o * * * * o o o	Console self tests 2 - 8: If any of these self test routines detect an error, the test will loop forever and the LEDs will reflect the number of the test that failed. Because the console terminal has not been tested, this is the only method used to indicate a test failure.	If any of these tests fail they will loop forever. These tests are checking the local PCI. Swap the L0201 module.

- * o o * Console self test 11: This test prints the 'PROM Vnn' banner on the CTY (nn = current console PROM version). The LEDs will remain in this state until self test completion. This LED state should occur about 3 sec after power-up and will remain for about 22 sec.
- The LEDs will remain at 1001 during the execution of the remaining self tests. Test pass/fail criteria: Look at the CTY and verify printout of PROM Vnn. If no printout, verify that CTY is set up for 9600 BPS, 8 bits/char, 1 SB, and no parity. Suspect cable to CPU, cable from ASYNC panel to CPU backplane (J10), or L0201.
- o o o * Console self test 33: SCP logic test. This test will again float a one through the SCP LEDs, reading the LEDs state each time.
- If any of these tests fail then check the SCP connections; swap the SCP; swap the L0201. Should also get an error message.
- o o o o Console self test completed: Self tests have completed successfully.
- From here on errors are reported on the CTY.
- o ? ? o The PROM code will read the state of the SCP switches and set the LEDs to reflect the state of the Remote port (only).
- 
- ? ? ? ? After the PROM runs the RLV12/RL02 tests it will boot the console operating system. At the time you see the 'Initialization' message on the CTY, the SCP LEDs are fully operational and reflect the current state below:
- For detailed information of the meaning of these LEDs refer to the KA86 Console Technical Description. Be aware that ALERT may result in a TOTAL-OFF condition.
- 
- * * * * NOTE: An alternating ones & zeros pattern in the SCP LEDs indicate a PROM Segment Switching error. This error can only occur during PROM code execution.
- If, during PROM execution, you get this display, swap the L0201 module.

4.5 CONSOLE SELF TESTS

Console Self Tests

Test	Title
0	PROM Checksum Test
1	SCP SDB Channel Test
2	CTY Interface Mode Register 1 Bit Test
3	CTY Interface Mode Register 2 Bit Test
4	CTY Interface Command Register Bit Test
5	CTY Interface Reset Test
6	CTY Interface TxRDY Bit Test
7	CTY Interface RxRDY Bit Test
10	CTY 9600 BPS Loop Back Test
11	PROM Version Banner Display Test
12	Parity Error Latch Test
13	Parity Circuit Test, Part 1
14	Parity Circuit Test, Part 2
15	58 KB RAM Data/Address Test, Bottom-up
16	58 KB RAM Data/Address Test, Top-down
17	Mapping RAM Location 0 QV Test
20	Mapping RAM Data Test, Bottom-up
21	Mapping RAM Data Test, Top-down
22	Mapping RAM Addressing Test
23	TOY Chip Access Test
24	RTY Interface Mode Register 1 Bit Test
25	RTY Interface Mode Register 2 Bit Test
26	RTY Interface Command Register Bit Test
27	RTY Interface Reset Test
30	RTY Interface TxRDY Bit Test
31	RTY Interface RxRDY Bit Test
32	RTY 1200 BPS Loop Back Test
33	SCP SDB Logic Test
34	CL15 TSTRT Interrupt Test
35	Unexpected Interrupt Test

4.6 VMB UNEXPECTED INTERRUPT TROUBLESHOOTING PROCEDURES

The following procedure may be used to aid in the analysis of boot failures resulting in VMB issuing an UNEXPECTED EXCEPTION message with a HALT PC of 39E.

The procedure patches VMB such that the SCB is initialized to contain VECTOR ADDRESS + 3 for all vectors except those otherwise initialized by VMB (i.e., Machine Check). Normally these vectors would point to the VMB UNEXPECTED EXCEPTION handler.

Execute this procedure as follow:

```
>>>BOOT/NOSTART      Boot without starting - note load
                        address = 200
>>>@VMBFLT           Execute this procedure to patch and
                        start VMB
```

INITIALIZE/BOOT TROUBLESHOOTING PROCEDURES

If an UNEXPECTED EXCEPTION condition occurs the CPU will halt. The HALT PC will reflect the instruction which caused the exception. EBox Scratch Pad location 12 will contain the contents of the exception vector. Examine this location and mask out bits <1:0> to determine the vector address.

For example:

```
CPU stopped, SCB VECTOR<1:0>=3, INVALID (CSM code 07)
PC 00002F0C
>>>>E/ESC 12
      S 12 0000001F
```

The example implies that the instruction which caused the exception is at 2F0C and that we vectored through SCBB 1C (1F with bits <1:0> = 0) indicating a reserved addressing mode.

NOTE

This procedure is only valid for VMB V-4.02 when it is loaded at 200. If FIND/MEMORY should return any value other than 200 in the SP this procedure can be executed manually by adding the value of (SP - 200) to those addresses used below (2600 and 260A).

Also, if using a different version of VMB, examine VMB.MAP to locate PSECT YBTMEM, assuming that the first three (3) instructions relative to the start of this PSECT do not change. This procedure should be modified to use the PSECT YBTMEM (starting address) + 200 for the base address of 2600 and PSECT YBTMEM starting address +20A for the base address of 260A.

VMB Unexpected Interrupt Patch Procedure

Command	Comments
EXAMINE 2600	The contents of this location should be xxxxCF9E reflecting MOVAB BOOTFAULT+1,R6
DEPOSIT * 2038F3C	Replace with MOVZWL 203,R6
EXAMINE/WORD 260A	The contents of this location should be 56D0 reflecting MOVL R6,-(R7)
DEPOSIT/WORD * 76DE	Replace with MOVAL -(R6),-(R7)
SET SNAP OFF	Ensure that the CONSOLE does not create a snapshot file
START 200	Start VMB

INITIALIZE/BOOT TROUBLESHOOTING PROCEDURES

4.7 VMB GPR USAGE

VMB GPR Usage

GPR CONTENTS

R0 BOOT DEVICE TYPE :

<07:00> BOOT DEVICE TYPE CODE:

0	MASSBUS device (RM02/3, RP04/5/6/7, RM80)
1	RK06/7
2	RL01/2
3	IDC (almost an RA80) on 11/730
17	UDA50
32	HSC on CI
64	Console block storage device

<15:08> reserved for future expansion

<31:16> device class dependent (RPB\$W_ROUBVEC)

UNIBUS - optional vector address; 0 implies use
of the default vector

MASSBUS - not used

R1 BOOT DEVICE'S BUS ADDRESS:

11/780 & 11/730 -

<31:04> MBZ

<03:00> TR number of adapter

11/750 -

<31:24> MBZ

<23:00> address of the I/O page for the boot device's
adapter

VAX 8600 -

<31:06> MBZ

<05:04> A-bus Adapter number

<03:00> TR number of the adapter

R2 BOOT DEVICE CSR or CONTROLLER NUMBER or PORT NUMBER:

- UNIBUS: <31:18> MBZ
<17:00> UNIBUS address of the device's CSR

- MASSBUS: <31:04> MBZ
<03:00> adapter's controller/formatter
number

- CI: <31:08> MBZ
<07:00> HSC port number (station address)

R3 BOOT DEVICE UNIT NUMBER:

R4 LOGICAL BLOCK NUMBER:

- logical block number to boot from if bit 3 is set in
R5 (not supported on 11/750)

R5 Software Boot Control Flags:

Bit	Title and Description
0	Conversational boot. At various points in the system boot procedure, the bootstrap code solicits parameters and other input from the console terminal. If the DIAG is also on, then the diagnostic supervisor should enter MENU mode and prompt user for devices to test.
1	Debug. If this flag is set, VMS maps the code for the XDELTA debuggger into the system page tables of the running system.
2	Initial breakpoint. If RPB\$V_DEBUG is set, VMS executes a BPT instruction immediately after enabling mapping.
3	Secondary boot from boot block. Secondary bootstrap is a single 512-byte block, whose LBN is specified in R4.
4	Diagnostic boot. Secondary bootstrap is image called [SYSMAINT]DIAGBOOT.EXE.
5	Bootstrap breakpoint. Stops the primary and secondary bootstraps with a break-point instruction before testing memory.
6	Image header. Takes the transfer address of the secondary bootstrap image from that file's image header. If RPB\$V_HEADER is not set, transfers control to the first byte of the secondary boot file.
7	Memory test inhibit. Sets a bit in the PFN bit map for each page of memory present. Does not test the memory.
8	File name. VMB prompts for the name of a secondary bootstrap file.
9	Halt before transfer. Executes a HALT instruction before transferring control to the secondary bootstrap.
10	No PFN deletion (Not implemented; intended to tell VMB not to read a file from the boot device that identifies bad or reserved memory pages, so that VMB does not mark these pages as valid in the PFN bitmap.)
11	Multi-port memory only. Specifies that multi-port memory is to be used for the total Exec memory requirement. No local memory is to be used. This is for tightly-coupled multi-processing.
12	Multi-port memory combined. Specifies that multi-port memory should be used in addition to local memory, as though both were one single pool of pages.

- 13 Execute extensive memory test.
 Specifies that a more extensive algorithm be used when
 testing main memory for hardware uncorrectable (RDS)
 errors.
- 14 Requests use of MA780 memory if MS780 is insufficient for
 booting. Used for 11/782 installations.
- 15 Used by Diagnostic Supervisor.
- 16 Specifies that memory pages with correctable (CRD) error
 not be discarded at bootstrap time. By default, pages
 with CRD errors are removed from use during the bootstrap
 memory test.

<31:28> Directory Number.

Specifies the top level directory number for system disks
with multiple systems.

The hardware or the CONSOLE program sets up the next 3
registers after a system crash or power failure:

R10 - halt PC
R11 - halt PSL
AP - halt code

SP - <baseaddress + X200> of 64 Kb of good memory

CHAPTER 5

ERRORS AND ERROR ANALYSIS

5.1 SYSTEM FAULT ISOLATION

The information which follows is extracted from the KA86 System Fault Isolation Manual (EK-8600S-MM). Refer to this manual for a detailed description, if required.

The following figure shows the overall organization of error detection, error handling, and error reporting for the KA86 processor. As shown in the figure, each box (MBox, IBox, EBox, and FBox) has its own error detection network. These detection networks constantly monitor for error conditions and report them directly to the EBox (except for the SBIA). The SBIA monitors for external and internal detected errors: external detected errors are reported to the EBox Interrupt Arbitration Logic, and internal detected errors are reported to the MBox, which sends them to the EBox.

5.1.1 EBox Interrupt and Exception Arbitration Logic


All errors, except for MBox and EBox control store parity errors, are reported to the EBox Interrupt and Exception Arbitration Logic. This logic prioritizes the errors and generates a micro-trap vector address which is the starting address of a special EBox microcode routine designed to handle error conditions.

5.1.2 Error Handling Microcode (EHM)

The EHM reads the state of major CPU Control and Status Registers and places the result in the EBox Scratch Pad RAM. This data is referred to as the Machine Check Stack Frame. The Interrupt/Exception micro-routine (not shown) pushes the Machine Check Stack Frame onto the interrupt stack and calls the VMS Machine Check Handler (MCHK).

5.1.3 VMS Machine Check Handler

The MCHK pops the Machine Check Stack Frame off the interrupt stack and puts it in the System Event Buffer, queues the buffer to be appended to the System Event File (ERRLOG.SYS), and either Bugchecks or REIs depending on the severity of the error.



MR-15959

SYSTEM FAULT ISOLATION
(THE BIG PICTURE)

Figure 5-1 System Fault Isolation - Functional Block Diagram

5.1.4 SPEAR (Standard Package for Error Analysis and Reporting)

SPEAR is a maintenance tool designed to sort, analyze, and display the contents of the System Event Files.

5.1.5 Keep Alive Fail (KAF)

The CPU has two KAF mechanisms; one is used by the console to monitor the operation of the CPU, and the other is used by VMS to monitor operation of the console.

5.2 CONSOLE SNAPSHOT FILE INFORMATION

Upon detection of a Keep Alive Failure, the Console will read and log the status of the machine into a snapshot file on the console RL02. Upon VMS system reboot, the snapshot file is transferred from the console to the system error log on the system disk. Since the current system Error Reporting Facility (ERF) does not recognize the format of this snapshot error file, there are a number of additional utility programs that must be used to interpret and analyze the snapshot file. The following text describes how they operate and the flow chart which follows illustrates the utilities.

NOTE

If you need to decode/translate a SNAPSHOT file that is on the RL02 disk, you can:

1. Reboot the system, which will transfer the valid SNAPSHOTS to the system disk. VSR may be used to translate the SNAPSHOT.
2. Call the RDC and ask them to upline dump and translate the SNAPSHOT.
3. Print the SNAPSHOT file using the Console command "SHOW SNAPn.DAT" where n is 1 or 2. Use the System Fault Isolation manual, Appendix D, to decode the console printout.

5.2.1 Guide to Decoding/Analysis of a SNAPSHOT

There is a command procedure that may be run which automatically performs many of the functions shown on the chart. A simplified method using this command procedure follows. Note that this procedure assumes that you have already set up the necessary programs and defaults to run VSRBLD.

1. After VMS is reloaded, the snapshot is transferred to ERRSNAP.LOG;nn
2. Rename the ERRSNAP.LOG;nn file to a unique name such as FILENAME.LOG

3. From the FIELD account, enter the command:

\$ @VSRBLD sys\$error:FILENAME.LOG

4. Either:

- a. Read and decode the output files FILENAME.HDR, FILENAME.SIG and FILENAME.REG; or
- b. Contact the RDC and request assistance (for SNAPSHOT file analysis)

5.2.2 Reference Documentation

VAX 8600 Console Software Specification, Revision 8.1
VSR Package Documentation
KA86 System Fault Isolation Manual, EK-8600S-MM


5.2.3 SNAPSHOT File Flowchart Notes

The following notes support the 'Console SNAPSHOT File Information Flow Chart'. The note number in brackets [n] refers to the circled numbers on the chart.

1. Console RL02 snapshot files: SNAP1.DAT and SNAP2.DAT. These are the original snapshot files as taken by the console hardware upon the detection of a Keep Alive Failure. These files reside on the console RL02. Refer to KA86 System Fault Isolation Manual for a description of the format of these files.
2. Transferring the snapshot file from the console RL02 to a remote system. If the remote system has a logging capability (e.g., VMS with an autodial DF03 using the 'SET HOST/DTE' command), it can connect to the 8600 via the remote port and by using the 'SHOW SNAPn.DAT/ASCII' command, type the snapshot file. This will in effect transfer the snapshot, in ASCII format, to the remote system. This method is also useful for accessing snapshots when a system is down solid.
3. Filenm.TXT is the output file created when the ASCII snapshot file is upline loaded using the 'SHOW SNAPn.DAT/ASCII' command. This file will not have carriage control (it will contain embedded <CR>s, <LF>s).

Note that when SNAPTO.EXE is run to convert this ASCII file into a binary file, an interim step takes place where the .TXT file is converted to a .DMP file using VSRGET.FDL. This step is necessary to create a file with carriage control.

4. SNAPTO.EXE is a program which converts the ASCII snapshot file (created via the 'SHOW SNAPn.DAT/ASCII' command) into a binary file which is suitable for input to the VSRBLD and VSA programs.



MR-15993

Figure 5-2 Console Snapshot File Information Flow Chart

5. Filenm.BIN, Filenm.SNP, or ERRSNAP.LOG;nnn. These are the binary snapshot files. These files may be the output from the SNAPTO.EXE program or they may be part of a system errorlog. In the latter case, the binary snapshot files are actually not part of the system error log, rather each snapshot file is a separate file (ERRSNAP.LOG;nn) with linkages to the system errorlog file.

6. At VMS system startup time, ERRFMT.COM is executed and determines whether or not valid snapshot files exist on the console RL02 pack. If a valid file is present, the file is transferred to the SYS\$ERROR area (filename: ERRSNAP.LOG;nn), an entry with a pointer to the snapshot file is made in the system errorlog file (this is done by ERRFMT.EXE), and the console RL02 snapshot file will be invalidated.
7. VSROLD.EXE is the original bit-to-text translation package that was used to translate these snapshot files. This program is menu driven and can be used for selective translation of the snapshot files. Note that the translation options include only signal names and block dumps; there are no register decodes or sorting done by VSROLD.EXE. The input file for VSROLD.EXE is the binary snapshot files and the output may be either TT: driven or file oriented (refer to the VSROLD menu for more details). The ASCII file signal name tables (*.CDF) are also required as input to VSROLD.EXE.
8. VSRBLD.EXE is used to provide formatted ASCII output from a binary snapshot file. Using a binary snapshot file as input, and the .CDF files as data, VSRBLD generates three output files:
 - o A "Filenm.HDR" file containing information on each record within the snapshot file, including the HEADER record.
 - o Two "Filenm.SIG" files which contain a list of all of the visibility points recorded in the snapshot file. The second version of this file will have the signals sorted alphabetically.
 - o A "Filenm.REG" file containing formatted bit-to-text translation of all records (except the module visibility channels) within the snapshot file.

The combination of all three of these output files represents all of the information available in the snapshot file. There is no error analysis done during the creation of these files, rather it is up to the Field Engineer to manually decode and analyze the snapshot or to contact the Remote Diagnosis Center for assistance.

9. VSA.EXE is used to ANALYZE snapshot files. The input to VSA.EXE includes the ASCII signal file generated by VSRBLD.EXE (*.SIG) as well as the original binary snapshot file (ERRSNAP.LOG;nnn). VSA.EXE will generate two ASCII output files, one containing stall analysis (if applicable) and signals of importance, the second file containing the analysis of embedded stack frames within the snapshot file.

NOTE

VSA.EXE is Company Confidential and the program is NOT AVAILABLE ON SITE. To run VSA, it is necessary to contact the Remote Diagnosis Center, which will upline load the SNAPSHOT File then run VSA.EXE at the remote site.

10. "Filenm.ANL", the output of the SNAPSHOT analysis program, will contain the following information:
 - A list of applicable STALL theories (if any)
 - STALL theory descriptions (optional)
 - Signals of importance (includes error signals that were found in the true state)
 - Default signal list (a list of nice-to-know signals such as UPCs etc.).
11. "Filenm.MC", the second output of the SNAPSHOT analysis program, includes the output of a machine check stack frame if one was found embedded within the snapshot. For example, if the snapshot was the result of a Double Error Halt and a stack frame was found in the EBox scratch pad registers, VSA.EXE will extract and analyze the stack frame and then output the results to this file.

5.3 CONTROL STORE PARITY ERROR CORRECTION

Control store parity errors are prioritized by the EBox, and transmitted as a three-bit code to the console. The presence of any of these three bits will generate a console interrupt, the code indicating which control store is in error. The console will disable external interrupts and suspend the KAF timer to prevent the EBox from interrupting the console and to prevent a keep alive fail condition while the EBox is not executing macro instructions. The console will correct the control store parity error, if possible, and set up the information for the EBox CSER register; the RAM ID, syndrome, CS or DRAM address, and the uncorrectable bit, if correction fails.


If the control store parity error occurs in the EBox, the clock to the control store data register is disabled preventing the EBox from executing any more micro-instructions.

After the console corrects the control store parity error and sets up the CSER register, it will reset the control store parity error and generate an EBox microtrap (CSPE RST LST CYC) with the CSB SDB control channel and "CL UNHANG RESET H". The microtrap will call the EBox error handling microcode.

If the control store parity error is in the IBox or FBox, the EBox will have been informed by the error handling microcode. The EBox will transfer the EHSR to EBCS, which will provide the stimulus to generate the three-bit code for the console. The EBox microcode will then clear RBUFC <07> (DONE) and loop while waiting for DONE to set.

After the console has corrected the parity error and set up the CSER, it will clear the DONE bit, which will allow the EBox error handling microcode to proceed with error logging.

If the control store parity error is in the MBox, there will be no attempt to restart the system because the MBox has already executed the faulty microinstruction.



MR-16385

Figure 5-3 Control Store Parity Error Simplified Flow Chart

5.4 SYSTEMATIC INFORMATION GATHERING PROCEDURES

The following methods can be used to gather information concerning the hardware status after an error.

You should first try to use Method 1. If unable to use this procedure due to something being hung, try Methods 2, 3, 4, and 5. When doing specialized initializations, each succeeding method destroys more and more information.

5.4.1 Method 1

NOTE

SNAP must have been set to "off" prior to the failure.

```
>>> DEB
>>>> STOP CPU
>>>> MIC or TMIC      Find the hung microcode loop
SBSM>>>> SPACE
SBSM>>>> SPACE
SBSM>>>> SPACE
SBSM>>>> SPACE (etc.)
SBSM>>>> CR          To get out of space bar step mode
>>>> UNHANG          Restarts CSM without disturbing anything
>>>> SET QUIET OFF
>>>> @STKFRM          Execute the command file that dumps the ESC
                      locations which may contain a Machine Check
>>>> E MAPEN          Is Memory Management turned on?
>>>> E SP

Use the appropriate command, depending upon the contents of
"MAPEN".

If MAPEN = 1
>>>> E/V/NEXT:100 @   Dump the STACK

If MAPEN = 0
>>>> E/P/NEXT:100 @   Dump the STACK
```

ERRORS AND ERROR ANALYSIS

Continue dumping other registers. The following examines are system configuration dependent.

```
>>>> @RDSBIO          Execute the command file to dump SBIA #0
                        registers

>>>> @RDSBIL          Execute the command file to dump SBIA #1
                        registers if the system has two SBIs

>>>> E/X xxxxxxxxx    Execute the appropriate console commands to
                        examine the SBI NEXUS and peripherals
```

5.4.2 Method 2

```
>>> DEB

>>>> RESET            This will reset the MBox, so the TB is lost

>>>> UNHANG           Restart CSM without disturbing anything

>>>> SET QUIET OFF

>>>> @STKFRM          Dumps ESC locations which may contain a
                        Machine Check

>>>> @RDSBIO          Execute the command file to dump SBIA #0
                        registers

>>>> @RDSBIL          Execute the command file to dump SBIA #1
                        registers if the system has two SBIs

>>>> E/X xxxxxxxxx    Execute the appropriate console commands to
                        examine the SBI NEXUS and peripherals
```

5.4.3 Method 3

```
>>>>INIT/CPU          Resets the CPU. Only the I/O registers will
                        be valid

>>>> @RDSBIO          Execute the command file to dump SBIA #0
                        registers

>>>> @RDSBIL          Execute the command file to dump SBIA #1
                        registers if the system has two SBIs

>>>> E/X xxxxxxxxx    Execute the appropriate console commands to
                        examine the SBI NEXUS and peripherals
```

5.4.4 Method 4

```
>>>>INIT/CPU          Resets the CPU. Only the I/O registers will
                        be valid

>>>>INIT/PAMM         SBIA registers are no longer valid

>>>> E/X xxxxxxxxx    Execute the appropriate console commands to
                        examine the SBI NEXUS and peripherals
```

5.4.5 Method 5

```
>>>>INIT/CPU      Resets the CPU. Only the I/O registers will
                    be valid
>>>>INIT/PAMM      SBIA registers are no longer valid
>>>> UNJAM          The UNIBUS and MASSBUS peripheral devices may
                    contain valid information, but everything
                    else is lost
>>>> E/X xxxxxxxx   Execute the appropriate console commands to
                    examine the SBI NEXUS and peripherals
```

5.5 DUMP.COM

The following command file should be put on each VAX 8600/8650 System RL02 pack.

The purpose of the file is to provide a quick method of executing a hardware dump for keep-alive failures, and whenever you have chosen not to use the "SNAP and VSR/VSA" facilities.

NOTE

The portion of this command file that examines the I/O controllers, and peripheral devices, is system configuration dependent. Therefore, it will have to be modified to reflect the configuration of the system it is to be used on.

After this file is dumped onto the RL02 pack (using the EXCHANGE copy command) you can use it by typing in "@DUMP" to the console prompt. For this information to be valid, "SNAP" must be set "OFF" prior to the failure.

This file must be typed in exactly as is, except for the comments, which may be left out. If you do not wish to type all this in, the command file is available on the ENET. You can then dump it on tape for transporting to the different sites. To have a copy mailed to your node, contact your local support organization.

```
!           Hardware Register & Stack dump command file
DEBUG
SET QUIET OFF
SET ABORT OFF
SET BASE 0
!
!   Get microcode loop PCs
!
STOP CPU
!
MICRO

MICRO

MICRO

MICRO
```

ERRORS AND ERROR ANALYSIS

MICRO

MICRO

MICRO

MICRO

MICRO

MICRO

MICRO

MICRO

UNHANG

HALT

```

!
! Examine SCRATCH PADS - data is as indicated only if
! a machine check was detected and the CPU was halted
! prior to re-entering MACROCODE program.
!
E/ESC 17      ! Byte count in Stack Frame
E/ESC 18      ! EHM.STS - Error Handling Microcode Status
E/ESC 19      ! VMQSAV - sometimes holds VMA for EBox port
E/ESC 1A      ! EBCS - EBox Control and Status
E/ESC 1B      ! EDPER - EBox Data Path Status
E/ESC 1C      ! CSLINT - Console Interrupt Word
E/ESC 1D      ! IBESR - IBox Error Summary
E/ESC 1E      ! EBXWD1 - Last (or 2nd to last) word sent to
!              MBox (write)
E/ESC 1F      ! EBXWD2 - Last (or 2nd to last) word sent to
!              MBox (write)
E/ESC 20      ! IVASAV - IBox Virtual Address
E/ESC 21      ! VIBASAV - VA of next IBUF Port request to fill
!              IBuffer
E/ESC 22      ! ESASAV - EBox Execution/Result storage PC
E/ESC 23      ! ISASAV - PC of instruction Op Port is working on
E/ESC 24      ! CPC - PC of instruction be evaluated in Ibuff
E/ESC 25      ! MSTAT1 - MBox Status
E/ESC 26      ! MSTAT2 - MBox Status
E/ESC 27      ! MDECC - MBox ECC status
E/ESC 28      ! MERG - Memory error status
E/ESC 29      ! CSHCTL - Cache control
E/ESC 2A      ! MEAR - Address in PA latch when error occurred
E/ESC 2B      ! MEDR - Data word in use when error occurred
E/ESC 2C      ! FBXERR - FBox Error (will be FFFFFFFF if no errors)
E/ESC 2D      ! CSES - CS correction (will be FFFFFFFF if no
!              errors)
E/ESC 2E      ! PC - Program PC when error occurred
E/ESC 2F      ! PSL - Processor Status Longword
!
! Examine all Scratch Pads, CPU registers, and I/O registers.
! Also verify contents of all Control Store RAMs.
!
E/ESC/N:FF 0  ! Dump all EBox Scratch locations
!
E/G/N:F 0     ! General Purpose Registers
!
E/I/N:24 0    ! Internal Registers
!

```

ERRORS AND ERROR ANALYSIS

[illegible]

5.6 PROGRAM TO SCAN MEMORY FOR PARITY ERRORS (SCAN.COM)

```
>>> DEB
>>>> SET SNAP OFF
>>>> DEP R0 0           ; setup starting address
>>>> DEP R1 0           ; temporary storage
>>>> DEP 100 175180D0    ; MOVL (R0)+,R1
>>>> DEP 104 0001009F    ; JUMP @#100
>>>> DEP 108 0           ; HALT
>>>> DEP SCBB 200        ; place SCB starting at location 200
>>>> DEP 204 207        ; setup Machine Check trap catcher.
>>>> DEP 254 257        ; setup SBE trap catcher.
>>>> DEP PSL 41C0000     ; allows interrupts from "1D" up.
                        ; MBox interrupt is at "1F".
>>>> DEP SP 1000        ; setup Stack Pointer.
>>>> DEP EHSR 0.         ; Clears all CPU error bits.
>>>> ST 100
```

; Should halt with ESC #12, and ESC #C4, containing a 207.
; This indicates that a machine check has occurred. Verify
; that the Machine Check was the result of a NXM by dumping
; ESC and checking errors.

; If ESC #12 contains 254 and ESC #C4 contain a 257, the
; problem was a single-bit error (SBE).

```
>>>> E/ESC 12
```

```
>>>> @STKFRM
```

; or dump all ESC locations with the following command:

```
>>>> E/ESC/N:FF 0
```

5.7 VMS AND THE SYSTEM EVENT FILE (ERRLOG.SYS)

The VMS Operating System maintains a System Event File called ERRLOG.SYS. The file is located in the SYSSYSROOT:[SYSERR] directory and is used to record errors, status changes, messages, and other events that occur during system operation.

Each time one of these events occur, the normal operation of VMS is interrupted and a special routine is called to handle the event. The routine requests a System Event Buffer and then gathers pre-defined information about the event (e.g., system status, hardware and software registers, etc.) and puts it in the buffer. Once the buffer is built the routine queues a request to append the buffer to the System Event File. When the queue is processed the buffer is appended to SYS\$SYSROOT:[SYSERR]ERRLOG.SYS.

Two programs (ANALYZE/ERRORLOG and RETRIEVE - a Spear Library function) are available to translate the contents of the System Event File into ASCII reports. Both of these programs use the Event Record Formatter (ERF) to translate the entries in the Event File. Therefore, regardless of which program you use the format of the translated entries will be the same. The main difference between the two programs is the command syntax, the selection criteria, and the format of the summary reports they produce. In addition to translating system event file entries Spear is capable of analyzing the contents of the event file and calculating system availability.

5.7.1 ANALYZE/ERRORLOG

ANALYZE/ERRORLOG uses a non-interactive command syntax. That is, the Command, Qualifiers and Arguments, are entered in a single string. The Qualifiers allow you to select specific entries from a binary System Event File and either produce a separate binary event file that contains only those entries, or translate the entries and produce an ASCII Report. For a complete description of this utility, including more information about the ANALYZE/ERRORLOG command and its qualifiers, see the VAX/VMS Utilities Reference Volume.

5.7.2 SPEAR Library Functions

SPEAR is a maintenance tool specifically designed to help Field Service Engineers sort and analyze the contents of System Event Files. There are two versions of Spear: SPEAR Basic and SPEAR Extended.

5.7.2.1 SPEAR Basic - SPEAR Basic is available at all sites that have a DEC Maintenance Contract. This version of SPEAR consists of five programs:

- **Instruct** - Instruct is a computer based instructional program that is designed to help new users learn to use the SPEAR Library Programs. In addition to explaining the SPEAR Programs, instruct also describes the organization of system event files and includes a review of some of the most common troubleshooting approaches.
- **Compute** - Compute is designed to use the contents of the System Event File to calculate system availability and effectiveness. The Compute report can be used (in part) to determine if the system is approaching the point where corrective maintenance will soon be required.

- Summarize - Summarize is designed to summarize the contents of the system event file. The Summarize report can be used to determine whether the CPU or one of the I/O subsystems needs further investigation.
- Retrieve - Retrieve is a bit-to-text translator. It is designed to extract specific entries from the System Event File and produce either a brief or full translation of the event. This information can be used to investigate the cause of CPU and I/O failures.
- VSR (Venus Snap File Report Builder) - This program was added to the Basic SPEAR Library specifically to support VAX 8600/8650 Systems. Like Retrieve, VSR is a bit-to-text translator. VSR, however, is designed to translate SNAP Files. A SNAP file is a file built by the console as a result of a Keep Alive Fail condition.

5.7.2.2 SPEAR Extended - SPEAR Extended is only available at Remote Diagnosis Centers. In addition to the programs that are available in SPEAR Basic, Spear Extended includes:

- Analyze - Analyze is designed to analyze the contents of large System Event Files and identify the most probable cause of certain failures. Analyze evaluates the events in a System Event File against a set of If-Then Isolation Theories. If the Events support a theory then the theory is displayed for consideration by the Engineer at the RD center.
- VSA (Venus Snap File Analysis Builder) - VSA is similar to Analyze except it is designed to analyze the contents of System SNAP Files.



CHAPTER 6

DIAGNOSTICS

NOTE

Chapter 6 will cover:

- EMM SELF TEST
- T11 (PROM) SELF TEST
- PROM COMMAND SET
- CONSOLE MODULE DIAGNOSTIC (ED0BA)
- MICRO-HARD-CORE DIAGNOSTIC (EDKAA)
- MHC COMMAND SET
- MICRO DIAGNOSTICS
- MICRO DIAGNOSTIC COMMAND SET
- MICRO DIAGNOSTIC COMMAND FILES
- DIAGNOSTIC SUPERVISOR (EDSAA)
- MACRO DIAGNOSTICS

The remaining command sets, GENERAL, MACRO, and HEX are located in Chapter 10, Console Commands.

DIAGNOSTICS
EMM SELF TEST

6.1 EMM SELF TEST

When the VAX 86xx is first turned on and power is applied to the EMM, the EMM will automatically run a set of Self Tests. The tests are listed in Table 6-1. The EMM uses the Error Codes listed in Table 6-2 to inform the console of error conditions.

6.1.1 Prerequisites

None

6.1.2 EMM Self Test Descriptions

Table 6-1 EMM Self Test

TEST	DESCRIPTION																		
ROMCHK	ROM Checksum Verification - Compute the ROM checksum and verify that it is correct.																		
UTEST1	Data test for MODE registers - Tests that MODE1, MODE2, and COMMAND registers can hold 125 and 252 This test doesn't verify that they are separately addressable. See Note 1.																		
UTEST2	Test Addressability of USART Registers - Verifies that MODE and COMMAND registers are independently addressable and that they can hold data without interfering. See Note 1.																		
UTEST3	Test USART in Local Loopback - Tests status register and data registers at 9600 baud (We don't test for some errors, e.g., framing and overrun, which could be forced, since the protocol will exclude incorrect messages because they don't checksum.) See Note 1.																		
RTEST1	Parity Circuit, Part 1 - The following algorithm is used to test parity for each RAM. <ol style="list-style-type: none">1. Disable RST 0 ON PARITY ERROR. If a RST 0 occurs because of a parity error it indicates that the RST 0 ON PARITY ERROR circuit could not be disabled.2. Select parity to be generated (GEN PAR)3. Write DATA pattern to first RAM location (2000H)<table><tr><td>GEN</td><td>TEST</td><td>PAR</td></tr><tr><td>PAR</td><td>DATA</td><td>ERR</td></tr><tr><td>ODD</td><td>10001010</td><td>YES</td></tr><tr><td>ODD</td><td>01010101</td><td>YES</td></tr><tr><td>EVEN</td><td>11101100</td><td>NO</td></tr><tr><td>EVEN</td><td>00110011</td><td>NO</td></tr></table>4. Read pattern back from first RAM location	GEN	TEST	PAR	PAR	DATA	ERR	ODD	10001010	YES	ODD	01010101	YES	EVEN	11101100	NO	EVEN	00110011	NO
GEN	TEST	PAR																	
PAR	DATA	ERR																	
ODD	10001010	YES																	
ODD	01010101	YES																	
EVEN	11101100	NO																	
EVEN	00110011	NO																	

5. Test returned DATA pattern. If error, report:
 - BAD DATA RAM LOCATION
6. Test for expected PAR ERR condition. If error, report:
 - BAD PARITY GENERATOR CIRCUIT, or
 - BAD PARITY RAM LOCATION, or
 - BAD PARITY-CHECK CIRCUIT
7. Repeat above steps for all TEST DATA

RTEST2 Parity Circuit, Part 2 - The following algorithm is used to test parity for each RAM.

1. Enable RST 0 ON PARITY ERROR
2. Set indicator so "RST 0" routine will know that this is a forced error.
3. Select ODD parity generation
4. Write something into FIRST RAM location and read it back
5. If no RST 0 occurs, report:
 - "PARITY ERROR FAILED TO RESET CPU"

RTEST3 RAM Data Test - The following algorithm is used to test data for each RAM.

1. Disable RST 0 ON PARITY ERROR
2. Select EVEN parity generation
3. Write data pattern into RAM location:

TEST DATA	PAR BIT	PAR ERR
00110011	0	NO
01010101	0	NO
10101000	1	NO

4. Read RAM location and compare result.
 - If compare fails in low-order nibble (bits 0-3)
report: "BAD DATA RAM LOCATION, LOW-ORDER NIBBLE"
 - If compare fails in high-order nibble (bits 4-7)
report: "BAD DATA RAM LOCATION, HIGH-ORDER NIBBLE"

DIAGNOSTICS
EMM SELF TEST

5. Test PAR ERR flag. If PAR ERR report: "BAD PARITY RAM LOCATION"
6. Repeat steps for all patterns and all RAM locations

RTEST4 RAM Addressing and Cell Interference Test - The following algorithm is used to test data for each RAM.

1. Disable RST 0 ON PARITY ERROR circuit
2. Generate RAM data pattern from column 'a'.
 - For '-1' values, select ODD parity generation.
 - For '0' values, select EVEN parity generation.

TEST DATA

[illegible]

3. Verify RAM data pattern. If error, report:
- "BAD DATA RAM ADDRESS SELECT"

4. Check for expected PAR ERR condition: (-1 data should have PAR ERR), (0 data should not have PAR ERR). If failure, report:

- "BAD PARITY RAM ADDRESS SELECT"

5. Repeat steps for each column

I55TST Test 5.5 Interrupt - Tests that if the output of the LAT DC LO flip flop is asserted, that it generates a 5.5 interrupt request to the CPU and that an interrupt will occur. This is not meant to be a comprehensive test, nor is a fault considered to be fatal.

I75TST Test 7.5 Interrupt - Tests that the RX CLK output of the USART and the 4 bit CTR work to cause interrupts at 840 microsec intervals. Failures are either that no interrupt request could be seen at the CPU when it should have existed, that when it did exist at the CPU no interrupt occurred, or that it did not time correctly.

NOTE

1. UERR (Error Handler for all USART Errors) - If a USART Test fails, toggle the Magnetic Disk Display once then loop on failing test. In order to toggle the disks, LAT AC LO must be deasserted. In a power up situation, this will not hurt the main CPU because the regulators have not been turned on yet. If the error is intermittent, the console may have to relatch the AC LO and then unlatch it again after LAT DC LO has been deasserted.
 2. The self test checks the USART, ROM, and RAM. Any errors detected during the self-test are reported by HDCODE, which sends A unique character for each error (see Table 6-2 below), waits 5 seconds, and returns to the Failing test (Loop on Error).
-

DIAGNOSTICS
EMM SELF TEST
T-11 (PROM) SELF TEST

6.1.3 EMM Error Code Descriptions

Table 6-2 EMM Error Code Descriptions

Code	Error Code Description
@	Module A not OK, sent at end of self-test
A	Completed self test successfully
B	Parity ERROR, either due to Parity Generator or Parity Checker or BAD Parity RAM
C	RAM Data ERROR - LOW order nibble
D	RAM Data ERROR - BOTH nibbles (might be addressing problem)
E	RAM Data ERROR - HIGH order nibble
F	Parity Error did not cause RESET to PC = 0
G	Parity RAM Data ERROR
H	Had Parity ERROR indication before accessing RAM (in SETCODE)
I	ROM had Checksum ERROR
J	LAT DC LO did not set 5.5 Interrupt request. No loop on error
K	5.5 Interrupt request did not cause interrupt. No loop on error
L	7.5 Interrupt set after CPU reset
M	1/2 CHAR timer did not set interrupt request (or set it at the wrong rate)
N	7.5 Interrupt request did not cause interrupt
O	7.5 Interrupt did not reset

6.2 T-11 (PROM) SELF TEST

During power-up, the T-11 microprocessor executes the PROM self-tests to validate the console module hardware logic. If the Self Test runs successfully then the PROM Code will sound the Bell on the CTY (RTY). If the operator responds within 5 seconds by pressing a any key on the keyboard the PROM Code will display the PROM Prompt; ROM> and enter Command Mode. The PROM Command set is described in Table 6-3. The individual tests are described in Table 6-4.

6.2.1 Prerequisites

Successful EMM Self Test and Power-up.

6.2.2 PROM Command Set

The PROM code signals the completion of the self-tests by sending the bell character to the CTY. At that point the operator can type any key to signal the PROM to enter its command loop. The PROM code indicates its readiness for input by displaying the ROM> prompt.

While in the null loop, the PROM code may service the CTY as well as the RTY (provided the front panel switch is in the REMOTE position and a remote connection has been made). The command parser in the PROM is extremely simple. It accepts single-character commands and alphanumeric arguments. The available commands are listed in Table 6-3.

Table 6-3 PROM Command Set

Command	Description
B	<p>B<cr> Boot the console software from the RL02. This command begins by testing the interface between the console and the RL02 controller. The sequence of tests follows.</p> <ol style="list-style-type: none"> 1. Checks for AC LOW and DC LOW conditions in the BALL. 2. Checks that console-generated BUS INIT reaches the RL02 controller and clears all RL02 controller registers. 3. Checks that RLCS, RLBA, and RLDA will retain a full complement of patterns. 4. Performs an RL02 MAINTENANCE TRANSFER to verify DMA logic between the console and RL02, and other logic on the RLV12 controller. 5. Checks that the first word read in from the RL02 boot block contains "240" (NOP). <p>If any of the above checks fail, a message is reported to both the CTY and RTY, and the B command aborts. There is no test looping capability. If a drive or controller status error is detected during the actual booting of the device, a number of retries are made.</p>
D	<p>D addr data<cr> Deposit the data word to the specified address. The address must be an even number.</p>
E	<p>E addr<cr> Examine the data word at the specified address. Odd addresses are made even by dropping the low order bit.</p>
S	<p>S addr<cr> Start the T-11 execution at the specified address. The address must be an even number. The command-argument delimiter is optional.</p>
T	<p>T file.ext<cr> Without any argument, this command reruns the PROM self-tests and then loads and runs the console diagnostic program (ED0BA) for two passes. If a filename is specified, the self-tests are not run and the file is loaded and started at location 200. The default filename extension is .SAV.</p>

NOTE

The console diagnostic ED0BA invoked with the PROM T command tests the RTY interface which causes the remote port to be disconnected. This prevents running ED0BA from the remote port.

DIAGNOSTICS
T-11 (PROM) SELF TEST

- Q** **Q addr data<cr>**
This command allows direct deposits to QBus registers. The addresses 174400, 174402, 174404, and 174406 are the RLCS, RLBA, RLDA, and RLMPR registers, respectively. All other addresses are rejected.
- R** **R addr<cr>**
This command allows direct examines of QBus registers. The addresses 174400, 174402, 174404, and 174406 are the RLCS, RLBA, RLDA, and RLMPR registers, respectively. All other addresses are rejected.
- V** **V<cr>**
With this command, the PROM code enters a loop which allows characters to pass directly between the CTY and RTY. The escape sequence "<CTRL/P><CTRL/X><CTRL/P>" can be entered from either input device to force the PROM code to exit this mode.
- X** **X<cr>**
This command complies (less any switches) with the description of same in Chapter 11 of Digital Standard 032. It is intended to be used for binary data transfers between T-11 memory and a computer using the remote port input. It is not intended for human use and will work properly only when issued from the RTY device.
-

6.2.3 T-11 (PROM) Self Test Descriptions

NOTE

Failures in tests 1 through 10 are indicated in the System Control Panel LEDs.

From test 11 onm, test failures are reported on the CTY (RTY) because the CTY interface, the cable, and the printer are assumed to be operational.

Table 6-4 T-11 (PROM) Self Test Descriptions

TEST DESCRIPTION

- 00 PROM CHECKSUM TEST - An additive checksum of both the lower and upper segments of the PROM is calculated. The result should be 377(8). On error, a "BR ." is executed.

LED state = 1111

- 01 SCP SDB CHANNEL TEST - A floating 1 pattern is shifted through the LEDs at a fairly slow speed so the operator can tell if there is a LED failure. The test checks most of the SDB control logic and the SCP LED logic which is used by subsequent tests to report test numbers. The test is open-ended and cannot fail.

LED state = 0001 --> 0010 --> 0100 --> 1000

- 02 CTY INTERFACE MODE REGISTER 1 BIT TEST - Alternating 01010101 and 10101010 patterns are written and read from the CTY's PCI_MODE_REGISTER_1.
LED state = 0010
- 03 CTY INTERFACE MODE REGISTER 2 BIT TEST - Alternating 01010101 and 10101010 patterns are written and read from the CTY's PCI_MODE_REGISTER_2.
LED state = 0011
- 04 CTY INTERFACE COMMAND REGISTER BIT TEST - Both a 01010101 and a 10101010 pattern are written and read from the CTY's PCI_COMMAND_REGISTER.
LED state = 0100
- 05 CTY INTERFACE RESET TEST - A pattern is loaded into the PCI_COMMAND_REGISTER and a PCI RESET is performed. If the command register clears, then the PCI's RESET input is connected and working.
LED state = 0101
- 06 CTY INTERFACE TXRDY BIT TEST - The local PCI is configured to run in its normal operating mode (9600 baud, 8-bit, no parity, 1 stop bit). The TXRDY bit in the PCI status register is then expected to set within 100 ms. If ok, the PCI transmit register is loaded and the TXRDY bit is expected to clear immediately.
LED state = 0110
- 07 CTY INTERFACE RXRDY BIT TEST - The local PCI is reinitialized, but this time in local loop back mode. A character is transmitted and the RXRDY bit in the PCI status register is expected to set. When the RECEIVED_CHARACTER_REGISTER is read, the RXRDY bit is expected to clear.
LED state = 0111
- 10 CTY INTERFACE LOOPBACK TEST - LED state = 1000 This is essentially the same as the previous test except that several loopback transmissions are performed to ensure the PCI and crystal can handle it.
LED state = 0111
- 11 CTY BANNER TEST - LED state = 1001 This is an open-ended test that relies on the operator to observe the system banner.
LED state = 0111
- 12 PARITY ERROR LATCH TEST - Tests whether the latch responsible for indicating parity errors can be set and cleared directly.
- 13 PARITY CIRCUIT TEST, PART 1 - Simultaneously tests that RAM location 0 will hold a 01010101 pattern. If all right, parity RAM location 0 is expected to contain 1.

DIAGNOSTICS
T-11 (PROM) SELF TEST

- 14 PARITY CIRCUIT TEST, PART 2 - Simultaneously tests whether RAM location 0 will hold a 10101010 pattern. If all right, parity RAM location 0 is expected to contain 0 (since the "force parity error" bit in MCSR0 was set prior to depositing the pattern).
- 15 58 KB RAM DATA/ADDRESS TEST, BOTTOM-UP - A modified moving-inversions test is performed on the first 58 Kbytes of physical RAM. The test verifies all data faults that are likely to occur in the console RAM configuration, as well as verifying all addressing faults in the positive (incrementing) direction. On error, the address, expected data, and received data are displayed.
- 16 58 KB RAM DATA/ADDRESS TEST, TOP-DOWN - A modified moving-inversions test is performed on the first 58 Kbytes of physical RAM. The test verifies all data stuck-at faults likely to occur in the console RAM configuration, as well as all addressing faults in the negative (decrementing) direction. On error, the address, expected data, and received data are displayed.
- 17 MAP RAM LOCATION 0 QV TEST - A loop is first performed that uses the first mapping RAM location (MAPR00) to initialize all of physical memory with 0's and good parity, and places each 4 Kbyte page number in the first location of its own 4 Kbyte page boundary. The process is repeated to check that the first byte of each page contains the correct value.
- 20 MAPPING RAM DATA TEST, BOTTOM-UP - This test uses the memory pattern verified by the previous test to check that all mapping RAM locations can access pages uniquely, in the positive direction.
- 21 MAPPING RAM DATA TEST, TOP-DOWN - This test uses the memory pattern verified by the previous test to check that all mapping RAM locations can access pages uniquely, in the negative direction.
- 22 MAPPING RAM ADDRESSING TEST - This test uses the memory pattern verified by the previous tests to check that all mapping RAM locations are themselves uniquely addressable. The memory mapper is then turned off.
- 23 TOY CHIP ACCESS TEST - This test checks that registers in the console's TOY chip can be accessed to verify that the TOY chip is receiving power from the +5 B signal input from the BBU.
- 24 RTY INTERFACE MODE REGISTER 1-BIT TEST - Normal operation patterns are loaded into the RTY's PCI_MODE_REGISTER_1 and checked.
- 25 RTY INTERFACE MODE REGISTER 2-BIT TEST - Normal operation patterns are loaded into the RTY's PCI_MODE_REGISTER_2 and checked.
- 26 RTY INTERFACE COMMAND REGISTER BIT TEST - Both a 01010101 and a 10101010 pattern are written and read from the RTY's PCI_COMMAND_REGISTER.
- 27 RTY INTERFACE RESET TEST - A pattern is loaded into the PCI_COMMAND_REGISTER and a PCI RESET is performed. If the command register clears, it means the PCI's RESET input is connected and working.

- 30 RTY INTERFACE TXRDY BIT TEST - The remote PCI is configured to run in its normal operating mode (1200 baud, 8-bit, no parity, 1 stop bit). The TXRDY bit in the PCI status register is then expected to set within 100 ms. If ok, the PCI transmit register is loaded and the TXRDY bit is expected to clear immediately.
- 31 RTY INTERFACE RXRDY BIT TEST - The remote PCI is reinitialized, but this time in local loopback mode. A character is transmitted and the RXRDY bit in the PCI status register is expected to set. When the RECEIVED CHARACTER REGISTER is read, the RXRDY bit is expected to clear.
- 32 RTY INTERFACE LOOPBACK TEST - This test duplicates the function of the previous test in order to verify that the remote PCI can handle consecutive character transmissions.
- 33 SCP SDB LOGIC TEST - This test checks the continuity of the SDB control channel on the SCP. This test will affect the state of the front panel LEDs, but is done so quickly it is unnoticeable.
- 34 "CL15 TSTRT" INTERRUPT TEST - This test checks that the TSTRT interrupt input to the console is not asserted. This interrupt is not maskable through the PSW, so it must be cleared before the console program will run.
- 35 UNEXPECTED INTERRUPT TEST - This test checks that after a full console reset there are no pending (or stuck) interrupts to the T-11 microprocessor. This ensures the proper start-up of RT and the console kernel. <CTRL/E> - Exit failed test loop is also available.

NOTE

Allowable control characters for tests 12 - 35 are:

- <CTRL/S> - Stop test execution.
- <CTRL/Q> - Resume test execution.
- <CTRL/O> - Suppress Error Report

DIAGNOSTICS
CONSOLE MODULE DIAGNOSTIC (ED0BA)

6.3 CONSOLE MODULE DIAGNOSTIC (ED0BA)

ED0BA is a T-11 based console module diagnostic designed to test all the logic on the console module, including the console sections of the clock, SDB, CBus, Q-Bus, and local and remote PCI interface logic. ED0BA does not test any logic in the VAX CPU logic itself.

6.3.1 Prerequisite

The T-11 (PROM) Self Test must have run error free.

6.3.2 ED0BA Switch Register Options

BIT	SWITCH	DESCRIPTION
<15>	100000	Exit subtest loop and proceed
<14>	040000	Loop on failing subtest
<13>	020000	Inhibit error display
<12>	010000	Enable trace
<11>	004000	Inhibit test iterations
<09>	001000	Loop on test number in <07:00>
<07:00>	000xxx	Select test xxx for loop

6.3.3 ED0BA Control Characters

Control Key	Function
<CTRL/C>	Restart ED0BA
<CTRL/S>	Suspend output
<CTRL/Q>	Resume output
<CTRL/U>	Erase command line
<CTRL/G>	Enter SWR-CHANGE mode
<CTRL/P>	Exit to the PROM CLI

6.3.4 ED0BA Test Descriptions

TEST NO.	DESCRIPTION	NO. OF SUBTESTS
SDB Control Logic Tests		
001	SDMS Register Test (CL20)	3
002	Sddb Register Test (CL20)	3
003	SDCS Register Test (CL20)	3
004	CL18 Stop Clock Test (CL18)	2
005	DB Single Step Mode Test (CL19)	3
006	SDB Normal Mode Test (CL19)	2
007	SDB Loopback Test, Normal Mode (CL19)	2

Tester SDB Channel Continuity Tests

010*	SDB Channel 00 Continuity Test (CL21)	1
011*	SDB Channel 01 Continuity Test (CL21)	2
012*	SDB Channel 02 Continuity Test (CL21)	2
013*	SDB Channel 03 Continuity Test (CL21)	1
014*	SDB Channel 04 Continuity Test (CL21)	2
015*	SDB Channel 05 Continuity Test (CL21)	1
016*	SDB Channel 06 Continuity Test (CL21)	2
017*	SDB Channel 07 Continuity Test (CL21)	1
020*	SDB Channel 08 Continuity Test (CL21)	1
021*	SDB Channel 09 Continuity Test (CL21)	1
022*	SDB Channel 10 Continuity Test (CL21)	1
023*	SDB Channel 11 Continuity Test (CL21)	1
024*	SDB Channel 12 Continuity Test (CL21)	1
025*	SDB Channel 13 Continuity Test (CL21)	2
026*	SDB Channel 14 Continuity Test (CL21)	2
027*	SDB Channel 15 Continuity Test (CL21)	1
030*	SDB Channel 16 Continuity Test (CL21)	1
031*	SDB Channel 17 Continuity Test (CL21)	1
032*	SDB Channel 18 Continuity Test (CL21)	1
033*	SDB Channel 19 Continuity Test (CL21)	1
034*	SDB Channel 20 Continuity Test (CL21)	1
035*	SDB Channel 21 Continuity Test (CL21)	1
036*	SDB Channel 22 Continuity Test (CL21)	1
037*	SDB Channel 23 Continuity Test (CL21)	1

Miscellaneous Register Tests

040	MCSR0 Register Test (CL08)	3
041	MCSR1 Register Test (CL08)	2
042	MCSR2 Register Test, Part 1 (CL08)	3
043	MCSR2 Register Test, Part 2 (CL08)	3

Miscellaneous Console Functions Tests

044*	CL09 DC Low Test (CL20)	2
045*	CL CSM Request Test (CL09)	2
046*	EMM3 CPU AC Low Test (CL08)	2
047*	CL09 System AC Fault Test (CL08)	4
050*	CL CPU Power Fail Interrupt Test (CL09)	2
051*	CL Unhang Reset Test (CL18)	2
052*	CL Master Reset Test (CL09)	2
053*	CL ABUS Enable Test (CL09)	2
054*	CL Array DC OK Test (CL09)	3
055*	CL09 CPU Alive Test (CL08)	3
056*	CL09 Error 0 Test (CL08)	2
057*	CL09 Error 1 Test (CL08)	2
060*	CL09 Error 2 Test (CL08)	2
061*	CL09 CPU Control Store PE Test (CL08)	6
062*	CL09 ABUS Request 0 Test (CL08)	2
063*	CL09 ABUS Request 1 Test (CL08)	2
064*	CL09 ABUS Request 2 Test (CL08)	2
065*	CL09 ABUS Request 3 Test (CL08)	2
066*	CL09 ABUS Dead Interrupt Test (CL08)	5
067*	SID0 Register Test (CL12)	2
070*	SID1 Register Test (CL12)	2
071*	SID2 Register Test (CL12)	2
072*	CL ID0 Bit Test (CL08)	2
073*	CL ID1 Bit Test (CL08)	2
074*	CL ID2 Bit Test (CL08)	2

DIAGNOSTICS
CONSOLE MODULE DIAGNOSTIC (ED0BA)

EMM PCI Tests

075	EMM PCI Mode Register 1 Test (CL10)	3
076	EMM PCI Mode Register 2 Test (CL10)	3
077	EMM PCI Command and Status Register Tests (CL10)	4
100	EMM PCI Register Addressing Tests (CL10)	3
101	EMM PCI TXRDY Bit Test (CL10)	1
102	EMM PCI Local Loopback Test, 19.2K Baud (CL10)	1
103	EMM PCI Bus Loopback Test, 19.2K Baud (CL10)	1
104	EMM PCI Bus Inhibit Test (RTS Deasserted) (CL10)	1

Remote PCI Tests, Part 1

105	Remote PCI Mode Register 1 Test (CL10)	3
106	Remote PCI Mode Register 2 Test (CL10)	3
107	Remote PCI Command and Status Register Tests (CL10)	4
110	Remote PCI Register Addressing Tests (CL10)	3

Remote PCI Tests, Part 2

111*	CDSRS Test (CL11)	2
112*	CL11 RTERM Carrier Test (CL10)	2
113*	CL11 RTERM DSR Test (CL10)	2
114*	CRTS Test (CL10)	2
115*	Assert CDTR Test (CL10)	2
116*	REMOTE PCI TXEMT/DSCHG Test (CL10)	1
117*	CL RTERM DSC Test (CL10)	1
120*	REMOTE PCI TXRDY Test, Part 1 (CL10)	1

Remo PCI Tests, Part 3

121	Remote PCI Local Loopback Test, 75 Baud (CL10)	1
122	Remote PCI Local Loopback Test, 110 Baud (CL10)	1
123	Remote PCI Local Loopback Test, 150 Baud (CL10)	1
124	Remote PCI Local Loopback Test, 1800 Baud (CL10)	1

Remote PCI Test, Part 4

125*	Remote PCI Split Baud Rate Test (CL10)	1
------	--	---

SCP Interface Tests, Part 1

126	SCP Channel Continuity Test (SCP1)	1
127	SCP Channel Init Test (SCP1)	1
130	SCP LED Drive/Sense Test (SCP1)	3

SCP Interface Tests, Part 2

131*	SCP Switch Input Test (SCP1)	2
------	------------------------------	---

CBUS Tests, Part 1

132	CL15 TSEL Test (CL13)	3
133*	CL15 TXCS RDY Test, Part 1 (CL13)	3
134*	CL15 RXCS DNE Test, Part 1 (CL13)	3
135*	CL15 STOR RDY Test, Part 1 (CL13)	3
136	CL15 TSTRT Test (CL13)	3

CBUS Tests, Part 2

137*	CBus RAM Data Test, TTL Port, Part 1 (CL16)	2
140*	CBus RAM Addressing Test, TTL Port (CL16/CL17)	1
141*	CBus Access Test, ECL Port (CL16)	2
142*	CBus RAM Addressing Test, ECL Port (CL16/CL17)	1
143*	CL15 TXCS IE Test (CL13)	5
144*	CL15 RXCS IE Test (CL13)	5
145*	CL15 STOR TIE Test (CL13)	5
146*	CL15 TSTRT Test (CL13)	4
147*	CL15 TXCS RDY Test, Part 2 (CL13)	2
150*	CL15 TXCS RDY Test, Part 3 (CL13)	2
151*	CL15 RXCS DNE Test, Part 2 (CL13)	2
152*	CL15 RXCS DNE Test, Part 3 (CL13)	1
153*	CL15 STOR RDY Test, Part 2 (CL13)	2
154*	CL15 STOR RDY Test, Part 3 (CL13)	1
155*	CL15 TSEL Sensed by ECL Port Test (CL13)	2
156*	CL TTX Interrupt Test (CL15)	4
157*	CL TRX Interrupt Test (CL15)	4
160*	CL RL02 Interrupt Test (CL15)	4

TOY Clock Tests

161	TOY Software-Master-Reset Test (CL22)	16
162	TOY Counter Group 1 Register Test (CL22)	8
163	TOY Counter Group 2 Register Test (CL22)	8
164	TOY Counter Group 3 Register Test (CL22)	8
165	TOY Counter Group 4 Register Test (CL22)	8
166	TOY Counter Group 5 Register Test (CL22)	8
167	TOY Master Mode Register Test (CL22)	2
170	TOY Counter Register Count Test (CL22)	15
171	CL22 TOY 15 Out Test (CL22)	1

RAM Parity Tests

172	RAM Data Parity Tests (CL06)	3
-----	------------------------------	---

Mapped RAM Data and Addressing Tests (64 TO 256 Kbytes)

173	Mapped RAM Data/Addressing Test (CL04)	2
-----	--	---

T-11 Interrupt Tests

174	CL19 ENA TXRDY Test (CL20)	3
175	CL19 ENA STOR RDY Test (CL20)	3
176	Unsolicited Interrupt Test (CL02)	3
177	CL15 TSTRT Interrupt Test (CL02)	3
200	CL04 CSL PE Internal Interrupt Test (CL02)	6
201*	CL09 System AC Fault Interrupt Test, Part 1 (CL02)	5
202	CL09 ABUS Dead Internal Interrupt Test (CL02)	4
203	CL22 TOY LMS Internal Interrupt Test (CL02)	6
204	CL15 TXCS RDY Interrupt Test (CL02)	5
205	CL15 STOR RDY Interrupt Test (CL02)	5
206	CL31 QBA Internal Interrupt Test (CL02)	6
207	CL10 ETERM RDY Interrupt Test (CL02)	5
210	CL11 RTERM Internal Interrupt Test (CL02)	6
211	CL10 Local RDY Interrupt Test (CL02)	5
212	CL30 RPLY Timeout Interrupt Test (CL02)	4

T-11 Interrupt Tests

213*	CL09 CPU Control Store PE Interrupt Test (CL02)	4
214*	T-11 Manual Restart Interrupt Test (CL02)	3

DIAGNOSTICS
CONSOLE MODULE DIAGNOSTIC (ED0BA)

QBUS Adapter Tests

215	QCSR0 Register Test (CL29)	4
216	QCSR1 Register Test (CL29)	3
217	QBA Address Register Test (CL27)	2
220	QBA Data Register Test (CL27)	2
221	CL31 CSL Master Pend Test (CL29)	5
222	QBA Timeout Counter Test (CL20)	6
223	CL30 RPLY Timeout Test, Part 1 (CL20)	6
224	QBA Simulated-Read-Cycle Test, Part 1 (CL23)	13
225	QBA Simulated-Read-Cycle Test, Part 2 (CL23)	2
226	QBA Simulated-Write-Cycle Test (CL23)	13
227	QBA Simulated-Intr-Ack-Cycle Test, Part 1 (CL23)	8
230	QBA Simulated-Intr-Ack-Cycle Test, Part 2 (CL23)	3
231	CL32 SREC SACK Test (CL29)	3
232	QBA Simulated-DMA-Read Test, Part 1 (CL23)	24
233	QBA Simulated-DMA-Read Test, Part 2 (CL23)	3
234	QBA Simulated-DMA-Write Test (CL23)	24
235	CL30 RPLY Timeout Test, Part 2 (CL29)	2

RL02-specific QBA Tests

236	RL02 Register Read Test (CL23)	10
237	RL02 Register Write Test (CL23)	10
240	RL02 Register Write/Read Test (CL23)	2
241	RL02 DMA Read Test (CL23)	3

* Indicates a special test fixture is required; the test is ignored unless the fixture is installed.

6.4 EDKAA - MICRO-HARD-CORE DIAGNOSTIC (MHC)

OVERVIEW - EDKAA (MHC) is a T-11 based diagnostic. It is designed to verify the proper operation of the VAX CPU hardware logic required to successfully load and run micro-diagnostics.

6.4.1 Prerequisites

Successful execution of ED0BA. EDKAA also assumes that the CDF860.DAT or CDF865.DAT file on the RL02 is correct. CDF860.DAT and CDF865.dat contains the names and revision levels of the SDB signal name files.

6.4.2 Loading and Starting MHC

To load and start MHC type:

MHC<cr>

at either the Macro Context Prompt: >>>, or the Diagnostic Context Prompt: DC>. Once MHC has been started, it will display the version name and number, followed by the MHC Prompt: MH>. MHC then waits for the user to type a command. See Table 6-5.

6.4.3 Micro-Hard-Core Control Characters

Character	Function
-----------	----------

^C	Control C Each sub test may be exited by typing ^C. The program will abort at the completion of the current sub test and return to the Micro-Hard-Core Prompt: MH>.
----	--

^T	Control T If the "/Printmode:Quiet" switch was selected, typing ^T will report the next sub test name at completion of the current sub test.
----	---

6.4.4 Micro-Hard-Core Control Switches

The user may append the following switches to a command in order to change the characteristics of the program execution.

SWITCH	FUNCTION
/Bell:	STARTQ/BELL:arg<cr> Control the action of the BELL as specified by the argument. Valid arguments are: OFF (default) - Do not sound bell on error. ON - Sound bell on error.
/ERROR_DUMPS:	STARTQ/ERROR_DUMPS:arg_#<CR> Report only the number Errors (per sub test) specified by the argument_#.

DIAGNOSTICS
EDKAA - MICRO-HARD-CORE DIAGNOSTIC (MHC)

/Fault: STARTQ/FAULT:arg<cr>
Upon detection of a error take the action
specified by the argument. Valid arguments are:

- CONTINUE - (default) Continue on error.
- ISOLATE - (default) Isolate the cause of the
 error to RAM Chip.
- LOOP - Loop on failing test.
- PAUSE - Pause on error and exit to "MH".
 See CONTINUE Command.

/PASS: STARTI/PASS:arg_#<CR>
Run selected tests for the number of passes
specified by argument_#.

/PRINT_MODE: START/PRINT_MODE:arg<cr>
Control the error reporting as specified by the
argument. Valid arguments are:

- BRIEF - Cancel "/PRINT_MODE:QUIET" and report
 errors in short form, no RAM chip
 callout.
- QUIET - Suppress all but error typeouts.
- VERBOSE - (default) Cancel "/PRINT_MODE:QUIET"
 and report errors in long form (i.e.,
 RAM chip callout)

/QUICKVERIFY STARTE/QUICKVERIFY<CR>
Run selected test with Quick Verify Flag set.

/NUMBER START/Number:n1,n2<cr>
Run only tests "n1" thru "n2".

6.4.5 Micro-Hard-Core Commands

The following Table describes the commands associated with the
Micro-Hard-Core Diagnostic.

Table 6-5 Micro-Hard-Core Commands

COMMAND	DESCRIPTION
START	Start<cr> Run one complete pass of all tests and then return to the Micro-Hard-Core Prompt (MH>).
STARTQ	STARTQ<cr> Run one pass of all tests in Quick Verify Mode (shorter run time).
	QUICK VERIFY MODE: When the Quick Verify suffix is appended to either the START or LOOP command only the RAM addresses that cross physical chip boundaries are checked. For example, each bit of the EBox Control Store is 8192 addresses deep. The memory chip used has 1024 addresses.

DIAGNOSTICS

EDKAA - MICRO-HARD-CORE DIAGNOSTIC (MHC)

When the STARTQ or LOOPQ Command is specified the program will not increment through each address. Instead it will update uPC <02:00>, which will select a bank of RAMs. Each bank represents 1K microwords of the total 8K. The uPC bits will be uncremented until all 8 banks have been selected at least once.

The STARTQ and LOOPQ commands also executes certain sub tests once instead of the default number of times. (See list below.) These two differences reduced the amount of time required to run the Micro-Hard-Core Diagnostic. In addition, however, they also reduce the fault detection level. In other words, you cannot be sure the RAMs are functioning properly unless you run at least one full pass of MHC.

GROUP TESTS

FBox F-8, F-9, F-A, F-B, F-E, and F-F
IBox I-A, I-B, and I-D
MBox M-5 and M-6
EBox S-C and S-D

STARTC	STARTC<cr> Run Clock Tests only. See Table 6-6
STARTD	STARTD<cr> Run Disk Tests only. See Table 6-7.
STARTF	STARTF<cr> Run FBox Tests only. See Table 6-8.
STARTI	STARTI<cr> Run IBox Tests only. See Table 6-9.
STARTL	STARTL<cr> Run Last Multi Box Access Tests only. See Table 6-10.
STARTM	STARTM<cr> Run MBox Logic Tests only. See Table 6-11.
STARTN	STARTN<cr> Run MBox UCODE Tests only. See Table 6-12.
STARTR	STARTR<cr> Run EBox MCF-CTX RAM and Basic UCODE Tests only. See Table 6-13.
STARTS	STARTS<cr> Run EBox SDB and CS Tests only. See Table 6-14.
STARTU	STARTU<cr> Run EBox Expanded UCODE Tests only. See Table 6-15.
LOOP	LOOP<cr> Loop on all tests continuously until stopped by "^C".
LOOPQ	LOOPQ<cr> Continuously loop on all tests in Quick Verify Mode (shorter run time). See QUICK VERIFY MODE under STARTQ.
LOOPC	LOOPC<cr> LOOP on Clock Tests only. See Table 6-6.

DIAGNOSTICS
EDKAA - MICRO-HARD-CORE DIAGNOSTIC (MHC)

LOOPD	LOOPD<cr> Loop on Disk Tests only. See Table 6-7.
LOOPF	LOOPF<cr> Loop on FBox Tests only. See Table 6-8.
LOOPI	LOOPI<cr> Loop on IBox Tests only. See Table 6-9.
LOOPL	LOOPL<cr> Loop on Last Multi Box Access Tests only. See Table 6-10.
LOOPM	LOOPM<cr> Loop on MBox Logic Tests only. See Table 6-11.
LOOPN	LOOPN<cr> Loop on MBox UCODE Tests only. See Table 6-12.
LOOPR	LOOPR<cr> Loop on EBox MCF-CTX RAM and Basic UCODE Tests only. See Table 6-13.
LOOPS	LOOPS<cr> Loop on EBox SDB and CS Tests only. See Table 6-14.
LOOPU	LOOPU<cr> Loop on EBox Expanded UCODE Tests only. See Table 6-15.
CONTINUE	CONTINUE<cr> Continue on to the next sub test. This command should only be necessary if the "/FAULT:PAUSE" switch was selected and an error was detected.
REPORT	REPORT<cr> Retype the end of pass report. See Example 6-1

6.4.6 Micro-Hard-Core Test Descriptions

The following set of Tables list the subtests that can be run via the Micro-Hard-Core Diagnostic.

Table 6-6 Clock Subtests

TEST	MODULE AND DESCRIPTION
CLK (C-1)	L0217 (CLK) SDB SHIFT
CLK (C-2)	L0217 (CLK) SDB SHIFT CHAIN LOAD FUNCTION
CLK (C-3)	L0217 (CLK) VIS MUX SELECTS
CLK (C-4)	L0217 (CLK) VIS DATA AND LD FUNC_REG_B
CLK (C-5)	L0217 (CLK) LOAD FREQUENCY REG
CLK (C-6)	L0217 (CLK) CLK2 START H CIRCUIT
CLK (C-7)	L0217 (CLK) CLK3 MARK BIT
CLK (C-8)	L0217 (CLK) BURST COUNTER READ AND WRITE
CLK (C-9)	L0217 (CLK) CPU CLOCK STOP
CLK (C-A)	L0217 (CLK) MARK BIT STOP CONDITION
CLK (C-B)	L0217 (CLK) BURST COUNTER ABILITY TO COUNT
CLK (C-C)	L0217 (CLK) WBUS AND FBOX T3 TO T3 SHIFT LOOP
CLK (C-D)	L0217 (CLK) WBUS T2 CLK-EBE,EDP,FBA,IDP WBUS ENABLE
CLK (C-E)	L0217 (CLK) STOP FBOX IN PHASE 0 AND PHASE 1

Table 6-7 RL02 Disk Subtests

TEST	MODULE and DESCRIPTION
DSK (D-1)	Disk (non-destructive) Write-Read Exerciser
DSK (D-A)	Disk Oscillation seek 1 = 1-1
DSK (D-B)	Disk Oscillation seek 1 = 1-85
DSK (D-C)	Disk Oscillation seek 1 = 1-170
DSK (D-D)	Disk Oscillation seek 1 = 1-255
DSK (D-E)	Disk Oscillation seek 1 = 1-511
DSK (D-F)	Disk (DESTRUCTIVE) Write-Read Exerciser

Table 6-8 FBox Subtests

TEST	MODULE and DESCRIPTION
FBOX (F-1)	L0213 (FBM) F BOX Present V\$TERM
FBOX (F-2)	L0212 (FBA) SDB SHIFT AND LOOPBACK
FBOX (F-3)	L0213 (FBM) SDB SHIFT AND LOOPBACK
FBOX (F-4)	FBOX MODULES SDB SELECT LINE AND ENABLE
FBOX (F-5)	L0217 (CLK) CLK 141 RESET
FBOX (F-6)	L0212 (FBA) UPC REGISTER TESTS
FBOX (F-7)	L0213 (FBM) UPC REGISTER TESTS
FBOX (F-8)	L0212 (FBA) CONTROL STORE "55" DATA TEST
FBOX (F-9)	L0212 (FBA) CONTROL STORE "AA" DATA TEST
FBOX (F-A)	L0213 (FBM) CONTROL STORE "55" DATA TEST
FBOX (F-B)	L0213 (FBM) CONTROL STORE "AA" DATA TEST
FBOX (F-C)	L0213 (FBM) CONTROL STORE ADDRESS TEST
FBOX (F-D)	L0212 (FBA) CONTROL STORE ADDRESS TEST
FBOX (F-E)	L0213 (FBM) DECODE RAM "55" DATA TEST
FBOX (F-F)	L0213 (FBM) DECODE RAM "AA" DATA TEST
FBOX (F-10)	L0213 (FBM) DECODE ADDRESS TEST
FBOX (F-11)	L0213 (FBM) BASIC MICRO-CODE TEST (EDKAF1)
FBOX (F-12)	L0212 (FBA) BASIC MICRO-CODE TEST (EDKAB1)
FBOX (F-13)	L0213 (FBM) EXPANDED UPC UPDATE TEST (EDKAF2)
FBOX (F-14)	L0212 (FBA) EXPANDED UPC UPDATE TEST (EDKAB2)
FBOX (F-15)	L0212 (FBA) MICRO-CODE TEST (EDKAB3)

Table 6-9 IBox Subtests

TEST	MODULE and DESCRIPTION
IBOX (I-1)	SDB SHIFT AND LOOPBACK
IBOX (I-2)	SDB SELECT LINE AND ENABLE
IBOX (I-3)	L0208 (IBD) MODULE SDB CONTROL CHANNEL
IBOX (I-4)	L0207 (ICA) MODULE SDB CONTROL CHANNEL
IBOX (I-5)	L0217 (CLK) CLK 141 RESET
IBOX (I-6)	L0207 (ICA) ICS UPC REGISTER TEST
IBOX (I-7)	L0207 (ICA) ICS "55" DATA TEST
IBOX (I-8)	L0207 (ICA) ICS "AA" DATA TEST
IBOX (I-9)	L0207 (ICA) ICS ADDRESS TEST
IBOX (I-A)	L0208 (IBD) IDRAM "55" DATA TEST
IBOX (I-B)	L0208 (IBD) IDRAM "AA" DATA TEST
IBOX (I-C)	L0208 (IBD) IDRAM ADDRESS TEST
IBOX (I-D)	L0207 (ICA) ICS RAM PARITY TEST
IBOX (I-E)	QUIESCENT STATE FOR I BOX CONTROL SIGNALS
IBOX (I-F)	L0207 (ICA) UJUMP MICRO-CODE TEST (EDKAI1)

NOTE

When executed on VAX-8650 CPU, L0231 will be reported in place of L0217.

Table 6-10 Last Box Subtests

TEST	MODULE and DESCRIPTION
VAX-8600 (L-1)	CLK and E,I,M boxes Uword MARK BIT
VAX-8600 (L-2)	V\$TERM MASTER RESET TEST
VAX-8650 (L-1)	CLK and E,I,M boxes Uword MARK BIT
VAX-8650 (L-2)	V\$TERM MASTER RESET TEST

NOTE

1. When executed on VAX-8650 CPU, L0231 will be reported in place of L0217
2. When executed on VAX-8650 CPU, L0230 will be reported in place of L0220

Table 6-11 MBox Logic Subtests

TEST	MODULE and DESCRIPTION
MBOX (M-1)	SDB SHIFT AND LOOPBACK
MBOX (M-2)	L0222 (MTM) SDB SHIFT AND LOOPBACK
MBOX (M-3)	SDB SELECT LINE AND ENABLE
MBOX (M-4)	L0217 (CLK) CLK 141 RESET
MBOX (M-5)	L0220 (MCC) MCS "55" DATA TEST
MBOX (M-6)	L0220 (MCC) MCS "AA" DATA TEST
MBOX (M-7)	L0220 (MCC) CYCLE RAM "55" DATA TEST
MBOX (M-8)	L0220 (MCC) CYCLE RAM "AA" DATA TEST
MBOX (M-9)	L0220 (MCC) ACCESS RAM DATA TEST
MBOX (M-A)	L0220 (MCC) CYCLE RAM ADDRESS TEST
MBOX (M-B)	L0220 (MCC) MCS RAM ADDRESS TEST
MBOX (M-C)	L0220 (MCC) ACCESS RAM ADDRESS TEST

Table 6-12 MBox Ucode Subtests

TEST	MODULE and DESCRIPTION
MBOX (N-1)	L0220 (MCC) BASIC UCODE FUNCTION (EDKAM1)
MBOX (N-2)	L0220 (MCC) BASIC STACK UCODE (EDKAM2)
MBOX (N-3)	L0220 (MCC) STACK PUSH LEVEL (EDKAM3)
MBOX (N-4)	L0220 (MCC) STACK POP LEVEL (EDKAM4)

Table 6-13 MCF, CTX, and MISC EBox Subtests

TEST	MODULE and DESCRIPTION
EBOX (R-1)	L0216 (CSB) UPC+UPC SAVE INITIALIZATION
EBOX (R-2)	L0215/L0216 (ECS) "55" 1 WORD (V\$TERM) TEST
EBOX (R-3)	L0215/L0216 (ECS) "AA" 1 WORD (V\$TERM) TEST
EBOX (R-4)	L0210 (EBC) MCF RAM DATA TEST
EBOX (R-5)	L0210 (EBC) MCF RAM ADDRESS TEST
EBOX (R-6)	L0210 (EBC) CONTEXT RAM DATA TEST
EBOX (R-7)	L0210 (EBC) CONTEXT RAM ADDRESS TEST
EBOX (R-8)	L0215/L0216 (ECS) RAM PARITY
EBOX (R-9)	L0210 (EBC) MCF RAM PARITY TEST
EBOX (R-A)	QUIESCENT STATE FOR UTRAP + STALL (EDKAU2)

DIAGNOSTICS

EDKAA - MICRO-HARD-CORE DIAGNOSTIC (MHC)

EBOX (R-B) L0216 (CSB) BASIC UPC UPDATE TEST (EDKAU1)
 EBOX (R-C) L0216 (CSB) EXPANDED UPC UPDATE TEST (EDKAU1)
 EBOX (R-D) L0216 (CSB) UJUMP REGISTER TEST (EDKAU2)

NOTE

When executed on VAX-8650 CPU, L0231 will be
 reported in place of L0217

Table 6-14 EBox, SDB, and C/S Subtests

TEST	MODULE and DESCRIPTION
EBOX (S-1)	MODULES SDB SHIFT AND LOOPBACK
EBOX (S-2)	L0215 (CSA) MODULE SDB SHIFT AND LOOPBACK
EBOX (S-3)	SDB SELECT LINE AND ENABLE
EBOX (S-4)	L0215 (CSA)/L0216 (CSB) SDB CONTROL CHANNEL
EBOX (S-5)	L0209 (EDP) MODULE SDB CONTROL CHANNEL
EBOX (S-6)	L0210 (EBC) MODULE SDB CONTROL CHANNEL
EBOX (S-7)	L0219 (EBE) MODULE SDB CONTROL CHANNEL
EBOX (S-8)	L0219 (EBE) MODULE ICR TIME BASE COUNTER
EBOX (S-9)	L0210 (EBC) MODULE DIAG & EIS REG CLK3
EBOX (S-A)	L0210 (EBC) MODULE MCF RAM CLK3
EBOX (S-B)	L0217 (CLOCK) CLK 141 RESET
EBOX (S-C)	L0215 (CSA)/L0216 (CSB) ECS "55" DATA TEST
EBOX (S-D)	L0215 (CSA)/L0216 (CSB) ECS "AA" DATA TEST
EBOX (S-E)	L0215 (CSA)/L0216 (CSB) ECS Addr (KA8600)
EBOX (S-F)	L0215 (CSA)/L0216 (CSB) ECS Addr (EDKBU)

Table 6-15 EBox Ucode Subtests

TEST	MODULE and DESCRIPTION
EBOX (U-1)	L0216 (CSB) MICROSTACK TEST (EDKAU2)
EBOX (U-2)	L0209 (EDP)/L0210(EBC)WBUS REQ CTX (EDKAU2)
EBOX (U-3)	L0209 (EDP) SHIFT COUNTER FUNCTION (EDKAU2)
EBOX (U-4)	L0209/L0206/L0212/L0205 DATA PATH (EDKAU2)
EBOX (U-5)	L0216 (CSB)/L0209 (EDP) BRANCH COND. (EDKAU2)
EBOX (U-6)	L0209 (EDP) ALU FUNCTION (EDKAU2)
EBOX (U-7)	L0209 (EDP) SCRATCH PADS DATA (EDKAU2)
EBOX (U-8)	L0219 (EBE)/L0201(CSL) CBUS/CSL-INT (EDKAU2)
EBOX (U-9)	L0219 (EBE) EBCS REGISTER <31:27> (EDKAU2)

Below is an example of the End of Pass report when an error occurred.

Example 6-1: End of Pass Report

SECTION TOTAL OF ERRORS

CLOCK (SC) = 00000
 E SDB/CS (SS) = 00000
 E RAMS (SR) = 00000
 E UCODE (SU) = 00009
 I BOX (SI) = 00000
 M LOGIC (SM) = 00000
 M UCODE (SN) = 00000
 F BOX (SF) = 00000
 RL02 DSK (SD) = 00000
 VAX-86xx (SL) = 00000

PASS COUNTER = 00001

OF ERRORS = 00009, TOTAL # OF ERRORS = 00009

DIAGNOSTICS
MICRO DIAGNOSTIC CONTROL PROGRAM (DCP)

6.5 MICRO DIAGNOSTIC CONTROL PROGRAM (DCP)

6.5.1 Overview

DCP is a Tll based Diagnostic Utility program designed to control the running of the micro diagnostics. It is evoked by typing the DIAGNOSE Command at either the MACRO Prompt (>>>) or the Micro-Hard-Core Prompt (MH>). Once evoked, DCP will initialize the system to the point where microdiagnostics can be loaded, executed, and monitored. The steps taken by this initialization procedure are as follows:

1. Take control of the TXCS RDY interrupt vector.
2. Submit the DCP initialization file, DCLOAD.COM, internally in order to perform the following steps.
 - Stop the CPU clock and perform a master reset.
 - Load the Diagnostic Support Microcode (DSM) into the EBox control store.
 - Load other control stores, as necessary, to initialize parity logic, etc.
 - Enable the console's external logic interrupt, using the SET EXTI ON command.
 - Force the EBox to begin executing at the DSM start address and start the CPU clocks.
3. Pass the default diagnostic switch settings to DSM (via the CBus).
4. Display the diagnostic context command prompt (DC>) and await commands.

NOTE

DCLOAD.COM contains a DEBUG command that leaves the HEX command set enabled when it terminates, as evidenced by the DC>> prompt.

6.5.2 DCP Control Characters

Control Character	Description
-------------------	-------------

- | | |
|----------|--|
| <CTRL/P> | Interrupts the currently running micro- diagnostic and returns control to the user. This places the microdiagnostic in the "pause" state, allowing the user to examine or modify the state of the diagnostic test environment, and then resume execution of the microdiagnostic. |
| <CTRL/C> | Aborts the current command, which may include the need to abort a currently running microdiagnostic, and returns control to the user. |

<CTRL/T> Commands DCP to display information about the state of the currently running microdiagnostic without disturbing its execution.

6.5.3 DCP Command Summary

Command	Description
---------	-------------

CLEAR DATA	CLEAR DATA<cr>
------------	----------------

	Clear the table of pointers defined by the SET DATA command and should be used prior to redefining a new set of EBox scratchpad locations for error reporting purposes.
--	---

CONTINUE	CONTINUE<cr>
----------	--------------

	This command allows the currently loaded microdiagnostic to resume test execution after being paused by either a switch setting (/FAULT:PAUSE, /FAULT:ISOLATE) or <CTRL/P>. The microdiagnostic resumes at the test following the one that was being executed when the pause occurred. If /SINGLE_STEP is in effect and CONTINUE command is issued, single stepping is stopped and the remaining tests are run. A CONTINUE command, issued prior to giving either a RUN or START command, will result in an error message.
--	--

DEPOSIT	DEPOSIT/switch hex_addr hex_data<cr>
---------	--------------------------------------

	This command allows the user to modify the EBox scratchpad RAM, the system cache, or the WBus RAM. The 32-bit hexdata is deposited into the hexaddr location of the specified RAM. The CPU clock must be running.
--	---

	Valid Switches: /CACHE /ESCRATCH /WBUS
--	--

EXAMINE	EXAMINE/switch hex_addr<cr>
---------	-----------------------------

	This command allows the user to examine the contents of specific EBox scratchpad locations, cache locations, or WBus locations. The CPU clock must be running.
--	--

	Valid Switches: /CACHE /ESCRATCH /WBUS
--	--

GENERATE	GENERATE file.ext<cr>
----------	-----------------------

	The Generate command is used to evoke the DCP generate/verify process for generation and validation of isolation data. This command is not for field use. It is used to support the in-house development of isolation algorithms. There are no switches associated with this command. The only option is the name of the command file responsible for loading the microdiagnostic to be generated.
--	--

DIAGNOSTICS
MICRO DIAGNOSTIC CONTROL PROGRAM (DCP)

RUN

RUN/switch file.ext<cr>

This command initiates the execution of a command file whose purpose is to load and start a microdiagnostic program. Execution begins with the first number specified in the /NUMBER switch and ends with either the last test in the group of microdiagnostic tests or with the last test specified in the /NUMBER switch.

NOTE

1. The CPU clock must be running for the RUN command to work.
2. Switches can be combined in any order provided that the command line does not exceed 80 characters.
3. Switches appended to the RUN command remain in effect until the command completes.
4. Refer to the SWITCH Command for a description of this switch.

Valid Switches: (SWITCH DEFAULTS are printed in upper case)

/BELL:{ON, OFF}

See Note 4.

/FAULT:{ISOLATE, noabort, loop, pause, continue, ignore}

See Note 4.

/LINES:{ON, OFF}

See Note 4.

/NUMBER:FIRST_TEST,[[<space>,<comma>]LAST_TEST]

This switch is used to specify the starting and ending test. Numbers in hex. If the switch is omitted, the default values are used (default = 01,FF).

/PASSES:decimal number (default = 100)

The decimal number indicates the number of test passes to execute before continuing to the next test or attempting isolation. If the /PASSES switch is not specified, the default value (100) will be used. A special case of /PASSES:0 modifies the sequencing of the tests so that a particular group of tests can be run indefinitely. If the user specifies a 0 pass count, DCP will run each of the tests indefinitely (from FIRST to LAST) until <CTRL/C> or <CTRL/P> interrupts or a fault is detected. When a fault is detected, the action will be governed by the current setting of the /FAULT switch.

/PRINT_MODE:{brief, VERBOSE}

See Note 4.

/SINGLE_STEP

When single_step is enabled, diagnostic execution is interrupted after completing the proper number of passes of an individual test. A message, along with the test number just completed, is displayed and the operator is prompted for input. The STEP command can be used to run the next test and is followed by another pause when it completes. The CONTINUE command can be used to clear this mode and resume full speed test execution.

SET
DATA

SET DATA escratch_address data_name<cr>
Where:

- "escratch_address" is a hexadecimal address within the EBox scratchpad RAM (0 to FF)
- "data name" is a 1-30 character string to be associated with the specified Escratch data

This command allows a symbolic name to be assigned to a location in the EBox scratchpad RAM. When a microdiagnostic test detects a fault and DCP is in verbose printing mode, the "data name" and data taken from the associated "escratch_address" are included in the error report.

Set Data commands are normally used in command files responsible for loading microdiagnostics and setting diagnostic control switches. A maximum of 16 SET DATA commands can be used at one time. The CLEAR DATA command should be used to initialize the SET DATA memory prior to defining set data information. The SHOW DATA command can be used to display the current settings of SET DATA, along with the current state of the Escratch variables.

SET
ISOLATION

SET ISOLATION/switch<cr>

This command provides a way to modify default parameters associated with isolation. Once the defaults are modified, they remain in effect until DCP is reloaded (i.e., DIAG command).

Valid Switches:

/PASSES:decimal number

The decimal number indicates the number of times each test will be executed before continuing to the next test or attempting isolation (default = 100). It is not recommended that this number be altered in the field, as it affects the confidence level of any isolation data that may follow. Factory settings are preferred. This number should always be greater than zero (0).

/ERROR DUMPS:decimal number

The decimal number indicates the maximum number of error printouts that will occur due to faults with different syndromes within a given test (default = 10). Lowering this number has the effect of reducing the amount of error printouts at the expense of throwing away what may be useful data for tracking down an intermittent. This number has a maximum value of 10.

DIAGNOSTICS
MICRO DIAGNOSTIC CONTROL PROGRAM (DCP)

SET NAME SET NAME microdiagnostic filename<cr>
This command is normally used within a command file. It specifies the name of the microdiagnostic currently being loaded. This information is included in the fault report and is used to locate other associated files with the same name (different extensions).

SET SWITCH SET SWITCH/switch<cr>
This command redefines the default switch settings that govern the behavior of DCP and DSM in the control and running of microdiagnostics. A description of each switch is provided below, including the default setting of the switch when DIAGNOSTIC context is entered.

NOTE

1. Switches can be combined in any order provided that the command line does not exceed 80 characters.
2. Switches altered with this command retain the new setting until changed again with the SET SWITCH command, or until DCP is reloaded.

Valid Switches:

/BELL:{ON,OFF}

When "ON," this switch causes the terminal bell to ring each time a new fault is detected and reported.

/FAULT:{ISOLATE,noabort,loop,pause,continue,ignore}
This switch controls the action DCP takes after a microdiagnostic test detects a fault. Only one of the above arguments may be specified; they are mutually exclusive.

ISOLATE - This setting, which is the default, directs DCP to attempt isolation on all solid faults encountered. After the isolation attempt is completed, DCP returns to its command prompt. The CONTINUE or STEP commands can be used to resume test execution.

NOABORT - This setting directs DCP to attempt isolation on all solid faults encountered. After the isolation attempt is completed, DCP will continue onto the next test, thus providing a way to continue with the diagnostic execution after isolating.

LOOP - Tests within a diagnostic are targeted to run /PASSES times. When an error is detected, the standard error report is displayed and then DSM is instructed to loop forever on the failing test. Only <CTRL/C> or <CTRL/P> can terminate the loop.

PAUSE - This setting causes DCP to return to its command prompt after reporting a test failure. The CONTINUE or STEP command can be used to resume test execution.

DIAGNOSTICS
MICRO DIAGNOSTIC CONTROL PROGRAM (DCP)

CONTINUE - With this switch in effect, DCP will perform all of its normal error reporting. After each error report, DCP will continue its normal test sequencing as if no error had occurred. Isolation will not take place.

IGNORE - This is a special switch intended only for microcoder use. It has no useful application in the field. It directs DSM never to signal DCP that an error has occurred. No hardware errors can ever be detected or reported.

/LINES:{ON, OFF}

This switch is used by microcoders to debug isolation code. If the switch has been set to ON and DCP is processing isolation statements, a source line number will be displayed as the statement is processed. This line number matches the line number of the isolation source statement that is currently being processed.

/PRINT MODE:{brief, VERBOSE}

This switch controls the level of detail included in an error report.

SHOW
DATA

SHOW DATA<cr>

This command displays all symbolic names and associated data currently defined by the SET DATA command. The range of diagnostic test numbers, with the number of passes, is also displayed under this command for the user's information.

SHOW
SWITCHES

SHOW SWITCHES<cr>

This command displays the current switch settings and the default switch settings. The default settings are either those settings that were in place when DCP was loaded or those that have been modified via the SET SWITCH command.

The current switch settings are normally the same as the default settings since local settings (i.e., appending switches to RUN or START) return to defaults when the command completes.

The current switches will differ from the defaults when they are examined from within another command. This could occur by examining the switches from the paused state of a RUN or START command which uses the /SINGLE STEP switch. When proceeding from that point with the CONTINUE or STEP command, the current switch settings will remain in effect until the initial RUN or START command completes.

DIAGNOSTICS
MICRO DIAGNOSTIC CONTROL PROGRAM (DCP)

START **START/switch<cr>**
This command initiates the execution of a test or group of tests within an already loaded microdiagnostic program. Execution begins with the first number specified in the /NUMBER switch. It ends with either the last test in the group of microdiagnostic tests or with the last test specified in the /NUMBER switch.

NOTE

1. The CPU clock must be running for the START command to work.
2. Switches can be combined in any order provided that the command line does not exceed 80 characters.
3. Switches appended to the START command remain in effect until the command completes.
4. Refer to the SWITCH Command for a description of this switch.
5. Refer to the RUN Command for a description of this switch.

Valid Switches: (SWITCH DEFAULTS are printed in upper case)

/BELL:{ON, OFF}
See Note 4.

/FAULT:{ISOLATE, noabort, loop, pause, continue, ignore}
See Note 4.

/LINES:{ON, OFF}
See Note 4.

/NUMBER:FIRST_TEST [{<space>,<comma>}] LAST_TEST
See Note 5.

/PASSES:decimal_number
See Note 5.

/PRINT_MODE:{brief, VERBOSE}
See Note 4.

/SINGLE STEP
See Note 5.

STEP **STEP<cr>**
This command causes the next test in the currently loaded microdiagnostic to be executed. The STEP command is invalid unless the microdiagnostics have been started. Once they have been started and there is a pause in the diagnostic execution (/FAULT:PAUSE, /FAULT:ISOLATE, or <CTRL/P>), the STEP command may be used. A STEP command issued prior to giving either a RUN or START command will result in an error message.

6.6 VAX 86XX MICRODIAGNOSTICS

Table 6-16 lists the Microdiagnostics for the VAX 86XX CPU. With the exception of Micro-Hard-Core these diagnostics are designed to run under control of the Diagnostic Control Program (DCP).

Table 6-16 VAX 86XX Microdiagnostics

NAME	DESCRIPTION
EDKAA	Micro-Hard-Core
EDKBA	EBox Series
EDKCA	MBox Series, Part 1
EDKIA	MBox Array Go/No Go Control Test
EDKDA	MBox Series, Part 2
EDKJA	Array Minimum Functionality Test
EDKEA	MBox Series, Part 3
EDKFA	MBox Series, Part 4
EDKGA	MBox Series, Part 5
EDKHA	MBox Series, Part 6
EDKOA	IBox Series, Part 1
EDKPA	IBox Series, Part 2
EDKQA	IBox Series, Part 3
EDKRA	IBox Series, Part 4
EDKSA	IBox Series, Part 5
EDKTA	IBox Series, Part 6
EDKUA	IBox Series, Part 7
EDKVA	IBox Series, Part 8
EDKWA	IBox Series, Part 9
EDK1A	FBox Series, Part 1
EDK2A	FBox Series, Part 2
EDK3A	FBox Series, Part 3
EDK4A	FBox Series, Part 4
EDKZA	FBox Series, Part 5
EDK5A	Array Series
EDK6A	SBIA Series, Part 1
EDK7A	SBIA Series, Part 2

6.7 STANDARD MICRODIAGNOSTIC COMMAND FILES

Table 6-17 lists some common Command Files that can be executed under the control of DCP.

Table 6-17 Standard Microdiagnostic Command Files

Command File	Description
TSTCPU.COM	@TSTCPU<cr> Run one pass of the Micro-Hard-Core Diagnostic then run one pass each of the individual Micro-diagnostics.
MICROS.COM	@MICROS<cr> Run one pass each of the individual Micro-diagnostics. Do not run the Micro-Hard-Core first.

DIAGNOSTICS
STANDARD MICRODIAGNOSTIC COMMAND FILES

Table 6-17 Standard Microdiagnostic Command Files (Cont)

Command File	Description
QVX###	@QVX###<cr> Run one pass of the Micro-Hard-Core Diagnostic then run the test sequences that are necessary to test (Quick Verify) the CPU module specified by ###. The individual Quick Verify tests are listed by module tested in Table 6-18.
QVL###	@QVL###<cr> Run one pass of the test sequences that are necessary to test (Quick Verify) the CPU module specified by ###. This series of Quick Verify Command Files will not run MHC first. The individual Quick Verify are listed by module tested in Table 6-19.

Table 6-18: MHC/Module Quick Verify Command Files

COMMAND FILE	MODULE TESTED
QVX202.COM	L0202 (SBS)
QVX203.COM	L0203 (SBA)
QVX204.COM	L0204 (MCD)
QVX205.COM	L0205 (MAP)
QVX220.COM	L0220 (MCC)
QVX222.COM	L0220 (MTM)
QVX206.COM	L0206 (IDP)
QVX207.COM	L0207 (ICA)
QVX208.COM	L0208 (IBD)
QVX214.COM	L0214 (ICB)
QVX209.COM	L0209 (EDP)
QVX210.COM	L0210 (EBC)
QVX211.COM	L0211 (EBD)
QVX215.COM	L0215 (CSA)
QVX216.COM	L0216 (CSB)
QVX219.COM	L0219 (EBE)
QVX212.COM	L0212 (FBA)
QVX213.COM	L0213 (FBM)
QVX218.COM	L0218 (FJM)
QVX223.COM	L0223 (FTM)
QVX217.COM	L0217 (CLK)

DIAGNOSTICS
STANDARD MICRODIAGNOSTIC COMMAND FILES

Table 6-19 CPU Module Quick Verify Command Files

COMMAND FILE	MODULE TESTED
QVL202.COM	L0202 (SBS)
QVL203.COM	L0203 (SBA)
QVL204.COM	L0204 (MCD)
QVL205.COM	L0205 (MAP)
QVL220.COM	L0220 (MCC)
QVL222.COM	L0220 (MTM)
QVL206.COM	L0206 (IDP)
QVL207.COM	L0207 (ICA)
QVL208.COM	L0208 (IBD)
QVL214.COM	L0214 (ICB)
QVL209.COM	L0209 (EDP)
QVL210.COM	L0210 (EBC)
QVL211.COM	L0211 (EBD)
QVL215.COM	L0215 (CSA)
QVL216.COM	L0216 (CSB)
QVL219.COM	L0219 (EBE)
QVL212.COM	L0212 (FBA)
QVL213.COM	L0213 (FBM)
QVL218.COM	L0218 (FJM)
QVL217.COM	L0217 (CLK)

DIAGNOSTICS
DIAGNOSTIC SUPERVISOR (EDSAA) OVERVIEW

6.8 DIAGNOSTIC SUPERVISOR (EDSAA) OVERVIEW

The Diagnostic Supervisor (EDSAA) is a utility program designed to simplify loading, running, and controlling the operation of the following types of diagnostics:

- LEVEL 3 - Diagnostics that are designed to run under the Diagnostic Supervisor in standalone mode only. Typically these are: Functional Level Peripheral Diagnostics, Repair Level Peripheral Diagnostics, and CPU Cluster Diagnostics.
- LEVEL 2 - Diagnostics that are designed to run under the Diagnostic Supervisor in either standalone or on-line mode. Typically these are: Bus Interaction Diagnostics and Formatter/Reliability Peripheral Diagnostics.
- LEVER 2R - Diagnostics that are designed to run under the Diagnostic Supervisor in on-line mode only. Typically these are Diagnostic Control Programs such as File Maintenance and Update Utilities.

6.8.1 Diagnostic Supervisor (EDSAA) Control

The operation of the Diagnostic Supervisor is effected by either Control Characters (Table 6-20) or Direct Commands entered at the Diagnostic Supervisor Prompt: DS> (Table 6-21).

Table 6-20 Diagnostic Supervisor Control Character Summary

Control Character	Description
^C	Interrupt the execution of the diagnostic currently running.
^S	Suspend terminal output.
^Q	Resume terminal output.

Table 6-21 Diagnostic Supervisor Command Summary

Command	Description
SET LOAD	SET LOAD device:[directory]<cr> Sets the default load directory to a device and directory where the diagnostics and other maintenance software is stored; e.g., DMA0:[SYSMAINT].
SHOW LOAD	SET LOAD<cr> Display the default device and directory. See the SET LOAD Command.
LOAD	LOAD filename.extension<cr> Load but do not start the file specified. The default extension is .EXE.

ATTACH

ATTACH

dev-type link-name dev-name parameters<cr>
Define a test path based on the device type, the link name, the device name, and the parameters specified. Table 6-22 lists some common device types, links, and device names along with associated parameters.

NOTE

1. A device must be attached using HUB as the link name before it can itself be used as a link. For example,

DS> ATTACH DW780 HUB DW0 3 4<cr>

In this command DW0 is defined as a DW780 that has, in this case, a TR Level of 3 and a BR Level of 4. DW0 can now be used as a link to further define the test path. For example,

DS> ATTACH VS100 DW0 VBA0 760440 400 5<cr>

In this case VBA0 is defined as a VS100 that is connected to the CPU via DW0. In addition the parameters specify that the Unibus Control and Status Register (CSR) address is 760440, the Vector Address is 400, and the BR Level is 4 for VBA0.

2. The test path (device name) must be selected before the test path can be tested. See SELECT command.

SELECT

SELECT device-name<cr>

Add the device specified to the list of units to be tested. See ATTACH and DESELECT Command.

DESELECT

DESELECT device-name<cr>

Remove the unit specified from the list of units to be tested.

SHOW DEVICE

SHOW DEVICE device-name<cr>

Display the characteristics of the device name specified. If ALL is specified display the characteristics of all devices.

SHOW SELECTED

SHOW SELECTED<cr>

Display the characteristics of all selected devices.

DIAGNOSTICS
DIAGNOSTIC SUPERVISOR (EDSAA) OVERVIEW

START **START/SWITCH/SWITCH...<cr>**
Initialize the system and begin execution of the diagnostic program currently in memory. Switches appended to the command change the characteristics the program execution as follows:

/SECTION: **START/SECTION:argument<cr>**
Do not run the default sections of the diagnostic. Instead run only the section specified by the argument. The specific sections are unique to each diagnostic. Consult the program document for further information.

/PASS: **START/PASS:arg<cr>**
Run the program for the specified number (arg) times. The default is 1. If 0 is specified run the program indefinitely.

/TEST: **START/TEST:arg1:arg2<cr>**
Begin running the diagnostic at the first test specified (arg1) and run the diagnostic through the last test specified (arg2).

/SUBTEST: **START/TEST:arg1/SUBTEST:arg2<cr>**
If /SUBTEST is specified as an argument to /TEST then run the diagnostic from the first test specified (arg1) through the subtest specified (arg2).

RUN **RUN file.ext/switch/switch<cr>**
Initialize the system, then load and run the program specified in accordance with the switches specified. If no file extension is specified then default to .EXE. The applicable switches are described under the START command.

SUMMARY **SUMMARY<cr>**
Display a statistical report describing the performance of the diagnostic to date. Normally you would ask for a summary report after a diagnostic has run, or you would type ^C to interrupt the execution of the diagnostic, ask for a summary report, and then type CONTINUE to continue running the diagnostic.

CONTINUE **CONTINUE<cr>**
Continue execution of the diagnostic currently in memory.

DIAGNOSTICS
DIAGNOSTIC SUPERVISOR (EDSAA) OVERVIEW

ABORT

ABORT<cr>

Execute the clean up routine necessary to return the system to a known state and return to the diagnostic Supervisor command wait state: DS>. This is the recommended method of aborting the execution a diagnostic. Normally you would want to do this after diagnostic execution has been interrupt either because of a breakpoint or because you typed ^C.

SET FLAGS

SET FLAGS arg,arg,arg<cr>

Set the program control flags specified by the arguments.

Valid control flags are:

HALT	(DEFAULT:OFF) Stop diagnostic execution if an error is detected.
LOOP	(DEFAULT:OFF) Loop on the first test that detects an error. Typing ^C will break the loop and return to the Diagnostic Supervisor prompt: DC>.
BELL	(DEFAULT:OFF) Sound the bell each time an error is detected.
IE1	(DEFAULT:OFF) Inhibit all messages except those forced by either the diagnostic program or the Diagnostic Supervisor.
IE2	(DEFAULT:OFF) Inhibit all but the first three lines (Header Information) associated with each error message.
IE3	(DEFAULT:OFF) Inhibit any extended information associated with each error message.
IES	(DEFAULT:OFF) Inhibit the summary (statistical) report that is normally displayed when diagnostic execution is complete.
QUICK	(DEFAULT:OFF) Run the diagnostic in Quick Verify Mode. This will reduce the diagnostic run time. In many cases the diagnostic does this by shorting test algorithms and by reducing the number of passes per test.
TRACE	(DEFAULT:OFF) Report the header line (name) of each test as it is executed.
OPERATOR	(DEFAULT:ON) When set indicates that an operator is available should operator intervention be required.

DIAGNOSTICS
DIAGNOSTIC SUPERVISOR (EDSAA) OVERVIEW

PROMPT	(DEFAULT:ON) Enter extended dialogue. Display all limits and defaults associated with any questions associated with an operator response.						
ALL	(DEFAULT:OFF) Set all flags. Note: HALT will take precedence over the LOOP.						
SET FLAGS DEFAULT	SET FLAGS DEFAULT<cr> Restore the Control Flags to their default state: OPERATOR and PROMPT set, all others cleared.						
SHOW FLAGS	SHOW FLAGS<cr> Display the state of each flag listed under the SET FLAGS command.						
CLEAR FLAGS	CLEAR FLAGS arg,arg,arg<cr> Clear the flags specified by the arguments. The flags and their effect on the execution of a diagnostic are described under the SET FLAGS command. Also see the SET FLAGS DEFAULT command.						
SET EVENT FLAGS	SET EVENT FLAGS arg,arg<cr> Set the event flags specified by the arguments. The arguments which range from 1 through 23 are: <table border="0"> <tr> <td>1</td> <td>Directs VMS to log errors detected by the diagnostics in the System Event.</td> </tr> <tr> <td>2</td> <td>Directs VMS to execute the retry algorithms when an error is detected and reported by a diagnostic.</td> </tr> <tr> <td>3-23</td> <td>These are program specific event flags. Refer to the individual diagnostic documents for specific details. ALL Set all Event Flags.</td> </tr> </table>	1	Directs VMS to log errors detected by the diagnostics in the System Event.	2	Directs VMS to execute the retry algorithms when an error is detected and reported by a diagnostic.	3-23	These are program specific event flags. Refer to the individual diagnostic documents for specific details. ALL Set all Event Flags.
1	Directs VMS to log errors detected by the diagnostics in the System Event.						
2	Directs VMS to execute the retry algorithms when an error is detected and reported by a diagnostic.						
3-23	These are program specific event flags. Refer to the individual diagnostic documents for specific details. ALL Set all Event Flags.						
CLEAR EVENT FLAGS	CLEAR EVENT FLAGS arg,arg<cr> Clear the Event Flags specified by the arguments. The flags and their effect on the execution of a diagnostic are described under the SET EVENT FLAGS command.						
SHOW EVENT FLAGS	SHOW EVENT FLAGS<cr> Display the state of each Event Flag listed under the SET EVENT FLAGS command.						
SET BASE	SET BASE address<cr> Set the base address to the value specified by address argument. Once the base address is set all address references will be offset by the value of the base address. For example, if the base address was set to 200 and the command EXAMINE 50 were entered, the Diagnostic Supervisor would display the contents of address 250.						

DIAGNOSTICS
DIAGNOSTIC SUPERVISOR (EDSAA) OVERVIEW

SET BREAKPOINT **SET BREAKPOINT** address<cr>
Insert a breakpoint at the address specified by the address argument. If the program attempts to execute the instruction in the specified address, interrupt execution and return to the Diagnostic Supervisor Command Prompt: DS>. See the CONTINUE command. Also see the CLEAR BREAKPOINT command.

NOTE

The Diagnostic Supervisor will support up to 15 independent breakpoints.

CLEAR BREAKPOINT **CLEAR BREAKPOINT** address<cr>
Remove the breakpoint that is set at the address specified by the address argument.

ALL If the argument ALL is specified instead of an address then clear all breakpoints.

SHOW BREAKPOINT **SHOW BREAKPOINT**<cr>
Display the address associated with all breakpoints that are currently in effect.

SET DEFAULT **SET DEFAULT** arg1,arg2<cr>
Set the default qualifiers for the EXAMINE and DEPOSIT commands where argument 1 represents data length and argument 2 represents the radix. Valid data length arguments are:

BYTE 08 bits
WORD 16 bits
LONG 32 bits (default)

Valid Radix arguments are:

HEX Hexadecimal (default)
DEC Decimal
OCT Octal

EXAMINE **EXAMINE**/arg1/arg2 address<cr>
Display the contents of the address specified in the data length specified by argument 1, and in the radix specified by argument 2.

Valid data length arguments are:

/B - Byte (08 bits)
/W - Word (16 bits)
/L - Longword (32 bits)

Valid radix arguments are:

/H - Hexadecimal (base 16)
/D - Decimal (base 10)
/O - Octal (base 8)
/A - ASCII bytes

If no arguments are specified then display the contents of the address using the values specified by the last SET DEFAULT command.

DIAGNOSTICS
DIAGNOSTIC SUPERVISOR (EDSAA) OVERVIEW

If the address is proceeded by one of the following symbols then interpret the address in the radix indicated.

%Address - Decimal
%HAddress - Hexadecimal
%Oaddress - Octal

DEPOSIT DEPOSIT/arg1/arg2 address data<cr>
Deposit the data specified in the address specified. If no arguments are specified then interpret data in the data length and radix values specified by the last SET DEFAULT command. The arguments are the same as those for the EXAMINE command.

NEXT NEXT arg<cr>
Execute the decimal number of macro instructions specified by the argument. Then display the new PC and the next 4 bytes.

NOTE

Normally this command would be used in conjunction with breakpoints.

Table 6-22 Device List for ATTACH, SELECT, and DESELECT Commands

Device Type	Link	Device Name	Additional Parameters
CR11	DWa	CRA	<ucsr><uvector><ubr>
DMC11	DWa	XMan	<ucsr><uvector><ubr>
DR11B	DWa	??a	<ucsr><uvector><ubr>
DR780	SBI	??a	<tr>
DUP11	DWa	XJan	<ucsr><uvector><ubr>
DW780	SBI	DWa	<tr>
DZ11	DWa	TTa	<ucsr><uvector><ubr><EIA> !<20MA>
KA780	SBI	KAn	<G-floating><H-floating> <WCS-last-address>
KMC11	DWa	XMan	<ucsr><uvector><ubr>
LP11	DWa	LPa	<ucsr><uvector><ubr>
MS780	SBI	MSa	<tr>
PCL11	DWa	??a	<ucsr><uvector><ubr>
RH780	SBI	RHa	<tr>
RK06	DMa	DMan	
RK07	DMa	DMan	
RK611	DWa	DMa	<ucsr><uvector><ubr>
RL02	??a	??an	
RL11	Dwa	??a	<ucsr><uvector><ubr>
RM03	RHa	DRan	
RP04	RHa	DBan	
RP05	RHa	DBan	
RP06	RHa	DBan	
RP07	RHa	DBan	
TE16	MTa	MTan	
TM03	RHa	MTa	<drive>
TS04	Dwa	MTan	<ucsr><uvector><ubr>
TU45	MTa	MTan	
TU77	MTa	MTan	

The definitions for the additional parameters are:

Parameter	Description	Radix	Range
<tr>	Adapter TR Number	Decimal	1-15
 	Adapter BR Level	Decimal	4-7
<drive>	Massbus Drive	Decimal	0-7
<ucsr>	Unibus CSR Address	Octal	760000-777776
<uvector>	Unibus Vector	Octal	2-776
<ubr>	Unibus BR Level	Decimal	4-7

6.9 RL02 RESIDENT VAX MACRO-DIAGNOSTICS

Table 6-23 lists the Macro-Diagnostics that are available on the RL02 load medium.

Table 6-23: RL02 Resident VAX Macrodiagnostics

Name	Description
EVKAA.EXE	VAX Hardcore Instruction Test
EDSAA.EXE	VAX 8600 Diagnostic Supervisor (8600/8650)
EDKAB.EXE	VAX Basic Instruction Exerciser (8600/8650)
EVKAB.EXE	VAX Basic Instruction Exerciser
EVKAC.EXE	VAX Floating-Point Exerciser
EVKAD.EXE	VAX Compatibility Mode Instructions Exerciser
EVKAE.EXE	VAX Privileged Architecture Exerciser
EVCAA.EXE	RH780 Diagnostic
EVCBA.EXE	DW780 Repair Diagnostic
EDCLA.EXE	DW780, CI780, DR780, RH780 SBI Exerciser (8600/8650)
EVCGA.EXE	CI780 Repair Level Diagnostic Part 1
EVCGB.EXE	CI780 Repair Level Diagnostic Part 2
EVCGC.EXE	CI780 Repair Level Diagnostic Part 3
EVCGD.EXE	CI780 Repair Level Diagnostic Part 4
EVGAA.EXE	CI780 Functional Diagnostic Part 1
EVGAB.EXE	CI780 Functional Diagnostic Part 2
EVMAA.EXE	VAX Generic Tape Exerciser
EVMAB.EXE	TM03-TE16/TU45/TU77 Function Timing Tests
EVMAC.EXE	TM03-TE16/TU45/TU77 Control Logic Tests
EVMAE.EXE	VAX TM78/TU78 Control Logic Diagnostic
EVMBB.EXE	TU81 Front End/Host Functional Diagnostic
EVMBD.EXE	VAX TU80 Functional Diagnostic Part 1
EVMBE.EXE	VAX TU80 Functional Diagnostic Part 2
EVQTF.EXE	TM78 Loadable Driver
EVQTM.EXE	TM03-TE16/TU77 Loadable Driver
EVQTS.EXE	VAX TS11 Standalone Driver
EVQUE.EXE	VAX UBE Driver/UBE QIO Driver
EVRLA.EXE	VAX UDA and RA Drive Diagnostic
EVRLB.EXE	VAX RA60/RA80/RA81 Formatter
EVSBA.EXE	Autosizer Level 3
EDKAX.EXE	VAX 8600 CPU Cluster Exerciser (8600/8650)



CHAPTER 7

SYSTEM INFORMATION

7.1 VAX 8600 TO 8650 DIFFERENCES/UPGRADE

The packaging, reliability, and features of the VAX 8650 are the same as the VAX 8600. The physical characteristics and footprint are the same. The VAX 8650 delivers 1.44 times the performance of the VAX 8600. The performance improvement has been achieved by increasing the clock rate from 50 MHz to 72 Mhz, reducing the CPU microcycle time from 80 nsec to 55 nsec.

The increase in clock rate requires two new modules, and requires that certain other modules be at specified revisions as per the following table. Note that the MCC and CLK modules are new modules for the VAX 8650.

Modules Pertaining to VAX 8600/8650 Upgrade

Module Name	VAX 8600	VAX 8650	Revision
MCC--MBox Control	L0220	L0230	--
CLK--Clock	L0217	L0231	--
MCD--MBox Data Paths	L0204	L0204	F1
MAP--MBox Address Paths	L0205	L0205	E1
IDP--IBox Data Paths	L0206	L0206	H1
EBD--EBox Data Paths	L0211	L0211	E1
FBA--FBox Adder	L0212	L0212	H1
MOS Memory Array, 4 Mb	L0200	-----	<D1
MOS Memory Array, 4 Mb	L0200	L0200	=,>D1
MOS Memory Array, 4 Mb	L0226	L0226	Any
MOS Memory Array, 16 Mb	L0225	L0225	Any
MOS Memory Array, 64 Mb	L0235	L0235	Any

NOTES

1. The L0230 (MCC) and L0231 (CLK) make up the 861UP-AA upgrade kit.
2. The revision shown for the L0204, L0205, L0206, L0211, and L0212 is the minimum revision required to upgrade from 8600 to 8650. If these modules are not up to minimum revision, the upgrade prerequisite kit, 861UP-BA, must be ordered.
3. The L0200, revision level D1 or above, L0226, L0225, and L0235 are backward compatible with the VAX 8600.
4. The L0200 below revision level D1 can only be used on the VAX 8600.
5. The minimum required version of VAX/VMS to support the VAX 8650 is Version 4.3.




Figure 7-1 System Block Diagram




Figure 7-2 CPU Block Diagram

SYSTEM INFORMATION

7.2 KA8600/8650 RAM AND MICROCODE LISTING INFORMATION

7.2.1 KA8600/8650 Common RAM and Microcode Listing Information

Control Store	Last Addr	Size (DxW)	Term Used	List Name	Module Location	Console Label
ESC	FF	256x32	E	ECODE	EDP/209	ESC
Context	1FF	512x4	X	CTX	EBC/210	CONTEXT
FADD CS	1FF	512x48	B	FADD	FBA/212	FBACS
FDRAM	3FF	1Kx8	G	FADD	FBM/213	FDRAM
FMUL CS	1FF	512x40	F	FMUL	FBM/213	FBMCS
MCF	FF	256x16	Y	MCF	EBC/210	MCF
IBox CS	FF	256x52	I	IBOX	ICA/207	ICS

7.2.2 KA8600 Specific RAM and Microcode Listing Information

Control Store	Last Addr	Size (DxW)	Term Used	List Name	Module Location	Console Label
EBox CS	1FFF	8Kx92	U	KA8600	CSA/215 CSB/216	ECS
IDRAM	FFF	4Kx20	D	KA8600	IBD/208	IDRAM
MBox CS	FF	256x80	M	UCODE0	MCC/220	MCS
CYCLE	FF	256x20	N	CYCLE	MCC/220	CYCLE
Access	FF	256x1	H	ACCESS	MCC/220	ACCESS

7.2.3 KA8650 Specific RAM and Microcode Listing Information

Control Store	Last Addr	Size (DxW)	Term Used	List Name	Module Location	Console Label
EBox CS	1FFF	8Kx92	U	KA8650	CSA/215 CSB/216	ECS
IDRAM	FFF	4Kx20	D	KA8650	IBD/208	IDRAM
MBox CS	FF	256x80	M	UCODE5	MCC/230	MCS
Access	FF	256x1	H	ACCESS	MCC/230	ACCESS
CYCLE	FF	256x20	N	CYCLE	MCC/230	CYCLE

Field	Descriptions
Control Store:	The name of the control store.
Last Address:	The last address within the range of the specified control store.
Size (DxW):	Size of the control store: Depth (D, number of locations) X Width (W, number of bits).
Term Used:	The term used in the listings files which indicates the contents of the specified control store location.
Listing Name:	The listing name where the contents of the specified control store can be found. Listing has a .MCR extension.
Module Location:	The module mnemonic and module number where the control store is located.
Console Label:	The console mnemonic used with the EXAMINE and DEPOSIT commands. Note 1.

NOTES

1. With the exception of the ESC, the HEX debugger must be loaded and the clock stopped to deposit/examine these control stores.
2. The CONTEXT RAMs are 1K RAMs.
3. The file extension for the listing files is .MCR (e.g., FADD.MCR). The actual source files (for loading from the console disk to the control stores) have either a .BPN (binary packed normalized) or .PHY (physical/ASCII) extension.
4. During system initialization the console software reads KA86n.REV (where n=0 for a KA8600 and n=5 for a KA8650). The contents of this file is used to assure that the correct version of the microcode is loaded.

SYSTEM INFORMATION

7.3 INTERRUPT LEVEL ASSIGNMENTS/SOURCES

Level	Condition	Vector	Source
IPR 1F	None Assigned	-----	-----
IPR 1E	CPU Power Fail	00C	Internal
	SBI 0 Fail	064	External
	SBI 1 Fail	264	External
IPR 1D	M Box Error	054	Internal
IPR 1C	SBIA 0 Error	060	External
	SBI 0 Fault	05C	External
	SBIA 1 Error	260	External
	SBI 1 Fault	25C	External
IPR 1B	SBI 0 Alert	058	External
	SBI 1 Alert	258	External
IPR 1A	None Assigned	-----	-----
IPR 19	SBI 0 Silo Compare	050	External
	SBI 1 Silo Compare	250	External
IPR 18	Interval Timer	0C0	Internal
IPR 17	SBI 0 REQ 7/UNIBUS BR 7	1C0-1FC	External
	SBI 1 REQ 7/UNIBUS BR 7	3C0-3FC	External
IPR 16	SBI 0 REQ 6/UNIBUS BR 6	180-1BC	External
	SBI 1 REQ 6/UNIBUS BR 6	380-3BC	External
IPR 15	SBI 0 REQ 5/UNIBUS BR 5	140-17C	External
	SBI 1 REQ 5/UNIBUS BR 5	340-37C	External
IPR 14	Console Terminal Receive	0F8	Internal
	Console Terminal Transmit	0FC	Internal
	SBI 0 REQ 4/UNIBUS BR 4	100-13C	External
	SBI 1 REQ 4/UNIBUS BR 4	300-33C	External
IPR 13	None Assigned	-----	-----
IPR 12	None Assigned	-----	-----
IPR 11	None Assigned	-----	-----
IPR 10	None Assigned	-----	-----
IPR 0F	Software Request 0F	0BC	Software
IPR 0E	Software Request 0E	0B8	Software
IPR 0D	Software Request 0D	0B4	Software
IPR 0C	Software Request 0C	0B0	Software
IPR 0B	Software Request 0B	0AC	Software
IPR 0A	Software Request 0A	0A8	Software
IPR 09	Software Request 09	0A4	Software
IPR 08	Software Request 08	0A0	Software
IPR 07	Software Request 07	09C	Software
IPR 06	Software Request 06	098	Software
IPR 05	Software Request 05	094	Software
IPR 04	Software Request 04	090	Software
IPR 03	Software Request 03	08C	Software
IPR 02	Software Request 02	088	Software
	or AST Delivery		
IPR 01	Software Request 01	084	Software

This table represents only those external interrupts which can originate from the two SBI adapters or SBI devices attached to them.

Generally, the ABus supports hardware interrupt levels 10 through 1E. Future ABus attachments may make use of this capability and require the assignment of additional locations in the SCB.

7.4 VAX 8600/8650 SYSTEM CONTROL BLOCK

Vector	Name	Type	Code
000	Unused	----	3
004	Machine Check	Fault/Abort	1
008	Kernel Stack Not Valid	Abort	1
00C	CPU Power Fail	Interrupt	1
010	DEC Reserved Opcodes & Privileged Instructions	Fault	0
014	Reserved Customer Opcodes	Fault	0
018	Reserved Operands	Fault/Abort	0
01C	Reserved Addressing Modes	Fault	0
020	Access Control violation	Fault	0
024	Translation not Valid	Fault	0
028	Trace Pending	Fault	0
02C	Breakpoint	Fault	0
030	Compatibility Mode	Fault/Abort	0
034	Arithmetic	Trap/Fault	0
038	Unused	----	3
03C	Unused	----	3
040	CHMK Opcode	Trap	0
044	CHME Opcode	Trap	0
048	CHMS Opcode	Trap	0
04C	CHMU Opcode	Trap	0
050	SBI 0 Silo Compare	Interrupt	1
054	Array Single Bit Error	Interrupt	1
058	SBI 0 Alert	Interrupt	1
05C	SBI 0 Fault	Interrupt	1
060	SBI 0 Error	Interrupt	1
064	SBI 0 Fail	Interrupt	1
068/080	Unused	----	3
084	Software Request 01	Interrupt	1
088	Software Request 02 or AST Delivery	Interrupt	0
08C	Software Request 03	Interrupt	1
090	Software Request 04	Interrupt	1
094	Software Request 05	Interrupt	1
098	Software Request 06	Interrupt	1
09C	Software Request 07	Interrupt	1
0A0	Software Request 08	Interrupt	1
0A4	Software Request 09	Interrupt	1
0A8	Software Request 0A	Interrupt	1
0AC	Software Request 0B	Interrupt	1
0B0	Software Request 0C	Interrupt	1
0B4	Software Request 0D	Interrupt	1
0B8	Software Request 0E	Interrupt	1
0BC	Software Request 0F	Interrupt	1
0C0	Interval Timer	Interrupt	1
0C4/0EC	Unused	----	3
0F0	Console Block Storage	Interrupt	0
0F4	Unused	----	3
0F8	Console Terminal Receive	Interrupt	1
0FC	Console Terminal Transmit	Interrupt	1
100-13C	SBI 0 REQ 4/UNIBUS BR 4	Interrupt	1
140-17C	SBI 0 REQ 5/UNIBUS BR 5	Interrupt	1
180-1BC	SBI 0 REQ 6/UNIBUS BR 6	Interrupt	1
1C0-1FC	SBI 0 REQ 7/UNIBUS BR 7	Interrupt	1

SYSTEM INFORMATION

Vector	Name	Type	Code
200-24C	Unused	----	3
250	SBI 1 Silo Compare	Interrupt	1
254	SBI 1 Fail	Interrupt	1
258	SBI 1 Alert	Interrupt	1
25C	SBI 1 Fault	Interrupt	1
260	SBI 1 Error	Interrupt	1
264-2FC	Unused	----	3
300-33C	SBI 1 REQ 4/UNIBUS BR 4	Interrupt	1
340-37C	SBI 1 REQ 5/UNIBUS BR 5	Interrupt	1
380-3BC	SBI 1 REQ 6/UNIBUS BR 6	Interrupt	1
3C0-3FC	SBI 1 REQ 7/UNIBUS BR 7	Interrupt	1
400-7FC	Unused	----	3

Code	Description
0	Service on Kernel Stack (Interrupt Stack if selected)
1	Service on Interrupt Stack
2	Service via WCS (if no WCS HALT)
3	Reserved

NOTE

The Interrupt Vectors for SBI 1 are offset from SBI 0 by a page (200 words). The offset is added by the EBox Interrupt handling microcode after it examines CSLINT <22:21> and determines which adapter needs service.


7.5 CONFIGURATION GUIDELINES

7.5.1 Kernel System

The basic parts of the "Kernel" system are the CPU and the front end cabinet. These two parts make up the base level machine from which all system packages are derived.

The kernel system contains the following:

1. CPU cabinet (1)
2. DB86 SBI Adapter (1)
3. DF112 modem [(for 60 Hz systems only) (1)]
4. DW780 UNIBUS adapter (1)
5. ECC MOS memory (up to 68 Megabytes)
6. Front End Cabinet (FEC) (1)



MR-16591

Figure 7-3 Kernel System - Front View

Nomenclature:

- | | |
|------------------------------|---|
| 1. CI780-MA | SBI-based Computer Interconnect Adapter |
| 2. DB86-AA | SBI Adapter (SBIA) |
| 3. DW780-MA | SBI-based UNIBUS Adapter |
| 4. FP86-AA | Floating Point Accelerator |
| 5. MS86-AA, BA, CA,
or DA | ECC MOS memory |
| 6. RB86-AA | IDTC option (comprised of DW780-MA and UDA50-A) |
| 7. RES | Reserved for expansion |
| 8. STD | Standard, part of basic KERNEL package |


7.5.2 CPU Cabinet Expansion

The CPU can accommodate the following:

- | | |
|------------------------------|---|
| 1. CI780-MA | Computer Interconnect (1) |
| 2. DB86-AA | SBI Adapters (2) |
| 3. DW780-MA, DW780-MB | UNIBUS adapters (2) |
| 4. FP86-AA | Floating Point Accelerator (1) |
| 5. MS86-AA, BA, CA,
or DA | (up to 260 megabytes with battery backup) |
| 6. RB86-AA | IDTC option (1) |

These options have dedicated and pre-wired slots within the CPU cabinet. Only the proper variations of these options can be configured into the CPU cabinet.

SYSTEM INFORMATION



CPU CABINET - FRONT VIEW

MR-16593

Figure 7-4 CPU Cabinet - Front View

The CPU has enough power and cooling to handle the maximum configuration, as is illustrated below, without requiring any additional power supplies.

The CPU cabinet can be divided into four separate backplanes: Memory, CPU, ABUS, and I/O. All four backplanes are standard with the kernel system.

7.5.2.1 CPU Backplane - The CPU backplane contains all the CPU modules and the memory controller. It also has reserved slots for the FP86-AA option. The design of the KA86 CPU requires the use of substitution modules in the CPU backplane when the FP86-AA is not present. If the FP86-AA is present, slot 7 will contain an L0213 (FBM) and slot 8 an L0212 (FBA). If the FP86-AA is not installed, slot 7 will contain an L0218 (FJM) and slot 8 an L0223 (FTM).

7.5.2.2 Memory Backplane - The memory backplane accepts the MS86-AA, BA, CA, or DA ECC MOS memory boards, for a maximum capacity of 260 megabytes. The MS86-AA option is an L0226 4 megabyte module. It may be used on both the VAX 8600 and 8650. The MS86-BA option is an L0200 module with 4 megabytes. L0200 modules below revision D1 can only be used on the VAX 8600 while L0200 modules, with revision levels of D1 and upward, can be used on both the VAX 8600 and 8650. The MS86-CA is an L0225 16 Mb memory board that takes up the space of two backplane slots. It may be used on both the VAX 8600 and 8650. The MS86-DA is an L0235 64 Mb memory board that takes up the space of two backplane slots. It may also be used on both the VAX 8600 and 8650. The system memory backplane cannot be expanded to any external memory. No other memory is supported on the system.

When installing additional memory array modules, always start from the lowest slot number and work your way up. For example, if the system currently has three 4 Mb array modules (12 Mb) in slots 1, 2, and 3, install the fourth array module into slot 4. This method of module utilization (contiguous from slot 1 through 8) is recommended but not mandatory. In other words, you can interchange memory modules in any slot (1-8) for troubleshooting procedures.

If memory modules of unlike sizes are installed in the same system, install the larger capacity modules first. If a combination of four 64 Mb and 16 Mb modules have already been installed, one 4 Mb module may be installed in slot 8.

Use of L9200 Memory Load Modules

The L9200 is a memory array load module. It is used to put the minimum specified load on the appropriate regulator. This module is to be used in systems that have an insufficient number of array modules for correct loading. If there is no memory array module in slot 5 or 8, then an L9200 is required in those slots. There is an exception to this rule for systems that are using RL02 version 2 and 3 packs. For these cases, a memory array module must be installed in slot 8, and if slot 7 is empty, it must have an L9200.

7.5.2.3 ABUS Backplane - The ABUS, which performs critical timing and data transfers from the SBI to the CPU, is capable of supporting two DB86-AA SBI Adapters (SBIA). The first unit (SBIA0) is the SBI adapter for the I/O backplane. The second unit (SBIA1) is used for additional SBI expansion capabilities.

7.5.2.4 I/O Backplane - The I/O backplane is a dedicated, pre-wired SBI, UNIBUS backplane than can support one CI780-MA, one DW780-MA, one DW780-MB, and a RB86-AA.

1. The CI780-MA is used for connection to a cluster environment. The CI cables connect to the rear bulkhead of the CPU cabinet.
2. The DW780-MA is included with the kernel system. The UNIBUS for this DW connects to the Ball UNIBUS drawer in the front end cabinet. This adapter is dedicated for front end use only.
3. The DW780-MB is designed for UNIBUS expansion out of the I/O backplane. The UNIBUS for this DW connects to a Ball drawer in a UNIBUS expansion cabinet mounted to the left of the front end cabinet.
4. The RB86-AA is comprised of a DW780-MA and a UDA50-A. These options mount in a reserved area of the I/O backplane which supports a TU81 controller module. Note that these three SPC UNIBUS slots are wired specifically for these options (UDA50 and TU81 controller) and will not work with other UNIBUS options. Furthermore, this UNIBUS is terminated within the I/O backplane (M9302 in slot 1) and is not intended to be expanded beyond the CPU cabinet on a permanent basis.

Contact your local field support organization for information on expanding this UNIBUS for troubleshooting purposes.

5. The M9040 module installed in slot 5 provides termination for the SBI. This module must be removed if SBI0 is expanded to an expansion cabinet.

SYSTEM INFORMATION




Figure 7-5 Ball-AL Front End Cabinet

7.5.3 Front End Cabinet

The Front End Cabinet (FEC) contains the console RL02 disk, the RLV12 controller, Ball-AL expansion boxes and UNIBUS backplanes. Within the FEC there is space reserved for mounting a 50HZ transformer.

The Ball-AL is controlled by the DW780-MA (DW0) in the CPU cabinet and is configured with five UNIBUS system units and one QBus system unit (for the console). The standard kernel system, shown above, includes:


1. DEUNA (1)
2. DMF32 (1)
3. DMZ32 (4)

This is the MAXIMUM configuration allowed within this Ball-AL mounting box and is not expandable. You can, however, alter the UNIBUS configuration within the Ball-AL by replacing some of the options. Furthermore, this UNIBUS may be expanded to a second Ball-A drawer mounted in a UNIBUS expansion cabinet. Refer to 'Ball-AL/AM EXPANSION RULES' for more details on configuring options within the Front End Ball-AL.

7.5.4 Ball-AL/AM EXPANSION RULES

The Ball-AL/AM can accommodate six system units, DD11-CK or DD11-DK. The maximum output power in the Ball-A box cannot exceed 500 watts. The power supply in the Ball-A box is partitioned into two areas; the first area containing the first four system units and the second area containing the remaining two system units. The power supply is rated at +5 V 96 A. The system units are as follows:

System unit 1-2	+5 V	32 A
System unit 3-4	+5 V	32 A
System unit 1-4	+15 V	3 A
	-15 V	3 A
System unit 5-6	+5 V	32 A
	+15 V	5 A
	-15 V	1.5 A



BA11-AL/AM BACKPLANE DIAGRAM

MR-15594

Figure 7-6 Ball-AL/AM Backplane Diagram

Configuration Rules for Ball-AL/AM

When adding an option or backplane to a Ball-A expansion box the following rules apply:

1. In addition to the regular configuring rules on the amperage available for the backplane, the Ball-A expansion box requires that the power drawn by options be known and used as a configuring requirement. The total power drawn by UNIBUS options mounted in the expansion box cannot exceed 500 watts (see discussion below).
2. Locate hex-sized options in the backplane starting in slot 3. Slots 1, 2, and 9 are available only for use by quad-sized options, unless configuring quad-sized options in these slots violates rule 3.
3. Any single module option that produces more than 40 watts requires that the slot adjacent to the component side of the option be unoccupied (due to cooling restrictions). Dual-module options (i.e., DEUNA) that produce over 40 watts can be mounted in consecutive slots, and require the slot adjacent to the component side of the dual-module option be unoccupied.
4. Standard UNIBUS configuration rules apply to any UNIBUS on the system. Use the 'PDP 11 BUS HANDBOOK' or the Field Service 'PAULI' program for assistance.

Example 7-1: Power consumption for the DMF32

The DMF32 Communications Controller draws 8 Amps @ +5 V, 0.50 Amps @ +15 V, and .50 Amps @ -15 V. Using these figures as input to the formula the following results are achieved:

$$\begin{aligned}
 8 \times 5 &= 40 \text{ (watts)} \\
 .5 \times 15 &= 7.5 \text{ (watts)} \\
 .5 \times 15 &= 7.5 \text{ (watts)} \\
 \hline
 \text{Option total} &= 55 \text{ watts}
 \end{aligned}$$

This result is important in two ways. One, because the DMF32 option produces more than 40 watts, the previous slot (slot adjacent to the component side of the module) needs to be unoccupied. Second, the power consumed by the DMF32 (55) is subtracted from the available total of 500 watts. Therefore, to add the DMF32 to an unpopulated DD11-DK backplane in a Ball-A expansion box, the option will require two slots; slot 2 for the 40 watt rule, slot 3 for the module. This leaves 445 watts remaining. Adding a second DMF32 to the backplane would require two slots, slot 4 remains unoccupied and the second DMF32 module is configured into slot 5.

Proceed in the same manner for additional UNIBUS options, tracking the total power consumption for the box, and following the slot rule based on each options power requirements.

7.5.5 UNIBUS Expansion

There are three ways to utilize the UNIBUS expansion capabilities of the system.

1. Use the DW780-MB (installed in the I/O backplane).

The DW780-MB mounts in the I/O backplane (DW1). Order the H9652-F UNIBUS expansion cabinet and DD11-DK backplanes. These cabinets will mount to the left side of the front end cabinet. See diagram of UNIBUS expansion configuration.


2. To use the DW780-AA/AB (installed in SBI expansion cabinet).

This variation mounts in an H9652-C series SBI expansion cabinet. Order H9652-F series UNIBUS expansion cabinets and DD11-DK backplanes. The UNIBUS cabinets will mount to the right of the last H9652-C series SBI cabinet.

3. To expand the front-end UNIBUS (DW0).

The UNIBUS in the Front End Ball-A drawer (DW0) may be expanded to a second Ball-A drawer in a UNIBUS expansion cabinet. Order H9652-F Series UNIBUS expansion cabinets and DD11-DK backplanes. The UNIBUS cabinets will mount to the left of the Front End cabinet (see diagram below).

The standard UNIBUS configuration rules apply (i.e., bus loads, bus length). See the section 'Ball-AL/AM EXPANSION RULES' for more information on configuring the Ball-A UNIBUS expansion box. Also, the Field Service 'PAULI' system may be used for reference.



MM-16592

Figure 7-7 UNIBUS Expansion Configurations

7.5.6 SBI Expansion

The system is capable of supporting two independent SBI adapters. There are two ways to utilize these SBI expansion capabilities.

1. Expand the SBI adapter included in the CPU.
 - a. The configuration rule for the first SBI allows a maximum of one H9652-C SBI expansion cabinet (4 option panel spaces) which mounts to the right of the CPU cabinet.
 - b. Refer to system SBI configuration rules for more details.
2. Order the optional SBI adapter, DB86-AA.
 - a. The configuration rule for the second SBI allows a maximum of two H9652-C SBI expansion cabinets (8 SBI NEXUS slots) which mount to the right of the CPU cabinet.
 - b. Refer to system SBI configuration rules for more details.

SYSTEM INFORMATION

7.5.6.1 SBI Configuration Rules -

1. Only one SDI can be expanded per system.
2. Maximum of two CI780s per system (either on the internal SBI or the optional SBI). See cluster rules for more details.
3. Maximum of two CI780s per SBI (only one if a DR780 is also connected).
4. Maximum of four DR780s per SBI (only one if a CI780 is also connected).
5. Maximum of four RH780s per SBI.
6. Maximum of four DW780s per SBI.
7. When expanding the internal SBI (SBIA-0) from the CPU cabinet to the H9652-C SBI expansion cabinet, be sure to remove the SBI terminator (M9040) from slot 5 of the I/O backplane.

7.5.6.2 SBI TR Level Assignments - The chart below is suggested as a guideline for assigning TR levels on SBIs. On a system with two separate SBIs, configure each SBI independently.

Absolute TR levels and unused TR levels do not matter. Relative TR levels determine relative priority and do not matter. High number TR levels mean low priority in competing for SBI access. TR 0 is the highest priority and TR 16 is the lowest priority.

The following restrictions apply:

1. TR 00 is reserved for HOLD
2. TR 01 is reserved for DMA return (asserted by SBIA)
3. TR 02 is reserved for the CPU (actually SBIA) (see note 2)

VAX 8600 SYSTEM SBI TR LEVEL ASSIGNMENT CHART

TR level	SBI Nexus
0	HOLD
1	DMA return (SBIA)
2	CPU (SBIA) (see note 2)
3	first UBA (DW780)
4	second UBA
5	third UBA
6	fourth UBA
7	- - -
8	first MBA (for disks)
9	second MBA (for tapes)
10	third MBA
11	fourth MBA
12	- - -
13	first CI780
14	first DR780 (or second CI780)
15	second DR780
16	- - -

NOTES

1. Refer to section SBI NEXUS and INTERNAL OPTIONS for information on setting the TR level for a particular option. This section will include information on jumper settings.
2. Where the CPU(SBIA) TR level is 2, the SBI ID number remains at 16.
3. The DR780 and CI780 TR levels may be interchanged, however, if a DR780 and a CI780 exist on the same SBI then the CI780 must be at the higher priority (as shown).

7.5.7 Cluster Rules

1. Every CPU in a cluster must be able to communicate with every other CPU. (Each CPU must have a least one CI connected to a common star coupler.)
2. A CPU may be a member of only one cluster at a time.
3. HSC50s connected to a CPU on a star coupler other than the star coupler on the public cluster are considered 'private HSC50s'.
4. Disks connected to private HSC50s cannot be made cluster accessible.
5. VMS can presently support only two CIs per CPU. Three or more are possible in a future release.
6. Only 16 nodes per star coupler.
7. Each node connected to a star coupler must have a unique node number and node name.

SYSTEM INFORMATION

7.6 PM PROCEDURES

The following PM procedure has been developed in an effort to increase the MTBF for the VAX 8600/8650 systems. This procedure should be followed in the field on a consistent basis to ensure maximum reliability.

It is recommended that error logs be checked and diagnostics be run prior to performing this procedure to ensure that no problems are injected into the system during this procedure.

7.6.1 Summary of Quarterly PM Procedures

1. Clean air vents, check fans and check voltages in BA boxes.
2. Check system cables for damage.
3. Clean and replace filters.
4. Verify revisions.
5. Check system power.
6. Perform scheduled device PMs.
7. Run systems exerciser.

7.6.2 Summary of Annual PM Procedures

1. Run margins.
2. Run system diagnostics.
3. Replace RL02 filter absolute filter

7.6.3 Quarterly PM Procedures

1. Clean air vents, check fans and check voltages in BA boxes.
 - a. Visually inspect air vents and clean as necessary.
 - b. Ensure fans are operating correctly and replace as needed.

SYSTEM INFORMATION

- c. Measure voltages in the BALL box using a digital volt meter (DVM). The table below lists the color code, and associated backplane pin, used on each of the power harnesses within the BALL expansion drawer.

Color	Voltage	Backplane Pin
BLACK	GROUND	C2
RED	+ 5 VOLTS	A2
GRAY	+15 VOLTS	CU1
WHITE	+15 VOLTS	CU1
BLUE	-15 VOLTS	CB2
GREEN	-15 VOLTS	CB2
BROWN	- 5 VOLTS	CD1
VIOLET	DC LOW	CN1
YELLOW	AC LOW	CV1

NOTE

Log and retain these power measurements for comparison at each PM performance, for indications of power degradation. The H7140 is an FRU as a complete unit and voltage adjustments are to be done at the factory only.

2. Check system cables for damage.
 - Visually inspect system cables for fraying, crimping, or any other types of damage. Replace as necessary.
3. Clean and replace filters.
 - a. CPU card cage filter - Power down the system. Turn the two black catches at the bottom of the card cage support assembly so they are parallel to the support assembly. Slide the filter out of the CPU cabinet. Use a vacuum to clean the filter, then reinstall the filter.
 - b. Front End cabinet - Open front and rear doors of the front end cabinet. Remove the filters mounted on the inside of the doors by peeling them away from the velcro strips holding them in place. Insert the new filters, part numbers 12-11255-14 (1), 12-11255-08 (3), and 12-11255-02 (1).
 - c. RL02 prefilter - Remove the 6 screws holding the front bezel in place. Remove the front bezel. Replace the prefilter located on the right front side of the drive (PN 74-15297-00).
 - d. CPU Air Mufflers - Insure that free air flow exists in the air mufflers mounted on the rear doors of the CPU.

SYSTEM INFORMATION

4. Verify revisions.
 - a. Check system revisions by referencing the Revision Matrix documents in the microfiche, K-RM-8650-0-0 for the VAX 8650 or K-RM-8600-0-0 for the VAX 8600.
 - b. Install any necessary FCOs.
 - c. Insure that the latest RL02 Console release is being used on the system.
5. Check system power.
 - Measure system regulator power and ground current by use of the show power command (>>>SHOW POWER). Retain this for comparison at each quarterly PM, for indications of possible system power degradation.
6. Perform scheduled device PMs.
 - Refer to microfiche PM listings.
7. Run systems exerciser <EDKAX>.
 - Run the VAX 86XX system exerciser diagnostic, EDKAX, for 5 passes, referring to the diagnostic microfiche listing for specific operating instructions.

```
>>>@EDSAA  
DS> ATT KA86 HUB KAO Y Y 0 1  
DS> SEL KAO  
DS> R EDKAX/PASS:5
```

7.6.4 Annual PM Procedures

1. Replace RL02 absolute filter
 - Locate the 2 plenum springs and plenum cover latches. Lift one of the plenum latches. While holding the plenum spring, squeeze the latch and remove the latch from the bracket. Remove the plenum spring then repeat the procedure for the 2nd latch and spring. The plenum cover may now be removed by pulling the cover forward. Use a screwdriver to pry the left side of the filter out slightly. The filter can then be removed by rocking it from side to side until it slides free. Replace the filter (PN 12-13097-00).

2. Run system diagnostics.

- Execute 1 pass of the TSTCPU.COM file. This will take about 45 minutes and test the complete CPU.

```
>>>@TSTCPU
```

3. Run margins.

- Run one pass of the TSTCPU script with voltage margins high. Repeat with voltage margins low.

```
>>>DIAG
DC>SET MARG HI
DC>@TSTCPU
DC>SET MARG LO
DC>@TSTCPU
```

```
DC>SET MARG NO
```

4. Execute CPU MACRO diagnostics.

a. Load the Diagnostic Supervisor and ATTACH the CPU

```
>>>@EDSAA
DS> ATT KA86 HUB KA0 Y Y 0 1
DS> SEL KA0
```

b. Run 1 pass of the CPU macro diagnostics.

```
DS> R diagnostic_name
Diagnostics to be run are:
EVKAB
EVKAC
EVKAD
EVKAE
EDKAX
```

SYSTEM INFORMATION

7.6.5 VAX 8600/8650 PM Checklist

TASK	QUARTERLY
BA BOXES	
1. Air vents cleaned	
2. Fans operating correctly	
3. Voltages checked	
KERNEL	
1. System cables inspected	
2. CPU card cage filter cleaned	
FRONT END	
1. Door filters replaced	
2. RL02 prefilter replaced	
SYSTEM	
1. Revisions verified per RM	
2. System power checked	
DEVICES	
1. All system PMs performed	
TESTING	
1. EDKAX runs error free	
ANNUAL	
FRONT END	
1. RL02 absolute filter replaced	
TESTING	
1. High margins performed	
2. Low margins performed	
3. TSTCPU runs at normal margin	
4. MACRO diags run error free	

CHAPTER 8

SYSTEM CLOCKS

8.1 CLOCK INTRODUCTION

Two types of clock modules are used in the VAX 8600/8650 processors, the L0217 and L0231. There are two versions of the L0217 module, revision C5, which will be phased out over time, and revision E. The VAX 8600 can use either revision of the L0217, or the L0231, but with the L0231, use is restricted to the lower frequencies. The VAX 8650 can only use the L0231.

The main difference between the two L0217 versions is the source of the clock signal. The revision C5 clock is provided by a 50 MHz oscillator, a phase lock loop, or an external clock. The phase lock loop provides clocking rates between 40 and 64 MHz. The revision E L0217 has no phase locked loop, but has four oscillators and an external clock.

The L0231 module is similar to the L0217 rev. E, but has six oscillators instead of four, and the delays are different, being adjusted to the faster clocking rate of the VAX 8650. The L0231 also has an external clock input.

8.2 CLOCK CONSOLE COMMANDS

The clock is controlled by the following console commands:

- SET CLOCK
- SET SOMM
- SHOW CLOCK
- START/STOP CPU
- START/STOP SYSTEM

These commands are part of the General Command Set, and may be found in Chapter 10, Console Software and Commands.

The SET SOMM command works in conjunction with the DEPOSIT/MARK console command to allow stopping on a micro-mark. See the HEX command set (Chapter 10) for DEPOSIT/MARK.

8.3 CLOCK OUTPUTS

Table 8-1 lists the WBus enable signals and Table 8-2 lists the clock reset signals. For the remainder of the clock outputs, see VAX 8600/8650 System Clocks Technical Description, EK-KA86K-TD, Appendix A.

Table 8-1 WBus Enable Signals

Signal Name	Source			Destination		
	Module	Slot	Pin	Module	B/P	Slot Pin
CLK FBA WBUS ENABLE L	CLK	11	B38	FBA	02	08 B92
CLK EBE WBUS ENABLE L	CLK	11	B36	EBE	02	09 B45
CLK EDP WBUS ENABLE L	CLK	11	B37	EDP	02	10 C10
CLK ICP WBUS ENABLE L	CLK	11	B34	IDP	02	14 A91

Table 8-2 Clock Reset Signals


Signal Name	Source			Destination		
	Module	Slot	Pin	Module	B/P	Slot Pin
CLK RESET 141 A	CLK	11	A85	MCD	02	16 B50
CLK RESET 141 A L	CLK	11	A85	MAP	02	17 B50
CLK RESET 141 A L	CLK	11	A85	MCC	02	18 B50
CLK RESET 141 B L	CLK	11	A86	ICB	02	12 B50
CLK RESET 141 B L	CLK	11	A86	ICA	02	13 B50
CLK RESET 141 B L	CLK	11	A86	IDP	02	14 B50
CLK RESET 141 B L	CLK	11	A86	IBD	02	15 B50
CLK RESET 141 C L	CLK	11	A87	EBD	02	06 B50
CLK RESET 141 C L	CLK	11	A87	EBE	02	09 B50
CLK RESET 141 C L	CLK	11	A87	EDP	02	10 B50
CLK RESET 141 D L	CLK	11	A88	CSA	02	03 B50
CLK RESET 141 D L	CLK	11	A88	CSB	02	04 B50
CLK RESET 141 D L	CLK	11	A88	EBC	02	05 B50
CLK RESET 141 E L	CLK	11	A89	FBM	02	07 B50
CLK RESET 141 E L	CLK	11	A89	FBA	02	08 B50
CLK SBA0 RESET 141 L	CLK	11	A91	SBA	03	03 C50
CLK SBA1 RESET 141 L	CLK	11	A93	SBA	03	05 C50
CLK SBA2 RESET 141 L	CLK	11	B14	-	-	-
CLK SBA3 RESET 141 L	CLK	11	B15	-	-	-

8.4 CLOCK BLOCK DIAGRAMS

Block diagrams are included for the clock distribution systems, the L0217 Rev. C5 module, the L0231/L0217 Rev. E modules, backplane clock distribution, and clock control logic, the CLC MCA.


NOTE

The CLC MCA is the same for all of the modules.



MR-1530S

Figure 8-1 Clock Distribution System, L0217 Rev. C5



MR-15330

Figure 8-2 Clock Distribution System, L0231/L0217 Rev. E




Figure 8-3 L0217 Rev. C5 Block Diagram (Sheet 1 of 2)




Figure 8-3 L0217 Rev. C5 Block Diagram (Sheet 2 of 2)




Figure 8-4 L0231/L0217 Rev. E Block Diagram (Sheet 1 of 2)




Figure 8-4 L0231/L0217 Rev. E Block Diagram (Sheet 2 of 2)





Figure 8-5 Backplane Clock Distribution (Sheet 1 of 2)



MM-133318

Figure 8-5 Backplane Clock Distribution (Sheet 2 of 2)




Figure 8-6 Clock Control Logic, CLC MCA

CHAPTER 9 CONSOLE HARDWARE




Figure 9-1 Console Interconnect Block Diagram

9.1 SYSTEM CONTROL PANEL

The system control panel, (SCP), is located on the top right hand side of the CPU cabinet. See Figure 9-2. It consists of two switches and four status indicators (LEDs). The SCP communicates only with the console by means of the Serial Diagnostic Bus (SDB). The console can read the state of the switches and read and write the LED register, which is the input to the indicators. The setting of the two switches combined with the current console mode determines the response of the console program to various external inputs.

The right switch, the terminal control switch, is used to apply, or remove, DC power to the CPU and for setting the mode of operation for the local and remote terminals. The left switch, the restart control switch, is used for bootstrapping the system and controlling automatic restarts.

The status indicators show the CPU run state, the status of the remote diagnostic link, and the occurrence of an environmental (or other) fault that is detected by the Environmental Monitor Module (EMM).


9.1.1 Console Operating Modes

The console operates in one of two modes:

1. Console I/O mode (CIO): Operator command input is accepted.
2. Program I/O mode (PIO): VMS running, the console acts as a slave to the VAX processor and services its requests.

9.1.2 SCP Switches and Indicators

The control panel switches and indicators are shown in Figure 9-2. The control panel indicators are described in Table 9-1 and the switches are described in Table 9-2.



MR-13562

Figure 9-2 System Control Panel Switches and LEDs

Table 9-1 System Control Panel Indicators

Control Panel Indicators	State	Description
VAX State	OFF	CPU is not running, or the console program is not in PIO mode.
	BLINKING	CPU is executing a macro program.
Remote Enable	ON	Terminal Control Switch is in the Remote or Remote Disable position. Console program is in PIO mode.
Remote Active	ON	Remote terminal is connected and the line is active.
Alert	ON	EMM has detected a fault condition, an error message has been printed on the console terminal indicating a "yellow-zone" temperature condition. LED is turned off when violation has been eliminated, as detected by the EMM.
	BLINKING	Flashed in 1 second intervals to indicate "red-zone" condition, and message is printed on the console terminal. Total system power shutdown occurs in 1 minute if condition is not eliminated. Conditions that border between yellow and normal may cause LED to appear as flashing.
	BLINKING	Flashes when an air flow fault is pending. Automatic shutdown is armed to trip in 3 minutes for a single air flow violation. Shortened for a double air flow fault (2 sensors).

NOTE

These indicator descriptions are valid only when console software is up and running. When PROM code is running, the indicators may have different meanings, see SCP troubleshooting, Chapter 4.

Table 9-2 summarizes actions taken by the console for all combinations of the Restart Control Switch (RCS) and the Terminal Control Switch (TCS) on the System Control Panel (SCP).

Table 9-2 System Control Panel Switch Summary

Restart Control Switch	Terminal Control Switch	Action		
		After Keep Alive Fail and Initialization	Remote Port Enabled?	^P HALT Enabled?
Any	Local Disable	Restart Boot	No	No
Boot	Local	Boot	No	Yes
Restart Boot	Local	Restart Boot	No	Yes
Restart Halt	Local	Restart Halt	No	Yes
Halt	Local	Halt	No	Yes
Boot	Remote Disable	Boot	Yes *	No
Restart Boot	Remote Disable	Restart Boot	Yes *	No
Restart Halt	Remote Disable	Restart Halt	Yes *	No
Halt	Remote Disable	Halt	Yes *	No
Boot	Remote	Boot	Yes	Yes
Restart Boot	Remote	Restart Boot	Yes	Yes
Restart Halt	Remote	Restart Halt	Yes	Yes
Halt	Remote	Halt	Yes	Yes

* Remote access allowed in PIO mode only.

9.2 CONSOLE (T11) INTERRUPT AND VECTOR INFORMATION

Table 9-3 lists the console interrupt vectors and their relative priority.

Table 9-3 T11 Interrupt Vectors

Vector	PR	ID	Device
00			Reserved trap 0
04			Reserved trap 4
10			Reserved Instruction trap
14			Breakpoint vector
20			IOT trap
24	8	00	Prom Restart (unmaskable) - EXT SW input (power fail)
30			EMT Instruction trap
34			Trap Instruction trap
60	4	01	Remote PCI Transmit/Receive/Modem
64	4	02	Local PCI Transmit/Receive
70	4	03	QBus Reply Timeout
100	6	04	Unused
104	6	05	TOY 1 Ms Interrupt
110	6	06	CPU Control Store Parity Error
114	6	07	STOR Ready
120	5	10	TXCS Ready
124	5	11	RXCS Done
130	5	12	QBus Adapter
134	5	13	EMM PCI Transmit/Receive
140	7	14	Console RAM Parity Error
144	7	15	Unused
150	7	16	System AC Low
154	7	17	ABus Dead

NOTE

1. VECTOR format:

VECTOR location The new PC of the Interrupt Service Routine is stored here.

VECTOR + 2 The new PSW is stored here. Currently, this includes the Processor priority which is set to PR7 (highest) and the ID of the vector is ORed into the least significant 4 bits.

2. Self-Test numbers 34 & 35 will set up the interrupt vectors, enable interrupts then check that no spurious interrupts occur. The object is to verify the integrity of the interrupt system prior to booting RT11.

3. When a spurious interrupt does occur, the following message will be printed on the console terminal (and control will be placed back to PROM prompt):

```
?PROM ENTRY THRU INTERRUPT VECTOR nnnnnn
?REGS ..R0....R1....R2....R3....R4....R5...
R6....PSW....PC..
ROM>
```

4. CL15 TSTRT interrupt can be generated by the CPU and causes the T11 to jump directly to PROM address 172004. This restart will reinitialize the console logic and reboot the console software without affecting the CPU (basically the VMS reboot console request). Note that this is interrupt vector 24.
5. CL02 MAN RESTART interrupt (which also vectors to 24) is from an external input on the CPU backplane (slot 2, pin C69...grounded to assert). This interrupt, as with the TSTRT cannot be masked. The interrupt forces the T11 to PROM address 172010 which simply prints the T11 status and returns to the PROM null loop (prompt: "ROM>"). The console message will read as follows:

```
?PROM ENTRY THRU INTERRUPT VECTOR 000024
?REGS ..R0....R1....R2....R3....R4....R5...
...PSW....PC..
ROM>
```

6. The interrupt system is controlled by "CL09 ENA T11 INTR H" which must be asserted before ANY of these interrupts can be seen by the T11. The signal is controlled as follows: Interrupts are enabled by setting bit <0> in MCSR0, 176040. Interrupts are disabled by clearing bit <0> in MCSR0, 176040.

9.3 CBUS

The console and EBox communicate over the CBus, a backplane interconnect between the two devices. See Figure 9-3. The 16 CBus backplane connections are listed in Table 9-5, and the signals are described in Table 9-4.

Table 9-4 CBus Signal Description

Signal Name	Description
CBUS A<5:0>H	The Console Bus interface consists of a dual port RAM which has thirty-two RAM plus Four external eight bit register locations. The CBUS signal lines enables the CPU to access the entire CSL CBUS interface register space.

Table 9-4 CBUS Signal Description (Cont.)

Signal Name	Description
CBUS D<7:0>H	A CPU CBUS access involves the transfer of eight bits of data. The CBUS data path is an ECL bi-directional interconnect and it is controlled by the CPU EBox.
CBUS WRITE H	When this CPU controlled signal line is set and used with the generation of a CBUS CLOCK a CBUS write access is executed. The CPU clearing of this signal, and the use of the CBUS Clock initiates a CBUS read access.
CBUS CLOCK L	This signal line is sourced by the CPU and is used in conjunction with the CBUS WRITE signal to enable the timed sequencing of either a read or write access.




Figure 9-3 CBUS Block Diagram

Table 9-5 CBUS Signal Backplane Pin Location

Signal Name	CSL L0201 Slot 2	EBE L0219 Slot 9
CBUS D0 H	C68	C66
CBUS D1 H	C66	C65
CBUS D2 H	C70	C68
CBUS D3 H	C71	C71
CBUS D4 H	C67	C67
CBUS D5 H	C73	C75
CBUS D6 H	C54	C55
CBUS D7 H	C64	C62
EBE CBUS A0 H	C78	C80
EBE CBUS A1 H	C74	A25
EBE CBUS A2 H	C46	C44
EBE CBUS A3 H	C76	C76
EBE CBUS A4 H	C45	C47
EBE CBUS A5 H	C44	A74
EBE CBUS WRITE H	C53	C53
EBE CBUS CLOCK L	C58	C56

9.4 QBUS

The console interface to the RL02 is through the QBus adapter and over the QBus to the RLV12. Figure 9-4 is a block diagram of the QBus interconnect between the console and RLV12 Disk controller. Table 9-6 lists the QBus backplane pin connections, and Table 9-7 is a description of the QBus signals. For more information, see KA86 Console Technical Description, EK-KA86C-TD.




Figure 9-4 QBus Interconnect Block Diagram

Table 9-6 QBus Signal Backplane Pin Locations

Signal Name	CPU Backplane		Ball Front End	
	CSL Slot 2	Cable	M9403 Cable	Backplane Slot 26
BSPARE			J1 B	AA1
BDAL 0 L	A32	J7 04	J1 D	AU2
BDAL 1 L	A38	J7 06	J1 F	AV2
BDAL 2 L	A30	J7 0	J1 J	BE2
BDAL 3 L	A39	J7 10	J1 L	BF2
BDAL 4 L	A34	J7 12	J1 N	BH2
BDAL 5 L	A46	J7 14	J1 R	BJ2
BDAL 6 L	A41	J7 16	J1 T	BK2
BDAL 7 L	A36	J7 18	J1 V	BL2
BDAL 8 L	A05	J7 20	J1 X	BM2
BDAL 9 L	A20	J7 22	J1 AA	BN2
BDAL 10 L	A06	J7 24	J1 CC	BP2
BDAL 11 L	A12	J7 26	J1 EE	BR2
BDAL 12 L	A08	J7 28	J1 HH	BS2
BDAL 13 L	A18	J7 30	J1 KK	BT2
BDAL 14 L	A10	J7 32	J1 MM	BU2
BDAL 15 L	A14	J7 34	J1 PP	BV2
BWTBT L			J1 SS	AK2
BBS7 L	A94	J7 38	J1 UU	AP2
BDOUT L	A86	J8 04	J2 D	AE2
BRPLY L	A89	J8 06	J2 F	AF2
BDIN L	A88	J8 08	J2 J	AH2
BSYNC L	A87	J8 10	J2 L	AJ2
BIRQ L	A62	J8 12	J2 N	AL2
BIAKL L	A74	J8 14	J2 R	AN2,AV2
BDMR L	A64	J8 16	J2 T	AN1
BDMG L	A70	J8 18	J2 V	AS2,AR2
BNIT L	A78	J8 20	J2 X	AT2
BHALT L			J2 AA	AP1
BSPARE 3 L			J2 CC	AC1
BREF L			J2 EE	AR1
BSPARE 4 L			J2 HH	AD1
BDCOK L	A76	J8 30	J2 KK	BA1
BPOK L	A93	J8 32	J2 MM	BB1
BSPARE 6 L			J2 PP	BP1
BSACK L	A68	J8 36	J2 SS	BN1
BEVNT L			J2 UU	BR1

NOTE

In order to avoid confusion between QBus and console signals that have the same name but different meanings, all QBus signals are prefixed with a "B", e.g., "BSYNC" is a QBus signal and "SYNC" is a console (QBA) signal.

Table 9-7 QBus Signal Descriptions


BDAL<15:0> L	Sixteen multiplexed data/address lines.
BBS7 L	Bank 7 (I/O page) select. Asserted by console (bus master) during a DATO or DATI when address is a controller (I/O) address. (Needed for some applications in other systems when both I/O and memory devices are connected to the bus.)

Table 9-7 QBus Signal Descriptions (Cont.)

BWTBT L	Write/byte. Asserted by bus master during address portion of DATO to indicate write data is to follow.
BSYNC L	Synchronize. Asserted by bus master during DATO or DATI to indicate it has placed address on bus. The data transfer is in progress until SYNC is negated.
BDOUT L	Data out. Asserted by bus master during a DATO to indicate it has placed data on bus.
BDIN L	Data in. Asserted by bus master during a DATI to indicate slave may place data on bus. Also asserted by console during interrupt acknowledge to indicate controller (the interrupting device) may place interrupt vector on bus.
BRPLY L	Reply. Asserted by slave during a DATO to indicate it has taken data on bus, and during a DATI to indicate it has placed data on bus. Also asserted by controller during interrupt acknowledge (by console) to indicate it has placed interrupt vector on bus.
BDMR L	Direct Memory Access (DMA) request. Asserted by controller to request bus mastership for DMA transfers.
BDMG L	Direct Memory Access (DMA) grant. Asserted by console (bus arbitrator) to grant bus mastership to controller for DMA transfers.
BSACK L	Selection acknowledged. Asserted by controller to indicate it has assumed bus mastership following a DMA request.
BIRQ L	Interrupt request. Asserted by controller to interrupt the console.
BIACK L	Interrupt acknowledge. Asserted by the console to tell controller to place interrupt vector on bus.
BDCOK H	DC power OK. Indicates there is sufficient dc voltage to maintain reliable operation. Negated by console or controller when cabinet power supply detects DC LOW condition.
BDPOK H	AC power OK. Indicates normal ac power. Negated by console or controller when cabinet power supply detects AC LOW condition.
BINIT L	Initialize. Asserted by console to reset controller to initial state.

9.5 SDB

The console uses the SDB to load and verify system microcode, and to read the state of backplane signals for diagnostics and error handling. Figure 9-5 is a block diagram of the SDB interface, Table 9-8 lists the SDB interface to the SCP, Table 9-9 lists the SDB control signal interface, and Table 9-10 lists the SDB clock and data out interface. Figure 9-5 refers to signal charts A (Table 9-8), B (Table 9-9), and C (Table 9-10).



- NOTES:
1. X = A, B, OR C – REFER TO SIGNAL CHARTS FOR VARIATION.
nnn = MODULE MNEMONIC. REFER TO CHARTS FOR VARIATION.
 2. ○ = LETTER DESIGNATES SIGNAL CHART.
 3. L0217 (VAX 8600)
L0231 (VAX 8650)
 4. L022Q (VAX 8600)
L0230 (VAX 8650)

MR-16597

Figure 9-5 SDB Interface

Table 9-8 SDB Interconnect Chart A - SCP Interface

Signal Name	CSL	CPU B/P	SCP
CL SCP CLK H	B02-69	J11-04	J12-04
CL SCP CNTRL S1 H	B02-58	J11-08	J12-08
CL SCP CNTRL S2 H	B02-66	J11-10	J12-10
CL SCP DATA IN H	B02-64	J11-02	J12-02
CL SCP VIS SHIFT	B02-67	J11-14	J12-14
CL SCP DATA OUT H	B02-68	J11-06	J12-06

Table 9-9 SDB Interconnect Chart B - SDB Control Signals

Module	CL SDB CNTRL S1 X H		CL SDB CNTRL S2 X H		CL SDB DATA IN X H		CL SDB VIS SHIFT X H	
	X	CSL	X	CSL	X	CSL	X	CSL
L0204 MCD					A	C02-52	A	C02-59
L0205 MAP					B	C02-55	B	C02-63
L0206 IOP					A	C02-52	A	C02-59
L0207 ICA	B	C02-20	A13-44	B	C02-19	A13-04	A	C02-59
L0208 IBD	B	C02-20	A15-44	B	C02-19	A15-04	A	C02-59
L0209 EDP	A	C02-15	C05-15	A	C02-22	C10-90	A	C02-59
L0210 EBC	A	C02-15	C05-15	A	C02-22	C05-22	A	C02-59
L0211 EBD					A	C02-52	A	C02-59
L0212 FBA	B	C02-20	B08-58	B	C02-19	B08-57	B	C02-63
L0213 FBM	B	C02-20	A07-89	B	C02-19	A07-93	B	C02-63
L0214 ICB	B	C02-20	A12-44	B	C02-19	A12-04	B	C02-63
L0215 CSA					A	C02-52	A	C02-59
L0216 CSB	A	C02-15	C04-15	A	C02-22	C04-22	A	C02-59
L0217/								
L0231 CLK	A	C02-15	B11-07	A	C02-22	B11-06	A	C02-59
L0219 EBE					A	C02-22	B	C02-63
L0220/								
L0230 MCC	A	C02-15	B18-09	A	C02-22	C18-21	A	C02-59
L0232 MTM	B	C02-20	J06-23	B	C02-22	J06-25	B	C02-63
L0219 EBE	C	C02-17	J14-08	C	C02-21	J14-10	C	C02-65

NOTE

- To determine the correct signal name, replace the "X" with the letter under the "X" column. For example, on the L0207, ICA, Module, the signal "CL SDB CNTRL S1 X H" becomes "CL SDB CNTRL S1 B H".
- The connections in the ABUS backplane to the MTM module are as follows:
 CL SDB CNTRL S1 B H J06-24 A09-09
 CL SDB DATA IN B H J06-26 A09-25
 CL SDB VIS SHIFT B H J06-32 A09-10
- These connections are reserved for the SBIA visibility modules, which are for manufacturing use only.

Table 9-10 SDB Interconnect Chart C - SDB Clock and Data Out Connections

Module	CL SDB CLK CSL	nnn H Module	nnn SDB CSL	DATA OUT Module	nnn H
L0204 MCD	B02-77	B16-77	B02-57	B16-57	
L0205 MAP	C02-06	B17-77	C02-31	C17-45	
L0206 IDP	B02-75	A14-04	B02-55	A14-55	
L0207 ICA	B02-74	C13-25	B02-52	B13-25	
L0208 IBP	B02-76	A15-50	B02-54	A15-57	
L0209 EDP	C02-06	B17-77	C02-57	A10-03	
L0210 EBC	C02-05	C05-05	C02-38	C05-38	
L0211 EBD	C02-07	C06-07	C02-36	C06-36	
L0212 FBA	B02-80	B08-60	B02-63	A08-30	
L0213 FDM	B02-78	A07-91	B02-56	B07-42	
L0214 ICB	B02-73	B12-28	B02-53	C12-86	
L0215 CSA	C02-18	C03-17	C02-40	C03-40	
L0216 CSB	C02-11	C04-11	C02-35	C04-35	
L0217/					
L0231 CLK	B02-65	C11-84	B02-49	C11-87	
L0219 EBE	C02-08	C09-10	C02-62	B09-20	
L0220/					
L0230 MCC	C02-10	B18-81	C02-34	C18-34	
L0222 MTM	C02-29	J06-21	C02-50	J06-27	Note 2
IOA0	C02-26	J14-12	C02-37	J14-42	Note 3
IOA1	C02-28	J14-14	C02-42	J14-06	Note 3
IOA2	C02-30	J14-16	C02-39	J14-02	Note 3
IOA3	C02-32	J14-18	C02-41	J14-04	Note 3
21	C02-27		C02-47		Note 4
22	C02-25		C02-29		Note 4
23	C02-24		C02-60		Note 4

NOTES

1. To determine the correct signal name, replace the "nnn" with the appropriate module mnemonic. For example, on the L0204 MCD module, the signal "CL SDB CLOCK nnn H" becomes "CL SDB CLOCK MCD H".
2. The connections in the ABUS backplane to the MTM module are as follows:

CL SDB CLOCK MTM H	J06-22	A09-59
MTM SDB DATA OUT MTM	J06-28	A09-73
3. These connections are reserved for the SBIA visibility modules, which are for manufacturing use only.
4. These connections are spare connections reserved for future use.

9.5.1 SDB Signal Name File Information

To support the SDB channels, Signal Name Files or CADIF files (Computer Aided Design Information Files) are required to translate a given logical SDB signal name or symbol to the physical SDB location. The following text outlines some of the components used in the visibility logic.

9.5.2 CADIF File Description

The following text is taken from a sample CADIF file: CSBB02.CDF

```
;CHASER Version 1(31)-1, 21 January 1984. Sources in LSCAD:<SDB>
/CADIF-VERSION/ 3(5)
/SUDS-SDB/ 1(2)
$SUDS-CHANNEL-TO-SIGNAL
16000                V$E124      EDP BMUX 15 H
16001                V$E125      EBC DIAG BR COND 1 H
16002                V$E126      EBC TRAP EB WRT H
:                    :           :
:                    :           :
16345                V$E153      FBA CARRY TO EBOX H
16346                V$E154      EDP UCC 2 H
16347                V$E155      BRANCH CONDITION 23 B H
```

\$SUDS-SIGNAL-TO-CHANNEL

```
16141                V$E101
16200                V$E101
16201                V$E101
16115                V$E101
16117                V$E101
16105                V$E101
16107                V$E101
16150                V$E140      -CSBR FLIP USTK PAR H
16204                V$E166      -CSBT CLK6 PHASE T0A H
:
:
16102                V$E186      MCC TRAP OP WCHK H
16043                V$E135      MCC TRAP OP WRT H
```

NOTE

1. There is one CADIF file for each module that has a visibility channel and the file contains a list of all signals that are visible (and thus terminated) on that module. The CADIF file does not list all the signals generated from the module, rather it lists all the signals that terminate on the module.
2. The CADIF file is divided into two equal sections, a CHANNEL-TO-SIGNAL section and a SIGNAL-TO-CHANNEL section. Each section contains a complete list of all the visible signals; the first section sorted by the SDB ID, and the second section sorted by the signal name.

3. The following is a description of the three fields of an entry in the CADIF file:

```

                16345   V$E153   FBA CARRY TO EBOX H
                |       |       |
SDB ID-----+
SDB Symbol-----+
SDB Signal Name -----+

```

9.5.3 SDB ID

This is the physical 'address' of a given signal name. The information contained within this 14-bit octal value includes the SDB channel number, bit select, VTERM MUX select and VTERM MUX enable (see SDB ID Format). Every visibility point within the system has a unique SDB ID code. The SDB ID code may change from one revision module to another. The console software uses the information from the SDB ID code to program the actual SDB registers (SDDB, SDMS, and SDCS).

This field contains an OCTAL value. If the entry is 37777, it indicates that there is no physical address for a given symbol/name. This case occurs when a signal is removed from the visibility logic on a new revision of the module.

The SDB ID is not a hardware register. It is simply a 'logical' register used by the console software to identify the physical location of a given visibility point. In general, the SDB ID is broken down into two parts. The first part, the CHANNEL SELECT field, identifies which channel (or module) we want to look at. The second part, consists of the BIT SELECT and MUX SELECT and ENABLE fields, which is used to address one bit of a possible 512. It is this last portion which is implemented differently on different modules. For the current system, the following table indicates the number of visibility points per module. Refer to the appropriate technical description manual for a detailed functional description of how the SDB logic is implemented on the individual modules.

Module(s)	Maximum Number of Visibility Points Implemented
FBA, FBM	288 (12 X 24)
ICA, ICB, IBD, IDP	256 (8 X 32)
All others	192 (8 X 24)

Figure 9-6 shows the bit breakdown of the SDB ID and Table 9-11 defines the SDB ID.

CONSOLE HARDWARE




Figure 9-6 SDB ID Format

Table 9-11 SDB ID Bit Descriptions

SDB Bit	Bit Description	
CHANNEL SELECT <4:0>	Select one of 32 SDB possible channels. Currently used channels are:	
	Channel	Module Mnemonic
	00	L0212 FBA
	01	L0213 FBM
	02	L0204 MCD
	03	L0208 IBD
	04	L0206 IDP
	05	L0207 ICA
	06	L0214 ICB
	07	L0217 CLK
	08	L0209 EDP
	09	L0219 EBE
	0A	L0220 MCC
	0B	L0205 MAP
	0C	L0211 EBD
	0D	L0210 EBC
	0E	L0216 CSB
	0F	L0215 CSA
	10	N/A IOA0
	11	N/A IOA1
	12	N/A IOA2
	13	N/A IOA3
	14	L0222 MTM
	15-1F	RESERVED
BIT SELECT <3:0>	Select one of 16 bits for a given bit position on the visibility channel. The FBA and FBM modules support 12 bits, while all other modules support 8. The SDDB register is 8 bits wide, so the actual number of bits read must be a multiple of 8. When reading data on the FBA and FBM visibility channels, there will be 4 filler bits.	
MUX ENABLE <1:0>	Select which bank of SDB visibility channel multiplexers will be selected.	
MUX SELECT <2:0>	Select 1 of 8 inputs to the SDB visibility channel multiplexers.	

9.5.4 SDB Symbol

The SDB symbol is the logical symbol assigned to a given signal name. The objective is to assign a permanent code to a given signal name which can be coded into the diagnostics (MHC and Micro diagnostics). By using the SDB symbol, rather than the actual signal name, less program space is required. The SDB Symbol for a given signal name will not change.

The format for the SDB symbol is: V\$CNN, where:

V\$ - symbolizes that this is an SDB Symbol

C - represents the SDB visibility channel number thus:

0 = FBA	1 = FBM	2 = MCD
3 = IBD	4 = IDP	5 = ICA
6 = ICB	7 = CLK	8 = EDP
9 = EBE	A = MCC	B = MAP
C = EBD	D = EBC	E = CSB
F = CSA	G = IOA0	H = IOA1
I = IOA2	J = IOA3	K = MTM

NNN - is a unique DECIMAL number identifying a given signal name on the module.

9.5.5 SDB Signal Name

This is the signal name which is used in the circuit schematic drawings. Although the signal polarity may change within the schematics (e.g., from MCC9 MAPPED H to -MCC9 MAPPED L) it follows a common convention in the CADIF files. All SDB signal names contain the 'H' suffix. Thus if the signal is actually a true low signal such as 'MCC9 MAPPED L' it will be listed in the CADIF file as '-MCC9 MAPPED H'.

Thus, if you are tracing through the print set using the 'EXAMINE/SDB SIGNAL NAME' command under HEX and come across a signal such as 'ICB ID FULL STALL L' and you enter the command:

```
>>>>EXAMINE/SDB "ICB ID FULL STALL L"
```

You will get the following error message:

```
?DCN-W-EUSIG, signal name not found in CAD tables
```

You need to convert the signal name to the 'H' polarity thus:

```
>>>>EXAMINE/SDB "-ICB ID FULL STALL H"
V$5196 -ICB ID FULL STALL H = 1
```

DP 865
EDF 860

9.5.6 CADIF File Revisions and the ~~CONFIG~~.DAT file

It is possible that for every revision of a given module, the related CADIF file may change. Hence, the names allocated to the CADIF files were intended to reflect the revision of the module. (For example, CSBB02.CDF is the CADIF file for the CSB module, revision B02). This, however, became the exception rather than the rule and as a result, the naming convention for the CADIF files was not followed.

To determine the correct CADIF file for any revision of a given module within the system, use Table 9-12 for the VAX 8600 and Table 9-13 for the VAX 8650. To ease the task of keeping track of the different CADIF files, the CONFIG.DAT file was implemented. This file contains a list of the .CDF files and is initially loaded by the console software. Thus, for a given system, the CONFIG.DAT file must be at a specific revision. This is taken care of via console RL02 pack revisions. For example, if your system (KA86) is at Rev. H3, then you must use a Rev. 5.0 RL02 pack (which will have the appropriate CADIF and CONFIG.DAT files).

Note that if the correct RL02 pack revision is used on a given revision KA86 system, it should not be necessary to investigate and/or alter these files as the console software and CONFIG.DAT file should handle the configuration.

The CONFIG.DAT file may contain a comment field for each of the CADIF files which indicates a module revision. Beware that this field is information only and may not accurately reflect the revision(s) of the module(s) supported by the CADIF file.

Table 9-12 VAX 8600 CADIF File Revision Information

Module	CADIF File	Module Revisions Supported
L0217	CLKC03.CDF	Revision C5 and earlier
L0217	CLKE01.CDF	Revision E1 and later
L0215	CSAB02.CDF	ALL
L0216	CSBB02.CDF	ALL
L0210	EBCC05.CDF	ALL
L0211	EBDD02.CDF	ALL
L0219	EBEB02.CDF	ALL
L0209	EDPC02.CDF	ALL
L0212	FBAB01.CDF	ALL
L0213	FBMC01.CDF	ALL
L0208	IBDF05.CDF	ALL
L0207	ICAH02.CDF	ALL
L0214	ICBF01.CDF	ALL
L0206	IDPF02.CDF	ALL
L0205	MAPD02.CDF	ALL
L0220	MCCJ04.CDF	Revision J04 and earlier
L0220	MCCK01.CDF	Revision K01 and later
L0204	MCDD04.CDF	ALL
L0222	MTMB01.CDF	ALL
L0NNN	VBAA01.CDF	(SBIA VISIBILITY MODULE 1) Mfg only
L0NNN	VBBA01.CDF	(SBIA VISIBILITY MODULE 2) Mfg only

NOTE

This table reflects a VAX 8600 with Rev. 5.0 RL02 or hardware revision KA86 Rev. H3.

Table 9-13 VAX 8650 CADIF File Revision Information

Module	CADIF File	Module Revisions Supported
L0231	CLKE01.CDF	ALL
L0215	CSAB02.CDF	ALL
L0216	CSBB02.CDF	ALL
L0210	EBCC05.CDF	ALL
L0211	EBDD02.CDF	ALL
L0219	EBEB02.CDF	ALL
L0209	EDPC02.CDF	ALL
L0212	FBAB01.CDF	ALL
L0213	FBMC01.CDF	ALL
L0208	IBDF05.CDF	ALL
L0207	ICAH02.CDF	ALL
L0214	ICBF01.CDF	ALL
L0206	IDPF02.CDF	ALL
L0205	MAPD02.CDF	ALL
L0230	MCCK01.CDF	ALL
L0204	MCDD04.CDF	ALL
L0222	MTMB01.CDF	ALL
L0NNN	VBAA01.CDF	(SBIA VISIBILITY MODULE 1) Mfg only
L0NNN	VBBA01.CDF	(SBIA VISIBILITY MODULE 2) Mfg only

NOTE

This table reflects a VAX 8650 with Rev. 1.2 RL02 or hardware revision KA86 Rev. B.

9.6 REMOTE DIAGNOSIS

9.6.1 General

This section describes the use of remote diagnosis (RD) to troubleshoot the CPU. Use remote diagnosis to help solve problems with the system that you cannot isolate at your particular site.

RD involves connecting the system to the Digital Diagnostic Center (DDC), by telephone line.

The DDC can find system failures to the device level and identify faulty operational problems over the telephone. This service allows you to run tests on the system, without having an engineer at the site.

To use RD, you must have a direct dial phone line in the computer room. This phone line must be connected to an AT&T 103 (or equivalent) full duplex modem.


9.6.2 Setting-up the DF112 Modem

Remote Diagnosis involves setting up the DF112 modem, connecting the modem to the system and the telephone line, self-testing the modem, and using the console software to make the necessary connections to the DDC. The DDC takes over from there, running the appropriate diagnostic routines to isolate the problem.

For systems shipped to sites within the U.S. and Canada, a DF112 modem will be included with the system.

The chapter references in the following steps refer to the DF112 User's Guide (EK-DF112-UG). This guide comes with the DF112 modem. Install the modem as follows:

1. Unpack and inspect the DF112 modem (Chapter 2).
2. Set the switchpacks S1 - S4 (Refer to Figure 9-7) for the required modem options.
3. If you are using a standalone modem, install the standalone modem module in the DF112 modem (Chapter 2).
4. Connect the standalone modem to the appropriate public telephone network service (Chapter 2).
5. Connect one end of the data terminal equipment (DTE) cable (BC22E-xx) into the DTE connector on the rear of the DF112 modem as shown in Figure 9-9. Connect the other end of the cable to the connector marked REMOTE on the KA86 line distribution panel (refer to Figure 9-8).
6. Set the DF112 front panel pushbuttons to the correct positions.
7. Ensure that the VAX 8600/8650 system is in CIO mode (i.e., at the ">>>>" prompt) and the terminal control switch, on the SCP, is in the REMOTE ENABLE position.
8. Verify that all indicator lights on the DF112, except for "TR", are off.
9. Test modem operation by making a connection using an alternate originating modem and terminal.
10. Call the RDC and request an "RD install" verify call.



- NOTES:
1. STANDARD FACTORY SELECTIONS SHOWN
 2. REFER TO DF112 MODEM FAMILY USER GUIDE (EK-DF112-UG) FOR SWITCH SELECTIONS

Figure 9-7 DF112-AA Switchpack Locations

MR-10141




Figure 9-8 KA86 Line Distribution Panel

MR-14564




Figure 9-9 DF112 Modem

9.6.3 Using the Set Terminal Command

Once you have completed steps 1 through 10 above, you may use the SET TERMINAL command to change the communication parameters for the modem. Use the SET TERMINAL command for the following:

1. Change the baud rate for receive and transmit
2. Enter the DDC password

The SET TERMINAL command sets terminal port characteristics for the CTY or RTY interfaces on the system. See Table 9-14.

Table 9-14 Set Terminal Syntax and Switch Description

SET TERMINAL/switch, where "switch" can be any of the following parameters.

Parameter	Function
/BAUD:nnnn	Sets the transmit and receive baud rate for the CTY port.

Table 9-14 SET TERMINAL Syntax and Switch Description (Cont.)

Parameter	Function
/RECEIVE:nnnn	Sets the receive baud rate for the RTY port.
/TRANSMIT:nnnn	Sets the transmit baud rate for the RTY port.
NOTE	
The possible values for "nnnn" in the above switches are: 50, 75, 110, 134, 150, 300, 600, 1200, 1700, 2000, 2400, 3600, 4800, 7200, 9600, and 19200.	
/[NO]PARITY	Enables or disables the use of a parity bit on characters transmitted from the RTY port.
/EVEN	Selects even parity for RTY port transmissions.
/ODD	Selects odd parity for RTY port transmissions.
/[NO]DSRS	Data Set Rate Select (DSRS) selects low speed or high speed modem operation. This switch generates an output at the RTY port on pin 23.
/[NO]SCOPE	Specifies the type of terminal device used at the RD port so that the device handles rubout characters correctly.
/PASSWORD	Sets the login password for the RTY port. The password, if used, must consist of no more than 6 characters and must contain only alphanumeric characters (0 - 9, a - z, A - Z). If no password is used, the RTY port password feature is disabled. With no password, the setting of the front panel Terminal Control Switch controls RTY access to the CPU.

NOTE

All terminal characteristics set by the SET TERMINAL command are saved in console memory and lost when the console reboots or fails. Therefore, it is important that the SET TERMINAL commands be placed in the CPU initialization file, LOAD.COM

Example 9-1 Set Terminal Command

SET TERMINAL/BAUD:9600<RETURN>	Set the transmit and receive baud rates to 9600 for the CTY port.
SET/TERMINAL/TRANSMIT:4800<RETURN>	To set the transmit and receive baud rates to 4800 for the RTY port.
SET/TERMINAL/RECEIVE:4800<RETURN>	

After completing the above steps and using the SET TERMINAL command to set the communication environment, the DDC can now diagnose the system. See Figure 9-10 for a flowchart on control of the remote port.





Figure 9-10 Console Remote Port Control Flowchart


CHAPTER 10 CONSOLE SOFTWARE AND COMMANDS



MR-15383

NOTE: CONTROL-P DOES NOT SWITCH MODES
IF THE TERMINAL SELECT SWITCH IS
IN ONE OF THE TWO DISABLE POSITIONS.

Figure 10-1 Console Software Modes



MR-13503

Figure 10-2 Console Mode Contexts

10.1 CONSOLE COMMANDS

Chapter 10 will include the console commands not found in Chapter 6, Diagnostics, namely: General commands, MACRO Context commands, and HEX commands. The PROM commands, MHC Context commands, and Micro-Diagnostic Context commands are in Chapter 6.

If more help is needed on any console command, use the help facility as shown in the following example.

Example 10-1: Help on Console Commands

1. If the context and command is known, type: "HELP {context} {command}", for instance, "HELP MACRO DEPOSIT".
2. If you are looking for a command and are not sure what context to use, you can find out what commands are available for each context by typing: "HELP {context}", for instance, "HELP MACRO". The console will print out all of the commands within the MACRO Context.
3. If the names of the contexts escape you, then just type "HELP".

10.1.1 Control Characters

The control characters for the console commands are listed in Table 10-1.

Table 10-1 Console Command Control Characters

DELETE	Rubout last character typed
CONTROL-U	Flush Command Line
CONTROL-R	Retype command line from RTTY
CONTROL-O	Toggle output display ON/OFF
CONTROL-P	Abort current command
CONTROL-S	Abort current command

10.1.2 Console Command Syntax

The console commands use brackets ([]) to indicate an optional switch or keyword and braces { } to show a list of choices where one item must be selected. For example, in the MACRO command: "EXAMINE [/space] [/next:hex_number] [/data_type] {[hex_addr, reg_name]}", the /space switch is optional and will default to /PHYSICAL if not used. The /next switch allows the examination of the next "hex_number" locations if used, and if not used, the default is to examine only the addressed location. The /data_type switch is also optional, and the default is /LONG. Within the braces, we have to pick one of the two, either a hex_addr or a reg_name to provide the location that we want to examine.

10.1.3 Architecturally Defined Commands and Switches

Table 10-2 lists the architecturally defined commands and switches.

Table 10-2 Architecturally Defined Commands and Switches

Short Form	Long Form	Short Form	Long Form
B	BOOT	N	NEXT
C	CONTINUE	S	START
D	DEPOSIT	SE	SET
E	EXAMINE	SH	SHOW
F	FIND	U	UNJAM
H	HALT	V	VERIFY
I	INITIALIZE	W	WAIT
L	LOAD	/P	/PHYSICAL

NOTE

The standard register names are listed under the MACRO Context DEPOSIT command. For GPRs, see Table 10-7, IPRs, see Table 10-8, and IRs, see Table 10-10.

10.2 GENERAL COMMANDS

Commands in the GENERAL COMMAND set are available to all CIO mode contexts (MACRO, DIAG, and MHC). It provides the commands necessary to change context and control the basic console functions.

The control characters ^C and ^P are considered to be a part of the general command set. While in CIO mode, these control characters are treated as equivalent and will abort most command lines and all levels of command files.

Table 10-3 is a complete list of the commands in the general command set with a brief description of each command. For more information, use the "HELP" command.

10.2.1 The General Command Set

Table 10-3 General Commands

DEBUG	Enables the HEX debugger command set to be concatenated to the MACRO and DIAGNOSTIC context command sets. All trace breakpoints are cleared. See HEX command set, Table 10-11.
DIAGNOSE	Switch to CIO mode DIAGNOSTIC context with diagnostic context initialization. See Chapter 6.
HELP	This command provides on-line help on the various console commands.
IF	IF [Cond, Cond] Cmd_string "Cond" is one or more of 8600, 8650, FPA, or NOFPA, and "Cmd_string" is any command valid in the current context.

If the condition(s) is (are) TRUE, then execute the command, otherwise do not execute the command.

INITIALIZE INITIALIZE {/CLOCK, /POWER, /SDB}

This command performs the initialization of three fundamental system components.

1. INIT/CLOCK - Initializes the system clock and clock distribution logic (10141 reset) and sets the clock parameters to those saved with the last SET CLOCK DEFAULT command. For console reboot, the saved parameters are lost and this command will use normal frequency, and full speed. The state of the SOMM enables is cleared by this command.
2. INIT/POWER - This command initializes the EMM and the power system. At command completion, all voltage regulators are on with normal margins, and the EMM is monitoring regulator outputs, air flow, and temperature conditions.
3. INIT/POWER/ELEV:n - An optional form of the INIT/POWER command, it is used to adjust the EMM yellow and red zone temperature limits to account for systems at sites considerably above sea level. "n" is the site elevation in feet.
4. INIT/SDB - This command forces all SDB control channels to the state necessary for normal system operation. The control channels are loaded as follows:
 - a. CSB = 0008; -FLIP USTK PAR H
 - b. EDP = 0060; -FLIP GPRA H, -FLIP GPRB H
 - c. EBC = A000; Set DIAG register to 0
 - d. EBC = C000; Set EIS register to 0
 - e. EBC = E000; Set control to NOP
 - f. FBA = 0000; Normal operation
 - g. FBM = 0000; Normal operation
 - h. IBD = 1000; Normal operation (Optimize)
 - i. ICA = 0000; Normal operation
 - j. MCC = 0000; Normal operation
 - k. VBA = 0801; Normal SBIA operation

LOAD (CS) LOAD {/Switch} [filename [.BPN]]

"Switch" can be any of the following: /ACCESS, /CONTEXT, /CYCLE, /ECS, /FBACS, /FBMCS, /FDRAM, /ICS, /IDRAM, /MCF, or /MCS and "filename" is the name of the .BPN file to load. If no filename is specified, the default system microcode will be loaded.

CONSOLE SOFTWARE AND COMMANDS
The General Command Set

This command loads the specified file (.BPN) from the console load medium to the specified control store or RAM. Not all control stores can be loaded without having been initialized with the INIT/MICRO console command (see MACRO context commands). The INIT/MICRO command used KA86n.REV to load the default system microcode, see Table 10-4.

Table 10-4 Default System Microcode

RAM	VAX 8600	VAX 8650
ACCESS	ACCESS.BPN	ACCESS.BPN
CONTEXT	CTX.BPN	CTX.BPN
CYCLE	CYCLE.BPN	CYCLE.BPN
ECS	KA8600.BPN	KA8650.BPN
FBACS	FADD0.BPN	FADD5.BPN
FBMCS	FMUL.BPN	FMUL.BPN
FDRAM	FADD0.BPN	FADD5.BPN
ICS	IBOX.BPN	IBOX.BPN
IDRAM	KA8600.BPN	KA8650.BPN
MCF	MCF.BPN	MCF.BPN
MCS	UCODE0.BPN	UCODE5.BPN

If the specified control store has already been loaded, and has not been modified, the command will terminate without reloading the control store.

Example 10-2: LOAD/ECS KA8650

LUPC LUPC /Switch hex_address

"Switch" is one of the following: /ECS, /ICS, /MCS, /FBACS, or /FBMCS.

This command will force the specified microsequencer to the address specified by hex_address.

MACRO This command switches to the CIO mode MACRO context. The MACRO context will perform its own initialization then prompt for command input. See Table 10-6 for MACRO context commands.

MHC This command switches to the CIO mode MICROHARDWARE CONTEXT. MHC will perform its own initialization, then prompt for command input. See Chapter 6 for MHC commands.

ODT The Octal Debugging Tool, ODT, is invoked with this command. The ODT prompt is an asterisk, *. The ODT command set is similar to that of the standard DEC ODT products.

PROM PROM [/RT [filename]]

The PROM command will pass control to the console PROM. The user is asked to confirm the request before control is changed. This command is valid from the RTY, and the PROM will continue to service the RTY.

If the /RT switch is provided to allow an entry to the RT monitor, it is for INTERNAL use only and is not recommended nor supported.

CONSOLE SOFTWARE AND COMMANDS
The General Command Set

- REBOOT** This command will reboot the console software.
- The console will follow its normal power-up procedure and attempt to re-enter PIO mode, if the REBOOT command was issued while in the MACRO context, and if the CP was running at the time.
- When issued from the DIAG or MHC contexts, this command will not attempt to re-enter PIO mode.
- REPEAT** REPEAT [Dec_num] command
- "Dec_num" specifies the number of times the command is to be repeated. If not specified, the command will be repeated indefinitely, or until a ^C or ^P is entered.
- Commands requiring user input cannot be repeated. The ^O character may be used to bypass the output, causing the repeat function to run faster.
- RESET** This command performs a CPU logic initialization sequence as follows:
1. The CPU clock is stopped and state-stepped to the T3 state.
 2. The signal "CL09 CPU RESET H" is asserted.
 3. The signal "CL09 HOLD STATE RESET H" is asserted.
 4. The CPU clock is burst at a frequency of 60 MHz for 1024 steps.
 5. The CPU clock is forced to the T3 state.
 6. The signals "CL09 CPU RESET H" and "CL09 HOLD STATE RESET" are deasserted.
- RESTART** This command will force a console program initialization and a restart of the console program, without reloading the console software. A REBOOT command is needed to reload the console software. At the end of the initialization, control is passed to CIO mode MACRO context, followed by the MACRO context initialization.
- SET BASE** SET BASE hex_number
- The base, a 32-bit value, is added to both virtual and physical memory addresses during E/V, D/V, E/P, or D/P commands.
- SET** SET Flag {ON/OFF} {INVALID, /NOVERIFY, NOW}
- "Flag" can be any of the following: ABORT, ABUS, BBU, COLD, EXTI, FBOX, IOSAFE, LOCAL-COPY, MEMENA, SNAP, STXALT, WARM, or QUIET. This command controls the setting of software and hardware flags in the console subsystem.

CONSOLE SOFTWARE AND COMMANDS
The General Command Set

Setting the COLD, WARM, FBOX, and STXALT flags are applicable to the MACRO context only and result in no immediate action by the console program. The ABORT and QUIET flags control the handling of errors and command line echoing during a command file. The EXTI (external interrupt) flag and the ABUS flags directly control hardware signals on the console module. Use the SHOW FLAG command to examine the state of all flags. The /INVALID, /NOVERIFY, and NOW options apply to the SNAP flag only.

During a console reboot, the ABORT flag is forced ON, and the COLD, FBOX, and WARM flags are forced OFF. The remaining flags are restored to their original state or are not affected.

Table 10-5 lists the flags and a brief description of each.

Table 10-5 Console Flags

-
1. **ABORT** - This flag is set ON during console program initialization or whenever the console is rebooted.

The ABORT flag provides a limited control over the error handling within a command file. Command file execution will be aborted upon detection of an error if the ABORT flag is on.

2. **ABUS** - This flag is set OFF during console program initialization and is unaffected by reboots.

The ABUS flag controls the signal "CL09 ABUS ENABLE". If this flag is on, the ABUS is enabled. The transition from OFF to ON causes an ABUS INIT pulse to be generated in the SBIA's. The INIT/PAMM command generates the ABUS INIT sequence and leaves the ABUS enabled.

3. **BBU** - The BBU flag is set ON during console initialization and by the INIT/POWER command, and is unaffected by a console reboot.

When the BBU flag is on, the battery backup unit is enabled to provide power to the system if ac power is lost.

4. **COLD** - The COLD flag is set ON by the console program during a CPU bootstrap. The flag is set to OFF when the bootstrap completes with success.

The COLD flag is used to inhibit repeated attempts at unsuccessful CPU bootstraps.

5. **EXTI** - The EXTI flag controls the enabling of external interrupts, interrupts from the EBox to the console. When ON, the console will receive the interrupts from:

CONSOLE SOFTWARE AND COMMANDS
The General Command Set

- a. EBE CPU ERR (control store parity errors)
- b. ABus DEAD
- c. EMM CPU AC LO

The EXTI flag is set ON by the INIT/CPU command and remains in this state during PIO mode operation. In CIO mode, this flag is turned off if any of the three CBus interrupts occur.

- 6. FBOX - This flag DOES NOT turn the FBox on or off. This flag controls the action of the INIT, INIT/CPU, or INIT/PAMM commands. If the FBox flag is on, these commands will enable the FBox. If the FBox flag is off, these commands will disable the FBox.

This flag is set to OFF during console program initialization.

- 7. IOSAFE - The IOSAFE flag controls a software write protect feature for STX transfers from the CPU. When OFF, the CPU can modify the RL02 pack.

This flag is set to OFF during console program initialization and its state is preserved through console reboots.

- 8. LOCAL-COPY - With this flag on, all RTY activity is logged on the CTY. The flag is set OFF during console program initialization, its state is preserved during a console reboot, and the RTY cannot set this flag off.

- 9. MEMENA - This flag controls the state of "CL09 MEM BUS ENABLE", which, when off, disables write access to the arrays and switches all array modules to their internal refresh state.

This flag is set ON by the console software during CPU initialization and normally remains on until a power failure or system shutdown occurs.

- 10. SNAP - This flag is set to OFF during console program initialization, and its state is preserved during console reboot.

When the SNAP flag is on, the console will perform a CPU snapshot whenever the CPU stops executing macro instructions. SET SNAP ON/NOVERIFY may be used to disable control store and PAMM verification during the snapshot, thereby providing a quicker snapshot procedure.

SET SNAP INVALID is used to invalidate both SNAP1.DAT and SNAP2.DAT snapshot files on the RL02. This command has no affect on the SNAP flag.

CONSOLE SOFTWARE AND COMMANDS
The General Command Set

SET SNAP NOW may be used to force the creation of a snapshot file based upon the current machine state. If both SNAP1 and SNAP2 are valid, this command will rename SNAP2 to SNAP1 and create a new SNAP2.

11. QUIET - When the QUIET flag is ON, all input taken from a command file will not be echoed to the CTY, only output will be displayed. When OFF, all commands in the command file are echoed on the CTY before being executed.

This flag is set ON during console program initialization, and its state is preserved during console reboots.

12. STXALT - This flag is intended to be used by manufacturing and is not for customer use. It is used to direct CPU data to the alternate console disk, Unit #1. When this flag is on, all console disk access will be to RL02 #0, while all CPU traffic will be to Unit #1.

This flag is set to OFF during console program initialization, and its state is preserved during console reboots.

13. WARM - The WARM flag is set ON by the console program when a CPU restart is being attempted. The CPU sets this flag OFF when the restart is successful. The purpose of the WARM flag is to inhibit repeated attempts at unsuccessful CPU restarts.

14. SET CLOCK - For Rev E01 and above clock modules

- a. SET CLOCK Xn Dec_num [{/NORMAL, /HIGH}] - This command assigns the "Dec_num" (clock frequency in MHz, 40 to 65 for a VAX 8600 and 40 to 90 for a VAX 8650) to the specified crystal mnemonic, X1, X2, etc., where the mnemonic can then be used to set the clock frequency. Any of the Xn mnemonics can be assigned as the normal or high clock rate with the /NORMAL or /HIGH switches. These assignments should be done once in CLOCK.COM. The Xn assignment is preserved during console reboots.

Example 10-3: SET CLOCK

```
SET CLOCK X1 40
SET CLOCK X2 50
SET CLOCK X3 68
SET CLOCK X4 72/NORMAL
SET CLOCK X5 74/HIGH
SET CLOCK X6 76
```

- b. SET CLOCK FREQUENCY {NORMAL, HIGH, X1, X2, X3, X4, X5, X6, EXTERNAL} - This command is used to select one of the previously assigned values (X1, X2, etc.) as the system clock frequency, or the nominal and high margin values can be selected with the keywords NORMAL or HIGH.

CONSOLE SOFTWARE AND COMMANDS
The General Command Set

EXTERNAL can be used to specify that the clock be taken from the external input backplane pin. The SET CLOCK Xn "Dec_num" command must have been executed prior to this command.

- c. SET CLOCK {FULL, ONE-FIFTH, DEFAULT} - This command sets the clock rate to full or one-fifth execution speed. Or, it forces the console to save the current base frequency and FULL/ONE-FIFTH information to be used by subsequent INIT/CLOCK commands as the default setting.

15. SET CLOCK - For Rev C05 clock modules

- a. SET CLOCK FREQUENCY {Dec_num, NORMAL, QUIET} - This command selects the source of the CPU clock frequency source, a 50 MHz crystal (NORMAL), or a variable control oscillator (VCO), with frequencies in the range of 40 to 64 MHz (Dec_num). The QUIET argument can be used to silence the warning messages that may occur at some VCO settings.
- b. SET CLOCK {FULL, ONE-FIFTH, DEFAULT} - This command sets the clock rate to full or one-fifth speed, and forces the default clock settings to become the present values used by the INIT/CLOCK command.

SET SOMM

SET SOMM [/Switches] {ON OFF}

SOMM means Stop On MicroMark, and switches can be any combination of the following: /ECS, /ICS, /MCS, or /FIELD. If no switch is specified when turning SOMM on, the default is /ECS. If no switch is specified when turning SOMM off, all SOMM enables are turned off.

This command controls the enabling and disabling of micro-mark breakpoint detection in the CPU clock module. When enabled for one or more control stores the CPU clocks are stopped in the T0 state when a mark breakpoint is encountered. A microcode mark bit has to have been previously set with the DEPOSIT/MARK command. See HEX commands, Table 10-11.

When the micro breakpoint is detected, the current UPC of the EBox, IBox, and MBox is displayed. If the clock rate was FULL, the UPC data will be 2 microcycles past the breakpoint microinstruction. If clock rate is One-fifth, the UPC data will match the breakpoint micro address, and the micro instruction will have already been executed. For this case, it is necessary to SET SOMM OFF to proceed with a TMIC or TSTATE.

All SOMM flags are initialized to the OFF state during console program initialization and by the INIT/CLOCK command.

Example 10-4: SET SOMM/ECS ON

SET TERMINAL SET TERMINAL /Switches

The defaults shown are the ones set during console software initialization.

Switch	Initially Set to
/BAUD:nnnn	As set in STARTF.COM
/RECEIVE:nnnn	1200
/TRANSMIT:nnnn	1200
/PASSWORD [password]	No password defined
/[NO]SCOPE	SCOPE
/[NO]PARITY	NOPARITY
/[NO]DSRS	NODSRS
/ODD	Default if parity is enabled
/EVEN	

The value of "nnnn" can be: 50, 75, 110, 134, 150, 300, 600, 1200, 1800, 2000, 2400, 3600, 4800, 7200, 9600, or 19200.

This command sets the terminal port characteristics for the CTY and RTY interfaces. While in CIO mode the most significant bit of characters received from the CTY or RTY is stripped off, while in PIO mode, full 8-bit character handling is supported.

The default for the RTY is 1200 BPS transmit/receive, 1 stop bit, no parity, no DSRS, SCOPE, and no password.

The /BAUD switch applies to the CTY while all other switches apply to the RTY.

The RTY can enter only the [NO]SCOPE switch. All other switches must be issued from the CTY. The CTY [NO]SCOPE flag can only be done by modifying the STARTF.COM command file and rebooting the console so that RT executes the command file. By default, the CTY is NOSCOPE.

SHOW CLOCK This command displays the current state of the CPU and system clock.

SHOW FILE SHOW filename[.DAT] [{/ASCII, /BINARY}] This command displays the selected file on the console terminal in a binary format (default) or in a straight ASCII format if the /ASCII switch is used. The /BINARY switch can only be issued from the RTY with the remote protocol running. It is meant as a means for transferring binary files to a remote site.

Example 10-5: SHOW SNAP1.DAT/ASCII

SHOW FLAGS This command displays the current state of the console program control flags.

CONSOLE SOFTWARE AND COMMANDS
The General Command Set

SHOW PANEL SHOW PANEL [/TEST]

This command displays the current settings of the SCP switches and indicator LEDs. The /TEST switch causes the command to loop while shifting a floating "1" through the LEDs and reading back each pattern to verify the LED logic. Changes in either SCP switch will be included in the updated display.

SHOW POWER This command displays the current status of the EMM, power system, and of the CPU cabinet environment.

SHOW TERMINAL This command displays the state of the CTY and RTY ports.

SHOW UCODE This command displays the state of all control stores and RAMs as follows:

1. The current (last loaded) .BPN file name.
2. The default .BPN file name for that control store.
3. The UCODE revision of the currently loaded microcode.
4. The RAM status as follows:
 - a. Bit 15 - If it equals a "1", the contents of the control store has been modified since the last load.
 - b. Bit 14 - If it equals a "1", the VERIFY command has detected one or more discrepancies in the control store data.
 - c. Bit <13:00> - These bits indicate the parity error count, the total number of detected parity errors for the control store, whether they were corrected or not. The MCF, CTX, CYC, and ACC RAMs always show "0" in this field.

SHOW VERSION This command shows the revision information for the following items:

1. The console program major revision
2. The revision of the console PROM code
3. The revision of the EMM PROM code
4. The major revision of the system microcode
5. Various address of interest to developers and debuggers
6. System ID register (Hex value and broken down by fields)

START CPU
STOP CPU

These two commands provide ON/OFF control of the CPU clock. If the SYSTEM clock is off, then the START CPU command will start it before starting the CPU clock. The STOP CPU command stops the CPU clock but does not affect the system clock.

CONSOLE SOFTWARE AND COMMANDS
The General Command Set

START SYSTEM These two commands provide ON/OFF control of the
STOP SYSTEM SYSTEM clock. If the CPU clock is on, then STOP
SYSTEM will stop it before stopping the system clock.
The START SYSTEM command starts the system clock
running at the frequency last set by the SET CLOCK
FREQUENCY command.

UNHANG The UNHANG command will reset the CPU without
clearing latched error status or affecting the system
cache. The command performs the UNHANG by:

1. Stopping the CPU clocks
2. Asserting the console signal "CL09 HOLD STATE
RESET"
3. Bursting the CPU clock 1024 ticks
4. Deasserting "CL09 HOLD STATE RESET"
5. Loading the EBox uPC with 100D
6. Starting the CPU clock

VTERM VTERM {Symbol_name, Hex_ID}

Symbol_name is the V\$ symbol assigned to the
visibility signal by the SDB CADIF (.CDF) files, and
Hex_ID is a 16-bit SDB ID. SDB IDs are hardware
visibility addresses and are defined in the .CDF
files.

This command provides a fundamental aid for isolating
faults in VTERM and visibility logic. The command
accepts a V\$ symbol or SDB hex ID and sets up the
visibility control logic to select the specified bit.
The visibility bit is left selected so that static
measurements can be made. Only a console RESTART,
REBOOT, or another VTERM command will reset the state
of the SDB control logic.

WAIT WAIT [Hex_count]

This command will cause the console to stop
processing commands for "Hex_count" number of 20
millisecond intervals. It is used in command files
to introduce delays.

X X Hex_adr Hex_count

Hex_adr is the address of main memory where data is
to be transferred to/from.

Hex_count is a 32-bit integer count of the number of
bytes to be transferred. Bit 31 implies the
direction of the data transfer. If a "1", read
memory.

CONSOLE SOFTWARE AND COMMANDS
The General Command Set

Example 10-6: X command examples

1. X 100 FF writes FF bytes into main memory starting at location 100
2. X 100 800000FF reads FF bytes from main memory at location 100

This command is for automatic communication between the console and other systems. It is used to load (write) and unload (read) the contents of main memory. Refer to DEC STD 032.

@

@ filename[.COM]

The @ (at) command causes command input to be taken from the file indicated by "filename". The commands may or may not be echoed on the CTY depending upon the QUIET flag. Outputs generated from the commands are always displayed.

Command files may be nested up to four levels deep, but at that level, no command can be executed that specifies access to a file on the disk (such as LOAD filename).

10.3 MACRO CONTEXT

MACRO context is the default context after a power-on or console reboot. MACRO context provides console commands to initialize the machine as a VAX processor. It also allows access to PIO mode operation of the console, which allows VAX macrocode to be run while the console acts as an interface for both console terminals and the EMM.

10.3.1 MACRO Context Initialization

Whenever MACRO context is entered MACRO context initialization is performed. If MHC or DIAGNOSTIC context is desired, MACRO context initialization may be aborted by the ^C or ^P characters. If the initialization is in response to a power-on, wait until "Initializing CPU" has been printed on the CTY before aborting the MACRO context initialization.

The RL02 file "LOAD.COM" performs a complete initialization of the CPU for use as a macrocode processor. Below is a brief description of the MACRO context initialization.

1. RESET performs a master reset of the system.
2. INIT/POWER initializes or ensures that the power system is fully operational.
3. INIT/SDB forces all SDB control channels to a known state to allow microcode loading.
4. Using ULOAD.COM, INIT/MICRO loads all control stores with the default system microcode.
5. INIT/SDB command is again executed to force all SDB control channels to a NOP or RUN state.
6. INIT/PAMM will initialize the PAMM.
7. Unconditionally clear cache and perform an UNJAM on the IO adapters found on the system.
8. If this is the first initialization after a power-on and the battery backup unit was not active, or if this is a context switch from DIAG or MHC contexts, then clear main memory (CLEAR MEMORY).
9. Monitor the terminal control and restart control switches to determine whether to do a warm start, cold start, or enter the CIO null loop.

10.3.2 Console Support Microcode (CSM)

Many of the functions of MACRO context depend upon Console Support Microcode (CSM), a microcode package which allows the console program to communicate with the CPU. Part of CSM microcode is contained in the normal EBox microcode. CSM is also divided into microcode overlays which are loaded into EBox control store by the console in response to typed commands. The console and CPU pass data packets over the CBus interface.

10.3.3 MACRO Context Command Set

Table 10-6 lists the MACRO context commands and a brief description of each command.

Table 10-6 MACRO Context Commands

BOOT	<p>BOOT [/switches] [device]</p> <p>"Switches" can be a combination of:</p> <p>/R5:Hex_num specify value to place in R5, default is 0</p> <p>/NOSTART specify that the boot command file not start the operating system</p> <p>"Device" is a one to three character device mnemonic, such as DUO or CS1. This is appended with "BOO.COM" to locate the boot file, as DUOBOO.COM. If "Device" is more than three characters, it is taken as a filename with the default extension .COM. This file is used to boot the operating system. If "device" is not specified, DEFBOO.COM is the default.</p>
CONTINUE	<p>If the CPU is running, but has been interrupted by a ^P, a CONTINUE will cause a transition from CIO mode to PIO mode. If the CPU is not running then the CONTINUE command performs an IBUFF FLUSH and forces instruction execution to begin from the current PC.</p>
CLEAR MEMORY	<p>CLEAR [MEMORY] The first block of contiguous array memory, as determined by the contents of the PAMM, is cleared.</p>
DEPOSIT	<p>DEPOSIT [/space] [/next:Hex_num] [/data_type] {hex_adr, reg_name} Hex_data</p> <p>"Space" can be any one of the following. The default is /PHYSICAL.</p> <p>/ESCRATCH access EBox scratch pad RAM space</p> <p>/GENERAL access VAX processor GPR register space. See Table 10-7</p> <p>/INTERNAL access VAX processor IPR register space. See Table 10-8</p> <p>/PAMM access the PAMM RAMs</p> <p>/PHYSICAL the default, access VAX physical memory space</p> <p>/U access T-11 RAM address space</p> <p>/VIRTUAL access VAX virtual memory space if the memory mapping is enabled, otherwise access physical address space and ignore address bits 30 and 31.</p> <p>"Data_type can be any one of the following if the /space access is for /PHYSICAL, /VIRTUAL, or /U.</p> <p>/BYTE access a single byte of data</p> <p>/LONG the default, access a longword (4 bytes) of data</p> <p>/WORD access a word (2 bytes) of data</p>

CONSOLE SOFTWARE AND COMMANDS
MACRO Context Command Set

"Hex_adr" is the numeric address of the register or address being deposited. Any of the following positional operators can be used to represent a "hex_adr" relative to the last address accessed

The default address is set to 0 by the INIT command.

- * Access last specified address
- + Access the address following the last specified address
- Access the address preceding the last specified address
- @ Use the contents of the last specified address as the address to be accessed

"Reg_name" is a valid register name for GPRs (see Table 10-7), IPRs (see Table 10-8), Internal Registers (IR, see Table 10-9), or miscellaneous registers (see Table 10-10).

"Hex_data" is the hexadecimal data to be deposited into the specified address space.

NOTE

To deposit to T11 space, the address and data must be preceded by a "%O" (percent Octal) to define the address/data as octal instead of hexadecimal, the default.

Table 10-7 Supported GPR Names

Name	Access	G Address	Purpose
R0	E/D	00	Processor Register 0
R1	E/D	01	Processor Register 1
R2	E/D	02	Processor Register 2
R3	E/D	03	Processor Register 3
R4	E/D	04	Processor Register 4
R5	E/D	05	Processor Register 5
R6	E/D	06	Processor Register 6
R7	E/D	07	Processor Register 7
R8	E/D	08	Processor Register 8
R9	E/D	09	Processor Register 9
R10	E/D	0A	Processor Register 10
R11	E/D	0B	Processor Register 11
AP	E/D	0C	Processor Argument Pointer
FP	E/D	0D	Processor Frame Pointer
SP	E/D	0E	Processor Stack Pointer
PC	E/D	0F	Processor PC

Table 10-8 Supported IPR Names

Name	Access	I Address	Purpose
KSP	E/D	00	Kernel Stack Pointer
ESP	E/D	01	Exec Stack Pointer
SSP	E/D	02	Supervisor Stack Pointer
USP	E/D	03	User Stack Pointer
ISP	E/D	04	Interrupt Stack Pointer
POBR	E/D	08	P0 Base Register
POLR	E/D	09	P0 Length Register
PIBR	E/D	0A	P1 Base Register
PILR	E/D	0B	P1 Length Register
SBR	E/D	0C	System Base Register
SLR	E/D	0D	System Limit Register
PCBB	E/D	10	Process Control Block Base
SCBB	E/D	11	System Control Block Base
IPL	E/D	12	Interrupt Priority Level
ASTLVL	E/D	13	AST Level
SIRR	D	14	Software Interrupt Request Register
SISR	E/D	15	Software Interrupt Summary Register
ICCS	E/D	18	Interval Clock Control
NICR	D	19	Next Interval Count Register
ICR	E	1A	Interval Count Register
TODR	E/D	1B	Time of Day Register
RXCS	E/D	20	Receive Transfer Control status
RXDB	E	21	Receive Transfer Data Buffer
TXCS	E/D	22	Transmit Transfer Control Status
TXDB	D	23	Transmit Transfer Data Buffer
ACCS	E/D	28	Accelerator Status Register
MAPEN	E/D	38	Memory Management enable
TBIA	D	39	Translation Buffer Invalid All
TBIS	D	3A	Translation Buffer Invalid Single
PME	E/D	3D	Performance Monitor Enable
PMR	E/D	3D	Performance Monitor Register (same as PME)
SID	E	3E	System ID
PAMACC	E/D	40	Physical Array Map access
PAMLOC	E/D	41	Physical Array Map Location
CSWP	E/D	42	Cache Sweep
MDECC	E/D	43	MBox Data ECC
MENA	E/D	44	MBox Error Enable
MDCTL	E/D	45	MBox Data Control
MCCTL	E/D	46	MBox MCC Ctrl
MERG	E/D	47	MBox Error generation
CRBT	D	48	Console Reboot
DFI	D	49	Diagnostic Fault Insertion Register
EHSR	E/D	4A	Error Handling Status Register
STXCS	E/D	4C	Storage Transfer Exchange Control Status
STXDB	E/D	4D	Storage Transfer Exchange Data Buffer

Table 10-9 Supported IR Names

Name	Access	Purpose
CPC	E	IBox Current PC Register
CSHCTL	E/D	MBox Cache Control Register
CSES	E	Control Store Error Status Register
CSLINT	E/D	Console Interrupt status Register (EBox)
EBCS	E/D	EBox Control Status Register
EDMC	D	EBox Diagnostic Maintenance Control Register
EDPSR	E	EBox Data path status Register
EMD	E	IBox EMD Register
ESASAV	E	IBox ESASAV Register
IBESR	E	IBox error status Register (from EBox)
ISASAV	E	IBox ISASAV Register
IVASAV	E	IBox IVASAV Register
MEDR	E	MBox Error Data Register
MEAR	E	MBox Error address Register
MSTAT1	E	MBox status 1 Register
MSTAT2	E	MBox Status 2 Register
VIBASAV	E	IBox VIBASAV Register
VPCBITS	E	Valid PC Bits

Table 10-10 Supported Miscellaneous Register Names

Name	Access	Purpose
IBGPR	E	IBox GPR
PSL	E/D	Program Status Longword
SPADR	E/D	Scratch Pad Address
STATE	E/D	STATE register
EVMQSAV	E	VMQ save
EXAMINE	EXAMINE [/space] [/next:Hex_num] [/data_type] {[hex_adr, reg_name]} "SPACE" can be any one of the following. The default is /PHYSICAL. /ESCRATCH access EBox scratch pad RAM space. /GENERAL access VAX processor GPR register space. See Table 10-7. /INTERNAL access VAX processor IPR register space. See Table 10-8. /PAMM access the PAMM RAMs. /PHYSICAL the default, access VAX physical memory space. /U access T11 RAM address space. /VIRTUAL access VAX virtual memory space if the memory mapping is enabled, otherwise access physical address space and ignore address bits 30 and 31. /Data_type can be any ONE of the following if the /space access is for /PHYSICAL, /VIRTUAL, or /U. /BYTE access a single byte of data.	

CONSOLE SOFTWARE AND COMMANDS
MACRO Context Command Set

/LONG the default, access a longword (4 bytes)
 of data.

/WORD access a word (2 bytes) of data.

"Hex_adr" is the numeric address of the register or address being examined. Any of the following positional operators can be used to represent a "hex_adr" relative to the last address accessed. The default address is set to 0 by the INIT command.

* Access last specified address

+ Access the address following the last specified address

- Access the address preceding the last specified address

@ Use the contents of the last specified address as the address to be accessed

"Reg_name" is a valid register name for GPRs (See Table 10-7), IPRs (See Table 10-8), Internal Registers (IR, See Table 10-9), or miscellaneous registers (See Table 10-10).

"Hex_data" is the hexadecimal data to be deposited into the specified address space.

NOTE

To examine T11 space, the address and data must be preceded by a "%0" (percent Octal) to define the address/data as octal instead of hexadecimal, the default.

FIND FIND [/RPB, /MEMORY]}

The default is FIND/RPB, and this command searches main memory, starting at location 0, for a page aligned 64K block of good physical memory, or a Restart Parameter Block (RPB). If the item is found its address plus 200 (hex) is loaded into the SP register.

HALT Halt is used to halt the CPU by forcing it to the CSM wait loop.

The Macro PC is displayed and the CSM status code should be 11 (hex). If the CPU is already halted, a message to this effect will be printed, followed by the last recorded Macro PC and CSM status.

INITIALIZE INITIALIZE [/switch]

"/Switch" may be none, or any one of the following: /CPU, /ESCRATCH, /MICRO, or /PAMM. This command is used to initialize various facets of the CPU.

CONSOLE SOFTWARE AND COMMANDS
MACRO Context Command Set

- INIT Without any switch, this command meets the requirements of DEC STD 032. The steps performed include:
- ACCS register (enabled if FBox flag is on)
 - RX, TX, and STX registers are initialized
 - ASTLVL is set to 4
 - SISR, ICCS, MAPEN, and PME are set to 0
 - MCCTL is set to 0 to enable MBox overlaps if the CPU clock is running full speed
 - Turns off the VAX STATE lamp
 - The Ibuff and system cache are not affected
- INIT/CPU If the EBox has been loaded with system microcode, this command performs a full CSM initialization. It combines the CSM initialization with the steps for the INIT/ESC and INIT commands. The command does the following:
- Stop CPU clocks
 - Master reset
 - Loads and runs CSM040 and CSM041 overlays
 - Sets EXTI flags ON
 - Performs INIT/ESCRATCH
 - Performs INIT
- INIT/ESCRATCH This command uses CSM to load the EBox scratch pad registers with the values needed to start the CPU. Data is taken from ECODE.BPN, unless the filename is specified as INIT/ESC "filename.BPN". This file will initialize GPRs R0 - SP.
- INIT/MICRO This command will check KA86n.REV (n = 0 for 8600 and 5 for 8650) the microcode revision information. It will then execute ULOAD.COM to load the system microcode according to the loaded microcode revision.
- INIT/PAMM This command determines the amount of physical memory and the number of IO adapters on the system and configures the PAMM accordingly. After an ABUS INIT the IO adapter configuration registers are loaded with the number of megabytes of physical memory present, and SBI CYCLES IN and SBI CYCLES OUT are set in the SBIA CONTROL STATUS register.

CONSOLE SOFTWARE AND COMMANDS
MACRO Context Command Set

LOAD LOAD [/start:hex_adr] filename[.exe]

This command is used to load main memory with binary data taken from the specified file. If the /start switch is used then the data is loaded starting at the specified "hex_adr", otherwise, the data is loaded starting at location zero.

START START [hex_address]

This command is the same as a "CONTINUE" except that if a "hex_address" is specified, it is used as the current PC at which to start the VAX processor. If the CPU is already running, then this command simply re-enters PIO mode without affecting the running CPU, even if "hex_address" is included.

START/STEP START/STEP [hex_address]

This command prepares the CPU for micro-stepping macro instructions. It loads a CSM overlay, sets the PC if specified, and starts the CSM idle loop. The HEX commands may then be enabled to MIC or TMIC through the macro instructions.

When stepping is completed, the UNHANG command may be used to reset the EBox to the start of the CSM idle loop without affecting the state of the machine.

NEXT NEXT [Hex_count]

This command single steps the VAX processor the specified number of macro instructions, or the default of one if no count is given. At the completion of the full step count, the PC of the next macro instruction is displayed and the command enters space-bar-step-mode, indicated by the >>> prompt at the end of the line instead of the beginning of the line.

UNJAM UNJAM [IOA0, IOA1, IOA2, IOA3]

An UNJAM sequence is generated by the SBIA selected. SBI0 or SBI1 may be used instead of IOA0 or IOA1.

VERIFY VERIFY [/switch]

Switch is any of the following values: /ACCESS, /CONTEXT, /CYCLE, /ECS, /FBACS, /FBMCS, /FDRAM, /ICS, /IDRAM, /MCF, /MCS, or /PAMM.

The contents of the selected CS/RAM is verified by comparing the data read from the CS/RAM with the contents of the .BPN file used to load it. If no switch is used, all the control stores and RAMs are verified.

This command will display the total number of discrepancies if the HEX debugger command set is not enabled. If HEX is enabled, each failure is reported with good/bad data.

10.4 THE HEX DEBUGGER

This section discusses the hardware debug and trace facility, or HEX, which can be enabled from either MACRO or DIAGNOSTIC contexts. The HEX commands allow the operator to modify and/or interrogate the state of the CPU.

The HEX command set is enabled by the "DEBUG" console command, and is indicated by the addition of one angle bracket (>) to the end of the current prompt. The MACRO prompt will become >>>> and the DIAG prompt will become DC>>.

10.4.1 The HEX Command Set

Table 10-11 contains a list of the HEX commands and a brief description of each.

Table 10-11 The HEX Command Set

CLEAR BREAK	<p>CLEAR {ABREAK, OBREAK} {Symbol, Reg, Hex_ID, All}</p> <p>"Symbol" is a V\$XXXX visibility symbol name, "Reg" is a visibility register name, "Hex ID" is a 16-bit hexadecimal ID number (see EXAMINE/SDB) and "All" will remove all breakpoints from the specified table.</p> <p>This command removes the specified breakpoint from the appropriate table. If "All" is specified, all of the breakpoints in that table are cleared.</p> <p>Example 10-7: CLEAR BREAK</p> <ol style="list-style-type: none"> 1. >>>>CLEAR ABREAK V\$A123 2. >>>>CLEAR OBREAK ALL
CLEAR COUNT	<p>This command clears the step counter. This counter keeps track of the number of machine steps (micro or state) since the last time the counter was cleared. This counter will also be cleared if you enter TSTATE from TMIC or vice versa.</p>
DEPOSIT (CS)	<p>DEPOSIT [/NEXT:Hex_num] [/Switch] Hex_adr Hex_data</p> <p>"/Switch" can be any of the following: /ACCESS, /CONTEXT, /CYCLE, /ECS, /FBACS, /FBMCS, /FDRAM, /ICS, /IDRAM, /MCF, or /MCS</p> <p>"Hex_adr" can be a hexadecimal number or one of the following specifiers that determines the address relative to the last specified address.</p> <ul style="list-style-type: none"> * Access last specified address + Access address followed by the last specified address - Access address preceding the last specified address

CONSOLE SOFTWARE AND COMMANDS
The HEX Command Set

"Hex_data" is any hexadecimal number within the range limits of the specified control store or RAM

This command allows the operator to modify the contents of control store or RAM locations in the VAX 86XX CPU. The /NEXT switch can be used in combination with any other switch to perform successive deposits of the same data into consecutive locations.

NOTE

The MCS, ACCESS, and CYCLE RAMs can be deposited only if the system is out of the reset state. This will be true if the command "MICROSTEP 3" is executed.

Example 10-8: DEPOSIT

1. >>>>DEPOSIT/ACCESS 0 0 ;Deposit 0 into ACCESS RAM location 0
2. >>>>DEPOSIT/ECS/NEXT:10 0 0 ;Deposit 0 in the first 16 EBCS locations
3. >>>>DEPOSIT/CYCLE * 0FA ;Deposit 0FA into the presently addressed CPR location

DEPOSIT/CHANNEL DEPOSIT/CHANNEL Hex_channel Hex_data

"Hex_channel" is one of the SDB channel numbers according to Table 10-12.

Table 10-12 SDB Control Channels

00 - FBA	09 - EBE
02 - FBM	0A - MCC
03 - IBD	0D - EBC
05 - ICA	0E - CSB
08 - EDP	10 - VBA

"Hex_data" is a 16-bit hexadecimal value to be deposited into the selected control channel.

This command deposits the specified data into the selected SDB control channel. Control channels vary in length, so if the data exceeds the length of the channel, the high order bits will be shifted out of the control channel and into the bit bucket. Table 10-13 lists the control channel bit positions.

Table 10-13 Control Channel Bit Positions

Channel	Bit	Signal Name
00 (FBA)	00	MSQ4 SBDADR 0 L
	01	MSQ4 SBDADR 1 L
	02	MSQ4 SBDADR 2 L
	03	MSQ4 SBDADR 3 L
	04	MSQ4 SBDADR 4 L

CONSOLE SOFTWARE AND COMMANDS
The HEX Command Set

	05	MSQ4	SBDADR	5	L
	06	MSQ4	SBDADR	6	L
	07	MSQ4	SBDADR	7	L
	08	MSQ4	SBDADR	8	L
	09	MSQ4	SDBCTL	0	L
	10	MSQ4	SDBCTL	1	L
	11	MSQ4	SDBCTL	2	L
01 (FBM)	00	FM02	SDB	FDR	A4 H
	01	FM02	SDB	FDR	A5 H
	02	FM02	SDB	FDR	A6 H
	03	FM02	SDB	FDR	A7 H
	04	FM02	SDB	FDR	A8 H
	05	FM02	SDB	FDR	A9 H
03 (IBD)	00	IBDH	SDB	DA00	H
	01	IBDH	SDB	DA01	H
	02	IBDH	SDB	DA02	H
	03	IBDH	SDB	DA03	H
	04	IBDH	SDB	DA04	H
	05	IBDH	SDB	DA05	H
	06	IBDH	SDB	DA06	H
	07	IBDH	SDB	DA07	H
	08	IBDH	SDB	DA08	H
	09	IBDH	SDB	DA09	H
	10	IBDH	SDB	DA10	H
	11	IBDH	SDB	DA11	H
	12	IBDH	SDB	DA12	H
	13	IBDH	SDB	DA13	H
	14	IBDH	SDB	DA14	H
	15	IBDH	SDB	DA15	H
05 (ICA)	00	ICA1	ICS	CNTRL	CHNL 0
	01	ICA1	ICS	CNTRL	CHNL 1
	02	ICA1	ICS	CNTRL	CHNL 2
	03	ICA1	ICS	CNTRL	CHNL 3
08 (EDP)	00	EDPI	DISA	BYTE	32 PAR H
	01	EDPI	DISA	BYTE	10 PAR H
	02	EDPI	FLIP	WREG	PAR H
	03	EDPI	DISA	SCE	AR BUS H
	04	EDPI	DISA	ALU	AR BUS H
	05	-EDPI	FLIP	GPRA	H
	06	-EDPI	FLIP	GPRB	H
	07	EDPI	SPARE	0	H
09 (EBE)	00	EBEH	SDB	CTL	D00 H
	01	EBEH	SDB	CTL	D01 H
	02	EBEH	SDB	CTL	D02 H
	03	EBEH	SDB	CTL	D03 H
	04	EBEH	SDB	CTL	D04 H
	05	EBEH	SDB	CTL	D05 H
	06	EBEH	SDB	CTL	D06 H
	07	EBEH	SDB	CTL	D07 H
	08	EBEH	SDB	CTL	D08 H
	09	EBEH	SDB	CTL	D09 H

CONSOLE SOFTWARE AND COMMANDS
The HEX Command Set

0A (MCC)	00	MCCA LOAD ENA H
	01	MCCA WRITE MICRO A L
	02	Unused
	03	MCCA SHIFT ENA H
	04	MCCA WRITE MICRO B L
	05	Unused
	06	MCCB DIAG INTR H
	07	MCCB WRITE VIOL L
	08	Unused
	09	MCCB DIAG RAM WRITE H
	10	MCCB CPR WRITE L
	11	Unused
0D (EBC)	00	EBC1 SDB CTL D00 H
	01	EBC1 SDB CTL D01 H
	02	EBC1 SDB CTL D02 H
	03	EBC1 SDB CTL D03 H
	04	EBC1 SDB CTL D04 H
	05	EBC1 SDB CTL D05 H
	06	EBC1 SDB CTL D06 H
	07	EBC1 SDB CTL D07 H
	08	EBC1 SDB CTL D08 H
	09	EBC1 SDB CTL D09 H
	10	EBC1 SDB CTL D10 H
	11	EBC1 SDB CTL D11 H
	12	EBC1 SDB CTL D12 H
	13	EBC1 SDB CTL D13 H
	14	EBC1 SDB CTL D14 H
	15	EBC1 SDB CTL D15 H
0E (CSB)	00	CSBR CNSL OP1 FLAG H
	01	CSBR CNSL OP2 FLAG H
	02	CSBR LOAD DIAG CNTR H
	03	-CSBR FLIP USTK PAR H
10 (VBA)	00	VB06 CLK CNTRL DATA 0 H
	01	VB06 CLK CNTRL DATA 1 H
	02	VB06 CLK CNTRL DATA 2 H
	03	VB06 CLK CNTRL DATA 3 H
	04	VB06 CLK CNTRL DATA 4 H
	05	VB06 CLK CNTRL DATA 5 H
	06	VB06 CLK CNTRL DATA 6 H
	07	VB06 CLK CNTRL DATA 7 H
	08	VB06 CLK CNTRL 8 H
	09	VB06 CLK CNTRL 9 H
	10	VB06 CLK CNTRL 10 H
	11	VB06 CLK REG LD ENA H

DEPOSIT/CSPE

DEPOSIT/CSPE [/Switch] [/Nofile] Hex_adr

"Switch" can be any of the following: /ECS,
/FBACS, /FBMCS, /ICS, /MCS, /IDRAM, or FDRAM

"Hex_adr" is a hexadecimal address within the selected control stores address range.

This command allows the operator to re-deposit to a control store location with bad parity. The data is taken from the .BPN file used to load the control store, and modified to contain bad parity (parity bit(s) are flipped). If the /Nofile switch is specified, the .BPN file is not used, but the actual data in the RAM is used.

Correct parity can be restored by either reloading the entire control store (LOAD/ECS for instance), or by using the DEPOSIT command with the original control store data. For the EBox, IBox, and MBox, the DEPOSIT/MARK command can be used to restore the data and correct parity.

Example 10-9: DEPOSIT CSPE

1. >>>>DEPOSIT/CSPE/ECS 100D
2. >>>>DEPOSIT/CSPE/MCS 07

DEPOSIT/MARK DEPOSIT/MARK [/Switch] [/Nofile] Hex_adr {On, Off}

"Switch" can be either /ECS, /ICS, or /MCS

"Hexadr" is a hexadecimal address within the bounds of the selected control store.

This command allows the operator to set or clear the mark bit in the selected control store location. On/Off determines whether the mark bit is set or cleared. The data deposited to the control store location is taken from the .BPN file used to load the control store unless the /Nofile switch is used. Correct parity is maintained.

If the SOMM flag (Stop On Micro Mark) is set for the selected control store, the CPU clock will be stopped when a set mark bit is encountered.

When running at full system clock speed, the SOMM flag need not be cleared because the CPU clock is actually stopped beyond the selected micro-instruction. But, if the system clock is at 1/5 speed, the CPU clock will be stopped right at the selected micro-instruction. Attempts to TMIC or TSTATE will not succeed because the micro-instruction being executed has the mark bit set. Clearing the SOMM flag will allow the micro-instructions to be stopped.

Example 10-10: DEPOSIT MARK

1. >>>>DEPOSIT/MARK/ECS 100D ON
2. >>>>DEPOSIT/MARK/ECS 100D OFF

CONSOLE SOFTWARE AND COMMANDS
The HEX Command Set

EXAMINE (CS) EXAMINE [/Next:Hex_num] [/switch] hex_addr

"Switch" can be any of the following: /ACCESS, /CONTEXT, /CYCLE, /ECS, /FBACS, /FBMCS, /FDRAM, /ICS, /IDRAM, /MCF, and /MCS.

"Hex_addr" can be a hexadecimal number or relative to the last specified address as follows:

- * Access last specified address.
- + Access address following last specified address. If "Hex_addr" is not specified, + is assumed.
- Access address preceding last specified address.

This command allows the operator to examine the contents of the selected control store at the specified address, or an address relative to the last specified address. The MCS, ACCESS, and CYCLE RAMs can only be examined if the system is out of the reset state. The command "MICROSTEP 3" can be used to ensure that this is true.

NOTE

The EXAM/MCS command performs a special function when the address is out of range of the MBox control store addresses (greater than FF). The command will read the state of the MCC shift path and convert it to .ULD format (UCODE.ULD) and display the result. This allows the operator to inspect the data in the MCC shift path that has caused an MBox parity error.

Example 10-11: EXAMINE CONTROL STORE

1. >>>>EXAMINE/ECS/NEXT:10 0 ;Examine 10 (hex) ECS locations, starting at location 0
2. >>>>EXAMINE/ECS + ;Examine ECS following last ECS access

EXAMINE/CHANNEL EXAMINE/CHANNEL Hex_channel

"Hex_channel" is the SDB channel number. See Table 10-14 for the SDB channel numbers.

Table 10-14 SDB Channel Numbers

00 - FBA	01 - FBM	02 - MCD
03 - IBD	04 - IDP	05 - ICA
06 - ICB	07 - CLK	08 - EDP
09 - EBE	0A - MCC	0B - MAP
0C - EBD	0D - EBC	0E - CSB
0F - CSA	10 - IOA0	11 - IOA1
12 - IOA2	13 - IOA3	14 - MTM
15 - RESERVED	16 - RESERVED	17 - RESERVED

NOTE

The MTM visibility channel would have a "K" in the V\$ symbol, as V\$K123, whereas channels 00 through 0F would have 0 - F.

This command will display all visibility bits in the specified SDB channel. The data is displayed as a string of hexadecimal characters followed by a three character checksum. The number of characters displayed is:

FBA/FBM 72 characters. The FBox shift channels are 12 bits in length. There are 24 shifts which provides 288 bits.

IDP/IBD/ICB 64 characters. The IBox shift paths are 8 bits in length, and there are 32 shifts which provides 256 bits.

ALL OTHERS 48 characters. The rest of the shift paths are also 8 bits. With 24 shifts each, this provides 192 bits.

Example 10-12: EXAMINE/CHANNEL

1. >>>>EXAMINE/CHAN 0
2. >>>>EXAMINE/CHAN 14

EXAMINE/SDB

EXAMINE/SDB {Symbol_name, Register_name, Hex_ID, "Signal_name"}

"Symbol_name" is the V\$ symbol assigned to the particular visibility signal by the SDB CAD (.CDF) files.

"Register_name" is the name of a default visibility register or a visibility register defined within HEX by the TRACE DEFINE command. A visibility register is a group of VTERM bits joined together in a logical arrangement. Table 10-15 contains the names of the default visibility registers. See also the TRACE DEFINE command. A list of the default visibility registers wouldn't be complete without the contents of each of the registers. See Table 10-16. Table 10-16 will be located at the end of this section due to its length.

Table 10-15 Names of Default Visibility Registers

ABUS	ARADR	ARBUS	ARYBUS
DBUS	EBFLSH	EDPPE	EFORK
EMCF	ESTALL	LUPC	EVABUS
FABUS	FAUPC	FMUPC	IBDBUF
IBUF	IBXERR	IDIAG	INCR
IOPSEL	IUPC	IVABUS	MDBUSI
MDBUSM	MEMREQ	MUPC	NATRAM
OPAR	OPBUS	OPCODE	OPMCF
OPPORT	PAACK	PAMD	PAMM
PARITY	PSL	REGBUS	STALL
UPCSAV	WBUS		

"Hex_ID" is a 16-bit SDB or register ID. SDB_ID's are hardware visibility-bit addresses and are defined in the .CDF files. REG IDs are software-defined numerical tags for Visibility registers.

"Signal_name" is the full visibility signal name, including the High/Low specified.

NOTE

The signal_name must be enclosed in quotes ("signal_name"). Also, the .CDF files do not contain any LOW signal names i.e., the signal "THIS SIGNAL L" would be listed as "-THIS SIGNAL H".

This command displays the name and state of a single visibility signal, or the name and state of a visibility register.

Example 10-13: EXAMINE/SDB

1. >>>>EXAMINE/SDB V\$A123 ;Use symbol name
2. >>>>EXAMINE/SDB WBUS ;Use register name
3. >>>>EXAMINE/SDB 1 ;Use SDB ID
4. >>>>EXAMINE/SDB 800B ;Use register ID

EXIT

This command disables the HEX command set.

MICROSTEP

MICROSTEP [Hex_number]

"Hex_number" is a hexadecimal step count in the range of 1 to 100. The default is 1.

The MICROSTEP command causes "Hex_number" of microinstructions to be executed at full system clock speed. Before stepping begins, the CPU clock is forced to T3 state. CPU clocks must be stopped for this command to function.

The execution of a MICROSTEP command invokes space-bar-step-mode (SBSM), which is indicated by the SBSM>> or SBSMDC>> prompts. In space-bar-step-mode, the next step can be executed by depressing the space-bar.

CONSOLE SOFTWARE AND COMMANDS
The HEX Command Set

SBSM remains in effect until any key other than the space-bar is depressed.

After stepping has finished, all UPC's are displayed.

REPORT

The REPORT command will display all default trace visibility register data. REPORT is invoked on completion of any TMICRO or TSTATE.

The trace reported assumes that all visibility registers are 48 bits in length. If a register greater than 48 bits in length is added to the trace list, the display will be truncated to 48 bits. A "T" will precede the register in the trace list to indicate the truncation.

Any register or signal value whose value is different from that observed on the previous report will be prefixed with an asterisk (*) to denote the change.

SET BREAK

SET {ABREAK, OBREAK} {Symbol, Reg, Hex_ID} [Span, Value:val]

"Symbol" is a V\$XXXX visibility symbol name assigned from the .CDF file.

"Reg" is the name of a visibility register defined within HEX or by the TRACE DEFINE command.

"Hex_ID" is a 16-bit SDB or register ID. SDB_IDs are hardware visibility-bit addresses and are defined in the .CDF files. REG IDs are software defined for visibility registers.

"Span" and "Value:val" are optional breakpoint parameters.

Up to 4 breakpoints can be set in each table (OBREAK, ABREAK). If the signal or register specified is already in the table, the user will be asked if he wants to alter the parameters of that table entry. If so, new parameters are accepted.

The TMICRO or TSTATE commands will stop and report the current machine state only when a break condition is met, when all of the "AND" conditions are true, or any of the "OR" conditions are true.

The "SPAN" option causes a break condition when that signal or register is in a state other than what it was when the trace was started.

The "Value:val" option causes a break condition when that signal or register equals the value specified (1 or 0).

If neither option is selected, "Change" is implied, and a break will occur every time the selected signal or register changes.

CONSOLE SOFTWARE AND COMMANDS
The HEX Command Set

Example 10-14: SET BREAK

1. >>>>SET ABREAK V\$123 ;Break when V\$123 changes
2. >>>>SET ABREAK V\$456 VAL:1 ;Break when V\$456 equals a 1
3. >>>>SET OBREAK WBUS SPAN ;Break if WBus is different than it is now

SET HISTORY

For use by engineering during the development of microcode.

SET MARGIN

SET MARGIN {High, Low, Normal} [{A, B, C, DE, FH, All}]

This command allows the operator to adjust the output level of the power supplies for purposes of detecting marginal faults. Margins can be set +5% (High) or -5% (Low). The outputs of the D and E regulators and the F and H regulators are tied together so these regulators must be margined together (DE, FH).

The regulator outputs to be margined are specified by the second argument (A, B, C, DE, FH). If no regulator is specified, the default is "ALL".

SHOW BREAK

This command shows the contents of the ABREAK or OBREAK tables. The signal or register ID, name, and optional break conditions are shown for each table entry.

SHOW DEFINE

SHOW DEFINE {Reg_name, Hex_ID}

"Reg_name" is the name of a visibility register defined within HEX or by the TRACE DEFINE command. See Table 10-15 for a list of the default visibility registers.

"Hex ID" is a 16-bit SDB or Register ID. SDB IDs are hardware visibility-bit addresses and are defined in the .CDF files.

REG IDs are software defined numerical tags for visibility registers.

This command displays a list of all visibility symbol names (V\$NNNN) used to construct the visibility register. The display is oriented in descending order (high order to low order, left to right) with 12 (decimal) terms per line. The last four characters of each V\$NNNN (NNNN) symbol is shown.

Example 10-15: SHOW DEFINE

1. >>>>SHOW DEFINE REGNAM

```
NNNN REGNAM 13.      V$NNNN, Name, and number
                        of VTERMS that make up
                        this register
1001 2002 3003 4004
5005 6006 7007 8008   The symbols for the 13
9009 1010 1111 1212   VTERMS in this
1313                  register (V$NNNN)
```

SHOW HISTORY SHOW HISTORY [/Output:filename[.DAT]] [Hex_num]
[Hex_num]

The behavior of this command is unpredictable if the optional history module is not in place in the system. It is designed to be used by engineers during the development of microcode.

SHOW NAME SHOW NAME {Symbol_name, Reg_name, Hex_ID,
"Signal_name"}

"Symbol_name" is the name of a visibility register defined within HEX or by the TRACE DEFINE command. See Table 10-16 on Page 38 for a list of default visibility registers with bit definitions.

"Hex_ID" is a 16-bit SDB or Register ID. SDB IDs are hardware visibility-bit addresses and are defined in the .CDF files. Reg IDs are software defined numerical tags for visibility registers.

"Signal_name" is the full visibility signal name, including the "HIGH" or "LOW" specified. The signal name must be enclosed in quotes ("signal name L").

This command looks up the symbol name, register name, ID, or signal name and prints the corresponding V\$ symbol, signal/register name and ID. If displaying a register, the size (number of VTERMS) is also displayed.

Example 10-16: SHOW NAME

1. >>>>SHOW NAME V\$5163 Symbol name
5145 V\$5163 IBD DRAM LAST H
2. >>>>SHOW NAME STALL Register name
802C STALL 29.
3. >>>>SHOW NAME 8000 Register ID
8000 LUPC 13.
4. >>>>SHOW NAME "IBD DRAM LAST H" Signal name
5145 V\$5163 IBD DRAM LAST H

CONSOLE SOFTWARE AND COMMANDS
The HEX Command Set

SHOW REGISTER This command displays a list of all visibility registers currently defined, whether within HEX or by the TRACE DEFINE command. The display includes each register's ID_number, name, and size.

NOTE

A validity check is done on each register before it is displayed. If a bad entry in a register is found, the name "-badreg-" is assigned to the register. Because of the bad register definition, there is no way for the code to display the true name of the register.

SHOW TRACE This command displays a list of all registers and signals currently selected for tracing. The trace list may be changed by the user using the TRACE ADD command. The current breakpoint options are also included.

STATESTEP STATESTEP [Hex_num]
"Hex_num" is a hexadecimal step count in the range of 1 to 400 (hex). The default is 1 step.

The STATESTEP command causes "Hex_num" clock ticks to be executed.

A STATESTEP count of 4 is equivalent to one MICROSTEP. The micro-pc's of the boxes are not shown for STATESTEP. Statesteps are executed at full machine speed.

The execution of the STATESTEP command invokes space-bar-step-mode (SBSM) as indicated by the SBSM>> or SBSMDC>> prompts. In SBSM, the user can cause additional steps to be executed by depressing the space-bar (one STATESTEP per space character). SBSM remains in effect until a character other than the space-bar is depressed.

TMICRO, TSTATE TMICRO [Hex_num], TSTATE [Hex_num]
"Hex_num" is a hexadecimal step count. If not specified, the default is 1.

These commands initialize the trace facility and execute CPU clock steps (1 clock cycle for TMICRO (TMIC), 1 clock phase for TSTATE) while watching for a trace breakpoint condition, or until the step count expires. The state of the machine is then captured and reported in accordance with the current trace settings (see SHOW TRACE).

If any trace breakpoints are set, trace stepping stops, and the trace report generated, as soon as a brake condition is met. If no step count is given, and trace breakpoint conditions are defined, then stepping continues indefinitely until either a breakpoint or ^C input character is detected.

When a breakpoint is detected, or the step count expires, HEX enters SBSM.

NOTE

If QUIET is ON, no trace information is displayed until the final trace step has completed; if QUIET is OFF, then trace information is displayed for each step.

TMIC is equivalent to MICROSTEP followed by REPORT. TSTATE is equivalent to STATESTEP followed by report.

TRACE ADD

TRACE ADD item

Item is any combination of "Regname" (add registers to the trace list) or V\$NNNN (add signals to the trace list).

This command is used to customize the register and signal trace lists (see SHOW TRACE). The list of items to add is included in the command line and may specify as many items as will fit on the remainder of that line. The V\$ prefix is required. Use a SHOW REGISTER command to display available registers.

Example 10-17: TRACE ADD

```
1. >>>>TRACE ADD LUPC USRREG PARITY V$1001 V$2345
```

TRACE DEFINE

TRACE DEFINE Reg_name

"Reg_name" is a unique name to be assigned to the new "user-defined" register. Name strings must be 6 characters or less in length, and will be truncated to 6 characters if names of more than 6 characters are entered.

This command is used to define visibility registers in addition to those already defined (See Table 10-15). The command will check to see if the new name is not already defined and if not, will prompt the user to enter a list of V\$ symbol names. Only the last four characters of the six character V\$NNNN (NNNN) need be entered. Enter the signals beginning with the most significant. Signals must be separated with a space or a comma, but not both.

Signal names may be continued on the next line with a CR (Carriage Return) at the end of the line. Terminate the definition with an additional carriage return. HEX will display the verification. Note in the example NNNN, the register number, NEWREG, the register name (truncated to 6 characters), and n, the number of signals in the register. A register defined with TRACE DEFINE is added to the default trace list (SHOW TRACE).

Example 10-18: TRACE DEFINE

```
1. >>>>TRACE DEFINE newregister
Enter V$ terms separated with <SP> or <,>
1001 2002 3003 4004 5005 6006 7007 8008<CR>
9009 1010 1111 1212 1313 1414 1515 1616<CR>
<CR>
NNNN NEWREG n.
```

TRACE DELETE TRACE DELETE Reg_name

This command will delete a user defined visibility register established by TRACE DEFINE. The command will ask for confirmation before taking any action. If the delete request is confirmed, the named register is removed from the register list and removed from the register trace list (TRACE REMOVE). Registers in the default register list may not be deleted.

Example 10-19: TRACE DELETE

```
1. >>>>TRACE DELETE newreg
Delete register NEWREG -- confirm (Y/N) y
;Confirm response
```

TRACE REMOVE TRACE REMOVE Item

"Item" can be any of the following:

R* Remove all registers from the list
S* Remove all signals from the list
Reg_name Remove named registers from the list
V\$NNNN Remove named signal from the list

This command is used to customize the register and signal trace list by allowing unwanted information to be removed. The list of items to remove is included in the command line and may specify as many items (separated by a space) as will fit on the remainder of the line. The V\$ is required for signal names. A default register will just be removed from the trace list, it will not be removed from the register list.

Example 10-20: TRACE REMOVE

```
1. >>>>TRACE REMOVE V$1234 V$4567 NEWREG
```

TRACE RESTORE

This command is used to restore the default trace list (including all default visibility registers and signals) and zero all counters and variables.

10.4.2 Default Visibility Registers

The HEX debugger command set provides access to a number of pre-defined visibility registers useful for tracing the machine state. Most of these registers are part of the default TRACE list used by the TMICRO, TSTATE, and REPORT commands. The TRACE ADD command can be used to add a register to the TRACE list. The TRACE DEFINE command can be used to define a new visibility register. Table 10-15 lists the visibility registers present in the console program.

Just the name of the register is not enough when trying to decipher a TMIC, or any trace; a bit breakdown of the registers is necessary. Table 10-16 is a complete list of visibility registers and the signal names that make them up. Note that bits are listed in order of the MOST-SIGNIFICANT BIT FIRST. The special filler symbol 'XXXX' is used to 0-pad a visibility register in places where signals are no longer defined or where nibble alignment is desired. Visibility register definition can be found in the source listing for the HEXBOX module (HEXBOXT11.LST).

Table 10-16 Default Visibility Registers

ABUS

V\$ symbol	Bit	Nibble	Signal name
V\$A223	43	11	SB ABUS IOA REQUEST 3 H
V\$A225	42		SB ABUS IOA REQUEST 2 H
V\$A215	41		SB ABUS IOA REQUEST 1 H
V\$A217	40		SB ABUS IOA REQUEST 0 H
V\$A130	39	10	ABUS CPU BUF DONE H
V\$A226	38		ABUS CPU BUF ERROR H
V\$A220	37		ABUS LEN STAT 1 H
V\$A222	36		ABUS LEN STAT 0 H
V\$A211	35	9	ABUS CMD MASK 3 H
V\$A214	34		ABUS CMD MASK 2 H
V\$A219	33		ABUS CMD MASK 1 H
V\$A210	32		ABUS CMD MASK 0 H
V\$B195	31	8	ABUS DATA ADDRS 31 H
V\$B203	30		ABUS DATA ADDRS 30 H
V\$B139	29		ABUS DATA ADDRS 29 H
V\$B128	28		ABUS DATA ADDRS 28 H
V\$B199	27	7	ABUS DATA ADDRS 27 H
V\$B197	26		ABUS DATA ADDRS 26 H
V\$B198	25		ABUS DATA ADDRS 25 H
V\$B183	24		ABUS DATA ADDRS 24 H
V\$B200	23	6	ABUS DATA ADDRS 23 H
V\$B130	22		ABUS DATA ADDRS 22 H
V\$B204	21		ABUS DATA ADDRS 21 H
V\$B131	20		ABUS DATA ADDRS 20 H
V\$B189	19	5	ABUS DATA ADDRS 19 H
V\$B135	18		ABUS DATA ADDRS 18 H
V\$B138	17		ABUS DATA ADDRS 17 H
V\$B136	16		ABUS DATA ADDRS 16 H

CONSOLE SOFTWARE AND COMMANDS
Default Visibility Registers

V\$ symbol	Bit	Nibble	Signal name
V\$B140	15	4	ABUS DATA ADDRS 15 H
V\$B190	14		ABUS DATA ADDRS 14 H
V\$B141	13		ABUS DATA ADDRS 13 H
V\$B191	12		ABUS DATA ADDRS 12 H
V\$B127	11	3	ABUS DATA ADDRS 11 H
V\$B196	10		ABUS DATA ADDRS 10 H
V\$B208	09		ABUS DATA ADDRS 09 H
V\$B193	08		ABUS DATA ADDRS 08 H
V\$B194	07	2	ABUS DATA ADDRS 07 H
V\$B169	06		ABUS DATA ADDRS 06 H
V\$B209	05		ABUS DATA ADDRS 05 H
V\$B206	04		ABUS DATA ADDRS 04 H
V\$B205	03	1	ABUS DATA ADDRS 03 H
V\$B168	02		ABUS DATA ADDRS 02 H
V\$B176	01		ABUS DATA ADDRS 01 H
V\$B177	00		ABUS DATA ADDRS 00 H

ARADR

V\$ symbol	Bit	Nibble	Signal name
V\$K103	28	8	MAP1 ARRAY ADR 28 H
V\$K105	27		MAP1 ARRAY ADR 27 H
V\$K101	26		MAP1 ARRAY ADR 26 H
V\$K179	25		MAP1 ARRAY ADR 25 H
V\$K174	24	6	MAP1 ARRAY ADR 24 H
V\$K177	23		MAP1 ARRAY ADR 23 H
V\$K173	22		MAP1 ARRAY ADR 22 H
V\$K171	21		MAP1 ARRAY ADR 21 H
V\$K159	20	5	MAP1 ARRAY ADR 20 H
V\$K162	19		MAP1 ARRAY ADR 19 H
V\$K161	18		MAP1 ARRAY ADR 18 H
V\$K157	17		MAP1 ARRAY ADR 17 H
V\$K156	16	4	MAP2 ARRAY ADR 16 H
V\$K155	15		MAP2 ARRAY ADR 15 H
V\$K151	14		MAP2 ARRAY ADR 14 H
V\$K154	13		MAP2 ARRAY ADR 13 H
V\$K148	12	3	MAP2 ARRAY ADR 12 H
V\$K147	11		MAP2 ARRAY ADR 11 H
V\$K143	10		MAP2 ARRAY ADR 10 H
V\$K146	09		MAP2 ARRAY ADR 09 H
V\$K142	08	2	MAP2 ARRAY ADR 08 H
V\$K145	07		MAP2 ARRAY ADR 07 H
V\$K141	06		MAP2 ARRAY ADR 06 H
V\$K140	05		MAP2 ARRAY ADR 05 H
V\$K139	04	1	MAP2 ARRAY ADR 04 H
V\$K135	03		MAP2 ARRAY ADR 03 H
V\$XXXX	02		Zero-Filler
V\$XXXX	01		Zero-Filler
V\$XXXX	00		Zero-Filler

ARBUS

V\$ symbol	Bit	Nibble	Signal name
V\$K113	31	8	ARRAY BUS D31 H
V\$K112	30		ARRAY BUS D30 H
V\$K106	29		ARRAY BUS D29 H
V\$K107	28		ARRAY BUS D28 H
V\$K108	27	7	ARRAY BUS D27 H
V\$K102	26		ARRAY BUS D26 H
V\$K175	25		ARRAY BUS D25 H
V\$K178	24		ARRAY BUS D24 H
V\$K104	23	6	ARRAY BUS D23 H
V\$K100	22		ARRAY BUS D22 H
V\$K176	21		ARRAY BUS D21 H
V\$K172	20		ARRAY BUS D20 H
V\$K167	19	5	ARRAY BUS D19 H
V\$K169	18		ARRAY BUS D18 H
V\$K166	17		ARRAY BUS D17 H
V\$K170	16		ARRAY BUS D16 H
V\$K131	15	4	ARRAY BUS D15 H
V\$K127	14		ARRAY BUS D14 H
V\$K129	13		ARRAY BUS D13 H
V\$K130	12		ARRAY BUS D12 H
V\$K126	11	3	ARRAY BUS D11 H
V\$K125	10		ARRAY BUS D10 H
V\$K128	09		ARRAY BUS D09 H
V\$K119	08		ARRAY BUS D08 H
V\$K123	07	2	ARRAY BUS D07 H
V\$K124	06		ARRAY BUS D06 H
V\$K122	05		ARRAY BUS D05 H
V\$K118	04		ARRAY BUS D04 H
V\$K121	03	1	ARRAY BUS D03 H
V\$K117	02		ARRAY BUS D02 H
V\$K120	01		ARRAY BUS D01 H
V\$K116	00		ARRAY BUS D00 H

DBUS

V\$ symbol	Bit	Nibble	Signal name
V\$3271	31	8	-DBUS D31 H
V\$3262	30		-DBUS D30 H
V\$3272	29		-DBUS D29 H
V\$3266	28		-DBUS D28 H
V\$3170	27	7	-DBUS D27 H
V\$3225	26		-DBUS D26 H
V\$3241	25		-DBUS D25 H
V\$3240	24		-DBUS D24 H
V\$3270	23	6	-DBUS D23 H
V\$3263	22		-DBUS D22 H
V\$3273	21		-DBUS D21 H
V\$3275	20		-DBUS D20 H

CONSOLE SOFTWARE AND COMMANDS
Default Visibility Registers

V\$ symbol	Bit	Nibble	Signal name
V\$3171	19	5	-DBUS D19 H
V\$3187	18		-DBUS D18 H
V\$3237	17		-DBUS D17 H
V\$3236	16		-DBUS D16 H
V\$3269	15	4	-DBUS D15 H
V\$3268	14		-DBUS D14 H
V\$3274	13		-DBUS D13 H
V\$3267	12		-DBUS D12 H
V\$3220	11	3	-DBUS D11 H
V\$3222	10		-DBUS D10 H
V\$3239	09		-DBUS D09 H
V\$3242	08		-DBUS D08 H
V\$3176	07	2	-DBUS D07 H
V\$3178	06		-DBUS D06 H
V\$3105	05		-DBUS D05 H
V\$3104	04		-DBUS D04 H
V\$3145	03	1	-DBUS D03 H
V\$3144	02		-DBUS D02 H
V\$3243	01		-DBUS D01 H
V\$3126	00		-DBUS D00 H

EBFLSH

V\$ symbol	Bit	Nibble	Signal name
V\$3198	04	2	-ICA BUF FLUSH MRES3 H
V\$5230	03	1	-ICAB EFLSH FR CPC LAT H
V\$5218	02		-CSB UMC F 2 A H
V\$5242	01		ICA6 IFORK CTL 2 H
V\$5194	00		-CSB UMC F 0 A H

EDPPE

V\$ symbol	Bit	Nibble	Signal name
V\$9104	43	11	EDP EDPE D3 H
V\$D157	42		EDP EDPE D2 H
V\$9102	41		EDP EDPE D1 H
V\$D156	40		EDP EDPE D0 H
V\$E138	39	10	EDP STATE 7 H
V\$E109	38		EDP STATE 6 H
V\$E177	37		EDP STATE 5 H
V\$E120	36		EDP STATE 4 H
V\$E184	35	9	EDP STATE 3 H
V\$E136	34		EDP STATE 2 H
V\$E110	33		EDP STATE 1 H
V\$E178	32		EDP STATE 0 H
V\$A180	31	8	ICA ISTALL A H
V\$9103	30		EBD RSV MODE H
V\$9100	29		ICB RLOG PE H
V\$9181	28		ICB IBUF PE H

CONSOLE SOFTWARE AND COMMANDS
Default Visibility Registers

V\$ symbol	Bit	Nibble	Signal name
V\$5123	27	7	ICA7 ICS PAR ERR H
V\$9101	26		ICB IDRAM PE H
V\$9176	25		IDP IAMUX PE H
V\$9182	24		IDP IBMUX PE H
V\$XXXX	23	6	Zero-Filler
V\$6127	22		MCC OP PA ACK B H
V\$5167	21		MCC IBF PA ACK H
V\$9162	20		MCC MBOX CS PE H
V\$5221	19	5	EBD ESTALL TO ICA H
V\$5186	18		EBE IBOX ERR LTH A H
V\$9170	17		EBD ECS PE FLAG H
V\$9110	16		EBD ECS PE LST CYC H
V\$D166	15	4	EBD EBOX ERR LST CYC H
V\$4167	14		EBD EBOX ERR TO IDP H
V\$9170	13		EBD ECS PE FLAG H
V\$9110	12		EBD ECS PE LST CYC H
V\$D158	11	3	EBD EDP PE FLAG A H
V\$9169	10		EBD EDP PE FLAG H
V\$9173	09		EBD EMCR PE FLAG H
V\$9161	08		EBD EN ETRAP H
V\$9174	07	2	EBD USTK PE FLAG H
V\$9143	06		EBD WBUS PE FLAG H
V\$C159	05		-EBC MCF RAM PAR ERR H
V\$C161	04		EBD6 EVC D09 H
V\$4139	03	1	-ICA BMUX CHK WITH CTX H
V\$0131	02		EBE WBUS OPAR B2 C H
V\$0129	01		EBE WBUS OPAR B1 C H
V\$4281	00		-DBUS D08 H

EFORK

V\$ symbol	Bit	Nibble	Signal name
V\$6146	08	3	-CSB EBOX FORK E H
V\$0100	07	2	-CSB EBOX FORK D H
V\$8124	06		-CSB EBOX FORK C H
V\$5159	05		-CSB EBOX FORK B H
V\$C226	04		-CSB EBOX FORK A H
V\$XXXX	03	1	Zero-Filler
V\$C102	02		-CSB EBOX IRD A H
V\$6101	01		-CSB EBOX IRD B H
V\$1231	00		-CSB EBOX IRD C H

CONSOLE SOFTWARE AND COMMANDS
Default Visibility Registers

EMCF

V\$ symbol	Bit	Nibble	Signal name
V\$D184	37	10	CSA UMCF 5 A H
V\$D186	36		CSA UMCF 4 A H
V\$D181	35	9	CSA UMCF 3 A H
V\$D183	34		CSB UMCF 2 A H
V\$D180	33		CSB UMCF 1 A H
V\$D182	32		CSB UMCF 0 A H
V\$XXXX	31	8	Zero-Filler
V\$XXXX	30		Zero-Filler
V\$A153	29		EBC EBOX MCF 5 H
V\$A182	28		EBC EBOX MCF 4 H
V\$A174	27	7	EBC EBOX MCF 3 H
V\$A165	26		EBC EBOX MCF 2 H
V\$A164	25		EBC EBOX MCF 1 H
V\$A154	24		EBC EBOX MCF 0 H
V\$XXXX	23	6	Zero-Filler
V\$D154	22		-EBC9 MCF-LOAD N H
V\$D153	21		-EBC9 MCF-LOAD T H
V\$D155	20		-EBC9 MCF-REQUE N H
V\$D151	19	5	-EBC9 MCF-REQUE T H
V\$D146	18		EBCA MCF-EN MBOX H
V\$D140	17		EBCA MCF-WCHK H
V\$D150	16		EBC8 MCF-E DISP I H
V\$C179	15	4	-EBC MCF-ACK REQ LTH H
V\$C187	14		-EBC MCF-CLR EBPS LTH H
V\$C184	13		-EBC MCF-CLR IBPS LTH H
V\$C186	12		-EBC MCF-CLR OPPS LTH H
V\$C180	11	3	-EBC MCF-EN OWSTL LTH H
V\$C178	10		-EBC MCF-MEM REQ LTH H
V\$C127	09		-EBC MCF-MEM WRT LTH H
V\$C199	08		-EBC MCF-OP WRT LTH H
V\$D143	07	2	-EBCA MCF-ACK REQ H
V\$D138	06		-EBC8 MCF-CLR EBPS H
V\$D149	05		-EBC8 MCF-CLR IBPS H
V\$D137	04		-EBC8 MCF-CLR OPPS H
V\$D134	03	1	-EBC7 MCF-EN OWSTL H
V\$D139	02		-EBC7 MCF-MEM REQ H
V\$D104	01		-EBC7 MCF-MEM WRT H
V\$D105	00		-EBC7 MCF-OP WRT H

CONSOLE SOFTWARE AND COMMANDS
Default Visibility Registers

ESTALL

V\$ symbol	Bit	Nibble	Signal name
V\$E183	11	3	-EBD ESTALL TO CSB H
V\$D171	10		EBD ESTALL TO EBC H
V\$9166	09		EBD ESTALL TO EBE H
V\$8160	08		EBD ESTALL TO EDP H
V\$0190	07	2	EBD ESTALL TO FBA H
V\$1123	06		EBD ESTALL TO FBM H
V\$3157	05		-EBD ESTALL TO IBD H
V\$5221	04		EBD ESTALL TO ICA H
V\$6138	03	1	EBD ESTALL TO ICB H
V\$4126	02		EBD ESTALL TO IDP H
V\$A184	01		EBD ESTALL TO MCC H
V\$2114	00		EBD ESTALL TO MCD H

EUPC

V\$ symbol	Bit	Nibble	Signal name
V\$F122	12	4	CSB UPC 12 H
V\$F123	11	3	CSB UPC 11 H
V\$F111	10		CSB UPC 10 H
V\$F113	09		CSB UPC 09 H
V\$F107	08		CSB UPC 08 H
V\$F112	07	2	CSB UPC 07 H
V\$F115	06		CSB UPC 06 H
V\$F109	05		CSB UPC 05 H
V\$F110	04		CSB UPC 04 H
V\$F114	03	1	CSB UPC 03 H
V\$F126	02		CSB UPC 02 A H
V\$F118	01		CSB UPC 01 A H
V\$F127	00		CSB UPC 00 A H

EVABUS

V\$ symbol	Bit	Nibble	Signal name
V\$B222	31	8	EDP EVA A31 H
V\$B112	30		EDP EVA A30 H
V\$B187	29		EDP EVA A29 H
V\$B182	28		EDP EVA A28 H
V\$B188	27	7	EDP EVA A27 H
V\$B132	26		EDP EVA A26 H
V\$B201	25		EDP EVA A25 H
V\$B119	24		EDP EVA A24 H
V\$B118	23	6	EDP EVA A23 H
V\$B133	22		EDP EVA A22 H
V\$B134	21		EDP EVA A21 H
V\$B123	20		EDP EVA A20 H

CONSOLE SOFTWARE AND COMMANDS
Default Visibility Registers

V\$ symbol	Bit	Nibble	Signal name
V\$B126	19	5	EDP EVA A19 H
V\$B192	18		EDP EVA A18 H
V\$B122	17		EDP EVA A17 H
V\$B207	16		EDP EVA A16 H
V\$B215	15	4	EDP EVA A15 H
V\$B143	14		EDP EVA A14 H
V\$B146	13		EDP EVA A13 H
V\$B145	12		EDP EVA A12 H
V\$B144	11	3	EDP EVA A11 H
V\$B216	10		EDP EVA A10 H
V\$B213	09		EDP EVA A09 H
V\$B175	08		EDP EVA A08 H
V\$B171	07	2	EDP EVA A07 H
V\$B179	06		EDP EVA A06 H
V\$B173	05		EDP EVA A05 H
V\$B174	04		EDP EVA A04 H
V\$B167	03	1	EDP EVA A03 H
V\$B170	02		EDP EVA A02 H
V\$B159	01		EDP EVA A01 A H
V\$B162	00		EDP EVA A00 A H

FABUS

V\$ symbol	Bit	Nibble	Signal name
V\$1197	31	8	-FBA FA BUS D31 H
V\$1269	30		-FBA FA BUS D30 H
V\$1138	29		-FBA FA BUS D29 H
V\$1180	28		-FBA FA BUS D28 H
V\$1171	27	7	-FBA FA BUS D27 H
V\$1167	26		-FBA FA BUS D26 H
V\$1250	25		-FBA FA BUS D25 H
V\$1170	24		-FBA FA BUS D24 H
V\$1198	23	6	-FBA FA BUS D23 H
V\$1260	22		-FBA FA BUS D22 H
V\$1139	21		-FBA FA BUS D21 H
V\$1165	20		-FBA FA BUS D20 H
V\$1261	19	5	-FBA FA BUS D19 H
V\$1248	18		-FBA FA BUS D18 H
V\$1137	17		-FBA FA BUS D17 H
V\$1169	16		-FBA FA BUS D16 H
V\$1199	15	4	-FBA FA BUS D15 H
V\$1262	14		-FBA FA BUS D14 H
V\$1134	13		-FBA FA BUS D13 H
V\$1183	12		-FBA FA BUS D12 H
V\$1263	11	3	-FBA FA BUS D11 H
V\$1244	10		-FBA FA BUS D10 H
V\$1249	09		-FBA FA BUS D09 H
V\$1164	08		-FBA FA BUS D08 H

CONSOLE SOFTWARE AND COMMANDS
Default Visibility Registers

V\$ symbol	Bit	Nibble	Signal name
V\$1200	07	2	-FBA FA BUS D07 H
V\$1265	06		-FBA FA BUS D06 H
V\$1133	05		-FBA FA BUS D05 H
V\$1196	04		-FBA FA BUS D04 H
V\$1264	03	1	-FBA FA BUS D03 H
V\$1245	02		-FBA FA BUS D02 H
V\$1251	01		-FBA FA BUS D01 H
V\$1168	00		-FBA FA BUS D00 H

FAUPC

V\$ symbol	Bit	Nibble	Signal name
V\$0243	08	3	FA11 UPCA A8 H
V\$0321	07	2	FA11 UPCA A7 H
V\$0320	06		FA11 UPCA A6 H
V\$0319	05		FA11 UPCA A5 H
V\$0325	04		FA11 UPCA A4 H
V\$0324	03	1	FA11 UPCA A3 H
V\$0322	02		FA11 UPCA A2 H
V\$0242	01		FA11 UPCA A1 H
V\$0335	00		FA11 UPCA A0 H

FMUPC

V\$ symbol	Bit	Nibble	Signal name
V\$1152	08	3	FM11 UPC A8 H
V\$1149	07	2	FM11 UPC A7 H
V\$1179	06		FM11 UPC A6 H
V\$1178	05		FM11 UPC A5 H
V\$1155	04		FM11 UPC A4 H
V\$1154	03	1	FM11 UPC A3 H
V\$1148	02		FM11 UPC A2 H
V\$1153	01		FM11 UPC A1 H
V\$1150	00		FM11 UPC A0 H

IBDBUF

V\$ symbol	Bit	Nibble	Signal name
V\$4289	42	11	IBD DRAM CTX 2 H
V\$4288	41		IBD DRAM CTX 1 H
V\$4287	40		IBD DRAM CTX 0 H
V\$5117	39	10	IBD DRAM TYPE 1 H
V\$5211	38		IBD DRAM TYPE 0 H
V\$5116	37		IBD DRAM REF 1 H
V\$5214	36		IBD DRAM REF 0 H

CONSOLE SOFTWARE AND COMMANDS
Default Visibility Registers

V\$ symbol	Bit	Nibble	Signal name
V\$5192	35	9	IBD BDEST NEXT H
V\$5163	34		IBD DRAM LAST H
V\$5171	33		IBD DRAM SUSP H
V\$5236	32		IBD DISABLE SB HIT H
V\$5245	31	8	IBD BUF FD INST H
V\$5249	30		IBD EXT OPC H
V\$6129	29		IBD BUF IBUF PE H
V\$6128	28		IBD BUF DRAM PE H
V\$5270	27	7	IBD IFORK VALID H
V\$5175	26		IBD DMUX VALID H
V\$5172	25		IBD EXC ONLY H
V\$5213	24		IBD EPC 0 OR 7 H
V\$5111	23	6	IBD ISEL B2 H
V\$3193	22		ICA LD IFORK DISP H
V\$5101	21		IBD BUF LD CTL 1 H
V\$5103	20		IBD BUF LD CTL 0 H
V\$4286	19	5	-IBD OPTIMIZED H
V\$4192	18		IBD BUF DELTA PC 2 H
V\$4187	17		IBD BUF DELTA PC 1 H
V\$4193	16		IBD BUF DELTA PC 0 H
V\$6132	15	4	IBD IBGPR 3 H
V\$6179	14		IBD IBGPR 2 H
V\$6135	13		IBD IBGPR 1 H
V\$6133	12		IBD IBGPR 0 H
V\$4285	11	3	IBD IGPR 3 H
V\$4284	10		IBD IGPR 2 H
V\$4283	09		IBD IGPR 1 H
V\$4282	08		IBD IGPR 0 H
V\$5161	07	2	IBD BUF FA 7 H
V\$5136	06		IBD BUF FA 6 H
V\$5253	05		IBD BUF FA 5 H
V\$5158	04		IBD BUF FA 4 H
V\$5179	03	1	IBD BUF FA 3 H
V\$6123	02		IBD BUF FA 2 H
V\$6119	01		IBD BUF FA 1 H
V\$6121	00		IBD BUF FA 0 H

IBUF

V\$ symbol	Bit	Nibble	Signal name
V\$5114	15	4	IBD IBUF DATA B1 7 H
V\$5208	14		IBD IBUF DATA B1 6 H
V\$5209	13		IBD IBUF DATA B1 5 H
V\$5210	12		IBD IBUF DATA B1 4 H
V\$5237	11	3	IBD IBUF DATA B1 3 H
V\$5233	10		IBD IBUF DATA B1 2 H
V\$5246	09		IBD IBUF DATA B1 1 H
V\$5243	08		IBD IBUF DATA B1 0 H

CONSOLE SOFTWARE AND COMMANDS
Default Visibility Registers

V\$ symbol	Bit	Nibble	Signal name
V\$5104	07	2	IBD IBUF DATA B0 7 H
V\$5106	06		IBD IBUF DATA B0 6 H
V\$5108	05		IBD IBUF DATA B0 5 H
V\$5105	04		IBD IBUF DATA B0 4 H
V\$5250	03	1	IBD IBUF DATA B0 3 H
V\$5248	02		IBD IBUF DATA B0 2 H
V\$5247	01		IBD IBUF DATA B0 1 H
V\$5252	00		IBD IBUF DATA B0 0 H

IBXERR

V\$ symbol	Bit	Nibble	Signal name
V\$C197	04	2	-EBE IBOX ERR LTH E H
V\$8163	03	1	EBE IBOX ERR LTH D H
V\$4166	02		EBE IBOX ERR LTH C H
V\$6204	01		EBE IBOX ERR LTH B H
V\$5186	00		EBE IBOX ERR LTH A H

IDIAG

V\$ symbol	Bit	Nibble	Signal name
V\$D102	05	2	ICA IBOX DIAG DONE H
V\$5244	04		EBC E DISP I DLY H
V\$D150	03	1	EBC8 MCF-E DISP I H
V\$5196	02		-ICB ID FULL STALL H
V\$6116	01		ICA PC ISTALL H
V\$4130	00		IDP5 ISTALL A H

INCR

V\$ symbol	Bit	Nibble	Signal name
V\$4175	07	2	-IBD INCR VIBA BY 4 H
V\$3131	06		IBD9 SHIFT COUNT 2 B H
V\$3150	05		IBDD LAT CTX 1 H
V\$3253	04		IBD9 SHIFT COUNT 0 B H
V\$6171	03	1	IBD UNLAT CUR VAL 3 H
V\$6170	02		IBD UNLAT CUR VAL 2 H
V\$6174	01		IBD UNLAT CUR VAL 1 H
V\$6206	00		IBD UNLAT CUR VAL 0 H

CONSOLE SOFTWARE AND COMMANDS
Default Visibility Registers

IOPSEL

V\$ symbol	Bit	Nibble	Signal name
V\$3163	05	2	CSB UOPSEL 1 B H
V\$3206	04		CSB UOPSEL 0 B H
V\$8146	03	1	CSA UMISC 3 H
V\$8168	02		CSA UMISC 2 H
V\$8143	01		CSA UMISC 1 H
V\$8150	00		CSA UMISC 0 H

IUPC

V\$ symbol	Bit	Nibble	Signal name
V\$5120	07	2	ICA8 LD OR SAV 7 H
V\$5119	06		ICA8 LD OR SAV 6 H
V\$5157	05		ICA8 LD OR SAV 5 H
V\$5121	04		ICA8 LD OR SAV 4 H
V\$5155	03	1	ICA8 LD OR SAV 3 H
V\$5154	02		ICA8 LD OR SAV 2 H
V\$5150	01		ICA8 LD OR SAV 1 H
V\$5156	00		ICA8 LD OR SAV 0 H

IVABUS

V\$ symbol	Bit	Nibble	Signal name
V\$B160	31	8	IVA BUS 31 H
V\$B223	30		IVA BUS 30 H
V\$B202	29		IVA BUS 29 H
V\$B185	28		IVA BUS 28 H
V\$B117	27	7	IVA BUS 27 H
V\$B186	26		IVA BUS 26 H
V\$B184	25		IVA BUS 25 H
V\$B115	24		IVA BUS 24 H
V\$B114	23	6	IVA BUS 23 H
V\$B129	22		IVA BUS 22 H
V\$B116	21		IVA BUS 21 H
V\$B125	20		IVA BUS 20 H
V\$B121	19	5	IVA BUS 19 H
V\$B120	18		IVA BUS 18 H
V\$B124	17		IVA BUS 17 H
V\$B217	16		IVA BUS 16 H
V\$B214	15	4	IVA BUS 15 H
V\$B147	14		IVA BUS 14 H
V\$B149	13		IVA BUS 13 H
V\$B148	12		IVA BUS 12 H
V\$B218	11	3	IVA BUS 11 H
V\$B219	10		IVA BUS 10 H
V\$B220	09		IVA BUS 09 H
V\$B211	08		IVA BUS 08 H

CONSOLE SOFTWARE AND COMMANDS
Default Visibility Registers

V\$ symbol	Bit	Nibble	Signal name
V\$B172	07	2	IVA BUS 07 H
V\$B210	06		IVA BUS 06 H
V\$B180	05		IVA BUS 05 H
V\$B166	04		IVA BUS 04 H
V\$B178	03	1	IVA BUS 03 H
V\$B181	02		IVA BUS 02 H
V\$B161	01		IVA BUS 01 H
V\$B158	00		IVA BUS 00 H

MDBUSI

V\$ symbol	Bit	Nibble	Signal name
V\$3281	31	8	MD BUS D31 H
V\$3232	30		MD BUS D30 H
V\$3244	29		MD BUS D29 H
V\$3251	28		MD BUS D28 H
V\$3252	27	7	MD BUS D27 H
V\$3282	26		MD BUS D26 H
V\$3116	25		MD BUS D25 H
V\$3165	24		MD BUS D24 H
V\$3280	23	6	MD BUS D23 H
V\$3234	22		MD BUS D22 H
V\$3229	21		MD BUS D21 H
V\$3235	20		MD BUS D20 H
V\$3120	19	5	MD BUS D19 H
V\$3279	18		MD BUS D18 H
V\$3118	17		MD BUS D17 H
V\$3283	16		MD BUS D16 H
V\$3277	15	4	MD BUS D15 H
V\$3230	14		MD BUS D14 H
V\$3248	13		MD BUS D13 H
V\$3233	12		MD BUS D12 H
V\$3121	11	3	MD BUS D11 H
V\$3256	10		MD BUS D10 H
V\$3119	09		MD BUS D09 H
V\$3168	08		MD BUS D08 H
V\$3276	07	2	MD BUS D07 H
V\$3228	06		MD BUS D06 H
V\$3249	05		MD BUS D05 H
V\$3250	04		MD BUS D04 H
V\$3254	03	1	MD BUS D03 H
V\$3257	02		MD BUS D02 H
V\$3135	01		MD BUS D01 H
V\$3164	00		MD BUS D00 H

CONSOLE SOFTWARE AND COMMANDS
Default Visibility Registers

MDBUSM

V\$ symbol	Bit	Nibble	Signal name
V\$2130	31	8	MD BUS D31 H
V\$2131	30		MD BUS D30 H
V\$2129	29		MD BUS D29 H
V\$2132	28		MD BUS D28 H
V\$2140	27	7	MD BUS D27 H
V\$2139	26		MD BUS D26 H
V\$2135	25		MD BUS D25 H
V\$2136	24		MD BUS D24 H
V\$2144	23	6	MD BUS D23 H
V\$2134	22		MD BUS D22 H
V\$2155	21		MD BUS D21 H
V\$2161	20		MD BUS D20 H
V\$2154	19	5	MD BUS D19 H
V\$2153	18		MD BUS D18 H
V\$2162	17		MD BUS D17 H
V\$2160	16		MD BUS D16 H
V\$2166	15	4	MD BUS D15 H
V\$2156	14		MD BUS D14 H
V\$2167	13		MD BUS D13 H
V\$2157	12		MD BUS D12 H
V\$2158	11	3	MD BUS D11 H
V\$2101	10		MD BUS D10 H
V\$2195	09		MD BUS D09 H
V\$2100	08		MD BUS D08 H
V\$2103	07	2	MD BUS D07 H
V\$2102	06		MD BUS D06 H
V\$2106	05		MD BUS D05 H
V\$2198	04		MD BUS D04 H
V\$2107	03	1	MD BUS D03 H
V\$2199	02		MD BUS D02 H
V\$2200	01		MD BUS D01 H
V\$2105	00		MD BUS D00 H

MEMREQ

V\$ symbol	Bit	Nibble	Signal name
V\$C171	25	7	MCC EBOX PA ACK A H
V\$C172	24		MCC OP PA ACK A H
V\$5167	23	6	MCC IBF PA ACK H
V\$C215	22		EBC EBD MAST RST DLY H
V\$C173	21		MCC DEST CODE 1 H
V\$C174	20		-EBD9 MEM REQ LST CYC H
V\$C193	19	5	MCC PORT STAT CODE 3 H
V\$C191	18		MCC PORT STAT CODE 2 H
V\$C190	17		MCC PORT STAT CODE 1 H
V\$C192	16		MCC PORT STAT CODE 0 H

CONSOLE SOFTWARE AND COMMANDS
Default Visibility Registers

V\$ symbol	Bit	Nibble	Signal name
V\$A180	15	4	ICA ISTALL A H
V\$A167	14		ICA IBF REQUEST H
V\$C231	13		MCC STAT CODE OUT 1 H
V\$C226	12		-CSB EBOX FORK A H
V\$A168	11	3	ICB OP MCF 3 H
V\$A179	10		ICB OP MCF 2 H
V\$A190	09		ICB OP MCF 1 H
V\$A186	08		ICB OP MCF 0 H
V\$A221	07	2	ICA OP ABORT A H
V\$A184	06		EBD ESTALL TO MCC H
V\$A153	05		EBC EBOX MCF 5 H
V\$A182	04		EBC EBOX MCF 4 H
V\$A174	03	1	EBC EBOX MCF 3 H
V\$A165	02		EBC EBOX MCF 2 H
V\$A164	01		EBC EBOX MCF 1 H
V\$A154	00		EBC EBOX MCF 0 H

MUPC

V\$ symbol	Bit	Nibble	Signal name
V\$A192	07	2	MCC1 UADR B 7 H
V\$A231	06		MCC1 UADR B 6 H
V\$A273	05		MCC1 UADR B 5 H
V\$A274	04		MCC1 UADR B 4 H
V\$A109	03	1	MCC1 UADR A 3 H
V\$A110	02		MCC1 UADR A 2 H
V\$A288	01		MCC1 UADR A 1 H
V\$A279	00		MCC1 UADR A 0 H

NATRAM

V\$ symbol	Bit	Nibble	Signal name
V\$3213	19	5	IBDC NAT CTX 2 H
V\$3217	18		IBDC NAT CTX 1 H
V\$3209	17		IBDC NAT CTX 0 H
V\$3112	16		IBDC NAT TYPE 1 H
V\$3183	15	4	IBDC NAT TYPE 0 H
V\$3167	14		IBDC NAT REF 1 H
V\$3182	13		IBDC NAT REF 0 H
V\$3210	12		IBDC NAT CTL 1 H
V\$3177	11	3	IBDC NAT CTL 0 H
V\$3208	10		IBDC NAT SUSPEND H
V\$3109	09		IBDC NAT BDEST NXT H
V\$3211	08		IBDC NAT LAST H
V\$3184	07	2	IBDB NAT OPAR H
V\$3101	06		IBDB NAT FPA H
V\$3180	05		IBDB NAT ADRS 05 H
V\$3103	04		IBDB NAT ADRS 04 H

CONSOLE SOFTWARE AND COMMANDS
Default Visibility Registers

V\$ symbol	Bit	Nibble	Signal name
V\$3278	03	1	IBDB NAT ADRS 03 H
V\$3102	02		IBDB NAT ADRS 02 H
V\$3108	01		IBDB NAT ADRS 01 H
V\$3100	00		IBDB NAT ADRS 00 H
OPAR			
V\$ symbol	Bit	Nibble	Signal name
V\$4278	37	10	ICA FORCE AMUX OPAR H
V\$4102	36		ICA FORCE BMUX OPAR H
V\$C144	35	9	EDP OPR PAR ERR H
V\$3184	34		IBDB NAT OPAR H
V\$3221	33		IBDD LAT OPAR H
V\$5170	32		ICA5 ICS OPAR H
V\$XXXX	31	8	Zero-Filler
V\$4206	30		-ICA EN OP OPAR VAL H
V\$8184	29		-IDP OP OPAR VALID H
V\$8191	28		IDP OP LWD OPAR H
V\$8154	27	7	EBE WBUS OPAR B3 A H
V\$8155	26		EBE WBUS OPAR B2 A H
V\$8153	25		EBE WBUS OPAR B1 A H
V\$8156	24		EBE WBUS OPAR B0 A H
V\$0186	23	6	EBE WBUS OPAR B3 C H
V\$0131	22		EBE WBUS OPAR B2 C H
V\$0129	21		EBE WBUS OPAR B1 C H
V\$0180	20		EBE WBUS OPAR B0 C H
V\$4205	19	5	EBE WBUS OPAR B3 B H
V\$4123	18		EBE WBUS OPAR B2 B H
V\$4210	17		EBE WBUS OPAR B1 B H
V\$4209	16		EBE WBUS OPAR B0 B H
V\$2126	15	4	-EBE WBUS OPAR B3 H
V\$2127	14		-EBE WBUS OPAR B2 H
V\$2125	13		-EBE WBUS OPAR B1 H
V\$2113	12		-EBE WBUS OPAR B0 H
V\$3153	11	3	MCD MD BUS OPAR B3 H
V\$3149	10		MCD MD BUS OPAR B2 H
V\$3152	09		MCD MD BUS OPAR B1 H
V\$3148	08		MCD MD BUS OPAR B0 H
V\$XXXX	07	2	formerly MCD MD BUS OPAR B3 H
V\$XXXX	06		formerly MCD MD BUS OPAR B2 H
V\$XXXX	05		formerly MCD MD BUS OPAR B1 H
V\$XXXX	04		formerly MCD MD BUS OPAR B0 H
V\$4101	03	1	IBD DBUS OPAR B3 H
V\$4104	02		IBD DBUS OPAR B2 H
V\$4140	01		IBD DBUS OPAR B1 H
V\$4100	00		IBD DBUS OPAR B0 H

CONSOLE SOFTWARE AND COMMANDS
Default Visibility Registers

OPBUS

V\$ symbol	Bit	Nibble	Signal name
V\$0178	31	8	OP BUS D31 H
V\$0174	30		OP BUS D30 H
V\$0148	29		OP BUS D29 H
V\$0106	28		OP BUS D28 H
V\$0203	27	7	OP BUS D27 H
V\$0260	26		OP BUS D26 H
V\$0153	25		OP BUS D25 H
V\$0232	24		OP BUS D24 H
V\$0202	23	6	OP BUS D23 H
V\$0261	22		OP BUS D22 H
V\$0149	21		OP BUS D21 H
V\$0228	20		OP BUS D20 H
V\$0285	19	5	OP BUS D19 H
V\$0172	18		OP BUS D18 H
V\$0154	17		OP BUS D17 H
V\$0229	16		OP BUS D16 H
V\$0295	15	4	OP BUS D15 H
V\$0198	14		OP BUS D14 H
V\$0344	13		OP BUS D13 H
V\$0289	12		OP BUS D12 H
V\$0301	11	3	OP BUS D11 H
V\$0300	10		OP BUS D10 H
V\$0293	09		OP BUS D09 H
V\$0271	08		OP BUS D08 H
V\$0286	07	2	OP BUS D07 H
V\$0274	06		OP BUS D06 H
V\$0103	05		OP BUS D05 H
V\$0275	04		OP BUS D04 H
V\$0179	03	1	OP BUS D03 H
V\$0264	02		OP BUS D02 H
V\$0152	01		OP BUS D01 H
V\$0233	00		OP BUS D00 H

OPCODE

V\$ symbol	Bit	Nibble	Signal name
V\$1101	07	2	ICA OPC BIT 7 A H
V\$1103	06		ICA OPC BIT 6 A H
V\$1238	05		ICA OPC BIT 5 A H
V\$1125	04		ICA OPC BIT 4 A H
V\$1240	03	1	ICA OPC BIT 3 A H
V\$1237	02		ICA OPC BIT 2 A H
V\$1141	01		ICA OPC BIT 1 A H
V\$1241	00		ICA OPC BIT 0 A H

CONSOLE SOFTWARE AND COMMANDS
Default Visibility Registers

OPMCF

V\$ symbol	Bit	Nibble	Signal name
V\$A168	03	1	ICB OP MCF 3 H
V\$A179	02		ICB OP MCF 2 H
V\$A190	01		ICB OP MCF 1 H
V\$A186	00		ICB OP MCF 0 H

OPPORT

V\$ symbol	Bit	Nibble	Signal name
V\$6186	63	16	ICA OPV CTL 0 H
V\$6190	62		ICA OPV CTL 1 H
V\$5149	61		-ICAG SET OPV FB H
V\$5141	60	15	-ICB SET OPV H
V\$6158	59		-ICB9 IMD OPV LAT H
V\$6154	58		-ICB9 PEND IMD OPV H
V\$XXXX	57		Zero-Filler
V\$XXXX	56	14	Zero-Filler
V\$C172	55		MCC OP PA ACK A H
V\$6127	54		MCC OP PA ACK B H
V\$XXXX	53		Zero-Filler
V\$XXXX	52	13	Zero-Filler
V\$0191	51		EBD OPBUS VALID H
V\$1206	50		-FBA OPBU VAL TO FBM H
V\$XXXX	49		Zero-Filler
V\$C212	48	12	-ICB ALWAYS OP VALID H
V\$C211	47		-ICB ALMOST OP VALID H
V\$6155	46		-ICB8 ALMOST SET OPV H
V\$XXXX	45		Zero-Filler
V\$A221	44	11	ICA OP ABORT A H
V\$C183	43		ICA OP ABORT B LAT H
V\$1120	42		ICA IBF OR OP FLUSH H
V\$A264	41		ICA MBOX FLUSH A H
V\$C188	40	10	-ICA OP FLUSH B H
V\$4206	39		-ICA EN OP OPAR VAL H
V\$8184	38		-IDP OP OPAR VALID H
V\$XXXX	37		Zero-Filler
V\$XXXX	36	9	Zero-Filler
V\$C201	35		ICB KILL OP WRT H
V\$E102	34		MCC NEXT OP WRT H
V\$E186	32		MCC TRAP OP WCHK H
V\$E135	31	8	MCC TRAP OP WRT H
V\$C176	30		-EBD9 EN OP WRT STALL H
V\$5254	29		-ICAG OP REQ CIP LAT H
V\$5148	28		ICB SET OP WRT CIP H
V\$6109	27	7	-ICBA OP WRT CIP H
V\$C213	26		-EBD9 OP WRT IN PROG H
V\$C148	25		-EBD9 OP WRT LST CYC H
V\$6134	24		-ICA OP WRT LAT H

CONSOLE SOFTWARE AND COMMANDS
Default Visibility Registers

V\$ symbol	Bit	Nibble	Signal name
V\$C170	23	6	-ICA EN OP WRT ACK H
V\$6165	22		-ICA ENA OP MD RESP H
V\$XXXX	21		Zero-Filler
V\$4147	20		-ICA IVA SEL OP VA H
V\$4176	19	5	-ICA ENA OP VA LD H
V\$5131	18		IDP OP VA BIT 00 H
V\$5241	17		IDP OP VA BIT 01 H
V\$A186	16		ICB OP MCF 0 H
V\$A190	15	4	ICB OP MCF 1 H
V\$A179	14		ICB OP MCF 2 H
V\$A168	13		ICB OP MCF 3 H
V\$XXXX	12		Zero-Filler
V\$A185	11	3	ICB OP MEM CTX 0 H
V\$A170	10		ICB OP MEM CTX 1 H
V\$A183	09		ICB OP MEM CTX 2 H
V\$3143	08		ICB OP MEM REQ H
V\$4148	07	2	ICB OP MEM REQ A H
V\$XXXX	06		Zero-Filler
V\$6182	05		-ICA SET FA OPMEM REQ H
V\$C117	04		ICB FA OP MEM REQ H
V\$XXXX	03	1	Zero-Filler
V\$4172	02		IDP5 IVA SEL OP VA A H
V\$4221	01		IDP5 IVA SEL OP VA B H
V\$4108	00		IDP5 IVA SEL OP VA C H

PAACK

V\$ symbol	Bit	Nibble	Signal name
V\$D167	06	2	-MCC EBOX PA ACK B H
V\$C171	05		MCC EBOX PA ACK A H
V\$6142	04		EBD EB PA ACK LTH H
V\$XXXX	03	1	Zero-Filler
V\$5167	02		MCC IBF PA ACK H
V\$C172	01		MCC OP PA ACK A H
V\$6127	00		MCC OP PA ACK B H

PAMD

V\$ symbol	Bit	Nibble	Signal name
V\$D167	23	6	-MCC EBOX PA ACK B H
V\$A184	22		EBD ESTALL TO MCC H
V\$C215	21		EBC EBD MAST RST DLY H
V\$A167	20		ICA IBF REQUEST H
V\$A264	19	5	ICA MBOX FLUSH A H
V\$A180	18		ICA ISTALL A H
V\$A221	17		ICA OP ABORT A H
V\$A277	16		ICA MBOX FLUSH B H

CONSOLE SOFTWARE AND COMMANDS
Default Visibility Registers

V\$ symbol	Bit	Nibble	Signal name
V\$A168	15	4	ICB OP MCF 3 H
V\$A179	14		ICB OP MCF 2 H
V\$A190	13		ICB OP MCF 1 H
V\$A186	12		ICB OP MCF 0 H
V\$C193	11	3	MCC PORT STAT CODE 3 H
V\$C191	10		MCC PORT STAT CODE 2 H
V\$C190	09		MCC PORT STAT CODE 1 H
V\$C192	08		MCC PORT STAT CODE 0 H
V\$C172	07	2	MCC OP PA ACK A H
V\$5167	06		MCC IBF PA ACK H
V\$A153	05		EBC EBOX MCF 5 H
V\$A182	04		EBC EBOX MCF 4 H
V\$A174	03	1	EBC EBOX MCF 3 H
V\$A165	02		EBC EBOX MCF 2 H
V\$A164	01		EBC EBOX MCF 1 H
V\$A154	00		EBC EBOX MCF 0 H

PAMM

V\$ symbol	Bit	Nibble	Signal name
V\$A212	04	2	MAP9 PAMM CONF A H
V\$A173	03		MAP9 PAMM CONF 8 H
V\$A172	02		MAP9 PAMM CONF 4 H
V\$A224	01		MAP9 PAMM CONF 2 H
V\$A216	00		MAP9 PAMM CONF 1 H

PARITY

V\$ symbol	Bit	Nibble	Signal name
V\$9170	65	17	EBD ECS PE FLAG H
V\$D158	64		EBD EDP PE FLAG A H
V\$9169	63	16	EBD EDP PE FLAG H
V\$9173	62		EBD EMCR PE FLAG H
V\$9174	61		EBD USTK PE FLAG H
V\$9143	60		EBD WBUS PE FLAG H
V\$XXXX	59	15	Zero-Filler
V\$XXXX	58		Zero-Filler
V\$XXXX	57		Zero-Filler
V\$9110	56		EBD ECS PE LST CYC H
V\$C219	55	14	-CSB ECS PAR ERR H
V\$E164	54		CSA PAR ERR H
V\$F104	53		CSAS CSA PAR H
V\$F124	52		-CSB CS PAR OK A H
V\$C142	51	13	CSB USTK PAR ERR H
V\$E140	50		-CSBR FLIP USTK PAR H
V\$E151	49		CSBS DATA PAR H
V\$C144	48		EDP OPR PAR ERR H

CONSOLE SOFTWARE AND COMMANDS
Default Visibility Registers

V\$ symbol	Bit	Nibble	Signal name
V\$C160	47	12	-EDP RESULT PAR ERR H
V\$8134	46		DISA BYTE 10 PAR H
V\$8165	45		EDPI DISA BYTE 32 PAR H
V\$8126	44		EDPI FLIP WREG PAR H
V\$9150	43	11	EBC FLIP WBUS PAR B0 H
V\$9149	42		ERC FLIP WBUS PAR B1 H
V\$9145	41		EBC FLIP WBUS PAR B2 H
V\$9144	40		EBC FLIP WBUS PAR B3 H
V\$XXXX	39	10	Zero-Filler
V\$C159	38		-EBC MCF RAM PAR ERR H
V\$D142	37		EBCA MCF PAR H
V\$D133	36		EBCH FLIP MCF RAM PAR H
V\$XXXX	35	9	Zero-Filler
V\$0240	34		FA17 GPR PPAR 00 H
V\$0241	33		FA17 GPR PPAR 01 H
V\$0122	32		FA17 GPR PPAR 02 H
V\$0121	31	8	FA19 UWD PARITY H
V\$0169	30		FBM CS PAR ERROR H
V\$0165	29		FBM FDRAM PAR ERROR H
V\$1275	28		FM16 UWD PARITY H
V\$XXXX	27	7	Zero-Filler
V\$6128	26		IBD BUF DRAM PE H
V\$6129	25		IBD BUF IBUF PE H
V\$4201	24		ICA FORCE GPR PE H
V\$6115	23	6	ICA FORCE RLOG PE H
V\$9179	22		ICA ICS PE H
V\$9181	21		ICB IBUF PE H
V\$9101	20		ICB IDRAM PE H
V\$9100	19	5	ICB RLOG PE H
V\$9176	18		IDP IAMUX PE H
V\$9182	17		IDP IBMUX PE H
V\$XXXX	16		Zero-Filler
V\$XXXX	15	4	Zero-Filler
V\$XXXX	14		Zero-Filler
V\$2165	13		MAP2 <29:4> PAR H
V\$XXXX	12		formerly MCC1 MMS PAR ERR H
V\$XXXX	11	3	formerly MCC2 ACCESS PAR H
V\$A118	10		MCCC U CPR PAR A H
V\$A126	09		MCCC U CPR PAR B H
V\$2109	08		MCCM INV CACH BYT PAR H
V\$A201	07	2	MCD3 ABUS DAT PERR H
V\$A251	06		-MCDU CACH DAT PERR H
V\$A250	05		-MCDU WR DAT PERR H
V\$A200	04		MAP2 ABUS ADR PERR H
V\$A204	03	1	MAPL TAG PERR H
V\$A202	02		MAPL TAG W PERR H
V\$A148	01		-MAPR TB PERR H
V\$9162	00		MCC MBOX CS PE H

CONSOLE SOFTWARE AND COMMANDS
Default Visibility Registers

PSL

V\$ symbol	Bit	Nibble	Signal name
V\$E117	20	6	EBE PSL CM TO CSB H
V\$C113	19	5	-EBE PSL TP H
V\$E112	18		EBD UTRAP VECTOR 4 H
V\$E152	17		EBE PSL IS TO CSB H
V\$A144	16		EBE CURMOD 1 TO MCC H
V\$A162	15	4	EBE CURMOD 0 TO MCC H
V\$XXXX	14		Zero-Filler
V\$XXXX	13		Zero-Filler
V\$D125	12		EBE PSL IPL 4 H
V\$D127	11	3	EBE PSL IPL 3 H
V\$D126	10		EBE PSL IPL 2 H
V\$D131	09		EBE PSL IPL 1 H
V\$D130	08		EBE PSL IPL 0 H
V\$XXXX	07	2	Zero-Filler
V\$XXXX	06		Zero-Filler
V\$C109	05		-EBE PSL IV TO EBD H
V\$XXXX	04		Zero-Filler
V\$9171	03	1	EDP PSL N BIT A H
V\$9172	02		EDP PSL Z BIT A H
V\$9168	01		EDP PSL V BIT A H
V\$9167	00		EDP PSL C BIT A H

REGBUS

V\$ symbol	Bit	Nibble	Signal name
V\$2205	07	2	REG BUS 7 H
V\$2203	06		REG BUS 6 H
V\$2227	05		REG BUS 5 H
V\$2226	04		REG BUS 4 H
V\$2224	03	1	REG BUS 3 H
V\$2225	02		REG BUS 2 H
V\$2204	01		REG BUS 1 H
V\$2223	00		REG BUS 0 H

STALL

V\$ symbol	Bit	Nibble	Signal name
V\$6202	28	8	ICA IFORK NOP H
V\$3189	27	7	ICA IFORK CYCLE H
V\$6185	26		ICA CTX UNALIGNED H
V\$5133	25		ICA6 UTRAP CTL 1 H
V\$5132	24		ICA6 UTRAP CTL 0 H
V\$A180	23	6	ICA ISTALL A H
V\$9107	22		ICA ISTALL B H
V\$C205	21		ICA ISTALL BUF A H
V\$6137	20		ICA ISTALL C H

CONSOLE SOFTWARE AND COMMANDS
Default Visibility Registers

V\$ symbol	Bit	Nibble	Signal name
V\$3197	19	5	ICA ISTALL D H
V\$4156	18		ICA ISTALL F H
V\$5196	17		-ICB ID FULL STALL H
V\$3190	16		ICA PC ISTALL A H
V\$9103	15	4	EBD RSV MODE H
V\$9100	14		ICB RLOG PE H
V\$5123	13		ICA7 ICS PAR ERR H
V\$9181	12		ICB IBUF PE H
V\$9101	11	3	ICB IDRAM PE H
V\$9176	10		IDP IAMUX PE H
V\$9182	09		IDP IBMUX PE H
V\$XXXX	08		Zero-Filler
V\$C172	07	2	MCC OP PA ACK A H
V\$6127	06		MCC OP PA ACK B H
V\$5167	05		MCC IBF PA ACK H
V\$9162	04		MCC MBOX CS PE H
V\$5221	03	1	EBD ESTALL TO ICA H
V\$5186	02		EBE IBOX ERR LTH A H
V\$9170	01		EBD ECS PE FLAG H
V\$9110	00		EBD ECS PE LST CYC H

UPCSAV

V\$ symbol	Bit	Nibble	Signal name
V\$E173	12	4	CSBQ UPCSARE 12 H
V\$E172	11	3	CSBQ UPCSARE 11 H
V\$E143	10		CSBQ UPCSARE 10 H
V\$E157	09		CSBQ UPCSARE 09 H
V\$E156	08		CSBQ UPCSARE 08 H
V\$E150	07	2	CSBQ UPCSARE 07 H
V\$E171	06		CSBQ UPCSARE 06 H
V\$E174	05		CSBQ UPCSARE 05 H
V\$E170	04		CSBQ UPCSARE 04 H
V\$E149	03	1	CSBQ UPCSARE 03 H
V\$E141	02		CSBP UPCSARE 02 H
V\$E142	01		CSBP UPCSARE 01 H
V\$E148	00		CSBP UPCSARE 00 H

CONSOLE SOFTWARE AND COMMANDS
Default Visibility Registers

WBUS

V\$ symbol	Bit	Nibble	Signal name
V\$4231	30		WBUS D30 H
V\$4227	29		WBUS D29 H
V\$4223	28		WBUS D28 H
V\$4107	27	7	WBUS D27 H
V\$4257	26		WBUS D26 H
V\$4271	25		WBUS D25 H
V\$4256	24		WBUS D24 H
V\$4251	23	6	WBUS D23 H
V\$4252	22		WBUS D22 H
V\$4266	21		WBUS D21 H
V\$4253	20		WBUS D20 H
V\$4157	19	5	WBUS D19 H
V\$4131	18		WBUS D18 H
V\$4127	17		WBUS D17 H
V\$4128	16		WBUS D16 H
V\$4247	15	4	WBUS D15 H
V\$4243	14		WBUS D14 H
V\$4244	13		WBUS D13 H
V\$4245	12		WBUS D12 H
V\$4122	11	3	WBUS D11 H
V\$4274	10		WBUS D10 H
V\$4276	09		WBUS D09 H
V\$4202	08		WBUS D08 H
V\$4184	07	2	WBUS D07 H
V\$4182	06		WBUS D06 H
V\$4158	05		WBUS D05 H
V\$4177	04		WBUS D04 H
V\$4194	03	1	WBUS D03 H
V\$4191	02		WBUS D02 H
V\$4178	01		WBUS D01 H
V\$4188	00		WBUS D00 H

CHAPTER 11

EBOX

11.1 WBUS

The WBus, or Write Bus, is used by the EBox, IBox, and FBox to write GPR/Scratch Pads, or to transfer result or operand data. Figure 11-2 shows how the GPR/SP registers receive WBus data and parity for each box. This figure also shows the print set location of where data is driven onto the WBus.

Figure 11-3 shows the WBus termination, and provides a closer look at the WBus drivers and receivers.

Table 11-1 lists the WBus pin location and VTERM for each of the WBus data bits. Table 11-2 shows the WBus pin location and VTERM for each of the WBus byte parity bits.






Figure 11-1 EBox Modules Block Diagram (Sheet 1 of 2)




8-13






**EBOX
WBUS**



MR-15810

Figure 11-3 WBus Physical Distribution (Sheet 1 of 2)



MR-15851

Figure 11-3 WBUS Physical Distribution
(Sheet 2 of 2)

EBOX
WBus Signal Pin Location

11.1.1 WBus Signal Pin Location

Table 11-1 WBus Signal Pin Location

Signal Name	WBUS D<31:00> A H			WBUS D<31:00> B H			
	EBE 9	FBA 8	VTERM	EBE 9	EDP 10	IDP 14	VTERM
WBUS D00	A09	A10	V\$0230	A10	A45	A15	V\$4188
WBUS D01	A63	A64	V\$0151	A64	A83	A21	V\$4178
WBUS D02	C05	C06	V\$0263	C06	C27	A25	V\$4191
WBUS D03	C57	C58	V\$0267	C58	C69	A31	V\$4194
WBUS D04	A11	A12	V\$0294	A12	A27	A45	V\$4177
WBUS D05	A65	A66	V\$0345	A66	A67	A53	V\$4158
WBUS D06	C07	C08	V\$0197	C08	C11	A63	V\$4182
WBUS D07	C59	C60	V\$0272	C60	C55	A7	V\$4184
WBUS D08	A17	A18	V\$0268	A18	A25	A47	V\$4202
WBUS D09	A75	A76	V\$0273	A76	A65	A57	V\$4276
WBUS D10	C11	C12	V\$0341	C12	C09	A67	V\$4274
WBUS D11	C63	C64	V\$0288	C64	C51	C75	V\$4122
WBUS D12	A19	A20	V\$0231	A20	A49	B09	V\$4245
WBUS D13	A7	B32	V\$0238	A78	A87	B15	V\$4244
WBUS D14	C39	C40	V\$0287	C40	C31	B21	V\$4243
WBUS D15	C69	C70	V\$0270	C70	C73	B31	V\$4247
WBUS D16	A45	A46	V\$0239	A46	A47	B45	V\$4128
WBUS D17	B49	A89	V\$0117	B52	A85	B57	V\$4127
WBUS D18	B53	C17	V\$0262	B54	C29	B69	V\$4131
WBUS D19	C73	C74	V\$0177	C74	C71	B77	V\$4157
WBUS D20	A53	A54	V\$0104	A54	A29	C09	V\$4253
WBUS D21	A83	A84	V\$0167	A84	A69	C19	V\$4266
WBUS D22	C41	C42	V\$0196	C42	C15	C25	V\$4252
WBUS D23	C77	C78	V\$0176	C78	C57	C35	V\$4251
WBUS D24	A55	A56	V\$0107	A56	A41	C07	V\$4256
WBUS D25	A85	A86	V\$0150	A86	A81	C17	V\$4271
WBUS D26	C45	C46	V\$0199	C46	C25	C27	V\$4257
WBUS D27	C85	C86	V\$0200	C86	C67	C37	V\$4107
WBUS D28	A59	A60	V\$0105	A60	A31	C45	V\$4223
WBUS D29	A87	A88	V\$0166	A88	A71	C53	V\$4227
WBUS D30	C51	C52	V\$0175	C52	C17	C65	V\$4231
WBUS D31	C87	C88	V\$0201	C88	C59	C77	V\$4232

Table 11-2 Distribution of WBus Byte Parity Signals

WBUS Signal Name	EBE 09	MCD 16	EDP 10	IDP 14	FBA 08	Vterm
-EBE WBUS OPAR B0 H	A52	B32				V\$2113
EBE WBUS OPAR B0 A H	A57		C78			V\$8157
EBE WBUS OPAR B0 B H	A68			A41		V\$4209
EBE WBUS OPAR B0 C H	A71				A75	V\$0180
-EBE WBUS OPAR B1 H	A62	B25				V\$2125
EBE WBUS OPAR B1 A H	A73		C89			V\$8154
EBE WBUS OPAR B1 B H	A69			A40		V\$4210
EBE WBUS OPAR B1 C H	A67				A85	V\$0129

Table 11-2 Distribution of WBus Byte Parity Signals (Cont.)

WBUS Signal Name	EBE	09	MCD	16	EDP	10	IDP	14	FBA	08	Vterm
-EBE WBUS OPAR B2 H	B07		B27								V\$2127
EBE WBUS OPAR B2 A H	B10				C85						V\$8156
EBE WBUS OPAR B2 B H	B18						A49				V\$4123
EBE WBUS OPAR B2 C H	B12								A83		V\$0131
-EBE WBUS OPAR B3 H	B04		B30								V\$2126
EBE WBUS OPAR B3 A H	B08				C80						V\$8155
EBE WBUS OPAR B3 B H	B15						A39				V\$4205
EBE WBUS OPAR B3 C H	B11								A57		V\$0186

NOTE

The defined visibility register "WBUS", 801A is the "B-side" of the WBUS (that is, terminated on the IDP module).

11.2 EBOX GPR/SCRATCH PAD USAGE

Table 11-3 shows the usage of EBox GPR Scratch Pad registers in the KA86. If a more detailed listing is needed, refer to DEF.MIC in the EBox microcode listing, KA8600.MCR or KA8650.MCR.

There are a total of 256 32-bit registers, with two copies of each to provide redundancy. If there is a parity error in the "A" set of the GPRs, the "B" set can be copied into the "A" set.

Table 11-3 EBox GPR/Scratch Pad Usage

Usage/Assignment		Scratch Pad Address(es) (EXAM/ESC)
General Purpose Registers	R0 - R11 AP FP SP	0 - 11 12 13 14
Temporaries	T0 - T1F	10 - 2F
Secondary Temps or Misc		30 - 3F
Constants		40 - AF
Block of Zeros		B0 - BF
CSM Registers		C0 - C8
Extra Temps		CA - CD
KA86 Status Registers		CF - DE
VAX Architectural Registers		E0 - EE
DSM Mnemonic names		EE - EF
Microcode Stack		F0 - FF

EBOX
EBOX MICROWORD

11.3 EBOX MICROWORD

A worksheet is provided for the EBox microword, followed by a description of the EBox microword. The physical bit numbers are determined by the RAM chips on the CSA and CSB boards. The logical bit position is the bit positions as they would be displayed for an E/ECS "Adrs" Console command.

11.3.1 EBox Control Store

ADDRESS (HEX)

--	--	--	--

DATA (HEX)

--	--	--	--	--	--	--	--

EBOX CONTROL STORE MICROWORD (UL0 FORMAT)
EXAMINE FROM CONSOLE >>>E/ECS ADDRESS

MICROWORD BITS <91 00>
CSA, CSB

										91	90	89	88	87	86	85	84	83	82	81	80	
										SPARE <05 00>					UCCSYN		UNODEST		UPAR <01 00>		UMISC <03 00>	
										05	04	03	02	01	00	00	00	01	00	03	02	

79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64
UMISC <03 00>		UDT <01 00>		UCCK <03 00>				UFBOX <01 00>		UMARK		UMCF <05 00>			
01	00	01	00	03	02	01	00	01	00	00	05	04	03	02	01

63	62	61	60	59	58	57	56	55	54	53	52	51	50	49	48
UMCF <05 00>		UDPSEL <01 00>		ULIT <05 00>				ULITCTL <01 00>		USCK <02 00>		UDEST <05 00>			
00	01	00	05	04	03	02	01	00	01	00	02	01	00	05	04

47	46	45	44	43	42	41	40	39	38	37	36	35	34	33	32
UDEST <05 00>				USRC2 <05 00>				USRC1 <07 00>							
03	02	01	00	05	04	03	02	01	00	07	06	05	04	03	02

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
USRC1 <07 00>		USMI		UVMOK <01 00>		UBMX		UAMX		UALU <04 00>				UBEN <04 00>	
01	00	00	01	00	00	00	04	03	02	01	00	04	03	02	01

15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
UBEN <04 00>		USUB <01 00>		UJUMP <12 00>											
00	01	00	12	11	10	09	08	07	06	05	04	03	02	01	00

Figure 11-4 EBox Control Store Microword Worksheet

EBox Control Store




Figure 11-5 EBox Microword <91:80>

SPARE FIELD

The SPARE field contains the free bits of the microword. There are 92 bits in each EBox microword. Currently, only 86 bits (microword <85:00>) are used to control the EBox and CPU.

UCCSYNC<00>

The MICRO CONDITION CODE SYNC field indicates that the PSL condition codes are valid. The IBox uses this field to know when it can use the condition codes for branching.

UNODEST

This field notifies the hardware that the EBox will request the WBus.

UPAR<01:00>

The MICRO PARITY field contains the parity for the microword. UPAR<1> and UPAR<0> cover mutually exclusive sets in the EBox microword.

UMISC<03:00>

The MICRO MISCELLANEOUS field provides those miscellaneous functions which do not require the assignment of an entire field for control.

UMISC															
0	1	0	2	0	1	0	0								
0	0	0	0	0											
0	0	0	0	1											
0	0	0	1	0											
0	0	0	1	1											
0	1	0	0	0											
0	1	0	0	1											
0	1	1	0	0											
0	1	1	1	0											
1	0	0	0	0											
1	0	0	1	0											
1	0	1	0	0											
1	0	1	1	0											
1	1	0	0	0											
1	1	0	1	0											
1	1	1	0	0											
1	1	1	1	0											
1	1	1	1	1											

EBOX

EBox Control Store




Figure 11-6 EBox Microword <79:64>

UDT<01:00>

The MICRO DATA TYPE field is the EBox data type specifier. The data type is used for EBox initiated memory references and condition code functions. If data type OCTA or QUAD is desired, the instruction dependent data type must be used.

UDT	
01001	
0 0	BYTE
0 1	WORD
1 0	LONG
1 1	USE INST DEPENDENT CONTEXT

UCCK <03:00>

The MICRO CONDITION CODE field controls loading of the PSL and microcondition codes. In the following condition code table, the values for ALU.x are a function of the ALU result in the current cycle and are independent of the UCC condition codes latched from a previous cycle.

UCCK		PSL.N	PSL.Z	PSL.V	PSL.C
0	0	0	ALU.N(UDT)	ALU.Z(UDT)	0
0	0	1	ALU.N(UDT)	ALU.Z(UDT)	NOT.ALU.Z(UDT)
0	0	1	PSL.N	PSL.Z	PSL.V
0	0	1	ALU.N(UDT) .XOR. ALU.V(UDT)	ALU.Z(UDT)	0
0	1	0	ALU.N(UDT)	ALU.Z(UDT)	0
0	1	0	ALU.N(UDT)	ALU.Z(UDT)	ALU.V(UDT)
0	1	1	ALU.N(UDT)	ALU.Z(UDT)	ALU.V(UDT)
0	1	1	PSL.N	PSL.Z	1
1	0	0	PSL.N	PSL.Z	NOT.ALU.Z(UDT)
1	0	0	PSL.N	PSL.Z	PSL.V
1	0	1	ALU.N(UDT)	ALU.Z(UDT)	ALU.V(UDT)
1	0	1	ALU.N(UDT)	ALU.Z(UDT)	PSL.V
1	0	1	AND. PSL.Z	PSL.V	PSL.C
1	1	0	LOAD THE BMX CONDITION CODES AND WREG<31> BRANCH		
1	1	0	LOAD THE UCC CONDITION CODES FROM ALU RESULTS		
1	1	1	LOAD ALL THE MICRO CONDITION CODES (BOTH UCC AND BMX)		
1	1	1	LOAD THE PSL CONDITION CODES FROM THE F-BOX		

UFBOX <01:00>

The MICRO FBOX field is used to control and synchronize EBox operations with the FBox.

UFBOX	
01100	
0 0	NOP
0 1	CPSTNC
1 0	TRAP
1 1	TRAP AND SYNC

UMARK<00>

The MICRO MARK field is used for setting breakpoints in the microcode to assist in micro program debug.

UMCF<05:00>

THE MICRO MEMORY CONTROL FUNCTION field specifies a memory function <05:00>, or a register select function <02:00>.

UMCF						
05	04	03	02	01	00	
0	0	0	0	0	0	READ.VA.SAV
0	0	0	0	0	1	READ.V18A.SAV (CLR.AL.INTR)
0	0	0	0	1	0	READ.E5A (CLR.TRX.INTR)
0	0	0	0	1	1	READ.ID
0	0	0	1	0	0	READ.CPC (CLR.TTX.INTR)
0	0	0	1	0	1	READ.T5A
0	0	0	1	1	0	
0	0	0	1	1	1	CLR.INTR.EN
0	0	1	0	0	0	
0	0	1	0	0	1	E.DISPATCH.I
0	0	1	0	1	0	FUNC.EC01
0	0	1	0	1	1	PROBE.READ
0	0	1	1	0	0	READ.FBOX.REG
0	0	1	1	0	1	READ.PTE.TAG
0	0	1	1	1	0	READ.PTE
0	0	1	1	1	1	SLEEP.CACHE
0	1	0	0	0	0	EC01
0	1	0	0	0	1	EC02
0	1	0	0	1	0	READ.DIAG.IOA
0	1	0	0	1	1	READ.V.UCHK
0	1	0	1	0	0	READ.EC01
0	1	0	1	0	1	READ.V.LOCK.UCHK
0	1	0	1	1	0	READ.V.UCHK.NOROT
0	1	0	1	1	1	READ.V.RCHK.NOROT
0	1	1	0	0	0	READ.V.SEC.REF
0	1	1	0	0	1	READ.V.NOPAGE
0	1	1	0	1	0	READ.P
0	1	1	0	1	1	READ.V.RCHK
0	1	1	1	0	0	READ.V.UCHK
0	1	1	1	0	1	REGQUEUE.IB.REF
0	1	1	1	1	0	REGQUEUE.EB.NEXT.REF
0	1	1	1	1	1	REGQUEUE.EB.TRAP.REF
1	0	0	0	0	0	STOP.OP.PORT
1	0	0	0	0	1	ENABLE.OP.PORT
1	0	0	0	1	0	CLEAR.SUSPEND.BIT
1	0	0	0	1	1	OP.WRITE
1	0	0	1	0	0	UTRAP.TO.IFORK
1	0	0	1	0	1	FLUSH.IB.IBUSHD.CPC
1	0	0	1	1	0	FLUSH.IB.IBUSHD.CPC
1	0	0	1	1	1	FLUSH.IB.CPC
1	0	1	0	0	0	EN.OP.WRITE.STALL
1	0	1	0	0	1	CLEAR.EB.STATUS
1	0	1	0	1	0	CLEAR.FBOX.ERR.REG
1	0	1	0	1	1	PROBE.WRITE
1	0	1	1	0	0	WRITE.FBOX.REG
1	0	1	1	0	1	CLEAR.T0.ENTRY
1	0	1	1	1	0	WRITE.PTE
1	0	1	1	1	1	CLEAR.CACHE
1	1	0	0	0	0	WRITE.END
1	1	0	0	0	1	EC03
1	1	0	0	1	0	WRITE.DIAG.IOA
1	1	0	0	1	1	WRITE.V.UCHK
1	1	0	1	0	0	WRITE.V.UCHK
1	1	0	1	0	1	WRITE.V.UNLOCK
1	1	0	1	1	0	WRITE.V.STRING.SEC.REF
1	1	0	1	1	1	WRITE.EC01
1	1	1	0	0	0	WRITE.V.SEC.REF
1	1	1	0	0	1	WRITE.V.NOPAGE
1	1	1	0	1	0	WRITE.P
1	1	1	0	1	1	WRITE.V.STRING
1	1	1	1	0	0	WRITE.V.UCHK
1	1	1	1	1	0	REGQUEUE.OP.IBF
1	1	1	1	1	1	REGQUEUE.OP.REF
1	1	1	1	1	1	REGQUEUE.OP.NOPAGE

EBOX EBox Control Store

EBOX CONTROL STORE MICROWORD (ULID FORMAT)														MICROWORD BITS <63:48> CSA CSB																	
EXAMINE FROM CONSOLE >>>E/ECS ADDRESS																															
63	62	61	60	59	58	57	56	55	54	53	52	51	50	49	48																
UMCF <05:00>		UOPSEL <01:00>		ULIT <05:00>										ULITCTL <01:00>		USCR <02:00>		UDEST <05:00>													
00		01 00		05 04		03 02		01 00		01 00		02 01 00				05 04															
29		33 32		40		41		42		43		88				89		90		91		45		46		47		36		37	
PHYSICAL BIT NUMBERS																															

Figure 11-7 EBox Microword <63:48>

UOPSEL<01:00>

The MICRO OPERAND SELECT field is used to control the source of data the IBox will transfer over the OP Bus.

UOPSEL	
0100	
0 0 1 0	REG SELECTED BY UREGSEL UMCF<2:0>
0 1 1 0	END
1 0 1 0	BYTE BUFFER (# OF BYTES SELECTED BY UMISC<1:0>)
1 1 1 0	OPERAND

ULIT<05:00>

The MICRO LITERAL field provides the values for each configuration of the ULITCTL field.

ULITCTL<01:00>

THE MICRO LITERAL CONTROL field controls the use of the MICRO LITERAL field.

ULITCTL/ULIT															
01000050403020100															
0 0 0 0 0 0 0 0 0 0	SHIFT AMX : AMX LEFT <SC> BITS														
0 0 0 0 0 1 X 0 0 0	PASS SC REGISTER														
0 0 0 0 1 1 X 0 0 0	PASS ALU (NO SHIFT)														
0 0 0 0 1 0 0 0 0 1	SHIFT ALU LEFT 1, INPUT VMK<31>														
0 0 0 0 1 0 0 0 1 0	SHIFT ALU RIGHT 2, INPUT 00														
0 0 0 0 1 X 0 0 1 1	SHIFT ALU RIGHT 1, INPUT 0														
0 0 0 0 1 0 0 1 0 1	SHIFT ALU LEFT 1, INPUT UCC.N														
0 0 0 0 1 0 0 1 1 0	SHIFT ALU RIGHT 2, INPUT 01														
0 0 0 0 1 X 0 1 1 1	SHIFT ALU RIGHT 1, INPUT 1														
0 0 0 0 1 1 0 0 0 1	SHIFT ALU LEFT 1, INPUT 0														
0 0 0 0 1 1 0 0 1 0	SHIFT ALU RIGHT 2, INPUT 10														
0 0 0 0 1 1 0 0 1 1	SHIFT ALU LEFT 1, INPUT 1														
0 0 0 0 1 1 0 1 0 1	SHIFT ALU RIGHT 2, INPUT 11														
0 0 1 1 0 0 0 0 0 0	RIBBLE SWAP (OR CVTEP)														
0 0 1 0 0 0 1 0 0 0	BYTE SWAP														
0 0 1 0 0 1 0 0 0 0	CVTPM														
0 0 1 1 0 0 0 0 0 0	F FORMAT PACK+														
0 0 1 1 0 0 1 0 0 0	F FORMAT PACK-														
0 1 1 X X X X X X X	USE ULIT FIELD AS SHIFT COUNT; ROTATE LEFT 0 THROUGH 63 PLACES														
1 0 1 X X X X X X X	USE THE ULIT FIELD<4:0> TO SELECT THE HARDWARE REGISTER TO BE WRITTEN OVER THE U BUS														
1 0 0 X X X X X X X	USE THE ULIT FIELD<4:0> TO SELECT THE HARDWARE REGISTER TO BE READ OVER THE U BUS														
1 1 0 X X X X X X X	USED FOR FBOX CONTROL IF ULIT<5>=0 THEN THE FBOX WILL ENABLE DATA ONTO THE UBUS (FBOX RESULT DATA)														
1 1 1 X X X X X X X	USED FOR FBOX CONTROL IF ULIT<5>=1 THEN EBOX WILL ENABLE DATA ON UBUS TO BE GIVEN TO FBOX (FBOX OPER DATA)														
1 1 1 X X X X X X X	IF UFBX FIELD EQUAL TO TRAP OR TRAP AND SYNC, THEN USE ULIT<4:0> AS NEW PC FOR FBOX MICRO SEQUENCER														

USCK<02:00>

The MICRO SHIFT COUNTER CONTROL field controls functions involving the SC and STATE registers. Incrementing or decrementing the SC, and loading the SC from the ULIT field affect shifting operations in the current cycle. Branch tests always use the value of the SC or STATE registers at the beginning of the cycle.

USCK			
0	2	1	0
0	0	0	DECREMENT SC REGISTER
0	0	1	INCREMENT SC REGISTER
0	1	0	LOAD SC FROM AR BUS
0	1	1	LOAD STATE FROM AR BUS
1	0	0	LOAD SC FROM NV1. OTHER BITS GET 0
1	0	1	LOAD SC FROM NV2. OTHER BITS UNAFFECTED
1	1	0	NOP
1	1	1	LOAD SC FROM ULIT<5:0>

EBOX EBox Control Store




Figure 11-9 EBox Microword <31:16>

SMI<00>

The START MACRO INSTRUCTION field is used to indicate the start of a new macroinstruction. It is asserted low in the first cycle of a macroinstruction, and deasserted at all other times.

UVMQK<01:00>

The MICRO VMQ REGISTER CONTROL field controls the loading and shifting of the VMQ register.

UVMQK	
0100	
0 0	HOLD
0 1	LOAD ALU RESULT
1 0	SHIFT LEFT 1, SHIFT IN ALU.C.31
1 1	SHIFT RIGHT 2, SHIFT IN ALU.K1:0

UBMX<00>

The MICRO B MULTIPLEXER field selects the scratchpad location addressed by RB if "0" or the OP Bus (if "1") as the B input to the ALU.

UAMX<00>

The MICRO A MULTIPLEXER field selects the scratchpad location addressed by RA if "0" or VMQ (if "1") as the A input to the ALU.

UALU<04:00>

The MICRO ARITHMETIC LOGIC UNIT field specifies any one of 32 arithmetic or logic operations for the ALU.

UALU					CARRY/BORROW	
04	03	02	01	00	OPERATION	
LOGICAL						
0	0	0	0	0	A.AND.B	X
0	0	0	0	1	A.XOR.B	X
0	0	0	1	0	B	X
0	0	0	1	1	A.OR.B	X
0	0	1	0	0	A.AND.(NOT.B)	X
0	0	1	0	1	A	X
0	0	1	1	1	(NOT.A).AND.B	X
ARITHMETIC						
0	0	1	1	0	DIVIDE A÷B	UCC.C=0/1
0	1	0	0	0	A++	+0
0	1	0	0	1	A--	-0
0	1	0	1	0	A+B CORRECT (BCD)	
0	1	0	1	1	LOAD CONFIG	
0	1	1	0	0	A-B	-1
0	1	1	0	1	A-B	-0
0	1	1	1	0	A-B	- NOT UCC.C
0	1	1	1	1	A-B	-PSL.C
1	0	0	0	0	A+B	+0
1	0	0	0	1	A+B	+1
1	0	0	1	0	A+B	+UCC.C
1	0	0	1	1	A+B	+PSL.C
1	0	1	0	0	B-A	-1
1	0	1	0	1	B-A	-0
1	0	1	1	0	B-A	- NOT UCC.C
1	0	1	1	1	B-A	-PSL.C
1	1	0	0	0	A+B (BCD)	+0
1	1	0	0	1	A+B (BCD)	+1
1	1	0	1	0	A+B (BCD)	+UCC.C
1	1	0	1	1	A+B (BCD)	+PSL.C
1	1	1	0	0	A-B (BCD)	-1
1	1	1	0	1	A-B (BCD)	-0
1	1	1	1	0	A-B (BCD)	- NOT UCC.C
1	1	1	1	1	A-B (BCD)	-PSL.C

EBOX EBox Control Store




Figure 11-10 EBox Microword <15:00>

UBEN<04:00>

The MICRO BRANCH ENABLE field specifies one of 23 possible branch enable functions. Each branch enable can provide an 8-way branch. The results are ORed into the three low-order bits of the next UPC.

UBEN	UPC <2>	UPC <1>	UPC <0>
0 0 0 0 0 0	UCC.N	UCC.2	UCC.C
0 0 0 0 0 1	UCC.1	UCC.2	UCC.C
0 0 0 0 1 0	DIAG1	UCC.2	DIAG0
0 0 0 0 1 1	B.RAM.PE	0	B.RAM.PE
0 0 0 1 0 0	SC.EQ.0	0	UCC.C
0 0 0 1 0 1	PSL.N	PSL.2	PSL.C
0 0 0 1 1 0	ISA.VALID	ISA.VALID	UWAIT0.DONE
0 0 0 1 1 1	OPCODE2	OPCODE1	OPCODE0
0 0 1 0 0 0	OPCODE4	UCC.N	EXT.OPCODE
0 1 0 0 0 0	STATE2	UCC.N	DECIMAL.SIGN
0 1 0 0 0 1	IBUF.VA	NEXT.EB.VALID	TRAP.OP.WCHK
0 1 0 0 1 0	SC.EQ.0	VMD1	VMD0
0 1 0 0 1 1	PSL.IS	PSL.FPD	KERNEL
0 1 0 1 0 0	CPC.VALID	PSL.CH	INTERRUPT
0 1 0 1 0 1	STATE2	STATE1	STATE0
0 1 0 1 1 0	STATE5	STATE4	STATE3
0 1 0 1 1 1	STATE7	STATE6	WREG31
1 0 0 0 0 0	TRAP.EB.WCHK	YS.CHECK1	YS.CHECK0
1 0 0 0 0 1	VMD1	VMD0	PSL.V
1 0 0 0 1 0	SC.EQ.0	UCC.2	30.LE.BMX.LE.39
1 0 0 0 1 1	BPM15	UCC.2	FL.EXP#0
1 0 0 1 0 0	FBOX2	FBOX CARRY	FBOX ENABLED
1 0 0 1 0 1	TRAP.EB.WRITE	NEXT.EB.WRITE	TRAP.EB.WORD.OR.BYTE
1 0 0 1 1 0	TRAP.OP.WRITE		NEXT.OP.WR
1 0 0 1 1 1			
1 0 1 0 0 0			
1 0 1 0 0 1			
1 0 1 0 1 0			
1 0 1 0 1 1			
1 0 1 1 0 0			
1 0 1 1 0 1			
1 0 1 1 1 0			
1 0 1 1 1 1			
1 1 0 0 0 0			
1 1 0 0 0 1			
1 1 0 0 1 0			
1 1 0 0 1 1			
1 1 0 1 0 0			
1 1 0 1 0 1			
1 1 0 1 1 0			
1 1 0 1 1 1			
1 1 1 0 0 0			
1 1 1 0 0 1			
1 1 1 0 1 0			
1 1 1 0 1 1			
1 1 1 1 0 0			
1 1 1 1 0 1			
1 1 1 1 1 0			
1 1 1 1 1 1			

== GENERATES THE SIGNAL IRO

USUB<01:00>

The MICROSEQUENCER CONTROL field specifies how the UPC will be formed.

USUB
0 0 JUMP
0 1 RETURN
1 0 FORK
1 1 CALL SUB.

UJUMP <12:00>

The MICRO JUMP field generally specifies the next microaddress. Depending on the USUB field content, there are other components that get ORed with the UJUMP field to produce the actual microaddress.

11.3.2 EBox Context

The Context RAMs are loaded by the console over the SDB, and contain native mode instruction dependent contexts. Figure 11-11 shows the format of the Context RAM microword. Table 11-4 lists the bit description for the context RAM.




Figure 11-11 EBox Context (CTX) Microword Worksheet

Table 11-4 Context <3:0>

0	= Byte
2	= Longword
3	= Quadword
4	= Octaword
9	= Word

11.3.3 Memory Control Function (MCF)

The MCF RAMs provide a lookup table to decode the EBox MCF microcode field. The RAMs are addressed by the uMCF field, and are loaded and verified by the Console over the SDB. The decodes provide various control functions throughout the EBox. Figure 11-12 shows the layout of the MCF microword, and Table 11-5 contains the bit descriptions for the MCF RAM microwords




Figure 11-12 MCF Microword Worksheet

Table 11-5 MCF Microword Bit Description

-
1. <15> WRITE CHECK - This bit is asserted if the uMCF field specifies a memory command for which write access checking is performed.
 2. <14> -ACK REQ - The default for this bit is no ACK REQ. It will be asserted (low) for those encodings of the uMCF field for which EBox PA ACK is expected from the MBox.
 3. <13> EN MBox - This bit will be set for any uMCF that provokes MBox activity.
 4. <12> MCF PAR - Odd parity over MCR RAM field.
 5. <11> -LOAD NEXT REQ - Asserted (low) for those uMCF commands which must be loaded into the Next Register.
 6. <10> -LOAD TRAP REQ - This bit is asserted (low) for those uMCF commands which must be loaded into the Trap Register.
 7. <09> -REQUEUE NEXT REF - This bit is asserted (low) if the EBox uMCF field specifies the Requeue EBox Port Next Reference function.
 8. <08> -REQUEUE TRAP REF - Another low asserted bit, -REQUEUE TRAP REF will be asserted if the uMCF field specifies the REQUEUE EBox Port Trapped Reference function.
 9. <07> -CLR IB PS - This bit will be asserted (low) during the Requeue Instruction Buffer Port Reference or Requeue Operand Port Reference (on behalf of IBuffer) to reset the memory port status code for the IBuffer port.
 10. <06> -CLR OP PS - This bit will be asserted (low) if the uMCF field specifies the Requeue Operand Port Reference or Requeue Operand Port Reference with No Cross Page Boundary Checking to reset the OP PORT port status.
 11. <05> -CLR EB PS - This bit is asserted (low) if the uMCF field specifies the Clear EBox Port Status function to reset the EBox Port status latches.
 12. <04> E DISP I - This signal is asserted if the uMCF field specifies the EBox Dispatch IBox function. This function is used by diagnostic microcode to test the IBox. The IBox will dispatch its microcode based on the contents of the EBox uMCF in the microinstruction following the microinstruction that has a uMCF equal to E DISP I.
 13. <03> -MEM REQ - This bit is asserted (low) for those encodings of the uMCF for which both EBox PA ACK and EB MD RESP are expected from the MBox.
 14. <02> MEM WRT - If -MEM REQ is asserted, this bit will be set for those uMCF encodings that are OP PORT memory write commands.
 15. <01> -OP WRT - This bit is asserted (low) if the uMCF field specifies the Operand Port Write Function.
 16. <00> EN OP WRT STL - This signal is asserted if the uMCF field specifies the Operand Port Write function or the Enable Operand Port Write Stall function.
-

11.4 EBOX MICROTRAP VECTOR ASSIGNMENTS

The EBox Microtrap Vector assignments are listed in Table 11-6.

Table 11-6 EBox Microtrap Vectors

Vector	Microtrap Condition	Action
02	FBox Problem	The FBox service routine determines if an FBox hardware error occurred and if so, sets the request for FBox service in EHM.STS, then it passes control to EHM.
04	MBox Error Register	The MBox interrupts the EBox when it latches the MBox error address register and wants it saved. EHM reads the register and places it in scratchpad MEAR.SAV, calls interrupt code, then rolls back pending instructions and restarts at PC interrupted.
06	Interrupt	Interrupt requests are filtered by EBox hardware and the request with highest priority is latched in CSLINT and a microtrap to interrupt microcode is generated. If the IPL is 1D then the MBox has latched an error. Interrupt microcode notices this fact and sets EHM.STS <07>, the MBox service request and branches to EHM.
08	EBox Hardware Error	When the EBox detects a hardware error, it latches the reason in EDPE and EBCS and generates a microtrap at vector 8.
08	MBox TB Error	When the MBox detects a problem with the TB during EBox port requests it reports the event with a Port Status Code = 8 and destination code = 2. The error is serviced by EHM.
08	MBox Fatal Error	Errors which cause unpredictable results in the MBox for any type of request are reported to the EBox the same as EBox errors are reported.
10	IBox Hardware Error	An IBox hardware error is latched in the IBE and the IBox stalls. ORed IBox errors form an IBox microtrap request, if E ENA is set. Ebox hardware services the request when it finishes current execution and attempts to get operands from the IBox (fork).

EBOX
EBOX MICROTRAP VECTOR ASSIGNMENTS

11 - 17 MBox TB Error	If the MBox returns an OP PORT status code of other than no problem for a memory request issued by the OP PORT, the microtrap vector will be in the range of 11 - 17, with the least significant bits being supplied by the least significant bits of the OP PORT status latches.
18 IBox Hardware Error	When IBF PE, DRAM PE, or R-MODE PE is detected, the IBox stalls the IBUF PORT, and sends the error flags to the EBox where they are latched in IBE. If a flush command is executed before the EBox forks for an operand, the error will be cleared. Otherwise, it will be reported through this vector.
19 - 1F MBox TB Error	If the MBox returns an IBUF PORT status code of other than no problem for a memory request issued by the IBUF PORT, the microtrap vector will be in the range of 19 - 1F. The least significant bits of the vector will be provided by the least significant bits of the IBUF PORT status latches.
1E IBox Sync	After the EBox flushes and starts the IBUFF, it stalls until the CPC is valid. CPC VALID indicates that a new macro instruction is being processed. If an IBox error occurs which inhibits loading of CPC, a microtrap will be generated through this vector.
1F Unwind Rlog	If an IBox error occurs during the RLog Unwind command it will be reported through this vector.

11.5 EHM FATAL ERROR LOOPS

When EHM detects a condition which it can't handle or report to another part of microcode, it branches to a sunset loop and waits for the console to detect a Keep Alive Ceased condition. Console software checks for the micro PC's in Table 11-7 and if found, reports a corresponding message to describe the KAF.

Table 11-7 EHM Fatal Error Loops

EBox uPC	Reason
20	RAM A and RAM B parity error in the same cycle
21	Multiple EBox errors (two errors detected at EHM entry vector 8)

11.6 CONSOLE SUPPORT MICROCODE (CSM)

CSM utilizes a 32 location section of EBox microcode (addresses 1080 - 109F) for the execution of console commands. When required, the console will load the appropriate routine into the the ECS/CSM overlay region, then pass control to CSM to execute the routine.

CSM.MIC contains the resident CSM source code and overlay (non-resident) area. CSM.MIC can be found in KA8600.MCR or KA8650.MCR, and contains:

1. DC022 read and write subroutines
2. Packet read and write subroutines
3. Command and response read and write subroutines
4. Certain resident entry points
5. Command fetch, checksum calculation microcode
6. Console wait loop

Table 11-8 lists the special CSM microaddresses, and Table 11-9 lists the CSM overlays.

Table 11-8 Special CSM Microaddresses

Address	Contents
1080	The start of the non-resident section
1081	The restart address of the Find_64 Kb and Find_RPB procedures
1087	The jump-dots used to tell the console that certain special commands have finished (e.g., the end or power-on part #1)
0E30	The start of the Compatibility Mode microcode
1005	The microaddress to send a 1-packet response
1000	The microaddress to send a 2-packet response
1001	The microaddress to start housekeeping after having loaded CSM.STATUS
1A7C	The entry into REI microcode, used by the IRD command
04C2	The start address of CSM.CNSL_READ
0041	The start address of CSM.CNSL_WRITE
04D0	The start address of EHM.MREG.RW, needed for some CSM commands
0040	The start address of PR.INVALIDATE.TB
0042	The start address of MTRP.CACHE.SWEEP
0044	The start address of READ.FBOX.REG
0047	The start address of FBOX.RESET.0
0048	The start address of REQUEST.SOFTWARE.INTRPT
0265	The start address of GET.PTE.SUBROUTINE
0279	The start address of GTE.PTE.2
09C2	The start address of MTPR.TODR.SUB
09C4	The start address of MTPR.CSL.WRITE
09C8	The start address of MTPR.CSL.WRITE.1

Table 11-9 CSM Overlays

CSM001	Read IPR Group 0 [KSP, ESP, SSP, USP, ISP, POBR, POLR, PCBB, PlBR, PlLR, SCBB, SBR, SLR]
CSM002	IRD
CSM003	Continue Microflow
CSM004	Examine Ebox Scratchpad Register
CSM005	Examine Ebox Misc. Register [SPADR, STATE, IBGPR]
CSM006	Examine Ibox Misc. Register [EMD, VA.SAV, VIBA.SAV, CPC, ISA, ESA, VPCBITS]
CSM007	Deposit Ebox Scratchpad Register
CSM008	Deposit Ebox Misc. Register [SPADR, STATE]
CSM009	Examine Physical CPU Memory
CSM010	Flush Ibox and Loop
CSM011	Deposit Physical CPU Memory
CSM012	Translate Test Virtual Read
CSM013	Find 64kb
CSM014	Read Internal Mbox Register
CSM015	Read Internal Ebox Register [CSLINT, PSL, EDPSR, IBE, EBCS, EDMS]
CSM016	Write Internal Mbox Register
CSM017	Write Internal Ebox Register [CSLINT, PSL, EDMC, EBCS]
CSM018	Clear Internal Mbox Register
CSM019	Translate Test Virtual Write
CSM020	Examine PAMM Location
CSM021	Flush IBOX (and do not loop)
CSM022	Access IOA
CSM023	Find RPB
CSM024	Examine PC
CSM025	Read IPR Group 1 [IPL, ASTLV, TODR, SISR, ICR, EHSR, ICCS, PAMLOC, SID, CSWP]
CSM026	Read IPR Group 2 [RXCS, MAPEN, PMR, TXCS, RXDB]
CSM027	Read IPR Group 3 [STXCS, PAMACC, ACCS, ESPD, STXDB]
CSM028	Write IPR Group 0 [KSP, ESP, SSP, USP, ISP, POBR, POLR, PCBB, PlBR, PlLR, SCBB, SBR, SLR]
CSM029	Write IPR Group 1 [IPL, ASTLV, SISR, SISR, NICR, ICCS]
CSM030	Write IPR Group 2 [RXCS, DFI, EHSR, PAMLOC, TXCS, PAMACC, TXDB, PMR, ACCS]
CSM031	Write IPR Group 3 [MAPEN, TBIA, TBIS, TBCHK, CSWP, CRBT]
CSM032	Write IPR Group 4 [STXCS, STXDB, ESPA, ESPD]
CSM033	Read IPR Group 4 [MDECC, MENA, MDCTL, MCCTL, MERG]
CSM034	Write IPR Group 5 [MDECC, MENA, MDCTL, MCCTL, MERG]
CSM035	Write IPR Group 6 [TODR, TXCS]
CSM036	Clear Main memory
CSM037	RESERVED FOR FUTURE GROWTH
CSM038	RESERVED FOR FUTURE GROWTH
CSM039	RESERVED FOR FUTURE GROWTH
CSM040	CSM.ENTRY.PO PART 1
CSM041	CSM.ENTRY.PO PART 2
CSM042	CSM.ENTRY.MICRO
CSM043	(formerly CSMY21) Flush Ibox and IRD without NOPs

NOTE

To determine which CSM overlay was last loaded,
use the following procedure:

1. Determine the T11 memory address where the overlay number is stored using the SHOW VERSION console command.
2. Examine the T11 address using the EXAM console command.

3. Convert the octal value to decimal to determine the CSM overlay loaded.

Example 11-1 Determining which CSM overlay was loaded

1. >>>>SHOW VERSION
CSMOVN:013251
2. >>>>E/U/B %013251 ;USE %O TO SPECIFY OCTAL
U 013251 000017
3. 17 (octal) = 15 decimal, therefore the last CSM overlay loaded was CSM015.BPN

11.7 EBOX MICROCODE LOCATIONS/REGIONS

Table 11-10 contains a list of EBox microcode locations/regions.

Table 11-10 EBox Microcode Locations/Regions

Address	Contents
0001	Integer overflow trap after IRD
0007	Trace trap entry point
000A	EBox TB miss routine
000B	Memory management faults (Access violation or translation not valid)
000C	M-Bit not set for EBox references
000E	EBox page boundary crossing
000F	Unaligned reference traps
0012	OP PORT TB miss routine
0014	M-Bit not set for OP PORT references
0015	Retry OP PORT write and OP PORT I/O read (combined)
0016	Page boundary crossing in OP PORT
001A	IBUF TB miss routine
001D	IBUF read from I/O space
0040	Invalidate TB routine
0265	Routine to fetch PTE from Page Tables
1800-18FF	Native mode C and D Forks
1A00-1AFF	Native mode B Fork
1B00-1BFF	Native mode A Fork
1C00-1FFF	User microcode (WCS)

EBOX
EBOX UPC TESTPOINTS

11.8 EBOX UPC TESTPOINTS

Table 11-11, a list of the EBox UPC backplane pins, may be used for scoping or used with a logic analyzer. For triggering, use "CLOCK5 141 D H" and enable with "LD ENA L".

Table 11-11 EBox Micro PC Testpoints

Channel	Signal Name	Print	Section/Slot/Pin
0	EUPC 00 H	CSB	A03.68
1	EUPC 01 H	CSB	C03.06
2	EUPC 02 H	CSB	C03.42
3	EUPC 03 H	CSB	B03.03
4	EUPC 04 H	CSB	B03.48
5	EUPC 05 H	CSB	B03.10
6	EUPC 06 H	CSB	B03.56
7	EUPC 07 H	CSB	B03.06
8	EUPC 08 H	CSB	B03.53
9	EUPC 09 H	CSB	B03.08
A	EUPC 10 H	CSB	B03.54
B	EUPC 11 H	CSB	B03.04
C	EUPC 12 H	CSB	B03.49
CQ	LD ENA L	CSB	A03.94
CLK	CLOCK5 141D H	CSB	B03.44
MARK	EBOX MARK H	CSA	C03.63 or B11.45

CHAPTER 12

FBOX






Figure 12-1 FBox Basic Block Diagram

MR-14812



MR-12741

Figure 12-2 FBox Block Diagram



USEL RA<2:0>

This field selects the scratchpad or GPR address, and has the following encoding:

- 0 = base address (30) for scratchpad locations 30 - 3F
- 1 = base address (20) for scratchpad locations 20 - 2F
- 2 = base address (10) for scratchpad locations 10 - 1F
- 3 = base address (00) for GPRs in locations 00 - 0F
- 4 = GPR/SP address = GPR/SP address +1
- 5 = hold the GPR/SP address
- 6 = GPR address from IBox for optimized instruction
- 7 = GPR address = previous address +1 if OPBus is valid,
otherwise GPR address = previous GPR address

UDRTY<1:0>

This field controls DATA READY, DATA REQUEST, and holding the SOPC latch. The field has the following encoding:

- 0 = NO OP
- 1 = At T3 assert DATA RDY. At T1 hold SOPC
- 2 = At T3 predict DATA RDY for F-format, else, if in range
assert DATA RDY. At T1, clock the conditions in the FBR
- 3 = At T3 assert DATA REQUEST

UPAR<0>

This bit reflects the microword parity, and has the following encoding:

- 0 = microword has odd parity, parity bit is reset
- 1 = microword has even parity, parity bit is set

UEALU<4:0>

This field controls the FXP, GXP, and FBR. The following field encoding specifies the related macro definitions:

- | | |
|--------------------|----------------------------|
| 00 = COMP.SIGN | 10 = SPARE 4 |
| 01 = GXP DIFF | 11 = SUBG XOPA - XOPB |
| 02 = SPARE 3 | 12 = ALIGN ADD GXP |
| 03 = FXP DIFF | 13 = SPARE 2 |
| 04 = LOAD EXP | 14 = CLOCK SELF TEST ERROR |
| 05 = WBUX -> XOPA | 15 = SET DIVIDE BY 0 |
| 06 = WBUS + 1 | 16 = SUM AND LOAD BIAS |
| 07 = CLR EXP | 17 = SUB AND LOAD BIAS |
| 08 = LD BYT NORM | 18 = DIVIDE ADJ EXPONENTS |
| 09 = CLR XOPB | 19 = MUL.ADJ EXPONENTS |
| 0A = CLR XOPA | 1A = ADJ ADD FXP |
| 0B = HOLD EXPS | 1B = SPARE 1 |
| 0C = WBUS -> XOPB | 1C = SAVE EXPS |
| 0D = LOAD 32 | 1D = SUBF XOPA - XOPB |
| 0E = LD BIT NORM | 1E = CLK EXCEPTS |
| 0F = LD 80 -> XOPB | 1F = NORM EXPS |

FBOX
FBox Adder (FBA) Microcode

UFADROTK<2:0>

This field specifies loading of the latch that controls the bit rotator. The field has the following encoding:

- 0 = DIVIDE, set up for a rotate 1
- 1 = HOLD, do not change the content of the BIT ROT latches
- 2 = UNDEFINED, not used
- 3 = UNDEFINED, not used
- 4 = NO ROTATE, do not rotate
- 5 = NORM, load bit normalize count
- 6 = ALIGN, load bit alignment count
- 7 = DIVIDE UNPACK, load 7 (F or D - format) or 2 (G-format) for divide unpack

UFADSIG<0>

This field defines the operand significance for addition or subtraction. The field has the following encoding:

- 0 = data being processed by fraction adder is of low significance
- 1 = data being processed by fraction adder is of high significance




Figure 12-6 FBA Microword <31:16>

UFADK<1:0>

This field controls the fraction adder, and has the following encoding:

- 0 = ADD, add A + B
- 1 = OPCODE, add or subtract A+B depending on op code and op code sign
- 2 = DIV, add or subtract A/B depending on previous quotient bit
- 3 = SUBT, subtract A - B

UBSIDE<1:0>

This field controls the AUGL, and has the following encoding:

- 0 = load FAD, clear EXT
- 1 = load BYT ROT, ROT and BSMX potentially unpacked, aligned, or normalized
- 2 = ZERO, clear
- 3 = HOLD

USHFTX<0>

This field controls loading the FARA and FMRB and the input to the SHFTX MUX, and has the following macro definition encoding:

- 0 = READ.FMRB
- 1 = LOAD.ADDL

USOPK<1:0>

This field selects the inputs to the source operand muxs, and has the following macro definition encoding:

- 0 = FARA.OPBUS
- 1 = WBUS.FARA
- 2 = OPBUS.OPBUS
- 3 = GPRBUS.OPBUS

UFARAK<1:0>

This field controls loading of the FARA, and has the following macro definition encoding:

- 0 = LOAD.H.G, load the packed high bits of G-format: load FARA <31:00>. GROVER will rotate FARA output left 4 bits.
- 1 = LOAD.H.DF, load the packed high bits of F/D-format: load FARA <31:00>. GROVER will rotate FARA output left 8 bits.
- 2 = LOAD.L.G, if the previous FARA was 0, load the packed low bits of G-format, load FARA<31:00>. GROVER will rotate the FARA output left 4 bits.

LOAD.L.DF, if the previous FARA was 1, load the packed low bits of F/D-format, load FARA<31:08> GROVER will rotate FARA output left 8 bits.
- LOAD.NOROT, if the previous FARA was 2, load FARA <31:08>. GROVER will rotate FARA output left 8 bits.
- 3 = HOLD, hold FARA.

FBOX
FBox Adder (FBA) Microcode

UALNSIG<00>

This field determines the significance of operands for alignment, and has the following encoding:

- 0 = process low-order bits
- 1 = process high-order bits

UAUXK<1:0>

This field CONTROLS THE AUXA and AUXD latches, and has the following macro definition encoding:

- 0 = HOLD
- 1 = LOAD.AUXA
- 2 = LOAD.AUXD
- 3 = LOAD.AUXA.AUXD

UROT<2:0>

This field controls the AMX/BMX inputs and the BSIDE byte rotator, and has the following macro definition encoding:

- 0 = INPUT.A.B
- 1 = INPUT.B.A
- 2 = ALN.LD.CNT
- 3 = ALN HOLD.CNT
- 4 = DATA.A.B
- 5 = DATA.B.A
- 6 = DATA.A.B.NRM
- 7 = NORM

UKHMX<0>

This bit generates the K input to the AHMX, and has the following macro definition encoding:

- 0 = K.ZERO, generate zero for AHMX.K
- 1 = K.RND.DT, generate a rounding constant dependent on the data type for AHMX.K




Figure 12-7 FBA Microword <15:00>

UHMx<2:0>

This field enables the hidden-bit MUXs, and has the following macro definition encoding:

- 0 = K.BERT
- 1 = K.AUXD
- 2 = BERT.0
- 3 = BERT.WRTL
- 4 = AUX.AUXD
- 5 = AUX.AUXD
- 6 = AUX.AUXD
- 7 = AUX.WRTL

UBEN<3:0>

This field enables modifying the UJUMP field, and has the following macro definition encoding:

- 0 = IRD and DATA IN
- 1 = PREDICT.NORM.RESP
- 2 = ED.INFO
- 3 = not used
- 4 = FAD.ZERO
- 5 = MUL.SYNC
- 6 = DATA SYNC
- 7 = DATA.IN
- 8 = EXP.ZERO
- 9 = OPVAL and EXP.DIFF
- A = not used
- B = EXP.DIFF <64
- C = OPC.SS
- D = RETURN
- E = CALL
- F = NOP

UJUMP<8:0>

This field generally defines the next micro address, but may be modified by the UBEN field which is ORed into it.

FBOX
FBox Multiplier (FBM) Microcode

12.1.2 FBox Multiplier (FBM) Microcode

ADDRESS (HEX)

--	--	--	--

DATA (HEX)

--	--	--	--	--	--	--	--	--	--

FBOX MULTIPLIER (FBM) MICROWORD (ULB FORMAT)
EXAMINE FROM CONSOLE >>>E'FBMCS ADDRESS

MICROWORD BITS <39:00>
FM 14-18

																39	38	37	36	35	34	33	32
																PARITY	SPARE <1 0>		MUL SYNC	LOFMRA	MSMX CTL <1 0>		MRMX SEL <2 0>
																	1	0			1	0	2

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
MRMX SEL <2 0>		EXAC LD <1 0>		CARRY CTL <2 0>			LDACC <1 0>		GBMUX SEL	COUNTER CLEAR	MPLR SEL <2 0> (MPLR ENAB)		MCAND SELD	MHOLD SEL <3 0>	
1	0	1	0	2	1	0	1	0			2	1	0		3

15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
MHOLD SEL <3 0>			BEN <3 0>				NEXT ADDRESS (J) <8 0>								
2	1	0	3	2	1	0	8	7	6	5	4	3	2	1	0

MM 12-78

Figure 12-8 FBox Multiplier Microcode Worksheet

FBOX FBox Multiplier (FBM) Microcode




Figure 12-9 FBM Microword <39:32>

PARITY<0>

This bit reflects the microword parity, and has the following encoding:

- 0 = ODD, uword has odd parity and parity bit is reset
- 1 = EVEN, uword has even parity and parity bit must be set

SPARE<1:0>

This is a spare field and all encoding is 0 and is decoded as NOP.

MUL SYNC<0>

This bit informs the FBA that the FBM has result data ready, and has the following encoding:

- 0 = NOP
- 1 = SYNC, send SYNC to FBA

LDFMRA<0>

This bit enables loading of the FMRA latches, and has the following encoding:

- 0 = HOLD FMRA
- 1 = LOAD FMRA

MSMX CTL<1:0>

This field selects the input to the MSMX mixer, and has the following macro definition encoding:

- 0 = EXACC
- 1 = EXACC and 0
- 2 = EXACC and BYPASS
- 3 = FMRA and BYPASS

FBOX FBox Multiplier (FBM) Microcode




Figure 12-10 FBM Microword <31:16>

MRMX SEL<2:0>

This field selects the input to the MRMX mixer, and has the following encoding:

- | | |
|--------------------------------|---|
| 0 = PROD.F
DIVISOR.LOW | MRMX enabled for FMRA unshifted |
| 1 = PROD.D.HIGH
QUOT.D.HIGH | MRMX enabled for FMRA unshifted |
| 2 = PROD.G.HIGH
QUOT.D.HIGH | FRMX enabled for FMRA shifted left 1 bit |
| 3 = not used | |
| 4 = QUOT.F
ACC.LEFT24 | MRMX enabled for EXACC unshifted |
| 5 = PROD.D.LOW
QUOT.D.LOW | MRMX enabled for EXACC unshifted |
| 6 = PROD.G.LOW
QUOT.G.LOW | MRMX enabled for EXACC shifted left 1 bit |
| 7 = ZERO | MRMX disabled and output is 0 |

EXAC LD<1:0>

This field enables loading of the EXACC latches, and has the following macro definition encoding:

- 0 = LD.Q
- 1 = MSMX.TO.EXACC
- 2 = Q.TO.EXACC
- 3 = NOP

CARRY CTL<2:0>

This field controls the Carry Save logic, and has the following encoding:

- 0 = add ACC CLACOUT A and ACC CLACOUT D to the partial product
- 1 = add ACC CLACOUT B and ACC CLACOUT D to the partial product
- 2 = add ACC CLACOUT C and ACC CLACOUT D to the partial product
- 3 = add ACC CLACOUT D to the partial product

- 4 = load CRY A
- 5 = load CRY B
- 6 = load CRY C
- 7 = not used

LDACC<1:0>

This field controls the loading of the ACC, and has the following encoding:

- 0 = hold accumulator
- 1 = shift ACC right 8 bits
- 2 = shift ACC left 24 bits
- 3 = clear accumulator

QBMUX SEL<0>

This bit selects the input to the MDQX multiplexer (multiplicand or quotient), and has the following encoding:

- 0 = SEL.MCAND, select MDQX for MCAND
- 1 = SEL.QUOT, select MDQX for quotient bits

COUNTER CLEAR<0>

This bit enables and clears the Quotient Bit Counter, and has the following encoding:

- 0 = INC, enable quotient bit counter to increment
- 1 = CLR, initialize quotient bit counter to 0001

MLPR SEL<2:0>

This bit selects the active 8-bit multiplier, and has the following macro definition encoding:

- 0 = MHLDC.B0, select MHLDC byte 0
- 1 = MHLDD.B0, select MHLDD byte 0
- 2 = MHLDC.B1, select MHLDC byte 1
- 3 = MHLDD.B1, select MHLDD byte 1
- 4 = MHLDC.B2, select MHLDC byte 2
- 5 = MHLDD.B2, select MHLDD byte 2
- 6 = MHLDC.B3, select MHLDC byte 3
- 7 = MHLDD.B3, select MHLDD byte 3

MCAND SEL<0>

This bit selects the active 32-bit multiplicand, and has the following encoding:

- 0 = SEL.MHLDA, select MCAND MUX for MHLDA
- 1 = SEL.MHLDB, select MCAND MUX for MHLDB

FBOX FBox Multiplier (FBM) Microcode




Figure 12-11 FBM Microword <15:00>

MHLD SEL<3:0>

This field controls the loading of the multiply hold latches, and has the following macro definition encoding:

- 0 = LOAD.A.F
- 1 = LOAD.A.D.H
- 2 = LOAD.A.G.H
- 3 = LOAD.A
- 4 = SPARE
- 5 = DATA.LOAD.AB.D.L
- 6 = LOAD.AB.G.L
- 7 = LOAD.B
- 8 = LOAD.C.F
- 9 = LOAD.C.D.H
- A = LOAD.C.G.H
- B = LOAD.C
- C = HOLD
- D = LOAD.CD.D.L
- E = LOAD.CD.G.L
- F = LOAD.D

BEN<3:0>

The Branch Enable field allows the modification of the NEXT ADDRESS (UJUMP) field, and has the following macro definition encoding:

- 0 = OPBUS.VAL and IRD
- 1 = not used
- 2 = DATA.SYNC
- 3 = EXPONENT.ZERO
- 4 = not used
- 5 = not used
- 6 = not used
- 7 = not used
- 8 = OPBUS.VALID
- 9 = not used
- A = not used
- B = not used
- C = not used
- D = RETURN
- E = CALL
- F = NOP

NEXT ADDRESS<8:0>

The UJUMP field specifies the next microaddress. The field may be modified by the content of the BEN field which is ORED into it.

12.1.3 FBox Dispatch RAM (FDRAM)




Figure 12-12 FBox Dispatch Ram (FDRAM) Microword

NOTE

The ULD and physical bit number assignments are identical.

FDRAM PARITY<0>

This bit represents the odd FDRAM parity.

FORMAT<0>

This field is enabled only when an OP Code is being decoded. The field is routed to the FBR where it is decoded to provide G-format, F-format, and I-format (integer) data formats.

FORK ADDRESS<4:0>

This field is routed to the FBA and FBM MSQs as the micro PC for fork and trap conditions.

12.1.4 FBox Substitution Modules

If the FBox is removed for troubleshooting, or any other reason, the FBox substitution modules must be installed. The FBox Jumper Module (FJM), an L0218, will replace the FBM (L0213) in slot AC7. The FBox Terminator Module (FTM), and L0223, will replace the FBA (L0212) in slot AC8. The FBox terminates the WBus and OPBus.

FBOX

Turning the FBox ON and OFF

12.1.5 Turning the FBox ON and OFF

The FBox can be turned on and off via the Accelerator Control and Status register (ACCS - IPR number 28). This register may be written or read via any Macro program or alternatively via console commands. When the FBox is turned off, EBox microcode will handle those floating point instructions normally executed by the FBox.

The default mode of operation is for the console to enable the FBox (if present) upon booting. VMS, in turn, will also attempt to turn on the FBox at system startup time. Note that in order to disable the FBox while running VMS, you must write the ACCS register AFTER VMS has been booted.

12.1.5.1 To Disable the FBox - After the system is up and running a Macro program (such as VMS):

```
^P                ; enter CIO mode
>>>HALT           ; halt the processor
>>>DEPOSIT ACCS 0  ; turn the FBox off
>>>CONTINUE       ; then continue
```

12.1.5.2 To Enable the FBox - After the system is up and running a Macro program (such as VMS):

```
^P                ; enter CIO mode
>>>HALT           ; halt the processor
>>>DEPOSIT ACCS 8000 ; turn on the FBox
>>>CONTINUE       ; then continue
```

12.1.5.3 To Determine the Status of the FBox - After the system is up and running a Macro program (such as VMS):

```
^P                ; enter CIO mode
>>>HALT           ; halt the processor
>>>EXAMINE ACCS    ; read the ACCS register
    I 28 0000X001 ; ACCS contents printed on console, where
                    X=0 if FBox is disabled
                    X=8 if FBox is enabled
                    ; Note that the '1' digit refers to the
                    ; accelerator type and is set by microcode
                    ; Refer to the register description for ACCS
>>>CONTINUE       ; then continue
```

NOTE

There is a console flag called 'FBOX' which may be set or cleared via the SET FBOX ON and SET FBOX OFF commands. In addition, the status of this flag will be displayed with the SHOW FLAGS console command.

FBOX
Turning the FBox ON and OFF

This command DOES NOT directly control the enabling or disabling of the FBox. Its purpose is to control the action of the INIT console command regarding the enabling or disabling of the FBox. If set ON, the FBox (if present) will be enabled by the INIT, INIT/CPU, or INIT/PAMM commands.

Accessing the ACCS register is the only way to determine the actual status of the FBox and to control enabling and disabling it.



CHAPTER 13

IBOX

IBOX
IBOX MODULES

13.1 IBOX MODULES




Figure 13-1 IBox Module Block Diagram




Figure 13-2 Ibox Data Paths Block Diagram



13.2 IBOX MICROCODE

DATA (HEX)

1

$\begin{array}{c} \\ \\ \end{array}$	$\begin{array}{c} \\ \\ \end{array}$	$\begin{array}{c} \\ \\ \end{array}$	$\begin{array}{c} \\ \\ \end{array}$

MICROWORD BITS <50:00>
ICA 2-6

EXAMINE FROM CONSOLE  EING ADDRESS										50	49	48
										ICS	UMSC2 <20>	
										OPAR	2	1

47	46	45	44	43	42	41	40	39	38	37	36	35	34	33	32		
UMISC2 <2>0> 0		IBOX MARK		DIAG UNSTALL		IR HOLD (UNHBIT IBUF SHIFT)		UNSTALL		CYCLE ID <10> 1 0		UMISC3<3>0> 3 2 1 0		MCF <3>0> 3 2 1 0		UNPACK CTL <10> 1	

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
UNPACK CTL <10>			REG MODE	UCODE WBUS REQ		GPR SEL <20>			CTX CTL <20>			BMUX SEL <20>			AMUX SEL <20>	
0 1 0						2 1 0			2 1 0			2 1 0			2 1	

15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
AMUX SEL <2:0>		UTRAP CTL <1:0>		IFORK CTL <2:0>		UBEN CTL <1:0>		NEXT ADDRESS (NA) <7:0>							
0		1 0		2 1 0		1 0		7 6 5 4 3 2 1 0							

MAR 16 1987

Figure 13-3 IBox Microword Worksheet

MICROWORD BITS <50:48>
ICA 2-6

EXAMINE FROM CURSORE >>> EINGABEADRESS	50	49	48
	IC5 OPAR	UMISC2 <2 D>	
	2	1	
	47	50	49

PHYSICAL BIT NUMBERS

Figure 13-4 IBox Microword <50:48>

ICS OPAR<0>

13-4

IBOX IBOX MICROCODE

IBOX CONTROL STORE MICROWORD																MICROWORD BITS <47:32>													
EXAMINE FROM CONSOLE >>>E/ICS ADDRESS																ICA 2-6													
47	46	45	44	43	42	41	40	39	38	37	36	35	34	33	32														
UMISC2<2:0>	IBOX MARK	DIAG UNSTALL	IB HOLD (INHIBIT IBUF SHIFT)	UNSTALL	CYCLE ID <1:0>		UMISC<3:0>			MCF<3:0>			UNPACK CTL<1:0>																
0					1	0	3	2	1	0	3	2	1	0															
48	45	32	46	31	24	23	15	14	13	12	30	29	28	27	44														
PHYSICAL BIT NUMBERS																													

Figure 13-5 IBox Microword <47:32>

UMISC2<2:0>

The MICRO MISCELLANEOUS field provides those miscellaneous functions which do not require the assignment of an entire field for control.

- 0 = NOP
- 1 = INDEX.IMM
- 2 = ENA.OPBUS.PARITY
- 3 = UNUSED
- 4 = FORCE.SET.SB.VALID
- 5 = INHIBIT.SET.SB.VALID
- 6 = FORCE.SET.SB.ENA.OPBUS.PARITY
- 7 = UTRAP.CIP

IBOX MARK<0>

The IBOX MARK field is used to mark a microinstruction for microcode or hardware debugging.

- 0 = Normal: no microbreak
- 1 = Microbreak

DIAG UNSTALL<0>

The DIAGNOSTIC UNSTALL field is used only in diagnostic mode, and will override all IBox stall conditions.

- 0 = NOP
- 1 = Override any IBox stall condition

IB HOLD (INHIBIT IBUF SHIFT)<0>

This field inhibits the IBUF from shifting, and is used only in diagnostic mode.

- 0 = Nohold
- 1 = Hold

UNSTALL (DIAGNOSTIC UNSTALL)<0>

This field is used in some IBox microtrap routines to override all ISTALL terms: ISTALL due to an EBox STOP command, or due to DRAM SUSP.

- 0 = NORMAL
- 1 = Override STALL

IBOX
IBOX MICROCODE

CYCLE ID<1:0>

The CYCLE ID field classifies the current cycle into one of the following types:

- 0 = NORMAL: NON-IFORK CYCLE
- 1 = INDEX IFORK ENTRY [RX]
- 2 = BASE OPERAND ADDRESS (BOA) ENTRY
- 3 = IFORK ENTRY AND -(BOA+[RX])

UMISC<3:0>

The MICRO MISCELLANEOUS field handles miscellaneous IBox functions.

- 0 = NOP
- 1 = Stall until EBox OP.WRITE command
- 2 = IB.FLUSH.LD.CPC
- 3 = IB.FLUSH
- 4 = CON.BRANCH
- 5 = IB.FLUSH.COND
- 6 = READ.IMD
- 7 = INH.SB.CHECK
- 8 = Reserved Addressing Mode (RAF)
- 9 = DIAG.DONE
- A = DIAG.RESET
- B = BMUX.CHK.CTX
- C = POP Stack
- D = Clear CPC VALID; for Flush and Branch
- E = COND.FA.OP.MEM.REQ
- F = FA.OP.MEM.REQ

MCF<3:0>

The MICRO MEMORY CONTROL FUNCTION field defines the OP PORT MCF field.

- 0 = READ.RCHK if DRAM MEM equals read and READ.WCHK if DRAM MEM equals modify
- 1 = NO OP-PORT MEMORY REQUEST
- 2 = WRITE.V.NOPAGE
- 3 = WRITE.V.NOPAGE.2ND
- 4 = UNUSED
- 5 = WRITE.V.WCHK
- 6 = UNUSED
- 7 = UNUSED
- 8 = READ.V.WCHK
- 9 = UNUSED
- A = READ.V.RCHK
- B = READ.V.RCHK.2ND
- C = READ.V.NOPAGE
- D = READ.V.NOPAGE.2ND
- E = 1B.FILL.OP
- F = 1B.FILL.IBF

IBOX IBOX MICROCODE




Figure 13-6 IBox Microword <31:16>

UNPACK CTL<1:0>

The UNPACKER CONTROL field determines how the ID register data should be unpacked before being driven onto the OP Bus.

- 0 = NOP
- 1 = SIGN EXTEND IF -ASRC
- 2 = Unpack as short literal according to DRAM CTX and type fields.
- 3 = Unused

OP VALID CTL<1:0>

The OPERAND VALID CONTROL field controls the setting of the OP VALID flag for the ID and IMD operand buffers.

- 0 = NOP
- 1 = Set OPVALID if ((READ + MODIFY + VSRC) * RMODE) + -(ASRC * RMODE)
- 2 = Set OPVALID if ASRC + ((READ + MODIFY) * ALIGNED)
- 3 = Set OPVALID unconditionally

REG MODE<0>

The REGISTER MODE field marks the beginning of register mode specifier processing. It determines the validity of an entry into the scoreboard. These are the only cases when scoreboard entries are validated.

- 0 = Not an RN specifier
- 1 = RN specifier

UCODE WBUS REQ<0>

The UCODE WBUS REQUEST bit partially controls updating the RLOG and requesting an IBox WBus cycle.

- 0 = RLOG entry is pushed if this is the first IFORK for this OPCODE. WBus is conditionally requested if doing an UNWIND (GPR SEL = 3)
- 1 = RLOG entry is pushed with valid GPR number and context entry. WBus is requested.

IBOX
IBOX MICROCODE

GPR SEL<2:0>

The GPR SELECT field determines the source of the GPR read address.

- 0 = GPR address from IBUF <B1>
- 1 = Index register is being addressed by a saved index register number
- 2 = Last GPR address plus 1
- 3 = GPR address is previous GPR address
- 4 = RLOG unwind
- 5 = GPR address <3:2> from CTX CTL<1:0>; GPR address <1:0> from UNPACK.CTL<1:0>
- 6 = UNUSED
- 7 = UNUSED

CTX CTL<2:0>

The CONTEXT CONTROL field controls the various contexts (data types) for the adder, memory references, and RLOG entries during a microcycle.

CONTEXTS (IN BYTES)

	ADDER CTX	MEM CTX	RLOG CTX
0	DRAM CTX	DRAM CTX	DRAM CTX
1	4	4	4
2	X	2	X
3	+ RLOG CTX	X	X
4	-DRAM CTX	DRAM CTX	-DRAM CTX
5	-4	4	X

X = UNDEFINED

BMUX SEL<2:0>

The BMUX SELECT field controls the input to the BMUX.

- 0 = ZERO
- 1 = VA
- 2 = Adder CTX as defined by CTX CTL
- 3 = UNUSED
- 4 = DMX.IBF
- 5 = DMX.IMD
- 6 = CPC, used for string continued flushes
- 7 = Hold VA, inhibit VA clocking. Not a BMUX SEL function




Figure 13-7 IBox Microword <15:00>

AMUX SEL<2:0>

The AMUX SELECT field controls the input to the AMUX.

- 0 = ZERO
- 1 = AMUX PC
- 2 = +4
- 3 = -4
- 4 = GPR, if WBus match then replace GPR data with WBus data
- 5 = GPR (Left Shift 1)
- 6 = GPR (Left Shift 2)
- 7 = WBUS
- 4-6 = Enable ISTALL if scoreboard hit
- 5-6 = ENABLE ISTALL if WBus match

UTRAP CTL<1:0>

The MICROTRAP CONTROL field enables a microtrap to occur in the next cycle if the current OP PORT memory request is unaligned.

- 0 = Inhibit Micro-trap due to unalignment
- 1 = Micro-trap next cycle for unaligned indirect fetch
- 2 = Micro-trap for unaligned (RN) or any other unaligned operand

IFORK CTL<1:0>

The IFORK CONTROL field determines if the next cycle is an IFORK entry or not. The field has the following encoding (where B = byte, W = word, L = longword):

- 0 = Do not IFORK
- 1 = IFORK if ASRC + (READ* (BWL))
- 2 = IFORK if VSRC + WRITE + ((READ + MODIFY) * (BWL))
- 3 = IFORK if READ * (BWL)
- 4 = IFORK if QUAD
- 5 = IFORK IF EBOX UMCF equals 24
- 6 = Unconditional IFORK
- 7 = unused

IBOX
IBOX MICROCODE

UBEN<1:0>

The BRANCH ENABLE field enables a multi-way (up to 16-way) branch in microcode in the absence of IFORK or microtrap.

UBEN MUX BITS

	3	2	1	0
0	0	0	0	0
1	0	QUAD + OCTA	DRAM MEM 1	DRAM MEM 0
2	RLOG FIRST	DRAM CTX 2	DRAM CTX 1	DRAM CTX 0
3	0	0	0	0

NA<7:0>

The NEXT ADDRESS field addresses the next microinstruction in the absence of a branch, IFORK, or microtrap. For a branch, NA<3:0> are Ored with the branch conditions.

13.3 IBOX DISPATCH RAM (IDRAM)

ADDRESS (HEX)

--	--	--

DATA (HEX)

--	--	--	--	--	--	--	--

IDRAM MICROWORD (U/LD/PHYSICAL FORMAT)
EXAMINE FROM CONSOLE >>>E/IDRAM ADDRESS

MICROWORD BITS<19:00>
IBDB C

																19	18	17	16
																CONTEXT <2:0>			TYPE <1:0>
																2	1	0	1
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00				
TYPE <1:0>	REF <1:0>		CONTROL <1:0>		SUSPEND	BOEST	LAST	OPAR	FPA	ADDRESS <05:00>									
0	1	0	1	0						05	04	03	02	01	00				

4/19/10/81

Figure 13-8 IDRAM MICROWORD WORKSHEET

13.3.1 IDRAM Address Generation

The IDRAM address is a 12-bit address which is generated from the execution point counter (EPC), the OPCODE, and a bit controlled by whether or not the instruction is extended (an FD instruction). The initial FDRAM address for any instruction, has the least significant three bits equal to zero because the EPC is initially zero, being incremented for each specifier.

Table 13-1 shows how to generate the initial FDRAM address, and Example 13-1 gives examples.

NOTE

IDRAM code may be found in KA86*.MCR.

Table 13-1 IDRAM Address Generation

IDRAM ADRS	11	<10:03>	<02:00>
	FD	OPCODE <07:00>	EPC <02:00>

Example 13-1 Generating IDRAM Addresses

1. CVTLD instruction, OPCODE = 6E

IDRAM ADRS	0	0 1 1 0 1 1 1 0	0 0 0
	FD	OPCODE <07:00>=6E	EPC <02:00>

IDRAM ADRS = 001101110000 = 370

2. CVTLH instruction, OPCODE = 6EFD

IDRAM ADRS	1	0 1 1 0 1 1 1 0	0 0 0
	FD	OPCODE <07:00>=6E	EPC <02:00>

IDRAM ADRS = 101101110000 = B70

13.3.2 IDRAM Microword



Figure 13-9 IDRAM Microword <19:16>

CONTEXT<2:0>

```
0 = BYTE
1 = WORD (2 bytes)
2 = LONG (4 bytes)
3 = QUAD (8 bytes)
4 = OCTA (16 bytes)
5-7 = UNPREDICTABLE
```

TYPE<1:0>

```
0 = INTEGER, ASOURCE
1 = FLOATING, F, D, or H
2 = G-FLOAT
3 = VSOURCE
```



Figure 13-10 IDRAM Microword <15:00>

REF<1:0>

The MEMORY REFERENCE field specifies the memory reference and the checking applied.

ACCESS CHECK

ON READ ON WRITE

```

0 = ASOURCE  ----  ----
0 = VSOURCE  ----  ----
1 = READ     READ   ----
2 = WRITE    ----   WRITE
3 = MODIFY   READ   WRITE

```


CONTROL<1:0>

The CONTROL (CTL) field determines the content of the FORK address. See Figure 13-11, Fork Address Generation.

- 0 = EXECUTE
- 1 = SINGLE
- 2 = OPT-TWO
- 3 = OPT-TWO & EXECUTE

CTL

FORK ADDRESSES

	07	06	05		00
EXECUTE	0	DRAM<FPA> & FEN OR -DRAM<FPA>	DRAM ADRS <05:00>		
	07	06	05	01	00
SINGLE *	1	DRAM<FPA> & FEN OR -DRAM<FPA>	DRAM ADRS <05:01>		DRAM ADRS <00> & RMODE & -BDEST
	07	06	05	04	00
OPT-TWO RMODE	1	DRAM<FPA> & FEN	DRAM ADRS <05> & B1 = REGMODE	DRAM ADRS <04:00>	
	07	06	05	04	03 02 00
OPT-TWO NOT RMODE	1	DRAM<FPA> & FEN	DRAM ADRS<05> & B1=REGMODE	DRAM TYPE<1:0>	DRAM CTX<2:0>
	07	06	05	01	00
OPT-TWO & EXEC RMODE	0	DRAM<FPA> & FEN	DRAM ADRS <05:01>		DRAM ADRS <00> OR RMODE
	07	06	05	04	00
OPT-TWO & EXEC NOT RMODE †	0	DRAM<FPA> & FEN	DRAM ADRS <05> & B1 = REGMODE	DRAM ADRS <04:00>	

NOTE

* If FORK ADRS bit 0 (FA<00>) = 1, turn off scoreboard

† If FORK ADRS bit 5 (FA<05>) = 1, turn off scoreboard

Figure 13-11 Fork Addressess Generation

IBOX
IDRAM Microword

SUSPEND<0>

If set (1), the SUSPEND (SUSP) field causes the Address Calculation Unit to suspend operation after processing the specifier that had the SUSPEND bit set.

BDEST<0>

The BRANCH DISPLACEMENT NEXT field is set in the DRAM entry preceding a displacement. This bit is not set for Opcodes in which the first item following the Opcode is a branch displacement.

- 0 = Next byte after this specifier is a mode-register specifier or new OPCODE.
- 1 = Next byte after this specifier is a branch displacement.

LAST<0>

The LAST bit indicates that the current DRAM entry is the last one for this instruction. This bit is implied if an instruction is optimized.

OPAR<0>

The ODD PARITY bit is used to check the integrity of DRAM data. The console attempts to correct DRAM parity errors.

FPA<0>

The FPA OVERRIDE bit specifies that the FPA may override the EBox for the specifier that the IBox is currently processing.

ADDRESS<5:0>

The EXECUTION ADDRESS field supplies the basic FORK address (FA) that will be sent to the EBox if no error is detected. It is modified before becoming the EBox FA.

13.4 IBUFFER AND OPCODE TESTPOINTS

Table 13-2 lists oscilloscope/logic analyzer test points for the IBUFFER (bytes 0 and 1) and Table 13-3 lists the oscilloscope/logic analyzer testpoints for the OPCODE bits (sent from the ICA to FBH) which are available on the backplane. The tables include channel number suggested for use with a logic analyzer, signal name, print page on which the signal originates, and the CPU backplane pin location.

Table 13-2 IBUFFER Testpoints

Channel	Signal Name	Print	Section/Slot/Pin
#0	IBD IBUF DATA B1 7 H	IBD3	C15_08
#1	IBD IBUF DATA B1 6 H	IBD3	C15_24
#2	IBD IBUF DATA B1 5 H	IBD2	C15_12
#3	IBD IBUF DATA B1 4 H	IBD2	C15_15
#4	IBD IBUF DATA B1 3 H	IBD2	C15_44
#5	IBD IBUF DATA B1 2 H	IBD1	C15_50
#6	IBD IBUF DATA B1 1 H	IBD1	C15_68
#7	IBD IBUF DATA B1 0 H	IBD1	C15_71
#8	IBD IBUF DATA B0 7 H	IBD3	C15_02
#9	IBD IBUF DATA B0 6 H	IBD3	B15_82
#A	IBD IBUF DATA B0 5 H	IBD2	B15_56
#B	IBD IBUF DATA B0 4 H	IBD2	B15_53
#C	IBD IBUF DATA B0 3 H	IBD2	A15_89
#D	IBD IBUF DATA B0 2 H	IBD1	B15_30
#E	IBD IBUF DATA B0 1 H	IBD1	B15_18
#F	IBD IBUF DATA B0 0 H	IBD1	B15_46

Table 13-3 OP CODE Testpoints


Channel	Signal Name	Print	Section/Slot/Pin
#0	ICA OPTIMIZED A H	ICAE	B07_83
#1	ICA EXT OPC A H	ICAE	B07_85
#2	ICA OPC BIT 7 A H	ICAE	B07_81
#3	ICA OPC BIT 6 A H	ICAE	B07_82
#4	ICA OPC BIT 5 A H	ICAE	B07_86
#5	ICA OPC BIT 4 A H	ICAE	B07_77
#6	ICA OPC BIT 3 A H	ICAE	B07_87
#7	ICA OPC BIT 2 A H	ICAE	B07_80
#8	ICA OPC BIT 1 A H	ICAE	B07_76
#9	ICA OPC BIT 0 A H	ICAE	B07_84



CHAPTER 14

MBOX


14.1 MBOX MODULES





MR 13125

Figure 14-1 MBox Physical Organization









MR 13-48

Figure 14-5 MBox Error Reporting Block Diagram

5275-16763

Figure 14-6 MBox Control Store Microword Worksheet

MBOX MBOX MICROCODE




Figure 14-7 MBox Microword <79:64>

ADDRESS PARITY<0>

The address parity bit reflects odd parity of the address where the microword is stored in the control store.

RES CORR REQ<0>

When set, the RESET CORRECTION REQUEST bit resets the data correction cycle request.

IOA SEL <1:0>

The I/O ADAPTER SELECT field provides commands to the ABUS interface MCA to select the specified I/O adapter. The field has the following encoding:

- 0 = DMA DONE not sent to ABUS
- 1 = LATCH B sends DMA DONE to ABUS
- 2 = LATCH A sends DMA DONE to ABUS
- 3 = CPA sends DMA DONE to ABUS

STACK<1:0>

This field provides stack control. The field encoding is:

- 0 = NOP
- 1 = push current micro address on the stack
- 2 = pop a micro address from the stack
- 3 = when asserted, either does a return from top of stack, or return to MFORK. ARB SEL must be specified to disable arbitration.

UNUSED FIELDS

Two 2-bit fields are unused in the ULD: <73:72> and <66:65>.

MBOX CYCLE TYPE<3:0>

Indicates the cycle type the MBox controller will perform.

00 = no type
01 = read register cycle
02 = write register cycle
03 = writeback cycle
04 = ABUS array write cycle
05 = data correction cycle
07 = probe cycle
08 = ABUS cycle
09 = CP refill cycle
0A = invalidate TB cycle
0B = TB cycle
0C = CP array write cycle
0D = CP write cycle
0E = CP read cycle
0F = refill cycle

-REFILL LATCH LOAD<0>

When reset (asserted low), this bit enables loading of the ADDRESS REFILL LATCH.

-ABUS DATA ENABLE<0>

When asserted low, the ABUS DATA EN bit asserts data and longword parity onto the ABUS

MBOX CONTROL STORE (MCS) MICROWORD (ULF FORMAT)
EXAMINE FROM CONSOLE >>>=MCS ADDRESS

MICROWORD BITS <63:48>
MCCD-H

63	62	61	60	59	58	57	56	55	54	53	52	51	50	49	48
CB DRIVE ENABLE	-ENABLE ARRAY BUS	REG LOAD<1:0>		ABUS IOA SELECT DISABLE	CLEAR BD SELECT	ABUS2 HOLD	ENABLE BYTE MERGE	-ARB SELECT	MARK	-ABUS REFILL BRANCH	CLEAR CACHE WIV BITS	ENABLE LRU WRITE	-CACHE WRITE ENABLE	SELECT WORD COUNT	LOAD WORD COUNT
79	13	43	54	26	39	33	18	48	85	53	21	09	04	17	78

PHYSICAL BIT NUMBERS

MM 14-721

Figure 14-8 MBox Microword <63:48>

CB DRIVE ENABLE<0>

When asserted, CB DRIVE EN gates check bits, read from the data cache, and stored in the DATA CB MUX LATCH OUT, to the Array Bus. When there is a cache data parity error, the cache correction cycle requires that the check bits be read from the cache. The bit has the following encoding:

0 = do not gate CB MUX LATCH OUT to check bit bus
1 = gate CB MUX LATCH OUT to check bit bus

-ENABLE ARRAY BUS<0>

When asserted low, this bit enables gating 32 data bits from the CACHE WRITE DATA MUX LATCH to the Array Bus.

MBOX
MBOX MICROCODE

REG LOAD<1:0>

The REGISTER LOAD field provides inputs to the ABUS interface MCA to load the I/O adapter latches, and has the following encoding:

- 0 = do not load IOA latches
- 1 = load LATCH A with IOA REQ
- 2 = load LATCH B from LATCH A
- 3 = load CPA latch from PAMM

ABUS IOA SELECT DISABLE<0>

When set, the ABUS IOA SEL DIS bit inhibits IOA SELECT if XFER IN PROGRESS is not true.

CLEAR BD SELECT<0>

The CLR BD SEL bit is used for array select on refills. Two latches retain the array select information for current and pending refills. If set, this bit allows loading of the current latch from the pending latch.

ABUS2 HOLD<0>

When set during DMA writes, this bit causes data to be held in the A2 DAT REG. The bit has the following encoding:

- 0 = do not hold A2 DAT REG
- 1 = hold A2 DAT REG

ENABLE BYTE MERGE<0>

The EN BYT MERGE bit enables the DATA OUT MUX select hardware during a CP byte write. When the DO MUX selection is for the DATA SOURCE MUX and BYT MERGE is enabled, the hardware will merge the data in the CP DATA LAT with the data coming from the DATA SOURCE MUX.

-ARB SELECT<0>

This bit selects the arbiter address instead of the next micro address. However, <VECTOR .and. NOT STACK EMPTY> override the ARB SEL bit and disables arbitration. The bit has the following encoding:

- 0 = select next micro address from arbiter
- 1 = select next micro address from NEXT ADDRESS field

MARK<0>

This bit is a trace bit used for debugging.

-ABUS REFILL BRANCH<0>

When asserted low, this bit enables the optimized refill branch logic.

CLEAR CACHE W/V BITS<0>

When asserted with the CACHE WRITE ENABLE bit, this bit will cause the written and valid (W/V) bits to be set to 0.

ENABLE LRU WRITE<0>

This bit enables LRU to be written, switching cache selection.

-CACHE WRITE ENABLE<0>

When this bit is asserted low, it enables writing the cache data and tag.

SELECT WORD COUNT<0>

When a refill, writeback, or ABUS multi-word array reference takes place, the word counter keeps track of the current longword being read or written. If SELECT WORD COUNT is set the word counter is selected for addressing the cache. If reset, the physical address is used.

LOAD WORD COUNT<0>

When asserted, the LD WD CNT bit will load the longword counter from PA LATCH <03:02>.




Figure 14-9 MBox Microword <47:32>

CLEAR WORD COUNT<0>

When asserted, the CLR WD CNT bit will clear the longword counter in the WVP MCA on the address module.

INC WORD COUNT<0>

The INC WD CNT bit increments the longword counter.

MBOX
MBOX MICROCODE

PA MUX LATCH SEL<2:0>

This field controls the PA MUX on the Address Path module, and determines the input to the PA MUX LATCH. The field encoding is as follows:

- 0 = VA MUX
- 1 = Refill Latch
- 2 = Error Latch
- 3 = ABUS Latch
- 4 = TB PTE Store
- 5 = TB TAG Store
- 6 = C0 TAG Store
- 7 = C1 TAG Store

-ABUS CLUP<0>

The ABUS CLEAN UP bit conditions an array step. It also informs the ABUS interface logic to start looking for a word count match for ABUS Transfer. The bit has the following encoding:

- 0 = Array Step Enable causes array step
- 1 = ON and NOT ABUS REFILL CYCLE TYPE. (Array Step En causes array step only if NOT refill in progress AND NOT block hit.)

HOLD ON ARRAY BUSY<0>

The combination of this bit set and ARRAY BUSY true, will prevent the micro address from changing until ARRAY BUSY is false. The bit has the following encoding:

- 0 = do not hold here and wait for ARRAY BUSY to drop
- 1 = hold here until ARRAY BUSY is false

A1 HOLD<0>

When HOLD is set, the A1 DATA LATCH will be loaded. If reset, the A1 DATA LATCH is held.

ECC CHECK<0>

The ECC CHECK field controls whether the ECC MCA on the data path module is checking data read from memory for errors (refill), or generating check bits on data being written to memory (writeback). The bit will be reset for a writeback and set for a refill. The bit has the following encoding:

- 0 = generate check bits
- 1 = check read data for errors

DATA OUT MUX<1:0>

The DO MUX field determines the DATA OUT MUX selections. On a CP byte write or an ABUS masked write, the UCODE selects the DATA SOURCE MUX and the hardware selects the bytes to be written. If the operation is a CP byte write, the hardware selects the CP DATA LATCH for valid bytes to be written. On an ABUS masked write, the hardware selects the A2 DAT REG for valid bytes to be written. The field has the following encoding:

- 0 = select DATA SOURCE MUX
- 1 = select A2 DATA REGISTER
- 2 = select CP DATA LATCH
- 3 = select ARRAY 2 DATA LATCH

MD RESPONSE ENABLE<0>

When MD RES EN is asserted, it indicates to the CP port interface MCA that the current cycle has completed. This bit also indicates when to send the status code.

ABUS ADDRESS DRIVE ENABLE<0>

If set, the ABUS ADR DR EN bit enables the ABUS drivers on the address module, allowing an address from the PA MUX LATCH to the ABUS. This function is used for CP initiated requests.

-ENABLE ERROR TRAP<0>

When asserted low, the ENABLE ERROR TRAP bit is a signal to the micro address control to go to micro address FF if there is an ABUS address parity error. It forces a POP of the stack if an error trap is taken.

ABUS ADDRESS CONTROL<1:0>

This bit is a signal to the ABUS interface MCA to allow control of the I/O adapter register file. The field has the following encoding:

- 0 = hold current address in I/O adapter register file
- 1 = increment if write
- 2 = increment current address in I/O adapter register file
- 3 = load current address in I/O adapter register file

NOTE

MCC ABUS ADDRS CTRL <01:00>, the signals on the ABUS that control the register file, are not the same as the MBox microcode bits.

MBOX MBOX MICROCODE

MBOX CONTROL STORE (MCS) MICROWORD (OLD FORMAT)																MICROWORD BITS <31:16> MCCD-H	
EXAMINE FROM CONSOLE >>>E/MCS ADDRESS																	
31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16		
ABUS MBOX OUT	ARRAY 2 HOLD	-ABUS LATCH LOAD	ARRAY READ DATA ENABLE	ARRAY START	-ARRAY STEP ENABLE	ABUS INHIBIT INCREMENT	DSM VALID	DS MUX SEL <1:0>		MIC PAR	ASSERT LAST WD	-SEL CACHE	-PA LATCH LOAD	FORCE ABUS TRANSFER	BEN SEL <2:0>		
61	40	51	80	57	08	74	35	37	42	82	70	84	16	83	41		
PHYSICAL BIT NUMBERS																	

Figure 14-10 MBox Microword <31:16>

ABUS MBOX OUT<0>

When asserted, this bit is a signal to the ABus interface MCA to indicate that the MBox is ready to send data to the I/O adapter register file.

ARRAY 2 HOLD<0>

If ARRAY 2 HOLD is reset, the ARY 2 DATA LAT will be loaded. If the ARY2 HLD bit is set the ARY 2 DATA LAT will hold data presented to the CACH WRIT DAT MUX LAT, thus preventing the CACH WRIT DAT MUX LAT from changing.

-ABUS LATCH LOAD<0>

When asserted low, this bit causes the ADR A LAT to be loaded at T7A (second T3A). The bit is also used to clear ABUS XFER EN, and used as an enable into the GO REFILL logic.

ARRAY READ DATA ENABLE<0>

When asserted the ARRAY RD DATA EN bit will enable the array board drivers of the selected board. Data from the DC109 will be asserted on the Array Bus.

ARRAY START<0>

When this bit is asserted to the array interface MCA, it indicates that the microsequencer wants the array to initiate a write or read operation. The array interface MCA will issue the start signal to the array at the first T2 after the array becomes available.

-ARRAY STEP ENABLE<0>

When asserted low, this bit is used on array cycles, and conditions the array interface MCA to issue ARRAY DATA SHIFT to the array. Note that this is an enable function and not the actual step. Hardware issues the array step at T2 in the subsequent cycle.

ABUS INHIBIT INCREMENT<0>

This bit inhibits an address increment function from being transmitted to the ABus device if ABUS TRANSFER IN PROGRESS is not true.

DATA SOURCE MUX<2:0>

DSM VALID<0>

DS MUX SEL<1:0>

The DATA SOURCE MUX field consists of three subfields: DATA SOURCE MUX, DSM VALID, and DS MUX SEL. The overall field selects the data source to have byte parity generated or checked and clocked into the CP DATA LATCH, DATA ERROR LATCH, or A2 DAT REG, and sent to the DATA OUT MUX. When explicitly set it also tells the MBox that the DATA SOURCE MUX is valid, that is, that parity counts. The field encodings are as follows:

DATA SOURCE MUX<24:22>:

- 4 = select MDBus and valid
- 5 = select MDMUX and valid
- 6 = select A2 DATA LAT and valid
- 7 = select A1 DATA REG and valid

DS MUX SEL<23:22>

- 0 = MDBus
- 1 = MDMUX
- 2 = ARRAY BUS
- 3 = ABUS DATA

DSM VALID<24:24>

- 0 = No valid data at DATA SOURCE MUX output
- 1 = valid data at DATA SOURCE MUX output

MIC PAR<0>

The MIC PAR bit reflects the odd microword parity. MIC PAR will be calculated after the address parity bit is calculated.

ASSERT LAST WD<0>

ASSERT LAST WD is used to force last word valid for DMA write optimization.

-SEL CACHE<0>

The NOT SELECT CACHE bit specifies whether the MD MUX LAT will select the cache, or either the DATA OUT MUX or DATA ERR LAT based on the encoding of the DSM VALID and DS MUX SEL fields. The -SEL CACHE bit has the following encoding:

- 0 = select cache
- 1 = select DATA ERR LAT or DATA OUT MUX

MBOX
MBOX MICROCODE

-PA LATCH LOAD<0>

When asserted low, the PA MUX LATCH will be loaded, otherwise it will be held.

FORCE ABUS TRANSFER<0>

Used during DMA writes to force ABus transfer in progress.




Figure 14-11 MBox Microword <15:00>

BEN SEL<2:0>

The BRANCH ENABLE SELECT field enables one of eight inputs to 8:1 multiplexers. The outputs are Ored with the four low-order bits of the NEXT ADDRESS field. Individual multiplexers are disabled through the BEN MASK field. See Table 14-1.

BEN MASK<3:0>

Each bit in this field enables one of the 8:1 branch condition multiplexers. Bit zero enables multiplexer 0, bit 1 enables multiplexer 1, and so forth. Table 14-1 lists the branch conditions that are Ored with next address <03:00>.

Table 14-1 MBox Branch Conditions

MUX SEL	MUX 3	MUX 2	MUX 1	MUX 0
0	NOT.INT. MEM	CP.BW.HIT	ABUS.REFL. REQ	W.EQ.1/NO.BK.HT OR (NO.CACHE.HIT * LAT.RD.CYC * W.EQ.1)
1	ARRAY.BUSY	IO.WRT	REFL.PROG	CACHE.HIT
2	PAMM.SEL. ABUS	W.EQ.1. CACHE.ON	REFL.PROG	0
3	TAG.PERR	IO.MASK	BLK.HIT	IO.WRT
4	CACH.DAT. PERR	ABUS.XFR. DN	0	PA3
5	TAG.PERR	LAST.WD	COFF	0
6	BYT.WRT	NEXT.ABUS	ADR.ERR. LAT	DATA.ERR.LAT
7	ARRAY.BUSY	CP.WRT	REFL.PROG	BLK.HIT

CLEAR FLAGS<0>

When set, this bit clears the ABUS REFILL REQUEST and CP REFILL REQUEST flags used in MFORK address arbitration.

-ABUS MFORK ENABLE<0>

This bit is asserted to cause a return to MFORK for a DMA request, and has the following encoding:

- 0 = enable ABUS
- 1 = do not enable ABUS

NEXT ADDRESS<7:0>

This field designates the next micro address, which may be ORed with the branch conditions, or modified by the arbitration logic or stack logic.

14.3 MBOX MFORK ENTRIES

Table 14-2 is a list of the MBox micro address entries for MFORK conditions.

Table 14-2 MBox Entries on MFORK

02: M.DIAG.READ.IOA	16: M.CP.REFILL
06: M.BUFF.DONE	17: M.ABUS.REFILL
07: M.ABUS.DMA.REQ	18: M.IDLE
0B: M.PROBE.READ	19: M.CP.CACHE.READ
0C: M.READ.MBOX.REG	1A: M.CP.CACHE.WRITE
0D: M.READ.PTE.TAG	1B: M.PROBE.WRITE
0E: M.READ.PTE	1C: M.WRITE.MBOX.REG
0F: M.SWEEP.CACHE	1D: M.CLEAR.TB.ENTRY
10: M.WRITE.EMD	1E: M.WRITE.PTE
12: M.DIAG.WRITE.IOA	1F: M.CLEAR.CACHE
14: M.CACHE.READ.PAR.ERROR	

MBOX
MBOX CYCLE CONDITION CODE MICROWORD

14.4 MBOX CYCLE CONDITION CODE MICROWORD

ADDRESS (HEX)

--	--

DATA (HEX)

--	--	--	--	--	--

MBOX CYCLE CONDITION CODE (CYCLE) MICROWORD

(ULF FORMAT)

EXAMINE FROM CONSOLE >>>E/CYCLE ADDRESS

MICROWORD BITS <31:0>

MCCC

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
NEXT ADDRESS FIELD (USED ONLY BY UCODE ASSEMBLER THERE ARE NO PHYSICAL BITS PRESENT)												RESERVED (NO PHYSICAL BITS)		CP PAR B	-DEST CP <10> 1 0	-SECTION REFER ENCE

15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
CP PAR A	TB PROBE	ADDRESS FROM IVA	CP LOCK	ACCESS VIOLA TION CHECK	READ CHECK	EN PAGE BOUNDARY CROSS CHECK	ENABLE ALIGN CHECK	CACHE READ	-IO ACC ENABLE	DEST CP <10> 1 0	CP MODIFY	WRITE CHECK	CACHE WRITE	-NO ROT	

14-14 (1/2)

Figure 14-12 MBox Cycle Condition Code Microword Worksheet

MBOX CYCLE CONDITION CODE (CYCLE) MICROWORD

(ULF FORMAT)

EXAMINE FROM CONSOLE >>>E/CYCLE ADDRESS

MICROWORD BITS <31:16>

MCCC

31	10	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
NEXT ADDRESS FIELD (USED ONLY BY UCODE ASSEMBLER THERE ARE NO PHYSICAL BITS PRESENT)												RESERVED (NO PHYSICAL BITS)		CP PAR B	-DEST CP <10> 1 0	-SECOND REFER ENCE

PHYSICAL BIT NUMBERS

77 87 75 59

14-14 (2/2)

Figure 14-13 MBox Cycle Condition Code Microword <31:16>

CP PAR B <00>

This bit reflects the parity calculated on the following fields:

-NO ROT

-IO ACC ENABLE

DEST CP 0

CACHE READ

ENABLE ALIGN CHECK

TB PROBE

ADDRESS FROM IVA

CP LOCK

-DEST CP<1:0>

This bit specifies the destination of the MD RESPONSE to the current request. The field has the following encoding:

- 0 = IBF
- 1 = OP FETCH
- 2 = EBOX
- 3 = IBF FROM OP

-SECOND REFERENCE<00>

This bit is reset to indicate to the MBox logic that this is a second reference request.




Figure 14-14 MBox Cycle Condition Code Microword <15:00>

CP PAR A<00>

This bit reflects the parity calculated on the following fields:

- WRITE CHECK
- DEST CP 1
- EN PAGE BOUNDARY CROSS CHECK
- READ CHECK
- ACCESS VIOLATION CHECK
- SECTION REFERENCE
- CACHE WRITE
- CP MODIFY
- DEST CP 0
- DEST CP 1

TB PROBE<00>

This bit specifies a TB PROBE request.

MBOX
MBOX CYCLE CONDITION CODE MICROWORD

ADDRESS FROM IVA<00>

This bit specifies that this is an ADR FROM IBOX VA cycle.

CP LOCK<00>

This bit specifies that this is a CP LOCK request.

ACCESS VIOLATION CHECK<00>

This bit enables the access violation RAM when a READ CHECK or WRITE CHECK is required.

READ CHECK<00>

This bit specifies that a read access violation check is required, and is asserted with ACCESS VIOLATION CHECK.

EN PAGE BOUNDARY CROSS CHECK<00>

This bit enables the Crossing Page Boundary trap.

ENABLE ALIGN CHECK<00>

This bit enables longword alignment references to cause a Longword Alignment trap.

CACHE READ<00>

This bit is asserted whenever the EBox or IBox requests a read from the cache.

-IO ACC ENABLE<00>

When this bit is reset (asserted low) it will enable a trap on IBUFF or OP port read requests to IO space.

DEST CP<1:0>

This bit specifies the destination of the MD RESPONSE to the current request. The field has the following encoding:

- 0 = IBF
- 1 = OP FETCH
- 2 = EBOX
- 3 = IBF FROM OP

CP MODIFY<00>

This bit specifies a CP MODIFY request.

WRITE CHECK<00>

This bit specifies that a write access violation check is required. The bit is asserted with ACCESS VIOLATION CHECK. It is also used whenever an M Bit check is required, and is asserted with CACHE WRITE.

CACHE WRITE<00>

This bit is asserted whenever the EBox or IBox requests a write to the cache.

-NO ROT<00>

When reset (asserted low) this bit inhibits MBox alignment checks for EBox requests on the first reference.

MBOX
MBOX REGISTERS

14.5 MBOX REGISTERS




Figure 14-15 MBox Register Read/Write Data Paths

MBOX
MBOX REGISTERS

ADR	NAME	07	06	05	04	03	02	01	00	
04	RW ADDR CONTROL 1					FORCE CACH MISS	FORCE CYL	CACHE 1 ON	CACHE 0 ON	REG MCA MAPP
14	RW ADDR CONTROL 2			ADR RAM DIAG	EVN TB TAG PAR	GEN TB VAL ERR	GEN EVN WBIT PAR	GEN EVN TAG PAR	GEN EVN PA PAR	
24	RO ADDR STATUS	-TB HIT	BLK HIT	-CACHE 0 TAG MAT	-CACHE HIT	TB VAL ERR	PTE B PAR ERR	PTE A PAR ERR	TB TAG PAR ERR	
34	RW STATUS ERR EN					1	1	1	1	
54	RW PAMM				PAMM CONF A	PAMM CONF 8	PAMM CONF 4	PAMM CONF 2	PAMM CONF 1	RAM MAP9
7C	RW ERROR ADDR	PHYSICAL ADDRESS IN PA LATCH WHEN ERROR DETECTED								ADAB MCA MAP 1-2

MR-13145

Figure 14-16 MAP Module MBox Registers

ADR	NAME	07	06	05	04	03	02	01	00	
0C	RW MCC CONTROL 1							REP ARY ACCESS	INH MEM OVR LP	CRA MCA MCCJ
1C	RW MCC CONTROL 2			WR DAT L/S 1	WR DAT L/S 0	WR C/M 3	WR C/M 2	WR C/M 1	WR C/M 0	
2C	RO MCC STATUS 1	LAT DEST CP 1	LAT DEST CP 0	U CYC TYP 3	U CYC TYP 2	U CYC TYP 1	U CYC TYP 0	WD CNT 3	WD CNT 2	
5C	RO MCC STATUS 2	CP BYTE WRITE	AB BAD DATA ERROR	LABUS STAT 1	LABUS STAT 0	LABUS MSK 3	LABUS MSK 2	LABUS MSK 1	LABUS MSK 0	
18	RW MCC CONTROL 3				INH DMA REQ	CMD BAD PAR	INH ARY CORR REP	IOA DIAG IN PROG	MEM MAN EN	CRD MCA MCCJ
28	RO MCC STATUS 3	CPR PERR B	CPR PERR A	ABUS DAT PERR	ABUS CNTL PERR	ABUS ADR PERR	ABUS LD CMD	ABUS SEL 1	ABUS SEL 0	
38	RW MCC ERROR ENAB	1	1	1	1	1				
58	RO MCC STATUS 4	MULTIPLE ERROR	CACHE TAG PERR	TAG W PERR	W BRCH	CP NXM ERR	LAT BUF ERR	ABUS MEMORY LOCK		

MR-13158

Figure 14-17 MCC Module MBox Registers

MBOX
MBOX REGISTERS

ADR	NAME	07	06	05	04	03	02	01	00	
00	RW DATA CONTROL 1					CACHE PERR 3	CACHE PERR 2	CACHE PERR 1	CACHE PERR 0	UFO MCA MCDU
10	RW DATA CONTROL 2					INH BAD DATA FLAG	DISA ECC	INV CK EN	EN CACH BYTE PERR	
20	RO DATA STATUS	WR BYTE 3 PAR ERR	WR BYTE 2 PAR ERR	WR BYTE 1 PAR ERR	WR BYTE 0 PAR ERR	CACH DAT PERR	CACHE 1 DAT	ANY REFILL	CACH DAT BYT WR PERR	
30	RW DATA ERROR ENABLE	1	1	1	1	1			1	
50	RW DATA CHECK INVERT	DATA INVERT							DATA LWP INVERT	ECC MCA MCDM
60	RO DATA SYNDROME	C0	C6	C5	C4	C3	C2	C1		
70	RO DATA ECC ERROR	DATA LWP INVERT	SYNDROME							
		32	16	8	4	2	1			
		DATA MULTIPLE ERROR	BAD DATA ERROR	DATA SBE	DATA DBE	DATA ADR PAR ERR	1	1		
78	RO DATA ERROR	DATA WORD USED DURING READ							MDP MCA MCD1-3	

MR-10101

Figure 14-18 MCD Module MBox Registers

**MBOX
MBOX REGISTERS**

<u>NAME</u>	<u>T#</u>	<u>ESC</u>	<u>IPR</u>	31	16	15	00
MSTAT1	T15	25		MCC CRA 2C	MCC CRB 28	MAP REG 24	MCD UFO 20
MSTAT2	T16	26			MAP REG 54	MCC CRA 5C	MCC CRB 58
MDECC	T17	27	43		MCD ECC 70	MCD ECC 60	MCD ECC 50
MERG	T18	28	47			MCC CRB 18	MAP REG 14
CSHCIL	T19	29	42				MAP REG 04
MEAR	T1A	2A		MAP ADA/ADB 7C			
MEDR	T1B	2B		MCD MDP 78			
MCCTL			46			MCC CRA 1C	MCC CRA 0C
MDCTL			45			MCD UFO 20	MCD UFO 00
MENA			44		MCC CRB 38	MAP REG 34	MCD UFO 30

MR-13160

Figure 14-19 EBox Microcode Assembly of MBox Registers





Figure 14-20 Physical Address Memory Map


14.6 ABUS INTERFACE



MR13187


Figure 14-21 ABUS Interface Block Diagram

**MBOX
ABUS INTERFACE**




MR-15855

Figure 14-22 ABus CPU Command/Address Cycle Format



MR-15856

Figure 14-23 ABus DMA Command/Address Cycle Format



MR-14979

Figure 14-24 ABus Read/Write Cycle Format

Table 14-3 ABUS Signal Pin Location

Signal Name	ABUS Backplane			CPU Backplane			
	STM 1	SBA 3/5 NT 1	J Conn	J Conn	MCD 16	MAP 17	MCC 18 NT 2
ABUS ADR DATA PTY H	C39	C80	J1803	J1804	C35	A37	
ABUS CMD MSK 0 H	B15	C42	J1621	J1622			C10
ABUS CMD MSK 1 H	B18	C47	J1625	J1626			C12
ABUS CMD MSK 2 H	B17	C40	J1615	J1616			C08
ABUS CMD MSK 3 H	B20	C51	J1631	J1632			C14
ABUS CPU BUF DONE H	C90	C31	J1531	J1532			B36
ABUS CPU BUF ERROR H	C87	C46	J1623	J1624			C09
ABUS CTRL PTY H	C83	C63	J1715	J1716			C37
ABUS DATA ADDRS 0 H	B32	C07	J1433	J1434	A05	A05	
ABUS DATA ADDRS 1 H	B29	C08	J1435	J1436	A07	A07	
ABUS DATA ADDRS 2 H	C28	C09	J1437	J1438	A09	A09	
ABUS DATA ADDRS 3 H	C30	C10	J1439	J1440	A12	A11	
ABUS DATA ADDRS 4 H	C32	C11	J1441	J1442	A20	A19	
ABUS DATA ADDRS 5 H	C34	C18	J1443	J1444	A21	A21	
ABUS DATA ADDRS 6 H	B24	C10	J1511	J1512	A57	A57	
ABUS DATA ADDRS 7 H	B26	C20	J1513	J1514	A60	A59	
ABUS DATA ADDRS 8 H	B25	C21	J1515	J1516	A64	A63	
ABUS DATA ADDRS 9 H	B28	C22	J1517	J1518	A65	A65	
ABUS DATA ADDRS 10 H	B27	C25	J1519	J1520	A70	A69	
ABUS DATA ADDRS 11 H	B30	C26	J1521	J1522	B09	B09	
ABUS DATA ADDRS 12 H	B19	C27	J1523	J1524	B15	B15	
ABUS DATA ADDRS 13 H	B22	C28	J1525	J1526	B17	B17	
ABUS DATA ADDRS 14 H	B21	C29	J1527	J1528	B19	B19	
ABUS DATA ADDRS 15 H	B31	C30	J1529	J1530	B87	B87	
ABUS DATA ADDRS 16 H	B34	C32	J1543	J1444	B57	B57	
ABUS DATA ADDRS 17 H	B35	C35	J1601	J1602	B59	B59	
ABUS DATA ADDRS 18 H	B36	C36	J1603	J1604	B63	B63	
ABUS DATA ADDRS 19 H	B37	C37	J1605	J1606	C71	C37	
ABUS DATA ADDRS 20 H	B38	C38	J1607	J1608	B73	C31	
ABUS DATA ADDRS 21 H	B39	C39	J1613	J1614	C08	C07	
ABUS DATA ADDRS 22 H	B40	C41	J1619	J1620	C10	C09	
ABUS DATA ADDRS 23 H	B41	C49	J1627	J1628	C11	C91	
ABUS DATA ADDRS 24 H	B42	C53	J1639	J1640	C21	C85	
ABUS DATA ADDRS 25 H	B44	C54	J1641	J1642	C24	C77	
ABUS DATA ADDRS 26 H	B45	C66	J1721	J1722	C54	C53	
ABUS DATA ADDRS 27 H	B48	C67	J1723	J1723	C56	C55	
ABUS DATA ADDRS 28 H	B50	C68	J1725	J1726	C57	B28	
ABUS DATA ADDRS 29 H	B52	C71	J1731	J1732	C63	B81	
ABUS DATA ADDRS 30 H	C42	C73	J1733	J7434	C65	C65	
ABUS DATA ADDRS 31 H	B41	C74	J1735	J1736	C69	A77	
ABUS DEAD0 L		A0331	J1509	J1510			A0252
ABUS DEAD1 L		A0531	J1501	J1502			A0240
ABUS DMA DONE 0 H		C0364	J1717	J1718			C39
ABUS DMA DONE 1 H		C0564	J1705	J1706			C29
ABUS DMA DONE 2 H			J1703	J1704			C27
ABUS DMA DONE 3 H			J1707	J1708			C32

Table 14-3 ABUS Signal Pin Location (Cont.)

ABUS IPR RETURN 0 H	C38	C76	J1739	J1740	C0575
ABUS IPR RETURN 1 H	C86	C75	J1737	J1738	C0573
ABUS IPR RETURN 2 H	C37	C77	J1741	J1742	C0576
ABUS IPR RETURN 3 H	C35	C78	J1743	J1744	C0578
ABUS IPR RETURN 4 H	C36	C88	J1805	J1806	C0583
ABUS IPR SELECT 0 H		C0390	J1807	J1808	C0584
ABUS IPR SELECT 1 H		C0590	J1801	J1802	C0581
ABUS IPR SELECT 2 H			J1809	J1810	C0586
ABUS IPR SELECT 3 H			J1541	J1542	C0588
ABUS LEN STAT 0 H	C40	C40	J1729	J1730	C62
ABUS LEN STAT 1 H	C84	C69	J1727	J1728	C60
ABUS MEMORY LOCK H	C89	C05	J1429	J1430	B85
ABUS MSKD CMD H	A48	C04	J1427	J1428	C02
ABUS WR CMD H	A49	C06	J1431	J1432	C04
MCC ABUS CPU BUF SEL H	C85	C55	J1643	J1644	C24
MCC ABUS DMA ERROR H	B49	C60	J1711	J1712	C36
MCC ABUS IOA SELECT 0 H		C0357	J1701	J1702	C25
MCC ABUS IOA SELECT 1 H		C0557	J1609	J1610	C03
MCC ABUS IOA SELECT 2 H			J1617	J1618	C07
MCC ABUS IOA SELECT 3 H			J1611	J1612	C05
MCC ABUS MBOX OUT H	C88	C65	J1719	J1720	C25
MCC ADDRS CTRL 0 L	C31	C62	J1713	J1714	C35
MCC ADDRS CTRL 1 L	C29	C59	J1709	J1710	C03
SB ABUS IOA REQUEST 0 H		C0352	J1635	J1636	C20
SB ABUS IOA REQUEST 1 H		C0552	J1629	J1630	C11
SB ABUS IOA REQUEST 2 H			J1633	J1634	C17
SB ABUS IOA REQUEST 3 H			J1637	J1638	C19

NOTE

1. The pin number under the column titled "SBA 3/5" refers to the signal pin for both slots 3 and 5 unless it is 5 characters, in which case it designates the SBA module in one particular slot.
2. Under the column titled "MCC 18", if the pin designation is 5 characters, then the signal is not connected to the MCC module, but rather to another module in the slot identified by the pin number.
3. The numbers under the module designations refer to the slot number(s) for the particular modules, as slot 1 for the STM module (ABUS backplane) and slot 16 for the MCD module (CPU backplane).

14.7 ABUS INTERFACE SIGNALS

The following sections provide the ABus interface signals and their meanings.

- DATA/ADDRESS <31:00>--During Command/Address cycles, these bi-directional bits will carry a 28-bit physical address between the MBox and SBIA. The most significant 4 bits will be 0.

During read or write data cycles, these bi-directional bits carry the data between the MBox and SBIA.

- DATA/ADDRESS PARITY--Odd parity computed over the 32 bit data/address field.
- COMMAND/MASK <03:00>--During a Command/Address cycle, these bi-directional four bits indicate the ABus command to the MBox or SBIA according to Table 14-4.

Table 14-4 ABus Commands

Command/Mask <03:00>	Command	Command Application
0001	Read	CPU/DMA
0010	Read lock	CPU/DMA
0100	Read modify	CPU
1000	Write	DMA
1101	Write mask	CPU/DMA
1110	Write mask unlock	CPU/DMA

During write data cycles these bits are the MASK bits, and are used to specify which byte(s) are written. If a bit is set, the corresponding byte is written.

During read data return cycles, the MASK bits are not used.

- DATA LENGTH/STATUS <1:0>--These bits indicate the data length during Command/Address cycles according to Table 14-5 and Table 14-6.

Table 14-5 Length/Status for CPU Command/Address Cycle

Length/Status <01:00>	CPU Command/Address Function
01	Even Word
10	Odd Word
11	Longword

Table 14-6 Length/Status for DMA Command/Address Cycle

Length/Status <01:00>	DMA Command/Address Function
00	Longword (4 bytes)
01	Quadword (8 bytes)
10	Octaword (16 bytes)

NOTE

The SBIA only supports Longword and Quadword transfers.

- During Data cycles, these bits indicate the status of the data. The Status bits only have meaning during a CPU read data cycle. Normally zero, they will be "11" to indicate bad data, if the SBIA received Read Data Substitute (RDS), during the SBI read data cycle (SBI data cycle mask bits = 0010).
- CONTROL PARITY--Odd parity computed over the Length/Status and Command/Mask bits.
 - MSKED CMD--This bit, when set, tells the MBox that the ABus command is for a masked operation. It allows the MBox microcode to branch before decoding the command field in the command/address.
 - ABUS WR CMD--Like the MSKED CMD, ABUS WR CMD allows the MBox microcode to branch before decoding the command field in the command/address. This bit indicates that the ABus command is for a write operation.
 - CLK SBA[N] CLOCK5 141 B[D]--Each I/O adapter receives clock signals from the KA86 system clock module to control the ABus interface logic.
 - CLK SBA[N] RESET--A reset signal to each of the I/O adapters used to initialize the clock generation and distribution logic.
 - IOA REQUEST <03:00>--One line from each I/O adapter used to request the MBox to service a DMA.
 - DMA DONE <03:00>--A signal to each of the I/O adapters to signify that the MBox has completed the DMA transfer. Only the I/O adapter that had a DMA being serviced will receive the DMA DONE. In case of a DMA error, DMA DONE will be sent with DMA ERROR.
 - DMA ERROR--A signal to each of the I/O adapters to indicate that the MBox has detected an error while processing the DMA. DMA ERROR is sent at the same time as DMA DONE.

- **ABUS ADDR CTRL <01:00>**--These two signals are used in the selected I/O adapter to control the loading, holding, or incrementing of the DC022 register file address, according to Table 14-7. These bits are asserted low, and in the table, a logic 1 indicates an asserted signal.

Table 14-7 Address Control of the DC022 Register File

ADDRS CTRL <01:00>	DC022 Function
0 0	Hold address
0 1	Increment address
1 0	Not used
1 1	Load address

- **MBOX OUT**--MBox OUT controls whether the I/O adapter register file, for the I/O adapter selected by ABUS IOA SELECT, will be read or written. It is also used with ABUS CPU BUF SEL to control the two least significant bits of the DC022 address being loaded by the MBox (see Table 14-8). If ABUS MBOX OUT is asserted data will be driven by the MBox to the I/O adapter. If it is not asserted, the I/O adapter will be sending data to the MBox.
- **ABUS CPU BUF SEL**--This signal is used along with ABUS MBOX OUT, to control the register file address loaded by the MBox in the selected I/O adapter (see Table 14-8).

Table 14-8 DC022 Register File Address Control

ABUS CPU BUF SEL	ABUS MBOX OUT	Register File ECL Address	Comments
0	0	**00	Prepare to read the DMA C/A
0	1	**00	Prepare to write a CPU C/A or an ABUS diagnostic cycle
1	0	0011	Prepare to read the CPU read data return word
1	1	0010	Prepare to write the CPU C/A

** The upper two bits are determined by the DMA transaction buffer that requested service.

MBOX
ABUS INTERFACE SIGNALS

- CPU BUF DONE--Asserted by the I/O adapter to inform the MBox that a CPU read or write transaction is complete. A CPU write is complete when the NEXUS has acknowledged the command/address and write data. A read is complete when the read data is placed in the DC022 register file. CPU BUF DONE will be asserted if CPU BUF ERROR is asserted.
- CPU BUF ERROR--CPU BUF ERROR is asserted by the selected I/O adapter to indicate to the MBox that an error was detected during a CPU initiated I/O transaction. It indicates that the I/O adapter aborted the command.
- MEMORY LOCK--A bi-directional line between the MBox and I/O adapters to signal that an interlock operation is in progress.
- ABUS IPR RETURN <04:00>--The encoded value of the highest priority interrupt the I/O adapter has pending, when the I/O adapter is polled by the EBox with the assertion of ABUS IPR SELECT[N].
- ABUS IPR SELECT[N]--ABUS IPR SELECT is used by the EBox to poll each of the I/O adapters for pending interrupts. The EBox polls the adapters in modulo 4 order.
- ABUS ENABLE--This bit is controlled by the console with MCSR1<01>. When this bit is asserted, the I/O adapters are enabled.
- ABUS DEAD[N]--This bit is asserted as a result of the assertion of SBI FAIL and used to forward a reboot request from another processor on the CI to the console, or to inform the console of an SBI power failure.
- AC LO--A signal from the EMM to the I/O adapters used to indicate impending power failures. It is used by the I/O adapter to assert BUS SBI FAIL on the SBI.
- DC LO--DC LO from the EMM is used to assert BUS SBI DEAD and force an initialize within the I/O adapters.

14.8 MBOX TESTPOINTS

14.8.1 MBox MicroPC and ABUS Control Testpoints

Table 14-9 is a list of MBox microPC and ABUS control testpoints that may be used when troubleshooting MBox microcode and ABUS control problems.

Table 14-9 MBox MicroPC and ABus Control Testpoints

Channel	Signal Name	Print	Section/Slot/Pin
F	MUPC 0 H (LSB)	MCCD-H	Exx.13 (ECL)
E	MUPC 1 H	MCCD-H	Exx.14 (ECL)
D	MUPC 2 H	MCCD-H	Exx.15 (ECL)
C	MUPC 3 H	MCCD-H	Exx.16 (ECL)
B	MUPC 4 H	MCCD-H	Exx.17 (ECL)
A	MUPC 5 H	MCCD-H	Exx.09 (ECL)
9	MUPC 6 H	MCCD-H	Exx.10 (ECL)
8	MUPC 7 H (MSB)	MCCD-H	Exx.11 (ECL)
7	ABUS IOA REQ 0 H	SBA5	C03.52 (ECL)
or	ABUS IOA REQ 1 H	SBA5	C05.52 (ECL)
6	ABUS IOA SEL 0 H	SBA5	C03.56 (ECL)
or	ABUS IOA SEL 1 H	SBA5	C05.56 (ECL)
5	ABUS ADR CTL 1 H	SBA5	C03.59 (ECL)
4	ABUS ADR CTL 0 H	SBA5	C03.62 (ECL)
3	ABUS MBOX OUT H	SBA5	C03.65 (ECL)
2	ABUS WR CMD H	SBA5	C03.06 (ECL)
1	----	----	-----
0	SS31 FAULT OR ERROR H	SS31	B02.49 (TTL)
CLK	CLOCK	MCCK	E51.12 (ECL)

NOTE

1. "Exx" indicates any RAM chip for MBox microcode.
2. To display the MBox uPC in HEX, MUPC 7 is the MSB and MUPC 0 is the LSB.

14.8.2 ABus/SBIA Testpoints

Table 14-10 contains a list of ABus signals and SBI FAULT, which can be used when troubleshooting SBI FAULT/ABus problems.

Table 14-10 ABus/SBIA Testpoints

Channel	Signal Name	Print	Section/Slot/Pin
0	SS31 FAULT OR ERROR H	SBS	B02.49 (TTL)
1	ABUS IOA REQ H	SBA	C03.52 (ECL)
2	ABUS IOA SELECT H	SBA	C03.56 (ECL)
3	ABUS ADR CTL 1 L	SBA	C03.59 (ECL)
4	ABUS ADR CTL 0 L	SBA	C03.62 (ECL)
5	ABUS MBOX OUT H	SBA	C03.65 (ECL)
6	ABUS WR CMD H	SBA	C03.06 (ECL)
7	ABUS MASKED CMD H	SBA	C03.04 (ECL)
8	ABUS DATA/ADR 00 H	SBA	C03.07 (ECL)
9	ABUS DATA/ADR 01 H	SBA	C03.08 (ECL)
A	ABUS DATA/ADR 02 H	SBA	C03.09 (ECL)
B	ABUS DATA/ADR 03 H	SBA	C03.10 (ECL)
C			
D			
E	ABUS BUF ERROR H	SBA	C03.46 (ECL)
F			

MBOX
CP Port Testpoints

14.8.3 CP Port Testpoints

Table 14-11 contains a list of CP port testpoints.

Table 14-11 CP Port Testpoints

Channel	Signal Name	Print	Section/Slot/Pin
0	MCC OP PA ACK A H	MCC6	B18.39
1	MCC EBOX PA ACK A H	MCC6	B18.41
2	MCC IBF PA ACK H	MCC6	B18.37
3	MCC MD RESP C H	MCC5	C18.75
4	MCC PORT STAT CODE 3 H	MCC7	B18.20
5	MCC PORT STAT CODE 2 H	MCC7	B18.25
6	MCC PORT STAT CODE 1 H	MCC7	B18.11
7	MCC PORT STAT CODE 0 H	MCC7	B18.18

CHAPTER 15

SBIA

15.1 SBIA GENERAL INFORMATION

The SBIA is configured/cleared during CPU initialization by the INIT/PAMM console command. This command is required to reset the SBIA. The SBIA must be configured prior to attempting any access to the SBI for an UNJAM or depositing/examining nexus control and status registers. Therefore, to reset the I/O world, the following sequence of console commands must be executed.

- >>>INIT/PAMM
- >>>UNJAM
- >>>INIT

For an example of SBI SILO interpretation, refer to Chapter 20, SBIA SBI SILO Register description.

15.2 SBIA JUMPER SETTINGS

The SBIA has two DC101 chips used for SBI arbitration. One DC101 is used to gain control of the SBI for CPU deposits/examines of SBI nexus control and status registers. The other DC101 is used to gain control of the SBI to transfer the DMA read word to the applicable nexus. Table 15-1 shows the jumper information for the SBIA DC101s.

Table 15-1 SBIA DC101 TR Jumpers

TR SEL 8 4 2 1	DEVICE TR	Transmit TR Jumper Needed	Jumper from XMIT TR L, C83* to BUS SBI TR ___ on Pin___
L L L L	16	No	-- ---
L L L H	15	Yes	15 C81
L L H L	14	Yes	14 C77
L L H H	13	Yes	13 C73
L H L L	12	Yes	12 C75
L H L H	11	Yes	11 C71
L H H L	10	Yes	10 C69
L H H H	09	Yes	09 C67
H L L L	08	Yes	08 C65
H L L H	07	Yes	07 C63
H L H L	06	Yes	06 C59

SBIA
SBIA JUMPER SETTINGS

Table 15-1 SBIA DC101 TR Jumpers (Cont)

TR SEL 8 4 2 1	DEVICE TR	Transmit TR Jumper Needed	Jumper from XMIT TR L, C83* to BUS SBI TR __ on Pin __
H L H H	05	Yes	05 C57
H H L L	04	Yes	04 C55
H H L H	03	Yes	03 C51
H H H L	02†	Yes	02 C53
H H H H	01‡	Yes	01 C47

*Jumper connections made on SBS backplane slots

†Normal configuration for CPU DC101

‡Normal configuration for DMA DC101

15.3 SBIA BLOCK DIAGRAM





Figure 15-1 SBIA Block Diagram

15.4 VAX 86XX PHYSICAL MEMORY ADDRESS ALLOCATION



MR-14938

Figure 15-2 VAX 86XX Physical Memory Address Allocation

SBIA
VAX 86XX PHYSICAL MEMORY ADDRESS ALLOCATION

HEX BYTE ADD		
2X00 0000	TR00 8 KBYTES	NEXUS REGISTERS 128 KBYTES
2X00 1FFF		
2X00 2000	TR01 8 KBYTES	
2X00 3FFF		
2X00 4000	TR02 8 KBYTES	
2X00 5FFF		
2X00 6000	TR03 8 KBYTES	
2X00 7FFF		
2X00 8000	TR04 8 KBYTES	
2X00 9FFF		
2X00 A000	TR05 8 KBYTES	
2X00 BFFF		
2X00 C000	TR06 8 KBYTES	
2X00 DFFF		
2X00 E000	TR07 8 KBYTES	
2X00 FFFF		
2X01 0000	TR08 8 KBYTES	384 KBYTES
2X01 1FFF		
2X01 2000	TR09 8 KBYTES	
2X01 3FFF		
2X01 4000	TR10 8 KBYTES	
2X01 5FFF		
2X01 6000	TR11 8 KBYTES	
2X01 7FFF		
2X01 8000	TR12 8 KBYTES	
2X01 9FFF		
2X01 A000	TR13 8 KBYTES	
2X01 BFFF		
2X01 C000	TR14 8 KBYTES	
2X01 DFFF		
2X01 E000	TR15 8 KBYTES	
2X01 FFFF		
2X02 0000	UNASSIGNED	
2X07 FFFF		512 KBYTES
2X08 0000	SBIA REGISTERS	
2X0F FFFF		256 KBYTES
2X10 0000	UNIBUS 0	
2X13 FFFF		256 KBYTES
2X14 0000	UNIBUS 1	
2X17 FFFF		256 KBYTES
2X18 0000	UNIBUS 2	
2X1B FFFF		256 KBYTES
2X1C 0000	UNIBUS 3	
2X1F FFFF		30 MBYTES
2X20 0000	UNASSIGNED	
21FF FFFF		
OR 23FF FFFF		
X = 0 FOR SBIA 0 X = 2 FOR SBIA 1		

MR-14939

Figure 15-3 I/O Adapter Physical Address Allocation

15.4.1 SBIA Register Addresses


Table 15-2 SBIA Register Addresses

Register Name	Hex Byte Address
Configuration Register	2X080000
Control Status Register	2X080004
Error Summary Register	2X080008
Diagnostic Control Register	2X08000C
DMAI Command/Address Register	2X080010
DMAI ID Register	2X080014
DMAA Command/Address Register	2X080018
DMAA ID Register	2X08001C
DMAB Command/Address Register	2X080020
DMAB ID Register	2X080024
DMAC Command/Address Register	2X080028
DMAC ID Register	2X08002C
SBI Silo	2X080030
SBI Error Register	2X080034
SBI Timeout Address Register	2X080038
SBI Fault/Status Register	2X08003C
SBI Silo Comparator	2X080040
SBI Maintenance Register	2X080044
SBI Unjam Register	2X080048
SBI Quadclear Register	2X08004C
Vector Registers	2X080080
↓	↓
V	V
Vector Registers	2X0800B8

NOTE

For SBIA 0, X = 0 and for SBIA 1, X = 2

15.5 SBI PROTOCOL



MR-14968

Figure 15-4 SBI Signal Names

Table 15-3 SBI Signal Names and Description

Arbitration Group

Arbitration Field [TR<15:00>] -- Establishes a fixed priority among nexus for access to and control of the information transfer path.

Information Transfer Group

Information Field [B<31:00>] -- Bidirectional lines that transfer data, command/address, and interrupt information between nexus.

Mask Field [M<03:00>] -- Encoded to indicate that a particular byte within the data field is to be read or written. With the read data, the mask bits indicate if the data is correct or in error.

Identifier Field [ID<02:00>] -- Indicates the logical source or destination of information contained in B<31:00>.

Tag Field [TAG<02:00>] -- Determines if the SBI cycle is for a command/address, read data, write data, or ISR.

Response Group

Confirmation Field [CNF<01:00>] -- The receiving nexus specifies its response to an SBI cycle:

1. 00 = no response
2. 01 = acknowledge
3. 10 = busy
4. 11 = error

Function Field [F<03:00>] -- Specifies the command code. The function field is bits <31:28> of the command/address (Figure 15-6).

Parity Field [P<01:00>] -- Indicates even parity over the SBI information. P0 is computed over the information in B<31:00> while P1 is computed over M<03:00>, ID<04:00>, and TAG<02:00> (Figure 15-5).

Interrupt Request Group

Request Field [REQ<07:04>] -- Each signal represents a level of priority whereby a nexus requests interrupt service.

Alert Field [ALERT] -- A signal that allows SBI memory to interrupt due to a power loss.

Table 15-3 SBI Signal Names and Description (Cont)

Control Group

Clock Field [CLOCK] -- Six control lines that provide the clock signals necessary to synchronize SBI activity.

Fail Field [FAIL] -- The assertion of AC LO within a nexus causes the assertion of SBI FAIL.

Dead Field [DEAD] -- The assertion of DC LO within a nexus causes the assertion of SBI DEAD.


Unjam Field [UNJAM] -- A reset signal to all SBI nexus.

Interlock Field [INTLK] -- A signal that indicates that a shared location is being modified by a nexus.

Unused Signals

Multiprocessor [MP<02,01>] -- Two unused lines

Spare [SPARE<01:00>] -- Two additional unused lines




MR-14970

Figure 15-5 SBI Command/Address Format

MASK	FUNCTION	ADDRESS
M <3:0>	F <3:0>	A <27:00>
MASK USE	FUNCTION CODE	FUNCTION DEFINITION
IGNORED	0000	RESERVED
USED	0001	READ MASKED
USED	0010	WRITE MASKED
IGNORED	0011	RESERVED
USED	0100	INTERLOCK READ MASKED
IGNORED	0101	RESERVED
IGNORED	0110	RESERVED
USED	0111	INTERLOCK WRITE MASKED
IGNORED	1000	EXTENDED READ
IGNORED	1001	RESERVED
IGNORED	1010	RESERVED
USED	1011	EXTENDED WRITE MASKED
IGNORED	1100	RESERVED
IGNORED	1101	RESERVED
IGNORED	1110	RESERVED
IGNORED	1111	RESERVED


MR-14971

Figure 15-6 SBI Command Codes



MR-14969

Figure 15-7 SBI Parity Field Configuration




MR-14972

Figure 15-8 SBI Read Data Formats


SBIA

SBI -- I/O BACKPLANE INTERCONNECTIONS



MR-14973

Figure 15-9 SBI Write Data Format



MR-14974

Figure 15-10 SBI Interrupt Summary Formats

15.6 SBI -- I/O BACKPLANE INTERCONNECTIONS

Table 15-4 lists the cable connectors associated with the SBI cables from the ABus backplane to the I/O backplane and for expansion of the SBIs from the I/O backplane. See also Figure 15-11 for locations of the cable connectors. Table 15-5 lists the SBI signals along with their backplane pin for the cable from the ABus backplane to the I/O backplane and from the I/O backplane to an SBI expansion cabinet.

Table 15-4 SBI Cable Interconnections

Row	(SBI Expansion)		ABus Backplane to I/O Backplane			
	I/O Backplane		I/O Backplane		ABus Backplane	
	SB11 OUT	SB10 OUT	SB11 IN	SB10 IN	SB10	SB11
A	J47	J41	J19	J25	J25	J19
B	J48	J42	J20	J26	J26	J20
C	J49	J43	J21	J27	J27	J21
D	J50	J44	J22	J28	J28	J22
E	J51	J45	J23	J29	J29	J23
F	J52	J46	J24	J30	J30	J24
				+---SB10---+		
				+-----SB11-----+		



Figure 15-11 I/O Backplane Assemblies

SBIA
SBI -- I/O BACKPLANE INTERCONNECTIONS

Table 15-5 SBI Signal and Backplane Pins

Signal Name Note 1	ABus Out Note 2	I/O In Note 2	I/O Out Note 3	Nexus Note 4
B00	J25 B	J25 A	J41 B	AB1
B01	J25 D	J25 C	J41 D	AC1
B02	J25 J	J25 H	J41 J	AD1
B03	J25 R	J25 D	J41 R	AE1
B04	J25 BB	J25 AA	J41 BB	AM1
B05	J25 FF	J25 EE	J41 FF	AN1
B06	J25 NN	J25 MM	J41 NN	AP1
B07	J25 DD	J25 CC	J41 DD	AP2
B08	J25 LL	J25 KK	J41 LL	AS2
B09	J25 RR	J25 PP	J41 RR	AT2
B10	J25 TT	J25 SS	J41 TT	AU1
B11	J25 VV	J25 UU	J41 VV	AU2
B12	J26 L	J26 K	J42 L	BF2
B13	J26 T	J26 S	J42 T	BH2
B14	J26 N	J26 M	J42 N	BJ1
B15	J26 X	J26 W	J42 X	BJ2
B16	J26 JJ	J26 HH	J42 JJ	BS2
B17	J26 RR	J26 K	J42 L	BT2
B18	J26 TT	J26 SS	J42 TT	BU1
B19	J26 VV	J26 UU	J42 VV	BU2
B20	J27 D	J27 C	J43 D	CB1
B21	J27 J	J27 H	J43 J	CC1
B22	J27 N	J27 M	J43 N	BU1
B23	J27 F	J27 E	J43 F	CD2
B24	J27 BB	J27 AA	J43 BB	CM1
B25	J27 FF	J27 EE	J43 FF	CN1
B26	J27 LL	J27 KK	J43 LL	CP1
B27	J27 DD	J27 CC	J43 DD	CP2
B28	J27 JJ	J27 HH	J43 JJ	CS2
B29	J27 NN	J27 MM	J43 NN	CT2
B30	J27 RR	J27 PP	J43 RR	CU1
B31	J27 VV	J27 UU	J43 VV	CU2
FAIL	J27 TT	J27 SS	J43 TT	CV2
DEAD	J28 D	J28 C	J44 D	DA1
ID0	J28 DD	J28 CC	J44 DD	DP2
ID1	J28 LL	J28 KK	J44 LL	DS2
ID2	J28 RR	J28 PP	J44 RR	DT2
ID3	J28 TT	J28 SS	J44 TT	DU1
ID4	J28 VV	J28 UU	J44 VV	DU2
M0	J28 B	J28 A	J44 B	DB1
M1	J28 F	J28 E	J44 F	DC1
M2	J28 L	J28 K	J44 L	DD1
M3	J28 J	J28 H	J44 J	DD2

Table 15-5 SBI Signal and Backplane Pins (Cont)

P0	J28 N	J28 M	J44 N	DV2
P1	J28 T	J28 S	J44 T	DH2
SPARE 0	J28 R	J28 P	J44 R	
SPARE 1	J28 Z	J28 Y	J44 Z	
TAG0	J28 BB	J28 AA	J44 B	DM1
TAG1	J28 FF	J28 EE	J44 FF	DN1
TAG2	J28 NN	J28 MM	J44 NN	DP1
ALERT	J29 LL	J29 KK	J45 LL	EP2
CNF0	J29 RR	J29 PP	J45 RR	ES2
CNF1	J29 VV	J29 UU	J45 VV	ET2
FAULT	J29 TT	J29 SS	J45 TT	EU1
MP1	J29 FF	J29 EE	J45 FF	EM1
MP2	J29 DD	J29 CC	J45 DD	EN1
PCLK H	J29 R	J29 P	J45 R	EH2
PCLK L	J29 Z	J29 Y	J45 Z	EJ1
PDCLK H	J29 X	J29 W	J45 X	EJ2
PDCLK L	J29 BB	J29 AA	J45 BB	EK2
REQ 4	J29 B	J29 A	J45 B	EB1
REQ 5	J29 F	J29 E	J45 F	EC1
REQ 6	J29 N	J29 M	J45 N	ED1
REQ 7	J29 D	J29 C	J45 D	ED2
TP H	J29 T	J29 S	J45 T	EF1
TP L	J29 J	J29 H	J45 J	EF2
UNJAM	J29 NN	J29 MM	J45 NN	EP1
INTLK	J30 B	J30 A	J46 B	FA1
TR00	J30 D	J30 C	J46 D	FB1
TR01	J30 F	J30 E	J46 F	FC1
TR02	J30 J	J30 H	J46 J	FD1
TR03	J30 L	J30 K	J46 L	FE1
TR04	J30 N	J30 M	J46 N	FF2
TR05	J30 T	J30 S	J46 T	FH2
TR06	J30 V	J30 U	J46 V	BFJ1
TR07	J30 X	J30 W	J46 X	FJ2
TR08	J30 Z	J30 Y	J46 Z	FM1
TR09	J30 DD	J30 CC	J46 DD	FN1
TR10	J30 FF	J30 EE	J46 FF	FP1
TR11	J30 JJ	J30 HH	J46 JJ	FP2
TR12	J30 RR	J30 MM	J46 NN	FS2
TR13	J30 LL	J30 KK	J46 LL	FT2
TR14	J30 TT	J30 SS	J46 TT	FU1
TR15	J30 VV	J30 UU	J46 VV	FU2

NOTES

1. Signal names are prefixed by "BUS SBI".
2. J numbers shown are for SBI 0. For SBI 1, subtract 6.
3. J numbers shown are for SBI 0. For SBI 1, add 6.

SBIA

SBI -- I/O BACKPLANE INTERCONNECTIONS

4. Standard signal pins for slot 1 of any nexus, including I/O backplane slots 6, 11, and 16.
 5. All signals are asserted low when true.
 6. All signals are TTL except PCLK, PDCLK, and TP, which are ECL.
 7. Nexus power and ground pins are:
 - +5 V at A2 and V1
 - Gnd at C2, H1, N2, and T1
-

15.7 SBI FAULT DEFINITIONS

Table 15-6 lists the SBI faults and their definitions.

Table 15-6 SBI Fault Definitions

Parity Error -- An information path error generated by one or more nexus when the parity calculated over the received data does not agree with the received parity.

Write Sequence Fault -- When a nexus, which received a write masked, extended write masked, or interlock write masked command on the previous cycle, does not receive the write data in the current cycle.

Unexpected Read Data -- When a nexus receives read data, but did not receive a command for extended read, read masked, or interlock read masked on the previous cycle.

Interlock Sequence Fault -- When a nexus receives an interlock write masked command and interlock has not been set by an interlock read masked command.

Multiple Transmitter Fault -- When a transmitting nexus receives an ID different from the transmitted ID.

15.8 SBI CONFIRMATION AND FAULT DECISION FLOW

Figure 15-12 is a flow chart that indicates how SBI nexus check for SBI faults and the decisions involved with sending SBI confirmation, SBI CNF<01:00>.




Figure 15-12 SBI Confirmation and Fault Decision Flow

CHAPTER 16

SBI

16.1 SBI NEXUS ADDRESS INFORMATION

This chapter contains information on SBI nexus addressing, the CI780, DR780, DW780, and RH780. There will be a section covering the module utilization, block diagrams, and jumper selection for each of the devices.

16.1.1 SBI Nexus Addressing

Table 16-1 contains a list of SBI nexus base addresses as a function of the TR number. The address is listed for each SBIA. If the address for Unibus address space is desired, see Figure 15-3.

Table 16-1 SBI Nexus Base Address

TR#	SBIA 0		SBIA 1	
	Byte Address	Longword Address	Byte Address	Longword Address
1	20002000	8000800	22002000	8800800
2	20004000	8001000	22004000	8801000
3	DW0 20006000	8001800	DW4 22006000	8801800
4	DW1 20008000	8002000	DW5 22008000	8802000
5	DW2 2000A000	8002800	DW6 2200A000	8802800
6	DW3 2000C000	8003000	DW7 2200C000	8803000
7	2000E000	8003800	2200E000	8803800
8*	RH0 20010000	8004000	RH4 22010000	8804000
9*	RH1 20012000	8004800	RH5 22012000	8804800
10*	RH2 20014000	8005000	RH6 22014000	8805000
11*	RH3 20016000	8005800	RH7 22016000	8805800
12	20018000	8006000	22018000	8806000
13	2001A000	8006800	2201A000	8806800
14	2001C000	8007000	2201C000	8807000
15	2001E000	8007800	2201E000	8807800

*RH780

16.1.2 SBI Nexus Address Generation

An SBI nexus physical byte address (the CPU address) may be calculated using Figure 16-1 and the following steps.

1. Fill in bits <26:25> of Figure 16-1 with the I/O adapter number.
2. Fill in bits <16:13> of Figure 16-1 with the TR number of the nexus.

SBI
SBI Nexus Address Generation

3. Add the register offset (see the register description in Chapter 20 for the register offset) to the bit combination derived from the first two steps.




Figure 16-1 SBI Nexus Address Generation

Table 16-2 SBI Nexus Address Generation Bit Descriptions

Bit Number	Description
<26:25>	I/O Adapter Number <div style="margin-left: 20px;"> 0 = SBIA0 1 = SBIA1 2 = currently unused 3 = currently unused </div>
<16:13>	TR Number - The TR level of the addressed NEXUS
<12:02>	Register Offset - The register offset within the nexus I/O address space. These bits refer to the registers position in SBI address space. When calculating the physical byte address, do not place the register offset into these bits, they are to be added.

Example 16-1 Nexus Address Calculation

Generate the physical byte address of the USAR (UBA Status Register, which has a register offset of 8) for DW0 (TR 3) on SBIA 0. Filling in bits <26:25> with 00 (I/O adapter number) and <16:13> with 0011 (TR3) provides a base address of 20006000. Adding the register offset of 8 to the base address gives us a physical byte address of 20006008.

16.1.3 SBI Nexus Interrupt Vector Generation




Figure 16-2 SBI Interrupt Vector Generation

Table 16-3 SBI Vector Generation Bit Description

Bit Number	Description
<10:09>	I/O Adapter Number <div style="margin-left: 20px;"> 0 = SBIA0 1 = SBIA1 2 = currently unused 3 = currently unused </div>
<07:06>	BR/REQ LEVEL - The interrupt request level or BR level. <div style="margin-left: 20px;"> 00 = BR 4 01 = BR 5 10 = BR 6 11 = BR 7 </div>

Table 16-3 SBI Vector Generation Bit Description (Cont)

Bit Number	Description
<05:02>	TR Number - The TR number of the NEXUS

Example 16-2 Interrupt Vector generation

An interrupt from a BR4 Unibus device on DW0 (TR = 3) will generate an interrupt vector of 10C.

16.2 CI780




Figure 16-3 CI780 I/O Backplane Module Utilization

MR 15862




Figure 16-4 CI780 Block Diagram (Sheet 1 of 2)






Figure 16-4 CI780 Block Diagram (Sheet 2 of 2)



- NOTES:
- CONN J1 J6 ARE SBI BUS OUT CONN
 - CONN J7 J12 ARE SBI BUS IN CONN
 - EXTRA JUMPER ITEM 30 TO BE SHIPPED IN ITEM 42 PLASTIC BAG

CI780 BACKPLANE IN SBI EXPANSION CABINET



CI780 JUMPER LOCATION ON VAX 8600 I/O BACKPLANE

Figure 16-5 CI780 Backplane Jumper Locations

16.2.1 CI780 Backplane Jumper Settings

Table 16-4 contains a list of the CI780 jumpers with jumper names, and a description of the jumpers.

Table 16-4 CI780 Backplane Jumpers

CI780 Jumpers

J17 or J31	Signal Name	Description
W1	LT Jumper	In = 2048 SBI cycles before CXTMO Out = 512 SBI cycles before CXTMO
W2	TR Jumper D	
W3	TR Jumper C	
W4	TR Jumper A	
W5	PRI Jumper 0	
W6	PRI Jumper 1	
W7	TR Jumper B	
W8	Panic Mode Jumper	In = Panic mode disabled Out = Panic mode enabled
W9	Boot Jumper 3 H	
W10	Boot Jumper 4 H	
W11	Reserved	
W12	Boot Jumper 0 H	
W13	Boot Jumper 2 H	
W14	Disable Arb	In = No arbitration on CI before transmission Out = Normal CI arbitration
W15	Extend HDR/TRLR	In = Extends header/trailer Out = Normal header/trailer
W16	Alter Delay Time	In = Long delta time Out = Short delta time
W17	Extend ACK Timeout	In = Long timeout Out = Short timeout

NOTE

For the SBI expansion cabinet, use J17, and for the VAX 8600/8650 I/O backplane, use J31.

Interrupt/Priority Level

W5	W6	BR Level
0	0	4
0	1	5
1	0	6
1	1	7

0 = Jumper out
1 = Jumper in

SBI
CI780 Backplane Jumper Settings

Table 16-4 CI780 Backplane Jumpers (Cont.)

Boot Timer

W9	W13	W10	W12	Time (Seconds)
0	0	0	0	0000
0	0	0	1	0100
0	0	1	0	0200
0	0	1	1	0300
0	1	0	0	0400
0	1	0	1	0500
0	1	1	0	0600
0	1	1	1	0700
1	0	0	0	0800
1	0	0	1	0900
1	0	1	0	1000
1	0	1	1	1100
1	1	0	0	1200
1	1	0	1	1300
1	1	1	0	1400
1	1	1	1	1500

0 = Jumper in
1 = Jumper out

TR Level

W2	W3	W7	W4	TR Level
0	0	0	0	1
0	0	0	1	2
0	0	1	0	3
0	0	1	1	4
0	1	0	0	5
0	1	0	1	6
0	1	1	0	7
0	1	1	1	8
1	0	0	0	9
1	0	0	1	10
1	0	1	0	11
1	0	1	1	12
1	1	0	0	13
1	1	0	1	14
1	1	1	0	15
1	1	1	1	16

0 = Jumper out
1 = Jumper in

Table 16-4 CI780 Backplane Jumpers (Cont.)

SBI TR Arbitration

For	Wirewrap from CXX-53 (BUS TR L) To
TR1	CXX-57
TR2	CXX-63
TR3	CXX-62
TR4	CXX-65
TR5	CXX-69
TR6	CXX-71
TR7	CXX-73
TR8	CXX-75
TR9	CXX-77
TR10	CXX-81
TR11	CXX-83
TR12	CXX-85
TR13	CXX-86
TR14	CXX-87
TR15	CXX-88

For SBI expansion cab, X = C01
For I/O backplane, X = C24

NOTES

1. The standard configuration is TR4 with all other jumpers out.
 2. Other wirewrap needed:
 - a. Expansion cab: Jumper B05-05 to B05-06
 - b. I/O backplane: Jumper B24-05 to B24-06
 3. The jumper selection for TR level must match the wirewrap for TR arbitration.
 4. TR0 is reserved for holding the SBI.
-

16.3 DR780

	6	5	4	3	2	1
A	DR780 PADDLE CARD					A
B						B
C						C
D						D
E	DDIP		SILO MODULE	MICROPROCESSOR	CONTROL BOARD	
F	M3046 BLANK	DSM	DUP	DCB	DSC	SBI INTERFACE
		M8299	M8298	M3297	M8296	


NOTES:

1. VIEW FROM MODULE SIDE.
2. SBI EXPANSION CAB USE.
3. M9046 PADDLE CARD MOUNTS ON PIN SIDE OF BACKPLANE.

MR 16153

Figure 16-6 DR780 Module Utilization

DR780 SBI CONTROL (DSC) 48296



MR 167B7

Figure 16-7 DR780 Block Diagram (Sheet 1 of 4)




Figure 16-7 DR780 Block Diagram (Sheet 2 of 4)




Figure 16-7 DR780 block Diagram (Sheet 3 of 4)





Figure 16-7 DR780 block Diagram (Sheet 4 of 4)



MR-14680

Figure 16-8 DR780 Backplane Jumper Location


Table 16-5 DR780 Backplane Jumper Settings and Wirewrap Selection

TR No.	TR SELD L	TR SELC L	TR SELB L	TR SELA L	Wirewrap F02L2 To
1	--	--	--	--	F02C1
2	--	--	--	I	F02D1
3	--	--	I	--	F02E1
4	--	--	I	I	F02F2
5	--	I	--	--	F02H2
6	--	I	--	I	F02J1
7	--	I	I	--	F02J2
8	--	I	I	I	F02M1
9	I	--	--	--	F02N1
10	I	--	--	I	F02P1
11	I	--	I	--	F02P2
12	I	--	I	I	F02S2
13	I	I	--	--	F02T2
14	I	I	--	I	F02U1
15	I	I	I	--	F02U2
16	I	I	I	I	--

NOTES

1. An "I" in the table indicates that a jumper is installed.
2. The first DR780 is at TR 13, and has W4 and W3 installed. The second DR780 is at TR 14 and has W4, W3, and W1 installed.
3. The first DR780 has a wirewrap from F02L2 to F02T2. The second DR780 has a wirewrap from F02L2 to F02U1
4. W5, W6: For a BR of 6, W5 is in and W6 is out.
5. W7, MSEL Jumper Select: If the DR780 is not going to perform DDI arbitration, or be its master, then W7 is installed. If the DR780 is to be the master device, the jumper is not installed.
6. W8, DI Clock Jumper Select: If the DR780 is to be the clock source for the Data Interconnect (DI), then jumper W8 is not installed. If the customers device is to be the clock source for the DR780 Device Interconnect (DDI), then jumper W8 is installed.
7. W9 - W12: These jumpers are not used by the DR780, but may contain spare jumpers for installation in W8 or W7.
8. Disable Wirewrap Selection: If the DR780 interface is device A, wirewrap E03R1 to E03T2 and E03R2 to E03F2. Otherwise, wirewrap E03R1 to E03F2 and E03R2 to E03T2. When connecting two DR780 interfaces (DR780 to DR780), only one can be device A.

16.4 DW780



- NOTES:
1. DW0 AND DW1 HAVE EXTERNAL UNIBUS.
 2. DW2 HAS INTERNAL UNIBUS, I.E., DOES NOT LEAVE CABINET.
 3. UNIBUS OUT CABLES AND M9044 MODULES MOUNT ON PIN SIDE OF BACKPLANE.

MR-15864

Figure 16-9 DW780 I/O Backplane Module Utilization

	6	5	4	3	2	1
	A	B	C	D	E	F
	M9044 LBT UNIBUS TR		M9042 UNIBUS OUT			
	UNIBUS ADDRESS AND INT					
	M8273 UAD					
	M8272 UMD					
	M8271 UCB					
	CONTROL BOARD					
	M8270 USI					
	SBI INTERFACE					
	A	B	C	D	E	F

NOTES:

1. VIEW FROM MODULE SIDE
2. SBI EXPANSION CAB USE
3. M9042 AND M9044 MODULES MOUNT ON PIN SIDE OF BACKPLANE.

MR. 16151

Figure 16-10 DW780 Expander Cabinet
Module Utilization





Figure 16-11 DW780 Block Diagram



NOTE:
DW2 IS FOR INTERNAL UNIBUS OPTIONS INSTALLED IN THE I/O BACKPLANE. THEREFORE
THERE IS NO EXTERNAL UNIBUS CONNECTION.

Figure 16-12 DW780 I/O Backplane Jumper Locations

16.4.1 DW780 Jumper Settings

The DW780 jumpers are installed in the I/O backplane, in J35, J39, and J40 for DW0, DW1, and DW2 respectively. If the DW780 is installed in the SBI expansion cabinet, the jumpers are installed in J24 of the UBA backplane.

The DW780 jumpers in the I/O backplane are not the same as the DW780 jumpers in an SBI expansion cabinet. Although Unibus adapter (UBA) interrupt level selection is the same, UBA TR arbitration selection differs by slot numbers, and the jumpers for UBA Unibus address space selection are reversed. Table 16-6 lists the DW780 Unibus adapter jumpers.

Table 16-6 DW780 Jumper Settings

UBA TR Arbitration Level Selection

TR No.	USIC TR SEL	USIC TR SEL	USIC TR SEL	USIC TR SEL	Wirewrap From DXXR2 To
	A L	B L	C L	D L	
	W3	W4	W5	W6	
1	--	--	--	--	FXXC1
2	I	--	--	--	FXXD1
3	--	I	--	--	FXXE1 16
4	I	I	--	--	FXXF2
5	--	--	I	--	FXXH2
6	I	--	I	--	FXXJ1
7	--	I	I	--	FXXJ2
8	I	I	I	--	FXXM1
9	--	--	--	I	FXXN1
10	I	--	--	I	FXXP1
11	--	I	--	I	FXXP2
12	I	I	--	I	FXXS2
13	--	--	I	I	FXXT2
14	I	--	I	I	FXXU1
15	--	I	I	I	FXXU2
16	I	I	I	I	--

NOTES

1. The "I" indicates that the jumper is installed to provide a low (true) signal.
2. The XX indicates the slot number as follows.
 - a. I/O backplane DW0 - I/O backplane slot 16
 - b. I/O backplane DW1 - I/O backplane slot 11
 - c. I/O backplane DW2 - I/O backplane slot 6
 - d. SBI expansion cabinet - UBA backplane Slot 01
3. The first UBA (DW0) is jumpered as TR3. Subsequent UBAs are jumpered as TR4, TR5, and TR6.

Table 16-6 DW780 Jumper Settings (Cont)

UBA Unibus Address Space Selection

SBI Expansion Cabinet

I/O Backplane

Adapter Number	USID Adapter	USID Adapter	Adapter Number	USID Adapter	USID Adapter
	1 L W1	0 L W2		1 L W2	0 L W1
0	--	--	0	--	--
1	--	I	1	--	I
2	I	--	2	I	--
3	I	I	3	I	I

WARNING

The use of W1 and W2 in the expansion cabinet has the opposite use as in the I/O cabinet.

NOTE

The "I" indicates that the jumper is installed to provide a low (true) signal.

UBA Interrupt Level Selection

Request Level	UAIF SBI	UAIF SBI
	PRI JMP 0 L W7	PRI JMP 1 L W8
4	--	--
5	I	--
6	--	I
7	I	I

NOTES

1. The "I" indicates that the jumper is installed to provide a low (true) signal.
2. The UBAs are installed as BR4 devices.

16.4.2 UDA 50 Module Utilization





Figure 16-13 UDA 50 Module Utilization

16.4.3 Unibus Signals



MR 15991

Figure 16-14 Unibus Signals

Table 16-7 Unibus Signal Descriptions

Signal	Description
Data Transfer Group	
Address Lines SA<17:00>	These lines are used by the master device to select the slave (a unique memory or device register address). SA<17:01> specifies a unique 16-bit word. SA<00> specifies a byte within the word.
Data Lines [D<15:00>]	These lines transfer 16 bits of information between master and slave.
Control [C1, C0]	These signals are coded by the master device to control the slave in one of four possible data transfer operations as specified below. The transfer direction is always designated with respect to the master device.

Table 16-7 Unibus Signal Descriptions (Cont.)

Signal	Description
	C1 C0
	0 0 Data In (DATI): A data word or byte is transferred into the master from the slave.
	0 1 Data In Pause (DATIP): Similar to DATI except that it is always followed by a DATO(B) to the same location.
	1 0 Data Out (DATO): A data word is transferred out of the master to the slave.
	1 1 Data Out Byte (DATOB): Identical to the DATO except a byte is transferred instead of a full word.
Parity [PA, PB]	These signals transfer Unibus parity information. PA is currently unused and not asserted. PB, when true indicates a device parity error.
Master Synchronization (MSYN)	MSYN is asserted by the master to indicate to the slave that valid address and control information (and data for a DATO or DATOB) is present on the bus.
Slave Synchronization (SSYN)	SSYN is asserted by the slave. On a DATO it indicates that the slave has latched the write data. On a DATI(P) it indicates that the slave has asserted read data on the Unibus.
Interrupt (INTR)	This signal is asserted by an interrupting device after it becomes bus master to inform the UBA that an interrupt is to be performed, and that the interrupt vector is present on the D lines. INTR is negated upon receipt of the assertion of SSYN by the UBA at the end of the transaction. INTR may be asserted only by a device that obtained bus mastership under the authority of a BG signal.
Priority Arbitration Group	
Bus Request (BR7-BR4)	These signals are used by peripheral devices to request control of the bus for an interrupt operation.
Bus Grant (BG7-BG4)	These signals form the CPU and UBA response to a bus request. Only one of the four will be asserted at any one time.

Table 16-7 Unibus Signal Descriptions (Cont.)

Signal	Description
Nonprocessor Request (NPR)	This is a bus request from a device for a transfer not requiring CPU intervention (i.e., DMA).
Nonprocessor Grant (NPG)	This is the grant in response to an NPR.
Selection Acknowledge (SACK)	SACK is asserted by a bus-requesting device after having received a grant. Bus control passes to this device when the current bus master completes its operation.
Bus Busy (BBSY)	BBSY indicates that the data lines of the bus are in use. It is asserted by the Unibus master.
Initialization Group	
Initialize (INIT)	Asserted by the terminator board (UBT) when DC LO is asserted on the Unibus. It stays asserted for 10 milliseconds following the negation of DC LO.
AC Line Low (AC LO)	This is an anticipatory signal that warns of an impending power failure. AC LO initiates the power fail trap sequence and may also be issued in peripheral devices to terminate operations in preparation for power loss.
DC Line Low (DC LO)	This signal is available from each system power supply and remains clear as long as all dc voltages are within the specified limits. If an out-of-voltage condition occurs, DC LO is asserted.

Table 16-8 Unibus Pin Assignments - Standard and Modified

Pin	Standard Signal	Modified Signal	Pin	Standard Signal	Modified Signal
AA1	INIT L	INIT L	BA1	BG6 H	SPARE
AA2	+5 V	+5 V	BA2	+5 V	+5 V
AB1	INTR L	INTR L	BB1	BG5 H	SPARE
AB2	GROUND	TEST POINT	BB2	GROUND	TEST POINT
AC1	D00 L	D00 L	BC1	BR5 L	BR5 L
AC2	GROUND	GROUND	BC2	GROUND	GROUND
AD1	D02 L	D02 L	BD1	GROUND	BAT BACKUP +5 V
AD2	D01 L	D01 L	BD2	BR4 L	BR4 L
AE1	D04 L	D04 L	BE1	GROUND	INT SSYN*
AE2	D03 L	D03 L	BE2	BG4 H	PAR:DFT*
AF1	D06 L	D06 L	BF1	AC LO L	AC LO L
AF2	D05 L	D05 L	BF2	DC LO L	DC LO L
AH1	D08 L	D08 L	BH1	A01 L	A01 L
AH2	D07 L	D07 L	BH2	A00 L	A00 L
AJ1	D10 L	D10 L	BJ1	A03 L	A03 L
AJ2	D09 L	D09 L	BJ2	A02 L	A02 L
AK1	D12 L	D12 L	BK1	A05 L	A05 L
AK2	D11 L	D11 L	BK2	A04 L	A04 L
AL1	D14 L	D14 L	BL1	A07 L	A07 L
AL2	D13 L	D13 L	BL2	A06 L	A06 L
AM1	PA L	PA L	BM1	A09 L	A09 L
AM2	D15 L	D15 L	BM2	A08 L	A08 L
AN1	GROUND	P1*	BN1	A11 L	A11 L
AN2	PB L	PB L	BN2	A10 L	A10 L
AP1	GROUND	P0*	BP1	A13 L	A13 L
AP2	BBSY L	BBSY L	BP2	A12 L	A12 L
AR1	GROUND	BAT BACKUP +15 V	BR1	A15 L	A15 L
AR2	SACK L	SACK L	BR2	A14 L	A14 L
AS1	GROUND	BAT BACKUP +15 V	BS1	A17 L	A17 L
AS2	NPR L	NPR L	BS2	A16 L	A16 L
AT1	GROUND	GROUND	BT1	GROUND	GROUND
AT2	BR7 L	BR7 L	BT2	C1 L	C1 L
AU1	NPG H	+20 V	BU1	SSYN L	SSYN L
AU2	BR6 L	BR6 L	BU2	C0 L	C0 L
AV1	BG7 H	+20 V	BV1	MSYN L	MSYN L
AV2	GROUND	+20 V	BV2	GROUND	-5 V

*Pins used by parity control module.

SBI

Unibus Address to VAX Physical Address Conversion

16.4.4 Unibus Address to VAX Physical Address Conversion

An example will be used to show how to convert from a Unibus byte address (Octal) of 760270 to the VAX physical address (Hex).

Example 16-3 Conversion from Unibus address to VAX physical address

1. First change the octal number to binary digits.

111 110 000 010 111 000

2. Prepare to convert the binary number into Hexadecimal by re-ordering the octal binary number into 4-digit segments.

11 1110 0000 1011 1000

3. Add the appropriate DW780 Unibus Adapter Base Address to the HEX number of the preceding step (Figure 15-3). For this example we will use DW0, 20100000. The resultant number is the HEX representation of the VAX Physical Byte Unibus Address.

20100000

+ 3E0B8

2013E0B8

Unibus Adapter Base Address (Adapter 0)
HEX representation of Unibus address

HEX representation of the Unibus address
converted to a VAX Physical Byte Unibus
address

NOTE

For a word access, always examine on a word boundary.

16.4.5 VAX Physical Address (Hex) to Unibus Address (Octal) Conversion

An example will be used to show the conversion from VAX physical address space to Unibus address space. The physical address of 2013E008 will be used.

1. To make this conversion, the physical byte address must be assigned to the Unibus space for the DW780 adapter. Use Figure 15-3 to compare the address with the range of addresses for each UBA. Determine which UBA corresponds to this address.
2. Change the HEX digits to the binary equivalent and extract the 18 least significant bits (bits 17-0).

2	0	1	3	E	0	0	8
0010	0000	0001	0011	1110	0000	0000	1000
+-----+-----+-----+-----+							
31				17	0		
11 1110 0000 0000 1000							

VAX Physical Address (Hex) to Unibus Address (Octal) Conversion

3. Reformat the 18 binary bits into 3-bit sections. The result is the Unibus byte address in octal.

111 110 000 000 001 000 = 760010

16.4.6 DW780 Unibus Device Addresses

Table 16-9 is a list of VAX physical addresses for Unibus devices.

Table 16-9 DW780 Unibus Device Addresses

Unibus Device Address	Equivalent #0	DW780 Adapter #1	"BYTE" Address (SBIA 0) #2	#3
760010	2013E008	2017E008	201BE008	201FE008
760020	2013E010	2017E010	201BE010	201FE010
760030	2013E018	2017E018	201BE018	201FE018
760040	2013E020	2017E020	201BE020	201FE020
760050	2013D028	2017E028	201BE028	201FE028
760060	2013E030	2017E030	201BE030	201FE030
760070	2013E038	2017E038	201BE038	201FE038
760100	2013E040	2017E040	201BE040	201FE040
760110	2013E048	2017E048	201BE048	201FE048
760120	2013E050	2017E050	201BE050	201FE050
760130	2013E058	2017E058	201BE058	201FE058
760140	2013E060	2017E060	201BE060	201FE060
760150	2013E068	2017E068	201BE068	201FE068
760160	2013E070	2017E070	201BE070	201FE070
760170	2013E078	2017E078	201BE078	201FE078
760200	2013E080	2017E080	201BE080	201FE080
760210	2013E088	2017E088	201BE088	201FE088
760220	2013E090	2017E090	201BE090	201FE090
760230	2013E098	2017E098	201BE098	201FE098
760240	2013E0A0	2017E0A0	201BE0A0	201FE0A0
760250	2013E0A8	2017E0A8	201BE0A8	201FE0A8
760260	2013E0B0	2017E0B0	201BE0B0	201FE0B0
760270	2013E0B8	2017E0B8	201BE0B8	201FE0B8
760300	2013E0C0	2017E0C0	201BE0C0	201FE0C0
760310	2013E0C8	2017E0C8	201BE0C8	201FE0C8
760320	2013E0D0	2017E0D0	201BE0D0	201FE0D0
760330	2013E0D8	2017E0D8	201BE0D8	201FE0D8
760340	2013E0E0	2017E0E0	201BE0E0	201FE0E0
760350	2013E0E8	2017E0E8	201BE0E8	201FE0E8
760360	2013E0F0	2017E0F0	201BE0F0	201FE0F0
760370	2013E0F8	2017E0F8	201BE0F8	201FE0F8
760400	2013E100	2017E100	201BE100	201FE100
760410	2013E108	2017E108	201BE108	201FE108
760420	2013E110	2017E110	201BE110	201FE110
760430	2013E118	2017E118	201BE118	201FE118

SBI
DW780 Unibus Device Addresses

Table 16-9 DW780 Unibus Device Address (Cont.)

Unibus Device Address	Equivalent DW780 Adapter "BYTE" Address (SBIA 0)			
	#0	#1	#2	#3
760440	2013E120	2017E120	201BE120	201FE120
760450	2013E128	2107E128	201BE128	201FE128
764004	2013E804	2017E804	201BE804	201FE804
764014	2013E80C	2017E80C	201BE80C	201FE80C
764024	2013E814	2017E814	201BE814	201FE814
770460	2013F130	2017F130	201BF130	201FF130
772410	2013F508	2017F508	201BF508	201FF508
774400	2013F900	2017F900	201BF900	201FF900
777160	2013FE70	2017FE70	201BFE70	201FFE70
777440	2013FF20	2017FF20	201BFF20	201FFF20
777514	2013FF4C	2017FF4C	201BFF4C	201FFF4C

NOTE

For DW780 addresses on SBIA 1, simply add 02000000 to the address. For example, Unibus address 760010 on DW0, SBIA 1 will be 2213E008.

16.5 RH780

	6	5	4	3	2	1
A						A
B						B
C						C
D						D
E						E
F						F
M9041	MASSBUS PADDLE CARD (MOUNTS ON PIN SIDE OF BP)					
	BLANK					
M8278	MCP					
M8277(M8274)	MASSBUS CONTROL PATHS					
	MASSBUS DATA PATHS					
M8276	MIR					
M8275	MSI					
	MBA/SBI INTERFACE					

NOTES:

1. VIEW FROM MODULE SIDE.
2. THE M9041 MASSBUS PADDLE CARD MOUNTS ON THE PIN SIDE OF THE BACK-PLANE. SLOT 6 IS EMPTY ON THE MODULE SIDE.
3. THE M8277 MDP MODULE IS STANDARD, AND CONTAINS A 32 X 8 BIT SILO.
4. THE M8274 MDP MODULE HAS AN EXTENDED SILO (256 X 8) AND IS USED FOR HI-SPEED RPO7 DISKS.

MR-16152

Figure 16-15 RH780 Module Utilization




Figure 16-16 RH780 Block Diagram (Sheet 1 of 2)





Figure 16-16 RH780 Block Diagram (Sheet 2 of 2)



NOTE:

1 = JUMPER PLUG INSTALLED (SIGNAL IS LOW)
W1 - W12 ARE SPARES. JUMPER PLUGS NOT
BEING USED ON W1-W6 SHOULD BE STORED
ON W7 - W12.

TRANSFER REQUEST ARBITRATION
LEVEL SELECTION

TR#	W1	W2	W3	W4	FROM	TO
1	—	—	—	—	—	F02C1
2	—	—	—	—	—	F02D1
3	—	—	—	—	—	F02E1
4	—	—	—	—	—	F02H2
5	—	—	—	—	—	F02I1
6	—	—	—	—	—	F02J2
7	—	—	—	—	—	F02M1
8	—	—	—	—	—	F02N1
9	—	—	—	—	—	F02P1
10	—	—	—	—	—	F02Q2
11	—	—	—	—	—	F02R2
12	—	—	—	—	—	F02S2
13	—	—	—	—	—	F02T2
14	—	—	—	—	—	F02U1
15	—	—	—	—	—	F02V1
16	—	—	—	—	—	F02W2

INTERRUPT
LEVEL SELECTION

BR #	W5	W6
4	—	—
5	—	—
6	—	—
7	—	—





Figure 16-17 RH780 Jumper Settings

16.5.1 MAP Register Address Calculation

The following steps may be used to calculate a MAP register address.

1. Determine the desired MAP Register location or offset. It must be in the range of 00-FF (Hex) as there are 256 MAP Registers in the MBA.
2. Enter the MAP Register offset into the MAP Register Address Calculation diagram (Figure 16-18). The register offset will be shifted two bits left, creating a longword boundary.
3. Add the MBA base address (Table 16-10) to the calculated address. The result is the CPU HEX address of the desired MAP register.

MAP REGISTER ADDRESS CALCULATION



MR-16142

Figure 16-18 Map Register Address Calculation

16.5.2 MASSBUS Register Address Calculation

The following steps may be used to calculate a MASSBUS register address. The example will be used to calculate the MASSBUS register address for the control and status register (register 0) for drive 7, SBI 1, RH780 # 0.

1. Use the MASSBUS Register Offset table (Table 16-11) and determine the correct offset for the desired register.
2. Add this offset to the MBA base address from Table 16-10. The result is the CPU HEX address of the desired external register. Do not let the bit configuration of Figure 16-19 confuse you. Bits 01 and 00 will always be zero, bits <06:02> indicates which register is being selected, and bits <09:07> indicates which drive is selected.

Example 16-4 Calculating a physical byte address

Calculate the physical byte address of CS1 (register 0) for drive 7, SBI 1, RH780 # 0 (TR8).

1. MBA base address from Table 16-10 = 22010000
2. MASSBUS register offset from Table 16-11 = 380
3. Adding the two together provides the physical byte address of 22010380.

SBI
MASSBUS Register Address Calculation

MASSBUS REGISTER ADDRESS CALCULATION

11	10	09	08	07	06	05	04	03	02	01	00
0	1	DRIVE SELECT			REGISTER SELECT					0	0

MR-16143

Figure 16-19 MASSBUS Register Address Calculation

Table 16-10 MBA Base Addresses

TR Level	SBIA 0 Base Address	SBIA 1 Base Address
8	20010000	22010000
9	20012000	22012000
10	20014000	22014000
11	20016000	22016000

NOTE

Always examine MASSBUS registers on a longword boundary.

Table 16-11 MASSBUS Register Offset

REG NO.		MASSBUS DEVICE TYPE				DRIVE NUMBER							
HEX	OCT	RP DISK	RM DISK	TE TAPE	TM78 TAPE	0	1	2	3	4	5	6	7
0	0	CS1	RMCS1	CS1	CAS00	0	80	100	180	200	280	300	380
1	1	DS	RMDS	DS	CAS01	4	84	104	184	204	284	304	384
2	2	ER1	RMER1	ER	CAS02	8	88	108	188	208	288	308	388
3	3	MR	RMMR1	MR	CAS03	C	8C	10C	18C	20C	28C	30C	38C
4	4	AS	RMAS	AS	CAS04	10	90	110	190	210	290	310	390
5	5	DA	RMDA	FC	CAS05	14	94	114	194	214	294	314	394
6	6	DT	RMDT	DT	CAS06	18	98	118	198	218	298	318	398
7	7	LA	RMLA	CX	CAS07	1C	9C	11C	19C	21C	29C	31C	39C
8	10	SN	RMSN	SN	CAS08	20	A0	120	1A0	220	2A0	320	3A0
9	11	OFF	RMOF	TC	CAS09	24	A4	124	1A4	224	2A4	324	3A4
A	12	DCA	RMOC		CAS10	28	A8	128	1A8	228	2A8	328	3A8
B	13	CCA	RMNR		CAS11	2C	AC	12C	1AC	22C	2AC	32C	3AC
C	14	ER2	RMMR2		CAS12	30	B0	130	1B0	230	2B0	330	3B0
D	15	ER3	RMER2		CAS13	34	B4	134	1B4	234	2B4	334	3B4
E	16	ECCPOS	RMEC1		CAS14	38	B8	138	1B8	238	2B8	338	3B8
F	17	ECCPAT	RMEC2		CAS15	3C	BC	13C	1BC	23C	2BC	33C	3BC
10	20				CAS16	40	C0	140	1C0	240	2C0	340	3C0
11	21				CAS17	44	CA	144	1C4	244	2C4	344	3C4
						•	•	•	•	•	•	•	•
1F	37					7C	FC	17C	1FC	27C	2FC	37C	3FC

CHAPTER 17

REVISION CONTROL

17.1 VAX 8600/8650 REVISION INFORMATION

The following tables are a check list for the KA86 unit revision. They do not replace the RM document and are to be used for reference only. They are a history of changes that have occurred to the KA86 from revision H4 to K3. For prior history, see early revisions of the RM document. The following information is subject to change.

Table 17-1 shows revision information for the VAX 8600 and Table 17-2 shows revision information for the VAX 8650. Table 17-3 and Table 17-4 contains the diagnostic media revision information for VAX 8600 and VAX 8650 respectively.

For file revision information, read the file RL2REV.MEM.

Table 17-1 VAX 8600 Revision Information

UNIT REVISION LEVEL COMPATIBILITY			RELEASE		REVISION		L1
Part No.	Description	J1	K1	K2,K3	K4	Revisions	
Backplanes							
70-19193-01	MEM BACKPLANE		A1,A2	A1,A2	A1,A2	A1,A2	A1,A2
70-19194-00	I/O BACKPLANE		C1,C2	C1,C2	C1,C2	C1,C2	A1,C2
70-19196-01	ABUS BACKPLANE		A1,A2	A1,A2	A1,A2	A1,A2	A1,A2
70-19198-01	CPU BACKPLANE		A1,A2	A1,A2	A1,A2	A1,A2	A1,A2
Modules							
L0200-BA	MEMORY ARRAY (4 MEG. MS86-BA)		C1,D1	C1,D1	C1,D1	C1,D1	C1,D1
L0201-00	(CSL) CONSOLE		E1,E2,E3,F1	E1,E2,E3,F1	E1,F1,F2,H1,H2	E1,F1,F2,H1,H2	E1,E3,F1,F2,H1,H2
L0202-00	(SBS) SBIA		B1,B2,B3	B1,B2,B3	B1,B2,B3	B1,B2,B3	B1,B2,B3
L0203-00	(SBA) SBIA ABUS INTERFACE		B1,B2,C1,C2,C3	B1,B2,C1,C2,C3	B1,B2,C1,C2,C3	B1,B2,C1,C2,C3	B1,B2,C1,C2,C3
			Note 1	Note 1	Note 1	Note 1	Note 1
L0204-00	(MCD) MBOX		D5,D6,E1,F1	D5-D7,E1,F1,F2,F3	D5-D7,E1,F1,F2,F3	D5-D7,E1,F1,F2,F3	D5-D7,E1,F1,F2,F3
L0205-00	(MAP) MBOX		D3,D4,D5,D6,E1	D3-D6,E1,E2,E3,E4	D3-D6,E1,E2,E3,E4	D3-D6,E1,E2,E3,E4	D3-D6,E1,E2,E3,E4
L0206-00	(IDP) IBOX		F3,F4,F5,H1	F3,F4,F5,H1,H3	F3,F4,F5,H1,H3	F3,F4,F5,H1,H3	F3,F4,F5,H1,H3
L0207-00	(ICA) IBOX		J1	J1,J2	J1,J2	J1,J2	J1,J2
L0208-00	(IBD) IBOX		F5,F6,F7,F8	F5,F6,F7,F8	F5,F6,F7,F8,F9	F5,F6,F7,F8,F9	F5,F6,F7,F8,F9
L0209-00	(EDP) EBOX		C2,C3,C4,C5	C2,C3,C4,C5	C2,C3,C4,C5	C2,C3,C4,C5	C2,C3,C4,C5
L0210-00	(EBC) EBOX		C3,C4,C5,C6,C7	C3,C4,C5,C6,C7	C3,C4,C5,C6,C7,C8	C3,C4,C5,C6,C7,C8	C3,C4,C5,C6,C7,C8
L0211-00	(EBD) EBOX		D3,D4,D5,E1	D3,D4,D5,E1	D3,D4,D5,E1,E2	D3,D4,D5,E1,E2	D3,D4,D5,E1,E2
L0212-00	(FBA) FBOX		B3,E7,F1,H1,H2	B3,E7,F1,H1,H2	B3,E7,F1,H1,H2	B3,E7,F1,H1,H2	B3,E7,F1,H1,H2
L0213-00	(FBM) FBOX		C5,C7,C8 (Note 2)	C5,C7,C8 (Note 2)	C5,C7,C8 (Note 2)	C5,C7,C8 (Note 2)	C5,C7,C8 (Note 2)
L0214-00	(ICB) IBOX		H1	H1,H2,H3	H1,H2,H3,H4	H1,H2,H3,H4	H1,H2,H3,H4
L0215-00	(CSA) EBOX		B2,B3,B4	B2,B3,B4	B2,B3,B4,B5	B2,B3,B4,B5	B2,B3,B4,B5
L0216-00	(CSB) EBOX		B2,B3,B4,B5	B2,B3,B4,B5	B2,B3,B4,B5	B2,B3,B4,B5	B2,B3,B4,B5
L0217-00	(CLK) CLOCK		C5,C6,E1,E2	C5,C6,E1,E2	C5,C6,E1,E2	C5,C6,E1,E2	C5,C6,E1,E2
L0218-00	(FIM) NO FBOX		A2	A2	A2	A2	A2
L0219-00	(EBE) EBOX		B2,B3,B4	B2,B3,B4	B2,B3,B4,B5	B2,B3,B4,B5	B2,B3,B4,B5
L0220-00	(MCC) MBOX		K1,K2,K3,K4	L1,L2	L1,L2	L1,L2	L1,L2
L0222-00	(MTM) MEMORY TERMINATOR		B1,B2	B1,B2,B3	B1,B2,B3	B1,B2,B3	B1,B2,B3
L0223-00	(FTM) NO FBOX		A2	A2	A2	A2	A2
L0224-00	(STM) ABUS TERMINATOR		B4,B5,B6	B4,B5,B6	B4,B5,B6	B4,B5,B6	B4,B5,B6

Table 17-1 VAX 8600 Revision Information (Cont)

Part No.	UNIT REVISION LEVEL COMPATIBILITY Description	RELEASE				REVISION			
		J1	K1	K2,K3	K4	L1	Revisions		
L0225-00	MEMORY ARRAY (16 MEG, MS86-CA)	A1	A1	A1	A1	A1			
L0226-BA	MEMORY ARRAY (4 MEG, MS86-AA)	A1,A2	A1,A2	A1,A2	A1,A2	A1,A2			
L0235-00	MEMORY ARRAY (64 MEG, MS86-DA)	A1	A1	A1	A1	A1			
L9200-00	MEMORY LOAD BOARD	A1,A2,B1 (Note 3)	A1,A2,B1 (Note 3)	A1,A2,B1 (Note 3)	A1,A2,B1 (Note 3)	A1,A2,B1 (Note 3)			
L0100-	C1780 INTER PROCESSOR INTERFACE	D1	D1	D1	D1	D1			
L0101-	C1780 PACKET BUFFER	H1,H2	H1,H2	H1,H2	H1,H2	H1,H2			
L0102-	C1780 DATA PATH	D1	D1	D1	D1	D1			
L0104-	C1780 SBI INTERFACE	C,C1,D1	C,C1,D1	C,C1,D1	C,C1,D1	C,C1,D1			
M8270-	DW780 UNIBUS ADAPTER SBI	C,D	C,D	C,D	C,D	C,D			
M8271-	DW780 UNIBUS ADAPTER CONTROL	F1,F2	F1,F2	F1,F2	F1,F2	F1,F2			
M8272-	DW780 UNIBUS ADAPT MAP & DATA	C,D	C,D	C,D	C,D	C,D			
M8273-	DW780 UNIBUS ADAPTER ADDRESS	D1	D1	D1	D1	D1			
M9302-	DW780 UNIBUS TERMINATOR FAR END	A	A	A	A	A			
M9040-	I/O BACKPLANE TERM	A2 (Note 5)	A2 (Note 5)	A2 (Note 5)	A2 (Note 5)	A2 (Note 5)			
M9044-	DW780 UNIBUS TERMINATOR	B,C	B,C	B,C	B,C	B,C			
M8739-	TU81 MODULE ADAPTER	D1	D1	D1	D1	D1			
M7485-VA	UNIBUS DISK ADAPTER (UDAS0-A)	H1,H2	H1,H2	H1,H2	H1,H2	H1,H2			
M7486-	UNIBUS DISK ADAPTER (UDAS0-A)	H4	H4	H4	H4	H4			
54-16500-AA	SMU (DAUGHTER BOARD, MS86-CA)	-	-	-	-	-			
54-16500-BA	SMU (LOW POWER DAUGHTER BOARD, MS86-CA)	A3	A3	A3	A3	A3			
54-17052-AA	SMU (DAUGHTER BOARD, MS86-DA)	A1	A1	A1	A1	A1			

NOTES

1. Any field returned module at revision B must be upgraded to revision C.
2. Revision C6 cancelled.
3. Memory load modules are installed in slots 5 and 8 if no memory module occupies the slot.
4. Revision E1 was built for test use only.
5. Past releases of the RM document showed the M9040 to be at revision level B1 and C. This was incorrect, it should have been revision A2.

Table 17-2 VAX 8650 Revision Information

UNIT REVISION LEVEL COMPATIBILITY		RELEASE REVISION				
Part No.	Description	B2	C1	C2	C3	D1
Revisions						
Backplanes						
70-19193-01	MEM BACKPLANE	A1,A2	A1,A2	A1,A2	A1,A2	A1,A2
70-19194-00	I/O BACKPLANE	C1,C2	C1,C2	A1,A2	A1,A2	C1,C2
70-19195-01	ABUS BACKPLANE	A1,A2	A1,A2	A1,A2	A1,A2	A1,A2
70-19198-01	CPU BACKPLANE	A1,A2	A1,A2	A1,A2	A1,A2	A1,A2
Modules						
L0200-BA	MEMORY ARRAY (4 MEG, MS86-BA)	D1	D1	D1	D1	D1
L0201-BA	(CSL) CONSOLE	F1	F1	F1,F2,H1,H2	F1,F2,H1,H2	F1,F2,H1,H2
L0202-00	(SBS) SBIA	B1,B2,B3	B1,B2,B3	B1,B2,B3	B1,B2,B3	B1,B2,B3
L0203-00	(SBA) SBIA ABUS INTERFACE	B1,B2,C1	B1,B2,C1,C2,C3	B1,B2,C1,C2,C3	B1,B2,C1,C2,C3	B1,B2,C1,C2,C3
		Note 1	Note 1	Note 1	Note 1	Note 1
L0204-00	(MCD) MBOX	F1	F1	F1,F2,F3	F1,F2,F3	F1,F2,F3
L0205-00	(MAP) MBOX	E1	E1	E1,E2,E3	E1,E2,E3,E4	E1,E2,E3,E4
L0206-00	(IDP) IBOX	H1	H1	H1,H3	H1,H3	H1,H3
L0207-00	(ICA) IBOX	H3,H4,H5	J1	J1,J2	J1,J2	J1,J2
L0208-00	(IBD) IBOX	F5,F6,F7,F8	F5,F6,F7,F8	F5,F6,F7,F8,F9	F5,F6,F7,F8,F9	F5,F6,F7,F8,F9
L0209-00	(EBD) EBOX	C2,C3,C4,C5	C2,C3,C4,C5	C2,C3,C4,C5	C2,C3,C4,C5	C2,C3,C4,C5
L0210-00	(EBC) EBOX	C3,C4,C5,C6,C7	C3,C4,C5,C6,C7	C3,C4,C5,C6,C7,C8	C3,C4,C5,C6,C7,C8	C3,C4,C5,C6,C7,C8
L0211-00	(EBD) EBOX	E1	E1	E1,E2	E1,E2	E1,E2
L0212-00	(FBA) FBOX	H1	H1,H2	H1,H2	H1,H2	H1,H2
L0213-00	(FBM) FBOX	C5,C7 (Note 2)	C5,C7,C8 (Note 2)	C5,C7,C8 (Note 2)	C5,C7,C8 (Note 2)	C5,C7,C8 (Note 2)
L0214-00	(ICB) IBOX	F4,F5,F6,F7,F8	H1	H1,H2,H3	H1,H2,H3,H4	H1,H2,H3,H4
L0215-00	(CSA) EBOX	B2,B3,B4	B2,B3,B4	B2,B3,B4,B5	B2,B3,B4,B5	B2,B3,B4,B5
L0216-00	(CSB) EBOX	B2,B3,B4,B5	B2,B3,B4,B5	B2,B3,B4,B5	B2,B3,B4,B5	B2,B3,B4,B5
L0217-00	(FJM) NO FBOX	A2	A2	A2	A2	A2
L0218-00	(EBE) EBOX	B2,B3,B4	B2,B3,B4	B2,B3,B4,B5	B2,B3,B4,B5	B2,B3,B4,B5
L0219-00	(EBE) EBOX	B1,B2	B1,B2	B1,B2,B3	B1,B2,B3	B1,B2,B3
L0222-00	MEMORY TERMINATOR					
L0223-00	(FTM) NO FBOX	A2	A2	A2	A2	A2
L0224-00	ABUS TERMINATOR	B4,B5,B6	B4,B5,B6	B4,B5,B6	B4,B5,B6	B4,B5,B6
L0225-00	MEMORY ARRAY (16 MEG, MS86-CA)	A1	A1	A1	A1	A1
L0226-BA	MEMORY ARRAY (4 MEG, MS86-AA)	A1	A1,A2	A1,A2	A1,A2	A1,A2

Table 17-2 VAX 8650 Revision Information (Cont.)

UNIT REVISION LEVEL COMPATIBILITY		RELEASE		REVISION	
Part No.	Description	B2	C1	C2	D1
		Revisions			
L0230-00	(MCC) MBOX	A1,A2	A1,A2	A1,A2	A1,A2
L0231-00	(CLK) CLOCK	B1	B1	B1	B1
L0233-00	MEMORY ARRAY (64 MEG, MS86-DA)	A1	A1	A1	A1
L9250-00	MEMORY LOAD BOARD	A1,A2,B1 (Note 3)	A1,A2,B1 (Note 3)	A1,A2,B1 (Note 3)	A1,A2,B1 (Note 3)
L0100-	C1780 INTER PROCESSOR INTERFACE	D1	D1	D1	D1
L0101-	C1780 PACKET BUFFER	H1,H2	H1,H2	J1,K1	D1,E1,E2 (Note 4)
L0102-	C1780 DATA PATH	D1	D1	D1	J1,K1
L0104-	C1780 SBI INTERFACE	C,C1,D1	C,C1,D1	C,C1,D1	D1
M8270-	DW780 UNIBUS ADAPTER SBI	D	D	D	C,C1,D1
M8271-	DW780 UNIBUS ADAPTER CONTROL	D1,F2	F1,F2	F1,F2	D
M8272-	DW780 UNIBUS ADAPTER DATA	D	D	D	F1,F2
M8273-	DW780 UNIBUS ADAPTER ADDRESS	C	C	D	D
M9302-	DW780 UNIBUS TERMINATOR FAR END	A	A	A	A
M9040-	I/O BACKPLANE TERM	A2	A2 (Note 5)	B1 (Note 5)	A2
M9044-	DW780 UNIBUS TERMINATOR	B,C	B,C	B,C	B,C
M8739-	TU81 MODULE ADAPTER	B5	D1	D1	D1
M7485-YA	UNIBUS DISK ADAPTER (UDA80-A)	H1	H1,H2	H1,H2	H1,H2
M7486	UNIBUS DISK ADAPTER (UDA90-A)	H2	H4	H4	H4
54-16500-AA	SMU (DAUGHTER BOARD, MS86-CA)	A3	A3	A3	A3
54-16500-BA	SMU (LOW POWER DAUGHTER BOARD, MS86-CA)	-	-	-	-
54-17052-AA	SMU (DAUGHTER BOARD, MS86-DA)	A1	A1	A1	A1

NOTES

- Any field returned module at revision B must be upgraded to revision C.
- Revision C6 cancelled.
- Memory load modules are installed in slots 5 and 8 if no memory module occupies the slot.
- Revision E1 was built for test only.
- An ECO issued by mistake changed the revision of the M9040 from A2 to B1. A supplemental ECO corrected the mistake, changing the revision back to A2.

Table 17-3: VAX 8600 Diagnostic Media Revision Information

Part No.	Description	UNIT REVISION LEVEL COMPATIBILITY				RELEASE REVISION			L1	
		J1	K1	K2,K3	K4	Revisions	D (Note)	D (Note)		D (Note)
BB-FF157-DE	VAX 8600 MACRO DIAG TAPE	D (Note)	D (Note)	D (Note)	D (Note)				D (Note)	
BB-FF587-DE	VAX 86XX CONSOLE - UPDATE TAPE	B (Note)	B (Note)	- (Note)	-				D (Note)	
BB-T9907-DE	VAX 8600 CONSOLE W/DIAG TAPE	F (Note)	F (Note)	-	-					
BC-T9877-ME	VAX 8600 CONSOLE -NO DIAG PACK	VER 6.0/6.1	VER 6.0/6.1	VER 6.0/6.1	-					
		F (Note)	F (Note)	F (Note)	-					
BB-T9887-YE	FIELD SERVICE UPD TAPE PT2	VER 6.0/6.1	VER 6.0/6.1	VER 6.0/6.1	-					
		F (Note)	F (Note)	F (Note)	-					
BC-T9897-DE	VAX 8600 CONSOLE - W/DIAG PACK	A (Note)	A (Note)	A (Note)	A (Note)				A (Note)	
BB-FI167-DE	VAX 8600/8650 CNSL W/DIAG TAPE	VER 6.0	VER 6.0	VER 6.0	-					
		-	-	-	A (VER 1.0)				C (VER 3.0)	
BC-FI177-ME	VAX 8600/8650 CNSL RLO2 PACK	-	-	-	A (VER 1.0)				C (VER 2.0)	
BC-FI187-DE	VAX 8600/8650 CNSL W/DIAG RLO2	-	-	-	A (VER 1.0)				C (VER 3.0)	

NOTE

1. The "?" in the part number reflects the revision in the release revision column.

Table 17-4: VAX 8650 Diagnostic Media Revision Information

Part No.	UNIT REVISION LEVEL COMPATIBILITY	Description	RELEASE REVISION				D1
			B2	C1	C2	C3	
			Revisions				
BB-FF157-DE	VAX 8650 MACRO DIAG TAPE	D (Note)	D (Note)	D (Note)	D (Note)	D (Note)	
BB-FF587-DE	VAX 86XX CONSOLE - UPDATE TAPE	-	B (Note)	-	-	D (Note)	
BC-FG457-ME	VAX 8650 CONSOLE NO-DIAG PACK	B (Note)	B (Note)	-	-	-	
BC-FG477-DE	VAX 8650 CONSOLE W/DIAG PACK	VER 1.2	B (Note)	-	-	-	
		B (Note)	B (Note)	-	-	-	
BB-FG487-DE	VAX 8650 CONSOLE W/DIAG TAPE	VER 1.2	B (Note)	-	-	-	
		B (Note)	B (Note)	-	-	-	
BB-FI167-DE	VAX 8600/8650 CNSL W/DIAG TAPE	VER 1.2	-	A (VER 1.0)	B (VER 2.0)	C (VER 3.0)	
BC-FI177-ME	VAX 8600/8650 CNSL RLO2 PACK	-	-	A (VER 1.0)	B (VER 2.0)	C (VER 3.0)	
BC-FI187-DE	VAX 8600/8650 CNSL W/DIAG RLO2	-	-	A (VER 1.0)	B (VER 2.0)	C (VER 3.0)	

NOTE

- The "?" in the part number reflects the revision in the release revision column.

CHAPTER 18

REMOVAL AND REPLACEMENT PROCEDURES

18.1 GENERAL

This chapter describes how to remove and replace assemblies in the kernel system. Only the major field replaceable units (FRUs) for the system are covered.

This chapter covers the two major system components included in a kernel system, the front end and CPU cabinets, and is divided into four major parts, one part for each of these components, this introduction, and a section on module paddle connector cleaning.

The procedures are listed in a specific order because some procedures depend on the completion of preceding ones. Be sure you follow this order as you work on each system component, or you may run into problems in performing the procedures.

As you work on each component, pay attention to the following rules.

- Use all screws and bolts when you reassemble a component and put them in their correct places.
- Do not bundle signal cables with power cables.
- Unless otherwise stated, to replace an FRU, reverse the order of the removal procedures.
- Perform the appropriate diagnostic test for each FRU that you replace.

REMOVAL AND REPLACEMENT PROCEDURES

18.2 FRU PART NUMBERS

	Digital PN
A. FRUS FOR CPU CABINET ASSEMBLY 60 Hz	70-19219-00
50 Hz	70-19219-01
POWER SUPPLY ASSEMBLY	70-20340-00
(2) AC Input Assembly (2.8 Kw)	H7170-A
(2) Modular Power Supply (+5 V @ 200 A)	H7180-A
EMM Assembly (with PROM)	H7188-A
(2) Modular Power Supply (+2.5 V @ 100 A)	H7187-A
(2) Modular Power Supply (+5 V @ 85 A)	H7186-A
Modules in CARD CAGE ASSEMBLY	PNs available
H7231 POWER SUPPLY 120 V/240 V	H7231-A
876 POWER CONTROLLER 120 V/208 V	876-A
BLOWER, CENTRIFUGAL 1500 CFM 60 Hz	12-19197-00
50 Hz	12-19197-01
Filter in CARD CAGE SUPPORT ASSEMBLY	12-23034-02
Air Flow Sensor (with LED)	12-22805-01
Temperature Sensor	12-19526-01
B. FRUS FOR FRONT END CABINET ASSEMBLY 60 Hz	70-19218-00
50 Hz	70-19218-01
CVT	30-23959-00
RL02 DISK DRIVE	RL02-FK
Ball-A UNIT ASSEMBLY	Ball-AL
Modules in Ball-A	PNs available
H7140 POWER SUPPLY in Ball-A	H7140
FAN PANEL ASSEMBLY (50 Hz)	70-19886-00
Filters (four, two in front door and two in back door)	12-11255-08
Filter in Back Door Assembly	12-11255-02

18.3 FRONT END CABINET ASSEMBLY

This paragraph describes how to electrically disconnect the Front End cabinet from the CPU cabinet and how to remove and replace the field replaceable units in the front end cabinet.


NOTE

Some of the modules in the 50 Hz system are different from those in the 60 Hz system. All 50 Hz system differences are noted.

18.3.1 Preliminary Steps


This procedure describes steps that you must take before you begin work on the front end cabinet.

1. On the front of the CPU cabinet, turn the keyed system control panel terminal control switch to the OFF position (Figure 18-1).
2. Open the front and rear doors of the front end cabinet.
3. On the lower left panel at the rear of the front end cabinet, switch the main circuit breaker to the OFF position (Figure 18-3).
4. Contact the customer and ensure that the customer power circuit breaker is switched off.
5. Open the front doors of the CPU cabinet. On the front of the 876-A power controller, switch CB1 to the OFF position (Figure 18-2).



MR-13562

Figure 18-1 System Control Panel



MR-16332

Figure 18-2 876-A Power Controller - Front View

REMOVAL AND REPLACEMENT PROCEDURES




Figure 18-3 Front End Cabinet Cable Connections - Rear View

18.3.2 Front End Cabinet Disconnection

This procedure describes how to electrically disconnect the front end cabinet from the CPU cabinet. Before you begin this procedure, make sure you complete the preliminary steps in Paragraph 18.3.1.

1. Ensure that the customer has turned off power to the system.
2. Disconnect the front end cabinet main ac power cable from the wall receptacle at the customer site.
3. Disconnect triple ribbon cable connectors P4, P5, and P6 from cable connectors J32, J33, and J34 on the I/O backplane of the CPU cabinet (Figure 18-3).

NOTE

When reconnecting ribbon cables, the notch indicates pin 1 and the red stripe points up.

4. Disconnect double ribbon cable connectors P3 and P4 from cable connectors J7 and J8 on the CPU backplane of the CPU cabinet (Figure 18-3).
5. Disconnect the right angle end of the large ac power cable connector P18 from cable connector J18 at rear of 876-A power controller in the CPU cabinet (Figure 18-3).

NOTE

When reconnecting the power cable, be careful not to pull out any cable connectors in the CPU cabinet.

6. Disconnect the RL02 disk drive ac line cord from receptacle L1 at the rear of the 876-A power controller in the CPU cabinet (Figure 18-3).
7. Disconnect the Ball-A unit ac power cord from receptacle L2 at the rear of 876-A power controller in the CPU cabinet (Figure 18-3).

18.3.3 Constant Voltage Transformer (CVT) Assembly Removal

This procedure describes how to remove the CVT assembly from the front end cabinet. Before performing this procedure, make sure you complete the preliminary steps in Paragraph 18.3.1. Remove the CVT module as follows.

(to be supplied)

REMOVAL AND REPLACEMENT PROCEDURES

18.3.4 RL02 Disk Drive Removal and Installation

This procedure describes how to remove the RL02 disk drive unit from the front end cabinet. Before performing this procedure, make sure you complete the preliminary steps in Paragraph 18.3.1.

18.3.4.1 RL02 Disk Drive Removal - Remove the RL02 disk drive unit as follows.

1. Disconnect the I/O "CABLE IN" connector from the rear disk drive unit (Figure 18-4).
2. Disconnect the ac line cord from the rear of the 876-A power controller in the CPU cabinet.
3. Disconnect all cable ties that bind the ac line cord to the front end frame.
4. Move to the front of the front end cabinet and carefully slide the RL02 unit out from the front end cabinet until it catches (Figure 18-5).

WARNING

The RL02 disk drive unit is a heavy piece of equipment. The next three steps of this procedure is best handled by two people, one on each side.

5. Remove the two rear slide screws, one on each side of the drive unit (Figure 18-6).
6. Remove the two front slide screws, one on each side of the drive unit (Figure 18-6).
7. Lift the two locking latches on the slide mounting rails on each side of the drive unit (Figure 18-6). Carefully remove the drive.





Figure 18-4 RL02 Disk Drive - Rear View


MR 11/87

REMOVAL AND REPLACEMENT PROCEDURES



MR-16155

Figure 18-5 RL02 Disk Drive Mounted in Slides




MR-16154

Figure 18-6 Slide Mounting Rail and Slide

REMOVAL AND REPLACEMENT PROCEDURES

18.3.4.2 RL02 Disk Drive Installation - This procedure describes how to install the RL02 disk drive unit into the front end cabinet. Figure 18-5 shows a cabinet-mounted RL02 unit. Install the unit as follows.

1. Open the front and rear doors of the front end cabinet.
2. Remove the slides from the carton containing the disk drive unit. (Retain the hardware for reassembly.)
3. Install the slides in the cabinet using the enclosed hardware. Be sure the slides are at the correct height to permit installation of dress panels when you finish installing the unit. Also make sure that the slides do not bind on any hardware used to mount the slide.
4. Extend the slides to lock position.
5. Place the drive unit on the slides and reinstall the mounting hardware.
 - a. Figure 18-5 shows the relationship between the drive, slide mounting rails, and the slides. Notice the position of the slide mounting rails. These rails are riveted to the sides of the drive.
 - b. The cabinet slides fit under the edge of the mounting rails. The forward edge of the mounting rails are curved to grip the curled edge of the slides (Figures 18-5 and 18-6).
 - c. At the rear of each slide is a locking tab that grips the top rear edge of the rail (Figure 18-6).
 - d. Carefully place the drive on top of the slides, hooking the front and rear of each slide.
 - e. Ensure that the locking latch on each mounting rail drops into a groove on each slide (Figure 18-6).
 - f. Insert the front slide screws to secure the front of each slide to the drive (Figure 18-6).
 - g. Using the slide extension release catch, adjust the length of the slide and insert the rear slide screws. The rear slide screws secure the rear of the slides to the drive.
6. Make sure that the disk drive moves easily on the slides, that there is no binding in the cabinet, and that there is enough room to insert the dress panels.
7. Open the drive access cover by loosening the four captive fasteners holding the cover. Lift the drive access cover off the drive. You can rest the access cover on the rear lip of the drive (Figure 18-7).




MR 15990

Figure 18-7 RL02 Disk Drive with Exposed Drive Logic Module

REMOVAL AND REPLACEMENT PROCEDURES

8. Loosen the head restraining bracket screw on the positioner. Turn the bracket 90 degrees and retighten the screw (Figure 18-8).
9. On the bottom of the drive, remove the two shipping screws that secure the spindle/blower motor.
10. Make sure that the terminal block covers are configured correctly for the input power available (Figure 18-4).



MR-15987

Figure 18-8 RL02 with Covers Removed


REMOVAL AND REPLACEMENT PROCEDURES

11. If there is only one drive in the system, or if this is the last drive of the daisy chain, install a terminator (Digital part number 70-12293) on the "CABLE OUT" receptacle at the rear of the drive.
12. If this is a multidrive system, connect an I/O cable from "CABLE IN" of this drive to the "CABLE OUT" of the previous drive. Repeat for each drive.

NOTE

The total length of cable from controller to the last drive must not exceed 30 m (100 ft).

13. Install the proper unit select plug at the front of the drive (Figure 18-9).
14. Connect the ac line cord to receptacle L1 on the rear of the 876-A power controller in the CPU cabinet.



MR-15988

Figure 18-9 RL02 Disk Drive - Front View

REMOVAL AND REPLACEMENT PROCEDURES

18.3.5 Ball-A Unit Assembly Removal and Installation

This procedure describes how to remove and install the Ball-A unit assembly from the front end cabinet. Before performing this procedure, make sure you complete the steps in Paragraph 18.3.1 and 18.3.2.

18.3.5.1 Ball-A Unit Assembly Removal -

1. In the CPU cabinet, disconnect the Ball-A ac power cord plug from receptacle L2 at the rear of the 876-A power controller.
2. Release all fasteners or clamps used to secure the power cord to the frame.
3. At the rear of the Ball-A mounting box, remove the cable clamp bars that secure the external cables to the unit. Each clamp is held by two 1/4 inch nuts (Figure 18-10).
4. Insert a small screwdriver into the slot in the top right of the front bezel. Release the latch that holds the mounting box by sliding the screwdriver to the left (Figure 18-11).
5. Pull the front of the mounting box until it is fully extended and the slide hold levers are engaged (Figure 18-12).
6. Remove and retain the four 6-32 screws that secure the top cover to the mounting box and remove the top cover.
7. Remove the UNIBUS cable connector from the backplane, the I/O cables attached to the console interface module (M7090), and all other cable connectors in the modules.
8. Route the cables away from the mounting box.




Figure 18-10 Cable Clamps

MR-18077





Figure 18-11 Release Latch

MR 16003



MR 16002

Figure 18-12 BA11-A Installed In Slide Mount


REMOVAL AND REPLACEMENT PROCEDURES

9. Remove and retain the three 8-32 screws that secure the left and right index plates to the slide assembly (Figure 18-13).

WARNING

The BALL-A mounting box is a heavy piece of equipment. Removal of the mounting box requires two people, one on each side of the unit.

10. Remove the mounting box from the slides by lifting the box until the alignment tabs on the index plates are free from the slide mounting bracket.



MR-16000

Figure 18-13 Slide to Index Plate Mounting

REMOVAL AND REPLACEMENT PROCEDURES

18.3.5.2 Ball-A Unit Assembly Replacement - This procedure describes how to replace a Ball-A unit assembly in the front end cabinet.

1. Open the front and rear doors of the front end cabinet.
2. Extend the left and right slide channel to their maximum position at the front of the cabinet.

WARNING

The Ball-A mounting box is a heavy piece of equipment. Installation of the mounting box requires two people, one on each side of the unit.

3. Carefully lift the mounting box above the extended slides and set the index plates over the slide mounting brackets on each side of the box (Figures 18-12 and 18-13). The index plate alignment tabs will engage the sides of the slide mounting bracket.

NOTE

When the slides are fully extended, you may have to force the ends of the slides in toward the sides of the mounting box during installation.

4. Insert the three 8-32 screws through the left index plate tab and into the threaded holes of the slide mounting bracket. Tighten the screws (Figure 18-13). Repeat the process for the right index plate.
5. Perform steps 1 through 7 of Paragraph 18.3.5.1, in the reverse order, to complete the replacement process.


18.3.6 H7140 Power Supply Removal

This procedure describes how to remove the H7140 power supply from the Ball-A unit assembly in the front end cabinet. Before performing this procedure, make sure you complete the preliminary steps in Paragraph 18.3.1 and 18.3.2.

1. In the CPU cabinet, remove the Ball-A ac power cord from receptacle L2 at the rear of the 876-A power controller.
2. Release all fasteners or clamps used to secure the ac power cord to the cabinet frame.
3. At the rear of the Ball-A box, remove the cable clamp bars that secure the external cables to the box. Each clamp is held by two 1/4 inch nuts (Figure 18-10).
4. Remove and retain the four 6-32 screws that secure the top cover to the mounting box, and remove the top cover.
5. Remove the I/O bus cables from the cable trough at the left side of the power supply and route the cables over the top of the power supply.


REMOVAL AND REPLACEMENT PROCEDURES

6. Remove and retain the two 8-32 screws located in each of the two chassis angles at the rear of the mounting box (Figure 18-14).
7. Release the pawl retractors on each side of the box and tilt the box 90 degrees to the maintenance position (Figure 18-15).
8. Remove and retain the four 6-32 screws that secure the bottom cover to the mounting box (Figure 18-15). Remove the cover.
9. Remove and retain the four 6-32 screws that secure the cover plate to the bottom of the power supply assembly (Figure 18-15). Remove the cover.



MR-15999

Figure 18-14 Power Supply Unit, Rear Mounting Screws




MR-19004

Figure 18-15 Power Supply Unit Removal

REMOVAL AND REPLACEMENT PROCEDURES

10. Remove and retain the 10-32 screw that secures the ground lead to the ground bus (Figure 18-16).
11. Loosen the two 3/8 inch nuts on the clamp holding the Flexprint cable to the ground bus bar.
12. Loosen the two 3/8 inch nuts on the clamp holding the +5 V Flexprint cable to the +5 V bus bar.
13. Slide the ground and +5 V cables away from the clamps and bend the cables up toward the backplane.
14. Remove the power Flexprint connector P1 from the power supply connector J11 and bend the connector up toward the backplane.
15. If one or more additional backplanes are mounted in the box, disconnect the connectors attached to J2, J3, and J4 of the power distribution board. Disconnect the backplane connectors from P2, P3, and P4 of the power distribution harness.



MR-16006A

Figure 18-16 Mounting Box, Power Cable Connection

16. Remove and retain the 6-32 screws located on each side of the mounting box, toward the rear (Figure 18-15).
17. Slide the power supply assembly forward about 5.0 cm (2.0 inches) and disconnect the fan assembly power cable from connectors J2 and J3 on the power supply PC board.
18. Slide the power supply assembly from the mounting box and away from the cabinet.

NOTE

When replacing the power supply, make sure you set the mounting box in the maintenance position. Then perform the reverse of steps 18 through 1 above.

18.3.7 Fan Panel Assembly Removal (50 Hz system)

This procedure describes how to remove the fan panel assembly from the front end cabinet and how to remove each fan from the panel. Before performing this procedure, make sure you complete the preliminary steps in Paragraph 18.3.1 and 18.3.2.

NOTE

This procedure is for 50 Hz systems only. The 60 Hz system does not have a Fan Panel Assembly.

1. Remove the ten screws surrounding the fan panel then carefully pull out the entire panel until it catches on the fan power cable (Figure 18-3).
2. Pull the power cable connector away from the ac plug on the power supply (Figure 18-17).
3. Remove each fan by removing the four screws surrounding the fan.





Figure 18-17 Fan Panel Assembly

18.3.8 Front Door Filter Removal

This procedure describes how to remove the two filters from the front door of the front end cabinet. Before performing this procedure, make sure you complete the preliminary steps in Paragraph 18.3.1.

The filters are on the inside of the door. Remove each filter by peeling it away from the velcro strip holding it in place (Figure 18-18). The part number for the filters are: top, 12-11255-08; and bottom, 12-11255-14.




MR 16163

Figure 18-18 Front End Cabinet - Front Door Filters

18.3.9 Rear Door Filter Removal

This procedure describes how to remove the three filters from the rear door of the front end cabinet. Before performing this procedure, make sure you complete the preliminary steps in Paragraph 18.3.1.

The filters are on the inside of the door. Remove each filter by peeling it away from the velcro strip holding it in place. The part numbers for the filters are: top, 12-11255-02; and middle and bottom, 12-11255-08. (Figure 18-19).



MR-16144

Figure 18-19 Front End Cabinet - Rear Door Filters


18.4 CPU CABINET ASSEMBLY

This section describes how to remove and replace the major field replaceable units in the CPU cabinet assembly.

18.4.1 Preliminary Steps

Complete the following steps before you do any work on the CPU cabinet.

1. On the front of the CPU cabinet, turn the keyed system control panel terminal control switch to the OFF position (Figure 18-20).
2. Open the front and rear doors of the CPU and front end cabinets.



MR-13962

Figure 18-20 System Control Panel

18.4.2 Centrifugal 1500 CFM Blower Removal

This procedure describes how to remove the Centrifugal 1500 CFM Blower from the CPU cabinet. Before performing this procedure, make sure you complete the preliminary steps in Paragraph 18.4.1.

1. On the lower left panel at the rear of the front end cabinet, turn the main circuit breaker to the OFF position.
2. On the front of the 876-A power controller in the CPU cabinet, switch CB1 to the OFF position (Figure 18-2).
3. Remove the two screws from the rear of the top cover of the CPU cabinet (Figure 18-21).
4. Lift off the top cover.




Figure 18-21 CPU Cabinet - Top Cover Removal


MR 10156

REMOVAL AND REPLACEMENT PROCEDURES

5. At the rear of the CPU cabinet, disconnect the blower leads from terminal block 1 (Figure 18-22).
6. Loosen the blower cable clamp and release the blower cable (Figure 18-22).
7. On top of the CPU cabinet, remove the 26 screws securing the blower to the CPU cabinet frame (Figure 18-23).

WARNING

The centrifugal blower is a heavy piece of equipment. Removal of the blower should be done by two people.



CPU CABINET — REAR VIEW

NOTES:

1. TERMINAL BLOCK
2. SCREWS (10 - 32)
3. BLOWER CABLE
4. CABLE CLAMP


MR 16140

Figure 18-22 CPU Blower Cable Removal

8. Using the handles on top of the blower, lift the blower up and away from the CPU cabinet frame.

NOTE

Upon power up after installation of a new blower assembly, ensure that the blower fans rotate in the downward direction (as viewed from the rear of the cabinet, looking into the blower exhaust port). If the direction of rotation is reversed, check the harness connection on the terminal block (Figure 18-22) for reversed leads.



MR-16159

Figure 18-23 CPU Blower Removal - Rear View


18.4.3 Modular Power Supply Removal

This procedure describes how to remove individual modular power supplies from the power supply assembly in the CPU cabinet. Before performing this procedure, make sure you complete the preliminary steps in Paragraph 18.4.1.

1. On the front of the 876-A power controller, switch CB1 to the OFF position (Figure 18-2).
2. Select the modular power supply you want to remove from the power supply assembly. Loosen the thumbscrew at the bottom of the module.
3. Using the handle at the middle of the module, slide the module out of the Power Supply Assembly (Figure 18-24).

NOTE

You can remove all of the modular power supplies from the Power Supply Assembly using the above procedure.



MR-16162

Figure 18-24 Modular Power Supply Removal

4. To replace the modular power supply, simply repeat steps 1 - 3 above in the reverse order. Exercise caution when the regulator is being "mated" to the backplane and bus bar assemblies.

18.4.4 CPU Module Replacement

This procedure describes how to remove module boards from the card cage assembly. Before performing this procedure, make sure you complete the preliminary steps in Paragraph 18.4.1. The cleaning procedure for module paddle fingers is found in Section 18.5.

1. If replacing the L0201 console module, turn the TOY ON/OFF switch to the OFF position. It is located on the H7231 battery back-up unit (Figure 18-2).
2. Connect the grounding cord, on the side of the CPU cabinet frame, to the plug on the module case (Figure 18-25).
3. Strap the velcro wrist strap, connected to the cabinet frame, around your wrist.
4. Break the recessed seal on the left side of the module case and open the case.
5. Place the module case on the floor so that the foam padding on the upper half of the case is exposed.




Figure 18-25 Module Case Ground Connection

MR 18158

6. Choose the module board you want to replace. Turn the wing nut at the top of the hinged gate covering that module board and open the gate (Figure 18-26).

-
- This diagram illustrates the assembly of the Module Access Gate. It shows the gate panel being positioned into the frame. A wing nut is used to secure the gate to the frame. The diagram also shows the internal components of the gate, including a latch mechanism and a locking pin. The labels 'WING NUT' and 'MODULE ACCESS GATE' are present.

588 1453/350

18.4.5 Array Modules

The 64 Mb, 16 Mb, or 4 Mb array modules are removed as previously described for CPU modules. However, if a 64 Mb or 16 Mb array module is to be replaced, the SMUS (standard memory units) will have to be removed and reinstalled on the new array module. To remove an SMU from the 64 Mb or 16 Mb array, use the following procedure:

1. Remove the two mounting screws from the faulty SMU, or disengage the SMU from the four standoff crowns.
2. Carefully work the SMU from its connector on the mother board.
3. Reverse the previous two steps to install a replacement SMU, insuring that the standoffs are locked, and then install the memory module.

18.4.6 Air Filter Removal

This procedure describes how to remove the air filter under the card cage support assembly.

WARNING

Before performing this procedure, make sure you have completed the preliminary steps in Paragraph 18.4.1. The CPU must be powered down. If not, the CPU will power down automatically if you try to remove the air filter. You cannot power up the CPU without an air filter in the proper position.

1. Turn the two black catches at the bottom of the card cage support assembly so that they are parallel to the support assembly (Figure 18-27).
2. Slide the air filter out of the CPU cabinet.




Figure 18-27 CPU Card Cage Air Filter Removal

REMOVAL AND REPLACEMENT PROCEDURES

18.4.7 Air Flow Sensor Removal and Installation

This procedure describes how to remove the air flow sensors from the card cage assembly. Before performing this procedure, make sure you complete the preliminary steps in Paragraph 18.4.1.

18.4.7.1 Air Flow Sensor Removal -

1. There are two air flow sensors on the card cage support assembly (Figure 18-28). Disconnect the cable connector from the air flow sensor (P1 or P3).
2. Remove the screw from the middle of the air flow sensor and remove the air flow sensor.

18.4.7.2 Air Flow Sensor Installation -

1. Installation is the reverse of the removal procedure.
2. Test the new sensor after power-up by giving a SHOW POWER command. The sensor is good if no fault is reported.

18.4.8 Air Temperature Sensor Replacement

This procedure describes how to remove the temperature sensors from the CPU cabinet. Before performing this procedure, make sure you complete the preliminary steps in Paragraph 18.4.1.

18.4.8.1 Temperature Sensor Removal -

1. There are four temperature sensors; three on the card cage assembly, and one on the card cage support assembly. Disconnect the EMM harness cable spade lugs from the temperature sensor you are removing (Figure 18-28).
2. Remove the screw from the right side of the heat sensor and remove the temperature sensor.

NOTE

For troubleshooting or emergency situations only, the system may be operated with one or more temperature sensors removed or disconnected. Once a sensor is disconnected, the console (if in PIO mode) will report the condition via a message as follows:

?EMM DETECTED TEMPERATURE INPUT TN IS OPEN OR
VERY COLD. THIS IS A WARNING AND WILL NOT
INITIATE A POWER DOWN SEQUENCE.

- 18.4.8.2 Temperature Sensor Installation - The temperature sensor installation procedure is the reverse of the removal procedure.




Figure 18-28 Temperature and Air Sensor Locations

18.4.9 876-A Power Controller Removal

This procedure describes how to remove the 876-A power controller from the CPU cabinet. Before performing this procedure, make sure you complete the preliminary steps in Paragraph 18.4.1.

1. Disconnect the ac distribution cable from J18 at the rear of the 876-A (power to the 876-A).
2. On the lower left panel at the rear of the front end cabinet, switch the main circuit breaker to the off position. This action cuts off power to the power controller.
3. Disconnect MPS cable connectors from outlets J11 and J12 at the rear of the power controller (Figure 18-29).
4. Disconnect the blower assembly cable connector from outlet J13 at the rear of the power controller.
5. Disconnect SCP "DEC Pwr Bus" cable connector from outlet J6 at the rear of the power controller.
6. Disconnect BBU "Delay Out" cable connector from outlet J7 at the rear of the power controller.
7. Disconnect BBU power connector from J17 at the rear of the power controller.
8. Disconnect MPS "Total Off" connector from outlet J8 at the rear of the power controller.
9. Disconnect MPS "Alarm" black/white cable connector from outlet J10 at the rear of the power controller.




Figure 18-29 Power Controller and BBU - Rear View


REMOVAL AND REPLACEMENT PROCEDURES

10. Disconnect the RL02 disk drive and BALL-A unit assembly power cords from outlets L1 and L2 (respectively) at the rear of the power controller.
11. Move around to the front of the CPU cabinet and remove the six screws, three on the left and three on the right side of the power controller (Figure 18-30).

WARNING

The 876-A power controller is a heavy piece of equipment. Be careful when sliding out the old power controller and inserting the new. The task of removal and insertion is best handled by two people.

12. Slide the power controller out from the CPU cabinet.



MR-16157

Figure 18-30 Power Controller Removal

REMOVAL AND REPLACEMENT PROCEDURES

18.4.10 H7231 BBU Power Supply Removal

This procedure describes how to remove the H7231 battery back-up power supply from the CPU cabinet. Before performing this procedure, make sure you complete the preliminary steps in Paragraph 18.4.1.

1. On the front of the 876-A power controller, switch CB1 to off to remove power to the BBU. Then turn the TOY ON/OFF switch on the front of the BBU to the off position (Figure 18-2).
2. Disconnect cable connector P18 from the rear of the BBU power supply (Figure 18-31).
3. Disconnect bus bar ground connector and bus bar cable connector from the rear of the BBU power supply.
4. Disconnect BBU main power cord connector from outlet L3 at the rear of the 876-A power controller.
5. Disconnect black/white cable connector P6 from the rear of the BBU power supply.




Figure 18-31 BBU Cabling

MR-16195

REMOVAL AND REPLACEMENT PROCEDURES

6. Move around to the front of the CPU cabinet and remove the two securing nuts, on the sides of the power supply (Figure 18-32).
7. Slide the power supply forward out from the CPU cabinet.
8. Remove the four screws, two on the left and two on the right side, from the power supply shell.
9. Slide the power supply shell out from the CPU cabinet.
10. A new H7231 power supply comes with shell sleeves. Reverse the above procedure to install the new power supply.

NOTE

Make sure the voltage select switch on the front of the power supply is set correctly for your environment (120 V). Also, make sure that the TOY ON/OFF switch is set to the on position when the system is powered-up.




Figure 18-32 BBU Removal

REMOVAL AND REPLACEMENT PROCEDURES

18.5 MODULE PADDLE CONNECTOR CLEANING PROCEDURE

18.5.1 Introduction

This procedure describes the cleaning method for the gold plated module paddle connector fingers.

NOTE

This procedure replaces the traditional eraser method - which removes up to 10 microinches of gold each time an eraser is used for cleaning.

The continuous gold removal causes corrosion of the base metals (copper and nickel) under the gold, which in turn causes contact intermittents and opens.

For additional detail refer to:

1. Engineering Standard EL-FS266-00, Title: Printed Wiring Board (PWB) Gold Contact Cleaning Process

DOCUMENT IDENTIFIER: A-SP-ELFS266-00

2. Miscellaneous Fiche (Green) Field Service Miscellaneous Tech Tip Number 1, April 4, 1984, Title: Gold Finger Cleaning Using Gold Wipes

18.5.2 Required Materials

1. Cleaning material: TX809 GOLD WIPES Cleansing Pads, Digital part number: 49-01603-01.
2. Protective gloves, SOLVEX gloves by Edmont, vendor part number 37-175-X (where X = size). There is no Digital part number at this time.

18.5.3 Precautions

1. DO NOT USE gold wipes to clean any part of a disk or tape assembly such as disk heads and packs, tape heads and magnetic tapes, etc.
2. NO SMOKING - Highly toxic phosgene gas can develop from fumes coming into contact with a burning cigarette tip.
3. Do not expose Gold Wipe pads to sources of extreme heat (e.g., soldering iron) as toxic gases can be generated.
4. Use with adequate ventilation.
5. Avoid prolonged contact with skin and eyes.
6. Wear the specified gloves. Do not use Latex or polyethylene gloves - they will dissolve and leave harmful plasticized film on the contact surfaces.

7. Wear safety glasses with side shields.
8. Contact lenses should not be worn.
9. After using Gold Wipes, wash hands thoroughly with soap and water before handling food or drink.
10. Do not use Gold Wipes on rubber, polystyrene, aluminum, and most plastics.

18.5.4 Cleaning Procedure

1. Ground yourself properly using a grounding strap.
2. Follow the previous PRECAUTIONS.
3. Place the module on a static mat, or on a clean, conductive, and grounded table surface.
4. Use one Gold Wipe cleansing pad for each module.
5. Open a TX809 packet, and remove the cleansing pad.
6. Firmly grasp the module to be cleaned by the handle, or an unpopulated area of the module - minimizing the risk of static and physical damage.
7. Hold the pre-folded pad partially open.
8. Place the module paddle fingers into the partially opened pad and apply finger pressure against the pad.
9. Maintain finger pressure while pulling the pad away from the paddle fingers. As shown in Figure 18-33, the cleansing action should be parallel to the length of the fingers.
10. Wipe all paddle fingers reversing the fold of the pad as required.
11. After cleaning each module, discard the pad and packet in a disposal receptacle which is located in an adequately ventilated area.




Figure 18-33 Paddle Finger Cleaning Action



CHAPTER 19
TECHNOLOGY AND TOOLS

19.1 MCA DESCRIPTIONS, LOCATIONS, AND PRINT SET CROSS REFERENCE

Table 19-1 contains an alphabetical list of MCAs, with their mnemonics, name descriptions, and print set locations.

Table 19-1 MCA/Print Set Cross Reference

MCA	Description	Print Location (Quantity)
ABS	ABus interface	MCC4
ADA	Address translate	MAP1(3)
		MAP2(2)
ADB	Address translate	MAP2
ADD	GPRA/GPRB address, WBus match A/B,	
	EBox WBus address	EDPC
ALU	EVA, ARbus, BROT	EDP1(2)
		EDP2(2)
		EDP3(2)
		EDP4(2)
ARB	Arbitor	MCC6
ACB	Adder Control B	FA13
ACC	Adder Control C	FA13
ACL	Adder Carry Look-ahead	FA10
ALN	Alignment	FA04(2)
		FA05(2)
BEN	UPC, micro stack address counter	CSBP(3)
CAM	Match	MAP3(2)
CKP	Check bit	MCDW
CLA	Carry Look-ahead	EDPF
CRA	Control Register A	MCCJ
CRB	Control Register B	MCCJ
DBS	Double Buffer Slice	IBD6(2)
		IBD7(2)
DPC	Data Patch Control - ALU control, WBus match control, parity control	EDPD
DPP	Data Path Parity and carry look-ahead	IDP6(2)
ECC	ECC	MCDM
ERR	Error	MCCM

TECHNOLOGY AND TOOLS

MCA DESCRIPTIONS, LOCATIONS, AND PRINT SET CROSS REFERENCE

Table 19-1 MCA/Print Set Cross Reference (Cont.)

MCA	Description	Print Location (Quantity)
FBR	FBox Registers	FA01
FAD	Fraction Adder	FA06(2)
		FA07(2)
		FA08(2)
		FA09(2)
FXP	F Exponent Processor	FA01
GXP	G Exponent Processor	FA01
IAD	IBox Adder	IDP1(4)
		IDP2(4)
IBF	Instruction Buffer	IBD1(3)
		IBD2(3)
		IBD3(3)
IFG	Decode Flags, buffer control	IBDA
IOP	OP Bus data path	IBD4(2)
		IBD5(2)
IST	IBox Stall	ICAG
IVA	IBox Virtual Address	IDP3(4)
		IDP4(4)
MAI	MBox Array Interface	MCC8
MAX	Multiplier Accumulator Extension	FM11
MCF	Microcontrol Field Decode	MCC6
MCB	Multiply Control B	FM09(2)
		FM10(2)
MCL	Multiply Carry Look-ahead	FM08
MDP	Memory Data Paths	MCD1(2)
		MCD2(2)
		MCD3(2)
MIC	UPC, CSDR load sync., clear flag sync.	CSBQ(2)
MMD	MBox Microcode Data Registers	MCCA(2)
		MCCB(2)
MMS	MBox Microsequencer	MCC1
MPR	Multiplier Unpacker	FM01(2)
		FM02(2)
MPY	Multiplier	FM03(2)
		FM04(2)
		FM05(2)
		FM06(2)
		FM07(1)
MPZ	Multiplier Extension	FM07
MSQ	Micro Sequencer (FBox adder)	FA11
MSQ	Micro Sequencer (FBox multiplier)	FM12
PDP	Data path parity checker - GPRA/B, ALU, WBus, ALU shift bits, VMQ shift bits OPBus long word, WReg longword	EDPH
REG	Address Register	MAPP
RES	Response	MCC5
RRC	RAM Register Control	FA12

TECHNOLOGY AND TOOLS

MCA DESCRIPTIONS, LOCATIONS, AND PRINT SET CROSS REFERENCE

Table 19-1 MCA/Print Set Cross Reference (Cont.)

MCA	Description	Print Location (Quantity)
SCE	Shift Count Element - shift count information and control, ALU control, data path control, ARBus receivers	EDPE
SEQ	IBox micro sequencer	ICA8
SHF	Shifter - Post ALU shifting, data formatting, 0 - 63 data rotation, WBus receive	EDPA(2) EDPB(2) FA02(2)
SOP	Source Operand	IDP7
SPA	Scratch Pad Addressing	IBD9
SPD	Specifier Decode	MCC7
STA	Port Status	
UFO	Data Register	MCDU
UPC	IBox Micro PC	ICA8
UPK	Unpacker	IDP6
VAL	IBuf Valid Bits	IBD8
WVP	Write Valid	MAPL

Table 19-2 contains a list of MCAs by module, with corresponding print set locations.

Table 19-2 MCA Descriptions and Locations

Module Name	MCA Name	Qty	Location	Description
EBox MCAs				
L0209 (EDP) EBox Data Path				
	ADD	1	C	Address
	ALU	8	1-4	Arithmetic Logic Unit
	CCD	1	F	Condition Codes
	CLA	1	F	Carry Look Ahead
	DPC	1	D	Data Path Control
	PDP	1	H	Parity Data Path
	SCE	1	E	Shift Counter
	SHF	4	A-B	Shifter
L0216 (CSB) Control Store B				
	BEN	3	P	Branch Enable
	MIC	2	Q	Microsequencer

TECHNOLOGY AND TOOLS
MCA DESCRIPTIONS, LOCATIONS, AND PRINT SET CROSS REFERENCE

Table 19-2 MCA Descriptions and Locations (Cont.)

Module Name	MCA Name	Qty	Location	Description
FBOX MCAs				
L0212 (FBA, FA) FBox Adder				
	ACB	1	13	Adder Control B
	ACC	1	13	Adder Control C
	ACL	1	10	Add Carry Look Ahead
	ALN	4	4-5	Alignment
	FAD	8	6-9	Adder
	FBR	1	1	Register
	FXP	1	1	Exponent
	GXP	1	1	G Exponent
	MSQ	1	11	Microsequencer
	RRC	1	12	RAM Register Control
	SOP	4	2-3	Source Operand
L0213 (FBM, FM) FBox Multiply				
	MAX	4	9-10	Multiply ACC Extension
	MCB	1	11	Multiply Control B
	MCL	1	8	Multiply Carry Look Ahead
	MPR	4	1-2	Multiply Unpacker
	MPY	9	3-7	Multiply
	MPZ	1	7	Multiply Extension
	MSQ	1	12	Microsequencer
IBOX MCAs				
L0208 (IBD) IBox Buffer Decode				
	DBS	4	6	Double Buffer Slice
	IBF	9	1	Instruction Buffer
	IFC	1	A	IBox Flag Control
	IOP	4	4	IBox Op Bus
	SPD	1	9	Specifier Decode
	VAL	1	8	Valid Bit Logic
L0207 (ICA) IBox Control Logic A				
	IST	1	G	Install
	SEQ	1	8	Sequencer
	UPC	1	8	Micro-PC
L0206 (IDP) IBox Data Path				
	DPP	2	6	Data Path Parity
	IAD	8	1	IBox Address
	IVA	8	3	IBox Virtual Address
	SPA	1	7	Scratch Pad Address
	UPK	1	6	Unpacker

Table 19-2 MCA Descriptions and Locations (Cont.)

Module Name	MCA Name	Qty	Location	Description
MBOX MCAs				
L0205 (MAP) MBox Address Path				
	ADA	5	1	Address Path A
	ADB	1	2	Address Path B
	CAM	2	6	Match
	REG	2	5	Register
	WVP	1	L	Written-Valid-Parity
L0220† (MCC) Control				
	ABS	1	4	ABus Control
	ARB	1	6	Arbitrator
	CRA	1	J	Control Register A
	CRB	1	J	Control Register B
	ERR	1	M	Error
	MAI	1	8	Memory Array Interface
	MCF	1	6	Micro Control Function
	MMD	4	A	Memory Data Register
	MMS	1	1	MBox Microsequencer
	RES	1	5	Response
	STA	1	7	Status
L0204 (MCD) Data Path				
	CKP	1	W	Check Parity
	ECC	1	M	Error Correction Code
	MDP	1	1	MBox Data Path
	UFO	1	U	Data Registers
CLOCK MCA				
L0217† (CLK) Clock				
	CLC	1	3	Clock Control
†L0230 for VAX 8650				
†L0231 for VAX 8650				

NOTE

"Location" refers to a specific module print.
e.g., the Clock Control MCA is found on CLK3.

19.2 ECL TROUBLESHOOTING INFORMATION

The VAX 8600 processor logic is implemented with Emitter Coupled Logic (ECL) technology. There are numerous Technical Data books available which describe the theory of this family of logic, including the advantages and disadvantages of its use.

From a troubleshooting aspect, there are a number of concerns that must be considered when investigating ECL circuits.

19.2.1 Test Equipment

As ECL logic is relatively fast, comparable test equipment must be used. For scoping, a 200 MHz or faster oscilloscope is required, along with equal length probes and short (6 inch or less) ground clips. Beware that 'kinks' in the probe leads may distort the waveforms.


19.2.2 Termination

One of the most critical components in an ECL circuit is the termination. It can be the source of many circuit problems. The text that follows describes the basic ECL circuit and termination techniques used in the VAX 8600/8650, followed by a troubleshooting flowchart and related waveforms.

Every ECL signal run requires termination. The VAX 8600/8650 CPU employs parallel termination techniques on both single-ended and double-ended buses.

19.2.2.1 Single-ended ECL Signal Run - This type of termination is used to terminate a signal at or near the end of the run. The termination consists of a 56 ohm resistor tied to -2 V. See Figure 19-1.

19.2.2.2 Bi-directional ECL Signal Run - This type of termination (Figure 19-2) is used in bus applications where multiple bus drivers are employed, and the signal run is terminated at both ends of the run with 56 ohms to -2 V. For this application, 25 ohm bus drivers are used (as the circuit impedance will be 28 ohms). Note that these special 25 ohm bus drivers have a very high output impedance. When all drivers are disabled, the signal will be at a -2 V level (rather than a typical -1.8 V level).



MR-15823

Figure 19-1 Single-ended ECL Signal Run




Figure 19-2 Bi-directional ECL Signal Run

19.2.2.3 Termination Components - Following is a list of termination components used in the VAX 8600/8650 system.

1. 56 ohm discrete component resistor (13-02602-00). For instance, ABUS termination on STM/L0224 module (print STM1)
2. 10-pin STERM SIP (19-17493-00) used on CPU modules where the signal does not leave the module.
3. 18-pin VTERM SIP (20-21347-01) used on CPU modules where the signal leaves the module or requires visibility.

Refer to the STERM SIP and VTERM SIP data sheets for more details on these components.


19.2.2.4 How to Locate the Termination Point of a Given Signal - There are several methods used by the engineering CAD tool to indicate the termination of an ECL signal in the engineering drawings. Although there are no hard and fast rules to determine where a signal is terminated, there are some general guidelines that are used. Beware that these guidelines are sometimes not followed.

1. If the signal does not leave the module on which it was generated, it will be terminated on that module. The schematic representation will depend upon whether the termination is on an STERM or a VTERM.

If terminated by an STERM, a resistor will be drawn at the output of the signal source gate. If terminated by a VTERM, the signal is terminated within the VTERM which is shown on the visibility terminator print pages near the end of the module schematic set. See Figures 19-3 and 19-4. Figure 19-3 is taken from print set sheet MCDT, and Figure 19-4 is taken from print set sheet MCDV.


TECHNOLOGY AND TOOLS

Termination



MR 16146

Figure 19-3 STERM Termination



MR 16147

Figure 19-4 VTERM Termination

Notice two of the output signals shown on print MCDT, MCDT CLK3 T1B A L and MCDT CLK3 T1B C L, are terminated on this module and do not have visibility (termination is shown at the gate output). The signal MCDT CLK3 T1B B L is terminated at the VTERM on print set sheet MCDV as illustrated.

VTERM termination of a signal will identify the termination component location using the 'Znn' identifier within the SUDS drawing. The physical type and location of the termination component for STERM and discrete termination can be found only by using the module NAME-SORT wirelist.

2. If the signal leaves the module on which it was generated, the signal will be terminated on another module. To determine where the signal is terminated, use:
 - a. the BL or NAMESORT wirelist.
 - b. the console SHOW NAME 'signal name' command.
 - c. the 'signal name sort' SDB table.

Once you determine which module the signal is terminated on, refer to the 'SDB VISIBILITY' pages (which are generally near the end of the module schematic set). This will give you the pin and component number of the termination package (either a VTERM SIP or a 10164V DIP). See the example that follows.

Example 19-1 Off Module Termination

The signal 'CSA UMC F 4 A L' (Figure 19-5) originates on print CSAS and is terminated on print ICAK at VTERM Z29 (Figure 19-6). Note that on print ICAK, the signal is titled '-CSA UMC F 4 A H' and there is no designator to show that the signal is on backplane pin A13-42. This is due to a deficiency in the CAD tools. Note that the wirelist BL sort entry gives the pin number of the backplane, as well as some print pages where the signal goes to (See Example 19-2). Since there is no designator for the signal on print ICAK, the print page number is excluded from the BL list. However, once you determine which module the signal feeds, you need only check the VTERM print page to find the signal.




Figure 19-5 UMC F 4 A L Signal Generation




Figure 19-6 UMC F 4 A L Signal Termination

Example 19-2 Extract from CPU Backplane Wirelist BL-sort (70-19198)



-CSA UMC F 4 A H

AC3	A47	EO	0.00	0.00	-10.00	0.00	CSAO	C8	CSAS
AC3	A47						CSAS	C4	
AC13	A42	EIPZ	3.42	17.09	0.00	-200.00	ICAO	B7	
AC13	A42						ICAB	D8	
		EOIPZ	3.42	17.09	-10.00	-200.00			

19.2.3 Troubleshooting ECL Signals

Figures 19-7 through 19-20 illustrate some of the more common ECL circuit failures that may be experienced. Although many of these problems were more symptomatic of older wire-wrapped backplanes, you may experience similar faults caused by electrical/mechanical failures due to current processes such as dirty finger pins, bad ground cubes, nicked backplane wires (from an ECO), or cold solder joints. Figure 19-7 illustrates a typical ECL waveform.

TYPICAL ECL WAVEFORM



MR-15821

Figure 19-7 Typical ECL Waveform




Figure 19-8 Flowchart, ECL Signal Troubleshooting

TECHNOLOGY AND TOOLS
Troubleshooting ECL Signals

IMPROPER TERMINATION: TOO LOW




Figure 19-9 Improper Termination: Too low

SIGNAL SHORTED TO -2 V





Figure 19-10 Output Shorted to -2 v


UNTERMINATED WAVEFORM: 56Ω RESISTOR MISSING



MR-15827

Figure 19-11 Unterminated Waveform, 56 Ohm Resistor Missing

SIGNAL SHORTED TO -2 V




MR-15829

Figure 19-12 Inverted Output Shorted to - 2 v

TECHNOLOGY AND TOOLS
Troubleshooting ECL Signals


IMPROPER TERMINATION: TOO HIGH



MR-15830

Figure 19-13 Improper Termination: Too High

CAPACITOR IN SIGNAL RUN



MR-15832

Figure 19-14 Capacitor in Signal Run

OPEN ETCH: NO CONNECTION TO -2 V




Figure 19-15 Open Etch, No Connection to -2 v

MR-15834

IMPEDANCE MISMATCH




Figure 19-16 Impedance Mismatch

MR-15824

TECHNOLOGY AND TOOLS
Troubleshooting ECL Signals




Figure 19-17 Signal Shorted to Ground

MR 15836





Figure 19-18 Open Input Etch

MR 15835


TWO SHORTED SIGNALS



MR-15837


Figure 19-19 Two Shorted Signals

COMPLEMENTARY OUTPUTS SHORTED TOGETHER



MR-15833

Figure 19-20 Complementary Outputs Shorted Together



CHAPTER 20

VAX 8600/8650 REGISTER DESCRIPTION

Chapter 20 has been reorganized. There are no longer multiple copies of any register. Unfavorable feedback from the field, the increase in page count due to size reduction, and additional material for some registers, necessitated the removal of duplicate registers.

The registers are listed alphabetically, except the CI780 registers, DR780 registers, DW780 registers, and SBIA registers are listed alphabetically within the individual groups, ie., all CI780 registers are listed under CI780.

In the index, The Internal Privileged Registers (IPRs), Internal Registers (IRs), Miscellaneous Registers (Misc), and Machine Check Stack Frame (MHCK Stack Frame) are listed both by individual registers and alphabetically within groups. The Stack Frame registers are listed in two sub-groups, Machine Check Stack Frame, and Stack Frame.

Keep in mind that the Stack Frame is not valid unless Error Handling Microcode has loaded the EBox scratch pad locations.

VAX 8600/8650 REGISTER DESCRIPTION

ACCS	20-7	EBCS	20-48
ASTLVL	20-7	EBXWD1	20-51
		EBXWD2	20-51
		EDMC	20-52
BTOY0_3	20-8	EDPSR	20-53
		EHMSTS	20-55
CBUS REGISTERS		EHSR	20-60
BTOY0_3	20-8	EMD	20-63
CMISC	20-20	ERRSUM	20-148
RBUF0_3	20-113	ESASAV	20-63
RBUFC	20-114	ESP	20-63
RXCS	20-129	ESPA	20-64
RXDB	20-130	ESPD	20-64
STXCS	20-176	EVMQSAV	20-65
STXDB	20-177		
TURN	20-180	FBXERR	20-66
TXCS	20-182		
TXDB	20-184	IBESR	20-68
UTOY0_3	20-187	IBGPR	20-70
XBUF0_3	20-189	ICCS	20-71
XBUFC	20-189	ICR	20-72
		IPL	20-72
CI780 CNFGR	20-8		
CI780 MADR	20-10	INTERNAL PRIVILEGED REGISTERS	
CI780 MDATR	20-10	ACCS	20-7
CI780 PMCSR	20-13	ASTLVL	20-7
CI780 PORT CONTROL	20-14	CRBT	20-21
CI780 PORT ERR STATUS	20-16	CSWP	20-27
CI780 PORT FAILING ADR	20-17	DFI	20-28
CI780 PORT PARAMETER	20-18	EHSR	20-60
CI780 PORT QUE BLK BASE	20-18	ESP	20-63
CI780 PORT STATUS	20-19	ESPA	20-64
		ESPD	20-64
CMISC	20-20	ICCS	20-71
CPC	20-20	ICR	20-72
CRBT	20-21	IPL	20-72
CSSES	20-22	ISP	20-73
CSHCTL	20-23	KSP	20-73
CSLINT	20-24	MAPEN	20-80
CSM STATUS	20-26	MCCTL	20-80
CSWP	20-27	MDCTL	20-86
		MDECC	20-87
DFI	20-28	MENA	20-90
DIAGCS	20-144	MERG	20-91
DMAICA	20-144	NICR	20-98
DMAIID	20-145	POBR	20-98
		POLR	20-98
DR780 CR READ	20-29	P1BR	20-99
DR780 CR WRITE	20-30	P1LR	20-99
DR780 DCRAR	20-31	PAMACC	20-100
DR780 UTL	20-32	PAMLOC	20-101
		PCBB	20-102
DW780 BRRVR4_7	20-33	PMR	20-104
DW780 BRSVR0_3	20-34	PTE	20-107
DW780 CNFGR	20-35	RXCS	20-129
DW780 DCR	20-37	RXDB	20-130
DW780 DPR0_15	20-38	SBR	20-166
DW780 FMER	20-40	SCBB	20-166
DW780 FAILED UNIBUS		SID	20-171
ADDRESS REGISTER	20-40	SIRR	20-173
DW780 MRO 495	20-41	SISR	20-173
DW780 UACR	20-42		
DW780 USAR	20-45		

INTERNAL PRIVILEGED REGISTERS

(continued)

SLR	20-174
SSP	20-175
STXCS	20-176
STXDB	20-177
TBCHK	20-177
TBIA	20-178
TBIS	20-178
TODR	20-179
TXCS	20-182
TXDB	20-184

IVASAV	20-73
MDECC	20-87
MEAR	20-89
MEDR	20-89
MERG	20-91
MSTAT1	20-93
MSTAT2	20-96
PC	20-101
PSL	20-105
SFBCNT	20-170
VIBASAV	20-188

INTERNAL REGISTERS

CPC	20-20
CSES	20-22
CSHCTL	20-23
CSLINT	20-24
EBCS	20-48
EDMC	20-52
EDPSR	20-53
EMD	20-63
ESASAV	20-63
IBESR	20-68
ISASAV	20-72
IVASAV	20-73
MEAR	20-89
MEDR	20-89
MSTAT1	20-93
MSTAT2	20-96
VIBASAV	20-188
VPCBITS	20-188

ISASAV	20-72
ISP	20-73
IVASAV	20-73

KSP	20-73
-----	-------

LRHR	20-74
LRSR	20-74
LTHR	20-75
LWCR	20-76
LWMR_HI_ORDER	20-78
LWMR_LO_ORDER	20-77

MACHINE CHECK STACK FRAME

CPC	20-20
CSES	20-22
CSHCTL	20-23
CSLINT	20-24
EBCS	20-48
EBXWD1	20-51
EBXWD2	20-51
EDPSR	20-53
EHMSTS	20-55
ESASAV	20-63
EVMQSAV	20-65
FBXERR	20-66
IBESR	20-68
ISASAV	20-72

MAINT	20-154
MAPEN	20-80
MCCTL	20-80
MCSR0	20-81
MCSR1	20-82
MCSR2	20-83
MCSR3 READ	20-84
MCSR3 WRITE	20-85
MDCTL	20-86
MDECC	20-87
MEAR	20-89
MEDR	20-89
MENA	20-90
MERG	20-91

MISCELLANEOUS REGISTERS

EVMQSAV	20-65
IBGPR	20-70
PSL	20-105
SPADR	20-174
STATE	20-175

MSTAT1	20-93
MSTAT2	20-96

NICR	20-98
------	-------

PCI REGISTERS

ERCR	20-76
ERHR	20-74
ERMNR	20-77
ERSR	20-74
ETHR	20-75
EWCR	20-76
EWMR	20-77
LRCR	20-76
LRHR	20-74
LRMR	20-77
LRSR	20-74
LTHR	20-75
LWCR	20-76
LWMR_HI_ORDER	20-78
LWMR_LO_ORDER	20-77
RBSR	20-113
RRCR	20-76
RRHR	20-74
RRMR	20-77
RRSR	20-74

VAX 8600/8650 REGISTER DESCRIPTION

PCI REGISTERS

(continued)

RTHR 20-75
RWCR 20-76
RWMR 20-77

POBR 20-98
POLR 20-98
P1BR 20-99
P1LR 20-99
PAMACC 20-100
PAMLOC 20-101
PC 20-101
PCBB 20-102
PECAS 20-103
PERAS 20-103
PMR 20-104
PSL 20-105
PTE 20-107

QADR0 20-108
QADR1 20-108
QCSR0 20-109
QCSR1 20-110
QCSR2 20-111
QCSR3 20-112
QDATA0 20-112
QDATA1 20-112
QUADCLR 20-159

RBSR 20-113
RBUF0 3 20-113
RBUFC 20-114

RH780 BCR 20-114
RH780 CAR 20-115
RH780 CR 20-115
RH780 CSR 20-116
RH780 DR 20-117
RH780 SMR 20-118
RH780 SR 20-118
RH780 VAR 20-121

RLBA 20-121
RLCSR 20-122
RLDA GET STATUS 20-124
RLDA READ WRITE 20-125
RLDA SEEK 20-126
RLMPR GET STATUS 20-126
RLMPR READ 20-128
RLMPR WRITE 20-128
RXCS 20-129
RXDB 20-130

SBIA CR 20-142
SBIA CSR 20-143

SBIA REGISTERS

SBIA CONFIG REG 20-142
SBIA CONTROL STATUS 20-143
SBIA DIAG CONTROL 20-144

SBIA DMA CA 20-146
SBIA DMA ID 20-147
SBIA ERROR SUMMARY 20-148
SBIA SBI ERROR 20-152
SBIA SBI FAULT STATUS 20-154
SBIA SBI MAINT 20-156
SBIA SBI QUADCLR 20-158
SBIA SBI SILO 20-159
SBIA SBI SILO COMPARE 20-162
SBIA SBI TIMEOUT ADR 20-164
SBIA SBI UNJAM 20-164
SBIA SBI VECTOR 20-165

SBIERR 20-152
SBISTS 20-154
SBR 20-166
SCBB 20-166
SDCS 20-167
SDDB 20-168
SDMS 20-169
SFBCNT 20-170
SID 20-171
SILO 20-159
SILOCOMP 20-162
SIRR 20-173
SISR 20-173
SLR 20-174
SPADR 20-174
SSP 20-175

STACK FRAME

CPC 20-20
CSES 20-22
CSHCTL 20-23
CSLINT 20-24
EBCS 20-48
EBXWD1 20-51
EBXWD2 20-51
EDPSR 20-53
EHMSTS 20-55
ESASAV 20-63
EVMQSAV 20-65
FBXERR 20-66
IBESR 20-68
ISASAV 20-72
IVASAV 20-73
MDECC 20-87
MEAR 20-89
MEDR 20-89
MERG 20-91
MSTAT1 20-93
MSTAT2 20-96
PC 20-101
PSL 20-105
SFBCNT 20-170
VIBASAV 20-188

STATE 20-175
STXCS 20-176
STXDB 20-177

TBCHK	20-177
TBIA	20-178
TBIS	20-178
TOADR	20-164
TODR	20-179

TOY REGISTERS

TRDR	20-179
TRSR	20-180
TWCR	20-181
TWDR	20-179

TRDR	20-179
TRSR	20-180
TURN	20-180
TWCR	20-181
TWDR	20-179
TXCS	20-182
TXDB	20-184

UNJAM	20-164
-------	--------

USART REGISTERS

ERCR	20-76
ERHR	20-74
ERMR	20-77
ERSR	20-74
ETHR	20-75
EWCR	20-76
EWMR	20-77
LRCR	20-76
LRHR	20-74
LRMR	20-77
LRSR	20-74
LTHR	20-75
LWCR	20-76
LWMR_HI_ORDER	20-78
LWMR_LO_ORDER	20-77
RBSR	20-113
RRCR	20-76
RRHR	20-74
RRMR	20-77
RRSR	20-74
RTHR	20-75
RWCR	20-76
RWMR	20-77


USP	20-187
UTOYO_3	20-187

VECTOR	20-165
VIBASAV	20-188
VPCBITS	20-188

XBUF0_3	20-189
XBUFC	20-189



VAX 8600/8650 REGISTER DESCRIPTION
ACCS
ASTLVL



Note: The ACCS is a read/write register that contains the accelerator type, the revision status, and the enable bit.

<31:24> RESERVED

<23:16> FBOX REVISION

Number for the VAX 86xx FBox, or for the FTM and FJM boards that replace the FBox when there is no FBox present.


<15> FBOX ENABLE

Enables the execution of Floating Point instructions by the FBox. Writing a one to this position initializes the FBox and enables it to execute VAX instructions.

<14:08> RESERVED

<07:00> FBOX TYPE

Specifies the type of the accelerator. For a VAX 86xx FBox, this field is set to a 1 by ECODE (Escratch location: DC). If no accelerator is present, this field equals 0.



<31:03> MBZ

Must be zero.


<02:00> ASYNCHRONOUS SYSTEM TRAP LEVEL

Contains access mode number (established by software) of the most privileged access mode for which an Asynchronous System Trap (AST) is pending. Controls the triggering of the AST delivery interrupt during REI instructions.

ASTLVL MEANING

- 0 AST pending for access mode 0 (KERNEL)
- 1 AST pending for access mode 1 (EXECUTIVE)
- 2 AST pending for access mode 2 (SUPERVISOR)
- 3 AST pending for access mode 3 (USER)
- 4 No pending AST
- 5-7 Reserved for Digital

VAX 8600/8650 REGISTER DESCRIPTION
BTOY
CI780 CNFGR



NR-14200

The BTOY registers consist of four CBus RAM byte locations.

<07:00> **BUFFERED TOY DATA**


The console software loads the BTOY registers from the TOY counter once every 10 milliseconds. This maintained value is read by EBox microcode when executing an MFPR #TODR instruction. The byte alignment is:

<31-24> = BTOY 3
<23-16> = BTOY 2
<15-08> = BTOY 1
<07-00> = BTOY 0

NOTE: Refer to the VAX 8600/8650 Console Technical Description Manual, EK-KA86C-TD, for more detailed information on TOY CLOCK operation.

CNFR
XXXXX000

(CI780) CONFIGURATION REGISTER



NR-14212

<31:26> **SBI FAULT BITS**

These bits are set when the port detects the respective fault condition as described below. The fault bits are read only.

<31> **PARITY FAULT**

Set when the port detects an SBI Parity error.

<30> **WRITE SEQUENCE FAULT**

Set when the port receives a write mask command that is not immediately followed by the expected write data.

<29> **UNEXPECTED READ DATA FAULT**


Set when the port receives read data but did not issue a read command.

<28> **RESERVED**

VAX 8600/8650 REGISTER DESCRIPTION
CI780 CNFGR

- <27> **MULTIPLE TRANSMIT FAULT**
Set when the ID bits transmitted by the port do not match the ID bits received back from the SBI.
- <26> **TRANSMIT FAULT**
Set if the CI780 was the SBI nexus that caused the SBI FAULT line to assert.
- <25:24> **RESERVED**
- <23> **POWER DOWN**
Set if the port is powering down. PDN is set by the assertion of SUPPLY ACLO if the port is in the uninitialized state, otherwise it is set by the microcode via the PDN bit. Cleared: by writing a 1 to it or by setting the PUP bit.
- <22> **POWER UP**
Set by the negation of SUPPLY ACLO. Cleared by writing a 1 to it or by setting the PDN bit.
- <21> **RESERVED**
- <20> **COMMAND TRANSMIT TIMEOUT**
Set when the port initiates an SBI transfer and does not receive an ACK or error confirmation within 102 microseconds. The timeout period is selectable by backplane jumpers.
- <19> **READ DATE TIMEOUT**
Set when the port initiates an SBI read transfer and read data is not returned within 102 microseconds.
- <18> **COMMAND TRANSMIT ERROR**
Set when the port receives an error confirmation in response to a port initiated SBI command transmission.
- <17> **READ DATA SUBSTITUTE**
Set when the port receives an RDS (uncorrectable read data) confirmation in response to a port initiated SBI read command.
- <16> **CORRECTED READ DATA**
Set when the port receives a CRD confirmation in response to a port initiated SBI read command.
- <15:11> **RESERVED**
- <10> **TRANSMIT FAIL**
Set by the microcode through the miscellaneous control field when PFV (power fail valid) and ASSERT FAIL are true.
- <09> **TRANSMIT DEAD**
Set by the microcode through the miscellaneous control field when PFV and ASSERT DEAD are true.
- <08> **POWER FAIL DISABLE**
Set when the SBI FAIL and SBI DEAD drivers to the SBI are disabled.
- <07:00> **ADAPTOR CODE**
These bits contain the CI780 SBI adaptor code, 38(16).


VAX 8600/8650 REGISTER DESCRIPTION
 CI780 MADR
 CI780 MDATR



<31:13> RESERVED

<12:00> MADR

Contains the address of the control store location to be accessed. It is read or written only in the uninitialized state.



The CI780 MDATR (maintenance data register) does not exist as a physical register. A read or write of MDATR will read or write the microword in the control store location specified by the address in the MADR (maintenance address register). When MADR 12 = 0, MDATR (31:00) contains microword bits (31:00). When MADR 12 = 1, MDATR (15:00) contains microword bits (47:32) (MDATR (31:16) are all 0's). MDATR is read or written only in the uninitialized state.

<47> SYNC

A programmable bit that is used during port debugging to indicate the execution of a specific microword. The SYNC bit is not included in the parity check of the microword. The SYNC bit can be written in both the RAM and PROM areas of the CS (control store). The bit is available on the port backplane.

<46> PARITY

The odd parity bit on bits (45:00) of the CS microword.

<45:43> ALU FUNCTION <2:0>

Function code for the 2901 ALU on the DP (data paths).

<42:40> ALU SOURCE CODE <2:0>

Operand source code for the 2901 ALU on the DP.

<39:37> ALU DESTINATION CODE <2:0>

Destination code for the 2901 ALU on the DP.


<36:33> ALU A/B ADDRESS LINES <3:0>

The A and B address lines for the 2901 scratch pads on the DP.

- <32> **TYPE**
Selects the definition of bits <31:24> as shown below.
- <31:24> **LITERAL <7:0>**
Valid when TYPE = 0. Used in the DP as a number or as an address.
- <31:24> **LINK AND PB (PACKET BUFFER) CONTROL BITS**
Valid when TYPE = 1. The bit fields are defined below.
- <31> **RESERVED**
- <30> **SELECT**
Indicated that the LINK CONTROL lines (<27:24>) are valid.
- <29:28> **PMUX <1:0>**
Selects a byte in the packet buffer input and output registers on the DP.
- <29:24> **LINK CONTROL <3:0>**
Specifies operations on the link and PB. This field is valid when SELECT = 1.
- *<23:21> **IB SOURCE <2:0>**
Selects the source of BUS IB (internal bus) data in the DP.
- *<20:17> **IB DESTINATION <3:0>**
Selects the destination for BUS IB data in the DP.


*These bits bypass the microword register and go directly to the DP.
- <16:12> **SEQUENCE CONTROL <4:0>**
Specifies the operation of the 2911 micro-sequencer, selects the branch conditions that alter the microaddress, and selects the definition of bit <11:00>.
- <11:00> **NEXT MICROADDRESS**
This field is the base address that is modified by the branch bits to form the address of the next microword. It allows the microcode to jump to any address in the CS. This field is valid so long as the Sequence Control field is not all 1's.
- <11:00> **MISCELLANEOUS CONTROL**
This field (MISCELLANEOUS CONTROL) allows the microcode to control miscellaneous flags and functions in the port. The field is valid when the Sequence Control field is all 1's. The Miscellaneous Control bits are described below.
- <11> **MCLR**
This bit (MAINTENANCE CLEAR) causes the port to enter the uninitialized state.
- <10> **INTERRUPT REQUEST**
Sets the INTERRUPT REQUEST flag that initiates an interrupt sequence to the host CPU.
- <09> **INITIALIZE**
Generates an INITIALIZE signal to the link.

VAX 8600/8650 REGISTER DESCRIPTION
CI780 MDATR




- <08> CLEAR REGISTER WRITE
Clears the Register Write flag in the DP.
- <07> POWER FAIL VALID (PFV)
When the POWER-FAIL VALID bit is set, the ASRT DEAD and ASRT FAIL bits are valid.
- <06> ASRT DEAD
Facilitates processor initialization and booting.
- <05> ASRT FAIL
Facilitates processor initialization and booting.
- <04> SET A GO
Starts an external bus transfer with the host using the A parameters.
- <03> SET B GO
Starts an external bus transfer with host using the B parameters.
- <02> UP POWER DOWN
Allows the microcode to set the Power Down bit in the port configuration register.
- <01> INHIBIT RBPE
Set during a DP read of the first byte from a packet buffer. The first byte read is always undefined data. INH RBPE (receive buffer parity error) prevents a parity error from asserting on the undefined data.
- <00> RESERVED

VAX 8600/8650 REGISTER DESCRIPTION
CI780 PMCSR




- <15> **PARITY ERROR**
This bit is set when any of bits <14:08> are set. It is cleared when PMCSR (14:08) bits are all cleared.
- <14> **CONTROL STORE PARITY ERROR**
This bit is set when a parity error is detected in the Control Store in the Packet Buffer (PB). Note: CSPE can only be set when the microcode is running.
- <13> **LOCAL STORE PARITY ERROR**
This bit is set when a parity error is detected while reading the Local Store (LS) or the Virtual Circuit Descriptor Table (VCDT). Note: A Local Store Parity Error can only be set by a microcode read of the LS or the VCDT. It will not set during an unsolicited SBI request.
- <12> **RECEIVE BUFFER PARITY ERROR**
This bit is set when a parity error is detected while reading a packet buffer.
- <11> **TRANSMIT DATA PARITY ERROR**
This bit is set when a parity error is detected in the link transmit channel.
- <10> **INPUT PARITY ERROR**
This bit is set when a parity error is detected on a data transfer from the SBI module to the DP.
- <09> **OUTPUT PARITY ERROR**
This bit is set when a parity error is detected on a data transfer from the output buffer to the transceivers within the SBI module.
- <08> **TRANSMIT BUFFER PARITY ERROR**
This bit is set when a parity error is detected while the PB is unloading a transmit buffer.
- <07> **UNINITIALIZED STATE**
This bit is set when the port is in the uninitialized state. Note: The microcode is not running and the port will not respond to data packet traffic. UNINIT is set by DEAD, MIN (maintenance initialize) or MTE (maintenance error). The microcode is started when UNINIT is cleared by writing a 1 into the Port Initialize Control Register (PICR) or by a boot time-out.
- <06> **PROGRAMMABLE STARTING ADDRESS**
When set, the microcode will start at the address in the MADR (maintenance address register), when a "1" is written into the PICR or a boot time-out occurs. When reset the microcode starts at location 000.
- <05> **RESERVED**

VAX 8600/8650 REGISTER DESCRIPTION
 CI780 PMCSR
 CI780 PORT CONTROL REGISTERS



- <04> **WRONG PARITY**
 This bit is set when the DP (data path) parity generator/checker will generate and check even parity instead of odd. Note: This bit is used to generate parity errors for maintenance purposes.
- <03> **MAINTENANCE INTERRUPT FLAG**
 This bit is set when an interrupt-causing condition has occurred.
- <02> **MAINTENANCE INTERRUPT ENABLE**
 This bit is set by PS DC LO from the SBI module or by writing MIE with a "1". Note: When set, interrupts are enabled.
- <01> **MAINTENANCE TIMER DISABLE**
 This bit is set when the boot and maintenance timers are disabled and cannot cause an interrupt. When reset, the timers are enabled.
- <00> **MAINTENANCE INITIALIZE**
 This bit is set when an initialize signal is generated that clears all port errors and leaves the port in the uninitialized state.



The port control registers are 32-bit write only registers, and are written by the port driver. Each port control register controls one function, and this function is invoked when a "1" is written to the register. The register offset, name and function, and description follows.

XXXXX908 PORT COMMAND QUEUE 0 CONTROL REGISTER (PCQ0CR)
 When the port driver inserts an entry in an empty CMDQ0, the port driver writes PCQ0CR to initiate port execution of the command queue. PCQ0CR can be written only when the port is in the enabled or enabled/maintenance state.

XXXXX90C PORT COMMAND QUEUE 1 CONTROL REGISTER (PCQ1CR)
 Same as PCQ0CR except refers to CMDQ1.


VAX 8600/8650 REGISTER DESCRIPTION
CI780 PORT CONTROL REGISTERS

- XXXXX910 PORT COMMAND QUEUE 2 CONTROL REGISTER (PCQ2CR)
Same as PCQ0CR except refers to CMDQ2.
- XXXXX914 PORT COMMAND QUEUE 3 CONTROL REGISTER (PCQ3CR)
Same as PCQ0CR except refers to CMDQ3.
- XXXXX918 PORT STATUS RELEASE CONTROL REGISTER (PSRCR)
After the port driver has received an interrupt and read the PSR, it returns the PSR to the port by writing PSRCR.
- XXXXX91C PORT ENABLE CONTROL REGISTER (PECR)
The port driver enables the port by writing PECR. PECR is ignored if the port is in the uninitialized, uninitialized/maintenance, enabled, or enabled/maintenance state.
- XXXXX920 PORT DISABLE CONTROL REGISTER (PDCR)
The port driver disables the port by writing PDCR. When the port is disabled, the port requests an interrupt. PDCR is ignored if the port is in the uninitialized, uninitialized/maintenance, disabled, or disabled/maintenance state.
- XXXXX924 PORT INITIALIZE CONTROL REGISTER (PICR)
The port driver initializes the port by writing PICR. When the initialization is complete the port requests an interrupt. As part of the initialization, the maintenance timer is set to expire in 100 seconds.
- XXXXX928 PORT DATAGRAM FREE QUEUE CONTROL REGISTER (PDFQCR)
When the port driver inserts an entry on the DFREQ and the latter was previously empty, the port driver writes PDFQCR to indicate the availability of DFREQ entries. PDFQCR can be written only if the port is in the enabled or enabled/maintenance state.
- XXXXX92C PORT MESSAGE FREE QUEUE CONTROL REGISTER (PMFQCR)
Same as PDFQCR except refers to MFREQ.
- XXXXX930 PORT MAINTENANCE TIMER CONTROL REGISTER (PMTCR)
The port driver forces the maintenance timer to reset its expiration time by writing the PMTCR. If the PMTCR is not written again before the expiration time, the port will enter the uninitialized/maintenance state and request a maintenance timer expiration interrupt (Port status <06>). PMTCR is ignored if the maintenance timer is not running.
- XXXXX934 PORT MAINTENANCE TIMER EXPIRATION CONTROL REGISTER (PMTECR)
The port driver forces a maintenance timer expiration interrupt by writing the PMTECR. This register may be written only when the port is in the enabled, enabled/maintenance, disabled, and disabled/maintenance states and only while the maintenance timer is not disabled.

VAX 8600/8650 REGISTER DESCRIPTION

CI780 PORT ERROR STATUS

(CI780) PORT ERROR STATUS
XXXXX93C



The Port Error Status Register (PESR) indicates the type of error which resulted in a DSE interrupt. The PESR is read only by the port driver and valid after a DSE interrupt. The codes and a brief description follow.

CODE DESCRIPTION


1. Illegal system virtual address format. Bits <31:30> of the virtual address are not equal 10. The Port Failing Address Register (PFAR) contains a virtual address.
2. Non-existent system virtual address. VA <29:09> >= SPT_LEN. PFAR contains a virtual address.
3. Invalid system PTE. Bits <31,26,22> not equal lxx, 000, or 001. PFAR contains the virtual address being mapped.
4. Invalid buffer PTE. Bits <31,26,22> not equal lxx, 000, or 001. PFAR contains the PTE virtual address.
5. Non-existent system global virtual address. GPTX >= GPT_LEN. PFAR contains the virtual address.
6. Non-existent buffer global virtual address. GPTX >= GPT_LEN. PFAR contains the PTE virtual address.
7. Invalid system global PTE. PTE <31,26,22> not equal lxx or 000. PFAR contains the virtual address.
8. Invalid buffer global PTE. PTE <31,26,22> not equal lxx or 000. PFAR contains the PTE virtual address.
9. Invalid system global PTE mapping. The system virtual address of system global PTE is itself globally mapped. PFAR contains the virtual address.
10. Invalid buffer global PTE mapping. The system virtual address of buffer global PTE is itself globally mapped. PFAR contains PTE virtual address.
11. Queue interlock retry failure. Interlock was tested and found locked an implementation specific consecutive number of times. PFAR contains the queue head virtual address.

VAX 8600/8650 REGISTER DESCRIPTION
 CI780 PORT ERROR STATUS
 CI780 PORT FAILING ADDRESS (PFAR)

CODE DESCRIPTION

12. Illegal queue offset alignment. FLINK <2:1> or BLINK <2:1> is not 0. PFAR contains the queue head virtual address.
13. Illegal PQB format. A field of the PQB specified to be zero was found to be other than zero. (The check for zero fields is optional so not all ports will return this error.) PFAR contains the field offset in the PQB in bytes.
14. Register protocol violation. Register was written with the wrong value or under the wrong conditions. (The check for protocol violations is optional so not all ports will return this error.) PFAR contains the register byte offset from device base address.

(CI780) PORT FAILING ADDRESS
 XXXXX938




After a MSE or DSE interrupt and after a response with buffer memory system error status, the Port Failing Address Register (PFAR) contains the memory address at which the failure occurred. The address may be the exact failing address, an address in the same page as the failing address, or, in the case of DSE interrupts, an address in some part of the data structure. For DSE interrupts PFAR contains a virtual address or offset, while for MSE interrupts and buffer memory system errors the PFAR contains a physical address.

Since the port continues command execution and packet processing after buffer memory system errors, the PFAR is overwritten if subsequent errors occur. For DSE and MSE interrupts the PFAR is effectively fixed since the port enters the disabled or disabled/maintenance state.

PFASR is read only by the port driver and readable after a DSE or MSE interrupt or after a response with buffer memory system error status.

VAX 8600/8650 REGISTER DESCRIPTION
 CI780 PORT PARAMETER REGISTER (PPR)
 CI780 PORT QUEUE BLOCK BASE (PQBBR)

(CI780) PORT PARAMETER
 XXXXX940




The Port Parameter Register (PPR) contains port implementation parameters and the port number. The value of the PPR is set by the port during initialization and valid after a PIC interrupt. PPR is read only by the port driver.

<31> **CLUSTER SIZE**
 Cluster size = 0 indicates a maximum of 16 ports on the CI. Cluster size = 1 indicates a maximum of 224 ports on the CI.

<28:16> **INTERNAL BUFFER LENGTH**
 The internal buffer length indicates the size of internal buffers available for message and data transfers. The maximum data packet is IBUF_LEN - 16 bytes. Maximum message or datagram length = IBUF_LEN. The minimum value is 592.

<07:00> **PORT NUMBER**

(CI780) PORT QUEUE BLOCK BASE
 XXXXX954




This register contains the physical address of the base of the Port Queue Block. The PQBB register is read/write by the port driver and writable only when the port is in the disabled or disabled/maintenance state.

<31:30> MBZ

<29:09> Port Queue Block Base address

<08:00> MBZ

(C1780) PORT STATUS
XXXXX900



<31> MAINTENANCE ERROR
This bit, if set, indicates that the port has detected an implementation specific error (or hardware status condition). The source of the error may be more accurately determined from the implementation specific maintenance registers.

<06> **MAINTENANCE TIMER EXPIRATION**
When this bit is set, it indicates that the maintenance timer has expired. The port is in the uninitialized/maintenance state.

```
<05>    MEMORY SYSTEM ERROR
When Memory System Error is set, the port has encountered
an uncorrectable data or non-existent memory error while
referencing memory. The port is in the disabled or
disabled/maintenance state. See the Port Failing Address
Register for further information.
```

```

<04> DATA STRUCTURE ERROR
When this bit is set, the port has encountered an error in
a port data structure (i.e., queue entry, PQB, BDT or page
table). The port is in the disabled or
disabled/maintenance state. See Port Error Status
Register and the Port Failing Address Register for further
information. The errors in the queue structure leave the
queues locked.

```


<03> PORT INITIALIZATION COMPLETE
When Port Initialization Complete is set, the port has completed internal initialization. The port is in the disabled or disabled/maintenance state.

<02> PORT DISABLE COMPLETE
When Port Disable Complete is set, the port is in the disabled or disabled/maintenance state.

<01> MESSAGE FREE QUEUE EMPTY
When set, Message Free Queue Empty indicates that the port attempted to remove an entry from the message free queue and found it empty. Port processing of commands continues so the message free queue may not be empty at the time the port driver gets control.

<00> RESPONSE QUEUE AVAILABLE
When set, Response Queue Available indicates that the
port has inserted an entry on an empty response queue.

VAX 8600/8650 REGISTER DESCRIPTION
CMISC
CPC



This register is implemented by two flip-flops outside of the CBUS RAM. It contains two bits: TOY Update Pending (UPND) and T-11 Restart (TSTR).

<07> TOY UPDATE PENDING

CS15 TSEL H


This bit is set by the console software while it is updating the BTOY register from the TOY register. This operation is performed every 10 ms by the console software.

<06> T-11 RESTART

CL15 TSTR H

Setting this bit forces a console (T-11) interrupt to vector 24 which reboots the console from PROM. This bit may be set by the MACRO program running in the CPU. Under VMS, this is done by writing the Console Reboot (CRBT) IPR. The console program may also select this bit indirectly by writing MCSR3 <07:05> with a function code of 7 which will also force a T-11 reboot via PROM.


<05:00> RESERVED



<31:00> CURRENT PROGRAM COUNTER

This register contains the address (Macro PC) of the instruction that the IBox Address Calculation Unit will process next.

VAX 8600/8650 REGISTER DESCRIPTION
CRBT




This write only register is used by software to reboot the console processor without having to reboot the whole system. To determine when to reboot the console, macrocode examines the TOY every 90 sec. to see if the content has been updated by the console software. If TOY hasn't changed, the console needs to be rebooted. The Reboot Code/Address is supplied by microcode not VMS.

<15:08> REBOOT CODE
80 hex

<07:00> REBOOT ADDRESS
CBus to console address (33 hex) used to force the reboot to occur.

VAX 8600/8650 REGISTER DESCRIPTION CS




The contents of this register are generated by the console during Control Store and Dispatch RAM ECC correction. The console sends this register to the CPU as part of the ECC correction process.

- <31> **CORRECTION FAILURE**
Indicates that the console was unable to correct the Control Store or Dispatch RAM identified in the CS/DRAM ID field <02:00>.
- <30:29> **RESERVED**
- <28:16> **CONTROL STORE ADDRESS**
Address the console used when correcting the Control Store or DRAM Parity Error.
- <15:08> **CONTROL STORE SYNDROME**
This is the syndrome the console used to correct the bit in error.
- <07:03> **RESERVED**
- <02:00> **CONTROL STORE/DRAM IDENTIFICATION CODE**
This is the code passed to the console from the EBox to determine what Control Store to apply correction to.

CODE	MEANING
----	-----
0	No Error
1	EBox Control Store Parity Error
2	IBox Control Store Parity Error
3	IBox DRAM Parity Error
4	FBox DRAM Parity Error
5	FBox Adder Module Control Store Parity Error
6	FBox Multiplier Module Control Store Parity Error
7	MBox Control Store Errors (Data, Address, or Micro-stack)

CSHCTL
(ESCRATCH LOC 29 - T19)

CACHE CONTROL



This register is made up of MBOX Register 04 (byte 0).

<31:08> RESERVED

<07:00> SOURCE: MAPP (REG) - MBOX REG 04 (ADDR CONTROL 1)

<07:04> RESERVED

<03> FORCE CACHE MISS

REG4 FORCE CACHE MISS (MAPP)

When set, forces a cache miss (overrides CACHE 1 ENABLE and CACHE 0 ENABLE). This bit is used for forcing a cache refill during diagnostics.

<02> FORCE CACHE HIT

REG4 FORCE CYC (MAPP)

This bit works in conjunction with CACHE 1 ENABLE and CACHE 0 ENABLE as shown in the following table:

Force Hit	C1 En	C0 En	Function
0	0	0	Cache Miss
0	0	1	Cache 0 determines Hit or Miss
0	1	0	Cache 1 determines Hit or Miss
0	1	1	Both Caches determine Hit or Miss
1	0	0	Cache Miss
1	0	1	Force Hit in Cache 0
1	1	0	Force Hit in Cache 1
1	1	1	Illegal, gives tag parity error with Written Bit = 1

The three bits <02:00> reflect the following:

- Code 000 - Cache 0 and 1 Disabled
- Code 001 - Cache 1 Disabled
- Code 010 - Cache 0 Disabled
- Code 011 - Normal Running Code.
- Code 100 - Cache 0 and 1 Disabled
- Code 101 - Used to force a sweep of Cache 0 if Written Bit is set. Also used for diagnostic purposes to force a hit in a given cache.
- Code 110 - Used to force a sweep of Cache 1 if Written Bit is set. Also used for diagnostic purposes to force a hit in a given cache.
- Code 111 - This is an illegal code that covers the case of a hit in both caches. A tag parity error with W=1 is also forced if, during normal operation, both caches give indications of a hit. This is considered an MBOX FATAL ERROR.

<01> ENABLE CACHE 1

REG4 CACH 1 ON (MAPP)


When set, enables Cache 1 (allows Cache 1 to be read and written).

<00> ENABLE CACHE 0

REG4 CACH 0 ON (MAPP)

When set enables Cache 0 (allows Cache 0 to be read and written).

VAX 8600/8650 REGISTER DESCRIPTION CSLINT



CSLINT (Console and Interrupt Register)

This is a two part register. Bits <31:16> reflect the System Interrupt Status and bits <15:00> reflect the CBus Status.

<31:30> RESERVED

<29:23> CPU INTERRUPT

Setting a bit in this field will result in a CPU interrupt.

<29> CONSOLE HALT PENDING

EBC3 CSL HP

Posted by the console. Indicates that the console wants to interrupt the EBox and force it to execute a Console Halt. The Ebox micro code will be forced to the CSM wait loop.

<28> CPU POWER FAIL

EBC2 CPU PF INTR LVL3

Posted by the console. Indicates that the EMM has notified the console about an impending power failure. VMS has approximately 300 ms to shut down in an orderly manner.

<27> MBOX ERROR

EBC2 MBOX INTR LVL3

Posted by the MBox. Indicates that the MBox detected an error of any type (excluding TB parity errors). The interrupt is handled by the EBox at IRD time. (Same as EBCS <14>).

<26> INTERVAL TIMER

EBE9 TIME INTR LVL3

Posted by the EBox. Indicates that the Interval Count Register has overflowed.

<25> CONSOLE RL02

EBC2 RL INTR LVL3

Posted by the console. Indicates that the console wants to interrupt the EBox to transfer a byte to or from the RL02.


During an RL02 read (SNAP files, etc.), the T11 assembles 512 bytes and then transfers them to the EBox a byte at a time via this interrupt mechanism.

During an RL02 write, the T11 interrupts the EBox for byte of data until it has assembled 512 bytes. It then transfers the data to the RL02.

- <24> CONSOLE RECEIVE
EBC2 TRX INTR LVL3
Posted by the console. Indicates that the console has acknowledged the last CPU transmission.
- <23> CONSOLE TRANSMIT
EBC2 TTX INTR LVL3
Posted by the console. Indicates that the console wants to transfer a byte of information to the CPU via the CBus.
- <22:21> IOA WITH HIGHEST INTERRUPT REQUEST
EBC1 EXT INTR SRC 1:0
This field indicates the I/O Adapter (SBIA) that has the highest IPR.
- <20> INTERRUPT SOURCE (0=EXT/1=INT)
EBC3 INT INTR
Set by hardware. When set, indicates that the source of the pending interrupt is internal. When clear, indicates that the source of the pending interrupt is external.
- <19:16> EBOX IPR STATUS <03:00>
EBC3 ACTIVE IPR 3:0
This field represents the least significant four bits of the highest active hardware (internal or external) interrupt request during the previous machine cycle. When this field is zero, there was no hardware interrupt.
- <15:08> CBUS DATA <D7:D0>
EBE2 CBUS IN REG D7:D0
Although this register is used primarily to receive data from the console, all data transfers between the console to the CPU are latched in this register.
- <07> CBUS CLOCK
EBE2 CBUS CLOCK
This bit represents the state of the CBus Clock Line. The CBus Clock must be asserted by writing a one to this bit and negated (in a subsequent microinstruction) by writing a zero to this bit in order to complete a CBus read or write operation.
- <06> CBUS R/W (0=RD CSL/1=WR CSL)
EBE2 CBUS WRITE
This bit determines whether a CPU read or write operation is to be performed over the CBus. The EBox is enabled to drive the CBus data lines when this bit is set. The console is enabled to drive the CBus data lines when this bit is reset.
- <05:00> CBUS ADDRESS <A5:A0>
EBE2 CBUS A5:A0
The address of the console location to be read or written is loaded into this register.

VAX 8600/8650 REGISTER DESCRIPTION

CSM.STATUS



CSM.STATUS (CSM Status Register)

This is the status word used to control the Console Support Microcode (CSM). It is located in ESC C0.

<31:16> DOUBLE ERROR STATUS

This field is normally equal to zero. If this field is non-zero then it indicates that a non-Box double error condition has occurred.

<15:08> EXECUTION STATUS

If this field is equal to zero it indicates that CSM is executing in the EBox. If this field is not equal to zero (i.e., non-zero) then it indicates that the VAX ISP microcode is executing in the EBox.


<07:00> ENTRY CODE

This field contains a code that indicates reason why CSM was started.

Code Reason

- 00 CSM is not executing.
- 04 Interrupt Stack not Valid (Software Error).
- 05 A non-EBox double error was detected.
- 06 Halt Instruction was decoded in Kernel Mode.
- 07 SCB Vector Code <1:0> = 3 (Software Error).
- 08 SCB Vector Code <1:0> = 2 (no WCS Microcode).
- 09 Pending Error on Halt.
- 0A CHMx Instruction decoded and Interrupt Stack = 1.
- 0B CHMx Instruction decoded and Vector <1:0> ≠ 0.
- 10 Micro-break was encountered which caused the console to start CSM at CSM.ENTRY.MICRO:.
- 11 Console Halt Pending was set which caused CSM to start running on AFork at A.CSM.ENTRY.MICRO:.
- 15 The CPU was powered up and the Console started CSM at CSM.ENTRY.PO:.
- 16 During the power up sequence this code is used by the FIND 64KB and FIND RPB procedures to interface with CSM.ERROR: routine. The Console should never see this code. If it does then there something very wrong in the CPU.

VAX 8600/8650 REGISTER DESCRIPTION
CSWP



<31:04> RESERVED

<03:00> CACHE CONTROL

<03> INVALIDATE

When set, clears written and valid bits and does not update memory. Both caches are always invalidated, regardless of whether they were previously enabled. The cache access mode is then set to select one or both cache halves as expressed by C0 ENA and C1 ENA.

State of Cache after operation:

CACHE 1 ENABLE	CACHE 0 ENABLE	
0	0	Both Caches are off
0	1	Cache 0 is active Cache 1 is off
1	0	Cache 1 is active Cache 0 is off
1	1	Cache 0 and 1 are active

<02> VALIDATE MEMORY

When set, copies cache written locations to memory, according to the previous enable bits. The cache access mode is then set to select cache halves as expressed by C0 ENA and C1 ENA in the table above.


If neither INV or VAL are set, the only effect of an MTPR CSWP will be to enable the cache according to bits <01:00>.

<01> CACHE 1 ENABLE

<00> CACHE 0 ENABLE

VAX 8600/8650 REGISTER DESCRIPTION

DFI



<31> **ARMED**
When set, fault insertion is armed and controlled by the hardware associated with this register.

<30:28> **EVENT SELECT CODE <02:00>**
These bits form the count modes for the EVEN COUNTER increment enable. When enabled, the counter increments at CLK T3C.

The following Count Modes exist:

SEL 1:0	ACTION
-----	-----
0	NEVER COUNT
1	ALWAYS COUNT
2	-ESTALL
3	-ISTALL
4	EBOX UMARK + IBOX UMARK
5	EBOX UMARK * -ESTALL + IBOX UMARK * -ISTALL
6	IRD * -STALL

<27> **OVERRIDE MICRO CODE MARK**
When set, overrides microcode mark as one of the conditions needed to insert the fault. In other words, fault insertion occurs when the EVENT COUNTER overflows.

<26:16> **RESERVED**

<15> **TP LOAD PTE**
When set, causes PTE in R1 to be loaded into TB location corresponding to virtual address in R0. All other bits are ignored. This bit does not exist in hardware. It is recognized by MTPR DFI microcode (branch condition), and may be used by macrocode to generate TB parity errors.

<14:11> **RESERVED**

<10:00> **EVENT COUNTER**
The event counter is capable of counting 1 to 2047 cycles, EBox and IBox microcode mark bits with and without stalls, unstalled IRD cycles, unstalled IBox or EBox cycles, or an external event until EVENT COUNTER OVERFLOW occurs.

VAX 8600/8650 REGISTER DESCRIPTION DR780 CONTROL REGISTER (READ)

DCR (READ)
OFFSET 000


DR780 CONTROL REGISTER (READ)

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
PE FAULT	WRITE SEQUENCE FAULT	UNEXPCD READ DATA	SBI FAULTS	MULTIPLE XMITTER	XMITTER DURING FAULT	EXTERNAL ABORT	ADAPTOR POWER DOWN	ADAPTOR POWER UP	INTERUPT ENABLE	PACKET INTERUPT	ABORT	HALT	CORRECTD READ DATA		
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
READ DATA SUB STITUTE	COMMAND ADDRESS TIME OUT ID1	READATA EXPECTED TIME OUT ID1	RECEIVED ERROR CONFIRM ID1	DATA INTER- CONNECT STALL	COMMAND ADDRESS TIME OUT ID2	READATA EXPECTED TIME OUT ID2	RECEIVED ERROR CONFIRM ID2	ADAPTOR CODE							
								0	0	1	1	0	0	0	0

DR780-122-14

- <31> PARITY FAULT
- <30> WRITE SEQUENCE FAULT
- <29> UNEXPECTED READ DATA
- <28> RESERVED
- <27> MULTIPLE TRANSMITTER FAULT
- <26> TRANSMITTER DURING FAULT
- <25> RESERVED
- <24> EXTERNAL ABORT
- <23> POWER DOWN
- <22> POWER UP
- <21> RESERVED
- <20> INTERRUPT ENABLE
- <19> PACKET INTERRUPT
- <18> ABORT
- <17> HALT
- <16> CORRECTED READ DATA
- <15> READ DATA SUBSTITUTE
- <14> COMMAND/ADDRESS TIME OUT ID1
- <13> READ DATA EXPECTED TIME OUT ID1
- <12> RECEIVED ERROR CONFIRMATION ID1
- <11> DATA INTERCONNECT STALL
- <10> COMMAND/ADDRESS TIME OUT ID2
- <09> READ DATA EXPECTED TIME OUT ID2
- <08> RECEIVED ERROR CONFIRMATION ID2
- <07:00> ADAPTER TYPE CODE
 Adapter type code = 30(16)

VAX 8600/8650 REGISTER DESCRIPTION
DR780 CONTROL REGISTER (WRITE)



<31:15> RESERVED

<14:12> CONTROL FIELD B

14 13 12

0	0	0	No operation
0	0	1	Clear corrected read data (DCR read <16>)
0	1	0	Set external abort (DCR read <24>)
0	1	1	Clear packet interrupt (DCR read <19>)
1	0	0	Reset
1	0	1	Set out of sequence test
1	1	0	Clear out of sequence test
1	1	1	No operation

<11> RESERVED

<10:08> CONTROL FIELD A

10 09 08


0	0	0	No operation
0	0	1	Clear power up (DCR read <22>)
0	1	0	Clear power down (DCR read <23>)
0	1	1	No operation
1	0	0	Clear abort interrupt and read data substitute (DCR read <18, 16>)
1	0	1	Clear interrupt enable
1	1	0	Set interrupt enable
1	1	1	Clear halt

<07:00> RESERVED

VAX 8600/8650 REGISTER DESCRIPTION DR780 ADDRESS REGISTER (DCRAR)

DCRAR
OFFSET 014

DR780 SBI ADDRESS REGISTER



000 14110

<31:30> RESERVED

<29:17> DR780 ADDRESS SPACE

These bits are used as the ADDRESS SPACE available to the DR780. The addresses for the DR780 fall into the adapter address space as do all hardware addresses. Bit 29 is set to a 1 and <28:26> and <24:17> are all 0's. Bit 25 is 0 for SBIA 0 and 1 for SBIA 1.

<16:13> TRANSFER REQUEST IDENTIFIER

The number for the transfer request bits is set when the DR780 is installed. The number used in this field can be any numbers from 1 through 15.

<12:11> MBZ

Must be zero.

<10:09> PAGE SELECT

These bits inform the DSC which page in the DR780 is to be accessed. This register contains a table of page selection bits.

<08:00> REGISTER ADDRESS

VAX 8600/8650 REGISTER DESCRIPTION
DR780 UTL

UTL
OFFSET 004

DR780 UTILITY REGISTER


31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
GENERAL PE	DI PE	PARITY ERRORS CONTROL ICT PE	WCS PE	ENABLE DI PE ABORT	FORCE DI PE	FORCE CI PE									
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
				WRITABLE CONTROL STORE VALID				DATA RATE							

- <31> **GENERAL PARITY ERROR**
Indicates that a parity error was detected either on the CI, the DI, or the WCS. This bit is generated on the SBI Interface Module.
- <30> **DEVICE INTERCONNECT PARITY ERROR**
Indicates that the DSM detected a parity error on the DI. This bit is generated on the Silo Module.
- <29> **CONTROL INTERCONNECT PARITY ERROR**
Indicates that the Microprocessor Module detected a parity error on the CI. This bit is generated on the DUP.
- <28> **WRITABLE CONTROL STORE PARITY ERROR**
Indicates that the DUP detected a Writable Control Store RAM Parity Error. This bit is generated on the Microprocessor Module.
- <27> **ENABLE DEVICE INTERCONNECT PARITY ERROR ABORT**
When this bit is set and a DI parity error is detected it will cause the DR780 to abort the data transfer and notify the processor.
- <26> **FORCE DEVICE INTERCONNECT PARITY ERROR**
This is a diagnostic feature used to test the DI parity circuits on the DSM. When set this bit will force a parity error on the DI.
- <25> **FORCE COMPUTER INTERCONNECT PARITY ERROR**
This is a diagnostic feature used to test the CI parity circuits on the DUP. When set this bit will force a parity error on the CI.
- <24:12> **RESERVED**
- <11> **WRITABLE CONTROL STORE VALID**
When set this bit allows the DR780 microprocessor to operate. When cleared the DR780 aborts the data transfer in progress.
- <10:08> **RESERVED**
- <07:00> **DATA RATE**
Specifies the 2's complement of the DI data transfer rate in megabytes/second. The data transfer rate (in MB/sec.) is calculated using the following formula: $DR = 40/256$. Where 256 is the value of the data rate in bytes.

NOTE

The maximum data rate is five (eight MB/sec). Any rate less than five prevents this field from being loaded and the field will retain its previous value.

VAX 8600/8650 REGISTER DESCRIPTION DW780 BRRVR 4 - 7



BR RECEIVE VECTOR REGISTERS 4-7

Note: The UBA contains four BRRVR's: BRRVR 7, BRRVR 6, BRRVR 5, BRRVR 4. Each BRRVR corresponds to a Unibus interrupt bus request level: 7, 6, 5, or 4. Each BRRVR is a read only register and will contain the interrupt vector of the Unibus device interrupting at the corresponding BR level. Each BRRVR is read by the software as a part of the UBA interrupt service routine. Note that the UBA interrupt service routine is the routine to which the VAX 8600/8650 CPU will transfer control once it has determined that the UBA or the Unibus has issued an interrupt request to the SBI.

<31> ADAPTOR INTERRUPT REQUEST INDICATOR
0 = No UBA interrupt pending
1 = UBA interrupt pending


<30:16> RESERVED

<15:00> DEVICE INTERRUPT VECTOR FIELD
These bits contain the device interrupt vector loaded by the UBA during the Unibus interrupt transaction.

VAX 8600/8650 REGISTER DESCRIPTION
DW780 BRSVR 0-3

BRSVR 0-3
OFFSET: 020-02C

DW780 BUFFER SELECTION VERIFICATION REGISTERS 0-3
UMDT, U




MR-14303

<15:00> FAILED UNIBUS ADDRESS BITS <17:02>

BUFFER SELECTION VERIFICATION REGISTERS 0-3

Note: These four read/write do-nothing registers are provided to give the diagnostic software a means of accessing and testing the integrity of the data path RAM. Four locations in the data path RAM have been assigned to these registers. Writing and reading the BRSVR's has no effect on the behavior of the UBA.

VAX 8600/8650 REGISTER DESCRIPTION DW780 CNFGR



<31:27> SBI FAULTS

These bits are set when the UBA detects specific fault conditions on the SBI. Note: These bits cannot be set once FAULT has been asserted. The negation of FAULT and the clearing of the fault conditions clear the bits. The setting of any bits <31:27> will cause the UBA to assert the FAULT signal for one cycle on the SBI during the confirmation time for the associated transfer.

<31> PARITY FAULT

This bit is set when the UBA detects an SBI parity error.

<30> WRITE SEQUENCE FAULT

This bit is set when the UBA receives a write masked or interlock write masked command and does not receive the expected write data in the following cycle.

<29> UNEXPECTED READ DATA FAULT

This bit is set when the UBA receives read data when a read command was not issued.

<28> INTERLOCK SEQUENCE FAULT

This bit is set when an interlock write masked command to the Unibus address space is received by the UBA without a previous interlock read mask command.

<27> MULTIPLE TRANSMITTER FAULT

This bit is set when the UBA is transmitting on the SBI and the ID bits received do not match the ID transmitted.

<26> TRANSMIT FAULT

This bit is set if the UBA was transmitting during a detected fault condition. Note: When the software subsequently reads the configuration and status registers of each of the nexus on the SBI in order to identify the source of the fault, the UBA will be identified as that source if bit 26 is set.

<25:24> RESERVED

<23> ADAPTOR POWER DOWN

Set when the UBA power supply asserts AC LO. Cleared by writing a 1 to this bit or when Adaptor Power Up is set.

<22> ADAPTOR POWER UP


Set by negation of AC LO. Cleared by writing a 1 to this bit or when Adaptor Power Down is set.

<21:19> RESERVED

VAX 8600/8650 REGISTER DESCRIPTION
DW780 CNFGR

CNFGR
OFFSET: 000

DW780 CONFIGURATION REGISTER
USJF



SEP 14/87

- <18> **UNIBUS INITIALIZATION ASSERTED (UBINIT)**
This bit is set by the assertion of Unibus Init. It is cleared by setting the Unibus Initialization Complete Bit (UBIC) or by writing a 1 to this bit.
- <17> **UNIBUS POWER DOWN (UBPDN)**
Set when Unibus AC LO is asserted. Note: This indicates that the Unibus has initiated a power down sequence. The setting of the UBIC bit or writing a 1 to this bit will clear UBPDN.
- <16> **UNIBUS INITIALIZATION COMPLETE (UBIC)**
This bit is set by a successful completion of a power up sequence on the Unibus. Note: It is the last of the status bits that can be set during a UBA initialization sequence, and it can be interpreted to mean that the UBA and the Unibus are ready. The assertion of Unibus AC LO or Unibus Init, or the writing of a 1 to this bit location clears UBIC.
- <07:00> **ADAPTOR CODE**
These bits define the code assigned to the UBA.

ADAPTOR CODE BIT ASSIGNMENT

Bit Number	7	6	5	4	3	2	1	0	
Value	0	0	1	0	1	0	Vb	Va	
UBA Number							Vb	Va	
0							0	0	
1							0	1	
2							1	0	
3							1	1	

VAX 8600/8650 REGISTER DESCRIPTION
DW780 DCR


DW780 DIAGNOSTIC CONTROL REGISTER

- 20-37

VAX 8600/8650 REGISTER DESCRIPTION
DW780 DPR

BDP 0-15
OFFSET 040-07C

DW780 DATA PATH REGISTERS 0-15
UMDT



MM-1-6800

<31>

BUFFER NOT EMPTY

Note: Each DPR contains a data path status bit called buffer not empty.

- 1 = Buffer not empty
- 0 = Buffer empty

The BNE bit reflects the state of the associated BDP. If this bit is set (1), the BDP contains valid data. If clear, then the BDP does not contain valid data. The UBA uses the bit to determine the proper action for DMA transfers via the BDP. If bit 31 is set as a DATI transfer begins, the data in the BDP will be asserted on the Unibus. If bit 31 is clear on a DATI, the UBA will initiate a read transfer to SBI memory, gate the addressed data to the Unibus, and then load the read data into the BDP, thereby setting bit 31.

For a DMA write transfer via the associated BDP, the BNE bit is set each time Unibus data is loaded into the BDP. The bit is then cleared when the contents of the BDP are transferred to SBI memory.

The software will write a 1 to the BNE bit to initiate a purge operation at the completion of a DMA transfer using the corresponding buffered data path. The UBA executes purge operations as follows:

1. WRITE TRANSFERS TO MEMORY

This bit is set if any bytes of data remain in the corresponding BDP. The bit is cleared if no data remains to be transferred. Note: The UBA will transfer this data to the SBI location addressed. The UBA will then initialize the BDP and clear the BNE bit. The purge operation will be treated as a no-op (it is a legal do-nothing function).

2. READ TRANSFERS TO MEMORY


Note: If any bytes of data remain in the BDP, the UBA will initialize the BDP by clearing the BNE bit.

In addition, the following considerations apply to the purge operation:

- For purge operations in which data is transferred to memory, the SBI transfer takes about 2 us. The UBA will not respond to data path register read transfers during this period (busy confirmation), thereby preventing a race condition when testing for BNE bit.
- A purge operation to data path register 0 (direct data path) is treated by the UBA as a no-op.

- <30> BUFFER TRANSFER ERROR**
Note: This is a read-write-one-to-clear bit. The UBA sets the BTE bit if a failure occurs during a BDP to SBI write or a purge, or for a buffer parity failure during a Unibus to BDP read access. If bit 30 is set, any additional DMA transfers via the BDP will be aborted until the bit is cleared by the software. Note that if a parity error on the Unibus occurs during a DMA read, the Unibus signal PB will be asserted, giving the Unibus device the opportunity to abort its own DMA transfer. If the device does not abort its own transfer, the UBA will abort the transfer on the next access. The purge operation does not clear the BTE bit. The software clears this bit by writing a 1 to the bit location.
- <29> DATA PATH FUNCTION**
Note: The DPF is a read only bit. This bit indicates the function of the DMA transfer using this data path.
- 0 = DMA read
1 = DMA write
- <23:16> BUFFER STATE**
Note: These eight read only bits indicate the state of each of the eight byte buffers of the associated BDP during a DMA write transfer. They are included in the data path register for diagnostic purposes only. The UBA generates the SBI mask bits from the BS bits during a BDP to SBI write transfer or purge operation. The bits are set as each byte is written from the Unibus. The bits are cleared during the SBI write operation.
- 0 = Empty
1 = Full
- <15:00> BUFFERED UNIBUS ADDRESS**
Note: This portion of each DPR contains the upper 16 bits of the Unibus address, UA <17:02>, asserted during a Unibus to BDP write transfer using the associated BDP. If the transfer through the associated BDP is in the byte offset mode, and the last Unibus transfer has spilled over into the next quadword, then these bits contain UA <17:02> + 1. Equation:
- $$\text{BUBA } \langle 15:00 \rangle = \text{Upper 16 bits of UA } \langle 17:00 \rangle + \text{Byte Offset}$$
- Note: This is the Unibus address from which the SBI address will be mapped during a purge operation.

VAX 8600/8650 REGISTER DESCRIPTION
 DW780 FMER
 DW780 FAILED UNIBUS ADDRESS REGISTER




<31:09> RESERVED

<08:00> MAP REGISTER NUMBER

These bits contain the binary value of the number of the map register that was in use at the time of a failure. Bits <08:00> correspond to bits <17:08> of the Unibus address.

Note: The Failed Map Entry Register contains the map register number used for either a DMA transfer or a purge operation that has resulted in the setting of one of the following status register error bits: IVMR, MRPF, DPPE, CXTMO, CXTER, RDS, RDTO. This register is locked and unlocked with the Unibus to SBI data transfer error field of the status register. The FMER is a read only register. Attempts to write the FMER will result in an SBI error confirmation. When the FMER is not locked, its contents are invalid.



<31:16> RESERVED

<15:00> FAILED UNIBUS ADDRESS BITS <17:02>

Note: The FAILED UNIBUS ADDRESS REGISTER contains the upper 16 bits of the unibus address translated from an SBI address during a previous software initiated data transfer. The occurrence of either of two errors indicated in the status register will lock the FAILED UNIBUS ADDRESS REGISTER: Unibus Select Time Out (UBSTO) and Unibus Slave Sync Time Out (UBSSYNTO). When the error is cleared, the register will be unlocked.

The FAILED UNIBUS ADDRESS REGISTER is a read only register. Attempting to write to the register will result in an error confirmation. No signals or conditions will clear the register. The contents of the FAILED UNIBUS ADDRESS REGISTER are listed below.

VAX 8600/8650 REGISTER DESCRIPTION DW780 MAP REGISTER

MR 0-495
OFFSET: 800-FBC

DW780 MAP REGISTERS 0-495
UMDT: U

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
MAP REGISTER RESERVED BITS (S/R 0)						BYTE OFFSET	DATA PATH DESIGNATOR				SBI PAGE ADDRESS (PFN)				
MAP REGISTER VALID	4	3	2	1	LWAE						27	26	25	24	23
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
SBI PAGE ADDRESS (PFN)															
22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7

MR 1480

<31> **MAP REGISTER VALID (MRV)**
The MRV bit is set by software to indicate that the contents of this map register is valid. The MRV is tested each time a map register is accessed. If the bit is set, the transfer continues. If the bit is not set, the Unibus transfer is aborted (NXM) and the invalid map register bit (IVMR) is set in the UBA status register, provided that the map register has not been disabled by the map register disable (MRD) bits of the control register.

<30:27> **RESERVED**

<26> **LONGWORD ACCESS ENABLE (LWAE)**
If set, and the map register selects a buffered data path (BDP), then the longword aligned 32-bit random access mode is enable for the BDP. This bit has no effect if the direct data path is selected by the map register. This bit is cleared on initialization.

<25> **BYTE OFFSET BIT**
This read/write bit is set if "this Unibus page" is using one of the BDP's, and the transfer is to an SBI memory address. This bit is cleared by initialization. Note: Then the UBA will perform a byte offset operation on the current Unibus data transfer. The software can interpret this operation as increasing the physical SBI memory address, mapped from the Unibus address, by one byte. This allows word-aligned Unibus devices to transfer to odd byte memory addresses.

Unibus transfers via the DDP or to SBI I/O addresses will ignore the byte offset bit.

<24:21> **DATA PATH DESIGNATOR BITS**

Note: 0000 = Direct Data Path (DDP)
0001 = Buffered Data Path 1
1111 = Buffered Data Path 15

The data path designator bits are read/write bits that are set and cleared by the software to designate the data path that "this Unibus page" will be using.


The software can assign more than one Unibus transfer to the DDP. The software must ensure that not more than one active Unibus transfer is assigned to any BDP.

<20:00> **SBI PAGE ADDRESS**
The "Unibus page" will be mapped. These bits perform the Unibus to SBI page address translation. When an SBI transfer is initiated the contents of SPA <27:07> are concatenated with Unibus address bits UA <08:02> to form the 28 bit SBI address.

VAX 8600/8650 REGISTER DESCRIPTION DW780 UACR

NACB
OFFSET: 004

DW780 CONTROL REGISTER
UAIL, M



<31> RESERVED

<30:26> MAP REGISTER DISABLE (MRD)

This read/write field disables Map Registers in groups of sixteen according to the binary value contained in the field. The MRD bits prevent the UBA from responding to a Unibus address that points to a disabled Map Register. The software will load this field with a binary value equal to the number of 4K word units of memory attached to the Unibus as follows:

MAP REGISTER DISABLE BITS

MRD <4:0>	AMOUNT OF UNIBUS MEMORY (WORDS)	MAP REGISTERS DISABLED
00000	0K	NONE
00001	4K	0 - 15 (10)
00010	8K	0 - 31 (10)
00011	12K	0 - 47 (10)
.	.	.
.	.	.
11110	120K	0 - 480 (10)
11111	124K	0 - 495 (10) (ALL)

<25:07> RESERVED

<06> INTERRUPT FIELD SWITCH (IFS)

This bit determines whether interrupts from a Unibus-Out side of the UBA will be fielded by the VAX86xx CPU or passed to the Unibus-In side of the UBA. If this bit is set and if bit <05> (BRIE) is set, then the interrupt will be passed to the CPU. If this bit is cleared, then the interrupt will be passed to the Unibus-In side of the UBA and it is not seen by the SBI.

<05> BUS REQUEST INTERRUPT ENABLE (BRIE)

When this bit is set, the UBA is allowed to pass interrupts from the Unibus to the CPU, providing that bit <06> (IFS) is set. It is cleared by the Adaptor INIT, SBI UNJAM, and SBI DEAD signals. Note: The power up state of the BRIE bit is 0.

- <04> UNIBUS TO SBI ERROR FIELD INTERRUPT ENABLE (USEFIE)
This bit enables an interrupt request to the CPU whenever any of the following DW780 Status Register bits are set during a DMA transfer.

- <10> - RDTO (Read Data Time Out)
- <09> - RDS (Read Data Substitute)
- <08> - CXTER (Command Transmit Error)
- <07> - CXTMO (Command Transmit Time Out)
- <06> - DPPE (Data Path Parity Error)
- <05> - IVMR (Invalid Map Register)
- <04> - MRPF (Map Register Parity Failure)

The power up state of the USEFIE bit is 0. SBI UNJAM and Adaptor INIT will clear USEFIE.

- <03> SBI TO UNIBUS ERROR FIELD INTERRUPT ENABLE
If this bit is set, the UBA will generate interrupt requests to the CPU when either of the following DW780 Status register bits are set.

- <01> - UBSTO (Unibus Select Time Out)
- <00> - UBSSYNTO (Unibus Slave Sync Time Out)

This bit is cleared when in the power up state. SBI UNJAM, SBI DEAD and Adaptor INIT will clear the SUEFIE bit.

- <02> CONFIGURATION INTERRUPT ENABLE
If this bit is set, the UBA will initiate an interrupt request to the CPU whenever any of the following Environmental Status bits in the Configuration Register are set.

- <23> - AD PDN (Adaptor Power Down)
- <22> - AD PUP (Adaptor Power Up)
- <18> - UB INIT (Unibus Init Asserted)
- <17> - UB PDN (Unibus Power Down)
- <16> - UBIC (Unibus Initialization Complete)


This bit is set when the power up state is set. It is cleared by Adaptor INIT, SBI UNJAM and SBI DEAD.

- <01> UNIBUS POWER FAIL
This bit is set when a power fail sequence on the Unibus, asserting AC LO, DC LO and INIT are in their correct sequence. The software uses this bit to initialize the Unibus. The Unibus will remain powered down as long as UPF is set. It is cleared when a Unibus power up sequence or when the Unibus power down sequence has finished and Unibus power is OK.

VAX 8600/8650 REGISTER DESCRIPTION
DW780 UACR

UACR
OFFSET: 004

DW780 CONTROL REGISTER
UAIL, M



<00>


ADAPTOR INIT

When this bit is set it will completely initialize the UBA and the Unibus. The Map Registers, the Data Path Registers, the Status Register and the Control Register will be cleared. The UBA will start the initialization routine in the microsequencer, and it will generate a Unibus initialization sequence and a Unibus power fail sequence on the Unibus. The UBA initialization sequence takes only 500 us to complete, while the Unibus power fail sequence requires approximately 25 ms.

Only the Configuration Register and the Diagnostic Control Register can be read during the adaptor initialization sequence. Only the Configuration Register, the Diagnostic Control Register, the Control Register and the Status Register can be written during the adaptor initialization sequence.

Once the sequence has been completed, all UBA registers can be accessed. However, the Unibus cannot be accessed until the Unibus initialization sequence has been completed as well. The software can test for this condition by reading bit <16> (UBIC) of the Configuration Register, or by setting bit <02> (CNFIE) of the Control Register and looking for the interrupt generated by the setting of the UBIC bit. Note, however, that the assertion of either Unibus INIT or Unibus power down will also initiate an interrupt (UBINIT). The Adaptor INIT bit can be set by writing a 1 to the bit location; it is self-clearing.

VAX 8600/8650 REGISTER DESCRIPTION DW780 USAR



<31:28> RESERVED

<27:24> BR RECEIVE VECTOR REGISTER FULL

These bits indicate the state of the SBI addressable BRRVR's. Each bit is set when the interrupt vector is loaded into the corresponding BRRVR during a Unibus interrupt transaction, providing that the SBI processor is fielding Unibus device interrupts.

Each bit is cleared by the successful completion of a read data transmission following a read BRRVR command. The software will see these bits set only after a read data failure has occurred during the execution of a read BRRVR command and the Unibus interrupt vector has been saved by the UBA. These bits are cleared only by a subsequent read to the corresponding BRRVR or by an adaptor initialization sequence.

Bit 27 = BRRVR 7 Full

Bit 26 = BRRVR 6 Full

Bit 25 = BRRVR 5 Full

Bit 24 = BRRVR 4 Full

<23:11> RESERVED

<10> READ DATA TIME OUT (RDTO)

The UBA sets the RDTO bit when the following conditions are all true. A Unibus device has initiated a DMA read transfer. The UBA has successfully transmitted a read command on the SBI. The SBI memory or SBIA has not returned the requested data within 100 us, and the Unibus device has not timed out. Note that the normal Unibus time out is 10 us, and that after 10 us, the Unibus device will set its non-existent memory bit. Thus, the RDTO bit will be set on the UBA status register only if the Unibus device timeout function is inoperative, or takes more than 100 us. This bit is not set for a BDP to SBI prefetch. Also see Note 1.


<09> READ DATA SUBSTITUTE (RDS)

This bit is set if a read data substitute is received in response to a Unibus to SBI read command (DMA read transfer). No data will be sent to the Unibus device, and when the device timeout occurs it will set the non-existent memory bit on the device. Also see Note 1.

<08> CORRECTED READ DATA (CRD)

The UBA sets this bit when it receives corrected read data in response to an SBI read command during a DMA read transfer.

VAX 8600/8650 REGISTER DESCRIPTION
DW780 USAR



<07> COMMAND TRANSMIT ERROR (CXTER)

This bit is set when the UBA receives an error confirmation in response to an SBI command transmission during a Unibus to SBI access, a BDP to SBI read, a BDP to SBI write, or a purge operation. This bit is not set for a BDP to SBI prefetch. Also see Note 1.

<06> COMMAND TRANSMIT TIMEOUT (CXTMO)

This bit is set when the UBA fails to complete an SBI command transfer within 100 us for any of the following operations:

1. A BDP to SBI write
2. A BDP purge operation
3. A BDP to SBI read operation for which the Unibus device has timed out

This bit is not set for a timeout for a BDP to SBI prefetch. Also see Note 1.

<05> DATA PATH PARITY ERROR (DPPE)

This bit is set when a parity error in a buffered data path occurs during either a Unibus to BDP read, BDP to SBI write, or a BDP purge operation. Also see Note 1.

<04> INVALID MAP REGISTER (IVMR)

The UBA sets this bit during a Unibus DMA transfer or purge operation when the Unibus address points to a map register that has not been validated by the software and has not been disabled by the MRD bits. Also see Note 1.

<03> MAP REGISTER PARITY FAILURE (MRPF)

This bit is set with the occurrence of a map register parity error during one of the following operations:

1. A Unibus access in which the Unibus address points to a map register that has a parity error in the upper 16 bits, providing that the map register has not been disabled by the MRD bits.
2. Mapping a Unibus address to an SBI address during a direct data path to SBI operation or a BDP to SBI read operation (but not during a prefetch).
3. Mapping an address from a buffered data path to an SBI address during a purge operation or a BDP to SBI write. Also see Note 1.

<02> LOST ERROR BIT

The UBA sets this bit if the locking error field is locked and another error within this field occurs. The lost error bit does not initiate an interrupt request. See Note 1.

<01> UNIBUS SELECT TIME OUT (UBSTO)

The UBA sets this bit if it cannot gain access to the Unibus within 50 us in the execution of a software initiated transfer (SBI to Unibus transfer). Note: When UBSTO is set it indicates that the UBA has issued NPR on the Unibus but has not become bus master. This condition indicates the presence of a hardware problem on the Unibus. The Unibus may be inoperative, or one device may be holding it for extended periods. Note that if the Unibus does become inoperative, it may be possible to clear the problem with the assertion of UNJAM on the SBI, the setting and clearing of the Unibus Power Fail bit (control register bit 1) or the setting of Adaptor INIT (control register bit 0).

<00> UNIBUS SLAVE SYNC TIME OUT (UBSSYNTO)

This bit is set when an SBI to Unibus transfer (software initiated transfer) times out during the data transfer cycle on the Unibus. The timeout occurs after 12.8 us. This bit indicates a transfer failure resulted when a Non-Existent Memory or device on the UNIBUS is addressed. The above two bits, UBSTO and UBSSYNTO, form an SBI to Unibus transfer error locking field. They are set by the occurrence of the conditions mentioned. The setting of either bit will cause the UBA to make an interrupt request on the SBI if the SBI to Unibus error interrupt enable bit <03> (SUEFIE) in the control register is set. The setting of either UBSTO or UBSSYNTO will lock the Failed Unibus Address Register, thus storing the high 16 bits of the UNIBUS address identified with the failure. The Failed Unibus Address Register will remain locked until the UBSTO and UBSSYNTO bits are cleared.

NOTE: 1. Seven of the above bits (RDTO, RDS, CXTER, CXTMO, DPPE, IVMR and MRPF) form an error locking field. If any of these bits is set, the field is locked, thereby preventing the setting of other bits within this field, until the bit indicating the error is cleared. The failed map entry register (FMER) is also locked and unlocked with this field. The setting of these bits will cause the UBA to initiate an interrupt request if the interrupt enable bit for the Unibus to SBI data transfer error field (USEFIE) in the control register is set.

VAX 8600/8650 REGISTER DESCRIPTION EBCS

EBCS
(ESCRATCH LOC 1A - TOA)

EBOX CONTROL AND STATUS WORD

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
CONSOLE ECC CORRECTION REQUEST								STACK FRAME REVISION				PERFORM MONITOR ENABLE		PROCESS ABORT REASON CODE		
FBM CS	FBA CS	FBOX DRAM	IBOX DRAM	IBOX CS												
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00	
MBOX FATAL ERROR	MBOX INTERRUPT PENDING	IBOX ERROR	EBOX MCF RAM PE	EBOX CS PE	EBOX D-STACK PE	EBOX DATA PATH PE	EBOX WBUS PE					EBOX ABORT	MACHINE STATE MODIFIED	MEMORY OR I/O WRITE	I/O READ	

SEP 1 1976

This register is made up from the EBCS register (see EBD2, EBD3 and EBE5) and other EBox status bits (see EBEB and EBEC).

<31:27> CONSOLE ECC CORRECTION REQUESTS

The bits in this field are set by the EHM in order to interrupt the Console for Control Store or Dispatch RAM correction.

When set, these bits will cause an immediate Console interrupt. The EHM will loop waiting for the Console to set "DONE" in RBUFC. When correction is complete, control is returned to the EBox by setting "DONE". The EHM will then clear the correction request EBCS <31:27> and thus release the Console interrupt.

<31> FBM CONTROL STORE CORRECTION REQUEST

EBE5 FBOX FBM CS PE

The Console will attempt to correct the parity error and then return control to the EHM by setting the "DONE" bit <07> in RBUFC.

<30> FBA CS CORRECTION REQUEST

EBE5 FBOX FBA CS PE

The Console will attempt to correct the parity error and then return control to the EHM by setting the "DONE" bit <07> in RBUFC.

<29> FBOX DRAM CORRECTION REQUEST

EBE5 FBOX DRAM PE

The Console will reload the FBox Dispatch RAM and then return control to the EHM by setting the "DONE" bit <07> in RBUFC.

<28> IBOX DRAM CORRECTION REQUEST

EBE5 IBOX DRAM PE

The Console will attempt to correct the parity error and then return control to the EHM by setting the "DONE" bit <07> in RBUFC.

<27> IBOX CS CORRECTION REQUEST

EBE5 IBOX CS PE

The Console will attempt to correct the parity error and then return control to the EHM by setting the "DONE" bit <07> in RBUFC.

<26:24> RESERVED

<23:21> STACK FRAME REVISION

The stack frame revision is written by the error handling microcode to indicate how many times the stack frame has been revised. The previous stack frame was revision 0, and the current stack frame is revision 1.

- <20> **PERFORM MONITOR ENABLE**
EBE5 PERFORMANCE MONITOR ENABLE
 This is an architecturally defined bit which is controlled by System software. It is wired to a CPU backplane pin (Slot 09 Pin A07) and allows system performance to be monitored externally. See the PMR description for further information.
- <19:16> **PROCESS ABORT REASON CODE**
 If EHMSTS <17>, PROCESS ABORT, is set, EBCS <19:16> is the reason why the faulted instruction cannot be retried.
- 0001 Unrecoverable GPR parity error
 0010 EBox WBus parity error
 0011 All IBox PC's are invalid
 0100 EBox failed to detect OPBus byte parity error
 0101 CPR parity error that did not result in an MBox fatal error
 0110 RLog parity error
- <15> **MBOX FATAL ERROR**
ERR6 MBOX FATAL ERROR
 Set via EBox Port Status Line 0. Indicates that the MBox detected one of the following Fatal Error conditions:
- ERR1 WR DAT PE & WRITE REG ERR2 CP IO PE
 ERR2 TAG PE & WBIT ERR6 CP BUFF ERR
 ERR2 DMA PE ERR6 CP NXM ERR
 MCCJ CPR FTL ERR
- <14> **MBOX INTERRUPT PENDING**
EBC2 MBOX INTR LVL3
 The Mbox generates an interrupt request when it detects an error of any kind (excluding TB parity errors). This bit is set by the EBox on the third occurrence of T3 after it receives MBox Interrupt and is usually handled at IRD Time.
- <13> **IBOX ERROR**
EBCA IBOX ERR LTH
 Set by the EBox when the IBox reports one of the following error conditions.
- ICBC IDRAM PE IDP6 IBMUX PE ICA7 ICS PE
 EBD7 RSV MODE IDP6 IAMUX PE ICBC IBUF PE
 ICB6 RLOG PE
- <12> **EBOX MEMORY CONTROL FIELD RAM PARITY ERROR**
EBD2 EMCR PE FLAG
 Set when the EBox detected a parity error in the Memory Control Field (MCF) RAM.
- <11> **EBOX CONTROL STORE PARITY ERROR**
EBD2 ECS PE FLAG
 Set when the EBox detected a Control Store Parity Error. Setting this bit results in a immediate trap to the Console for ECC Correction. When the Console finishes correcting the error it will force the EBox to trap to EHM (Vector 8).
- <10> **EBOX MICRO-STACK PARITY ERROR**
EBD2 USTK PE FLAG
 Set when the EBox detected a parity error when it popped the last entry off the micro-stack.

VAX 8600/8650 REGISTER DESCRIPTION EBCS

EBCS
(ESCRATCH LOC 1A - TDA)

EBOX CONTROL AND STATUS WORD

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
CONSOLE ECC CORRECTION REQUEST								STACK FRAME REVISION				PERFORM MONITOR ENABLE		PROCESS ABORT REASON CODE	
FBI CS	FBI CS	FBI CS	FBI CS	FBI CS	FBI CS	FBI CS	FBI CS								
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
MBOX FATAL ERROR	MBOX INTERRUPT PENDING	IBOX ERROR	EBOX MCF RAM PE	EBOX CS PE	EBOX USTACK PE	EBOX DATA PATH PE	EBOX WBUS PE					EBOX ABORT	MACHINE STATE MODIFIED	MEMORY OR GPR WRITE	IO READ

MR 13018

- <09> **EBOX DATA PATH PARITY ERROR**
EBD2 EDP PE FLAG
 Set when the EBox detected either an Operand parity error or a Result parity error.
- <08> **EBOX WBUS PARITY ERROR**
EBD2 WBUS PE FLAG
 Set when the EBox detected a WBus Parity Error while it was driving the bus.

NOTE

- Writing 1 to this bit clears bits <15>, <12:09> and <4>.
- This bit has a different use in diagnostic mode.

- <04:01> **VMS ABORT FLAGS**
 VMS uses these flags, in part, to determine whether or not the error is recoverable.
- <04> **EBOX ABORT**
EBD3 EB ABORT FLAG
 Set when the EBox detected an MCF RAM Parity Error or a Result Parity Error. Both cases are non-recoverable.
- <03> **MACHINE STATE MODIFIED**
EBD3 STA MOD FLAG
 Set by Microcode via the UMISC Field. Indicates that the state of the machine has been modified such that, should an error occur while this bit is set the operation currently executing in the EBox cannot be retried.
- <02> **MEMORY OR GPR WRITE**
EBD3 MEM WRT FLAG
 Set when a Memory or GPR write operation was in progress when the error occurred.
- <01> **IO READ**
EBD3 IO RD FLAG
 Set when the error involved an I/O register read. Since some I/O registers automatically clear after being read the contents of the I/O register may have been lost.
- <00> **RESERVED**

VAX 8600/8650 REGISTER DESCRIPTION


EBXWD1

EBXWD2

EBXWD1

(ESCRATCH LOC 1E — TOE)

EBOX WORD 1



MM-1300X


<31:00> LAST EBOX WORD WRITTEN

This register contains a copy of the last word that the EBox wrote to the MBox. This word is obtained by popping the last word off the Scratch Pad Stack (EScratch Location F0).

EBXWD2

(ESCRATCH LOC 1F — TOF)

EBOX WORD 2



MM-1300X

<31:00> SECOND TO LAST EBOX WORD WRITTEN


This register contains a copy of the second to last word that the EBox wrote to the MBox. This word is obtained by popping the second to last word off the Scratch Pad Stack (EScratch Location F1).

VAX 8600/8650 REGISTER DESCRIPTION

EDMC

EDMC

EBOX DIAGNOSTIC/MAINTENANCE CONTROL REGISTER
EBD4



SEP 13 1980


The EBox Diagnostic/Maintenance Control Register (EDMC) is a write only register which shares the same WBus register address as the EBox Data Path Error Register (EDPE), a read only register. EDMC implements up to 8 bits which can be used by EBox microdiagnostics to control hardware in the CPU.

A Master Reset or Diagnostic Reset causes EDMC to be written with all zeros, thus clearing INH STALL, CLR FLAG, RST IBOX, and MB UADR <07:06>.

<07:05> RESERVED

- <04> DIAGNOSTIC MBOX MICRO ADDRESS 07
EBD DIAG MBOX UADR 7 H <Pin A06-69> V\$A102
Diagnostic MBox Microaddress Bit 7. This bit is used by diagnostics to control bit 7 of the MBox Microsequencer Address.
- <03> DIAGNOSTIC MBOX MICRO ADDRESS 06
EBD DIAG MBOX UADR 6 H <Pin A06-71> V\$A101
Diagnostic MBox Microaddress Bit 6. This bit is used by diagnostics to control bit 6 of the MBox Microsequencer Address.
- <02> DIAGNOSTIC RESET IBOX
EBD DIAG RST IBOX H <Pin A06-87> V\$D116
Diagnostic Reset IBox. This bit initiates an IBox reset.
- <01> DIAGNOSTIC CLEAR CYCLE IN PROGRESS FLAGS
EBD4 DIAG CLR FLAGS H V\$C198
Diagnostic Clear Cycle in Progress Flags. The assertion of this bit clears the Cycle in Progress Flags in the EBox Control Logic when they are clocked at the end of a machine cycle.
- <00> DIAGNOSTIC INHIBIT ESTALLS
EBD4 DIAG INH STALLS H V\$C177
Diagnostic Inhibit EBox Stalls. The assertion of this bit prevents the EBox Microsequencer and EBox Data Path from stalling when EBox Stall is asserted. The bit does not inhibit the assertion of copies of EBox Stall used by the FBox, IBox, MBox, or EBox Control Logic or the copy which serves as a branch condition to the EBox Microsequencer.

VAX 8600/8650 REGISTER DESCRIPTION STATE EDPSPR



This register is made up from the nibble registers in the PDP MCA.

<31:28> BMUX BYTE IN ERROR
PDP4 BMX ERR BYTE <3:0> (EDPH)
This field is only valid when either bit <07> or bit <00> is set. This field indicates the byte(s) that were associated with the BMux Parity Error.

<27:24> AMUX BYTE IN ERROR
PDP3 AMX ERR BYTE <3:0> (EDPH)
This field is only valid when either bit <01> is set, or when bit <02> is set, or when bit <03> is set and bits <00:02> and <06:07> are reset. This field indicates the byte(s) that were associated with the AMUX Parity Error.

<23:16> EBOX GPR PARITY ERROR ADDRESS
If EHMSTS <26> (EBox GPR B PE) or <25> (EBox GPR A PE) is set, these bits indicate the failing GPR address.

<15:12> VMQ BYTE IN ERROR
PDP5 VMQ ERR BYTE <3:0> (EDPH)
This field is only valid when bit <05> is set and bit <08> is reset. It indicates the byte(s) that were associated with the Result parity error.

<11> WREGISTER PARITY ERROR
PDP6 WREG ERR (EDPH)
Indicates that the parity at the input to the WReg Mux did not match the parity generated at the output of the WReg. The inputs to the WReg Mux are:

- The AMux and BMux for WReg Shift Operations.
- The BMux for WReg Format Operations.
- The ALU for post ALU Wreg Shift Operations.


NOTE

This error will also cause a RESULT PE.

<10:09> RESERVED

<08> EDP MISCELLANEOUS PARITY ERROR
PDP8 EDP MISC (EDPH)
Indicates that the ALU was the input to the VMQMUX when a parity error was detected at the VMQMUX output. When this bit is set the contents of bits <12:15> are not valid. This error will also cause a RESULT PE.

VAX 8600/8650 REGISTER DESCRIPTION STATE EDP8R



- <07> BMUX WBUS PARITY ERROR**
PDP8 B WBUS (EDPH)
 Indicates that the WBUS was the input to the BMux when a parity error was detected at the BMux output. Bits <28:31> indicate the byte(s) in error.
- <06> BMUX OPBUS PARITY ERROR**
PDP8 B OPBUS (EDPH)
 Indicates that the OPBus (which is protected by longword parity) was the input to the BMux when a BMux parity error was detected at the BMux output. When this bit is set the contents of bits <28:31> are not valid.
- <05> RESULT PARITY ERROR**
PDP8 RSLT CHK (EDPH)
 If neither WREG PE <11> nor EDP MISC <08> are set, this bit indicates that the VMQSAV Register was the input to the VMQMUX when a VMQMUX parity error was detected. Otherwise, this bit is the "or" of all three of those conditions.
- <04> RESERVED**
- <03> OPERAND PARITY ERROR**
PDP8 OPER CHK (EDPH)
 If bits <02:00> and <07:06> are reset, then this bit indicates that the VMQSAV Register was the input to the AMux when an AMux Parity error was detected. Otherwise, this bit indicates that one of the following errors were detected:
- BMux GPR B PE AMux GPR A PE
 BMux WBUS PE AMux WBUS PE
 BMux OPBUS PE
- <02> EB0X GENERAL PURPOSE REGISTER A PARITY ERROR**
PDP8 A RAM (EDPH)
 Indicates that Scratch Pad-A was the input to the AMux when a parity error was detected at the AMux output.
- <01> AMUX WBUS PARITY ERROR**
PDP8 A WBUS (EDPH)
 Indicates that the WBUS was the input to the AMux when a parity error was detected at the AMux output.
- <00> EB0X GENERAL PURPOSE REGISTER B PARITY ERROR**
PDP8 B RAM (EDPH)
 Indicates that Scratch Pad-B was the input to the BMux when a parity error was detected at the output of the BMux.

VAX 8600/8650 REGISTER DESCRIPTION EHMSTS

EHMSTS
(SCRATCH LOC. 18 - T08)

ERROR HANDLING MICROCODE STATUS WORD

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
MBOX SERVICE REQUEST	EHM ENTERED	VMS ENTERED	FBOX SERVICE REQUEST	FBOX GPR	FBOX GPR B	FBOX GPR A	IBOX GPR	FBI CS	FBI CS	FBOX DRAM	IBOX DRAM	IBOX CS	MEAR SAVED	PROCESS ABORT	
EHM HAS STARTED PARITY ERROR CORRECTION PROCESS															
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
MICRO-TRAP VECTOR ADDRESS								MBOX INTERRUPT ENTRY VALID	SBIA SUMMARY ENTRY VALID	SBIA FULL RPT FOLLOWS	RESOURCE TURNED OFF	PRIMARY ERROR CODE (SUPPLIED BY VMS)			
												3	2	1	0

MAP 13015

This status word contains a modified copy of the Error Handling Status Register (EHSR) which is stored in Scratch Pad location 0DA. The Error Handling Microcode uses EHSR to keep track of status during the error handling process.

In addition, two other Microcode Routines use the EHSR to pass status to the EHM Routine. The Interrupt Handling Microcode Routine uses bit 31 to report MBox error interrupts; and the FBox Problem Handling Routine uses bit 28 to report FBox hardware errors.

The EHM copies the contents of EHSR into EBox Scratch Pad location 18 just before it sets VMS ENTERED and clears EHM ENTERED. The EHM then calls the Interrupt Exception Microcode to push the stack frame onto the interrupt stack and call the Machine Check Handler.

<31> MBOX SERVICE REQUEST

If the Interrupt Handling Microcode determines that it was called to handle an MBox Error Interrupt it will set this flag and call the EHM. The EHM will test this flag and, if set, the EHM will process the MBox Error.

<30> EHM ENTERED


This flag is used by the EHM to detect a double error trap condition. That is, those cases when a second error trap occurs before the EHM Routine is able to finish processing the first error and pass control to VMS.

This flag is checked each time the EHM routine is entered. If the flag is clear (which is the expected case) then the EHM Routine will set this flag and process the error in the normal manner. If the flag is set, however, indicating that the EHM Routine was in the process of handling an error when it was called to handle a second error, then one of two things will happen:

1. If the second error was detected by either the EBox or the MBox Fatal Error detection circuitry, then the EHM Routine will loop at UPC 21. This in turn will cause a Keep Alive Fail condition and the Console will Print the following message and Snap Shot the state of the system.

"Attempting to save machine state due to" "MACHINE DOUBLE ERROR"

VAX 8600/8650 REGISTER DESCRIPTION EHMSTS



2. If the second error was detected by the IBox then the EHM will put a code of 5 in CSM.STATUS (Scratch Pad location: C0) and call the CSM.ENTRY.DE Routine. This will result in a Keep Alive Fail Condition and the Console will print the following message and Snap Shot the state of the system.

"Attempting to save machine state due to" "CPU ERROR HALT"

NOTE

Because the state of EHSR is saved in EScratch 18 before the EHM Routine clears EHM ENTERED, this flag will always be set in the copy of the Stack Frame saved by the VMS MCHK Handler.

<29>

VMS ENTERED

This flag is similar to the EHM ENTERED flag. It is used to detect the case where the VMS Machine Check Handler is in the process of handling an error when a second error is detected.

The EHM Routine sets this flag just before it calls the Machine Check Handler. The Machine Check Handler processes the errors and clears this flag just before it executes an REI to continue the operation (or a BUGCHECK to halt the operation).

If a second error trap occurs while the Machine Check Handler is still processing the first error, then the EHM Routine will process the error in the normal manner. That is, build a Stack Frame, clear the error condition, roll back the PCs and determine if it should call VMS.

However, since the VMS ENTERED flag is set (indicating that VMS was processing an error when a second error was detected), the EHM will not call VMS. Instead it will put a code of 5 in CSM.STATUS (EBox Scratch Pad Location: C0) and call the CSM.ENTRY.DE Routine. This in turn will result in a Keep Alive Fail Condition and the Console will print the following message and Snap Shot the state of the system.

"Attempting to save machine state due to" "CPU ERROR HALT"

- <28> FBOX SERVICE REQUEST
The micro-routine that handles FBox Problems will set this flag if it determines that the problem was caused by an FBox hardware error. The routine will then call the EHM Routine to process the error. The EHM will test this flag, to determine if it was called to handle an FBox error.
- <27> FIX FBOX GENERAL PURPOSE REGISTER PARITY ERROR
Set by the EHM when it starts to correct an FBox GPR parity error.
- <26> FIX EBOX GENERAL PURPOSE REGISTER B PARITY ERROR
Set by the EHM when it starts to correct an EBox GPR B parity error.
- <25> FIX EBOX GENERAL PURPOSE REGISTER A PARITY ERROR
Set by the EHM when it starts to correct an EBox GPR A parity error.
- <24> FIX IBOX GENERAL PURPOSE REGISTER PARITY ERROR
Set by the EHM when it starts to correct an IBox GPR parity error.
- <23> FIX FBM CONTROL STORE PARITY ERROR
Set by the EHM when it starts to correct an FBM Control Store parity error.
- <22> FIX FBA CONTROL STORE PARITY ERROR
Set by the EHM when it starts to correct an FBA Control Store parity error.
- <21> FIX FBOX DRAM PARITY ERROR
Set by the EHM when it starts to correct an FBox Dispatch RAM parity error.
- <20> FIX IBOX DRAM PARITY ERROR
Set by the EHM when it starts to correct an IBox Dispatch RAM parity error.
- <19> FIX IBOX CONTROL STORE PARITY ERROR
Set by the EHM when it starts to correct an IBox Control Store parity error.
- <18> MEAR SAVED
Indicates that the MBox Error Address Register (MEAR) was saved (in EScratch Location: DB) as a result of the last MBox Error Register Full trap.
- <17> PROCESS ABORT
The EBox microcode detected a condition which prevents a retry of the faulted instruction. See EBCS <19:16> for the reason code.
- <16> RESERVED

VAX 8600/8650 REGISTER DESCRIPTION EHMSTS

EHMSTS (ESCRATCH LOC 18 - 10B)																ERROR HANDLING MICROCODE STATUS WORD																							
31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16																								
MBOX SERVICE REQUEST	EHM ENTERED	VMS ENTERED	FBOX SERVICE REQUEST	FBOX GPR	EBOX GPR R	EBOX GPR A	IBOX GPR	FBI CS	FBI CS	FBOX DRAM	IBOX DRAM	IBOX CS	MEAR SAVED	PROCESS ABORT																									
EHM HAS STARTED PARITY ERROR CORRECTION PROCESS																																							
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00																								
MICRO-TRAP VECTOR ADDRESS																MBOX INTERRUPT ENTRY VALID	SBIA SUMMARY ENTRY VALID	SBIA FULL RPT FOLLOWS	RESOURCE TURNED OFF	PRIMARY ERROR CODE (SUPPLIED BY VMS)																			
																				3	2	1	0																

<15:08> MICRO TRAP VECTOR ADDRESS

Contains the vector address through which the EHM was entered.

VECTOR REASON

- 2 FBox Error (Called by FBox Interrupt Handler)
- 4 EHM Detected a Process Abort condition during a MBox Error Register Full Micro-trap.
- 6 MBox Error (Called by MBox Interrupt Handler)
- 8 EBox Error
- 8 MBox Fatal Error.
- 8 TB PE Error (EBox Port Request only)
- 10 IBox Op-Port-Write and IBox Error
- 10 IBox Op-Port-Write and TB Parity Error
- 10 EBox IMD Read and IBox Error
- 10 EBox IMD Read and TB Parity Error
- 18 EBox Fork and IBox Error
- 18 EBox Fork and TB Parity Error
- 18 EBox ID Read and IBox Error
- 18 EBox String Read and IBox Error
- 18 EBox String Read and TB Parity Error
- 1E IBox Sync Failure
- 1F Rlog Unwind Failure

<07:00> REASON CODE

This field is supplied by the VMS Machine Check Handler. Therefore, this field will be valid only after the Machine Check has been processed by VMS. This field will not be valid for Stack Frames extracted directly from the EBox Scratch Pad RAMs or the Interrupt Stack. See <03:00> for the actual Reason Code.

<07> MBOX INTERRUPT ENTRY VALID

Indicates that the Stack Frame was generated as a result of an MBOX ID interrupt.

<06> SBIA SUMMARY ENTRY VALID

Indicates that a copy of the SBIA Error Summary Register has been appended to the end of the stack frame.

<05> SBIA FULL REPORT FOLLOWS

Indicates that a full SBIA Error Log entry follows this entry in the System Event File (ERRLOG.SYS).

<04> RESOURCE TURNED OFF
 Indicates that VMS disabled either the FBox or one of the
 Caches.

<03:00> PRIMARY ERROR CODE
 This field indicates which Box detected the error.


Code	Box Detecting Error
-----	-----
001	FBox
010	EBox
011	IBox
100	MBox (Fatal Error)

VAX 8600/8650 REGISTER DESCRIPTION EHSR

EHSR

IPR 4A (ESC DA)

ERROR HANDLING STATUS REGISTER



MAP - 12923

<31:27> EHM IS FIXING

The EHM sets the appropriate bit in this field just before it sets the corresponding bit in EBCS <31:27>. Setting a bit in EBCS <31:27> causes the EBox to interrupt the Console for Control Store or Dispatch RAM correction.

<26> MEAR SAVED

When the EHM is called to handle an MBox Error Register Full (ERF) micro trap, it saves MEAR in ESC: DB and sets this bit. Later, when the EHM is servicing the MBox interrupt associated with the ERF micro trap, it checks this bit to determine whether it should get MEAR from the MBox or ESC: DB.

<25> PROCESS ABORT

The EHM sets this bit if it determines that: 1) An MBox CPR Parity Error failed to result in an MBox Fatal Error, or 2) The EBox failed to detect bad data on the OPBus. If this bit is set, VMS will either Bugcheck the user or the system.

<24> MBOX TRAP TO 4

This bit indicates the occurrence of an MBox trap to 4. When running with the the IPL above 1D this may be the only sign of an SBE. It is used by VMB to check for single bit errors.

<23:16> MICRO-TRAP VECTOR ADDRESS

The EHM saves the entry level trap vector address in this field. The vector addresses are:

VECTOR	REASON
2	FBox error (Called by FBox interrupt handler)
4	EHM detected a process abort condition during a MBox ERF micro-trap
6	MBox error (Called by MBox interrupt handler)
8	EBox error
8	MBox fatal error
8	TB parity error (Ebox port request only)
10	EBox Op-Port-Write and IBox error
10	IBox Op-Port-Write and TB parity error
10	EBox IMD read and IBox error
10	EBox IMD read and TB parity error
VECTOR	REASON (Cont)
18	EBox fork and IBox error
18	EBox fork and TB parity error
18	EBox ID read and IBox error
18	EBox string read and IBox error
18	EBox string read and TB parity error
1E	EBox sync failure
1F	RLog unwind parity error

<15:08> RESERVED

<07> MBOX SERVICE REQUEST

If the interrupt handling microcode determines that it was called to handle an MBox error interrupt, it will set this flag and call the EHM. The EHM will test this flag and, if set will process the MBox error.

<06> EHM ENTERED

This flag is used by the EHM to detect a double error trap condition. That is, those cases when a second error trap occurs before the EHM routine is able to finish processing the first error and pass control to VMS.

This flag is checked each time EHM is entered. If the flag is clear (which is the expected case), then EHM will set this flag and process the error in the normal manner. If the flag is set, however, indicating that EHM was in the process of handling an error when it was called to handle a second error, then one of two things will happen:

1. If the second error was detected by either the EBox or the MBox fatal error detection circuitry, then EHM will loop at UPC 21. This in turn will cause a Keep Alive Fail condition and the Console will print the following message and capture (Snap Shot) the state of the system:

" Attempting to save machine state due to"
"MACHINE DOUBLE ERROR"

2. If the second error was detected by the IBox then EHM will put a code of 5 in CSM.STATUS (ESC: C0) and call the CSM.ENTRY.DE routine. This will result in a Keep Alive Fail Condition and the Console will print the following message and Snap Shot the state of the system:

" Attempting to save machine state due to"
"CPU ERROR HALT"

NOTE


When EHM finishes processing the error, it will set the VMS ENTERED flag, clear this flag and call the VMS Machine Check Handler.

<05> VMS ENTERED

This flag is similar to the EHM ENTERED flag. It is used to detect the case where the VMS Machine Check Handler is in the process of handling an error when a second error is detected.

EHM sets this flag just before it calls the Machine Check Handler. The Machine Check Handler processes the errors and clears this flag just before it executes an REI to continue the operation (or a BUGCHECK to halt the operation).

VAX 8600/8650 REGISTER DESCRIPTION EHSR



If a second error trap occurs while the Machine Check Handler is still processing the first error, then the EHM routine will process the error in the normal manner. That is, build a Stack Frame, clear the error condition, roll back the PC's and determine if it should call VMS.


However, since the VMS ENTERED flag is set (indicating that VMS was processing an error when a second error was detected), EHM will not call VMS. Instead, it will put a code of 5 in CSM.STATUS (ESC: C0) and call the CSM.ENTRY.DE routine. This in turn will result in a Keep Alive Fail condition and the Console will print the following message and capture (Snap Shot) the state of the system:

" Attempting to save machine state due to"
"CPU ERROR HALT"

- <04> **FBOX SERVICE REQUEST**
The micro-routine that handles FBox problems will set this flag if it determines that the problem was caused by an FBox hardware error. The routine will then call the EHM routine to process the error. The EHM will test this flag to determine if it was called to handle an FBox error.
- <03> **FIX FBOX GPR PE**
Set by the EHM when it attempts to correct an FBox GPR parity error.
- <02> **FIX EBOX GPRB PE**
Set by the EHM when it attempts to correct an EBox GPR B parity error.
- <01> **FIX EBOX GPRA PE**
Set by the EHM when it attempts to correct an EBox GPR A parity error.
- <00> **FIX IBOX GPR PE**
Set by the EHM when it attempts to correct an IBox GPR parity error.

VAX 8600/8650 REGISTER DESCRIPTION


EMD
ESASAV
ESP




<31:00> **IBOX EBOX MEMORY DATA REGISTER**
The contents are displayed in bit <31:00>.

Additional Notes:

- (1) CSM Overlay 6 "EIMR",
"Examine IBox Miscellaneous Register", is used to read the contents of the EMD Register. Basically, the UOPSEL field selects the EMD register to drive the OPBUS which in turn is loaded into an ESC location.
- (2) The EMD register is not visible on any backplane pins nor on the SDB visibility path.



<31:00> **CURRENT PC FOR EXECUTION UNIT (EBOX)**
This register contains the address (Macro PC) of the instruction that the EBox or FBox is currently processing.




<31:00> **EXECUTIVE STACK POINTER**
Contains the stack pointer to be used when the current access mode field in the PSL is 1 (Executive Mode).

VAX 8600/8650 REGISTER DESCRIPTION
ESPA/ESPD


ESPA/ESPD

These registers allow VMS to access the EBox GPR/SP RAMS using macro instructions (MTPR/MFPR). For example, during machine checks for array single bit errors, the VMS machine check handler would access the MBox state saved in RAM locations 25 thru 28 (HEX). Executing macro instructions between the MTPR and MFPR will yield unpredictable results. The ESPA must be loaded with the RAM address followed immediately by reading the data from ESPD.

The reason for the above scenario is that for array single bit errors, the Stack Frame is not pushed on the Interrupt Stack. Therefore, the VMS machine check handler must access the GPR/SP explicitly.




This write only register is loaded with the address of an EBox scratchpad location to be accessed.



This read only register contains the data requested by the MTPR to ESPA. If ESPA is not loaded prior to accessing the data, unpredictable results will occur.

VAX 8600/8650 REGISTER DESCRIPTION

EVMQSAV



EVMQSAV (EBox Virtual Memory Address/Multiplier Quotient Save Register).

During EBox port requests this register contains the virtual address that was acknowledged by the MBox (PA ACK). During normal operation, this register is used to temporarily store partial EBox results.

<31:00> May contain an EBox Virtual Address or a partial calculated EBox result depending on the operation of the EBox.

VAX 8600/8650 REGISTER DESCRIPTION FBXERR

FBXERR
(ESCRATCH LOC 2C - T1G)

FBX ERROR REGISTER

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
						EXPONENT EXTENSION				FBM CS PE	FBA CS PE	FBOX DRAM PE	SELF TEST ERROR	FBOX GPR PE	RESERVED OPERAND
						1	0								
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
INSTRUCTION FORMAT CODE		FPX RESULT				DENORM RESULT						IF SELF TEST ERR 0 = FBA 1 = FBM		FBOX PROBLEM	
1	0	6	5												

MR-13023

The EHM builds this register in the EBox Scratch Pads by reading three FBox registers: 03, 02, and 01.

<31:26> RESERVED

<25:24> EXPONENT EXTENSION <01:00>

FBRD EXT <1:0> (FA01)

This field, which is an extension of the exponent field, indicates overflow and underflow conditions as follows:

FIELD CONDITION

----	-----
00	Normal
01	Overflow
10	Underflow
11	Underflow

<23:22> RESERVED

<21> FBM CONTROL STORE PARITY ERROR

MPZ5 CS PAR ERR (FM07)

Set when the FBM module detected an FBM Control Store Parity Error. When set, the CS Address is latched in the FBM MSQ MCA.

<20> FBA CONTROL STORE PARITY ERROR

ACC4 RAM PERR (FA13)

Set when the FBA module detected an FBA Control Store Parity Error. When set, the Control Store Address is latched in the FBA MSQ MCA.

<19> FBOX DRAM PARITY ERROR

MCB3 FDRAM PAR ERR (FM11)

Set when the FBM module detected a Dispatch RAM Parity Error. Neither the DRAM address nor the DRAM data are latched.

<18> SELF TEST ERROR

FBR3 SELF TEST ERROR (FA01)

Set when the FBox module detected an error while running the Self Test. Bit <02> will indicate whether the error was associated with the FBA or FBM Module.

<17> FBOX GENERAL PURPOSE REGISTER PARITY ERROR

FBR4 GPR ERROR (FA01)

Set when the FBA Module detected a GPR Parity Error. The specific byte in error cannot be identified.

- <16> RESERVED OPERAND
FBR6 RESERVED OP (FA01)
This bit generally indicates a software problem and has no significance in the context of a hardware error. It indicates that one of the operands received by the FBox had a negative sign and an exponent of zero.
- <15:14> INSTRUCTION FORMAT CODE <01:00>
FBR9 FORM <01:00> (FA01)
This field indicates the format of the instruction that the FBox was executing when the FBox status was saved in this register.
- | CODE | FORMAT |
|------|--------|
| 00 | F |
| 01 | G |
| 10 | D |
| 11 | I or H |
- <13:12> FPX RESULT <06:05>
FXP6 FXRES <5:6> (FA01)
This field has no significance in the context of an error. It represents exponent result bits <13:12>.
- <08> DENORM RESULT
FBR1 DENORM (FA01)
This bit has no significance in the context of errors. It indicates that a rounding operation resulted in a "carry out".
- <07:03> RESERVED
- <02> IF SELF TEST ERROR (0=FA/FM=1)
FBR4 WBUS D00 (FA01)
This bit has a double meaning. During normal operation this bit indicates that the divisor was equal to zero. If SELF TEST ERROR is set, however, this bit indicates which FBox module detected the Self Test error (0=FA/FM=1).
- <01> RESERVED
- <00> FBOX PROBLEM
FBR1 FBOX PROBLEM (FA01)
Set when the FBox detected one of the following conditions:
- | | |
|------------------------------------|--------------|
| Exponent Extension Problem | Bits <25:24> |
| GPR Parity Error | Bit <17> |
| FBM Control Store Parity Error ... | Bit <21> |
| FBA Control Store Parity Error ... | Bit <20> |
| FDRAM Parity Error | Bit <19> |
| Self Test Error | Bit <18> |
| Divide by Zero | Bit <02> |
| Denormalize Result | Bit <08> |
| Reserved Operand | Bit <16> |

VAX 8600/8650 REGISTER DESCRIPTION
IBESR

IBEX (ESCRATCH LOC 10 - TOD)															IBOX ERROR STATUS WORD				
31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16				
JAMUX BYTE IN CRAND CODE			JAMUX SOURCE 0 = GPR 1 = WBUS		RESERVED MODE DETECTED		IBOX BMUX PE		INST BUFFER PE		IBOX AMUX PE		IBOX DRAM PE		IBOX CS PE				
1			0																
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00				
ENABLE IBOX U-TRAP LOGIC				U-TRAP PRIORITY LEVEL			OPBUS SOURCE 1 = IMD 0 = ID		UOPSEL				ESA VALID		ISA VALID				
2				1			0		1		0		1		1				
															CPC VALID				

This register is a combination of the IBox Error register (IBE) and the EBox Diagnostic Maintenance register (EDMS).

<31> RESERVED

<30:29> IBOX AMUX BYTE IN ERROR CODE

EBEA IAMUX EC <1:0> LTH

Indicates the most significant byte associated with the IBox AMux parity error.

Code Byte

1999 2000 2001 2002 2003 2004 2005 2006 2007 2008 2009 2010 2011 2012 2013 2014 2015 2016 2017 2018 2019 2020 2021 2022 2023 2024 2025 2026 2027 2028 2029 2030 2031 2032 2033 2034 2035 2036 2037 2038 2039 2040 2041 2042 2043 2044 2045 2046 2047 2048 2049 2050 2051 2052 2053 2054 2055 2056 2057 2058 2059 2060 2061 2062 2063 2064 2065 2066 2067 2068 2069 2070 2071 2072 2073 2074 2075 2076 2077 2078 2079 2080 2081 2082 2083 2084 2085 2086 2087 2088 2089 2090 2091 2092 2093 2094 2095 2096 2097 2098 2099 2100 2101 2102 2103 2104 2105 2106 2107 2108 2109 2110 2111 2112 2113 2114 2115 2116 2117 2118 2119 2120 2121 2122 2123 2124 2125 2126 2127 2128 2129 2130 2131 2132 2133 2134 2135 2136 2137 2138 2139 2140 2141 2142 2143 2144 2145 2146 2147 2148 2149 2150 2151 2152 2153 2154 2155 2156 2157 2158 2159 2160 2161 2162 2163 2164 2165 2166 2167 2168 2169 2170 2171 2172 2173 2174 2175 2176 2177 2178 2179 2180 2181 2182 2183 2184 2185 2186 2187 2188 2189 2190 2191 2192 2193 2194 2195 2196 2197 2198 2199 2200 2201 2202 2203 2204 2205 2206 2207 2208 2209 2210 2211 2212 2213 2214 2215 2216 2217 2218 2219 2220 2221 2222 2223 2224 2225 2226 2227 2228 2229 2230 2231 2232 2233 2234 2235 2236 2237 2238 2239 2240 2241 2242 2243 2244 2245 2246 2247 2248 2249 2250 2251 2252 2253 2254 2255 2256 2257 2258 2259 2260 2261 2262 2263 2264 2265 2266 2267 2268 2269 2270 2271 2272 2273 2274 2275 2276 2277 2278 2279 2280 2281 2282 2283 2284 2285 2286 2287 2288 2289 2290 2291 2292 2293 2294 2295 2296 2297 2298 2299 2300 2301 2302 2303 2304 2305 2306 2307 2308 2309 2310 2311 2312 2313 2314 2315 2316 2317 2318 2319 2320 2321 2322 2323 2324 2325 2326 2327 2328 2329 2330 2331 2332 2333 2334 2335 2336 2337 2338 2339 2340 2341 2342 2343 2344 2345 2346 2347 2348 2349 2350 2351 2352 2353 2354 2355 2356 2357 2358 2359 2360 2361 2362 2363 2364 2365 2366 2367 2368 2369 2370 2371 2372 2373 2374 2375 2376 2377 2378 2379 2380 2381 2382 2383 2384 2385 2386 2387 2388 2389 2390 2391 2392 2393 2394 2395 2396 2397 2398 2399 2400 2401 2402 2403 2404 2405 2406 2407 2408 2409 2410 2411 2412 2413 2414 2415 2416 2417 2418 2419 2420 2421 2422 2423 2424 2425 2426 2427 2428 2429 2430 2431 2432 2433 2434 2435 2436 2437 2438 2439 2440 2441 2442 2443 2444 2445 2446 2447 2448 2449 2450 2451 2452 2453 2454 2455 2456 2457 2458 2459 2460 2461 2462 2463 2464 2465 2466 2467 2468 2469 2470 2471 2472 2473 2474 2475 2476 2477 2478 2479 2480 2481 2482 2483 2484 2485 2486 2487 2488 2489 2490 2491 2492 2493 2494 2495 2496 2497 2498 2499 2500 2501 2502 2503 2504 2505 2506 2507 2508 2509 2510 2511 2512 2513 2514 2515 2516 2517 2518 2519 2520 2521 2522 2523 2524 2525 2526 2527 2528 2529 2530 2531 2532 2533 2534 2535 2536 2537 2538 2539 2540 2541 2542 2543 2544 2545 2546 2547 2548 2549 2550 2551 2552 2553 2554 2555 2556 2557 2558 2559 2560 2561 2562 2563 2564 2565 2566 2567 2568 2569 2570 2571 2572 2573 2574 2575 2576 2577 2578 2579 2580 2581 2582 2583 2584 2585 2586 2587 2588 2589 2590 2591 2592 2593 2594 2595 2596 2597 2598 2599 2600 2601 2602 2603 2604 2605 2606 2607 2608 2609 2610 2611 2612 2613 2614 2615 2616 2617 2618 2619 2620 2621 2622 2623 2624 2625 2626 2627 2628 2629 2630 2631 2632 2633 2634 2635 2636 2637 2638 2639 2640 2641 2642 2643 2644 2645 2646 2647 2648 2649 2650 2651 2652 2653 2654 2655 2656 2657 2658 2659 2660 2661 2662 2663 2664 2665 2666 2667 2668 2669 2670 2671 2672 2673 2674 2675 2676 2677 2678 2679 2680 2681 2682 2683 2684 2685 2686 2687 2688 2689 2690 2691 2692 2693 2694 2695 2696 2697 2698 2699 2700 2701 2702 2703 2704 2705 2706 2707 2708 2709 2710 2711 2712 2713 2714 2715 2716 2717 2718 2719 2720 2721 2722 2723 2724 2725 2726 2727 2728 2729 2730 2731 2732 2733 2734 2735 2736 2737 2738 2739 2740 2741 2742 2743 2744 2745 2746 2747 2748 2749 2750 2751 2752 2753 2754 2755 2756 2757 2758 2759 2760 2761 2762 2763 2764 2765 2766 2767 2768 2769 2770 2771 2772 2773 2774 2775 2776 2777 2778 2779 2780 2781 2782 2783 2784 2785 2786 2787 2788 2789 2790 2791 2792 2793 2794 2795 2796 2797 2798 2799 2800 2801 2802 2803 2804 2805 2806 2807 2808 2809 2810 2811 2812 2813 2814 2815 2816 2817

00 0

01 1

10 2

11 3

<28> IAMUX SOURCE (0=GPR/1=WBUS)

EBEA IWBUS DATA LTH

Indicates that the WBus was the input to the IBox AMux when an error was detected at the output of the IBox AMux.

<27> RESERVED MODE DETECTED

EBEA RSV MODE LTH

Indicates that an operand specifier attempted to use an addressing mode that is not allowed in the situation in which it occurred.

<26> IBOX BMUX PARITY ERROR

EBEA IBMUX PE LTH

Indicates that a parity error was detected at the output of the IBox BMux. The input to the BMux was either the IBuffer or the IMD Latch.

<25> INST BUFFER PARITY ERROR

EBEA IBUF PE LTH

Indicates that a parity error was detected on either the OPCode bytes (Byte 0 or Byte 1 in the IBuffer), or on the byte selected by the RMode Finder (IBGPR) during optimization.

<24> RLOG PARITY ERROR

EBEA RLOG PE LTH

Indicates that a parity error was detected while unwinding the RLog.

<23> IBOX AMUX PARITY ERROR

EBEA IAMUX PE LTH

Indicates that a parity error was detected at the output of the IBox AMux. The input to the AMux was either the WBus or a GPR. See: IBESR <30:29> and <28>.


<22> IBOX DRAM PARITY ERROR

EBEA IDRAM PE LTH

Indicates that a parity error was detected on the DRAM data.

- <21> IBOX CS PARITY ERROR
EBEA ICS PE LTH
Indicates that a parity error was detected on the IBox Control Store data.
- <20:16> RESERVED
- <15:08> EDMS REGISTER BITS <D15:D08>
See EBEA
- <15> RESERVED
- <14> ENABLE EBOX MICRO TRAP LOGIC
EBD3 EN ETRAP
Enables the EBox microtrap mechanism. This in turn allows CPU error reporting.
- <13:11> MICRO TRAP PRIORITY LEVEL
EBDE UTRP <2:0>
This field indicates the priority of the last microtrap request.
- | Priority | Microtrap Type |
|----------|---------------------------|
| 0 | EBox Read/Write Microtrap |
| 1 | OP Write Microtrap |
| 2 | IBox Error Microtrap |
| 3 | Misc Microtrap |
| 4 | Fork Microtrap |
| 5 | IMD Read Microtrap |
| 6 | ID Read Microtrap |
| 7 | STRING Read Microtrap |
- <10> OPBUS SOURCE (0=ID/1=IMD)
EBD5 SRC IMD LVL3
This bit is only valid when IBESR <09:08> = 3. When set, this bit indicates that the OPBus came from IMD register. When cleared, it indicates that the OPBus data came from ID register.
- <09:08> UOPSEL <1:0>
EBD5 UOPSEL <1:0>
This field indicates the OPBus data source.
- | <1:0> | Data Source |
|-------|---|
| 0 | IBox Register Select |
| 1 | Operand Source is EMD |
| 2 | Operand Source is IBUFFER |
| 3 | Operand Source is IMD or ID Registers
(See Bit 10 above) |
- <07:03> RESERVED
- <02> ESA VALID
This bit is set by the EHM if the IBox ESA VALID bit is set.
- <01> ISA VALID
This bit is set by the EHM if the IBox ISA VALID bit is set.
- <00> CPC VALID
This bit is set by the EHM if the IBox CPC valid bit is set.

VAX 8600/8650 REGISTER DESCRIPTION IBGPR



<03:00> IBOX GPR ADDRESS

Lines are generated by the IBOX (Print:ICBB) and are distributed to the EBOX (Print:EDPC) and the FBOX (Print:FA12) when OPTIMIZATION is done. Note that the IBGPR lines are also latched and distributed internally within the IBOX to perform a variety of functions.

NOTE

1. The IBGPR register (read only) is accessed via the following console command:

>>>EXAM IBGPR<cr>
2. The IBGPR address lines are also available on the SDB visibility bus (all signals are generated on ICBB and are terminated on the FBA module).


IBGPR BIT	SIGNAL NAME	SDB SYMBO	B/P PIN(ICB)
3	ICB IBGPR 3 H	V\$0187	AC12A60
2	ICB IBGPR 2 H	V\$0108	AC12A54
1	ICB IBGPR 1 H	V\$0118	AC12A71
0	ICB IBGPR 0 H	V\$0119	AC12A60

VAX 8600/8650 REGISTER DESCRIPTION

ICCS

ICCS
IPR 18

INTERVAL CLOCK CONTROL AND STATUS REGISTER




MAI-12001

- <31> **ERROR**
Whenever ICR overflows, if INT is already set, then ERR is set. Thus, ERR indicates a missed clock tick. An attempt to set this bit via MTPR clears ERR.
- <30:08> **MBZ**
Must be zero.
- <07> **INTERRUPT**
Set by hardware every time ICR overflows. If IE is set then an interrupt is also generated. An attempt to set this bit via MPTR clears INT, thereby reenabling the clock tick interrupt (if IE is set).
- <06> **INTERRUPT ENABLE**
When set, an interrupt request at IPL 18(16) is generated every time ICR overflows (INT is set). When clear, no interrupt is requested. Similarly, if INT is already set and the software sets IE, an interrupt is generated [i.e., an interrupt is generated whenever the function (IE and INT) changes from 0 to 1]. At bootstrap time this bit is cleared.
- <05> **SIGNAL**
A write only bit. If RUN is clear, each time this bit is set, ICR is incremented by one.
- <04> **TRANSFER**
A write only bit. Each time a 1 is written to this bit, NICR is transferred to ICR.
- <03:01> **MBZ**
Must be zero.
- <00> **RUN**
When set, ICR increments each microsecond. When clear, ICR does not increment automatically. At bootstrap time, RUN is cleared.


VAX 8600/8650 REGISTER DESCRIPTION

ICR
ICR
IPL
ISASAV



<31:00> INTERVAL COUNT

The interval register is a read only register incremented once every microsecond. It is automatically loaded from NICR upon a carry out from bit 31 (overflow) which also interrupts at IPR 18(16) if the interrupt is enabled.




<31:05> MBZ

Must be zero.

<04:00> INTERRUPT PRIORITY LEVEL

Writing to the IPL with the MTPR instruction will load the processor priority field in the Program Status Longword (PSL), that is, PSL <20:16> is loaded from IPL <04:00>. Reading from IPL with the MFPR instruction will read the processor priority field from the PSL. On writing IPL, bits <31:05> are ignored, on reading IPL bits <31:05> are returned as zero.




<31:00> CURRENT PC FOR ADDRESS CALCULATION UNIT

This register contains the address (Macro PC) of the instruction that the IBox Address Calculation Unit is currently processing.


VAX 8600/8650 REGISTER DESCRIPTION

ISP
IVASAV
KSP




<31:00> VIRTUAL ADDRESS OF TOP OF STACK

This is the stack pointer for the interrupt stack. Unlike the stack pointer for process context stacks, which are stored in the hardware PCB, the interrupt stack pointer is stored in an internal register. Refer to PSL to determine which SP is currently being used. The ISP is in use if we are in Kernel mode and if PSL <26>, Interrupt Stack, is set.



IVASAV (IBox Virtual Address Save) - This register contains the last virtual address that was calculated by the Address Calculation Unit and acknowledged by the MBox with PA ACK. Therefore, IVASAV will contain the Virtual Address associated with either the current operand fetch cycle, or the current result store cycle.

<31:00> Last Virtual Address used by the IBox for either an Operand Fetch or Result Store.



<31:00> KERNEL STACK POINTER

Contains the stack pointer to be used when the current access mode field in the PSL is 0 and IS = 0 (Kernel Mode).

VAX 8600/8650 REGISTER DESCRIPTION


USART RECEIVE HOLDING REGISTER

USART STATUS REGISTERS

USART RECEIVE HOLDING REGISTER

175400 LRHR LOCAL RECEIVE HOLDING REGISTER
 175410 RRHR REMOTE RECEIVE HOLDING REGISTER
 175420 ERHR EMM RECEIVE HOLDING REGISTER

CL10,11



NOTE:
ALL BITS READ ONLY

MR-14100


<07:00> RECEIVED CHARACTER

When a complete character has been received on the USART serial line, it is moved from the USART shift register to the USART Receive Holding Register.

USART STATUS REGISTER

175402 LRSR LOCAL READ STATUS REGISTER (USART)
 175412 RRSR REMOTE READ STATUS REGISTER (USART)
 175422 ERSR EMM READ STATUS REGISTER (USART)

CL10,11



NOTE:
ALL BITS READ ONLY

MR-14100

<07:06> RESERVED

<05> FRAMING ERROR

Indicates that the character just received was not framed by the correct number of stop bits.

<04> OVERRUN ERROR

Indicates that a data character was not read by the T-11 program before the next one was assembled and loaded in the Receive Holding Register.

<03> PARITY ERROR

Indicates that bad parity was received.

<02> DEVICE STATUS CHANGE

The transmitter has completed serialization of character in Transmit Holding Register, or DSR or DCD have changed state.

<01> RECEIVED READY


RXRDY indicates to the T-11 program that it may read the USART holding register to take the data.

<00> TRANSMIT READY

TXRDY is set by the USART, signifying that the USART is ready to accept the character. This generates a T-11 interrupt request.

VAX 8600/8650 REGISTER DESCRIPTION
USART TRANSMIT HOLDING REGISTERS

USART TRANSMIT HOLDING REGISTER
175401 LTHR LOCAL TRANSMIT HOLDING REGISTER
175411 RTHR REMOTE TRANSMIT HOLDING REGISTER
175421 ETHR EMM TRANSMIT HOLDING REGISTER



NOTE:
ALL BITS WRITE ONLY

MAP.14.101

The T-11 program loads the character in the USART Transmit Holding Register. TXRDY is negated. When the character previously loaded (if any) has been transmitted, the character is moved to an internal shift register and transmitted on the serial line. When the character is moved to the shift register, TXRDY is again asserted, indicating that the transmit holding register is empty and ready to accept another character.

VAX 8600/8650 REGISTER DESCRIPTION USART COMMAND REGISTERS

USART COMMAND REGISTER
175407 LWCR LOCAL WRITE COMMAND REGISTER
175417 RWCR REMOTE WRITE COMMAND REGISTER
175427 EWCR EMM WRITE COMMAND REGISTER
175406 LRCR LOCAL READ COMMAND REGISTER
175416 RWCR REMOTE READ COMMAND REGISTER
175426 ERCR EMM READ COMMAND REGISTER

CL10.11

07	06	05	04	03	02	01	00
SUBMODE	REQUEST TO SEND	ERROR RESET	SEND BREAK CHARAC- TER	RECEIVE ENABLE	DATA TERMINAL READY	TRANSMIT ENABLE	

MR. 14102

NOTE: One address is used to write a command register and another address to read the same register.

<07:06> SUBMODE

00 = Normal
01 = Auto Echo
10 = Local Loopback
11 = Remote Loopback

<05> REQUEST TO SEND (RTS)

For the remote line only, Request To Send (RTS) is asserted in the USART Command Register. This signal is set by the T-11 program when it is ready to place or answer a call on the remote line.

<04> ERROR RESET (ER)

The setting of this bit clears the Parity Error, Overrun Error and Framing Error bits (Read Status Register bits <05:03>). Error Reset must be performed when Receive Enable is set.

<03> SEND BREAK CHARACTER (SBRK)

This is a programmable bit and when set, the output of the USART transmitter, TX DATA, goes to a logical zero state. This condition will generate a continuous spacing signal to be asserted. When this flag is cleared, normal operation is exercised.

<02> RECEIVE ENABLE (RXEN)

0 = Disable
1 = Enable

<01> DATA TERMINAL READY (DTR)

For the remote line Data Terminal Ready (DTR) is asserted in the USART Command Register. The T-11 sets DTR when the remote line is enabled by the switch on the system control panel. DTR enables the modem to receive a call and indicates that the USART is ready to accept data.

<00> TRANSMIT ENABLE (TXEN)

0 = Disable
1 = Enable

VAX 8600/8650 REGISTER DESCRIPTION
USART MODE REGISTERS, LOW ORDER

USART MODE REGISTER	LOW-ORDER MODE REGISTER BITS
175405 LWMR LOCAL WRITE MODE REGISTER	(FIRST ACCESS)
175415 RWMR REMOTE WRITE MODE REGISTER	CL10,11
175425 EWMR EMM WRITE MODE REGISTER	
175404 LWMR LOCAL READ MODE REGISTER	
175414 RWMR REMOTE READ MODE REGISTER	
175424 EWMR EMM READ MODE REGISTER	

07	06	05	04	03	02	01	00
NUMBER OF STOP BITS	EVEN PARITY	ENABLE PARITY	CHARACTER LENGTH				MODE AND BR FACTOR

APR 14 1983

<07:06> STOP BITS

00 = Invalid
*01 = 1 Stop Bit
11 = 2 Stop Bits

<05> EVEN PARITY

<04> ENABLE PARITY

<03:02> CHARACTER LENGTH

00 = 5 Bits
01 = 6 Bits
*11 = 8 Bits

<01:00> MODE BR FACTOR


00 = Sync.1X
*01 = Async.1X
11 = Async.64X

NOTE: * = NORMALLY USED VALUE

VAX 8600/8650 REGISTER DESCRIPTION

USART MODE REGISTERS, HIGH ORDER

USART MODE REGISTER			HIGH-ORDER MODE REGISTER BITS (SECOND ACCESS) CL10, 11		
175405	LWMR	LOCAL WRITE MODE REGISTER			
175415	RWMR	REMOTE WRITE MODE REGISTER			
175425	EWMR	EMM WRITE MODE REGISTER			
175404	LRMR	LOCAL READ MODE REGISTER			
175414	RRMR	REMOTE READ MODE REGISTER			
175424	ERMW	EMM READ MODE REGISTER			



NOTE:
ALL BITS ARE READ/WRITE

<07:06> RESERVED

<05> TRANSMIT CLOCK

Selects the source clock for the transmit frequency where:

- 1 = Internal clock
- 0 = External clock

If set to 0, External clock, the External USART clock is used as transmit frequency. The baud rate is selected via bits <03:00>. The External baud rate must be the same for transmit and receive. If set to 1, Internal clock, the clock source is Internal (pin 9 of USART). The standard setting is Internal clock for CTY and E-ETERM, External clock for RTY.

<04> RECEIVE CLOCK

Selects the source clock for the receive frequency where:

- 1 = Internal clock
- 0 = External clock

If set to 0, External clock, the External USART clock is used as receive frequency. The baud rate is selected via bits <03:00>. The External baud rate must be the same for transmit and receive. If set to 1, Internal clock, the clock source is Internal (pin 9 of USART). The standard setting is Internal clock for CTY E-ETERM, External clock for RTY.

VAX 8600/8650 REGISTER DESCRIPTION
USART MODE REGISTERS, HIGH ORDER

<03:00> INTERNAL BAUD RATE

If Internal baud rate is selected via bits <05> or <04>, bits <03:00> determine the frequency (baud rate).

BITS <03:00>	BAUD RATE
0000	50
0001	75
0010	110
0011	134.5
0100	150
0101	300
0110	600
0111	1200
1000	1800
1001	2000
1010	2400
1011	3600
1100	4800
1101	7200
1110	9600
1111	19.2K

The default setting for these bits are as follows:

CTY: 3E(X)
ETERM: 3E(X)
RTY: 07(X)

NOTE

Each of the USARTS on the console module has a 16-bit mode register, one for each port: local port (CTY), remote port (RTY) and the EMM port (ETERM). Access to this register is achieved by addressing an 8-bit register twice. The first access addresses the low-order bits <07:00> and the second access addresses the high-order bits <15:08>.

VAX 8600/8650 REGISTER DESCRIPTION


MAPEN

MCCTL

MAPEN

IPR: 38

MEMORY MANAGEMENT ENABLE



Memory Management Control - The action of translating a virtual address to a physical address is governed by the setting of the MEMORY MAPPING ENABLE (MME) bit in the MAPEN Internal Processor Register.

<31:01> RESERVED

<00>


MME

When MME, the MEMORY MAPPING ENABLE BIT is set to 1, memory management is enabled. When MME is set to 0, memory management is disabled. At processor initialization time, MAPEN is initialized to 0.

MCCTL

IPR: 46

MBOX MCC CONTROL REGISTER



<31:14> On a write to the MBox (MTPR) these bits must be zero, but on a read (MFPR) they will be undefined.

<13:12> DIAGNOSTIC WRITE LENGTH/STATUS <1:0> H

When the MBox is using the ABUS in diagnostic mode, the bits stored in these locations are substituted for the normal data length/status bits when writing to the I/O adapter register file. They are used for diagnostics only.

<11:08> DIAGNOSTIC WRITE COMMAND/MASK <3:0> H

When the MBox is using the ABUS in diagnostic mode, the bits stored in these locations are substituted for the normal command/mask bits when writing to the I/O adapter register file. They are used for diagnostics only.

<07:02> RESERVED

<01>

SLOW ARRAY ACCESS MODE

When set, memory access time from the array is repeatable (and slow). This is for diagnostic reasons. The access time is greater than the normal access time plus the refresh time.

<00>

INHIBIT MEMORY OVERLAP

When set, memory overlap is inhibited [i.e., not starting another array read unless the data from the previous array read has been extracted from the array register file (DC109)]. This is needed if the clock is to be stopped and continued. This is also used to do single step on DMA transfers by affecting DMA done.

VAX 8600/8650 REGISTER DESCRIPTION
MCSRO

MCSRO 176040		MISCELLANEOUS CONTROL/STATUS REGISTER 0						CL09 (W, CL08 (R))	
07	06	05	04	03	02	01	00		
HOLD STATE RESET	CL04 CLK PE	FORCE PE	ENABLE PROM S1	ENABLE MAP	FLAGS ENABLE	ENABLE TOY INTERRUPT	ENABLE T-11 INTERRUPT		

NOTE: READ/WRITE

SEP 1983

- <07> **HOLD STATE RESET**
CL09 HOLD STATE RESET H
Initialize the VAX CPU but do not clear error status information.
- <06> **CL04 CLK PE**
CL04 CLK PE H
Output of parity error F/F. Clocks PECAS and PERAS registers during normal operation. When in the test bench, the T-11 may set CL09 DIAG TRIGGER, which may be used as a scope trigger by console diagnostics.
- <05> **FORCE PARITY ERROR**
CL09 FORCE PE H
Write bad parity in the T-11 RAM.
- <04> **ENABLE PROM S1**
CL09 ENA PROM S1
Select upper 4KB of PROM.
- <03> **ENABLE MAP**
CL09 ENA MAP H
Enable virtual to physical address translation of the T-11 RAM address by paging (mapping) RAM.
- <02> **FLAGS ENABLE**
CL09 ENA CPU FLAGS H
Enable console (T-11) interrupt requests generated by the VAX CPU. Enable VAX CPU interrupt requests generated by the console.
- <01> **ENABLE TOY INTERRUPT**
CL09 ENA TOY INTR H
Enable T-11 interrupt requests generated by Time of Year Clock every 1 ms.
- <00> **ENABLE T-11 INTERRUPT**
CL09 ENA TOY INTR H
Enable T-11 interrupt requests to the T-11 program.

VAX 8600/8650 REGISTER DESCRIPTION
MCSR1

MCSR1
176041

MISCELLANEOUS CONTROL/STATUS REGISTER 1

CL09 (W), CL08 (R)

07	06	05	04	03	02	01	00
RTERM INTERRUPT ENABLE	RTERM DSRS	SIMULATE CPU ERROR	CSM REQUEST ENABLE	CPU RESET	MEM BUS ENABLE	ABUS ADAPTOR INIT- LIZE	ENABLE QMAINT CLOCK

MM-10021

- <07> RTERM INTERRUPT ENABLE
CL09 TERM IE H
Enable T-11 interrupt request generated by remote line receiver ready condition or change in modem status.
- <06> RTERM DSRS
CL09 RTERM DSRS H
Enable some remote line modems to operate at different (split) transmit and receive baud rates.
- <05> SIMULATE CPU ERROR
CL09 SIM CPU ERROR H
Force T-11 interrupt request normally generated by VAX CPU control store parity error.
- <04> CSM REQUEST ENABLE
CL09 CSM REQ ENA H
Request that the VAX CPU microprogram in the EBox enter console support microcode.
- <03> CPU RESET
CL09 CPU RESET
Initialize VAX CPU (master reset).
- <02> MEMORY BUS ENABLE
CL09 MEM BUS ENABLE H
Enable main memory array to respond to read/write requests by the MBox.
- <01> ABUS ABORT INITIALIZE
CL09 ABUS ADAPT INIT H
Initialize SBIA and ABUS devices.
- <00> ENABLE QMAINTENANCE CLOCK
CL09 ENA QMAINT CLK H
Enable alternate clock source (SDB clock) for testing of QBus RPLY timeout counter.

VAX 8600/8650 REGISTER DESCRIPTION
MCSR2

MCSR2
175042

MISCELLANEOUS CONTROL/STATUS REGISTER 2
CL08

07	06	05	04	03	02	01	00
SYSTEM AC FAULT	CPU ALIVE	RPLY TIMEOUT	-ABUS REQUEST <3:0> H				ABUS DEAD INTERRUPT
R/W	R/W	R	3	2	1	0	R/W

MM-14038

- <07> SYSTEM AC FAULT
CL09 SYS AC FAULT H
Latched AC LO indication from EMM. Bit may be written to simulate AC LO for test purposes.
- <06> CPU ALIVE
CL09 CPU ALIVE H
VAX CPU executing another instruction. Set by EBox at IRD. Bit is cleared and rechecked periodically to determine that VAX CPU program is running.
- <05> REPLY TIMEOUT
CL30 RPLY TIMEOUT H
RPLY was not received on QBus during QBus read/write operation. T-11 program is interrupted.
- <04:01> -ABUS REQUEST <3:0> H
-CL09 ABUS REQ H <03:00>
VAX CPU restart requests from system's four possible ABUS adapters. A restart request originates from another (CI connected) processor. Bits are asserted when in the zero state.
- <00> ABUS DEAD INTERRUPT
CL09 ABUS DEAD INTERRUPT H
Latched VAX CPU restart request from one or more of the system's four possible ABUS adapters (such as the OR of bits <04:01>). The console T-11 <01> program is interrupted. Bits may be written to simulate ABUS DEAD for test purposes.

VAX 8600/8650 REGISTER DESCRIPTION MCSR3 (READ)

MCSR3
176043

MISCELLANEOUS CONTROL/STATUS REGISTER 3 (READ)
CL08

07	06	05	04	03	02	01	00
-CPU AC LO H	CONSOLE IDENTITY			-- ERROR H		-CPU CONTROL STORE PE H	
	0	1	2	2	1	0	

NOTE: READ

MAP 1-10817

<07> -CPU AC LO H
-EMM CPU AC LO H
AC LO is unlatched from the the EMM. Indicates that AC power has dropped, but not enough to cause loss of DC power. DC LO, QCSR3, indicates that software operation is unpredictable.

<06:04> CONSOLE IDENTITY <0:2>
CL09 ID <0:2> H
Console identity bits programmed at backplane to establish access privileges on EMM multi-drop bus. These bits originate from backplane jumpers (see CL12 and drawing BD-L0201-0-BPC). Currently these bits are unused and read as 0's (jumpers out).

<03:01> -ERROR <2:0> H
-CL09 ERROR <2:0> H
Complement of error code from EBox specifying type of control store error condition in the VAX CPU. These signals originate on EBE3 and are transmitted to the console module (print CL09). Used by the console for VAX CPU CS error correction and reporting:

0-MBOX CS PE	3-FBOX DRAM PE	6-EBOX CS PE
1-FBOX MULTIPLIER CS PE	4-IBOX DRAM PE	7-NO ERROR
2-FBOX ADDER CS PE	5-IBOX CS PE	

<00> -CPU CONTROL STORE PARITY ERROR H
CL09 CPU CS PE L
This bit indicates that a CPU control store parity exists and will interrupt the console program at vector 110. This signal is asserted if any of the control store parity errors specified by bits <03:01> exist, or if SIMULATE CPU ERROR, MCSRI bit <05> is set. The latter is for diagnostic purposes only.

VAX 8600/8650 REGISTER DESCRIPTION
MCSR3 (WRITE)

MCSR3
176043

MISCELLANEOUS CONTROL/STATUS REGISTER 3 WRITE

07	06	05	04	03	02	01	00
SET TSTRT	SET PE L	CLEAR TIMEOUT	CLEAR TSTRT	SET TIMEOUT	SET STOP CLOCK L	CLEAR TOY INTERRUPT L	CLEAR PE L

NOTE: WRITE

MS-10814

A write to MCSR3 enables a decode of DAL<07:05> to provide 8 diagnostic functions.

<07:05> FUNCTION


The following functions/operations are performed when the bits in this field equal an octal 7, 6, 5, 4, 3, 2, 1, or 0. Note: Only one function can be performed at a time.

- 7 SET TSTRT L
Set TSTRT (CMISC<6>), simulates the console reboot request by a VAX CPU. Generates a T-11 interrupt request.
- 6 SET PARITY ERROR L
Sets the parity error indicator to simulate detection of bad parity in the T-11 RAM. Generates a T-11 interrupt request.
- 5 CLEAR TIMEOUT L
Clears the Reply Timeout (MCSR2<5>) and the corresponding T-11 interrupt request.
- 4 CLEAR TSTRT L
Clears TSTRT (CMISC<6>) and the corresponding T-11 interrupt request.
- 3 SET TIMEOUT L
Set the Reply Timeout (MCSR2 <5>). Simulates a Reply Timeout condition on the QBus. Generates a T-11 interrupt request.
- 2 SET STOP CLOCK L
Stop generation of SDB clocks.
- 1 CLEAR TOY INTERRUPT L
Clear the T-11 interrupt request generated by the Time Of Year Clock.
- 0 CLEAR PARITY ERROR L
Clear the T-11 interrupt request generated by the T-11 RAM parity error.

<04:00> RESERVED

VAX 8600/8650 REGISTER DESCRIPTION

MDC1L



- <31:15>** On a write to the MBox (MTPR) these bits must be zero, but on a read (MFPR) they will be undefined.
- <14>** **INHIBIT DATA PARITY ERROR CHECK**
When Set, MD BUS WRITE PARITY ERR and CACHE DATA PARITY ERR errors will not be detected or reported by the MBox.
- <13>** **DIAGNOSTIC CHECK RAM READ**
When set, check bits will be read from the selected Cache RAMs. This function will only be used by diagnostics.
- <12>** **RESERVED**
- <11>** **INHIBIT BAD DATA FLAG**
When set, will inhibit the bad data code check bits being generated. See MDECC for a description of the BAD DATA CODE.
- <10>** **DISABLE ECC ON DATA**
When set, ensures that no correction takes place on the data. Error information will still be logged and reported unless INHIBIT ERROR REPORTING bits are set in register MERG.
- <09>** **ENABLE INVERT REGISTER**
When set, allows the data stored in the DATA CHECK BIT INVERT REGISTER to complement the check bits generated on any write data. The check bit invert bits are in register MDECC. Also allows bad ABUS parity to be generated for DMA array reads if MDECC <0> had been written.
- <08>** **ENABLE CACHE BYTE PARITY ERROR**
When set, allows bad byte parity to be written into Cache from a CP request as determined by CACHE PERR <03:00> bits. Once this bit is enabled, the MBox will invert parity for one MBox request. After the first request the bit will stay set but no more parity inversions will take place. To enable a second parity inversion the ENA CACHE BYTE PE bit must be reset, then set.


To invert byte parity in Cache, the ENA CACHE BYTE PERR bit must be set along with ENA CACHE PERR <03:00> and INH DAT PERR CHK. If the INH DAT PERR CHK is not set the MBox will detect parity errors on the incoming data. This function can be used to produce WRITE DATA PARITY ERRORS, REGISTER WRITE PARITY ERROR and ABUS DATA LW PARITY ERRORS on a CP write.
- <07:04>** **RESERVED**
- <03:00>** **ENABLE CACHE BYTE PARITY ERROR**
When set in conjunction with ENABLE CACHE BYTE PE, will generate even parity on byte <03:00> being written into the Cache during CPU longword writes. This is also used to generate single longword failures for CPU ABUS write.

VAX 8600/8650 REGISTER DESCRIPTION

MDECC

MDECC
(ESC 27-T17) IPR43

MBOX DATA ECC REGISTER



MDECC (MBox Data ECC Status Register) - This register is made up of three MBox registers; 70 (byte 2), 60 (byte 1), and 50 (byte 0).

<31:24> Reserved

<23:16> Source: MCDM (ECC) MBox Reg 70 (DATA ECC ERROR)
Held at: ECC4 ERR HLD and T2D

<23> Reserved

<22> BAD DATA SYNDROME DETECTED
ECC4 BD ERR (MCDM)

The bad data bit is Xored into the ECC check bit generation whenever "known" bad data is written into either the cache or the array. A read to that location will result in the detection of a Bad Data code and cause this bit to be set. Note that to read check bits from cache a cache byte parity error must have been found to invoke the check bit read.

<21> SINGLE BIT ERROR

ECC4 SB ERR (MCDM)

The data word read from cache or main memory had a single bit (ECC correctable) error.

<20> DOUBLE BIT ERROR

ECC4 DB ERR (MCDM)

The data word read from cache or main memory had a double bit error or a detectable multiple bit error.

<19> ADDRESS PE

ECC4 AP ERR (MCDM)

The word fetched from memory was either written or read from the wrong location. The ECC code indicates that the parity of the address written and the parity of the address read from are different. ECC is generated over the data bits and a parity bit computed over the physical address bits <29:04>.

<18:16> 110

ECC2 DATA <33:32> (MCDM)

These bits should always return as a binary 110. Therefore, this field position can be used as a key to confirm the location of MDECC in a Stack Frame.

<15:08> Source: MCDM (ECC) MBox Reg 60 (DATA SYNDROME)
Held at: ECC4 ERR HLD

<15> INVERT ABUS LONGWORD PARITY

ECC3 LWP INVERT REG (MCDM)


When this bit is set, and bit <01> in Register 10 (Data Control 2) is set the ECC MCA will generate bad ABUS longword parity.

VAX 8600/8650 REGISTER DESCRIPTION
MDECC

MDECC

(ESC 27-T17) IPR43

MBOX DATA ECC REGISTER



MM-12935

<14:09> ECC DATA CORRECTION SYNDROME

ECC3 SYN REG <32:1> (MCDM)

ECC3 SYN REG <32:1> (MCDM) - This field corresponds to the syndrome generated by the ECC chip and indicates the failing bit number.

SYNDROME (MSB) 70 0421000 6666665555444433332222111111
IN OCTAL (LSB) 07 0000421 65432132654654326543265432654321

DATA BIT (MSB) BA CCCCCC 332222222221111111110000000000
(LSB) DP 0654321 10987654321098765432109876543210

<08> Reserved

<07:00> Source: MCDM (ECC) MBox Reg 50 (DATA CHECK INVERT)

<07:01> DIAGNOSTIC CHECK BIT INVERT <CP:C1>

ECC3 <CP:C1> INVERT REG (MCDM)

When set the corresponding ECC check bits will be inverted.


<00> INVERT ARRAY BUS LONGWORD PARITY

ECC3 LWP INVERT REG (MCDM)

When this bit is set, and bit <01> in Register 10 (Data Control 2) is set, then the longword parity generated on ARRAY BUS data will be inverted when the ECC MCA is the check mode. This bit is write only and is read via bit <15> in MDECC (MBox Register 60).

MEAR

(ESCRATCH LOC: 2A - T1A)

MEMORY ERROR ADDRESS REGISTER

MR-12612

This is a copy of MAP1/3 (ADA/ADB) MBOX REG 7C (ERROR ADDR). It contains the physical address present at the output of the PA Mux when the MBox detected an error. Interpreting this address depends on the MBox Data Destination Code (MSTAT1 <31:30>) and the MBox Cycle Type (MSTAT1 <29:26>).


1. CP initiated (Non I/O) Read/Write Operations - MEAR will contain the address of the longword that was associated with the error unless:

CP REFILL or WRITEBACK - (The CP request caused either a Cache Refill Cycle, or a Cache Writeback Cycle). Then MSTAT1 <25:24> (Longword Count <A3:A2>) must be used to determine the address of the longword that was associated with the error. If MSTAT1 <25:24> equal MEAR <03:02> then MEAR contains the address of the longword associated with the error. Otherwise, you must substitute MEAR <03:02> with MSTAT <25:24> to determine the address.

2. CP Initiated I/O Read/Write Cycles - MEAR is not valid for any CP initiated I/O Cycles.
3. ABUS Initiated Read/Write Cycles - MEAR will contain the starting address of the data to be processed (i.e., longword, quadword, or octaword). MSTAT1 <25:24> (Longword Count <A3:A2>) must be used to determine the address of the longword that was associated with the error. If MSTAT1 <25:24> equal MEAR <03:02> then MEAR contains the address of the longword associated with the error. Otherwise, you must substitute MEAR <03:02> with MSTAT <25:24> to determine the address.

MEDR

(ESCRATCH LOC: 2B - T1B)


MEMORY ERROR DATA REGISTER

MR-12613

This is a copy of MCD1/3 (MDP) MBOX REG 78 (DATA ERROR). It is only valid (held) for ABUS Parity Errors (DMA Data PES and CPU Read PES only), ABUS BDC Errors, and CPU Write PES. It contains the data word latched in the MCD MCAs when the error occurred.

VAX 8600/8650 REGISTER DESCRIPTION


MENA



If these bits are reset, they only prevent the status bits from being latched, they do not prevent the error from being reported, the trap still occurs. If these bits are reset, software will see what appears to be spurious traps or interrupts if the corresponding error is detected.

- <31:24> On a write to the MBox (MTPR) these bits must be zero, but on a read (MFPR) they will be undefined.
- <23:16> **MBOX STATUS REPORT ENABLE**
Enable value = F8 HEX.
- <23> CPR B PARITY ERROR
- <22> CPR A PARITY ERROR
- <21> ABUS DATA PARITY ERROR
- <20> ABUS CONTROL PARITY ERROR
- <19> ABUS ADDRESS PARITY ERROR
- <15:12> RESERVED
- <11:08> **MBOX TB ERROR REPORT ENABLE**
- <11> VALID PARITY ERROR
- <10> PTE B PARITY ERROR
- <09> PTE A PARITY ERROR
- <08> TAG PARITY ERROR
- <07:00> **MBOX DATA ERROR REPORT ENABLE**
- <07> WR BYTE 3 PARITY ERROR
- <06> WR BYTE 2 PARITY ERROR
- <05> WR BYTE 1 PARITY ERROR
- <04> WR BYTE 0 PARITY ERROR
- <03> CACHE DATA PARITY ERROR
- <02:01> RESERVED
- <00> CACHE BYTE WRITE PARITY ERROR

VAX 8600/8650 REGISTER DESCRIPTION MERG



MERG (MBox Error Generation Register) - This register is made up of MBox registers 18 (byte 1) and 14 (byte 0).

<31:16> Reserved

<15:08> Source: MCCJ (CRB) MBox Reg 18 (MCC CONTROL 3)
Note: This field is set by loading the Control Register on CRB4.

<15:13> Reserved

<12> INHIBIT DMA REQUESTS
MCCJ INH DMA REQ
When set, the Mbox will not honor any DMA requests.

<11> GENERATE BAD ABUS CMD/MASK PARITY
MCCJ CMD BAD PAR
When set, ABus Command/Length and ABus Mask/Status will be transferred with even parity.

<10> INHIBIT ARRY SBE REPORTS
MCCJ INH ARY CORR REP
When set, this bit prevents the MBox from reporting ECC correctable errors. The errors will still be corrected as usual.

<09> IOA DIAG IN PROG
MCCJ IOA DIAG IN PROG
When set, the Abus command/mask field and length/status lines are driven from MCC CONTROL REGISTER 1C <03:00>.

<08> MEMORY MGMT ENABLE
MCCJ MEM MAN EN
When set, memory management is enabled. All virtual references are then translated by the TB. When this bit is cleared, all references will be treated as physical and all TB parity error checking will be disabled.

<07:00> Source: MAPP (REG) MBox Reg 14 (ADDR CONTROL 2)


<07:06> Reserved

<05> ADDRESS TB RAM VIA DIAG
MAPP ADR RAM DIAG
The effect of this bit depends on the cycle type:

Write TB - Causes the TB RAMs containing physical address bits <12:09> and selected by the IVA lines to be written instead of those selected by the EVA lines. Used for diagnostic testing of TB RAMs.

Read TB - Causes the contents of the TB RAMs containing physical address bits <12:09> and selected by the IVA to be read instead of those selected by the EVA lines. Used for diagnostic testing of TB RAMs.

VAX 8600/8650 REGISTER DESCRIPTION
MERRG



Diagnostic Read Cache Tag Address - Causes the written bit, written parity valid bits and cache tag parity to be read in place of the cache tag address bits. Used for diagnostic testing of the cache tag RAMs.

- <04:00> **GENERATE EVEN PARITY**
When set, the bits in this field will cause the MBox to generate even (bad) parity for the corresponding function.
- <04> **GENERATE EVEN PARITY TB TAG**
MCCJ EVN TB TAG PAR
When set, a write to the TB will result in the TB tag being written with even parity. A read to this TB location will result in a TB TAG parity error.
- <03> **GENERATE EVEN PARITY TB VALID**
MAPP GEN TB VAL ERR
When set, a write to the TB will result in the TB Valid bit field being written with even parity. A read to this TB location will result in a TB Valid parity error.
- <02> **GENERATE EVEN PARITY CACHE WBIT**
MAPP GEN EVN WBIT PAR
When set, parity for the cache written bit will be complemented before being written in the cache. A read to this Cache location will result in a Cache WBit parity error.
- <01> **GENERATE EVEN PARITY CACHE TAG**
MAPP GEN EVN TAG PAR
When set, the cache data address tag is stored with even parity during a cache write. A read to this Cache location will result in a Cache Tag parity error.
- <00> **GENERATE EVEN PARITY PHYSICAL ADDRESS**
GEN EVN PA PAR
The effect of this bit depends on the type of operation the MBox is performing.

Cache or Array Writes - When set, the address parity bit generated as part of the ECC character generation will be complemented. If the write was to the array this condition will be detected when that array location is next read. If the write was to the Cache a Cache Byte parity error will have to be forced by some other means in order to detect this condition.

DMA - The MBox will detect an ABus Address Parity Error.

CP to I/O Transfers - The ABus Adapter will detect bad address parity and set CP I/O Buffer Error.

TB Writes - Bad parity will be forced in both PTE A and PTE B.

VAX 8600/8650 REGISTER DESCRIPTION MSTAT1

MSTAT1
(ESCRATCH LOC 25 - T15)

MBOX STATUS WORD 1

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
MBOX DATA DESTINATION CODE		MBOX CYCLE TYPE				LONGWORD COUNT		CPR B PE	CPR A PE	ABUS DATA PE	ABUS CMD OR MASK PE	ABUS ADDRESS PE	ABUS CMD/ADDR CYCLE	IDA SELECT	
1	0	3	2	1	0	A3	A2							1	0
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
TB MISS	BLOCK HIT	CACHE 0 TAG MISS	CACHE MISS	TB VALID PE	TB PTE B PE	TB PTE A PE	TB TAG PE	CPU WRITE PE (BYTE IN ERROR)				CACHE DATA PE	CACHE 1 SELECT	CACHE DATA PE DURING BYTE WRT	
								B3	B2	B1	B0				

MM-12802

This register is made up of the following MBOX REGISTERS: 2C (byte 3), 28 (byte 2), 24 (byte 1), and 20 (byte 0).

<31:24> MBOX REGISTER 2C (MCC STATUS 1)
SOURCE: MCCJ (CRA) MBOX REG 2C (MCC STATUS 1)
ACCESS: Read Only
HELD AT: MCCJ TOT CYC ERR + T2

<31:30> MBOX DESTINATION CODE <1:0>
MCCC LAST DEST CP <1:0>
Indicates the destination code associated with the error.

Code Destination

```

-----
00  IBUF (IBox - Don't Load Tail Pointer)
01  IMD (IBox - FETCH/STORE Operand)
10  EMD (EBox - FETCH/STORE)
11  IBUF (IBox - FETCH - Load Tail Pointer)

```

<29:26> MBOX CYCLE TYPE
MCCD U CYC TYP <3:0>
Indicates the microword cycle type associated with the error.

CODE CYCLE	CODE CYCLE
-----	-----
0000 NOP	1000 ABUS
0001 READ REG	1001 CP REFILL
0010 WRITE REG	1010 INVAL TB
0011 WRITEBACK	1011 TB CYC
0100 ABUS ARRAY WRT	1100 CP ARRAY WRT
0101 DATA CORRECTION	1101 CP WRITE
0110 CLEAR CACHE	1110 CP READ
0111 TB PROBE	1111 ABUS REFILL

<25:24> LONGWORD COUNT
MCCJ WD CNT <03:02>
Indicates the longword that was being processed when the error was detected.

<23:16> MBOX REGISTER 28 (MCC STATUS 3)
SOURCE: MBox Register 28 (MCA: CRB) MCCJ (CRB) MBOX REG 28 (MCC STATUS 3)
ACCESS: Read Write
HELD AT: MCCM CYC ERR SUM + T0

<23> CYCLE PARAMETER RAM B PARITY ERROR
MCCC CPR PERR B
Indicates that a Cycle Parameter RAM B parity error was detected. The MBox response is unpredictable.

<22> CYCLE PARAMETER RAM A PARITY ERROR
MCCC CPR PERR A
Indicates that a Cycle Parameter RAM A parity error was detected. The MBox response is unpredictable.

VAX 8600/8650 REGISTER DESCRIPTION MSTAT1

MSTAT1
(ESCRATCH LOC 25 - T15)

MBOX STATUS WORD 1

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
MBOX DATA DESTINATION CODE		MBOX CYCLE TYPE				LONGWORD COUNT		CPB B PE	CPB A PE	ABUS DATA PE	ABUS CMD OR MASK PE	ABUS ADDRESS PE	ABUS CMD/ADR CYCLE	IOA SELECT	
1	0	3	2	1	0	A3	A2							1	0

15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
TB MISS	BLOCK HIT	CACHE 0 TAG MISS	CACHE MISS	TB VALID PE	TB PTE B PE	TB PTE A PE	TB TAG PE		CPU WRITE PE (BYTE IN ERROR)			CACHE DATA PE	CACHE 1 SELECT		CACHE DATA PE DURING BYTE WRIT
								B3	B2	B1	B0				

MAP - 1-1000

- <21> **ABUS DATA PARITY ERROR**
MCD3 ABUS DAT PERR
 Indicates that a longword parity error was detected on the ABUS Data Field during either a CP I/O READ or DMA WRITE Cycle.
- <20> **ABUS COMMAND OR MASK PARITY ERROR**
MCC4 ABUS CNTL PERR
 If bit <18> is set, this bit indicates that a parity error was detected on the command/length field during an ABUS Command Address cycle. If bit <18> is reset then this bit indicates that a parity error was detected on the Mask/Status Field during an ABUS Data Cycle.
- <19> **ABUS ADDRESS PARITY ERROR**
MAP2 ABUS ADR PERR
 Indicates that a parity error was detected on the Address Field associated with an ABUS Command Address Cycle.
- <18> **ABUS COMMAND/ADDRESS CYCLE**
MCCJ ABUS LD CMD
 Indicates that the MBox was executing a DMA Command Address cycle when an error was detected.
- <17:16> **IOA SELECT <01:00>**
MCC4 ABUS SEL <01:00>
 Indicates the ABUS Adapter that was selected when the error was detected.
- <15:08> **MBOX REGISTER 24 (ADDRESS STATUS)**
 SOURCE: MAPP (REG) MBOX REG 24 (ADDR STATUS)
 ACCESS: Read Only
 HELD AT: Self holding at T3
- <15> **TB MISS**
MAP3 TB HIT
 Indicates that the TB TAG (indexed by VA <16:09>) did not match VA <30:17> or the valid bit was not set. The MBox will send a Port Status of "A" (TB Miss) back to the EBox.
- <14> **BLOCK HIT**
MAPL BUF BLOCK HIT
 Indicates that either the Tag for Cache 0 or the Tag for Cache 1 matched PA <28:13>, at least one valid bit was set, and an I/O adapter was not selected.
- <13> **CACHE 0 TAG MISS**
MAP3 C0 TAG MAT
 Indicates that Tag in Cache 0 did not match PA <28:13>.


- <12> **CACHE MISS**
MAPL BUF CACHE HIT
Indicates that either PA <28:13> failed to match both the Cache 0 Tag and the Cache 1 Tag or, if a match did occur then the valid bit for the target word(s) was not set.
- <11> **TB VALID PARITY ERROR**
MAPP TB VAL ERR
Indicates that a parity error was detected on the valid bit when the TB was read. The MBox will send a Port Status of "8" (TB Error) back to the EBox.
- <10> **TB PTE B PARITY ERROR**
MAP3 PTE B PAR ERR
Indicates that a parity error was detected when the TB PTE RAM containing PA <24:09> was read. The MBox will send a Port Status of "8" (TB Error) back to the EBox.
- <09> **TB PTE A PARITY ERROR**
MAP4 PTE A PAR ERR
Indicates that a parity error was detected when the TB PTE RAM containing PA <29:25>, PROTECTION <D:A>, and MODIFY Bits were read. The MBox will send a Port Status of "8" (TB Error) back to the EBox.
- <08> **TB TAG PARITY ERROR**
MAP3 TB TAG PAR ERR
Indicates that a parity error was detected when the TB TAG RAMs were read. The MBox will send a Port Status of "8" (TB Error) back to the EBox.
- <07:00> **MCDU REGISTER 20**
SOURCE: MCDU REG 20 (DATA STATUS)
ACCESS: Read Only
HELD AT: MCCJ TOT CYC ERR + T3
- <07:04> **CPU WRITE (BYTE IN ERROR)**
UFO5 WR BYT <3:0> PERR (MCDU)
This field indicates that a parity error was detected on the data received from the CPU during a CPU write. Furthermore, this field indicates which byte(s) had the parity error.
- <03> **CACHE DATA PARITY ERROR**
UFO5 CACHE BYT PERR (MCDU)
Indicates that a byte parity error was detected on data read from cache during any Cache operation other than a CPU Byte Write Hit. Includes: CPU Read, DMA Read, Writeback, and DMA Masked Write.
- <02> **CACHE 1 SELECT**
MAPL CACHE 1 DAT
This bit indicates the Cache that was selected when the error was detected.
- <01> **ARRAY READ**
MCCJ ANY REFILL
Indicates that a Cache Refill was in progress when an error was detected.
- <00> **CACHE DATA PARITY ERROR DURING BYTE WRITE**
UFO5 CACHE BWRT PERR (MCDU)
Indicates that a Cache Data Parity Error was detected during a CP Byte-write Operation.

VAX 8600/8650 REGISTER DESCRIPTION

MSTAT2

MSTAT2
(ESCRATCH LOC 26 - T16)

MBOX STATUS WORD 2



This register is made up from the following MBox Registers: 54 (byte 2), 5C (byte 1), and 58 (byte 0).

<31:24> VMS SUPPLIED

This field is supplied by VMS and describes the array type selected at the time that the error occurred.

<31:28> RESERVED

<27> ARRAY TYPE CODE VALID

Indicates that the Array Type Code in bits <26:24> is valid.

<26:24> ARRAY TYPE CODE

Indicates the Array type that was selected when the error occurred.

CODE	ARRAY TYPE	CODE	ARRAY TYPE
000	Reserved	100	Reserved
001	16 Mb Array	101	Reserved
010	04 Mb Array	110	Reserved
011	64 Mb Array	111	Reserved

<23:21> RESERVED

<20:16> MBOX REGISTER 54

SOURCE: MAP9 (RAM) MBOX REG 54 (PAMM)

<20:16> PAMM CONFIGURATION CODE <A:1>

MAP9 PAMM CONF <A:1>

The Error Handling Microcode uses MEAR <29:20> to address the PAMM and then loads the five-bit PAMM code into this field. Normally this field will indicate the Array Module or I/O Adapter selected when the error was detected. If, however, the error involved a CP to I/O transfer, then this field will not be valid.

CODE	SELECTS	CODE	SELECTS
00	Array Slot 0	18	I/O Adapter 0
01	Array Slot 1	19	I/O Adapter 1
02	Array Slot 2	1A	I/O Adapter 2 (Not used)
03	Array Slot 3	1B	I/O Adapter 3 (Not used)
04	Array Slot 4	1C	Reserved
05	Array Slot 5	1D	Reserved
06	Array Slot 6	1E	Reserved
07	Array Slot 7	1F	Non-Existent Address
08 - 17	Reserved		

<15:08> MBOX REGISTER 5C

SOURCE: MCCJ (CRA) MBOX REG 5C (MCC STATUS 2)

<15> BYTE WRITE

MCC7 CP BYTE WRITE

Indicates that the MBox was servicing a byte write request.

- <14> ABUS BAD DATA CODE
MCC4 AB BAD DAT ERR
Indicates that the CP IO read data received from the ABus Adapter was marked as bad data via the ABUS Status Field.
- <13:12> DIAGNOSTIC ABUS LENGTH/STATUS FIELD
MCC4 LABUS STAT <1:0>
Indicates the state of the ABUS Length and Status lines during an I/O diagnostic operation.
- <11:08> DIAGNOSTIC ABUS COMMAND/MASK FIELD
MCC4 LABUS MSK <3:0>
Indicates the state of the ABUS Command and Mask lines during an I/O diagnostic operation.
- <07:00> MBOX REGISTER 58
SOURCE: MCCJ (CRB) MBOX REG 58 (MCC STATUS 4)
- <07> MULTIPLE ERROR
CRB5 MULT ERR (MCCJ)
Indicates that a second MBox error was detected before the EBox could read and clear the first error. Most or all of the information associated with the second error will be lost.
- <06> CACHE TAG PARITY ERROR
CRB5 CACHE TAG PERR (MCCJ)
Indicates that a parity error was detected in the address and valid bit portion of the Cache tag.
- <05> CACHE WRITTEN BIT PARITY ERROR
CRB5 TAG WRT PERR (MCCJ)
Indicates that a parity error was detected in the Cache tag Written Bit Field. The MBox handles the request as though the written bit was a one.
- <04> CACHE WRITTEN BIT SET
CRB5 WRITTEN (MCCJ)
Indicates that the cache written bit was set when an error was detected.
- <03> NON EXISTENT MEMORY
CRB5 NXM (MCCJ)
Indicates that either the memory request was to Non-Existent Memory or an I/O adapter attempted to address another I/O adapter. An MBox Fatal Error status code is sent to the EBox for CP initiated requests, and the DMA ERROR line is asserted to the I/O Adapter for I/O initiated requests. All writes are cancelled.
- <02> CP I/O BUFFER ERROR
CRB5 CP IO BUF ERR (MCCJ)
Indicates that the selected ABUS Adapter detected an error while processing a CPU request.
- <01> ABUS MEMORY LOCK
CRB5 LOCK LINE (MCCJ)
When set, indicates that the Memory Lock Line was being driven on the ABUS. This line may be driven by either the MBox or an ABUS Adapter.
- <00> RESERVED

VAX 8600/8650 REGISTER DESCRIPTION

NICR


POBR

POLR

NICR

IPR 19

NEXT INTERVAL COUNT REGISTER



MR-12001


<31:00> NEXT INTERVAL COUNT

The reload register is a write only register that holds the value to be loaded into ICR when it overflows. The value is retained when ICR is loaded. NICR is capable of being loaded regardless of the current values of ICR and ICCS.

POBR

IPR 08 (ESCRATCH LOCATION: E8)

PO BASE REGISTER



MR-12008

<31:02> PO BASE REGISTER

Contains the system virtual longword address of the start of Process 0 Page Table (POPT).


<01:00> MBZ

Must be zero.

POLR

IPR 09 (ESCRATCH LOCATION: E9)

PO LENGTH REGISTER



MR-12009

<31:27> MBZ

Must be zero.

<26:24> RESERVED

<23:22> MBZ

Must be zero.


<21:00> PROCESS 0 LENGTH REGISTER

Contains the size (in longwords) of Process 0 Page Table (POPT).

VAX 8600/8650 REGISTER DESCRIPTION


P1BR

P1LR



<31:02> **P1BR (PROCESS 1 BASE REGISTER)**
Base register for page table describing process virtual addresses from $2^{**}31-1$.


<01:00> **MBZ**
Must be zero.



<31:22> **MBZ**
Must be zero.

<21:00> **P1LR PROCESS 1 LENGTH REGISTER**
Length register for page table located by P1BR. Describes effective length of page table.

VAX 8600/8650 REGISTER DESCRIPTION PAMACC



NOTE

PAMACC and PAMLOC are used to write/read the PAMM. When writing the PAMM, the PAMM address and data is written to PAMACC with a MTPR. EBox micro code will carry out the write to the PAMM with an MBox register write. When reading, PAMLOC will be loaded with a MTPR PAMLOC, with the PAMM address to be read. The PAMM data will be gated from the PAMM to the PAMACC via MFPR PAMACC which will cause the EBox micro code to read the PAMM with an MBox register read.

<31:30> RESERVED

<29:20> PAMM ADDRESS

The PAMM address specifies the PAMM address to be read or written. It can specify one of 1024 possible entries in the PAMM. Each PAMM address, when mapped corresponds to a 1-MByte window of physical address space. The bit alignment in the PAMM address field corresponds to the bit alignment of the physical address.


<19:05> RESERVED

<04:00> CONFIGURATION CODE

CONF A,8,4,2,1 - CONF CODE <8:1> defines Memory Array Card, Adapter Code, or NXM. CONFIG CODE "A" set to one specifies on one mega-byte boundaries to inhibit writing data to Cache (used to inhibit writing I/O data to cache).

CONFIG CODE	SELECTS
00	Internal Array Slot 0 (Array Card 0)
01	Internal Array Slot 1
02	Internal Array Slot 2
03	Internal Array Slot 3
04	Internal Array Slot 4
05	Internal Array Slot 5
06	Internal Array Slot 6
07	Internal Array Slot 7 (Array Card 7)
08-17	Unused Codes
18	I/O Adapter 0
19	I/O Adapter 1
1A	I/O Adapter 2
1B	I/O Adapter 3
1C-1E	Unused Codes
1F	Non Existent Address

VAX 8600/8650 REGISTER DESCRIPTION
PAMLOC
PC




NOTE

See PAMACC. The PAMM is addressed on 1 Mega-byte boundaries, which is why the PAMM address starts at bit 20.

<31:30> RESERVED


<29:20> PAMM ADDRESS

<19:00> RESERVED



This register contains the PC to be used by VMS if it determines that an REI is possible. The contents of this register are determined by the Error Handling Microcode. Depending on the instruction in the pipeline that was associated with the error, this register will reflect the CPC, the ISA, or the ESA.

VAX 8600/8650 REGISTER DESCRIPTION
PCBB




<31:30> MBZ
Must be zero.


<29:02> PHYSICAL LONGWORD ADDRESS OF PCB
The Process Control Block Base (PCBB) Register points to the process control block for the currently executing process. The PCBB Register is an internal privileged register, which contains the physical longword address of the Process Control Block (PCB). The PCB itself contains all of the switchable process context collected into a compact form for ease of movement to and from the privileged internal registers.

<01:00> MBZ
Must be zero.

VAX 8600/8650 REGISTER DESCRIPTION PECAS/PERAS



NOTE: See description of PECAS register.




When a parity error is detected, the failing RAM address is stored in two 8-bit registers that may be read by the T-11. The Parity Error CAS (PECAS) register stores the high-order address byte. The Parity Error RAS (PERAS) register stores the low-order address byte.

In pass mode, the failing T-11 address (SAL<15:08> and RAS<7:00>) is stored in these registers.

In map mode, the failing virtual address (SAL<15:08> and RAS<7:00>) is stored. The physical address depends on the corresponding physical page number in the mapping RAM. The T-11 program must therefore calculate the physical address in order to determine which RAM location is bad.

In either case the Console prints an error message and awaits rebooting either by the operator or by the operating system. This is done by the PROM code.

VAX 8600/8650 REGISTER DESCRIPTION
PMR



<31:01> RESERVED

<00> PERFORMANCE MONITOR ENABLE

Performance Monitor Enable controls a signal visible to an external hardware performance monitor. This bit is set to identify those processes for which monitoring is desired and to permit their behavior to be observed without interference from other system activity.

Writing a 1 to bit <00> via an MTPR instruction will provide an ECL logic "high" output on pin AC9A07 of the CPU backplane (EBE5).

VAX 8600/8650 REGISTER DESCRIPTION PSL

PSL
(ESCRATCH LOC 2F - T1F)

PROCESSOR STATUS LONGWORD

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16		
COMPAT ABILITY MODE	TRACE PENDING			FIRST PART DONE	INTERRUPT STACK	CURRENT ACCESS MODE		PREVIOUS ACCESS MODE				INTERRUPT PRIORITY LEVEL					
						1	0	1	0			4	3	2	1	0	
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00		
								TRAP ENABLES				CONDITION CODES					
								DECIMAL OVERFLOW	FLOATING UNDERFLOW	INTEGER OVERFLOW	TRACE	NEGATIVE N	ZERO Z	OVERFLOW V	CARRY C		

MR-12927

<31> **COMPATIBILITY MODE**
When set, indicates that the processor is in PDP-11 compatibility mode. When clear, indicates that the processor is in native (VAX) mode.

<30> **TRACE PENDING**
This bit works in conjunction with Enable Trace bit <04>. If Enable Trace is set at the beginning of an instruction then the processor will automatically set this bit and thus cause a trap to the Trace Handler Routine.

The Trace Handler Routine will gather the desired information about the state of the system and REI (leaving the Enable Trace and Trace Pending bit alone). This will allow the next instruction to be traced. When the Trace Handler Routine wants to discontinue tracing it will clear both bits (Enable Trace and Trace Pending).

<29:28> **RESERVED**

<27> **FIRST PART DONE**
This bit is set by long instructions that can be interrupted during execution (e.g., Move String). The REI following the interrupt will continue the interrupted instruction.

<26> **INTERRUPT STACK**
When set, the processor is executing on the interrupt stack. Any mechanism that sets this bit also clears current mode and raises the IPL above 0. If an REI attempts to restore a PSL with IS=1 and non-zero current mode or zero IPL, a reserved operand fault is taken. When this bit is clear, the processor is executing on the stack specified by current mode. At bootstrap time, IS is set.

<25:24> **CURRENT ACCESS MODE**
This field indicates the access mode of the currently executing process, as follows: 0 - KERNEL, 1 - EXECUTIVE, 2 - SUPERVISOR, 3 - USER

<23:22> **PREVIOUS ACCESS MODE**
This field is loaded from the Current Access Mode by exceptions and CHMx instructions. It is cleared by interrupts, and restored by REI's.

<21> **RESERVED**

<20:16> **INTERRUPT PRIORITY LEVEL**
Indicates the current processor priority, in the range 0 to 1F (Hex). The processor will accept interrupts only on levels greater than the current level. At bootstrap time, IPL is initialized to 1F (Hex).

<15:08> **RESERVED**

VAX 8600/8650 REGISTER DESCRIPTION PSL


PSL
(ESCRATCH LOC 2F - T1F)

PROCESSOR STATUS LONGWORD

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
COMPAT ABILITY MODE	TRACE PENDING			FIRST PART DONE	INTERUPT STACK	CURRENT ACCESS MODE		PREVIOUS ACCESS MODE					INTERRUPT PRIORITY LEVEL		
						1	0	1	0		4	3	2	1	0
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
								TRAP ENABLES				CONDITION CODES			
								DECIMAL OVERFLOW	FLOATING UNDERFLOW	INTEGER OVERFLOW	TRACE	NEGATIVE N	ZERO Z	OVERFLOW V	CARRY C

MR-13007

- <07> **DECIMAL OVERFLOW TRAP ENABLE**
When this bit is set, it forces a decimal overflow trap after execution of an instruction that had a conversion error, or produced a result with a decimal overflow (e.g., numeric string, or packed decimal). When this bit is clear, no trap will occur, however, the condition code V bit will still set.
- <06> **FLOATING UNDERFLOW EXCEPTION ENABLE**
When this bit is set, it forces a floating underflow exception after execution of the instruction that produced a result with an underflow (e.g., a result exponent, after normalization and rounding, less than the smallest representable exponent for the data type). When this bit is clear, no exception occurs.
- <05> **INTEGER OVERFLOW TRAP ENABLE**
When this bit is set, it forces an integer overflow trap after execution of an instruction that produced an integer result that overflowed or had a conversion error. When this bit is clear, no integer overflow trap will occur, however, the condition code V bit will still set.
- <04> **TRACE ENABLE**
When this bit is set at the beginning of an instruction, it will cause Trace Pending <30> to set. When Trace Pending is set at the end of an instruction, a trace fault is taken before the execution of the next instruction. When TP is clear, no trace exception occurs.
- <03:00> **CONDITION CODES: N, Z, V, C**
- N BIT** - When set, the N (negative) condition code bit indicates that the last instruction that affected this bit produced a negative result. If this bit is clear, the result was positive or zero.
- Z BIT** - When set, the Z (zero) condition code bit indicates that the last instruction which affected this bit produced a result which was zero. When this bit is clear, the result was non-zero.
- V BIT** - When set, the V (overflow) condition code bit indicates that the last instruction which affected this bit either had a conversion error or produced a result whose magnitude was too large to be properly represented in the operand which received the result. When this bit is clear, there was no conversion error or overflow.
- C BIT** - When set, the C (carry) condition code bit indicates that the last instruction which affected this bit either had a carry out of the most significant bit of the result or a borrow into the most significant bit. When this bit is clear, there was no carry or borrow.



<31> VALID BIT
Governs the validity of the M bit and PFN field. V=1 for valid; V=0 for not valid. When V=0, the M and PFN fields are reserved for DIGITAL software.

<30:27> PROTECTION FIELD
This field is always valid and is used by the CPU hardware even when V=0.

<26> MODIFY BIT
When the Valid bit is clear, M is not used by CPU hardware, and is reserved for DIGITAL software and I/O devices. When the Valid bit is set, M shows whether the page has been modified. If M is clear, the page has not been modified. If M is set, the page may have been modified.

M is cleared only by software. It is set by EBox Microcode (firmware). In addition, it may be set by the probe-write instruction (PROBEW) or by an implied probe-write. M is not set if a fault occurs in an instruction which would otherwise have modified the page.

For example, if a write reference crosses a page boundary where the first page is not accessible and the second page is accessible, the reference will fault. M is unchanged in the PTE mapping the first page. It is UNPREDICTABLE whether M is set in the PTE mapping the second page.

It is UNPREDICTABLE whether the modification of a process PTE<M> bit causes modification of the system PTE that maps that process page table. Note that the update of the M bit is not interlocked in a multiprocessor system.


<25> ZERO BIT
Bit 25 is reserved to DIGITAL and must be zero. The hardware does not necessarily test that this bit is zero because the PTE is established by privileged software.

<24:23> OWNER BITS
Reserved for DIGITAL software use as the access mode of the owner of the page, (that is, the mode allowed to alter the page protection or to delete the page); not examined or altered by any hardware.


<22:21> SOFTWARE BITS
Bits 22 and 21 are reserved for DIGITAL software.

<20:00> PAGE FRAME NUMBER
The upper 21 bits of the physical address of the base of the page. Used by CPU hardware only if V=1.

VAX 8600/8650 REGISTER DESCRIPTION
QADRO/QADRI



Note: See QADRI for register description.



The program loads the address in the address registers. It first loads the low-order byte in QADR <00> and then the high-order byte in QADRI. When the data is read it is stored in the data registers, QDATA0 and QDATA1 and CONSOLE MASTER PENDING is cleared. This signifies that the read operation is completed and that the data may be retrieved from QDATA0 and QDATA1.

QCSRO
176400

QBA CONTROL AND STATUS REGISTER 0
CL 29

07	06	05	04	03	02	01	00
MAINT MODE	QBA AND QBUS INIT	ENABLE QBUS DMA	QBA INTERRUPT ENABLE	QBUS READ BY CONSOLE	QBUS WRITE BY CONSOLE	CONSOLE MASTER PEND	CONSOLE REQUEST MASTER

NOTE
BIT 01 READ ONLY, ALL OTHER BITS READ/WRITE

SEP 14 2008

- <07> **MAINT MODE**
 CL29 MAINT MODE H
 Set maintenance mode to allow simulation of QBus device.
- <06> **QBA AND QBUS INIT**
 CL29 QBA INIT H
 Initialize QBA and QBus devices.
- <05> **ENABLE QBUS DMA**
 CL29 ENA QBUS DMA H
 Enable QBus DMA transfer requests.
- <04> **QBA INTERRUPT ENABLE**
 CL29 QBA IE H
 Enable QBA to acknowledge QBus device interrupt request.
- <03> **QBUS READ BY CONSOLE**
 CL29 QBA READ H
 Request QBus read operation by Console.
- <02> **QBUS WRITE BY CONSOLE**
 CL29 QBA WRITE H
 Request QBus write operation by Console.
- <01> **CONSOLE MASTER PEND**
 CL31 CSL MASTER PEND H
 Qbus read/write operation by Console in progress.
- <00> **CONSOLE REQUEST MASTER**
 CL31 CSL REQ MASTER H
 Request QBus for read/write operation by Console.

VAX 8600/8650 REGISTER DESCRIPTION QCSR1

QCSR1
176401

QBA CONTROL AND STATUS REGISTER 1
CL 29

07	06	05	04	03	02	01	00
SIMULATED QBUS SIGNALS DURING MAINTENANCE MODE							
SLAVE ACK	INTERRUPT REQUEST	DMA REQUEST	RPLY	DATA OUT	DATA IN	SYNC CLOCK	

NOTE:
ALL BITS ARE READ/WRITE

<07> UNUSED

Bits <06:00> are used during maintenance only and simulate QBUS signals. If QCSR0 <07>, MAINT MODE, is set, the setting of QCSR1 <06:00> will assert the corresponding signal on the QBus.

<06> SIMULATE SLAVE ACK (QBUS SIGNAL:BSACKL)
CL29 SIM SACK H

<05> SIMULATE INTERRUPT REQUEST (QBUS SIGNAL:BRIO L)
CL29 SIM IRQ H

<04> SIMULATE DMA REQUEST (QBUS SIGNAL:BDMR L)
CL29 SIM DMR H

<03> SIMULATE REPLY (QBUS SIGNAL:BRPLY L)
CL29 SIM RPLY H

<02> SIMULATE DATA OUT (QBUS SIGNAL:BDOUT L)
CL29 SIM DOUT H

<01> SIMULATE DATA IN (QBUS SIGNAL:BDIN L)
CL29 SIM DIN H

<00> SIMULATE SYNC CLOCK (QBUS SIGNAL:BSYNC L)
CL29 SIM SYNCH H

VAX 8600/8650 REGISTER DESCRIPTION
QCSR2

QCSR2
176402

QBA CONTROL AND STATUS REGISTER 2
CL29


07	06	05	04	03	02	01	00
SLAVE RECEIVED SLAVE ACK	-AC POWER OK (QBUS)	-DC POWER OK (QBUS)	BYTE COUNT		STATE COUNTER		
			B1	B2	2	1	0

NOTE
ALL BITS READ ONLY


SEP 14/79

- <07> SLAVE RECEIVED SLAVE ACK
CL32 SREC SACK H
BSACK received on QBus indicating QBus device is bus master.
- <06> -AC POWER OK (QBUS)
-CL32 RPOK H
When asserted, indicates the reception of QBus signal "-BRPOK H", which indicates a loss of AC power on the QBus.
- <05> -DC POWER OK (QBUS)
-CL32 RDOK H
When asserted, indicates the reception of QBus signal "-BRDOK H", which indicates a loss of DC power on the QBus.
- <04:03> BYTE COUNT
CL33 <B1:B0> H
At the initiation of a QBus DMA sequence, this field counts the byte transfers required to translate a QBus word operation to a byte orientated data path to memory. Cleared by Console initialization.
- <02:00> STATE COUNTER
CL30 <CNT 2:0> H
Output of time state generator in QBus control.


VAX 8600/8650 REGISTER DESCRIPTION
 QCSR3
 QDATA0/QDATA1



- <07> NOT USED
- <06> EMM CPU DC LO L
 -CL09 DC LOW H
 This signal reflects the status of the DC Lo signal from the EMM. When asserted (= 0), a DC LO condition exists.
- <05> RPLY TIMEOUT
 CL30 RPLY TIMEOUT H
 RPLY not received on QBus during QBus read/write operation (8 usec). Interrupts Console (T-11) program.
- <04> TIMEOUT
 CL30 TIMEOUT H
 QBus RPLY timeout counter in QBus control has timed out (8 usec).
- <03:00> QBUS TIMEOUT COUNT
 CL30 TIME <3:0> H
 Output of QBus RPLY timeout counter in QBus control.




Note: See QDATA1 for register description.



The data registers, QDATA0 and QDATA1, are loaded first. The console program then loads the address in the address registers. It first loads the low-order byte in QADR0 and then the high-order byte in QADR1. Loading the high-order byte in the address register causes the hardware to automatically begin the QBus operation if the CONSOLE MASTER PENDING bit is set. The hardware automatically clears CONSOLE MASTER PENDING at the end of the QBus write. This indicates to the console program that the operation has ended.


VAX 8600/8650 REGISTER DESCRIPTION
 USART RBSR
 CBUS RBUF 0 - 3



The T-11 program specifies the baud rate by loading the Remote Baud Select Register (RBSR). The clock rates are set by loading two 4-bit codes (one for the transmit clock and the other for the receive clock).


REMOTE BAUD SELECT REGISTER

BITS<7:4> BITS<3:0>	BAUD RATE	BITS<7:4> BITS<3:0>	BAUD RATE
0000	50	1000	1800
0001	75	1001	2000
0010	110	1010	2400
0011	134.5	1011	3600
0100	150	1100	4800
0101	300	1101	7200
0110	600	1110	9600
0111	1200	1111	19.2K




The RBUF0-3 registers are used in conjunction with the RBUFC register for transferring data packets from the console to the EBox microcode. This communication occurs only in Console I/O (CIO) mode and will take place between CSM and MCP (if in MACRO context) or DSM and DCP (if in DIAGNOSTIC context). Refer to CSM and DSM specifications for operation of these registers, as well as the "KA86 Console Technical Description" manual, EK-KA86C-TD.

VAX 8600/8650 REGISTER DESCRIPTION
 CBUS RBUFC
 RH780 BCR



The RBUFC register is used in conjunction with the RBUF0-3 registers for communication between the console software and EBox microcode. This communication occurs only in Console I/O (CIO) mode and will take place between CSM and MCP (if in MACRO context) or DSM and DCP (if in DIAGNOSTIC context). Refer to CSM and DSM specifications for operation of these registers, as well as the "KA86 Console Technical Description" manual, EK-KA86C-TD.

- <07> **DONE RIGHT-OF-ACCESS BIT**
 When DONE is set, the EBox microcode may read the RBUF register. When DONE is cleared, the T-11 program may write the RBUF register.
- <06> **PACKET CONTROL**
 When this bit is set, another packet will be sent by the EBox microcode. When it is not set, the current packet is the last one for this transaction.
- <05:00> **DATA**
 Applications dependent; refer to DSM and CSM specifications.




The program loads (writes) the 2's complement of the number of bytes to transfer into bits <15:00> of this register. Upon initiation of the transfer, the MBA hardware will load these 16 bits into <31:16> and into <15:00>. The Byte Count Register may not be modified during a data transfer. Any attempt to do so will be ignored and will result in a programming error, setting bit <19>, PGE, of the RH780 Status Register.

- <31:16> **MASSBUS BYTE COUNTER**
 The 2's complement byte count of the number of bytes to be transferred on the MASSBUS.
- <15:00> **SBI BYTE COUNTER**
 The 2's complement byte count of the number of bytes to be transferred on the SBI.

VAX 8600/8650 REGISTER DESCRIPTION
RH780 COMMAND/ADDRESS REGISTER (CAR)
RH780 CR

CAR
 OFFSET: 01C

RH780 COMMAND/ADDRESS REGISTER




MR-14214

READ ONLY

This register is read only and valid only when DT BUSY is set. It contains the value of bits 31 through 00 of the SBI during the command/address part of the MBA's next data transfer.

CR
 OFFSET: 004

RH780 CONTROL REGISTER
 (MIR)



MR-14208

<31:04> RESERVED

<03> MAINTENANCE MODE

Set when the MBA is in the maintenance mode, which will allow the diagnostic programmer to exercise and examine the Massbus operations without a Massbus device. When set, the MBA will block RUN, DEM, and assert FAIL to the Massbus so that all the devices on the Massbus will detach from the Massbus. This bit can only be set if a data transfer is not in progress.

<02> INTERRUPT ENABLE

Set by writing a 1 or at power up. Cleared by writing a 0 or INIT. Setting this bit allows the MBA to interrupt the CPU when certain conditions occur.

<01> ABORT DATA TRANSFER

Set by writing a 1 and cleared by writing a 0, INIT or UNJAM. Setting this bit will initiate the data transfer abort sequences that will stop sending commands and addresses, and stop the byte counter. It will also negate RUN, assert EXC to the Massbus, wait for EBL, and set ABORT to a 1 at trailing edge of EBL. The CPU is interrupted if the Interrupt Enable bit is 1.

<00> INITIALIZATION

This bit is self-clearing (always reads 0). Setting this bit clears status bits in the MBA configuration register, clears ABORT and IE bits in the MBA control register, clears the MBA status register, clears control and status bits of diagnostic registers. It will also cancel all pending commands except the read data pending abort data transfer command as well as asserting the Massbus Init command.

VAX 8600/8650 REGISTER DESCRIPTION RH780 CSR

CSR
OFFSET: 000

RH780 CONFIGURATION/STATUS REGISTER
MRR: S, T, U

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
SBI FE	WRITE SEQUENCE	UNEXPCD RD DATA	0	MULTIPLE XMITTER	XMITTER DURING FAULT				ADAPTER POWER DOWN	ADAPTER POWER UP					
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00

MR-14307

NOTE


When bits 31, 30, 29, or 27 are set, FAULT will be asserted on the SBI for one cycle. In addition, they will be reset by a power fail or upon the deassertion of FAULT.

- <31> **SBI PARITY ERROR (FAULT A)**
This bit is set when an SBI parity error is detected.
- <30> **WRITE DATA SEQUENCE (FAULT B)**
This bit is set when a received command address indicates a write operation, but is not followed by write data.
- <29> **UNEXPECTED READ DATA (FAULT C)**
This bit will be set when read data is received but is not expected (no read command address transmitted).
- <28> **RESERVED**
- <27> **MULTIPLE TRANSMITTER FAULT (FAULT D)**
When the ID received does not agree with the ID transmitted on the SBI, this bit will be set.
- <26> **TRANSMITTER DURING FAULT**
This bit is set when the SBI fault is detected on the 2nd cycle after the MBA transmits information on the SBI. It is cleared by a power fail or the deassertion of FAULT on the SBI.
- <25:24> **RESERVED**
- <23> **ADAPTER POWER DOWN**
This bit will be set when the MBA receives the assertion of AC LO. It will be reset when power comes up, by the assertion of INIT, UNJAM, DC LO, or the writing of a "1" to this bit. The setting of this bit will generate an interrupt if interrupt enable is set.
- <22> **ADAPTER POWER UP**
This bit will be set when the MBA receives the deassertion of AC LO. It will be cleared upon power down, or by the assertion of INIT, UNJAM, DC LO, or the writing of a "1" to this bit. The setting of this bit will set the interrupt enable bit and interrupt the CPU.
- <21> **OVER TEMPERATURE**
Always 0
- <20:08> **RESERVED**
- <07:00> **ADAPTER CODE**
The MBA adapter code is: <07:00> = 00100000

VAX 8600/8650 REGISTER DESCRIPTION
RH780 DR

RR
OFFSET: 014

RH780 DIAGNOSTIC REGISTER
MIRJ, R, S




- <31> INVERT MASSBUS DATA PARITY GENERATOR
- <30> INVERT MASSBUS CONTROL PARITY GENERATOR
- <29> INVERT MAP PARITY
- <28> BLOCK SENDING COMMAND TO THE SBI
During a data transfer, the setting of this bit will eventually cause a DLT bit set and a DT ABORT.
- <27> SIMULATE SCLK
If CR <03>, Maintenance Mode (MM) is set, this bit will simulate the assertion of SCLK.
- <26> SIMULATE EBL
When the MM bit is set, this bit will simulate the assertion of EBL.
- <25> SIMULATE OCC
When MM bit is set, this bit will simulate the assertion of OCC.
- <24> SIMULATE ATTN
When MM bit is set, this bit will simulate assertion of ATTN.
- <23> MAINTENANCE MASSBUS DATA INPUT BUFFER SELECT
When this bit is set, the upper eight bits (B<15:08>) of the MDIB will be sent out from bits 07 through 00 of the diagnostic register, if the diagnostic register is read. When the bit is cleared, the lower eight bits (B<07:00>) of the MDIB will be sent out from bits 07 through 00 of the diagnostic register, if the diagnostic register is read.
- <22:21> MAINTENANCE USE ONLY
Read/write with no effect. Used to test the writability of these bits.
- <20> MASSBUS FAIL (Read Only)
Fail is asserted when MM is set.
- <19> MASSBUS RUN (Read Only)
- <18> MASSBUS WCLK (Read Only)
- <17> MASSBUS EXC (Read Only)
- <16> MASSBUS METHOD (Read Only)
- <15:13> MASSBUS DEVICE SELECT (Read Only)
- <12:08> MASSBUS REGISTER SELECT (Read Only)
- <07:00> MAINTENANCE UPPER/LOWER MDIB

VAX 8600/8650 REGISTER DESCRIPTION
RH780 SMR
RH780 SR

SMR
OFFSET: 018

RH780 SELECTED MAP REGISTER



MR-14213

There are 256 MAP registers, and the Selected MAP Register (SMR) contains the contents of the MAP register pointed to by VAR <16:09>. The SMR is a read only register and is valid only when DT BUSY is set (SR <31>, data transfer command has been received).

The MAP registers can only be written when there is no data transfer operation in progress. A write to a MAP register while a data transfer is in progress will be ignored and cause the setting of PGE (SR <19>) and interrupt the CPU at the end of a transfer if IE is set.


<31> **VALID BIT**
Bits <20:00> is a valid physical page frame number.

<30:21> **MBZ**

<20:00> **PHYSICAL PAGE FRAME NUMBER**

SR
OFFSET: 008

RH780 STATUS REGISTER
MIR, S, T, U



NOTE: WRITE 1 TO CLEAR BITS EXCEPT BIT 31 WHICH IS READ ONLY.

MR-14209

NOTE

When set, the following bits will interrupt the CPU if IE is set: <19:17>, <16>, <13:12> and <08>. The following bits, when set, will cause the transfer to be aborted: <11:09> and <07:00>.

<31> **DATA TRANSFER BUSY**
This bit is set when a data transfer command is received. It is cleared when a data transfer is aborted. Read only.

<30> **NO RESPONSE CONFIRMATION**
This bit is set when the MBA received a no-response confirmation for a read or write command. It is cleared by writing a 1 to this bit or INIT. Setting of this bit will cause retry of the command.

- <29> **CORRECTED READ DATA (CRD)**
Set when read data has a MASK field of 0001 (CRD), which indicates that the data has been corrected. It is cleared by writing a 1 to this bit or INIT.
- <28:20> **RESERVED**
- <19> **PROGRAM ERROR**
This bit is set when the program tries to: 1) Initiate a data transfer when a data transfer is already in progress; 2) Load MAP, VAR, or BC while a data transfer is in progress; 3) Set MBA maintenance mode during a data transfer operation; or Initiate an illegal data transfer command. It is cleared by writing a 1 to this bit.
- <18> **NON-EXISTING DRIVE**
This bit is set when the drive fails to assert TRANSFER within 1.5 us after assertion of DEMAND. It is cleared by writing a 1 to this bit.
- <17> **MASSBUS CONTROL PARITY ERROR**
This bit is set when a Massbus control parity error occurs. It is cleared by writing a 1 to this bit.
- <16> **ATTENTION FROM MASSBUS**
This bit is set when the ATTENTION line on the Massbus is asserted.
- <15:14> **RESERVED**
- <13> **DATA TRANSFER COMPLETED**
This bit is set when data transfer is completed. It is cleared by writing a 1 to this bit.
- <12> **DATA TRANSFER ABORTED**
This bit is set with the trailing edge of EBL when the data transfer has been aborted. It is cleared by writing a 1 to this bit or INIT.
- <11> **DATA TRANSFER LATE**
This bit is set 1) for either a write data transfer or a write check data transfer providing the data buffer is empty when WCLK is sent to the Massbus, 2) for a read data transfer providing the data buffer is full when SCLK is received from the Massbus.
- <10> **WRITE CHECK UPPER ERROR**
This bit is set when a compare error is detected in the upper byte while the MBA is performing a write check operation. It is cleared by writing a 1 to this bit or INIT.
- <09> **WRITE CHECK LOWER ERROR**
This bit is set when a compare error is detected in the lower byte while the MBA is performing a write check operation. It is cleared by writing a 1 to this bit or INIT.
- <08> **MISSED TRANSFER ERROR**
This bit is set when no OCC or SCLK is received within 50 us after data transfer busy is set. It is cleared by writing a 1 to this bit or INIT.

VAX 8600/8650 REGISTER DESCRIPTION
RH780 SR

SR OFFSET 008																RH780 STATUS REGISTER MIRR, S, T, U			
31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16				
DATA TRANSFER BUSY	NO RESPONSE CONFIRM	CORRECTED READ DATA										PROGRAM ERROR	NON EXISTENT DRIVE	MASSBUS CONTROL PARITY ERROR	MASSBUS ATTENTION				
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00				
		DATA TRANSFER		WRITE CHECK UPPER ERROR	WRITE CHECK LOWER ERROR	MISSED TRANSFER ERROR	MASSBUS EXCEPTION	MASSBUS DATA PE	MAP PE	INVALID MAP	ERROR CONFIRMATION	READ DATA SUBSTITUTE	INTERFACE SEQUENCE TIMEOUT	READ DATA TIMEOUT					
		COMPLETE	ABORT	LATE															


NOTE: WRITE 1 TO CLEAR BITS EXCEPT BIT 31 WHICH IS READ ONLY.

- <07> **MASSBUS EXCEPTION**
This bit is set when EXC is received from Massbus. It is cleared by writing a 1 to this bit or INIT.
- <06> **MASSBUS DATA PARITY ERROR**
This bit is set when a Massbus data parity error is detected during a read data transfer operation. It is cleared by writing a 1 to this bit or INIT.
- <05> **MAP PARITY ERROR**
This bit is set when a parity error is detected on the data read from the map during a data transfer. It is cleared by writing a 1 to this bit or INIT.
- <04> **INVALID MAP**
This bit is set while reading a map register if the valid bit of the next page frame number is zero and the byte counter is not zero. It is cleared by writing a 1 to this bit or INIT.
- <03> **ERROR CONFIRMATION**
This bit is set when the MBA receives error confirmation for a read or write command on the SBI. It is cleared by writing a 1 to this bit or INIT.
- <02> **READ DATA SUBSTITUTE**
This bit is set when the TAG of the read data received from memory on the SBI is READ DATA SUBSTITUTE. It is cleared by writing a 1 to this bit or INIT.
- <01> **INTERFACE SEQUENCE TIMEOUT**
This bit will be set for the following conditions: 1) SBI arbitration is received and no ACK for the command address, and write data (for a write operation) within 102.4 usec; or 2) ERR confirmation is received for a command address. It is cleared by writing a 1 to this bit or INIT.
- <00> **READ DATA TIMEOUT**
This bit will be set if, starting from the acknowledge for the read command address, read data is not received within 102.4 usec. It is cleared by writing a 1 to this bit or INIT.

VAX 8600/8650 REGISTER DESCRIPTION
RH780 VAR
RLBA

VAR
OFFSET: 00C

RH780 VIRTUAL ADDRESS REGISTER



MR-14210

Note: The Virtual Address Register should not be written to during a data transfer. An attempt to do so will set PROGRAM ERROR (bit <19> in the RH780 Status Register). The virtual address register will not be modified and the data transfer will continue.

<31:17> RESERVED

<16:09> MAP POINTER


Select one of the 256 MAP registers.

<08:00> PHYSICAL PAGE BYTE ADDRESS

This field specifies the byte offset into the current (data) page. The contents of the selected MAP register and the value of this field are used to assemble a physical SBI address to be sent to memory.

RLBA
174402

RLV12 BUS ADDRESS REGISTER



MR-15992

The Bus Address Register is a 16 bit, word-addressable register with a standard address of 174402 for the 16 bit QBus. Bits <15:00> can be read or written; bit <00> is usually written as 0. The Bus Address Register indicates the memory location for the DMA transfer during a read or write operation. The register's contents are automatically incremented by 2 as each word is transferred between the system memory and the controller.

Although unused on the VAX 8600 console, the Bus Address can be expanded for an 18 bit LSI-11 Bus using bits <05:04> of the RLCSR (as BA <17:16>) or to a 22 bit LSI-11 Bus by using the RLBAE (RLV12 Bus Address Extension) register bits <05:00>.

The RLBA register is cleared by initializing the Bus (BINIT L).

VAX 8600/8650 REGISTER DESCRIPTION RLCSR

RLCSR
174400

RLV12 CONTROL STATUS REGISTER

15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
COMPOSITE ERROR	DRIVE ERROR	ERROR CODE				DRIVE SELECT		CON- TROLLER READY	INTER- RUPT ENABLE	EXTENDED ADDRESS BITS		FUNCTION CODE			DRIVE READY
E3	E2	E1	E0		DS0	DS1				BA17	BA16	F2	F1	F0	
R	R	R	R	R	R	R/W	R/W	R/W	R		R	R	R	R	R

<15> **COMPOSITE ERROR**
When set, this bit indicates that one or more of the error bits (bits <14:10>) are set. Cleared by initializing the bus by starting a new command, with the exception of DE and ERR if they were caused by a drive error. Note: When an error occurs, the current operation terminates and an interrupt routine is started if the interrupt enable bit (bit 06 of the CSR) is set.

<14> **DRIVE ERROR**
When set, it indicates that the selected drive has flagged an error. The source can be determined by executing a get status command. Note: DE will not set ERR (bit 15) or CRDY (bit 07) until the usual occurrence of CRDY. This bit is buffered from the drive error interface line.

<13:10> **CONTROLLER STATUS ERRORS**
Set by the controller to indicate one of the following errors:

ERROR CODE BITS	OCTAL
E3 E2 E1 E0 ERROR	CODE
0 0 0 1 OPERATION INCOMPLETE (OPI)	1
0 0 1 0 DATA CRC (DCRC)	2
0 0 1 1 HEADER CRC (HCRC)	3
0 1 0 0 DATA LATE (DLT)	4
0 1 0 1 HEADER NOT FOUND (HNF)	5
1 0 0 0 NONEXISTENT MEMORY (NXM)	10
1 0 0 1 PARITY ERROR ABORT (PAR ERR)	11

Operation incomplete indicates that the current command was not completed within the OPI timeout period of 550 ms.

A data CRC error indicates that while reading the data field from the disk an error was found.

A header CRC error indicates that while reading the header from the disk an error was found. The CRC check is performed on the first and second header words, although the second header word is always 0.

Data late indicates that the FIFO RAM was more than half full and the controller was not able to read the next sequential sector. This error may occur during a read without header check command.

Header not found indicates that an OPI timeout occurred while the controller was searching for the correct sector to read or write. A header compare did not occur.

A non-existent memory error indicates that during a DMA transfer the memory location addressed did not respond with RPLY within 10 us.

A memory parity error abort indicates that a parity error was detected while reading the system's optional memory that has parity error checking. If an error was detected, the current command to the RLV12 is aborted.

<09:08> **DRIVE SELECT**
When set, these bits determine which drive will communicate with the controller via the drive bus. Cleared by initializing the bus.

<07> **CONTROLLER READY**
Set by the controller at the completion of a command, at the detection of an error, or by initializing the bus. Cleared by software. This bit indicates that the command in bits 01-03 is to be executed. Note: Software cannot set this bit because registers are not accessible while CRDY is 0.

<06> **INTERRUPT ENABLE**
Set when CRDY is asserted, bit 06 allows the controller to interrupt the processor. Cleared by initializing the bus. Note: This interrupt occurs at the termination of a command. Once an interrupt request is placed on the LSI-11 bus, it is not removed until acknowledged by the LSI-11 processor even if IE (bit 06) is cleared.

<05:04> **EXTENDED ADDRESS BITS**
These two bits are the upper-order bus address bits for 18-bit buses. These bits are read and written as bits 04 and 05 of the CSR. They function as address bits 16 and 17 of the BAR. Writing bits 04 and 05 of the CSR also writes bits 0 and 1 of the BAE.

<03:01> **FUNCTION CODE**
Set by software to indicate the command to be executed.

FUNCTION			COMMAND	OCTAL CODE
F2	F1	F0		
0	0	0	MAINTENANCE MODE	0
0	0	1	WRITE CHECK	1
0	1	0	GET STATUS	2
0	1	1	SEEK	3
1	0	0	READ HEADER	4
1	0	1	WRITE DATA	5
1	1	0	READ DATA	6
1	1	1	READ DATA WITHOUT HEADER CHECK	7

Cleared by initializing the bus (BINIT L). Note: Command execution starts when CRDY (bit 07) of the CSR is cleared by software.

<00> **DRIVE READY**
When set this bit indicates that the selected drive is ready to receive a command or supply valid read data. Cleared when a seek or head select operation is started and set when the seek operation is completed.

VAX 8600/8650 REGISTER DESCRIPTION
RLDA (GET STATUS)

RLDA
174404

RLV12 DISK ADDRESS REGISTER (DURING A GET STATUS COMMAND)

15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
NOT USED DURING A GET STATUS								MUST BE A ZERO				RESET	MUST BE ZERO 0	GET STATUS 1	MARKER BIT 1

W01-10002

The Disk Address Register is a 16 bit Read/Write register with a standard address of 174404. Its contents have one of three meanings, depending on the command being performed. The RLDA is cleared by initializing the bus (BINIT L).

RLDA during a GET STATUS command: Both the RLCSR and the RLDA registers must be programmed to execute the GET STATUS command.

<15:08> RESERVED

<07:04> MBZ
Must be zero.

<03> RESET
When this bit is set, the disk drive clears its error register of soft errors before sending a status word to the controller.

<02> MBZ
Must be zero.

<01> GET STATUS
Must be a 1, indicating to the drive to send its status word. At the completion of the get status command, the drive status word is read into the controller multipurpose register (RLMPR). With this bit set, bits 08-15 are ignored by the drive.

<00> MARKER
Must be a 1.

VAX 8600/8650 REGISTER DESCRIPTION

RLDA (READ/WRITE)

RLDA 174404		RLV12 DISK ADDRESS REGISTER (DURING READ, WRITE OR WRITE CHECK COMMAND)																
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00			
CYLINDER ADDRESS DIFFERENCE <08:00>									HEAD SELECT		SECTOR ADDRESS <05:00>							
RLD2 ONLY CA5																		
CA7		CA6	CA5	CA4	CA3	CA2	CA1	CA0	CAU1	CAU0	SA5	SA4	SA3	SA2	SA1	SA0		

The Disk Address Register is a 16 bit Read/Write register with a standard address of 174404. Its contents have one of three meanings, depending on the command being performed. The RLDA is cleared by initializing the bus (BINIT L).

RLDA during READ, WRITE or WRITE CHECK commands: For these commands, the RLDA register is loaded with head select information and the address of the first sector to be transferred. As each sector is transferred, the RLDA sector address increments by 1.

- <15:07> **CYLINDER ADDRESS**
Address of one of the 256 cylinders for RL01 or 512 cylinders for RL02. (Octal range is 0 to 777.)
- <06> **HEAD SELECT**
Indicates which head (disk surface) is to be selected: 1 = lower, 0 = upper.
- <05:00> **SECTOR ADDRESS**
Address of one of the 40 sectors on a track. (Octal range is 0 to 47.)

VAX 8600/8650 REGISTER DESCRIPTION
 RLDA (SEEK)
 RLMPR (AFTER A GET STATUS)

RLDA 174404																RLV12 DISK ADDRESS REGISTER (DURING A SEEK COMMAND)									
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00										
CYLINDER ADDRESS DIFFERENCE OF 08'00										0		0		HEAD SELECT	MUST BE A ZERO	DIRECTION	MUST BE A ZERO	MARKER BIT MUST BE ONE							
RLDZ ONLY	DF7	DF6	DF5	DF4	DF3	DF2	DF1	DF0																	

The Disk Address Register is a 16 bit Read/Write register with a standard address of 174404. Its contents have one of three meanings, depending on the command being performed. The RLDA is cleared by initializing the bus (BINIT L).

RLDA during a SEEK command: The program will execute a SEEK command by loading the RLDA with the head select, direction to move and cylinder difference information.

<15:07> CYLINDER ADDRESS DIFFERENCE
 Indicates the number of cylinders the heads are to move on a seek.

<06:05> RESERVED

<04> HEAD SELECT
 Indicates which head (disk surface) is to be selected: 1 = lower, 0 = upper

<03> MBZ
 Must be zero.

<02> DIRECTION
 This bit indicates the direction in which the seek is to take place. The actual distance moved depends on the cylinder address difference (bits 07-15).

This bit is set when the heads move toward the spindle (to a higher cylinder address). It is cleared when the heads move away from the spindle (to a lower cylinder address).

<01> MBZ
 Must be zero. Indicates to the drive that a seek command is being issued and that the other bits in the register hold the seek applications.

<00> MARKER
 Must be a 1.

RLMPR 174405																RLV12 MULTIPURPOSE REGISTER (AFTER A GET STATUS COMMAND)							
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00								
WRITE DATA ERROR	HEAD CURRENT ERROR	WRITE LOCK	SEEK TIME OUT	SPIN ERROR	WRITE GATE ERROR	VOLUME CHECK	DRIVE SELECT ERROR	DRIVE TYPE	HEAD SELECT	COVER OPEN	HEADS OUT	BRUSH HOME	MAJOR STATE CODE										
												STC				STB		STA					

Following the GET STATUS command, a status word is stored in the RLMPR. The status word from the selected disk drive includes information on the functional state of the drive, including any drive errors.


<15> WRITE DATA ERROR
 Indicates write gate was asserted, but no pulses were detected on the write data line.

VAX 8600/8650 REGISTER DESCRIPTION
RLMPR (AFTER A GET STATUS)


- <14> **HEAD CURRENT ERROR**
Indicates that write current was detected in the heads when write gate was not asserted.
- <13> **WRITE LOCK**
Indicates write lock status of selected drive: 0 = unlocked; 1 = protected.
- <12> **SEEK TIME OUT**
Indicates that the heads did not come onto track within a specific time during a seek command.
- <11> **SPIN ERROR**
Indicates that the spindle did not reach full speed within a specific time, or that it is turning too fast.
- <10> **WRITE GATE ERROR**
Indicates that the write gate was asserted when the drive was not ready, the sector pulse was asserted, or the drive was write locked.
- <09> **VOLUME CHECK**
VC is set every time the drive goes into load heads state. This asserts a drive error at the controller, but not on the front panel. VC is an indication that the program does not know which disk is present until it has read the serial number and bad sector file. (The disk might have been changed while the heads were unloaded.)
- <08> **DRIVE SELECT ERROR**
Indicates multiple drive selection is detected.
- <07> **DRIVE TYPE**
Indicates the type of disk drive: 0 = RL01, 1 = RL02.
- <06> **HEAD SELECT**
Indicates the head selected: 1 = lower, 0 = upper.
- <05> **COVER OPEN**
Asserted when the cover is open or the dust cover is not in place.
- <04> **HEADS OUT**
Asserted when the heads are over the disk.
- <03> **BRUSH HOME**
Asserted when the brushes are not over the disk.
- <02:00> **MAJOR STATE CODE STA, STB, STC**

C	B	A	STATE OF DRIVE
0	0	0	LOAD STATE
0	0	1	SPIN UP
0	1	0	BRUSH CYCLE
0	1	1	LOAD HEADS
1	0	0	SEEK TRACK COUNTING
1	0	1	SEEK LINEAR MODE (LOCK ON)
1	1	0	UNLOAD HEADS
1	1	1	SPIN DOWN

VAX 8600/8650 REGISTER DESCRIPTION
 RLMPR (READ)
 RLMPR (WRITE)



After a READ HEADER command is executed, three words can be sequentially read from RLMPR. The first word includes the sector address, the head selected, and the cylinder address. The second word is all zeros. The third word is CRC computed over the header.



RLMPR loaded with a word count:

Before starting a DMA transfer, the RLMPR is loaded with the word count. The program must load the RLMPR with the 2's complement of the number of words to be transferred. The bits are described below. As each word is transferred, the RLMPR is automatically incremented by 1. The READ or WRITE operation continues until a word count overflow occurs, indicating that all words have been transferred.


The word count can range from 1 to 5120 data words. The maximum count is limited by the maximum number of sectors available (40) and the maximum words per sector (128).

Once written, the word count cannot be read back. Reading the RLMPR does not change the word count. The word count is cleared by initializing the Qbus (BINIT L).

<15:13> MUST BE ALL ONES
 For word count in correct range.

<12:00> WORD COUNT
 This is the 2'S complement of the total number of words to be transferred. The maximum count is 5120.

VAX 8600/8650 REGISTER DESCRIPTION RXCS



<31:24> **RXCS3 - RESERVED**

<23:20> **RXCS2 - DATA TERM READY**
Reserved for Other Console Resident Interfaces.

<19:16> **RXCS2 - DATA TERM READY**
Logical Data Terminal Ready (DTR). Write Only by CPU.
Initialized to zero by the console.

If any of the above bits (19-16) are set, the CPU is ready to accept data from the modem device. If any of the above bits (19-16) are not set, the CPU wants to disconnect from the modem.

<19> **CONSOLE DATA**
Corresponds To "Logical" Console Subsystem Data.

<18> **EMM**
Corresponds to EMM Data Line.

<17> **REMOTE TERMINAL**
Corresponds to the remote services port on the console.

<16> **LOCAL TERMINAL**
Corresponds to console terminal.

<15:08> **RXCS1 - RESERVED**


<07:00> **RXCS0**

<07> **DONE**
Read only by the CPU. Initialized to zero by the console. When set to a one, this bit indicates that data is available from the console, and that the data and the ID of the source of the data are both available in the IPR RXDB.

<06> **INTERRUPT ENABLE**
Read/Write by the CPU. Initialized to zero by the console. When the logical AND of "RXCS DONE" and "RXCS IE" is equal to 1 a CPU interrupt is generated via System Control Block (SCB) vector "F8".

<05:00> **RXCS0 - RESERVED**

VAX 8600/8650 REGISTER DESCRIPTION RXDB



- <31:24> **RXDB3 - MBZ**
Must be zero.
- <23:20> **RESERVED**
Must be zero.
- <19:16> **RXDB2 CARRIER DESTINATION**
Read only by the CPU. Initialized by the console based on the state of the corresponding DTR Field <19:16> in RXCS and the state of any modem connection associated with that line.
- <19> **LOGICAL CONSOLE DATA**
Because this is a hard-wired line (no modem involved) this bit will always be set.
- <18> **EMM**
Because this is a hard-wired line (no modem involved) this bit will always be set.
- <17> **REMOTE TERMINAL (RTY)**
Indicate that the modem associated with the Remote Line (RTY) is active.
- <16> **LOCAL TERMINAL (CTY)**
Because this is a hard-wired line (no modem involved) this bit will always be set.
- <15:12> **RXDB1 - RESERVED**
Must be zero.
- <11:08> **RXDB1 DATA ID CODE**
Read only by the CPU. Initialized to zero by the console. Identifies the destination of the data byte in bits <07:00>.
- | | |
|----|----------------------------|
| ID | DESTINATION |
| -- | ----- |
| 00 | Console Terminal |
| 01 | Remote Services Port |
| 02 | EMM Data |
| 03 | Logical Console Data |
| 04 | Reserved to DEC |
| . | . |
| . | . |
| 0E | Reserved to DEC |
| 0F | "Carrier" Byte Has Changed |
- <07:00> **RXDB0 - DATA**
Read only by the CPU. The Data Byte has different meanings depending of the destination specified by the DATA ID CODE <11:08>.

RXDB Data Byte Definitions:

RXDB	
DATA ID	Data Source
0	Console Terminal - RXDB <07:00> contains a byte of data received from the Console Terminal (CTY).
1	Remote Services Port - RXDB <07:00> contains a byte of data received from the Remote Services Port.
2	Environmental Monitoring Module (EMM) - In this case the RXDB data byte is used to identify the type of EMM data bytes that follow the RXDB.

The format for an EMM (RXDB) Data Byte is as follows:

7	6	5	4	3	2	1	0
TYPE	ASD	x	EMM OPCODE ID				

<07> Identifies the type of EMM Opcode contained in bits <04:00>. There are two types:

<07>	OPCODE TYPE
1	EMM EXCEPTION
0	EMM RESPONSE

EMM EXCEPTION OPCODES indicate that the EMM is reporting a status change. All Exception Reports consist of a single data byte which is also sent via RXDB0.


EMM RESPONSE OPCODES indicate that the EMM is sending information in response to a request for information. Depending on the Response Opcode type, one or more bytes of additional information will be sent via RXDB0.

<06> ASD (Automatic Shutdown) - Indicates that the EMM Automatic Shutdown Timer is running and that a total system power shutdown is pending. If the cause of the condition is not rectified (RED ZONE Temperature Fault or AIR FLOW Fault) the EMM will shutdown the system when the timer times out.

<05> RESERVED

VAX 8600/8650 REGISTER DESCRIPTION

RXDB



RXDB

DATA ID Data Source

2

(Continued)

<04:00> EMM OPCODE ID - Used in conjunction with bit <07> to identify the type of EMM data that follows in the next RXDB0 byte transfer.

If set, <07> bit indicates that this field contains an EMM Exception Opcode and a single byte of data follows that describes the exception. Table 1 lists the EMM Exception Opcodes and describes the associated data byte.

If clear <07> bit indicates that this field contains an EMM Response Opcode and one or more bytes of data follows that describes the exception. Table 2 lists the EMM Response Opcodes and describes the associated data bytes.

3 Logical Console Data. In this case RXDB0 contains a Header ID that identifies the type of Logical Console data that follows via additional RXDB0 transmissions.

HDR	DATA			
ID	BYTE	BITS	DESCRIPTION	

10	00	<07:00>	Returned_Warm_Flag	
	01	<06:01>	RESERVED	
		<00>	0 = Warm_Flag Clear 1 = Warm_Flag Set	
11	00	<07:00>	Returned_Cold_Flag	
	01	<06:01>	RESERVED	
		<00>	0 = Cold_Flag clear 1 = Cold_Flag set	
12	00	<07:00>	Returned_UCODE_Version	
	01	<07:00>	Version_Lower_8_Bits	
	02	<07:00>	Version_Upper_8_bits	
13	00	<07:00>	Returned_Array_Config	
	01	<07:00>	Array_slots_(n+1)_in_use	
	02	<01:00>	Array_type_in_slot_1	
		<03:02>	Array_type_in_slot_2	
		<05:04>	Array_type_in_slot_3	
		<07:06>	Array_type_in_slot_4	

RXDB
DATA ID

Data Source

3

(Continued)

HDR DATA

ID BYTE BITS DESCRIPTION

ID	BYTE	BITS	DESCRIPTION
03	<01:00>		Array type in slot 5
	<03:02>		Array type in slot 6
	<05:04>		Array type in slot 7
	<07:06>		Array type in slot 8

ARRAY

CODES

ARRAY TYPE

CODES	ARRAY TYPE
0	Slot empty
1	16 Megabyte array
2	04 Meagbyte array
3	Reserved

20	00	<07:00>	Console_Command_String_Complete The Console has successfully completed executing the CCS
----	----	---------	--

21	00	<07:00>	Returned Last VAX_PC
	01	<07:00>	VAX PC <07:00>
	02	<07:00>	VAX PC <15:08>
	03	<07:00>	VAX PC <23:16>
	04	<07:00>	VAX PC <31:24>

22	00	<07:00>	Returned Last CSM_Status
	01	<07:00>	CSM Status <07:00>
	02	<07:00>	CSM Status <15:08>
	03	<07:00>	CSM Status <23:16>
	04	<07:00>	CSM Status <31:24>

30	00	<07:00>	Snapfile_Status_Returned The data byte indicates validity of the snapshot files
----	----	---------	---

01	<07:02>	RESERVED
	<00>	0 = SNAP1.DAT Invalid 1 = SNAP1.DAT Valid
	<01>	0 = SNAP2.DAT Invalid 1 = SNAP2.DAT Valid

40	00	<07:00>	Console_Reboot_Successful Response to VMS after a successful console reboot initiated by a MTPR CRBT.
----	----	---------	--

82	00	<07:00>	Console_Command_String_Error Indicates that:
----	----	---------	---

- the Console encountered an error while trying to execute an Console Command String (CCS) or,
- the CCS was rejected because the CCS exceeded the 512 byte console buffer space or,
- the console is locked via the terminal control switch

VAX 8600/8650 REGISTER DESCRIPTION RXDB




TABLE 1 - EMM EXCEPTION REPORTS

Use this table to interpret the meaning of the Opcode in bits <04:00> if bit <07> is set. In addition to listing the Opcodes, this table also describes the meaning of the contents of the data byte associated with each Opcode.

OPCODE EXCEPTION TYPE

00 Status Change in Regulator A +5v
The contents of the Data Byte associated with this and Opcodes 0 through A indicates that the status has changed in the following manner:

DATA BYTE	BITS	MEANING
1	<07:01> <00>	RESERVED 0 = Voltage Normal 1 = Voltage out of Spec.

- 01 Status Change in Regulator B +5v
Data Byte definition: See OPCODE 00.
- 02 Status Change in Regulator C +5v
Data Byte definition: See OPCODE 00.
- 03 Status Change in Regulator D -2v
Data Byte definition: See OPCODE 00.
- 04 Status Change in Regulator E -2v
Data Byte definition: See OPCODE 00.
- 05 Status Change in Regulator F -5.2v
Data Byte definition: See OPCODE 00.
- 06 Status Change in Regulator H -5.2v
Data Byte definition: See OPCODE 00.
- 07 Status Change in Regulator L +12v
Data Byte definition: See OPCODE 00.
- 08 Status Change in Regulator L -12v
Data Byte definition: See OPCODE 00.
- 09 Status Change in Regulator K +15v
Data Byte definition: See OPCODE 00.
- 0A Status Change in Regulator K -15v
Data Byte definition: See OPCODE 00.

TABLE 1 - EMM EXCEPTION REPORTS (continued)

OPCODE

EXCEPTION TYPE

0B

Status Change in T1 Temperature
The Data Byte associated with the OPCODE ID's B through E indicates the following status change:

DATA BYTE	BITS	MEANING
1	<07:02> <01:00>	RESERVED 0 = Temperature Normal 1 = Temperature in Yellow Zone 2 = Temperature in Red Zone. This will result in an automatic shutdown if not corrected. 3 = Temperature Below Nominal Range

0C

Status Change in T2 Temperature
Data Byte meaning: See ID 0B.

0D

Status Change in T3 Temperature
Data Byte meaning: See ID 0B.

0E

Status Change in T4 Temperature
Data Byte meaning: See ID 0B.

0F

Status of Delta T2-T1 has Changed
The Data Byte associated with the OPCODE ID's F through 11 indicates the following status change:

DATA BYTE	BITS	MEANING
1	<07:02> <01:00>	RESERVED 0 = Difference Normal 1 = Difference in Yellow Zone 2 = Difference in Red Zone. This will result in an automatic shutdown if not corrected.

10

Status of Delta T3-T1 has Changed
Data Byte meaning: See ID 0F.

11

Status of Delta T4-T1 has Changed
Data Byte meaning: See ID 0F.

12

Status of AIR FLOW SENSOR 1 has Changed
The Data Byte associated with the OPCODE ID's 12 and 13 indicates the following status change:

DATA BYTE	BITS	MEANING
1	<07:01> <00>	RESERVED 0 = Air Flow Normal 1 = Air Flow out of spec. This will result in an automatic shutdown if not corrected.

13

Status of AIR FLOW SENSOR 2 has Changed
Data Byte meaning: See ID 12.

VAX 8600/8650 REGISTER DESCRIPTION
RXDB




TABLE 1 - EMM EXCEPTION REPORTS (continued)

OPCODE EXCEPTION TYPE

- 14 Status of BBU Availability has Changed. Byte 0 associated with this ID has the following meaning:

DATA BYTE	BITS	MEANING
1	<07:01> <00>	RESERVED 0 = BBU available 1 = BBU not available

- 15 EMM STATUS CHANGED - Except for the case where the EMM is dead, the EMM is rebooted by the console when any of the following errors occur.

1	<07:04> <03:00>	RESERVED 0 = EMM Dead (failed to restart) 1 = EMM encountered RAM parity error 2 = EMM encountered an illegal instruction 3 = EMM encountered an unknown trap to 0 4 = EMM encountered an unexpected trap 5 = EMM encountered an unexpected 6.5 interrupt 6 = Excessive collisions on EMM bus 7 = No transport acknowledge from EMM 8 = No response from EMM 9 = Negative response from EMM A = EMM has no buffers available B = CSL to EMM message transmit timeout
---	--------------------	--

- 16 TX_RDY_TIMEOUT - The TXCS RDY bit has not been set by the console for 2 seconds. Operation in progress aborted.

DATA BYTE	BITS	MEANING
1	<07:01> <01:00>	RESERVED 0 = Local terminal operation aborted 1 = Remote services port operation aborted 2 = EMM operation aborted 3 = Logical console operation aborted

TABLE 2 - EMM RESPONSE REPORTS

Use this table to interpret the meaning of the Opcode in bits <04:00> if bit <07> is clear. In addition to listing the Opcodes, this table also describes the meaning of the contents of the data bytes associated with each Opcode.

NOTE

The first data byte following the RXDB is always a byte count.

ID	INDICATION	
00	RESPONSE TO "EMM STATUS" - This operation returns the status of the EMM status registers and PROM revision number. This response consists of the following 8 Data Bytes.	
BYTE	BITS	MEANING
0	<07:00>	Packet size = 8 bytes (10)
1		POWER CONTROL REGISTER
	<00>	Regulator B +5V BBU *
	<01>	Regulator C +5V SBIA *
	<02>	Regulator D -2V ECL *
	<03>	Regulator E -2V ECL *
	<04>	Regulator F +5.2 ECL *
	<05>	Regulator H +5.2 ECL *
	<06>	Regulator J (unused)
	<07>	BBU disable **
		* 0 = regulator off ** 0 = enabled
2		MARGIN ENABLE REGISTER
	<00>	Regulator A +5V CSL *
	<01>	Regulator B +5V BBU *
	<02>	Regulator C +5V SBIA *
	<03>	Regulator D -2V ECL *
	<04>	Regulator E -2V ECL *
	<05>	Regulator F +5.2 ECL *
	<06>	Regulator H +5.2 ECL *
	<07>	Regulator J (unused)
		* 1 = Margin Enabled
3		MARGIN SELECT REGISTER
	<00>	Regulator A +5V CSL *
	<01>	Regulator B +5V BBU *
	<02>	Regulator C +5V SBIA *
	<03>	Regulator D -2V ECL *
	<04>	Regulator E -2V ECL *
	<05>	Regulator F +5.2 ECL *
	<06>	Regulator H +5.2 ECL *
	<07>	Regulator J (unused)
		* 1 = Margin Enabled
4		MODOK REGISTER
	<00>	Regulator A +5V CSL *
	<01>	Regulator B +5V BBU *
	<02>	Regulator C +5V SBIA *
	<03>	Regulator D -2V ECL *
	<04>	Regulator E -2V ECL *
	<05>	Regulator F +5.2 ECL *
	<06>	Regulator H +5.2 ECL *
	<07>	Regulator J (unused)
		* 1 = MOD OK

VAX 8600/8650 REGISTER DESCRIPTION
RXDB




TABLE 2 - EMM RESPONSE REPORTS (continued)

ID	INDICATION	
00	(Continued)	
BYTE	BITS	MEANING
5		MODOK REGISTER
	<00>	Regulator K OK *
	<01>	Regulator L OK *
	<02>	Module K AC LO
	<03>	Module L AC LO
	<04:06>	EMM unit number **
	<07>	Key OVERRIDE circuit status
		* 1 = MOD OK
		** 0 = KA86xx
6		MISCELLANEOUS HARDWARE STATUS REGISTER
	<00>	Air Flow 1 Sensor Status (1 = fault)
	<01>	BBU unit (1 = failure)
	<02>	Minus 2V CROBAR fault (1 = crobar)
	<03>	Air Flow 2 Sensor Status (1 = fault)
	<04>	Latched AC LO (1 = AC LO)
	<05>	Latched DC LO (1 = DC LO)
	<06>	Parity Bit
	<07>	Parity Error
7		MISCELLANEOUS SOFTWARE STATUS REGISTER
	<00>	External Output Signal (1 = asserted)
	<01>	Default Mode Enable (1 = enabled)
	<02>	Process Abort (1 = active)
	<03>	Interrupt Disable (1 = disabled)
	<04:07>	Reserved
8		EMM PROM VERSION NUMBER
	<07:00>	Integer value of the EMM PROM version
01	Response to System Environment Information Request. This operation returns 32 bytes which reflect all measured environmental information, which includes the voltage outputs of all regulators and temperature measurements at all sensors.	

TABLE 2 - EMM RESPONSE REPORTS (continued)

ID	INDICATION
01	(Continued)

NOTE

Values returned are in their digitized format and must be converted using the formulas below before being displayed or interpreted. The number in parentheses for each entry indicates which equation must be used to perform the conversion.

1. Volts = $.0276 * \text{MAGNITUDE}$
2. Milliamps = $70 + (2.8 * \text{MAGNITUDE})$
3. Volts = $.0762 * \text{MAGNITUDE}$
4. Volts = $.0691 * \text{MAGNITUDE}$
5. Degrees Celsius = $16 + (.3333 * \text{MAGNITUDE})$

o All numbers in equations are decimal.

BYTE	BITS	MEANING
0	<07:00>	Packet size = 32 bytes (10)
1	<07:00>	REGULATOR A (+5V TTL) Magnitude See note 1.
2	<07>	REGULATOR A (+5V TTL) Polarity 0 = Positive Polarity 1 = Negative Polarity
	<06:00>	Reserved
3	<07:00>	REGULATOR B (+5V BBU) Magnitude See Note 1.
4	<07>	REGULATOR B (+5V BBU) Polarity See Byte 2
	<06:00>	Reserved
5	<07:00>	REGULATOR C (+5V SBIA) Magnitude See Note 1.
6	<07>	REGULATOR C (+5V SBIA) Polarity See Byte 2
	<06:00>	Reserved
7	<07:00>	REGULATOR D (-2V ECL) Magnitude See Note 1.
8	<07>	REGULATOR D (-2V ECL) Polarity See Byte 2
	<06:00>	Reserved
9	<07:00>	REGULATOR E (-2V ECL) Magnitude See Note 1.

VAX 8600/8650 REGISTER DESCRIPTION
RXDB




TABLE 2 - EMM RESPONSE REPORTS (continued)

ID	INDICATION	
01	(Continued)	
BYTE	BITS	MEANING
10	<07> <06:00>	REGULATOR E (-2V ECL) Polarity See Byte 2 Reserved
11	<07:00>	REGULATOR F (-5.2V ECL) Magnitude See Note 1.
12	<07> <06:00>	REGULATOR F (-5.2V ECL) Polarity See Byte 2 Reserved
13	<07:00>	REGULATOR H (-5.2V ECL) Magnitude See Note 1.
14	<07> <06:00>	REGULATOR H (-5.2V ECL) Polarity See Byte 2 Reserved
15	<07:00>	GROUND CURRENT Magnitude See Note 2.
16	<07> <06:00>	GROUND CURRENT Polarity 0 = Positive Polarity 1 = Negative Polarity Reserved
17	<07:00>	REGULATOR L (+12V TTL) Magnitude See Note 3.
18	<07> <06:00>	REGULATOR L (+12V TTL) Polarity Always Positive (i.e., 0) Reserved
19	<07:00>	REGULATOR L (-12V TTL) Magnitude See Note 4.
20	<07> <06:00>	REGULATOR L (-12V TTL) Polarity Always Negative (i.e., 1) Reserved
21	<07:00>	REGULATOR K (+15V TTL) Magnitude See Note 3.
22	<07> <06:00>	REGULATOR K (+15V TTL) Polarity Always Positive (i.e., 0) Reserved


TABLE 2 - EMM RESPONSE REPORTS (continued)

ID	INDICATION	
01	(Continued)	
BYTE	BITS	MEANING
23	<07:00>	REGULATOR K (-15V TTL) Magnitude See Note 3.
24	<07> <06:00>	REGULATOR K (-15V TTL) Polarity Always Positive (i.e., 1) Reserved
25	<07:00>	THERMISTOR (T1) Magnitude See Note 5.
26	<07> <06:00>	THERMISTOR (T1) Polarity Always Negative (i.e., 1) Reserved
27	<07:00>	THERMISTOR (T2) Magnitude See Note 5.
28	<07> <06:00>	THERMISTOR (T2) Polarity Always Negative (i.e., 1) Reserved
29	<07:00>	THERMISTOR (T3) Magnitude See Note 5.
30	<07> <06:00>	THERMISTOR (T3) Polarity Always Negative (i.e., 1) Reserved
31	<07:00>	THERMISTOR (T4) Magnitude See Note 5
32	<07> <06:00>	THERMISTOR (T4) Polarity Always Negative (i.e., 1) Reserved

VAX 8600/8650 REGISTER DESCRIPTION

SBIA CONFIGURATION REGISTER

CONFIGURATION REGISTER
2008 000 2208 0000



408-1-001

<31:30> **MBZ (SS28)**
Must be zero.

<29:20> **MEMORY SEPARATOR**
SS28 MSR <27:18>

This field defines the memory address boundry and is equal to the number of megabytes of memory addressable over the ABUS. If bit 29 is asserted, there are 512 MBytes of memory and bits <28:20> are disregarded when the hardware checks the DMA address. These bits are bits <29:20> in the Memory Separator register, but within the SBIA they are shifted right by two bits to match the physical address.

<19:08> **MBZ (SS36)**
Must be zero.


<07:04> **ABUS ADAPTER TYPE**
BUS REG D<07:04> (SS28)
These bits identify the type of ABUS adapter, 0001 for the SBIA.

<03:00> **ABUS ADAPTER REVISION**
BUS REG D<03:00> (SS28)
These bits identify the revision of the ABUS adapter; these bits are hardwired.

VAX 8600/8650 REGISTER DESCRIPTION

SBIA CONTROL STATUS REGISTER

CONTROL AND STATUS REGISTER
2008 0004, 2208 0004



- <31> MASTER INTERRUPT ENABLE**
SS29 MSTR INTR ENA
 When set, this bit will enable the SBA module to prioritize the interrupts and generate the appropriate interrupt priority level for CPU polling.
- <30> ENA SBI CYCLES OUT**
SS29 ENA SBI OUT
 This bit must be set for normal operation. It enables the CPU to access SBI NEXUS registers. If the CPU attempts to access an SBI NEXUS register with this bit reset, it is an error condition, and ERROR SUMMARY register <20> and <19> will be set. See description of ERROR SUMMARY register.
- <29> ENA SBI CYCLES IN**
SS29 ENA SBI IN
 This bit must also be set for normal operation. It enables all DMA activity through the SBIA. If this bit is not set, the SBIA will not recognize SBI function codes and will not respond to SBI commands (SBI confirmation is 00, no response).
- <28> ZERO (SS33)**
 This read only bit will always be zero.
- <27:24> CPU TR SELECT <08:04>**
CPU TR SEL <08:04> (SS07)
 These bits provide backplane visibility of the jumpers used to select the SBI TR for CPU transactions. The contents of this field is the two's complement of the TR level.
- <23:00> ZERO (SS36)**
 These bits are always read as zero provided by the zero fill logic.

VAX 8600/8650 REGISTER DESCRIPTION SBIA DIAGNOSTIC CONTROL REGISTER

DIAGNOSTIC CONTROL REGISTER
2008 000C. 2208 000C

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
RO												R/W			
												FORCE DMA TRANSACTION BUFFER BUSY			
												DMAC		DMAA	

15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
RO							WO	WO	WO	RO	R/W	R/W	R/W	R/W	R/W
							CLEAR SILO ADDRESS	DISABLE SILO INCREMENT	DIAG DEAD		DISABLE SBI TIMEOUT	FORCE QUADWORD DATA	LOOP BACK MODE	FORCE STATE PARITY ERROR	ENABLE SHORT TIMEOUT

<31:20> MBZ (SS36)
Must be zero.

<19:16> FORCE DMA TRANSACTION BUFFER BUSY
SS29 FORCE DMAC (DMAB, DMAA, DMAI) BUSY
These bits are used to direct DMA traffic into specific DMA transaction buffers by forcing other buffers to be busy. The state of these bits has no effect on a DMA transaction already in progress.

<15:09> MBZ (SS32)
Must be zero.

<08> CLEAR SILO ADDRESS
SS19 CLR SILO ADR
This bit will clear the silo address upon setting. When this register is read, this bit will always be zero (hardwired).

<07> DISABLE SILO INCREMENT
SS29 DISABLE SILO INC
When set, this bit will prevent the silo address from incrementing. This bit will be reset during normal operations to allow the silo address to increment. This bit is also read as zero.

<06> DIAGNOSTIC DEAD
SS29 DIAG DEAD
When this bit sets, it will simulate ABUS DEAD, interrupting the console and causing a reboot. ABUS DEAD is normally asserted by SBI FAIL. This bit is also read as zero.

<05> MBZ (SS30)
Must be zero.

<04> DISABLE SBI TIMEOUT
SS29 DISABLE SBI TMO
When set for diagnostics, this bit will prevent a timeout condition while waiting for the SBIA to gain control of the SBI, while waiting an acknowledgment from a NEXUS or while waiting for CPU read data.

<03> FORCE QUADWORD DATA
SS29 FORCE QUAD DATA
This bit is used by microdiagnostics with bit <02> (Loop Back Mode), to provide a way to use a quadclear to loop data back on the SBI. FORCE QUAD DATA is set, then the CPU will execute a quadclear, but for microdiagnostics, the address will be a memory address instead of an SBI address (bit 27 is clear).

VAX 8600/8650 REGISTER DESCRIPTION
SBIA DIAGNOSTIC CONTROL REGISTER

The ABUS command/address is the same; it specifies a CPU write to the quadclear register. The ABUS write data is the same except for the address, which will be for a memory (cache) address. When the command/address is transmitted on the SBI it will be received by the SBIA, as it always is, but in this case, the address will be less than the configuration register. To the SBIA it looks like a DMA extended write mask to memory and it will be handled as such.

For a normal quadclear, the write data is forced to all zeros. In this case, FORCE QUAD DATA will enable the A-Data Assembly Multiplexers to transfer the contents of the Write Data Latch (the ABUS Write Data, 1011 and the Quadword Boundary Address) to the SBI. When the second write data longword is transferred to the SBI transceivers, bits 30 and 27 will be toggled (set). This will allow the setting of all data bits on the SBI.

<02>

LOOP BACK MODE

SS29 LOOP BACK MODE

This bit is used by microdiagnostics to allow a CPU read or write to be looped back in the SBIA. The PAMM has to be configured such that a memory (cache) address is mapped to an I/O adapter, and the same PAMM address, but with bits 27 and 28 inverted, is mapped to a memory address.

In the SBIA, LOOP BACK MODE will invert address bits 25 and 26, if bit 27 is reset, which will be the case if the CPU write is to a memory address.

When the CPU writes a memory location that is mapped to an I/O adapter, the MBox will write the command/address and write data longword into the register file. The SBIA will carry out the command like a normal CPU write. When the command/address is transferred from the command/address latch to the SBI, because LOOP BACK MODE is set and address bit 27 is reset, address bits 25 and 26 will be inverted.

The command/address, followed by the write data will be transmitted on the SBI. When the SBIA clocks the SBI receivers and looks at the received data, the address is less than the memory separator (in the configuration register), it will transfer the command/address and write data to the register file and request MBox service.

The MBox will write the data into memory because the address, with bits 27 and 28 inverted (bits 25 and 26 in the SBIA), addresses a different PAMM location. This location is mapped to memory.

This diagnostic bit can also be used with a CPU read in a similar manner to further check out the SBIA logic.

<01>

FORCE STATE PARITY ERROR

SS29 FORCE STATE PTY

If this bit is set, a state machine parity error will be forced during the CPU ARB WAIT state.

<00>

ENABLE SHORT TIMEOUT



SS29 ENA SHORT TIMEOUT

When set, this bit will enable an SBI timeout in 8 SBI cycles instead of the normal 512 cycles. This bit is read as a zero.

VAX 8600/8650 REGISTER DESCRIPTION SBIA DMA COMMAND/ADDRESS REGISTER

DMA COMMAND/ADDRESS REGISTER

DMAI	DMAA	DMAB	DMAC
2008 0010	2008 0018	2008 0020	2008 0028
2208 0010	2208 0018	2208 0020	2208 0028



801-1-0055

These four registers (DMAACA, DMABCA, DMACCA, and DMAICA) are used to save information about transactions in the DMA buffers. Each time a command/address is loaded into a DMA buffer, a copy of the command/address and SBI ID of the commander is saved in the two registers corresponding to the DMA buffer. If an error is detected by the MBox or the SBIA after the transaction is confirmed, the two registers are locked.

<31:00> RECEIVED SBI COMMAND/ADDRESS



BUS REG <31:00> (SS32, SS33)

Each time a command/address is loaded into a DMA transaction buffer in the DC022, that command/address is also loaded into the corresponding DMA Command/Address error register. These error registers are actually TTL register files that are addressed by the upper two bits of the DC022 write address. SBI B <31:00> are written in these registers, with bits <31:28> being the SBI command codes and bits <27:00> the longword address. These error registers are locked if the SBIA or MBox detects a DMA error.

VAX 8600/8650 REGISTER DESCRIPTION SBIA DMA ID

DMA ID REGISTER

DMAI 2008 0014 2208 0014	DMAA 2008 001C 2208 001C	DMAB 2008 0024 2208 0024	DMAC 2008 002C 2208 002C
--------------------------------	--------------------------------	--------------------------------	--------------------------------



VM 1-100

These four registers (DMAAID, DMABID, DMACID, and DMAID) are used to save information about transactions in the DMA buffers. Each time a command/address is loaded into a DMA buffer, a copy of the command/address and SBI ID of the commander is saved in the two registers corresponding to the DMA buffer. If an error is detected by the MBox or the SBIA after the transaction is confirmed, the two registers are locked.

<31:08> MBZ (SS36)
Must be zero.

<07:00> RECEIVED SBI IDENTIFICATION
BUS REG <07:00> <SS23>

Each time a command/address is loaded into a DMA transaction buffer in the DC022, the SBI ID is also loaded into the corresponding DMA ID error register, an extension of the DMA command/address error registers. These error registers are TTL register files like the command/address error registers, and addressed the same way, by the upper two bits of the DC022 write address. Bits <07:05> have the inputs at ground potential so they will always be read as zero. Bits <04:00> are loaded with REC SBI ID <04:00>. Like the DMA command/address error registers, these registers are locked if the SBIA or MBox detects a DMA error.

VAX 8600/8650 REGISTER DESCRIPTION SBIA ERROR SUMMARY

ERROR SUMMARY REGISTER
0008 0008, 2208 0008

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
COMMAND								CPU BUFFER ERROR LOCK	CPU A/D PARITY ERROR	CPU CONTROL PARITY ERROR	CPU ADDRESS ERROR	ERROR DETECTED ON CIA	STATE MACHINE PARITY ERROR	0	MULTIPLE CPU ERROR
03	02	01	00	01	00	0	0								
R/W								R/W	RO	RO	RO	RO	R/W	RO	RO

15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
DMAC TRANSACTION BUFFER				DMAB TRANSACTION BUFFER				DMAA TRANSACTION BUFFER				DMAI TRANSACTION BUFFER			
0	SBIA DETECTED A/D PE	SBIA DETECTED CNTRL PE	MBOX DETECTED ERROR	0	SBIA DETECTED A/D PE	SBIA DETECTED CNTRL PE	MBOX DETECTED ERROR	0	SBIA DETECTED A/D PE	SBIA DETECTED CNTRL PE	MBOX DETECTED ERROR	INTER-LOCK TIMEOUT	SBIA DETECTED A/D PE	SBIA DETECTED CNTRL PE	MBOX DETECTED ERROR
R/W															

The error summary register contains most of the information about errors which have been detected by the SBIA on transactions involving the SBIA.

- <31:28> **COMMAND <03:00>**
BUS REG D<31:28> (SS26)
 These bits represent the ABus command bits for a CPU I/O register read/write. They are loaded each time the command/address latch is loaded, and are latched by CPU ERROR LOCK, bit <23>.
- <27:26> **LENGTH/STATUS <01:00>**
BUS REG <27:26> (SS26)
 These bits represent the ABus data length for a CPU I/O register read/write. They are also loaded each time the command/address latch is loaded, and are latched by CPU ERROR LOCK, bit <23>.
- <25:24> **MBZ**
 Must be zero.
- <23> **CPU BUFFER ERROR LOCK**
SS37 CPU ERROR LOCK
 This bit will be asserted for any of the following errors on a CPU I/O read/write.
1. A/D Parity Error (bit <22>)
 2. Control Parity Error (bit <21>)
 3. Address Error (bit <20>)
 4. CPU read/write timeout on SBI (SBI Error Register bit <12>)
 5. SBI Error (SBI Error Register <08>)
- If this bit is set, Error Summary Register <31:26> and the Timeout Address Register are latched. If clear, these bits will represent the most recent transaction. Writing this bit will clear Error Summary Register <22:19,16>.
- <22> **CPU A/D PARITY ERROR**
SBAN A/D PTY BAD
 This bit is set if a parity error is detected on the address/data bits of the command/address or write data for a CPU I/O read/write. If the error is detected on the command/address, bit <19> will also be set. Parity is checked on the output of the file data latch. If this bit sets, bit <23> is set. This bit is cleared when the CPU writes bit <23>.

- <21> CPU CONTROL PARITY ERROR
SBAN CNTRL PTY BAD
This bit is set if a parity error is detected on the control field of the command/address or write data for a CPU I/O read/write. If the error is detected on the command/address cycle, bit <19> will also be set. Parity is checked on the output of the file data latch. If this bit sets, bit <23> is also set. This bit is also cleared when the CPU writes bit <23>.
- <20> CPU ADDRESS ERROR
SS38 LOCAL ADR ERR
This bit is set if the CPU accesses a nonexistent SBIA register or when an SBI NEXUS register is accessed when Control/Status Register <30> is clear (CPU access to the SBI is disabled). When it sets, it will set bit <23>, and it is cleared when the CPU writes bit <23>. This error will be detected when the command/address word is available, so bit <19> should also be set.
- <19> ERROR DETECTED ON COMMAND/ADDRESS CYCLE
SBAN ERR ON C/A
This read only bit is set if a address/data, control parity, or address error is detected on the command/address cycle. The setting of this bit will set bit <23>. This bit will be reset when the CPU writes a one to bit <23>.
- <18> STATE MACHINE PARITY ERROR
SBAO FORCE PARITY TRAP
This error bit will be set if the state machine microword does not contain even parity. The occurrence of this error will cause a CPU transaction to be aborted, if one is in progress, and generate an interrupt. A state machine parity error can occur if no CPU transaction is in progress so it will not set bit <23>.
- <17> MBZ (SS33)
Must be zero.
- <16> MULTIPLE CPU ERROR
SBAN MULT CPU ERR
This bit can only be set if bit <23> is already set and a CPU addressing error is detected on the command/address cycle or there is an address/data or control parity error on the command/address or write data. This bit will not be set for a write data parity error for the transaction that sets bit <23>, but for a subsequent transaction. Bit <16> is reset when the CPU writes bit <23>.
- <15> MBZ (SS32)
Must be zero.
- <14> DMAC TRANSACTION BUFFER SBIA DETECTED A/D PARITY ERROR
SS30 DMAC A/D ERROR
This bit will be set for a data parity error when the read data is being transferred from transaction buffer C to the SBI during a DMA read. This bit cannot be set if bits <13> or <12> have been previously set. This bit is cleared by the CPU writing it. The DMAC Command/Address Register and DMAC ID Register will be locked if this bit sets. The setting of this bit will generate a local interrupt.

VAX 8600/8650 REGISTER DESCRIPTION

SBIA ERROR SUMMARY

ERROR SUMMARY REGISTER
2008 0008 2208 0008

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
COMMAND				LENGTH/STATUS		U	U	CPU BUFFER ERROR LOCK	CPU A/D PARITY ERROR	CPU CONTROL PARITY ERROR	CPU ADDRESS ERROR	ERROR DETECTED ON SBI	STATE MACHINE PARITY ERROR	0	MULTIPLE LUI ERROR
03	02	01	00	01	00										
R0								R/W	R0	R0	R0	R0	R/W	R0	R0

15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
DMAC TRANSACTION BUFFER				DMAB TRANSACTION BUFFER				DMAA TRANSACTION BUFFER				DMAL TRANSACTION BUFFER			
0	SBIA DETECTED A/D PE	SBIA DETECTED CNTRL PE	MBOX DETECTED ERROR	0	SBIA DETECTED A/D PE	SBIA DETECTED CNTRL PE	MBOX DETECTED ERROR	0	SBIA DETECTED A/D PE	SBIA DETECTED CNTRL PE	MBOX DETECTED ERROR	INTER- LOCK TIMEOUT	SBIA DETECTED A/D PE	SBIA DETECTED CNTRL PE	MBOX DETECTED ERROR
R/W															

<13> DMAC TRANSACTION BUFFER SBIA DETECTED CONTROL PARITY ERROR SS30 DMAC CONTROL ERROR

This bit will be set for a control parity error when the read data is being transferred from transaction buffer C to the SBI during a DMA read. This bit cannot be set if bits <14> or <12> have been previously set. This bit is cleared by the CPU writing it. The DMAC Command/Address Register and DMAC ID Register will be locked if this bit sets. The setting of this bit will generate a local interrupt.

<12> DMAC TRANSACTION BUFFER MBOX DETECTED ERROR SS30 DMAC MBOX ERR

This bit will be set if the MBox detects a parity error or NXM on the transfer of command/address from the DMAC transaction buffer. This bit cannot be set if bits <14> or <13> have been previously set. This bit is cleared by the CPU writing it. The DMAC Command/Address Register and DMAC ID Register will be locked if this bit sets. The setting of this bit will generate a local interrupt.

<11> MBZ Must be zero.

<10> DMAB TRANSACTION BUFFER SBIA DETECTED A/D PARITY ERROR SS30 DMAB A/D ERROR

This bit will be set for a data parity error when the read data is being transferred from transaction buffer B to the SBI during a DMA read. This bit cannot be set if bits <09> or <08> have been previously set. This bit is cleared by the CPU writing it. The DMAB Command/Address Register and DMAB ID Register will be locked if this bit sets. The setting of this bit will generate a local interrupt.

<09> DMAB TRANSACTION BUFFER SBIA DETECTED CONTROL PARITY ERROR SS30 DMAB CONTROL ERROR

This bit is set for a control parity error when the read data is being transferred from transaction buffer B to the SBI during a DMA read. This bit cannot be set if bits <10> or <08> have been previously set. This bit is cleared by the CPU writing it. The DMAB Command/Address Register and DMAB ID Register will be locked if this bit sets. The setting of this bit will generate a local interrupt.

- <08> DMAB TRANSACTION BUFFER MBOX DETECTED ERROR**
SS30 DMAB MBOX ERR
 This bit is set if the MBox detects a parity error or NXM on the transfer of command/address from the DMAB transaction buffer. This bit cannot be set if bits <10> or <09> have been previously set. This bit is cleared by the CPU writing it. The DMAB Command/Address Register and DMAB ID Register will be locked if this bit sets. The setting of this bit will generate a local interrupt.
- <07> MBZ**
 Must be zero.
- <06> DMAA TRANSACTION BUFFER SBIA DETECTED A/D PARITY ERROR**
SS30 DMAA A/D ERROR
 This bit is set for a data parity error when the read data is being transferred from transaction buffer A to the SBI during a DMA read. This bit cannot be set if bits <05> or <04> have been previously set. This bit is cleared by the CPU writing it. The DMAA Command/Address Register and DMAA ID Register will be locked if this bit sets. The setting of this bit will generate a local interrupt.
- <05> DMAA TRANSACTION BUFFER SBIA DETECTED CONTROL PARITY ERROR**
SS30 DMAA CCNTRL ERR
 This bit is set for a control parity error when the read data is being transferred from transaction buffer A to the SBI during a DMA read. This bit cannot be set if bits <06> or <04> have been previously set. This bit is cleared by the CPU writing it. The DMAA Command/Address Register and DMAA ID Register will be locked if this bit sets. The setting of this bit will generate a local interrupt.
- <04> DMAA TRANSACTION BUFFER MBOX DETECTED ERROR**
SS30 DMAA MBOX ERR
 This bit is set if the MBox detects a parity error or NXM on the transfer of command/address from the DMAA transaction buffer. This bit cannot be set if bits <06> or <05> have been previously set. This bit is cleared by the CPU writing it. The DMAA Command/Address Register and DMAA ID Register will be locked if this bit sets. The setting of this bit will generate a local interrupt.
- <03> DMAI TRANSACTION BUFFER INTERLOCK TIMEOUT**
SS30 DMAI TIMEOUT
 This bit is set if an interlock write masked does not occur within 512 SBI cycles (102.4 microseconds) after an interlock read masked. This bit cannot be set if bits <02>, <01>, or <00> have been previously set. The setting of this bit will generate a local interrupt. This bit is cleared by the CPU writing it. The DMAI Command/Address and DMAI ID Register will be locked if this bit sets.
- <02> DMAI TRANSACTION BUFFER SBIA DETECTED A/D PARITY ERROR**
SS30 DMAI A/D ERROR
 This bit is set for a data parity error when the read data is being transferred from transaction buffer I to the SBI during a DMA interlock read. This bit cannot be set if bits <03>, <01>, or <00> have been previously set. This bit is cleared by the CPU writing it. The DMAI Command/Address and DMAI ID Register will be locked if this bit sets. The setting of this bit will generate a local interrupt.

VAX 8600/8650 REGISTER DESCRIPTION SBIA ERROR SUMMARY SBIA SBI ERROR REGISTER

ERROR SUMMARY REGISTER
2008 0008, 2208 0008

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
COMMAND				LENGTH/STATUS		0	0	CPU BUFFER ERROR LOCK	CPU A/D PARITY ERROR	CPU CONTROL PARITY ERROR	CPU ADDRESS ERROR	ERROR DETECTED ON G/A	STATE MACHINE PARITY ERROR	0	MULTIPLE CPU ERROR
03	02	01	00	01	00										
R/W								R/W	RO	RO	RO	RO	RO	R/W	RO

15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
DMAI TRANSACTION BUFFER				DMAI TRANSACTION BUFFER				DMAI TRANSACTION BUFFER				DMAI TRANSACTION BUFFER			
0	SBIA DETECTED A/D PE	SBIA DETECTED CNTRL PE	MBOX DETECTED ERROR	0	SBIA DETECTED A/D PE	SBIA DETECTED CNTRL PE	MBOX DETECTED ERROR	0	SBIA DETECTED A/D PE	SBIA DETECTED CNTRL PE	MBOX DETECTED ERROR	INTER-LOCK TIMEOUT	SBIA DETECTED A/D PE	SBIA DETECTED CNTRL PE	MBOX DETECTED ERROR
R/W								R/W	RO	RO	RO	RO	RO	RO	RO

MSB-1003.1

<01> DMAI TRANSACTION BUFFER SBIA DETECTED CONTROL PARITY ERROR SS30 DMAI CNTRL ERROR

This bit is set for a control parity error when the read data is being transferred from transaction buffer I to the SBI during a DMA interlock read. This bit cannot be set if bits <03:02> or <00> have been previously set. This bit is cleared by the CPU writing it. The DMAI Command/Address Register and DMAI ID Register will be locked if this bit sets. The setting of this bit will generate a local interrupt.

<00> DMAI TRANSACTION BUFFER MBOX DETECTED ERROR SS30 DMAI MBOX ERR

This bit is set if the MBox detects a parity error or NXM on the transfer of command/address from the DMAI transaction buffer. This bit cannot be set if bits <03>, <02>, or <01> have been previously set. This bit is cleared by the CPU writing it. The DMAI Command/Address Register and DMAI ID Register will be locked if this bit sets. The setting of this bit will generate a local interrupt.

SBI ERROR REGISTER
2008 0034, 2208 0034

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
RO															

15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
0	0	0	CP TIMEOUT	CP TIMEOUT STATUS <01>	CP TIMEOUT STATUS <00>	0	CP SBI ERROR CONF	0	0	0	0	0	0	0	0
RO			R/W	R/W	RO	RO	RO	RO							

MSB-1003.2

The SBI error register stores information about CPU transactions which failed on the SBI due to timeout or error confirmation.

<31:16> ZERO (SS36)

These bits are read as zeros provided by the zero fill logic.

<15:13> ZERO (SS32)

These read only bits are forced to zero by hardware ground potential.

<12>

CP TIMEOUT

BUS REG D<12> (SS32)

This bit will be set when there is an SBI timeout on a CPU reference for one of the following reasons:

1. Unsuccessful access: When the SBIA does not receive an acknowledge confirmation for a CPU command/address or write data within 512 SBI cycles (102.4 microseconds) from the time the SBIA first requests the SBI. Unsuccessful access can be caused by the following:
 - a. SBIA is unable to win the SBI through bus arbitration
 - b. Target NEXUS is always busy when accessed
 - c. The address is for a non-existent device or address
 - d. Combinations of the first two
2. If the SBIA does not receive the read data within 512 SBI cycles of the acknowledge for the command/address, it is a read data timeout.

When this bit sets, Error Summary Register <23> will be set, locking Error Summary Register <31:26> (type of reference), SBI Error Register <11:10, 08>, and the Timeout Address Register (referenced address). This bit is reset when the CPU writes it to a one. This will also reset <11:10, 08>.

<11:10> CP TIMEOUT STATUS <01:00>

BUS REG D <11:10> (SS32)

The timeout status bits are made up of two signals as follows:

1. Bit <01>: State machine is in the read pending state.
2. Bit <00>: SBI confirmation equals 01, busy.

Together these two signals indicate the type of SBI timeout.

- a. 00: SBI NEXUS did not respond (No Response)
- b. 01: Device was busy (Busy)
- c. 10: Waiting for read data
- d. 11: Cannot happen

These bits are locked by Error Summary Register <23>, and reset when the CPU writes SBI Error Register <12>.

<09> ZERO (SS32)

These read only bits are forced to zero by hardware ground potential.

<08> CPU SBI ERROR CONFIRMATION

BUS REG D <08> (SS32)

This bit is set when the SBI state machine enters the error abort state if the SBI NEXUS has returned an error confirmation on a CPU read/write command/address cycle. If this bit is set, Error Summary Register <23> will be set, locking the Timeout Address Register, Error Summary Register <31:26>, and bits <12:10> of this register. This bit is reset when the CPU writes bit <12>.

<07:00> ZERO (SS32)

These read only bits are forced to zero by hardware ground potential.

VAX 8600/8650 REGISTER DESCRIPTION SBIA SBI FAULT STATUS REGISTER

SBI FAULT/STATUS REGISTER
200B 003C 220B 003C

SBISTS

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
SBI PARITY FAULT	WRITE SEQUENCE FAULT	UNEXPCD READ DATA FAULT	INTER- LOCK SEQUENCE FAULT	MULTIPLE TRANSMITTER FAULT	SBI XMITTER DURING FAULT	0	0	SBI P1 PARITY ERROR	SBI P0 PARITY ERROR	0	0	FAULT LATCH	FAULT INTERUPT ENABLE	SBI FAULT WIRE	FAULT SLO LOCK
RO												R/W	R/W	RO	RO

15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
RO															

The SBI fault/status register saves information on SBI faults on transactions in which the SBIA may or may not have been involved. All SBI devices monitor the SBI every cycle and check for errors. If an error is detected, the Fault wire is asserted and a fault/status register (part of the configuration register for non-CPU devices) is locked.


- <31> **SBI PARITY FAULT**
 SBI1 FAULT REG B <31>
 This bit will set if the SBIA detects an SBI parity error on received SBI information. Bits <23:22> will indicate whether it was an address/data or control parity error. The register is written every SBI cycle, and locked when SBI FAULT is asserted. This bit will be cleared when SBI FAULT is deasserted. This bit is only valid if bit <19> is set.
- <30> **WRITE SEQUENCE FAULT**
 SBI1 FAULT REG B <30>
 This bit is set if the SBIA is expecting write data, and receives SBI information, with no parity error, but the tag does not indicate write data (101). This bit is also locked when SBI FAULT is asserted, and clears when SBI FAULT clears. This bit is only valid if bit <19> is set.
- <29> **UNEXPECTED READ DATA**
 SBI1 FAULT REG B <29>
 This bit sets if the SBIA receives information with the SBIA ID (10000) with a read data tag (000), but the SBIA is not expecting read data (no read pending). This bit is locked when SBI FAULT is asserted, and clears when SBI FAULT clears. This bit is only valid if bit <19> is set.
- <28> **INTERLOCK SEQUENCE FAULT**
 SBI1 FAULT REG B <28>
 This bit is set if the SBIA receives a valid command/address for an interlock write masked but the interlock flip-flop is not set (an interlock read has not occurred). This bit is also locked when SBI FAULT is asserted, and clears when SBI FAULT clears. This bit is only valid if bit <19> is set.
- <27> **MULTIPLE TRANSMITTER FAULT**
 SBI1 FAULT REG B <27>
 This bit will set if the SBIA detects an ID that is not the same as the ID it transmitted on the SBI. This bit is also locked when SBI FAULT is asserted, and clears when SBI FAULT clears. This bit is only valid if bit <19> is set.

- <26> SBI TRANSMITTER DURING FAULT**
SS11 FAULT REG B <26>
This bit sets when the SBIA was the nexus transmitting on the SBI. This bit is locked when SBI FAULT is asserted, and clears when SBI FAULT clears. This bit is only valid if bit <19> is set.
- <25:24> MBZ (SS33)**
Must be zero.
- <23> SBI P1 PARITY ERROR**
SS11 FAULT REG B <23>
This bit indicates that an SBI parity error was over SBI B <31:00>. It is only valid if bit <19> is set. It is locked when SBI FAULT is asserted, and will clear when SBI FAULT clears.
- <22> SBI P0 PARITY ERROR**
SS11 FAULT REG B <22>
This bit indicates that an SBI parity error was over SBI TAG <02:00>, SBI ID <04:00>, and SBI MASK <03:00>. It too, is only valid if bit <19> is set, and is locked when SBI FAULT is set. It will clear when SBI FAULT clears.
- <21:20> MBZ (SS33)**
Must be zero.
- <19> FAULT LATCH**
BUS REG D <19> (SS33)
If an SBI nexus, including the SBIA, detects an SBI fault, the nexus will assert SBI FAULT. The SBIA, upon reception of SBI FAULT will set the fault latch, which will keep SBI FAULT asserted. It will remain asserted until the CPU clears the fault latch by writing a one to bit <19>. SBI FAULT will be asserted for the following SBI error conditions:
1. Interlock sequence fault
 2. Unexpected read fault
 3. Write sequence fault
 4. Multiple transmitter fault
 5. Parity fault
- When this bit sets, Fault/Status Register <31:26> and <23:22> will be locked.
- <18> FAULT INTERRUPT ENABLE**
SS21 FAULT INTR ENA
The CPU will set this bit by writing bit <17> to enable an SBI fault to generate an interrupt. The interrupt will be asserted if the fault latch, bit <19>, is set.
- <17> SBI FAULT WIRE**
SS33 BUS REG D <17>
This bit indicates the state of the SBI FAULT signal.
- <16> FAULT SILO LOCK**
SS33 BUS REG D <16>
This bit will be set when the silo locks due to an SBI fault. It will be reset when the CPU resets the fault latch, bit <19>.
- <15:00> MBZ (SS36)**
Must be zero.

VAX 8600/8650 REGISTER DESCRIPTION

SBIA SBI MAINT REG

SBIA MAINTENANCE REGISTER
2008 0044: 2208 0044



MR-1482

This register is used as a diagnostic and maintenance tool. Operational software does not use this register.

- <31> FORCE PO REVERSAL**
SS24 FRC PO REV ON SBI
When set, this bit will cause the SBIA to transmit bad PO parity on the SBI for all SBIA to SBI transactions. This includes CPU read/write and DMA read data.
- <30> FORCE WRITE SEQUENCE FAULT**
SS24 FORCE WSQ FAULT
When set, this bit will force SBI TAG <01> to a logic 1. When used with a CPU write to an SBI nexus register, it will force the write data tag to 111, the diagnostic tag. This will cause a write sequence fault because SBI devices are looking for a tag of 101, write data.
- <29> FORCE UNEXPECTED READ FAULT**
SS24 FORCE UNEXP READ
When this bit is set, the maintenance ID, bits <27:23>, with a TAG of zero, will be repeatedly transmitted on the SBI (the data is undefined). When the nexus, as selected by the maintenance ID, receives read data (TAG = 0), it should assert BUS SBIT FAULT because of the unexpected read data.
- <28> FORCE MULTIPLE TRANSMITTER FAULT**
SS24 FORCE MULTI
Setting this bit forces a multiple transmitter fault in any selected nexus. The CPU will load the maintenance ID with the ID of the selected nexus, then read that nexus configuration register. On the cycle after the command/address is transmitted on the SBI, the SBIA will enable the SBI to continually transmit a TAG = 111 with the maintenance ID (data is undefined).
- When the nexus transmits the read data, the ID transmitted by the nexus is the SBIA's ID. It will be ORED with the maintenance ID, and as long as the bits are not masked, will cause the nexus to detect a multiple transmitter fault.
- <27:23> MAINTENANCE ID <04:00>**
SS24 MAINT ID <04:00>
These bits are used to generate the maintenance ID in the following instances:

1. Generation of unexpected read fault
2. Generation of multiple transmitter fault
3. Used by the silo as the compare ID
4. Used to check ID logic

- <22:12> MBZ (SS33, SS36, SS32)
Must be zero.
- <11> FORCE P1 REVERSAL ON SBI
SS24 FRC P1 REV ON SBI
When set, this bit will cause the SBIA to transmit bad P1 parity on the SBI for all SBIA to SBI transactions. This includes CPU read/write and DMA read data.
- <10:09> MBZ (SS32)
Must be zero.
- <08> FORCE READ DATA TIMEOUT
SS24 FORCE TIMEOUT
This bit will preset the state machine timeout counter to all ones when the state machine enters the read wait start state. The timer will expire on the first count, generating a timeout condition while waiting for CPU read data.
- <07:05> MBZ (SS32)
Must be zero.
- <04> FORCE SBI INTERRUPT REQUEST
SS24 MAINT REQ ENA
When set, this bit will enable SBI Silo Comparator Register <07:04> and <03> to force interrupt requests and ALERT on the SBI.
- <03> FORCE TR SEQUENCE
SS24 FORCE TR SEQ
This bit will enable SBI Silo Comparator Register <15:00> to assert TR <15:00> on the SBI when a CPU Command/Address is transmitted. It is used in conjunction with a loop back read to test the SBIA and SBI nexus arbitration logic.
- <02> FORCE MAINTENANCE TR
SS24 FORCE MAINT TR
This bit will unconditionally assert the TR corresponding to SBI Silo Comparator Register <15:00>.
- <01> FORCE INTERRUPT SUMMARY READ DATA
SS24 FORCE ISR DATA
This bit is used to enable the SBIA to respond to an interrupt summary read to check out the circuitry that prioritizes the ISR data and generates the vectors.
- During the response cycle of an interrupt summary read, the SBIA will enable the write data latch to be transmitted on the SBI along with a TAG, MASK, and ID of zero.
- <00> USE MAINTENANCE ID
SS24 USE MAINT ID
This bit will enable the use of the maintenance ID, bits <27:23> for diagnostic purposes.

VAX 8600/8650 REGISTER DESCRIPTION SBIA SBI QUADCLR REGISTER

SBI QUADCLEAR REGISTER
2008 004C 2208 004C

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
SBI FUNCTION CODE					QUADWORD ALIGNED PHYSICAL ADDRESS										
1	0	1	1	0	ADR <26>, ADR <25>, ADR <24>, ADR <23>, ADR <22>, ADR <21>, ADR <20>, ADR <19>, ADR <18>, ADR <17>, ADR <16>										

15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
QUADWORD ALIGNED PHYSICAL ADDRESS															
ADR <15>, ADR <14>, ADR <13>, ADR <12>, ADR <11>, ADR <10>, ADR <09>, ADR <08>, ADR <07>, ADR <06>, ADR <05>, ADR <04>, ADR <03>, ADR <02>, ADR <01>, ADR <00>															

The purpose of the quadclear register is to clear ECC errors in SBI memory. The quadclear register does not exist as a physical register. When the CPU writes the SBI Quadclear Register, the CPU register address, in the command/address, is decoded as a quadclear operation. The write data is used to generate the SBI command/address. Two longwords of all zero data is supplied by the SBIA.

<31:28> SBI FUNCTION CODE

Bits <31:28> must be 1011, as they will become the SBI function code, extended write masked. If this register is read, the quadclear is not done, and the read data will be all zeros supplied by the zero fill logic.

<27> MBZ

Must be zero. This bit is written as zero because the address must be a memory address, not an I/O address. This bit is also read as a zero provided by the zero fill logic.

<26:00> QUADWORD ALIGNED PHYSICAL ADDRESS - ADR <26:00>

These bits will become the quadword address in the command/address. This bit is also read as a zero provided by the zero fill logic.

VAX 8600/8650 REGISTER DESCRIPTION

SBIA SBI SILO

SBI SILO REGISTER
2008 0030, 2208 0030

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
AFTER FAULT	RECEIVED SBI INTER- LOCK	RECEIVED SBI ID <04:00>					RECEIVED SBI TAG <02:00>			RECEIVED SBI MASK OR FUNCTION				RECEIVED SBI CONF <01:00>	
		ID<04>	ID<03>	ID<02>	ID<01>	ID<00>	TAG<02>	TAG<01>	TAG<00>	MASK<03> OR SBI B<31>	MASK<02> OR SBI B<30>	MASK<01> OR SBI B<29>	MASK<00> OR SBI B<28>	CONF<01>	CONF<00>
RO															

15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
RECEIVED TR <15:00>															
TR<15>	TR<14>	TR<13>	TR<12>	TR<11>	TR<10>	TR<09>	TR<08>	TR<07>	TR<06>	TR<05>	TR<04>	TR<03>	TR<02>	TR<01>	TR<00>
RO															

MS-1457

The SBI silo is a read only register file that provides temporary storage of various SBI signals for the last 16 SBI cycles.

The assertion of SBI FAULT by any SBI nexus locks the silo, sets FAULT SILO LOCK in the SBI FAULT/STATUS register, and makes the data available through the SILO register. The silo may also be locked using the SBI COMPARE register. See DB86 SBIA Technical Description, EK-DB86X-TD for a description of the SILO. An example of silo interpretation follows the register description.

<31> AFTER FAULT
BUS REG D<31> (SS20)
SBI silo bit <31> is loaded with AFTER FAULT, an indication that the SBI fault condition has cleared. AFTER FAULT is only asserted for one SBI cycle, and will be written into the first silo location after the fault clears. It may be used to recognize frequently occurring fault conditions.

<30> RECEIVED SBI INTERLOCK
BUS REG D<30> (SS20)
Silo bit <30> is loaded with REC SBI INTLK from the SBI transceivers.

<29:25> RECEIVED SBI ID <04:00>
BUS REG D<29:25> (SS20)
Silo bits <29:25> are loaded with REC SBI ID <04:00>, an indication of which nexus is in control of the SBI. See the table that follows.

ID CODE	DEVICE	TR
--	--	0*
--	SBIA (DMA)	1**
16	SBIA (CPU)	2***
3	DW780	3
4	DW780	4
5	DW780	5
6	DW780	6
7		7
8	RH780	8
9	RH780	9
10	RH780	10
11	RH780	11
12		12
13	CI780	13
14	DR780	14
15		15
--		16

VAX 8600/8650 REGISTER DESCRIPTION

SBIA SBI SILO

SBI SILO REGISTER
2008 0030, 2208 0030

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
AFTER FAULT	RECEIVED SBI INTER- LOCK	ID<04>	ID<03>	ID<02>	ID<01>	ID<00>	RECEIVED SBI TAG <02:00>		RECEIVED SBI TAG <02:00>	MASK<03> OR SBI B<31>	MASK<02> OR SBI B<30>	MASK<01> OR SBI B<29>	MASK<00> OR SBI B<28>	RECEIVED SBI CONF <01:00>	CONF<00>
RO															

15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
RECEIVED TR <15:00>															
TR<15>	TR<14>	TR<13>	TR<12>	TR<11>	TR<10>	TR<09>	TR<08>	TR<07>	TR<06>	TR<05>	TR<04>	TR<03>	TR<02>	TR<01>	TR<00>
RO															

MS-14861

Notes:

- A TR 0 is used to hold the SBI for the next SBI cycle.
- A TR 1 is used by the SBIA for DMA reads to transfer the read data return word to the SBI. The ID will be the ID of the device that originated the DMA read transaction.
- A TR 2 is used by the SBIA for CPU read/writes of SBI nexus registers.

<24:22> RECEIVED SBI TAG <02:00>

BUS REG D<24:22> (SS20)

Silo bits <24:22> are loaded with REC SBI TAG <02:00>, an indication of the type of SBI cycle as follows:

1. 000: Read Data
2. 011: Command/Address
3. 101: Write Data
4. 110: Interrupt Summary Read
5. 111: Diagnostic Tag

<21:18> RECEIVED SBI MASK OR FUNCTION

BUS REG D <21:18> (SS20)

The contents of silo bits <21:18> depend upon the SBI tag. If the tag is 011, command/address, the silo is loaded with the SBI function from bits <31:28>. Otherwise, the silo is loaded with the mask bits. The function codes are decoded as:

1. 0001: Read Masked
2. 0010: Write Masked
3. 0100: Interlock Read Masked
4. 0111: Interlock Write Masked
5. 1000: Extended Read
6. 1011: Extended Write Masked

The mask bit meanings for a command/address or write data are:

1. Mask <03> = 1: Read or write to byte 3
2. Mask <02> = 1: Read or write to byte 2
3. Mask <01> = 1: Read or write to byte 1
4. Mask <00> = 1: Read or write to byte 0

The mask bit meanings for read data are:

1. 0000: Valid read data
2. 0001: Corrected read data
3. 0010: Uncorrectable error

<17:16> RECEIVED SBI CONFIRMATION <01:00>

BUS REG D<17:16> (SS20)

Silo bits <17:16> are loaded with the SBI confirmation bits which have the following meanings:

1. 00: No response
2. 01: Acknowledge
3. 10: Busy
4. 11: Error on command/address

<15:00> RECEIVED SBI TRANSFER REQUEST <15:00>

BUS REG D<15:00> (SS19)

Silo bits <15:00> are loaded with any SBI transfer requests that may be asserted.

Example of interpreting a deposit byte to DW780 #0 at TR3.

D/B 2X006000 AA

The SILO may be read as follows:

REPEAT 16 EXAMINE 2X080030


The following information would appear in the silo if it was locked after 16 SBI cycles (or less) by SBI FAULT or by using the SILO COMPARE register. Note that the first silo location read would be the first location loaded. Only silo 4 locations are shown.

SILO CONTENTS	BREAKDOWN
20C80001	ID = 16, CPU; TAG = 3, C/A; FUNCTION = 0010, WRITE MASKED; TR = 0, HOLD
21440000	ID = 16, CPU; TAG = 5, WRITE DATA, MASK = 0001, WRITE BYTE 0
00010000	CONF = 01, ACK
00010000	CONF = 01, ACK

VAX 8600/8650 REGISTER DESCRIPTION

SBIA SBI SILO COMPARE

SBI SILO COMPARE REGISTER
2008 0040, 2208 0040





- <31> **COMPARATOR SILO LOCK**
SS21 CMP SILO LOCK
 The Comparator Silo Lock bit is set if the count in the silo counter has reached F. When this bit sets, the CPU will be interrupted if bit <30> is set. This bit is cleared when the CPU loads the silo count field with a count other than F.
- <30> **SILO LOCK INTERRUPT ENABLE**
SS25 SILO LOCK INTR EN
 The CPU sets this bit to enable an interrupt when bit <31>, CMP SILO LOCK, sets.
- <29> **LOCK UNCONDITIONAL**
SS25 LOCK UNCOND
 When this bit is set, the silo counter will count on each SBI cycle. It will cause a silo lock within 16 SBI cycles, depending upon the count that had been previously loaded into the silo count field.
- <28:27> **CONDITIONAL LOCK CODE <01:00>**
SS25 COND LOCK CODE <01:00>
 These two bits determine the comparisons that will enable counting the silo counter to achieve a silo lock. If the SBI data matches the silo comparator bits, for the enabled comparison, the counter is incremented. The conditions are as follows:
- 00: No compare (no comparison is made)
 - 01: SBI ID
 - 10: SBI ID and SBI TAG
 - 11: SBI ID and SBI TAG and SBI COMMAND/MASK
- <26:23> **COMPARATOR COMMAND/MASK**
SS25 COND CMD/MSK <03:00>
 These bits provide the base for the silo comparison, when it is enabled to compare the command/mask. If the SBI tag is 011, command/address, then this field is compared with SBI B <31:28>, the SBI function. If the SBI tag is other than 011, this field is compared to the SBI mask bits.

- <22:20> COMPARATOR TAG
SS25 COMP TAG <02:00>
These bits provide the base for the silo comparison, when it is enabled to compare the tag. This field is compared with SBI TAG <02:00>.
- <19:16> COUNT FIELD
SS19 COUNT FIELD
The CPU loads the silo counter with the two's complement of the number of SBI cycles to be loaded into the silo after a comparison is made. When the count reaches F, the silo is locked. The counter is also enabled by the Lock Unconditional bit <29>.
- <15:00> MAINTENANCE TRANSFER REQUEST <15:00>
SS25 MAINT TR <15:00>
These bits provide the means to simulate SBI transfer requests, SBI interrupt requests, and SBI alert for diagnosing the interrupt logic and SBI priority arbitration logic. They also provide a means of testing the lower 16 bits of the silo. They are controlled by SBI Maintenance Register bits <04:02> as follows:
1. The asserted MAINT TR <07:04> bit will cause the corresponding SBI REQ <07:04> bit to be asserted if SBI Maintenance Register <04>, MAINT REQ ENA, is set.
 2. If MAINT TR <03> and SBI Maintenance Register <04> are both set, SBI ALERT will be asserted.
 3. If SBI Maintenance Register <03> is set, the asserted MAINT TR <15:00> will cause the corresponding SBI TR <15:00> to be asserted when a CPU command/address is transmitted on the SBI. See SBI Maintenance Register bit <03>.
 4. MAINT TR <15:00> will cause the corresponding SBI TR <15:00> to be asserted if SBI Maintenance Register bit <02>, FORCE MAINT TR, is set.

VAX 8600/8650 REGISTER DESCRIPTION
SBIA SBI TIMEOUT ADDRESS
SBIA SBI UNJAM

SBI TIMEOUT ADDRESS REGISTER
2008 0038, 2208 0038

TOADR




The SBI timeout address register holds the address for all CPU transactions in the SBIA. When an error occurs on a CPU transaction, the timeout address register is locked.

<31:28> MBZ (SS36)

These bits are forced to zero by the zero fill logic.

- <27:00> SBI LONGWORD PHYSICAL ADDRESS - BUS REG D <27:00> (SS27)
The Timeout Address Register is loaded with the physical address, for the CPU command, each time a command/address is transferred from the file data latch to the command/address latch. It will be locked if Error Summary Register bit <23> is set.

SBI UNJAM REGISTER
2008 0048, 2208 0048





<31:00> SBAQ

The SBI Unjam Register does not exist as a hardware register. When the SBIA decodes the address of the Unjam register, for a CPU write, the Unjam sequence will be initiated. If this register is read, the contents will show all zeros, provided by the zero fill logic on SS36. For a read, the Unjam sequence will not be done.

VAX 8600/8650 REGISTER DESCRIPTION SBIA SBI VECTOR

SBI VECTOR REGISTER
2208 0080 TO 2208 008C
2208 0090 TO 2208 009C



NOTE:
THE REGISTER FORMAT SHOWN IS FOR IPR
LEVELS 14, 15, 16, AND 17. VECTORS FOR IPR
LEVELS 19, 18, 17, 16, AND 15 ARE READ FROM A
PROM. THESE VECTORS AND THE ADDRESSES
ARE AS FOLLOWS.

ADDRESS	INTERRUPT	VECTOR	INTERRUPT PRIORITY LEVEL
2208 00A0, 2208 00A4	COMPARE INTERRUPT	50	(IPR 19)
2208 00A8, 2208 00AC	SBI ALERT	58	(IPR 18)
2208 00B0, 2208 00B4	SBI FAULT	5C	(IPR 17)
2208 00B8, 2208 00BC	SBI ERROR	60	(IPR 16)
2208 00C0, 2208 00C4	SBI FAIL	64	(IPR 15)

The CPU will read the appropriate vector register in response to the arbitrated interrupt priority requests, which it will use, along with the I/O adapter number to build the vector register. If the interrupt being serviced originated on the SBI, the vector is made up of the interrupt priority request level and the TR level. If the interrupt being serviced originated on the SBIA, the vector is read from a 32 X 8 PROM.

<31:12> MBZ (SS36)
Must be zero.

<11:09> MBZ (SS36 or SS31)
Must be zero. If the interrupt being serviced originated on the SBI, these zeros are forced by ground potentials in the hardware on SS31. If the interrupt is a local SBIA interrupt, these zeros are provided by the zero fill logic.


<08> LOGIC ONE (SS31)
SS31 BUS REG <08>
This bit is tied to +3 volts for an SBI interrupt and is always read as a logic zero from the PROM.

<07:06> REQUEST LEVEL
SS31 BUS REG <07:06>
These fields are supplied by the two least significant address bits, which correspond to the request level, for an SBI interrupt. They are provided by the PROM for a local SBIA interrupt.

<05:02> TR LEVEL (SS31)
BUS REG <05:02>
The TR level is represented by bits <05:02> if the interrupt is an SBI interrupt. If the interrupt is a local SBIA interrupt, these bits are provided by the PROM.

<01:00> ZERO
SS31 BUS REG <01:00>
This field is read as zeros. It is supplied by the PROM for local SBIA interrupts, or inverting +3 volts for an SBI interrupt.


VAX 8600/8650 REGISTER DESCRIPTION
SBR
SCBB



<31:30> MBZ
Must be zero.

<29:02> **PHYSICAL LONGWORD ADDRESS**
The address points to the first PTE in the SPT. In turn, this PTE maps the first page of System Space, that is, virtual byte address 80000000 (hex).

<01:00> MBZ
Must be zero.



<31:30> MBZ
Must be zero.

<29:09> **PHYSICAL PAGE ADDRESS OF SYSTEM CONTROL BLOCK**
The SCBB is a privileged register containing the physical address of the System Control Block, which must be page-aligned.

<08:00> MBZ
Must be zero.

VAX 8600/8650 REGISTER DESCRIPTION SDCS


SDCS 174403		SDB CONTROL/STATUS REGISTER CL20							
07	06	05	04	03	02	01	00		
STOP CLOCK	SHIFT VALUE START	-TEST ENABLE	ENABLE STORE READY	ENABLE TRANSMIT READY	SINGLE EVENT FLAG	CHANNEL		WRITE	READ
R	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W

- <07> **STOP CLOCK**
When set, it indicates to the T-11 program that all SDB clocks have been generated and that the operation is complete.
- <06> **SHIFT VALUE START**
The T-11 program asserts Shift Value Start to generate the SDB clock or clocks needed to perform an SDB operation.
- <05> **-TEST READY**
This is an unused pin, the input to DAL <5> via the SDB to the DAL multiplexer. It is used to inform the software that the console module is in the console test station.
- <04> **ENABLE STORE READY**
Enable STX interrupts from the VAX CPU.
- <03> **ENABLE TRANSMIT READY**
Enable TX interrupts from the VAX CPU.
- <02> **SINGLE EVENT FLAG**
When this bit is negated, eight SDB clocks are generated. When it is asserted, one SDB clock is generated.
- <01:00> **CHANNEL WRITE, READ**
The direction of the data transfer is specified by setting either the CHANNEL WRITE or CHANNEL READ bits.
- <02:00> **SDCS**
Specify the operations used to transfer data from a selected visibility channel. See Table below.

CONTROL BIT SETTINGS TO READ OR WRITE A VISIBILITY CHANNEL

SINGLE EVENT	CHANNEL WRITE	CHANNEL READ	OPERATION
0	1	0	Shift eight bits in SDB out to visibility register (if SDMS VIS SHIFT = 1). Generates eight SDB clocks.
0	0	1	Shift eight bits from visibility register into SDB (if SDMS VIS SHIFT = 1). Generates eight SDB clocks.
1	1	0	Shift one bit in SDB out to visibility register (if VIS SHIFT = 1). Generates one SDB clock.
1	0	1	Shift one bit from visibility register (if VIS SHIFT = 1). Generates one SDB clock.
1	0	0	Load visibility register from diagnostic terminators (if VIS SHIFT = 0). Generates one SDB clock.

VAX 8600/8650 REGISTER DESCRIPTION SDDB




W01-148311

The SDDB is an 8-bit shift register. It is parallel loaded by the T-11 program with the data to be shifted out to a visibility or control channel.

This data is either diagnostic terminator select and enable information loaded prior to shifting data back to the console, or control data when the channel is used for control purposes.

The serial data shifted back to the console is loaded in the SDDB where it may be read by the T-11 Program. The direction of the shift paths is as follows:



For additional information, refer to the SDB section of this Maintenance Guide and the VAX 8600/8650 Console Technical Description, EK-KA86C-TD.

SDMS 174402				SDB MODULE/CHANNEL SELECT REGISTER CL18, 20			
07	06	05	04	03	02	01	00
MODULE/CHANNEL SELECT					VISI- BILITY SHIFT	CONTROL CHANNEL	
4	3	2	1	0		S2	S1

MM 11/83

The SDMS register is used by the console program to control/set-up the SDB prior to initiating the SDB sequence via the SDCS register. For additional information pertaining to SDB operation and the register, refer to the SDB section of the Maintenance Guide and to the KA86 Technical Description Manual (EK-KA86C-TD).

<07:03> MODULE/CHANNEL SELECT

The module/channel select field determines which channel to perform the SDB operation on and is encoded as shown in the following table.

Module Channel Select	Module	Control Channel (NOTE 1)	Module Channel Select	Module	Control Channel (NOTE 1)
00	FBA	Yes	16	CSB	Yes
01	FBM	Yes	17	CSA	No
02	MCD	No	20	IOA 0	Note 2
03	IBD	Yes	21	IOA 1	Note 2
04	IDP	No	22	IOA 2	Note 3
05	ICA	Yes	23	IOA 3	Note 3
06	ICB	No	24	MTM	No
07	CLK	Yes	25	Spare	--
10	EDP	Yes	26	Spare	--
11	EBE	Yes	27	Spare	--
12	MCC	Yes	32	SDD B	N/A
13	MAP	No		Loopback Test	
14	EBD	No	34	SCP	Yes
15	EBC	Yes			

- NOTES:
- (1) Module has both control and visibility channels.
 - (2) IOA0 and IOA1 visibility and control is available to manufacturing only (via special test ABUS backplane)
 - (3) IOA2 and IOA3 are currently nonexistent


<02> VISIBILITY SHIFT

This signal is distributed (daisy chained) to each visibility channel and used to control the loading and shifting of shift register logic in the selected visibility channel. When asserted, the visibility channel shift register will shift data one bit position for each SDB clock. When cleared, the visibility channel shift register will perform a parallel load operation.

<01:00> CONTROL CHANNEL S2, S1

These two signals are distributed (daisy chained) to each control channel and are implemented within the control channel to perform specific functions. The implementation of these bits within the control channel is channel dependent (may be implemented differently in each channel). Refer to the appropriate technical description manual for the module (box) in question for a description of SDB, S2 and S1 operation.

VAX 8600/8650 REGISTER DESCRIPTION
SFBCNT




This longword is built by the Error Handling Microcode (EHM). It contains the number of bytes (in HEX) that the EHM will assemble in the EBox Scratch Pad RAMS (location 18 through 1D). When the EHM is finished building the Machine Check Stack Frame, it calls the Interrupt Exception Microcode. The microcode pushes the contents of the Scratch Pad RAMS onto the Interrupt Stack and calls the VMS Machine Check (MCHK) Handler. The MCHK Handler will use the contents of this longword to process the stack but the SFBCNT will not appear in the Stack Frame Record written to ERRLOG.SYS.

<31:08> RESERVED


<07:00> BYTE COUNT

Indicates the number of bytes, currently 58 HEX-88 Decimal, that the EHM has pushed onto the Interrupt Stack.

VAX 8600/8650 REGISTER DESCRIPTION SID



MR-12842



NOTE:
ALL EVEN NUMBERED PINS (RIGHT HAND SIDE)
ARE GROUND

MR-12842

The System Identification (SID) register contains information unique to the system: the CPU serial number, the processor type, the manufacturing plant name and the CPU revision. The source of this register is the Console, with bits <31:24> being generated by Console software and bits <23:00> jumper selectable on the CPU backplane, J09. The contents of this register (except the software generated bits <31:24>) are also addressable from the console, using the console registers as shown in the BITMAP above: SID2 <23:16>, SID1 <15:08> and SID0 <07:00>.

<31:24> CPU TYPE

This field identifies the CPU type and specifies the processor as 04(X). These bits <31:24> are generated by the console software when the register is read (i.e., are not set in jumpers on the backplane like the rest of the bits in this register).

<23>

VAX CPU TYPE

0 = VAX 8600, 1 = VAX 8650

<22:16>

CPU REVISION

This field specifies the hardware revision of the kernal CPU. Only MAJOR ECO revision levels are considered here. To calculate the letter revision, simply use a one-to-one conversion from number to alphabet thus: 01(X) = A, 02(X) = B, 03(X) = C, etc.

<15:12>


MANUFACTURING PLANT CODE

This field contains a code which represents the Manufacturing plant where the CPU was built. Current codes are as follows:

PLANT CODE (HEX)	MANUFACTURING PLANT
1, 2, 3	GALWAY
5, 6, 7	FRANKLIN, MA
A, B, C	BURLINGTON, VT
D, E, F	MARLBORO, MA

VAX 8600/8650 REGISTER DESCRIPTION

SID



<11:00> CPU SERIAL NUMBER

This field contains the CPU serial number (also shown on the silver label attached to the CPU cab: top left rear) converted to hexadecimal. For example, if the CPU serial number displayed on the serial number tag were MR00617, the conversion would be 269(X).

Additional Notes:

- (1) Refer to the diagram at left which illustrates the relative bit positions of the SID jumper, located on the CPU backplane.
- (2) The SID register is read by VMS (via the Console) and will be logged into each entry of the error log. To read manually, you can use the MFPR instruction (IPR number 3E) or from the Console thus:

```
>>>E SID
```

```
I 3E 04045269
```

In addition, the Console command 'SHOW VERSION' will display the Hardware Revision Level in hex, which is the contents of SID <23:16> or console register SID2 / 176403.

(3) VAX 8650 System SID Jumper Settings

JP PINS	SID BIT	JUMPER (IN/OUT)	VALUE	FUNCTION
17 - 18	23	OUT	1	1 = 8650
19 - 20	22	IN	0	
21 - 22	21	IN	0	
23 - 24	20	IN	0	
25 - 26	19	IN	0	
27 - 28	18	IN	0	
29 - 30	17	IN	0	
31 - 32	16	OUT	1	1 = REV A

To verify the correct SID register jumper settings, perform an EXAMINE SID at the MHC prompt (>>>) as shown in the following example:

```
>>>EXAMINE SID
```

```
0481F095 (sample system ID)
```

SIRR
SISR

SOFTWARE INTERRUPT REQUEST REGISTER



<03:00> INTERRUPT REQUEST LEVEL

Executing MTPR SIRR requests an interrupt at the level specified by bits <03:00>. Once a software interrupt request is made, it will be cleared by the hardware when the interrupt is taken. If SRC <03:00> is greater than the current IPL, the interrupt occurs before execution of the following instruction. If SRC <03:00> is less than or equal to the current IPL, the interrupt will be deferred until the IPL is lowered to less than SRC <03:00> with no higher interrupt level pending. This lowering of IPL is by either REI or by MTPR x, IPL. If SRC <03:00> is 0, no interrupt will occur.


SOFTWARE INTERRUPT SUMMARY REGISTER

```
<15:01>  PENDING SOFTWARE INTERRUPTS - Levels 01-0F (HEX)
```

SISR is a read/write privileged register accessible only to privileged software. At bootstrap time, the contents of SISR is cleared. The SISR is accessed using MTPR and MFPR instructions.


20-173

VAX 8600/8650 REGISTER DESCRIPTION
SLR
SPADR



<31:22> MBZ
Must be zero.

<21:00> LENGTH OF SPT IN LONGWORDS
The System Virtual Address space is defined by the System Page Table (SPT), which is a collection of Page Table Entries (PTE's). The SPT is always located in physical address space. The base address of the SPT is also a physical address and is contained in the System Base Register (SBR). The size of the SPT in longwords (that is, the number of PTE's) is contained in the System Length Register (SLR).



<07:00> CURRENT CONTENTS OF SPADR
When accessed by the Console, this register will contain the current contents of the Scratch Pad address lines <07:00>. Note that a CSM Overlay is required to access these contents, which may not reflect the actual address prior to loading the CSM Overlay. To examine the contents of SPADR before CSM is started, the Console must examine CSM.SPADRSC (which is ESC location C2).


NOTE

1. The SPADR register (read/write) is accessed via the following console commands:


```
>>>EXAM SPADR<cr>
>>>DEPOSIT SPADR data<cr>
```

2. The SPADR lines are generated on logic print EDPC by the ADD MCA and are distributed and used on the EDP module only and are not available on the backplane or via SDB visibility.

VAX 8600/8650 REGISTER DESCRIPTION
SSP
EDP STATE



<31:00> SUPERVISOR STACK POINTER
Contains the stack pointer to be used when the current access mode field in the PSL is 2 (Supervisor Mode).



<07:00> CONTENTS OF STATE REGISTER
The STATE register is utilized by EBox Microcode as a miscellaneous register to control the microprogram flow. A microinstruction is used to load the STATE register from the ARBUS (refer to DEF.MIC and any EDP block diagram). The BEN field of the EBox microword is used to control microprogram flow and may be used to select the various bits of the STATE register to control selection of UPC bits <02:00>.

NOTE

1. The STATE register (read/write) is accessed via the following console commands:


```
>>>EXAM STATE<cr>
>>>DEPOSIT STATE data<cr>
```

2. This register is also available on the SDB visibility bus (all signals are generated on Print:EDPE and are terminated on the CSB module).

STATE BIT	SIGNAL NAME	SDB SYMBOL	B/P PIN
7	EDP STATE 7 H	V\$E138	AC10B84
6	EDP STATE 6 H	V\$E109	AC10B86
5	EDP STATE 5 H	V\$E177	AC10B80
4	EDP STATE 4 H	V\$E120	AC10B76
3	EDP STATE 3 H	V\$E184	AC10B74
2	EDP STATE 2 H	V\$E136	AC10A07
1	EDP STATE 1 H	V\$E110	AC10A12
0	EDP STATE 0 H	V\$E178	AC10A17

VAX 8600/8650 REGISTER DESCRIPTION

STXCS



<31:24> STXCS0 STATUS CODE
Status of current transfer. Read Only by CPU.
Initialized to ONE by the console.

CODE	STATUS
01	Transaction Complete
02	Continue Transaction
03	Transaction Aborted
04	Return Device Status
80	Handshake Error During Transaction
81	Hardware Error During Transaction

<23:16> STXCS2 HIGH ORDER DISK ADDRESS
Write only by CPU. Logical block number of current transfer. The console software will NOT perform bad block replacement on the RL02.

<15:08> STXCS1 LOW ORDER DISK ADDRESS

<07:00> STXCS0

<07> READY
Read only by CPU. Initialized to ONE by the console.


<06> INTERRUPT ENABLE
Write only by CPU.

<05:04> RESERVED

<03:00> DISK FUNCTION CODE
Disk functions to perform. Write only by CPU.
Initialized to ZERO by the console.

CODE	FUNCTION
0	No Operation
2	Continue Transaction
3	Abort Current Transfer
4	Read Device Status
5	Write Block Data
6	Read Block Data

VAX 8600/8650 REGISTER DESCRIPTION
STXDB
TBCHK



<31:16> STXDB3 Must be zero


<23:16> STXDB2 Must be zero

<15:08> STXDB1 High order disk data

<07:00> STXDB0 Low order disk data


Data should be read from the STXDB only when STXCS RDY, STXCS <07>, is set, and is valid only if the STXCS status field is 1 (Continue transaction) or 4 (Return Device Status), or the function field is 4 (Reset and Return Device Status).

Data is to be written to this field by the CPU only when the STXCS status field is 2 (Continue Transaction) and the function field is 5 (Write Block Data).



The TBCHK register is included in the architecture due to anticipated use by VAX/VMS. Its specification and use is reserved to DIGITAL. On the VAX-11/730, the condition code V bit is cleared on a MTPR to TBCHK if the virtual address maps into I/O space or if the protection field in the PTE specifies no access for all modes.

VAX 8600/8650 REGISTER DESCRIPTION
 TBIA
 TBIS




When the software changes a System Page Table Entry which maps any part of the current process page table, all process pages so mapped must be invalidated in the translation buffer. They may be invalidated by moving an address within each such page into the TBIS register. They may also be invalidated by clearing the entire translation buffer. This is done by moving 0 to the Translation Buffer Invalidate All (TBIA) register with the MTPR instructions.

The translation buffer must not store invalid PTE's. Therefore, the software is not required to invalidate translation buffer entries when making changes for PTE's that are already invalid.


When the location or size of the system map is changed (SBR, SLR) the entire translation buffer must be cleared.

Whenever Memory Management Enable (MME) is a 0, the contents of the translation buffer are UNPREDICTABLE. Therefore, before enabling memory management at processor initialization time, or any other time, the entire translation buffer must be cleared.



When the software changes any part of a valid Page Table Entry for the system or a current process region, it must also move a virtual address within the corresponding page to the Translation Buffer Invalidate Single (TBIS) register with the MTPR instruction.


VAX 8600/8650 REGISTER DESCRIPTION

TODR
TRDR/TWDR


The Time of Year (TOY) clock is an elapsed time indicator for VMS and the means by which VMS knows whether the console is running. Power for the TOY clock (+5V B) is supplied by the Battery Backup Unit (BBU) as long as the batteries can retain enough charge and if the TOY ON/OFF switch on the BBU is in the ON position. If the batteries are fully charged, the BBU can supply power to the TOY clock for 100 hours.

The TOY clock is implemented by a 32-bit counter that is incremented at a rate of 10 ms per count. It uses an Am9513 system timing control chip that is controlled by the T-11 program. VMS communicates with the TOY clock via TODR, the VAX Time of Day Register. The KA86 implements this register as a software register in the CBus RAM. VMS loads and reads the TOY clock with MTPR/MFPR #TODR. The assembler translates "TODR" to address "1B" (hex). The EBox microcode in turn interprets "1B" as a CBus RAM location. If the TOY clock count becomes invalid, VMS asks the operator to load the correct time.

The timing of the Am9513 is controlled by a crystal which is also used by the console operating system for EMM communications. If the BBU +5V is lost, EMM communications as well as TOY operations cease.




See TWDR Register Description.




All TOY Chip (Am9513) registers (except the Command Write Register) can be read or written one byte at a time from the Read/Write Data Registers via the TOY Data Port. The Data Port is enabled when the C/-D input to the Am9513 (CL03 RAS ADR 2) is true.

The registers that can be accessed in the CSL module are: the Data Pointer and Master Mode Registers; and for each counter group, the Hold, Load and Counter Mode Registers. The Data Pointer Register determines which register is accessed.

VAX 8600/8650 REGISTER DESCRIPTION
 TRSR
 TURN



The Read Status Register (read-only) allows the byte pointer bit (BP) and the state of the counter outputs (OUT <05:01>) to be examined. The Read Status Register may also be read via the Data Port.




The TURN register is implemented in the CBUS RAM. Refer to the KA86 Console Technical Description manual (EK-KA86C-TD), for a detailed description of TOY clock operation.

<07> TOY SELECT
 This bit has two uses:

1. It is set before (and cleared after) the console updates the BTOY Register. This will cause the EBox microcode to read the UTOY register (instead of the BTOY Register) if it executes an MFPR TODR while the console is in the process of updating the BTOY Register.
2. It is set by the EBox microcode when it updates the TURN Register (via an MTPR #TODR). This will cause the Console to update the BTOY Register in the Console and the TOY Counter in the 9513 (TOY) Chip. The Console will perform the update request during its next interrupt cycle.

<06:00> UPDATE REQUEST NUMBER
 This field contains a count of the number of times that the UTOY register has been written (updated via a MTPR #TODR instruction) by the EBox microcode.



The 9513 (TOY Chip) Control Registers include the 8-bit Command and Status Registers which is accessed via the Control Port. The Control Port is enabled when the C/-D input to the 9513 (CL03 RAS ADR 2) is false. The following table lists the TOY Chip Commands.

COMMAND CODE								FUNCTION
C7	C6	C5	C4	C3	C2	C1	C0	
0	0	0	E2	E1	G4	G2	G1	Load Data Pointer Register with contents of E and G fields. (000<G<110 or G=111)
0	0	1	S5	S4	S3	S2	S1	Arm counting for all selected counters
0	1	0	S5	S4	S3	S2	S1	Load contents of specified source into all selected counters (NOTE 1).
0	1	1	S5	S4	S3	S2	S1	Load and arm all selected counters (NOTE 1).
1	0	0	S5	S4	S3	S2	S1	Disarm and save all selected counters (NOTE 1).
1	0	1	S5	S4	S3	S2	S1	Save all selected counters in Hold Register. (NOTE 1).
1	1	0	S5	S4	S3	S2	S1	Disarm all selected counters (NOTE 1).
1	1	1	0	1	N4	N2	N1	Set output bit for counter N (N=001 to 101).
1	1	1	0	0	N4	N2	N1	Clear output bit for counter N (N=001 to 101).
1	1	1	1	0	N4	N2	N1	Step counter N (N=001 to 101).
1	1	1	0	1	0	0	0	Disable data pointer seq., set MM<14> (NOTE 2).
1	1	1	0	1	1	1	0	Gate off FOUT, set MM<12> (NOTE 2).
1	1	1	0	1	1	1	1	Enter 16-bit mode, set MM<13> (NOTE 2).
1	1	1	0	0	0	0	0	Ena. data pointer seq., clear MM<14> (NOTE 2).
1	1	1	0	0	1	1	0	Gate on FOUT, clear MM<12> (NOTE 2).
1	1	1	0	0	1	1	1	Enter 8-bit mode, clear MM<13> (NOTE 2).
1	1	1	1	1	0	0	0	Enable Prefetch for Write Operations
1	1	1	1	1	0	0	1	Disable Prefetch for Write Operations
1	1	1	1	1	1	1	1	Master reset.

NOTE


- Source is determined for each counter by its Counter Mode Register.
- Sets or clears appropriate bit in Master Mode Register (MM).

VAX 8600/8650 REGISTER DESCRIPTION

TXCS

TXCS
IPR 22

CONSOLE TRANSMIT CONTROL AND STATUS REGISTER



WPR 13045

<31:24> TXCS3
Must be zero

<23:16> TXCS2

<19:16> TRANSMIT ENABLE MASK

This field is Read/Write by the CPU and Read only by the Console. It is initialized to 01 by the Console (Local Line Enabled).

A bit set in this field indicates that the CPU wants to activate interrupts for that line. When the line is ready the console will generate an interrupt via the TXCS.

<19> ENABLE LOGICAL TERMINAL
Corresponds to the "LOGICAL" Console Subsystem (i.e., the Console to CPU interface path).

<18> ENABLE EMM
Corresponds to EMM data line.

<17> ENABLE REMOTE PORT
Corresponds to Console Remote Services Port.

<16> ENABLE CONSOLE TERMINAL
Corresponds to Console Terminal.

<15:08> TXCS1


<15> Write Mask Now
Read/Write by CPU and Console. Initialized to zero by the Console.

This bit is set by the CPU to allow the MTPR microcode to write to the Transmit Enable Mask Field. The bit is used by the Console to determine which operation caused the Console interrupt; a Mask Field Write or a TXDB Write.

<14:12> MBZ
Must be zero.

- <11:08> ID Field
Read only by CPU. Initialized to zero by the Console.
- When the CPU receives a "RDY" interrupt, this field will identify the line that caused the interrupt, i.e., which line is now ready to transmit data.
- ID = 0 Console Terminal
 - ID = 1 Remote Services Port
 - ID = 2 Environmental Monitoring Module (EMM) Data
 - ID = 3 Logical Console Data
 - ID = F No Lines Currently Enabled
- <07:00> TXCS0
- <07> TXCS Ready
Read only by CPU. Initialized to one by the Console. When set to a one, this bit indicates that the line specified in ID Field is ready to transmit, provided that the Transmit Enable Mask Field is not zero.
- <06> TXCS Interrupt Enable
Read/Write by CPU. Initialized to zero by the Console. When the logical AND of "TXCS RDY" and "TXCS INTERRUPT ENABLE" is 1, a CPU interrupt is generated via System Control Block (SCB) vector "FC".
- <05:00> MBZ
Must be zero.

VAX 8600/8650 REGISTER DESCRIPTION
TXDB



<31:08> MBZ
Must be zero.

<07:00> Data Byte
Write only by CPU. Initialized to zero by the Console.

The code in TXCS <11:08> (ID Code) determines the destination of this data byte.

TXCS ID TXDB DATA BYTE DESTINATION AND DEFINITION

- | | |
|---|--|
| 0 | Console Terminal. Output the Data Byte to the Console Terminal Line (CTY). |
| 1 | Remote Services Port. Output the Data Byte to the Remote Terminal Line (RTY). |
| 2 | Environmental Monitoring Module (EMM). Output the Data Byte to the EMM. The TXDB data byte may contain any one of four HEX values. All other value will be ignored by the Console. |
| | 00 = CPU Request for EMM Status Information. The EMM data response is returned via the RX registers. |
| | 01 = CPU Request for System Environment Information. The EMM data response is returned via the RX registers. |
| | 10 = CPU Command to Control Regulator Margins.
If: Byte 1 = 0 -- Set all margins NORMAL
Byte 1 = 1 -- Set all margins LOW
Byte 1 = 2 -- Set all margins HIGH |
| | 11 = CPU Command to cancel current and Queued EMM requests. |
| 3 | Logical Console. Send the Data Byte to the Logical Console for processing. The TXDB data byte may contain any one of the following HEX values. All other value will be ignored by the Console. |

NOTE

The following codes (2, 3, and 4) return no data to the CPU.

02 = Request Console to initiate system.

03 = Request Console to clear the Console copy of the Warm_Start_Flag.

TXCS ID TXDB DATA BYTE DESTINATION AND DEFINITION

04 = Request Console to clear the Console copy of the Cold_Start_Flag.

NOTE

The following codes (10, 11, 12, 13, and 20) return data to the CPU via the RX registers.

10 = Request the value of the Console's copy of the Warm_Start_Flag.

11 = Request the value of the Console's copy of the Cold_Start_Flag.

12 = Request the 16-bit value of the system microcode version currently being executed.


13 = Request 3 bytes of condensed array configuration data.

20 = Used by diagnostics and error handler verification tools. Commands the Console to begin accepting a Console Command String (CCS). Any previous CCS in progress is aborted.

NOTE

- The CCS may consist of up to 512 ASCII bytes including the Null Terminator.
- Bit <7> must be set in each ASCII byte that is part of the CCS. The Console uses Bit <7> to identify the data as part of the CCS.
- Individual commands in a CCS must be separated with a <cr><lf> character pair.
- The Console stores the ASCII bytes in a buffer until it detects a Null Byte. The Null Byte terminates CCS mode and causes the Console to begin processing the CSS. The Console stops the CPU, exits PIO Mode, enters CIO Mode, processes the command (just as though it were entered via the CTY). The Console then exits CIO mode, enters PIO Mode, "CONTINUES" the CPU from its halted PC, and re-enters CCS Mode.
- The Console will remain in CSS Mode until it receives a CSS terminator character set (<cr><lf><null>).

VAX 8600/8650 REGISTER DESCRIPTION
TXDB



TXCS ID TXDB DATA BYTE DESTINATION AND DEFINITION

CCS ERRORS - The Console will reject the CCS and return an error code via the RX registers if:


1. The CCS EXCEEDS the 512 byte BUFFER SPACE
2. The front panel switch indicates that the CONSOLE is LOCKED. The check for the locked Console is not made until the NULL character is received.

Because of the possibility of an RX abort message occurring at any time during the issuing of a CCS, the CPU program is required to poll the RX register during the transfer.


- 21 = Request the 32-bit value of the VAX PC at the time of its last halt.
- 22 = Request the 32-bit value of the CSM Status at the time of its last entry.
- 30 = Request to the console to have it return the status of the two machine SNAPSHOT Files.
- 31 = A request to the console to have it invalidate the SNAP1.DAT File. The CPU should make this request after successfully processing the SNAP2.DAT File.
- 32 = A request to the console to have it invalidate the SNAP2.DAT File. The CPU should make this request after successfully processing the SNAP2.DAT File.
- 70 = Cancel all current and Queued Logical Console Requests.

VAX 8600/8650 REGISTER DESCRIPTION

USP
UTOY 0-3




<31:00> **USER STACK POINTER**
Contains the stack pointer to be used when the current access mode field in the PSL is 3 (User Mode).



The UTOY register consists of four CBUS RAM byte locations.

<07:00> **TOY UPDATE DATA**
The EBox microcode will load the UTOY registers with the 32 bit data specified in an MTPR #TODR instruction. The byte alignment is as follows:



When the EBox executes a MFPR #TODR instruction, the EBox microcode will read the data from the UTOY registers if the BTOY registers are being updated (see BTOY register description).


NOTE

Refer to the KA86 Console Technical Description manual (EK-KA86C-TD), for more detailed information on TOY clock operation.

VAX 8600/8650 REGISTER DESCRIPTION
VIBASAV
VPCBITS

VIBASAV
(ESCRATCH LOC 21 — T11)

VIRTUAL IBUFFER ADDRESS SAVE REGISTER



<31:00> IBOX IBUF PORT VIRTUAL ADDRESS
This register contains the last IBuffer virtual address that was acknowledged by the MBox (PA ACK).

VPC BITS
(ADDRESSED BY NAME FROM CONSOLE ONLY)

VALID PC BITS
PRINT LOCATION: ICB6, 7



NOTE: BITS <2:0> ARE READ ONLY

<31:03> RESERVED

<02:00> VALID PC BITS


These bits represent the validity of the three Program Counters: CPC, ISA and ESA. If the Valid bit is set, then the corresponding register contains valid data. When the CSM overlay is called to read this register, it simply reads the status of the following signals and sets the corresponding bits:

VPC BIT	SIGNAL NAME	SDB SYMBOL	ICB B/P PIN
2	ICB CPC VALID H	V\$E144	AC12C24
1	ICB ISA VALID H	V\$E161	AC12B56
0	ICB ESA VALID H	V\$E129	AC12C14


NOTE

1. These signals are generated on the ICB module (prints ICB6, ICB7) and are each terminated on the CSB module.
2. The VPCBITS register (read only) is accessed via the following console command:

>>>EXAM VPCBITS



These four registers (XBUF0-3) are used in conjunction with the XBUFC register for transferring data packets from the EBox microcode to the console. This communication occurs only in Console I/O (CIO) mode and will take place between CSM and MCP (if in MACRO context) or DSM and DCP (if in DIAGNOSTIC context). Refer to CSM and DSM specifications, and the "KA86 Console Technical Description" manual, EK-KA86C-TD for operation of these registers.



The XBUFC register is used in conjunction with the XBUF0-3 registers for communication between the console software and EBox microcode. This communication occurs only in Console I/O (CIO) mode and will take place between CSM and MCP (if in MACRO context) or DSM and DCP (if in DIAGNOSTIC context). Refer to CSM and DSM specifications, "KA86 Console Technical Description", EK-KA86C-TD, and "VAX 8600/8650 System Diagnostic User's Guide", EK-KA86D-UG.

- <07> **READY RIGHT-OF-ACCESS BIT**
When set indicates that the EBox microcode may load data into the XBUF register. When cleared indicates that the Console software may read the XBUF register.
- <06> **PACKET CONTROL**
When set indicates that another packet will follow. When clear indicates that the current packet is the last one for this transaction.
- <05:00> **DATA**
Application dependent; refer to both the DSM and CSM specifications.

