

MicroVAX 3100 Platform

KA45 CPU System Maintenance

Order Number: EK-A0513-MG.001

November 1991

This manual gives maintenance information for systems that use the KA45 CPU module.

Revision Information:

This is a new manual.

**Digital Equipment Corporation
Maynard, Massachusetts**

November 1991

The information in this document is subject to change without notice and should not be construed as a commitment by Digital Equipment Corporation. Digital Equipment Corporation assumes no responsibility for any errors that may appear in this document.

No responsibility is assumed for the use or reliability of software on equipment that is not supplied by Digital Equipment Corporation or its affiliated companies.

Restricted Rights: Use, duplication, or disclosure by the U.S. Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013.

© Digital Equipment Corporation 1991.

All Rights Reserved.

The postpaid Reader's Comments forms at the end of this document request your critical evaluation to assist in preparing future documentation.

The following are trademarks of Digital Equipment Corporation: DEC, Digital, MicroVAX, ThinWire, VAX DOCUMENT, VMS, VT330, and the DIGITAL logo.

This document was prepared using VAX DOCUMENT, Version 2.0.

Contents

Preface	ix
 1 KA45 CPU Module Description	
1.1 KA45 CPU Module	1-1
1.2 MS44 and MS44L Memory Modules	1-8
1.3 MS44 or MS44L Memory Option Installation	1-10
 2 Configuration	
2.1 Memory Configurations	2-1
2.2 Mass Storage Devices	2-1
2.2.1 Internal Mass Storage Devices	2-1
2.2.2 External Mass Storage Devices	2-2
2.2.3 SCSI ID Numbers	2-4
2.3 Communications Options	2-4
2.3.1 Asynchronous Communications Options	2-5
2.3.2 Synchronous Communications Options	2-5
 3 KA45 Firmware	
3.1 Power-Up Test and Initialization	3-1
3.2 Console Program	3-4
3.2.1 Console Device	3-4
3.2.2 Console Commands	3-6
3.2.3 Console Mode	3-6
3.2.4 Console Security	3-7
3.2.5 Console Command Conventions	3-9
3.3 Self-Test	3-11
3.3.1 Additional Error Information for Self-Tests	3-14

3.3.2	Test Environments	3-15
3.3.2.1	Customer Environment	3-15
3.3.2.2	Digital Services Environment	3-15
3.3.2.3	Manufacturing Environment	3-16
3.4	Utilities	3-16
3.4.1	SCSI Utilities	3-17
3.4.2	COMM Utilities	3-19
3.5	System Exerciser	3-19
3.5.1	Selective System Exerciser Test (T 106)	3-23
3.5.2	Summary Screens	3-24
3.5.3	Additional Error Information for System Exerciser Tests ...	3-29

4 Testing and Troubleshooting

4.1	General Troubleshooting Information	4-1
4.2	No Display on the Console Terminal	4-3
4.2.1	Troubleshooting Procedure for No Display on the Console Terminal	4-4
4.3	NVR Test (Test 1)	4-6
4.4	DZ Test (Test 3)	4-7
4.5	CACHE Test (Test 4)	4-8
4.6	MEM Test (Test 5)	4-9
4.7	FPU Test (Test 6)	4-10
4.8	IT Test (Test 7)	4-11
4.9	SYS Test (Test 8)	4-12
4.10	NI Test (Test 9)	4-13
4.11	SCSI Test (Test 10)	4-15
4.11.1	Troubleshooting an RRD42 CDROM Drive	4-18
4.11.2	Troubleshooting an RX26 Diskette Drive	4-18
4.11.3	Troubleshooting an RZ23L, an RZ24, or an RZ25 Disk Drive	4-18
4.11.4	Troubleshooting a TZ30 Tape Drive	4-19
4.11.5	Troubleshooting a TZK10 Tape Drive	4-19
4.11.6	Troubleshooting an External SCSI Device	4-19
4.12	COMM Test (Test 12)	4-19
4.12.1	Troubleshooting a DSW41 or a DSW42 Synchronous Communications Option	4-21
4.13	ASYN Test (Test 14)	4-23
4.13.1	Troubleshooting a DHW41 or a DHW42 Asynchronous Communications Option	4-24
4.14	Troubleshooting Procedures for the Power Supply	4-25

A Troubleshooting Flowchart

B Memory Map

C FRU Numbers

C.1	FRU Number Assignments	C-1
C.1.1	FRU Numbers of SCSI Devices	C-2

D KA45 CPU Module Jumper Wires

Glossary

Index

Figures

1-1	KA45 CPU Module	1-2
1-2	KA45 CPU Module Block Diagram	1-4
1-3	KA45 Controls, Indicators, Ports, and Connectors	1-6
1-4	Memory Expansion Connectors	1-9
1-5	Memory Module Installation	1-11
2-1	SZ Expansion Box Numbering System	2-3
3-1	Successful Power-Up Test Display	3-2
3-2	Unsuccessful Power-Up Test Display	3-3
3-3	Location of the Console-Related Ports and Switches	3-5
3-4	Location of the NVR Contacts for Clearing the Password ...	3-9
3-5	Successful Self-Test Display	3-13
3-6	Unsuccessful Self-Test Display	3-13
3-7	Additional Error Information for Self-Tests	3-14
3-8	Successful System Exerciser Test	3-21
3-9	Unsuccessful System Exerciser Test	3-22
3-10	Selective System Exerciser Test (T 106) Example	3-23
3-11	Summary Screen for System Exerciser DZ Test	3-25
3-12	Summary Screen for System Exerciser NI Test	3-26
3-13	Summary Screen for System Exerciser SCSI Test	3-27
3-14	Summary Screen for System Exerciser COMM Test	3-28

3-15	Summary Screen for System Exerciser ASYNC Test	3-29
3-16	Additional Error Information for System Exerciser Tests ...	3-30
4-1	Flowchart for Normal System Power-Up	4-4
4-2	Cable Loopback Connectors for the DSW41 and DSW42 Options	4-22
4-3	Cable Loopback Connectors for the DHW41 and DHW42 Options	4-25
4-4	Flowchart for Troubleshooting the Power Supply	4-26
4-5	KA45 CPU Module Power Connector Pin Voltages	4-27
4-6	Drive Power Connector Pin Voltages	4-27
A-1	Troubleshooting Flowchart (Page 1 of 4)	A-2
A-2	Troubleshooting Flowchart (Page 2 of 4)	A-3
A-3	Troubleshooting Flowchart (Page 3 of 4)	A-4
A-4	Troubleshooting Flowchart (Page 4 of 4)	A-5
B-1	Memory Connectors	B-2
D-1	KA45 CPU Module Jumper Wires	D-2

Tables

1-1	Functions of the Controls, Indicators, Ports, and Connectors	1-7
1-2	KA45 CPU Module Memory Configurations	1-10
2-1	KA45 Internal Mass Storage Devices	2-2
2-2	Supported External Mass Storage Devices	2-3
2-3	Recommended SCSI ID Numbers for Devices	2-4
2-4	Supported Asynchronous Communications Options	2-5
2-5	Supported Synchronous Communications Options	2-6
2-6	DSW41-AA and DSW42-AA Communications Support	2-6
3-1	Console Device Port Selection	3-4
3-2	Terminal Settings	3-6
3-3	Console Mode Control Keys	3-10
3-4	Device Numbers and Mnemonics	3-11
3-5	Typical TEST Command Lines	3-12
3-6	Predefined System Exerciser Tests	3-20
4-1	Troubleshooting Procedures	4-3
4-2	SCSI Device Troubleshooting Procedures	4-17
B-1	Memory Map	B-1

Page viii is a blank page

Preface

This manual describes the KA45 CPU module used in the MicroVAX™ 3100 Model 30 and Model 40 systems. It provides the configuration guidelines, ROM-based diagnostic information, and troubleshooting information for systems containing the KA45 CPU module.

Audience

This manual is for Digital™ Services personnel who provide support and maintenance for systems that use the KA45 CPU module. It is also for customers who have a self-maintenance agreement with Digital Equipment Corporation.

Structure of This Manual

This manual is divided into four chapters, four appendixes, a glossary, and an index:

- **Chapter 1 describes the KA45 CPU module.**
- **Chapter 2 describes the KA45 system configurations.**
- **Chapter 3 describes the structure and operation of the KA45 firmware.**
- **Chapter 4 describes the ROM-based diagnostic testing and troubleshooting procedures for the KA45 systems.**
- **Appendix A gives a flowchart of the procedure used to troubleshoot KA45 systems.**
- **Appendix B gives a memory map for a KA45 system.**
- **Appendix C gives the FRU numbers of the devices in MicroVAX 3100 platform systems.**
- **Appendix D gives the location and the function of the jumper wires on the KA45 CPU module.**

Associated Documents

The following documents contain more information about the MicroVAX 3100 platform systems:

- *MicroVAX 3100 Model 30 Cover Letter, EK-A0515-CL*
- *MicroVAX 3100 Model 30 Installation Information, EK-A0520-IN*
- *MicroVAX 3100 Model 30 Operator Information, EK-A0521-UG*
- *MicroVAX 3100 Model 30 Customer Technical Information, EK-A0522-TD*
- *MicroVAX 3100 Model 30 Troubleshooting and Diagnostic Information, EK-A0516-TM*
- *MicroVAX 3100 Model 40 and Model 80 Cover Letter, EK-A0517-CL*
- *MicroVAX 3100 Model 40 and Model 80 Installation Information, EK-A0523-IN*
- *MicroVAX 3100 Model 40 and Model 80 Operator Information, EK-A0524-UG*
- *MicroVAX 3100 Model 40 and Model 80 Customer Technical Information, EK-A0525-TD*
- *MicroVAX 3100 Model 40 and Model 80 Troubleshooting and Diagnostic Information, EK-A0518-TM*
- *VMS™ Factory Installed Software User Guide, EK-A0377-UG*

Related Documents

The following documents contain additional maintenance information about the KA45 CPU systems:

- *Guide to MicroVAX 3100 Platform Maintenance Information Kit, EK-A0512-MG*
- *CPU Reference Information, EK-A0574-HR*
- *BA42-A Enclosure Maintenance, EK-A0510-MG*
- *BA42-B Enclosure Maintenance, EK-A0511-MG*
- *IPB, EK-MV310-IP*
- *Options, EK-A0519-MG*
- *TZ30 Cartridge Tape Drive Service Manual, EK-OTZ30-SV*

Conventions

The following conventions are used in this manual:

Convention	Description
Ctrl/ <i>x</i>	Ctrl/ <i>x</i> indicates that you hold down the Ctrl key while you press another key or mouse button (indicated here by <i>x</i>).
<i>x</i>	A lowercase italic <i>x</i> indicates the generic use of a letter. For example, <i>xxx</i> indicates any combination of three alphabetic characters.
<i>n</i>	A lowercase italic <i>n</i> indicates the generic use of a number. For example, 19 <i>nn</i> indicates a 4-digit number in which the last 2 digits are unknown.
{ }	In format descriptions, braces indicate required elements. You must choose one of the elements.
[]	In format descriptions, brackets indicate optional elements. You can choose none, one, or all of the options.
()	In format descriptions, parentheses delimit the parameter or argument list.
...	In format descriptions, horizontal ellipsis points indicate one of the following: <ul style="list-style-type: none">• An item that is repeated• An omission such as additional optional arguments• Additional parameters, values, or other information that you can enter
	In format descriptions, a vertical bar separates similar options, one of which you can choose.
<i>italic type</i>	Italic type emphasizes important information, indicates variables, and indicates the complete titles of manuals.
boldface type	Boldface type in examples indicates user input. Boldface type in text indicates the first instance of terms defined either in the text, in the glossary, or both.
<i>nn nnn.nnn nn</i>	A space character separates groups of 3 digits in numerals with 5 or more digits. For example, 10 000 equals <i>ten thousand</i> .
<i>n.nn</i>	A period in numerals signals the decimal point indicator. For example, 1.75 equals <i>one and three-fourths</i> .
MONOSPACE	Text displayed on the screen is shown in monospace type.

Convention	Description
Radix indicators	The radix of a number is written as a word enclosed in parentheses, for example, 23(decimal) or 34(hexadecimal).
>>>	Three right angle brackets indicate the console prompt.
UPPERCASE	A word in uppercase indicates a command.
Note	A note contains information that is of special importance to the user.
Caution	A caution contains information to prevent damage to the equipment.

KA45 CPU Module Description

This chapter describes the KA45 **central processing unit (CPU)** module that is used in the MicroVAX 3100 Model 30 and Model 40 systems. It gives information on the following:

- KA45 CPU module
- MS44 or MS44L memory modules
- MS44 or MS44L memory option installation

1.1 KA45 CPU Module

The KA45 CPU module is based on **system-on-a-chip (SOC)** silicon technology. It uses MS44 or MS44L memory modules and a set of supported **small computer system interface (SCSI)** devices. Figure 1-1 shows the KA45 CPU module.


The KA45 CPU module is the primary component of the MicroVAX 3100 system in which it is installed. The KA45 CPU module contains the following components:

- The DC222 (SOC) processor chip—This chip is a 32-bit **complementary metal oxide semiconductor (CMOS)** virtual memory microprocessor. It includes an internal floating-point unit and a cache memory. The key features of the chip are as follows:
 - Support for the MicroVAX chip subset of the VAX™ instruction set
 - Support for the MicroVAX chip subset of the VAX data types
 - Full VAX memory management
 - Contains a 32-bit external data bus

KA45 CPU Module Description

- Packaged in a single chip

Figure 1-1 KA45 CPU Module



RE_EN08195A_91


- **The DC7201 S-chip**—This chip is the primary interface between the CDAL bus and all memory, video, and input/output circuits. It contains the following primary logic circuits:
 - Memory system control
 - Cache invalidate assist
 - Single SCSI controller interface
 - Direct memory access (DMA) control
 - Input/output address decode and control for numerous design specific features.
- 8M bytes of onboard **random-access memory (RAM)** with parity checking
- Support for up to 24M bytes of additional RAM
- 256K bytes of **read-only memory (ROM)**—This ROM contains the boot and diagnostic firmware for the system.

- **Provision for 32K bytes of additional ROM**—This ROM contains the boot and diagnostic firmware for the onboard options.
- **32-byte network address ROM**
- **Time-of-year clock that includes 50 bytes of nonvolatile RAM**
- **Four asynchronous communications ports as follows:**
 - **Three DEC423 ports**—These ports are **modified modular jack (MMJ) connectors**.
 - **One modem control port**—This port is a **D-sub 25-way connector**.
- **Ethernet controller for standard or ThinWire™ Ethernet**
- **SCSI controller, NCR 53C94**
- **Provision for asynchronous communications options that provide one of the following:**
 - **Eight additional DEC423 ports for Model 30 systems and eight or sixteen additional DEC423 ports for Model 40 systems**
 - **Four additional modem control ports for Model 30 systems and eight additional modem control ports for Model 40 systems**
- **Provision for synchronous communications options that provide:**
 - **One synchronous port for Model 30 systems and two synchronous ports for Model 40 systems**

Figure 1-2 is a block diagram of the KA45 CPU module.

KA45 CPU Module Description

Figure 1-2 KA45 CPU Module Block Diagram



RE_EN08188M_31

The KA45 CPU module supports the following VAX™ data types:

- byte, word, longword, quadword
- character string
- variable-length bit field
- f_floating-point, d_floating-point, and g_floating-point

The operating system uses software emulation to support other VAX data types. The KA45 CPU module supports the following VAX instructions:

- integer and logical
- address
- variable-length bit field
- control
- procedure call
- miscellaneous
- queue
- character string instructions:
- CMPC3/CMPC5
- LOCC
- MOVC3/MOVC5
- SCANC
- SKPC
- SPANC
- operating system support
- f_floating-point, d_floating-point, and g_floating-point

The operating system uses software emulation to support other VAX instructions. Figure 1-3 shows the controls, indicators, ports, and connectors on the KA45 CPU module. Table 1-1 describes the functions of the controls, indicators, ports, and connectors.

KA45 CPU Module Description

Figure 1-3 KA45 Controls, Indicators, Ports, and Connectors




Table 1-1 Functions of the Controls, Indicators, Ports, and Connectors

Component	Description
Internal SCSI connector	A connector that provides a connection to SCSI devices mounted inside the system enclosure.
Memory expansion connectors	Three pairs of connectors for memory options.
External SCSI connector	A connector that provides a connection to SCSI devices that are external to the system enclosure.
Power connector	A connector for direct current (dc) power.
ThinWire Ethernet port	A port that provides a connection to a ThinWire Ethernet network.
Ethernet switch	<p>A two-position switch that determines the type of Ethernet that the system uses as follows:</p> <ul style="list-style-type: none"> • Left position—selects the standard Ethernet type • Right position—selects the ThinWire Ethernet type
Standard Ethernet port	A port that provides a connection to a standard Ethernet network.
LED display	A set of eight LEDs that provides power-up and self-test diagnostic code information.
Break/Enable LED	<p>A LED indicator that shows the function of MMJ port 3 as follows:</p> <ul style="list-style-type: none"> • On—MMJ port 3 functions as a console port. • Off—MMJ port 3 functions as a communications port.
Break/Enable switch¹	<p>A two-position switch that determines the function of MMJ port 3 as follows:</p> <ul style="list-style-type: none"> • Up position—MMJ port 3 functions as a console port. In this state, you can press the Break key on the keyboard of a terminal connected to MMJ port 3 to put the system in console mode. • Down position—MMJ port 3 functions as a normal communications port. MMJ port 0 functions as the console port.

¹The system recognizes the position of this switch only when the system is turned on.

(continued on next page)

Table 1-1 (Cont.) Functions of the Controls, Indicators, Ports, and Connectors

Component	Description
Halt push button	A momentary-contact push button that puts the system in console mode.
Asynchronous modem control port 2	EIA-232 compatible asynchronous port with modem control.
MMJ port 3	DEC423 compatible asynchronous port. This port functions as an alternate console port when the Break/Enable switch is set to the up position when you turn on the system.
MMJ port 1	DEC423 compatible asynchronous port.
MMJ port 0	DEC423 compatible asynchronous port. This port is the primary console port.
DSW41 or DSW42 I/O connector	A connector that provides a connection for the DSW41 input/output cable or the DSW42 input/output cable.
DHW41 or DHW42 I/O connector	A connector that provides a connection for the DHW41 input/output cable or the DHW42 input/output cable.
DHW41 or DHW42 logic board connectors	Two connectors that provide connections for a DHW41 logic board or a DHW42 logic board.
DSW41 or DSW42 logic board connectors	Two connectors that provide connections for a DSW41 logic board or a DSW42 logic board.

1.2 MS44 and MS44L Memory Modules

The MS44 and MS44L memory modules provide memory expansion for the KA45 CPU module. The KA45 CPU module supports the MS44-BA (8M-byte) option, which contains two MS44L-AA (4M-byte) memory modules, and the MS44L-BA (8M-byte) memory option, which contains two MS44L-AA (4M-byte) memory modules.

Note


Use only MS44 or MS44L memory modules qualified by Digital.

The rules for adding MS44-AA or MS44L-AA memory modules are as follows:

- You must install both memory modules of a memory option. This means that you can expand memory in 8M-byte increments.
- You must install memory options in the next available connector pair in ascending numerical order.

Figure 1-4 shows the location of the onboard memory (8M bytes) and the memory expansion connectors. Table 1-2 lists the memory configurations.

Figure 1-4 Memory Expansion Connectors



RE_EN06198A_91

Table 1-2 KA45 CPU Module Memory Configurations

Total Memory (bytes)	Onboard Memory (bytes)	Increment 1		Increment 2		Increment 3	
		1H ¹	1L	2H	2L	3H	3L
8M	8M						
16M	8M	MS44-AA ²	MS44-AA				
24M	8M	MS44-AA	MS44-AA	MS44-AA	MS44-AA		
32M	8M	MS44-AA	MS44-AA	MS44-AA	MS44-AA	MS44-AA	MS44-AA

¹1H, 1L, 2H, 2L, 3H, 3L are the connector identifiers (see Figure 1-4).

²The MS44-AA memory module is a 4M-byte memory module. The MS44-BA memory option consists of two MS44-AA memory modules. You can use MS44L-AA memory modules instead of MS44-AA memory modules.

1.3 MS44 or MS44L Memory Option Installation

The MS44 and MS44L memory options consist of two memory modules. Install an MS44 or MS44L memory option on the KA45 CPU module as follows:

1. Position the KA45 CPU module, component side up, so that the edge connectors are facing you.
2. Identify the connectors on the KA45 CPU module into which you must install the memory option (see Figure 1-4 and Table 1-2).
3. Insert the first memory module, with the side containing the bar code facing you, into the connector on the KA45 CPU module (see Figure 1-5).


Caution

The connectors are keyed so that you install the memory modules with the correct orientation. Do not force the modules into the connectors with an incorrect orientation.

Caution

Make sure that you fully install the memory module into the connector before you tilt the module towards the front of the enclosure.

Figure 1-5 Memory Module Installation



RE_EN06100A_01

4. Tilt the memory module towards the front of the enclosure until the metal locking clips on the connector lock the memory module in position.
5. Repeat the procedure in step 1 for the second memory module. Insert it into the other connector for that memory increment on the KA45 CPU module.
6. Run the MEM diagnostic test (see Section 4.6) after you reinstall the KA45 CPU module into the system enclosure to check that the memory is working correctly.

Caution

When removing memory modules, you must release the metal clips on the connectors of the CPU module.

Configuration

This chapter describes the KA45 system configurations. It gives information on the following:

- Memory configurations
- Mass storage devices
- Communications options

2.1 Memory Configurations

A KA45 system has 8M bytes of onboard memory. You can add memory in 8M-byte increments, up to a maximum of 32M bytes. See Section 1.2 for information on the memory configurations.

2.2 Mass Storage Devices

A KA45 system supports mass storage devices in the following categories:

- Internal mass storage devices—These devices are mounted inside the system enclosure.
- External mass storage devices—These devices are self-contained units that you can connect to the system externally.

2.2.1 Internal Mass Storage Devices

Table 2-1 shows the internal mass storage devices that a KA45 system supports.

Table 2-1 KA45 Internal Mass Storage Devices

Option Name	Description	Size ¹ (in)	Capacity
RZ29L	Disk drive	3.5	120M bytes
RZ24	Disk drive	3.5	209M bytes
RZ25	Disk drive	3.5	400M bytes
TZ30 ⁴	Tape drive	5.25	95M-byte cartridge
TZK10 ⁴	Tape drive	5.25	Range of cartridges ²
RX26 ⁴	Diskette drive	3.5	Range of diskettes ³
RRD42 ⁴	CDROM drive	5.25	600 Mbytes

¹Size of half-height device.

²Supports 320-Mbyte and 525-Mbyte cartridges.

³Supports 1.4-Mbyte and 2.8-Mbyte diskettes.

⁴Removable media device.

The combinations of internal mass storage devices that you can have in a KA45 system depend on the system enclosure. See the *BA42-A Enclosure Maintenance* or the *BA42-B Enclosure Maintenance* manual.

2.2.2 External Mass Storage Devices


The external mass storage devices connect to KA45 systems via the SCSI connector on the back of the system enclosure. In KA45 systems, the SCSI bus supports a maximum of seven mass storage devices. Therefore, the number of external mass storage devices that you can connect depends on the number of mass storage devices that are mounted inside the system enclosure.

In Model 30 systems, the maximum number of mass storage devices in the system enclosure is three. This means that you can connect at least four external mass storage devices.

In Model 40 systems, the maximum number of mass storage devices in the system enclosure is five. This means that you can connect at least two external mass storage devices.

A KA45 system supports the SZ series of mass storage expansion boxes. The SZ number defines the contents of each expansion box. Figure 2-1 shows the numbering system for SZ expansion boxes.

Figure 2-1 SZ Expansion Box Numbering System



¹ The RZ25 disk drive fits in the BA42 enclosure only.

² The TLZ04 tape drive fits in the BA46 enclosure only.

A KA45 system also supports other types of external mass storage devices. Table 2-2 gives the other external mass storage devices that a KA45 system supports.

Table 2-2 Supported External Mass Storage Devices

Device	Description
RRD42-DA	RRD42 CDROM tabletop
TLZ04-FA	TLZ04 tape drive tabletop
TK50Z-GA/G3	TK50Z tape drive tabletop

The following rules apply when you are adding mass storage devices:

- You can add a maximum of four external SCSI devices. A fully configured SZ12 enclosure contains two SCSI devices.
- You can add a maximum of two SCSI tape devices. Depending on the configuration, the system may support two TLZ04 tape drives.
- The BA40 single drive expansion box contains one SCSI device.

Configuration

- The RRD42 CDROM drive is a single SCSI device. You can add a maximum of three RRD42 CDROM drives.
- Terminate the SCSI bus correctly. Failure to do this can cause a system failure or corrupt data.
- Digital recommends that you connect all SCSI devices to the same ac power source.
- Do not add or remove devices that are connected to the SCSI bus while the power is on.
- Digital does not guarantee the correct operation of a SCSI bus that does not use the cables supplied by Digital or is not configured in accordance with Digital recommendations.

2.2.3 SCSI ID Numbers

Each mass storage device must have a unique SCSI ID number. Table 2-3 gives the recommended SCSI ID numbers for the different types of internal and external mass storage devices.

Table 2-3 Recommended SCSI ID Numbers for Devices

SCSI ID	Device
0	
1	RZ2* ¹
2	RZ2* ¹
3	RZ2* ¹ (system disk)
4	RRD42
5	TZ30 or TZK10 (system backup device)
6	SCSI controller (INITR)
7	

¹The asterisk (*) indicates that these devices can be RZ23L, RZ24, or RZ25 disk drives.

2.3 Communications Options

A KA45 system supports the following types of communications options:

- Asynchronous communications options
- Synchronous communications options

Each communications option has components that are installed in the system enclosure and components that connect to the system externally.

2.3.1 Asynchronous Communications Options

The asynchronous communications options that a KA45 system supports depend on the model type of the system. Table 2-4 gives the asynchronous communications options that the KA45 systems support.

Table 2-4 Supported Asynchronous Communications Options

Option	Description
Model 30	
DHW41-AA	Eight-line DEC423 asynchronous option
DHW41-BA	Four-line EIA-232 modem control asynchronous option
Model 40	
DHW42-AA	Eight-line DEC423 asynchronous option
DHW42-BA	Sixteen-line DEC423 asynchronous option
DHW42-CA	Eight-line EIA-232 asynchronous modem control option
DHW42-UP	Eight-line to 16-line DEC423 asynchronous upgrade option

2.3.2 Synchronous Communications Options

The synchronous communications options that a KA45 system supports depend on the model type of the system. Table 2-5 gives the synchronous communications options that the KA45 systems support.

Table 2-5 Supported Synchronous Communications Options

Option	Description
Model 30	
DSW41-AA ¹	One-line EIA-232/V.24 synchronous option with one external cable, BC19D-02 (17-01110-01)
Model 40	
DSW42-AA ²	Two-line EIA-232/V.24 synchronous option with two external cables, BC19D-02 (17-01110-01)
¹ This option is supplied with one external cable that supports the EIA-232/V.24 interface.	
² This option is supplied with two external cables that support the EIA-232/V.24 interface.	

The DSW41-AA and the DSW42-AA options also support the communications interfaces listed in Table 2-6, but you must order the external cables separately.

Table 2-6 DSW41-AA and DSW42-AA Communications Support

Communications Interface	External Cable
EIA-423/V.10	BC19E-02 ¹ (17-01111-01)
EIA-422/V.11	BC19B-02 ¹ (17-01108-01)
¹ Two required for DSW42-AA.	

KA45 Firmware

This chapter describes the structure and operation of the KA45 firmware. It gives information on the following:

- **Power-Up test and initialization**—This code tests and initializes all the devices in a KA45 system.
- **Console program**—This program parses and executes all the commands entered at the console prompt (>>>).
- **Self-Test**—This code executes when a user runs a diagnostic self-test by entering the command **TEST** at the console prompt. This code also executes when a user runs tests in the Manufacturing test environment.
- **Utilities**—This code provides device-specific functions that are not provided by the other KA45 firmware functions.
- **System exerciser**—This code tests the operation of devices in the system concurrently. The purpose of this code is to provide a high level of DMA and interrupt activity for devices in the KA45 system.

3.1 Power-Up Test and Initialization

When you turn on the system, the system executes the power-up test and initialization code, which builds a power-up test display on the console terminal that is connected to the system unit. When the default recovery action is set to 3 (see *CPU Reference Information*, Section 1.11.5), the system is in console mode when the power-up test and initialization code is completed. Figure 3-1 shows a successful power-up test display. The display differs slightly depending on the type of console terminal you use.

Figure 3-1 Successful Power-Up Test Display

```
KA45-A V1.0
08-C0-2B-04-03-12
32MB
+-----+
#####
>>>
```

A—On a Standard ASCII Terminal

```
KA45-A V1.0
08-00-2B-04-03-12
32MB
████████████████████████████████████████████████████████████████████████████████
>>>
```

B—On a Graphics Display Terminal

- The CPU name and the version of the KA45 firmware. The character V indicates the version of the system firmware. The number 1.0 indicates the release number.
- The Ethernet address of the system.
- The size of the internal system memory.
- The status bar shows the progress of the test. When the status bar reaches the completion mark, the test is completed successfully.
- The console prompt.

Figure 3-2 shows an unsuccessful power-up test display. In Figure 3-2, the incomplete status bar shows that the power-up test did not complete because of an error. The system displays the error information under the status bar.

Figure 3-2 Unsuccessful Power-Up Test Display

KA45-A V1.0
 08-00-2B-04-03-12
 32MB

-----+
 #####

?? 001 9 NI 0066

>>>

A—On a Standard ASCII Terminal

KA45-A V1.0
 08-00-2B-04-03-12
 32MB

-----|

?? 001 9 NI 0066

>>>

B—On a Graphics Display Terminal

- The CPU name and the version of the KA45 firmware. The character V indicates the version of the system firmware. The number 1.0 indicates the release number.
- The Ethernet address of the system.
- The size of the internal system memory.
- Incomplete status bar.
- Completion mark.
- An error message—The elements are as follows:
 - Two question marks (??) indicate a hard error, that is, an error that you must correct before you boot the system. A single question mark (?) indicates a soft error, that is, an error that you do not have to correct before you boot the system.
 - 001 is the field replaceable unit (FRU) number of the device that fails. See Appendix C for the list of FRU numbers.
 - 9 is the test number (in this example, the Ethernet test number).
 - NI is the test mnemonic (in this example, the Ethernet test mnemonic).

- 0066(decimal) is an error code (see *CPU Reference Information*, Table 3-11).
- The console prompt.

Note

The rest of the console screen illustrations in this manual show the system output only on an **American Standard Code for Information Interchange (ASCII)** terminal. The system output on a graphics display terminal is slightly different from a standard ASCII terminal; a solid status bar replaces the line of number signs (#).

3.2 Console Program

The console program is firmware code that controls a device (the console device). This device allows you to enter diagnostic test commands (console commands) when the system is in a halt state (console mode).

The console program also contains the input and output routines that control the transfer of data to and from the console device. The power-up tests, extended self-tests, utilities, system exerciser, and virtual machine bootstrap (VMB) program also use these routines to transfer data to and from the console device.

3.2.1 Console Device

When you turn on the system with the default recovery action set to 3 (see *CPU Reference Information*, Section 1.11.5), the system is in console mode after the power-up tests are completed. Depending on the position of the break/enable switch on the back of the system unit, the terminal connected to either MMJ port 0 or MMJ port 3 is the console device (see Table 3-1).

Table 3-1 Console Device Port Selection


Break/enable Switch Position ¹	Console Terminal Port
Down	MMJ Port 0
Up	MMJ Port 3 ²

¹The system recognizes the position of the switch only when you turn on the system.

²On a terminal connected to MMJ port 3, you can press the Break key to put the system in console mode.

Figure 3-3 shows the location of the MMJ ports on the system module.

Figure 3-3 Location of the Console-Related Ports and Switches



When a system is delivered, the break/enable switch is set to the down position, therefore MMJ port 0 is the console terminal port. To use MMJ port 3 as the console terminal, follow these steps:

1. Turn off the system unit.
2. Set the break/enable switch to the up position.
3. Turn on the system unit.

MMJ port 3 is now the console port terminal. You can connect one of the following console devices to this port:

- A VT™ series type terminal (for example, VT330™)
- A printer (for example, LA34)

- A host computer that runs special test software (for example, APT)

If you connect a VT series type terminal to MMJ port 3, you can press the Break key on the keyboard to put the system in console mode. To ensure the correct operation of the terminal, you must set the communication parameters for a terminal connected to MMJ port 3. Table 3-2 gives the correct terminal settings.

Table 3-2 Terminal Settings

Feature	Setting
Terminal mode	VTnnn-7bit
Transmit speed	9600 baud
Receive speed	receive = transmit
Character format	8 bits, no parity
Stop bits	1
Comm1 port	DEC-423 (data-leads-only)

3.2.2 Console Commands

You can enter console commands from a console device. *CPU Reference Information*, Chapter 1, describes the console commands that you can enter. When you enter a command at the console prompt, the console program parses and executes the command. If the console program detects an error, it displays an error message. *CPU Reference Information*, Chapter 2, gives the console messages for KA45 systems.

3.2.3 Console Mode

The system is in console mode when one of the following conditions occurs:

- System power-up—When you turn on the system, and the recovery action flag is set to halt the system.
- External halt—You can initiate an external halt in one of two ways:
 - Press the halt push button on the back of the system unit.
 - Press the Break key on the keyboard of a console device that is connected to MMJ port 3 on the back of the system unit. This function is effective only when the break/enable switch is set to the break (up) position before you turn on the system.
- Boot failure—The system fails to boot correctly.

- **Critical CPU condition**—The system forces a CPU restart or a reboot when it detects an event that it interprets as a severe corruption of its operating environment. The virtual memory system (VMS) sysgen parameter, BUGREBOOT determines if the system restarts or reboots. If BUGREBOOT is 0, the system restarts; if BUGREBOOT is 1, the system reboots.
- **Kernel program mode**—The system processes a halt instruction in kernel program mode. The recovery action flag is set to halt the system.

When the system is in console mode, it displays the console prompt. You can enter console commands at this prompt (see *CPU Reference Information*, Chapter 1).

3.2.4 Console Security

The KA45 systems have a console security feature that you can use to restrict the use of certain console commands to authorized users. You use the SET PSE command to enable the security system (see *CPU Reference Information*, Section 1.11.8), and you use the SET PSWD command to enter a console security password (see *CPU Reference Information*, Section 1.11.9). Users must know this password to access the full range of console commands. When the console security feature is enabled, there are two console modes in which the system operates as follows:

- Unprivileged console mode
- Privileged console mode

When you put the system in console mode, and the console security system is enabled, the system operates in unprivileged console mode. You can enter only the following console commands:

- LOGIN
- BOOT (without parameters)
- CONTINUE
- ! (Comment)

When you enter a command other than the four commands shown previously while the system is in unprivileged console mode, the system displays an error message as follows:

```
?23 ILL CMD
```


You can use the **LOGIN** command (see *CPU Reference Information*, Section 1.9) to enter privileged console mode. To use this command, you must know the current console security password. When you enter the correct password, you can use all of the console commands.

In privileged console mode, you can use the **SET PSE** command to disable the console security feature (see *CPU Reference Information*, Section 1.11.8). When the system is in privileged console mode, you can enter one of the following commands to return the system to unprivileged console mode:

- **BOOT**
- **CONTINUE**
- **HALT**
- **START**

If the system owner forgets the password, you can clear the password in the nonvolatile RAM (NVR) as follows:

1. Set the on/off switch on the system unit to the off (O) position.
2. Remove the enclosure cover. See the *BA42-A Enclosure Maintenance* or the *BA42-B Enclosure Maintenance* manual for more information.
3. Use a screwdriver to short-circuit two NVR contacts on the CPU module (see Figure 3-4).

Figure 3-4 Location of the NVR Contacts for Clearing the Password

4. Install the enclosure cover.

5. Turn on the system unit.

When the console prompt is displayed, the owner can use the SET PSWD command (see *CPU Reference Information*, Section 1.11.9) to enter a new password.

3.2.5 Console Command Conventions

When entering console commands, the following rules apply:

- Commands cannot be more than 80 characters long.
- The command interpreter is not sensitive to case. The command interpreter treats lowercase ASCII characters as uppercase ASCII characters.
- The command parser rejects the characters that have ASCII codes greater than 7FH. You can, however, include these characters in comments.
- Type-ahead text entry is not supported. The command interpreter checks characters that it receives before it displays the console prompt, but ignores all other characters except control characters (see Table 3-3).

In console mode, certain keys have special control functions. Table 3-3 lists these keys and control functions.

Table 3-3 Console Mode Control Keys

Key	Function
Return key	Ends a command line.
Delete key	Deletes the previously typed character. On VT series terminals, press this key to delete a character from the screen. On hard copy terminals, the system prints a slash (/) before and after the deleted character.
Break key ¹	On a console device connected to MMJ port 3, press the Break key to put the system in console mode.
Ctrl/C	Causes the console program to abort processing a command. The console program displays Ctrl/C as ^C.
Ctrl/O	Causes the console program to discard output until you enter the next Ctrl/O sequence or until the console program receives the next console prompt or error message. Ctrl/C also cancels Ctrl/O. The console program displays Ctrl/O as ^O.
Ctrl/Q	Resumes the console output that is suspended when you press Ctrl/S.
Ctrl/R	Causes the current command line to be displayed, without the deleted characters.
Ctrl/S	Suspends the current command line that the console program displays until the next Ctrl/Q sequence.
Ctrl/U	Discards all the characters on the current command line. The console program does not abort a command if it receives this control character while processing the command. The console program displays this control key as ^U.

¹Applies only if the break/enable switch on the back of the system unit is set to the break (up) position before you turn on the system.

Note

During X command data transfers, the command interpreter treats the codes for the control keys as binary data.

3.3 Self-Test

The KA45 firmware provides a set of diagnostic tests that you can access using the console command, **TEST** (see *CPU Reference Information*, Section 1.14). The console program passes a list of the device numbers (or device mnemonics) and test parameters to the test command dispatcher. The test command dispatcher is the code that runs the self-test for each device that the console program passes. The tests run until all the tests complete successfully or an error occurs.

When you use the **TEST** command, you must specify a device. Table 3-4 gives the device number and device mnemonic for all the devices in KA45 systems.

Table 3-4 Device Numbers and Mnemonics

Device Number	Device Mnemonic	Description
1	NVR	Nonvolatile RAM
2		Reserved for future use
3	DZ	Serial line controller
4	CACHE	Cache system
5	MEM	Memory
6	FPU	Floating-point unit
7	IT	Interval timer
8	SYS	Miscellaneous CPU module hardware
9	NI	Network interface
10	SCSI	SCSI controller
11		Reserved for future use
12	COMM	Synchronous communications option
13		Reserved for future use
14	ASYNC	Asynchronous communications option
15 to 99		Reserved for future use

When you use the **TEST** command to test a device, you can specify either the device number or the device mnemonic. You can enter a command to test the following:

- A single device
- Multiple devices

- A range of devices
- A combination of the three previous options

Table 3–5 gives some typical TEST (T) command lines.

Table 3–5 Typical TEST Command Lines

Type	Command Using Device Numbers	Command Using Device Mnemonics	Description
Single device	T 5	T MEM	Runs the self-test on memory.
Multiple devices	T 3,4	T DZ,CACHE	Runs the self-test on the serial line controller and the cache system.
Device range	T 5:7	T MEM:IT	Runs the self-test on the memory in the system, the floating-point unit, and the interval timer (IT).
Combination	T 1,3,8:10	T NVR,DZ,SYS:SCSI	Runs the self-test on the nonvolatile RAM, serial line controller, miscellaneous CPU module hardware, network interface, and SCSI controller.

You can include device numbers and device mnemonics on the same TEST command line. The following command is an example of a TEST command that has device numbers and device mnemonics on the command line:

```
>>> T 10:8,6, MEM:DZ
```

When you enter the test commands, the following rules apply:

- You can specify device numbers and mnemonics in any order on the command line.
- You can include a device number or a device mnemonic many times on the same command line.
- The maximum number of tests specified on a single command line must not exceed fifteen.

In the example shown previously, although the combined number of device mnemonics and device numbers on the command line is five, the number of tests specified is seven. This means that you can specify only eight more tests on this command line. Figure 3-5 shows a successful self-test display.

Figure 3-5 Successful Self-Test Display

```
>>> T 9:7
+-----+
##### ●
OK●
>>>
```

- Complete status bar.
- A console status message that indicates a successful test.

Figure 3-6 shows an unsuccessful self-test display.

Figure 3-6 Unsuccessful Self-Test Display

```
>>> T 9:7
+-----+
##### ●
● ● ● ● ●
?? 001 07 FP 22
84 FAIL●
>>>
```

- Incomplete status bar.
- Two question marks (??) indicate a hard error, that is, an error that you must correct before you boot the system. One question mark (?) indicates a soft error, that is, an error that you do not have to correct before booting the system.
- The FRU number of the device that fails.
- The device number of the device that fails.
- The device mnemonic of the device that fails.
- An error code that corresponds to a specific device error.
- A console error message that indicates a test failure (see *CPU Reference Information*, Chapter 2).

CPU Reference Information, Chapter 3, lists the error codes and messages that the KA45 diagnostic tests generate.

3.3.1 Additional Error Information for Self-Tests

When a test fails, you can get more error information about the test using the following command:

```
>>> SHOW ERROR
```

Figure 3–7 is an example of the information that this command displays.

Figure 3–7 Additional Error Information for Self-Tests

```

●   ●   ●       ●   ●
?? 001   3       DZ 0050
001 000B 00000051 00000220 00001E08 00000000 00000000 00000000
>>>

```

- Two question marks (??) indicate a hard error, that is, an error that you must correct before booting the system. One question mark (?) indicates a soft error, that is, an error that you do not have to correct before you boot the system.
- The FRU number of the device that fails.
- The device number of the device that fails.
- The device mnemonic of the device that fails.
- An error code that corresponds to a specific device error.
- A line of error information that is related to the device name (or test number) on the line immediately preceding it. In the example, the additional error information line is related to the DZ test (test 3). See *CPU Reference Information*, Chapter 3, for information about the formats and meaning of the additional error information line for the various tests.

3.3.2 Test Environments

You can run diagnostic self-tests in three different environments as follows:

- Customer environment
- Digital Services environment
- Manufacturing environment

The test environment determines the level of device testing. For example, testing in the Customer environment is minimal, whereas testing in the Digital Services environment and the Manufacturing environment is more extensive.

3.3.2.1 Customer Environment

This is the default test environment in which the user tests the operation of the system. To return the system to the Customer environment from another test environment, enter the following command:

```
>>> SET DIAGENV 1
```

3.3.2.2 Digital Services Environment

This is the test environment that Digital Services personnel use to test the system.

Note

You must connect a loopback connector (29-24795-00) to the asynchronous modem control port 2 on the back of the system unit before you can put the system in the Digital Services environment.

The firmware verifies that the loopback connector is present by checking that pin 12 and pin 18 of asynchronous modem control port 2 are looped. To put the system in the Digital Services environment, enter the following command:

```
>>> SET DIAGENV 2
```

In this test environment, certain tests and utilities require loopback connectors (see Chapter 4).

3.3.2.3 Manufacturing Environment

This is the test environment that Manufacturing personnel use to test the system. Running tests in this environment is also known as *extended self-test*.

Note

You must connect a loopback connector (29-24795-00) to the asynchronous modem control port 2 on the back of the system unit before you can put the system in the Manufacturing environment.

The firmware verifies that the loopback connector is present by checking that pin 12 and pin 18 of asynchronous modem control port 2 are looped. To put the system in the Manufacturing environment, enter the following command:

```
>>> SET DIAGENV 3
```

In this test environment, certain tests require loopback connectors and media with special keys (see Section 3.4) to which the system can write data (see Chapter 4).

3.4 Utilities

The KA45 firmware provides utilities for the following devices:

- SCSI
- COMM

You invoke a utility using a TEST command that has the following format:

```
>>> T[EST]/UT[ILITY] <devnam | devnbr>
```

where:

- *T[EST]* is the TEST command
- */UT[ILITY]* is the utility qualifier
- *devnam* is the device mnemonic
- *devnbr* is the device number

If an error occurs or you press Ctrl/C to interrupt a utility, the console generates a display similar to the following:

SCSI_E_err 196●

84 FAIL●

>>>

- Utility error message and code (see *CPU Reference Information*, Chapter 4)
- Console error message (see *CPU Reference Information*, Chapter 2)

3.4.1 SCSI Utilities

To get a list of the utilities available for SCSI devices, enter the following command:

>>> TEST/UTIL SCSI

The system displays the following menu:

- 1 - SCSI-flp_key
- 2 - SCSI-tp_key
- 3 - SCSI-hd_dsk_eras
- 4 - SCSI-flp_fmt

SCSI_util>>>

The functions of these utilities are as follows:

- SCSI-flp_key—Puts a special diagnostic key on a floppy diskette that enables the firmware to write data to the diskette during tests in the Manufacturing environment.

Note

This utility works only in the Digital Services environment. To put the system in the Digital Services environment, see Section 3.3.2.2.

- SCSI-tp_key—Puts a special diagnostic key on a tape cartridge that enables the firmware to write data to the tape cartridge during tests in the Manufacturing environment.

Note

This utility works only in the Digital Services environment. To put the system in the Digital Services environment, see Section 3.3.2.2.

Caution

You can use the `SCSI-hd_dsk_eras` utility in the Customer environment.

- `SCSI-hd_dsk_eras`—Erases the contents of a disk drive.
- `SCSI-floppy_fmt`—Formats a floppy diskette.

For example, to erase the data on a hard disk, enter 3 at the `SCSI_util>>>` prompt as follows:

```
SCSI_util>>> 3
```

The KA45 firmware prompts you for the SCSI ID of the disk drive from which you want to erase the data. If the SCSI ID of the disk drive is 1, for example, enter 1 in response to the prompt as follows:

```
SCSI_id(0-7)>>> 1
```

The KA45 firmware prompts you for the logical number of the drive, usually 0, unless there is another SCSI controller in the system. Enter 0 in response to the prompt as follows:

```
SCSI_lun(0-7)>>> 0
```

The KA45 firmware displays a status message, then a prompt. You must enter OK in response to this prompt as follows:

```
SCSI HD_DSK_ERAS_UTIL
```

```
DKA100 OK? OK
```

The KA45 firmware displays a status bar, indicating that the erasing of the disk is progressing. This operation takes several minutes. When the operation is complete, the KA45 firmware displays a complete status bar and status messages as follows:

```
+-----+  
#####
```

```
SCSI_bb_repl 0
```

```
SCSI_util_succ
```


3.4.2 COMM Utilities

The KA45 firmware includes some utilities for synchronous communications devices. These utilities are not intended for use by Digital Services personnel.

3.5 System Exerciser

The KA45 firmware has a system exerciser that tests the simultaneous operation of multiple devices in a KA45 system. The system exerciser tests the interaction of devices in the system by causing maximum DMA and interrupt activity. You invoke the system exerciser by entering a TEST command that has a test number in the range 100 to 106. For example:

```
>>> T 100
```

The KA45 firmware causes the VMB program to load the system test kernel and monitor. The system test monitor determines which TEST command caused it to load. Control then passes to the system test kernel, which defines the appropriate operating environment. You can run the system exerciser in any of the following environments:

- Customer environment
- Digital Services environment
- Manufacturing environment

Table 3-6 gives the predefined system exerciser commands and the test environments in which they run.

Caution

The system exerciser tests, T 102 and T 104, are destructive tests. When you run these tests, the data on the disk drives (excluding the system disk that contains VMS) and the data on the removable media, which are installed in tape drives and diskette drives, are deleted.

Table 3-6 Predefined System Exerciser Tests

Command	Action	Environment	Code
T 100	Runs two passes of the system exerciser.	Customer environment	CU
T 101	Runs two passes of the system exerciser.	Digital Services	CS
T 102	Runs the system exerciser until you press Ctrl/C.	Digital Services	CS
T 103	Runs the system exerciser until you press Ctrl/C.	Manufacturing	MU
T 104	Runs the system exerciser until you press Ctrl/C.	Special ¹	
T 106	Runs the system exerciser on selected tests. The firmware prompts you to choose the tests you want to run.	Digital Services or Manufacturing ²	

¹This is a special environment used by Manufacturing.

²Use the SET DIAGENV command to put the system in the environment you want (see *CPU Reference Information*, Section 1.11.3).

Figure 3-8 shows a successful, system exerciser test that was run in the Digital Services environment.

Figure 3-8 Successful System Exerciser Test

```

>>> T 101
KA45/47 V1.0   System Test CS           0 00:01:29

  3   DZ #
  9   NI #
 10   SCSI #
 12   COMM #
 14   ASYNC #

```

```

***** SYT_DISPLY_SUMRY (('1'=Y), ('0'=N))..... ?

```

- The CPU name and the version of the console program. The character V indicates the version of the system firmware. The number 1.0 is the release number.
- CS is the Digital Services environment (see Table 3-6).
- The duration of the test in the format: days hours:minutes:seconds.
- A status bar for each device that the system exerciser tests.
- A prompt for summary screens (see Section 3.5.2)—Enter 1 to display the summary screens; enter 0 to display the console prompt.

Figure 3-9 shows an unsuccessful system exerciser test that was run in the Digital Services environment.

Figure 3-9 Unsuccessful System Exerciser Test

```

>>> T 101
KA45/47 V1.0   System Test CS           0 00:00:59
    3    DZ #
    9    NI #
   10    SCSI #
   12    COMM #
  ?? 14    ASYNC 40    0305           0 00:01:26

```

```

***** SYT_DISPLY_SUMRY (('1'=Y), ('0'=N))..... ?

```

- The CPU name and the version of the console program. The character V indicates the version of the system firmware. The number 1.0 is the release number.
- CS is the Digital Services environment (see Table 3-6).
- The duration of the test in the format: days hours:minutes:seconds.
- Two question marks (??) indicate a hard error, that is, an error that you must correct before booting the system. One question mark (?) indicates a soft error, that is, an error that you do not have to correct before booting the system.
- The device number of the failing device.
- The device mnemonic of the failing device.
- The number of the most suspect FRU.
- A device-specific error code (a decimal number, see *CPU Reference Information*, Section 5.3).
- The time when the test failure occurred.
- A prompt for the summary screens (see Section 3.5.2). Enter 1 to display the summary screens; enter 0 to display the console prompt.

3.5.1 Selective System Exerciser Test (T 106)

In the Digital Services and Manufacturing environments, you can use the command T 106 to select devices that you want to include in the system exerciser test. When you enter this command, the system prompts you to choose if you want to include or exclude any of the devices in the system exerciser. Figure 3-10 is an example of the display that the system exerciser command T 106 produces.

Figure 3-10 Selective System Exerciser Test (T 106) Example

```
>>> T 106
```

```
-PRA0
```

```
TST DEV - DZ          ? 1
TST DEV - NI          ? 1
TST DEV - SCSI        ? 0
TST DEV - COMM        ? 0
TST DEV - ASYNC       ? 1
```

In Figure 3-10, you must enter 1 or 0 after each prompt. Enter 1 to include the device in the system exerciser test; enter 0 to exclude it. In Figure 3-10, the system exerciser runs on the devices DZ, NI, and ASYNC.

Note

When you run test T 106 and if you do not include the DZ test, you cannot press Ctrl/C to stop the test. When a console terminal is connected to MMJ port 3, you can press the Break key to stop the test. When a console terminal is connected to MMJ port 0, you can press the Halt button on the back of the system unit to stop the test.

When the test is finished, you can enter the SHOW ESTAT command to display the summary screens that test T 106 generated.

3.5.2 Summary Screens

The system exerciser generates summary screens that show the progress or results of the most recent system exerciser test. The system displays a summary screen when one of the following conditions is satisfied:

- When the system exerciser test completes and you choose to view the summary screens
- When you press Ctrl/C to interrupt a system exerciser test and you choose to view the summary screen
- When you enter the command SHOW ESTAT (see *CPU Reference Information*, Section 1.12.7)

The summary screens are displayed in the order in which the tests are performed. When the system exerciser test is complete, it displays a prompt at the bottom of the screen as follows:

```
***** SYT_DISPLY_SUMRY (('1'=Y), ('0'=N))..... ?
```

Enter 1 to view the first summary screen or 0 to display the console prompt.

Figure 3–11 is an example of a summary screen for the DZ test that was performed during a system exerciser test. The summary screens formats of the individual tests are the same in all test environments.

Figure 3-11 Summary Screen for System Exercise: DZ Test

```

***** FST EXT_ERRPT 3DZ 0 00:01:25 *****
Line  L_Param  Chr_Xmt  Chr_Rec  Error
-----
0      00000780 00000780 ***** No Err *****
1      00000780 00000780 ***** No Err *****
2      00000780 00000780 ***** No Err *****
3      00000000 00000000 *Not Tstd - Cons_lin*

```

***** SYSTST_NXT_SCR ((' ('1'=Y), ('0'=N))..... ?

- Summary screen identifier.
- Test number and mnemonic.
- The time taken to complete the test.
- The number of the line that is being tested as follows:
 - 0 represents MMJ port 0
 - 1 represents MMJ port 1
 - 2 represents asynchronous modem control port 2
 - 3 represents MMJ port 3
- The communication line parameters (displayed only when an error occurs).
- The number of characters transmitted.
- The number of characters received.
- A comment denoting the type of error.
- A prompt for the next summary screen. Enter 1 to display the next summary screen; enter 0 to display the console prompt.

Figure 3–12 is an example of a summary screen for the NI test that was performed during a system exerciser test.

Figure 3–12 Summary Screen for System Exerciser NI Test

```
***** FST EXT_ERRPT 9NI 0 00:01:35 *****
```

```
***** SYSTST_NXT_SCR ((' ('1'=Y), ('0'=N))..... ?
```

- Summary screen identifier.
- Test number and mnemonic.
- The time taken to complete the test.
- A prompt for the next summary screen. Enter 1 to display the next summary screen; enter 0 to display the console prompt.

Figure 3–13 is an example of a summary screen for the SCSI test that was performed during a system exerciser test.

Figure 3-13 Summary Screen for System Exerciser SCSI Test

```

***** FST EXT_ERRPT 10SCSI 0 00:01:31 *****
ADR  RDS  WRTS  ERR FRU CMD  PHS INF LBNSTRT XFERSIZ
-----
1/0 00010987 00000000
3/0 00005643 00005643          36 1378 119
4/0 00000028 00000028 160 150 28 1
-----

```

```

***** SYSTST_NXT_SCR ((' ('1'=Y), ('0'=N))..... ?

```

- Summary screen identifier.
- Test number and mnemonic.
- The time taken to complete the test.
- The SCSI ID and the logic unit number of each device.
- The number of read operations (decimal) performed on each device.
- The number of write operations (decimal) performed on each device.
- The error code (hexadecimal).
- The field replaceable unit number.
- The SCSI command (hexadecimal) that was executing at the time of failure.
- The SCSI bus phase (hexadecimal) at the time of failure.
- Error information code (see *CPU Reference Information*, Section 3.9.1).
- The starting logical block-number of the data transfer that failed.
- The size (in blocks) of the data transfer that failed.
- A prompt for the next summary screen—Enter 1 to display the next summary screen; enter 0 to display the console prompt.

Figure 3-14 is an example of a summary screen for the COMM test that was performed during a system exerciser test.

Figure 3-14 Summary Screen for System Exerciser COMM Test

```
***** FST EXT_ERRPT 12COMM      0 00:01:29 *****
```

```
COMM Test Summary Screen.....
```

```
CH1 TX:00000030 RX:00000030 ERR:00000000
CH2 TX:00000030 RX:00000030 ERR:00000000
CH3 TX:0000000C RX:0000000C ERR:00000000
```

```
COMM Test Status Block .....
```

```
FRU: 0014  FTY: 0006
CSR: 0A04  STA: 0001
HWV: 0003  SWV: 000D
CC1: 0000  CC2: 0000
MOD: 0001  CNT: 0002
CHN: 0002  SEL: 0003
PROT:0002  SCM: F0C2
ABI: 0002  ALO: 4000
BPS: 5214  SIZ: 0008
EXP: 0000  ACT: 0000
```

```
***** SYSTST_NXT_SCR ((' ('1'=Y), ('0'=N))..... ?
```

- Summary screen identifier.
- Test number and mnemonic.
- The time taken to complete the test.
- The number of the channel that is being tested as follows:
 - CH1 corresponds to synchronous port 1.
 - CH2 corresponds to synchronous port 0.
 - CH3 is not used.
- The number of transmit operations performed on each channel.
- The number of receive operations performed on each channel.
- The number of errors detected on each channel.
- The contents of relevant status registers.

- A prompt for the next summary screen—Enter 1 to display the next summary screen; enter 0 to display the console prompt.

Figure 3–15 is an example of a summary screen for the ASYNC test that was performed during a system exerciser test.

Figure 3–15 Summary Screen for System Exerciser ASYNC Test

```

***** FST EXT_ERRPT 14ASYNC      0 00:02:02 *****
ASYNC Test Summary Screen.....
-----

ASYNC Test Status Block.....

FRU: 0028  STA: 0000●
CSR: 0101  LPR: FF18
EXT: 0000  MOD: 0000
PRT: 0000
BPS: 000F
EXP: 0000  ACT: 0000

-----

SYT_EXT_STATUS - PRMT_NXT_SCRN ? ●

```

- Summary screen identifier.
- Test number and mnemonic.
- The time taken to complete the test.
- The contents of relevant status registers.
- A prompt indicating that the last summary screen is displayed. Press Return to display the console prompt.

3.5.3 Additional Error Information for System Exerciser Tests

When the system exerciser test is complete, you can get more information about the test using the following command:

```
>>> SHOW ERROR
```

Figure 3–16 is an example of the information that this command displays.

Figure 3-16 Additional Error Information for System Exerciser Tests

```

●   ●   ●   ●   ●
?  000  1      NVR  0003
?? 130  10      SCSI 0018
130 000E 00000003 00120012 00180000 FFFF001B 00000000 00000000 FFFFFFFF●

```

- One question mark (?) indicates a soft error, that is, an error that you do not have to correct before you boot the system. Two question marks (??) indicate a hard error, that is, an error that you must correct before you boot the system.
- The FRU number of the device that fails.
- The device number of the device that fails.
- The device mnemonic of the device that fails.
- An error code that corresponds to a specific device error.
- A line of error information that is related to the test name (or test number on the line immediately preceding it). In the example, the additional error information line is related to the SCSI test (test 10). See *CPU Reference Information*, Chapter 3, for information about the formats and meaning of the additional error information for the various tests.

Testing and Troubleshooting

This chapter describes how to troubleshoot a MicroVAX 3100 system that uses the KA45 CPU module. It gives information on the following:

- General troubleshooting information
- No display on the console terminal
- NVR test (test 1)
- DZ test (test 3)
- CACHE test (test 4)
- MEM test (test 5)
- FPU test (test 6)
- IT test (test 7)
- SYS test (test 8)
- NI test (test 9)
- SCSI test (test 10)
- COMM test (test 12)
- ASYNC test (test 14)
- Power supply troubleshooting procedures

4.1 General Troubleshooting Information

You perform troubleshooting procedures while the system is in console mode, that is, while the operating system software is in a halt state. The troubleshooting procedures are based on the diagnostic test firmware provided with the system. When you turn on the system, it runs the power-up test and initialization. This test runs the individual diagnostic tests that check the various components in the system. Table 4-1 lists the diagnostic tests and the FRUs on which each diagnostic test focuses.

Troubleshooting

The system runs the power-up test and initialization automatically when you turn on the system. If the power-up and initialization test fails, follow these steps:

1. Read the console terminal display or read the code on the LED display (see *CPU Reference Information*, Chapter 6).
2. Note the test number and mnemonic of the failing device or use the LED code that you read during step 1 to identify the test number and mnemonic of the failing device (see Table 4-1).
3. See Table 4-1 for a reference to a section in this chapter that provides the testing and troubleshooting information for the failing device.

The testing and troubleshooting procedures that Table 4-1 references, describe the procedures for isolating a fault to FRU level.

In general, it is recommended that you run the individual self-test (see Section 3.3) on the failing device when the system is in the Digital Services environment.

Note

You must connect a loopback connector (29-24795-00) to the asynchronous modem control port 2 before you can put the system in the Digital Services environment.

To put the system in the Digital Services environment, enter the following command at the console prompt:

```
>>> SET DIAGENV 2
```

See the *CPU Reference Information*, Section 1.11.3, for a list of all the test environments. In the Digital Services environment, you must use loopback connectors, terminators, or test media to run certain tests successfully. The sections that Table 4-1 references describe the requirements of each test.

For more comprehensive testing and to check the interaction of devices in the system, you can run the system exerciser (see Section 3.5). The system exerciser is also useful for troubleshooting intermittent errors in the system.

Table 4-1 Troubleshooting Procedures

Failing Test	Device Mnemonic	LED Display Indication	Most Suspect FRUs	Section Reference
1	NVR	0001 xxxx ¹	CPU module	4.3
3	DZ	0011 xxxx	CPU module	4.4
4	CACHE	0100 xxxx	CPU module	4.5
5	MEM	0101 xxxx	MS44 or MS44L memory option	4.6
			CPU module	4.6
6	FPU	0110 xxxx	CPU module	4.7
7	IT	0111 xxxx	CPU module	4.8
8	SYS	1000 xxxx	CPU module	4.9
9	NI	1001 xxxx	CPU module	4.10
10	SCSI	1010 xxxx	RZ2* ² disk drive	4.11
			TZ30 tape drive	4.11
			TZK10 tape drive	4.11
			RX26 diskette drive	4.11
			RRD42 CDROM drive	4.11
			CPU module	4.11
12	COMM	1100 xxxx	DSW41 or DSW42 synchronous communications option	4.12
			CPU module	4.12
14	ASYN	1110 xxxx	DHW41 or DHW42 asyn-chronous communications option	4.13
			CPU module	4.13


¹ xxxx represents device-specific codes.

² This device can be RZ23L, RZ24, or RZ25.

4.2 No Display on the Console Terminal

Figure 4-1 shows the sequence of events that occurs when you turn on the system. Follow the procedure in Section 4.2.1 if the console terminal does not show any display.

Figure 4-1 Flowchart for Normal System Power-Up



4.2.1 Troubleshooting Procedure for No Display on the Console Terminal

Follow these steps to locate the failing FRU:

1. Ensure that the terminal is properly connected to the system unit. Make sure that the terminal is on. The LED indicator on the terminal turns on

when the terminal is turned on. Check the terminal setup. The correct setup values for the terminal are as follows:

- DEC423 operation
- Transmit = Receive = 9600 baud
- Eight bits
- One stop bit
- No parity

If you do not know how to change the terminal setup, see the terminal documentation. Turn the brightness control until the raster scan is shown on the terminal display. When the terminal does not display a raster scan, see the terminal troubleshooting documentation.

2. Turn off the system unit. Check the position of the break/enable switch on the back of the system unit. The switch must be set to the down position before you turn on the system if you want to use the terminal that is connected to MMJ port 0 as the console device. Ensure that the switch is in the up position before you turn on the system if you want to use the terminal connected to MMJ port 3 as the console device. Confirm that the terminal does not produce a display when it is connected to either port.

Note

The system reads the position of the break/enable switch only when you turn on the system.

3. Turn on the system unit. Check that the green LED on the front of the system unit is on and that you can hear the sound of the fans operating. If this does not occur, follow the procedure in Section 4.14.
4. Turn off the system unit and remove the following drive-mounting panels depending on the enclosure type:
 - For a system in a BA42-A enclosure, remove the drive mounting panel. See the *BA42-A Enclosure Maintenance* manual for more information.
 - For a system in a BA42-B enclosure, remove the upper and lower drive mounting panel combination. See the *BA42-B Enclosure Maintenance* manual for more information.
5. Remove the logic boards of the asynchronous communications options (DHW41 or DHW42) and the synchronous communications options (DSW41 or DSW42) from the CPU module (if connected).

6. Remove the MS44 or MS44L memory modules from the CPU module (if connected).
7. Turn on the system. If the terminal produces a display, one of the components that you disconnected is causing the problem. Install the components, one at a time in the order you removed them and test the system each time. If the terminal does not produce a display, the component that you installed last is the cause of the problem.
If the terminal does not produce a display, turn off the system unit, replace the CPU module, and go to step 8.
8. Turn on the system unit. When the terminal produces a display, reassemble the system unit.

4.3 NVR Test (Test 1)

The NVR test checks the nonvolatile RAM (NVR) and the time-of-year (TOY) clock on the CPU module. This test runs automatically, as part of the power-up test and initialization, when you turn on the system. This NVR test performs the following subtests:

- NVR subtest—This subtest checks the NVR for valid data. When the NVR is not initialized, this subtest checks all NVR locations and initializes the NVR. When the NVR is initialized, this test checks the temporary NVR locations only.
- TOY subtest—This subtest checks that the TOY clock contains a valid time entry. If not, this subtest checks all TOY registers by writing and reading values to the TOY registers.

If the test fails during a power-up test and initialization, put the system in the Digital Services environment (see *CPU Reference Information*, Section 1.11.3), and run the NVR test as an individual self-test. To run the NVR test as an individual self-test, enter one of the following commands at the console prompt:

```
>>> T 1  
>>> T NVR
```

If the NVR test fails, the LED display on the back of the system unit displays an error code in the range 10 to 11(hexadecimal) (see *CPU Reference Information*, Table 6-2), and the console terminal displays a hard error code as follows:

```
?? 001 1 NVR 0004
```

The error code, 0004(decimal) in this example, indicates a battery fault.

CPU Reference Information, Table 3-1 describes the error codes that the NVR test produces. If this test fails, you must replace the CPU module.

4.4 DZ Test (Test 3)

The DZ test checks the asynchronous MMJ ports 0,1, and 3 and the modem control port (2) on the CPU module. This test runs automatically, as part of the power-up test and initialization, when you turn on the system. This test performs the following subtests:

- **Reset subtest**—This subtest resets the DZ chip and sets the communication parameters of the serial lines to their default values. When the device does not reset or the communication parameters of the serial lines cannot be set correctly, this subtest generates an error.
- **Polled subtest**—This subtest configures the DZ chip in polled mode and checks each serial line in internal loopback mode.
- **Interrupt subtest**—This subtest configures the DZ chip in interrupt mode and checks each serial line in internal loopback mode. Interrupts are enabled and characters are transmitted on all serial lines excluding the serial line that the console device uses. The subtest compares the characters returned with the characters transmitted. It signals an error if the characters are not equal.

If the DZ test fails during the power-up test and initialization, put the system in the Digital Services environment (see *CPU Reference Information*, Section 1.11.3), and run the DZ test as an individual self-test.

Note

In the Digital Services environment, you must connect the H3103 loopback connectors to MMJ ports 0,1, and 3, excluding the port to which the console terminal connects. You must also connect a 29-24795-00 loopback connector to the asynchronous modem control port (2). The test fails if you do not install the loopback connectors.

To run the DZ test as an individual self-test, enter one of the following commands at the console prompt:

```
>>> T 3
```

```
>>> T DZ
```

If the DZ test fails, the LED display on the back of the system unit displays an error code in the range 30 to 34(hexadecimal) (see *CPU Reference Information*, Table 6-3), and the console terminal displays a hard error code as follows:

```
?? 001 3 DZ 0064
```

The error code, 0064(decimal) in this example, indicates that the polled test failed. *CPU Reference Information*, Table 3-2, describes the error codes that the DZ test produces. To get additional information about the error, enter the command:

```
>>> SHOW ERROR
```

CPU Reference Information, Section 3.2.1, gives the formats and describes the additional error information that the DZ test produces. The additional error information indicates which serial line is faulty.

To troubleshoot intermittent failures, you can run the system exerciser (see Section 3.5). *CPU Reference Information*, Section 5.1, gives the error messages that the system exerciser produces for this test. If this test fails repeatedly, you must replace the CPU module.

4.5 CACHE Test (Test 4)

The CACHE test checks the cache memory on the CPU module. This test runs automatically, as part of the power-up test and initialization, when you turn on the system. This test performs the following subtests:

- **Data store subtest**—This subtest checks the data store of the primary cache memory. The subtest includes read, compare, complement, and write operations in the forward and reverse direction. The subtest accesses the data store through the I/O address space.
- **Tag store subtest**—This subtest checks the tag store of the primary cache memory. The subtest includes read, compare, complement, and write operations in both the forward and reverse direction. The subtest accesses the tag store through the I/O address space.

If the CACHE test fails during the power-up test and initialization, put the system in the Digital Services environment (see *CPU Reference Information*, Section 1.11.3) and run the test as an individual self-test.

To run the CACHE test as an individual self-test, enter one of the following commands at the console prompt:

```
>>> T 4
```

```
>>> T CACHE
```

If the CACHE test fails, the LED display on the back of the system unit displays an error code in the range 41 to 4C(hexadecimal) (see *CPU Reference Information*, Table 6-4), and the console terminal displays a hard error code as follows:

```
?? 001 4 CACHE 0512
```

The error code, 0512(decimal) in this example, indicates that the test failed on a read/write operation to the data store. *CPU Reference Information*, Table 3-4, describes the error codes that the CACHE test produces. To get more information about the error, enter the command:

```
>>> SHOW ERROR
```

CPU Reference Information, Section 3.3.1, gives the formats and describes the additional error information that the CACHE test produces. If this test fails, you must replace the CPU module.

4.6 MEM Test (Test 5)

The MEM test checks the system memory, that is, the memory on the system module and the MS44 or MS44L memory options. This test runs automatically, as part of the power-up test and initialization, when you turn on the system. This test performs the following subtests:

- **Byte mask subtest**—This subtest checks the byte mask signals that the CPU generates. The subtest operates on each page boundary. When the subtest is complete, all free memory locations contain the number AA(hexadecimal).
- **Forward pass memory subtest**—This subtest includes read, compare, complement, and write operations to all memory locations in the forward direction.
- **Reverse pass memory subtest**—This subtest includes read, compare, complement, and write operations to all memory locations in the reverse direction.
- **Final parity subtest**—This subtest fills all the memory locations with the pattern 01h. The subtest then reads the contents of each location and checks that the parity bit is set. If the parity bit of any location is not set, the subtest generates an error. The unused memory locations are set to the pattern 01010101h.

If the MEM test fails during the power-up test and initialization, put the system in the Digital Services environment (see *CPU Reference Information*, Section 1.11.3), and run the MEM test as an individual self-test. To run the MEM test as an individual self-test, enter one of the following commands at the console prompt:

```
>>> T 5
```

```
>>> T MEM
```

If the MEM test fails, the LED display on the back of the system unit displays an error code in the range 50 to 54(hexadecimal) (see *CPU Reference Information*, Table 6-5), and the console terminal displays a hard error code as follows:

```
?? 001 5 MEM 0770
```

The error code, 0770(decimal) in this example, indicates that the test failed a comparison check while performing the reverse pass memory test. *CPU Reference Information*, Table 3-5, describes the error codes that the MEM test produces. To get more information about the error, enter the command:

```
>>> SHOW ERROR
```

CPU Reference Information, Section 3.4.1, gives the formats and describes the additional error information that the MEM test produces. The additional error information gives an FRU number that identifies which memory module is faulty.

4.7 FPU Test (Test 6)

The FPU test checks the floating-point unit (FPU) on the CPU module. This test runs automatically, as part of the power-up test and initialization, when you turn on the system. The FPU test performs instruction tests on the FPU. If an instruction produces unexpected results or an exception occurs during the execution of an instruction, this test generates an error. If the FPU test fails during the power-up test and initialization, put the system in the Digital Services environment (see *CPU Reference Information*, Section 1.11.3) and run the FPU test as an individual self-test.

To run the FPU test as an individual self-test, enter one of the following commands at the console prompt:

```
>>> T 6
```

```
>>> T FPU
```

If the FPU test fails, the LED display on the back of the system unit displays the error code 60(hexadecimal), and the console terminal displays a hard error code as follows:

```
?? 001 6 FPU 0258
```

The error code, 0258(decimal) in this example, indicates that the test failed during the MOVF instruction. *CPU Reference Information*, Table 3-7, describes the error codes that the FPU test produces. To get more information about the error, enter the command:

```
>>> SHOW ERROR
```

CPU Reference Information, Section 3.5.1, gives the format and description of the additional error information that the FPU test produces. If the FPU test fails, replace the CPU module.

4.8 IT Test (Test 7)

The IT test checks the interval timer (IT) on the CPU module. This test runs automatically, as part of the power-up test and initialization, when you turn on the system. The IT test enables interval timer interrupts. If there are too many or too few interrupts within a 30 millisecond (ms) interval, the test generates an error.

If the IT test fails during the power-up test and initialization, put the system in the Digital Services environment (see *CPU Reference Information*, Section 1.11.3) and run the IT test as an individual self-test. To run the IT test as an individual self-test, enter one of the following commands at the console prompt:

```
>>> T 7
```

```
>>> T IT
```

If the IT test fails, the LED display on the back of the system unit displays the error code 70(hexadecimal) and the console terminal displays a hard error code as follows:

```
?? 001 7 FPU 0002
```

The error code, 0002(decimal) in this example, indicates that the test failed because the IT is not interrupting at the correct rate. *CPU Reference Information*, Table 3-7, describes the error code that the IT test produces. Additional error information is not available for this test. If the IT test fails, replace the CPU module.

4.9 SYS Test (Test 8)

The SYS test checks the system ROMs and the invalidate filter RAM on the CPU module. This test runs automatically, as part of the power-up test and initialization, when you turn on the system. This test performs two subtests as follows:

- **System ROM subtest**—This subtest checks each byte of the system ROMs to ensure that they contain the correct Manufacturing check data and the correct checksum.
- **Filter RAM subtest**—This subtest performs two passes on the invalidate filter RAMs. The subtest detects address locations that cannot be changed and data faults.

If the SYS test fails during the power-up test and initialization, put the system in the Digital Services environment (see *CPU Reference Information*, Section 1.11.3) and run the SYS test as an individual self-test. To run the SYS test as an individual self-test, enter one of the following commands at the console prompt:

```
>>> T 8
```

```
>>> T SYS
```

If the SYS test fails, the LED display on the back of the system unit displays an error code in the range 80 to 82(hexadecimal) (see *CPU Reference Information*, Table 6-6), and the console terminal displays a hard error code as follows:

```
?? 001 8 SYS 0128
```

The error code, 0128(decimal) in this example, indicates that the test failed the invalidate filter RAM subtest. *CPU Reference Information*, Table 3-10, describes the error code that the SYS test produces. To get more information about the error, enter the command:

```
>>> SHOW ERROR
```

CPU Reference Information, Section 3.7.1, gives the format and describes the additional error information that the SYS test produces. If the SYS test fails, replace the CPU module.

4.10 NI Test (Test 9)

The NI test checks the network interconnection circuitry on the system module. This test runs automatically, as part of the power-up test and initialization, when you turn on the system. This test performs nine subtests as follows:

- **Network address ROM subtest**—This subtest checks the 32-byte network address ROM, which contains the unique 6-byte network address, a 2-byte checksum, and the test data type. The subtest checks for a null or multicast address, calculates and compares the checksums, and verifies the test data bytes.
- **LANCE register subtest**—This subtest checks the address and data paths to the LANCE register address port (RAP) and the register data port (RDP) for each of the four control status registers (CSRs).
- **LANCE initialization subtest**—This subtest sets up the LANCE data structures and initializes the LANCE chip, which causes the LANCE circuit to perform a single word DMA read operation on the system memory.
- **LANCE internal loopback subtest**—This subtest verifies the correct operation of the LANCE transmit and receive circuitry in internal loopback mode. The subtest also verifies burst-mode DMA read and DMA write operations on non-word-aligned data buffers for data packets of varying length and different data patterns.
- **LANCE interrupt subtest**—This subtest enables, forces, and services the LANCE interrupts for initialization, transmission, and reception in internal loopback mode.
- **LANCE CRC subtest**—This subtest checks the LANCE character recognition code (CRC) generation during data transmission. The subtest also performs incorrect CRC detection during data reception in internal loopback mode.
- **LANCE receive MISS/BUFF subtest**—This subtest checks the LANCE circuits for any missed data packets and buffer errors during a data reception in internal loopback mode.
- **LANCE collision subtest**—This subtest verifies a collision detection and retry activity during a data transmission in the internal loopback mode.
- **LANCE address filtering subtest**—This subtest checks the LANCE receiver address filtering for the broadcast, promiscuous, and null destinations in the internal loopback mode.

If the NI test fails during the power-up test and initialization, put the system in the Digital Services environment (see *CPU Reference Information*, Section 1.11.3) and run the NI test as an individual self-test.

Note

1. When the network select switch is set for a ThinWire Ethernet operation, the NI test generates an error if you do not connect the system to a ThinWire Ethernet network or install the ThinWire Ethernet T-connector and terminators.
 2. When the network select switch is set for a standard Ethernet operation, the NI test generates an error if you do not connect the system to a standard network or install the standard Ethernet loopback (12-22196-01).
-

To run the NI test as an individual self-test, enter one of the following commands at the console prompt:

```
>>> T 9  
>>> T NI
```

If the NI test fails, the LED display on the back of the system unit displays an error code in the range 90 to 9B(hexadecimal) (see *CPU Reference Information*, Table 6-7), and the console terminal displays a hard error code as follows:

```
?? 001 9 NI 0166
```

The error code, 0166(decimal) in this example, indicates that the test produced a packet comparison failure in the external loopback mode. *CPU Reference Information*, Table 3-11, describes the error codes that the NI test produces. To get more information about the error, enter the command:

```
>>> SHOW ERROR
```

CPU Reference Information, Section 3.8.1, gives the format and describes the additional error information that the NI test produces. If the NI test fails and the system is connected to a network, disconnect the system from the network, and connect either the ThinWire Ethernet terminators or the standard loopback connector depending on the type of network to which the system connects.

Run the NI test again. If the system passes the NI test, something in the network is causing the problem; contact the network co-ordinator. If the system fails the NI test, replace the CPU module.

To troubleshoot intermittent failures, you can run the system exerciser (see Section 3.5). The system exerciser runs this test when testing the interaction of components in the system. *CPU Reference Information*, Section 5.2, gives the error messages that the system exerciser produces for this test. If this test fails repeatedly, replace the CPU module.

4.11 SCSI Test (Test 10)

The SCSI test checks the SCSI controller on the CPU module and its interface with all the SCSI devices on the SCSI bus. This test runs automatically as part of the power-up test and initialization, when you turn on the system. The SCSI test performs three subtests as follows:

- **Register subtest**—This subtest verifies that the SCSI controller registers are fully operational.
- **Interrupt subtest**—This subtest checks the SCSI bits in the interrupt mask register, the interrupt request register, and the interrupt clear register. The subtest forces a SCSI interrupt when the SCSI bit in the interrupt mask is set to 1, then set to 0. The subtest repeats this operation for both high-priority interrupts and low-priority interrupts.
- **Data transfer subtest**—This subtest verifies the SCSI bus communication between the SCSI controller and SCSI devices on the SCSI bus. It also checks the data path between the SCSI controller, the system chip (S-chip), and memory. The subtest issues four inquiry commands to each SCSI device in four different modes as follows:
 - Programmed input/output mode
 - Asynchronous mode with DMA
 - Asynchronous mode with DMA, starting on a nonword-aligned boundary and crossing a page boundary
 - Synchronous mode with DMA

If the test fails during the power-up test and initialization, put the system in the Digital Services environment (see *CPU Reference Information*, Section 1.11.3), and run the SCSI test as an individual self-test.

To run the SCSI test as an individual self-test, enter one of the following commands at the console prompt:

```
>>> T 10
>>> T SCSI
```

If the SCSI test fails, the LED display on the back of the system unit displays an error code in the range A0 to A5(hexadecimal) (see *CPU Reference Information*, Table 6–8), and the console terminal displays a hard error code as follows:

```
?? 150 10 SCSI 0050
```

The error code, 0050(decimal) in this example, indicates that the SCSI minimal device test failed. *CPU Reference Information*, Table 3–12, describes the error codes that the SCSI test produces. To get more information about the error, enter the command:

```
>>> SHOW ERROR
```

CPU Reference Information, Section 3.9.1, gives the format and describes the additional error information that the SCSI test produces. If the SCSI test fails, the problem may be the CPU module or one of the SCSI devices connected to the SCSI bus.

Note

In the Digital Services environment, you must install test media in the removable media devices.

Enter the command **SHOW DEVICE** (see *CPU Reference Information*, Section 1.12.4) or **SHOW CONFIG** (see *CPU Reference Information*, Section 1.12.3) to check that the SCSI controller on the CPU module acknowledges all the SCSI devices on the SCSI bus. If the display does not show all the SCSI devices in the system, check the following:

- Each SCSI device has a unique SCSI ID. See Table 2–3 for the recommended SCSI ID numbers for devices.
- The internal power cable and the internal SCSI cable are correctly connected to each internal SCSI device.
- The power cable and the SCSI cable are correctly connected to each external SCSI device.

When you are sure that all the SCSI devices have unique SCSI IDs and that the cables are connected correctly, run the SCSI test again. When the SCSI controller acknowledges all the SCSI devices on the SCSI bus, but the fault persists, disconnect any external SCSI devices from the system unit, and connect the SCSI terminator to the SCSI port.

Run the SCSI test again. When the test passes, the fault is in one of the external devices connected to the system unit or the last SCSI device on the SCSI bus is not terminated correctly.

Run the SCSI test. If the test fails, replace the CPU module. When the test passes, reconnect the internal SCSI cable to the CPU module.

Run the SCSI test again. If the test passes, the internal SCSI cable or the connection to the CPU module is faulty. If the test fails, enter the command **SHOW ERROR** (see *CPU Reference Information*, Section 1.12.6) to get more information about the SCSI error. *CPU Reference Information*, Section 3.9.1, gives the format and description of the additional error information that the SCSI test produces. The additional error information gives you the SCSI ID of the failing SCSI device. The SCSI ID also indicates the type of failing SCSI device. Table 4-2 lists the subsections in this chapter that describe the troubleshooting procedures for each type of SCSI device.

Table 4-2 SCSI Device Troubleshooting Procedures

SCSI Device Type	Section
RRD42 CDROM drive	4.11.1
RX26 diskette drive	4.11.2
RZ23L, RZ24, RZ25 disk drives	4.11.3
TZ30 tape drive	4.11.4
TZK10 tape drive	4.11.5
External SCSI devices	4.11.6

To perform a more comprehensive test on the SCSI devices, put the system in the Digital Services environment (see Section 3.3.2.2) and enter the following command:

```
>>> T 106
```

The system prompts you for the devices you want to test (see Section 3.5.1). Select the SCSI device that you want to test. If the test is successful, the display shows the following:

```
10 SCSI #
```

If the test is not successful, the display shows the following:

```
?? 10 SCSI 150 0160 8:18:41
```

The error code, 0160(decimal) in this example, indicates a device test failure. *CPU Reference Information*, Table 5-4, describes the error codes that the system exerciser produces for the SCSI test.

The system exerciser generates a summary screen. When the test completes, press Return to display the summary screen. Section 3.5.2 gives examples of the summary screens that the system exerciser generates. The system exerciser summary screen shows which SCSI device is faulty. Replace the faulty SCSI device.

4.11.1 Troubleshooting an RRD42 CDROM Drive

The RRD42 CDROM drive is a single FRU. When the SCSI test (test 10) isolates the fault to an RRD42 CDROM drive, you must replace the RRD42 CDROM drive (RRD42-AA). See the *BA42-A Enclosure Maintenance* or the *BA42-B Enclosure Maintenance* manual for information about removing and replacing FRUs.

4.11.2 Troubleshooting an RX26 Diskette Drive

When the SCSI test (test 10) isolates the fault to an RX26 diskette drive, you must identify the faulty FRU. The RX26 diskette drive contains three FRUs:

1. SCSI/FDI board (54-20764-02)
2. RX26 diskette drive unit (RX26-AA)
3. RX26 ribbon cable (17-00285-00)

To identify the faulty FRU, replace each FRU in turn, in the order shown previously, and run the SCSI test (test 10) again until the test passes. See the *BA42-A Enclosure Maintenance* or the *BA42-B Enclosure Maintenance* manual for information about removing and replacing FRUs. The last FRU that you replace is the faulty FRU.

4.11.3 Troubleshooting an RZ23L, an RZ24, or an RZ25 Disk Drive

The RZ23L, RZ24, and RZ25 disk drives are single FRUs. When the SCSI test (test 10) isolates the fault to an RZ23L, an RZ24, or an RZ25 disk drive, you must replace the disk drive. See the *BA42-A Enclosure Maintenance* or the *BA42-B Enclosure Maintenance* manual for information about removing and replacing FRUs.

4.11.4 Troubleshooting a TZ30 Tape Drive

When the SCSI test (test 10) isolates the fault to a TZ30 tape drive, you must identify the faulty FRU. The TZ30 tape drive contains two FRUs:

- Take-up leader (74-34273-01)
- TZ30 tape drive unit (TZ30-AX)

To identify the faulty FRU, inspect the take-up leader for damage. If necessary, replace the take-up leader according to the instructions in the *TZ30 Cartridge Tape Drive Service* manual (EK-OTZ30-SV). If the take-up leader is not damaged or incorrectly aligned, replace the TZ30 tape drive. See the *BA42-A Enclosure Maintenance* or the *BA42-B Enclosure Maintenance* manual for information about removing and replacing the FRUs.

4.11.5 Troubleshooting a TZK10 Tape Drive

The TZK10 tape drive is a single FRU. When the SCSI test (test 10) isolates the fault to a TZK10 tape drive, you must replace the TZK10 tape drive (TZK10-AA). See the *BA42-A Enclosure Maintenance* or the *BA42-B Enclosure Maintenance* manual for information about removing and replacing the FRUs.

4.11.6 Troubleshooting an External SCSI Device

When the SCSI test (test 10) isolates the fault to an external SCSI device, replace the external SCSI device according to the maintenance information for that device.

4.12 COMM Test (Test 12)

The COMM test checks the operation of the synchronous communications option (DSW41 or DSW42) in the system. This test runs automatically, as part of the power-up test and initialization, when you turn on the system. This test performs eight subtests as follows:

- Subtest 1—This subtest verifies the checksum of the 128K-byte read-only memory (ROM).
- Subtest 2—This subtest checks the 256K-byte static RAM. The operations performed include write, verify, complement, verify.
- Subtest 3—This subtest performs a self-test on the MC68302 processor.
- Subtest 4—This subtest checks the RAM dual access.
- Subtest 5—This subtest checks the electrically programmable read-only memory (EPROM) dual access.

- **Subtest 6**—This subtest checks that the synchronous communications option can interrupt the system CPU.
- **Subtest 7**—This subtest checks the host buffer loopback and interrupt. The test transfers data from the CPU to the synchronous communications option, returns it, and waits for an interrupt.
- **Subtest 8**—This subtest resets the synchronous communications option and waits for an interrupt.

If the COMM test fails during the power-up test and initialization, follow these steps:

1. Disconnect all the external cables from the synchronous communications ports on the back of the system unit.
2. Put the system in the Digital Services environment (see *CPU Reference Information*, Section 1.11.3).
3. Run the COMM test as an individual self-test.

Note

In the Digital Services environment, you must connect one H3199 loopback (DSW41) or two H3199 loopback connectors (DSW42) to the synchronous communications ports on the back of the system unit. The test fails on ports that do not have loopback connectors fitted.

To run the COMM test as an individual self-test, enter one of the following commands at the console prompt:

```
>>> T 12
```

```
>>> T COMM
```

If the COMM test fails, the LED display on the back of the system unit displays an error code in the range C0 to C8(hexadecimal) (see *CPU Reference Information*, Table 6-9), and the console terminal displays a hard error code as follows:

```
?? 020 12 COMM 0274
```

The error code, 0274(decimal) in this example, indicates that the synchronous communications option diagnostic test did not complete. *CPU Reference Information*, Table 3-15 describes the error codes that the COMM test produces. To get more information about the error, enter the command:

```
>>> SHOW ERROR
```

CPU Reference Information, Section 3.10.2, gives the format and describes the additional error information that the COMM test produces. The system exerciser runs this test when testing the interaction of components in the system. *CPU Reference Information*, Section 5.4, gives the error messages that the system exerciser produces for this test. See Section 4.12.1 to identify the faulty FRU.

4.12.1 Troubleshooting a DSW41 or a DSW42 Synchronous Communications Option


The DSW41 and DSW42 synchronous communications options contain the following FRUs:

1. Input/output module
2. Logic board
3. Ribbon cable
4. External cables

To identify the faulty FRU, run the COMM test (test 12) repeatedly as an individual self-test, replacing the FRUs one at a time in the order shown previously, until you find the faulty FRU.

To check the external cables, you can connect cable loopback connectors and run the test again. The external cable loopback connectors that you must connect depend on the communications interface you are using. Figure 4-2 shows the loopback connectors for the different communications interfaces that the DSW41 and DSW42 synchronous communications options support.

Figure 4-2 Cable Loopback Connectors for the DSW41 and DSW42 Options



Note: For Model 40 systems, you must also connect loopback connectors to synchronous communications port 1.

4.13 ASYNC Test (Test 14)

The ASYNC test checks the operation of the asynchronous communications option (DHW41 or DHW42) in the system. This test runs automatically, as part of the power-up test and initialization, when you turn on the system. If the ASYNC test fails during the power-up test and initialization, follow these steps:

1. Disconnect all the external cables from the asynchronous communications ports, which the option provides on the back of the system unit.
2. Put the system in the Digital Services environment (see *CPU Reference Information*, Section 1.11.3).
3. Run the ASYNC test as an individual self-test.

Note

In the Digital Services environment, you must connect loopback connectors to the asynchronous ports on the back of the system unit as follows:

- If a system has one eight-channel data only port, connect a H3101 loopback connector.
 - If a system has two eight-channel data only ports, connect two H3101 loopback connectors.
 - If a system has one four-channel modem control port, connect a H4081-A loopback connector.
 - If a system has two four-channel modem control ports, connect two H4081-A loopback connectors.
-

To run the ASYNC test as an individual self-test, enter one of the following commands at the console prompt:

```
>>> T 14
```

```
>>> T ASYNC
```

If the ASYNC test fails, the LED display on the back of the system unit displays an error code in the range E0 to EE(hexadecimal) (see *CPU Reference Information*, Table 6-10), and the console terminal displays a hard error code as follows:

```
?? 021 14 ASYNC 1280
```

The error code, 1280(decimal) in this example, indicates that the asynchronous communications option failed the receiver interrupt test. *CPU Reference Information*, Table 3-17, describes the error codes that the ASYNC test produces. To get more information about the error, enter the command:

```
>>> SHOW ERROR
```

CPU Reference Information, Section 3.11.1, gives the formats and describes the additional error information that the ASYNC test produces. If the ASYNC test fails, enter the SHOW ERROR command to get more information about the error. The additional error information indicates which asynchronous communications channel is faulty. See Section 4.13.1 to identify the faulty FRU.

The system exerciser (see Section 3.5) runs this test when testing the interaction of components in the system. *CPU Reference Information*, Section 5.5, gives the error messages that the system exerciser produces for this test.

4.13.1 Troubleshooting a DHW41 or a DHW42 Asynchronous Communications Option


The DHW41 and DHW42 asynchronous communications options contain the following FRUs:

1. Input/output module
2. Logic board
3. Ribbon cable
4. External cables
5. Harmonicas (DHW41-AA, DHW42-AA, DHW42-BA)

To isolate the fault to an FRU, run the ASYNC test (test 14) repeatedly as an individual self-test, replacing the FRUs, one at a time in the order shown previously, until you find the faulty FRU.

To check the external cables, you can connect cable loopback connectors and run the test again. The external cable loopback connectors that you must connect depend on the communication type (data only or modem control) that you are using. Figure 4-3 shows the loopback connectors for the different communication types that the DHW41 and DHW42 asynchronous communications options support. Use Digital Services procedures to troubleshoot the operation of the harmonicas or the 4-way modem cables.

Figure 4-3 Cable Loopback Connectors for the DHW41 and DHW42 Options



Note: For Model 40 systems, you must also connect external cables and loopback connectors to asynchronous communications port B.

4.14 Troubleshooting Procedures for the Power Supply

Figure 4-4 is a flowchart for troubleshooting the power supply in a KA45 system.

Figure 4-4 Flowchart for Troubleshooting the Power Supply





Figure 4-5 shows the voltages on the pins of the power connector (see Figure 1-3), which is next to the ThinWire Ethernet connector on the KA45 CPU module.


Figure 4-5 KA45 CPU Module Power Connector Pin Voltages



Note: The -9.0 V dc supply is an isolated supply.

Figure 4-6 shows the voltages on the pins of the connectors on the power cables that provide power to the internal mass storage devices. See the *BA42-A Enclosure Maintenance* manual or the *BA42-B Enclosure Maintenance* manual for more information on power distribution.

Figure 4-6 Drive Power Connector Pin Voltages




Troubleshooting Flowchart

This appendix shows a flowchart of the procedure used to troubleshoot KA45 systems.


Troubleshooting Flowchart

Figure A-1 Troubleshooting Flowchart (Page 1 of 4)



¹ This assumes that the console terminal is connected to MMJ port 0.

Figure A-2 Troubleshooting Flowchart (Page 2 of 4)



Troubleshooting Flowchart

Figure A-3 Troubleshooting Flowchart (Page 3 of 4)





Figure A-4 Troubleshooting Flowchart (Page 4 of 4)



¹ For data only ports use H3101.
For modem control ports use H4081-A.

[illegible]

B

Memory Map

Table B-1 is a memory map for MicroVAX 3100 systems that have a KA45 CPU module (Model 30 and Model 40 systems).

Table B-1 Memory Map

Memory (M Bytes)	Address Range	Memory Component
4	00000000 to 003FFFFFFF	System module
8	00400000 to 007FFFFFFF	System module
12	00800000 to 00BFFFFFFF	1st ¹
16	00C00000 to 00FFFFFFF	1st
20	01000000 to 013FFFFFFF	2nd ²
24	01400000 to 017FFFFFFF	2nd
28	01800000 to 01BFFFFFFF	3rd ³
32	01C00000 to 01FFFFFFF	3rd


¹1st indicates the first memory increment (connectors 1H and 1L; see Figure B-1).

²2nd indicates the second memory increment (connectors 2H and 2L; see Figure B-1).

³3rd indicates the third memory increment (connectors 3H and 3L; see Figure B-1).

Memory Map


Figure B-1 Memory Connectors



RE_EN06198A_91

Note

A failing address ending in 0 or 8 indicates that the memory module in connector 1H, 2H, or 3H is faulty. A failing address ending in 4 or C indicates that the memory module in connector 1L, 2L, or 3L is faulty.

A large, dark, stylized letter 'C' logo, resembling a thick, textured ring or a stylized 'C' shape, positioned on the left side of the page.

A black and white photograph of a document page. On the left side, there is a large, dark, irregular shape, possibly a shadow or a piece of tape. The page itself contains a series of horizontal lines of varying lengths, arranged in a grid-like pattern. These lines are composed of small, dark, rectangular segments, resembling a barcode or a series of dashes. The lines are arranged in a way that they appear to be part of a larger, structured layout, possibly a table or a list. The overall image is somewhat blurry and has a high-contrast, grainy appearance.

FRU Numbers

This appendix gives the FRU numbers of devices in MicroVAX 3100 platform systems.

C.1 FRU Number Assignments

Table C-1 lists the FRU numbers of devices in MicroVAX 3100 platform systems.

Table C-1 FRU Numbers

FRU Number (Decimal)	Definition
001	CPU module
020	Synchronous communications module DSW41 or DSW42
021	Asynchronous communications module DHW41 or DHW42
040	Memory module in connector 1L
041	Memory module in connector 1H
042	Memory module in connector 2L
043	Memory module in connector 2H
044	Memory module in connector 3L
045	Memory module in connector 3H
100-199	SCSI devices (see Section C.1.1)

FRU Numbers


C.1.1 FRU Numbers of SCSI Devices

The FRU numbers of SCSI devices have the following format:

$x_1 x_2 x_3$

where:

- x_1 is the SCSI controller number. This number is always 1 because there is only one SCSI controller in the system.
- x_2 is a number in the range 0 to 7. This number is the SCSI ID number of the SCSI device.
- x_3 is a number in the range 0 to 8. This number is the logical unit number.




D

KA45 CPU Module Jumper Wires

This appendix describes the functions of the jumper wires on the KA45 CPU module. Figure D-1 identifies the location of each jumper wire and describes the function of each jumper wire on the KA45 CPU module.

KA45 CPU Module Jumper Wires

Figure D-1 KA45 CPU Module Jumper Wires



Glossary

The glossary defines some of the technical terms used in this manual.

ASCII

American standard code for information interchange.

CMOS

Complementary metal oxide semiconductor.

CPU

Central processing unit. The main unit of a computer containing the circuits that control the interpretation and execution of instructions. The CPU holds the main storage, arithmetic unit, and special registers.

CRC

Character code recognition. The use of pattern recognition techniques to identify characters by automatic means.

CSR

Control status register. A register used to control the operation of a device and record the status of an operation or both.

DMA

Direct memory access. A method of accessing a device's memory without interacting with the device's CPU.

EPROM

Erasable programmable read-only memory. EPROM is a type of read-only memory that can be erased and so returns the device to a blank state.

FPU

Floating-point unit. A unit that handles the automatic positioning of the decimal point during arithmetic operations.

FRU

Field-replaceable unit.

IT

Interval timer.

LED

Light emitting diode.

MMJ

Modified modular jack.

NVR

Nonvolatile random access memory. A memory device that retains information in the absence of power.

RAM

Random access memory. A read/write memory device.

RAP

Register address port.

RDP

Register data port.

ROM

Read-only memory. A memory device that cannot be altered during the normal use of the computer.

S-chip

System chip. A single integrated circuit containing most of the system's functionality.

SCSI

Small computer system interface. An interface designed for connecting disks and other peripheral devices to computer systems. SCSI is defined by an American National Standards Institute (ANSI) standard.

SOC

System-on-a-chip. An integrated circuit design architecture.

TOY

Time of year.

VMB

Virtual machine bootstrap. The VMB program loads and runs the operating system.

VMS

Virtual memory system. The operating system for a VAX computer.

Index

A

- ASync test, 4-23
- Asynchronous communications device
 - interfaces support for, 2-5
 - troubleshooting, 4-24
- Asynchronous communications devices
 - testing, 4-23
- Asynchronous communications options
 - list of, 2-5

B

- Block diagram, 1-3
- Break/Enable switch
 - function of, 3-5

C

- Cache memory test, 4-8
- CACHE test, 4-8
- Clearing the password, 3-8
- COMM test, 4-19
- Communications option types, 2-4
- Configuration
 - memory, 1-8
- Connectors
 - function of, 1-7
 - identification of, 1-5
- Console commands
 - overview of, 3-6
- Console devices
 - communication parameters, 3-6
 - function of, 3-4

Console devices (cont'd)

- types of, 3-5
- Console mode, 3-6
 - privileged, 3-7
 - unprivileged, 3-7
- Console port, 3-4
- Console program
 - function of, 3-4
- Console security, 3-7
- Controls
 - function of, 1-7
 - identification of, 1-5
- Customer environment, 3-15

D

- Device mnemonics
 - list of, 3-11
- Device names
 - list of, 3-11
- Device numbers
 - list of, 3-11
- DHW41
 - troubleshooting, 4-24
- Diagnostic test environment
 - setting, 3-15
- Diagnostic tests, 3-11
- Digital Services test environment, 3-15
 - loopback requirement, 3-15
- DSW41
 - troubleshooting, 4-21
- DSW42
 - troubleshooting, 4-21, 4-24
- DZ serial line controller test, 4-7

DZ test, 4-7

E

Environment

testing, 3-15

Error information, 3-14, 3-29

Ethernet circuit test, 4-13

Extended self-test, 3-16

External mass storage devices, 2-2

list of, 2-3

F

Firmware overview, 3-1

Floating-point unit test, 4-10

FPU test, 4-10

FRUs

numbers for, C-1

H

Halt state, 3-4

I

Indicators

function of, 1-7

identification of, 1-5

Initialization, 3-1

Internal mass storage devices

list of, 2-1

Interval timer

See IT, 4-11

IT test, 4-11

K

KA45 CPU module

block diagram of, 1-3

features of, 1-1

KA45 system

communications options, 2-4

configurations of, 2-1

mass storage device configurations, 2-1

memory configurations, 2-1

M

Manufacturing test environment, 3-16

loopback requirement, 3-16

Mass storage devices, 2-1

external, 2-2

internal, 2-1

SCSI ID assignments, 2-4

MEM test, 4-9

Memory

configurations, 1-10

expansion connector identification, 1-8

expansion of, 1-8

map, B-1

rules for adding, 1-8

Memory configuration

KA45 system, 2-1

Memory modules, 1-8

Memory option

installation of, 1-10

Memory test, 4-9

Miscellaneous system test, 4-12

Modem communications, 4-7, 4-23

Modes

for diagnostic tests, 3-15

MS44 memory modules, 1-8

MS44L memory modules, 1-8

N

NI test, 4-13

Nonvolatile RAM

See NVR, 4-6

NVR

clearing the password, 3-8

NVR test, 4-6

O

Onboard memory

location of, 1-8

P

Password

- clearing, 3-8

Ports

- function of, 1-7
- identification of, 1-5

Power supply

- troubleshooting, 4-25

Power-up test, 3-1

- display format, 3-1
- error format, 3-3

Privileged console mode, 3-7

R

RRD42

- troubleshooting, 4-18

RX26

- troubleshooting, 4-18

RZ23L

- troubleshooting, 4-18

RZ24

- troubleshooting, 4-18

RZ25

- troubleshooting, 4-18

S

SCSI ID assignments

- recommendations for, 2-4

SCSI test, 4-15

Security, 3-7

Self-test

- display format, 3-13
- error format, 3-13
- overview of, 3-11

Serial line controller test, 4-7

Status bar

- complete, 3-1

Synchronous communications device testing, 4-19

Synchronous communications devices - troubleshooting, 4-21

Synchronous communications options - list of, 2-5

Synchronous communications standards - support for, 2-5

SYS test, 4-12

System exerciser

- display format, 3-21
- error format, 3-22
- overview of, 3-19
- predefined tests, 3-19
- TEST command format, 3-19
- test results, 3-24

System initialization, 3-1

System test kernel

- function of, 3-19

System test monitor

- function of, 3-19

T

TEST command

- rules, 3-12
- variations of, 3-11

Test command dispatcher

- function of, 3-11

TEST command lines

- typical examples, 3-11

Test environments

- customer environment, 3-15
- Digital Services environment, 3-15
- list of, 3-15

Test results

- for system exerciser, 3-24

Troubleshooting

- asynchronous communications devices, 4-24
 - DHW41, 4-24
 - DHW42, 4-24
 - DSW41, 4-21
 - DSW42, 4-21
- external SCSI devices, 4-19
- flowchart, A-1
- general procedures, 4-1
- no screen display, 4-3
- RRD42, 4-18

Troubleshooting (cont'd)

RX26, 4-18

RZ23L, 4-18

RZ24, 4-18

RZ25, 4-18

synchronous communications devices,
4-21

TZ30, 4-19

TZK10, 4-19

TZ30

troubleshooting, 4-19

TZK10

troubleshooting, 4-19

U

Unprivileged console mode, 3-7

Utilities

error format, 3-16

overview of, 3-16

TEST command format, 3-16

V

VAX data types

support of, 1-5

VAX instructions

support of, 1-5