



# Hardware Installation Guide for the QLA2200/2200F/2202F

Fibre Channel Host Adapter Boards  
for the PCI Bus

*FC0151103-00 B*  
*October 1, 1999*

Information furnished in this manual is believed to be accurate and reliable. However, QLogic Corporation assumes no responsibility for its use, nor for any infringements of patents or other rights of third parties which may result from its use. QLogic Corporation reserves the right to change product specifications at any time without notice. Applications described in this document for any of these products are for illustrative purposes only. QLogic Corporation makes no representation nor warranty that such applications are suitable for the specified use without further testing or modification. QLogic Corporation assumes no responsibility for any errors that may appear in this document.

No part of this document may be copied nor reproduced by any means, nor translated nor transmitted to any magnetic medium without the express written consent of QLogic Corporation.

QLogic is a trademark of QLogic Corporation.

Seagate is a trademark of Seagate Technology, Inc.

Microsoft is a trademark of Microsoft Corporation.

All other brand and product names are trademarks or registered trademarks of their respective holders.

Document Revision History

Rev. A initial release, 4/16/99
Rev. B update, 10/4/99, extended firmware settings added to <i>Fast/UTIL</i>
Boards Affected
QLA2200 family QLA2200F family QLA2202F family

Copyright 1999 QLogic Corporation  
First Printed: April 1999  
All Rights Reserved Worldwide  
Printed in U.S.A

# Table of Contents

## Section 1 Introduction

1.1	General Description .....	1-1
1.2	What is Fibre Channel?.....	1-1
1.3	Features.....	1-2
1.3.1	Mixed Peripheral Support .....	1-2

## Section 2 Hardware Installation

2.1	Preinstallation Procedures.....	2-1
2.2	What You Need for Installation .....	2-1
2.3	Power Supply .....	2-3
2.4	Installation in the Computer .....	2-3
2.5	Installation Help .....	2-5

## Section 3 Troubleshooting

3.1	Problems After Installation.....	3-1
3.2	Hardware Problem Checklist .....	3-1
3.3	System Configuration Problem Checklist.....	3-2
3.4	Fibre Channel Problem Checklist.....	3-2

## Appendix A *Fast!UTIL*

A.1	Introduction .....	A-1
A.2	Configuration Settings .....	A-1
A.2.1	Host Adapter Settings .....	A-1
A.2.2	Selectable Boot Settings .....	A-2
A.2.3	Restore Default Settings .....	A-2
A.2.4	Raw NVRAM Data .....	A-3
A.2.5	Advanced Adapter Settings .....	A-3
A.2.6	Extended Firmware Settings .....	A-5
A.3	Scan Fibre Channel Devices .....	A-7
A.4	Fibre Disk Utility .....	A-7
A.5	Select Host Adapter .....	A-7

Appendix B    Specifications

FIGURES

Figure		Page
2-1	QLA2200 Board Layout. . . . .	2-2
2-2	QLA2200F Board Layout. . . . .	2-2
2-3	QLA2202F Board Layout. . . . .	2-3

TABLES

Table		Page
A-1	Host Adapter Settings. . . . .	A-1
A-2	Advanced Adapter Settings . . . . .	A-3
A-3	Extended Firmware Settings. . . . .	A-5
A-4	RIO Operation Modes . . . . .	A-6
A-5	Connection Options . . . . .	A-6
B-1	QLA2xxx Board Operating Environment . . . . .	B-1
B-2	QLA2xxx Board Specifications . . . . .	B-1

# *Section 1*

## Introduction

**NOTE:** The following QLogic host adapter boards are collectively referred to as the *QLA2xxx board* unless otherwise noted:

QLA2200 family (64-bit PCI to Fibre Channel copper media)

QLA2200F family (64-bit PCI to Fibre Channel optical media)

QLA2202F family (64-bit PCI to dual channel optical media)

### *1.1*

#### **General Description**

Thank you for selecting the QLA2xxx Fibre Channel (FC) board. The QLA2xxx board is an intelligent, high-performance, DMA bus master host adapter designed for high-end systems. The intelligence and performance are derived from the ISP2xxx chips, making the QLA2xxx board a leading-edge host adapter. The ISP2xxx combines a powerful RISC processor, a fibre protocol module (FPM) with gigabit transceivers, and a peripheral component interconnect (PCI) local bus interface in a single-chip solution. The QLA2xxx board supports all FC peripherals that support private loop direct attach (PLDA) and fabric loop attach (FLA). Installation of the QLA2xxx board is quick and easy.

### *1.2*

#### **What is Fibre Channel?**

Fibre channel technology is outlined in the *SCSI-3 Fibre Channel Protocol* (SCSI-FCP) standard. Fibre Channel is a high-speed data transport technology used for mass storage and networking. It connects mainframes, super computers, workstations, storage devices, and servers. Using a Fibre Channel arbitrated loop (FC-AL), 126 devices can be supported, compared to 15 devices with Ultra SCSI.

Fibre Channel supports data transfer rates of 100 Mbytes/sec on copper and optical interfaces, which is more than twice that of Ultra SCSI (40 Mbytes/sec). A copper interface is used for short connections (less than 30 meters); a multimode optical interface is used for intermediate distances (less than 500 meters).

With increased connectivity and performance, Fibre Channel is the technology preferred and used by system designers.

### 1.3

## Features

- ❑ Compliance with PCI version 2.2 specification
- ❑ Compliance with *Third Generation Fibre Channel Physical and Signaling Interface* (FC-PH-3) standard
- ❑ Compliance with *Fibre Channel-Arbitrated Loop* (FC-AL-2) standard
- ❑ Compliance with U.S. and international safety and emissions standards
- ❑ Support for bus master DMA
- ❑ *Fast!*UTIL BIOS utility to customize the configuration parameters on the QLA2xxx board and attached drives
- ❑ Two independent channels on a single board. Channel one has an external optical connector and an internal copper connector. Each individual connector (or both connectors) can be used without manual configuration (QLA2202F board).
- ❑ Supports Fibre Channel SCSI (FCP-SCSI) and internet protocol (IP) protocols
- ❑ Supports point-to-point fabric connection (F-PORT FABRIC LOGIN)
- ❑ Supports Fibre Channel service (Classes 2 and 3)

### 1.3.1

## Mixed Peripheral Support

Simultaneous mixed-peripheral configurations and bootable device support for FC devices that meet the following standards:

- ❑ *Fibre Channel – Private Loop Direct Attach Technical Report* (FC-PLDA)
- ❑ *Fibre Channel – Fabric Loop Attachment Technical Report* (FC-FLA)

## Section 2

# Hardware Installation

### 2.1

#### Preinstallation Procedures

Before installing your QLA2xxx board, take a moment to read this guide.

**CAUTION!** The QLA2xxx board contains parts that can be damaged by electrostatic discharge (ESD). Before handling the QLA2xxx board, use standard methods to discharge static electricity. Keep the QLA2xxx board in the antistatic bag until you are ready to install it. Place the board on the bag when you examine or configure it. Retain the bag for future use.

### 2.2


#### What You Need for Installation

Before you install the QLA2xxx board in your computer, you need the following:


- ☐ A screwdriver (usually a Phillips #1)
- ☐ A high-speed, serial data connector (HSSDC) cable for the QLA2200 board
- ☐ An optical, multimode cable with an SC-style duplex connector for the QLA2200F/2202F boards
- ☐ Two three-position point-to-point, internal fibre channel cables for the QLA2202F board, if you are using an internal connector

Figures 2-1 through 2-3 identify the QLA2xxx board components referenced throughout this section.


Each QLA2xxx board has a unique serial number; its location on the board is noted in figures 2-1 through 2-3. Take a minute to write down the serial number of the QLA2xxx board in the unlikely event that the NVRAM is corrupted. If the NVRAM is corrupted, you will be prompted for the QLA2xxx serial number.



**Figure 2-1. QLA2200 Board Layout**



**Figure 2-2. QLA2200F Board Layout**



**Figure 2-3. QLA2202F Board Layout**

## 2.3

### Power Supply

The QLA2200 board supplies +5 volts to pin 7 of the **HSSDC** copper interface to support an external media interface adapter (MIA), if required. (An MIA converts optical bus signals to copper bus signals.)

## 2.4

### Installation in the Computer

Perform the following steps to install the QLA2xxx board in your PC:

1. Check the motherboard and make any configuration changes necessary to accommodate the QLA2xxx board.

The QLA2xxx board is self-configuring; however, some motherboards require manual configuration. For example, some systems have a *PCI Device Configuration* menu in the motherboard setup BIOS where you must enable host adapter boards, bus master slots, and interrupt request (IRQ) levels. If the motherboard supports triggering, use *level triggering* for the QLA2xxx board. See the documentation supplied with your

computer, or contact your computer dealer to determine if your motherboard requires configuration.

2. Power down the peripherals, then the computer.
3. Remove the computer cover and save the screws.
4. Choose any PCI bus slot that supports bus mastering. Most motherboards automatically assign an IRQ level and interrupt line; if your motherboard does not, you must assign the IRQ level and use **interrupt line A** for this slot.

**NOTE:**

- ❑ Some motherboards have two kinds of PCI bus slots: master and slave. The QLA2xxx board must be in a PCI bus master slot. (Some motherboards have PCI bus master slots that are shared with onboard devices. QLA2xxx boards do not work in shared slots.)
  - ❑ PCI connectors vary among system board manufacturers. The QLA2xxx board is a 64-bit PCI device that can function in a 32-bit PCI slot that conforms to the PCI specification (the rear edge of the PCI slot is notched). If you try to install the QLA2xxx board into a PCI slot that does not conform to the PCI specification, you may damage the QLA2xxx board.
5. Unscrew and remove the slot cover. Retain the screw; you will use it when you install the QLA2xxx board.
  6. Place the QLA2xxx board into the slot. Carefully press the board into the slot until it seats firmly.

**NOTE:** QLA2xxx boards are designed with the components on the opposite side compared with non-PCI boards.

7. Secure the QLA2xxx board with the slot cover screw.
8. Connect the appropriate cable from the devices to the J1 connector.

**NOTE:** For the QLA2202F board, the J1 and J2 connectors are external, and the J3 and J4 connectors are internal.

9. Carefully reinstall the computer cover. Insert and tighten the computer cover screws.

10. Power up all external FC devices, then power up the PC and observe the monitor. The BIOS is disabled by default. Consequently, the devices attached to the QLA2xxx board are not identified. For example:

```
QLogic Corporation
QLA2xxx PCI Fibre Channel ROM BIOS Version X.XX
Copyright (C) QLogic Corporation 1998 All rights reserved.
www.qlogic.com
```

```
Press <Alt-Q> for Fast!UTIL
```

```
BIOS for Adapter 0 is disabled
ROM BIOS not installed
```

**NOTE:** For further information about enabling the QLA2xxx BIOS, see appendix A.

If the information displayed on your monitor is correct, congratulations! You have successfully installed the QLA2xxx board in your computer.

See the appropriate QLogic software installation guide for detailed instructions on how to install the software drivers.

If the information displayed is not correct and you have checked the QLA2xxx board's configuration, see section 3 for troubleshooting information.

## 2.5

### Installation Help

If your system has an integrated drive electronics (IDE) fixed disk device, it is assigned device number 80 and is the boot device. If your system does not have an IDE disk device, the first bootable FC disk device configured (the one with the lowest ID) is assigned device number 80 and is the boot device. The QLA2xxx BIOS must be enabled if the boot device is connected to the QLA2xxx.

If you do not have an IDE disk device, set the motherboard BIOS parameters to None or Not Installed. The ROM BIOS on the FC controller automatically configures the FC peripherals.



## *Section 3*

# Troubleshooting

### 3.1

#### **Problems After Installation**

There are three basic types of installation problems that can cause your QLA2xxx board to function incorrectly: hardware problems, system configuration problems, and Fibre Channel problems. The following section provides itemized checklists to help you determine why your QLA2xxx board is not functioning.

### 3.2

#### **Hardware Problem Checklist**

- ☐ Are all of the circuit cards installed securely in the PC?
- ☐ Are all of the cables securely connected to the correct connectors? Be sure that the FC connectors that attach from the QLA2xxx connectors to the device are connected correctly. For example, the optical transmit connector on the board should be connected to the optical receive connector on the device. Some connectors require a firm push to ensure proper seating. An easy way to check is to switch the connectors on either the QLA2xxx or the device, then reboot your system.
- ☐ Is the QLA2xxx board installed correctly in the PC slot? Is it seated firmly in the slot? Check for interference due to nonstandard PCI connectors.
- ☐ Are all external peripherals properly powered up? See appendix A.3 for information about displaying attached devices.

### 3.3

#### **System Configuration Problem Checklist**

Check the motherboard for proper configuration (see section 2.4).

See the documentation supplied with your computer, or contact your computer dealer to determine if your motherboard requires configuration.

### 3.4

#### **Fibre Channel Problem Checklist**

- ☐ Were all of the FC devices powered up before you powered up the PC?
- ☐ Check that all cables are properly connected.

# Appendix A

## *Fast!*UTIL

### A.1

#### Introduction

This appendix provides detailed configuration information for advanced users who want to customize the configuration of the QLA2xxx board and the connected devices.

The board can be configured using *Fast!*UTIL. Access *Fast!*UTIL by pressing <ALT>-<Q> during the QLA2xxx board BIOS initialization (it may take a few seconds for the *Fast!*UTIL menu to appear). If you have more than one QLA2xxx board, *Fast!*UTIL asks you to select the board you want to configure. After changing the settings, *Fast!*UTIL reboots your system to load the new parameters.

**CAUTION!** If the configuration settings are incorrect, your QLA2xxx board may not function properly.

The following sections describe the *Fast!*UTIL options.

### A.2

#### Configuration Settings

The first selection on the *Fast!*UTIL *Options* menu is *Configuration Settings*. These settings configure the FC devices and the QLA2xxx board to which they are attached.

#### A.2.1

##### Host Adapter Settings

From the *Configuration Settings* menu in *Fast!*UTIL, select Host Adapter Settings. The default settings for the QLA2xxx host adapter board are listed in table A-1 and described in the following paragraphs.

**Table A-1. Host Adapter Settings**

Setting	Options	Default
Host Adapter BIOS	<i>Enabled or Disabled</i>	<i>Disabled</i>
Frame Size	<i>512, 1024, 2048</i>	<i>1024</i>
Loop Reset Delay	<i>0-15 seconds</i>	<i>5 seconds</i>

**Table A-1. Host Adapter Settings (Continued)**

Setting	Options	Default
Adapter Hard Loop ID	<i>Enabled or Disabled</i>	<i>Disabled</i>
Hard Loop ID	<i>0-125</i>	<i>0</i>

- ☐ **Host Adapter BIOS.** When this setting is disabled, the ROM BIOS on the QLA2xxx board is disabled, freeing space in upper memory. This setting must be enabled if you are booting from an FC disk drive attached to the QLA2xxx board. The default is *Disabled*.
- ☐ **Frame Size.** This setting specifies the maximum frame length supported by the QLA2xxx board. The default size is *1024*. If using F-Port (point-to-point) connections, change this setting to *2048* for maximum performance.
- ☐ **Loop Reset Delay.** After resetting the loop, the firmware refrains from initiating any loop activity for the number of seconds specified in this setting. The default is *5 seconds*.
- ☐ **Adapter Hard Loop ID.** This setting forces the adapter to attempt to use the ID specified in the Hard Loop ID setting. The default is *Disabled*.
- ☐ **Hard Loop ID.** If the Adapter Hard Loop ID setting is enabled, the adapter attempts to use the ID specified in this setting. The default ID is *0*.

**A.2.2**  
**Selectable Boot Settings**

The *Selectable Boot Settings* option is accessed from the *Configuration Settings* menu. If you enable this option, you can select the node name from which you want to boot. Once enabled, this option forces the system to boot on the selected FC drive, ignoring any IDE drives attached to your system. If you disable this option, the system looks for a boot device (as selected in the system BIOS). In disabled mode, the Boot ID and Boot LUN parameters have no effect.

**NOTE:** This option applies only to disk devices; it does not apply to tape drives and other nondisk devices.

**A.2.3**  
**Restore Default Settings**

The *Restore Defaults* option from the *Configuration Settings* menu restores the QLA2xxx board default settings.

#### A.2.4

### Raw NVRAM Data

This option displays the adapter's NVRAM contents in hexadecimal format. This is a QLogic troubleshooting tool; you cannot modify the data.

#### A.2.5

### Advanced Adapter Settings

From the *Configuration Settings* menu in *Fast!UTIL*, select Advanced Adapter Settings. The default settings for the QLA2xxx host adapter board are listed in table A-2 and described in the following paragraphs.

**Table A-2. Advanced Adapter Settings**

Setting	Options	Default
Execution Throttle	<i>1-256</i>	<i>16</i>
Fast Command Posting	<i>Enabled or Disabled</i>	<i>Enabled</i>
>4GByte Addressing	<i>Enabled or Disabled</i>	<i>Disabled</i>
Luns per Target	<i>0, 8, 16, 32, 64, 128, 256</i>	<i>8</i>
Enable LIP Reset	<i>Yes or No</i>	<i>No</i>
Enable LIP Full Login	<i>Yes or No</i>	<i>Yes</i>
Enable Target Reset	<i>Yes or No</i>	<i>No</i>
Login Retry Count	<i>0-255</i>	<i>8</i>
Port Down Retry Count	<i>0-255</i>	<i>8</i>
Drivers Load RISC Code	<i>Enabled or Disabled</i>	<i>Enabled</i>
Enable Database Updates	<i>Yes or No</i>	<i>No</i>
Disable Database Load	<i>Yes or No</i>	<i>No</i>
IOCB Allocation	<i>1-512 buffers</i>	<i>256 buffers</i>
Extended Error Logging	<i>Enabled or Disabled</i>	<i>Disabled</i>

- ☐ **Execution Throttle.** This setting specifies the maximum number of commands executing on any one port. When a port's execution throttle is reached, no new commands are executed until the current command finishes executing. The valid options for this setting are *1-256*. The default (optimum) is *16*.
- ☐ **Fast Command Posting.** This setting decreases command execution time by minimizing the number of interrupts. The default is *Enabled*.

- ❑ **>4GByte Addressing.** This option should be enabled if the system has more than 4 Gbytes of memory available. The default is *Disabled*.
- ❑ **LUNs per Target.** This setting specifies the number of LUNs per target. Multiple LUN support is typically for redundant array of independent disks (RAID) boxes that use LUNs to map drives. The default is 8. If you do not need multiple LUN support, set the number of LUNs to 0.
- ❑ **Enable LIP Reset.** This setting determines the type of loop initialization process (LIP) reset that is used when the operating system initiates a bus reset routine. When this setting is yes, the driver initiates a global LIP reset to clear the target device reservations. When this setting is no, the driver initiates a global LIP reset with full login. The default is *No*.
- ❑ **Enable LIP Full Login.** This setting instructs the ISP chip to re-login to all ports after any LIP. The default is *Yes*.
- ❑ **Enable Target Reset.** This setting enables the drivers to issue a Target Reset command to all devices on the loop when a SCSI Bus Reset command is issued. The default is *No*.
- ❑ **Login Retry Count.** This setting specifies the number of times the software tries to log in to a device. The default is 8 retries.
- ❑ **Port Down Retry Count.** This setting specifies the number of times the software retries a command to a port returning port down status. The default is 8 retries.
- ❑ **Drivers Load RISC Code.** When this setting is enabled, the host adapter uses the RISC firmware that is embedded in the software driver. When this setting is disabled, the software driver loads the RISC firmware that is stored in the QLA2xxx BIOS. The default is *Enabled*.

**NOTE:** The driver being loaded must support this setting. If the driver does not support this setting, the result is the same as disabled regardless of the setting. Leaving this option enabled guarantees a certified combination of software driver and RISC firmware.

- ❑ **Enable Database Updates.** When enabled, this setting allows the software to save the loop configuration information in flash memory when the system powers down. The default is *No*.
- ❑ **Disable Database Load.** When enabled, the device database is read from the Registry during driver initialization. When disabled, the device database is created dynamically during driver initialization. The default is *No*.

**NOTE:** This option usually applies to Windows NT operating environment.

- ❑ **IOCB Allocation.** This setting specifies the maximum number of buffers from the firmware’s buffer pool that are allocated to any one port. The default is *256 buffers*.
- ❑ **Extended Error Logging.** This setting provides additional error and debug information to the operating system. When enabled, events are logged into the Windows NT Event Viewer. The default is *Disabled*.

### A.2.6

## Extended Firmware Settings

From the *Configuration Settings* menu in *Fast!UTIL*, select Extended Firmware Settings. The default settings for the QLA2xxx host adapter board are listed in table A-3 and described in the following paragraphs.

**Table A-3. Extended Firmware Settings**

Setting	Options	Default
Extended Control Block	<i>Enabled or Disabled</i>	<i>Enabled</i>
RIO Operation Mode	<i>0, 1, 2, 3, 4</i>	<i>0</i>
Connection Options	<i>0, 1, 2, 3</i>	<i>3</i>
NonParticipating Hard ID	<i>Enabled or Disabled</i>	<i>Disabled</i>
Class 2 Service	<i>Enabled or Disabled</i>	<i>Disabled</i>
ACK0	<i>Enabled or Disabled</i>	<i>Disabled</i>
Fibre Channel Tape Support	<i>Enabled or Disabled</i>	<i>Disabled</i>
Fibre Channel Confirm	<i>Enabled or Disabled</i>	<i>Disabled</i>
Command Reference Number	<i>Enabled or Disabled</i>	<i>Disabled</i>
Read Transfer Ready	<i>Enabled or Disabled</i>	<i>Disabled</i>
Response Timer	<i>0-255</i>	<i>0</i>
Interrupt Delay Timer	<i>0-255</i>	<i>0</i>

- ☐ **Extended Control Block.** This setting enables all other extended firmware settings. The default is *Enabled*.
- ☐ **RIO Operation Mode.** This setting specifies the reduced interrupt operation (RIO) modes, if supported by the software driver. RIO modes allow posting multiple command completions in a single interrupt (see table A-4). The default is 0.

Table A-4. RIO Operation Modes

Option	Operation Mode
0	No multiple responses
1	Multiple responses, 16 bit handles, interrupt host
2	Multiple responses, 32 bit handles, interrupt host
3	Multiple responses, 16 bit handles, delay host interrupt
4	Multiple responses, 32 bit handles, delay host interrupt

- ☐ **Connection Options.** This setting defines the type of connection (loop or point to point) or connection preference (see table A-5). The default is 3.

Table A-5. Connection Options

Option	Type of Connection
0	Loop only
1	Point to point only
2	Loop preferred, otherwise point to point
3	Point to point, otherwise loop

- ☐ **NonParticipating Hard ID.** This setting is reserved. The default is *Disabled*.
- ☐ **Class 2 Service.** This setting enables Class 2 service parameters to be provided during all automatic logins (loop ports). The default is *Disabled*.
- ☐ **ACK0.** This setting determines the type of acknowledge (ACK) used. When this setting is enabled, sequence ACK is used. When this setting is disabled, frame ACK is used. The default is *Disabled*.

**NOTE:** The Class 2 Service setting must be enabled to use the ACK0 setting.

- ☐ **Fibre Channel Tape Support.** This setting is reserved for Fibre Channel tape support, which will be implemented in a future version of the QLA2xxx. The default is *Disabled*.
- ☐ **Fibre Channel Confirm.** This setting is reserved for Fibre Channel tape support, which will be implemented in a future version of the QLA2xxx. The default is *Disabled*.
- ☐ **Command Reference Number.** This setting is reserved for Fibre Channel tape support, which will be implemented in a future version of the QLA2xxx. The default is *Disabled*.
- ☐ **Read Transfer Ready.** This setting is reserved. The default is *Disabled*.
- ☐ **Response Timer.** This setting contains the value (in 100-microsecond increments) used by a timer to limit the time waiting accumulating multiple responses. For example, if this field is 8, the time limit is 800 microseconds. The default is *0*.
- ☐ **Interrupt Delay Timer.** This setting contains the value (in 100-microsecond increments) used by a timer to set the wait time between accessing (DMA) a set of handles and generating an interrupt. The default is *0*.

### A.3

## Scan Fibre Channel Devices

This option scans the FC loop and lists all the connected devices by loop ID. Information about each device is listed, for example, vendor name, product name, and revision. This information is useful when configuring your QLA2xxx board and attached devices.

### A.4

## Fibre Disk Utility

This option scans the FC loop bus and lists all the connected devices by loop ID. You can select a disk device and perform a low-level format or verify the disk media.

**CAUTION!** Performing a low-level format destroys all data on the disk.

### A.5

## Select Host Adapter

Use this setting to select a specific QLA2xxx board if you have multiple QLA2xxx boards in your system.



# Appendix B

## Specifications

**Table B-1. QLA2xxx Board Operating Environment**

Environment	Minimum	Maximum
Operating temperature	0°C/32°F	55°C/131°F
Storage temperature	-20°C/-4°F	70°C/158°F
Relative humidity (noncondensing)	10%	90%
Storage humidity (noncondensing)	5%	95%

**Table B-2. QLA2xxx Board Specifications**

Type	Specification
Host bus	Conforms to <i>PCI Local Bus Specification</i> , revision 2.2
PCI signaling environment	3.3 V and 5.0 V busses supported
PCI transfer rate	132 Mbytes/sec maximum burst rate for 32-bit PCI operation at 33 MHz 264 Mbytes/sec maximum burst rate for 32-bit PCI operation at 66 MHz 264 Mbytes/sec maximum burst rate for 64-bit PCI operation at 33 MHz 528 Mbytes/sec maximum burst rate for 64-bit PCI operation at 66 MHz
Fibre Channel specifications	Bus type: copper media, twisted pair (QLA2200) fibre optic media (QLA2200F/2202F) copper media (QLA2202F, internal channel 1) Bus transfer rate: 100 Mbytes/sec maximum at half duplex 200 Mbytes/sec maximum at full duplex Interface chip: ISP2200 or ISP2200A
Central processing unit (CPU)	Single-chip design that includes a RISC processor, Fibre Channel protocol manager, PCI DMA controller, and 1-gigabit transceivers
Host data transfer	64-bit, 33-MHz bus master DMA data transfers to 264 Mbytes/sec 64-bit, 66-MHz bus master DMA data transfers to 528 Mbytes/sec
RAM	128K bytes of SRAM
BIOS ROM	128K bytes of flash ROM in two 64K-byte, software selectable banks. The flash is field programmable.
NVRAM	256 bytes, field programmable

**Table B-2. QLA2xxx Board Specifications (Continued)**

Type	Specification
Onboard DMA	Three independent DMA channels: two data and one command. Integrated 4K-byte frame buffer FIFO for each data channel
Connectors (external)	QLA2200: HSSDC connector that supports copper cabling. Fibre optic support available using an external MIA. QLA2200F/2202F: SC-style connector that supports non-OFC, multimode fibre optic cabling using 1 x 9 fibre optic transceiver module. QLA2202F: Two three-position point-to-point copper (internal).
Form factor	17.78cm x 10.67 cm (7.0" x 4.2")
Operating power	Less than 15 watts