



Digital FM Transmitter



97651

Instructions

1. Connect the 3.5mm audio input plug from the FM Transmitter to your portable DVD, CD, MP3 player or other portable device using the head phone jack.
2. Plug the 12V DC plug into the cigarette lighter socket in your vehicle.
3. The unit will come on and the backlight will light up.
4. Turn on your FM radio. Select a station that is not being used in your area.
5. Press the + or - on the FM Transmitter to adjust the FM frequency to the station previously selected on the radio. There is about a second delay before the signal is locked in.
6. Turn on your music or video player and set the volume to the middle of the volume dial.
7. Increase the volume on your radio until your music or video is at the desired level.



To Save Stations into Memory

1. Tune the FM Transmitter to the desired station.
2. Press and hold the M button for 2 seconds.
3. M1 will flash. M1 is now selected.
4. To choose between M1, M2, M3 and M4 press the + or - button.
5. When you select the correct memory preset, press M again to save the station.



How to Improve the Transmitted Sound

1. Make sure the FM station you select is the quietest one on the FM dial in your area. For example, manually tune through all stations on your FM dial and note the ones that pick up the least amount of FM radio stations. It is best to record 3 or 4 stations and program all of them into your FM transmitter.
2. Make sure the input to your FM Transmitter is not being overloaded. This can cause dipping and distortion through your FM stereo. If you suspect this simply turn down your CD/DVD, MP3 player or computer.

To Rotate Memory Presets

1. Press the **M** button once to show the next memory preset.
2. Press the **M** button again to select the next memory preset.
3. Pressing the **M** button again and again will rotate thru all memory presets.



One Year Limited Warranty

Jasco Products Company warrants this product to be free from manufacturing defects for a period of one year from the original date of consumer purchase. This warranty is limited to the repair or replacement of this product only and does not extend to consequential or incidental damage to other products that may be used with this unit. THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES EXPRESS OR IMPLIED. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS OR PERMIT THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU. This warranty gives you specific rights, and you may also have other rights which vary from state to state. If unit should prove defective within the warranty period, return prepaid with dated proof of purchase to: Jasco Products Company, 10 E. Memorial Rd., Oklahoma City, OK 73114.

FCC Regulations

Notice: Federal Communications Commission (FCC) requirements, Part 15

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Any changes of modifications not expressly approved by the grantee of this device could void the users authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Instrucciones

1. Conecte la entrada de audio de 3.5mm del Transmisor FM a la salida para audífonos de su reproductor portátil de DVD/CD, MP3 o de cualquier otro reproductor portátil.
2. Conecte el conector de CC de 12V al enchufe del encendedor de cigarrillos de su auto.
3. La unidad se encenderá y la luz posterior se iluminará.
4. Encienda su radio FM. Escoja una estación disponible en su área.
5. Presione + ó - para seleccionar la frecuencia FM de modo que coincida con la estación que ha seleccionado en la radio. Hay acerca de una segunda demora antes la señal es encerrada.
6. Encienda su reproductor de música o video y ajuste el volumen a la mitad.
7. Suba el volumen de su radio hasta que alcance el volumen deseado.



Para Guardar Las Estaciones En La Memoria

1. Sintonice el Transmisor FM en la estación que desea.
2. Presione y mantenga el botón M por 2 segundos.
3. El botón M1 empezará a parpadear. M1 ya estará configurado.
4. Para escoger entre M1, M2, M3 y M4, presione el botón + ó -.
5. Cuando sintonice la memoria predefinida que desee, presione M nuevamente para guardar la estación.



Modos De Mejorar La Señal Del Sonido

1. Asegúrese de que la estación FM que haya escogido, sea la más limpia de las radios en su área. Por ejemplo, sintonice manualmente todas las estaciones de radio y apunte las sintonías que captan la menor cantidad de ruido. Lo mejor es grabar 3 ó 4 estaciones y programarlas todas en el transmisor FM.
2. Asegúrese que la entrada al Transmisor FM de GE no se sobrecargue. Esto puede ocasionar una oscilación y distorsión en su radio FM estéreo. Si piensa que esto está ocurriendo, apague su computadora o su reproductor de CD/DVD o MP3.

Para Seleccionar los Pre-posicionamientos de Memoria

1. Presione el botón M una sola vez para mostrar el siguiente pre-posicionamiento de memoria.
2. Presione el botón M nuevamente para seleccionar el siguiente pre-posicionamiento de memoria.
3. Presionando el botón M subsecuentemente hará pasar por todos los pre-posicionamientos de memoria.



Garantía Limitada De Un Año

Jasco Products Company garantiza este producto por un periodo de un año desde la fecha de la compra original, como libre de defectos de fabricación. Esta garantía está limitada a la reparación o reemplazo de este producto y no se extiende a daños consecuentes o incidentales en otros productos que puedan ser usados con esta unidad. Esta garantía es en vez de cualquier otra expresa o implícita. Algunos estados no permite limitaciones al tiempo de limitada o permite el exclusión o limitaciones del daños incidental o consiguiente, así el limitación del arriba no aplicarse. Esta limitada darse justicia, y talvez tiene otro justicias que cambia del estado a estado. Si la unidad resulta defectuosa durante el periodo de garantía, devolverla prepagada a: Jasco Products Company, 10 E. Memorial Rd., Oklahoma City, OK. 73114.

Declaración de FCC

Viso: Las comunicaciones federales Comisión (FCC) los requisitos, parte 15

Este equipo se ha provado y se ha encontrado para conformarse con los límites para un dispositivo digital de la clase B, conforme a la parte 15 de la FCC que los límites de Rules. Estos se diseñan para proporcionar a la protección razonable contra interferencia dañosa en un equipo residencial de installation. This generan, de aplicaciones y puede irradiar energía de la radio frecuencia y, si no instalado y utilizado de acuerdo con las instrucciones, puede causar interferencia dañosa a las comuncaciones por radio. Sin embargo, no hay garantía que interferencia no ocurrirá en una instalación determinada. Si este equipo causa interferencia dañosa a laradio o la recepción de televisión, que puede ser determinada girando el equipo apagado y, se anima al utilizador que intente corregir la interferencia por una o más de las medidas siguientes:

- Reoriente o vuelva a poner la antena de recepción.
- Aumente la separación entre el equipo y el receptor
- Conecta el equipo en un enchufe en un circuito diferente de el con las cuales el receptor esté conectado
- Consulta al distribuidor o a técnico experimentado de radio/TV para la ayuda

PRECAUCIÓN: Cualquier cambio de las modificaciones no no expreso aprobadas por el grantee de este dispositivo podía anular la autoridad de los utilizadores para funcionar el equipo. Este dispositivo se conforma con la parte 15 de las reglas de la FCC. La operación está conforme a las dos condiciones siguientes: (1) este dispositivo puede no causar interferencia dañosa, y (2) este dispositivo debe validar cualquier interferencia recibida, incluyendo interferencia que pueda causar la operación indiseada.



is a registered trademark of General Electric Company and is used under license to Jasco Products Company, LCC

All brand names and products listed/shown are registered trademarks of their respective owners.

© JASCO 2007