
ide line®

ART.NR. 750-024



UK	Double cooking plates	2
DK	Dobbelt kogeplade	5

INTRODUCTION

Please read this instruction manual carefully and familiarise yourself with your new cooking plate, before using the first time. Please retain this manual for future reference.

IMPORTANT SAVEGUARDS

When using your cooking plate, basic safety precautions should always be followed:

- Read all instructions.
- Use only cooking plate for its intended use.
- To protect against a risk of electric shock, do not immerse the cooking plate in water or any other liquids.
- Never yank cord to disconnect from outlet; instead, grasp plug and pull to disconnect.
- Do not allow cord to touch hot surface. Let appliance cool completely before cleaning.
- Do not operate cooking plate with a damaged cord or if the cooking plate has been dropped or damaged.
- To avoid the risk of electric shock, do not disassemble the cooking plate, take it to a qualified serviceman for examination and repair. Incorrect reassembly can cause a risk of electric shock when the cooking plate is used.
- Close supervision is necessary for any appliance being used by or near children. Do not leave appliance unattended while connected.
- To avoid a circuit overload, do not operate another high voltage appliance on the same circuit.
- If an extension cord is absolutely necessary, a 10-ampere cord should be used. Cords rated for less amperage may overheat. Care should be taken to arrange the cord so that it cannot be pulled or tripped over.
- All repair work should be carried out by an approved service center.
- Remember that the cooking plate becomes extremely hot and it takes a while before the cooking plate is completely cooled off.

BEFORE USE

- Make sure that the cooking plate is completely dry before use.
- The cooking plate should not be placed on a untreated wood surface. Place the cooking plate on a heat resistant surface.
- Before using for the first time, the protective coating must be burned off the hotplates. Ensure the room is well ventilated while doing this, as it may give off an unpleasant smell. This is normal and will disappear after a couple of minutes.

OVERVIEW

1. Large cooking plate
2. Indicator light
3. Heat level selector
4. Small cooking plate
5. Indicator light
6. Heat level selector



FUNCTION

The cooking plates are controlled by a thermostat. This means that the power will be switched on and off from time to time. Consequently, the thermostat lamps will also be switched on and off from time to time.

Pls. note that when the cooking plates are switched on for the beginning of a cooking process the thermostat will switch on and off during this heat up process until final max. set temperature is reached.

In case the unit is used in e.g. a cottage or summerhouse where the ambient temperature is low during the winter season the thermostat can switch on the unit by itself. So, since there is no on/off switch on the unit **ALWAYS UNPLUG THE UNIT AFTER EACH USE.**

USE

- Plug in the appliance and turn the socket on.
- Choose the desired heat setting.
- The indicator light will go on and off when the thermostat switch on and off.
- Always use flat-bottomed saucepans which make good contact with the hot plate.

POWER RANGE

Large cooking plate: 1500 W

Small cooking plate: 1000 W

AFTER USE

- Turn off the cooking plate, unplug the appliance from the outlet and let it cool off.

MAINTENANCE AND CLEANING

- Unplug the appliance before cleaning starts.
- Do not immerse the appliance in water. All surfaces can be cleaned with a clean damp cloth.
- If stains still appear, it is recommended to use soap.
- Do not use abrasive cleaners or sharp utensils to clean the cooking plate.
- Always make sure that the cooking plate is wiped off and completely dry before using.

ENVIRONMENTAL TIP

An electronic appliance should, when it is no longer capable of functioning be disposed with least possible environmental damage. The appliance should be disposed according to the local regulations in your municipality, in most cases you can discharge the appliance at your local recycling center.

THE WARRENTY DOES NOT COVER

- If the above points have not been observed.
- If the appliance has not been properly maintained, if force has been used against it or if it has been damaged in any other way.
- Errors or faults owing to defects in the distribution system.
- If the appliance has been repaired or modified or changed in any way or by any person not properly authorized.

Owing to our constant development of our products on both functionality and design we reserve the right to change the product without preceding notice.

IMPORTER

Adexi Group

We take reservation for printing errors.

INTRODUKTION

For at De kan få mest glæde af Deres kogeplade, beder vi Dem venligst gennemlæse denne brugsanvisning, før de tager kogepladen i brug. Vi anbefaler Dem yderligere at gemme brugsanvisningen, hvis De på et senere tidspunkt skulle få brug for at opfriske kogepladens funktioner.

VIGTIGE SIKKERHEDSFORANSTALTNINGER

- Læs hele brugsanvisningen.
- Brug kun apparatet til det fremstillede formål.
- Apparatet må aldrig nedsænkes i nogen former for væske.
- Ryk aldrig i ledningen, men tag istedet fat i stikket og træk det forsigtigt ud.
- Ledningen bør holdes væk fra varme overflader.
- Hvis ledningen på dette apparat bliver beskadiget, må den kun udskiftes på et af fabrikanten angivet værksted, da anvendelse af special værktøj er påkrævet.
- Hvis selve apparatet skulle blive beskadiget, skal det indleveres til en fagmand for reparation. Hvis der foretages uautoriseret indgreb i apparatet bortfalder garantien.
- Børn der befinder sig i nærheden af apparatet, når dette er i brug, bør holdes under opsyn. Apparatet bør opbevares utilgængeligt for børn.
- Hvis brug af forlængerledning er nødvendig, bør man bruge en 10-ampere ledning. Man skal være forsigtig med placeringen af forlængerledningen, så man ikke snubler over denne.
- Brug ikke apparatet hvis der er tydelige tegn på skader.
- Brug kun apparatet indendøre.
- Kogepladen skal stå stabilt på fødderne på et fladt plan ved anvendelse.
- Ledningen må ikke røre nogen dele af apparatet.
- Husk at kogepladen bliver meget varm, og at det varer et stykke tid, førend den er fuldstændig afkølet.

FØR KOGEPLADEN TAGES I BRUG

- Sørg for at kogepladen er helt tør før brug.
- Bør ikke opstilles på en ubehandlet træoverflade. Placér kogepladen på en varmebestandig overflade.
- For at fjerne beskyttelseshinden og hærde kogepladen skal kogepladen stå på maximum temperatur i ca. 5 minutter. Der kan udvikles en smule røg fra kogepladen, dette er helt normalt og ganske ufarligt og forsvinder efter kort tid.

FUNKTIONSOVERSIGT

1. Stor kogeplade
2. Kontrollampe
3. Temperaturvælger
4. Lille kogeplade
5. Kontrollampe
6. Temperaturvælger



FUNKTIONER

Kogepladerne er termostatstyret, det vil sige at termostaten vil slå strømmen til og fra, kontrollamperne vil som følge deraf også tænde og slukke i takt med termostaten.

Vær også opmærksom på at termostaten vil kunne slå til og fra før eksempelvis vand begynder at koge, dette er helt normalt.

Efter endt brug bør stikket tages ud af stikkontakten, da der ikke er en on/off kontakt på apparatet. Hvis ikke stikket tages ud, vil kogepladerne kunne tænde af sig selv om vinteren hvis temperaturen falder meget f.eks. i sommerhuse eller kolonihavehuse.

BRUG

- Sæt stikket i stikkontakten og tænd for denne.
- Vælg den ønskede varmeindstilling. Den røde indikator lampe lyser.
- Kontrollampen vil tænde og slukke i takt med at termostaten slår til og fra.
- Anvend kun kogegrej (gryder, pander m.v.) med flad/plan bund, der er beregnet til brug på elektriske kogeplader.

EFFEKTFORDELING

Stor kogeplade: 1500 W

Lille kogeplade: 1000 W

EFTER BRUG

- Efter brug anbefales det at man slukker kogepladen, tager stikket ud og lader den afkøle fuldstændigt.

VEDLIGEHOVELDELSE OG RENGØRING

- Tag stikket ud af stikkontakten inden rengøringen påbegyndes.
- Kogepladen må ikke nedsænkes i nogen former for væske. Alle overflader må rengøres med en let fugtig klud.
- Ved genstridige pletter anbefales det at bruge flydende sæbe.
- Brug ikke slibende eller ridsende rengøringsmidler.
- Sørg altid for at kogepladen tørres af og ikke tages i brug før den er fuldstændig tør.

MILJØ TIPS

Et el/elektronik produkt bør, når det ikke længere er funktionsdygtigt, bortskaffes med mindst mulig miljøbelastning. Apparatet skal bortskaffes efter de lokale regler i din kommune, men i de fleste tilfælde kan du komme af med produktet på din lokale genbrugsstation.

GARANTIEN GÆLDER IKKE

- Hvis ovennævnte ikke iagttages.
- Hvis apparatet har været misligholdt, været udsat for vold eller lidt anden form for overlast.
- For fejl som måtte opstå grundet fejl på ledningsnettet.
- Hvis der har været foretaget uautoriseret indgreb i apparatet.

Grundet konstant udvikling af vore produkter på funktions- og designside n forbeholder vi os ret til ændringer af produktet uden forudgående varsel.

IMPORTØR:

Adexi Group

Med forbehold for trykfejl

