



3. LIST OF SPECIFICATIONS

Part nos. of ign- ition distributor	Date of manufac.	See microcard W-001/	Coordinate
u 237 001 001		017	A03
002		017	A04
003		017	A05
004		017	A06
006		017	A07
007		018	A03
002 001		017	A08
004		017	A09
005		017	A10
006		017	A11
007		017	A12
010		017	A13
011		017	A14
012		017	A15
013		017	A16
014		017	A17
015		017	A18
017		017	A19
018		017	A20
020/021		017	A21
022		017	A22
023		017	A23
024		017	A24
026		017	B01
031		017	B02
032		017	B03
033		017	B04
034		017	B05
035		017	B06
036		017	B07

Part nos. of ign- ition distributor	Date of manufac.	See microcard W-001/	Coordinate
0 237 002 037		017	B08
038		017	B09
039		017	B10
041		018	A04
044		017	B12
049		017	B13
050		017	B14
053		017	B15
054/055		017	B16
056		017	B17
057		018	A05
058		017	B18
059/060		017	B19
061		017	B20
062		017	B21
063		017	B22
064		017	B23
065		018	G24
066/067		017	B24
069		017	C01
070		018	A06
071		017	C02
072		017	C03
073		018	H01
075		018	H02
076		018	H03
078		018	H04
080		018	A07
081		018	F19
082		018	F20
083		018	F21
084/085		018	A08
086		018	F22
087		018	F23

Part nos. of ignition distributor	Date of manufac.	See microcard W-001/	Coordinate
0 237 002 088		018	F24
089	->342	018	H05
089	343-441	018	H06
089	442->	018	H07
092		017	K20
093		017	K21
094/095		018	H08
096		017	K22
097		017	K23
098/099		017	K24
100		017	L01
101		017	L02
102		017	L03
103/104		017	L04
105/106		017	L05
107/108		018	L14
109		019	A27
110		018	L15
111		018	L16
113		018	L17
114		018	L18
115		018	L19
116		019	A28
117		018	L20
118/119		018	L21
121		019	B01
122		018	L22
123		019	B02
124/125		019	B03
126		019	B04

Part nos. of ignition distributor	Date of manufac.	See microcard W-001/	Coordinate
0 237 002 128		019	B05
129		019	B06
130		019	B07
133		019	B08
134/135		019	E08
0 237 003 001		017	C04
001	628->	018	A09
003		017	C05
008	->729	018	A10
008	730->	017	C06
009		017	C07
013		017	C08
014		017	C09
018/019		017	C10
022/023		017	C11
024		017	C12
025/026		017	C13
027		017	C14
028		017	C15
029		017	C16
034		017	C17
035		018	A11
036		018	H09
039		017	L09
040		018	L23
041		018	L24
042		018	M01
043		018	M02
004 001/002		017	C18
005/006		017	C19
005 001		017	C20
002		017	C21
003		017	C22
004		017	C23
005		017	C24

Part nos. of ign- ition distributor	Date of manufac.	See microcard W-001/	Coordinate
0 237 005 008		018	A12
009		018	A13
010		017	L07
011		018	H10
012		017	L08
006 001/002		017	D01
003/004		017	D02
005/006	822->	017	D03
006 005/006	->822	018	H11
009/010		017	D04
007 001	->727	018	A14
001/003	728->	017	D05
002/004		017	D06
005/006		017	D07
007/008		017	D08
008 001/002	->821	018	H12
001/002	822->	017	D09
009 001		018	A15
002		018	A16
003		017	D10
004		017	D11
006		018	A17
007		017	D12
008		017	D13
009		018	H13
010		018	H14
011		018	H15
012		018	H16
013	->246	018	A18
013	247->	018	A19

Part nos. of ign- ition distributor	Date of manufac.	See microcard W-001/	Coordinate
0 237 009 015		018	G01
016		018	G02
017		018	G03
018		018	G04
019		018	G05
020		018	G06
022		018	G07
023		018	G08
024		018	H17
025		018	G09
026		017	L09
028		017	L10
031		018	M03
032		019	B09
033		018	H18
034		018	H19
035		019	B10
036		017	L11
037		018	M04
039		018	M05
040		018	M06
041		018	M07
042		018	M08
043		018	M09
044		018	M10
045		018	M11
046		018	M12
047		017	L12
049		019	B11
050		019	B12
051		019	B13

Part nos. of ignition distributor	Date of manufac.	See microcard W-001/	Coordinate
0 237 009 052		019	B14
054		019	B15
055		019	B16
056		019	B17
057		019	B18
059		019	B19
061		019	B20
062		019	B21
063		019	B22
064		019	B23
065		019	B24
066		019	B25
067		019	B26
068		019	B27
069		019	B28
070		019	C01
071		019	C02
072		019	C03
073		019	E09
086		019	E10
087		019	E11
089		019	E12
601		019	C04
601		019	C05
602		019	C06
603		019	C07
604		019	C08
605		019	C09
607		019	C10
609		019	C11
610		019	C12
611		019	C13
612		019	C14
613		019	C15

Part nos. of ignition distributor	Date of manufac.	See microcard W-001/	Coordinate
614		019	C16
615		019	C17
616		019	C18
618		019	C19
620		019	E13
621		019	F14
622		019	E15
623		019	E16
624		019	E17
625		019	E18
953		019	C20
010 001/002		017	D14
003		017	D15
005/006		019	C21
011 001		017	D16
002		017	D17
003		017	D18
004		017	D19
005		017	D20
006		018	A20
012 001/002		017	D21
013 001		017	D22
014 002		019	C22
016 001/002		017	D23
005/006		018	A21
020 001		017	D24
002		017	E01
003		017	E02
004		017	E03
005		017	E04
006		017	E05
007		017	E06
008		017	E07
010		017	E08
011		017	E09
017		017	E10

Part nos. of ignition distributor	Date of manufac.	See microcard W-001/	Coordinate
0 237 020 020		017	E11
021		017	E12
025		017	E13
028		017	E14
029		017	A22
030		017	E15
031		017	E16
033		017	E17
034		017	E18
035		017	E19
037/038		017	E20
039		017	E21
040		017	E22
041		017	E23
042		017	E24
043		017	F01
044		017	F02
045/066		017	F03
047		017	F04
048		017	F05
049		017	F06
050		018	A23
051/052		017	F07
C54		018	H20
055		018	A24
056		018	B01
058		018	B02
059		018	B03
061		018	B04
062/063	->242	018	B05
062/063	243->	018	B06
064		018	B07
065		018	B08
066		018	H21
067/068		018	B09

Part nos. of ignition distributor	Date of manufac.	See microcard W-001/	Coordinate
0 237 020 069/070		018	B10
071/072		018	B11
073/074		018	B12
075		018	H22
076		018	H23
079		017	L13
081/082		018	H24
083/084		018	J01
085/086	243->	018	J02
087/088		018	J03
089/090		018	J04
091/092		018	J05
093/094		018	J06
095/096		018	J07
097/098		018	J08
099/100		018	J09
101		018	J10
103/104		018	J11
105/106		018	J12
107/108		017	L14
109/110		018	J13
115/116		017	L15
117/118	243->	018	M14
119/120		017	L17
131/132		018	M15
133/134		018	M16
135/136		018	M17
137/138		019	C23
140/141		019	C24
150		019	E19
152		019	E20
158		019	E21
162/163		019	C25

Part nos. of ign- ition distributor	Date of manufac.	See microcard W-001/	Coordinate
0 237 020 166		019	C26
167		019	C27
168		019	C28
169/170		019	D01
171/172		019	D02
173		019	D03
174		019	D04
175/176		019	D05
177/178		019	D06
179		019	D07
180/181		019	D08
188		019	E22
196		019	E23
204/205		019	E24
206/207		019	E25
021 003/004		017	F08
005		017	F09
005/006	149->	017	F10
009		017	F11
010		017	F12
011		018	B13
012		017	F13
013		017	F14
014		017	F15
015		017	F16
016		018	J14
019		018	G10
021		017	L18
022		017	L19
023		017	L20
024		018	J15
025		017	L21
026		017	L22
027		017	L23

Part nos. of ign- ition distributor	Date of manufac.	See microcard W-001/	Coordinate
0 237 021 028/029		017	L24
031		018	M18
034/035		018	M19
040		018	M20
041/042		018	M21
043/044		018	M22
045		019	E26
046		019	E27
047/048		019	D09
051		019	E28
053		019	F01
064/065		019	F02
022 007/008		017	F17
009/010		017	F18
013/014		017	F19
015/016		017	F20
017/018		017	F21
019/020		017	F22
021/022		017	F23
023/024		017	F24
025/026		018	B14
027		018	B15
028/029	->245	018	B16
028/029	246->	018	B17
030		018	G11
031		018	J16
035/036		018	J17
037/038		018	J18
039/040	246->	018	J19
043/044		018	J20
045/046		017	M01
047/048		017	M02
049/050	246->	017	M03
051/052		017	M04
053/054		019	F03

Part nos. of ign- ition distributor	Date of manufac.	See microcard W-001/	Coordinate
0 237 022 060/061		019	D10
068/069		019	F04
023 001/002		017	G01
005/006		017	G02
007/008		018	B18
009/010		017	G03
011/012		017	G04
013/014	->246	018	B19
013/014	247->	018	B20
017/018		018	G12
019/020	247->	017	M06
023		018	M23
024 003/004	->245	018	B21
003/004	246->	018	B22
005/006		018	B23
007/008	246->	018	J21
009/010		018	J22
011/012		017	M07
013		017	M08
014		017	M09
015		017	M10
016/017	246->	017	M11
018/019		017	M12
022/023	243->	018	M24
024/025		017	M14
027/028		018	N01
029/030		018	N02
031/032		018	N03
033/034		018	N04
035/036		018	N05
025 001/002		017	G05

Part nos. of ign- ition distributor	Date of manufac.	See microcard W-001/	Coordinate
0 237 025 003/004		017	G06
009/010		017	G07
011/012		017	G08
013/014		017	G09
015/016		017	G10
017/018		017	G11
021/022		017	G12
025/026		018	B24
027/028		018	C01
031/032		017	M15
033/034		017	M16
026 001/002		017	G13
004		018	C02
005		018	C03
006		018	C04
007		018	C05
012		018	N06
027 001/002		017	G14
003/004		017	G15
005/006		017	G16
007/008		017	G17
009/010		017	G18
011/012		017	G19
013/014		017	G20
015/016		017	G21
017/018		018	C06
019/020		018	C07
021/022		018	C07
023/024		018	J23
029 001		018	C08



Part nos. of ign- ition distributor	Date of manufac.	See microcard W-001/	Coordinate
0 237 030		017	G22
		018	C09
		018	G13
		017	M17
		017	M18
		018	N07
		019	D11
	545->	019	D12
		019	D13
		019	D14
		019	D15
031		018	C10
		018	C11
		018	C12
		018	C13
		018	J24
		018	K01
		017	M19
		017	M20
		017	M21
	->544	019	D16
		018	N08
		019	D17
	545->	019	D18
		019	D19
034		018	C14
		018	C15
		018	K02
		018	K03
		017	M22

Part nos. of ign- ition distributor	Date of manufac.	See microcard W-001/	Coordinate
0 237 034		017	M23
		018	G14
		018	N09
		018	N10
		018	N11
		018	N12
		018	N13
		019	D20
		019	D21
		018	C16
		018	C17
		018	C18
		017	G23
		018	C19
		017	G24
		018	K04
		018	K05
		017	M24
		019	F05
		019	F06
		017	H01
		018	C20
		017	H02
		018	K06
		017	H03
		017	H04
		017	H05
		017	H06
		017	H07
		018	C21
		017	H08
		017	H09

Part nos. of ign- ition distributor	Date of manufac.	See microcard W-001/	Coordinate
0 237 302 013		017	H10
014		017	H11
015/016		017	H12
017/018		017	H13
019		017	H14
021		018	C22
023		017	H15
024		017	H16
026		017	H17
027		017	H18
028		018	K07
029		018	K08
030		018	C23
031		018	C24
032		018	D01
033		018	G15
034		018	D02
035		018	G16
036		018	G17
037		018	G18
038		018	G19
039		018	K09
040		018	K10
041		018	K11
042		018	K12
043		018	K13
044		018	K14
303 001		017	H19
033	725->	018	D03
003	->724	018	K15

Part nos. of ign- ition distributor	Date of manufac.	See microcard W-001/	Coordinate
0 237 304 001	725->	018	D04
002		017	H21
003		017	H22
004		017	H23
005		017	H24
006		017	J01
009		018	D05
010		017	J02
012/013		017	J03
015		017	J04
016		018	D06
017		017	J05
019		017	J06
021/022		018	D07
023		018	K16
024		017	N01
025		017	N02
026		017	N03
027		017	N04
028		017	N05
029		017	N06
030		017	N07
031		017	N08
032		019	D22
033		019	D23
034		019	D24
035		019	D25
036		019	D26
305 001		017	J07
306 001		018	D08

Part nos. of ign- ition distributor	Date of manufac.	See microcard W-001/	Coordinate
0 237 306 002		017	J08
003		017	J09
006/007		017	J10
013		018	D09
014		017	J11
017/018		017	J12
019/020		017	J13
021/022		017	J14
028/029		017	J15
030/031		017	J16
032/033		017	J17
034/035		017	J18
036		017	J19
040		017	J20
041		017	J21
042		018	D20
043		018	D11
044		017	J22
045/046		017	J23
047		017	J24
048	->245	018	D12
048	246->	018	D13
049		018	K17
050		018	K18
051		018	D14
052		018	K19
054		018	D15
055		018	K20
057		018	K21
058		018	K22

Part nos. of ign- ition distributor	Date of manufac.	See microcard W-001/	Coordinate
0 237 306 060		018	K23
061		018	K24
062		018	L01
063		018	L02
320 001	->250	017	K01
001	251->	018	G20
002		017	K02
003		017	K03
004		017	K04
005		017	K05
006		017	K06
009		019	D27
322 001		018	G21
002		019	D28
401 007		017	K07
008/009		017	K08
010/011	->245	018	D16
010/011	246->	018	D17
012/013		018	D18
018		018	D19
019		018	G22
402 001		017	K10
004		017	K11
006		017	K12
007		017	K13
007	624->	017	K14
008		017	K15
009		017	K16
010	725->	018	D20
010	->724	018	L03

Part nos. of ign- ition distributor	Date of manufac.	See microcard W-001/	Coordinate
0 237 402 011		018	D21
012		018	D22
013		018	D23
014		018	D24
015		018	E01
016		017	K17
017		018	E02
019		018	E03
020		018	E04
021		018	E05
022		018	E06
023		018	E07
024		018	E08
025		018	E09
026		017	K18
030		018	L04
031		017	N09
404 002		018	E10
003		018	E11
004		018	E12
006		018	E13
007		018	E14
008		018	E15
013		018	E16
405 001		018	E17
002		018	E18
006		018	E19
008		018	E20
010		018	E21
011		018	E22

Part nos. of ign- ition distributor	Date of manufac.	See microcard W-001/	Coordinate
0 237 405 012/013		018	E23
014/015		018	E24
016/017		018	F01
020		018	F02
021/022		018	F03
023		017	K19
024/025		018	F04
028/029		018	L05
406 001		018	F05
002		018	F06
003		018	F07
004	824->	018	F08
004	->823	018	L06
006		018	F09
007		017	N10
407 001		018	F10
503 001		018	L07
003/004		018	N14
005		019	E01
504 001		018	L08
002		018	L09
004		017	N11
005		018	L10
006		019	E02
007		017	A03
008		017	A04
009		017	A05
505 002		017	N12
507 001		017	L11
002		019	A06

Part nos. of ign- ition distributor	Date of manufac.	See microcard W-001/	Coordinate
0 237 507 004		019	A07
005		017	N14
006		019	A08
007/008		019	A09
010		019	F07
600 003/004		018	F11
006		018	F12
007/008		018	F13
009/010		018	F14
013		018	F15
014		018	F16
015		018	F17
050/051		018	F18
052		018	G23
053		018	L12
054		018	L13
601 001		019	A10
004		019	A11
005		019	A12
008	->549	019	A13
008	550->	019	A14
009		019	A15
010		019	A16
011		019	A17
012		019	A18
013		019	A19
014		019	E03
015		019	E04
017		019	E05
051		019	E06
			A20

Part nos. of ign- ition distributor	Date of manufac.	See microcard W-001/	Coordinate
0 237 601 052		019	A21
053		019	A22
054		019	A23
055		019	A24
056		019	A25
057		019	A26
058		019	E07

TABLE OF CONTENTS

Coordinates

0 237 001 001	->	A 03
002 ..	->	A 03
003 ..	->	A 06
004 ..	->	A 06
005 ..	->	A 06
006 ..	->	A 06
007 ..	->	A 07
008 ..	->	A 07
009 ..	->	A 07
010 ..	->	A 10
011 ..	->	A 10
012 ..	->	A 10
013 ..	->	A 10
016 ..	->	A 10
020 ..	->	A 10
021 ..	->	A 13
022 ..	->	A 14
023 ..	->	A 15
024 ..	->	A 15
025 ..	->	A 15
026 ..	->	A 16
027 ..	->	A 16
029 ..	->	A 16
030 ..	->	A 17
031 ..	->	A 17
034 ..	->	A 17
035 ..	->	A 18
037 ..	->	A 18
038 ..	->	A 18
301 ..	->	A 18
302 ..	->	A 18
303 ..	->	A 19
304 ..	->	A 20
305 ..	->	A 20
306 ..	->	A 20

For production reasons:  
continued on the following  
coordinate.

TABLE OF CONTENTS (CONTINUED)

Coordinates

0 237 320 ..	->	A 22
322 ..	->	A 22
401 ..	->	A 22
402 ..	->	A 22
404 ..	->	A 23
405 ..	->	A 23
406 ..	->	A 24
407 ..	->	A 24
503 ..	->	A 24
504 ..	->	A 24
505 ..	->	A 24
507 ..	->	A 24
600 ..	->	A 25
601 ..	->	A 25

PUBLICATION INFORMATION

(c) 1991 ROBERT BOSCH GmbH Automotive Equipment -  
 After-Sales Service, Department of Technical  
 Publications KH/VDT, Postfach 10 60 50,  
 D-7000 Stuttgart 10.  
 Published by: After-Sales Service Department for Training  
 and Technology (KH/VSK).  
 Press date 03.1991.  
 Please direct questions and comments concerning the  
 contents to our authorized representative in your country.  
 This publication is only for the use of the Bosch After-  
 Sales Service Organization and may not be passed on to  
 third parties.

Microfilmed in the Federal Republic of Germany.  
 Microphotographié en République Fédérale d'Allemagne.