



- at angle and hook on to 135° bottom front edge of griddle perimeter.
- 2. Align center of support bracket with center of griddle perimeter.
- Fasten lower bracket to upper bracket using (2) hex head screws and lockwashers.
- Tighten assembly in place using hex head screw #010776. <u>DO NOT OVERTIGHTEN.</u>

<u>NOTE:</u> CENTER SUPPORT BRACKET MUST BE INSTALLED BEFORE CUTTING BOARD IS INSTALLED.